Bluetooth Earphone

8B138BT



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE

Getting started

- Remove the product from the box.
- Remove any packaging from the product.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Bluetooth Stereo Sports Earbuds
- USB charging cable 2 spare silicon tips included Instruction Manual

Kev Features

- Enjoy music wirelessly via Bluetooth technology
- Stereo Sound
- USB Rechargeable (USB Cable Included)
- Built-in Microphone
- Easy to switch between calls and music, you will not miss the incoming call whilst listening to music
- Answer & end a call at click of a button
- Built-in Volume & Media Control (pause/play)
- Connects to previously connected device automatically

Keep the unit away from heat sources, direct sunlight, humidity, water and any other

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit. Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk. Do not use the unit with wet hands.

Do not put objects into any of the openings.

Keep the unit free from dust, lint etc.

Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children

This product is not a toy.

Do not use the handset at excessive volume levels, as damage to hearing may occur.

Description of Parts:



1	Speaker
2	LED Light Indicator
3	Charging port (side)
4	Volume Increase (+) / Next Track
5	MF (Multi-Function) / Phone button
6	Volume Decrease (-) / Previous Track
7	Bui lt-I n Microphone (rear)

INSTRUCTIONS FOR USE

Charging Instructions

The Bluetooth Earbuds come with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB Cord to charge the Bluetooth Earbuds. Please charge for about 2 hours.

Connect the USB charging cable to a computer USB port and the Micro USB plug to the charging port of the device. The Red LED light turns on while the device is charging. It

takes around 2 hours for the unit to fully charge. When the battery is fully charged, it will

Switching on/off the devicePress and hold the **MF** button for 4-6 seconds to turn ON or OFF the device with sound message 'Power On' or 'Power Off' correspondingly

Pairing the device with Bluetooth devices (phone or music device)
Ensure the device is turned off, then press and hold the MF button for 4-6 seconds to turn
on with sound message "Power On, Bluetooth Mode; and the LED flashes red and blue.
Place the Bluetooth Earbuds and Bluetooth device (phone or music device) so that they

are no further than 3 feet apart;

Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions for instructions on enabling Bluetooth on your

Once you have activated Bluetooth on your device, select the "SL BT EARBUDS" from the

list of available Bluetooth devices.

If required, enter the password '0000' to confirm & finalize pairing.

Once paired successful, beep sound with message 'Connected' will be heard and the LED

You can now start to use the device.
If pairing is unsuccessful, turn off the device first and then re-pair following the above

Once you have paired the Bluetooth Earbuds with a device, the Earbuds will remember

this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The Bluetooth Earbuds will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the

steps outlined above.

Once the Bluetooth Earbuds is paired with your device the music will transmit through the Bluetooth Earbuds. Please refer to your device's user manual for further information.

Once the Earbuds are paired with your device you can stream music wirelessly through the Bluetooth Earbuds. Should you encounter any problems while streaming please refer your device's user manual for further information.

反面印刷

Control Function

Function	Operation	Button
Increase Volume	Playing music	A long press on the + button once will increase the volume
Decrease Volume	Playing music	A long press on the - button once will decrease the volume
Pause	Playing music	A short press on the MF button will pause the music
Play	Pausing	A short press on the MF button will restart the music
		A short press on the - button will return you to the previous track
Next track	Playing music	A short press on the + button will take you to the next track

An indication tone will alert you when the volume is adjusted to the minimum level, and

Making a call with the Bluetooth Earbuds in Bluetooth mode

Function	Operation	Button
Answer a call	Incoming Call	Press the MF button once to answer an incoming call
Reject a call	Incoming Call	Press the MF button for 2 seconds, and you would hear message 'Call reject'.
End a call	Incoming Call	After your phone conversation, short press the MF button and you hear beep sound with message 'Hang up'.
Increase Volume	During a call	Long press on the + button once will increase the volume
Decrease Volume	During a call	Long press on the - button once will decrease the volume
Redial last number Standby mode and connected to a device		Short press the MF button twice

Please Note

Not all mobile phones support all the functions listed above. Please refer to your cell phone's user's manual for further information.

2

Certain functions and indication tone maybe vary depending on your mobile phone.

Please refer to the below tables for a list of the LED statuses whilst using the Bluetooth

Charging Indication

LED indicator	Status of the BT Earbuds
Red LED	Charging
LED Flashes red	Charging Completed

LED Indication

LED indicator	Status of the BT Earbuds
LED flashes red and blue alternately	Pairing mode

Care and Maintenance

Read the following recommendations before using the Bluetooth Earbuds. Following these you will be able to enjoy the product for many years.

- Do not expose the Bluetooth Earbuds to liquid, moisture or humidity to avoid the product's internal circuit being affected.

 Don't use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.

 Don't dispose of the device in a fire as it will result in an explosion.
- Don't expose the device to contact with sharp objects as this will cause scratches and
- Don't let the device fall on the floor. The internal circuit might get damaged. Don't attempt to disassemble the device as it may get damaged if you are not professional.

In case the device doesn't function properly, send it to the store you bought it. The staff will help you to the problem.

Specifications

Bluetooth3.0
33 Feet
Up to 3 hours (max volume)
DC 5V
About 2 hours
2 x 5mW
60mAh

(Note: Battery life & charging time may vary based on usage & types of devices used.)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

I IMITED WARRANTY

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original nsumer purchaser for a period of ninety (90) days from the original purchase da

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to; LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted