

## Voice Communication System















### VCS 3020X Rel. 4.1



#### Short User Manual


04A28 E502.10

© FREQUENTIS 2004

-  Procedure step number. Press the key or take another action.
-  Action leads to a reaction.
-  Introduces an alternative action or reaction.
-  Stands for, equals.
-  Symbol for incoming chime tone (for details on all other tones refer to the User Manual VCS 3020X Rel. 4.1, Doc.No. 04A28 E501).
-  Symbol for special tones (for details refer to the User Manual VCS 3020X Rel. 4.1).
-  Press PTT, release PTT.
-   Key text/names (in this example for a function key or sub-menu key).
-  Key is unavailable for activation.
-  Key is idle and available for activation.
-  Key is transient, i.e. blinking between available and active.
-  Key is active.
-  Messages on a display.

- 1 Are your headset/handset and/or your microphone connected to the plug-in panel?
- 2 Are incoming telephone calls signalled? Check whether **CHIME** is active or idle - it turns the acoustic indication on and off.
- 3 Can telephone communication be heard via headset or loudspeaker? Check whether **DAI LS**, **MASTER LS**, **GG LS** are active or idle - they route audio either to loudspeaker or headset.
- 4 Can radio communication be heard via headset or loudspeaker? Check the **LSP** toggle key on the frequency control window. Check if **AG LS** is active or idle - it routes audio either to loudspeaker or headset.
- 5 Press **PAGE** to scroll cyclically through the pages available on your panel. Scroll through to become familiar with them and see what the operational area looks like.
- 6 If you have two panels at your operator position, press **SPLIT** to activate split position operation. Works only, if split position is enabled on the TMCS, and at least one headset is connected. Result: there is radio and telephone operation on one panel, and telephone operation with radio status indication on the other.
- 7 Press **SET** to open the settings window for brightness and volume control.


Main Page



## Main Page

On the main page press **SET** to open the settings window.

## Settings Window



Move sliders to adjust:

- volume levels
- A/G-G/G-balance
- panel brightness

Clean the touch panel screen.

Panel calibration carried out by maintenance staff.

Accept new configurations or reset original ones.

Main Page











Alphabetical list of function keys:












AG HS+LS	<b>AIR/GROUND LOUDSPEAKER:</b> for routing all A/G-audio to a loudspeaker (toggle between headset and loudspeaker)
ACTIVE ROLE	Key carries the NAME of the <b>ACTIVE ROLE</b> ; for accepting a new layout/role during panel reconfiguration
CCB	<b>CHIME TONE SINGLE OR STEADY:</b> for toggling between single and steady chime (default: CCB active)
CHIME	<b>CHIME:</b> for toggling the chime for incoming call indication between ON/OFF
CLIR	<b>CLIR:</b> for activating CLIR, i.e. inhibit your identity during an active ISDN-call
CONF	<b>CONFERENCE:</b> for telephone conference calls
CUT IN	<b>CUT-IN:</b> for monitoring and interrupting calls on other operator positions (supervisors only)
DAI LS	<b>DIRECT ACCESS INTERCOM LOUDSPEAKER:</b> for routing DAI-audio to a loudspeaker (toggle between headset and loudspeaker)
DIAL PAD	<b>DIAL PAD:</b> for opening the dial pad
DIV	<b>DIVERSION:</b> for diverting all telephone calls to another operator position
DOOR	<b>DOOR:</b> for activating the door opener
DROP	<b>DROP:</b> for releasing the last party in a conference call

FAST CPL	<b>FAST COUPLING:</b> for coupling all frequencies in Tx-mode with one touch
FRO FWD	<b>FREQUENCY FORWARDING:</b> for forwarding frequencies to another operator position
FRO ICOM	<b>FREQUENCY INTERCOM:</b> for direct communication to all positions having frequencies in traffic or monitor mode
GG LS	<b>GROUND/GROUND LOUDSPEAKER:</b> for routing G/G-audio to loudspeaker (toggle between headset and loudspeaker)
HOLD	<b>HOLD:</b> for holding active telephone calls
HOOK FLASH	<b>HOOK FLASH SIGNAL:</b> for sending a hook flash signal to an external open line
LESS FN	<b>LESS:</b> for switching from the second layer of function keys back to the first layer
MAN RING	<b>MAN RING:</b> for sending a ringing signal for a defined period
MASTER LS	<b>MASTER LOUDSPEAKER:</b> for routing all audio to a loudspeaker (toggle between headset and loudspeaker)
MON	<b>MONITORING:</b> for position monitoring
MORE FN	<b>MORE:</b> for switching to the second row of function keys
OVR LS XFR	<b>LOUDSPEAKER OVERRIDE:</b> for overriding the automatic transfer of A/G-audio to LS during G/G-communication
PAGE	<b>PAGE:</b> for scrolling through the panel pages

PICK UP	<b>PICK-UP:</b> for picking up pending calls from other operator positions
PLAY BACK	<b>PLAY BACK:</b> for opening the play-back window
POS CHECK	<b>POSITION CONFIDENCE CHECK:</b> for activating a hardware test of the operator position
PRIO	<b>PRIORITY:</b> for increasing the priority of a telephone call
PRIV	<b>PRIVACY MODE:</b> for protecting supervisor positions from monitoring
RELIEF BRIEF	<b>RELIEF BRIEFING:</b> for activating a two-way communication between coach and trainee
RUNWAY INCURS	<b>RUNWAY INCURSION:</b> for toggling the function between ON and OFF
SET	<b>SETTINGS window:</b> for opening the setting windows
SPLIT	<b>SPLIT POSITION:</b> for splitting an operator position for separate A/G- and G/G-use
SUBST	<b>SUBSTITUTE:</b> for substituting another operator position, i.e. taking over incoming calls from there
XFR	<b>TRANSFER:</b> for transferring an active call to another party
WIRE LESS	<b>WIRELESS:</b> for answering calls with your wireless telephone while you are not at your operator position
END	<b>END:</b> for terminating telephone calls and certain functions




		Key is unavailable for activation.
DA: Direct Access		Key is idle, and available for activation.
		Key is deselected; there is no acoustic indication for incoming calls.
		Symbol shows that interface for wireless telephone call activated, incoming calls are redirected to wireless phone.
		Symbol shows that you act as substitute for this operator position.
		Key is blinking between idle and active; shows an incoming direct access call (DA) on a DA-key, or in the incoming call queue (configurable).
		Background active; key shows an active direct access call (DA).
CA: Common Answer		Key is blinking between idle and active; shows an incoming common answer call (CA) in the incoming call queue.
		Background active; key shows an active common answer call (CA).
CD: call display		Background active; key shows an active IA-call on the active call display key (CD).

	Background hold; key shows a held direct access call (DA).
	Frame steady, background active; key shows an outgoing direct access call (DA).
	Frame blinking, background idle; key shows that the called party is busy.
	Frame steady, background idle; key shows that the used line is busy.
	Frame and background blinking; key shows that this party is selected for transfer.
	Background blinking; key shows that this position is out-of-service.
	Frame blinking, background blinking; key shows an incoming priority call.
	Frame steady orange, background active; key shows that position monitoring is active.
	Frame blinking, background blinking; key shows that cut-in call is active.
	Background red; key shows that a monitored operator position is muted due to a supervisor's cut-in call.
	Background blinking; key shows that an operator at a muted position tried to set up a hotline-call, which is not possible in this state

**Direct Access**

**Direct Access Calls and Direct Access Intercom Calls**



- Incoming DA-calls are indicated:
- on the DA-layers
  - on the layer selection keys
  - on the CA-keys of the incoming call queue (if configured)

Set up an outgoing DA-call:




Answer an incoming DA-call:



Set up an outgoing hotline call:



Answer an incoming hotline call (intercom):




## Telephone: Indirect Access and Common Answer

### Indirect Access (Serial Dialling)

**Indirect Access:** On the main page press **DIAL PAD** to open the dial pad.


On the main page press **Phone Book** to open the phone book.




Incoming CA-calls are indicated:

- on the CA-keys in the incoming call queue


Set up an IA-call:




Set up an MFC-call:



Redial last number:



Answer incoming CA-call:



Set up phone book call:



## Priority Calls

Set up a priority call



Incoming priority call on a DA-key (*with call intrusion*):



Answer an incoming DA-priority call *without call intrusion*:



Answer an incoming CA-priority call *without call intrusion*:



## Short Code Dialling

Set up a short call:



## Function Codes

Activate a function:



## Frequency/Radio Objects

Non-coverage mode

Coverage mode

Without and with radio remote control:

123.456	Rx 1234	ABCDEF G	Rx 1234
⊕12	⊕	⊕12	⊕
▼	Tx 1234	▼	Tx 1234

123.456	Rx1 LOC1	Rx2 LOC2	Rx3 LOC3	ABCDEF G	Rx 1234	Rx 1234	Rx 1234
⊕1	⊕	Tx1 LOC1	Tx2 LOC2	Tx3 LOC3	⊕12	⊕	⊕
▼					Tx 1234	Tx 1234	Tx 1234

Open the frequency control window:



## Frequency Control Windows

Without and with radio remote control:

DEL	M	S
123.567	Rx 1234	
⊕12	⊕	Tx 1234
▼		
ADD	M	S
LSP	COUPLE	
1	2	OFF
	ON	OFF

DEL	M	S	Mode AM FM	Crypto ON OFF
ABCDEF G	Rx 1234		Squelch ON OFF	Crypto Mode99
⊕12	⊕	Tx 1234	SQ Level L M H	FRQ Set
▼			Tx Power L M H	CH Set
ADD	M	S	Remote M S	Scan ON OFF
LSP	COUPLE			
1	2	OFF		
	ON	OFF		

DEL	M	S	M	S	M	S
123.456	Rx1 LOC1	Rx2 LOC2	Rx3 LOC3			
⊕1	⊕	Tx1 LOC1	Tx2 LOC2	Tx3 LOC3		
▼						
ADD	M	S	M	S	M	S
LSP	COUPLE					
1	2	OFF				
	ON	OFF				

DEL	M	S	M	S	M	S	Mode AM FM	Crypto ON OFF
ABCDEF G	Rx 1234	Rx 1234	Rx 1234				Squelch ON OFF	Crypto Mode99
⊕12	⊕	Tx 1234	Tx 1234	Tx 1234			SQ Level L M H	FRQ Set
▼							Tx Power L M H	CH Set
ADD	M	S	M	S	M	S	Remote M S	Scan ON OFF
LSP	COUPLE							
1	2	OFF						
	ON	OFF						

With radio remote control

and

volume control per frequency:

DEL	M	S	+	Mode AM FM	Crypto ON OFF
ABCDEF G	Rx 1234			Squelch ON OFF	Crypto Mode99
⊕12	⊕	Tx 1234		SQ Level L M H	FRQ Set
▼				Tx Power L M H	CH Set
ADD	M	S		Remote M S	Scan ON OFF
LSP	COUPLE				
1	2	OFF			
	ON	OFF			


DEL	M	S	M	S	M	S	+	Mode AM FM	Crypto ON OFF
ABCDEF G	Rx 1234	Rx 1234	Rx 1234					Squelch ON OFF	Crypto Mode99
⊕12	⊕	Tx 1234	Tx 1234	Tx 1234				SQ Level L M H	FRQ Set
▼								Tx Power L M H	CH Set
ADD	M	S	M	S	M	S		Remote M S	Scan ON OFF
LSP	COUPLE						Site		
1	2	OFF					1 2 3		
	ON	OFF							

On the frequency control window:

Delete frequencies:



Add frequencies:



Cancel delete frequencies, cancel add frequencies:



Select loudspeaker:



Main/standby (Rx- or Tx-mode required):




Couple frequencies (Tx-mode required):




Terminate coupling:




Indications in idle mode:



Set frequency to monitor mode:




Set frequency to traffic mode:



Transmit on this frequency:




PTT-lockout:




Out-of-service indication:



Transmit on emergency frequency:



Status indications when two radio pages are used:



status indication

in detail









Radio remote control and number pad:



Open number pad.




- Delete digit.
- Accept entry, close window.
- Cancel entry, close window.
- Enter a decimal point.


1	Mode AM FM	=	toggle between <b>AM- and FM-mode</b>
1	Sque1ch ON OFF	=	toggle between <b>SQU ON and OFF</b>
1	SQ Level L M H	=	toggle <b>SQU detection</b> between LOW, MEDIUM, and HIGH
1	Tx Power L M H	=	toggle <b>Tx-output power</b> between LOW, MEDIUM, and HIGH
1	Remote M S	=	toggle between <b>main and standby</b>
1	Crypto ON OFF	=	toggle <b>encryption mode</b> between ON and OFF
1	Crypto Mode99	→	 2 enter number to select <b>crypto mode</b> (max. 2 digits)
1	FRQ Set	→	 2 enter number to select <b>frequency</b> (max. 7 digits)
1	CH Set	→	 2 enter number to select <b>channel</b> (max. 2. digits)
1	Scan ON OFF	=	toggle <b>scan mode</b> between ON and OFF

## VCS 3020X Rel. 3.2 only: Radio - Short-Term Recording

On the main page, open play-back window, and close window again:



Navigate and select play-back record:



Start and stop play-back:



Delete all records:



Record structure:

### Type:

- Tx - Transmission
- Rx - Reception (background shows entry is selected)
- RTx - Reception and transmission
- RTxⓄ - Reception and transmission in a coupling group
- Rx Ⓞ - Reception in a coupling group
- Tx Ⓞ - Transmission in a coupling group
- Ph - Phone call


### Time:

record start time


### ID:

- Frequency
- Name/number of connected telephone party
- CONF if the telephone call was a master conference

Manual selection of best receiver and/or transmitter.



BSS/receiver voting:



Tx follows best receiver:



Tx follows best receiver with default Tx:

- Define default Tx:



- BSS defines best Rx, Tx follows:



- Automatic reset to default Tx:



Stuck PTT:



This Short User Manual for the voice communication systems VCS 3020X Rel. 4.1 gives an overview of the touch panel layout, and the most important functions of these user interfaces. For a complete description of the user interface, its features and functions, refer to the User Manual for the VCS 3020X Rel. 4.1 (04A28 E502), delivered with your voice communication system. All warnings and recommendations contained in the User Manual mentioned above are valid.

June 2005

Prepared: I. Lenger  
Approved: P. Leybold  
Released: W. Pestitschek

*Dieses Dokument ist elektronisch freigegeben.  
This document is released electronically.*



All rights reserved. No part of the document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the written permission of FREQUENTIS GmbH.

Company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies.