

Monitoring & Notification

F3400/F1000 (F-Series)

User Guide



Copyright Notice

©2010 RLE Technologies. All rights reserved. No part of this publication may be reproduced or distributed in any form or by any means, or stored in a database or retrieval system, without the prior written permission of RLE Technologies.

Trademark Notices

RLE is a registered trademark and Falcon, Raptor, and SeaHawk are trademarks of RLE Technologies. All other trademarks or registered trademarks are the property of their respective companies.

Revision History

Part number 11049

Rev. No.	Date
3.0	June 2010

Note: As necessary, blank pages are added to make the page count even.

Product Registration

Product registration helps RLE Technologies inform owners of:

- Product upgrades
- Firmware enhancements
- New products and technologies
- Special offers available only to registered users

Access and submit Product Registration information from the F1000/F3400 Configuration Menu.

Any information provided to RLE Technologies through the registration form will be regarded as confidential. RLE will not sell or distribute any of the information to third parties. To read our Privacy Policy, please visit our website: www.rletech.com.

Technical Support

Personal assistance is available Monday through Friday, from 8:00 a.m. to 5:00 p.m. MST.

A request for assistance may be sent to support@rletech.com.

Otherwise, please call us directly at: **(970) 484-6510**, and press “2” for technical support.

The following information is located on the bottom of each F1000/F3400 unit. Please have this information available whenever a technical support call is placed:

Product Model Number	_____
Product Serial Number	_____
Product Manufacture Date	_____

Notes:

Contents

1	System Overview	13
	Product Description	13
	Front Panel Indicators and Controls	14
	Terminal Block Designations	15
	Rear Panel Indicators	18
	SW1 Switch Settings	18
2	Getting Started	19
	Installation	19
	Communication	19
	Set the F3400/F1000's IP Address	19
	Set the F3400/F1000's IP Address using the ARP and PING Commands	20
	Obtain the Ethernet Address	20
	Use the ARP Command	20
	Use the PING Command	20
	Troubleshooting the ARP/PING Commands	21
	Set the F3400/F1000's IP Address using a Web Browser	21
	Set the F3400/F1000's IP Address Using an EIA232 Connection	22
	Set the F3400/F1000's IP Address using a Telnet Connection	22
	F3400/F1000 Wiring	23
	Power Supply and Ground Connections	23
	EIA232 COM1 Connection	24
	RJ11 Phone Line Connection	24
	RJ45 Ethernet Connection	25
	Relay K1 and K2 Connection	26
3	F3400/F1000 Web Interface	27
	F3400/F1000 Web Interface Overview	27
	Main Menu	27
	Historical Data	28
	Alarm History	28
	Event History	29
	Digital Status History	30
	Web User Access Log	30
	Data History	31
	Minute, Hour, and Day View	31
	Data History Text Downloads	32
	Server History	32
	Server Status	33
	Identity	33
	Web Links	34
	Configuration	34

4	Configuration Menu	35
	Inputs	36
	Relays	40
	Schedules	41
	Alarm Management	42
	Modem	43
	Configure Phone Numbers	44
	Web Links	46
	Egg/Nest	47
	Falcon Links	47
	SNMP/SYSLOG	48
	Modbus Interface	49
	LD Unit Modbus Slave Configuration	50
	Modbus Register Data Log	51
	Modbus Packet Log	51
	Reset Modbus Port	52
	F-Series Modbus Slave Register Map	52
	BACnet	53
	Server Ping	54
	System	55
	Clock	56
	Internet Protocol	56
	User Administration (Web Access)	57
	Email	58
	Network Time Protocol	59
	Network Statistics	60
	Flash Program	60
	Product Registration	61
5	EIA-232 Interface	63
	Unit Start Up	64
	Flash Executable Code	64
	Main Menu	65
	Main Configuration Menu – SC	66
	IP Configuration Menu	67
6	Remote Access	69
	Remote Access Configuration (Modem Option)	69
7	Point-to-Point Protocol	71
	Configuring the F3400/F1000	71
	Configuring the PC	72
8	Upgrading Firmware and Managing Configuration Data	73
	Upgrading F3400/F1000 Firmware	73
	Upgrading F3400/F1000 Firmware via TFTP Client	74
	Updating F3400/F1000 Firmware via the EIA232 COM1 Port (X-Modem)	75
	Loading/Saving F3400/F1000 Configuration Data	76
	Saving Configuration Data via TFTP Client	76
	Saving Configuration Data via EIA232 COM1 Port (X-Modem)	76
	Loading Configuration Data via TFTP Client	77
	Loading Configuration Data via EIA232 COM1 Port (X-Modem)	77

A	Analog Input 4-20mA Reference Chart	79
B	F3400/F1000 Accessories Wiring	81
	Configuring the SeaHawk LD5100 as an Analog Input	84
C	Alarm ID Reference Tables	87
	Analog Tables	87
	Thermistor Tables	88
	Digital Tables	89
D	Technical Specifications	91

Notes:

Figures

1	System Overview	13
	Figure 1.1 Front Panel Indicators and Controls	14
	Figure 1.2 Terminal Block Designations	17
	Figure 1.3 Rear LED Indicator and Status	18
	Figure 1.4 SW1 Switch Is On and SW2 Switch Is Off.	18
2	Getting Started	19
	Figure 2.1 24 VDC Power Supply Connection	23
	Figure 2.2 EIA232 COM1 Connection	24
	Figure 2.3 F3400/F1000 Ethernet Connection to a PC using a Crossover Cable	25
	Figure 2.4 F3400/F1000 Ethernet Connection to a PC on a Subnet	25
	Figure 2.5 F3400/F1000 Relay Output Wiring Examples	26
3	F3400/F1000 Web Interface	27
	Figure 3.1 Example of F3400/F1000's Main Menu	27
	Figure 3.2 Example of the Alarm History Page	28
	Figure 3.3 Example of the Event History Page	29
	Figure 3.4 Example of the Digital Status History Page	30
	Figure 3.5 Example of Web User Access Log Page	30
	Figure 3.6 Example of the Data History Page	31
	Figure 3.7 Day View Example	31
	Figure 3.8 Example of the Data History Text Download Page	32
	Figure 3.9 Example of the Server History Page	32
	Figure 3.10 Example of the Server Status Page	33
	Figure 3.11 Example of the F3400/F1000 Identity Page	33
	Figure 3.12 Example of the Web Links Display Page	34
	Figure 3.13 Configuration Menu	34
4	Configuration Menu	35
	Figure 4.1 Configuration Menu	35
	Figure 4.2 Inputs Configuration Page	36
	Figure 4.3 Calculator Link	37
	Figure 4.4 Relays Configuration Page	40
	Figure 4.5 Schedules Configuration Menu	41
	Figure 4.6 Alarm Management	42
	Figure 4.7 Modem Configuration Page	43
	Figure 4.8 Phone Number Configuration Page	44
	Figure 4.9 Configuring Web Links	46
	Figure 4.10 Egg/Nest Configuration Page	47
	Figure 4.11 Falcon Links Configuration Page	47
	Figure 4.12 SNMP/SYSLOG Configuration Page	48

Figure 4.13 Modbus Interface Configuration	49
Figure 4.14 LD Unit Modbus Slave Configuration	50
Figure 4.15 Modbus Register Data Log Page	51
Figure 4.16 Modbus Packet Log	51
Figure 4.17 BACnet Configuration	53
Figure 4.18 Server Ping Configuration	54
Figure 4.19 System Configuration	55
Figure 4.20 Clock Configuration	56
Figure 4.21 Setting the Internet Protocol	56
Figure 4.22 User Administration Configuration	57
Figure 4.23 Email Configuration	58
Figure 4.24 Network Time Protocol Configuration	59
Figure 4.25 Setting the Network Statistics	60
Figure 4.26 Flash Programs	60
Figure 4.27 Product Registration Located at www.rletech.com	61
5 EIA-232 Interface	63
Figure 5.1 HyperTerminal Connection Screen	63
Figure 5.2 Com1 Properties Screen	64
B F3400/F1000 Accessories Wiring	81
Figure B.1 T120D Temperature Sensors	81
Figure B.2 TH140 & TH140D Temperature/Humidity Sensors	81
Figure B.3 Dwyer Temperature/Humidity Sensors	82
Figure B.4 BAPI Temperature/Humidity Sensor	82
Figure B.5 SMK Smoke Detector, Photoelectric	82
Figure B.6 HD150 & HD150-2 Gas Sensors	83
Figure B.7 SD Spot Detectors	83
Figure B.8 PFM Power Fail Monitor	83
Figure B.9 SeaHawk LD5100/LD2000 Distance Read Leak Detection (Dry Contact) ..	84
Figure B.10 SeaHawk LD5100 Distance Read Leak Detection (4-20mA)	84
Figure B.11 SeaHawk LDRA6, LD1000, and LD300 Leak Detection	84

Tables

1	System Overview	13
	Table 1.1 Terminal Block Designations	15
	Table 1.2 Rear Panel Status Indicators	18
4	Configuration Menu	35
	Table 4.1 Output Registers	52
	Table 4.2 Status Flags (Registers 40201-40232)	52
	Table 4.3 Status Flags (Registers 40401-40432)	52
5	EIA-232 Interface	63
	Table 5.1 Main Menu Commands	65
	Table 5.2 Main Configuration Menu (SC) Commands	66
	Table 5.3 IP Configuration Menu Commands	67
A	Analog Input 4-20mA Reference Chart	79
	Table A.1 Analog Input 4-20mA Reference Chart	79
C	Alarm ID Reference Tables	87
	Table C.1 Analog Alarm ID Reference Tables, Inputs 1-4	87
	Table C.2 Thermistor Alarm ID Reference Tables, Inputs 5-8	88
	Table C.3 Digital Alarm ID Reference Tables, Digital Inputs 5 through 32	89
D	Technical Specifications	91
	Table D.1 Technical Specifications	91

Notes:

SYSTEM OVERVIEW

1.1. Product Description

The F3400/F1000 monitoring system is a comprehensive system which provides additional equipment protection by monitoring critical operating parameters in enterprises, remote network facilities, communication rooms, remote and unmanned facilities, and critical support systems. The F3400/F1000 is a stand alone system. It operates via an embedded Web server that handles all data collection, alarm reporting, and multiple concurrent communication mediums.

The F3400/F1000 typically monitors analog and dry contact outputs from devices such as temperature sensors, humidity sensors, thermistors, gas detectors, smoke detectors, fire suppression systems, surveillance products (e.g., IP cameras), leak detection systems, power monitoring systems, uninterruptible power supplies (UPSs), power distribution units (PDUs), generators, DC power plants, commercial power, HVAC units, ATS and TVSSs.

The F3400/F1000 performs internal diagnostics that check the Flash Program code, serial ports, RAM, non-volatile RAM, real-time clock, internal power supplies, relay drivers, analog to digital converter (ADC), and modem. During operation, the F3400/F1000 monitors its status and uses several LED indicators to report its condition.

The F3400/F1000's embedded firmware enables system configuration, I/O setup, status inquiries, alarm reports, data logs, and troubleshooting. The F3400/F1000 is menu driven and operates with any Web browser, ASCII terminal or terminal emulation application such as HyperTerminal.

1.2. Front Panel Indicators and Controls



Figure 1.1 Front Panel Indicators and Controls

Communications LEDs – Four Modem Status LEDs

TX – Green (On) if information is being transmitted.

RX – Green (On) if information is being received.

OH – Green (On) if the Modem detects a dial tone (off hook).

CD – Green (On) if a carrier is detected.

System Status LED

Fault – Red if an alarm is present, green if system in normal.

Network LEDs – Two Network Status LEDs

Link – Green if network link is established.

Active – Green (On) if transmitting or receiving data.

Power LED – Green (On) if power is on.

1.3. Terminal Block Designations

Table 1.1 Terminal Block Designations

TB1-1	(+) Input for 24VDC power
TB1-2	(-) Input for 24VDC power
P1	24VDC wall adapter input (center +)
TB2-1	Channel 1 positive (+)
TB2-2	Channel 1 negative (-)
TB2-3	Channel 1 ground (c)
TB2-4	Channel 2 positive (+)
TB2-5	Channel 2 negative (-)
TB2-6	Channel 2 ground (c)
TB2-7	Channel 5 positive (+)
TB2-8	Channel 5 negative (-)
TB2-9	Channel 6 positive (+)
TB2-10	Channel 6 negative (-)
TB2-11	Channel 3 positive (+)
TB2-12	Channel 3 negative (-)
TB2-13	Channel 3 ground (c)
TB2-14	Channel 4 positive (+)
TB2-15	Channel 4 negative (-)
TB2-16	Channel 4 ground (c)
TB2-17	Channel 7 positive (+)
TB2-18	Channel 7 negative (-)
TB2-19	Channel 8 positive (+)
TB2-20	Channel 8 negative (-)
TB3-1	Relay 1 NC
TB3-2	Relay 1 NO
TB3-3	Relay 1 Common
TB3-4	Relay 2 NC
TB3-5	Relay 2 NO
TB3-6	Relay 2 Common
P2	COM1 EIA232 male DB9 pin connector (configurable)

Table 1.1 Terminal Block Designations (continued)

TB4-1	COM1 EIA 485 positive (+) (configurable)
TB4-2	COM1 EIA 485 negative (-) (configurable)
TB4-3	EIA 485 ground
TB4-4	COM1 EIA485 positive (+) (configurable)
TB4-5	COM1 EIA485 negative (-) (configurable)
TB4-6	EIA485 ground
SW1-1	Unit EIA485 termination switch
SW1-2	Two or four wire EIA485 termination.
P3	RJ45 Ethernet 10BASE-T connector
P4	RJ11 telephone line connector
TB5- 1	Channel 9 positive (+)
TB5-	Channel 9 negative (-)
TB5- 3	Channel 10 positive (+)
TB5- 4	Channel 10 negative (-)
TB5- 5	Channel 11 positive (+)
TB5- 6	Channel 11 negative (-)
TB5- 7	Channel 12 positive (+)
TB5- 8	Channel 12 negative (-)
TB5- 9	Channel 13 positive (+)
TB5-10	Channel 13 negative (-)
TB5-11	Channel 14 positive (+)
TB5-12	Channel 14 negative (-)
TB5-13	Channel 15 positive (+)
TB5-14	Channel 15 negative (-)
TB5-15	Channel 16 positive (+)
TB5-16	Channel 16 negative (-)
TB5-17	Channel 17 positive (+)
TB5-18	Channel 17 negative (-)
TB5-19	Channel 18 positive (+)
TB5-20	Channel 18 negative (-)
TB5-21	Channel 19 positive (+)
TB5-22	Channel 19 negative (-)
TB5-23	Channel 20 positive (+)

Table 1.1 Terminal Block Designations (continued)

TB5-24	Channel 20 negative (-)
TB5-25	Channel 21 positive (+)
TB5-26	Channel 21 negative (-)
TB5-27	Channel 22 positive (+)
TB5-28	Channel 22 negative (-)
TB5-29	Channel 23 positive (+)
TB5-30	Channel 23 negative (-)
TB5-31	Channel 24 positive (+)
TB5-32	Channel 24 negative (-)
TB5-33	Channel 25 positive (+)
TB5-34	Channel 25 negative (-)
TB5-35	Channel 26 positive (+)
TB5-36	Channel 26 negative (-)
TB5-37	Channel 27 positive (+)
TB5-38	Channel 27 negative (-)
TB5-39	Channel 28 positive (+)
TB5-40	Channel 28 negative (-)
TB5-41	Channel 29 positive (+)
TB5-42	Channel 29 negative (-)
TB5-43	Channel 30 positive (+)
TB5-44	Channel 30 negative (-)
TB5-45	Channel 31 positive (+)
TB5-46	Channel 31 negative (-)
TB5-47	Channel 32 positive (+)
TB5-48	Channel 32 negative (-)

**Figure 1.2** Terminal Block Designations

1.4. Rear Panel Indicators

The rear panel of the F3400/F1000 houses a pair of green LEDs. The chart below tracks indicator status when the corresponding green LED is illuminated:

Table 1.2 Rear Panel Status Indicators

EIA232 or EIA485 TX (COM1) Interface	Data is being transmitted.
EIA232 or EIA485 RX (COM1) Interface	Data is being received.




Figure 1.3 Rear LED Indicator and Status

1.5. SW1 Switch Settings

- ◆ **SW1-1:** EIA485 Termination switch should be On (down) if the F3400/F1000 is the end device on an EIA485 network. The switch should be in the OFF (up) position if the device is at the beginning or in the middle of an EIA485 network.
- ◆ **SW1-2:** EIA485 Termination switch should be On (down) if the device is connected via a four wire connection. OFF (up) if the device is connected via a two wire connection.




Figure 1.4 SW1 Switch Is On and SW2 Switch Is Off

GETTING STARTED

2.1. Installation

The F3400/F1000 comes in a 19 inch (.48m) rack mount enclosure. Install the F3400/F1000 in the rack. Use the proper anchoring method to mount the unit securely. Supply the 24VDC to the unit.

2.2. Communication

The F3400/F1000 will not communicate over a user's network the first time it is connected to the network. The manufacturer programs the F3400/F1000 with a default IP address: **10.0.0.186**, subnet: **255.255.255.0**. This default address must be changed to an IP address that corresponds with the user's network before the F3400/F1000 can communicate over the network.

2.3. Set the F3400/F1000's IP Address

There are four ways to set the F3400/F1000's IP address:

- ◆ Via the ARP and PING commands
- ◆ Via the Web browser
- ◆ Via the EIA232 interface
- ◆ Via Telnet commands

2.3.1 Set the F3400/F1000's IP Address using the ARP and PING Commands

To set the IP address of a manufacturer programmed F3400/F1000, you can use the ARP (Address Resolution Protocol) command together with the PING (ICMP echo request) command. However, before using these commands, you must know the Ethernet address of the F3400/F1000.

2.3.1.1 Obtain the Ethernet Address

Each network device must have its own unique identification. This identification sets it apart from all other manufacturers and ensures that no two network devices have the same address. Each manufacturer must use a six digit numbering convention, the first three digits determine the actual manufacturer and the remaining three digits determine the unique network serial number of each individual device.

A typical Ethernet address (also known as a MAC address - Media Access Control) from the F3400/F1000 looks like this: 00:90:5B:00:02:45

You can find the Ethernet (MAC) address of your F3400/F1000 by looking at the model number sticker located on the bottom of the device.

2.3.1.2 Use the ARP Command

Once you know the Ethernet address of the F3400/F1000, use the ARP command with the correct parameters from any computer located on the F3400/F1000's subnet (e.g., Class C with a net mask of 255.255.255.0).

For example, enter the following from a command prompt:

```
arp -s 192.168.1.14 00-90-5b-00-02-45
```

This command tells the computer (from which the ARP command was entered) that the network device with an IP address of 192.168.1.14 uses the Ethernet (MAC) address of 00-90-5b-00-02-45.

2.3.1.3 Use the PING Command

After the ARP command has been entered, the PING command must be entered from the same computer in order to set up the IP address of the F3400/F1000. The PING command will use the ARP entry added from 2.3.1.1, "Obtain the Ethernet Address" on page 20, to send the IP address information directly to the F3400/F1000 (which is just one of several methods to initially configure the IP address on a new F3400/F1000).

To do this, enter the following from a command prompt:

```
PING ip_address
```

Where "ip_address" is the IP address you entered using the ARP command. In the above example, the following would be entered:

```
PING 192.168.1.14
```

This changes the IP address of the F3400/F1000 to: 192.168.1.14.

2.3.1.4 Troubleshooting the ARP/PING Commands

If problems are encountered, it may be for one of the following reasons:

- ◆ The F3400/F1000 already has a non-default TCP/IP address. Once the IP address of the F3400/F1000 has been changed from the default of 10.0.0.186, it is not possible to change it again with the ARP/PING commands. This method of setting up the F3400/F1000's IP address can only be used on a F3400/F1000 that still has its original default IP address, as shipped from the manufacturer.
- ◆ The device is not on the same Class C subnet as the computer from which the ARP/PING commands were sent. The F3400/F1000's default router and net mask must be changed via a Web browser pointed at the F3400/F1000's default IP address (i.e., <http://10.0.0.186>) or via a direct EIA232 terminal connection to the F3400/F1000—both of which are alternate methods for setting up the F3400/F1000's IP address.

2.3.2 Set the F3400/F1000's IP Address using a Web Browser

- 1 Plug a crossover network cable into the laptop or workstation that will be used to configure the F3400/F1000. This cable is not intended to be connected to a network hub.
- 2 Write down the computer's IP address and Subnet Mask. Then change the IP address and Subnet Mask of the computer from its existing address to one that will allow it to communicate with the F3400/F1000, such as 10.0.0.188. It may be helpful to set the IP address to one that is one number different from the F3400/F1000's IP address. Consult the computer's manual or your IT Department before attempting this.
- 3 Connect the other end of the network cable to the Ethernet port on the back of the F3400/F1000. Access the F3400/F1000 through a Web browser by typing the IP address into the location bar. Enter the F3400/F1000 user name and password when prompted.

Note The default user name is “falcon” and there is no default password—leave the password field empty.

- 4 Select the **Configuration** link, then select the **Internet Protocol** link and change the IP Address, Net Mask, and Def Route to one provided by the network administrator. Press the **Submit Changes** button. The F3400/F1000 will save the new IP address and reboot. Once the F3400/F1000 reboots completely, the system status LED will stop flashing.
- 5 Change the IP address of the computer back to its original IP address. If the computer was configured as DHCP (the network domain controller assigns an IP address) return it to this state. This may require assistance from your IT Department, or you may need to consult the computer's manual.
- 6 The computer and the F3400/F1000 are now both configured to communicate on the network. Both should be accessible via the network. Connect the PC and the F3400/F1000 to the network. From the PC Web browser, type in the IP address of the F3400/F1000. Enter the user name and password.

Note The default user name is “falcon” and there is no default password - leave the password field empty.

2.3.3 Set the F3400/F1000's IP Address Using an EIA232 Connection

To use the EIA232 interface:

- 1 Connect the EIA232 port (P2 EIA232 - COM1) on the F3400/F1000 to a terminal or PC running terminal emulation software (HyperTerminal) with a 9-pin male-female straight through serial cable (a serial cable is supplied with the F3400/F1000).
- 2 Set the appropriate communication port to **9600 baud, NO parity, 8 data bits, 1 stop bit, (9600/N/8/1)**, and **no software or hardware flow command**.
- 3 Once the terminal emulation software starts, press **Enter** on the keyboard and the Main Menu should appear. If the Main Menu does not appear, check the communication settings and make sure the unit is powered on.
- 4 From the Main Menu type "**SC**" to select the System Configuration Menu.
- 5 From the main configuration menu type "**1**" to select the IP Configuration Menu.
- 6 From the IP Configuration Menu type "**i**" to change the IP address.
- 7 Enter the new IP address for the F3400/F1000. Separate each field with a decimal point - for example type 10.0.0.50 <enter>.
- 8 Enter "**x**" to Exit and Save the new IP address F3400/F1000 will erase a memory block and copy data to Flash memory before rebooting.
- 9 The F3400/F1000 IP address is now set and the F3400/F1000 can be accessed through a Web browser using the new IP address.

Refer to Chapter 5, "EIA-232 Interface" on page 63 for more information on the EIA232 command set.

2.3.4 Set the F3400/F1000's IP Address using a Telnet Connection

To use the Telnet interface:

- 1 Open a command prompt from your PC/Laptop.
- 2 Type in the Telnet, space, and the IP address of the Falcon. Once connected enter the user name and password; default user name is falcon (all lowercase) and no password (e.g., C:\>telnet 10.0.0.186).
- 3 To change the IP Address type **ip**, space, and the new IP address of the Falcon. Press **enter**.
- 4 To change the Subnet Mask, type "**sn**" space, and the new Subnet Mask number. Press **enter**.
- 5 To change the Default Gateway, type "**dg**", space, and the new Default gateway number. Then press **enter**.

2.4. F3400/F1000 Wiring

RLE Technologies recommends an 18AWG stranded copper wire for connection from each monitored point to a terminal block (TB) connection on the F3400/F1000. RLE recommends no more than 500 feet (152.4m) of wire at this specification. If longer runs are needed, please contact RLE Technologies for application guidance. Shielded twisted pair wiring is recommended for analog signal transmitters being wired outside of conduit runs and dropped ceiling applications.

2.4.1 Power Supply and Ground Connections

Connect an 18AWG ground wire from the ground terminal to a suitable earth ground. Plug the wall adapter into P1 and a UPS outlet as shown below. The wall adapter has a five foot power cord. RLE Technologies recommends powering the F3400/F1000 from a UPS supply to allow the F3400/F1000 to send alarm notification during a power outage.




Figure 2.1 24 VDC Power Supply Connection

2.4.2 EIA232 COM1 Connection

The EIA232 port can be connected to a PC for local configuration, firmware downloads, and troubleshooting. It is typically a temporary connection. Connect the straight through, 9-pin, cable as shown in Figure 2.2.




Figure 2.2 EIA232 COM1 Connection

2.4.3 RJ11 Phone Line Connection

The F3400/F1000 (with modem option the model no. would be F3400-M/F1000-M) contains an internal modem for dial in and dial out capabilities. The modem can be used for:

- ◆ Remote connection to accomplish a variety of tasks, including: viewing alarms, changing configurations, and acknowledging alarms.
- ◆ Pager notification to text, numeric pager or alpha-numeric pager (TAP changer). Text and numeric pagers do not use a TAP changer.

2.4.4 RJ45 Ethernet Connection

The F3400/F1000 has an internal 10BASE-T Ethernet port used to configure and monitor the F3400/F1000. The Ethernet port supports Web browser access, email (SMTP), BACnet, and SNMP. The following figures show the physical connections; refer to Chapter 4, “Configuration Menu” on page 35, for more detail on the Ethernet port. Figure 2.3 shows a direct connection between the F3400/F1000 and a PC using a crossover cable. Figure 2.4 shows a typical F3400/F1000 connection on a subnet using a hub or switch and straight through CAT5 cables.




Figure 2.3 F3400/F1000 Ethernet Connection to a PC using a Crossover Cable




Figure 2.4 F3400/F1000 Ethernet Connection to a PC on a Subnet

2.4.5 Relay K1 and K2 Connection

Relay outputs may be used to unlatch doors, signal annunciators, signal IP cameras, and to turn on auxiliary equipment such as exhaust fans. Relay outputs are Form C (SPST). Refer to Appendix D, “Technical Specifications” on page 91 for relay contact ratings. Relays may be wired for Normally Open (NO), or Normally Closed (NC) signals. See Figure 2.5 for examples.




Figure 2.5 F3400/F1000 Relay Output Wiring Examples

F3400/F1000 WEB INTERFACE

3.1. F3400/F1000 Web Interface Overview

The F3400/F1000's Web interface provides a convenient way to check the F3400/F1000's status and reconfigure basic settings from any Internet enabled computer.

The F3400/F1000 is shipped to the user with the IP address configured as **10.0.0.186** and a subnet of **255.255.255.0**. The user name is preconfigured as **Falcon**. The unit is configured without a password; when a password is requested, just leave the space blank. These pre-configurations can be customized through the **Internet Protocol** link on the **Configuration Menu** of the Web interface. To change the F3400/F1000 IP address, refer to 2.3., "Set the F3400/F1000's IP Address" on page 19.

3.2. Main Menu

Alarms Present	
1 22.5 Deg F	17 Dry Contact Input Normal
2 26.8 % RH	18 Dry Contact Input Normal
3 22.8 Deg F	19 Dry Contact Input Normal
4 Server 2 Temperature 81.0 Deg F	20 Dry Contact Input Normal
5 Dry Contact Input Normal	21 Dry Contact Input Normal
6 Thermostat 2	22 Dry Contact Input Normal
7 Dry Contact Input Normal	23 Dry Contact Input Normal
8 Dry Contact Input Alarm	24 Dry Contact Input Normal
9 Dry Contact Input Normal	25 Dry Contact Input Normal
10 Dry Contact Input Normal	26 Dry Contact Input Normal
11 Dry Contact Input Normal	27 Dry Contact Input Normal
12 Dry Contact Input Normal	28 Dry Contact Input Normal
13 Dry Contact Input Normal	29 Dry Contact Input Normal
14 Dry Contact Input Normal	30 Dry Contact Input Normal
15 Server Fan 7 On	31 Dry Contact Input Normal
16 Dry Contact Input Normal	32 Dry Contact Input Normal

Relay Status	
K1: Fan Switch 1 is Off	K2: Fan Switch 2 is Off

06/15/10 13:02:34
IP Address: 10.0.0.202
© 2009 RLE Technologies

Figure 3.1 Example of F3400/F1000's Main Menu

To access the F3400/F1000's **Main Menu**, type the IP address of the F3400/F1000 into the location bar of the Web browser. Then enter a user name and password.

The top of the page provides links to other pages for additional monitoring, control and configuration. The Falcon logo (default), IP camera image or company logo can be displayed on the Main Menu.

The bottom of the F3400/F1000 Main Menu features columns that list the F3400/F1000's configured inputs. The number of inputs displayed is configurable from the System Configuration page, explained below. Each input is numbered. The input's name is followed by its status. The space behind each input is shaded. This shading changes as the input's status changes. This allows users to see, at a glance, the status of their points. Color codes are as follows:

- ◆ Green: Input is normal—not in an alarm state.
- ◆ Yellow: Analog inputs only—input is in a high alarm 1 or low alarm 1 state.
- ◆ Red: Analog input is in a high alarm 2 or low alarm 2 state. Digital input is in an alarm state.
- ◆ Blue: Alarm/Input disabled by a schedule.
- ◆ White (no shading): Input is not configured - spare point for future use.
- ◆ Magenta, Green or Gold: Digital Status point is on. This color is configurable under the Configuration - System menu.

3.2.1 Historical Data

Historical Data provides an intermediate page to assist in navigating to desired data.

3.2.1.1 Alarm History

Alarm History displays the last 100 alarms captured by the F3400/F1000. Alarms are ranked from most recent (top of the page) to lest recent (bottom of the page).

Sever Room A Fort Collins	
Color Code:	Unacknowledged -- Acknowledged -- Return to Normal
AH043-0088-On	-05/14/10 15:15:18 Dry Contact Input Alarm
AH042-0086-On	-05/13/10 14:03:43 Thermistor 2
AH041-0012-Low2	-05/13/10 14:03:43 21 Deg. F
AH040-0010-Low1	-05/13/10 14:03:43 21 Deg. F
AH039-0095-On	-05/13/10 14:03:34 Server Fan 7: On
AH038-0088-RTN	-04/01/10 16:38:23 Dry Contact Input Normal
AH037-0088-On	-11/30/09 15:56:20 Dry Contact Input Alarm
AH036-0086-On	-11/30/09 15:56:20 Thermistor 2
AH035-0012-Low2	-11/30/09 15:56:20 22 Deg. F
AH034-0010-Low1	-11/30/09 15:56:20 22 Deg. F
AH033-0095-On	-11/30/09 15:56:11 Server Fan 7: On
AH032-0112-RTN	-11/24/09 10:42:27 Dry Contact Input Normal
AH031-0111-RTN	-11/24/09 10:42:10 Dry Contact Input Normal
AH030-0110-RTN	-11/24/09 10:41:58 Dry Contact Input Normal
AH029-0109-RTN	-11/24/09 10:41:22 Dry Contact Input Normal

Figure 3.2 Example of the Alarm History Page

The following format is used to record each alarm entry:

AH###-ID-Condition-Date Time (Value UOM) Label

- ◆ AH### is the alarm entry index.
- ◆ ID is the alarm identifier number; refer to Appendix C, “Alarm ID Reference Tables” on page 87.
- ◆ Condition is On, High1, High2, Low1, Low2, or RTN (Returned to Normal).
- ◆ Date and Time is the internal date and time stamp of the alarm condition.
- ◆ Label is the alarm descriptor, up to 64 characters long.
- ◆ Value and Unit of Measure (UOM) is captured for analog channels only. The value recorded is the actual analog value that exceeded its alarm threshold.

The Alarm History log entries are color coded as follows:

- ◆ Red: A point that is configured for dial out (pager) is in alarm and is unacknowledged. The alarm will be red if the point is configured for both pager and email notification.
- ◆ Blue: The alarm has been acknowledged.
- ◆ Black: The alarm has returned to normal.

Unacknowledged dial out alarms (marked in red) can be acknowledged from this page. To acknowledge an alarm, type the appropriate code in the box at the bottom of the page and click the Acknowledge Alarms by Code button. Acknowledge codes are set under the Phone Number Configuration pages. Refer to 4.5.1, “Configure Phone Numbers” on page 44, for more information on configuring phone numbers.

3.2.1.2 Event History

Sever Room A Fort Collins		
EL31-05/13/10	14:03:26	System Booted
EL30-11/30/09	15:56:03	System Booted
EL29-11/24/09	10:43:01	Email accepted by server
EL28-11/24/09	10:42:45	Email accepted by server
EL27-11/24/09	10:38:57	Email accepted by server
EL26-11/24/09	10:37:14	Email accepted by server
EL25-11/23/09	15:40:31	Email accepted by server
EL24-11/23/09	15:40:27	Email accepted by server
EL23-11/23/09	15:39:02	Email accepted by server
EL22-11/23/09	15:38:59	Email accepted by server
EL21-11/23/09	15:38:48	System Booted
EL20-11/23/09	15:48:36	Email accepted by server

Figure 3.3 Example of the Event History Page

Event History displays the past 100 events, as recorded by the F3400/F1000. Typical events logged are System Booted, Email Accepted by Server, No Dial Tone, Busy, No Carrier, Page Successful, Alarm History Cleared, Digital Status History Cleared, Force Acknowledge by <initials>, Program Upload - TFTP, etc.

3.2.1.3 Digital Status History




Figure 3.4 Example of the Digital Status History Page

Digital Status History displays a history of the state of digital points configured as “Status” points. A digital input can be configured as NO (normally open), NC (normally closed), or Status. If the digital input is configured as Status, it will not alarm, but any changes will be noted and appear on this page. The log displays the past 100 status changes, as recorded by the F3400/F1000.

3.2.1.4 Web User Access Log




Figure 3.5 Example of Web User Access Log Page

The **Web User Access Log** records the most recent 100 Web interface users.

3.2.1.5 Data History

Sever Room A Fort Collins				
CH	Description	View	View	View
1	BAPI Temperature Signal	Minute	Hour	Day
2	BAPI Humidity Signal	Minute	Hour	Day
3		Minute	Hour	Day
4	Server 2 Temperature	Minute	Hour	Day
5	Not Analog			
6	Not Analog			
7	Not Analog			
8	Not Analog			

[Data History Text Downloads](#)
[Historical Data](#) [Home](#)

Figure 3.6 Example of the Data History Page

Data History provides an intermediate page to assist in navigating to the desired data. Only points configured as analog 4-20mA and thermistor are shown.

- ◆ The **Data History Text Downloads** link allows the Alarm History Log to be downloaded as a text (.txt) file and the Minute, Hour and Day logs to be downloaded as a comma separated variable (.csv) file.

3.2.1.6 Minute, Hour, and Day View

F3400 Data History			
F3400 System Name: Sever Room A Fort Collins			
Channel:	1		
Data Type:	Daily		
Description:	BAPI Temperature Signal		
Unit of Measure:	Deg F.		
Date Time	Avg	High	Low
06/09/10 00:00	22	22	22
06/10/10 00:00	22	22	22
06/11/10 00:00	22	22	22
06/12/10 00:00	22	22	22
06/13/10 00:00	22	22	22
06/14/10 00:00	22	22	22
06/15/10 00:00	22	22	22

[Data History](#) [Home](#)

Figure 3.7 Day View Example

The **Minute**, **Hour**, and **Day** links on the Data History page display the detailed information the F3400/F1000 records in its logs. The Minute log displays the high, low and average values per minute for the last 60 minutes. The Hour log displays the high, low and average values per hour for the last 24 hours. The Day log displays the high, low and average values per day for the last seven (7) days. These values can be downloaded to a comma separated variable (.csv) file via the Data History Text Downloads button.

3.2.1.7 Data History Text Downloads

This link helps navigate to the desired data.

F3400 Index of /data

File Name	Type	Point Label
logd1.csv	Daily	BAPI Temperature Signal
logh1.csv	Hour	BAPI Temperature Signal
logm1.csv	Minute	BAPI Temperature Signal
logd2.csv	Daily	BAPI Humidity Signal
logh2.csv	Hour	BAPI Humidity Signal
logm2.csv	Minute	BAPI Humidity Signal
logd3.csv	Daily	
logh3.csv	Hour	
logm3.csv	Minute	
logd4.csv	Daily	Server 2 Temperature
logh4.csv	Hour	Server 2 Temperature
logm4.csv	Minute	Server 2 Temperature
alarmhistory.txt		

[Return to data history menu](#)

Falcon/1.3.0 Server at Port 80

Figure 3.8 Example of the Data History Text Download Page

3.2.1.8 Server History

Technical Support F1000

NH012-120-RTN -06/02/10 16:45:45 F110
NH011-120-On -06/02/10 16:31:43 F110 Offline
NH010-120-RTN -05/19/10 13:26:43 F110
NH009-120-On -05/18/10 10:43:03 F110 Offline
NH008-120-RTN -05/10/10 08:58:43 F110
NH007-120-On -05/10/10 07:47:32 F110 Offline
NH006-120-RTN -05/10/10 07:36:47 F110
NH005-120-On -04/29/10 15:53:31 F110 Offline
NH004-120-RTN -04/09/10 15:06:57 F110
NH003-120-On -04/09/10 14:49:01 F110 Offline
NH002-120-RTN -03/12/10 13:19:54 F110
NH001-120-On -03/12/10 13:10:10 F110 Offline

[Historical Data](#) [Home](#)

Figure 3.9 Example of the Server History Page

Server History displays the past 100 events for all servers, as recorded by the F3400/F1000. The following format is used to record each entry: **NH###-ID-Condition-Date Time Label**

3.2.1.9 Server Status

Sever Room A Fort Collins					
Server Status - 06/15/10 13:13:37					
ID	State	Description	Timeouts	Last Time	Ping Type
1		Server 1	0		None
2		Server 2	0		None
3		Server 3	0		None
4		Server 4	0		None
5		Server 5	0		None
6		Server 6 (P32)	0		None
7		Evolve F110	0		None
8		DataSphere Falcon	0		None
9			0		None
10			0		None

Figure 3.10 Example of the Server Status Page

Server Status displays the current status of each server selected to be monitored. The Status field is color coded. White indicates the relay output is de-energized; red indicates that the relay output is energized; green indicates relay output is in normal status. To setup server(s), refer to 4.17., “Email” on page 58.

3.3. Identity

Sever Room A Fort Collins	
Model Number	F3400/F1000
System Name	Sever Room A Fort Collins
System Up Time	32 days 4 hrs 24 mins 43 secs
System Contact	Technical Support
System Location	Tech Support Lab
Firmware Version	2.2 B07 10/08/09
IP Address	10.0.0.202
MAC Address	00:90:5B:03:01:8C
Current Time	Tuesday 06/15/10 13:14:43

Figure 3.11 Example of the F3400/F1000 Identity Page

Identity displays basic F3400/F1000 information including Model Number, System Name, MAC Address, Firmware Version, and IP Address.

3.4. Web Links




Figure 3.12 Example of the Web Links Display Page

Web links displays still images (.jpg) from all IP cameras and other URLs linked to the F3400/F1000.

3.5. Configuration




Figure 3.13 Configuration Menu

The Configuration link provides access to a series of menus from which qualified users can make adjustments to the F3400/F1000's settings; see Chapter 4, "Configuration Menu" on page 35, for a more detailed explanation.

CONFIGURATION MENU

The Configuration page allows users with administrator or read-write privileges to adjust the F3400/F1000's settings. Each link on the Configuration page displays more information about specific configuration settings.




Figure 4.1 Configuration Menu

4.1. Inputs

Configuration Home

Input: [1](#) [2](#) [3](#) [4](#) [5](#) [6](#) [7](#) [8](#) [9](#) [10](#) [11](#) [12](#) [13](#) [14](#) [15](#) [16](#) [17](#) [18](#) [19](#) [20](#) [21](#) [22](#) [23](#) [24](#) [25](#) [26](#) [27](#) [28](#) [29](#) [30](#) [31](#) [32](#)

Configuration Input #1:

Select Input type: ANALOG 4-20 MA Input Reading: 8.859 mA
 Gain: 35 Calculated Value: 22
 Offset: -55 High Limit2: 110
 Hysteresis: 3 High Limit1: 80
 Unit of Measure: Deg F Low Limit1: -100
 Alarm Delay: 0 Seconds Low Limit2: -200
 Alarm Label: BAPI Temperature Signal
 Normal Label:
 Relay Activate: K1 Fan Switch 1
 K2 Fan Switch 2
 Dial Out Notification: Phone #1 Phone #2
 Phone #3 Phone #4
 Email Recipient Notification: 1 tletcher@rlotech.com 2
 3 4
 Alarm Disable by Schedule: None A B
 BACnet Instance: ai:1 BACnet Units: 0

Figure 4.2 Inputs Configuration Page

Inputs allow users to program specific parameters for each F3400/F1000 input. This model allows different numbers of inputs. Only installed inputs are displayed. Inputs are identified by their name and slot channel number (S.Ch).

This page will be displayed when configuring the F3400/F1000's main board inputs, channels 1-32. The options on this page are described below:

Input Reading: Displays the input current as sensed by the F3400/F1000 and the calculated value based on the offset and gain settings.

Example: A current input of 10.5mA from the temperature sensor would convert to a value of 68.0°F. When the input Type is Digital NO, Digital NC or Digital Status, the Calculated Value will be a 0 or 1, with 1 representing an alarm condition.

Select Input Type: Select based on the type of device connected to the input channel. Options include:

- ◆ **Not Configured** – Select when there is nothing connected to the input.
- ◆ **Analog 4-20mA** – Select when the device connected to the input provides a 4-20mA output.
- ◆ **Digital NO** – Select when the device connected to the input is a dry contact that is normally open and closes on an alarm condition.
- ◆ **Digital NC** – Select when the device connected to the input is a dry contact that is normally closed and open on an alarm condition.
- ◆ **Digital Status** – Select when the device connected to the input is a dry contact that only needs to be monitored (status only), without alarms.
- ◆ **Thermistor** – Select when the device connected to the input provides resistance output.

Gain and Offset: Applies only to Analog 4-20mA input types. Inputs like temperature, humidity, pressure, etc. sensors connected to the F3400/F1000 convert information to a 4-20mA signal. The F3400/F1000 reads this raw 4-20mA signal and calculates a value based on the input and the predetermined gain and offset settings. The idea is to determine the correct gain and offset values so that the F3400/F1000 calculates and displays an accurate reading - one that corresponds closely to the sensor's reading (e.g., if the sensor measures a temperature of 50°F, the F3400/F1000 should display 50°F; if the sensor measures a temperature of 95°F, the F3400/F1000 should display 95°F). If the gain and offset settings are incorrect, the F3400/F1000 will calculate an incorrect value. Since the F3400/F1000's reading will not match the sensor's reading, over the entire sensor range, missed alarms or nuisance alarms could result.

To set gain and offset values, click the **Calculator** link.

4-20ma Gain/Offset Calculator: Input #1	
Current Readings: Raw = 8.858 mA Calc = 22	
Gain:	35
Offset:	-55
Sensor Range High 20ma =	<input type="text" value="120"/>
Sensor Range Low 4ma =	<input type="text" value="-20"/>
<input type="button" value="Calculate"/>	

Figure 4.3 Calculator Link

Enter the sensor's range and press the Calculate button. Click the Return to Input Configuration link and the gain and offset fields will be automatically entered with the correct offset and gain settings. Gain and offset values can also be determined by using the following formulas:

Gain for 4-20mA Transducer = (Sensor High Range Value - Sensor Low Range Value) / 4
Offset for 4-20mA Transducer = Sensor Low Range Value - Gain

Example: Temperature sensor with a sensing range of 50-95°F - displayed in Fahrenheit

$$\text{Gain} = (95-50) / 4 = 11 \text{ (round to the nearest integer)}$$

$$\text{Offset} = 50 - 11 = 39$$

Example: Temperature sensor with a sensing range of 50-95°F - displayed in Celsius

Convert 50-95°F to 10-35°C and use the Celsius range for the calculations

$$\text{Gain} = (35-10) / 4 = 6 \text{ (round to the nearest integer)}$$

$$\text{Offset} = 10 - 6 = 4$$

Example: Humidity sensor with a range of 0 - 100% RH

$$\text{Gain} = (100-0) / 4 = 25$$

$$\text{Offset} = 0 - 25 = -25$$

High Limit 2: Applies only when the input type is Analog 4-20mA. The F3400/F1000 will record an alarm and send notification when the F3400/F1000's calculated value exceeds this limit. The High Limit 1 and High Limit 2 are disabled when they are both set to 0.

High Limit 1: Applies only when the input type is set for Analog 4-20mA. The F3400/F1000 will record an alarm and send notification when the F3400/F1000's calculated value exceeds this limit. The High Limit 1 and High Limit 2 are disabled when they are both set to 0.

Low Limit 1: Applies only when the input type is Analog 4-20mA. The F3400/F1000 will record an alarm and send notification when the F3400/F1000's calculated value falls below this limit. The Low Limit 1 and Low Limit 2 are disabled when they are both set to 0.

Low Limit 2: Applies only when the input type is Analog 4-20mA. The F3400/F1000 will record an alarm and send notification when the F3400/F1000's calculated value falls below this limit. The Low Limit 1 and Low Limit 2 are disabled when they are both set to 0.

Unit Of Measure (UOM): The 10 character field used to assign a unit of measure label to analog values, such as °F, °C, % RH, Amps, Volts, PSI, etc. The unit of measure field is only required when the input type is Analog 4-20mA. The unit of measure field is displayed on the Main Menu and in notification (email/pager messages and SNMP Trap).

Alarm Label: Used for input identification. Applies to all input types except "Not Configured". For Analog input types, this label is displayed on the F3400/F1000 Main Menu and the Input Configuration Menu. When the input alarms and/or returns to normal, the label is included in the Alarm History and notification messages. For Digital NO and Digital NC inputs, the label is displayed on the F3400/F1000 Main Menu, Input Configuration Menu, Alarm History page and in notification messages only when the device is in alarm. For Digital Status inputs, the label is displayed on the F3400/F1000 Main Menu when the input is on. When the input turns on, the label is also included in the Digital Status History.

Normal Label: Applies to input types Digital NO, Digital NC and Digital Status. This field may be left blank. If it is left blank, the F3400/F1000 displays the Label (from above). This label is displayed on the main page when the input is normal, in the Alarm History when the input returns to normal and in notification messages. For Digital Status inputs, the label is displayed on the main page when the input is off. When the input turns off, the label is also included in the Digital Status History.

Alarm Delay: The amount of time the F3400/F1000 waits to send an alert after an alarm condition is detected. The F3400/F1000 uses this same time delay to report a return to normal after the alarm condition clears. The alarm delay is active for all input types except Not Configured.

Example:

An input is configured as a digital NO, labeled “CRAC UNIT ALARM” and has an alarm delay of 10 seconds. When the CRAC unit alarms, it closes the contact to the F3400/F1000. If the CRAC unit returns to normal and opens the contact to the F3400/F1000 within the 10 second alarm delay, no alarm is generated in the F3400/F1000. If the CRAC unit remains in alarm for 10 seconds or more, the F3400/F1000 records the alarm and generates notification per the input settings. If the CRAC unit returns to normal and alarms within the 10 second alarm delay, the F3400/F1000 does not record it as a return to normal. Once the CRAC unit returns to normal for the 10 second alarm delay, the F3400/F1000 records a return to normal and generates notification per the F3400/F1000 settings.

Hysteresis: The number that designates the amount an input reading must sway from its preset alarm reading before it is classified as returned to normal. The Hysteresis provides a deadband around the limit settings to prevent several alarms and return to normal alarms when the input is the same as a limit setting.

The Hysteresis applies when the input type is Analog 4-20mA or thermistor and is active for High Limit 1, High Limit 2, Low Limit 1 and Low Limit 2.

Example:

A temperature sensor alarms when it reaches its High Limit 1 of 80°F. If Hysteresis is set at four, the sensor must register less than 76°F before the F3400/F1000 reports it as returned to normal. In another example, a humidity sensor alarms when it reaches its Low Limit 2 of 30% RH. If the Hysteresis is set at five, the humidity must register more than 35% before the F3400/F1000 reports it as returned to normal.

Relay Activate: Used to assign a Threshold change to analog inputs, or Digital Alarm generated by this input to a specific relay. To select the relay, check the relay box. This feature can be set to activate on a High 2/Low 2 threshold for analog points, in the Relay configuration menu

Dial Out Notification: The list of up to 4 pager numbers to which the F3400/F1000 sends alarm notification. The numbers correspond to phone numbers configured from the Configure Phone Number links at the bottom of the Modem Configuration page. Separate each ID number with a comma. Enter zero to disable. The F3400/F1000 will dial the lowest number listed regardless of the order the numbers are listed. See 4.5.1, “Configure Phone Numbers” on page 44 for more information.

Example:

If the Alarm dial out string is set to “3, 5, 1, 0”, the F3400/F1000 will dial Pager #1, Pager #3 and then Pager #5 when an alarm occurs. Pager notification will be sent when an input alarms (high limit 2, high limit 1, low limit 1, low limit 2 is exceeded or the digital input is in alarm). An option on the Pager Configuration page determines if the F3400/F1000 will send a page when an input returns to normal.


Email Recipient Notification: Allows up to four email addresses to be designated for notification if the input goes into alarm. Email addresses will be displayed once they are entered on the Email Configuration page. Email notification will be sent when an input alarms and when an input returns to normal.

Alarm Disable by Schedule: Used to designate a period of time the input will be disabled or inactive. To do this, select either the A or B schedules, which are defined in the Schedule Configuration menu. Within the scheduled time, the point on the Main Menu will turn Blue to indicate that the input is currently being disabled during its scheduled time. Once the scheduled time has past, the point will reactivate and return to its normal color.

BACnet Instance: The BACnet object identifier. It is a numerical code used to identify the input. This code must be unique within the BACnet device.

BACnet Units: A numerical code used to assign engineering units to this BACnet Instance. Refer to the BACnet standard for further information.

4.2. Relays



← Configuration Home

Relay Configuration: Submit Changes

K1 Label: Fan Switch 1

K2 Label: Fan Switch 2

Analog Level 1 Alarm Relay Activation: Yes No

Figure 4.4 Relays Configuration Page

Relays allow users to identify each relay with custom label.

Analog Level 1 Alarm Relay Activation: This allows the users to select if the relays should activate on a High 2 or Low 2 threshold change. Default is set to “Yes”. The relay output is a common summary output to any alarm present to that channel.

4.3. Schedules

Schedule Configuration:

Schedule A Configuration

Status: Active

Begin DOW: ▼

End DOW: ▼

Begin Time:

End Time:

Schedule B Configuration

Status: Active

Begin DOW: ▼

End DOW: ▼

Begin Time:

End Time:

Figure 4.5 Schedules Configuration Menu

The **Schedules** page allows users to schedule the activation and deactivation of relay outputs. This is useful for cycling redundant equipment such as chillers, generators, etc. Relays are assigned these schedules through the Relay Configuration menus. **Begin DOW** is the day of the week the schedule will begin, and **End DOW** is the day of the week the schedule will end.

Note Press the Submit Changes button when done to save all schedule changes.

4.4. Alarm Management

Alarm Management

Acknowledge Alarms by Code Alarm Acknowledge Code:

Acknowledge All Alarms Enter Your Initials:

Clear Alarm History Enter Your Initials:

Clear Digital Status History

Acknowledge Persistent Traps

Acknowledge Server History Enter Your Initials:

Clear Server History Enter Your Initials:

Figure 4.6 Alarm Management

The **Alarm Management** link allows users to acknowledge current F3400/F1000 alarms and clear the F3400/F1000's Alarm History Logs. Click the button and enter the appropriate code or user's initials to complete the task.

- Note** Press the Submit Changes button after configuration is complete or all access user configuration changes will be lost.
- Note** Alarm Acknowledge Codes are set for individual phone numbers under the Modem Configuration.

4.5. Modem

The **Modem** link allows users to configure the F3400-M/F1000's internal modem (if the option is available). This instructs the F3400-M/F1000-M when, how, and whom to call when an alarm occurs. See definitions below for more information.

The screenshot shows a web-based configuration interface for a modem. At the top left, it says "Modem Configuration:" followed by a "Submit Changes" button. Below this are several configuration fields:

- Initialization String:
- Dial Prefix:
- Pager Deliveries:
- Pager Interval: Minutes
- Pager Baud Rate: 1200 2400
- Pager Resend: Yes No
- Modem Password:
- Redial Attempts:
- Redial Interval: Minutes
- Dial Back on Returns: Yes No
- Force Alarm Acknowledge Code:

At the bottom of the form, there is a link: "Config Phone Number: [1](#) [2](#) [3](#) [4](#)"

Figure 4.7 Modem Configuration Page

Initialization String: A maximum of 38 characters. **&c1 and &d3 are mandatory.** **s0=1** sets the modem to answer after one ring. **s0=0** disables the auto answer and prevents dial-in access.

Dial Prefix: Should be a specific Hayes compatible command or dial modifier depending on pager requirements. It is also limited to 38 characters. The default is set to **atdt**.

Pager Deliveries: Designates the number of times (0-255) the pager is called until the alarm is acknowledged. Pagers are called in sequence. For example, if Pager Deliveries is set to 3 and pagers 1, 7, and 10 are programmed to be notified, the F3400/F1000 dials 1, 7, 10, 1, 7, 10, 1, 7, 10. As soon as the alarm is acknowledged, the F3400/F1000 quits dialing the pagers with that particular access code. Pagers with different access codes are still dialed.

Pager Interval: Determines the number of minutes to wait between redials.

Pager Baud Rate: Allows the user to set the pager communications settings.

Pager Resend: Select yes for the F3400/F1000 to send *all* unacknowledged alarms in the Alarm History Menu. Select **no** to send only the last unacknowledged alarm. If **no** is selected, the F3400/F1000 will auto-acknowledge all alarms associated with that particular pager once a successful page has occurred.

Modem Password: Defines a remote access password, seven characters maximum. Used when remotely logging into the F3400/F1000 through a modem.

Redial Attempts: Determines the number of times (1-255) to call a number until the call is successful. Enter 0 to disable this function.

Redial Interval: Establishes the number of minutes (1-255) to wait between redials. Enter 0 to disable this function.

Dial Back on Returns: Determines whether to call the number again once the alarm condition returns to normal.

Force Alarm Acknowledge Code: Establishes a code that acknowledges all unacknowledged alarms. This acts as a master code and can override all other alarm acknowledge codes.

4.5.1 Configure Phone Numbers

Phone Number 1 Configuration

Select Phone type:

Number:

Pager Id:

Acknowledge Code:

Config Phone Number: [1](#) [2](#) [3](#) [4](#)

Figure 4.8 Phone Number Configuration Page

This page is accessed through the **Config Phone Number** link at the bottom of the Modem Configuration page. This screen allows users to configure pager and cell phone numbers that are used for alarm notification.

Select Phone Type: Determines which type of device the F3400/F1000 calls. Select the **Text** option to dial a PC receiving ASCII strings. Select **Numeric Pager** to dial a numeric pager. Select the **Alpha-numeric Pager** option to dial an alpha-numeric pager.

Number: Enter the pager service number for numeric and alphanumeric pager entries. Each comma after the pager number represents a two second delay. This delay is used to allow enough time for the pager service to answer before requesting the pager ID. Typically only one comma is needed. However, experimentation with the proper number of commas may be necessary. In some cases, a 9 must be entered to access an outside line.

Pager ID: Mandatory for numeric and alphanumeric pagers.

- ◆ **Alphanumeric pager** – The ID entered is sent to the paging service along with all queued alarm messages. The ID is the unique PIN for a specific pager. The ID may be a maximum of 16 characters.
- ◆ **Numeric pager** – The ID entered may be configured to deliver different numeric messages. The ID can contain 15 characters: any combination of the numerals 0 through 9 and a * or #. These are the only characters that will be transmitted to the paging service.
 - **Y** – Binary Alarm Condition: 1=on, 0=return to normal (RTN)
 - **ZZZ** – Alarm ID Number; see Appendix C, “Alarm ID Reference Tables” on page 87.

Example: A **1001** message is an Input 1, High Limit 1 Alarm. A 0093 message means that Digital Input #13 has returned to normal.

Note When using the \$, if multiple unacknowledged alarms are present in the Alarm History Log, the alarm code will be 99999.

An effective numeric page depends largely on the parameters established by the paging service. Experimentation may be required to achieve desired results.

Acknowledgement Code: Any number, up to six digits, used to acknowledge receipt of an alarm and to terminate any additional call outs for this phone number. This code will acknowledge only those alarms sent to this phone number. It can be acknowledged by selecting the Acknowledge Alarms button on the bottom of the Alarm History page.

Multiple phone numbers can use the same acknowledge code. This allows one user to acknowledge alarms sent to multiple pager numbers.

Note Changes will not go into effect until the Submit Changes button is clicked.

4.6. Web Links

Web Link Configuration:

Web Link #1 JPG URL:

Web Link #1 Home URL:

Web Link #1 Link Text:

Web Link #2 JPG URL:

Web Link #2 Home URL:

Web Link #2 Link Text:

Web Link #3 JPG URL:

Web Link #3 Home URL:

Web Link #3 Link Text:

Web Link #4 JPG URL:

Web Link #4 Home URL:

Web Link #4 Link Text:

Web Link #5 JPG URL:

Web Link #5 Home URL:

Web Link #5 Link Text:

Main WebCam Image Size: 320x240 640x480

Figure 4.9 Configuring Web Links

The Main Menu of the F3400/F1000's Web interface displays a large image and links to other images. These images can be graphics, logos or images from an IP camera. The **Web link** page allows users to specify which images and URLs will be available on the F3400/F1000's Main Menu.

For Axis207 Web Cameras set the URL link to the following:

- ◆ URL Link #x Image: <http://xxx.xxx.xxx.xxx/jpg/image.jpg>
- ◆ URL Link #x Home: <http://xxx.xxx.xxx.xxx>
- ◆ URL Link #x Label: Enter the Camera's Label

For Panasonic KX-HCM10A Web Cameras set the URL link to the following:

- ◆ URL Link #x Image:
<http://xxx.xxx.xxx.xxx/snapshotjpeg?resolution=320x240&quality=standard>
- ◆ URL Link #x Home:
<http://xxx.xxx.xxx.xxx/ImageViewer?Mode=Motion&resolution=320x240&quality=standard>
- ◆ URL Link #x Label: Enter the Camera's Label

Main WebCam Image Size: Designates the size of the image on the F3400/F1000 main page of 320x240 or 640x480.

4.7. Egg/Nest

Falcon Egg Cfg:

Egg Login:

Egg Alternate IP Address: (0.0.0.0 = Use lan IP address)

Figure 4.10 Egg/Nest Configuration Page

Setting the **Egg Login** as **Referred – Nologin** allows the F3400/F1000 nest unit to access the F3400/F1000 egg without a password. If password protection is desired, select **Always login**. The **Egg Alternate IP Address** is completed with the egg's internet/public IP address when the F3400/F1000 is behind a firewall or NAT (Network Address Translation). A NAT enables the local-area network (LAN) to use one set of IP addresses for internal traffic and a second set of addresses for external traffic.

4.8. Falcon Links

Links Configuration:

Link 1 Ip Address:

Link 2 Ip Address:

Link 3 Ip Address:

Link 4 Ip Address:

Figure 4.11 Falcon Links Configuration Page

The Main Menu allows users to link to up to four other F3400/F1000 units. The **F3400/F1000 Links** page allows users to designate the IP Addresses of these additional F3400/F1000 units.

Note Changes will not go into effect until the Submit Changes button is clicked.

4.9. SNMP/SYSLOG

SNMP/Syslog Configuration:

Persistent V1,V2C-Traps: Minutes

Analog Trap Type: Value/UOM/Label Label Only

Select Snmp Trap Type:

Max Inform Retries: (0 = unlimited, 1-99)

Communities

1 IP Address:	<input type="text" value="0.0.0.0"/>	String:	<input type="text" value="public"/>	Write:	<input type="checkbox"/> Trap:	<input type="checkbox"/> Syslog:	<input type="checkbox"/>
2 IP Address:	<input type="text" value="10.0.0.76"/>	String:	<input type="text" value="rletech"/>	Write:	<input checked="" type="checkbox"/> Trap:	<input checked="" type="checkbox"/> Syslog:	<input type="checkbox"/>
3 IP Address:	<input type="text" value="10.0.0.146"/>	String:	<input type="text" value="public"/>	Write:	<input type="checkbox"/> Trap:	<input type="checkbox"/> Syslog:	<input type="checkbox"/>
4 IP Address:	<input type="text" value="10.0.0.130"/>	String:	<input type="text" value="public"/>	Write:	<input type="checkbox"/> Trap:	<input type="checkbox"/> Syslog:	<input type="checkbox"/>
5 IP Address:	<input type="text" value="10.0.0.82"/>	String:	<input type="text" value="public"/>	Write:	<input checked="" type="checkbox"/> Trap:	<input type="checkbox"/> Syslog:	<input type="checkbox"/>
6 IP Address:	<input type="text" value="10.0.0.5"/>	String:	<input type="text" value="public"/>	Write:	<input type="checkbox"/> Trap:	<input checked="" type="checkbox"/> Syslog:	<input type="checkbox"/>
7 IP Address:	<input type="text" value="10.0.0.168"/>	String:	<input type="text" value="public"/>	Write:	<input type="checkbox"/> Trap:	<input checked="" type="checkbox"/> Syslog:	<input type="checkbox"/>
8 IP Address:	<input type="text" value="empty"/>	String:	<input type="text"/>	Write:	<input type="checkbox"/> Trap:	<input type="checkbox"/> Syslog:	<input type="checkbox"/>

Figure 4.12 SNMP/SYSLOG Configuration Page

Persistent V1,V2C-Traps: Enables the F3400/F1000 to issue continuous SNMP Traps until an alarm acknowledgement is received by the F3400/F1000 or until the alarming point returns to normal. The parameter is a user defined time interval that is set in minutes. Traps can be acknowledged from the Alarm Management page. The SNMP Traps do not include any delivery verification. A Persistent Trap setting of 5 or 10 minutes will trigger the F3400/F1000 to send the Trap on a regular interval in case the previous Trap did not reach the Network Management System (NMS). Typically, the NMS can be set to ignore duplicate Traps to prevent re-alarms at the NMS.

Analog Trap Type: Used for communication to a NMS via SNMP Traps. The default will add the Value, UOM (Unit of Measure), and the Label fields. If preferred, the F3400/F1000 can send only the label on analog Traps. This makes analog Traps the same format as digital Traps which may make parsing the Traps easier for the NMS.

Select SNMP Trap Type: Select SNMP V1-Trap, V2C-Trap, or V2C Inform based on individual network system configurations.

Max Inform Retries: Set options related to resending unacknowledged inform requests.

Communities: Identifies devices that receive SNMP Traps and/or Syslog messages from the F3400/F1000 and interacts with the F3400/F1000 over the network. To add a device to the Communities list, select a community number posted as “empty”. Enter the receiving device’s IP Address and a string that identifies the device. An IP Address of 0.0.0.0 in this field allows any device to access the F3400/F1000 through an MIB browser. Select “Write” if the device will have Read/Write network access. This allows the F3400/F1000 to be configured over the network. Select “Traps” if the device will receive Traps from the F3400/F1000. Select “Syslog” if the device will receive Syslog messages from the F3400/F1000.

Note Refer to the “MIB Files Information” document located in the F-Series webpage of our website (www.rletech.com) for more information on the SNMP Trap format and MIB files.

4.10. Modbus Interface

EIA-485/Modbus Interface/Comm Port:

EIA-485 Port: Modbus/RTU GPRS/SMS Modem (4-wire only)

Modbus/TCP Slave Unit Identifier: (1-254, 0 = disabled)

Modbus/RTU RS-485 Slave Unit Identifier: (1-254, 0 = disabled)

Note: To use the RS-485 port as a master, set the RS-485 Slave Unit Identifier to 0

Serial Baud Rate: 1200 2400 9600

EIA-485 DE TX Delay: (10 - 50) mS

EIA-485 DE Off Delay: (0 - 50) mS

Master Poll Timeout: (1 - 10) Seconds

Master Poll Interval: (250 - 2000) mS

Master Retry Attempts: (1 - 99)

LD Unit #1 Type: [LD Unit 1 Config](#)

LD Unit #2 Type: [LD Unit 2 Config](#)

LD Unit #3 Type: [LD Unit 3 Config](#)

LD Unit #4 Type: [LD Unit 4 Config](#)

LD Unit #5 Type: [LD Unit 5 Config](#)

LD Unit #6 Type: [LD Unit 6 Config](#)

LD Unit #7 Type: [LD Unit 7 Config](#)

LD Unit #8 Type: [LD Unit 8 Config](#)

[Modbus Slave Register Display Log](#)

[Modbus Master Register Data Log](#)

[Modbus Packet Log](#)

[Reset Modbus Port](#)

Figure 4.13 Modbus Interface Configuration

The **Modbus Interface** page allows users to configure Modbus features for RLE products and enable Modbus slave capabilities for the unit.

Modbus/TCP Slave Unit Identifier: Enables and sets the slave unit address for Modbus over TCP/IP.

Modbus/RTU EIA-485 Slave Unit Identifier: Enables and sets the slave unit address for Modbus over EIA-485, twisted-pair wire. Disabling the slave unit identifier for RTU will enable the unit to act as a master over EIA-485, twisted-pair wire.

Serial Baud Rate: Sets the EIA-485 COM2 port to 1200, 2400 or 9600 Baud.

EIA-485 DE TX Delay: Normally left at the 10ms default and is active only when the Serial Interface Type is “EIA485”. During the start of transmission, the transmit line is driven high for this amount of time prior to transmitting the message. The time is adjustable from 10ms to 50ms.

EIA-485 DE Off Delay: Normally left at the default of 10ms and is active only when the Serial Interface Type is “EIA485”. After a message is sent, the transmit line is held high for this amount of time prior to turning off. The time is adjustable from 10 to 500ms.

Modbus Master Poll Timeout: Sets the amount of time the F3400/F1000 waits for a response from the Slave device before moving on to read the next register. It is normally set to the default of 1. It is adjustable from 1 to 10 seconds.

Modbus Master Poll Interval: Sets the amount of time from when a response is received from a Slave to when the F3400/F1000 will ask for the next register and is adjustable from 250 to 2000ms. It is normally left at the 250ms default. The interval affects the overall scan rate. If the F3400/F1000 is configured to read 60 Modbus variables and the poll interval is set to 1000ms (1second), each Modbus variable will be read approximately once per minute.

Modbus Master Retry Attempts: Determines how many times the F3400/F1000 will request the same register when there is no response from the Slave before moving on to read the next register. It is normally left at the default of 1 second and is adjustable from 1 to 99.

LD Unit #1 Type - Unit #8: Select LD5000/LD5100/LD2000, LDRA6, or not installed.

4.10.1 LD Unit Modbus Slave Configuration

Modbus Slave #1 Cfg:

Slave/RTU Station Address: (1-254, 0 = disabled)

Description:

Input #1 Label:

Input #2 Label:

Input #3 Label:

Input #4 Label:

Input #5 Label:

Input #6 Label:

Dial Out Notification: Phone #1 Phone #2
 Phone #3 Phone #4

Email Recipient Notification: 1 2
 3 4

Figure 4.14 LD Unit Modbus Slave Configuration

RTU Station Address: Enter the address of the Modbus Slave device. Be sure this matches the address programmed on the particular Slave device.

Description: Enter a description for the Slave device.

Dial Out Notification: Select the Phone Number Configuration Entry ID for up to four pager numbers to which the F3400/F1000 will send notification when any alarm for this Slave occurs. The Entry ID numbers correspond to phone numbers configured from the Configure Phone Number links at the bottom of the Modem Configuration page.

Example: If the Alarm dial out string is set to “3, 5, 1, 0”, the F3400/F1000 will dial Pager #1, Pager #3 and then Pager #5 when an alarm occurs.

Email Recipient Notification: Select the recipient email addresses that require notification when any alarm occurs on this Slave. The email addresses correspond to the email addresses configured from the Email Configuration page.

4.10.2 Modbus Register Data Log

This link allows users to view the raw data the F3400/F1000 receives from the Slave(s).

Column 1= F3400/F1000 Modbus Master Register Number.

Column 2= Time the Data is Received.

Column 3= Number of Bytes Reserved for Data.

Column 4= Slave Data in Decimal Form.

Modbus Data Display			
1	13:51:34	2	0
2	13:51:34	2	0
3	13:51:35	2	1
4	13:51:35	2	0
5	13:51:36	2	3
6	13:51:36	2	15
7	13:51:37	2	10
8	13:51:37	2	2836
9	13:51:38	2	3

Figure 4.15 Modbus Register Data Log Page

4.10.3 Modbus Packet Log

This link displays a log of the Modbus packets that the F3400/F1000 is sending and receiving.

Modbus Packet Log			
0278215487	M0005	timeout	
0278215500	M0006	Out:	02 04 00 06 00 01 D1 F8
0278215800	M0006	timeout	
0278215812	M0007	Out:	02 04 00 07 00 01 80 38
0278216112	M0007	timeout	
0278216142	M0008	Out:	02 04 00 08 00 01 B0 3B
0278216425	M0008	timeout	
0278216438	M0000	Out:	02 04 00 00 00 01 31 F9
0278216737	M0000	timeout	
0278216750	M0001	Out:	02 04 00 01 00 01 60 39
0278217050	M0001	timeout	
0278217062	M0002	Out:	02 04 00 02 00 01 90 39
0278217362	M0002	timeout	
0278217375	M0003	Out:	02 04 00 03 00 01 C1 F9
0278217675	M0003	timeout	
0278217687	M0004	Out:	02 04 00 04 00 01 70 38
0278217987	M0004	timeout	
0278218000	M0005	Out:	02 04 00 05 00 01 21 F8
0278218300	M0005	timeout	

Figure 4.16 Modbus Packet Log

Column 1 = System Up Time.

Column 2 = Modbus Master Register Number.

Column 3 = Direction of Packet: OUT = Packet Sent from the F3400/F1000 (Master Request).

Column 4 = Modbus Packet.

4.10.4 Reset Modbus Port

This link allows users to reset the Modbus port so that the contents of the polling registers will be cleared.

4.10.5 F-Series Modbus Slave Register Map

Table 4.1 Output Registers

Register	Description	Range
40001-40032	Input #1-32 Value	0-65535
40033-40187	<i>Reserved</i>	
40188-40193	MAC Address	0-65535
40194-40197	IP Address	0-65535
40198	Model No.	0-65535
40199	Firmware Version	0-65535
40200	Number of Alarms Present	0-65535
40201-40232	Input #1-32 Alarm Bitmap	See Table 4.2
40233-40400	<i>Reserved</i>	
40401-40432	Input #1-32 Configuration	See Table 4.3

Table 4.2 Status Flags (Registers 40201-40232)

Bit	Description
00	1 = High1 Alarm
01	1 = Low1 Alarm
02	1 = High2 Alarm
03	1 = Low2 Alarm
04	1 = Digital Alarm

Table 4.3 Status Flags (Registers 40401-40432)

Integer	Description
0	Not Installed
1	Not Configured

Table 4.3 Status Flags (Registers 40401-40432) (continued)

Integer	Description
2	Analog 4-20mA
3	Digital NO
4	Digital NC
5	Digital Status
4-9	<i>Reserved</i>
10	Thermistor

4.11. BACnet

Bacnet Configuration:

BACnet Device Name:

BACnet Device ID:

BACnet Description:

Bacnet UDP Port: (0 = 47808)

Bacnet BBMD-BDT:

Falcon IP Address: 10.0.0.202.0 Mask: 32 (FFFFFFFF)

(Primary) #1 IP Address: Port: Mask: (1-32) 00000000

#2 IP Address: Port: Mask: (1-32) 00000000

#3 IP Address: Port: Mask: (1-32) 00000000

#4 IP Address: Port: Mask: (1-32) 00000000

Property Identifiers Supported

BACnet_Present_Value	BACnet_Object_Identifier	BACnet_Object_Name
BACnet_Object_Type	BACnet_Out_Of_Service	BACnet_Units
BACnet_Event_State	BACnet_Status_Flags	BACnet_Time_Delay

Bacnet Device Objects

BACnet_Object_Identifier	BACnet_Object_Name	BACnet_Object_Type
BACnet_System_Sstatus	BACnet_Vendor_Name	BACnet_Vendor_Id
BACnet_Model_Name	BACnet_Firmware_Revision	BACnet_App_Software_Revision
BACnet_Location	BACnet_Description	BACnet_Protocol_Version
BACnet_Conformance_Class	BACnet_Services_Supported	BACnet_Object_Types_Supported
BACnet_Object_List	BACnet_Max_APDU	BACnet_Segment_Supported
BACnet_Segment_Timeout	BACnet_APDU_Timeout	BACnet_APDU_Retries
BACnet_Bindings		

[Bacnet Packet Log](#)

Figure 4.17 BACnet Configuration

BACnet Device Name, BACnet Device ID and BACnet Description, BACnet UDP Port: Required for the F3400/F1000 to allow a Building Management System (BMS) to poll the F3400/F1000's inputs using the BACnet protocol over LAN connections. For further information regarding BACnet Device Name, BACnet Device ID and BACnet Description, consult the BACnet Standard or your IT Department.

4.12. Server Ping

Server Ping Configuration:		<input type="button" value="Submit Changes"/>	
Label	IP Address	Ping Enable	
Server 1	10.0.0.2	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Server 2	10.0.2.200	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Server 3	10.0.2.201	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Server 4	10.0.2.202	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Server 5	10.0.2.207	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Server 6 (P32)	10.0.2.209	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
Evolve F110	10.0.0.211	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
DataSphere Falcon	10.0.0.184	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP
	0.0.0.0	<input checked="" type="radio"/> None	<input type="radio"/> ICMP

Ping Interval: (Minutes) Ping Retries:

Dial Out Notification:
 Phone #1
 Phone #2
 Phone #3
 Phone #4

Email Recipient Notification:
 1 tlfletcher@rlotech.com
 2
 3
 4

Figure 4.18 Server Ping Configuration

The **Server Ping** page allows a user to monitor up to 16 devices by pinging at set intervals.

Ping Interval (Minutes): The time in minutes the F3400/F1000 will take to request time updates from the selected device(s). This can be set from 1-999. Enter 0 to disable.

Ping Retries: The amount of tries to establish communication with a device before entering an alarm state.

Dial Out Notification: The list of up to four pager numbers to which the F3400/F1000 sends alarm notification. The numbers correspond to phone numbers configured from the Configure Phone Number links at the bottom of the Modem Configuration page.

Email Recipient Notification: Allow up to four email addresses to be designated for notification if the input goes into alarm. Email addresses will be displayed once they are entered on the Email Configuration page. Email notification will be sent when a device alarms and when the device returns to normal.

4.13. System

The screenshot shows a web-based configuration interface for a system. At the top left, it says "System Configuration" with a "Submit Changes" button to its right. Below this, the IP Address is displayed as "10.0.0.201". The System Name field contains "Technical Support F1000". The System Contact field contains "Techncial Support Department". The System Location field contains "Technical Support Office". The Web Refresh Rate is set to "25" with the unit "Seconds". The TFTP Server Enable (udp port 69) option has the "Yes" radio button selected. The TCP Max Seg Size option has the "1436" radio button selected. The Digital Status Color is set to "Magenta" via a dropdown menu.

Figure 4.19 System Configuration

The **System** link allows users to configure basic F3400/F1000 information. The F3400/F1000's IP Address and Point-to-Point Protocol may also be configured through this menu, via the IP Configuration Menu link.

System Name: Appears on the F3400/F1000's Main Menu. The system name is also included as part of email and pager notifications.

System Contact: Lists the individual responsible for the F3400/F1000. The System Contact is only available through SNMP Gets and is not included in email, pager or SNMP Trap notifications.

System Location: Lists the location of the F3400/F1000. It is used to help identify the F3400/F1000 when viewing the webpages. The System Location is not included in email, pager or SNMP Trap notifications.


Web Refresh Rate: The rate at which the F3400/F1000's webpages refresh themselves within the Web browser. Only pages that display monitoring points are automatically refreshed (Main Menu, Relay Status, View Points, and Modbus Slave pages). The default is 0 seconds (disabled), but is typically set for 15 to 20 seconds.

TFTP Server Enable (udp port: 69): This setting opens or closes Port 69 on the LAN connection to the F3400/F1000. The TFTP port is used to upgrade firmware and save and load configurations. It can be disabled for security reasons and only opened for short periods of time during firmware upgrades; see Chapter 8, "Upgrading Firmware and Managing Configuration Data" on page 73, for more information.

Digital Status Color: Allows you to choose the color (green, gold, magenta) displayed on the main menu.

Note Changes will not go into effect until the Submit Changes button is clicked.

4.14. Clock



Clock Configuration:

Date:

Time:

Day: Tuesday


Figure 4.20 Clock Configuration

The **Clock** page allows users to set the date and time on the F3400/F1000's internal clock.

- ◆ Enter the date using a MM/DD/YY format, where MM is a two digit month, DD is a two digit day, and YY is a two digit year.
- ◆ Enter the time using a HH:MM:SS format, where HH is a two digit hour, MM is a two digit minute, and SS is a two digit second.

Note Press the Submit Changes button when done to save all changes.

4.15. Internet Protocol



Warning: Changing these parameters will cause the network interface to operate differently, only change parameters if you are sure the changes are correct.

IP Configuration:

MAC Address: 00:90:5B:02:05:4B

IP Address:

Net Mask:

DefRoute:

PPP Server:

PPP Assignment:

Figure 4.21 Setting the Internet Protocol

The **IP Configuration** link found on the System Configuration page allows users to change a variety of settings, including the F3400/F1000's IP Address (used in PPP), Default Router and Subnet Mask. Contact a network administrator to obtain a valid IP Address for the network. Then, type the appropriate IP Address, Subnet Mask, and Default Router into the interface.

PPP Server: Sets the IP Address of the F3400/F1000's network connection when accessing the F3400/F1000 via its internal modem. This is required to allow a remote PC to view the F3400/F1000's webpages over a dial-up connection. See Chapter 7, "Point-to-Point Protocol" on page 71, for more information.

PPP Assignment: Sets the IP Address of the remote PC's network connection when accessing the F3400/F1000 via its internal modem. This is required to allow a remote PC to view the

F3400/F1000's webpages over a dial-up connection. The remote PC's dial-up settings should be set to "Obtain an IP Address Automatically".

Note Changes will not go into effect until the Submit Changes button is clicked.

4.16. User Administration (Web Access)

Web User Configuration		Submit Changes		
#	User Name:	Password:	Privilege:	Last Web Access:
1	falcon		Administrator	06/15/10 14:04:17
2			None	
3			None	
4			None	
5			None	
6			None	
7			None	
8			None	

Figure 4.22 User Administration Configuration

The **User Administration (Web Access)** page allows the administrator to configure eight separate accounts, usernames, passwords and privileges for Web access accounts.

- ◆ **Read-Only** privileges allow the user to view the Main Menu page, Keypad Access History, Alarm History, Event History, Digital Data History, Identity, Relay Status, Relay Control and URL Links pages. The Configuration page cannot be viewed or changed by a Read-Only user. A Read-Only user can acknowledge alarms by entering their acknowledge code at the bottom of the Alarm History page. A Read-Only user can activate button controlled relay outputs through the Relay Control page. A Read-Only user cannot change any settings.
- ◆ **Read-Write** privileges allow the user to have full access to all pages (viewing and changing) except the User Administration (Web Access) page shown above.
- ◆ **Administrator** privileges allow the user to have full access to all pages including the User Administration (Web Access) page shown above.

Note Changes will not go into effect until the Submit Changes button is clicked.

4.17. Email

E-Mail Configuration:

Access Type: None LAN PPP

Primary DNS Server: 10 0 0 .10

Secondary DNS Server: 0 0 0 .0

Mail (SMTP) Server: smtp.bizmail.yahoo.com

Mail Sender Address: fletcher@rletech.com

Mail Subject: Falcon F3400 Alarm

Mail Recipient (1): fletcher@rletech.com

Mail Recipient (2):

Mail Recipient (3):

Mail Recipient (4):

SmtP Authentication: None Plain Login (Do not enable this unless instructed by your ISP or IT dept!)

SmtP Username: fletcher@rletech.com SmtP Password:

DUN User Name:

DUN Password:

Alarm History Entries: 67 / Emails sent: 0 / Emails unsent: 0
 Server History Entries: 12 / Emails sent: 0 / Emails unsent: 0

Mail Server DNS address logged for: "smtp.bizmail.yahoo.com" 206.190.48.12
 Mail Server Dns TTL: 56
 Ntp Server DNS address logged for: "india.colorado.edu" 0.0.0.0
 Ntp Server Dns TTL: 0

[View SmtP Log](#)

Figure 4.23 Email Configuration

The **Email** page allows users to configure the F3400/F1000 to send notification via email when inputs are in an alarm state. The F3400/F1000 will send one email message per alarm instance to a maximum of four email recipients.

Access Type: Specifies whether to send the message through a local network or over a PPP dial-up connection.

DNS Servers: Information provided by your ISP needed to deliver the email message.

Mail (SMTP) Server: Specifies the email server used to receive and send mail.

Mail Sender Address: The address displayed in the “From” field of the email message.

Mail Subject: Displayed in the subject field of the received email messages. Adding &m inserts the MAC Address of the F3400/F1000 into the email subject line. This ensures the email subject is always unique to a F3400/F1000.

Mail Recipient (1) - Mail Recipient (4): Enter the addresses of up to four email recipients.

SMTP Authentication: Used for ESMTP; use the recommended default setting unless instructed differently by your IT Department.

SMTP User Name: Used for ESMTP; use the recommended default setting unless instructed differently by your IT Department.


SMTP Password: Used for ESMTP; use the recommended default setting unless instructed differently by your IT Department.

DUN User Name and Password: Only used if PPP is selected. The DUN Username and password specifies the dial-up network user name and password. Contact your ISP for this information.

DUN Phone Number: The number the F3400/F1000 dials to connect to the ISP. Contact your IT Department to obtain this phone number.

Note When the information is complete, click Submit Changes for the changes to take effect.

4.18. Network Time Protocol



Network Time Protocol (NTP) Configuration:

Network Time (NTP) Server: (IP address or hostname)

Update Interval: (5-1440 Minutes - 0 for disabled)

Retry Interval: (10-120 Seconds)

Select Time Zone:

Daylight Savings Time:

DST Begin Date:

DST End Date:

Mail Server DNS address logged for: "smtp.bizmail.yahoo.com" 206.190.48.12
 Mail Server Dns TTL: 2
 Ntp Server DNS address logged for: "india.colorado.edu" 0.0.0.0
 Ntp Server Dns TTL: 0
 sysUpTime: 278365712
 NextNtpRetry: 0
 LastNtpRequestTime: 0
 NextNtpRequestTime: 0
 LastTransmitTimestamp: 00000000
 Last Ntp Update: ST (UTC 0)

Figure 4.24 Network Time Protocol Configuration

Network Time Protocol (NTP) is widely used in the Internet to synchronize computer clocks to national standard time or Coordinated Universal Time (UTC). It synchronizes the time of a computer or server (in this case, the F3400/F1000) to another server or reference time source. NTP is important in maintaining a high level of accuracy and reliability in time-stamped events. This page allows users to configure the F3400/F1000's NTP feature.

Network Time (NTP) Server: The IP address or hostname of the Network Time Protocol Server with which the F3400/F1000 will synchronize. Examples of public NTP Servers include "us.pool.ntp.org" and "time.nist.gov".

Update Interval: The time in minutes the F3400/F1000 will take to request time updates from the NTP Server. This can be set from 5-1440 minutes. Enter 0 to disable.

Retry Interval: The time in seconds the F3400/F1000 waits before retrying a failed connection to the NTP Server. This can be set from 10-120 seconds.

Select Time Zone: Enter the time zone in which the F3400/F1000 resides.

Daylight Savings Time: Select the hour Daylight Savings Time occurs. Typically, this is 2:00 A.M. local time.

DST Begin Date: Enter the date Daylight Savings Time will begin.

DST End Date: Enter the date Daylight Savings Time will end.

4.19. Network Statistics

```

Ethernet Port - CS8900:
Stats Last Reset At: 06/16/10 08:57:37 (auto)
 29931 ints          29931 pkts rcvd          0 refused
   0 missed          0 rxlenerror
14006 pkts sent      0 colls              0 txlenerror      0 tx timeout
 2064 arppackets     0 arpdropped         0 nonipdrop
27867 ippackets      0 ipbcdrop            0 ipnotforme

```

[Refresh netstats page](#)

[Reset netstats](#)

Figure 4.25 Setting the Network Statistics

The **Network Statistics** page displays network and EIA485 statistics including: network packets received, packets transmitted, and errors.

4.20. Flash Program

```

Flash Program Configuration

Flash #2 Program: F3400 V2.2 B07 10/08/09 Checksum: 1101 Serial #: 0008 (active)
Flash #1 Program: F3400 V2.1 B16 02/11/08 Checksum: 526C Serial #: 0007 (backup)

```

Note: This version supports program updates via FTP & TFTP.

Figure 4.26 Flash Programs

The **Flash Program** link displays which versions of F3400/F1000 firmware are loaded onto the F3400/F1000. Only two copies can be loaded onto the F3400/F1000 at a time. In order to upload a Firmware update, the backup Flash must be blank. If it is not, click the **Erase Backup** button to erase it. This erases the oldest version of firmware stored on the F3400/F1000. See Chapter 8, “Upgrading Firmware and Managing Configuration Data” on page 73.

Using a TFTP client software program, send the F3400 (vx.x bx).bin file to the IP address of the F3400/F1000. The F3400/F1000 verifies the file name starts with **F3400** and ends with **.bin**. Other file names or types will not be accepted. The F3400/F1000 will accept TFTP block sizes of 64, 128, 256, 512, or 1024. Once the program has been successfully uploaded, the F3400/

F1000 will automatically reboot. See Chapter 8, “Upgrading Firmware and Managing Configuration Data” on page 73, for more detailed instructions.

4.21. Product Registration

Our Company | **Products** | **Purchase** | **Case Studies** | **RLE Partners** | **Support**

Navigation Guide

- Our Company
- Products
- Purchase
- Case Studies
- RLE Partners
- Support
 - Tech Support Form
 - Product Registration**
 - Discontinued

Product Registration Form

Any information provided through the registration form will be regarded as confidential. See our [Privacy Policy](#) for more information. Required fields are marked with an asterisk.

*Company Name

*Contact First Name

*Contact Last Name

*Address line 1

Address line 2

*City

*State

*Zip Code

Country

*Phone Number

*E-mail

*Serial Number(s)

Enter multiple Serial #'s separated by commas.

*Purchased From

*Date Of Purchase

*Installed By

Installer's Phone

Installer's Email

Address

RLE Technologies
104 Racquette Dr
Fort Collins, CO 80524

Phone Contact

1-800-518-1519
(970) 484-6510
Fax: (970) 484-6550

E-Mail

Sales: sales@rletech.com
Support: support@rletech.com

Business Hours

Monday - Friday
8:00am - 5:00pm MST

Maps to RLE

[Google Map](#)
[Map from DIA & Accommodations](#)

Figure 4.27 Product Registration Located at www.rletech.com

The **Product Registration** link allows users to register their F3400/F1000 with RLE at the time of configuration. The F3400/F1000's IP Address, Subnet Masks, and Default Gateway must be configured before this link will be operational. Once configured, complete the registration form, and click the Register button to submit your information to RLE.

Notes:

EIA-232 INTERFACE

The F3400/F1000's EIA-232 interface provides a more detailed and intricate view of the F3400/F1000. It also allows a user to access more elaborate configuration options.

In order to proceed through this chapter, the F3400/F1000 must be connected to a PC via the EIA232 port. If the F3400/F1000 is not yet connected to a PC, connect the F3400/F1000's EIA232 COM1 port as follows:

- 1 Connect the EIA232 port on the F3400/F1000 to a terminal or PC running terminal emulation software (HyperTerminal) with a 9-pin male-female straight through serial cable (a serial cable is supplied with the F3400/F1000).



Figure 5.1 HyperTerminal Connection Screen

- 2 Set the appropriate COM Port to **9600 baud, NO parity, 8 data bits, 1 stop bit, (9600/N/8/1), and no software or hardware flow control.**




Figure 5.2 Com1 Properties Screen

- 3 Once the terminal emulation software starts, press Enter on the keyboard and the Main Menu should appear. If the Main Menu does not appear, check the communication settings and make sure the unit is powered on.

5.1. Unit Start Up

When the unit is powered up, diagnostic tests are performed and the Flash Program code is verified. The main system code is executed after a 10 second delay. During the boot up sequence, the System Status LED will flash at a rapid rate of 10 flashes per second. If the System Status LED continues to flash for more than twenty seconds, there is a fault with the unit and service is required.

5.2. Flash Executable Code

After the bootup sequence, the main program executes from Flash memory. In order to run properly, the unit must have a unique MAC address (assigned by the manufacturer) and an IP address. The factory default for the IP address is 10.0.0.186. If the unit is connected to the enterprise's network, an IP address must be obtained from the network administrator. The F3400/F1000 must be reconfigured with this new IP address. This reconfiguration can be done in the field. See the Configuration Menu, menu number 1. Once the system reaches this point, press Enter to display the System Main Menu.

5.3. Main Menu

All system functions begin in the Main Menu. Two letter commands display information, execute commands and display submenus for additional inquiry and system configuration functions.

Table 5.1 Main Menu Commands

Command	Description	Function
CA	Current Alarms	CA displays all active alarms on the master unit. If alarms are present, the System Status LED is red.
KA	Kill Alarms	KA acknowledges all alarms and terminates all dial-out communications and network Traps.
TI	Display Date/Time	TI displays the F3400/F1000's current time and date.
AD	ADC Input Values	AD allows the user to examine the readings of the 4-20mA inputs. These readings can be referenced during start-up to verify gain and offset calculations. Data displayed depends on the expansion card(s) installed.
MS	Modem Statistics	MS provides a summary of all modem information.
NS	Network Statistics	NS displays network and EIA485 statistics including: network packets received, packets transmitted, and errors.
SC	Main Configuration	SC displays a submenu that lists all items for system setup and configuration.
DU	Dump Network Packets	DU dumps the headers of all network packets received and sent. Only active until the next command is entered. This item is for network debugging only and is not normally enabled.
NT	Network Trace	NT displays troubleshooting messages during the processing of network packets. Only active until the next command is entered. Network Trace is for network troubleshooting only and is not normally enabled.
PING	PING	Allows user to PING another device on the network.
EX	Exit to Bootloader	EX is used to enter the Bootloader command section. The unit will stop monitoring the inputs and allow firmware updates to be loaded. To restore normal operation after updating firmware, type run and press Enter on the keyboard, or power the unit off and back on again.



WARNING

The Bootloader section is designed for experienced technicians or users responsible for maintaining the system. Exit immediately if you have not been trained in the use of the Bootloader commands. Contact RLE for more information regarding the commands in this section.

5.3.1 Main Configuration Menu – SC

Typing **SC** at the command prompt on the Main Menu displays the Main Configuration Menu that lists all items for system setup and configuration. This menu may be password protected. If it is, the password must be entered when the **SC** menu selection is made. To enter the password, type **SC**, press the space bar once, and then type the appropriate password.

Table 5.2 Main Configuration Menu (SC) Commands

Command	Description	Function
1	IP Configuration Menu	1 displays the IP Configuration Menu.
2	Factory Menu	2 displays the Factory Menu. This menu provides a means to change the MAC address and erase the user configuration stored in Flash memory. This area is password protected. If you are familiar with MAC assignments and configuring the F3400/F1000, contact RLE Technologies for the password to this menu. WARNING! Once you receive the password for this menu, you assume full responsibility for the system configuration and proper MAC addressing of the F3400/F1000.
3	Load/Save Configuration Data	3 allows user configurations to be saved and reloaded onto other F3400/F1000s. Windows HyperTerminal application software may be used to perform the load/save functions. Before the configuration can be loaded onto other F3400/F1000s, it must be checked for accuracy. Blank spaces or unwanted characters, such as the “ <i>Press <enter> to download the file</i> ” text, may be saved into the beginning of the configuration file. Open the file in notepad and examine the first few lines. Delete any characters that were accidentally embedded into the file.
4	Configuration Password	4 allows the user to password protect the configuration section of the F3400/F1000 Firmware. The password can be any combination of 7 numbers and/or characters.
x	Exit	x exits the Main Configuration Menu and returns to the Main Menu.

5.3.2 IP Configuration Menu

The **IP Configuration Menu** is accessed by typing a **1** at the command prompt in the Main Configuration Menu. This menu is used to establish IP/TCP and PPP interaction with the network. The F3400/F1000 must be set up with an IP address, mask, and default router. These addresses can be obtained from your Network Administrator or IT Department. To enable the SNMP receiving stations (create communities), the F3400/F1000 MIB, provided on a diskette with every unit, must be loaded on a system(s) running a Network Operating System (NOS). This MIB is compiled through standard functions of the NOS. Consult with your Network Administrator for proper installation of the F3400/F1000 MIB on the NOS. Once the MIB is loaded, the F3400/F1000 can be discovered and configured over the network. For proper operation, the IP addresses configured in the F3400/F1000 communities must match the IP addresses on the receiving stations. Only the administrator's username/password may be changed from this menu. All other Web users must be changed via the Web interface.

Table 5.3 IP Configuration Menu Commands

Command	Description	Function
i	LANIPAddress	Designates the LAN IP address.
m	Net Mask	Designates the Subnet Mask.
D	Default Route	Establishes the default IP address.
u	Web Administrator Username	Edits the Web administrator username.
p	Web Administrator Password	Edits the Web administrator password.
f	Web Refresh Rate	Changes the Web refresh rate.
s	PPP Server IP Address	Designates the PPP server IP address.
c	PPP Client IP Address	Designates the PPP client IP address.
z	Max Seg Size (TCP)	Establishes the maximum segment size.
	Communities	Communities are computers that receive SNMP Traps from the F3400/F1000 and interact with the F3400/F1000 over the network. To add a computer to the communities list, select a menu number posted as "empty." Enter the receiving computer's IP address, the type of network access the machine will have (r – read, w – read/write, n – none), and whether the computer will receive Traps or not (y – yes, n – no). Separate each of these items with a space and press Enter when done. The newly configured community member will appear in the appropriate space in the community listing. Type delete to remove an existing community.

Table 5.3 IP Configuration Menu Commands (continued)

Command	Description	Function
q	Quit	DOES NOT save changes and returns user to the Main Menu.
x	Exit & Save	Saves changes and returns user to the Main Menu.

REMOTE ACCESS

6.1. Remote Access Configuration (Modem Option)

The F3400/F1000 can be remotely accessed with any terminal emulation software package. To establish a proper dial-out session, set the appropriate modem port as follows:

- ◆ 33.6K baud
- ◆ NO parity
- ◆ 8 bits
- ◆ 1 stop bit
- ◆ (2400/N/8/1)
- ◆ No software or hardware flow control

Once the proper settings are made, dial the phone number assigned to the F3400/F1000. Once communication is established, press **Enter**. A logon prompt will appear on the screen. Type the login and press **Enter**; type the password and press **Enter**. The session will begin.

Note The factory default settings are username: `falcon` and password: `rletech`.

Type a question mark (?) to view the **System Menu**. To terminate the session, execute the command in the software package that disconnects the modem. The commands for accessing the system remotely are identical to the ones described earlier in this user guide. There is, however, a limited command set for remote access. The available commands are:

- ◆ Current Alarms (**CA**)
- ◆ Kill All Alarms (**KA**)
- ◆ Display Date/Time (**TI**)
- ◆ ADC Input Values (**AD**)
- ◆ Modem Stats (**MS**)
- ◆ System Configuration (**SC**)

System Configuration is limited to the **System Configuration Menu** section.

Pages can be acknowledged by phone number during a remote access session by entering **aa** followed by the alarm acknowledgement code for that phone number.

POINT-TO-POINT PROTOCOL

Point-To-Point Protocol (PPP) is an alternate method that may be used to communicate with the F3400/F1000. PPP can only be used through a modem, over a phone line. The F3400/F1000 and the user's computer must both be configured correctly in order for PPP to work.

7.1. Configuring the F3400/F1000

- 1 Access the F3400/F1000's Web interface.
- 2 Click the **Configuration** link. Enter the correct user name and password (if necessary).
- 3 From the **Configuration Menu**, click on the **System** link.
- 4 On the **System Configuration** page, click on the **IP Configuration Menu** link.

The **IP Configuration** page lists the IP addresses configured on the F3400/F1000. Both the **PPP Server** and **PPP Assignment** fields need to be completed in order for PPP to work.

PPP Server: Assigns an IP address to the F3400/F1000 for PPP communications. Any IP address may be used, as long as it is not in the same subnet as the F3400/F1000's primary IP address. A good example of an IP address to use is: 192.168.1.2. Use this address to view the F3400/F1000 Web interface through a browser when communicating with the F3400/F1000 through PPP.

PPP Assignment: Tells the F3400/F1000 what IP address to assign to the PC the user dials in from. Again, any IP address may be used, as long as it is in the same subnet as the PPP Server IP address. A good example of an IP address to use is: 192.168.1.3

7.2. Configuring the PC

Now the user is ready to configure the PC they will be dialing in from. These directions were written from a Windows XP machine. To configure the PC:

- 1 Click on **Start, Control Panel**, then **Network and Internet Connections**. Select **Internet Options**.
- 2 When the **Internet Properties** window appears, select the **Connections** tab at the top of the window and click on the **Setup** button to start the **New Connection Wizard**.
- 3 Click the **Next** button to begin the Wizard.
- 4 Select **Connect to the Internet** and click the **Next** button.
- 5 Select the **Set up my connection manually** button and click **Next**.
- 6 Select the **Connect using a dial-up modem** button and click **Next**.
- 7 Type “F3400/F1000” as the name of the ISP in the space provided and click **Next**.
- 8 Enter the **phone number** of the phone line that connects to the F3400/F1000. Click the **Next** button.
- 9 Enter the F3400/F1000’s Modem **User name and Password**—see 4.16., “User Administration (Web Access)” on page 57—and click **Next**.
- 10 Add a shortcut to the desktop. Click the **Finish** button.

UPGRADING FIRMWARE AND MANAGING CONFIGURATION DATA

8.1. Upgrading F3400/F1000 Firmware

You can upgrade F3400/F1000 firmware using either the:

- ◆ TFTP client
- ◆ EIA-232 interface

Follow the instructions for the method you want to use.

8.1.1 Upgrading F3400/F1000 Firmware via TFTP Client

This is the preferred method. However, it does not work with a PPP connection.

- 1 Download the most recent version of firmware appropriate for your F3400/F1000 from the Documentation/Files section of the F-Series webpage at www.rletech.com. Save it to the hard drive of your computer. Do not change the name of the file. **The name of the file, as downloaded from the RLE website, must remain the same.**
- 2 The F3400/F1000 can only accept one copy of firmware at a time. Before a new version can be uploaded, the oldest version must be deleted. To do this, access the **Flash Program** link on the **Configuration** menu of the F3400/F1000's Web interface. Click the **Erase Backup** button to erase the oldest version of firmware. It will take approximately 10 seconds for the firmware to be erased. A confirmation screen will appear once the firmware has been erased.
- 3 Click the Back button on your browser to return to the **Flash Program** screen. Reload this page to ensure the oldest firmware has been erased. A **Checksum** value of **FFFF** tells you the oldest firmware has been completely erased.
- 4 Uploading firmware via TFTP requires a TFTP Client. It may be possible to download a free license TFTP Client from the Internet. Consult your IT department to determine a compatible client program.
- 5 Verify that your PC and the F3400/F1000 are on the same subnetwork (LAN).
- 6 Open your TFTP client. Configure the client as follows.
 - a **Host** = F3400/F1000 IP Address
 - b **Port** = 69
 - c **Block Size** = 64, 128, 256, 512, or 1024

Note The file must be sent in BINARY (not ASCII).

- 7 **Send** or **PUT** the firmware file to the F3400/F1000. It may take ~10 seconds for the firmware upload to begin.
- 8 Reload the Flash Program Configuration page to ensure the new firmware has successfully loaded onto the F3400/F1000.

8.1.2 Updating F3400/F1000 Firmware via the EIA232 COM1 Port (X-Modem)

- 1 Connect to the F3400/F1000 using HyperTerminal. For instruction on how to do so, see our support document “Connect HyperTerminal” available on the Documentation/Files section of the F-Series webpage at www.rletech.com.
- 2 Start firmware updates by either:
 - a Pressing any key after power-up when a 10 second window provides an opportunity to abort the Flash Main Program, or
 - b Typing **EX** to exit to Bootloader once the Main Menu appears.
- 3 From the F3400/F1000 Boot prompt, type **?** and press **ENTER** to see the list of available commands.
- 4 From the F3400/F1000 Boot prompt, type **ID** and press **ENTER**. Note which Flash has the lowest serial number. The Flash with the lowest serial number is the backup. The idea is to erase the backup, load the new version, which becomes the active Flash, then erase and load the other Flash.
- 5 From the F3400/F1000 Boot Prompt, erase the back up Flash program (the one with the lowest serial number) by typing **ERASE PRGM1** or **ERASE PRGM2** followed by **ENTER**. After a second or so, the screen will update with an **OK**.
- 6 From the F3400/F1000 Boot prompt, type **LOAD PRGM1 XMODEM** or **LOAD PRGM2 XMODEM** followed by **Enter**. Select the same program that was erased.
- 7 From the HyperTerminal menu select **Transfer -> Send File**. Use the browse button to select the F3400/F1000 firmware file from the computer's directory. The file must be binary and have a **.bin** extension. Select the file and upload it using the **1K X-Modem protocol**. Then click **Send**.
- 8 A transfer status screen will be displayed. The transfer time will take about 10 minutes. Once the transfer is complete, the transfer status window will automatically close. The HyperTerminal window will indicate that the upload is complete.
- 9 From the F3400/F1000 Boot prompt, type **RUN** or power down the F3400/F1000 and restart it to verify that the new Flash program runs.
- 10 Press **ENTER** to display the F3400/F1000 Main Menu and repeat the steps above to erase and download to the other Flash program chip.
- 11 Once the firmware upgrade is complete, disconnect the serial cable and close HyperTerminal.

8.2. Loading/Saving F3400/F1000 Configuration Data

This menu allows user configurations to be saved and reloaded onto other F3400/F1000, or in the unlikely event the F3400/F1000 fails, a replacement F3400/F1000 can be quickly placed back in service after loading the saved configuration information. The configuration settings are saved to a binary file for backup purposes, which cannot currently be edited off line.

8.2.1 Saving Configuration Data via TFTP Client

- 1 Verify that your PC is connected to the F3400/F1000 over the LAN and that port 69 is open between your PC and the Falcon.
- 2 Open your TFTP client. Configure the client as follows.
 - a **Host** = F3400/F1000 IP Address
 - b **Port** = 69
 - c **Block Size** = 64, 128, 256, 512, or 1024

Note The file must be sent in BINARY (not ASCII).

- 3 The file name of the configuration being saved must contain the **.cfg** extension.
- 4 **Fetch** or **GET** the file. After a few seconds, the TFTP software should indicate when it is complete.
- 5 Use Windows Explorer to verify that the files exist on the PC's hard drive. Copy the files to your desired file backup location.

8.2.2 Saving Configuration Data via EIA232 COM1 Port (X-Modem)

- 1 Before starting, make sure the HyperTerminal properties are set correctly to perform load/save. Select the **Properties Menu** (under File) to establish a direct connection through an available COM Port. This port should be set to **9600 Baud, 8 Data bits, NO Parity, 1 Stop bit, and NO Flow control**.
- 2 Select the **Settings** tab for additional changes. The parameters under the Settings tab should reflect what is shown below.
- 3 To save settings, go to the F3400/F1000 onto which the configuration will be saved. Log into the F3400/F1000 (COM1) through HyperTerminal (Terminal Emulation Program). Navigate to the **Load/Save Configuration Data Menu** under the Main Configuration Menu.
- 4 Select option **1 (Save XModem-1K)** from the Load/Save Configuration Data Menu followed by the ENTER key. Then select the **Transfer/Receive File** from the menu at the top of the HyperTerminal screen.
- 5 Specify a name by which to save the file and select the **1K X-Modem** receiving protocol. Then click on the **Receive/Start** button.
- 6 Wait until the download is completed and enter **X** to exit the Load/Save Configuration Menu.

8.2.3 Loading Configuration Data via TFTP Client

Before the configuration can be loaded onto other F3400/F1000s, it must be checked for accuracy. Blank spaces or unwanted characters, such as the “*Press <enter> to download the file*” text, may be saved into the beginning of the configuration file. Open the file in Notepad and examine the first few lines. Delete any characters that were accidentally embedded into the file.

- 1 Verify that your PC is connected to the F3400/F1000 over the LAN and that port 69 is open between your PC and the Falcon.
- 2 Open your TFTP client. Configure the client as follows.
 - a **Host** = F3400/F1000 IP Address
 - b **Port** = 69
 - c **Block Size** = 64, 128, 256, 512, or 1024

Note The file must be sent in BINARY (not ASCII).

- 3 The file name of the configuration being loaded must contain the **.cfg** extension.
- 4 **Send** or **PUT** the file. After a few seconds, the TFTP software should indicate when it is complete.
- 5 Configurations are now loaded onto the replacement F3400/F1000. View the Falcon webpages to verify that the configurations are as expected.

8.2.4 Loading Configuration Data via EIA232 COM1 Port (X-Modem)

Before the configuration can be loaded onto other F3400/F1000s, it must be checked for accuracy. Blank spaces or unwanted characters, such as the “*Press <enter> to download the file*” text, may be saved into the beginning of the configuration file. Open the file in notepad and examine the first few lines. Delete any characters that were accidentally embedded into the file.

- 1 To load settings, go to the F3400/F1000 onto which the configuration will be loaded. Log into the F3400/F1000 (COM1) through HyperTerminal (Terminal Emulation Program). Navigate to the **Load/Save Configuration Data Menu** under the Main Configuration Menu.
- 2 Select option **2 (Load xmodem 1K)** from the Load/Save Configuration Menu and press **ENTER**. Then select **Transfer/Send File** from the menu at the top of the HyperTerminal screen.
- 3 Select the **1K X-Modem** protocol. Locate the correct configuration file under **Filename** (Browse), select **Open**, and then select the **Send** button.
- 4 Wait until the Upload is completed and enter **X** to exit the Load/Save Configuration Menu.

Notes:



ANALOG INPUT 4-20MA REFERENCE CHART

Analog 4-20Ma Gain/Offset Conversion Formula:

$$\text{Gain} = \text{Sensor Range (High Value - Low Value)} / 4$$

$$\text{Offset} = \text{Sensor Low Value} - \text{Gain}$$

Example: TH140 Humidity

$$\text{Gain} = (\text{High Value (100)} - \text{Low Value (0)}) / 4 = 25$$

$$\text{Offset} = (\text{Sensor Low Value (0)} - \text{Gain (25)}) = -25$$

Table A.1 Analog Input 4-20mA Reference Chart

RLE Product Number	Transducer Type	Range	Gain	Offset
TEMPERATURE				
TH140	Temperature (Display in Deg F)	50°F - 95°F	11	39
	Temperature (Display in Deg F)	32°F - 122°F	22	11
	Temperature (Display in Deg C)	10°C - 35°C	6	4
	Temperature (Display in Deg C)	0°C - 55°C	13	-13
	Humidity	0% - 100% RH	25	-25
T120	Temperature (Display in Deg F)	50°F - 95°F	11	39
	Temperature (Display in Deg F)	32°F - 122°F	22	11
	Temperature (Display in Deg C)	10°C - 35°C	6	4
	Temperature (Display in Deg C)	0°C - 50°C	13	-13
CURRENT				
CT55	Current	0 - 5 Amps	1	-1
		0 - 55 Amps	13	-13

Table A.1 Analog Input 4-20mA Reference Chart (continued)

RLE Product Number	Transducer Type	Range	Gain	Offset
CT20	Current	0 - 30 Amps	7	-7
		0 - 60 Amps	15	-15
		0 - 120 Amps	30	-30
CT200	Current	0 - 20 Amps	5	-5
		0 - 200 Amps	50	-50
CT300	Current	0 - 100 Amps	25	-25
		0 - 300 Amps	75	-75
VOLTAGE				
PT300	Voltage - Single Phase	0 - 300 VAC	75	-75
3PT300	Voltage - Three Phase	0 - 300 VAC	75	-75
PT600	Voltage - Single Phase	0 - 600 VAC	150	-150
3PT600	Voltage - Three Phase	0 - 600 VAC	150	-150
LD5100 4-20mA				
LD5100	Leak Detection 4-20mA Output (Calc. in ft/m)	0 - 1000ft / 305m	250	-250
		0 - 2500ft / 762m	625	-625
		0 - 5000ft / 1524m	1250	-1250
LD5000 4-20mA				
LD5000	Leak Detection 4-20mA Output (Calc. in ft/m)	0 - 500ft / 152m	143	-179
		0 - 1000ft / 305m	286	-357
		0 - 1500ft / 457m	429	-536
		0 - 2000ft / 610m	571	-714
		0 - 2500ft / 762m	714	-893
		0 - 3000ft / 914m	857	-1071
		0 - 3500ft / 1067m	1000	-1250
		0 - 4000ft / 1219m	1143	-1429
		0 - 4500ft / 1372m	1286	-1607
		0 - 5000ft / 1524m	1429	-1786

B

F3400/F1000 ACCESSORIES WIRING

The following figures show the typical wiring between the F3400/F1000 Monitoring System and other products offered by RLE Technologies.




Figure B.1 T120D Temperature Sensors




Figure B.2 TH140 & TH140D Temperature/Humidity Sensors




Figure B.3 Dwyer Temperature/Humidity Sensors




Figure B.4 BAPI Temperature/Humidity Sensor




Figure B.5 SMK Smoke Detector, Photoelectric




Figure B.6 HD150 & HD150-2 Gas Sensors




Figure B.7 SD Spot Detectors




Figure B.8 PFM Power Fail Monitor




Figure B.9 SeaHawk LD5100/LD2000 Distance Read Leak Detection (Dry Contact)

B.1. Configuring the SeaHawk LD5100 as an Analog Input

The F3400/F1000 averages/filters the analog inputs. The LD5100 will output approx. 3.95mA when there is no leak. The LD5000 will output a value between 4mA and 20mA when there is a water leak. The low limit 1 and low limit 2 set points should be set to a 0 value. High limit 1 should be set to a value, in feet, that represents 4.0mA (1 foot). This allows the F3400/F1000 to alarm whenever there is a leak. The high limit 2 should be set to a value, in feet, that will control the internal relay, if needed for the application. The Cable Fault relay, from the LD5100 should be tied back into the F3400/F1000 to detect a fault with the 5100 controller/cable. The analog output is only used for a Leak alarm distance.




Figure B.10 SeaHawk LD5100 Distance Read Leak Detection (4-20mA)




Figure B.11 SeaHawk LDRA6, LD1000, and LD300 Leak Detection

For assistance wiring the following F3400/F1000 accessories also offered by RLE, please contact our Technical Support Department at (970) 484-6510:

- ◆ CT55 and CT200 Single Phase Current Sensor
- ◆ CT300 and CT800 Single Phase Current Sensor
- ◆ PT150 Single Phase Voltage Sensor
- ◆ PT300 Three Phase Voltage Sensor
- ◆ PT600 Three Phase Voltage Sensor
- ◆ MD3 Motion Sensor
- ◆ MDS Magnetic Door Sensor
- ◆ PS-RC Relay Controlled Two Outlet Receptacle

Notes:



ALARM ID REFERENCE TABLES

C.1. Analog Tables

Table C.1 Analog Alarm ID Reference Tables, Inputs 1-4

Channel	Condition	ID
1	High Limit 1	001
1	Low Limit 1	002
1	High Limit 2	003
1	Low Limit 2	004
2	High Limit 1	005
2	Low Limit 1	006
2	High Limit 2	007
2	Low Limit 2	008
3	High Limit 1	009
3	Low Limit 1	010
3	High Limit 2	011
3	Low Limit 2	012
4	High Limit 1	013
4	Low Limit 1	014
4	High Limit 2	015
4	Low Limit 2	016

C.2. Thermistor Tables

Table C.2 Thermistor Alarm ID Reference Tables, Inputs 5-8

Channel	Condition	ID
5	High Limit 1	017
5	Low Limit 1	018
5	High Limit 2	019
5	Low Limit 2	020
6	High Limit 1	021
6	Low Limit 1	022
6	High Limit 2	023
6	Low Limit 2	024
7	High Limit 1	025
7	Low Limit 1	026
7	High Limit 2	027
7	Low Limit 2	028
8	High Limit 1	029
8	Low Limit 1	030
8	High Limit 2	031
8	Low Limit 2	032

C.3. Digital Tables

Table C.3 Digital Alarm ID Reference Tables, Digital Inputs 5 through 32

Channel	Condition	ID
5	On/Off	085
6	On/Off	086
7	On/Off	087
8	On/Off	088
9	On/Off	089
10	On/Off	090
11	On/Off	091
12	On/Off	092
13	On/Off	093
14	On/Off	094
15	On/Off	095
16	On/Off	096
17	On/Off	097
18	On/Off	098
19	On/Off	099
20	On/Off	100
21	On/Off	101
22	On/Off	102
23	On/Off	103
24	On/Off	104
25	On/Off	105
26	On/Off	106
27	On/Off	107
28	On/Off	108
29	On/Off	109
30	On/Off	110
31	On/Off	111
32	On/Off	112

Notes:

D

TECHNICAL SPECIFICATIONS

Table D.1 Technical Specifications

Power		24VDC Model: 24VDC ($\pm 10\%$), 600mA max., wall adaptor included
Inputs		
Analog/Digital		
	F1000	4 Configurable as 4-20mA (12-bit A/D conversion), 4 as Digital Input or Thermistor
	F3400	4 Configurable as 4-20mA (12-bit A/D conversion), 4 as Digital Input or Thermistor and 24 Digital Input (<15mA)
Communications Ports		
Ethernet		10BASE-T, RJ45 connector; 500VAC RMS isolation
EIA-232		DB9 female connector; 9600 baud; 3000VAC RMS optically isolated; 15kV ESD protection
EIA-485 (selectable as EIA232)		Two-wire half duplex; terminal block (selecting EIA232 switches to DB9 male connector); 9600 baud; 3000VAC RMS optically isolated
Modem (RJ11 Telco) – Optional		V.34bis/33.6 kbps; PPP-Enabled; FCC Part 68 approved; 1500VAC RMS isolation barrier; 2100V peak surge protection; (Modem optional)

Table D.1 Technical Specifications (continued)

Protocols		
TCP/IP; UDP/IP; ICMP/IP; FTP; NTP; Telnet	IPv4.0; up to 5 URL links to other IP addressable cameras/ devices; webpages comply with Rehabilitation Act of 1973, sections 504 and 508, US Dept of Education (website accessibility for computer users with disabilities)	
HTTP/HTML	V1; MIB-2 compliant; NMS Manageable with Get, Set, and Traps; V2c- Traps or Informs.	
SNMP	Supports Client Authentication (plain and login); compatible with ESMTP Servers	
SMTP (Email)	Slave; RTU Mode; Supports function codes 03, 04, 06 and 16	
Modbus	RTU transmission protocol; function codes: Slave - 03; master - 01,02,03,04	
Modbus/IP	Modbus Slave; TCP/IP transmission protocol	
BACnet/IP	Conformance Level 1	
Terminal Emulation	VT100 compatible	
TAP (Pager)	Telocator Alphanumeric Protocol Ver1.8	
Alarm Notification		
Pager (Modem)	4 Text, numeric and/or alphanumeric pager numbers; each Digital and Analog Alarm (HighLimit2 and LowLimit2) can notify any 4 of the 4 pagers	
Email (Ethernet, Modem PPP)	4 Email recipients; email sent on Alarm and Return To Normal; each Alarm can notify any or all of the 4 email recipients	
SNMP Traps (Ethernet)	8 Community Strings	
Escalation	Additional notification to 1 of the 4 pager numbers when initial page results in Failure To Acknowledge status	
Internal Hardware		
Real Time Clock	Battery backed; ± 1.53 min/month accuracy	
Memory	512K RAM; 128K NVRAM; 64K ROM; 2M Flash	
Logging Capabilities		
Alarm Log	Last 100 Alarms	
Event Log	Last 100 Events (e.g., Acknowledgement By Code, System Boot, Page Successful, etc.)	
Web User Access Log	Last 100 HTML Accesses (User, Date, and Time)	
Digital Status Log	Last 100 Digital Status entries	
Trending of Analog Inputs	244 Entries per time frame, per channel	
	Minute	Every minute, high/low/avg for the last 65 minutes
	Hour	Every hour, high/low/avg for the last 25 hours
	Day	Every day, high/low/avg for the last 7 days

Table D.1 Technical Specifications (continued)

Login Security	
Web Browser Access (Ethernet, Modem PPP)	1 Administrator plus 7 Users individually selectable for Read Only, Read/Write or Administrator
Terminal Emulation Access (Modem, EIA232)	1 Administrator (password for both Modem and EIA232) plus 1 Read Only; (password for Modem only, not EIA232)
Front Panel Interface	
Switches	Power: 1 (on/off)
LED Indicators	Power: 1 green (on/off); Status: 1 red (flashing = boot-up, on = alarm, off = normal); Network Link: 1 green; Network Activity: 1 green; Modem: 4 green (transmit, receive, off hook and carrier detect)
Operating Environment	
Temperature	32° to 158°F (0° to 70°C)
Humidity	5% to 95% RH, non-condensing
Altitude	15,000ft (4,572m) max.
Storage Environment	-40° to 185°F (-40° to 85°C)
Dimensions	16.8"W x 1.8"H x 7.9"D (427mmW x 46mmH x 201mmD)
Weight	6 lbs. (2.72kg)
Mounting	Rack mount, or wall mount (brackets required): WMB wall mount brackets (not included)
Certifications	CE; ETL listed: conforms to UL STD 61010-1, EN STD 61010-1; CSA C22.2 STD NO. 1010-1; RoHS compliant

Notes: