GODOX设计文件图注 项目类型 说明书 项目名称

RC-R9II说明书 产品料号 705-RCR920-00

尺寸(mm) 成品50x120mm 尺寸公差

±1mm 材质 105g铜版纸

工艺说明

中文为页正面, 英文页为反面

李佳龙

备注/色值

设计师

单色,黑色印刷,折页,双面印刷


校对

版本

吴水宁







60dox

19. Violet Button

20. Orange Button

23. Up Button

24. Left Button

25. Right Button


26. Down Button

21. Battery Compartment

22. Battery Compartment Cover

RC-R9II

Remote Control 使用手册 Instruction Manual



遥控器设置

短按电源开关按键实现开机/关机。

1. 遥控器频道/组别/ID调整

按无线设置 ② 按键, 进入频道/组别/ID设置界面。



CH设置: 按上下键选中CH频道, 按左键或右键选择频道, 频道选择范围32个: 1-32。



GR设置: 按上下键选中GR频道, 按左键或右键选择组别, 组别选择范围16组(ABCDEF, 0-9)。

ID设置: 按上下键选中ID. 按左键或右键选择ID. ID选择范围: 1-99。





GR:F

ID:OFF

2. FX光效模式设置

按FX进入光效模式, 按上键或下键选择光效模式种类, 选中后按左右键可选择当前类别中的模式: 情景光效模式有14类共39种: 可根据需求选择。

序号	显示	场景	显示	显示II	显示III
1	Q	彩光循环	慢速	中速	快速
2	**	闪光灯	闪光	发布会	狗仔队
3		派对	生日会	KTV	迪斯科
4	4	雷闪电	间歇	频繁	持续
5	ô	坏灯泡	间歇	频繁	持续
6	ŤÝ	电视机	慢速	中速	快速
7	۵	蜡烛	间歇	频繁	持续
8	※	火	柴火	篝火	火灾
9	186-	烟花	短暂	连续	演出
10	~	警车	暴闪	频闪	快闪
11	#	消防车	暴闪	频闪	快闪
12	ĘĴ,	救护车	暴闪	频闪	快闪
13	F	音乐	音乐I	音乐II	
14	SOS	sos			

3 双色温模式

按CCT按键(cr), 进入双色温模式, 按上/下/左/右键调节色温, 色温调节范围: 2500K~8500K, 上下键以 ±1000调节色温, 左右键以±100调节色温。也可直接短按 (3200K) (5500K) 选择对应的色温: 3200K、 5600K、6500K。








规格参数

调节色相H: 按上键或下键选择色相H, 再按左右键调节色相。色相调节范围0-360°。





也可以直接选择遥控器上对应的彩色: Red、Green、Blue、Cyan、Magenta、Yellow、Pink、Violet、Orange。

5. 亮度调节


4. 彩光模式

按HSI按键(m) 讲入彩光模式,

1. 当前单组灯亮度打开时, 按DIM"+"或"-"键调节亮度, 亮度调节范围为: 0-100%。



2. 打开/关闭单组亮度: 按无线设置键进入无线设置界面, 按上键或下键选中组别GR, 按FN打开或关闭当前 组别灯亮度。显示OFF为关闭状态、显示数字0-100为打开状态。





产品保修

尊敬的用户, 本保修卡是申请保修服务的重要凭证, 请您配合销售商填写并妥善保管, 谢谢!

产品信息	<u></u> 포등	产品条码
用户信息	姓名	联系电话
	通讯地址	
销售商信息	名称	
	联系电话	
	通讯地址	
	销售日期	
备注		

注: 此表应由销售商盖章确认

适用产品

其他出厂后附加的部件等)不在此保修承诺内。

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算,购买日以购买

产品时保修卡登记日期为准

如何获得保修服务

不适用保修的情况

产品保修和服务支持信息

产品类别 选件名称

部件 电路板

产品的保修期和服务类型按以下《产品保修信息》执行:

充电器等带电性能的部件。

加闪光管 诰型灯泡 外壳 保护置

锁紧装置、包装、电源线, 同步线等。

产品信息	코 号	产品条码
用户信息	姓名	联系电话
	通讯地址	
销售商信息	名称	
	联系电话	
	通讯地址	
	销售日期	
备注		

本文件适用于相关《产品保修信息》(见后面说明)所列产品, 其他非属此范围的产品或部件(如促销品、赠品及

深圳市神牛摄影器材有限公司

地址: 深圳市宝安区福海街道塘尾社区耀川工业区厂房2栋 电话: 0755-29609320(8062) 传真: 0755-25723423 邮箱: godox@godox.com

GODOX Photo Equipment Co., Ltd.

Add: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen, China Tel: +86-755-29609320(8062) Fax: +86-755-25723423

E-mail: godox@godox,com

Made in China | 705-RCR900-02



Names of Parts

01. OLED Panel

07. FN Button


02. Power Switch

04 EX Mode Button

03. Wireless Setting Button

05. CCT Bicolor Mode Button


06. HSI Colorful Light Mode Button



1. Remote Control Channel/Group/ID Adjustment



CH Setting: Press up and down button to choose CH channel and press left or right button to



GR Setting: Press up and down button to choose GR group and press left or right button to







Remote Control Setting

6. HSI/RGB彩光模式按键 13. Green按键

1. OLED屏

7. FN按键

2. 电源开关按键

3. 无线设置按键

4. FX光效模式按键

5 CCT双色温模式按键

Short press the power switch button to power on or off the remote control.

15. Cyan按键

16. Magenta按键

17. Yellow按键

18. Pink按键

19 Violet按键

20. Orange按键

21. 电池槽

23.上键

24.左键

25.右键

26.下键

Press wireless setting button (a) to enter channel/group/ID setting interface.

8. DIM高度调节按键

9.3200K色温按键


11.6500K色温按键

12. Red按键

14. Blue按键

10.5600K色温按键





choose group value from A to F and 0 to 9.





2. FX Modes Setting

Press FX to enter FX modes and press left or right button to choose the categories of them. After choosing the kinds, there are I, II and III modes can be selected.

No.	Display	Situation	Display I	Display II	Display III
1	4	Colorful lights recycle	Slowspeed	Medium speed	Quickspeed
2	*+	Flash	Flash	Press conference	Paparazzi
3		Party	Birthday party	KTV	Disco
4	4	Lightning	Discontinuous	Frequent	Sustainable
5	Q	Broken bulb	Discontinuous	Frequent	Sustainable
6	ŤÝ	TV	Slowspeed	Medium speed	Quick speed
7	۵	Candle	Discontinuous	Frequent	Sustainable
8	<u> </u>	Fire	Firewood	Campfire	Fire hazard
9	- AND	Firework	Brief	Continuous	Show
10	A	Policecar	Strongflash	Frequentflash	Quickflash
11	A	Firetruck	Strongflash	Frequentflash	Quickflash
12	401	Ambulance	Strongflash	Frequentflash	Quickflash
13	F	Music	MusicI	Music II	
14	202	202			

Press CCT button to enter bicolor modes and press up, down, left and right button to choose the



4. Colorful Light Mode Setting

There are 39 kinds of situational FX modes which are divided into 14 categories for your choice.

NO.	Display	Situation	Display I	Display II	Display III
1	4	Colorful lights recycle	Slowspeed	Medium speed	Quick speed
2	**	Flash	Flash	Press conference	Paparazzi
3		Party	Birthday party	KTV	Disco
4	4	Lightning	Discontinuous	Frequent	Sustainable
5	9	Broken bulb	Discontinuous	Frequent	Sustainable
6	ŤÝ	TV	Slowspeed	Medium speed	Quickspeed
7	à	Candle	Discontinuous	Frequent	Sustainable
8	*	Fire	Firewood	Campfire	Firehazard
9	1000	Firework	Brief	Continuous	Show
10	A	Policecar	Strongflash	Frequentflash	Quickflash
11	=	Firetruck	Strongflash	Frequentflash	Quickflash
12	400	Ambulance	Strongflash	Frequentflash	Quickflash
13	F	Music	MusicI	Music II	

3 Bicolor Modes

color temperature from 2500K to 8500K. Press the up and down button will change the color temperature by ±1000 per time while pressing the left and right button by ±100 per time. You



Adjust hue H: press the up or down button to choose hue H. Then, press the left or right button



Adjust saturation S: press the up or down button to choose saturation S. Then, press the left of right button to adjust saturation value from 0 to 100



directly by pressing the corresponding buttons...

Light Brightness Adjustment: 1. When the current single light's brightness is displayed, press DIM " + "or " - "button to adjust

the brightness from 0 to 100%.



setting interface. Press the up or down button to choose the group GR and press the FN button to turn on or off the single group's brightness. When the brightness is off, OFF will be displayed. When the brightness is on, figure 0 to 100 will be displayed. Note: Wireless signals can only be received when the receiving end is powered on.

Technique Data

Remote Control	RC-R9II		
Power Supply	3.0V(AAA*2)(battery not included)		
2.4G Frequency Range	2413.0MHz-2464.5MHz		
Max. Transmitting Power	5dbm		
Distance(empty)	100m		
Channel	32(1 to 32)		
Grouping	16 Group(A B C D E F, 0 to 9)		
ID	99 (1-99)		
Working Environment Temperature	-10~40°C		
Dimension	55x133x10mm		
Net Weight	63q		

△ Warning Operating frequency:2413.0MHz-2464.5MHz

Maximum EIRP Power: 5dBm

Declaration of Conformity GODOX Photo Equipment Co., Ltd. hereby declares that this equipment are in compliance with

the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link: https://www.godox.com/DOC/ Godox_RC-R9II_DOC.pdf. The device complies with RF specifications when the device used at 0mm from your body.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with he instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

- he equipment off and on, the user is encouraged to try to correct the interference by one or nore of the following measures: Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service please fill in the following form in coordination with the seller and safe-keep it. Thank

			How to Get the Maintenance Service
ustomer oformation	Name	Contact Number	If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.
eller	Name		Inapplicable Cases
	Contact Number		The guarantee and service offered by this document are not applicable in the following cases: ①.
	Address		The product or accessory has expired its warranty period; ②. Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp
	Date of Sale		environments, etc; ③. Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ④. The original
lote:			identifying information of product or accessory is modified, alternated, or removed; ⑤. No valid warranty card; ⑥. Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ⑦. Breakage or damage caused by force majeure or accident;

Product Code Number

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items giveaways and additional accessories attached etc.) are not included in this warranty scope

Warranty Period

The warranty period of products and accessories isimplemented according to the relevant Product MaintenanceInformation. The warranty period is calculated from the day(purchase date) when the product is bought for the first time, And the purchase date is considered as the date registered on the warranty card when buying the product.

您可直接与产品销售商或授权服务机构联系, 也可拨打神牛产品售后服务电话, 与我们联系, 由我们的服务 人员为您安排服务。申请保修时, 您应提供有效的保修卡作为保修凭证, 方可获得保修。如您不能提供有效

的保修卡,则在我们可确认产品或部件属于保修范围的情况下,也可以为您提供保修,但这不作为我们的

如产品存在下列清况, 本文件项下的保证和服务将不适用 ①产品或部件超过相应保修期; ②错误或不适当 使用、维护或 保管导致的故障或损坏, 如: 不当搬运; 非按产品合理预期用途使用; 不当插拨外接设备; 跌

落或外力挤压: 接触或暴露于不适当温度 溶剂 酸碱 水浸或潮湿环境:(3)中非神华授权机构或人员安装

修理、更改、添加或拆卸造成的故障或损坏; ④产品或部件原有识别信息被修改变更或除去; ⑤无有效保修

卡; ⑥使用非合法授权、非标准或非公开发行的软件造成的故障或损坏; ⑦因不可抗力或意外事件造成的故

障或损坏; ⑧其他非因产品本身质量问题导致的故障或损坏。遇上述情况, 您应向相关责任方寻求解决, 神

牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的 不是保

保修期(月) 保修服务类型

神牛产品售后服务电话 0755-29609320-8062

12

客户送修

客户送修

无保修

客户送修

修范围内的故障。产品使用过程中正常的脱色、磨损和消耗、不是保修范围内的故障。

How to Get the Maintenance Service

maintenance service is needed, you can directly contact the product distributor or authorized ervice institutions. You can also contact the Godox after-sale service call and we will offer you ervice. When applying for maintenance service, you should provide valid warranty card. If you annot provide valid warranty card, we may offer you maintenance service once confirmed that ne product or accessory is involved in the maintenance scope, but that shall not be considered s our obligation.

he product or accessory has expired its warranty period; ②. Breakage or damage caused by nappropriate usage, maintenance or preservation, such as improper packing, improper usage, nproper plugging in/out external equipment, falling off or squeezing by external force, ontacting or exposing to the improper temperature, solvent, acid, base, flooding and damp nvironments, etc; ③. Breakage or damage caused by non-authorized institution or staff in the rocess of installation, maintenance, alternation, addition and detachment; ④. The original lentifying information of product or accessory is modified, alternated, or removed; ⑤. No alid warranty card; ③. Breakage or damage caused by using illegally authorized, nonstandard r non-public released software; ⑦. Breakage or damage caused by force majeure or accident; ®. Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration. abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

Product Maintenance Information: Maintenance Warranty Service Type Period(month)

Circuit Board	12	Customer sends the product
		to designated site
Battery	3	Customer sends the product to designated site
Electrical parts e.g.battery charger, etc.	12	Customer sends the product to designated site
Flash tube, modeling lamp, lamp body, lamp cover, lockingdevice, package, power cord, sync cable, etc.	No	Without warranty
	Electrical parts e.g.battery charger, etc. Flash tube, modeling lamp, lamp body, lamp cover, lockingdevice, package,	Electrical parts e.g.battery charger, etc. 12 Flash tube, modeling lamp, lamp body, lamp cover, lockingdevice, package,



