

2D Wireless Barcode Scanner

Quick Guide



Reset to Default




Remark: This pamphlet is for quick guidance only. Please refer to the **Uses' Manual** for more detail instructions.

VER: TI4520_QG_EN_V1.00

Handset & Cradle



① Power Indicator
② Data Indicator
③ Trigger
④ View window of capture



① Pairing
② Channel Up
③ Channel Down
④ Power Indicator
⑤ Data Indicator
⑥ Reserved
⑦ Power Interface
⑧ Data Interface to PC
⑨ Wall-mounted Adjusting
⑩ Antenna

Installation

Connection and Pairing

Step 1. Refer to the below pictures, firstly connect the cradle⑧ to host (e.g. PC or POS) with cables of different interface:

USB: Plug the RJ45 in cradle⑧, and plug the USB end into the host.



Keyboard PS/2: Plug the RJ45 to cradle⑧, and connect the male PS/2 end to host port and the female end with keyboard wire.



RS232: Plug the RJ45 into the cradle⑧, and plug the RS232 into the PC port. The DC power should be plugged into the RS232 connector.



RS232 Cable

Typically the cradle will auto identify the interface type (COM) and cradle⑤ gets green on. In extreme case the cradle fails to identify (green flash of cradle⑤), please scan the barcode to set it manually.

Auto identifying (Default)



USB Mode


Keyboard (PS/2) Mode



Keyboard (PS/2) Mode



RS232 Mode



Note: The auto setting of interface type will only be activated when the pairing is well done. Please refer to the Step2 and Step3 for pairing.

Step 2. Place the handset onto the cradle. As in the picture below, firstly place the head of handset onto the wider end of cradle. Then press the other end onto the cradle till a "Pa" sound is out. It means well locked.



Handset onto Cradle

Step 3. Press the cradle①(P button) and hold till the **Dee-Doo-Doo** sound is out. Then the handset and cradle are well paired.

Remark: 1 cradle can support maximum 10 handsets. The handset cannot upload data if the handset and cradle were not well paired.

Usage of Scanner

Power On / Off

When trigger (handset①) is pulled and a **Beep-Deep** sound comes out, the handset is power on. If handset is not used for 60sec (default), the handset will auto turn off. The timing can be set to user need.


Code capture

In the standby mode, pull the trigger to capture code. Make sure the green aiming line is covering the full code, as in picture below

Correct way



Wrong way



Remark: 1. Once the code is well captured, the handset② will turn red and up for 1sec, and a "Dee" sound will come out.

2. To capture codes of different density, please move the handset forward and backward to gain a proper position.

Recharging

Place the handset back to cradle as Step2 to start recharging.

Remark: 1. Green flash of handset① means no power.
2. Red flash means recharging and it turns to yellow once finished.

Built-in Data Memory

If the handset is out of limit to wireless contact radius, or it works in the Manual Upload Mode, the captured code data will be stored in the handset memory. The Data Indicator (handset②) will be red on if data stored. It will turn green on once the data is well uploaded.

Multi-Cradles Working

In case two or more cradles working in the same room, please set them to different channels to ensure high upload efficiency as follow.

1. Press the "+" or "-" buttons (Cradle②, ③) on the cradle. (The No. of the channel will be displayed on the PC.)
2. Redo the pairing of handset and cradle to reset it to new channel.

Remark: If two or more cradles working in the same signal channel, it will slow down upload speed. However, they won't jam with each other.

Common Settings

Information Check

Firmware Version




Cradle Serial No.



Channel and Handset ID



Suffix Quick Setup



CR (Default)



No Suffix



Setting the Torch

Torch on when scanning*



Torch off



Common Symbol Setting

Start QR



Handset Serial No.



Start Data Matrix



Battery Power



Start PDF417



Stop QR



Stop Data Matrix



Stop PDF417



Setting the Data Upload Mode

Multiple upload modes are available for different usages:

No Storing Mode: Every code data will be uploaded instantly to the cradle once they are well captured. In case of unsuccessful upload, the

code data will be ignored and alarm of "Dee-Dee-Dee" will come out.

Auto Storage Mode (Default): The data will be stored in the handset memory in case of upload failure to cradle. And the data will be uploaded to cradle once the contact connection come back normal. It's the default working mode.

Manual Mode: The code data will firstly be stored in the built-in handset memory once well captured. It can store up to 10,000pcs code data. The data would be uploaded to cradle in one time once the Upload Start Code is manually triggered.

During the process of uploading or after upload well finished, if the Upload Start code is triggered, all code data stored in handset will be uploaded again.

Remark: In the Manual Mode, all stored code data will be kept until manually erased. Every time the Upload Start code is triggered, all code data stored in handset will be uploaded again. To avoid duplicating upload data, please trigger Erase Storage code to clear handset data.

Setting Power of Wireless Communication

Power-High (Default 14dBm)



Auto Storing (Default)

No Storing



Manual Mode



Upload Start (in Manual Mode)



Upload Start (in Manual Mode)

Erase Storage



Power Off



Power off at once

Power-Mid (7dBm)



Power-Low (0dBm)



Power-Low (0dBm)

Setting the Volume of the Beeper

Loud (default)



Mid



Low



Mute



Setting the Scanning Mode

Manual Scanning*



Auto Scanning Mode



Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting Power of Wireless Communication

Power-High (Default 14dBm)

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting the Volume of the Beeper

Loud (default)

Mid

Low

Mute

Setting the Scanning Mode

Manual Scanning*

Auto Scanning Mode

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting Power of Wireless Communication

Power-High (Default 14dBm)

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting the Volume of the Beeper

Loud (default)

Mid

Low

Mute

Setting the Scanning Mode

Manual Scanning*

Auto Scanning Mode

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting Power of Wireless Communication

Power-High (Default 14dBm)

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting the Volume of the Beeper

Loud (default)

Mid

Low

Mute

Setting the Scanning Mode

Manual Scanning*

Auto Scanning Mode

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting Power of Wireless Communication

Power-High (Default 14dBm)

Power Off

Power off at once

Power-Mid (7dBm)

Power-Low (0dBm)

Setting the Volume of the Beeper

Loud (default)

Mid</p

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.