

GARMIN.

Quick Start Manual

Getting Started

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Device Overview

①	Collar band
②	Contact points
③	Charge port (under weather cap)
④	Power and mode selection button
⑤	LED indicator
⑥	Tone mode
⑦	Auto-rise/smart mode
⑧	Vibration mode

Charging the Dog Collar Device

NOTICE

To prevent corrosion, thoroughly dry the contacts on the collar and the surrounding area before connecting the charging clip.

You should fully charge the battery before you use the device for the first time. Charging a fully depleted battery typically takes about two hours.

NOTE: The device does not charge when it is outside the approved temperature range (page 9).

- 1 Pull up the weather cap ① from the charging port ②.
- 2 Plug the power cable into a power source.

The color and number of lit status LED indicators change as the collar charges. All the status LED indicators turn solid green when the device is fully charged.

- 3 After all the status LED indicators turn solid green, remove the USB cord from the device.

NOTE: The device turns on automatically when you remove it from the charger.

Turning On the Dog Collar Device

The device remains on until you turn the device off manually (page 3)

TIP: The device does not issue corrections for two minutes after any button press, or after the device is removed from the charger.

Hold the power key until all of the status LED indicators turn green.

The device beeps, and an LED indicates the active mode. An LED turns blue when the smart mode is active. An LED turns green when any other mode is active. After two seconds, a blue or green LED turns red.

Turning Off the Device

- On the dog collar device, hold the power key until the status LED turns solid red, and release the power key. The device beeps.

Attaching the Dog Collar Device to a Collar Strap

You can attach the dog collar device to a collar strap that is a maximum of 25.4 mm wide (1 in.) and 2.78 mm thick (0.11 in.).

- 1 With the buckle facing outward, insert the end of the collar strap ① through the slot ② on the collar device.
- 2 Pull approximately two-thirds of the collar strap through the slot ③ on the opposite side of the device.

- 3 Snap the collar band onto the device.
- 4 Pull the collar strap until it is tight across the front of the device.

Pairing Your Smartphone with the Dog Collar Device

You can use the Garmin Canine™ app on your compatible smartphone to pair your dog collar device using Bluetooth® Smart wireless technology.

- 1 Go to www.garmin.com/apps, and download the Garmin Canine app to your smartphone.
- 2 Open the Garmin Canine app on your smartphone.
- 3 Follow the on-screen instructions to create an account, set up your dog profile, and pair the dog collar device.
- 4 Bring your smartphone within 10 m (33 ft.) of the dog collar device.
- 5 Connect the dog collar device to the charger.

The device enters pairing mode.

When the device is paired with your smartphone, a message appears.

Fitting the Collar on Your Dog

CAUTION

To help reduce the chance of irritation, remove the collar when not in use. You should check the fit and comfort of the collar daily.

This device is not intended for human use. Do not attempt to use on any person.

Do not spray the device with harsh chemicals including but not limited to flea or tick spray. Always ensure that all flea or tick spray applied to the dog is completely dry before placing the collar on the dog. Small amounts of harsh chemicals can damage the plastic components.

In order to effectively train the dog, the collar and device must fit the dog properly. If the collar is too loose or positioned incorrectly, stimulation may be inconsistent. This can delay or prevent successful training.

- 1 Position the device at the front of the dog's neck, with the status LED facing toward the dog's chin and the device against the throat.

TIP: For bark correction, the device should be positioned near the dog's


vocal cords. This location varies based on the breed of dog. If the device does not seem to detect the dog's barks, you should move the device closer to or farther from the dog's body to find the ideal location.

- 2 Confirm that the ID tags on the collar strap do not come into contact with the device.

NOTE: ID tags contacting the device may cause unintentional corrections.

- 3 Tighten the strap so that it is very snug around the dog's neck, and fasten the buckle.

NOTE: The collar should fit tightly and should not be able to rotate or slide on the dog's neck. The dog must be able to swallow food and water normally. You should observe your dog's behavior to verify that the collar is not too tight.



- 4 Wiggle the device to work the contact points through the dog's coat.

NOTE: The contact points must have contact with the dog's skin to be effective.

Garmin Canine

The free Garmin Canine app allows you to review your dog's daily activity and get insights into your dog's behavior. The app also allows you to wirelessly send software updates to your dog device.

Syncing the Dog Collar Device with the Garmin Canine App

Garmin® recommends you sync your device daily to review updated data in the app and receive important notifications, such as low battery alerts and software updates.

- 1 Bring your smartphone within 10 m (33 ft.) of the dog collar device.

TIP: You may need to wake the device if your dog is stationary for a long period of time.

2 Open the Garmin Canine app.

The dog collar device periodically syncs data with the Garmin Canine app automatically. The app indicates when the last sync occurred.

3 View your current data in the Garmin Canine app.

Bark Correction

NOTICE

Before playing with your dog, you should remove the dog collar device or deactivate the correction feature.

When using the device, you should remove all other collars, tags, or other items from your dog. These other items can cause the device to activate when the dog is not barking.

The device can correct your dog automatically when the dog barks. The device detects vibrations to distinguish between barking and other vocalizations. You can use the Garmin Canine app to manually adjust the amount of barking allowed. You can allow no

barking or set a custom number to indicate how many barks are allowed before correcting your dog. You can also allow some barking (up to 5 barks) to help avoid unintentional corrections resulting from everyday activity, such as yawning, sneezing, or going through a dog door.

You can use any of these methods when correcting your dog with the device.

- Tone
- Vibration
- Smart mode
- Stimulation

NOTE: If you turn off all correction methods, the device continues to detect your dog's barks without performing any corrections. This can help you track your dog's barking behavior using the Garmin Canine app.

Selecting a Training Mode

When your device is paired with a smartphone (page 5), you can use smart mode. You must select smart mode on the collar to use the settings in the Garmin Canine app. When you do not select smart

mode during setup, the device defaults to the last standard mode you used.

TIP: The device turns off when you hold the button for more than three seconds.

When the mode is set in the app, the center LED indicator turns blue and the smart mode option becomes available after you cycle through the standard corrections. You must press the button to see the current mode. When a correction is issued in smart mode, the corresponding LED indicates your selected correction.

You can select a standard or smart mode.

- 1 Remove the collar band from the device.
- 2 Press the mode button until the green LED indicates the current mode.
- 3 Press the mode button within two seconds to cycle the green LED through the modes, and select a mode.

NOTE: When the center LED is blue, you can select smart mode.

After two seconds, the LED turns from green to red, and the device issues a

sample correction of your selected mode.

When you select stimulation mode, the device does not issue a sample correction.

If the device is in smart mode, the blue LED cycles to a green, then a red LED on the selected correction mode.

Status LED Indicator

The center status LED indicators flashes when the device detects a bark or has a low battery charge.

LED Activity	State	Status
Flashing white		A bark was detected, and no correction was applied.
Flashing red	Correction mode	A bark was detected, and a correction was applied.
	After a correction	The battery is low.

Correction Methods

Stimulation: Applies a brief stimulation.

You can manually adjust the

stimulation intensity level using the Garmin Canine app.

Tone: Activates an audible tone. A tone can provide a patterned interruption to stop a behavior. The tone can be more effective when it is already associated with a negative consequence or alternate behavior.

Vibration: Applies a vibration to the dog for a short period of time to help break focus on the current cause of a behavior. The effectiveness of the vibration may vary based on the dog's temperament and experience.

Automatic Intensity

The device can set the stimulation intensity level automatically based on the barking behavior of the dog. The device starts at the lowest intensity level and increases the intensity level gradually until the dog stops barking. When the dog is quiet, the intensity decreases over time.

The automatic intensity feature is designed to eliminate excessive nuisance barking. To stop barks sooner, you should set the intensity level manually.

The extended panic guard is a safety feature that disables stimulation after four

corrections at the highest level, with 10 seconds between corrections. After the fourth correction, the device waits until no barks are detected in 2 minutes.

NOTE: When you set a fixed correction level, the device does not enter extended panic guard, even at the highest level of correction.

Choosing the Correct Intensity Level

You should choose the lowest intensity level that discourages the dog from barking. If you have never used a bark correction collar with the dog, the dog requires time and experience to learn that the bark is the cause of the correction.

- 1 From the Garmin Canine app, set the intensity to the lowest level.
- 2 For thirty minutes, when the dog barks, observe the dog for a reaction, such as a head shake, neck movement, a change in the way the dog barks, or just a change in expression.
- 3 If there is no reaction, increase the intensity by one level until the dog has a slight but recognizable reaction to the stimulation.
- 4 Allow 24 hours for the dog to learn to respond by not barking.

- If the dog continues barking while wearing the collar, increase the intensity level gradually until you find the level that discourages the dog from barking.

30 min. For more information, go to www.garmin.com/waterrating.

Device Information


Getting the Owner's Manual


Go to www.garmin.com/manuals/barklimiter2.

Specifications

Battery type	Rechargeable lithium-ion
Battery life	Up to 30 days, typical use
Operating temperature range	From -20 to 60 C (from -4 to 140 F)
Charging temperature range	From 0 to 40 C (from 32 to 104 F)
Storage temperature range (up to 1 month)	From -20 to 70 C (from -4 to 158 F)
Wireless frequencies/protocols	Bluetooth 2.4 GHz @ 4 dBm nominal
Water rating	1 ATM*

*The device withstands incidental exposure to water of up to 1 m for up to





support.garmin.com

© 2017 Garmin Ltd. or its subsidiaries

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries, and Garmin Canine™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license.



Printed in Taiwan
October 2017
I90-02356-xx

