


SPECIFICATION CONTROL DRAWING	Revisions			
	Rev.	Date	Description	ECO No.
	1	6/12/12	Experimental Release	----

Dimensions and drawings for reference only. Drawings are not to scale.

Trimmed and bound dimensions



Specifications

- | | |
|------------------------|---|
| 1. Description | Product documentation: Fenix Quick Start Manual (EN-US) |
| 2. Size | Trimmed and bound: Width = 2.4", Height = 5.15". |
| 3. Tolerance | ±0.0787" (±2 mm) |
| 4. Pagination | 16 pages |
| 5. Material | 120-lb matte-finish offset. Approved Equivalents Allowed. |
| 6. Finish | Matte |
| 7. Color | 4-color process |
| 8. Bindery | Saddle-stitched. |
| 9. Folds | N/A |
| 10. Electronic Artwork | Shall conform to Garmin Archive 190-01507-01_01.zip |
| 11. Languages | EN-US |
| 12. Notes | This part shall comply with Garmin Banned & Restricted Substances (GPN 001-00211-00). |

Files

The following files have been archived under the above ARCHIVE FILENAME.

File Name	File Contents
190-01507_01_01_Spec.indd	InDesign CS4 for PC, document specification sheet
190-01507_01_01.pdf	Portable Document Format, manual and specification sheet
fenix_QSM_WEB_EN.pdf	Portable Document Format, for online

<p style="text-align: center;">CONFIDENTIAL</p> <p>This drawing and the specifications contained herein are the property of Garmin Ltd. or its subsidiaries and may not be reproduced or used in whole or in part as the basis for manufacture or sale of products without written permission.</p>	 <p>Garmin Ltd. or its subsidiaries C/O Garmin International, Inc. 1200 E. 151st Street Olathe, Kansas 66062 U.S.A.</p>
--	---

	Initials	Date	TITLE Fenix Quick Start Manual (EN-US)		
Drawn By:	SMW	6/12/12	SIZE A	PART NO: 190-01507-01	REV: 1
Checked By:					
Project Manager:			SCALE N/A		Sht. Of 1 17
Approved By:					



fēnix™ Quick Start Manual

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

WARNING

Always consult your physician before you begin or modify any exercise program.

Getting Started

When using your device the first time, you should complete these tasks to set up the device and get to know the basic features.

- 1 Charge the device (page 2).
- 2 Register the device (page 13).
- 3 Learn about the sensor data and modes (page 4).
- 4 Acquire satellites (page 7).
- 5 Go for a hike (page 8).
- 6 Create a waypoint (page 9).
- 7 Get the owner's manual (page 12).

Charging the Device

NOTICE

To prevent corrosion, thoroughly dry the contacts and the surrounding area before charging or connecting to a computer.

The device is powered by a built-in lithium-ion battery that you can charge using a standard wall outlet or a USB port on your computer.

- 1 Plug the USB end of the cable into the AC adapter or a computer USB port.
- 2 Plug the AC adapter into a standard wall outlet.
- 3 Align the left side of the charging cradle ① with the groove on the left side of the device.







- 4 Align the hinged side of the charger ② with the contacts on the back of the device.

When you connect the device to a power source, the device turns on.

5 Charge the device completely.

Keys



①		Select to turn the backlight on and off. Hold to turn the device on and off.
②		Select to scroll through the data pages, options, and settings. On the map, select to zoom out.
③		Select to scroll through the data pages, options, and settings. On the map, select to zoom in.
④		Select to return to the previous screen.
⑤	Orange key	Select to open the menu for the current screen. Select to choose an option and to acknowledge a message. Hold to mark a waypoint.

Viewing the Status Page

You can quickly switch to this page to view the time of day, battery life, and GPS status information from any other page.

Hold ↶.



After five seconds the display automatically switches back to the previous page.

Viewing the Sensor Data

You can quickly access real-time data for the compass, altimeter, barometer, and temperature sensors.

NOTE: These data pages automatically time out to low-power mode.

NOTE: This data is not recorded to the device (page 7).

1 From the time of day page, select \triangle or ∇ .



2 Select ▾.



3 Select ▾.



4 Select ▾.



NOTE: Your body temperature affects the temperature sensor. To get the most accurate temperature reading, remove the device from your wrist and wait 20–30 minutes.

TIP: To purchase a *tempe™* wireless temperature sensor, go to www.garmin.com. See the owner's manual for more information.

Turning On a Sensor Mode

You can put the device in compass, altimeter, barometer, or temperature mode to display continuous sensor data. For example, you can put the device in altimeter mode and continuously monitor elevation data.




NOTE: If you have an optional heart rate or cadence sensor paired with the device, the list will include those data modes.

- 1** Select the **Orange** key.
- 2** Select **Compass, Altimeter, Barometer, or Temp..**

Acquiring Satellite Signals and Recording a Track

Before you can use the GPS navigation features, such as recording a track, you must acquire satellite signals.

The device may need a clear view of the sky to acquire satellite signals. The time and date are set automatically based on the GPS position.


- 1 Hold  to turn on the device.
- 2 Select your language (first time only).
- 3 Select the **Orange** key.
- 4 Select **GPS**.
- 5 Wait while the device locates satellites.
The device displays your coordinates when it has located satellites.
- 6 Select **Start**.
- 7 Walk around to record a track.
Your distance and time appear.
- 8 Select  to view the loop of data pages including compass data, altimeter data, ascent and speed, and the status page.
You can customize some data pages. See the owner's manual (page 12).
- 9 Select  to pause tracking.
- 10 Select an option:
 - Select **Resume** to continue tracking.
 - Select **Save** to save your track.
 - Select **Clear** to erase the track without saving.



Tracks

A track is a recording of your path. The track log contains information about points along the recorded path, including time, location, and elevation for each point.

Going for a Hike

Before you go for a hike, you should charge the device completely (page 2).

NOTE: The device turns on automatically while charging. If you do not charge the device before going for a hike, hold  to turn on the device.

- 1 Select the **Orange** key.
- 2 Select **GPS > Start**.
- 3 Start hiking.
- 4 When you want to take a break or pause the device from tracking, select .
- 5 Select **Resume**, and continue hiking.
- 6 When finished, select  **> Save** to save your hiking data.

Sending Your Hike to BaseCamp™

Before you can send data to BaseCamp, you must download BaseCamp to your computer (www.garmin.com/basecamp).

You can view your hike, other tracks, and waypoints on your computer.

- 1 Connect your device to your computer using the USB cable (page 2).

Your device appears as a removable drive in My Computer on Windows® computers

and as a mounted volume on Mac® computers.

- 2 Start BaseCamp.
- 3 Follow the on-screen instructions.

Waypoints

Waypoints are locations you record and store in the device.

Creating a Waypoint

You can save your current location as a waypoint.

- 1 Hold the **Orange** key.
- 2 Select an option:
 - To save the waypoint without changes, select **Save**.
 - To make changes to the waypoint, select **Edit**, make changes to the waypoint, and select **Save**.

Navigating to a Waypoint

- 1 Select the **Orange** key.
- 2 Select **GPS > Start**.
- 3 Select the **Orange** key.
- 4 Select **Waypoints**, and select a waypoint from the list.
- 5 Select **Go**.



The device displays time to destination ①, distance to destination ②, and estimated time of arrival ③.

- 6 Select ▾ to view the compass page.



The two pointer marks ④ serve as a bearing pointer. The top orange mark ⑤ points in the direction you are facing.

- 7 Align the pointer marks with the top orange mark.
- 8 Continue to walk in that direction until you reach the destination.

Navigating Using TracBack®

While navigating, you can navigate back to the beginning of your track. This can be helpful

when finding your way back to camp or the trail head.

- 1 Select the **Orange** key.
- 2 Select **Tracks > Current > TracBack**.



Your current location ①, track to follow ②, and end point ③ appear on the map.

Stopping Navigation

- 1 Select the **Orange** key.
- 2 Select **Stop Nav..**

Setting Alerts

You can set the device to alert you in many different situations where your awareness of the surrounding conditions or other data is important. For example, you can set the device to alert you when you reach a specified elevation.

- 1 Select the **Orange** key.
- 2 Select **Alerts**.
- 3 Follow the on-screen instructions.

Troubleshooting





Getting the Owner's Manual

You can get the latest owner's manual from the web.

- 1 Go to www.garmin.com/support.
- 2 Select **Product Documentation**.
- 3 Follow the on-screen instructions to select your product.



Locking the Keys

You can lock the keys to prevent inadvertent key presses.

- 1 Select the data page you want to view while the keys are locked.
- 2 Hold  and  to lock the keys.
- 3 Hold  and  to unlock the keys.

Resetting Your Device

If the device stops responding, you may need to reset it.

- 1 Hold  for at least 25 seconds.
- 2 Hold  for one second to turn on the device.

Specifications

Battery type	500 mAh Lithium-ion battery
--------------	-----------------------------

Battery life	Up to 6 weeks NOTE: The actual battery life depends on how much you use GPS, device sensors, optional wireless sensors, and the backlight (page 13).
Water resistance	Water resistant to 164 ft. (50 m)
Operating temperature range	From -4°F to 122°F (from -20°C to 50°C)
Radio frequency/ protocol	2.4 GHz ANT+™ wireless communications protocol Bluetooth® Smart device

Battery Information

The actual battery life depends on how much you use GPS, device sensors, optional wireless sensors, and the backlight.

Battery Life	Mode
16 hours	GPS normal mode
50 hours	GPS long-term mode
2–3 weeks	Continuous sensor mode
Up to 6 weeks	Watch mode

Registering Your Device

Help us better support you by completing our online registration today.

- Go to <http://my.garmin.com>.
- Keep the original sales receipt, or a photocopy, in a safe place.

Device Care

NOTICE

Do not use a sharp object to clean the device.

Avoid chemical cleaners and solvents that can damage plastic components.

Avoid pressing the keys under water.




Avoid extreme shock and harsh treatment, because it can degrade the life of the product.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Getting More Information

You can find more information about this product on the Garmin® website.

- Go to www.garmin.com/outdoor.
- Go to www.garmin.com/learningcenter.
- Go to <http://buy.garmin.com>, or contact your Garmin dealer for information about optional accessories and replacement parts.



Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin. ANT+™, BaseCamp™, fēnix™, and tempe™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. Mac® is a registered trademark of Apple Computer, Inc. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. Other trademarks and trade names are those of their respective owners.



MT102



© 2012 Garmin Ltd. or its subsidiaries

Garmin International, Inc.

1200 East 151st Street
Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.

Liberty House, Hounsdown Business Park
Southampton, Hampshire, SO40 9LR UK

Garmin Corporation

No. 68, Zangshu 2nd Road, Xizhi Dist.
New Taipei City, 221, Taiwan (R.O.C.)

www.garmin.com/support

June 2012

190-01507-01_01

Printed in Taiwan