## 6. TRANSMITTER OPERATION AND MOVEMENT OF EACH SERVO

### 1. Aileron Left Right Right (Viewed from the rear) Left


3. Throttle

High

High S

Engin throttle lever moves to the high speed side.

### 2. Elevator (Mode 1) Down Пþ Down (Mode 2) Цþ Down ф



### UTIONS

(Mode 1)

(Mode 2) Low

Engin throttle lever moves to the low speed side.

Low

Low

- Do not fly simultaneously on the same frequency.
- Extend the antenna to its full length, Always carry out a range check prior to fight.
- Always turn the transmitter on first, then the receiver. When you turn the system off, always turn the receiver off first then transmitter.

others as well as loss of control could occur. This step is very important always follow this procedure. If this procedure is not followed, injury to yourself and



# arand wing servo-tech co., Ita.

4F., 183, SEC. 1, TA-TUNG RD., SHI-JR CITY, TAIPEI HSIEN 221, TAIWAN http://www.gws.com.tw http://www.grandwing.com.tw TEL: 886-2-2647-0057~9/2643-3655~6 FAX: +886-2-2643-0292 E-mail: gws.tw@msa.hinet.net

### 1.INTRODUCTION

and developed using the latest manufacturing technologies and incorporate the finest modern precision electronic components.. GWS System are compatible with PPM (FM) System from Thank you for purchasing the GWS 4-Channel Radio System. This unit has been designed FUTABA, JR, Sanwa/Airtronics and Hi-tec. (72 Mhz only for . Д

Please read these instructions carefully in order to obtain safe operation and maximum performance from your GWS system.

## ZATRANSMITHER SPECIFICATIONS

Encoder: 4-Channel Model Number: GWT-4A

Frequency: 35, 36, 40, 41, 72 MHz

Modulation: PPM (FM)

Low Battery Indicator : Below 9.1V (LED turn to Red)


Power Source: 1.2V x 8 Ni-Cd Current Drain: 100mA RF Power: Approximately 350mw

Control range : 1.5ms  $\pm$  0.5ms

or 1.5V x 8 Dry Cell (AA SIZE)

### IRANSMI I ER

## TRANSMITTER T-4A (FRONT PANEL)




1. Throttle (Ch1)
2. Alleron (Ch2)
3. Elevator (Ch3)
4. Rudder (Ch4) Channel display reverse side.


Operating direction display

NOR: Normal side


## TRANSMITTER T-4A (REAR PANEL)




Use when replacing the battery. Slide the cover downward while pressing the part marked "PUSH".



### 5. CONNECTIONS



### FOR ELECTRIC POWER



### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### WARNING

To assure continued compliance, (example – use only shielded interface cables when connecting to computer or peripheral devices) any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### GRAND WING SERVO-TECH CO., LTD.

4F., 183, SEC. 1, TA-TUNG RD., SHI-JR CITY, TAIPEI HSIEN 221, TAIWAN TEL:886-2-2647-0057~9/2643-3655-6

FAX: 886-2-2643-0292

http://www.gws.com.tw http://www.grandwing.com.tw e-mail:gws.tw@msa.hinet.net