



# Grandstream Networks, Inc.

---

UCM6200 Series IP PBX

User Manual



# UCM6200 Series IP PBX User Manual

## Table of Content

<b>GNU GPL INFORMATION</b> .....	<b>17</b>
<b>CHANGE LOG</b> .....	<b>18</b>
<b>FIRMWARE VERSION 1.0.0.1</b> .....	18
<b>WELCOME</b> .....	<b>19</b>
<b>PRODUCT OVERVIEW</b> .....	<b>21</b>
TECHNICAL SPECIFICATIONS .....	21
<b>INSTALLATION</b> .....	<b>25</b>
EQUIPMENT PACKAGING .....	25
CONNECT YOUR UCM6200 .....	25
<i>CONNECT THE UCM6202</i> .....	25
<i>CONNECT THE UCM6204</i> .....	26
<i>CONNECT THE UCM6208</i> .....	27
SAFETY COMPLIANCES .....	28
WARRANTY .....	28
<b>GETTING STARTED</b> .....	<b>31</b>
USE THE LCD MENU .....	31
USE THE LED INDICATORS .....	33
USE THE WEB GUI .....	34
<i>ACCESS WEB GUI</i> .....	34
<i>SETUP WIZARD</i> .....	36
<i>WEB GUI CONFIGURATIONS</i> .....	37
<i>WEB GUI LANGUAGES</i> .....	37
<i>SAVE AND APPLY CHANGES</i> .....	38
MAKE YOUR FIRST CALL.....	38
<b>SYSTEM SETTINGS</b> .....	<b>39</b>
USER MANAGEMENT .....	39
<i>USER PRIVILEGES</i> .....	39
<i>CREATE NEW WEB UI USER</i> .....	40
<i>USER PORTAL</i> .....	42
<i>CONCURRENT MULTI-USER LOGIN</i> .....	43

<i>OPERATION LOG</i> .....	43
CHANGE PASSWORD .....	45
<i>CHANGE BINDNG EMAIL</i> .....	46
NETWORK SETTINGS .....	47
<i>BASIC SETTINGS</i> .....	47
<i>802.1X</i> .....	52
<i>STATIC ROUTES</i> .....	53
<i>PORT FORWARDING</i> .....	56
<i>DDNS SETTINGS</i> .....	58
FIREWALL .....	60
<i>STATIC DEFENSE</i> .....	60
<i>DYNAMIC DEFENSE</i> .....	63
<i>FAIL2BAN</i> .....	64
LDAP SERVER.....	65
<i>LDAP SERVER CONFIGURATIONS</i> .....	66
<i>LDAP PHONEBOOK</i> .....	67
<i>LDAP CLIENT CONFIGURATIONS</i> .....	70
HTTP SERVER.....	72
EMAIL SETTINGS .....	73
TIME SETTINGS .....	74
<i>AUTO TIME UPDATING</i> .....	74
<i>SET TIME MANUALLY</i> .....	76
<i>OFFICE TIME</i> .....	76
<i>HOLIDAY</i> .....	78
NTP SERVER.....	80
RECORDINGS STORAGE.....	80
LOGIN TIMEOUT SETTINGS .....	82
GOOGLE SERVICE SETTINGS SUPPORT .....	83
<b>PROVISIONING .....</b>	<b>87</b>
OVERVIEW .....	87
CONFIGURATION ARCHITECTURE FOR END POINT DEVICE.....	87
AUTO PROVISIONING SETTINGS .....	88
DISCOVERY.....	91
GLOBAL CONFIGURATION .....	92
<i>GLOBAL POLICY</i> .....	92
<i>GLOBAL TEMPLATES</i> .....	100
MODEL CONFIGURATION .....	102
<i>MODEL TEMPLATES</i> .....	102
<i>MODEL UPDATE</i> .....	104
DEVICE CONFIGURATION .....	105

<i>CREATE NEW DEVICE</i> .....	105
<i>MANAGE DEVICES</i> .....	106
SAMPLE APPLICATION.....	113
<b>EXTENSIONS.....</b>	<b>119</b>
CREATE NEW USER.....	119
<i>CREATE NEW SIP EXTENSION</i> .....	119
<i>CREATE NEW IAX EXTENSION</i> .....	125
<i>CREATE NEW FXS EXTENSION</i> .....	129
BATCH ADD EXTENSIONS .....	134
<i>BATCH ADD SIP EXTENSIONS</i> .....	134
<i>BATCH ADD IAX EXTENSIONS</i> .....	137
SEARCH AND EDIT EXTENSION .....	139
EXPORT EXTENSIONS.....	141
IMPORT EXTENSIONS.....	141
EMAIL TO USER .....	142
MULTIPLE REGISTRATIONS PER EXTENSION.....	144
SMS MESSAGE SUPPORT.....	145
<b>TRUNKS.....</b>	<b>147</b>
ANALOG TRUNKS.....	147
<i>ANALOG TRUNK CONFIGURATION</i> .....	147
<i>PSTN DETECTION</i> .....	150
VOIP TRUNKS .....	153
<i>DIRECT OUTWARD DIALING (DOD)</i> .....	164
<b>SLA STATION .....</b>	<b>167</b>
CREATE/EDIT SLA STATION .....	167
SAMPLE CONFIGURATION .....	168
<b>CALL ROUTES .....</b>	<b>171</b>
OUTBOUND ROUTES.....	171
INBOUND ROUTES .....	173
<i>INBOUND RULE CONFIGURATIONS</i> .....	174
<i>INBOUND ROUTE: PREPEND EXAMPLE</i> .....	175
<i>INBOUND ROUTE: MULTIPLE MODE</i> .....	176
<i>FAX INTELLIGENT ROUTE</i> .....	177
<i>FAX WITH TWO MEDIA</i> .....	178
<i>BLACKLIST CONFIGURATIONS</i> .....	178
<b>CONFERENCE BRIDGE.....</b>	<b>181</b>

<i>CONFERENCE BRIDGE CONFIGURATIONS</i> .....	181
<i>JOIN A CONFERENCE CALL</i> .....	183
<i>INVITE OTHER PARTIES TO JOIN CONFERENCE</i> .....	183
<i>DURING THE CONFERENCE</i> .....	184
<i>RECORD CONFERENCE</i> .....	185
<b>CONFERENCE SCHEDULE</b> .....	<b>187</b>
CONFERENCE SCHEUDLE CONFIGURATION.....	187
<b>IVR</b> .....	<b>191</b>
CONFIGURE IVR .....	191
CREATE CUSTOM PROMPT .....	193
<i>RECORD NEW CUSTOM PROMPT</i> .....	193
<i>UPLOAD CUSTOM PROMPT</i> .....	194
<b>LANGUAGE SETTINGS FOR VOICE PROMPT</b> .....	<b>195</b>
DOWNLOAD AND INSTALL VOICE PROMPT PACKAGE.....	195
CUSTOMIZE SPECIFIC PROMPT .....	197
<b>VOICEMAIL</b> .....	<b>199</b>
CONFIGURE VOICEMAIL .....	199
ACCESS VOICEMAIL .....	200
VOICEMAIL EMAIL SETTINGS .....	201
CONFIGURE VOICEMAIL GROUP .....	202
<b>RING GROUP</b> .....	<b>205</b>
CONFIGURE RING GROUP .....	205
REMOTE EXTENSION IN RING GROUP .....	207
<b>PAGING AND INTERCOM GROUP</b> .....	<b>211</b>
CONFIGURE PAGING/INTERCOM GROUP.....	211
<b>CALL QUEUE</b> .....	<b>213</b>
CONFIGURE CALL QUEUE .....	213
<b>EXTENSION GROUPS</b> .....	<b>217</b>
CONFIGURE EXTENSION GROUPS .....	217
USING EXTENSION GROUPS.....	218
<b>PICKUP GROUPS</b> .....	<b>219</b>
CONFIGURE PICKUP GROUPS .....	219

CONFIGURE PICKUP FEATURE CODE.....	219
<b>MUSIC ON HOLD.....</b>	<b>221</b>
<b>FAX/T.38.....</b>	<b>223</b>
CONFIGURE FAX/T.38 .....	223
SAMPLE CONFIGURATION TO RECEIVE FAX FROM PSTN LINE .....	224
SAMPLE CONFIGURATION FOR FAX-TO-EMAIL .....	227
<b>ASTERISK MANAGER INTERFACE (RESTRICTED ACCESS).....</b>	<b>229</b>
<b>BUSY CAMP-ON.....</b>	<b>231</b>
<b>FOLLOW ME.....</b>	<b>233</b>
<b>ONE-KEY DIAL .....</b>	<b>237</b>
<b>DISA.....</b>	<b>239</b>
<b>CALLBACK FEATURE .....</b>	<b>241</b>
<b>BLF AND EVENT LIST.....</b>	<b>243</b>
BLF .....	243
EVENT LIST .....	243
<b>DIAL BY NAME.....</b>	<b>247</b>
DIAL BY NAME CONFIGURATION.....	247
<b>ACTIVE CALLS AND MONITOR .....</b>	<b>251</b>
ACTIVE CALLS STATUS .....	251
HANG UP ACTIVE CALLS .....	252
CALL MONITOR.....	252
<b>CALL FEATURES .....</b>	<b>255</b>
FEATURE CODES .....	255
CALL RECORDING.....	259
CALL PARK .....	260
<i>PARK A CALL .....</i>	<i>260</i>
<i>RETRIEVE THE PARKED CALL .....</i>	<i>260</i>
ENABLE SPY .....	260
<b>INTERNAL OPTIONS.....</b>	<b>263</b>

INTERNAL OPTIONS/GENERAL .....	263
INTERNAL OPTIONS/JITTER BUFFER .....	265
INTERNAL OPTIONS/RTP SETTINGS .....	266
INTERNAL OPTIONS/PAYLOAD .....	266
<b>IAX SETTINGS .....</b>	<b>269</b>
IAX SETTINGS/GENERAL .....	269
IAX SETTINGS/REGISTRATION .....	269
IAX SETTINGS/STATIC DEFENSE .....	270
<b>SIP SETTINGS .....</b>	<b>271</b>
SIP SETTINGS/GENERAL .....	271
SIP SETTINGS/MISC .....	271
SIP SETTINGS/SESSION TIMER .....	272
SIP SETTINGS/TCP AND TLS .....	272
SIP SETTINGS/NAT .....	273
SIP SETTINGS/TOS .....	274
<b>PORTS CONFIG .....</b>	<b>277</b>
<b>VALUE-ADDED FEATURES .....</b>	<b>279</b>
FAX SENDING .....	279
ANNOUNCEMENTS CENTER .....	279
<i>ANNOUNCEMENTS CENTER SETTINGS</i> .....	280
<i>GROUP SETTINGS</i> .....	280
<b>STATUS AND REPORTING .....</b>	<b>283</b>
PBX STATUS .....	283
<i>TRUNKS</i> .....	283
<i>EXTENSIONS</i> .....	284
<i>QUEUES</i> .....	285
<i>CONFERENCE ROOMS</i> .....	286
<i>INTERFACES STATUS</i> .....	287
<i>PARKING LOT</i> .....	288
SYSTEM STATUS .....	289
<i>GENERAL</i> .....	289
<i>NETWORK</i> .....	290
<i>STORAGE USAGE</i> .....	290
<i>RESOURCE USAGE</i> .....	291
SYSTEM EVENTS .....	292
<i>ALERT EVENTS LIST</i> .....	292

ALERT LOG .....	294
ALERT CONTACT .....	295
CDR .....	295
CDR IMPROVEMENT .....	298
DOWNLOADED CDR FILE .....	299
STATISTICS.....	301
RECORDING FILES.....	301
API CONFIGURATION.....	302

## **UPGRADING AND MAINTENANCE .....305**

UPGRADING .....	305
UPGRADING VIA NETWORK.....	305
UPGRADING VIA LOCAL UPLOAD.....	306
NO LOCAL FIRMWARE SERVERS.....	308
BACKUP .....	308
BACKUP/RESTORE.....	308
DATA SYNC.....	311
RESTORE CONFIGURATION FROM BACKUP FILE .....	312
CLEANER.....	313
RESET AND REBOOT .....	314
SYSLOG .....	315
TROUBLESHOOTING .....	315
ETHERNET CAPTURE .....	315
IP PING .....	316
TRACEROUTE .....	317
ANALOG RECORD TRACE.....	317
SERVICE CHECK .....	318
NETWORK STATUS.....	318
REMOTE ACCESS.....	319
SSH ACCESS.....	319

## **EXPERIENCING THE UCM6200 SERIES IP PBX .....321**



**Table of Tables**  
**UCM6200 Series IP PBX User Manual**

Table 1: Technical Specifications.....	21
Table 2: UCM6202/UCM6204 Equipment Packaging.....	25
Table 3: LCD Menu Options.....	32
Table 4: UCM6202/UCM6204 LED INDICATORS.....	33
Table 5: UCM6208 LED INDICATORS.....	34
Table 6: User Management->Create New User.....	41
Table 7: Operation Log Column Header.....	44
Table 8: Change Binding Email option.....	47
Table 9: UCM6202/UCM6204 Network Settings->Basic Settings.....	47
Table 10: UCM6208 Network Settings->Basic Settings.....	49
Table 11: UCM6200 Network Settings->802.1X.....	53
Table 12: UCM6200 Network Settings->Static Routes.....	54
Table 13: UCM6202/UCM6204 Network Settings->Port Forwarding.....	56
Table 14: UCM6200 Firewall->Static Defense->Current Service.....	61
Table 15: Typical Firewall Settings.....	61
Table 16: Firewall Rule Settings.....	62
Table 17: UCM6200 Firewall Dynamic Defense.....	63
Table 18: Fail2Ban Settings.....	64
Table 19: HTTP Server Settings.....	73
Table 20: Email Settings.....	73
Table 21: Time Auto Updating.....	75
Table 22: Create New Office Time.....	77
Table 23: Create New Holiday.....	79
Table 24: Auto Provision Settings.....	90
Table 25: Global Policy Parameters->Localization.....	93
Table 26: Global Policy Parameters->Phone Settings.....	94
Table 27: Global Policy Parameters->Contact List.....	95
Table 28: Global Policy Parameters->Maintenance.....	97
Table 29: Global Policy Parameters->Network Settings.....	98
Table 30: Global Policy Parameters->Customization.....	99
Table 31: Create New Template.....	100
Table 32: Create New Model Template.....	102
Table 33: SIP Extension Configuration Parameters->Basic Settings.....	120
Table 34: SIP Extension Configuration Parameters->Media.....	121
Table 35: SIP Extension Configuration Parameters->Features.....	122
Table 36: SIP Extension Configuration Parameters->Specific Time.....	125
Table 37: IAX Extension Configuration Parameters->Basic Settings.....	125
Table 38: IAX Extension Configuration Parameters->Media.....	126

Table 39: IAX Extension Configuration Parameters->Features .....	127
Table 40: IAX Extension Configuration Parameters->Specific Time .....	129
Table 41: FXS Extension Configuration Parameters->Basic Settings .....	130
Table 42: FXS Extension Configuration Parameters->Media .....	131
Table 43: FXS Extension Configuration Parameters->Features .....	132
Table 44: FXS Extension Configuration Parameters->Specific Time .....	134
Table 45: Batch Add SIP Extension Parameters .....	135
Table 46: Batch Add IAX Extension Parameters .....	137
Table 47: Analog Trunk Configuration Parameters .....	147
Table 48: PSTN Detection for Analog Trunk .....	152
Table 49: Create New SIP Trunk .....	154
Table 50: SIP Register Trunk Configuration Parameters .....	155
Table 51: SIP Peer Trunk Configuration Parameters .....	158
Table 52: Create New IAX Trunk .....	161
Table 53: IAX Register Trunk Configuration Parameters .....	161
Table 54: IAX Peer Trunk Configuration Parameters .....	162
Table 55: SLA Station Configuration Parameters .....	167
Table 56: Outbound Route Configuration Parameters .....	171
Table 57: Inbound Rule Configuration Parameters .....	174
Table 58: Conference Bridge Configuration Parameters .....	181
Table 59: Conference Caller IVR Menu .....	185
Table 60: Conference Schedule Parameters .....	187
Table 61: IVR Configuration Parameters .....	191
Table 62: Voicemail Settings .....	199
Table 63: Voicemail IVR Menu .....	200
Table 64: Voicemail Email Settings .....	201
Table 65: Voicemail Group Settings .....	203
Table 66: Ring Group Parameters .....	205
Table 67: Paging/Intercom Group Configuration Parameters .....	211
Table 68: Call Queue Configuration Parameters .....	213
Table 69: FAX/T.38 Settings .....	223
Table 70: Follow Me Settings .....	234
Table 71: Follow Me Options .....	235
Table 72: DISA Settings .....	239
Table 73: Callback Configuration Parameters .....	241
Table 74: Event List Settings .....	243
Table 75: UCM6200 Feature Codes .....	255
Table 76: Internal Options/General .....	263
Table 77: Internal Options/Jitter Buffer .....	265
Table 78: Internal Options/RTP Settings .....	266
Table 79: Internal Options/Payload .....	266

Table 80: IAX Settings/General .....	269
Table 81: IAX Settings/Registration .....	269
Table 82: IAX Settings/Static Defense .....	270
Table 83: SIP Settings/General .....	271
Table 84: SIP Settings/Misc .....	271
Table 85: SIP Settings/Session Timer .....	272
Table 86: SIP Settings/TCP and TLS .....	272
Table 87: SIP Settings/NAT .....	273
Table 88: SIP Settings/ToS.....	274
Table 89: Internal Options/Ports Config .....	277
Table 90: Announcements Center Settings .....	280
Table 91: Group Settings.....	280
Table 92: Trunk Status.....	283
Table 93: Extension Status.....	285
Table 94: Agent Status .....	286
Table 95: Interface Status Indicators .....	287
Table 96: Parking Lot Status .....	288
Table 97: System Status->General .....	289
Table 98: System Status->Network .....	290
Table 99: CDR Filter Criteria .....	296
Table 100: CDR Statistics Filter Criteria .....	301
Table 101: API Configuration Files .....	302
Table 102: Network Upgrade Configuration .....	306
Table 103: Data Sync Configuration .....	311
Table 104: Cleaner Configuration .....	313

**Table of Figures**  
**UCM6200 Series IP PBX User Manual**

Figure 1: UCM6202 Front View.....	25
Figure 2: UCM6202 Back View.....	26
Figure 3: UCM6204 Front View.....	26
Figure 4: UCM6204 Back View.....	27
Figure 5: UCM6208 Front View.....	28
Figure 6: UCM6208 Back View.....	28
Figure 7: UCM6204 Web GUI Login Page.....	34
Figure 8: UCM6200 Setup Wizard.....	36
Figure 9: UCM6200 Web GUI Language.....	37
Figure 10: User Management Page Display.....	39
Figure 11: Create New User.....	41
Figure 12: User Management – New Users.....	41
Figure 13: Edit User Information by Super Admin.....	42
Figure 14: User Portal Login.....	42
Figure 15: User Portal Layout.....	43
Figure 16: Multiple User Operation Error Prompt.....	43
Figure 17: Operation Logs.....	44
Figure 18: Operation Logs Filter.....	45
Figure 19 : Change Password.....	46
Figure 20: Change Binding Email.....	46
Figure 21: UCM6200 Network Interface Method: Route.....	50
Figure 22: UCM6200 Network Interface Method: Switch.....	51
Figure 23: UCM6200 Network Interface Method: Dual.....	52
Figure 24: UCM6200 Using 802.1X as Client.....	52
Figure 25: UCM6200 Using 802.1X EAP-MD5.....	53
Figure 26: UCM6204 Static Route Sample.....	55
Figure 27: UCM6204 Static Route Configuration.....	55
Figure 28: UCM6202/UCM6204 Port Forwarding Configuration.....	57
Figure 29: GXP2160 Web Access Using UCM6202 Port Forwarding.....	58
Figure 30: Register Domain Name on noip.com.....	59
Figure 31: UCM6200 DDNS Setting.....	59
Figure 32: Using Domain Name to Connect to UCM6200.....	60
Figure 33: Create New Firewall Rule.....	62
Figure 34: Configure Dynamic Defense.....	64
Figure 35: LDAP Server Configurations.....	66
Figure 36: Default LDAP Phonebook DN.....	66
Figure 37: Default LDAP Phonebook Attributes.....	67
Figure 38: LDAP Server->LDAP Phonebook.....	67

Figure 39: Add LDAP Phonebook .....	68
Figure 40: Edit LDAP Phonebook .....	68
Figure 41: Import Phonebook.....	69
Figure 42: Phonebook CSV File Format .....	69
Figure 43: LDAP Phonebook After Import.....	70
Figure 44: Export Selected LDAP Phonebook .....	70
Figure 45: LDAP Client Configurations .....	71
Figure 46: GXP2200 LDAP Phonebook Configuration .....	72
Figure 47: UCM6200 Email Settings.....	74
Figure 48: Set Time Manually .....	76
Figure 49: Create New Office Time.....	77
Figure 50: Settings->Time Settings->Office Time .....	78
Figure 51: Create New Holiday .....	78
Figure 52: Settings->Time Settings->Holiday .....	79
Figure 53: Settings->Recordings Storage .....	80
Figure 54: Recordings Storage Prompt Information .....	81
Figure 55: Recording Storage Category .....	81
Figure 56: Login Timeout Settings .....	82
Figure 57: Google Service Settings->OAuth2.0 Authentication .....	83
Figure 58: Google Service->New Project .....	84
Figure 59: Google Service->Create New Credential .....	84
Figure 60: Google Service->OAuth2.0 Login.....	85
Figure 61: Zero Config Configuration Architecture for End Point Device .....	88
Figure 62: UCM6200 Zero Config .....	89
Figure 63: Auto Provision Settings .....	90
Figure 64: Auto Discover.....	92
Figure 65: Discovered Devices .....	92
Figure 66: Global Policy Categories .....	93
Figure 67: Edit Global Template.....	101
Figure 68: Edit Model Template .....	103
Figure 69: Template Management .....	104
Figure 70: Upload Model Template Manually.....	105
Figure 71: Create New Device .....	106
Figure 72: Manage Devices .....	106
Figure 73: Edit Device.....	107
Figure 74: Edit Customize Device Settings.....	109
Figure 75: Add P Value in Customize Device Settings .....	110
Figure 76: Modify Selected Devices - Same Model.....	111
Figure 77: Modify Selected Devices - Different Models.....	112
Figure 78: Device List in Zero Config.....	113
Figure 79: Zero Config Sample - Global Policy.....	114

Figure 80: Zero Config Sample - Device Preview 1.....	115
Figure 81: Zero Config Sample - Device Preview 2.....	116
Figure 82: Zero Config Sample - Device Preview 3.....	117
Figure 83: Create New Device.....	119
Figure 84: Manage Extensions.....	140
Figure 85: Export Extensions.....	141
Figure 86: Import Extensions.....	141
Figure 87: Email To User - Prompt Information.....	142
Figure 88: Account Registration Information and QR Code.....	143
Figure 89: LDAP Client Information and QR Code.....	143
Figure 90: Multiple Registrations per Extension.....	144
Figure 91: Extension - Concurrent Registration.....	144
Figure 92: SMS Message Support.....	145
Figure 93: UCM6200 FXO Tone Settings.....	150
Figure 94: UCM6200 PSTN Detection.....	151
Figure 95: UCM6200 PSTN Detection: Auto Detect.....	151
Figure 96: UCM6200 PSTN Detection: Semi-Auto Detect.....	152
Figure 97: DOD extension selection.....	164
Figure 98: Edit DOD.....	165
Figure 99: SLA Station.....	167
Figure 100: Enable SLA Mode for Analog Trunk.....	169
Figure 101: Analog Trunk with SLA Mode Enabled.....	169
Figure 102: SLA Example - SLA Station.....	169
Figure 103: SLA Example - MPK Configuration.....	170
Figure 104: Inbound Route feature: Prepend.....	176
Figure 105: Inbound Route - Multiple Mode.....	177
Figure 106: Blacklist Configuration Parameters.....	178
Figure 107: Blacklist csv File.....	179
Figure 108: Conference Invitation From Web GUI.....	183
Figure 109: Conference Recording.....	186
Figure 110: Conference Schedule.....	190
Figure 111: Click on Prompt to Create IVR Prompt.....	193
Figure 112: Record New Custom Prompt.....	194
Figure 113: Upload Custom Prompt.....	194
Figure 114: Language Settings for Voice Prompt.....	195
Figure 115: Voice Prompt Package List.....	196
Figure 116: New Voice Prompt Language Added.....	196
Figure 117: Upload Single Voice Prompt for Entire Language Pack.....	197
Figure 118: Voicemail Email Settings.....	202
Figure 119: Voicemail Group.....	203
Figure 120: Ring Group.....	205

Figure 121: Ring Group Configuration .....	207
Figure 122: Sync LDAP Server option .....	208
Figure 123: Manually Sync LDAP Server .....	208
Figure 124: Ring Group Remote Extension .....	209
Figure 125: Paging/Intercom Group.....	211
Figure 126: Page/Intercom Group Settings .....	212
Figure 127: Call Queue .....	213
Figure 128: Agent Login Settings .....	216
Figure 129: Edit Extension Group.....	217
Figure 130: Select Extension Group in Outbound Route.....	218
Figure 131: Edit Pickup Group .....	219
Figure 132: Edit Pickup Feature Code.....	220
Figure 133: Music On Hold Default Class.....	221
Figure 134: Configure Analog Trunk without Fax Detection .....	225
Figure 135: Configure Extension for Fax Machine: FXS Extension .....	225
Figure 136: Configure Extension for Fax Machine: Analog Settings .....	226
Figure 137: Configure Inbound Rule for Fax.....	226
Figure 138: Create Fax Extension .....	227
Figure 139: Inbound Route to Fax Extension .....	228
Figure 140: Create Follow Me.....	233
Figure 141: Edit Follow Me .....	233
Figure 142: Configure One-Key Dial.....	237
Figure 143: One-Key Dial Destinations.....	238
Figure 144: Create New DISA.....	239
Figure 145: Create New Event List .....	244
Figure 146: Create Dial By Name Group .....	247
Figure 147: Dial By Name Group In IVR Key Pressing Events .....	248
Figure 148: Dial By Name Group In Inbound Rule .....	249
Figure 149: Configure Extension First Name and Last Name .....	250
Figure 150: Status->PBX Status->Active Calls - Ringing.....	251
Figure 151: Status->PBX Status->Active Calls – Call Established .....	251
Figure 152: Configure to Monitor an Active Call .....	252
Figure 153: Download Recording File from CDR Page .....	259
Figure 154: Download Recording File from Recording Files Page.....	260
Figure 155: FXS Ports Signaling Preference .....	277
Figure 156: FXO Ports ACIM Settings .....	277
Figure 157: Fax Sending in Web UI.....	279
Figure 158: Announcements Center .....	280
Figure 159: Announcements Center Group Configuration.....	281
Figure 160: Announcements Center Code Configuration .....	282
Figure 161: Announcements Center Example .....	282

Figure 162: Status->PBX Status .....	283
Figure 163: Trunk Status .....	283
Figure 164: Extension Status .....	284
Figure 165: Queue Status .....	286
Figure 166: Conference Room Status.....	287
Figure 167: UCM6204 Interfaces Status.....	287
Figure 168: Parking Lot Status.....	288
Figure 169: System Status->Storage Usage.....	291
Figure 170: System Status->Resource Usage.....	291
Figure 171: System Events->Alert Events Lists: Disk Usage .....	292
Figure 172: System Events->Alert Events Lists: Memory Usage .....	293
Figure 173: System Events->Alert Events Lists: System Reboot.....	293
Figure 174: System Events->Alert Events Lists: System Crash.....	293
Figure 175: System Events->Alert Log .....	294
Figure 176: Filter for Alert Log .....	295
Figure 177: CDR Filter .....	296
Figure 178: Call Report .....	297
Figure 179: Call Report Entry with Audio Recording File.....	297
Figure 180: Automatic Download Settings .....	298
Figure 181: CDR Report .....	298
Figure 182: Detailed CDR Information.....	299
Figure 183: Downloaded CDR File Sample - Call To Shows "s" .....	299
Figure 184: Downloaded CDR File Sample - Source Channel and Dest Channel 1.....	300
Figure 185: Downloaded CDR File Sample - Source Channel and Dest Channel 2.....	300
Figure 186: Downloaded CDR File Sample - Source Channel and Dest Channel 3.....	300
Figure 187: CDR Statistics .....	301
Figure 188: CDR->Recording Files.....	302
Figure 189: Network Upgrade.....	305
Figure 190: Local Upgrade.....	306
Figure 191: Upgrading Firmware Files.....	307
Figure 192: Reboot UCM6200 .....	307
Figure 193: Create New Backup.....	309
Figure 194: Backup / Restore .....	310
Figure 195: Local Backup .....	310
Figure 196: Data Sync .....	311
Figure 197: Restore UCM6200 from Backup File.....	312
Figure 198: Cleaner .....	313
Figure 199: Reset and Reboot.....	314
Figure 200: Ethernet Capture.....	316
Figure 201: PING .....	316
Figure 202: Traceroute.....	317



Figure 203: Troubleshooting Analog Trunks .....	318
Figure 204: Service Check.....	318
Figure 205: Network Status.....	319
Figure 206: SSH Access .....	320

## GNU GPL INFORMATION

UCM6200 firmware contains third-party software licensed under the GNU General Public License (GPL). Grandstream uses software under the specific terms of the GPL. Please see the GNU General Public License (GPL) for the exact terms and conditions of the license.

Grandstream GNU GPL related source code can be downloaded from Grandstream web site from:

<http://www.grandstream.com/support/faq/gnu-general-public-license/gnu-gpl-information-download>

## CHANGE LOG

This section documents significant changes from previous versions of the UCM6200 user manuals. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

### **FIRMWARE VERSION 1.0.0.1**

- This is the initial version.

## WELCOME

Thank you for purchasing Grandstream UCM6200 series IP PBX appliance. The UCM6200 series IP PBX appliance is designed to bring enterprise-grade voice, video, data, and mobility features to small-to-medium businesses (SMBs) in an easy-to-manage fashion. This IP PBX series allows businesses to unify multiple communication technologies, such comprehensive voice, video calling, video conferencing, video surveillance, data tools and facility access management onto one common network that that can be managed and/or accessed remotely. The UCM6200 series supports a dual core 1GHz ARM Cortex™ A9 and 400Mhz VINETIC™ A8 processors, 1GB RAM and 4GB flash. The secure and reliable UCM6200 series delivers enterprise-grade features without any licensing fees, costs-per-feature or recurring fees.



**Caution:**

Changes or modifications to this product not expressly approved by Grandstream, or operation of this product in any way other than as detailed by this User Manual, could void your manufacturer warranty.



**Warning:**

Please do not use a different power adaptor with the UCM6200 as it may cause damage to the products and void the manufacturer warranty.

---

This document is subject to change without notice. The latest electronic version of this user manual is available for download here:

<http://www.grandstream.com/support>

Reproduction or transmittal of the entire or any part, in any form or by any means, electronic or print, for any purpose without the express written permission of Grandstream Networks, Inc. is not permitted.



## PRODUCT OVERVIEW

### TECHNICAL SPECIFICATIONS

**Table 1: Technical Specifications**

Interfaces	
<b>Analog Telephone FXS Ports</b>	2 ports (both with lifeline capability in case of power outage)
<b>PSTN Line FXO Ports</b>	<ul style="list-style-type: none"> <li>• UCM6202: 2 ports</li> <li>• UCM6204: 4 ports</li> <li>• UCM6208: 8 ports</li> </ul>
<b>Network Interfaces</b>	<ul style="list-style-type: none"> <li>• UCM6202/6204: Dual Gigabit RJ45 ports with integrated PoE Plus (IEEE 802.3at-2009)</li> <li>• UCM6208: Single Gigabit RJ45 port with integrated PoE Plus (IEEE 802.3at-2009)</li> </ul>
<b>NAT Router</b>	Yes, UCM6204/UCM6208 only
<b>Peripheral Ports</b>	USB, SD
<b>LED Indicators</b>	Power/Ready, Network, PSTN Line, USB, SD
<b>LCD Display</b>	128x32 graphic LCD with DOWN and OK button
<b>Reset Switch</b>	Yes
Voice/Video Capabilities	
<b>Voice-over-Packet Capabilities</b>	LEC with NLP Packetized Voice Protocol Unit, 128ms-tail-length carrier grade Line Echo Cancellation, Dynamic Jitter Buffer, Modem detection and auto-switch to G.711
<b>Voice and Fax Codecs</b>	G.711 A-law/U-law, G.722, G.723.1 5.3K/6.3K, G.726, G.729A/B, iLBC (30ms only), GSM, AAL2-G.726-32, ADPCM; T.38
<b>Video Codecs</b>	H.264, H.263, H.263+, VP8
<b>QoS</b>	Layer 3 QoS, Layer 2 QoS
Signaling and Control	
<b>DTMF Methods</b>	In Audio, RFC2833, and SIP INFO
<b>Provisioning Protocol and Plug-and-Play</b>	TFTP/HTTP/HTTPS, auto-discovery and auto-provisioning of Grandstream IP endpoints via ZeroConfig (DHCP Option 66/multicast SIP SUBSCRIBE/mDNS), eventlist between local and remote trunk
<b>Network Protocols</b>	TCP/UDP/IP, RTP/RTCP, ICMP, ARP, DNS, DDNS, DHCP, NTP, TFTP, SSH, HTTP/HTTPS, PPPoE, SIP (RFC3261), STUN, SRTP, TLS
<b>Disconnect Methods</b>	Call Progress Tone, Polarity Reversal, Hook Flash Timing, Loop Current Disconnect, Busy Tone

Security	
<b>Media</b>	SRTP, TLS, HTTPS, SSH
Physical	
<b>Universal Power Supply</b>	<ul style="list-style-type: none"> <li>Output: 12VDC, 1.5A</li> <li>Input: 100-240VAC, 50-60Hz</li> </ul>
<b>Dimensions</b>	<ul style="list-style-type: none"> <li>UCM6202/6204: 226mm (L) x 155mm (W) x 34.5mm (H)</li> <li>UCM6208: 440mm (L) x 185mm (W) x 44mm (H)</li> </ul>
<b>Environmental</b>	<ul style="list-style-type: none"> <li>Operating: 32 - 104°F / 0 - 40°C, 10-90% (non-condensing)</li> <li>Storage: 14 - 140°F / -10 - 60°C</li> </ul>
<b>Mounting</b>	<ul style="list-style-type: none"> <li>UCM6202/6204: Wall mount and Desktop</li> <li>UCM6208: Rack mount and Desktop</li> </ul>
<b>Weight</b>	<ul style="list-style-type: none"> <li>UCM6202: Unit weight 0.51kg, Package weight 0.94kg</li> <li>UCM6204: Unit weight 0.51kg, Package weight 0.94kg</li> <li>UCM6208: Unit weight 2.23kg, Package weight 3.09kg</li> </ul>
Additional Features	
<b>Multi-language Support</b>	English/Simplified Chinese/Traditional Chinese/Spanish/French/Portuguese/German/Russian/Italian/Polish/Czech for Web UI; Customizable IVR/voice prompts for English, Chinese, British English, German, Spanish, Greek, French, Italian, Dutch, Polish, Portuguese, Russian, Swedish, Turkish, Hebrew, Arabic; Customizable language pack to support any other languages
<b>Caller ID</b>	Bellcore/Telcordia, ETSI-FSK, ETSI-DTMF, SIN 227 - BT
<b>Polarity Reversal/ Wink</b>	Yes, with enable/disable option upon call establishment and termination
<b>Call Center</b>	Multiple configurable call queues, automatic call distribution (ACD) based on agent skills/availability busy level, in-queue announcement
<b>Customizable Auto Attendant</b>	Up to 5 layers of IVR (Interactive Voice Response)
<b>Maximum Call Capacity</b>	<ul style="list-style-type: none"> <li>UCM6202: Concurrent audio calls up to 50, concurrent WebRTC calls up to 25</li> <li>UCM6204: Concurrent audio calls up to 75, concurrent WebRTC calls up to 35</li> <li>UCM6208: Concurrent audio calls up to 100, concurrent WebRTC calls up to 50</li> </ul> Or up to 66% performance if calls are SRTP encrypted
<b>Conference Bridges</b>	<ul style="list-style-type: none"> <li>UCM6202/6204: Up to 3 password-protected conference bridges allowing up to 25 simultaneous PSTN or IP participants</li> <li>UCM6208: Up to 6 password-protected conference bridges allowing up to 32 simultaneous PSTN or IP participants</li> </ul>

<b>Call Features</b>	Call park, call forward, call transfer, DND, ring/hunt group, paging/intercom and etc
<b>Compliance</b>	<ul style="list-style-type: none"> <li>• FCC: Part 15 (CFR 47) Class B, Part 68</li> <li>• CE: EN55022 Class B, EN55024, EN61000-3-2, EN61000-3-3, EN60950-1, TBR21, RoHS</li> <li>• A-TICK: AS/NZS CISPR 22 Class B, AS/NZS CISPR 24, AS/NZS 60950, AS/ACIF S002 and ITU-T K.21 (Basic Level)</li> <li>• UL 60950 (power adapter)</li> </ul>



**Note:**

- UCM6200 FXS ports lifeline functionality:  
 The UCM6200 FXS interfaces are metallic through to the FXO interfaces. If there is power outage, FXS1 port will fail over to FXO 1 port, FXS 2 port will fail over to FXO 2 port. The user can still access the PSTN connected with the FXO interfaces from FXS interfaces.
-





## INSTALLATION

Before deploying and configuring the UCM6200 series, the device needs to be properly powered up and connected to network. This section describes detailed information on installation, connection and warranty policy of the UCM6200 series.


### EQUIPMENT PACKAGING

**Table 2: UCM6202/UCM6204 Equipment Packaging**


<b>Main Case</b>	Yes (1)
<b>Power Adaptor</b>	Yes (1)
<b>Ethernet Cable</b>	Yes (1)
<b>Quick Installation Guide</b>	Yes (1)
<b>GPL License</b>	Yes (1)

### CONNECT YOUR UCM6200

#### CONNECT THE UCM6202



**Figure 1: UCM6202 Front View**




**Figure 2: UCM6202 Back View**


To set up the UCM6202, follow the steps below:

1. Connect one end of an RJ-45 Ethernet cable into the WAN port of the UCM6202.
2. Connect the other end of the Ethernet cable into the uplink port of an Ethernet switch/hub.
3. Connect the 12V DC power adapter into the 12V DC power jack on the back of the UCM6202. Insert the main plug of the power adapter into a surge-protected power outlet.
4. Wait for the UCM6202 to boot up. The LCD in the front will show the device hardware information when the boot process is done.
5. Once the UCM6202 is successfully connected to network, the LED indicator for WAN in the front will be in solid green and the LCD shows up the IP address.
6. (Optional) Connect PSTN lines from the wall jack to the FXO ports; connect analog lines (phone and Fax) to the FXS ports.

## CONNECT THE UCM6204



**Figure 3: UCM6204 Front View**



**Figure 4: UCM6204 Back View**

To set up the UCM6204, follow the steps below:

1. Connect one end of an RJ-45 Ethernet cable into the WAN port of the UCM6204.
2. Connect the other end of the Ethernet cable into the uplink port of an Ethernet switch/hub.
3. Connect the 12V DC power adapter into the 12V DC power jack on the back of the UCM6204. Insert the main plug of the power adapter into a surge-protected power outlet.
4. Wait for the UCM6204 to boot up. The LCD in the front will show the device hardware information when the boot process is done.
5. Once the UCM6204 is successfully connected to network, the LED indicator for WAN in the front will be in solid green and the LCD shows up the IP address.
6. (Optional) Connect PSTN lines from the wall jack to the FXO ports; connect analog lines (phone and Fax) to the FXS ports.

## **CONNECT THE UCM6208**

To set up the UCM6208, follow the steps below:

1. Connect one end of an RJ-45 Ethernet cable into the LAN port of the UCM6208.
2. Connect the other end of the Ethernet cable into the uplink port of an Ethernet switch/hub.
3. Connect the 12V DC power adapter into the 12V DC power jack on the back of the UCM6208. Insert the main plug of the power adapter into a surge-protected power outlet.
4. Wait for the UCM6208 to boot up. The LCD in the front will show the device hardware information when the boot process is done.
5. Once the UCM6208 is successfully connected to network, the LED indicator for NETWORK in the front will be in solid green and the LCD shows up the IP address.

6. (Optional) Connect PSTN lines from the wall jack to the FXO ports; connect analog lines (phone and Fax) to the FXS ports.




Figure 5: UCM6208 Front View




Figure 6: UCM6208 Back View

## SAFETY COMPLIANCES

The UCM6200 series IP PBX complies with FCC/CE and various safety standards. The UCM6200 power adapter is compliant with the UL standard. Use the universal power adapter provided with the UCM6200 package only. The manufacturer's warranty does not cover damages to the device caused by unsupported power adapters.

## WARRANTY

If the UCM6200 series IP PBX was purchased from a reseller, please contact the company where the device was purchased for replacement, repair or refund. If the device was purchased directly from Grandstream, contact our Technical Support Team for a RMA (Return Materials Authorization) number before the product is returned. Grandstream reserves the right to remedy warranty policy without prior notification.

 **Warning:**

Use the power adapter provided with the UCM6200 series IP PBX. Do not use a different power adapter as this may damage the device. This type of damage is not covered under warranty.

---



## GETTING STARTED

The UCM6200 series provides LCD interface, LED indication and web GUI configuration interface.

- The LCD displays hardware, software and network information. Users could also navigate in the LCD menu for device information and basic network configuration.
- The LED indication at the front of the device provides interface connection and activity status.
- The web GUI gives users access to all the configurations and options for UCM6200 series setup.

This section provides step-by-step instructions on how to use the LCD menu, LED indicators and Web GUI of the UCM6200 series. Once the basic settings are done, users could start making calls from UCM6200 extension registered on a SIP phone as described at the end of this section.

### USE THE LCD MENU

- **Default LCD Display**

When the device is powered up, the LCD will show device model (e.g., UCM6204), hardware version (e.g., V1.0A) and IP address. Press "Down" button and the system time will be displayed as well.

- **Menu Access**

Press "OK" button to start browsing menu options. Please see menu options in [Table 3: LCD Menu Options].

- **Menu Navigation**

Press the "Down" arrow key to browser different menu options. Press the "OK" button to select an entry.

- **Exit**

If "Back" option is available in the menu, select it to go back to the previous menu. For "Device Info" "Network Info" and "Web Info" which do not have "Back" option, simply press the "OK" button to go back to the previous menu. Also, the LCD will display default idle screen after staying in menu option for 15 seconds.

- **LCD Backlight**

The LCD backlight will be on upon key pressing. The backlight will go off after the LCD stays in idle for 30 seconds.



**Table 3: LCD Menu Options**




<b>View Events</b>	<ul style="list-style-type: none"> <li>• <b>Critical Events</b></li> <li>• <b>Other Events</b></li> </ul>
<b>Device Info</b>	<ul style="list-style-type: none"> <li>• <b>Hardware:</b> Hardware version number</li> <li>• <b>Software:</b> Software version number</li> <li>• <b>P/N:</b> Part number</li> <li>• <b>WAN MAC:</b> WAN side MAC address (UCM6202/UCM6204 only)</li> <li>• <b>LAN MAC:</b> LAN side MAC address</li> <li>• <b>Uptime:</b> System up time</li> </ul>
<b>Network Info</b>	<p>For UCM6208:</p> <ul style="list-style-type: none"> <li>• <b>LAN Mode:</b> DHCP, Static IP, or PPPoE</li> <li>• <b>LAN IP:</b> IP address</li> <li>• <b>LAN Subnet Mask</b></li> </ul> <p>For UCM6202/UCM6204:</p> <ul style="list-style-type: none"> <li>• <b>WAN Mode:</b> DHCP, Static IP, or PPPoE</li> <li>• <b>WAN IP:</b> IP address</li> <li>• <b>WAN Subnet Mask</b></li> <li>• <b>LAN IP:</b> IP address</li> <li>• <b>LAN Subnet Mask</b></li> </ul>
<b>Network Menu</b>	<p>For UCM6208:</p> <ul style="list-style-type: none"> <li>• <b>LAN Mode:</b> Select LAN mode as DHCP, Static IP or PPPoE</li> <li>• <b>Static Route Reset:</b> Click to reset the static route setting</li> </ul> <p>For UCM6202/UCM6204:</p> <ul style="list-style-type: none"> <li>• <b>WAN Mode:</b> Select WAN mode as DHCP, Static IP or PPPoE</li> <li>• <b>Static Route Reset:</b> Click to reset the static route setting</li> </ul>
<b>Factory Menu</b>	<ul style="list-style-type: none"> <li>• <b>Reboot</b></li> <li>• <b>Factory Reset</b></li> <li>• <b>LCD Test Patterns</b> Press "OK" to start. Then press "Down" button to test different LCD patterns. When done, press "OK" button to exit.</li> <li>• <b>Fan Mode</b> Select "Auto" or "On".</li> <li>• <b>LED Test Patterns</b></li> </ul>

	<p>Select "All On" "All Off" or "Blinking" and check LED status.</p> <ul style="list-style-type: none"> <li>• <b>RTC Test Patterns</b> Select "2022-02-22 22:22" or "2011-01-11 11:11" to start the RTC (Real-Time Clock) test pattern. Then check the system time from LCD idle screen by pressing "DOWN" button, or from web GUI-&gt;<b>System Status</b>-&gt;<b>General</b> page. Reboot the device manually after the RTC test is done.</li> <li>• <b>Hardware Testing</b> Select "Test SVIP" to perform SVIP test on the device. This is mainly for factory testing purpose which verifies the hardware connection inside the device. The diagnostic result will display in the LCD after the test is done.</li> </ul>
<b>Web Info</b>	<ul style="list-style-type: none"> <li>• <b>Protocol:</b> Web access protocol. HTTP or HTTPS. By default it's HTTPS</li> <li>• <b>Port:</b> Web access port number. By default it's 8089</li> </ul>
<b>SSH Switch</b>	<ul style="list-style-type: none"> <li>• <b>Enable SSH:</b> Enable SSH access.</li> <li>• <b>Disable SSH:</b> Disable SSH access.</li> </ul> <p>By default the SSH access is disabled.</p>






## USE THE LED INDICATORS

The UCM6200 has LED indicators in the front to display connection status. The following table shows the status definitions.

Table 4: UCM6202/UCM6204 LED INDICATORS

LED Indicator	LED Status
LAN	 <b>Solid:</b> Connected  <b>Flashing:</b> Data Transferring  <b>OFF:</b> Not Connected
WAN	
USB	
SD	
FXS (Phone/Fax)	
FXO (Telco Line)	

**Table 5: UCM6208 LED INDICATORS**

LED	LED Status
NETWORK	 <b>Solid:</b> Connected  <b>OFF:</b> Not Connected
ACT	 <b>Solid:</b> Connected  <b>Flashing:</b> Data Transferring  <b>OFF:</b> Not Connected
USB	
SD	
Phone (FXS) Line (FXO)	

## USE THE WEB GUI

### ACCESS WEB GUI

The UCM6200 embedded Web server responds to HTTP/HTTPS GET/POST requests. Embedded HTML pages allow users to configure the device through a Web browser such as Microsoft IE, Mozilla Firefox, Google Chrome and etc.


**Figure 7: UCM6204 Web GUI Login Page**

To access the Web GUI:

1. Connect the computer to the same network as the UCM6200.
2. Ensure the device is properly powered up and shows its IP address on the LCD.
3. Open a Web browser on the computer and enter the web GUI URL in the following format:

***http(s)://IP-Address:Port***

where the ***IP-Address*** is the IP address displayed on the UCM6200 LCD.

By default, the protocol is HTTPS and the Port number is 8089.

For example, if the LCD shows 192.168.40.167, please enter the following in your web browser:

***https://192.168.40.167:8089***

4. Enter the administrator's login and password to access the Web Configuration Menu. The default administrator's username and password is "admin" and "admin". It is highly recommended to change the default password after login for the first time.



**Note:**

By default, the UCM6200 has "Redirect From Port 80" enabled. Therefore, if users type in the UCM6200 IP address in the web browser, the web page will be automatically redirected to the page using HTTPS and port 8089. For example, if the LCD shows 192.168.40.167, please enter 192.168.40.167 in your web browser and the web page will be redirected to:


https://192.168.40.167:8089

The option "Redirect From Port 80" can be configured under the UCM6200 web GUI->**Settings->HTTP Server**.

---

## SETUP WIZARD

When the user logs in the UCM6200 web UI for the first time, a setup wizard will guide the user to set up basic configuration. Configurations in setup wizard includes: **Time zone, Change password, Network settings, Extensions, Trunk and routes.**



**Figure 8: UCM6200 Setup Wizard**

During the wizard, the user can quit the setup wizard at any time to start over with manual configuration. At the last step of the wizard, the user will be provided with summary for review, before the configuration is loaded. Once the setup is completed, the system is ready to go.

## WEB GUI CONFIGURATIONS

There are four main sections in the Web GUI for users to view the PBX status, configure and manage the PBX.

- **Status:** Displays PBX status, System Status, System Events and CDR.
- **PBX:** To configure extensions, trunks, call routes, zero config for auto provisioning, call features, internal options, IAX settings and SIP settings.
- **Settings:** To configure user management, network settings, firewall settings, change password, LDAP Server, HTTP Server, Email Settings, Time Settings, NTP server, recording storage and login timeout.
- **Maintenance:** To perform firmware upgrade, backup configurations, cleaner setup, reset/reboot, syslog setup and troubleshooting.

## WEB GUI LANGUAGES

Currently the UCM6200 series web GUI supports **English, Simplified Chinese, Traditional Chinese, Spanish, French, Portuguese, Russian, Italian, Polish, German and etc.**

Users can select the displayed language in web GUI login page, or at the upper right of the web GUI after logging in.



Figure 9: UCM6200 Web GUI Language

## SAVE AND APPLY CHANGES

Click on "Save" button after configuring the web GUI options in one page. After saving all the changes, make sure click on "Apply Changes" button on the upper right of the web page to submit all the changes. If the change requires reboot to take effect, a prompted message will pop up for you to reboot the device.

## MAKE YOUR FIRST CALL

Power up the UCM6200 and your SIP end point phone. Connect both devices to the network. Then follow the steps below to make your first call.


1. Log in the UCM6200 web GUI, go to **PBX->Basic/Call Routes->Extensions**.
2. Click on "Create New SIP Extension" to create a new extension. You will need User ID, Password and Voicemail Password information to register and use the extension later.
3. Register the extension on your phone with the SIP User ID, SIP server and SIP Password information. The SIP server address is the UCM6200 IP address.
4. When your phone is registered with the extension, dial \*97 to access the voicemail box. Enter the Voicemail Password once you hear "Password" voice prompt.
5. Once successfully logged in to the voicemail, you will be prompted with the Voice Mail Main menu.
6. You are successfully connected to the PBX system now.

## SYSTEM SETTINGS

This section explains configurations for system-wide parameters on the UCM6200. System settings are under “Settings” tag on UCM6200 web GUI. System settings include User Management, Network Settings, Firewall, Change Password, LDAP server, HTTP server, Email settings, Time Settings, NTP Server, Recordings Storage and Login Timeout settings.

### USER MANAGEMENT

User management is on web GUI->**Settings->User Management** page. User could create multiple accounts for different administrators to log in the UCM6200 web GUI. Additionally, the system will automatically create user accounts along with creating new extensions for extension users to login to the web UI using their extension number and password. All existing user accounts for web UI login will be displayed on User Management page as shown in the following figure.



Username	Privilege	Login Time	Options
admin	Super Administrator	2015-02-03 11:09:57	[Edit] [Delete]
AdminBill	Administrator	2014-12-12 12:13:46	[Edit] [Delete]
AdminJane	Administrator	2014-11-19 15:59:15	[Edit] [Delete]
AdminE	Administrator	2015-02-02 11:13:41	[Edit] [Delete]
632	Consumer	-	[Edit] [Delete]
541	Consumer	-	[Edit] [Delete]
688	Consumer	-	[Edit] [Delete]
600	Consumer	-	[Edit] [Delete]
501	Consumer	-	[Edit] [Delete]
602	Consumer	-	[Edit] [Delete]

Figure 10: User Management Page Display

### USER PRIVILEGES


Three privilege levels are supported:

- **Super Admin**



- This is the highest privilege. Super Admin can access all pages on UCM6200 web GUI, change configuration for all options and execute all the operations.
  - Super Admin can create, edit and delete one or more users with “Admin” privilege
  - Super Admin can edit and delete one or more users with “Consumer” privilege
  - Super Admin can view operation logs generated by all users.
  - By default, the user account “admin” is configured with “Super Admin” privilege and it’s the only user with “Super Admin” privilege. The User Name and Privilege level cannot be changed or deleted.
  - Super Admin could change its own login password on web UI->**Settings->Change Password** page.
  - Super Admin could view operations done by all the users in web UI->**Settings->User Management->Operation Log**.
- **Admin**
    - Users with “Admin” privilege can only be created by “Super Admin” user.
    - “Admin” privilege users are not allowed to access the following pages:
      - Maintenance->Upgrade**
      - Maintenance->Backup**
      - Maintenance->Cleaner**
      - Maintenance->Reset/Reboot**
      - Settings->User Management->Operation Log**
    - “Admin” privilege users cannot create new users for login.
- **Consumer**
    - A user account for web UI login is created automatically by the system when a new extension is created.
    - The user could log in the web UI with the extension number and password to access user information, extension configuration and CDR of that extension.



## CREATE NEW WEB UI USER

When logged in as Super Admin, click on  to create a new account for web UI user. The following dialog will prompt. Configure the parameters as shown in below table.

**Figure 11: Create New User**

**Table 6: User Management->Create New User**


User Name	Configure a username to identify the user which will be required in web UI login. Letters, digits and underscore are allowed in the user name.
User Password	Configure a password for this user which will be required in web UI login. Letters, digits and underscore are allowed.
Privilege	This is the role of the web UI user. Currently only “Admin” is supported when Super Admin creates a new user.
Department	Enter the necessary information to keep a record for this user.
Fax	
Email Address	
First Name	
Last Name	
Home Number	
Phone Number	

Once created, the Super Admin can edit the users by clicking on  or delete the user by clicking on .

**Figure 12: User Management – New Users**

## USER PORTAL

The user could log in web UI user portal using the extension number and password. When there is an extension created in the UCM6200, the corresponding user account for the extension is automatically created. The user portal allows limited access including user information, extension configuration and CDR information of the extension. The login username is the extension number and the password is configured by Super Admin. The following figure shows the dialog of editing the account information by Super Admin. The User Name must be the extension number and it's not configurable.



User Name:	1001	User Password:	AvHJL1y
Privilege:	Consumer	Department:	Support
Fax:		Email Address:	tgya.tan@grandstream.com
First Name:	Jane	Last Name:	Tan
Home Number:		Phone Number:	

Buttons: Cancel, Save

Figure 13: Edit User Information by Super Admin

The following figure shows an example of login page using extension number 1000 as the username.



GRANDSTREAM  
CONNECTING THE WORLD

# UCM6204 IPPBX Appliance

Username:  
1000

Password:  
\*\*\*\*\*

[Forgot Password?](#) [English](#)

Login

Figure 14: User Portal Login

After login, the web UI displays is shown as below.




Figure 15: User Portal Layout

For the configuration parameter information in each page, please refer to **[Table 6: User Management->Create New User]** for options in **User Portal->Basic Information->User Information** page; please refer to **[EXTENSIONS]** for options in **User Portal->Basic Information->Extension** page; please refer to **[CDR]** for **User Portal->Basic Information->CDR** page.

## CONCURRENT MULTI-USER LOGIN

When there are multiple web UI users created, concurrent multi-user login is supported on the UCM6200. Multiple users could edit options and have configurations take effect simultaneously. However, if different users are editing the same option or making the same operation (by clicking on “Apply Changes”), a prompt will pop up as shown in the following figure.




Figure 16: Multiple User Operation Error Prompt

## OPERATION LOG

Super Admin has the authority to view operation logs on UCM6200 web GUI->**Settings->User Management->Operation Log** page. Operation logs list operations done by all the web UI users, for example, web UI login, creating trunk, creating outbound rule and etc. There are 6 columns to record the operation details “Date”, “User Name”, “IP Address”, “Results”, “Page Operation” and “Specific Operation”.


Date	User Name	IP Address	Results	Page Operation	Specific Operation
2014-11-05 17:54:12	admin	192.168.40.173	Operate Successfully	Login	User Name: admin
2014-11-05 14:57:38	admin	192.168.40.173	Operate Successfully	Login	User Name: admin
2014-11-05 14:32:40	admin	192.168.40.173	Operate Successfully	VoIP Trunks: Create New SIP Trunk	
2014-11-05 14:32:17	admin	192.168.40.173	Operate Successfully	Outbound Routes: Create New Outbound Route	Prilege Level: none 
2014-11-05 13:34:48	admin	192.168.40.173	Operate Successfully	Login	User Name: admin
2014-11-04 21:32:42	admin	192.168.40.173	Operate Successfully	Login	User Name: admin
2014-11-04 19:01:32	admin	192.168.40.173	Operate Successfully	Callback: Create New Callback	
2014-11-04 19:01:13	admin	192.168.40.173	Operate Successfully	IVR: Create New IVR	Extension: 7000, Permission: internal 
2014-11-04 18:51:38	admin	192.168.40.173	Operate Successfully	Login	User Name: admin
2014-11-04 18:33:38	admin	192.168.40.173	Operate Successfully	Login	User Name: admin

Total 69 Show 4/7 Go to

**Figure 17: Operation Logs**

The operation log can be sorted and filtered for easy access. Click on the header of each column to sort. For example, clicking on "Date" will sort the logs according to operation date and time. Clicking on "Date" again will reverse the order.

**Table 7: Operation Log Column Header**

<b>Date</b>	The date and time when the operation is executed.
<b>User Name</b>	The username of the user who performed the operation.
<b>IP Address</b>	The IP address from which the operation is made.
<b>Results</b>	The result of the operation.
<b>Page Operation</b>	The page where the operation is made. For example, login, logout, delete user, create trunk and etc.
<b>Specific Operation</b>	Click on  to view the options and values configured by this operation.

User could also filter the operation logs by time condition, IP address and/or username. Configure these conditions and then click on  .

**Operation Log**

From Date: 2014-11-01 00:00  
 To Date: 2014-11-06 15:38  
 IP Address: 192.168.40.173  
 User Name: support

[View Operation Logs](#)
[Delete Searched Operation Logs](#)
[Delete All Operation Logs](#)

Date	User Name	IP Address	Results	Page Operation	Specific Operation
2014-11-06 13:49:41	support	192.168.40.173	Operate Successfully	Login	User Name: support
2014-11-06 13:50:01	support	192.168.40.173	Operate Successfully	Logout	User Name: support
2014-11-06 15:02:25	support	192.168.40.173	Operate Successfully	Login	User Name: support
2014-11-06 15:23:10	support	192.168.40.173	Operate Successfully	Logout	User Name: support

Total: 4 Show 1/1 Go to:

**Figure 18: Operation Logs Filter**


The above figure shows an example that operations made by user “support” on device with IP 192.168.40.173 from 2014-11-01 00:00 to 2014-11-06 15:38 are filtered out and displayed.

To delete operation logs, users can perform filtering first and then click on [Delete Searched Operation Logs](#) to delete the filtered result of operation logs. Or users can click on [Delete All Operation Logs](#) to delete all operation logs at once.

## CHANGE PASSWORD

After logging in the UCM6200 web UI for the first time, it is highly recommended for users to change the default password "admin" to a more complicated password for security purpose. Follow the steps below to change the Web UI access password.

1. Go to Web UI->**Settings**->**User Management**-> **Change Password** page.
2. Enter the old password first.
3. Enter the new password and re-type the new password to confirm. The new password has to be at least 4 characters. The maximum length of the password is 30 characters.
4. Configure the Email Address that is used when login credential is lost.
5. Click on "Save" and the user will be automatically logged out.
6. Once the web page comes back to the login page again, enter the username "admin" and the new password to login.



**Change Password**

Enter Old Password\* :

Enter New Password\* :

Retype New Password\* :

Email Address\* :


Cancel Save

**Figure 19 : Change Password**

<b>Enter Old Password</b>	Enter the Old Password for UCM6200
<b>Enter New Password</b>	Enter the New Password for UCM6200
<b>Retype New Password</b>	Retype the New Password for UCM6200
<b>Email Address</b>	Configure the Email address for UCM6200. In case login credential is lost, Email address is used to retrieve login credential

### CHANGE BINDNG EMAIL

UCM6200 allows user to configure binding email in case login password is lost. UCM6200 login credential will be sent to the designated email address. The feature can be found under web UI->Settings->User Management->Change Binding Email.



**Change Binding Email**

Enter the password of the account:

Email Address:

Cancel Save

**Figure 20: Change Binding Email**

**Table 8: Change Binding Email option**

<b>Enter the password of the account</b>	Enter the current login user credential for UCM6200
<b>Email Address</b>	Email Address is used to retrieve password when password is lost

## NETWORK SETTINGS

After successfully connecting the UCM6200 to the network for the first time, users could login the Web GUI and go to **Settings->Network Settings** to configure the network parameters for the device.

Additional network functions and settings are available for UCM6202 and UCM6204:

- UCM6202/UCM6204 supports Route/Switch/Dual mode functions.

In this section, all the available network setting options are listed for all models. Select each tab in web GUI->**Settings->Network Settings** page to configure LAN settings, WAN settings (UCM6202/UCM6204 only), 802.1X and Port Forwarding (UCM6202/UCM6204 only).

## BASIC SETTINGS

Please refer to the following tables for basic network configuration parameters on UCM6202/UCM6204, and UCM6208 respectively.

**Table 9: UCM6202/UCM6204 Network Settings->Basic Settings**

<b>Method</b>	<p>Select "Route", "Switch" or "Dual" mode on the network interface of UCM6200. The default setting is "Route".</p> <ul style="list-style-type: none"> <li>• <b>Route</b> WAN port interface will be used for uplink connection. LAN port interface will be used to serve as router.</li> <li>• <b>Switch</b> WAN port interface will be used for uplink connection. LAN port interface will be used as bridge for PC connection.</li> <li>• <b>Dual</b> Both ports can be used for uplink connection. Users will need assign LAN 1 or LAN 2 as the default interface in option "Default Interface" and configure "Gateway IP" for this interface.</li> </ul>
---------------	---



<b>Preferred DNS Server</b>	Enter the preferred DNS server address. If Preferred DNS is used, UCM will try to use it as Primary DNS server.
<b>WAN (when "Method" is set to "Route")</b>	
<b>IP Method</b>	Select DHCP, Static IP, or PPPoE. The default setting is DHCP.
<b>IP Address</b>	Enter the IP address for static IP settings. The default setting is 192.168.0.160.
<b>Subnet Mask</b>	Enter the subnet mask address for static IP settings. The default setting is 255.255.0.0.
<b>Gateway IP</b>	Enter the gateway IP address for static IP settings. The default setting is 0.0.0.0.
<b>DNS Server 1</b>	Enter the DNS server 1 address for static IP settings. The default setting is 0.0.0.0.
<b>DNS Server 2</b>	Enter the DNS server 2 address for static IP settings.
<b>User Name</b>	Enter the user name to connect via PPPoE.
<b>Password</b>	Enter the password to connect via PPPoE.
<b>Layer 2 QoS 802.1Q/VLAN Tag</b>	Assign the VLAN tag of the layer 2 QoS packets for WAN port. The default value is 0.
<b>Layer 2 QoS 802.1p Priority Value</b>	Assign the priority value of the layer 2 QoS packets for WAN port. The default value is 0.
<b>LAN (when Method is set to "Route")</b>	
<b>IP Address</b>	Enter the IP address assigned to LAN port. The default setting is 192.168.2.1.
<b>Subnet Mask</b>	Enter the subnet mask. The default setting is 255.255.255.0.
<b>DHCP Server Enable</b>	Enable or disable DHCP server capability. The default setting is "Yes".
<b>DNS Server 1</b>	Enter DNS server address 1. The default setting is 8.8.8.8.
<b>DNS Server 2</b>	Enter DNS server address 2. The default setting is 208.67.222.222.
<b>Allow IP Address From</b>	Enter the DHCP IP Pool starting address. The default setting is 192.168.2.100.
<b>Allow IP Address To</b>	Enter the DHCP IP Pool ending address. The default setting is 192.168.2.254.
<b>Default IP Lease Time</b>	Enter the IP lease time (in seconds). The default setting is 43200.
<b>LAN (when Method is set to "Switch")</b>	
<b>IP Method</b>	Select DHCP, Static IP, or PPPoE. The default setting is DHCP.
<b>IP Address</b>	Enter the IP address for static IP settings. The default setting is 192.168.0.160.
<b>Subnet Mask</b>	Enter the subnet mask address for static IP settings. The default setting is 255.255.0.0.
<b>Gateway IP</b>	Enter the gateway IP address for static IP settings. The default setting is 0.0.0.0.
<b>DNS Server 1</b>	Enter the DNS server 1 address for static IP settings. The default setting is 0.0.0.0.
<b>DNS Server 2</b>	Enter the DNS server 2 address for static IP settings.

<b>User Name</b>	Enter the user name to connect via PPPoE.
<b>Password</b>	Enter the password to connect via PPPoE.
<b>Layer 2 QoS 802.1Q/VLAN Tag</b>	Assign the VLAN tag of the layer 2 QoS packets for LAN port. The default value is 0.
<b>Layer 2 QoS 802.1p Priority Value</b>	Assign the priority value of the layer 2 QoS packets for LAN port. The default value is 0.
<b>LAN 1 / LAN 2 (when Method is set to "Dual")</b>	
<b>Default Interface</b>	If "Dual" is selected as "Method", users will need assign the default interface to be LAN 1 (mapped to UCM6202 WAN port) or LAN 2 (mapped to UCM6202 LAN port) and then configure network settings for LAN 1/LAN 2. The default interface is LAN 2.
<b>IP Method</b>	Select DHCP, Static IP, or PPPoE. The default setting is DHCP.
<b>IP Address</b>	Enter the IP address for static IP settings. The default setting is 192.168.0.160.
<b>Subnet Mask</b>	Enter the subnet mask address for static IP settings. The default setting is 255.255.0.0.
<b>Gateway IP</b>	Enter the gateway IP address for static IP settings when the port is assigned as default interface. The default setting is 0.0.0.0.
<b>DNS Server 1</b>	Enter the DNS server 1 address for static IP settings. The default setting is 0.0.0.0.
<b>DNS Server 2</b>	Enter the DNS server 2 address for static IP settings.
<b>User Name</b>	Enter the user name to connect via PPPoE.
<b>Password</b>	Enter the password to connect via PPPoE.
<b>Layer 2 QoS 802.1Q/VLAN Tag</b>	Assign the VLAN tag of the layer 2 QoS packets for LAN port. The default value is 0.
<b>Layer 2 QoS 802.1p Priority Value</b>	Assign the priority value of the layer 2 QoS packets for LAN port. The default value is 0.


**Table 10: UCM6208 Network Settings->Basic Settings**

<b>Preferred DNS Server</b>	Enter the preferred DNS server address. If Preferred DNS is used, UCM will try to use it as Primary DNS server.
<b>IP Method</b>	Select DHCP, Static IP, or PPPoE. The default setting is DHCP.
<b>IP Address</b>	Enter the IP address for static IP settings.
<b>Subnet Mask</b>	Enter the subnet mask address for static IP settings.
<b>Gateway IP</b>	Enter the gateway IP address for static IP settings.

<b>DNS Server 1</b>	Enter the DNS server 1 address for static IP settings.
<b>DNS Server 2</b>	Enter the DNS server 2 address for static IP settings.
<b>User Name</b>	Enter the user name to connect via PPPoE.
<b>Password</b>	Enter the password to connect via PPPoE.
<b>Layer 2 QoS 802.1Q/VLAN Tag</b>	Assign the VLAN tag of the layer 2 QoS packets for LAN port. The default value is 0.
<b>Layer 2 QoS 802.1p Priority Value</b>	Assign the priority value of the layer 2 QoS packets for LAN port. The default value is 0.

- **Method: Route**

When the UCM6200 has method set to Route in network settings, WAN port interface is used for uplink connection and LAN port interface is used as a router. Please see a sample diagram below.



**Figure 21: UCM6200 Network Interface Method: Route**

- **Method: Switch**

WAN port interface is used for uplink connection; LAN port interface is used as bridge for PC connection.




Figure 22: UCM6200 Network Interface Method: Switch

- **Method: Dual**

Both WAN port and LAN port are used for uplink connection. Users will need assign LAN 1 or LAN 2 as the default interface in option "Default Interface" and configure "Gateway IP" if static IP is used for this interface.




Figure 23: UCM6200 Network Interface Method: Dual

### 802.1X

IEEE 802.1X is an IEEE standard for port-based network access control. It provides an authentication mechanism to device before the device is allowed to access Internet or other LAN resources. The UCM6200 supports 802.1X as a supplicant/client to be authenticated. The following diagram and figure show UCM6200 uses 802.1X mode “EAP-MD5” on WAN port as client in the network to access Internet.





Figure 24: UCM6200 Using 802.1X as Client



**Figure 25: UCM6200 Using 802.1X EAP-MD5**



The following table shows the configuration parameters for 802.1X on UCM6200. Identity and MD5 password are required for authentication, which should be provided by the network administrator obtained from the RADIUS server. If “EAP-TLS” or “EAP-PEAPv0/MSCHAPv2” is used as the 802.1X mode, users will also need upload 802.1X CA Certificate and 802.1X Client Certificate, which should be also generated from the RADIUS server.

**Table 11: UCM6200 Network Settings->802.1X**

<b>802.1X Mode</b>	Select 802.1X mode. The default setting is "Disable". The supported 802.1X mode are: <ul style="list-style-type: none"> <li>• EAP-MD5</li> <li>• EAP-TLS</li> <li>• EAP-PEAPv0/MSCHAPv2</li> </ul>
<b>Identity</b>	Enter 802.1X mode identity information.
<b>MD5 Password</b>	Enter 802.1X mode MD5 password information.
<b>802.1X Certificate</b>	Select 802.1X certificate from local PC and then upload.
<b>802.1X Client Certificate</b>	Select 802.1X client certificate from local PC and then upload.

## STATIC ROUTES

The UCM6200 provides users static routing capability that allows the device to use manually configured routes, rather than information only from dynamic routing or gateway configured in the UCM6200 web GUI->**Network Settings**->**Basic Settings** to forward traffic. It can be used to define a route when no other routes are available or necessary, or used in complementary with existing routing on the UCM6200 as a failover backup, and etc.

- Click on **Create New Static Route** to create a new static route. The configuration parameters are listed in the table below.
- Once added, users can select  to edit the static route.
- Select  to delete the static route.

**Table 12: UCM6200 Network Settings->Static Routes**

<b>Destination</b>	<p>Configure the destination IP address or the destination IP subnet for the UCM6200 to reach using the static route.</p> <p>Example:  IP address - <b>192.168.66.4</b>  IP subnet - <b>192.168.66.0</b></p>
<b>Netmask</b>	<p>Configure the subnet mask for the above destination address. If left blank, the default value is 255.255.255.255.</p> <p>Example:  <b>255.255.255.0</b></p>
<b>Gateway</b>	<p>Configure the gateway address so that the UCM6200 can reach the destination via this gateway. Gateway address is optional.</p> <p>Example:  <b>192.168.40.5</b></p>
<b>Interface</b>	<p>Specify the network interface on the UCM6200 to reach the destination using the static route.</p> <p>LAN interface is eth0; WAN interface is eth1.</p>

Static routes configuration can be reset from LCD menu->Network Menu.

The following diagram shows a sample application of static route usage on UCM6204.






Figure 26: UCM6204 Static Route Sample

The network topology of the above diagram is as below:

- Network 192.168.69.0 has IP phones registered to UCM6204 LAN 1 address
- Network 192.168.40.0 has IP phones registered to UCM6204 LAN 2 address
- Network 192.168.66.0 has IP phones registered to UCM6204 via VPN
- Network 192.168.40.0 has VPN connection established with network 192.168.66.0

In this network, by default the IP phones in network 192.168.69.0 are unable to call IP phones in network 192.168.66.0 when registered on different interfaces on the UCM6204. Therefore, we need configure a static route on the UCM6204 so that the phones in isolated networks can make calls between each other.

**Create New Static Route**

*i* Destination:

*i* Netmask:

*i* Gateway:

*i* Interface:

Figure 27: UCM6204 Static Route Configuration



## PORT FORWARDING

The UCM network interface supports router function which provides users the ability to do port forwarding. If the UCM6202/UCM6204 LAN mode is set to "Route" under web GUI->**Settings->Network Settings->Basic Settings** page, port forwarding is available for configuration.

The port forwarding configuration is under web GUI->**Settings->Network Settings->Port Forwarding** page. Please see related settings in the table below.

**Table 13: UCM6202/UCM6204 Network Settings->Port Forwarding**

<b>WAN Port</b>	<p>Specify the WAN port number or a range of WAN ports. Up to 8 ports can be configured.</p> <p><b>Note:</b> When it is set to a range, WAN port and LAN port must be configured with the same range, such as WAN port: 1000-1005 and LAN port: 1000-1005, and access from WAN port will be forwarded to the LAN port with the same port number, for example, WAN port 1000 will be port forwarding to LAN port 1000.</p>
<b>LAN IP</b>	<p>Specify the LAN IP address.</p>
<b>LAN Port</b>	<p>Specify the LAN port number or a range of LAN ports.</p> <p><b>Note:</b> When it is set to a range, WAN port and LAN port must be configured with the same range, such as WAN port: 1000-1005 and LAN port: 1000-1005, and access from WAN port will be forwarded to the LAN port with the same port number, for example, WAN port 1000 will be port forwarding to LAN port 1000.</p>
<b>Protocol Type</b>	<p>Select protocol type "UDP Only", "TCP Only" or "TCP/UDP" for the forwarding in the selected port. The default setting is "UDP Only".</p>

The following figures demonstrate a port forwarding example to provide phone's web UI access to public side.


- The UCM6202/UCM6204 network mode is set to "Route"
- The UCM6202/UCM6204 WAN port is connected to uplink switch, with a public IP address configured, e.g. 1.1.1.1.
- The UCM6202/UCM6204 LAN port provides DHCP pool that connects to multiple phone devices in the LAN network 192.168.2.x. The UCM6202/UCM6204 is used as a router, with gateway address 192.168.2.1

- There is a GXP2160 connected under the LAN interface network of the UCM6202/UCM6204. It obtains IP address 192.168.2.100 from UCM6200 DHCP pool
- On the UCM6202/UCM6204 web UI->**Settings->Network Settings->Port Forwarding**, configure a port forwarding entry as the figure shows below.

**WAN Port:** This is the port opened up on the WAN side for access purpose.

**LAN IP:** This is the GXP2160 IP address, under the LAN interface network of the UCM6202/UCM6204.

**Protocol Type:** We select TCP here for web UI access using HTTP.



Settings >> Network Settings >> Port Forwarding

### Port Forwarding

Please configure the LAN mode as Router to enable this function.


When Port Forwarding is set to range, the WAN port and the LAN port rules for only same start and end values (such as 1000-1005 and 1000-1005)  
 Range match Range, Single match Single, such as 4444 match 5555, 1500-1505 match 1500-1505.

WAN Port	LAN IP	LAN Port	Protocol Type
2999-3005	192.168.2.103	2999-3005	TCP Only
8088	192.168.2.100	80	TCP Only
			UDP Only
			UDP Only
			UDP Only
			UDP Only
			UDP Only
			UDP Only

Cancel Save

**Figure 28: UCM6202/UCM6204 Port Forwarding Configuration**

This will allow users to access the GXP2160 web UI from public side, by typing in address "1.1.1.1:8088".



**Figure 29: GXP2160 Web Access Using UCM6202 Port Forwarding**

## DDNS SETTINGS

DDNS setting allows user to access UCM6200 via domain name instead of IP address. The UCM supports DDNS service from the following DDNS provider:

- dydns.org
- noip.com
- freedns.afraid.org
- zoneedit.com
- oray.net

Here is an example of using noip.com for DDNS.

1. Register domain in DDNS service provider. Please note the UCM6200 needs to have public IP access.








Hostname Information	
Hostname:	haograndstream.ddns.net 
Host Type:	<input checked="" type="radio"/> DNS Host (A) <input type="radio"/> DNS Host (Round Robin) <input type="radio"/> DNS Alias (CNAME)  <input type="radio"/> Port 80 Redirect <input type="radio"/> Web Redirect
IP Address:	<input type="text" value="1.2.3.4"/> Last Update: 2015-01-07 17:29:20 PST 
Assign to Group:	<input type="text" value="- No Group -"/>  <a href="#">Configure Groups</a> 
Enable Wildcard:	Wildcards are a Plus / Enhanced feature. <a href="#">Upgrade Now!</a> 
Advanced Records:	TXT, SPF, and SRV records and the use of some special clients are Plus / Enhanced features. <a href="#">Upgrade now</a> to use them. 

Figure 30: Register Domain Name on noip.com

- On **web UI->Settings->Network Settings->DDNS Settings**, enable DDNS service and configure username, password and host name.

### DDNS Settings

DDNS allows you to access your network using domain names instead of IP address.







DDNS Settings	
 DDNS Server:	<input type="text" value="no-ip.com"/>
 Enable DDNS:	<input checked="" type="checkbox"/>
 Username:	<input type="text" value="hao_grandstream"/>
 Password:	<input type="password" value="....."/>
 Host Name:	<input type="text" value="haograndstream.ddns.net"/>

Figure 31: UCM6200 DDNS Setting

- Now you can use domain name instead of IP address to connect to the UCM6200 web UI.



The current password security level is low, please go to the [Change Password](#) page to modify the password and bind Email.

**Status** PBX Settings Maintenance

Status >> PBX Status >> PBX Status

**Trunks** [-]

Status	Trunks	Type	Username	Port/Hostname/IP
Reachable	test_6510	SIP		192.168.40.194

Total: 1 Show: 1/1 Go to:  Go First Prev Next Last

**Extensions** [-]

All Analog IAX SIP Ring Groups Voicemail Groups

Status	Extension	Name/Label	Message	Type
●	1000		Messages: 0/0/0	SIP
●	1001		Messages: 0/0/0	SIP
●	1002		Messages: 0/0/0	SIP

Total: 3 Show: 1/1 Go to:  Go First Prev Next Last

**Queues** [-]

Figure 32: Using Domain Name to Connect to UCM6200

## FIREWALL

The UCM6200 provides users firewall configurations to prevent certain malicious attack to the UCM6200 system. Users could configure to allow, restrict or reject specific traffic through the device for security and bandwidth purpose. The UCM6200 also provides Fail2ban feature for authentication errors in SIP REGISTER, INVITE and SUBSCRIBE. To configure firewall settings in the UCM6200, go to Web UI->**Settings**->**Firewall** page.

## STATIC DEFENSE

Under Web GUI->**Settings**->**Firewall**->**Static Defense** page, users will see the following information:

- Current service information with port, process and type.
- Typical firewall settings.
- Custom firewall settings.

The following table shows a sample current service status running on the UCM6200.

**Table 14: UCM6200 Firewall->Static Defense->Current Service**

Port	Process	Type	Protocol or Service
7777	Asterisk	tcp/IPv4	SIP
389	Slapd	tcp/IPv4	LDAP
22	Dropbear	tcp/IPv4	SSH
80	Lighthttpd	tcp/IPv4	HTTP
8089	Lighthttpd	tcp/IPv4	HTTPS
69	Opentftpd	udp/IPv4	TFTP
9090	Asterisk	udp/IPv4	SIP
6060	zero_config	udp/IPv4	UCM6200 zero_config service
5060	Asterisk	udp/IPv4	SIP
4569	Asterisk	udp/IPv4	SIP
5353	zero_config	udp/IPv4	UCM6200 zero_config service
37435	Syslogd	udp/IPv4	Syslog

For typical firewall settings, users could configure the following options on the UCM6200.


**Table 15: Typical Firewall Settings**

<b>Ping Defense Enable</b>	If enabled, ICMP response will not be allowed for Ping request. The default setting is disabled. To enable or disable it, click on the check box for the LAN or WAN (UCM6202/UCM6204) interface.
<b>Ping-of-Death Defense Enable</b>	Enable to prevent Ping-of-Death attack to the device. The default setting is disabled. To enable or disable it, click on the check box for the LAN or WAN (UCM6202/UCM6204) interface.

Under "Custom Firewall Settings", users could create new rules to accept, reject or drop certain traffic going through the UCM6200. To create new rule, click on "Create New Rule" button and a new window will pop up for users to specify rule options.

Right next to "Create New Rule" button, there is a checkbox for option "Reject Rules". If it's checked, all the rules will be rejected except the firewall rules listed below. In the firewall rules, only when there is a rule that meets all the following requirements, the option "Reject Rules" will be allowed to check:

- Action: "Accept"
- Type "In"
- Destination port is set to the system login port (e.g., by default 8089)
- Protocol is not UDP





**Figure 33: Create New Firewall Rule**

**Table 16: Firewall Rule Settings**

<b>Rule Name</b>	Specify the Firewall rule name to identify the firewall rule.
<b>Action</b>	<p>Select the action for the Firewall to perform.</p> <ul style="list-style-type: none"> <li>• ACCEPT</li> <li>• REJECT</li> <li>• DROP</li> </ul>
<b>Type</b>	<p>Select the traffic type.</p> <ul style="list-style-type: none"> <li>• IN If selected, users will need specify the network interface "LAN" or "WAN" (for UCM6202/UCM6204) for the incoming traffic.</li> <li>• OUT</li> </ul>
<b>Service</b>	<p>Select the service type.</p> <ul style="list-style-type: none"> <li>• FTP</li> <li>• SSH</li> <li>• Telnet</li> <li>• TFTP</li> <li>• HTTP</li> <li>• LDAP</li> <li>• Custom</li> </ul> <p>If "Custom" is selected, users will need specify Source (IP and port), Destination (IP and port) and Protocol (TCP, UDP or Both) for the service. Please note if the source or the destination field is left blank, it will be used as "Anywhere".</p>

Save the change and click on "Apply" button. Then submit the configuration by clicking on "Apply Changes" on the upper right of the web page. The new rule will be listed at the bottom of the page with sequence number, rule name, action, protocol, type, source, destination and operation. More operations below:

- Click on  to edit the rule
- Click on  to delete the rule

## DYNAMIC DEFENSE

Dynamic defense is supported on the UCM6200 series. It can blacklist hosts dynamically when the LAN mode is set to "Route" under web GUI->**Settings->Network Settings->Basic Settings** page. If enabled, the traffic coming into the UCM6200 can be monitored, which helps prevent massive connection attempts or brute force attacks to the device. The blacklist can be created and updated by the UCM6200 firewall, which will then be displayed in the web page. Please refer to the following table for dynamic defense options on the UCM6200.

**Table 17: UCM6200 Firewall Dynamic Defense**


<b>Dynamic Defense Enable</b>	Enable dynamic defense. The default setting is disabled.
<b>Periodical Time Interval</b>	Configure the dynamic defense periodic time interval (in minutes). If the number of TCP connections from a host exceeds the connection threshold within this period, this host will be added into Blacklist. The valid value is between 1 and 59 when dynamic defense is turned on. The default setting is 59.
<b>Blacklist Update Interval</b>	Configure the blacklist update time interval (in seconds). The default setting is 120.
<b>Connection Threshold</b>	Configure the connection threshold. Once the number of connections from the same host reaches the threshold, it will be added into the blacklist. The default setting is 100.
<b>Dynamic Defense Whitelist</b>	Configure the dynamic defense whitelist.  For example, <b>192.168.1.3</b> <b>192.168.1.4</b>

The following figure shows a configuration example like this:

- If a host at IP address 192.168.40.7 initiates more than 20 TCP connections to the UCM6200 within 1 minute, it will be added into UCM6200 blacklist.
- This host 192.168.40.7 will be blocked by the UCM6200 for 300 seconds.



- Since IP address 192.168.40.5 is in whitelist, if the host at IP address 192.168.40.5 initiates more than 20 TCP connections to the UCM6200 within 1 minute, it will not be added into UCM6200 blacklist. It can still establish TCP connection with the UCM6200.



**Figure 34: Configure Dynamic Defense**

## FAIL2BAN

Fail2Ban feature on the UCM6200 provides intrusion detection and prevention for authentication errors in SIP REGISTER, INVITE and SUBSCRIBE. Once the entry is detected within "Max Retry Duration", the UCM6200 will take action to forbid the host for certain period as defined in "Banned Duration". This feature helps prevent SIP brute force attacks to the PBX system.

**Table 18: Fail2Ban Settings**

Global Settings	
<b>Enable Fail2Ban</b>	Enable Fail2Ban. The default setting is disabled. Please make sure both "Enable Fail2Ban" and "Asterisk Service" are turned on in order to use Fail2Ban for SIP authentication on the UCM6200.
<b>Banned Duration</b>	Configure the duration (in seconds) for the detected host to be banned. The default setting is 300. If set to -1, the host will be always banned.
<b>Max Retry Duration</b>	Within this duration (in seconds), if a host exceeds the max times of retry as defined in "MaxRetry", the host will be banned. The default setting is 5.
<b>MaxRetry</b>	Configure the number of authentication failures during "Max Retry Duration" before the host is banned. The default setting is 10.
<b>Fail2Ban Whitelist</b>	Configure IP address, CIDR mask or DNS host in the whitelist. Fail2Ban will not

	ban the host with matching address in this list. Up to 5 addresses can be added into the list.
<b>Local Settings</b>	
<b>Asterisk Service</b>	Enable Asterisk service for Fail2Ban. The default setting is disabled. Please make sure both "Enable Fail2Ban" and "Asterisk Service" are turned on in order to use Fail2Ban for SIP authentication on the UCM6200.
<b>Protocol</b>	Configure the listening port number for the service. Currently only 5060 (for UDP) is supported.
<b>MaxRetry</b>	Configure the number of authentication failures during "Max Retry Duration" before the host is banned. The default setting is 10. Please make sure this option is properly configured as it will override the "MaxRetry" value under "Global Settings".

## LDAP SERVER

The UCM6200 has an embedded LDAP server for users to manage corporate phonebook in a centralized manner.

- By default, the LDAP server has generated the first phonebook with **PBX DN** "ou=pbx,dc=pbx,dc=com" based on the UCM6200 user extensions already.
- Users could add new phonebook with a different **Phonebook DN** for other external contacts. For example, "ou=people,dc=pbx,dc=com".
- All the phonebooks in the UCM6200 LDAP server have the same **Base DN** "dc=pbx,dc=com".

### Term Explanation:

cn= Common Name

ou= Organization Unit

dc= Domain Component

These are all parts of the LDAP data Interchange Format, according to RFC 2849, which is how the LDAP tree is filtered.

If users have the Grandstream phone provisioned by the UCM6200, the LDAP directory will be set up on the phone and can be used right away for users to access all phonebooks.

Additionally, users could manually configure the LDAP client settings to manipulate the built-in LDAP server on the UCM6200. If the UCM6200 has multiple LDAP phonebooks created, in the LDAP client configuration, users could use "dc=pbx,dc=com" as Base DN to have access to all phonebooks on the


UCM6200 LDAP server, or use a specific phonebook DN, for example "ou=people,dc=pbx,dc=com", to access to phonebook with Phonebook DN "ou=people,dc=pbx,dc=com " only.

UCM can also act as a LDAP client to download phonebook entries from other LDAP server.

To access LDAP server and client settings, go to **Web GUI->Settings->LDAP Server**.

### LDAP SERVER CONFIGURATIONS

The following figure shows the default LDAP server configurations on the UCM6200.




The screenshot shows a dialog box titled "LDAP Server configurations" with the following fields:



- Base DN:
- PBX DN:
- Root DN:
- Root Password:
- Confirm Root Password:

At the bottom, there are "Cancel" and "Save" buttons.

**Figure 35: LDAP Server Configurations**

The UCM6200 LDAP server supports anonymous access (read-only) by default. Therefore the LDAP client doesn't have to configure username and password to access the phonebook directory. The "Root DN" and "Root Password" here are for LDAP management and configuration where users will need provide for authentication purpose before modifying the LDAP information.

The default phonebook list in this LDAP server can be viewed and edited by clicking on  for the first phonebook under LDAP Phonebook.

No.	Phonebook DN	Options
1	ou=pbx,dc=pbx,dc=com	 

**Figure 36: Default LDAP Phonebook DN**

Edit Phonebook: ou=pbx,dc=pbx,dc=com

LDAP Attributes	Contact List																										
ⓘ AccountNumber: <input type="text" value="5000"/> ⓘ CallerIDName: <input type="text" value="John Doe"/> ⓘ Email: <input type="text"/> ⓘ FirstName: <input type="text"/> ⓘ LastName: <input type="text"/> ⓘ Department: <input type="text"/> ⓘ MobileNumber: <input type="text"/> ⓘ HomeNumber: <input type="text"/> ⓘ Fax: <input type="text"/>	<table border="1"> <thead> <tr> <th>AccountNumber</th> <th>CallerIDName</th> </tr> </thead> <tbody> <tr><td>5000</td><td>John Doe</td></tr> <tr><td>5001</td><td>Stacy Green</td></tr> <tr><td>5002</td><td>Tom Lin</td></tr> <tr><td>5003</td><td>Ricky Chan</td></tr> <tr><td>5004</td><td>Front Desk</td></tr> <tr><td>5005</td><td>Warehouse</td></tr> <tr><td>5006</td><td>Sales</td></tr> <tr><td>5007</td><td>Tech Support</td></tr> <tr><td>5008</td><td>Customer Service</td></tr> <tr><td>5009</td><td>RMA</td></tr> <tr><td>5010</td><td>Shipping</td></tr> <tr><td>5011</td><td>Test</td></tr> </tbody> </table>	AccountNumber	CallerIDName	5000	John Doe	5001	Stacy Green	5002	Tom Lin	5003	Ricky Chan	5004	Front Desk	5005	Warehouse	5006	Sales	5007	Tech Support	5008	Customer Service	5009	RMA	5010	Shipping	5011	Test
AccountNumber	CallerIDName																										
5000	John Doe																										
5001	Stacy Green																										
5002	Tom Lin																										
5003	Ricky Chan																										
5004	Front Desk																										
5005	Warehouse																										
5006	Sales																										
5007	Tech Support																										
5008	Customer Service																										
5009	RMA																										
5010	Shipping																										
5011	Test																										

Figure 37: Default LDAP Phonebook Attributes

## LDAP PHONEBOOK

Users could use the default phonebook, edit the default phonebook, add new phonebook, import phonebook on the LDAP server as well as export phonebook from the LDAP server. The first phonebook with default phonebook dn "ou=pbx,dc=pbx,dc=com" displayed on the LDAP server page is for extensions in this PBX. Users cannot add or delete contacts directly. The contacts information will need to be modified via Web GUI->**PBX->Basic/Call Routes->Extensions** first. The default LDAP phonebook will then be updated automatically.





Figure 38: LDAP Server->LDAP Phonebook

- **Add new phonebook**

A new sibling phonebook of the default PBX phonebook can be added by clicking on "Add" under "LDAP Phonebook" section.



Add PhonebookX



i Phonebook Prefix:


i Phonebook DN:

Cancel
Save

**Figure 39: Add LDAP Phonebook**

Configure the "Phonebook Prefix" first. The "Phonebook DN" will be automatically filled in. For example, if configuring "Phonebook Prefix" as "people", the "Phonebook DN" will be filled with "ou=people,dc=pbx,dc=com".

Once added, users can select  to edit the phonebook attributes and contact list (see figure below), or select  to delete the phonebook.



Edit Phonebook: ou=people,dc=pbx,dc=comX

LDAP Attributes

New

i AccountName:

i CallerIDName:

i Email:

i FirstName:

i LastName:

i Department:

i MobileNumber:

i HomeNumber:

i Fax:

Clean
Add

Contact List


AccountName	CallerIDName	Options

Cancel
Save All

**Figure 40: Edit LDAP Phonebook**

- **Import phonebook from your computer to LDAP server**

Click on “Import Phonebook” and a dialog will prompt as shown in the figure below.



**Figure 41: Import Phonebook**

The file to be imported must be a CSV file with UTF-8 encoding. Users can open the CSV file with Notepad and save it with UTF-8 encoding.

Here is how a sample file looks like. Please note “Account Number” and “Phonebook DN” fields are required. Users could export a phonebook file from the UCM6200 LDAP phonebook section first and use it as a sample to start with.

	A	B	C	D	E	F	G	H	I	J
1	First Name	Last Name	Account Number	CallerID Name	Email	Department	Mobile Number	Home Number	Fax	Phonebook DN
2	John	Doe	1001	1001		IT	1001000000			phonebook
3	Jane	Doe	1002	1002		Sales	1002000000			phonebook
4	William	Chung	1003	1003		Marketing	1003000000			phonebook
5	Linda	Kuo	1004	1004		Accounting	1004000000			phonebook
6	Steve	Chang	1005	1005		Support	1005000000			others

**Figure 42: Phonebook CSV File Format**

The Phonebook DN field is the same “Phonebook Prefix” entry as when the user clicks on “Add” to create a new phonebook. Therefore, if the user enters “phonebook” in “Phonebook DN” field in the CSV file, the actual phonebook DN “ou=phonebook,dc=pbx,dc=com” will be automatically created by the UCM6200 once the CSV file is imported.

In the CSV file, users can specify different phonebook DN fields for different contacts. If the phonebook DN already exists on the UCM6200 LDAP Phonebook, the contacts in the CSV file will be added into the existing phonebook. If the phonebook DN doesn’t exist on the UCM6200 LDAP Phonebook, a new phonebook with this phonebook DN will be created.

The sample phonebook CSV file in above picture will result in the following LDAP phonebook in the

UCM6200.



**Figure 43: LDAP Phonebook After Import**

As the default LDAP phonebook with DN “ou=pbx,dc=pbx,dc=com” cannot be edited or deleted in LDAP phonebook section, users cannot import contacts with Phonebook DN field “pbx” if existed in the CSV file.

- **Export phonebook to your computer from UCM6200 LDAP server**

Select the checkbox for the LDAP phonebook and then click on “Export Selected Phonebook” to export the selected phonebook. The exported phonebook can be used as a record or a sample CSV file for the users to add more contacts in it and import to the UCM6200 again.



**Figure 44: Export Selected LDAP Phonebook**

## LDAP CLIENT CONFIGURATIONS


The configuration on LDAP client is similar when you use other LDAP servers. Here we provide an example on how to configure the LDAP client on the SIP end points to use the default PBX phonebook.

**Assuming the server base dn is "dc=pbx,dc=com", configure the LDAP clients as follows (case insensitive):**

**Server Address: LDAP server IP address**

**Base DN:** dc=pbx,dc=com  
**User Name:** cn= "LDAP server login name", dc=pbx, dc=com [matching LDAP server format]  
**Password:** "LDAP server login password"  
**Filter:** ((CallerIDName=%)(AccountNumber=%))  
**Port:** 389

The following figure gives a sample configurations for UCM6200 acting as a LDAP client.



The screenshot shows a dialog box titled "LDAP Client Configurations" with the following fields and values:

LDAP Server:	Test_1
Server Address:	192.168.40.144
Base DN:	dc=pbx,dc=com
User Name:	cn=admin,dc=pbx,dc=com
Password:	.....
Filter:	((CallerIDName=%)(AccountNumbe
Port:	389

At the bottom of the dialog are "Cancel" and "Save" buttons.

**Figure 45: LDAP Client Configurations**

To configure Grandstream IP phones as the LDAP client, please refer to the following example:

**Server Address:** The IP address or domain name of the UCM6200  
**Base DN:** dc=pbx,dc=com  
**User Name:** Please leave this field empty  
**Password:** Please leave this field empty  
**LDAP Name Attribute:** CallerIDName Email Department FirstName LastName  
**LDAP Number Attribute:** AccountNumber MobileNumber HomeNumber Fax  
**LDAP Number Filter:** (AccountNumber=%)  
**LDAP Name Filter:** (CallerIDName=%)  
**LDAP Display Name:** AccountNumber CallerIDName  
**LDAP Version:** If existed, please select LDAP Version 3  
**Port:** 389

The following figure shows the configuration information on a Grandstream GXP2200 to successfully use the LDAP server as configured in **Figure 35: LDAP Server Configurations**.



Server Address :	<input type="text" value="192.168.40.134"/>
Port :	<input type="text" value="389"/>
Base DN :	<input type="text" value="dc=pbx,dc=com"/>
User Name :	<input type="text"/>
Password :	<input type="password"/>
LDAP Name Attributes :	<input type="text" value="CallerIDName"/>
LDAP Number Attributes :	<input type="text" value="AccountNumber"/>
LDAP Mail Attributes :	<input type="text"/>
LDAP Name Filter :	<input type="text" value="(CallerIDName=%)"/>
LDAP Number Filter :	<input type="text" value="(AccountNumber=%)"/>
LDAP Mail Filter :	<input type="text"/>
LDAP Displaying Name Attributes :	<input type="text" value="%AccountNumber %CallerIDName"/>
Max Hits :	<input type="text" value="50"/>
Search Timeout(ms) :	<input type="text" value="0"/>
LDAP Lookup For Dial :	<input type="checkbox"/> Enable
LDAP Lookup For Incoming Call :	<input type="checkbox"/> Enable

**Figure 46: GXP2200 LDAP Phonebook Configuration**

## HTTP SERVER

The UCM6200 embedded web server responds to HTTP/HTTPS GET/POST requests. Embedded HTML pages allow the users to configure the PBX through a Web browser such as Microsoft IE, Mozilla Firefox and Google Chrome. By default, the PBX can be accessed via HTTPS using Port 8089 (e.g., <https://192.168.40.50:8089>). Users could also change the access protocol and port as preferred under Web GUI->**Settings**->**HTTP Server**.

**Table 19: HTTP Server Settings**

<b>Redirect From Port 80</b>	Enable or disable redirect from port 80. On the PBX, the default access protocol is HTTPS and the default port number is 8089. When this option is enabled, the access using HTTP with Port 80 will be redirected to HTTPS with Port 8089. The default setting is "Enable".
<b>Protocol Type</b>	Select HTTP or HTTPS. The default setting is "HTTPS". This is also the protocol used for zero config when the end point device downloads the config file from the UCM6200.
<b>Port</b>	Specify port number to access the HTTP server. The default port number is 8089.

Once the change is saved, the web page will be redirected to the login page using the new URL. Enter the username and password to login again.


## EMAIL SETTINGS

The Email application on the UCM6200 can be used to send out alert event Emails, Fax (Fax-To-Email), Voicemail (Voicemail-To-Email) and etc. The configuration parameters can be accessed via Web GUI->**Settings**->**Email Settings**.

**Table 20: Email Settings**

<b>TLS Enable</b>	Enable or disable TLS during transferring/submitted your Email to other SMTP server. The default setting is "Yes".
<b>Type</b>	Select Email type. <ul style="list-style-type: none"> <li>• MTA: Mail Transfer Agent. The Email will be sent from the configured domain. When MTA is selected, there is no need to set up SMTP server for it or no user login is required. However, the Emails sent from MTA might be considered as spam by the target SMTP server.</li> <li>• Client: Submit Emails to the SMTP server. A SMTP server is required and users need login with correct credentials.</li> </ul>
<b>Domain</b>	Specify the domain name to be used in the Email when using type "MTA".
<b>Server</b>	Specify the SMTP server when using type "Client".
<b>Username</b>	Username is required when using type "Client". Normally it's the Email address.
<b>Password</b>	Password to login for the above Username (Email address) is required when using type "Client".
<b>Display Name</b>	Specify the display name in the FROM header in the Email.
<b>Sender</b>	Specify the sender's Email address. For example, pbx@example.mycompany.com.

The following figure shows a sample Email settings on the UCM6200, assuming the Email is using *smtp.gmail.com* as the SMTP server.



Field	Value
TLS Enable	Yes
Type	Client
Server	smtp.gmail.com:465
Username	pbx@company.gr
Password	.....
Display Name	Company PBX
Sender	pbx@company.gmail.com

**Figure 47: UCM6200 Email Settings**

Once the configuration is finished, click on "Test". In the prompt, fill in a valid Email address to send a test Email to verify the Email settings on the UCM6200.

## TIME SETTINGS

### AUTO TIME UPDATING

The current system time on the UCM6200 is displayed on the upper right of the web page. It can also be found under Web GUI->**Status**->**System Status**->**General**.

To configure the UCM6200 to update time automatically, go to Web GUI->**Settings**->**Time Settings**->**Time Auto Updating**.

---

 **Note:**

The configurations under Web GUI->**Settings**->**Time Settings**->**Time Auto Updating** page require reboot to take effect. Please consider configuring auto time updating related changes when setting up the UCM6200 for the first time to avoid service interrupt after installation and deployment in production.

---

**Table 21: Time Auto Updating**

<b>Remote NTP Server</b>	Specify the URL or IP address of the NTP server for the UCM6200 to synchronize the date and time. The default NTP server is ntp.ipvideotalk.com.
<b>Enable DHCP Option 2</b>	If set to "Yes", the UCM6200 is allowed to get provisioned for Time Zone from DHCP Option 2 in the local server automatically. The default setting is "Yes".
<b>Enable DHCP Option 42</b>	If set to "Yes", the UCM6200 is allowed to get provisioned for NTP Server from DHCP Option 42 in the local server automatically. This will override the manually configured NTP Server. The default setting is "Yes".
<b>Time Zone</b>	<p>Select the proper time zone option so the UCM6200 can display correct time accordingly.</p> <p>If "Self-Defined Tome Zone" is selected, please specify the time zone parameters in "Self-Defined Time Zone" field as described in below option.</p>
<b>Self-Defined Time Zone</b>	<p>If "Self-Defined Time Zone" is selected in "Time Zone" option, users will need define their own time zone following the format below.</p> <p>The syntax is: std offset dst [offset], start [/time], end [/time]</p> <p>Default is set to: MTZ+6MDT+5,M4.1.0,M11.1.0</p> <p><b>MTZ+6MDT+5</b></p> <p>This indicates a time zone with 6 hours offset and 1 hour ahead for DST, which is U.S central time. If it is positive (+), the local time zone is west of the Prime Meridian (A.K.A: International or Greenwich Meridian); If it is negative (-), the local time zone is east.</p> <p><b>M4.1.0,M11.1.0</b></p> <p>The 1st number indicates Month: 1,2,3..., 12 (for Jan, Feb, ..., Dec).</p> <p>The 2nd number indicates the nth iteration of the weekday: (1st Sunday, 3rd Tuesday...). Normally 1, 2, 3, 4 are used. If 5 is used, it means the last iteration of the weekday.</p> <p>The 3rd number indicates weekday: 0,1,2,...,6 ( for Sun, Mon, Tues, ... ,Sat).</p> <p>Therefore, this example is the DST which starts from the First Sunday of April to the 1st Sunday of November.</p>

## SET TIME MANUALLY

To manually set the time on the UCM6200, go to Web UI->**Settings**->**Time Settings**->**Set Time Manually**. The format is YYYY-MM-DD HH:MI:SS.




Figure 48: Set Time Manually

---


 **Note:**

Manually setup time will take effect immediately after saving and applying change in the web UI. If users would like to reboot the UCM6200 and keep the manually setup time setting, please make sure "Remote NTP Server", "Enable DHCP Option 2" and "Enable DHCP Option 42" options under Web GUI->**Settings**->**Time Settings**->**Time Auto Updating** page are unchecked or set to empty. Otherwise, time auto updating settings in this page will take effect after reboot.

---

## OFFICE TIME

On the UCM6200, the system administrator can define "office time", which can be used to configure time condition for extension call forwarding schedule and inbound rule schedule. To configure office time, go to Web UI->**Settings**->**Time Settings**->**Office Time**. Click on "Create New Office Time" to create an office time.



**Figure 49: Create New Office Time**



**Table 22: Create New Office Time**

<b>Start Time</b>	Configure the start time for office hour.
<b>End Time</b>	Configure the end time for office hour
<b>Week</b>	Select the work days in one week.
<b>Show Advanced Options</b>	Check this options to show advanced options. Once selected, please specify "Month" and "Day" below.
<b>Month</b>	Select the months for office time.
<b>Day</b>	Select the work days in one month.

Select "Start Time", "End Time" and the day for the "Week" for the office time. The system administrator can also define month and day of the month as advanced options. Once done, click on "Save" and then "Apply Change" for the office time to take effect. The office time will be listed in the web page as the figure shows below.




**Figure 50: Settings->Time Settings->Office Time**

- Click on  to edit the office time.
- Click on  to delete the office time.
- Click on "Delete Selected Office Times" to delete multiple selected office times at once.

## HOLIDAY

On the UCM6200, the system administrator can define "holiday", which can be used to configure time condition for extension call forwarding schedule and inbound rule schedule. To configure holiday, go to Web UI->**Settings->Time Settings->Holiday**. Click on "Create New Holiday" to create holiday time.





**Figure 51: Create New Holiday**

**Table 23: Create New Holiday**

<b>Name</b>	Specify the holiday name to identify this holiday.
<b>Holiday Memo</b>	Create a note for the holiday.
<b>Month</b>	Select the month for the holiday.
<b>Day</b>	Select the day for the holiday.
<b>Show Advanced Options</b>	Check this option to show advanced options. If selected, please specify the days as holiday in one week below.
<b>Week</b>	Select the days as holiday in one week.

Enter holiday "Name" and "Holiday Memo" for the new holiday. Then select "Month" and "Day". The system administrator can also define days in one week as advanced options. Once done, click on "Save" and then "Apply Change" for the holiday to take effect. The holiday will be listed in the web page as the figure shows below.


**Figure 52: Settings->Time Settings->Holiday**

- Click on  to edit the holiday.
- Click on  to delete the holiday.
- Click on "Delete Selected Holidays" to delete multiple selected holidays at once.

---

 **Note:**

For more details on how to use office time and holiday, please refer to the link below:

[http://www.grandstream.com/sites/default/files/Resources/How to use office time and holiday UCM6200.pdf](http://www.grandstream.com/sites/default/files/Resources/How%20to%20use%20office%20time%20and%20holiday%20UCM6200.pdf)

---



## NTP SERVER

The UCM6200 can be used as a NTP server for the NTP clients to synchronize their time with. To configure the UCM6200 as the NTP server, set "Enable NTP server" to "Yes" under web GUI->**Settings->NTP Server**. On the client side, point the NTP server address to the UCM6200 IP address or host name to use the UCM6200 as the NTP server.

## RECORDINGS STORAGE

The UCM6200 supports call recordings automatically or manually and the recording files can be saved in external storage plugged in the UCM6200 or on the UCM6200 locally. To manage the recording storage, users can go to UCM6200 web GUI->**Settings->Recordings Storage** page and select whether to store the recording files in USB Disk, SD card or locally on the UCM6200.





Figure 53: Settings->Recordings Storage


- If "Enable Auto Change" is selected, the recording files will be automatically saved in the available USB Disk or SD card plugged into the UCM6200. If both USB Disk and SD card are plugged in, the recording files will be always saved in the USB Disk.
- If "Local" is selected, the recordings will be stored in UCM6200 internal storage.
- If "USB Disk" or "SD Card" is selected, the recordings will be stored in the corresponding plugged in external storage device. Please note the options "USB Disk" and "SD Card" will be displayed only if they are plugged into the UCM6200.

Once “USB Disk” or “SD Card” is selected, click on “OK”. The user will be prompted to confirm to copy the local files to the external storage device.



**Figure 54: Recordings Storage Prompt Information**

Click on “OK” to continue. The users will be prompted a new dialog to select the categories for the files to be copied over.



**Figure 55: Recording Storage Category**

On the UCM6200, recording files are generated and exist in 3 categories: normal call recording files, conference recording files, and call queue recording files. Therefore users have the following options when select the categories to copy the files to the external device:

- Recording Files: Copy the normal recording files to the external device.
- Conference: Copy the conference recording files to the external device.
- Queue: Copy the call queue recording files to the external device.
- All: Copy all recording files to the external device.

## LOGIN TIMEOUT SETTINGS

After the user logs in the UCM6200 web UI, the user will be automatically logged out after certain timeout. This timeout value can be specified under UCM100 web GUI->**Settings->Login Timeout Settings** page.

The “User Login Timeout” value is in minute and the default setting is 10 minutes. If the user doesn’t make any operation on web UI within the timeout, the user will be logged out automatically. After that, the web UI will be redirected to the login page and the user will need to enter username and password to log in.

If set to 0, there is no timeout for the web UI login session and the user will not be automatically logged out.





Figure 56: Login Timeout Settings

## GOOGLE SERVICE SETTINGS SUPPORT

UCM6200 now supports Google OAuth 2.0 authentication. This feature is used for supporting UCM6200 conference scheduling system. Once OAuth 2.0 is enabled, UCM6200 conference system can access Google calendar to schedule or update conference.

Google Service Settings can be found under web GUI-> **Settings-> Google Service Settings-> Google Service Settings.**




The screenshot shows a web browser window with the address bar displaying "Settings >> Google Service Settings >> Google Service Settings". The main content area is titled "OAuth2.0 Authentication" and contains the following text: "Google use OAuth 2.0 for API authentication, if you do not fill out your own OAuth 2.0 client ID and secret, then the default built-in OAuth2.0 certificate will be used." Below this text are two input fields: "OAuth2.0 Client ID\*" and "OAuth2.0 Client Secret\*", each with an information icon to its left. At the bottom of the form are two buttons: "Cancel" and "Save".

**Figure 57: Google Service Settings->OAuth2.0 Authentication**

If you already have OAuth2.0 project set up on **Google Developers** web page, please use your existing login credential for "OAuth2.0 Client ID" and "OAuth2.0 Client Secret" in the above figure for the UCM6200 to access Google Service.

If you do not have OAuth2.0 project set up yet, please following the steps below to create new project and obtain credentials:

1. Go to Google Developers page <https://console.developers.google.com/start> Create a New Project in Google Developers page.



**New Project**

Project name <sup>?</sup>

OAuthTest

Your project ID will be animated-surfer-112001 <sup>?</sup> [Edit](#)

[Show advanced options...](#)

Please email me updates regarding feature announcements, performance suggestions, feedback surveys and special offers.


Yes  No

I agree that my use of any [services and related APIs](#) is subject to my compliance with the applicable [Terms of Service](#).

[Create](#) [Cancel](#)

**Figure 58: Google Service->New Project**

2. Enable Calendar API from API Library.
3. Click “Credentials” on the left drop down menu to create new OAuth2.0 login credentials.



**Figure 59: Google Service->Create New Credential**

4. Use the newly created login credential to fill in “OAuth2.0 Client ID” and “OAuth2.0 Client Secret”.
5. Click “Get Authentication Code” to obtain authentication code from Google Service.

**Google Calendar Authorization**

1. Click 'Get Authorization Code'.
2. Enter the Google account and password (Note: please make sure the account on authorization page is correct, if you have logged in other account, please log out then log in again).
3. Click 'Accept' on authorization page.
4. Copy the string to the Authorization code input box, click the 'authorize' button.

① Authorization Code:

① Authorized Account:

Please allow a new window to open, if the window is not open, please open the following link to obtain the authorization code: [Get Authorization Code](#)

**Figure 60: Google Service->OAuth2.0 Login**

6. Now UCM6200 is connected with Google Service.



# PROVISIONING

## OVERVIEW

Grandstream SIP Devices can be configured via Web interface as well as via configuration file through TFTP/HTTP/HTTPS download. All Grandstream SIP devices support a proprietary binary format configuration file and XML format configuration file. The UCM6200 provides a Plug and Play mechanism to auto-provision the Grandstream SIP devices in a zero configuration manner by generating XML config file and having the phone to download it within LAN area. This allows users to finish the installation with ease and start using the SIP devices in a managed way.

To provision a phone, three steps are involved, i.e., discovery, configuration and provisioning. This section explains how Zero Config works on the UCM6200. The settings for this feature can be accessed via Web UI->**PBX->Zero Config**.


## CONFIGURATION ARCHITECTURE FOR END POINT DEVICE

Started from firmware version 1.0.7.10, the end point device configuration in zero config is divided into the following three layers with priority from the lowest to the highest:

- Global  
This is the lowest layer. Users can configure the most basic options that could apply to all Grandstream SIP devices during provisioning via Zero config.
- Model  
In this layer, users can define model-specific options for the configuration template.
- Device  
This is the highest layer. Users can configure device-specific options for the configuration for individual device here.

Each layer also has its own structure in different levels. Please see figure below. The details for each layer are explained in sections **[GLOBAL CONFIGURATION]**, **[MODEL CONFIGURATION]** and **[DEVICE CONFIGURATION]**.






**Figure 61: Zero Config Configuration Architecture for End Point Device**

The configuration options in model layer and device layer have all the option in global layers already, i.e., the options in global layer is a subset of the options in model layer and device layer. If an option is set in all three layers with different values, the highest layer value will override the value in lower layer. For example, if the user selects English for Language setting in Global Policy and Spanish for Language setting in Default Model Template, the language setting on the device to be provisioned will use Spanish as model layer has higher priority than global layer. To sum up, **configurations in higher layer will always override the configurations for the same options/fields in the lower layer when presented at the same time.**

After understanding the zero config configuration architecture, users could configure the available options for end point devices to be provisioned by the UCM6200 by going through the three layers. This configuration architecture allows users to set up and manage the Grandstream end point devices in the same LAN area in a centralized way.

## **AUTO PROVISIONING SETTINGS**

By default, the Zero Config feature is enabled on the UCM6200 for auto provisioning. Three methods of auto provisioning are used.



**Figure 62: UCM6200 Zero Config**

- **SIP SUBSCRIBE**

When the phone boots up, it sends out SUBSCRIBE to a multicast IP address in the LAN. The UCM6200 discovers it and then sends a NOTIFY with the XML config file URL in the message body. The phone will then use the path to download the config file generated in the UCM6200 and take the new configuration.


- **DHCP OPTION 66**

This method should be used on the UCM6202/UCM6204 because only the UCM6202/UCM6204 have WAN and LAN port with LAN port supporting the router function. When the phone restarts (by default DHCP Option 66 is turned on), it will send out a DHCP DISCOVER request. The UCM6202 receives it and returns DHCP OFFER with the config server path URL in Option 66, for example, <https://192.168.2.1:8089/zccgi/>. The phone will then use the path to download the config file generated in the UCM6200.

- **mDNS**

When the phone boots up, it sends out mDNS query to get the TFTP server address. The UCM6200 will respond with its own address. The phone will then send TFTP request to download the XML config file from the UCM6200.

To start the auto provisioning process, under Web GUI->**PBX->Zero Config->Zero Config Settings**, fill in the auto provision information.



**Figure 63: Auto Provision Settings**

**Table 24: Auto Provision Settings**

<b>Enable Zero Config</b>	Enable or disable the zero config feature on the PBX. The default setting is enabled.
<b>Enable Automatic Configuration Assignment</b>	By default, this is disabled. If disabled, when SIP device boots up, the UCM6200 will not send the SIP device the URL to download the config file and therefore the SIP device will not be automatically provisioned by the UCM6200.  <b>Note:</b> When disabled, SIP devices can still be provisioned by manually sending NOTIFY from the UCM6200 which will include the XML config file URL for the SIP device to download.
<b>Automatically Assign Extension</b>	If enabled, when the device is discovered, the PBX will automatically assign an extension within the range defined in "Zero Config Extension Segment" to the device. The default setting is disabled.
<b>Zero Config Extension</b>	Click on the link "Zero Config Extension Segment" to specify the

<b>Segment</b>	extension range to be assigned if "Automatically Assign Extension" is enabled. The default range is 5000-6299. Zero Config Extension Segment range can be defined in web UI-> <b>PBX-&gt;Internal Options-&gt;General</b> page->Extension Preference section: "Auto Provision Extensions".
<b>Enable Pick Extension</b>	If enabled, the extension list will be sent out to the device after receiving the device's request. This feature is for the GXP series phones that support selecting extension to be provisioned via phone's LCD. The default setting is disabled.
<b>Pick Extension Segment</b>	Click on the link "Pick Extension Segment" to specify the extension list to be sent to the device. The default range is 4000 to 4999. Pick Extension Segment range can be defined in web UI-> <b>PBX-&gt;Internal Options-&gt;General</b> page->Extension Preference section: "Pick Extensions".
<b>Pick Extension Period (hour):</b>	Specify the number of minutes to allow the phones being provisioned to pick extensions.

Please make sure an extension is manually assigned to the phone or "Automatically Assign Extension" is enabled during provisioning. After the configuration on the UCM6200 web GUI, click on "Save" and "Apply Changes". Once the phone boots up and picks up the config file from the UCM6200, it will take the configuration right away.

## DISCOVERY

Users could manually discover the device by specifying the IP address or scanning the entire LAN network. Three methods are supported to scan the devices.

- PING
- ARP
- SIP Message (NOTIFY)

Click on "Auto Discover" under web **UI-> PBX-> Zero Config->Zero Config**, fill in the "Scan Method" and "Scan IP". The IP address segment will be automatically filled in based on the network mask detected on the UCM6200. If users need scan the entire network segment, enter 255 (for example, 192.168.40.255) instead of a specific IP address. Then click on "Save" to start discovering the devices within the same network. To successfully discover the devices, "Zero Config" needs to be enabled on the UCM6200 web GUI->**PBX->Zero Config->Auto Provisioning Settings**.

**Auto Discover** X

The PBX can automatically discover the new devices by ARP or PING. It can scan the entire network segment or a single IP address.

**Scan Method** Ping

**Scan IP** 192 . 168 . 2 . 145

Cancel
Save

**Figure 64: Auto Discover**

The following figure shows a list of discovered phones. The MAC address, IP Address, Extension (if assigned), Version, Vendor, Model, Connection Status, Create Config, Options (Edit/Delete/Update) are displayed in the list.

MAC Address	IP Address	Extension	Version	Vendor	Model	Create Config	Options
001882000000	-	-	1.0.1.55	GRANDSTREAM	GXP2115v2	-	[Edit] [Delete] [Power] [Refresh]
96068220109E	67.119.256.188	-	1.0.7.89	GRANDSTREAM	GXP3140	-	[Edit] [Delete] [Power] [Refresh]
00188227F2F7	-	-	1.0.5.14	GRANDSTREAM	GXP2124	-	[Edit] [Delete] [Power] [Refresh]
00188227FB79	67.119.256.175	-	1.0.1.48	GRANDSTREAM	GXP3240	-	[Edit] [Delete] [Power] [Refresh]
9606822A852C	192.168.46.3	-	1.0.4.8	GRANDSTREAM	GXP2180	-	[Edit] [Delete] [Power] [Refresh]
9606822B9B34	-	-	1.0.5.31	GRANDSTREAM	GXP2120	-	[Edit] [Delete] [Power] [Refresh]
0006822B3D04	192.168.46.143	-	1.0.5.26	GRANDSTREAM	GXP2110	-	[Edit] [Delete] [Power] [Refresh]

**Figure 65: Discovered Devices**

## GLOBAL CONFIGURATION

### GLOBAL POLICY


Global configuration will apply to all the connected Grandstream SIP end point devices in the same LAN with the UCM6200 no matter what the Grandstream device model it is. It is divided into two levels:

- Web UI->**PBX->Zero Config->Global Policy**
- Web UI->**PBX->Zero Config->Global Templates.**
- **Global Templates** configuration has higher priority to **Global Policy** configuration.

Global Policy can be accessed in web GUI->**PBX->Zero Config->Global Policy** page. On the top of the configuration table, users can select category in the "Options" dropdown list to quickly navigate to the category. The categories are:

- **Localization:** configure display language, data and time.
- **Phone Settings:** configure dial plan, call features, NAT, call progress tones and etc.
- **Contact List:** configure LDAP and XML phonebook download.
- **Maintenance:** configure upgrading, web access, Telnet/SSH access and syslog.
- **Network Settings:** configure IP address, QoS and STUN settings.
- **Customization:** customize LCD screen wallpaper for the supported models.

Select the checkbox on the left of the parameter you would like to configure to activate the dropdown list for this parameter.



**Figure 66: Global Policy Categories**

The following tables list the Global Policy configuration parameters for the SIP end device.

**Table 25: Global Policy Parameters->Localization**

Language settings	
<b>Language</b>	Select the LCD display language on the SIP end device.
Date and Time	
<b>Date Format</b>	Configure the date display format on the SIP end device's LCD.
<b>Time Format</b>	Configure the time display in 12-hour or 24-hour format on the SIP end device's LCD.
<b>NTP Server</b>	Configure the URL or IP address of the NTP server. The SIP end device may obtain the date and time from the server.
<b>Time Zone</b>	Configure the time zone used on the SIP end device.

**Table 26: Global Policy Parameters->Phone Settings**

Default Call Settings	
<b>Dial Plan</b>	Configure the default dial plan rule. For syntax and examples, please refer to user manual of the SIP devices to be provisioned for more details.
<b>Enable Call Features</b>	When enabled, "Do Not Disturb", "Call Forward" and other call features can be used via the local feature code on the phone. Otherwise, the ITSP feature code will be used.
<b>Use # as Dial Key</b>	If set to "Yes", pressing the number key "#" will immediately dial out the input digits.
<b>Auto Answer by Call-info</b>	If set to "Yes", the phone will automatically turn on the speaker phone to answer incoming calls after a short reminding beep, based on the SIP Call-Info header sent from the server/proxy. The default setting is enabled.
<b>NAT Traversal</b>	Configure which NAT traversal mechanism will be enabled on the endpoint device. If set to "STUN" and STUN server is configured, the phone system will periodically send STUN message to the SUTN server to get the public IP address of its NAT environment and keep the NAT port open. STUN will not work if the NAT is symmetric type. If set to "Keep-alive", the phone system will send the STUN packets to maintain the connection that is first established during registration of the phone. The "Keep-alive" packets will fool the NAT device into keeping the connection open and this allows the host server to send SIP requests directly to the registered phone. If it needs to use OpenVPN to connect host server, it needs to set it to "VPN". If the firewall and the SIP device behind the firewall are both able to use UPNP, it can be set to "UPNP". The both parties will negotiate to use which port to allow SIP through. The default setting is "Keep-alive".
<b>Use Random Port</b>	Configure whether to allow the endpoint device to use random ports for both SIP and RTP messages. This is usually necessary when multiple phones are behind the same full cone NAT. The default setting is "No". Note: This parameter must be set to "No" for Direct IP Calling to work.
General Settings	
<b>Call Progress Tones</b>	Configure call progress tones including ring tone, dial tone, second dial tone, message waiting tone, ring back tone, call waiting tone, busy tone and reorder tone using the following syntax: f1=val, f2=val[, c=on1/ off1[- on2/ off2[- on3/ off3]]];

	<ul style="list-style-type: none"> <li>• Frequencies are in Hz and cadence on and off are in 10ms).</li> <li>• “on” is the period (in ms) of ringing while “off” is the period of silence. Up to three cadences are supported.</li> <li>• Please refer to user manual of the SIP devices to be provisioned for more details</li> </ul>
<b>HEADSET Key Mode</b>	Select “Default Mode” or “Toggle Headset/Speaker” for the Headset key. Please refer to user manual of the SIP devices to be provisioned for more details.

**Table 27: Global Policy Parameters->Contact List**

<b>LDAP Phonebook</b>	
<b>Source</b>	Select "Manual" or "PBX" as the LDAP configuration source. <ul style="list-style-type: none"> <li>• If "Manual" is selected, the LDAP configuration below will be applied to the SIP end device.</li> <li>• If "PBX" is selected, the LDAP configuration built-in from UCM6200 web UI-&gt;<b>Settings-&gt;LDAP Server</b> will be applied.</li> </ul>
<b>Address</b>	Configure the IP address or DNS name of the LDAP server.
<b>Port</b>	Configure the LDAP server port. The default value is 389.
<b>Base DN</b>	This is the location in the directory where the search is requested to begin. Example: <ul style="list-style-type: none"> <li>• dc=grandstream, dc=com</li> <li>• ou=Boston, dc=grandstream, dc=com</li> </ul>
<b>User Name</b>	Configure the bind "Username" for querying LDAP servers. The field can be left blank if the LDAP server allows anonymous binds.
<b>Password</b>	Configure the bind "Password" for querying LDAP servers. The field can be left blank if the LDAP server allows anonymous binds.
<b>Number Filter</b>	Configure the filter used for number lookups. Please refer to user manual for more details.
<b>Name Filter</b>	Configure the filter used for name lookups. Please refer to user manual for more details.
<b>Version</b>	Select the protocol version for the phone to send the bind requests. The default value is 3.
<b>Name Attribute</b>	Specify the "name" attributes of each record which are returned in the LDAP search result. Example: <ul style="list-style-type: none"> <li>• gn</li> <li>• cn sn description</li> </ul>
<b>Number Attribute</b>	Specify the "number" attributes of each record which are returned in the



	<p>LDAP search result. Example:</p> <ul style="list-style-type: none"> <li>• telephoneNumber</li> <li>• telephoneNumber Mobile</li> </ul>
<b>Display Name</b>	<p>Configure the entry information to be shown on phone's LCD. Up to 3 fields can be displayed. Example:</p> <ul style="list-style-type: none"> <li>• %cn %sn %telephoneNumber</li> </ul>
<b>Max Hits</b>	<p>Specify the maximum number of results to be returned by the LDAP server. Valid range is 1 to 3000. The default value is 50.</p>
<b>Search Timeout</b>	<p>Specify the interval (in seconds) for the server to process the request and client waits for server to return. Valid range is 0 to 180. The default value is 30.</p>
<b>Sort Results</b>	<p>Specify whether the searching result is sorted or not. The default setting is No.</p>
<b>Incoming Calls</b>	<p>Configure to enable LDAP number searching when receiving calls. The default setting is No.</p>
<b>Outgoing Calls</b>	<p>Configure to enable LDAP number searching when making calls. The default setting is No.</p>
<b>Lookup Display Name</b>	<p>Configures the display name when LDAP looks up the name for incoming call or outgoing call. It must be a subset of the LDAP Name Attributes.</p>
<b>XML Phonebook</b>	
<b>Phonebook XML Server</b>	<p>Select the source of the phonebook XML server.</p> <ul style="list-style-type: none"> <li>• Disable Disable phonebook XML downloading.</li> <li>• Manual Once selected, users need specify downloading protocol HTTP, HTTPS or TFTP and the server path to download the phonebook XML file. The server path could be IP address or URL, with up to 256 characters.</li> <li>• Local UCM Server Once selected, click on the Server Path field to upload the phonebook XML file. Please note: after uploading the phonebook XML file to the server, the original file name will be used as the directory name and the file will be renamed as phonebook.xml under that directory.</li> </ul>
<b>Phonebook Download Interval</b>	<p>Configure the phonebook download interval (in Minute). If set to 0, automatic download will be disabled. Valid range is 5 to 720.</p>
<b>Remove manually-edited entries on download</b>	<p>If set to "Yes", when XML phonebook is downloaded, the entries added manually will be automatically removed.</p>

**Table 28: Global Policy Parameters->Maintenance**

Upgrade and Provision	
<b>Firmware Source</b>	<p>Firmware source via ZeroConfig provisioning could a URL for external server address, local UCM directory or USB media if plugged in to the UCM6200.</p> <p>Select a source to get the firmware file:</p> <ul style="list-style-type: none"> <li>• URL If select to use URL to upgrade, complete the configuration for the following four parameters: “Upgrade Via”, “Server Path”, “File Prefix” and “File Postfix”.</li> <li>• Local UCM Server Firmware can be uploaded to the UCM6200 internal storage for firmware upgrade. If selected, click on “Manage Storage” icon next to “Directory” option, upload firmware file and select directory for the end device to retrieve the firmware file.</li> <li>• Local USB Media If selected, the USB storage device needs to be plugged into the UCM6200 and the firmware file must be put under a folder named “ZC_firmware” in the USB storage root directory.</li> <li>• Local SD Card Media If selected, an SD card needs to be plugged into the UCM6200 and the firmware file must be put under a folder named “ZC_firmware” in the USB storage root directory.</li> </ul>
<b>Upgrade via</b>	When URL is selected as firmware source, configure upgrade via TFTP, HTTP or HTTPS.
<b>Server Path</b>	When URL is selected as firmware source, configure the firmware upgrading server path.
<b>File Prefix</b>	When URL is selected as firmware source, configure the firmware file prefix. If configured, only the firmware with the matching encrypted prefix will be downloaded and flashed into the phone, if URL is selected as firmware source.
<b>File Postfix</b>	When URL is selected as firmware source, configure the firmware file postfix. If configured, only the configuration file with the matching encrypted postfix will be downloaded and flashed into the phone.
<b>Allow DHCP Option 43/66</b>	If DHCP option 43 or 66 is enabled on the LAN side, the TFTP server can be redirected.
<b>Automatic Upgrade</b>	If enabled, the endpoint device will automatically upgrade if a new firmware is detected. Users can select automatic upgrading by day, by week or by minute.

	<ul style="list-style-type: none"> <li>• By week Once selected, specify the day of the week to check HTTP/TFTP server for firmware upgrades or configuration files changes.</li> <li>• By day Once selected, specify the hour of the day to check the HTTP/TFTP server for firmware upgrades or configuration files changes.</li> <li>• By minute Once selected, specify the interval <b>X</b> that the SIP end device will request for new firmware every <b>X</b> minutes.</li> </ul>
<b>Firmware Upgrade Rule</b>	Specify how firmware upgrading and provisioning request to be sent.
<b>Web Access</b>	
<b>Admin Password</b>	Configure the administrator password for admin level login.
<b>End-User Password</b>	Configure the end-user password for the end user level login.
<b>Web Access Mode</b>	Select HTTP or HTTPS as the web access protocol.
<b>Web Server Port</b>	Configure the port for web access. The valid range is 1 to 65535.
<b>Security</b>	
<b>Disable Telnet/SSH</b>	Enable Telnet/SSH access for the SIP end device. If the SIP end device supports Telnet access, this option controls the Telnet access of the device; if the SIP end device supports SSH access, this option controls the SSH access of the device.
<b>Syslog</b>	
<b>Syslog Server</b>	Configure the URL/IP address for the syslog server.
<b>Syslog Level</b>	Select the level of logging for syslog.
<b>Send SIP Log</b>	Configure whether the SIP log will be included in the syslog message.

**Table 29: Global Policy Parameters->Network Settings**

<b>Basic Settings</b>	
<b>IP Address</b>	<p>Configure how the SIP end device shall obtain the IP address. DHCP or PPPoE can be selected.</p> <ul style="list-style-type: none"> <li>• DHCP Once selected, users can specify the Host Name (option 12) of the SIP end device as DHCP client, and Vendor Class ID (option 60) used by the client and server to exchange vendor class ID information.</li> <li>• PPPoE Once selected, users need specify the Account ID, Password and Service Name for PPPoE.</li> </ul>
<b>Advanced Setting</b>	

<b>Layer 3 QoS</b>	Define the Layer 3 QoS parameter. This value is used for IP Precedence, Diff-Serv or MPLS. Valid range is 0-63.
<b>Layer 2 QoS Tag</b>	Assign the VLAN Tag of the Layer 2 QoS packets. Valid range is 0 -4095.
<b>Layer 2 QoS Priority Value</b>	Assign the priority value of the Layer 2 QoS packets. Valid range is 0-7.
<b>STUN Server</b>	Configure the IP address or Domain name of the STUN server. Only non-symmetric NAT routers work with STUN.
<b>Keep Alive Interval</b>	Specify how often the phone will send a blank UDP packet to the SIP server in order to keep the "ping hole" on the NAT router to open. Valid range is 10-160.

**Table 30: Global Policy Parameters->Customization**

<b>Wallpaper</b>	
<b>Screen Resolution 1024 x 600</b>	<p>Check this option if the SIP end device shall use 1024 x 600 resolution for the LCD screen wallpaper.</p> <ul style="list-style-type: none"> <li>• Source Configure the location where wallpapers are stored.</li> <li>• File If "URL" is selected as source, specify the URL of the wallpaper file. If "Local UCM Server" is selected as source, click to upload wallpaper file to the UCM6200.</li> </ul>
<b>Screen Resolution 800 x 400</b>	<p>Check this option if the SIP end device shall use 800 x 400 resolution for the LCD screen wallpaper.</p> <ul style="list-style-type: none"> <li>• Source Configure the location where wallpapers are stored.</li> <li>• File If "URL" is selected as source, specify the URL of the wallpaper file. If "Local UCM Server" is selected as source, click to upload wallpaper file to the UCM6200.</li> </ul>
<b>Screen Resolution 480 x 272</b>	<p>Check this option if the SIP end device shall use 480 x 272 resolution for the LCD screen wallpaper.</p> <ul style="list-style-type: none"> <li>• Source Configure the location where wallpapers are stored.</li> <li>• File If "URL" is selected as source, specify the URL of the wallpaper file. If "Local UCM Server" is selected as source, click to upload wallpaper file to the UCM6200.</li> </ul>
<b>Screen Resolution 320 x 240</b>	<p>Check this option if the SIP end device supports 320 x 240 resolution for the LCD screen wallpaper.</p> <ul style="list-style-type: none"> <li>• Source</li> </ul>

Configure the location where wallpapers are stored.

- **File**  
 If "URL" is selected as source, specify the URL of the wallpaper file. If "Local UCM Server" is selected as source, click to upload wallpaper file to the UCM6200.

## GLOBAL TEMPLATES

Global Templates can be accessed in web GUI->**PBX->Zero Config->Global Templates**. Users can create multiple global templates with different sets of configurations and save the templates. Later on, when the user configures the device in Edit Device dialog->Advanced Settings, the user can select to use one of the global template for the device. Please refer to section **[MANAGE DEVICES]** for more details on using the global templates.

When creating global template, users can select the categories and the parameters under each category to be used in the template. The global policy and the selected global template will both take effect when generating the config file. However, the selected global template has higher priority to the global policy when it comes to the same setting option/field. If the same option/field has different value configured in the global policy and the selected global template, the value for this option/field in the selected global template will override the value in global policy.

Click on "Create New Template" to add a global template. Users will see the following configurations.

**Table 31: Create New Template**

<b>Template Name</b>	Create a name to identify this global template.
<b>Description</b>	Provide a description for the global template. This is optional.
<b>Active</b>	Check this option to enable the global template.

- Click on  to edit the global template.

The window for editing global template is shown in the following figure. In the "Options" field, after entering the option name key word, the options containing the key word will be listed. Users could then select the options to be modified and click on "Add Option" to add it into the global template.

Edit Template : temp1
X

📘 Template Name:

📘 Description:

📘 Active:

Options
Phone Settings
▼
Add Option

Localization
▼

Language Settings
▼

📘 Language:

Phone Settings
▼

Default Call Settings
▼

📘 Dial Plan:

---

📘 Enable Call Features:

---

📘 Use # as Dial Key:

---

📘 Auto Answer by Call-Info:



---

📘 NAT Traversal:


---

Cancel
Save

**Figure 67: Edit Global Template**

The added options will show in the list. Users can then enter or select value for each option to be used in the global template. On the left side of each added option, users can click on  to remove this option from the template. On the right side of each option, users can click on  to reset the option value to the default value.

Click on “Save” to save this global template.

- The created global templates will show in the web UI->**PBX**->**Zero Config**->**Global Templates** page. Users can click on  to delete the global template or click on “Delete Selected Templates” to delete multiple selected templates at once.

- Click on “Toggle Selected Template(s)” to toggle the status between enabled/disabled for the selected templates.

## MODEL CONFIGURATION

### MODEL TEMPLATES

Model layer configuration allows users to apply model-specific configurations to different devices. Users could create/edit/delete a model template by accessing web GUI, page **PBX->Zero Config->Model Templates**. If multiple model templates are created and enabled, when the user configures the device in Edit Device dialog->Advanced Settings, the user can select to use one of the model template for the device. Please refer to section **[MANAGE DEVICES]** for more details on using the model template.

For each created model template, users can assign it as default model template. If assigned as default model template, the values in this model template will be applied to all the devices of this model. There is always only one default model template that can be assigned at one time on the UCM6200.

The selected model template and the default model template will both take effect when generating the config file for the device. However, the model template has higher priority to default model template when it comes to the same setting option/field. If the same option/field has different value configured in the default model template and the selected model template, the value for this option/field in the selected model template will override the value in default model template.



- Click on “Create New Template” to add a model template.

**Table 32: Create New Model Template**


<b>Model</b>	Select a model to apply this template. The supported Grandstream models are listed in the dropdown list for selection.
<b>Template Name</b>	Create a name for the model template.
<b>Description</b>	Enter a description for the model template. This is optional.
<b>Default Model Template</b>	Select to assign this model template as the default model template. The value of the option in default model template will be overridden if other selected model template has a different value for the same option.
<b>Active</b>	Check this option to enable the model template.

- Click on  to edit the model template.


The editing window for model template is shown in the following figure. In the “Options” field, enter the option name key word, the option that contains the key word will be listed. User could then select the option and click on “Add Option” to add it into the model template.

Once added, the option will be shown in the list below. On the left side of each option, users can click on  to remove this option from the model template. On the right side of each option, users can click on  to reset the option to the default value.

User could also click on “Add New Field” to add a P value number and the value to the configuration. The following figure shows setting P value “P1362” to “en”, which means the display language on the LCD is set to English. For P value information of different models, please refer to configuration template here <http://www.grandstream.com/support/tools>.



Edit Template : GXV3240
X



- i Model: GRANDSTREAM GXV3240 ▼
- i Template Name: GXV3240
- i Description: [Empty Field]
- i Default Model Template:
- i Active:

Options MPK 1 ▼
Add Option

Customize Fields

Name	Value	
P1362	en	Possible Match Exists

+ Add New Field

Phone ▼


Multiple-Purposed Key Settings

MPK 1:	Mode	Speed Dial ▼
	Account	Account 1 ▼
	Name	[Empty Field]
	UserID	[Empty Field]

Cancel
Save



**Figure 68: Edit Model Template**



- Click on Save when done. The model template will be displayed on web UI->**PBX->Zero Config->Model Templates** page.
- Click on  to delete the model template or click on “Delete Selected Templates” to delete multiple selected templates at once.
- Click on “Toggle Selected Template(s)” to toggle the status between enabled/disabled for the selected model templates.

## MODEL UPDATE

UCM6200 zero config feature supports provisioning all models of Grandstream SIP end devices. Templates for most of the Grandstream models are built in with the UCM6200 already. Templates for GS Wave and Grandstream surveillance products require users to download and install under web UI->**PBX->Zero Config->Model Update** first before they are available in the UCM6200 for selection. After downloading and installing the model template to the UCM6200, it will show in the dropdown list for “Model” selection when editing the model template.


- Click on  to download the template.
- Click on  to upgrade the model template. Users will see this icon available if the device model has template updated in the UCM6200.

Update Model Packages					
Vendor	Model	Version (Remote/Local)	Size	Option	
Grandstream	GSWave	1.0	8KB		
Grandstream	GSW400E	1.01.0	14KB		
Grandstream	GSW410E	1.01.0	12KB		
Grandstream	Surveillance	1.01.1	12KB		

Total 4 Show 1/1 Go to:

Figure 69: Template Management

In case the UCM6200 is placed in the private network and Internet access is restricted, users will not be able to get packages by downloading and installing from the remote server. Model template package can be manually uploaded from local device through web UI. Please contact Grandstream customer support if the model package is needed for manual uploading.



**Figure 70: Upload Model Template Manually**

## DEVICE CONFIGURATION

On web GUI, page **PBX->Zero Config->Zero Config**, users could create new device, delete existing device(s), make special configuration for a single device, or send NOTIFY to existing device(s).


### CREATE NEW DEVICE

Besides configuring the device after the device is discovered, users could also directly create a new device and configure basic settings before the device is discovered by the UCM6200. Once the device is plugged in, it can then be discovered and provisioned. This gives the system administrator adequate time to set up each device beforehand.

Click on "Create New Device" and the following dialog will show. Follow the steps below to create the configurations for the new device.

1. Firstly, select a model for the device to be created and enter its MAC address, IP address and firmware version (optional) in the corresponding field.
2. Basic settings will show a list of settings based on the model selected in step 1. Users could assign extensions to accounts, assign functions to Line Keys and Multiple-Purposed Keys if supported on the selected model.
3. Click on "Create New Device" to save the configuration for this device.

**Create New Device** X



i Model: GRANDSTREAM GXV3275 v

i MAC Address: 000B825E66E2

i IP Address: 192.168.40.132

i Version: 1.0.1.50

---

**Basic**

Accounts

<input checked="" type="checkbox"/>	Account 1:	1002 <span style="float: right;">v</span>
<input type="checkbox"/>	Account 2:	1002 <span style="float: right;">v</span>
<input type="checkbox"/>	Account 3:	1002 <span style="float: right;">v</span>
<input type="checkbox"/>	Account 4:	1002 <span style="float: right;">v</span>
<input type="checkbox"/>	Account 5:	1002 <span style="float: right;">v</span>
<input type="checkbox"/>	Account 6:	1002 <span style="float: right;">v</span>

Line Key Setting

<input type="checkbox"/>	Line 1:	Line <span style="float: right;">v</span>
--------------------------	---------	---

Cancel
Create New Device

**Figure 71: Create New Device**

## MANAGE DEVICES


The device manually created or discovered from Auto Discover will be listed in the web UI->**PBX->Zero Config->Zero Config** page. Users can see the devices with their MAC address, IP address, vendor, model and etc.

000B822A852C	192.168.40.3	-	1.0.4.9	GRANDSTREAM	GXP2100	-	
000B822B0B34	-	-	1.0.5.31	GRANDSTREAM	GXP2120	-	
000B822B2D94	192.168.40.143	-	1.0.5.26	GRANDSTREAM	GXP2110	-	

**Figure 72: Manage Devices**

- Click on to access the web UI of the phone.
- Click on to edit the device configuration.

A new dialog will be displayed for the users to configure “Basic” settings and “Advanced” settings. “Basic” settings have the same configurations as displayed when manually creating a new device, i.e., account, line key and MPK settings; “Advanced” settings allow users to configure more details in a five-level structure.







**Figure 73: Edit Device**

A preview of the “Advanced” settings is shown in the above figure. There are five levels configurations as described in (1) (2) (3) (4) (5) below, with priority from the lowest to the highest. The configurations in all levels will take effect for the device. If there are same options existing in different level configurations with different value configured, the higher level configuration will override the lower level configuration.

(1) Global Policy

This is the lowest level configuration. The global policy configured in web UI->**PBX->Zero Config->Global Policy** will be applied here. Clicking on “Modify Global Policy” to redirect to page **PBX->Zero Config->Global Policy**.





## (2) Global Templates

Select a global template to be used for the device and click on  to add. Multiple global templates can be selected and users can arrange the priority by adjusting orders via  and . All the selected global templates will take effect. If the same option exists on multiple selected global templates, the value in the template with higher priority will override the one in the template with lower priority. Click on  to remove the global template from the selected list.

## (3) Default Model Template

Default Model Template will be applied to the devices of this model. Default model template can be configured in model template under web UI->**PBX**->**Zero Config**->**Model Templates** page. Please see default model template option in [\[Table 32: Create New Model Template\]](#).


## (4) Model Templates

Select a model template to be used for the device and click on  to add. Multiple global templates can be selected and users can arrange the priority by adjusting orders via  and . All the selected model templates will take effect. If the same option exists on multiple selected model templates, the value in the template with higher priority will override the one in the template with lower priority. Click on  to remove the model template from the selected list.

## (5) Customize Device Settings

This is the highest level configuration for the device. Click on “Modify Customize Device Settings” and following dialog will show.

Edit Customize Device Settings : 000B825E66E2
X



Model: GRANDSTREAM GXV3275

MAC Address: 000B825E66E2

IP Address: 192.168.40.148

Version: 1.0.1.50

Options:  ▼

Customize Fields

Name	Value
<span style="color: #0070c0;">+</span> Add New Field	

Phone ▼

Accounts


<input type="checkbox"/>	Account 1:	Account Active	Yes ▼
		Account Name	<input type="text"/>
		SIP Server	<input type="text"/>
		Outbound Proxy	<input type="text"/>
		SIP User ID	<input type="text"/>
		Authenticate ID	<input type="text"/>

Cancel
Save

**Figure 74: Edit Customize Device Settings**

Scroll down in the dialog to view and edit the device-specific options. If the users would like to add more options which are not in the pre-defined list, click on “Add New Field” to add a P value number and the value to the configuration. The following figure shows setting P value “P1362” to “en”, which means the display language on the LCD is set to English. The warning information on right tells that the option matching the P value number exists and clicking on it will lead to the matching option. For P value information of different models, please refer to configuration template here <http://www.grandstream.com/sites/default/files/Resources/config-template.zip>.

Edit Customize Device Settings : 000B8262B023
X



Model	GRANDSTREAM GXP2140
MAC Address	000B8262B023
IP Address	192.168.40.161
Version	

Options
▼

Customize Fields

Name	Value	
P1362	en	⚠ Possible Match Exists

+
Add New Field

Phone
▼

Default Call Settings

i Dial Plan:

i Enable Call Features:  ▼


i Use # as Dial Key:  ▼

Cancel
Save


**Figure 75: Add P Value in Customize Device Settings**

- Select multiple devices that need to be modified and then click on Modify Selected Devices to batch modify devices.


If selected devices are of the same model, the configuration dialog is like the following figure. Configurations in five levels are all available for users to modify.



**Figure 76: Modify Selected Devices - Same Model**

If selected devices are of different models, the configuration dialog is like the following figure. Click on  to view more devices of other models. Users are only allowed to make modifications in Global Templates and Global Policy level.






**Figure 77: Modify Selected Devices - Different Models**

---

 **Note:**

Performing batch operation will override all the existing device configuration on the page.

---

After the above configurations, save the changes and go back to web UI->**PBX->Zero Config->Zero Config** page. Users could then click on  to send NOTIFY to the SIP end point device and trigger the provisioning process. The device will start downloading the generated configuration file from the URL contained in the NOTIFY message.

Manage Zero Config

Filter: All

WAC Address	IP Address	Extension	Version	Vendor	Model	Create Config	Options
000B262B023	192.168.40.161	-	-	GRANDSTREAM	GXP2140	-	
000B262B024	192.168.40.157	-	-	GRANDSTREAM	GXP2140	-	
000B2601BA9	192.168.40.188	-	-	GRANDSTREAM	GXP2180	-	
000B260ED01	192.168.40.125	1009	-	GRANDSTREAM	GXV3240	-	

Total 4 Show 1/1 Go to  Go

**Figure 78: Device List in Zero Config**

In this web page, users can also click on “Reset All Extensions” to reset the extensions of all the devices.

## SAMPLE APPLICATION

Assuming in a small business office where there are 8 GXP2140 phones used by customer support and 1 GXV3275 phone used by customer support supervisor. 3 of the 8 customer support members speak Spanish and the rest speak English. We could deploy the following configurations to provisioning the office phones for the customer support team.

1. Go to web GUI->**PBX->Zero Config->Zero Config Settings**, select “Enable Zero Config”.
2. Go to web GUI->**PBX->Zero Config->Global Policy**, configure Date Format, Time Format and Firmware Source as follows.

Localization ▼

**Language Settings**

ⓘ Language: English ▼

**Date and Time**

ⓘ Date Format: mm-dd-yyyy ▼

ⓘ Time Format: 24-Hour Clock ▼

ⓘ NTP Server: [Empty Field]

ⓘ Time Zone: GMT-12:00 (International Da ▼

Contact List ⋮

Maintenance ▼


**Upgrade and Provision**

ⓘ Firmware Source:
 


Source	URL	▼
Upgrade via	HTTPS	▼
Server Path	fm.grandstream.com/gs	
File Prefix	[Empty Field]	
File Posfix	[Empty Field]	

ⓘ Allow DHCP Option 43/66: No ▼

**Figure 79: Zero Config Sample - Global Policy**


3. Go to web GUI->**PBX->Zero Config->Model Templates**, create a new model template “English Support Template” for GXP2140. Add option “Language” and set it to “English”. Then select the option “Default Model Template” to make it the default model template.
4. Go to web GUI->**PBX->Zero Config->Model Templates**, create another model template “Spanish Support Template” for GXP2140. Add option “Language” and set it to “Español”.
5. After 9 devices are powered up and connected to the LAN network, use “Auto Discover” function or “Create New Device” function to add the devices to the device list on web UI->**PBX->Zero Config->Zero Config**.
6. On web GUI->**PBX->Zero Config->Zero Config** page, users could identify the devices by their MAC addresses or IP addresses displayed on the list. Click on  to edit the device settings.

- For each of the 5 phones used by English speaking customer support, in “Basic” settings select an available extension for account 1 and click on “Save”. Then click on “Advanced” settings tab to bring up the following dialog. Users will see the English support template is applied since this is the default model template. A preview of the device settings will be listed on the right side.



**Figure 80: Zero Config Sample - Device Preview 1**


- For the 3 phones used by Spanish support, in “Basic” settings select an available extension for account 1 and click on “Save”. Then click on “Advanced” settings tab to bring up the following dialog.




**Figure 81: Zero Config Sample - Device Preview 2**

Select “Spanish Support Template” in ④ “Model Template”. The preview of the device settings is displayed on the right side and we can see the language is set to “Español” since Model Template has the higher priority for the option “Language”, which overrides the value configured in default model template.

9. For the GXV3275 used by the customer support supervisor, select an available extension for account 1 on “Basic” settings and click on “Save”. Users can see the preview of the device configuration in “Advanced” settings. There is no model template configured for GXV3275.



**Figure 82: Zero Config Sample - Device Preview 3**

10. Click on “Apply Changes” to apply saved changes.
11. On the web UI->**PBX**->**Zero Config**->**Zero Config** page, click on  to send NOTIFY to trigger the device to download config file from UCM6200.

Now all the 9 phones in the network will be provisioned with an unique extension registered on the UCM6200. 3 of the phones will be provisioned to display Spanish on LCD and the other 5 will be provisioned to display English on LCD. The GXV3275 used by the supervisor will be provisioned to use the default language on LCD display since it's not specified in the global policy.




## EXTENSIONS

### CREATE NEW USER

#### CREATE NEW SIP EXTENSION

To manually create new SIP user, go to Web GUI->**PBX->Basic/Call Routes->Extensions**. Click on "Create New User"->"Create New SIP Extension" and a new dialog window will show for users to fill in the extension information.



**Figure 83: Create New Device**

SIP extension options are divided into four categories:

- Basic Settings
- Media
- Features
- Specific Time



Click on the tag to view or edit options belonging to that category.  
 The configuration parameters are as follows.

**Table 33: SIP Extension Configuration Parameters->Basic Settings**

General	
<b>Extension</b>	The extension number associated with the user.
<b>CallerID Number</b>	Configure the CallerID Number that would be applied for outbound calls from this user. <b>Note:</b> The ability to manipulate your outbound Caller ID may be limited by your VoIP provider.
<b>Permission</b>	Assign permission level to the user. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal". <b>Note:</b> Users need to have the same level as or higher level than an outbound rule's privilege in order to make outbound calls using this rule.
<b>SIP/IAX Password</b>	Configure the password for the user. A random secure password will be automatically generated. It is recommended to use this password for security purpose.
<b>Auth ID</b>	Configure the authentication ID for the user. If not configured, the extension number will be used for authentication.
<b>Enable Voicemail</b>	Enable voicemail for the user. The default setting is "Yes".
<b>Voicemail Password</b>	Configure voicemail password (digits only) for the user to access the voicemail box. A random numeric password is automatically generated. It is recommended to use the random generated password for security purpose.
<b>Skip Voicemail Password Verification</b>	When user dials voicemail code, the password verification IVR is skipped. If enabled, this would allow one-button voicemail access. By default this option is disabled.
<b>Disable This Extension</b>	If selected, this extension will be disabled on the UCM6200. <b>Note:</b> The disabled extension still exists on the PBX but can't be used on the end device.
User Settings	
<b>First Name</b>	Configure the first name of the user. The first name can contain characters, letters, digits and _.
<b>Last Name</b>	Configure the last name of the user. The last name can contain

	characters, letters, digits and _.
<b>Email Address</b>	Fill in the Email address for the user. Voicemail will be sent to this Email address.
<b>User Password</b>	Configure the password for user portal access. A random numeric password is automatically generated. It is recommended to use the randomly generated password for security purpose.
<b>Language</b>	Select the voice prompt language to be used for this extension. The default setting is "Default" which is the selected voice prompt language under web GUI-> <b>PBX-&gt;Internal Options-&gt;Language</b> . The dropdown list shows all the current available voice prompt languages on the UCM6200. To add more languages in the list, please download voice prompt package by selecting "Check Prompt List" under web UI-> <b>PBX-&gt;Internal Options-&gt;Language</b> .
<b>Concurrent Registrations</b>	The maximum endpoints which can be registered into this extension. For security concerns, the default value is 1.

**Table 34: SIP Extension Configuration Parameters->Media**

<b>SIP Settings</b>	
<b>NAT</b>	Use NAT when the UCM6200 is on a public IP communicating with devices hidden behind NAT (e.g., broadband router). If there is one-way audio issue, usually it's related to NAT configuration or Firewall's support of SIP and RTP ports. The default setting is enabled.
<b>Can Direct Media</b>	By default, the UCM6200 will route the media streams from SIP endpoints through itself. If enabled, the PBX will attempt to negotiate with the endpoints to route the media stream directly. It is not always possible for the UCM6200 to negotiate endpoint-to-endpoint media routing. The default setting is "No".
<b>DTMF Mode</b>	Select DTMF mode for the user to send DTMF. The default setting is "RFC2833". If "Info" is selected, SIP INFO message will be used. If "Inband" is selected, 64-kbit PCMU and PCMA are required. When "Auto" is selected, RFC2833 will be used if offered, otherwise "Inband" will be used.
<b>TEL URI</b>	If the phone has an assigned PSTN telephone number, this field should be set to "User=Phone". "User=Phone" parameter will be attached to the Request-Line and "TO" header in the SIP request to indicate the E.164 number. If set to "Enable", "Tel" will be used instead of "SIP" in the SIP request.
<b>Enable Keep-alive</b>	If enabled, empty SDP packet will be sent to the SIP server periodically to keep the NAT port open. The default setting is "Yes".

<b>Keep-alive Frequency</b>	Configure the Keep-alive interval (in seconds) to check if the host is up. The default setting is 60 seconds.
<b>Enable T.38 UDPTL</b>	Enable or disable T.38 UDPTL support.
<b>SRTP</b>	Enable SRTP for the call. The default setting is disabled.
<b>Fax Mode</b>	<p>Select Fax mode. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;PBX-&gt;Internal Options-&gt;Fax/T.38.</li> </ul>
<b>Strategy</b>	<p>This option controls how the extension can be used on devices within different types of network.</p> <ul style="list-style-type: none"> <li>• Allow All Device in any network can register this extension.</li> <li>• Local Subnet Only Only the user in specific subnet can register this extension. Up to three subnet addresses can be specified.</li> <li>• A Specific IP Address Only the device on the specific IP address can register this extension.</li> </ul> <p>The default setting is "Allow All".</p>
<b>Codec Preference</b>	Select audio and video codec for the extension. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.

**Table 35: SIP Extension Configuration Parameters->Features**

<b>Call Transfer</b>	
<b>Call Forward Unconditional</b>	Configure the Call Forward Unconditional target number. If not configured, the Call Forward Unconditional feature is deactivated. The default setting is deactivated.
<b>CFU Time Condition</b>	<p>Select time condition for Call Forward Unconditional. CFU takes effect only during the selected time condition. The available time condition are "Office Time", "Out of Office Time", "Holiday", "Out of Holiday", "Out of Office Time or Holiday" and "Specific".</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• "Specific" has higher priority to "Office Times" if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific</li> </ul>

	<p>time.</p> <ul style="list-style-type: none"> <li>Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Call Forward No Answer</b>	<p>Configure the Call Forward No Answer target number. If not configured, the Call Forward No Answer feature is deactivated. The default setting is deactivated.</p>
<b>CFN Time Condition</b>	<p>Select time condition for Call Forward No Answer. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>“Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Call Forward Busy</b>	<p>Configure the Call Forward Busy target number. If not configured, the Call Forward Busy feature is deactivated. The default setting is deactivated.</p>
<b>CFB Time Condition</b>	<p>Select time condition for Call Forward Busy. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>“Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>CC Settings</b>	
<b>Enable CC</b>	<p>If enabled, UCM6200 will automatically alert this extension when a called party is available, given that a previous call to that party failed for some reason. By default it's disabled.</p>
<b>CC Mode</b>	<p>Two modes for Call Completion are supported:</p> <ul style="list-style-type: none"> <li><b>Normal:</b> This extension is used as ordinary extension.</li> <li><b>For Trunk:</b> This extension is registered from a PBX.</li> </ul> <p>The default setting is “Normal”.</p>
<b>CC Max Agents</b>	<p>Configure the maximum number of CCSS agents which may be allocated</p>

	for this channel. In other words, this number serves as the maximum number of CC requests this channel is allowed to make. The minimum value is 1.
<b>CC Max Monitors</b>	Configure the maximum number of monitor structures which may be created for this device. In other words, this number tells how many callers may request CC services for a specific device at one time. The minimum value is 1.
<b>Ring Simultaneously</b>	
<b>Ring Simultaneously</b>	Enable this option to have an external number ring simultaneously along with the extension. If a register trunk is used for outbound, the register number will be used to be displayed for the external number as caller ID number.
<b>External Number</b>	Set the external number to be rang simultaneously. '-' is the connection character which will be ignored.
<b>Time Condition for Ring Simultaneously</b>	Ring the external number simultaneously along with the extension on the basis of this time condition.
<b>Other Settings</b>	
<b>Ring Timeout</b>	Configure the number of seconds to ring the user before the call is forwarded to voicemail (voicemail is enabled) or hang up (voicemail is disabled). If not specified, the default ring timeout is 60 seconds on the UCM6200, which can be configured in the global ring timeout setting under web GUI->Internal Options->IVR Prompt: General Preference. The valid range is between 5 seconds and 600 seconds. Note: If the end point also has a ring timeout configured, the actual ring timeout used is the shortest time set by either device.
<b>Auto Record</b>	Enable automatic recording for the calls using this extension. The default setting is disabled. The recording files can be accessed under web GUI->CDR->Recording Files.
<b>Skip Trunk Auth</b>	<ul style="list-style-type: none"> <li>• If set to "yes", users can skip entering the password when making outbound calls.</li> <li>• If set to "By Time", users can skip entering the password when making outbound calls during the selected time condition.</li> <li>• If set to "No", users will be asked to enter the password when making outbound calls.</li> </ul>
<b>Time Condition for Skip Trunk Auth</b>	If 'Skip Trunk Auth' is set to 'By Time', select a time condition during which users can skip entering password when making outbound calls.
<b>Dial Trunk Password</b>	Configure personal password when making outbound calls via trunk.
<b>Support Hot-Desking Mode</b>	If enabled, SIP Password will accept only alphabet characters and digits.

	Auth ID will be changed to the same as Extension.
<b>Enable LDAP</b>	If enabled, the extension will be added to LDAP Phonebook PBX list.
<b>Enable WebRTC Support</b>	Enable registration and call from WebRTC.
<b>Music On Hold</b>	Specify which Music On Hold class to suggest to the bridged channel when putting them on hold.
<b>Call Duration Limit</b>	The maximum duration of call-blocking.

**Table 36: SIP Extension Configuration Parameters->Specific Time**

Specific Time	
<b>Time Condition</b>	Click to add Time Condition to configure specific time for this extension.

## CREATE NEW IAX EXTENSION

The UCM6200 supports Inter-Asterisk eXchange (IAX) protocol. IAX is used for transporting VoIP telephony sessions between servers and terminal devices. IAX is similar to SIP but also has its own characteristic. For more information, please refer to RFC 5465.

To manually create new IAX user, go to Web GUI->**PBX->Basic/Call Routes->Extensions**. Click on "Create New User"->"Create New IAX Extension" and a new dialog window will show for users to fill in the extension information. The configuration parameters are as follows.

**Table 37: IAX Extension Configuration Parameters->Basic Settings**

General	
<b>Extension</b>	The extension number associated with the user.
<b>CallerID Number</b>	Configure the CallerID Number that would be applied for outbound calls from this user. <b>Note:</b> The ability to manipulate your outbound Caller ID may be limited by your VoIP provider.
<b>Permission</b>	Assign permission level to the user. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal". <b>Note:</b> Users need to have the same level as or higher level than an outbound rule's privilege in order to make outbound calls using this rule.
<b>SIP/IAX Password</b>	Configure the password for the user. A random secure password will be automatically generated. It is recommended to use this password for security purpose.

<b>Enable Voicemail</b>	Enable voicemail for the user. The default setting is "Yes".
<b>Voicemail Password</b>	Configure voicemail password (digits only) for the user to access the voicemail box. A random numeric password is automatically generated. It is recommended to use the random generated password for security purpose.
<b>Skip Voicemail Password Verification</b>	When user dials voicemail code, the password verification IVR is skipped. If enabled, this would allow one-button voicemail access. By default this option is disabled.
<b>Disable This Extension</b>	<p>If selected, this extension will be disabled on the UCM6200.</p> <p><b>Note:</b> The disabled extension still exists on the PBX but can't be used on the end device.</p>
<b>User Settings</b>	
<b>First Name</b>	Configure the first name of the user. The first name can contain characters, letters, digits and _.
<b>Last Name</b>	Configure the last name of the user. The last name can contain characters, letters, digits and _.
<b>Email Address</b>	Fill in the Email address for the user. Voicemail will be sent to this Email address.
<b>User Password</b>	Configure the password for user portal access. A random numeric password is automatically generated. It is recommended to use the randomly generated password for security purpose.
<b>Language</b>	Select the voice prompt language to be used for this extension. The default setting is "Default" which is the selected voice prompt language under web GUI-> <b>PBX-&gt;Internal Options-&gt;Language</b> . The dropdown list shows all the current available voice prompt languages on the UCM6200. To add more languages in the list, please download voice prompt package by selecting "Check Prompt List" under web UI-> <b>PBX-&gt;Internal Options-&gt;Language</b> .

**Table 38: IAX Extension Configuration Parameters->Media**

<b>SIP Settings</b>	
<b>Max Number of Calls</b>	Configure the maximum number of calls allowed for each remote IP address.
<b>Require Call Token</b>	Configure to enable/disable requiring call token. If set to "Auto", it might lock out users who depend on backward compatibility when peer authentication credentials are shared between physical endpoints. The default setting is "Yes".

<b>SRTP</b>	Enable SRTP for the call. The default setting is disabled.
<b>Fax Mode</b>	<p>Select Fax Mode. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax. This is the default setting.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;PBX-&gt;Internal Options-&gt;Fax/T.38.</li> </ul>
<b>Strategy</b>	<p>This option controls how the extension can be used on devices within different types of network.</p> <ul style="list-style-type: none"> <li>• Allow All Device in any network can register this extension.</li> <li>• Local Subnet Only Only the user in specific subnet can register this extension. Up to three subnet addresses can be specified.</li> <li>• A Specific IP Address Only the device on the specific IP address can register this extension.</li> </ul> <p>The default setting is "Allow All".</p>
<b>Codec Preference</b>	Select audio and video codec for the extension. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.

**Table 39: IAX Extension Configuration Parameters->Features**

<b>Call Transfer</b>	
<b>Call Forward Unconditional</b>	Configure the Call Forward Unconditional target number. If not configured, the Call Forward Unconditional feature is deactivated. The default setting is deactivated.
<b>CFU Time Condition</b>	<p>Select time condition for Call Forward Unconditional. CFU takes effect only during the selected time condition. The available time condition are "Office Time", "Out of Office Time", "Holiday", "Out of Holiday", "Out of Office Time or Holiday" and "Specific".</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• "Specific" has higher priority to "Office Times" if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>• Office Time and Holiday could be configured on page Settings-&gt;Time</li> </ul>



	Settings->Office Time/Holiday page.
<b>Call Forward No Answer</b>	Configure the Call Forward No Answer target number. If not configured, the Call Forward No Answer feature is deactivated. The default setting is deactivated.
<b>CFN Time Condition</b>	<p>Select time condition for Call Forward No Answer. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• “Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>• Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Call Forward Busy</b>	Configure the Call Forward Busy target number. If not configured, the Call Forward Busy feature is deactivated. The default setting is deactivated.
<b>CFB Time Condition</b>	<p>Select time condition for Call Forward Busy. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• “Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>• Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Ring Simultaneously</b>	
<b>Ring Simultaneously</b>	Enable this option to have an external number ring simultaneously along with the extension. If a register trunk is used for outbound, the register number will be used to be displayed for the external number as caller ID number.
<b>External Number</b>	Set the external number to be rang simultaneously. ‘-’ is the connection character which will be ignored.
<b>Time Condition for Ring Simultaneously</b>	Ring the external number simultaneously along with the extension on the basis of this time condition.
<b>Other Settings</b>	
<b>Ring Timeout</b>	Configure the number of seconds to ring the user before the call is

	forwarded to voicemail (voicemail is enabled) or hang up (voicemail is disabled). If not specified, the default ring timeout is 60 seconds on the UCM6200, which can be configured in the global ring timeout setting under web GUI->Internal Options->IVR Prompt: General Preference. The valid range is between 5 seconds and 600 seconds. Note: If the end point also has a ring timeout configured, the actual ring timeout used is the shortest time set by either device.
<b>Auto Record</b>	Enable automatic recording for the calls using this extension. The default setting is disabled. The recording files can be accessed under web GUI->CDR->Recording Files.
<b>Skip Trunk Auth</b>	<ul style="list-style-type: none"> <li>• If set to “Yes”, users can skip entering the password when making outbound calls.</li> <li>• If set to “By Time”, users can skip entering the password when making outbound calls during the selected time condition.</li> <li>• If set to “No”, users will be asked to enter the password when making outbound calls.</li> </ul>
<b>Time Condition for Skip Trunk Auth</b>	If “Skip Trunk Auth” is set to “By Time”, select a time condition during which users can skip entering password when making outbound calls.
<b>Dial Trunk Password</b>	Configure personal password when making outbound calls via trunk.
<b>Enable LDAP</b>	If enabled, the extension will be added to LDAP Phonebook PBX lists.
<b>Music On Hold</b>	Configure the Music On Hold class to suggest to the bridged channel when putting them on hold.
<b>Call Duration Limit</b>	The maximum duration of call-blocking.

**Table 40: IAX Extension Configuration Parameters->Specific Time**

Specific Time	
Time Condition	Click to add Time Condition to configure specific time for this extension.

### CREATE NEW FXS EXTENSION

The UCM6200 supports Foreign eXchange Subscriber (FXS) interface. FXS is used when user needs to connect analog phone lines or FAX machines to the UCM6200.

To manually create new FXS user, go to Web GUI->**PBX->Basic/Call Routes->Extensions**. Click on "Create New User"->"Create New FXS Extension" and a new dialog window will show for users to fill in the extension information. The configuration parameters are as follows.

**Table 41: FXS Extension Configuration Parameters->Basic Settings**

General	
<b>Extension</b>	The extension number associated with the user.
<b>Analog Station</b>	Select the FXS port to be assigned for this extension.
<b>CallerID Number</b>	<p>Configure the CallerID Number that would be applied for outbound calls from this user.</p> <p><b>Note:</b> The ability to manipulate your outbound Caller ID may be limited by your VoIP provider.</p>
<b>Permission</b>	<p>Assign permission level to the user. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal".</p> <p><b>Note:</b> Users need to have the same level as or higher level than an outbound rule's privilege in order to make outbound calls using this rule.</p>
<b>Enable Voicemail</b>	Enable voicemail for the user. The default setting is "Yes".
<b>Voicemail Password</b>	Configure voicemail password (digits only) for the user to access the voicemail box. A random numeric password is automatically generated. It is recommended to use the random generated password for security purpose.
<b>Skip Voicemail Password Verification</b>	When user dials voicemail code, the password verification IVR is skipped. If enabled, this would allow one-button voicemail access. By default this option is disabled.
<b>Disable This Extension</b>	<p>If selected, this extension will be disabled on the UCM6200.</p> <p><b>Note:</b> The disabled extension still exists on the PBX but can't be used on the end device.</p>
User Settings	
<b>First Name</b>	Configure the first name of the user. The first name can contain characters, letters, digits and _.
<b>Last Name</b>	Configure the last name of the user. The last name can contain characters, letters, digits and _.
<b>Email Address</b>	Fill in the Email address for the user. Voicemail will be sent to this Email address.
<b>User Password</b>	Configure the password for user portal access. A random numeric password is automatically generated. It is recommended to use the randomly generated password for security purpose.

<b>Language</b>	Select the voice prompt language to be used for this extension. The default setting is "Default" which is the selected voice prompt language under web GUI-> <b>PBX-&gt;Internal Options-&gt;Language</b> . The dropdown list shows all the current available voice prompt languages on the UCM6200. To add more languages in the list, please download voice prompt package by selecting "Check Prompt List" under web UI-> <b>PBX-&gt;Internal Options-&gt;Language</b> .
-----------------	---

**Table 42: FXS Extension Configuration Parameters->Media**

Analog Settings	
<b>Call Waiting</b>	Configure to enable/disable call waiting feature. The default setting is "No".
<b>User '#' as SEND</b>	If configured, the # key can be used as SNED key after dialing the number on the analog phone. The default setting is "Yes".
<b>RX Gain</b>	Configure the RX gain for the receiving channel of analog FXS port. The valid range is -30dB to +6dB. The default setting is 0.
<b>TX Gain</b>	Configure the TX gain for the transmitting channel of analog FXS port. The valid range is -30dB to +6dB. The default setting is 0.
<b>MIN RX Flash</b>	Configure the minimum period of time (in milliseconds) that the hook-flash must remain unpressed for the PBX to consider the event as a valid flash event. The valid range is 30ms to 1000ms. The default setting is 200ms.
<b>MAX RX Flash</b>	Configure the maximum period of time (in milliseconds) that the hook-flash must remain unpressed for the PBX to consider the event as a valid flash event. The minimum period of time is 256ms and it can't be modified. The default setting is 1250ms.
<b>Enable Polarity Reversal</b>	If enabled, a polarity reversal will be marked as received when an outgoing call is answered by the remote party. For some countries, a polarity reversal is used for signaling the disconnection of a phone line and the call will be considered as hangup on a polarity reversal. The default setting is "Yes".
<b>Echo Cancellation</b>	Specify "ON", "OFF" or a value (the power of 2) from 32 to 1024 as the number of taps of cancellation. <b>Note:</b> When configuring the number of taps, the number 256 is not translated into 256ms of echo cancellation. Instead, 256 taps means $256/8 = 32$ ms. The default setting is "ON", which is 128 taps.
<b>3-Way Calling</b>	Configure to enable/disable 3-way calling feature on the user. The default setting is enabled.
<b>Send CallerID After</b>	Configure the number of rings before sending CID. Default setting is 1.

<b>Fax Mode</b>	<p>For FXS extension, there are three options available in Fax Mode. The default setting is “None”.</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;PBX-&gt;Internal Options-&gt;Fax/T.38.</li> <li>• Fax Gateway: If selected, the UCM6200 can support conversation and processing of Fax data from T.30 to T.38 or T.38 to T.30. This feature is only available for FXS or FXO port.</li> </ul>
-----------------	--

**Table 43: FXS Extension Configuration Parameters->Features**

Call Transfer	
<b>Call Forward Unconditional</b>	Configure the Call Forward Unconditional target number. If not configured, the Call Forward Unconditional feature is deactivated. The default setting is deactivated.
<b>CFU Time Condition</b>	<p>Select time condition for Call Forward Unconditional. CFU takes effect only during the selected time condition. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• “Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>• Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Call Forward No Answer</b>	Configure the Call Forward No Answer target number. If not configured, the Call Forward No Answer feature is deactivated. The default setting is deactivated.
<b>CFN Time Condition</b>	<p>Select time condition for Call Forward No Answer. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>• “Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>• Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific</li> </ul>

	<p>time.</p> <ul style="list-style-type: none"> <li>Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>Call Forward Busy</b>	Configure the Call Forward Busy target number. If not configured, the Call Forward Busy feature is deactivated. The default setting is deactivated.
<b>CFB Time Condition</b>	<p>Select time condition for Call Forward Busy. The available time condition are “Office Time”, “Out of Office Time”, “Holiday”, “Out of Holiday”, “Out of Office Time or Holiday” and “Specific”.</p> <p>Note:</p> <ul style="list-style-type: none"> <li>“Specific” has higher priority to “Office Times” if there is a conflict in terms of time period.</li> <li>Specific time can be configured on the bottom of the extension configuration dialog. Scroll down the add Time Condition for specific time.</li> <li>Office Time and Holiday could be configured on page Settings-&gt;Time Settings-&gt;Office Time/Holiday page.</li> </ul>
<b>CC Settings</b>	
<b>Enable CC</b>	If enabled, UCM6200 will automatically alert this extension when a called party is available, given that a previous call to that party failed for some reason.
<b>Ring Simultaneously</b>	
<b>Ring Simultaneously</b>	<p>Enable this option to have an external number ring simultaneously along with the extension.</p> <p>If a register trunk is used for outbound, the register number will be used to be displayed for the external number as caller ID number.</p>
<b>External Number</b>	Set the external number to be rang simultaneously. ‘.’ is the connection character which will be ignored.
<b>Time Condition for Ring Simultaneously</b>	Ring the external number simultaneously along with the extension on the basis of this time condition.
<b>Hotline</b>	
<b>Enable Hotline</b>	If enabled, hotline dialing plan will be activated, a pre-configured number will be used according to the selected Hotline Type.
<b>Hotline Number</b>	Configure the Hotline Number
<b>Hotline Type</b>	<p>Configure the Hotline Type:</p> <ul style="list-style-type: none"> <li><b>Immediate Hotline:</b> When the phone is off-hook, UCM6200 will immediately dial the preset number</li> <li><b>Delay Hotline:</b> When the phone is off-hook, if there is no dialing within 5 seconds, UCM6200 will dial the preset number.</li> </ul>
<b>Other Settings</b>	

<b>Ring Timeout</b>	<p>Configure the number of seconds to ring the user before the call is forwarded to voicemail (voicemail is enabled) or hang up (voicemail is disabled). If not specified, the default ring timeout is 60 seconds on the UCM6200, which can be configured in the global ring timeout setting under web GUI-&gt;Internal Options-&gt;IVR Prompt: General Preference. The valid range is between 5 seconds and 600 seconds.</p> <p>Note: If the end point also has a ring timeout configured, the actual ring timeout used is the shortest time set by either device.</p>
<b>Auto Record</b>	<p>Enable automatic recording for the calls using this extension. The default setting is disabled. The recording files can be accessed under web GUI-&gt;CDR-&gt;Recording Files.</p>
<b>Skip Trunk Auth</b>	<ul style="list-style-type: none"> <li>• If set to "Yes", users can skip entering the password when making outbound calls.</li> <li>• If set to "By Time", users can skip entering the password when making outbound calls during the selected time condition.</li> <li>• If set to "No", users will be asked to enter the password when making outbound calls.</li> </ul>
<b>Time Condition for Skip Trunk Auth</b>	<p>If "Skip Trunk Auth" is set to "By Time", select a time condition during which users can skip entering password when making outbound calls.</p>
<b>Dial Trunk Password</b>	<p>Configure personal password when making outbound calls via trunk.</p>
<b>Enable LDAP</b>	<p>If enabled, this extension will be added to LDAP Phonebook PBX list; if disabled, this extension will be skipped when creating LDAP Phonebook.</p>
<b>Music On Hold</b>	<p>Select which Music On Hold class to suggest to extension when putting the active call on hold.</p>
<b>Call Duration Limit</b>	<p>Configure the maximum duration of call-blocking.</p>

**Table 44: FXS Extension Configuration Parameters->Specific Time**

Specific Time	
<b>Time Condition</b>	Click to add Time Condition to configure specific time for this extension.

## BATCH ADD EXTENSIONS

### BATCH ADD SIP EXTENSIONS

In order to add multiple SIP extensions, BATCH add can be used to create standardized SIP extension accounts. However, unique extension user name can't be set using BATCH add.

Under Web GUI->**PBX->Basic/Call Routes->Extensions**, click on "Batch Add Extensions"->"Batch Add SIP Extensions".

**Table 45: Batch Add SIP Extension Parameters**

General	
<b>Start Extension</b>	Configure the starting extension number of the batch of extensions to be added.
<b>Create Number</b>	Specify the number of extensions to be added. The default setting is 5.
<b>Permission</b>	<p>Assign permission level to the user. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal".</p> <p><b>Note:</b> Users need to have the same level as or higher level than an outbound rule's privilege in order to make outbound calls from this rule.</p>
<b>Enable Voicemail</b>	Enable Voicemail for the user. The default setting is "Yes".
<b>SIP/IAX Password</b>	<p>Configure the SIP/IAX password for the users. Three options are available to create password for the batch of extensions.</p> <ul style="list-style-type: none"> <li>• User Random Password. A random secure password will be automatically generated. It is recommended to use this password for security purpose.</li> <li>• Use Extension as Password.</li> <li>• Enter a password to be used on all the extensions in the batch.</li> </ul>
<b>Voicemail Password</b>	<p>Configure Voicemail password (digits only) for the users.</p> <ul style="list-style-type: none"> <li>• User Random Password. A random password in digits will be automatically generated. It is recommended to use this password for security purpose.</li> <li>• Use Extension as Password.</li> <li>• Enter a password to be used on all the extensions in the batch.</li> </ul>
<b>Ring Timeout</b>	<p>Configure the number of seconds to ring the user before the call is forwarded to voicemail (voicemail is enabled) or hang up (voicemail is disabled). If not specified, the default ring timeout is 60 seconds on the UCM6200, which can be configured in the global ring timeout setting under web GUI-&gt;<b>Internal Options-&gt;IVR Prompt</b>: General Preference. The valid range is between 5 seconds and 600 seconds.</p> <p><b>Note:</b> If the end point also has a ring timeout configured, the actual ring timeout used is the shortest time set by either device.</p>
<b>Auto Record</b>	Enable automatic recording for the calls using this extension. The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .
<b>Skip Voicemail Password Verification</b>	When user dials voicemail code, the password verification IVR is skipped. If enabled, this would allow one-button voicemail access. By default this



	option is disabled.
<b>Music On Hold</b>	Select which Music On Hold class to suggest to extensions when putting them on hold.
<b>Enable LDAP</b>	If enabled, the batch added extensions will be added to LDAP Phonebook PBX list; if disabled, the batch added extensions will be skipped when creating LDAP Phonebook.
<b>Enable WebRTC Support</b>	If enabled, extensions will be able to login to user portal and use Web RTC features.
<b>Call Duration Limit</b>	Configure the maximum duration of call-blocking.
<b>SIP Settings</b>	
<b>NAT</b>	Use NAT when the PBX is on a public IP communicating with devices hidden behind NAT (e.g., broadband router). If there is one-way audio issue, usually it's related to NAT configuration or Firewall's support of SIP and RTP ports. The default setting is enabled.
<b>Can Direct Media</b>	By default, the PBX will route the media steams from SIP endpoints through itself. If enabled, the PBX will attempt to negotiate with the endpoints to route the media stream directly. It is not always possible for the PBX to negotiate endpoint-to-endpoint media routing. The default setting is "No".
<b>DTMF Mode</b>	Select DTMF mode for the user to send DTMF. The default setting is "RFC2833". If "Info" is selected, SIP INFO message will be used. If "Inband" is selected, 64-kbit codec PCMU and PCMA are required. When "Auto" is selected, RFC2833 will be used if offered, otherwise "Inband" will be used.
<b>Enable Keep-alive</b>	If enabled, empty SDP packet will be sent to the SIP server periodically to keep the NAT port open. The default setting is "Yes".
<b>Keep-alive Frequency</b>	Configure the number of seconds for the host to be up for Keep-alive. The default setting is 60 seconds.
<b>TEL URI</b>	If the end device/phone has an assigned PSTN telephone number, this field should be set to "User=Phone". Then a "User=Phone" parameter will be attached to the Request-Line and TO header in the SIP request to indicate the E.164 number. If set to "Enable", "Tel:" will be used instead of "SIP:" in the SIP request. The default setting is disabled.
<b>Concurrent Registrations</b>	The maximum endpoints which can be registered into this extension. For security concerns, the default value is 1.
<b>Other Settings</b>	
<b>SRTP</b>	Enable SRTP for the call. The default setting is "No".
<b>Fax Mode</b>	Select Fax mode for this user. The default setting is "None".

	<ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;PBX-&gt;Internal Options-&gt;Fax/T.38.</li> </ul>
<b>Strategy</b>	<p>This option controls how the extension can be used on devices within different types of network.</p> <ul style="list-style-type: none"> <li>• Allow All Device in any network can register this extension.</li> <li>• Local Subnet Only Only the user in specific subnet can register this extension. Up to three subnet addresses can be specified.</li> <li>• A Specific IP Address. Only the device on the specific IP address can register this extension. The default setting is "Allow All".</li> </ul>
<b>Enable T.38 UDPTL</b>	Enable or disable T.38 UDPTL Support.
<b>Skip Trunk Auth</b>	If enable "All", users do not need to enter password when making an outbound call. If enable "Follow Me", the user can dial out via follow me without password.
<b>Codec Preference</b>	Select audio and video codec for the extension. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.722, G.729, G.723, Ilbc, ADPCM, LPC10, H.264, H.263, H.263p and VP8.

## BATCH ADD IAX EXTENSIONS

Under Web GUI->**PBX->Basic/Call Routes->Extensions**, click on "Batch Add Extensions"->"Batch Add IAX Extensions".




**Table 46: Batch Add IAX Extension Parameters**


General	
<b>Start Extension</b>	Configure the starting extension number of the batch of extensions to be added.
<b>Create Number</b>	Specify the number of extensions to be added. The default setting is 5.
<b>Permission</b>	<p>Assign permission level to the user. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal".</p> <p><b>Note:</b></p>

	Users need to have the same level as or higher level than an outbound rule's privilege in order to make outbound calls from this rule.
<b>Enable Voicemail</b>	Enable Voicemail for the user. The default setting is "Yes".
<b>SIP/IAX Password</b>	<p>Configure the SIP/IAX password for the users. Three options are available to create password for the batch of extensions.</p> <ul style="list-style-type: none"> <li>• User Random Password. A random secure password will be automatically generated. It is recommended to use this password for security purpose.</li> <li>• Use Extension as Password.</li> <li>• Enter a password to be used on all the extensions in the batch.</li> </ul>
<b>Voicemail Password</b>	<p>Configure Voicemail password (digits only) for the users.</p> <ul style="list-style-type: none"> <li>• User Random Password. A random password in digits will be automatically generated. It is recommended to use this password for security purpose.</li> <li>• Use Extension as Password.</li> <li>• Enter a password to be used on all the extensions in the batch.</li> </ul>
<b>Ring Timeout</b>	<p>Configure the number of seconds to ring the user before the call is forwarded to voicemail (voicemail is enabled) or hang up (voicemail is disabled). If not specified, the default ring timeout is 60 seconds on the UCM6200, which can be configured in the global ring timeout setting under web GUI-&gt;<b>Internal Options-&gt;IVR Prompt</b>: General Preference. The valid range is between 5 seconds and 600 seconds.</p> <p><b>Note:</b> If the end point also has a ring timeout configured, the actual ring timeout used is the shortest time set by either device.</p>
<b>Auto Record</b>	Enable automatic recording for the calls using this extension. The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .
<b>Skip Voicemail Password Verification</b>	When user dials voicemail code, the password verification IVR is skipped. If enabled, this would allow one-button voicemail access. By default this option is disabled.
<b>Music On Hold</b>	Select which Music On Hold class to suggest to extensions when putting them on hold.
<b>Enable LDAP</b>	If enabled, the batch added extensions will be added to LDAP Phonebook PBX list; if disabled, the batch added extensions will be skipped when creating LDAP Phonebook.
<b>Call Duration Limit</b>	Configure the maximum duration of call-blocking.
<b>IAX Settings</b>	
<b>Max Number of Calls</b>	Configure the maximum number of calls allowed for each remote IP








	address.
<b>Require Call Token</b>	Configure to enable/disable requiring call token. If set to "Auto", it might lock out users who depend on backward compatibility when peer authentication credentials are shared between physical endpoints. The default setting is "Yes".
<b>Other Settings</b>	
<b>SRTP</b>	Enable SRTP for the call. The default setting is "No".
<b>Fax Mode</b>	<p>Select Fax Mode for this user. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;<b>PBX-&gt;Internal Options-&gt;Fax/T.38</b>.</li> </ul>
<b>Strategy</b>	<p>This option controls how the extension can be used on devices within different types of network.</p> <ul style="list-style-type: none"> <li>• Allow All Device in any network can register this extension.</li> <li>• Local Subnet Only Only the user in specific subnet can register this extension. Up to three subnet addresses can be specified.</li> <li>• A Specific IP Address. Only the device on the specific IP address can register this extension.</li> </ul> <p>The default setting is "Allow All".</p>
<b>Skip Trunk Auth</b>	If enable "All", users do not need to enter password when making an outbound call. If enable "Follow Me", the call can dial out via follow me without password.
<b>Codec Preference</b>	Select audio and video codec for the extension. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.722, G.729, G.723, iLBC, ADPCM, LPC10, H.264, H.263, H.263p and VP8.

## SEARCH AND EDIT EXTENSION

All the UCM6200 extensions are listed under Web GUI->**PBX->Basic/Call Routes->Extensions**, with status, Extension, CallerID Name, Technology (SIP, IAX and FXS), IP and Port. Each extension has a checkbox for users to "Modify Selected Extensions" or "Delete Selected Extensions". Also, options "Edit" , "Reboot"  and "Delete"  are available per extension. User can search an extension by specifying the extension number to find an extension quickly.




**Figure 84: Manage Extensions**

- **Status**  
 Users can see the following icon for each extension to indicate the SIP status.
  -  Green: Free
  -  Blue: Ringing
  -  Yellow: In Use
  -  Grey: Unavailable (the extension is not registered or disabled on the PBX)
  
- **Edit single extension**  
 Click on  to start editing the extension parameters.
  
- **Reboot the user**  
 Click on  to send NOTIFY reboot event to the device which has an UCM6200 extension already registered. To successfully reboot the user, "Zero Config" needs to be enabled on the UCM6200 web GUI->PBX->Zero Config->Auto Provisioning Settings.
  
- **Delete single extension**  
 Click on  to delete the extension. Or select the checkbox of the extension and then click on "Delete Selected Extensions".
  
- **Modify selected extensions**  
 Select the checkbox for the extension(s). Then click on "Modify Selected Extensions" to edit the extensions in a batch.
  
- **Delete selected extensions**  
 Select the checkbox for the extension(s). Then click on "Delete Selected Extensions" to delete the extension(s).

## EXPORT EXTENSIONS

The extensions configured on the UCM6200 can be exported to csv format file with selected technology "SIP", "IAX" or "FXS". Click on "Export Extensions" button and select technology in the prompt below.




**Figure 85: Export Extensions**

The exported csv file can be serve as a template for users to fill in desired extension information to be imported to the UCM6200.

## IMPORT EXTENSIONS

The capability to import extensions to the UCM6200 provides users flexibility to batch add extensions with similar or different configuration quickly into the PBX system.

1. Export extension csv file from the UCM6200 by clicking on "Export Extensions" button.
2. Fill up the extension information you would like in the exported csv template.
3. Click on "Import Extensions" button. The following dialog will be prompted.




**Figure 86: Import Extensions**

4. Select the option in "On Duplicate Extension" to define how the duplicate extension(s) in the imported csv file should be treated by the PBX.
  - Skip: Duplicate extensions in the csv file will be skipped. The PBX will keep the current extension

information as previously configured without change.


- **Delete and Recreate:** The current extension previously configured will be deleted and the duplicate extension in the csv file will be loaded to the PBX.
- **Update Information:** The current extension previously configured in the PBX will be kept. However, if the duplicate extension in the csv file has different configuration for any options, it will override the configuration for those options in the extension.

5. Click on  to select csv file from local directory in the PC.
6. Click on "Save" to import the csv file.
7. Click on "Apply Changes" to apply the imported file on the UCM6200.

## EMAIL TO USER

Once the extensions are created with Email address, the PBX administrator can click on button "Email To User" to send the account registration and configuration information to the user. Please make sure Email setting under web UI->**Settings->Email Settings** is properly configured and tested on the UCM6200 before using "Email To User".

When click on "Email To User" button, the following message will be prompted in the web page. Click on OK to confirm sending the account information to all users' Email addresses.



**Figure 87: Email To User - Prompt Information**

The user will receive Email including account registration information and LDAP configuration. A QR code is also generated for Mobile applications to scan it and get automatically provisioned. QR code provisioning is supported on Grandstream Softphone GS Wave Android™ application and iOS application.

Account Name : 1001  
SIP Server : 192.168.2.1  
SIP User ID : 1001  
Authenticate ID : 1001  
Authenticate Password : t\*297eoS1h  
Name :

This is the QR code of this account.




Figure 88: Account Registration Information and QR Code

Server Address : 192.168.2.1  
Port : 389  
Base : dc=pbx,dc=com  
This is the QR code of this LDAP config.




Figure 89: LDAP Client Information and QR Code



## MULTIPLE REGISTRATIONS PER EXTENSION

UCM6200 supports multiple registrations per extension so that users can use the same extension on devices in different locations.



**Figure 90: Multiple Registrations per Extension**

This feature can be enabled by configuring option “Concurrent Registrations” under web **UI->PBX->Basic/Call Routes->Edit Extension**. The default value is set to 1 for security purpose.

Edit Extension : 1000
X

Basic Settings
Media
Features
Specific Time

**General**

<span style="font-size: small;">i</span> Extension*: <input style="width: 80%;" type="text" value="1000"/>	<span style="font-size: small;">i</span> CallerID Number: <input style="width: 80%;" type="text"/>
<span style="font-size: small;">i</span> Permission: <input style="width: 80%;" type="text" value="Internal"/>	<span style="font-size: small;">i</span> SIP/AX Password*: <input style="width: 80%;" type="password" value="••••••"/>
<span style="font-size: small;">i</span> AuthID: <input style="width: 80%;" type="text"/>	<span style="font-size: small;">i</span> Enable Voicemail: <input checked="" type="checkbox"/>
<span style="font-size: small;">i</span> Voicemail Password*: <input style="width: 80%;" type="password" value="••••"/>	<span style="font-size: small;">i</span> Skip Voicemail Password Verification: <input checked="" type="checkbox"/>
<span style="font-size: small;">i</span> Disable This Extension: <input type="checkbox"/>	

**User Settings**

<span style="font-size: small;">i</span> First Name: <input style="width: 80%;" type="text"/>	<span style="font-size: small;">i</span> Last Name: <input style="width: 80%;" type="text"/>
<span style="font-size: small;">i</span> Email Address: <input style="width: 80%;" type="text"/>	<span style="font-size: small;">i</span> User Password*: <input style="width: 80%;" type="password" value="••••••"/>
<span style="font-size: small;">i</span> Language: <input style="width: 80%;" type="text" value="Default"/>	<span style="font-size: small;">i</span> <span style="border: 2px solid red; padding: 2px;">Concurrent Registrations</span> : <input style="width: 80%;" type="text" value="1"/>

**Figure 91: Extension - Concurrent Registration**

## SMS MESSAGE SUPPORT

The UCM6200 provides built-in SIP SMS message support. For SIP end devices such as Grandstream GXP or GXV phones that supports SIP message, after an UCM6200 account is registered on the end device, the user can send and receive SMS message. Please refer to the end device documentation on how to send and receive SMS message.

SMS Message support is a new feature added since firmware 1.0.10.x.





Figure 92: SMS Message Support



# TRUNKS

## ANALOG TRUNKS

Go to Web GUI->**PBX->Basic/Call Routes->Analog Trunks** to add and edit analog trunks.

- Click on "Create New Analog Trunk" to add a new analog trunk.
- Click on  to edit the analog trunk.
- Click on  to delete the analog trunk.

## ANALOG TRUNK CONFIGURATION

The analog trunk options are listed in the table below.

**Table 47: Analog Trunk Configuration Parameters**

<b>Channels</b>	Select the channel for the analog trunk. <ul style="list-style-type: none"> <li>• UCM6202: 2 channels</li> <li>• UCM6204: 4 channels</li> <li>• UCM6208: 8 channels</li> </ul>
<b>Trunk Name</b>	Specify a unique label to identify the trunk when listed in outbound rules, incoming rules and etc.
<b>SLA Mode</b>	Enable this option to satisfy two primary use cases, which include emulating a simple key system and creating shared extensions on a PBX. Enable SLA Mode will disable polarity reversal.
<b>Barge Allowed</b>	The barge option specifies whether or not other stations are allowed to join a call in progress on this trunk. If enabled, the other stations can press the line button to join the call. The default setting is Yes.
<b>Hold Access</b>	The hold option specifies hold permissions for this trunk. If set to "Open", any station can place this trunk on hold and any other station is allowed to retrieve the call. If set to "Private", only the station that places the call on hold can retrieve the call. The default setting is Yes.
<b>Advanced Options</b>	
<b>Enable Polarity Reversal</b>	If enabled, a polarity reversal will be marked as received when an outgoing call is answered by the remote party. For some countries, a polarity reversal is used for signaling the disconnection of a phone line and the call will be considered as "hangup" on a polarity reversal. The

	default setting is “No”.
<b>Polarity on Answer Delay</b>	When FXO port answers the call, FXS may send a Polarity Reversal. If this interval is shorter than the value of “Polarity on Answer Delay”, the Polarity Reversal will be ignored. Otherwise, the FXO will onhook to disconnect the call. The default setting is 600ms.
<b>Current Disconnect Threshold (ms)</b>	This is the periodic time (in ms) that the UCM6200 will use to check on a voltage drop in the line. The default setting is 200. The valid range is 50 to 3000.
<b>Ring Timeout</b>	Configure the ring timeout (in ms). Trunk (FXO) devices must have a timeout to determine if there was a hangup before the line is answered. This value can be used to configure how long it takes before the UCM6200 considers a non-ringing line with hangup activity. The default setting is 8000.
<b>RX Gain</b>	Configure the RX gain for the receiving channel of analog FXO port. The valid range is from -13.5 (dB) to + 12.0 (dB). The default setting is 0.
<b>TX Gain</b>	Configure the TX gain for the transmitting channel of analog FXO port. The valid range is from -13.5 (dB) to + 12.0 (dB). The default setting is 0.
<b>Use CallerID</b>	Configure to enable CallerID detection. The default setting is “Yes”.
<b>Caller ID Scheme</b>	Select the Caller ID scheme for this trunk. The default setting is “Bellcore/Telcordia”.
<b>FXO Dial Delay(ms)</b>	Configure the time interval between off-hook and first dialed digit for outbound calls.
<b>Auto Record</b>	Enable automatic recording for the calls using this trunk. The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .
<b>Disable This Trunk</b>	If selected, the trunk will be disabled.
<b>DAHDI Out Line Selection</b>	<p>This is to implement analog trunk outbound line selection strategy. Three options are available:</p> <ul style="list-style-type: none"> <li>• Ascend When the call goes out from this analog trunk, it will always try to use the first idle FXO port. The port order that the call will use to go out would be port 1-&gt;port 2-&gt;port 10-&gt;port 16. Every time it will start with port 1 (if it's idle).</li> <li>• Poll When the call goes out from this analog trunk, it will use the port that is not used last time. And it will always use the port in the order of port 1-&gt;2-&gt;10-&gt;16-&gt;1-&gt;2-&gt;10-&gt;16-&gt;1-&gt;2-&gt;10-&gt;16..., following the last port being used.</li> <li>• Descend</li> </ul>

	<p>When the call goes out from this analog trunk, it will always try to use the last idle FXO port. The port order that the call will use to go out would be port 16-&gt;port 10-&gt;port 2-&gt;port 1. Every time it will start with port 16 (if it's idle).</p> <p>The default setting is "Ascend" mode.</p>
<b>Tone Settings</b>	
<b>Busy Detection</b>	<p>Busy Detection is used to detect far end hangup or for detecting busy signal. The default setting is "Yes".</p>
<b>Busy Tone Count</b>	<p>If "Busy Detection" is enabled, users can specify the number of busy tones to be played before hanging up. The default setting is 2. Better results might be achieved if set to 4, 6 or even 8. Please note that the higher the number is, the more time is needed to hangup the channel. However, this might lower the probability to get random hangup.</p>
<b>Congestion Detection</b>	<p>Congestion detection is used to detect far end congestion signal. The default setting is "Yes".</p>
<b>Congestion Count</b>	<p>If "Congestion Detection" is enabled, users can specify the number of congestion tones to wait for. The default setting is 2.</p>
<b>Tone Country</b>	<p>Select the country for tone settings. If "Custom" is selected, users could manually configure the values for Busy Tone and Congestion Tone. The default setting is "United States of America (USA)".</p>
<b>Busy Tone</b>	<p><b>Syntax:</b>  <code>f1=val[@level][,f2=val[@level]],c=on1/off1[-on2/off2[-on3/off3]];</code>          Frequencies are in Hz and cadence on and off are in ms.          Frequencies Range: [0, 4000)          Busy Level Range: (-300, 0)          Cadence Range: [0, 16383].          Select Tone Country "Custom" to manually configure Busy Tone value.  <b>Default value:</b>  <code>f1=480@-50,f2=620@-50,c=500/500</code></p>
<b>Congestion Tone</b>	<p><b>Syntax:</b>  <code>f1=val[@level][,f2=val[@level]],c=on1/off1[-on2/off2[-on3/off3]];</code>          Frequencies are in Hz and cadence on and off are in ms.          Frequencies Range: [0, 4000)          Busy Level Range: (-300, 0)          Cadence Range: [0, 16383].          Select Tone Country "Custom" to manually configure Busy Tone value.  <b>Default value:</b>  <code>f1=480@-50,f2=620@-50,c=250/250</code></p>


## PSTN Detection

Click on "Detect" to detect the busy tone, Polarity Reversal and Current Disconnect by PSTN. Before the detecting, please make sure there are more than one channel configured and working properly. If the detection has busy tone, the "Tone Country" option will be set as "Custom".

## PSTN DETECTION

The UCM6200 provides PSTN detection function to help users detect the busy tone, Polarity Reversal and Current Disconnect by making a call from the PSTN line to another destination. The detecting call will be answered and up for about 1 minute. Once done, the detecting result will show and can be used for the UCM6200 settings.

1. Go to UCM6200 web GUI->**PBX->Basic/Call Routes->Analog Trunks** page.
2. Click to edit the analog trunk created for the FXO port.
3. In the dialog window to edit the analog trunk, go to "Tone Settings" section and there are two methods to set the busy tone.
  - Tone Country. The default setting is "United States of America (USA)".
  - PSTN Detection.



Tone Settings	
Busy Detection:	<input checked="" type="checkbox"/> Busy Tone Count*: 2
Congestion Detection:	<input checked="" type="checkbox"/> Congestion Count*: 2
Tone Country*:	United States of America (USA)
Busy Tone*:	f1=480@-50,f2=620@-50,c=500/500
Congestion Tone*:	f1=480@-50,f2=620@-50,c=250/250
PSTN Detection:	<b>Detect</b>
<input type="button" value="Cancel"/> <input type="button" value="Save"/>	

Figure 93: UCM6200 FXO Tone Settings

4. Click on "Detect" to start PSTN detection.



**Edit Analog Trunk: trunk\_1** [X]

ⓘ Detect model:

ⓘ Source Channel (to be detected):

ⓘ Destination Channel:

ⓘ Destination Number:

Note: Detection will keep the call up for about 1 minute. If you have selected Semi-auto Detect, please pick up the phone only after you are informed.

**Figure 94: UCM6200 PSTN Detection**


- If there are two FXO ports connected to PSTN lines, use the following settings for auto-detection.

**Detect Model:** Auto Detect.

**Source Channel:** The source channel to be detected.

**Destination Channel:** The channel to help detecting. For example, the second FXO port.

**Destination Number:** The number to be dialed for detecting. This number must be the actual PSTN number for the FXO port used as the destination channel.



**Edit Analog Trunk: trunk\_1** [X]

ⓘ Detect model:

ⓘ Source Channel (to be detected):

ⓘ Destination Channel:

ⓘ Destination Number:

Note: Detection will keep the call up for about 1 minute. If you have selected Semi-auto Detect, please pick up the phone only after you are informed.

**Figure 95: UCM6200 PSTN Detection: Auto Detect**



- If there is only one FXO port connected to PSTN line, use the following settings for auto-detection.




Figure 96: UCM6200 PSTN Detection: Semi-Auto Detect

**Detect Model:** Semi-auto Detect.

**Source Channel:** The source channel to be detected.

**Destination Number:** The number to be dialed for detecting. This number could be a cell phone number or other PSTN number that can be reached from the source channel PSTN number.

5. Click "Detect" to start detecting. The source channel will initiate a call to the destination number. For "Auto Detect", the call will be automatically answered. For "Semi-auto Detect", the UCM6200 web GUI will display prompt to notify the user to answer or hang up the call to finish the detecting process.
6. Once done, the detected result will show. Users could save the detecting result as the current UCM6200 settings.

Table 48: PSTN Detection for Analog Trunk

<b>Detect Model</b>	<p>Select "Auto Detect" or "Semi-auto Detect" for PSTN detection.</p> <ul style="list-style-type: none"> <li>• Auto Detect Please make sure two or more channels are connected to the UCM6200 and in idle status before starting the detection. During the detection, one channel will be used as caller (Source Channel) and another channel will be used as callee (Destination Channel). The UCM6200 will control the call to be established and hang up between caller and callee to finish the detection.</li> <li>• Semi-auto Detect Semi-auto detection requires answering or hanging up the call</li> </ul>
---------------------	---

	<p>manually. Please make sure one channel is connected to the UCM6200 and in idle status before starting the detection. During the detection, source channel will be used as caller and send the call to the configured Destination Number. Users will then need follow the prompts in web GUI to help finish the detection.</p> <p>The default setting is "Auto Detect".</p>
<b>Source Channel</b>	Select the channel to be detected.
<b>Destination Channel</b>	Select the channel to help detect when "Auto Detect" is used.
<b>Destination Number</b>	Configure the number to be called to help the detection.







**Note:**

- The PSTN detection process will keep the call up for about 1 minute.
  - If "Semi-auto Detect" is used, please pick up the call only after informed from the web GUI prompt.
  - Once the detection is successful, the detected parameters "Busy Tone", "Polarity Reversal" and "Current Disconnect by PSTN" will be filled into the corresponding fields in the analog trunk configuration.
- 

## VOIP TRUNKS

VoIP trunks can be configured in UCM6200 under Web GUI->**PBX->Basic/Call Routes->VoIP Trunks**. Once created, the VoIP trunks will be listed with Provider Name, Type, Hostname/IP, Username and Options to edit/detect the trunk.

- Click on "Create New SIP Trunk" or "Create New IAX Trunk" to add a new VoIP trunk.
- Click on  to configure detailed parameters for the VoIP trunk.
- Click on  to configure Direct Outward Dialing (DOD) for the SIP Trunk.
- Click on  to start LDAP Sync.
- Click on  to delete the VoIP trunk.

For VoIP trunk example, please refer to the document in the following link:

[http://www.grandstream.com/sites/default/files/Resources/ucm\\_to\\_ucm\\_peer\\_guide.pdf](http://www.grandstream.com/sites/default/files/Resources/ucm_to_ucm_peer_guide.pdf)

The VoIP trunk options are listed in the table below.

**Table 49: Create New SIP Trunk**

<b>Type</b>	Select the VoIP trunk type. <ul style="list-style-type: none"> <li>Peer SIP Trunk</li> <li>Register SIP Trunk</li> </ul>
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.
<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Keep Original CID</b>	Keep the CID from the inbound call when dialing out. This setting will override "Keep Trunk CID" option. Please make sure that the peer PBX at the other side supports to match user entry using "username" field from authentication line.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".
<b>NAT</b>	Turn on this setting when the PBX is using public IP and communicating with devices behind NAT. If there is one-way audio issue, usually it is related to NAT configuration or SIP/RTP port support on the firewall.
<b>Disable This Trunk</b>	If checked, the trunk will be disabled. <p><b>Note:</b> If a current SIP trunk is disabled, UCM will send UNREGISTER message (REGISTER message with expires=0) to the SIP provider.</p>
<b>TEL URI</b>	If the trunk has an assigned PSTN telephone number, this field should be set to "User=Phone". Then a "User=Phone" parameter will be attached to the Request-Line and TO header in the SIP request to indicate the E.164 number. If set to "Enable", "Tel:" will be used instead of "SIP:" in the SIP request. The default setting is disabled.
<b>Caller ID</b>	Configure the Caller ID. This is the number that the trunk will try to use when making outbound calls. For some providers, it might not be possible to set the CallerID with this option and this option will be ignored. <p>When making outgoing calls, the following rules are used to determine which CallerID will be used if they exist:</p> <ul style="list-style-type: none"> <li>The CallerID configured for the extension will be looked up first.</li> </ul>

	<ul style="list-style-type: none"> <li>• If no CallerID is configured for the extension, the CallerID configured for the trunk will be used.</li> <li>• If the above two are missing, the "Global Outbound CID" defined in Web GUI-&gt;<b>PBX-&gt;Internal Options-&gt;General</b> will be used.</li> </ul>
<b>Need Registration</b>	Select whether the trunk needs to register on the external server or not when "Register SIP Trunk" type is selected. The default setting is No.
<b>Username</b>	Enter the username to register to the trunk from the provider when "Register SIP Trunk" type is selected.
<b>Password</b>	Enter the password to register to the trunk from the provider when "Register SIP Trunk" is selected.
<b>Auth ID</b>	Enter the Authentication ID for "Register SIP Trunk" type.
<b>Auto Record</b>	Enable automatic recording for the calls using this trunk (for SIP trunk only). The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .

**Table 50: SIP Register Trunk Configuration Parameters**

<b>Basic Settings</b>	
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.
<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Transport</b>	<p>Configure the SIP transport protocol to be used in this trunk. The default setting is "All - UDP Primary".</p> <ul style="list-style-type: none"> <li>• UDP Only</li> <li>• TCP Only</li> <li>• TLS Only</li> <li>• All - UDP Primary: UDP is the primary transport protocol when all the other SIP transport methods are available too.</li> <li>• All - TCP Primary: TCP is the primary transport protocol when all the other SIP transport methods are available too.</li> <li>• All – TLS Primary: TLS is the primary transport protocol when all the other SIP transport methods are available too.</li> </ul>
<b>Keep Original CID</b>	Keep the CID from the inbound call when dialing out. This setting will override "Keep Trunk CID" option. Please make sure that the peer PBX at the other side supports to match user entry using "username" field from authentication line.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".
<b>NAT</b>	Turn on this option when the PBX is using public IP and communicating

	with devices behind NAT. If there is one-way audio issue, usually it's related to NAT configuration or SIP/RTP port configuration on the firewall.
<b>Disable This Trunk</b>	<p>If selected, the trunk will be disabled.</p> <p><b>Note:</b> If a current SIP trunk is disabled, UCM will send UNREGISTER message (REGISTER message with expires=0) to the SIP provider.</p>
<b>TEL URI</b>	If the trunk has an assigned PSTN telephone number, this field should be set to "User=Phone". Then a "User=Phone" parameter will be attached to the Request-Line and TO header in the SIP request to indicate the E.164 number. If set to "Enable", "Tel:" will be used instead of "SIP:" in the SIP request. The default setting is disabled.
<b>Need Registration</b>	Select whether the trunk needs to register on the external server or not when "Register SIP Trunk" type is selected. The default setting is No.
<b>Username</b>	Enter the username to register to the trunk from the provider when "Register SIP Trunk" type is selected.
<b>Password</b>	Enter the password to register to the trunk from the provider when "Register SIP Trunk" is selected.
<b>Auth ID</b>	Enter the Authentication ID for "Register SIP Trunk" type.
<b>Auto Record</b>	Enable automatic recording for the calls using this trunk (for SIP trunk only). The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .
<b>Advanced Settings</b>	
<b>Codec Preference</b>	Select audio and video codec for the VoIP trunk. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.
<b>From Domain</b>	<p>Configure the actual domain name where the extension comes from. This can be used to override the From Header.</p> <p>For example, "trunk.UCM6200.provider.com" is the From Domain in From Header: sip:1234567@trunk.UCM6200.provider.com.</p>
<b>From User</b>	<p>Configure the actual user name of the extension. This can be used to override the From Header. There are cases where there is a single ID for registration (single trunk) with multiple DIDs.</p> <p>For example, "1234567" is the From User in From Header: sip:1234567@trunk.UCM6200.provider.com.</p>
<b>Send PPI Header</b>	<p>If enabled, the SIP INVITE message sent to the trunk will contain PPI (P-Preferred-Identity) header. The default setting is "No".</p> <p><b>Note:</b></p>

	<p>“Send PPI Header” and “Send PAI Header” cannot be enabled at the same time. Only one of the two headers is allowed to be contained in the SIP INVITE message.</p>
<b>Send PAI Header</b>	<p>If enabled, the SIP INVITE message sent to the trunk will contain PAI (P-Asserted-Identity) header. The default setting is “No”.</p> <p><b>Note:</b>          “Send PPI Header” and “Send PAI Header” cannot be enabled at the same time. Only one of the two headers is allowed to be contained in the SIP INVITE message.</p>
<b>Outbound Proxy Support</b>	<p>Select to enable outbound proxy in this trunk. The default setting is “No”.</p>
<b>Outbound Proxy</b>	<p>When outbound proxy support is enabled, enter the IP address or URL of the outbound proxy.</p>
<b>DID Mode</b>	<p>Configure where to get the destination ID of an incoming SIP call, from SIP Request-line or To-header. The default is set to “Request-line”.</p>
<b>DTMF Mode</b>	<p>Configure the default DTMF mode when sending DTMF on this trunk.</p> <ul style="list-style-type: none"> <li>• Default: The global setting of DTMF mode will be used. The global setting for DTMF Mode setting is under web UI-&gt;<b>PBX-&gt;SIP Settings-&gt;ToS</b>.</li> <li>• RFC2833: Send DTMF using RFC2833.</li> <li>• Info: Send DTMF using SIP INFO message.</li> <li>• Inband: Send DTMF using inband audio. This requires 64 bit codec, i.e., PCMU and PCMA.</li> <li>• Auto: Send DTMF using RFC2833 if offered. Otherwise, inband will be used.</li> </ul>
<b>Enable Qualify</b>	<p>If enabled, the UCM6200 will regularly send SIP OPTIONS to the device to check if the device is still online. The default setting is “No”.</p>
<b>Qualify Timeout</b>	<p>When “Enable Qualify” option is set to “Yes”, configure the timeout (in ms) for the Qualify SIP message. If no response is received within the timeout, the device is considered offline. The default setting is 1000ms.</p>
<b>Qualify Frequency</b>	<p>When “Enable Qualify” option is set to “Yes”, configure the interval (in seconds) of the SIP OPTIONS message sent to the device to check if the device is still online. The default setting is 60 seconds.</p>
<b>Maximum Number of Call Lines</b>	<p>The maximum number of concurrent calls using the trunk. The default settings 0, which means no limit.</p>
<b>Fax Mode</b>	<p>Select Fax mode. The default setting is “None”.</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address</li> </ul>

	configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI->PBX->Internal Options->Fax/T.38.
<b>SRTP</b>	Enable SRTP for the VoIP trunk. The default setting is "No".
<b>CC Settings</b>	
<b>Enable CC</b>	If enabled, the system will automatically alert the user when a called party is available, given that a previous call to that party failed for some reason.
<b>CC Max Agents</b>	Configure the maximum number of CCSS agents which may be allocated for this channel. In other words, this number serves as the maximum number of CC requests this channel is allowed to make. The minimum value is 1.
<b>CC Max Monitors</b>	Configure the maximum number of monitor structures which may be created for this device. In other words, this number tells how many callers may request CC services for a specific device at one time. The minimum value is 1.

**Table 51: SIP Peer Trunk Configuration Parameters**

<b>Basic Settings</b>	
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.
<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Transport</b>	<p>Configure the SIP transport protocol to be used in this trunk. The default setting is "All - UDP Primary".</p> <ul style="list-style-type: none"> <li>• UDP Only</li> <li>• TCP Only</li> <li>• TLS Only</li> <li>• All - UDP Primary: UDP is the primary transport protocol when all the other SIP transport methods are available too.</li> <li>• All - TCP Primary: TCP is the primary transport protocol when all the other SIP transport methods are available too.</li> <li>• All – TLS Primary: TLS is the primary transport protocol when all the other SIP transport methods are available too.</li> </ul>
<b>Keep Original CID</b>	Keep the CID from the inbound call when dialing out, this setting will override "Keep Trunk CID" option. Please make sure that the peer PBX at the other side supports to match user entry using "username" field from authentication line.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".

<b>NAT</b>	Turn on this option when the PBX is using public IP and communicating awith devices behind NAT. If there is one-way audio issue, usually it's related to NAT configuration or SIP/RTP port configuration on the firewall.
<b>Disable This Trunk</b>	If selected, the trunk will be disabled.  <b>Note:</b> If a current SIP trunk is disabled, UCM will send UNREGISTER message (REGISTER message with expires=0) to the SIP provider.
<b>TEL URI</b>	If the trunk has an assigned PSTN telephone number, this field should be set to "User=Phone". Then a "User=Phone" parameter will be attached to the Request-Line and TO header in the SIP request to indicate the E.164 number. If set to "Enable", "Tel:" will be used instead of "SIP:" in the SIP request. The default setting is disabled.
<b>Caller ID</b>	Configure the Caller ID. This is the number that the trunk will try to use when making outbound calls. For some providers, it might not be possible to set the CallerID with this option and this option will be ignored. When making outgoing calls, the following rules are used to determine which CallerID will be used if they exist: <ul style="list-style-type: none"> <li>• The CallerID configured for the extension will be looked up first.</li> <li>• If no CallerID configured for the extension, the CallerID configured for the trunk will be used.</li> <li>• If the above two are missing, the "Global Outbound CID" defined in Web GUI-&gt;<b>PBX-&gt;Internal Options-&gt;General</b> will be used.</li> </ul>
<b>CallerID Name</b>	Configure the name of the caller to be displayed when the extension has no CallerID Name configured.
<b>Auto Record</b>	Enable automatic recording for the calls using this trunk (for SIP trunk only). The default setting is disabled. The recording files can be accessed under web GUI-> <b>CDR-&gt;Recording Files</b> .
<b>Advanced Settings</b>	
<b>Codec Preference</b>	Select audio and video codec for the VoIP trunk. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.
<b>DID Mode</b>	Configure where to get the destination ID of an incoming SIP call, from SIP Request-line or To-header. The default is set to "Request-line".
<b>DTMF Mode</b>	Configure the default DTMF mode when sending DTMF on this trunk. <ul style="list-style-type: none"> <li>• Default: The global setting of DTMF mode will be used. The global setting for DTMF Mode setting is under web UI-&gt;<b>PBX-&gt;SIP Settings-&gt;ToS</b>.</li> <li>• RFC2833: Send DTMF using RFC2833.</li> </ul>



	<ul style="list-style-type: none"> <li>• Info: Send DTMF using SIP INFO message.</li> <li>• Inband: Send DTMF using inband audio. This requires 64 bit codec, i.e., PCMU and PCMA.</li> <li>• Auto: Send DTMF using RFC2833 if offered. Otherwise, inband will be used.</li> </ul>
<b>Enable Qualify</b>	If enabled, the UCM6200 will regularly send SIP OPTIONS to the device to check if the device is still online. The default setting is "No".
<b>Qualify Timeout</b>	When "Enable Qualify" option is set to "Yes", configure the timeout (in ms) for the Qualify SIP message. If no response is received within the timeout, the device is considered offline. The default setting is 1000ms.
<b>Qualify Frequency</b>	When "Enable Qualify" option is set to "Yes", configure the interval (in seconds) of the SIP OPTIONS message sent to the device to check if the device is still online. The default setting is 60 seconds.
<b>Maximum Number of Call Lines</b>	The maximum number of concurrent calls using the trunk. The default settings 0, which means no limite.
<b>Fax Mode</b>	<p>Select Fax mode. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;PBX-&gt;Internal Options-&gt;Fax/T.38.</li> </ul>
<b>SRTP</b>	Enable SRTP for the VoIP trunk. The default setting is "No".
<b>Sync LDAP Enable</b>	If enabled, the local UCM6200 will automatically provide and update the local LDAP contacts to the remote UCM6200 SIP peer trunk. In order to ensure successful synchronization, the remote UCM6200 peer also needs to enable this option on the SIP peer trunk. The default setting is "No".
<b>Sync LDAP Password</b>	This is the password used for LDAP contact file encryption and decryption during the LDAP sync process. The password must be the same on both UCM6200 peers o ensure successful synchronization.
<b>Sync LDAP Port</b>	Configure the TCP port used LDAP sync feature between two peer UCM6200.
<b>LDAP Outbound Rule</b>	Specify an outbound rule for LDAP sync feature. The UCM6200 will automatically modify the remote contacts by adding prefix parsed from this rule.
<b>LDAP Dialed Prefix</b>	Specify the prefix for LDAP sync feature. The UCM6200 will automatically modify the remote contacts by adding this prefix.

## CC Settings

<b>Enable CC</b>	If enabled, the system will automatically alert the user when a called party is available, given that a previous call to that party failed for some reason.
<b>CC Max Agents</b>	Configure the maximum number of CCSS agents which may be allocated for this channel. In other words, this number serves as the maximum number of CC requests this channel is allowed to make. The minimum value is 1.
<b>CC Max Monitors</b>	Configure the maximum number of monitor structures which may be created for this device. In other words, this number tells how many callers may request CC services for a specific device at one time. The minimum value is 1.

**Table 52: Create New IAX Trunk**

<b>Type</b>	Select the VoIP trunk type. <ul style="list-style-type: none"> <li>• Peer IAX Trunk</li> <li>• Register IAX Trunk</li> </ul>
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.
<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".
<b>Username</b>	Enter the username to register to the trunk from the provider when "Register IAX Trunk" type is selected.
<b>Password</b>	Enter the password to register to the trunk from the provider when "Register IAX Trunk" type is selected.
<b>Disable This Trunk</b>	If selected, the trunk will be disabled.

**Table 53: IAX Register Trunk Configuration Parameters**

<b>Basic Settings</b>	
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.
<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".
<b>Disable This Trunk</b>	If selected, the trunk will be disabled.
<b>Caller ID</b>	Configure the Caller ID. This is the number that the trunk will try to use when making outbound calls. For some providers, it might not be possible

	<p>to set the CallerID with this option and this option will be ignored.</p> <p>When making outgoing calls, the following rules are used to determine which CallerID will be used if they exist:</p> <ul style="list-style-type: none"> <li>• The CallerID configured for the extension will be looked up first.</li> <li>• If no CallerID configured for the extension, the CallerID configured for the trunk will be used.</li> <li>• If the above two are missing, the "Global Outbound CID" defined in Web GUI-&gt;<b>PBX-&gt;Internal Options-&gt;General</b> will be used.</li> </ul>
<b>CallerID Name</b>	Configure the name of the caller to be displayed when the extension has no CallerID Name configured.
<b>Username</b>	Enter the username to register to the trunk from the provider.
<b>Password</b>	Enter the password to register to the trunk from the provider.
<b>Advanced Settings</b>	
<b>Codec Preference</b>	Select audio and video codec for the VoIP trunk. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.
<b>Enable Qualify</b>	If enabled, the UCM6200 will regularly send SIP OPTIONS to the device to check if the device is still online. The default setting is "No".
<b>Qualify Timeout</b>	When "Enable Qualify" option is set to "Yes", configure the timeout (in ms) for the Qualify SIP message. If no response is received within the timeout, the device is considered offline. The default setting is 1000ms.
<b>Qualify Frequency</b>	When "Enable Qualify" option is set to "Yes", configure the interval (in seconds) of the SIP OPTIONS message sent to the device to check if the device is still online. The default setting is 60 seconds.
<b>Maximum Number of Call Lines</b>	The maximum number of concurrent calls using the trunk. The default settings 0, which means no limited.
<b>Fax Mode</b>	<p>Select Fax mode. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;<b>PBX-&gt;Internal Options-&gt;Fax/T.38</b>.</li> </ul>

**Table 54: IAX Peer Trunk Configuration Parameters**

<b>Basic Settings</b>	
<b>Provider Name</b>	Configure a unique label to identify this trunk when listed in outbound rules, inbound rules and etc.

<b>Host Name</b>	Configure the IP address or URL for the VoIP provider's server of the trunk.
<b>Keep Trunk CID</b>	If enabled, the trunk CID will not be overridden by extension's CID when the extension has CID configured. The default setting is "No".
<b>Disable This Trunk</b>	If selected, the trunk will be disabled.
<b>Caller ID</b>	<p>Configure the Caller ID. This is the number that the trunk will try to use when making outbound calls. For some providers, it might not be possible to set the CallerID with this option and this option will be ignored.</p> <p>When making outgoing calls, the following rules are used to determine which CallerID will be used if they exist:</p> <ul style="list-style-type: none"> <li>• The CallerID configured for the extension will be looked up first.</li> <li>• If no CallerID configured for the extension, the CallerID configured for the trunk will be used.</li> <li>• If the above two are missing, the "Global Outbound CID" defined in Web GUI-&gt;<b>PBX</b>-&gt;<b>Internal Options</b>-&gt;<b>General</b> will be used.</li> </ul>
<b>CallerID Name</b>	Configure the name of the caller to be displayed when the extension has no CallerID Name configured.
<b>Advanced Settings</b>	
<b>Codec Preference</b>	Select audio and video codec for the VoIP trunk. The available codecs are: PCMU, PCMA, GSM, AAL2-G.726-32, G.726, G.722, G.729, G.723, iLBC, ADPCM, H.264, H.263, H.263p and VP8.
<b>Enable Qualify</b>	If enabled, the UCM6200 will regularly send SIP OPTIONS to the device to check if the device is still online. The default setting is "No".
<b>Qualify Timeout</b>	When "Enable Qualify" option is set to "Yes", configure the timeout (in ms) for the Qualify SIP message. If no response is received within the timeout, the device is considered offline. The default setting is 1000ms.
<b>Qualify Frequency</b>	When "Enable Qualify" option is set to "Yes", configure the interval (in seconds) of the SIP OPTIONS message sent to the device to check if the device is still online. The default setting is 60 seconds.
<b>Maximum Number of Call Lines</b>	The maximum number of concurrent calls using the trunk. The default settings 0, which means no limited.
<b>Fax Mode</b>	<p>Select Fax mode. The default setting is "None".</p> <ul style="list-style-type: none"> <li>• None: Disable Fax.</li> <li>• Fax Detect: Fax signal from the user/trunk during the call can be detected and the received Fax will be sent to the Email address configured for this extension. If no Email address can be found for the user, the Fax will be sent to the default Email address configured in Fax setting page under web UI-&gt;<b>PBX</b>-&gt;<b>Internal Options</b>-&gt;<b>Fax/T.38</b>.</li> </ul>



## DIRECT OUTWARD DIALING (DOD)

The UCM6200 provides Direct Outward Dialing (DOD) which is a service of a local phone company (or local exchange carrier) that allows subscribers within a company's PBX system to connect to outside lines directly.

### Example of how DOD is used:

Company ABC has a SIP trunk. This SIP trunk has 4 DIDs associated to it. The main number of the office is routed to an auto attendant. The other three numbers are direct lines to specific users of the company. At the moment when a user makes an outbound call their caller ID shows up as the main office number. This poses a problem as the CEO would like their calls to come from their direct line. This can be accomplished by configuring DOD for the CEO's extension.

### Steps on how to configure DOD on the UCM6200:

1. To setup DOD go to UCM6200 web GUI->**PBX->Basic/Call Routes->VoIP Trunks** page.
2. Click  to access the DOD options for the selected SIP Trunk.
3. Click "Create a new DOD" to begin your DOD setup
4. For "DOD Number" enter one of the numbers (DIDs) from your SIP trunk provider. In the example above Company ABC received 4 DIDs from their provider. ABC will enter in the number for the CEO's direct line.
5. Select an extension from the "Available Extensions" list. Users have the option of selecting more than one extension. In this case, Company ABC would select the CEO's extension. After making the selection, click on the  button to move the extension(s) to the "Selected Extensions" list.

**Edit DOD**

Direct Outward Dialing (DOD) is a service of a local phone company (or local exchange carrier) that allows subscribers within a company's PBX system to connect to outside lines directly.

DOD Number:

Available Extensions

5001

5003

5000

➤

➤

➤

⌫

Selected Extensions

5004



Figure 97: DOD extension selection

6. Click "Save" at the bottom.  
 Once completed, the user will return to the EDIT DOD page that shows all the extensions that are associated to a particular DOD.

**Edit DOD**

Direct Outward Dialing (DOD) is a service of a local phone company (or local exchange carrier) that allows subscribers within a company's PBX system to connect to outside lines directly.

Create a new DOD
Edit DOD

DOD	Extensions	Options
6176518241	5002	
4451234567	5005	

Total: **2** Show: **1/1** Go to:  Go

First
Prev
Next
Last

**Figure 98: Edit DOD**



## SLA STATION

The UCM6200 supports SLA that allows mapping the key with LED on a multi-line phone to different external lines. When there is an incoming call and the phone starts to ring, the LED on the key will flash in red and the call can be picked up by pressing this key. This allows users to know if the line is occupied or not. The SLA function on the UCM6200 is similar to BLF but SLA is used to monitor external line i.e., analog trunk on the UCM6200. Users could configure the phone with BLF mode on the MPK to monitor the analog trunk status or press the line key pick up call from the analog trunk on the UCM6200.

### CREATE/EDIT SLA STATION

SLA Station can be configured on web GUI->**PBX->Basic/Call Routes->SLA Station**.



Figure 99: SLA Station






- Click on “Create New SLA Station” to add a SLA Station.
- Click on  to edit the SLA Station. The following table shows the SLA Station configuration parameters.
- Click on  to delete the SLA Station.

Table 55: SLA Station Configuration Parameters

<b>Station Name</b>	Configure a name to identify the SLA Station.
<b>Station</b>	Specify a SIP extension as a station that will be using SLA.
<b>Available SLA Trunks</b>	Existing Analog Trunks with SLA Mode enabled will be listed here.
<b>Selected SLA Trunks</b>	Select a trunk for this SLA from the Available SLA Trunks list. Click on    to arrange the order. If there are multiple trunks selected, when there are calls on those trunks at the same time, pressing the LINE key on the phone will pick up the call on the first trunk here.


#### SLA Station Options



<b>Ring Timeout</b>	Configure the time (in seconds) to ring the station before the call is considered unanswered. No timeout is set by default. If set to 0, there will be no timeout.
<b>Ring Delay</b>	Configure the time (in seconds) for delay before ringing the station when a call first coming in on the shared line. No delay is set by default. If set to 0, there will be no delay.
<b>Hold Access</b>	This option defines the competence of the hold action for one particular trunk. If set to "open", any station could hold a call on that trunk or resume one held session; if set to "private", only the station that places the trunk call on hold could resume the session. The default setting is "open".

## SAMPLE CONFIGURATION

1. On the UCM6200, go to web UI->**Basic/Call Routes->Analog Trunks** page. Create analog trunk or edit the existing analog trunk. Make sure "SLA Mode" is enabled for the analog trunk. Once enabled, this analog trunk will be only available for the SLA stations created under web UI->**Basic/Call Routes->SLA Station** page.



**Edit Analog Trunk: pstn1**

Channels:  1  2  3  4

Trunk Name\*:

**SLA Mode:**

Barge Allowed:

Hold Access:

**Advanced Options**

Enable Polarity Reversal:

Current Disconnect Threshold(ms):   Ring Timeout\*:

RX Gain\*:  TX Gain\*:

Use CallerID:

Fax Mode:

Caller ID Scheme:



FXO Dial Delay(ms)\*:  Auto Record:

Disable This Trunk:  DAHDI Out Line Selection:

The maximum number of call lines\*:

**Figure 100: Enable SLA Mode for Analog Trunk**

Click on “Save”. The analog trunk will be listed with trunk mode “SLA”.

Trunks	Trunk Mode	Analog Ports	Options
fxo1	SLA	1	 

**Figure 101: Analog Trunk with SLA Mode Enabled**

- On the UCM6200, go to web UI->**Basic/Call Routes->SLA Station** page, click on “Create New SLA Station”. Please refer to section **[CREATE/EDIT SLA STATION]** for the configuration parameters. Users can create one or more SLA stations to monitor the analog trunk. The following figure shows two stations, 1002 and 1005, are configured to be associated with SLA trunk “fxo1”.

Station Name	Station	Associated SLA Trunks	Options
ata2	1002	fxo1	 
teststa	1005	fxo1	 

**Figure 102: SLA Example - SLA Station**

- On the SIP phone 1, configure to register UCM6200 extension 1002. Configure the MPK as BLF mode

and the value must be set to “extension\_trunkname”, which is 1002\_fxo1 in this case.

4. On the SIP phone 2, configure to register UCM6200 extension 1005. Configure the MPK as BLF mode and value must be set to “extension\_trunkname”, which is 1005\_fxo1 in this case.

Mode	Account	Description	Value
MPK 1	Busy Lamp Field (BLF)	Account 2	1005_fxo1

**Figure 103: SLA Example - MPK Configuration**

Now the SLA station is ready to use. The following functions can be achieved by this configuration.







- Making an outbound call from the station/extension, using LINE key  
 When the extension is in idle state, pressing the line key for this extension on the phone to off hook. Then dial the station’s extension number, for example, dial 1002 on phone 1 (or dial 1005 on phone 2), to hear the dial tone. Then the users could dial external number for the outbound call.
- Making an outbound call from the station/extension, using BLF key  
 When the extension is in idle state, pressing the MPK and users could dial external numbers directly.
- Answering call using LINE key  
 When the station is ringing, pressing the LINE key to answer the incoming call.
- Barging-in active call using BLF key  
 When there is an active call between an SLA station and an external number using the SLA trunk, other SLA stations monitoring the same trunk could join the call by pressing the BLF key if “Barge Allowed” is enabled for the analog trunk.
- Hold/Unhold using BLF key  
 If the external line is previously put on hold by an SLA station, another station that monitors the same SLA trunk could unhold the call by pressing the BLF key if “Hold Access” is set to “open” on the analog trunk and the SLA station.

## CALL ROUTES

### OUTBOUND ROUTES

In the UCM6200, an outgoing calling rule pairs an extension pattern with a trunk used to dial the pattern. This allows different patterns to be dialed through different trunks (e.g., "Local" 7-digit dials through a FXO while "Long distance" 10-digit dials through a low-cost SIP trunk). Users can also set up a failover trunk to be used when the primary trunk fails.

Go to Web GUI->**PBX->Basic/Call Routes->Outbound Routes** to add and edit outbound rules.

- Click on "Create New Outbound Rule" to add a new outbound route.
- Click on  to edit the outbound route.
- Click on  to delete the outbound route.
- On the UCM6200, the outbound route priority is based on "Best matching pattern". For example, the UCM6200 has outbound route A with pattern 1xxx and outbound route B with pattern 10xx configured. When dialing 1000 for outbound call, outbound route B will always be used first. This is because pattern 10xx is a better match than pattern 1xxx. Only when there are multiple outbound routes with the same pattern configured, users can click on     to move the outbound route up/down to arrange the priority among those outbound routes.

**Table 56: Outbound Route Configuration Parameters**


<b>Calling Rule Name</b>	Configure the name of the calling rule (e.g., local, long_distance, and etc). Letters, digits, _ and - are allowed.
<b>Pattern</b>	<ul style="list-style-type: none"> <li>• All patterns are prefixed with the "_".</li> <li>• Special characters:  X: Any Digit from 0-9.  Z: Any Digit from 1-9.  N: Any Digit from 2-9.  ".": Wildcard. Match one or more characters.  "!": Wildcard. Match zero or more characters immediately.  Example: [12345-9] - Any digit from 1 to 9.</li> </ul>
<b>Password</b>	Configure the password for users to use this rule when making outbound calls.
<b>Call Duration Limit</b>	Enable to configure the maximum duration for the call using this outbound route.

<b>Maximum Call Duration</b>	Configure the maximum duration of the call (in seconds). The default setting is 0, which means no limit.
<b>Warning Time</b>	Configure the warning time for the call using this outbound route. If set to x seconds, the warning tone will be played to the caller when x seconds are left to end the call.
<b>Warning Repeat Interval</b>	Configure the warning repeat interval for the call using this outbound route. If set to x seconds, the warning tone will be played every x seconds after the first warning.
<b>Privilege Level</b>	<p>Select privilege level for the outbound rule.</p> <ul style="list-style-type: none"> <li>• Internal: The lowest level required. All users can use this rule.</li> <li>• Local: Users with Local, National, or International level are allowed to use this rule.</li> <li>• National: Users with National or International level are allowed to use this rule.</li> <li>• International: The highest level required. Only users with international level can use this rule.</li> <li>• Disable: The default setting is "Disable". If selected, only the matched source caller ID will be allowed to use this outbound route.</li> </ul> <p>Please be aware of the potential security risks when using "Internal" level, which means all users can use this outbound rule to dial out from the trunk.</p>
<b>Enable Filter on Source Caller ID</b>	<p>When enabled, users could specify extensions allowed to use this outbound route. "Privilege Level" is automatically disabled if using "Enable Filter on Source Caller ID".</p> <p>The following two methods can be used at the same time to define the extensions as the source caller ID.</p> <ol style="list-style-type: none"> <li>1. Select available extensions/extension groups from the left to the right. This allows users to specify arbitrary single extensions available in the PBX.</li> <li>2. Custom Dynamic Route: define the pattern for the source caller ID. This allows users to define extension range instead of selecting them one by one. <ul style="list-style-type: none"> <li>• All patterns are prefixed with the "_".</li> <li>• Special characters:  X: Any Digit from 0-9.  Z: Any Digit from 1-9.  N: Any Digit from 2-9.  ".": Wildcard. Match one or more characters.  "!": Wildcard. Match zero or more characters immediately.</li> </ul> </li> </ol>

	Example: [12345-9] - Any digit from 1 to 9.
<b>Send This Call Through Trunk</b>	
<b>Use Trunk</b>	Select the trunk for this outbound rule.
<b>Strip</b>	<p>Allows the user to specify the number of digits that will be stripped from the beginning of the dialed string before the call is placed via the selected trunk.</p> <p>Example:</p> <p>The users will dial 9 as the first digit of a long distance calls. However, 9 should not be sent out via analog lines and the PSTN line. In this case, 1 digit should be stripped before the call is placed.</p>
<b>Prepend</b>	<p>Specify the digits to be prepended before the call is placed via the trunk. Those digits will be prepended after the dialing number is stripped.</p>
<b>Use Failover Trunk</b>	
<b>Failover Trunk</b>	<p>Failover trunks can be used to make sure that a call goes through an alternate route, when the primary trunk is busy or down. If "Use Failover Trunk" is enabled and "Failover trunk" is defined, the calls that cannot be placed via the regular trunk may have a secondary trunk to go through.</p> <p>Example:</p> <p>The user's primary trunk is a VoIP trunk and the user would like to use the PSTN when the VoIP trunk is not available. The PSTN trunk can be configured as the failover trunk of the VoIP trunk.</p>
<b>Strip</b>	<p>Allows the user to specify the number of digits that will be stripped from the beginning of the dialed string before the call is placed via the selected trunk.</p> <p>Example:</p> <p>The users will dial 9 as the first digit of a long distance calls. However, 9 should not be sent out via analog lines and the PSTN line. In this case, 1 digit should be stripped before the call is placed.</p>
<b>Prepend</b>	<p>Specify the digits to be prepended before the call is placed via the trunk. Those digits will be prepended after the dialing number is stripped.</p>

## INBOUND ROUTES

Inbound routes can be configured via Web GUI->**PBX->Basic/Call Routes->Inbound Routes**.

- Click on "Create New Inbound Rule" to add a new inbound route.
- Click on "Blacklist" to configure blacklist for all inbound routes.
- Click on  to edit the inbound route.

- Click on  to delete the inbound route.

## INBOUND RULE CONFIGURATIONS

**Table 57: Inbound Rule Configuration Parameters**

<b>Trunks</b>	Select the trunk to configure the inbound rule.
<b>DID Pattern</b>	<ul style="list-style-type: none"> <li>• All patterns are prefixed with the "_".</li> <li>• Special characters:            X: Any Digit from 0-9.            Z: Any Digit from 1-9.            N: Any Digit from 2-9.            ".": Wildcard. Match one or more characters.            "!": Wildcard. Match zero or more characters immediately.            Example: [12345-9] - Any digit from 1 to 9.</li> <li>• The pattern can be composed of two parts, divided by a '/' character. The first part is used to specify the dialed number the second part is used to specify the caller ID and it is optional, if set it means only the extension with the specific caller ID is allowed to call in or call out. For example, patter '_2XXX/1234' means the only extension with the caller ID '1234' is allowed to use this rule.</li> </ul>
<b>Prepend Trunk Name</b>	Prepend trunk name to display
<b>Alert-Info</b>	Configure the Alert-Info, when UCM6200 receives an INVITE request, the Alert-Info header field specifies an alternative ring tone to the UAS.
<b>Inbound Multiple Mode</b>	Multiple mode allows user to switch between destinations of the inbound rule by feature codes. Configure related feature codes in the " <b>Feature Codes</b> " page. If this option is enabled, user can use feature code to switch between different destinations.
<b>Default Destination</b>	<p>Select the default destination for the inbound call.</p> <ul style="list-style-type: none"> <li>• Extension</li> <li>• Voicemail</li> <li>• Conference Room</li> <li>• Queue</li> <li>• Ring Group</li> <li>• Paging/Intercom</li> <li>• Voicemail Group</li> <li>• Fax</li> <li>• DISA</li> <li>• IVR</li> <li>• Dial By Name</li> </ul>

	<ul style="list-style-type: none"> <li>• External Number</li> <li>• By DID</li> </ul> <p>When "By DID" is used, the UCM6200 will look for the destination based on the number dialed, which could be local extensions, conference, call queue, ring group, paging/intercom group, IVR, voicemail groups and Fax extension as configured in "DID destination". If the dialed number matches the DID pattern, the call will be allowed to go through.</p>
<b>Strip</b>	Configure the number of digits to be stripped from the beginning of the DID. This option shows up only when "By DID" is selected.
<b>Prepend</b>	Configure the number of digits to be prepended to an inbound DID pattern, with strip taking precedence over prepend.
<b>Dial Trunk</b>	This option shows up only when "By DID" is selected. If enabled, the external users dialing in to the trunk via this inbound route can dial outbound call using the UCM6200's trunk.
<b>DID Destination</b>	<p>This option shows up only when "By DID" is selected. This controls the destination that can be reached by the external caller via the inbound route. The DID destination are:</p> <ul style="list-style-type: none"> <li>• Extension</li> <li>• Conference</li> <li>• Call Queue</li> <li>• Ring Group</li> <li>• Paging/Intercom Groups</li> <li>• IVR</li> <li>• Voicemail Groups</li> <li>• Fax Extension</li> <li>• Dial By Name</li> <li>• All</li> </ul>
<b>Time Condition</b>	
<b>Time Conditions</b>	Select the time condition for the inbound rule.
<b>Destination</b>	Select the destination for the inbound call during the specified time condition.

### **INBOUND ROUTE: PREPEND EXAMPLE**

UCM6200 now allows user to prepend digits to an inbound DID pattern, with strip taking precedence over prepend. With the ability to prepend digits in inbound route DID pattern, user no longer needs to create multiple routes for the same trunk in order to route calls to different extensions.



**Edit Inbound Rule**

**DID Pattern \***  /

**Prepend Trunk Name:**

**Alert-Info:**

**Inbound Multiple Mode:**

**Dial Trunk:**

**DID Destination:**  Extension  Conference  Call Queue  Ring Group  
 Paging/Intercom Groups  IVR  Voicemail Groups  
 Fax Extension  Dial By Name  All

**Default Mode** | **Mode 1**

---

**Default Destination \***

**Strip:**

**Prepend:**


**Figure 104: Inbound Route feature: Prepend**

The following example demonstrates the process,

1. If Trunk provides a DID pattern of 18005251163.
2. If **Strip** is set to 8, UCM6200 will strip the first 8 digits.
3. If **Prepend** is set to 2, UCM6200 will then prepend a 2 to the stripped number, now the number become 2163.
4. UCM6200 will now forward the incoming call to extension 2163.

### **INBOUND ROUTE: MULTIPLE MODE**

In the UCM6200, the user can configure inbound route to enable multiple mode to switch between different destinations. The inbound multiple mode can be enabled under Inbound Route settings.



**Edit Inbound Rule**

Prepend Trunk Name:

Alert-Info:

Inbound Multiple Mode:

Default Mode: Mode 1

Default Destination:

Time Condition	Time	Destination	Options
Click to add Time Condition			

**Figure 105: Inbound Route - Multiple Mode**

When Multiple Mode is enabled for the inbound route, the user can configure a “Default Destination” and a “Mode 1” destination for this route. By default, the call coming into this inbound route will be routed to the default destination.

SIP end devices that have registered on the UCM6200 can dial feature code \*62 to switch to inbound route “Mode 1” and dial feature code \*61 to switch back to “Default Destination”. Switching between different mode can be easily done without web UI login.

For example, the customer service hotline destination has to be set to a different IVR after 7PM. The user can dial \*62 to switch to “Mode 1” with that IVR set as the destination before off work.

## FAX INTELLIGENT ROUTE



The UCM6200 can automatically detect Fax and phone signal coming from the FXO port, and then forward Fax or phone signal to the right destination. For example, when a regular phone call is coming, the UCM6200 will be able to detect the phone signal and forward it through the correct inbound route to the destination; if Fax signal is coming, the UCM6200 will be able to forward it to the FXS extension where the Fax machine is connected.


## FAX WITH TWO MEDIA

The UCM6200 supports Fax re-invite with multiple codec negotiation. If a Fax re-invite contains both T.38 and PCMA/PCMU codec, UCM6200 will choose T.38 codec over PCMA/PCMU.


## BLACKLIST CONFIGURATIONS


In the UCM6200, Blacklist is supported for all inbound routes. Users could enable the Blacklist feature and manage the Blacklist by clicking on "Blacklist".

- Select the checkbox for "Blacklist Enable" to turn on Blacklist feature for all inbound routes. Blacklist is disabled by default.
- Enter a number in "Add Blacklist Number" field and then click  to add to the list.
- To remove a number from the Blacklist, select the number in "Blacklist list" and click on .



**Figure 106: Blacklist Configuration Parameters**

- To add blacklist number in batch, click on  to upload blacklist file in csv format. The supported csv format is as below.



	A	B	C	D	E
1	13238680006	12135958547	12136268547	6262357999	
2					
3					
4					
5					

**Figure 107: Blacklist csv File**



**Note:**

Users could also add a number to the Blacklist or remove a number from the Blacklist by dialing the feature code for "Blacklist Add" (default: \*40) and "Blacklist Remove" (default: \*41) from an extension. The feature code can be configured under Web GUI->**PBX->Internal Options->Feature Codes**.

---





## CONFERENCE BRIDGE

The UCM6200 supports conference bridge allowing multiple bridges used at the same time:

- UCM6202/6204 supports up to 3 conference bridges allowing up to 25 simultaneous PSTN or IP participants.
- UCM6208 supports up to 6 conference bridges allowing up to 32 simultaneous PSTN or IP participants.

The conference bridge configurations can be accessed under Web GUI->**PBX->Call Features->Conference**. In this page, users could create, edit, view, invite, manage the participants and delete conference bridges. The conference bridge status and conference call recordings (if recording is enabled) will be displayed in this web page as well.

### CONFERENCE BRIDGE CONFIGURATIONS

- Click on "Create New Conference Room" to add a new conference bridge.
- Click on  to edit the conference bridge.
- Click on  to delete the conference bridge.

**Table 58: Conference Bridge Configuration Parameters**

<b>Extension</b>	Configure the conference number for the users to dial into the conference.
<b>Password</b>	<p>When configured, the users who would like to join the conference call must enter this password before accessing the conference bridge.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• If "Public Mode" is enabled, the password is not required to join the conference bridge thus this field is invalid.</li> <li>• The password has to be at least 4 characters.</li> </ul>
<b>Admin Password</b>	Configure the password to join the conference bridge as administrator. Conference administrator can manage the conference call via IVR (if "Enable Caller Menu" is enabled) as well as invite other parties to join the conference by dialing "0" (permission required from the invited party) or "1" (permission not required from the invited party) during the conference call.

	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• If "Public Mode" is enabled, the password is not required to join the conference bridge thus this field is invalid.</li> <li>• The password has to be at least 4 characters.</li> </ul>
<b>Enable Caller Menu</b>	If enabled, conference participant could press the * key to access the conference bridge menu. The default setting is "No".
<b>Record Conference</b>	If enabled, the calls in this conference bridge will be recorded automatically in a .wav format file. All the recording files will be displayed and can be downloaded in the conference web page. The default setting is "No".
<b>Quiet Mode</b>	<p>If enabled, if there are users joining or leaving the conference, voice prompt or notification tone won't be played. The default setting is "No".</p> <p><b>Note:</b> "Quiet Mode" and "Announce Callers" cannot be enabled at the same time.</p>
<b>Wait For Admin</b>	<p>If enabled, the participants will not hear each other until the conference administrator joins the conference. The default setting is "No".</p> <p><b>Note:</b> If "Quiet Mode" is enabled, the voice prompt for "Wait For Admin" will not be announced.</p>
<b>Enable User Invite</b>	<p>If enabled, users could press 0 to invite other users (with the users' permission) or press 1 to invite other users (without the user's permission) to join the conference. The default setting is "No".</p> <p><b>Note:</b> Conference administrator can always invite other users without enabling this option.</p>
<b>Announce Callers</b>	<p>If enabled, the caller will be announced to all conference participants when there the caller joins the conference. The default setting is "No".</p> <p><b>Note:</b> "Quiet Mode" and "Announce Callers" cannot be enabled at the same time.</p>
<b>Public Mode</b>	If enabled, no authentication will be required when joining the conference call. The default setting is "Yes".
<b>Play Hold Music</b>	If enabled, the UCM6200 will play Hold music when there is only one user in the conference. The default setting is "No".

<b>Music On Hold</b>	Select the music on hold class to be played in conference call. Music On Hold class can be set up under web UI-> <b>PBX-&gt;Internal Options-&gt;Music On Hold</b> .
<b>Skip Authentication When Inviting User via Trunk from Web GUI</b>	If enabled, the invitation from Web GUI for a conference bridge with password will skip the authentication for the invited users. The default setting is "No".


## JOIN A CONFERENCE CALL

Users could dial the conference bridge extension to join the conference. If password is required, enter the password to join the conference as a normal user, or enter the admin password to join the conference as administrator.

## INVITE OTHER PARTIES TO JOIN CONFERENCE

When using the UCM6200 conference bridge, there are two ways to invite other parties to join the conference.

- Invite from Web GUI.

For each conference bridge in UCM6200 Web GUI->**PBX->Call Features->Conference**, there is an icon  for option "Invite a participant". Click on it and enter the number of the party you would like to invite. Then click on "Add". A call will be sent to this number to join it into the conference.




Figure 108: Conference Invitation From Web GUI

- Invite by dialing 0 or 1 during conference call.



A conference participant can invite other parties to the conference by dialing from the phone during the conference call. Please make sure option "Enable User Invite" is turned on for the conference bridge first. Enter 0 or 1 during the conference call. Follow the voice prompt to input the number of the party you would like to invite. A call will be sent to this number to join it into the conference.

**0:** If 0 is entered to invite other party, once the invited party picks up the invitation call, a permission will be asked to "accept" or "reject" the invitation before joining the conference.

**1:** If 1 is entered to invite other party, no permission will be required from the invited party.



**Note:**

Conference administrator can always invite other parties from the phone during the call by entering 0 or 1. To join a conference bridge as administrator, enter the admin password when joining the conference. A conference bridge can have multiple administrators.





---

## **DURING THE CONFERENCE**

During the conference call, users can manage the conference from web GUI or IVR.

- Manage the conference call from Web GUI.

Log in UCM6200 web GUI during the conference call, the participants in each conference bridge will be listed.

1. Click on  to kick a participant from the conference.
2. Click on  to mute the participant.
3. Click on  to lock this conference bridge so that other users cannot join it anymore.
4. Click on  to invite other users into the conference bridge.

- Manage the conference call from IVR.

If "Enable Caller Menu" is enabled, conference participant can input \* to enter the IVR menu for the conference. Please see options listed in the table below.

**Table 59: Conference Caller IVR Menu**

Conference Administrator IVR Menu	
1	Mute/unmute yourself.
2	Lock/unlock the conference bridge.
3	Kick the last joined user from the conference.
4	Decrease the volume of the conference call.
5	Decrease your volume.
6	Increase the volume of the conference call.
7	Increase your volume.
8	More options. <ul style="list-style-type: none"> <li>• 1: List all users currently in the conference call.</li> <li>• 2: Kick all non-Administrator participants from the conference call.</li> <li>• 3: Mute/Unmute all non-Administrator participants from the conference call.</li> <li>• 4: Record the conference call.</li> <li>• 8: Exit the caller menu and return to the conference.</li> </ul>
Conference User IVR Menu	
1	Mute/unmute yourself.
4	Decrease the volume of the conference call.
5	Decrease your volume.
6	Increase the volume of the conference call.
7	Increase your volume.
8	Exit the caller menu and return to the conference.


**Note:**



When there is participant in the conference, the conference bridge configuration cannot be modified.

---

**RECORD CONFERENCE**

The UCM6200 allows users to record the conference call and retrieve the recording from web GUI->**PBX->Call Features->Conference**.

To record the conference call, when the conference bridge is in idle, enable "Record Conference" from the conference bridge configuration dialog. Save the setting and apply the change. When the conference call starts, the call will be automatically recorded in .wav format.

The recording files will be listed as below once available. Users could click on  to download the recording or click on  to delete the recording. Users could also delete all recording files by clicking on "Delete All Recording Files", or delete multiple recording files at once by clicking on "Delete Selected Recording Files" after selecting the recording files.



Conference Recordings					
Delete Selected Recording Files		Delete All Recording Files		View: 10	
Name	Hours	Date	Size	Options	
meadme-conf-rec-6300-1407280814.30-0.wav	0:00	2014-08-05 19:20:36 UTC-04:00	341.39 KB		
meadme-conf-rec-6300-1407280506.27-0.wav	0:00	2014-08-05 18:15:22 UTC-04:00	386.92 KB		

Total: 2 Show 1/1 Go to

**Figure 109: Conference Recording**

## CONFERENCE SCHEDULE

### CONFERENCE SCHEUDLE CONFIGURATION

Conference Schedule can be found under UCM6200 web **UI->PBX->Call Features->Conference Schedule**. Users can create, edit, view and delete a Conference Schedule.

- Click on “Create New Conference Schedule” to add a new Conference Schedule.
- Click on the scheduled conference to edit or delete the event.

After the user configures UCM6200 with Google Service Settings **[GOOGLE SERVICE SETTINGS SUPPORT]** and enables Google Calendar for Conference Schedule, the conference schedule on the UCM6200 can be synchronized with Google Calendar for authorized Google account.

**Table 60: Conference Schedule Parameters**

Schedule Options	
<b>Conference Topic</b>	Configure the name of the scheduled conference. Letters, digits, _ and - are allowed.
<b>Conference Room</b>	Select a conference room for this scheduled conference.
<b>Kick Time(m)</b>	Set kick time before conference starts. When kick time is reached, a warning prompt will be played for all attendees in the conference room. After 5 minutes, this conference room will be cleared and locked for the scheduled conference to begin.  <b>Note:</b> Kick Time cannot be less than 6 minutes in order to clear the conference room.
<b>Description</b>	The description of scheduled conference.
<b>Repeat</b>	Repeat interval of scheduled conference. By default it's set to single event.
<b>Schedule Time</b>	Configure the beginning date and duration of scheduled conference.  <b>Note:</b> Please pay attention to avoid time conflict on schedules in the same conference room.
<b>Enable Google Calendar</b>	Select this option to sync scheduled conference with Google Calendar.  <b>Note:</b> Google Service Setting OAuth2.0 must be configured on the UCM6200. Please refer to section <b>[GOOGLE SERVICE SETTINGS SUPPORT]</b> .

<b>Conference Administrator</b>	Select the administrator of scheduled conference from selected extensions.  <b>Note:</b> “Public Mode” must be disabled from Conference Room Options tab.
<b>Local Extension</b>	Select available extensions from the list to attend scheduled conference.
<b>Remote Extension</b>	Select available extensions from the remote peer PBX.  <b>Note:</b> “LDAP Sync” must be enabled on the UCM6200 in order to view remote extensions here.
<b>Special Extension</b>	Add extensions that are not in the list (both local and remote list). If the user wishes to add the special extension, please match the pattern on the outbound route.
<b>Remote Conference</b>	Invite a remote conference.
<b>Conference Room Options</b>	
<b>Password</b>	Configure conference room password. Please note that if “Public Mode” is enabled, this option is automatically disabled.
<b>Admin Password</b>	Configure the password to join as conference administrator. Please note that if “Public Mode” is enabled, this option is automatically disabled.
<b>Enable Caller Menu</b>	If this option is enabled, conference participants will be able to access conference bridge menu by pressing the * key.
<b>Record Conference</b>	If this option is enabled, conference call will be recorded in .wav format. The recorded file can be found from <b>Conference</b> page.
<b>Quiet Mode</b>	If this option is enabled, the notification tone or voice prompt for joining or leaving the conference won't be played.  <b>Note:</b> Option “Quiet Mode” and option “Announce Caller” cannot be enabled at the same time.
<b>Wait For Admin</b>	If this option is enabled, the participants in the conference won't be able to hear each other until conference administrator joins the conference.  <b>Note:</b> If “Quiet Mode” is enabled, voice prompt for this option won't be played.
<b>Enable User Invite</b>	If this option is enabled, the user can: <ul style="list-style-type: none"> <li>• Press '0' to invite others to join the conference with invited party's permission</li> <li>• Press '1' to invite without invited party's permission</li> <li>• Press '2' to create a multi-conference bridge to another conference room</li> </ul>


	<ul style="list-style-type: none"> <li>Press '3' to drop all current multi-conference bridges</li> </ul> <p><b>Note:</b> Conference Administrator is always allowed to access this menu.</p>
<b>Announce Callers</b>	<p>If this option is enabled, when a participant joins the conference room, participant's name will be announced to all members in the conference room.</p> <p><b>Note:</b> Option "Quiet Mode" and option "Announce Caller" cannot be enabled at the same time.</p>
<b>Public Mode</b>	<p>If this option is enabled, no authentication is required for entering the conference room.</p> <p><b>Note:</b> Please be aware of the potential security risks when turning on this option.</p>
<b>Play Hold Music</b>	<p>If this option is enabled, UCM6200 will play Hold Music while there is only one participant in the conference room or the conference is not yet started.</p>
<b>Skip Authentication When Inviting Users via Trunk from Web GUI</b>	<p>If this option is enabled, the invitation from Web GUI via a trunk with password won't require authentication.</p> <p><b>Note:</b> Please be aware of the potential security risks when turning on this option.</p>

- Cleaner Options

Cleaner Options	
<b>Enable Conference Schedules Cleaner</b>	If this option is enabled, conference schedules will be automatically cleaned as configured.
<b>Conference Schedules Clean Time</b>	Enter the clean time (in hours). The valid range is from 0 to 23.
<b>Clean Interval</b>	Enter the clean interval (in days). The valid range is from 1 to 30.

- Show/hide Conference Schedule Table

Enable this option will allow web UI to display scheduled conference in Conference Schedule Table. Please see figure below.



**Figure 110: Conference Schedule**

Once the conference room is scheduled, at the kick time, all users will be removed from conference room and no extension is allowed to join the conference room anymore. At the scheduled conference time, UCM6200 will send INVITE to the extensions that have been selected for conference.

---



 **Note:**

- Please make sure that outbound route is properly configured for remote extensions to join the conference.
  - Once Kick Time is reached, Conference Schedule is locked and cannot be modified.
-

## IVR

### CONFIGURE IVR

IVR configurations can be accessed under the UCM6200 Web GUI->**PBX->Call Features->IVR**. Users could create, edit, view and delete an IVR.

- Click on "Create New IVR" to add a new IVR.
- Click on  to edit the IVR configuration.
- Click on  to delete the IVR.

**Table 61: IVR Configuration Parameters**

Basic Settings	
<b>Name</b>	Configure the name of the IVR. Letters, digits, _ and - are allowed.
<b>Extension</b>	Enter the extension number for users to access the IVR.
<b>DID Destination</b>	<p>This option shows up only when "By DID" is selected. This controls the destination that can be reached by the external caller via the inbound route. The DID destination are:</p> <ul style="list-style-type: none"> <li>• Extension</li> <li>• Conference</li> <li>• Call Queue</li> <li>• Ring Group</li> <li>• Paging/Intercom Groups</li> <li>• Voicemail Groups</li> <li>• Fax Extension</li> <li>• Dial By Name</li> <li>• All</li> </ul>
<b>Dial Trunk</b>	If enabled, all callers to the IVR is allowed to use trunk. The permission must be configured for the users to use the trunk first. The default setting is "No".
<b>Permission</b>	Assign permission level for outbound calls if "Dial Trunk" is enabled. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal". If the user tries to dial outbound calls after dialing into the IVR, the UCM6200 will compared the IVR's permission level with the outbound route's privilege level. If the IVR's permission level is higher than (or equal to) the outbound route's privilege level, the call will be




	allowed to go through.
<b>Welcome Prompt</b>	Select an audio file to play as the welcome prompt for the IVR. Click on "Prompt" to add additional audio file under web GUI-> <b>Internal Options-&gt;IVR Prompt</b> .
<b>Digit Timeout</b>	Configure the timeout between digit entries. After the user enters a digit, the user needs to enter the next digit within the timeout. If no digit is detected within the timeout, the UCM6200 will consider the entries complete. The default timeout is 3 seconds.
<b>Response Timeout</b>	After playing the prompts in the IVR, the UCM6200 will wait for the DTMF entry within the timeout (in seconds). If no DTMF entry is detected within the timeout, a timeout prompt will be played. The default setting is 10 seconds.
<b>Response Timeout Prompt</b>	Select the prompt message to be played when timeout occurs.
<b>Invalid Prompt</b>	Select the prompt message to be played when an invalid extension is pressed.
<b>Response Timeout Repeat Loops</b>	Configure the number of times to repeat the prompt if no DTMF input is detected. When the loop ends, it will go to the timeout destination if configured, or hang up. The default setting is 3.
<b>Invalid Repeat Loops</b>	Configure the number of times to repeat the prompt if the DTMF input is invalid. When the loop ends, it will go to the invalid destination if configured, or hang up. The default setting is 3.
<b>Language</b>	Select the voice prompt language to be used for this IVR. The default setting is "Default" which is the selected voice prompt language under web GUI-> <b>PBX-&gt;Internal Options-&gt;Language</b> . The dropdown list shows all the current available voice prompt languages on the UCM6200. To add more languages in the list, please download voice prompt package by selecting "Check Prompt List" under web GUI-> <b>PBX-&gt;Internal Options-&gt;Language</b> .
<b>Key Pressing Events</b>	
<b>Key Press Event:</b>	Select the event for each key pressing for 0-9, *, Timeout and Invalid. The event options are:
<b>Press 0</b>	
<b>Press 1</b>	<ul style="list-style-type: none"> <li>• Extension</li> </ul>
<b>Press 2</b>	<ul style="list-style-type: none"> <li>• Voicemail</li> </ul>
<b>Press 3</b>	<ul style="list-style-type: none"> <li>• Conference Rooms</li> </ul>
<b>Press 4</b>	<ul style="list-style-type: none"> <li>• Voicemail Group</li> </ul>
<b>Press 5</b>	<ul style="list-style-type: none"> <li>• IVR</li> </ul>
<b>Press 6</b>	<ul style="list-style-type: none"> <li>• Ring Group</li> </ul>
<b>Press 7</b>	<ul style="list-style-type: none"> <li>• Queues</li> </ul>
<b>Press 8</b>	<ul style="list-style-type: none"> <li>• Page Group</li> </ul>

<b>Press 9</b>	• Fax
<b>Press *</b>	• Custom Prompt
<b>Timeout</b>	• Hangup
<b>Invalid</b>	• DISA
	• Dial By Name
	• External Number
	• Callback

## CREATE CUSTOM PROMPT

To record new IVR prompt or upload IVR prompt to be used in IVR, click on “Prompt” next to the “Welcome Prompt” option and the users will be redirected to Custom Prompt page. Or users could go to Web GUI->**PBX->Internal Options->Custom Prompt** page directly.



**Figure 111: Click on Prompt to Create IVR Prompt**

Once the IVR prompt file is successfully added to the UCM6200, it will be added into the prompt list options for users to select in different IVR scenarios.

## RECORD NEW CUSTOM PROMPT

In the UCM6200 web UI->**PBX->Internal Options->Custom Prompt** page, click on “Record New Custom Prompt” and follow the steps below to record new IVR prompt.




**Figure 112: Record New Custom Prompt**

- Specify the IVR file name.
- Select the format (GSM or WAV) for the IVR prompt file to be recorded.
- Select the extension to receive the call from the UCM6200 to record the IVR prompt.
- Click the “Record” button. A request will be sent to the UCM6200. The UCM6200 will then call the extension for recording the IVR prompt from the phone.
- Pick up the call from the extension and start the recording following the voice prompt.
- The recorded file will be listed in the IVR Prompt web page. Users could select to re-record, play or delete the recording.



### UPLOAD CUSTOM PROMPT

If the user has a pre-recorded IVR prompt file, click on “Upload Custom Prompt” in Web GUI->**PBX->Internal Options->Custom Prompt** page to upload the file to the UCM6200. The following are required for the IVR prompt file to be successfully uploaded and used by the UCM6200:

- PCM encoded.
- 16 bits.
- 8000Hz mono.
- In .mp3 or .wav format; or raw/ulaw/alaw/gsm file with .ulaw or .alaw suffix.
- File size under 5M.



**Figure 113: Upload Custom Prompt**

Click on  to select audio file from local PC and click on  to start uploading. Once uploaded, the file will appear in the Custom Prompt web page.

## LANGUAGE SETTINGS FOR VOICE PROMPT


The UCM6200 supports multiple languages in web GUI as well as system voice prompt. Currently, there are 16 languages supported in system voice prompt: **English (United States), Arabic, Chinese, Dutch, English (United Kingdom), French, German, Greek, Hebrew, Italian, Polish, Portuguese, Russian, Spanish, Swedish and Turkish.**

English (United States) and Chinese voice prompts are built in with the UCM6200 already. The other languages provided by Grandstream can be downloaded and installed from the UCM6200 web GUI directly. Additionally, users could customize their own voice prompts, package them and upload to the UCM6200.

Language settings for voice prompt can be accessed under Web GUI->**PBX->Internal Options->Language.**

### DOWNLOAD AND INSTALL VOICE PROMPT PACKAGE

To download and install voice prompt package in different languages from UCM6200 web GUI, click on "Check Prompt List" button.




**Figure 114: Language Settings for Voice Prompt**

A new dialog window of voice prompt package list will be displayed. Users can see the version number (latest version available V.S. current installed version), package size and options to upgrade or download the language.




Voice Prompt Package List	Version (Remote / Local)	Size	Options
British English	1.0/-	3.7M	↓
Deutsch	1.1/-	3.5M	↓
English	1.0/1.0	5.1M	⊕
Español	1.1/-	3.7M	↓
Ελληνικά	1.0/-	3.6M	↓
Français	1.0/-	3.5M	↓
Italiano	1.0/-	3.4M	↓
Nederlands	1.0/-	3.0M	↓
Polski	1.0/-	4.2M	↓
Português	1.1/-	3.7M	↓
Русский	1.1/-	3.2M	↓
Svenska	1.0/-	3.9M	↓
Türkçe	1.0/-	3.1M	↓
עברית	1.0/-	3.4M	↓
العربية	1.1/-	4.3M	↓

**Figure 115: Voice Prompt Package List**

Click on  to download the language to the UCM6200. The installation will be automatically started once the downloading is finished.


### Language Settings

**Upload Voice Prompt Package**


 Choose Voice Prompt to    Upload

Upload:

**Voice Prompt Package List**

 Language:

English  
 中文  
 Deutsch


 Delete

**Figure 116: New Voice Prompt Language Added**

A new language option will be displayed after successfully installed. Users then could select it to apply in the UCM6200 system voice prompt or delete it from the UCM6200.



## CUSTOMIZE SPECIFIC PROMPT

On the UCM6200, if the user needs to replace some specific customized prompt, the user can upload a single specific customized prompt from web **UI->PBX->Internal Options->Language** instead of the entire language pack.



**Language Settings**

**Upload Voice Prompt Package**

Choose Voice Prompt to    Upload

Upload:

**Voice Prompt Package List**

Language:  中文  English

Figure 117: Upload Single Voice Prompt for Entire Language Pack



## VOICEMAIL

### CONFIGURE VOICEMAIL

If the voicemail is enabled for UCM6200 extensions, the configurations of the voicemail can be globally set up and managed under Web GUI->**PBX->Call Features->Voicemail**.

**Table 62: Voicemail Settings**

Max Greeting	Configure the maximum number of seconds for the voicemail greeting. The default setting is 60 seconds.
Dial '0' For Operator	If enabled, the caller can press 0 to exit the voicemail application and connect to the configured operator's extension. The operator extension can be configured under web GUI-> <b>PBX-&gt;Internal Options-&gt;General</b> .
Max Messages Per Folder	Configure the maximum number of messages per folder in users' voicemail. The valid range 10 to 1000. The default setting is 50.
Max Message Time	Select the maximum duration of the voicemail message. The message will not be recorded if the duration exceeds the max message time. The default setting is 15 minutes. The available options are: <ul style="list-style-type: none"> <li>• 1 minute</li> <li>• 2 minutes</li> <li>• 5 minutes</li> <li>• 15 minutes</li> <li>• 30 minutes</li> <li>• Unlimited</li> </ul>
Min Effective Message Time	Configure the minimum duration (in seconds) of a voicemail message. Messages will be automatically deleted if the duration is shorter than the Min Message Time. The default setting is 3 seconds. The available options are: <ul style="list-style-type: none"> <li>• No minimum</li> <li>• 1 second</li> <li>• 2 seconds</li> <li>• 3 seconds</li> <li>• 4 seconds</li> <li>• 5 seconds</li> </ul> <p><b>Note:</b> Silence and noise duration are not counted in message time.</p>
Announce Message Caller-ID	If enabled, the caller ID of the user who has left the message will be announced at the beginning of the voicemail message. The default setting



	is "No".
Announce Message Duration	If enabled, the message duration will be announced at the beginning of the voicemail message. The default setting is "No".
Play Envelope	If enabled, a brief introduction (received time, received from, and etc) of each message will be played when accessed from the voicemail application. The default setting is "Yes".
Play from Last	If enabled, UCM will play from the voice message left most recently; if disabled, UCM will play from the earliest left voice message
Allow User Review	If enabled, users can review the message following the IVR before sending the message out. The default setting is "No".

## ACCESS VOICEMAIL

If the voicemail is enabled for UCM6200 extensions, the users can dial the voicemail access feature code (by default \*98 or \*97) to access the extension's voicemail. The users will be prompt to enter the voicemail password and then can enter digits from the phone keypad to navigate in the IVR menu for different options.

**Table 63: Voicemail IVR Menu**

Main Menu	Sub Menu 1	Sub Menu 2
1 - New messages	3 - Advanced options	1 - Send a reply
		2 - Call the person who sent this message
		3 - Hear the message envelop
		4 - Leave a message
		* - Return to the main menu
	5 - Repeat the current message	
	7 - Delete this message	
	8 - Forward the message to another user	
2 - Change folders	9 - Save	
	* - Help	
	# - Exit	
	0 - New messages	
	1 - Old messages	
	2 - Work messages	
	3 - Family messages	
4 - Friend messages		
	# - Cancel	

3 - Advanced options	1 - Send a reply	
	2 - Call the person who sent this message	
	3 - Hear the message envelop	
	4 - Leave a message	
	* - Return to the main menu	
0 - Mailbox options	1 - Record your unavailable message	1 - Accept this recording
		2 - Listen to it
		3 - Re-record your message
	2 - Record your busy message	1 - Accept this recording
		2 - Listen to it
		3 - Re-record your message
	3 - Record your name	1 - Accept this recording
		2 - Listen to it
		3 - Re-record your message
	4 - Record temporary greeting	1 - Accept this recording
		2 - Listen to it
		3 - Re-record your message
	5 - Change your password	
	* - Return to the main menu	


## VOICEMAIL EMAIL SETTINGS

The UCM6200 can be configured to send the voicemail as attachment to Email. Click on "Voicemail Email Settings" button to configure the Email attributes and content.

**Table 64: Voicemail Email Settings**

Attach Recordings to E-Mail	If enabled, voicemails will be sent to user's Email address. The default setting is "Yes".
Keep Recordings	If enabled, voicemail will be stored in the UCM6200 after the email is sent. The default setting is "Yes".
Template For Voicemail Emails	<p>Fill in the "Subject:" and "Message:" content, to be used in the Email when sending to the user.</p> <p>The template variables are:</p> <ul style="list-style-type: none"> <li>• \t: TAB</li> <li>• \${VM_NAME}: Recipient's first name and last name</li> </ul>

- `{VM_DUR}`: The duration of the voicemail message
- `{VM_MAILBOX}`: The recipient's extension
- `{VM_CALLERID}`: The caller ID of the person who has left the message
- `{VM_MSGNUM}`: The number of messages in the mailbox
- `{VM_DATE}`: The date and time when the message is left



**Voicemail Email Settings**

Attach Recordings to E-mail:     
  Keep Recordings:

**Template for Voicemail Emails**

Template Variables: \t : TAB  
`{VM_NAME}` : Recipient's firstname and lastname  
`{VM_DUR}` : The duration of the voicemail message  
`{VM_MAILBOX}` : The recipient's extension  
`{VM_CALLERID}` : The caller ID of the person who has left the message  
`{VM_MSGNUM}` : The message number in the mailbox  
`{VM_DATE}` : The date and time when the message was left

Subject:

Message:


  
   

**Figure 118: Voicemail Email Settings**

Click on "Load Default Settings" button to view the default template as an example.

## CONFIGURE VOICEMAIL GROUP

The UCM6200 supports voicemail group and all the extensions added in the group will receive the voicemail to the group extension. The voicemail group can be configured under Web GUI->**PBX->Call Features->Voicemail Group**. Click on "Create New Voicemail Group" to configure the group.



**Figure 119: Voicemail Group**

**Table 65: Voicemail Group Settings**

Extension	Enter the Voicemail Group Extension. The voicemail messages left to this extension will be forwarded to all the voicemail group members.
Name	Configure the Name to identify the voicemail group. Letters, digits, _ and - are allowed.
Voicemail Password	Configure the voicemail password for the users to check voicemail messages.
Email Address	Configure the Email address for the voicemail group extension.
Voicemail Group Mailboxes	Select available mailboxes from the left list and add them to the right list. The extensions need to have voicemail enabled to be listed in available mailboxes list.






## RING GROUP

The UCM6200 supports ring group feature with different ring strategies applied to the ring group members. This section describes the ring group configuration on the UCM6200.



### CONFIGURE RING GROUP

Ring group settings can be accessed via Web GUI->**PBX->Call Features->Ring Group**.











Extension	Ring Group Name	Members	Options
8400	techsupport	8005, 8006, 8007	 

**Figure 120: Ring Group**

- Click on “Create New Ring Group” to add ring group.
- Click on  to edit the ring group. The following table shows the ring group configuration parameters.
- Click on  to delete the ring group.

**Table 66: Ring Group Parameters**

Ring Group Name	Configure ring group name to identify the ring group. Letters, digits, _ and – are allowed.
Extension	Configure the ring group extension.
Ring Group Members	Select available users from the left side to the ring group member list on the right side. Click on     to arrange the order.
Selected LDAP Numbers	Select available remote users from the left side to the ring group member list on the right side. Click on     to arrange the order. Note: LDAP Sync must be enabled first.
Ring Strategy	Select the ring strategy. The default setting is “Ring in order”. <ul style="list-style-type: none"> <li>• Ring simultaneously. Ring all the members at the same time when there is incoming call to the ring group extension. If any of the member answers the call, it will stop ringing.</li> <li>• Ring in order. Ring the members with the order configured in ring group list. If the first member doesn’t answer the call, it will stop ringing the first member and start ringing the second member.</li> </ul>

Custom Prompt	This option is to set a custom prompt for a ring group to announce to caller. Click on 'Prompt', it will direct to the page <b>PBX-&gt;Internal Options-&gt;Custom Prompt</b> , where users could record new prompt or upload prompt files.
Ring Timeout on Each Member	Configure the number of seconds to ring each member. If set to 0, it will keep ringing. The default setting is 30 seconds. <b>Note:</b> The actual ring timeout might be overridden by users if the phone has ring timeout settings as well.
Auto Record	If enabled, calls on this ring group will be automatically recorded. The default setting is No. The recording files can be accessed from web GUI-> <b>CDR-&gt;Recording Files</b> .
Enable Destination	If enabled, users could select extension, voicemail, ring group, IVR, call queue, voicemail group as the destination if the call to the ring group has no answer. Secret and Email address are required if voicemail is selected as the destination.
Secret	Configure the password to access the ring group extension's voicemail. <b>Note:</b> The password has to be at least 4 characters.
Email Address	Configure the Email address of the ring group extension's voicemail. If "Attach Recordings to E-mail" is enabled from Web GUI-> <b>PBX-&gt;Voicemail-&gt;Voicemail Email Settings</b> , the voicemail can be sent to the ring group's Email address as attachment.

Edit Ring Group: 6400
X

Ring Group Name:

Extension:

Available Extensions

656

657

658

659

660

661

➤

➤

➤

➤

➤

Ring Group Members

634

669

⊕

⊕

⊕

⊕

⊕

**Ring Group Options**

Ring Strategy:

ⓘ Ring Timeout on Each Member (s):

Enable Destination:

ⓘ Auto Record:

ⓘ Default Destination:


**Figure 121: Ring Group Configuration**

## REMOTE EXTENSION IN RING GROUP

Remote extensions from the peer trunk of a remote UCM6200 can be included in the ring group with local extension. An example of Ring Group with peer extensions is presented in the following:

1. Creating SIP Peer Trunk between both UCM6200\_A and UCM6200\_B. **SIP Trunk** can be found under web **UI-> PBX-> Basic/Call Routes-> VoIP Trunks**. Also, please configure their Inbound/Outbound routes accordingly.



2. Click edit button in the menu , and check if **Sync LDAP Enable** is selected, this option will allow UCM6200\_A update remote LDAP server automatically from peer UCM6200\_B. In addition, **Sync LDAP Password** must match for UCM6200\_A and UCM6200\_B in order to sync LDAP contact automatically. Port number can be anything between 0~65535, and use the outbound rule created in step 1 for the **LDAP Outbound Rule** option.



**Edit SIP Trunk: Test\_Ringgroup**

Basic Settings | **Advanced Settings**

**Codec Preference:**

Available Codecs	Selected Codecs
iLBC	PCMU
G.722	PCMA
AAL2-G.726-32	GSM
ADPCM	G.726
G.723	G.729

**DID Mode:** Request-line

**DTMF Mode:** Default

**Enable Quality:**

**Qualify Timeout:** 1000

**Qualify Frequency:** 60

**The maximum number of call lines:** 0

**Fax Mode:** None

**SRTP:**

**Sync LDAP Enable:**

**Sync LDAP Password:** admin1

**Sync LDAP Port:** 36789

**LDAP Outbound Rule:** Test\_Ringgroup

**LDAP Dialed Prefix:**

**LDAP Last Sync Date:** 2015-03-23T15:14:54-0700

Cancel Save

Figure 122: Sync LDAP Server option

- In case if LDAP server doesn't sync automatically, user can manually sync LDAP server. Under **VoIP Trunks** page, click sync button shown in the following figure to manually sync LDAP contacts from peer UCM6200.




Figure 123: Manually Sync LDAP Server

4. Under **Ring Groups** setting page, click Create New Ring Group. **Ring Groups** can be found under web **UI-> PBX-> Call Features-> Ring Groups**.
5. If LDAP server is synced correctly, **Available LDAP Numbers** box will display available remote extensions that can be included in the current ring group. Please also make sure the extensions in the peer UCM6200 can be included into that UCM6200's LDAP contact.

**Edit Ring Group: 6402**

Ring Group Name:

Extension:

**Available Extensions/Extension Groups**

- 1000 "jingya tan"
- 1003 "Test TestH"
- 1004 "Test"
- 1005 "UCM\_FAKE\_PEER"
- 3000 "Grandstream Test"
- 3001 "UCM\_PEER\_144"

**Available LDAP Numbers**

- 1002(ou=Test\_1)
- 2000(ou=Test\_1)
- 1010(ou=Test\_Ringgroup)
- 1011(ou=Test\_Ringgroup)
- 5000(ou=Test\_Ringgroup)
- 5002(ou=Test\_Ringgroup)

**Ring Group Members**

- 1001 "Emily"

**Selected LDAP Numbers**

- 5001(ou=Test\_Ringgroup)

**Ring Group Options**

Ring Strategy:

Permission:

Custom Prompt:  [Prompt](#)

Ring Timeout on Each Member (s):

Auto Record:

**Figure 124: Ring Group Remote Extension**

Firmware Version 1.0.0.1

UCM6200 Series IP PBX User Manual

Page 209 of 321




## PAGING AND INTERCOM GROUP

Paging and Intercom Group can be used to make an announcement over the speaker on a group of phones. Targeted phones will answer immediately using speaker. The UCM6200 paging and intercom can be used via feature code to a single extension or a paging/intercom group. This sections describes the configuration of paging/intercom group under Web GUI->**PBX->Call Features->Paging/Intercom**.

### CONFIGURE PAGING/INTERCOM GROUP



- Click on "Create New Paging/Intercom Group" to add paging/intercom group.




**Figure 125: Paging/Intercom Group**

**Table 67: Paging/Intercom Group Configuration Parameters**

Name	Configure paging/intercom group name.
Extension	Configure the paging/intercom group extension.
Type	Select "2-way Intercom" or "1-way Page".
Custom Prompt	This option is to set a custom prompt for a paging/intercom group to announce to caller. Click on 'Prompt', it will direct to the page <b>PBX-&gt;Internal Options-&gt;Custom Prompt</b> , where users could record new prompt or upload prompt files.
Page/Intercom Group Members	Select available users from the left side to the paging/intercom group member list on the right.

- Click on  to edit the paging/intercom group.
- Click on  to delete the paging/intercom group.
- Click on "Paging/Intercom Group Settings" to edit Alert-Info Header. This header will be included in the SIP INVITE message sent to the callee in paging/intercom call.



**Paging/Intercom Group Settings** X

**Paging & Intercom Settings**

Alert-Info Header:

**Paging/Intercom Feature Code Settings**

Please go to [Feature Codes](#) Configure the paging/intercom feature code.

Cancel Save

**Figure 126: Page/Intercom Group Settings**


- The UCM6200 has pre-configured paging/intercom feature code. By default, the Paging Prefix is \*81 and the Intercom Prefix is \*80. To edit page/intercom feature code, click on "Feature Codes" in the "Paging/Intercom Group Settings" dialog. Or users could go to Web GUI->**PBX->Internal Options->Feature Codes** directly.

## CALL QUEUE


The UCM6200 supports call queue by using static agents or dynamic agents. Call Queue system can accept more calls than the available agents. Incoming calls will be held until next representative is available in the system. This section describes the configuration of call queue under Web GUI->**PBX->Call Features->Call Queue**.

### CONFIGURE CALL QUEUE

Call queue settings can be accessed via Web GUI->**PBX->Call Features->Call Queue**.







**Figure 127: Call Queue**


- Click on "Create New Queue" to add call queue.
- Click on  to edit the call queue. The call queue configuration parameters are listed in the table below.

**Table 68: Call Queue Configuration Parameters**


Extension	Configure the call queue extension.
Name	Configure the call queue name to identify the call queue.
Strategy	Select the strategy for the call queue. <ul style="list-style-type: none"> <li>• Ring All Ring all available Agents simultaneously until one answers.</li> <li>• Linear Ring agents in the specified order.</li> </ul>

	<ul style="list-style-type: none"> <li>• Least Recent Ring the agent who has been called the least recently.</li> <li>• Fewest Calls Ring the agent with the fewest completed calls.</li> <li>• Random Ring a random agent.</li> <li>• Round Robin Ring the agents in Round Robin scheduling with memory.</li> </ul> <p>The default setting is "Ring All".</p>
Music On Hold	<p>Select the Music On Hold class for the call queue.</p> <p><b>Note:</b> Music On Hold classes can be managed from Web GUI-&gt; <b>PBX-&gt;Internal Options-&gt;Music On Hold.</b></p>
Leave When Empty	<p>Configure whether the callers will be disconnected from the queue or not if the queue has no agent anymore. The default setting is "Strict".</p> <ul style="list-style-type: none"> <li>• Yes Callers will be disconnected from the queue if all agents are paused or invalid.</li> <li>• No Never disconnect the callers from the queue when the queue is empty.</li> <li>• Strict Callers will be disconnected from the queue if all agents are paused, invalid or unavailable.</li> </ul>
Dial in Empty Queue	<p>Configure whether the callers can dial into a call queue if the queue has no agent. The default setting is "No".</p> <ul style="list-style-type: none"> <li>• Yes Callers can always dial into a call queue.</li> <li>• No Callers cannot dial into a queue if all agents are paused or invalid.</li> <li>• Strict Callers cannot dial into a queue if the agents are paused, invalid or unavailable.</li> </ul>
Dynamic Login Password	<p>If enabled, the configured PIN number is required for dynamic agent to log in. The default setting is disabled.</p>
Ring Time Out	<p>Configure the number of seconds an agent will ring before the call goes to the next agent. The default setting is 15 seconds.</p>
Wrapup Time	<p>Configure the number of seconds before a new call can ring the queue</p>

	after the last call on the agent is completed. If set to 0, there will be no delay between calls to the queue. The default setting is 15 seconds.
Max Queue Length	Configure the maximum number of calls to be queued at once. This number does not include calls that have been connected with agents. It only includes calls not connected yet. The default setting is 0, which means unlimited. When the maximum value is reached, the caller will be treated with busy tone followed by the next calling rule after attempting to enter the queue.
Report Hold Time	If enabled, the UCM6200 will report (to the agent) the duration of time of the call before the caller is connected to the agent. The default setting is "No".
Wait Time	If enabled, users will be disconnected after the configured number of seconds. The default setting is "No".  <b>Note:</b> It is recommended to configure "Wait Time" longer than the "Wrapup Time".
Auto Record	If enabled, the calls on the call queue will be automatically recorded. The recording files can be accessed in Queue Recordings under web GUI->PBX->Call Features->Call Queue.
Enable Destination	If enabled, the incoming call for the call queue will be routed to the destination configured in the next field if none of the agents answers the call after ringing for a time of "Ring Timeout".
Queue Timeout	Configure the global timeout (in seconds) of call queue. It must be bigger than the value of ring timeout. The call in the queue will be transferred to the failover destination directly if this time is exceeded.
Failover Destination	Configure the call destination for the call to be routed to if no agent in this call queue answers the call.
Enable Feature Codes	Enable feature codes option for call queue. For example, *83 is used for "Agent Pause"
Agents	Select the available users to be the static agents in the call queue. Choose from the available users on the left to the static agents list on the right. Click on     to arrange the order.



- Click on  to delete the call queue.
- Click on "Agent Login Settings" to configure Agent Login Extension Postfix and Agent Logout Extension Postfix. Once configured, users could log in the call queue as dynamic agent.





**Figure 128: Agent Login Settings**

For example, if the call queue extension is 6500, Agent Login Extension Postfix is \* and Agent Logout Extension Postfix is \*\*, users could dial 6500\* to login to the call queue as dynamic agent and dial 6500\*\* to logout from the call queue. Dynamic agent doesn't need to be listed as static agent and can log in/log out at any time.


- Call queue feature code "Agent Pause" and "Agent Unpause" can be configured under Web GUI->**PBX**->**Internal Options**->**Feature Codes**. The default feature code is \*83 for "Agent Pause" and \*84 for "Agent Unpause".
- Queue recordings are shown on the Call Queue page. Click on  to download the recording file in .wav format; click on  to delete the recording file. To delete multiple recording files by one click, select several recording files to be deleted and click on "Delete Selected Recording Files" or click on "Delete All Recording Files" to delete all recording files.

## EXTENSION GROUPS


The UCM6200 extension group feature allows users to assign and categorize extensions in different groups to better manage the configurations on the UCM6200. For example, when configuring "Enable Filter on Source Caller ID", users could select a group instead of each person's extension to assign. This feature simplifies the configuration process and helps manage and categorize the extensions for business environment.

### CONFIGURE EXTENSION GROUPS

Extension group can be configured via Web GUI->**PBX->Call Features->Extension Groups**.

- Click on "Create New Extension Group" to create a new extension group.
- Click on  to edit the extension group.

Select extensions from the list on the left side to the right side.



**Figure 129: Edit Extension Group**

- Click on  to delete the extension group.

## USING EXTENSION GROUPS

Here is an example where the extension group can be used. Go to Web GUI->**PBX->Basic/Call Routes->Outbound Routes** and select "Enable Filter on Source Caller ID". Both single extensions and extension groups will show up for users to select.

**Edit Outbound Rule: usa1**

i Calling Rule Name:

i Pattern:  +

i Password:

i Privilege Level: National ▼

i Enable Filter on Source Caller ID:

Available Extensions/Extension Groups

Extension Group -- Accounting\_Dept

Extension Group -- Marketing\_Dept

Extension Group -- IT\_Dept

Extension Group -- Sales\_Dept

Extension Group -- TechSupport\_Dept

⊕

➤

➤

⊖

Selected Extensions/Extension Groups

i Custom Dynamic Route:


**Figure 130: Select Extension Group in Outbound Route**

## PICKUP GROUPS

The UCM6200 supports pickup group feature which allows users to pick up incoming calls for other extensions if they are in the same pickup group, by dialing "Pickup Extension" feature code (by default \*8).

### CONFIGURE PICKUP GROUPS

Pickup groups can be configured via Web GUI->**PBX->Call Features->Pickup Groups**.

- Click on "Create New Pickup Group" to create a new pickup group.
- Click on  to edit the pickup group.

Select extensions from the list on the left side to the right side.



Figure 131: Edit Pickup Group

- Click on  to delete the pickup group.

### CONFIGURE PICKUP FEATURE CODE

When picking up the call for the pickup group member, the user only needs to dial the pickup feature code. It's not necessary to add the extension number after the pickup feature code. The pickup feature code is configurable under Web GUI->**PBX->Internal Options->Feature Codes**.

The default pickup feature code is \*8.

PBX >> Internal Options >> Feature Codes

① Feature Code Digits Timeout:	1000	① Call Park:	700
① Parking Lots:	701-720	① Use parklot as extension:	<input type="checkbox"/>
① Parking Timeout(s):	300		

Feature Codes

Reset All    Default All


① Voicemail Access Code:	*98	① My Voicemail:	*97
① Agent Pause:	*83	① Agent Unpause:	*84
① Paging Prefix:	*81	① Intercom Prefix:	*80
① Blacklist Add:	*40	① Blacklist Remove:	*41
① Call Pickup on Ringing:	**	① Pickup Extension:	*8
① Direct Dial Voicemail Prefix:	*	① Call Completion Request:	*11
① Call Completion Cancel:	*12	① Enable Spy:	<input type="checkbox"/>
① Listen Spy:	*54	① Whisper Spy:	*55
① Barge Spy:	*56		

Cancel    Save

Figure 132: Edit Pickup Feature Code



## MUSIC ON HOLD

Music On Hold settings can be accessed via Web GUI->**PBX->Internal Options->Music On Hold**. In this page, users could configure music on hold class and upload music files. The "default" Music On Hold class already has 5 audio files defined for users to use.





**Manage Music On Hold**

Create New MOH Class

Music On Hold Classes: default  







Upload an 8 KHz Mono Music file (file size under 5M):

Choose file to upload:    Upload

List of Sound Files



Delete Selected Sound Files




View: 10

<input type="checkbox"/>	Sound File 	Options
<input type="checkbox"/>	macroform-cold_day.wav	
<input type="checkbox"/>	macroform-robot_dity.wav	
<input type="checkbox"/>	macroform-the_simplicity.wav	
<input type="checkbox"/>	manolo_camp-morning_coffee.wav	
<input type="checkbox"/>	reno_project-system.wav	

Total: 5 Show: 1/1 Go to:

Figure 133: Music On Hold Default Class

- Click on "Create New MOH Class" to add a new Music On Hold class.
- Click on  to configure the MOH class sort method to be "Alpha" or "Random" for the sound files.
- Click on  next to the selected Music On Hold class to delete this Music On Hold class.

- Click on  to select music file from local PC and click on  to start uploading. The music file uploaded has to be 8 KHz Mono format with size smaller than 5M.
- Click on  next to the sound file to delete it from the selected Music On Hold Class.
- Select the sound files and click on **Delete Selected Sound Files** to delete all selected music on hold files.

**Note:**

Once the MOH file is deleted, there are two ways to recover the music files.

- Users could download the MOH file from this link:  
<http://downloads.asterisk.org/pub/telephony/sounds/releases/asterisk-moh-opsound-wav-2.03.tar.gz>  
After downloading and unzip the pack, users could then upload the music files to UCM.
  - Factory reset could also recover the MOH file on the UCM.
-

## FAX/T.38

The UCM6200 supports T.30/T.38 Fax and Fax Pass-through. It can convert the received Fax to PDF format and send it to the configured Email address. Fax/T.38 settings can be accessed via Web GUI->**PBX**->**Internal Options**->**FAX/T.38**. The list of received Fax files will be displayed in the same web page for users to view, retrieve and delete.

### CONFIGURE FAX/T.38



- Click on "Create New Fax Extension". In the popped up window, fill the extension, name and Email address to send the received Fax to.
- Click on "Fax Settings" to configure the Fax parameters.

**Table 69: FAX/T.38 Settings**

Enable Error Correction Mode	Configure to enable Error Correction Mode (ECM) for the Fax. The default setting is "Yes".
Maximum Transfer Rate	Configure the maximum transfer rate during the Fax rate negotiation. The possible values are 2400, 4800, 7200, 9600, 12000 and 14400. The default setting is 14400.
Minimum Transfer Rate	Configure the minimum transfer rate during the Fax rate negotiation. The possible values are 2400, 4800, 7200, 9600, 12000 and 14000. The default setting is 2400.
Max Concurrent Sending Fax	<p>Configure the concurrent fax that can be sent by UCM6200. Two mode "Only" and "More" are supported.</p> <ul style="list-style-type: none"> <li>• Only Under this mode, the UCM6200 allows only single user to send fax at a time.</li> <li>• More Under this mode, the UCM6200 supports multiple concurrent fax sending by the users.</li> </ul> <p>By default, this option is set to "only".</p>
Fax Queue Length	Configure the maximum length of Fax Queue from 6 to 10. The default setting is 6.
Default Email Address	<p>Configure the Email address to send the received Fax to if user's Email address cannot be found.</p> <p><b>Note:</b></p>



	<p>The extension's Email address or the Fax's default Email address needs to be configured in order to receive Fax from Email. If neither of them is configured, Fax will be not be received from Email.</p>
<p>Template Variables</p>	<p>Fill in the "Subject:" and "Message:" content, to be used in the Email when sending the Fax to the users.</p> <p>The template variables are:</p> <ul style="list-style-type: none"> <li>• <code>\${CALLERIDNUM}</code> : Caller ID Number</li> <li>• <code>\${CALLERIDNAME}</code> : Caller ID Name</li> <li>• <code>\${RECEIVEEXTEN}</code> : The extension to receive the Fax</li> <li>• <code>\${FAXPAGES}</code> : Number of pages in the Fax</li> <li>• <code>\${VM_DATE}</code> : The date and time when the Fax is received</li> </ul>


- Click on  to edit the Fax extension.
- Click on  to delete the Fax extension.

## SAMPLE CONFIGURATION TO RECEIVE FAX FROM PSTN LINE

The following instructions describe how to use the UCM6200 to receive Fax from PSTN line on the Fax machine connected to the UCM6200 FXS port.

1. Connect Fax machine to the UCM6200 FXS port.
2. Connect PSTN line to the UCM6200 FXO port.
3. Go to web GUI->**PBX**->**Analog Trunks** page.
4. Create or edit the analog trunk for Fax as below.

**Fax Mode:** Make sure "Fax Mode" option is set to "None".



**Edit Analog Trunk: Analog**

Channels:  1  2  3  4

Trunk Name\*: pstn1

SLA Mode:

**Advanced Options**

Enable Polarity Reversal:

Current Disconnect Threshold(ms):  200

Ring Timeout\*: 8000

RX Gain\*: 0

TX Gain\*: 0

Use CallerID:

Fax Mode: None

Caller ID Scheme: Bellcore/Telcordia

FXO Dial Delay(ms)\*: 0

Auto Record:


Disable This Trunk:

DAHDI Out Line Selection: Ascend

The maximum number of call lines\*: 0

**Figure 134: Configure Analog Trunk without Fax Detection**

5. Go to UCM6200 web GUI->PBX->Basic/Call Routes->Extensions page.
6. Create or edit the extension for FXS port.
  - **Analog Station:** Select FXS port to be assigned to the extension. By default, it's set to "None".
  - Once selected, analog related settings for this extension will show up in "**Analog Settings**" section.



**Create New FXS Extension**

Basic Settings | Media | Features | Specific Time

**General**

Extension\*: 1005

Analog Station: FXS 1

CallerID Number:

Permission: Internal

Enable Voicemail:

Voicemail Password\*: 7519014

Skip Voicemail Password Verification:

Disable This Extension:

**Figure 135: Configure Extension for Fax Machine: FXS Extension**

Create New FXS Extension
X

Basic Settings
Media
Features
Specific Time

**Analog Settings**

<input type="checkbox"/> Call Waiting:	<input checked="" type="checkbox"/> Use '#' as SEND:
<input type="text" value="0"/> RX Gain *:	<input type="text" value="0"/> TX Gain *:
<input type="text" value="200"/> MIN RX Flash *:	<input type="text" value="1250"/> MAX RX Flash *:
<input checked="" type="checkbox"/> Enable Polarity Reversal:	<input type="text" value="ON"/> Echo Cancellation:
<input checked="" type="checkbox"/> 3-Way Calling:	<input type="text" value="1"/> Send CallerID After:
<input type="text" value="None"/> Fax Mode:	

**Figure 136: Configure Extension for Fax Machine: Analog Settings**

7. Go to web GUI->**PBX->Basic/Call Routes->Inbound Routes** page.
8. Create an inbound route to use the Fax analog trunk. Select the created extension for Fax machine in step 4 as the default destination.

Create New Inbound Rule
X

Trunks \*:

DID Pattern \*:
 

S

/

Prepend Trunk Name:

Alert-Info:

Inbound Multiple Mode:

Default Mode
Mode 1

Default Destination \*:

**Time Condition**

Time Condition	Time	Destination	Options
Click to add Time Condition			

**Figure 137: Configure Inbound Rule for Fax**

Now the Fax configuration is done. When there is an incoming Fax calling to the PSTN number for the FXO port, it will send the Fax to the Fax machine.

## SAMPLE CONFIGURATION FOR FAX-TO-EMAIL

The following instructions describe a sample configuration on how to use Fax-to-Email feature on the UCM6200.

1. Connect PSTN line to the UCM6200 FXO port.
2. Go to UCM6200 web GUI->**Internal Options**->**Fax/T.38** page. Create a new Fax extension.




Figure 138 shows the 'Create New Fax Extension' web form. The form includes the following fields and values:

Field	Value
Extension:	5111
Name:	Fax
Email Address:	Faxtest@ucm6100mycompany.com

Buttons: Cancel, Save

Figure 138: Create Fax Extension

3. Go to UCM6200 web GUI->**Basic/Call Routes**->**Analog Trunks** page. Create a new analog trunk. Please make sure "Fax Detection" is set to "No".
4. Go to UCM6200 web GUI->**Basic/Call Routes**->**Inbound Routes** page. Create a new inbound route and set the default destination to the Fax extension.

Create New Inbound Rule
X

**Trunks \***: AnalogTrunks -- FAX\_LINE

**DID Pattern \***: S /

**Prepend Trunk Name:**

**Alert-Info:** None

**Inbound Multiple Mode:**

Default Mode | Mode 1

**Default Destination \***: Fax 5111

Time Condition			
Time Condition	Time	Destination	Options
Click to add Time Condition			

Cancel
Save

Figure 139: Inbound Route to Fax Extension

- Once successfully configured, the incoming Fax from external Fax machine to the PSTN line number will be converted to PDF file and sent to the Email address **Faxtest@ucm6200mycompany.com** as attachment.

## ASTERISK MANAGER INTERFACE (RESTRICTED ACCESS)

The UCM6200 supports Asterisk Manager Interface (AMI) with restricted access. AMI allows a client program to connect to an Asterisk instance commands or read events over a TCP/IP stream. It's particularly useful when the system admin tries to track the state of a telephony client inside Asterisk.

User could configure AMI parameters on UCM6200 web GUI->**PBX**->**Internal Options**->**AMI**. For details on how to use AMI on UCM6200, please refer to the following AMI guide:

[http://www.grandstream.com/sites/default/files/Resources/ucm6200\\_AMI\\_guide.pdf](http://www.grandstream.com/sites/default/files/Resources/ucm6200_AMI_guide.pdf)



**Warning:**

Please do not enable AMI on the UCM6200 if it is placed on a public or untrusted network unless you have taken steps to protect the device from unauthorized access. It is crucial to understand that AMI access can allow AMI user to originate calls and the data exchanged via AMI is often very sensitive and private for your UCM6200 system. Please be cautious when enabling AMI access on the UCM6200 and restrict the permission granted to the AMI user. By using AMI on UCM6200 you agree you understand and acknowledge the risks associated with this.

---



## BUSY CAMP-ON

The UCM6200 supports busy camp-on/call completion feature that allows the PBX to camp on a called party and inform the caller as soon as the called party becomes available given the previous attempted call has failed.

The configuration and instructions on how to use busy camp-on/call completion feature can be found in the following guide:

[http://www.grandstream.com/sites/default/files/Resources/ucm6200\\_busy\\_camp\\_on\\_guide.pdf](http://www.grandstream.com/sites/default/files/Resources/ucm6200_busy_camp_on_guide.pdf)






## FOLLOW ME

Follow Me is a feature on the UCM6200 that allows users to direct calls to other phone numbers and have them ring all at once or one after the other. Calls can be directed to users' home phone, office phone, mobile and etc. The calls will get to the user no matter where they are. Follow Me option can be found under web **GUI-> PBX-> Call Features->Follow Me**.


To configure follow me:

- Click on "Create New Follow Me" and then select an extension to be configured with Follow Me.



**Figure 140: Create Follow Me**

- Click on "Next" to continue editing Follow Me configuration.







**Figure 141: Edit Follow Me**

- Click on “Add Follow Me Number” to add local extensions or external numbers to be called after ringing the extension selected in the first step.
- Once created, it will be displayed on the follow me web page list. Click on  to edit the Follow Me configuration. Click on  to delete the Follow Me.

The following table shows the Follow Me configuration parameters.

**Table 70: Follow Me Settings**

Enable	Configure to enable or disable Follow Me for this user.
Skip Trunk Auth	If external number is added in the Follow Me, please make sure this option is enabled or the “Skip Trunk Auth” option of the extension is enabled, otherwise the external Follow Me number cannot be reached.
Music On Hold Class	Configure the Music On Hold class that the caller would hear while tracking the user.
Confirm When Answering	By default it is enabled and user will be asked to press 1 to accept the call or to press 2 to reject the call after answering a Follow Me call. If it is disabled, the Follow Me call will be established once after the user answers it.
Enable Destination	When enabled, the call will be routed to the default destination if no one in the Follow Me extensions answers the call.
Default Destination	Configure the destination if no one in the Follow Me extensions answers the call. The available options are: <ul style="list-style-type: none"> <li>• Extension</li> <li>• Voicemail</li> <li>• Queues</li> <li>• Ring Group</li> <li>• Voicemail Group</li> <li>• IVR</li> <li>• External Number</li> </ul>
Follow Me Numbers	The added numbers are listed here. Click on   to arrange the order. Click on  to delete the number. Click on  to add new numbers.
New Follow Me Number	Add a new Follow Me number which could be a ‘Local Extension’ or ‘External Number’. The selected dial plan should have permissions to dial the defined external number.
Dialing Order	Select the order in which the Follow Me destinations will be dialed to reach the user: ring all at once or ring one after the other.

- Click on “Follow Me Options” to enable or disable the options listed in the following table.

**Table 71: Follow Me Options**


Playback Incoming Status Message	If enabled, the PBX will playback the incoming status message before starting the Follow Me steps.
Record the Caller's Name	If enabled, the PBX will record the caller's name from the phone so it can be announced to the callee in each step.
Playback Unreachable Status Message	If enabled, the PBX will playback the unreachable status message to the caller if the callee cannot be reached.



## ONE-KEY DIAL

The UCM6200 supports One-Key Dial that allows users to call a certain destination by pressing one digit 0 to 9 on the keypad. This creates a system-wide speed dial access for all the extensions on the UCM6200.

To enable One-Key Dial, on the UCM6200 web GUI, go to page **PBX->Call Features->One-Key Dial**.



**Figure 142: Configure One-Key Dial**

User should first decide a digit used for One-Key Dial and check the option “Enable Destination” for the digit. Then select a dial destination from “Default Destination”. The supported destinations include extension, voicemail, conference room, voicemail group, IVR, ring group, call queue, page group, fax, DISA, Dial by Name and external number.



The screenshot shows the Grandstream PBX web interface. At the top, there is a navigation bar with 'Status', 'PBX', 'Settings', and 'Maintenance'. A yellow warning banner at the top right states: 'The current password security degree is low, please go to the [Change Password](#) page to modify the password and bind Email.' The left sidebar contains a menu with 'Basic/Call Routes' and 'Call Features' expanded, listing various features like Conference, IVR, Extension Groups, Voicemail, Ring Groups, etc. The main content area is titled 'One-Key Dial' and shows configuration for four different keys (Press 0, Press 1, Press 2, Press 3, Press 4). For 'Press 0', 'Enable Destination' is checked and the 'Default Destination' is set to 'Extension' with a value of '.2000 "John Doe"'. A dropdown menu is open for 'Press 1', showing options: 'Select an Option', 'Extension', 'Voicemail', 'Conference Rooms', 'Voicemail Group', 'IVR', 'Ring Group', 'Queues', 'Page Group', 'Fax', 'DISA', 'Dial By Name', and 'External Number'. 'Press 2' has 'Enable Destination' checked and 'Default Destination' set to 'Select an Option'. 'Press 3' and 'Press 4' have 'Enable Destination' unchecked and 'Default Destination' set to 'Select an Option'.


Figure 143: One-Key Dial Destinations

## DISA

In many situations the user will find the need to access his own IP PBX resources but he is not physically near one of his extensions. However, he does have access to his own cell phone. In this case we can use what is commonly known as DISA (Direct Inward System Access). Under this scenario the user will be able to call from the outside, whether it's using his cell phone, pay phone, regular PSTN, etc. After calling into UCM6200, the user can then dial out via the SIP trunk or PSTN trunk connected to UCM6200 as it is an internal extension.

The UCM6200 supports DISA to be used in IVR or inbound route. Before using it, create new DISA under web GUI->**Call Features->DISA**.

- Click on "Create New IVR" to add a new DISA.
- Click on  to edit the DISA configuration.
- Click on  to delete the DISA.



**Figure 144: Create New DISA**

**Table 72: DISA Settings**

Name	Configure DISA name to identify the DISA.
Password	Configure the password (digit only) required for the user to enter before using DISA to dial out.  <b>Note:</b> The password has to be at least 4 digits.



Permission	Configure the permission level for DISA. The available permissions are "Internal", "Local", "National" and "International" from the lowest level to the highest level. The default setting is "Internal". If the user tries to dial outbound calls after dialing into the DISA, the UCM6200 will compare the DISA's permission level with the outbound route's privilege level. If the DISA's permission level is higher than (or equal to) the outbound route's privilege level, the call will be allowed to go through.
Response Timeout	Configure the maximum amount of time the UCM6200 will wait before hanging up if the user dials an incomplete or invalid number. The default setting is 10 seconds.
Digit Timeout	Configure the maximum amount of time permitted between digits when the user is typing the extension. The default setting is 5 seconds.
Allow Hangup	If enabled, during an active call, users can enter the UCM6200 hangup feature code (by default it's *0) to disconnect the call or hang up directly. A new dial tone will be heard shortly for the user to make a new call. The default setting is "No".

Once successfully created, users can configure the inbound route destination as "DISA" or IVR key event as "DISA". When dialing into DISA, users will be prompted with password first. After entering the correct password, a second dial tone will be heard for the users to dial out.


## CALLBACK FEATURE

Callback is mainly designed for users who often use their mobile phones to make long distance or international calls which may have high service charges. The callback feature provides an economic solution for reduce the cost from this.

The callback feature works as follows:

1. Configure a new callback on the UCM6200.
2. On the UCM6200, configure destination of the inbound route for analog trunk to callback.
3. Save and apply the settings.
4. The user calls the PSTN number of the UCM6200 using the mobile phone, which goes to callback destination as specified in the inbound route.
5. Once the user hears the ringback tone from the mobile phone, hang up the call on the mobile phone.
6. The UCM6200 will call back the user.
7. The user answers the call.
8. The call will be sent to DISA or IVR which directs the user to dial the destination number.
9. The user will be connected to the destination number.

In this way, the calls are placed and connected through trunks on the UCM6200 instead of to the mobile phone directly. Therefore, the user will not be charged on mobile phone services for long distance or international calls.

To configure callback on the UCM6200, go to web GUI->**PBX->Call Features->Callback** page and click on . Configuration parameters are listed in the following table.

**Table 73: Callback Configuration Parameters**

Name	Configure a name to identify the Callback.
CallerID Pattern	Configure the pattern of the callers allowed to use this callback. The caller who places the inbound call needs to have the callerID match this pattern so that the caller can get callback after hanging up the call.  <b>Note:</b> If leaving as blank, all numbers are allowed to use this callback.
Outbound Prepend	Configure the prepend digits to be added at before dialing the outside number. The number with prepended digits will be used to match the outbound route. '-' is the connection character which will be ignored.

Delay Before Callback	Configure the number of seconds to be delayed before calling back the user.
Destination	Configure the destination which the callback will direct the caller to. Two destinations are available: <ul style="list-style-type: none"><li>• IVR</li><li>• DISA</li></ul> The caller can then enter the desired number to dial out via UCM6200 trunk.

## BLF AND EVENT LIST

### BLF



The UCM6200 supports BLF monitoring for extensions, ring group, call queue, conference room and parking lot. For example, on the user's phone, configure the parking lot number 701 as the BLF monitored number. When there is a parked call on 701, the LED for this BLF key will light up in red, meaning a call is parked against this parking lot. Pressing this BLF key can pick up the call from this parking lot.

 **Note:**

On the Grandstream GXP series phones, the MPK supports "Call Park" mode, which can be used to park the call by configuring the MPK number as call park feature code (e.g., 700). MPK "Call Park" mode can also be used to monitor and pickup parked call if the MPK number is configured as parking lot (e.g., 701).

### EVENT LIST


Besides BLF, users can also configure the phones to monitor event list. In this way, both local extensions on the same UCM6200 and remote extensions on the VOIP trunk can be monitored. The event list setting is under web GUI->**Call Features->Event List**.

- Click on "Create New Event List" to add a new event list.
- Click on  to edit the event list configuration.
- Click on  to delete the event list.

**Table 74: Event List Settings**

URI	Configure the name of this event list (for example, office_event_list). Please note the URI name cannot be the same as the extension name on the UCM6200. The valid characters are letters, digits, _ and -.
Local Extensions	Select the available extensions/Extension Groups listed on the local UCM6200 to be monitored in the event list.
Remote Extensions	If LDAP sync is enabled between the UCM6200 and the peer UCM6200, the remote extensions will be listed under "Available Extensions". If not,

	manually enter the remote extensions under "Special Extensions" field.
Special Extensions	Manually enter the remote extensions in the peer/register trunk to be monitored in the event list. Valid format: 5000,5001,9000



**Figure 145: Create New Event List**

Remote extension monitoring works on the UCM6200 via event list BLF, among Peer SIP trunks or Register SIP trunks (register to each other). Therefore, please properly configure SIP trunks on the UCM6200 first before using remote BLF feature. Please note the SIP end points need support event list BLF in order to monitor remote extensions.

When an event list is created on the UCM6200 and remote extensions are added to the list, the UCM6200 will send out SIP SUBSCRIBE to the remote UCM6200 to obtain the remote extension status. When the SIP end points registers and subscribes to the local UCM6200 event list, it can obtain the remote extension status from this event list. Once successfully configured, the event list page will show the status of total extension and subscribers for each event list. Users can also select the event URI to check the monitored extension's status and the subscribers' details.

**Note:**

- To configure LDAP sync, please go to UCM6200 web GUI->**PBX->Basic/Call Routes->VoIP Trunk**. You will see "Sync LDAP Enable" option. Once enabled, please configure password information for the remote peer UCM6200 to connect to the local UCM6200. Additional information such as port number, LDAP outbound rule, LDAP Dialed Prefix will also be required. Both the local UCM6200 and remote UCM6200 need enable LDAP sync option with the same password for successful connection and synchronization.
  - Currently LDAP sync feature only works between two UCM6200s.
  - (Theoretically) Remote BLF monitoring will work when the remote PBX being monitored is non-UCM6200 PBX. However, it might not work the other way around depending on whether the non-UCM6200 PBX supports event list BLF or remote monitoring feature.
-




## DIAL BY NAME

Dial By Name is a feature on the PBX that allows caller to search a person by first or last name via his/her phone's keypad. The administrator can define the Dial By Name directory including the desired extensions in the directory and the searching type by "first name" or "last name". After dialing in, the PBX IVR/Auto Attendant will guide the caller to spell the digits to find the person in the Dial By Name directory. This feature allows customers/clients to use the guided automatic system to get in touch with the enterprise employees without having to know the extension number, which brings convenience and improves business image for the enterprise.

### DIAL BY NAME CONFIGURATION

The administrators can create the dial by name group under web GUI->**PBX->Call Features->Dial By Name**.



Create New Dial By Name
X

Name:

Extension:

Available Extensions

1000

1004 "Tom Bryan"

1005 "Rachel White"

1006

1007

Selected Extensions

1001 "John Doe"

1002 "Jane Doe"

1003 "William Tsai"

Available LDAP

Selected LDAP

**Options**

Query Type:  By Last Name + First Name  By First Name + Last Name

Select Type:  By Order  By Menu

**Figure 146: Create Dial By Name Group**



## 1. Group Name

Enter the Group Name. This is to identify the Dial By Name group. The Dial By Name group can be used as the destination for inbound route and key pressing event for IVR. The group name defined here will show up in the destination list when configuring IVR and inbound route. If Dial By Name is set as a key pressing event for IVR, user could use “\*” to exit from Dial By Name, then re-enter IVR and start a new event. The following example shows how to use this option.

**Create New IVR**

**Name:**

**Extension:**

**Dial Other Extensions:**

**Dial Trunk:**

**Permission:** Internal ▼

**Welcome Prompt:** welcome ▼ [Prompt](#)

**Digit Timeout:**

**Response Timeout:**

**Response Timeout Prompt:** ivr-create-timeout ▼

**Invalid Prompt:** invalid ▼

**Response Timeout Repeat Loops:** 3 ▼

**Invalid Repeat Loops:** 3 ▼

**Language:** Default ▼

**Key Pressing Events**

<b>Press 0:</b>	<input type="text" value="Dial By Name"/>	<input type="text" value="DialByNameGP1"/>
<b>Press 1:</b>	<input type="text" value="Extension"/>	<input type="text" value="1000"/>
<b>Press 2:</b>	<input type="text" value="Conference Rooms"/>	<input type="text" value="6300"/>

**Figure 147: Dial By Name Group In IVR Key Pressing Events**

Edit Inbound Rule
X

ⓘ DID Pattern:  /

ⓘ Privilege Level:

ⓘ Default Destination:

ⓘ Prepend Trunk Name:

ⓘ Alert-Info:

Time Condition

ⓘ Time Condition:


**Figure 148: Dial By Name Group In Inbound Rule**

## 2. Extension

Configure the direct dial extension for the Dial By Name group.

## 3. Available Extensions/Selected Extensions

Select available extensions from the left side to the right side as the directory for the Dial By Name group. Only the selected extensions here can be reached by the Dial By Name IVR when dialing into this group. The extensions here must have a valid first name and last name configured under web GUI->**PBX->Basic/Call Routes->Extensions** in order to be searchable in Dial By Name directory through IVR. By specifying the extensions here, the administrators can make sure unscreened calls will not reach the company employee if he/she doesn't want to receive them directly.



**Figure 149: Configure Extension First Name and Last Name**

#### 4. Query Type

Specify the query type. This defines how the caller will need to enter to search the directory.

By First Name: enter the first 3 digits of the first name to search the directory.

By Last Name: enter the first 3 digits of the last name to search the directory.

By Full Name: enter the first 3 digits of the first name or last name to search the directory.

#### 5. Select Type

Specify the select type on the searching result. The IVR will confirm the name/number for the party the caller would like to reach before dialing out.

By Order: After the caller enters the digits, the IVR will announce the first matching party's name and number. The caller can confirm and dial out if it's the destination party, or press \* to listen to the next matching result if it's not the desired party to call.


By Menu: After the caller enters the digits, the IVR will announce 8 matching results. The caller can press number 1 to 8 to select and call, or press 9 for results in next page.

## ACTIVE CALLS AND MONITOR

The active calls on the UCM6200 are displayed in web UI->**Status->Active Calls** page. Users can monitor the status, hang up the call as well as barge in the active calls in real time manner.


### ACTIVE CALLS STATUS

To view the status of active calls, navigate to web GUI->**Status->Active Calls**. The following figure shows extension 1000 is calling 1001. 1001 is ringing.



**Figure 150: Status->PBX Status->Active Calls - Ringing**



The following figure shows the call between 1000 and 1001 is established.



**Figure 151: Status->PBX Status->Active Calls – Call Established**


In active call web page, click on  to refresh the active call status.

## HANG UP ACTIVE CALLS

To hang up an active call, click on  icon in the active call dialog. Users can also click on  to hang up all active calls.

## CALL MONITOR

During an active call, click on icon  and the monitor dialog will pop up.



**Figure 152: Configure to Monitor an Active Call**

In the “Monitor” dialog, configure the following to monitor an active call:

1. Enter an available extension for “Monitor’s Extension” which will be used to monitor the active call.
2. “Monitored Extension” must be one of the parties in the active call to be monitored.
3. Select spy mode. There are three options in “Spy Mode”.
  - Listen  
In “Listen” mode, the extension monitoring the call can hear both parties in the active call but the audio of the user on this extension will not be heard by either party in the monitored active call.
  - Whisper  
In “Whisper” mode, the extension monitoring the call can hear both parties in the active call. The user on this extension can only talk to the selected monitored extension and he/she will not be heard by the other party in the active call. This can be usually used to supervise calls.
  - Barge  
In “Barge” mode, the extension monitoring the call can talk to both parties in the active call. The call will be established similar to three-way conference.

4. Enable or disable “Require Confirmation” option. If enabled, the confirmation of the invited monitor’s extension is required before the active call can be monitored. This option can be used to avoid adding participant who has auto-answer configured or call forwarded to voicemail.
5. Click on “Add”. An INVITE will be sent to the monitor’s extension. The monitor can answer the call and start monitoring. If “Require Confirmation” is enabled, the user will be asked to confirm to monitor the call.

Another way to monitor active calls is to dial the corresponding feature codes from an extension. Please refer to **[Table 75: UCM6200 Feature Codes]** and **[ENABLE SPY]** section for instructions.



## CALL FEATURES

The UCM6200 supports call recording, transfer, call forward, call park and other call features via feature code. This section lists all the feature codes in the UCM6200 and describes how to use the call features.

### FEATURE CODES

**Table 75: UCM6200 Feature Codes**

Feature Maps	
Blind Transfer	<ul style="list-style-type: none"> <li>• Default code: #1.</li> <li>• Enter the code during active call. After hearing "Transfer", you will hear dial tone. Enter the number to transfer to. Then the user will be disconnected and transfer is completed.</li> <li>• Options               <ul style="list-style-type: none"> <li><b>Disable</b></li> <li><b>Allow Caller:</b> Enable the feature code on caller side only.</li> <li><b>Allow Callee:</b> Enable the feature code on callee side only.</li> <li><b>Allow Both:</b> Enable the feature code on both caller and callee.</li> </ul> </li> </ul>
Attended Transfer	<ul style="list-style-type: none"> <li>• Default code: *2.</li> <li>• Enter the code during active call. After hearing "Transfer", you will hear the dial tone. Enter the number to transfer to and the user will be connected to this number. Hang up the call to complete the attended transfer.</li> <li>• Options               <ul style="list-style-type: none"> <li><b>Disable</b></li> <li><b>Allow Caller:</b> Enable the feature code on caller side only.</li> <li><b>Allow Callee:</b> Enable the feature code on callee side only.</li> <li><b>Allow Both:</b> Enable the feature code on both caller and callee.</li> </ul> </li> </ul>
Disconnect	<ul style="list-style-type: none"> <li>• Default code: *0.</li> <li>• Enter the code during active call. It will disconnect the call.</li> <li>• Options               <ul style="list-style-type: none"> <li><b>Disable</b></li> <li><b>Allow Caller:</b> Enable the feature code on caller side only.</li> <li><b>Allow Callee:</b> Enable the feature code on callee side only.</li> <li><b>Allow Both:</b> Enable the feature code on both caller and callee.</li> </ul> </li> </ul>



Call Park	<ul style="list-style-type: none"> <li>• Default code: #72.</li> <li>• Enter the code during active call to park the call.</li> <li>• Options</li> </ul> <p><b>Disable</b></p> <p><b>Allow Caller:</b> Enable the feature code on caller side only.</p> <p><b>Allow Callee:</b> Enable the feature code on callee side only.</p> <p><b>Allow Both:</b> Enable the feature code on both caller and callee.</p>
Audio Mix Record	<ul style="list-style-type: none"> <li>• Default code: *3.</li> <li>• Enter the code followed by # or SEND to start recording the audio call and the UCM6200 will mix the streams natively on the fly as the call is in progress.</li> <li>• Options</li> </ul> <p><b>Disable</b></p> <p><b>Allow Caller:</b> Enable the feature code on caller side only.</p> <p><b>Allow Callee:</b> Enable the feature code on callee side only.</p> <p><b>Allow Both:</b> Enable the feature code on both caller and callee.</p>
<b>DND/Call Forward</b>	
Do Not Disturb (DND) Activate	<ul style="list-style-type: none"> <li>• Default code: *77.</li> </ul>
Do Not Disturb (DND) Deactivate	<ul style="list-style-type: none"> <li>• Default code: *78.</li> </ul>
Call Forward Busy Activate	<ul style="list-style-type: none"> <li>• Default Code: *90.</li> <li>• Enter the code and follow the voice prompt. Or enter the code followed by the extension to forward the call.</li> </ul>
Call Forward Busy Deactivate	<ul style="list-style-type: none"> <li>• Default Code: *91.</li> </ul>
Call Forward No Answer Activate	<ul style="list-style-type: none"> <li>• Default Code: *92.</li> <li>• Enter the code and follow the voice prompt. Or enter the code followed by the extension to forward the call.</li> </ul>
Call Forward No Answer Deactivate	<ul style="list-style-type: none"> <li>• Default Code: *93.</li> </ul>
Call Forward Unconditional Activate	<ul style="list-style-type: none"> <li>• Default Code: *72.</li> <li>• Enter the code and follow the voice prompt. Or enter the code followed by the extension to forward the call.</li> </ul>
Call Forward Unconditional Deactivate	<ul style="list-style-type: none"> <li>• Default Code: *73.</li> </ul>
<b>Feature Misc</b>	



Feature Code Digits Timeout	<ul style="list-style-type: none"> <li>• Default Setting: 1000.</li> <li>• Configure the maximum interval (in milliseconds) between the digits input to activate the feature code.</li> </ul>
Call Park	<ul style="list-style-type: none"> <li>• Default Extension: 700.</li> <li>• During an active call, initiate blind transfer and then enter this code to park the call.</li> </ul>
Parked Lots	<ul style="list-style-type: none"> <li>• Default Extension: 701-720.</li> <li>• These are the extensions where the calls will be parked, i.e., parking lots that the parked calls can be retrieved.</li> </ul>
Use Parklot as Extension	<ul style="list-style-type: none"> <li>• If checked, the parking lot number can be used as extension. The user can transfer the call to the parking lot number to park the call. Please note this parking lot number range might conflict with extension range.</li> </ul>
Parking Timeout (s)	<ul style="list-style-type: none"> <li>• Default setting: 300.</li> <li>• This is the timeout allowed for a call to be parked. After the timeout, if the call is not picked up, the extension who parks the call will be called back.</li> </ul>
<b>Feature Codes</b>	
Voicemail Access Code	<ul style="list-style-type: none"> <li>• Default Code: *98.</li> <li>• Enter *98 and follow the voice prompt. Or dial *98 followed by the extension and # to access the entered extension's voicemail box.</li> </ul>
My Voicemail	<ul style="list-style-type: none"> <li>• Default Code: *97.</li> <li>• Press *97 to access the voicemail box.</li> </ul>
Agent Pause	<ul style="list-style-type: none"> <li>• Default Code: *83.</li> <li>• Pause the agent in all call queues.</li> </ul>
Agent Unpause	<ul style="list-style-type: none"> <li>• Default Code: *84.</li> <li>• Unpause the agent in all call queues.</li> </ul>
Paging Prefix	<ul style="list-style-type: none"> <li>• Default Code: *81.</li> <li>• To page an extension, enter the code followed by the extension number.</li> </ul>
Intercom Prefix	<ul style="list-style-type: none"> <li>• Default Code: *80.</li> <li>• To intercom an extension, enter the code followed by the extension number.</li> </ul>

Blacklist Add	<ul style="list-style-type: none"> <li>• Default Code: *40.</li> <li>• To add a number to blacklist for inbound route, dial *40 and follow the voice prompt to enter the number.</li> </ul>
Blacklist Remove	<ul style="list-style-type: none"> <li>• Default Code: *41.</li> <li>• To remove a number from current blacklist for inbound route, dial *41 and follow the voice prompt to remove the number.</li> </ul>
Call Pickup on Ringing	<ul style="list-style-type: none"> <li>• Default Code: **.</li> <li>• To pick up a call for any extension xxxx, enter the code followed by the extension number xxxx.</li> </ul>
Pickup Extension	<ul style="list-style-type: none"> <li>• Default Code: *8.</li> <li>• This code is for the pickup group which can be assigned for each extension on the extension configuration page.</li> <li>• If there is an incoming call to an extension, the other extensions within the same pickup group can dial *8 directly to pick up the call.</li> </ul>
Direct Dial Voicemail Prefix	<ul style="list-style-type: none"> <li>• Default Code: *</li> <li>• This code is for the user to directly dial or transfer to an extension's voicemail.</li> <li>• For example, directly dial *5000 will have to call go into the extension 5000's voicemail. If the user would like to transfer the call to the extension 5000's voicemail, enter *5000 as the transfer target number.</li> </ul>
Call Completion Request	<ul style="list-style-type: none"> <li>• Default Code: *11</li> <li>• This code is for the user who wants to use Call Completion to complete a call.</li> </ul>
Call Completion Cancel	<ul style="list-style-type: none"> <li>• Default Code: *12</li> <li>• This code is for the user who wants to cancel Call Completion request.</li> </ul>
Enable Spy	Check this box to enable spy feature codes.
Listen Spy	This is the feature code to listen in on a call to monitor performance. Monitor's line will be muted, and neither party will hear from the monitor's extension. The default setting is *54.
Whisper Spy	This is the feature code to speak to one side of the call (for example, whisper to employees to help them handle a call). Only one side will be able to hear from the monitor's extension. The default setting is *55.

Barge Spy	This is the feature code to join in on the call to assist both parties. The default setting is *56.
Enable Inbound Multiple Mode	If enabled, user can switch between different inbound route modes with feature code. By default, this option is disabled.
Inbound Default Mode	This feature code is used to switch inbound route mode to default mode. The default setting is *61.
Inbound Mode 1	This feature code is used to switch inbound route mode to mode 1. The default setting is *62.

## CALL RECORDING

The UCM6200 allows users to record audio during the call. If "Auto Record" is turned on for an extension, ring group, call queue or trunk, the call will be automatically recorded when there is established call with it. Otherwise, please follow the instructions below to manually record the call.

1. Make sure the feature code for "Audio Mix Record" is configured and enabled.
2. After establishing the call, enter the "Audio Mix Record" feature code (by default it's \*3) followed by # or SEND to start recording.
3. To stop the recording, enter the "Audio Mix Record" feature code (by default it's \*3) followed by # or SEND again. Or the recording will be stopped once the call hangs up.
4. The recording file can be retrieved under Web GUI->**Status**->**CDR**. Click on  to play the recording or click on  to download the recording file.





No.	Start Time	Call From	Call To	Call Time	Talk Time	Status	Options
1	2013-07-03 17:55:04	6000	5001	0:00:18	0:00:15		  
2	2013-07-03 17:54:32	6000	5001	0:00:19	0:00:18		  
3	2013-07-03 17:53:11	6000	6300	0:00:11	0:00:11		  

Figure 153: Download Recording File from CDR Page

The above recorded call's recording files are also listed under the UCM6200 web GUI->CDR->**Recording Files**.



**Figure 154: Download Recording File from Recording Files Page**

## CALL PARK

The UCM6200 provides call park and call pickup features via feature code.

### PARK A CALL

There are two feature codes that can be used to park the call.

- Feature Maps->Call Park (Default code #72)  
During an active call, press #72 and the call will be parked. Parking lot number (default range 701 to 720) will be announced after parking the call.
- Feature Misc->Call Park (Default code 700)  
During an active call, initiate blind transfer (default code #1) and then dial 700 to park the call. Parking lot number (default range 701 to 720) will be announced after parking the call.

### RETRIEVE THE PARKED CALL

To retrieve the parked call, simply dial the parking lot number and the call will be established. If a parked call is not retrieved after the timeout, the original extension who parks the call will be called back.

## ENABLE SPY

If “Enable Spy” option is enabled, feature codes for Listen Spy, Whisper Spy and Barge Spy are available for users to dial from any extension to perform the corresponding actions.

Assume a call is on-going between extension A and extension B, user could dial the feature code from extension C to listen on their call (\*54 by default), whisper to one side (\*55 by default), or barge into the call (\*56 by default). Then the user will be asked to enter the number to call, which should be either side of the active call, extension A or B in this example.



**Caution:**

“Enable Spy” allows any user to listen to any call by feature codes. This may result in the leakage of user privacy.

---



## INTERNAL OPTIONS

This section describes internal options that haven't been mentioned in previous sections yet. The settings in this section can be applied globally to the UCM6200, including general configurations, jitter buffer, RTP settings, ports config and STUN monitor. The options can be accessed via Web GUI->**PBX->Internal Options-> General**.

### INTERNAL OPTIONS/GENERAL

**Table 76: Internal Options/General**

General Preferences	
Global OutBound CID	Configure the global CallerID used for all outbound calls when no other CallerID is defined with higher priority. If no CallerID is defined for extension or trunk, the global outbound CID will be used as CallerID.
Global OutBound CID Name	Configure the global CallerID Name used for all outbound calls. If configured, all outbound calls will have the CallerID Name set to this name. If not, the extension's CallerID Name will be used.
Operator Extension	Specify the operator extension, which will be dialed when users press 0 to exit voicemail application. The operator extension can also be used in IVR option.
Ring Timeout	Configure the number of seconds to ring an extension before the call goes to the user's voicemail box. The default setting is 60.  <b>Note:</b> This is the global value used for each extension if "Ring Timeout" field is left empty on the extension configuration page.
Call Duration Limit	Configure the maximum duration of call-blocking.
Record Prompt	If enabled, users will hear voice prompt before recording is started or stopped. For example, before recording, the UCM6200 will play voice prompt "The call will be recorded". The default setting is "No".
Extension Preferences	
Enforce Strong Passwords	If enabled, strong password will be enforced for the password created on the UCM6200. The default setting is enabled.  Strong Password Rules: 1. Password for voicemail, voicemail group, outbound route, DISA, call queue and conference requires non-repetitive and non-sequential



	<p>digits, with a minimum length of 4 digits. Repetitive digits pattern (such as 0000, 1111, 1234, 2345, and etc), or common digits pattern (such as 111222, 321321 and etc) are not allowed to be configured as password.</p> <p>2. Password for extension registration, web GUI admin login, LDAP and LDAP sync requires alphanumeric characters containing at least two categories of the following, with a minimum length of 4 characters.</p> <ul style="list-style-type: none"> <li>• Numeric digits</li> <li>• Lowercase alphabet characters</li> <li>• Uppercase alphabet characters</li> <li>• Special characters</li> </ul>
Enable Random Password	<p>If enabled, random password will be generated when the extension is created. The default setting is "Yes". It is recommended to enable it for security purpose.</p>
Enable Auto Email To User	<p>If enabled, UCM6200 will send Email notification to user automatically after editing extension settings or adding a new extension.</p>
Disable Extension Range	<p>If set to "Yes", users could disable the extension range pre-configured/configured on the UCM6200. The default setting is "No".</p> <p><b>Note:</b> It is recommended to keep the system assignment to avoid inappropriate usage and unnecessary issues.</p>
Extension Ranges	<p>The default extension range assignment is:</p> <ul style="list-style-type: none"> <li>• User Extensions: 1000-6299 User Extensions is referring to the extensions created under web UI-&gt;<b>PBX-&gt;Basic/Call Routes-&gt;Extensions</b> page.</li> <li>• Pick Extensions: 4000-4999 This refers to the extensions that can be manually picked from end device when being provisioned by the UCM6200. There are two related options in zero config page-&gt;Auto Provision Settings, "Pick Extension Segment" and "Enable Pick Extension". If "Enable Pick Extension" under zero config settings is selected, the extension list defined in "Pick Extension Segment" will be sent out to the device after receiving the device's request. This "Pick Extension Segment" should be a subset of the "Pick Extensions" range here. This feature is for the GXP series phones that support selecting extension to be provisioned via phone's LCD.</li> </ul>

	<ul style="list-style-type: none"> <li>• Auto Provision Extensions: 5000-6299 This sets the range for "Zero Config Extension Segment" which is the extensions can be assigned on the UCM6200 to provision the end device.</li> <li>• Conference Extensions: 6300-6399</li> <li>• Ring Group Extensions: 6400-6499</li> <li>• Queue Extensions: 6500-6599</li> <li>• Voicemail Group Extensions: 6600-6699</li> <li>• IVR Extensions: 7000-7100</li> <li>• Dial By Name Extensions: 7101-7199</li> <li>• Fax Extensions: 7200-8200</li> </ul>
--	--

## INTERNAL OPTIONS/JITTER BUFFER

**Table 77: Internal Options/Jitter Buffer**

SIP Jitter Buffer	
Enable Jitter Buffer	Select to enable jitter buffer on the sending side of the SIP channel. The default setting is "No".
Jitter Buffer Size	Configure the time (in ms) to buffer. This is the jitter buffer size used in "Fixed" jitter buffer, or used as the initial time for "adaptive" jitter buffer. The default setting is 100.
Max Jitter Buffer	Configure the maximum time (in ms) to buffer for "Adaptive" jitter buffer implementation, or used as the jitter buffer size for "Fixed" jitter buffer implementation. The default setting is 200.
Implementation	Configure the jitter buffer implementation on the sending side of a SIP channel. The default setting is "Fixed". <ul style="list-style-type: none"> <li>• <b>Fixed</b> The size is always equal to the value of "Max Jitter Buffer".</li> <li>• <b>Adaptive</b> The size is adjusted automatically and the maximum value equals to the value of "Max Jitter Buffer".</li> </ul>

## INTERNAL OPTIONS/RTP SETTINGS

**Table 78: Internal Options/RTP Settings**

RTP Start	Configure the RTP port starting number. The default setting is 10000.
RTP End	Configure the RTP port ending address. The default setting is 20000.
Strict RTP	Configure to enable or disable strict RTP protection. If enabled, RTP packets that do not come from the source of the RTP stream will be dropped. The default setting is "Disable".
RTP Checksums	Configure to enable or disable RTP Checksums on RTP traffic. The default setting is "Disable".
ICE Support	<p>Configure whether to support ICE. The default setting is enabled.</p> <p>ICE is the integrated use of STUN and TURN structure to provide reliable VoIP or video calls and media transmission, via a SIP request/ response model or multiple candidate endpoints exchanging IP addresses and ports, such as private addresses and TURN server address.</p>
STUN Server	<p>Configure STUN server address. STUN protocol is a Client/Server and also a Request/Response protocol. It's used to check the connectivity between the two terminals, such as maintaining a NAT binding entries keep-alive agreement. The default STUN Server is stun.ipvideotalk.com.</p> <p>Valid format:            [(hostname   IP-address) [:' port]            The default port number is 3478 if not specified.</p>

## INTERNAL OPTIONS/PAYLOAD

The UCM6200 payload type for audio codecs and video codes can be configured here.

**Table 79: Internal Options/Payload**

AAL2-G.726	Configure payload type for ADPCM (G.726, 32kbps, AAL2 codeword packing). The default setting is 112.
DTMF	Configured payload type for DTMF. The default setting is 101.

G.721 Compatible	Configure to enable/disable G.721 compatible. The default setting is Yes.
G.726	Configure the payload type for G.726 if "G.721 Compatible" is disabled. The default setting is 111.
iLBC	Configure the payload type for iLBC. The default setting is 97.
H.264	Configure the payload type for H.264. The default setting is 99.
H.263P	Configure the payload type for H.263+. The default setting is 100 103.
VP8	Configure the payload type for VP8. The default settings is 108.



## IAX SETTINGS

The UCM6200 IAX global settings can be accessed via Web GUI->**PBX**->**IAX Settings**.

### IAX SETTINGS/GENERAL

**Table 80: IAX Settings/General**

Bind Port	Configure the port number that the IAX2 will be allowed to listen to. The default setting is 4569.
Bind Address	Configure the address that the IAX2 will be forced to bind to. The default setting is 0.0.0.0, which means all addresses.
IAX1 Compatibility	Select to configure IAX1 compatibility. The default setting is "No".
No Checksums	If selected, UDP checksums will be disabled and no checksums will be calculated/checked on systems supporting this features. The default setting is "No".
Delay Reject	If enabled, the IAX2 will delay the rejection of calls to avoid DOS. The default setting is "No".
ADSI	Select to enable ADSI phone compatibility. The default setting is "No".
Music On Hold Interpret	Specify which Music On Hold class this channel would like to listen to when being put on hold. This music class is only effective if this channel has no music class configured and the bridged channel putting the call on hold has no "Music On Hold Suggest" setting.
Music On Hold Suggest	Specify which Music On Hold class to suggest to the bridged channel when putting the call on hold.
Bandwidth	Configure the bandwidth for IAX settings. The default setting is "Low".

### IAX SETTINGS/REGISTRATION

**Table 81: IAX Settings/Registration**

IAX Registration Options	
Min Reg Expire	Configure the minimum period (in seconds) of registration. The default setting is 60.
Max Reg Expire	Configure the maximum period (in seconds) of registration. The default setting is 3600.
IAX Thread Count	Configure the number of IAX helper threads. The default setting is 10.
IAX Max Thread Count	Configure the maximum number of IAX threads allowed. The default setting is 100.

Auto Kill	If set to "yes", the connection will be terminated if ACK for the NEW message is not received within 2000ms. Users could also specify number (in milliseconds) in addition to "yes" and "no". The default setting is "yes".
Authentication Debugging	If enabled, authentication traffic in debugging will not show. The default setting is "No".
Codec Priority	Configure codec negotiation priority. The default setting is "Reqonly". <ul style="list-style-type: none"> <li>• Caller Consider the callers preferred order ahead of the host's.</li> <li>• Host Consider the host's preferred order ahead of the caller's.</li> <li>• Disabled Disable the consideration of codec preference all together.</li> <li>• Reqonly This is almost the same as "Disabled", except when the requested format is not available. The call will only be accepted if the requested format is available.</li> </ul>
Type of Service	Configure ToS bit for preferred IP routing.
<b>IAX Trunk Options</b>	
Trunk Frequency	Configure the frequency of trunk frames (in milliseconds). The default setting is 20.
Trunk Time Stamps	If enabled, time stamps will be attached to trunk frames. The default setting is "No".

## IAX SETTINGS/STATIC DEFENSE

**Table 82: IAX Settings/Static Defense**

Call Token Optional	Enter a single IP address (e.g., 11.11.11.11) or a range of IP addresses (11.11.11.11/22.22.22.22) for which call token validation is not required.
Max Call Numbers	Configure the maximum number of calls allowed for a single IP address.
Max Unvalidated Call Numbers	Configure the maximum number of unvalidated calls for all IP addresses.
Call Number Limits	Configure to limit the number of calls for a give IP address of IP range.
IP or IP Range	Enter the IP address (11.11.11.11) or a range of IP addresses (11.11.11.11/22.22.22.22) to be considered for call number limits.

## SIP SETTINGS

The UCM6200 SIP global settings can be accessed via Web GUI->**PBX**->**SIP Settings**.

### SIP SETTINGS/GENERAL

**Table 83: SIP Settings/General**

Realm For Digest Authentication	Configure the host name or domain name for the UCM6200. Realms MUST be globally unique according to RFC3261. The default setting is Grandstream.
Bind UDP Port	Configure the UDP port used for SIP. The default setting is 5060.
Bind IP Address	Configure the IP address to bind to. The default setting is 0.0.0.0, which means binding to all addresses.
Allow Guest Calls	<p>If enabled, the UCM6200 allows unauthorized INVITE coming into the PBX and the call can be made. The default setting is "No".</p> <p><b>Warning:</b> Please be aware of the potential security risk when enabling "Allow Guest Calls" as this will allow any user with the UCM6200 address to dial into the UCM6200.</p>
Allow Transfer	If set to "No", all transfers initiated by the endpoint in the UCM6200 will be disabled (unless enabled in peers or users). The default setting is "Yes".
MWI From	When sending MWI NOTIFY requests, this value will be used in the "From:" header as the "name" field. If no "From User" is configured, the "user" field of the URI in the "From:" header will be filled with this value.

### SIP SETTINGS/MISC

**Table 84: SIP Settings/Misc**

Outbound SIP Registrations	
Register Timeout	Configure the register retry timeout (in seconds). The default setting is 20.
Register Attempts	Configure the number of registration attempts before the UCM6200 gives up. The default setting is 0, which means the UCM6200 will keep trying until the server side accepts the registration request.
Video	
Max Bit Rate (kb/s)	Configure the maximum bit rate (in kb/s) for video calls. The default setting is 384.



Support SIP Video	Select to enable video support in SIP calls. The default setting is "Yes".
Reject Non-Matching INVITE	If enabled, when rejecting an incoming INVITE or REGISTER request, the UCM6200 will always reject with "401 Unauthorized" instead of notifying the requester whether there is a matching user or peer for the request. This reduces the ability of an attacker to scan for valid SIP usernames. The default setting is "No".

## SIP SETTINGS/SESSION TIMER

**Table 85: SIP Settings/Session Timer**

Session Timers	Select the session timer mode. The default setting is "Accept". The options are: <ul style="list-style-type: none"> <li>• Originate Always request and run session timer.</li> <li>• Accept Run session timer only when requested by other UA.</li> <li>• Refuse Do not run session timer.</li> </ul>
Session Expire	Configure the maximum session refresh interval (in seconds). The default setting is 1800.
Min SE	Configure the minimum session refresh interval (in seconds). The default setting is 90.
Session Refresher	Select the session refresher to be UAC or UAS. The default setting is UAC.

## SIP SETTINGS/TCP AND TLS

**Table 86: SIP Settings/TCP and TLS**

TCP Enable	Configure to allow incoming TCP connections with the UCM6200. The default setting is "No".
TCP Bind Address	Configure the IP address for TCP server to bind to. 0.0.0.0 means binding to all interfaces. The port number is optional. If not specified, 5060 will be used.
TLS Enable	Configure to allow incoming TLS connections with the UCM6200. The default setting is "No".
TLS Bind Address	Configure the IP address for TLS server to bind to. 0.0.0.0 means binding to all interfaces. The port number is optional. If not specified, 5061 will be used.

	<p><b>Note:</b></p> <p>The IP address must match the common name (hostname) in the certificate. Please do not bind a TLS socket to multiple IP addresses. For details on how to construct a certificate for SIP, please refer to the following document:</p> <p><a href="http://tools.ietf.org/html/draft-ietf-sip-domain-certs">http://tools.ietf.org/html/draft-ietf-sip-domain-certs</a></p>
TLS Client Protocol	Select the TLS protocol for outbound client connections. The default setting is TLSv1.
TLS Do Not Verify	If enabled, the TLS server's certificate won't be verified when acting as a client. The default setting is "Yes".
TLS Self-Signed CA	<p>This is the CA certificate if the TLS server being connected to requires self-signed certificate, including server's public key. This file will be renamed as "TLS.ca" automatically.</p> <p><b>Note:</b></p> <p>The size of the uploaded ca file must be under 2MB.</p>
TLS Cert	<p>This is the Certificate file (*.pem format only) used for TLS connections. It contains private key for client and signed certificate for the server. This file will be renamed as "TLS.pem" automatically.</p> <p><b>Note:</b></p> <p>The size of the uploaded certificate file must be under 2MB.</p>
TLS CA Cert	<p>This file must be named with the CA subject name hash value. It contains CA's (Certificate Authority) public key, which is used to verify the accessed servers.</p> <p><b>Note:</b></p> <p>The size of the uploaded CA certificate file must be under 2MB.</p>
TLS CA List	Display a list of files under the CA Cert directory.

## SIP SETTINGS/NAT

**Table 87: SIP Settings/NAT**

External Host	Configure a static IP address and port (optional) used in outbound SIP messages if the UCM6200 is behind NAT. If it is a host name, it will only be looked up once.
Use IP address in SDP	If enabled, the SDP connection will use the IP address resolved from the external host.

External TCP Port	Configure the externally mapped TCP port when the UCM6200 is behind a static NAT or PAT.
External TLS Port	Configures the externally mapped TLS port when UCM6200 is behind a static NAT or PAT.
Local Network Address	Specify a list of network addresses that are considered inside of the NAT network. Multiple entries are allowed. If not configured, the external IP address will not be set correctly.  A sample configuration could be as follows: 192.168.0.0/16

## SIP SETTINGS/TOS


**Table 88: SIP Settings/ToS**

ToS For SIP	Configure the Type of Service for SIP packets. The default setting is None.
ToS For RTP Audio	Configure the Type of Service for RTP audio packets. The default setting is None.
ToS For RTP Video	Configure the Type of Service for RTP video packets. The default setting is None.
Default Incoming/Outgoing Registration Time	Configure the default duration (in seconds) of incoming/outgoing registration. The default setting is 120.
Max Registration/Subscription Time	Configure the maximum duration (in seconds) of incoming registration and subscription allowed by the UCM6200. The default setting is 3600.
Min Registration/Subscription Time	Configure the minimum duration (in seconds) of incoming registration and subscription allowed by the UCM6200. The default setting is 60.
Enable Relaxed DTMF	Select to enable relaxed DTMF handling. The default setting is "No".
DTMF Mode	Select DTMF mode to send DTMF. The default setting is RFC2833. If "Info" is selected, SIP INFO message will be used. If "Inband" is selected, 64-kbit codec PCMU and PCMA are required. When "Auto" is selected, "RFC2833" will be used if offered, otherwise "Inband" will be used. The default setting is "RFC2833".
RTP Timeout	During an active call, if there is no RTP activity within the timeout (in seconds), the call will be terminated. The default setting is no timeout.  <b>Note:</b> This setting doesn't apply to calls on hold.
RTP Hold Timeout	When the call is on hold, if there is no RTP activity within the timeout (in seconds), the call will be terminated. This value of RTP Hold Timeout


	should be larger than RTP Timeout. The default setting is no timeout.
Trust Remote Party ID	Configure whether the Remote-Party-ID should be trusted. The default setting is "No".
Send Remote Party ID	Configure whether the Remote-Party-ID should be sent or not. The default setting is "No".
Generate In-Band Ringing	<p>Configure whether the UCM6200 should generate inband ringing or not. The default setting is "Never".</p> <ul style="list-style-type: none"> <li>• Yes: The UCM6200 will send 180 Ringing followed by 183 Session Progress and in-band audio.</li> <li>• No: The UCM6200 will send 180 Ringing if 183 Session Progress has not been sent yet. If audio path is established already with 183 then send in-band ringing.</li> <li>• Never: Whenever ringing occurs, the UCM6200 will send 180 Ringing as long as 200OK has not been set yet. Inband ringing will not be generated even the end point device is not working properly.</li> </ul>
Server User Agent	Configure the user agent string for the UCM6200.
Send Compact SIP Headers	If enabled, compact SIP headers will be sent. The default setting is "No".
100rel	Configure the 100rel setting on UCM6200. The default setting is "Yes".



## PORTS CONFIG


The analog hardware (FXS port and FXO port) on the UCM6200 will be listed in this page. Click on  to edit signaling preference for FXS port or configure ACIM settings for FXO port.

Select "Loop Start" or "Kewl Start" for each FXS port. And then click on "Update" to save the change.



**Figure 155: FXS Ports Signaling Preference**

For FXO port, users could manually enter the ACIM settings by selecting the value from dropdown list for each port. Or users could click on "Detect" for the UCM6200 to automatically detect the ACIM value. The detecting value will be automatically filled into the settings.



**Figure 156: FXO Ports ACIM Settings**

**Table 89: Internal Options/Ports Config**

Tone Region	Select country to set the default tones for dial tone, busy tone, ring tone and etc to be sent from the FXS port. The default setting is "United States of America (USA)".
<b>Advanced Settings</b>	
FXO Opermode	Select country to set the On Hook Speed, Ringer Impedance, Ringer

	<p>Threshold, Current Limiting, TIP/RING voltage adjustment, Minimum Operational Loop Current, and AC Impedance as predefined for your country's analog line characteristics. The default setting is "United States of America (USA)".</p>
FXS Opermode	<p>Select country to set the On Hook Speed, Ringer Impedance, Ringer Threshold, Current Limiting, TIP/RING voltage adjustment, Minimum Operational Loop Current, and AC Impedance as predefined for your country's analog line characteristics. The default setting is "United States of America (USA)".</p>
FXS TISS Override	<p>Configure to enable or disable override Two-Wire Impedance Synthesis (TISS). The default setting is No.</p> <p>If enabled, users can select the impedance value for Two-Wire Impedance Synthesis (TISS) override. The default setting is 600Ω.</p>
PCMA Override	<p>Select the codec to be used for analog lines. North American users should choose PCMU. All other countries, unless already known, should be assumed to be PCMA. The default setting is PCMU.</p> <p><b>Note:</b> This option requires system reboot to take effect.</p>
Boost Ringer	<p>Configure whether normal ringing voltage (40V) or maximum ringing voltage (89V) for analog phones attached to the FXS port is required. The default setting is "Normal".</p>
Fast Ringer	<p>Configure to increase the ringing speed to 25HZ. This option can be used with "Low Power" option. The default setting is "Normal".</p>
Low Power	<p>Configure the peak voltage up to 50V during "Fast Ringer" operation. This option is used with "Fast Ringer". The default setting is "Normal".</p>
Ring Detect	<p>If set to "Full Wave", false ring detection will be prevented for lines where Caller ID is sent before the first ring and proceeded by a polarity reversal, as in UK. The default setting is "Standard".</p>
FXS MWI Mode	<p>Configure the type of Message Waiting Indicator on FXS lines. The default setting is "FSK".</p> <ul style="list-style-type: none"> <li>• FSK: Frequency Shift Key Indicator</li> <li>• NEON: Light Neon Bulb Indicator.</li> </ul>

## VALUE-ADDED FEATURES

### FAX SENDING

The UCM6200 supports sending Fax via web UI access. This feature can be found on web UI->**PBX->Value-added Features->Fax Sending** page. In order to send fax, pre-setup for analog trunk and outbound route is required. Please refer to **[ANALOG TRUNKS]**, **[VOIP TRUNKS]** and **[OUTBOUND ROUTES]** sections for configuring analog trunk and outbound route.

After making sure analog trunk or VoIP Trunk is setup properly and UCM6200 can reach out to PSTN numbers via the trunk, on Fax Sending page, enter the fax number and upload the file to be faxed. Then click on “Send” to start. The progress of sending fax will be displayed in web UI. Users can also view the sending history is in the same web page.




Figure 157: Fax Sending in Web UI

### ANNOUNCEMENTS CENTER

The UCM6200 supports Announcements Center feature which allows users to pre-record and store voice message into UCM6200 with a specified code. The users can also create group with specified extensions. When the code and the group number are dialed together in the combination of **code + group number**, the specified voice message is sent to all group members and only extensions in the group will hear the voice message.





**Figure 158: Announcements Center**

## ANNOUNCEMENTS CENTER SETTINGS

**Table 90: Announcements Center Settings**

Name	Configure a name for the newly created Announcements Center to identify this announcement center.
Code	Enter a code number for the custom prompt. This code will be used in combination with the group number. For example, if the code is 55, and group number is 666. The user can dial 55666 to send prompt 55 to all members in group 666.  <b>Note:</b> The combination number must not conflict with any number in the system such as extension number or conference number.
Custom Prompt	This option is to set a custom prompt as an announcement to notify group members. The file can be uploaded from page 'Custom Prompt'. Click 'Prompt' to add additional record.
Ring Timeout	Configure the ring timeout for the group members. The default value is 30 seconds.

## GROUP SETTINGS


**Table 91: Group Settings**

Name	Configure a name for the newly created group to identify the group.
------	---

Number	<p>Configure the group number. The group number is used in combination with the code. For example, if group number is 666, and code is 55. The user can dial 55666 to send prompt 55 to all members in group 666.</p> <p><b>Note:</b> The combination number must not conflict with any number in the system such as extension number or conference number.</p>
--------	---

Announcements Center feature can be found under **web UI->PBX->Value-added Features->Announcements Center**. The following example demonstrates the usage of this feature.

1. Click Create New Group to create new group.
2. Give a name to the newly created group.
3. Create a group number which is used with code to send voice message.
4. Select the extensions to be included in the group, who will receive the voice message.




**Figure 159: Announcements Center Group Configuration**

In this example, group “Test” has number 666. Extension 1000, 1001 and 1002 are in this group.

5. Click Create New Announcements Center to create a new Announcement Center.
6. Give a name to the newly created Announcement Center.
7. Specify the code which will be used with group number to send the voice message to.
8. Select the message that will be used by the code from the Custom Prompt drop down menu. To create

a new Prompt, please click “Prompt” link and follow the instructions in that page.




The dialog box titled "Create New Announcements Center" contains the following fields and controls:

- Name:** Text input field containing "Test".
- Code:** Text input field containing "55".
- Custom Prompt:** A dropdown menu showing "Test.gsm" and a blue "Prompt" link to its right.
- Ring Timeout:** Text input field containing "30".
- At the bottom, there are two buttons: "Cancel" (grey) and "Save" (orange).

**Figure 160: Announcements Center Code Configuration**

Code and Group number are used together to direct specified message to the target group. All extensions in the group will receive the message. For example, we can send code 55 to group 666 by dialing 55666 from any extension registered to the UCM6200. All the members in group 666 which are extension 1000, 1001 and 1002 will receive this voice message after they pick up the call.



The screenshot shows the "Announcements Center" configuration page in a web interface. It features two main sections: "Announcements Center" and "Group".

**Announcements Center Section:**

Code	Name	Options
55	Test	[Edit] [Delete]

Below the table, there is a search bar with "Total: 1", "Show 1/1", and a "Go to:" field with a "Go" button. Action buttons "First", "Prev", "Next", and "Last" are also present.

**Group Section:**

Number	Name	Members	Options
666	Test	1000,1001,1002	[Edit] [Delete]

Similar to the first section, it includes a search bar with "Total: 1", "Show 1/1", and a "Go to:" field with a "Go" button, along with "First", "Prev", "Next", and "Last" action buttons.

**Figure 161: Announcements Center Example**

## STATUS AND REPORTING

### PBX STATUS

The UCM6200 monitors the status for Trunks, Extensions, Queues, Conference Rooms, Interfaces and Parking lot. It presents administrators the real time status in different sections under web GUI->**Status->PBX Status**.



Figure 162: Status->PBX Status

### TRUNKS

Users could see all the configured trunk status in this section.

Status	Trunks	Type	Username	Port/Hostname/IP
Unmonitored	Grandstream	SIP		192.168.40.140
Unavailable	Trunk1	Analog		Ports 1


Figure 163: Trunk Status

Table 92: Trunk Status

Status	Display trunk status.
	<ul style="list-style-type: none"> <li>Analog trunk status:                             <ul style="list-style-type: none"> <li><b>Available</b></li> <li><b>Busy</b></li> <li><b>Unavailable</b></li> <li><b>Unknown Error</b></li> </ul> </li> <li>SIP Peer trunk status:                             <ul style="list-style-type: none"> <li><b>Unreachable</b>: The hostname cannot be reached.</li> </ul> </li> </ul>


	<p><b>Unmonitored:</b> QUALIFY feature is not turned on to be monitored.</p> <p><b>Reachable:</b> The hostname can be reached.</p> <ul style="list-style-type: none"> <li>SIP Register trunk status:           <ul style="list-style-type: none"> <li><b>Registered</b></li> <li><b>Unrecognized Trunk</b></li> </ul> </li> </ul>
Trunks	Display trunk name
Type	Display trunk Type: <ul style="list-style-type: none"> <li>Analog</li> <li>SIP</li> <li>IAX</li> </ul>
Username	Display username for this trunk.
Port/Hostname/IP	Display Port for analog trunk, or Hostname/IP for VoIP (SIP/IAX) trunk.

Other operations are also available in trunk status section:

- Click on "Trunks", the web page will redirect to trunk configuration page which can also be accessed via web GUI->**PBX->Basic/Call Routes->Analog Trunks**.
- Click on  to refresh the trunk status.
- Click on [ + ] to expand the status detail table.
- Click on [ - ] to hide the status detail table.

## EXTENSIONS





Users could see all the configured extension status in this section.










Status	Extension	Name/Label	Message	Type
<span style="color: green;">●</span>	1000	John Doe	Messages: 0/0/0	SIP
<span style="color: green;">●</span>	1001	Jane Doe	Messages: 0/0/0	SIP
<span style="color: grey;">●</span>	1002		Messages: 0/0/0	SIP

Figure 164: Extension Status

**Table 93: Extension Status**


Status	<p>Display extension number (including feature code). The color indicator has the following definitions.</p> <ul style="list-style-type: none"> <li> Green: Free</li> <li> Blue: Ringing</li> <li> Yellow: In Use</li> <li> Grey: Unavailable</li> </ul>
Extension	Display the extension number.
Name/Label	First name and last name of the extension.
Message	<p>Display message status for the extension.</p> <p>Example: 2/4/1</p> <p>Description: There are 2 urgent messages, 4 messages in total and 1 message that has been already read.</p>
Type	<p>Displays extension type.</p> <ul style="list-style-type: none"> <li>SIP User</li> <li>IAX User</li> <li>Analog User</li> <li>Ring Groups</li> <li>Voicemail Groups</li> </ul>

Other operations are also available in extension status section:

- Click on "Extensions", the web page will redirect to extension configuration page which can also be accessed via web GUI->**PBX->Basic/Call Routes->Extensions**.
- Click on  to refresh the extension status.
- Click on one of the tabs       to display the corresponding extensions accordingly.
- Click on [ + ] to expand the status detail table.
- Click on [ - ] to hide the status detail table.

## QUEUES





Users could see all the configured call queue status in this section. The following figure shows the call queue 6500 being in used.



**Figure 165: Queue Status**


The current call status (caller ID, duration), agent status, service level, calls summary (completed/abandoned) are shown for the call queue. The agent status is defined as below.

**Table 94: Agent Status**

	The agent is available/idle.
	The agent is ringing.
	The agent is talking/busy.
	The agent has been logged out.

On the UCM6200, **Service Level** is defined as the percentage of high-quality calls over all calls in the call queue, where high-quality call means calls answered within 10 seconds.

Other operations are also available in queue status section:

- Click on "Queues", the web page will redirect to call queue configuration page which can also be accessed via web GUI->**PBX->Call Features->Call Queue**.
- Click on  to refresh the call queue status.
- Click on [ + ] to expand the call queue detail.
- Click on [ - ] to hide the call queue detail.


## CONFERENCE ROOMS

Users could see all the conference room status in this section. It shows all the configured conference rooms, current users, call duration for each user and conference call.

Conference Rooms 				[ - ]
6300 <b>3 Users</b>				[ - ]
0:37		6000		0:37
		6005		0:36
		6007		0:16
6301 <b>Not In Use</b>				[ + ]

**Figure 166: Conference Room Status**

Other operations are also available in conference room status section:

- Click on "Conference Rooms", the web page will redirect to conference room configuration page which can also be accessed via web GUI->**PBX->Call Features->Conference**.
- Click on  to refresh the conference room status.
- Click on [ + ] to expand the conference room details.
- Click on [ - ] to hide the conference room details.





## INTERFACES STATUS

This section displays interface/port connection status on the UCM6200. The following example shows the interface status for UCM6204 with USB, WAN port, FXS1, FXS2 and FXO1 connected.









Interfaces Status 				[ - ]
USB		SD Card		
LAN		WAN		
FXS	 			
FXO	   			

**Figure 167: UCM6204 Interfaces Status**


**Table 95: Interface Status Indicators**

	USB connected.
	USB disconnected.
	SD Card connected.
	SD Card disconnected.



	LAN/WAN connected.
	LAN/WAN not configured.
	LAN/WAN disconnected.
	FXS/FXO connected.
	FXS/FXO waiting.
	FXS/FXO busy.
	FXS/FXO not configured.
	FXS/FXO disconnected.

Other operations are also available in interface status section:

- Click on "Interfaces Status", the web page will redirect to ports configuration page which can also be accessed via web GUI->**PBX->Internal Options->Ports Config**.
- Click on  to refresh the interface status.
- Click on [ + ] to expand the interface details.
- Click on [ - ] to hide the interface details.

## PARKING LOT

The UCM6200 supports call park using feature code. When there is call being parked, this section will display the parking lot status.

Parking Lot 				[-]
Caller ID	Channel	Extension	Timeout	
6010	SIP/6010-00000050	701	96	
6005	SIP/6005-00000052	702	113	


Figure 168: Parking Lot Status

Table 96: Parking Lot Status

Caller ID	Display the caller ID who parks the call.
Channel	Display channel for the call park.
Extension	Display the parking lot number where the call is parked/retrieved.
Timeout	Display timeout (in seconds) for the parked call. The status page will dynamically update this timer from 120 seconds (default) to 0. When the timer

reaches 0, the caller who parks the call will be called back.

Other operations are also available in parking lot status section:

- Click on "Parking Lot", the web page will redirect to feature codes page which can also be accessed via web GUI->**PBX->Internal Options->Feature Codes**.
- Click on  to refresh the parking lot status.
- Click on [ + ] to expand the parking lot details.
- Click on [ - ] to hide the parking details.

## SYSTEM STATUS

The UCM6200 system status can be accessed via Web GUI->**Status->System Status**, which displays the following system information.

- **General**
- **Network**
- **Storage Usage**
- **Resource Usage**

### GENERAL

Under Web GUI->**Status->System Status->General**, users could check the hardware and software information for the UCM6200. Please see details in the following table.

**Table 97: System Status->General**

Status ->System Status -> General	
Model	Product model.
Part Number	Product part number.
System Time	Current system time. The current system time is also available on the upper right of each web page.
Up Time	System up time since the last reboot.
Boot	Boot version.
Core	Core version.
Base	Base version.
Program	Program version. This is the main software release version.

Recovery	Recovery version.
----------	-------------------

## NETWORK

Under Web GUI->**Status->System Status->Network**, users could check the network information for the UCM6200. Please see details in the following table.

**Table 98: System Status->Network**

Status -> System Status -> Network	
MAC Address	Global unique ID of device, in HEX format. The MAC address can be found on the label coming with original box and on the label located on the bottom of the device.
IP Address	IP address.
Gateway	Default gateway address.
Subnet Mask	Subnet mask address.
DNS Server	DNS Server address.

## STORAGE USAGE

Users could access the storage usage information from web UI->**Status->System Status->Storage Usage**. It shows the available and used space for the following partitions.

- Configuration partition  
This partition contains PBX system configuration files and service configuration files.
- Data partition  
Voicemail, recording files, IVR file, Music on Hold files and etc.
- USB disk  
USB disk will display if connected.
- SD Card  
SD Card will display if connected.




Figure 169: System Status->Storage Usage

**RESOURCE USAGE**

When configuring and managing the UCM6200, users could access resource usage information to estimate the current usage and allocate the resources accordingly. Under web UI->**Status->System Status->Resource Usage**, the current CPU usage and Memory usage are shown in the pie chart.




Figure 170: System Status->Resource Usage

## SYSTEM EVENTS

The UCM6200 can monitor important system events, log the alerts and send Email notifications to the system administrator.

### ALERT EVENTS LIST

The system alert events list can be found under Web GUI->**Status->System Events->Alert Events List**. The following event are currently supported on the UCM6200 which will have alert and/or Email generated if occurred:

**Disk Usage**

**Modify Admin Password**

**Memory Usage**

**System Reboot**

**System Update**

**System Crash**

**Register SIP Failed**

**Register SIP Trunk Failed**

**Restore Config**

**User Login Success**

**User Login Failed**

**SIP Internal Call Failure**

**SIP Outgoing Call through Trunk Failure**


**Fail2ban Blocking**

**SIP Lost Registration**

**SIP Peer Trunk Status**

Click on  to configure the parameters for each event. See examples below.

1. Disk Usage.



**Alert Settings: Disk Usage**


minute(s)

%

Figure 171: System Events->Alert Events Lists: Disk Usage

- **Detect Cycle:** The UCM6200 will perform the internal disk usage detection based on this cycle. Users can enter the number and then select second(s)/minute(s)/hour(s)/day(s) to configure the cycle.
- **Alert Threshold:** If the detected value exceeds the threshold (in percentage), the UCM6200 system will send the alert.

## 2. Memory Usage




The screenshot shows a dialog box titled "Alert Settings: Memory Usage". It contains two configuration fields: "Detect Cycle" with a value of "10" and a unit dropdown set to "second(s)", and "Alert Threshold" with a value of "80" and a percentage sign. At the bottom, there are "Cancel" and "Save" buttons.

Figure 172: System Events->Alert Events Lists: Memory Usage

- **Detect Cycle:** The UCM6200 will perform the memory usage detection based on this cycle. Users can enter the number and then select second(s)/minute(s)/hour(s)/day(s) to configure the cycle.
- **Alert Threshold:** If the detected value exceeds the threshold (in percentage), the UCM6200 system will send the alert.

## 3. System Reboot



The screenshot shows a dialog box titled "Alert Settings: System Reboot". It contains one configuration field: "Detect Cycle" with a value of "1" and a unit dropdown set to "minute(s)". At the bottom, there are "Cancel" and "Save" buttons.

Figure 173: System Events->Alert Events Lists: System Reboot

- **Detect Cycle:** The UCM6200 will check the system reboot based on this cycle. Users can enter the number and then select second(s)/minute(s)/hour(s)/day(s) to configure the cycle.

## 4. System Crash



The screenshot shows a dialog box titled "Alert Settings: System Crash". It contains one configuration field: "Detect Cycle" with a value of "10" and a unit dropdown set to "minute(s)". At the bottom, there are "Cancel" and "Save" buttons.


Figure 174: System Events->Alert Events Lists: System Crash

- **Detect Cycle:** The UCM will detect the event at each cycle based on the specified time. Users can enter the number and then select second(s)/minute(s)/hour(s)/day(s) to configure the cycle.

Click on the switch  OFF  ON to turn on/off the alert and Email notification for the event. Users could also select the checkbox for each event and then click on button "Alert On", "Alert Off", "Email Notification On", "Email Notification Off" to control the alert and Email notification configuration.

## ALERT LOG

Under Web GUI->**Status->System Events->Alert Log**, system messages from triggered system events are listed as alert logs. The following screenshot shows system crash alert logs.



The screenshot shows the 'Alert Log' interface with search filters and a table of events. The search filters are set to 'All' for both Event Name and Type, with empty date ranges for Start Time and End Time. The table contains five entries for 'System Crash' events, all of type 'Generate Alert'.

Time	Event Name	Type	Content
2014-12-26 18:53:56	System Crash	Generate Alert	System crashed. System has restored automatically. The core dump file is: <a href="#">xxxx</a>
2014-12-26 09:33:54	System Crash	Generate Alert	System crashed. System has restored automatically. The core dump file is: <a href="#">xxxx</a>
2014-12-23 20:03:50	System Crash	Generate Alert	System crashed. System has restored automatically. The core dump file is: <a href="#">xxxx</a>
2014-12-21 14:43:50	System Crash	Generate Alert	System crashed. System has restored automatically. The core dump file is: <a href="#">xxxx</a>
2014-12-19 08:01:23	System Crash	Generate Alert	System crashed. System has restored automatically. The core dump file is: <a href="#">xxxx</a>

**Figure 175: System Events->Alert Log**

User could also filter alert logs by selecting a certain event category, type of alert log, and/or specifying a certain time period. The matching results will be displayed after clicking on . Alert logs are classified into two types by the system:

1. **Generate Alert:** Generated when alert events happen, for example, alert logs for disk usage exceeding the alert threshold.
2. **Restore to Normal:** Generated when alert events being cleared, for example, logs for disk usage dropping back below the alert threshold.

User could filter out alert logs of "Generate Alert" or "Restore to Normal" by specifying the type according to need. The following figure shows an example of filtering out alert logs of type of "Restore to Normal".

**Alert Log**

Event Name:

Type:

Start Time:

End Time:

View: 10

Time	Event Name	Type	Content
2014-10-20 10:03:25	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: H2PBX
2014-10-20 09:44:27	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: MoroccoPBX
2014-10-20 09:21:10	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: MoroccoPBX
2014-10-20 09:17:53	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: VenezuelaUCM
2014-10-20 09:08:55	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: MoroccoPBX
2014-10-20 09:54:03	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: H2PBX
2014-10-20 08:52:37	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: MoroccoPBX
2014-10-20 08:23:32	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: VenezuelaUCM
2014-10-20 08:21:20	SIP Peer Trunk Status	Restore to normal	SIP peer trunk service return to normal! Trunk name is: VenezuelaUCM

**Figure 176: Filter for Alert Log**

## ALERT CONTACT

Users could add administrator's Email address under Web GUI->**Status->System Events->Alert Contact** to send the alert notification to. Up to 10 Email addresses can be added.

## CDR

A Call Detail Record (CDR) is a data record produced by telephone exchange activities or other telecommunications equipment documenting the details of a phone call that passed through the PBX. The CDR is composed of the following data fields on the UCM6200.

- **Start Time.** Format: 2016-02-27 16:47:03.
- **Call From.** Format: "John Doe"<6012>.
- **Call To.** Format: 6005.
- **Answered By.** Format: 6005.
- **Call Time.** Format: 0:00:10.
- **Talk Time.** Format: 0:00:10
- **Status.** Format: NO ANSWER, BUSY, ANSWERED, or FAILED.
- **Options.** Voice record playing/downloading/deleting.

Users could filter the call report by specifying the date range and criteria, depending on how the users would like to include the logs to the report. Then click on "View Report" button to display the generated report.





**Figure 177: CDR Filter**

**Table 99: CDR Filter Criteria**

Inbound calls	Inbound calls are calls originated from a non-internal source (like a VoIP trunk) and sent to an internal extension.
Outbound calls	Outbound calls are calls sent to a non-internal source (like a VoIP trunk) from an internal extension.
Internal calls	Internal calls are calls from one internal extension to another extension, which are not sent over a trunk.
External calls	External calls are calls sent from one trunk to another trunk, which are not sent to any internal extension.
Inbound Trunks	Select certain inbound trunk(s) and the CDR of calls going inbound through the trunk(s) will be filtered out.
Outbound Trunks	Select certain outbound trunk(s) and the CDR of calls going outbound through the trunk(s) will be filtered out.
Start Time	Specify the start time to filter the CDR report. Click on the calendar icon on the right and the calendar will show for users to select the exact date and time.
End Time	Specify the end time to filter the CDR report. Click on the calendar icon on the right and the calendar will show for users to select the exact date and time.
Caller Number	<p>Enter the caller number to filter the CDR report. CDR with the matching caller number will be filtered out.</p> <p>User could specify a particular caller number or enter a pattern. '.' matches zero or more characters, only appears in the end. 'X' matches any digit from 0 to 9, case-insensitive, repeatable, only appears in the end.</p> <p>For example:            3XXX: It will filter out CDR that having caller number with leading digit 3 and of 4 digits length.            3.: It will filter out CDR that having caller number with leading digit 3 and of any length.</p>
Caller Name	Enter the caller name to filter the CDR report. CDR with the matching caller name will

	be filtered out.
Callee Number	Enter the callee number to filter the CDR report. CDR with the matching callee number will be filtered out.

The call report will display as the following figure shows.

No.	Start Time	Call From	Call To	Accounted By	Call Time	Talk Time	Status	Options
1	2014-11-03 15:29:44	1000	1005	1005	0:09:34	0:09:32		
2	2014-11-03 16:21:14	1000	1005	1005	0:02:18	0:01:57		
3	2014-11-03 14:17:50	1000	1005	1005	0:03:17	0:03:11		
4	2014-11-03 14:17:50	1000	1005	1005	0:00:02	0:00:00		

Total: 4 Show: 1/1 Go to:  Go

**Figure 178: Call Report**

Users could perform the following operations on the call report.

- Sort**  
 Click on the header of the column to sort by this category. For example, clicking on "Start Time" will sort the report according to start time. Clicking on "Start Time" again will reverse the order.
- Download Searched Results**  
 Click on "Download Search Result(s)" to export the records filtered out to a .csv file.
- Download All Records**  
 Click on "Download All Records" to export all the records to a .csv file.
- Delete All**  
 On the bottom of the page, click on "Delete All" button to remove all the call report information.
- Play/Download/Delete Recording File (per entry)**  
 If the entry has audio recording file for the call, the three icons on the most right column will be activated for users to select. In the following picture, the second entry has audio recording file for the call.


Click on to play the recording file; click on to download the recording file in .wav format; click on to delete the recording file (the call record entry will not be deleted).

2013-07-03 18:27:47	6000	5001	0:00:16	0:00:14		
2013-07-03 17:55:04	6000	5001	0:00:18	0:00:16		

**Figure 179: Call Report Entry with Audio Recording File**

- **Automatic Download CDR Records**

User could configure the UCM6200 to automatically download the CDR records and send the records to an Email address. Click on “Automatic Download Settings”, and configure the parameters in the dialog below.



**Automatic Download Settings** [X]

Automatically send the CDR records to configured email at a certain period. If you want to upload the CDR records to FTP/TFTP server, please go to the [Data Sync](#) page to configure.

Enable:

Automatic Download Period:

Email:

Cancel Save

**Figure 180: Automatic Download Settings**

To receive CDR record automatically from Email, check “Enable” and select a time period “By Day” “By Week” or “By Month” for the automatic download period. Make sure you have entered an Email address to receive the CDR records.

## CDR IMPROVEMENT

Starting from UCM6200 firmware 1.0.10.x, transferred call will no longer be displayed as a separate call entry in CDR. It will display within call record in the same entry. CDR new features can be found under **web UI-> Status->CDR->CDR**. The user can click on the option icon for a specific call log entry to view details about this entry, such as premier caller and transferred call information.

Click on the title of the column to sort by column. Click on the row to display full record.

No.	Start Time	Call Type	Call From	Call To	Call Time	Talk Time	Status	Recording File Options	Options
1	2015-08-28 17:52:16	DIAL	1000	1001	0:01:07	0:01:04		No Recording Files	
2	2015-08-28 17:51:56	DIAL	1000	1001	0:00:15	0:00:12		No Recording Files	
3	2015-08-28 17:50:33	DIAL	1000	1001	0:00:14	0:00:11		No Recording Files	
4	2015-08-28 17:50:17	DIAL	1000	1002	0:00:05	0:00:02		No Recording Files	
5	2015-08-28 17:49:59	DIAL	1000	1001	0:00:29	0:00:25		No Recording Files	

View: 10

**Figure 181: CDR Report**

Start Time	Premier Caller	Call Type	Call From	Call To	Call Time	Talk Time	Status	Recording File Options
2015-08-28 17:52:16	1000	DIAL	1000	1001	0:01:04	0:01:01		No Recording Files
2015-08-28 17:53:21	1000	TRANSFER	1001	1002	0:00:03	0:00:03		No Recording Files

Figure 182: Detailed CDR Information

## DOWNLOADED CDR FILE

The downloaded CDR (.csv file) has different format from the web UI CDR. Here are some descriptions.

- Call From, Call To**

"Call From": the caller ID.

"Call To": the callee ID.

If "Call From" shows empty, "Call To" shows "s" (see highlight part in the picture below) and the "Source Channel" contains "DAHDI", this means the call is from FXO/PSTN line. For FXO/PSTN line, we only know there is an incoming request when there is incoming call but we don't know the number being called. So we are using "s" to match it where "s" means "start".

call from	call to	context	start time	answer time	end time	call time	talk time	source channel	dest channel	status
610	19097622990	from-internal	1/29/2014 14:28	1/29/2014 14:28	1/29/2014 14:31	153	150	SIP/610-0000074	DAHDI/L-1	ANSWERED
	s	default	1/29/2014 14:33		1/29/2014 14:33	8	0	DAHDI/pseudo-149089967		NO ANSWER
	s	default	1/29/2014 14:33		1/29/2014 14:33	9	0	DAHDI/pseudo-1067045536		NO ANSWER
601	688	from-internal	1/29/2014 14:33	1/29/2014 14:33	1/29/2014 14:33	9	9	SIP/601-0000077		ANSWERED
	s	default	1/29/2014 14:34		1/29/2014 14:34	22	0	DAHDI/pseudo-1134093033		NO ANSWER
	s	default	1/29/2014 14:34		1/29/2014 14:34	22	0	DAHDI/pseudo-1719498666		NO ANSWER

Figure 183: Downloaded CDR File Sample - Call To Shows "s"

- Context**

There are different context values that might show up in the downloaded CDR file. The actual value can vary case by case. Here are some sample values and their descriptions.

**from-internal:** internal extension makes outbound calls.

**ext-did-XXXXX:** inbound calls. It starts with "ext-did", and "XXXXX" content varies case by case, which also relate to the order when the trunk is created.

**ext-local:** internal calls between local extensions.

- Source Channel, Dest Channel**

### Sample 1:

call from	call to	context	start time	answer time	end time	call time	talk time	source channel	dest channel	status
3122731459	s	ext-did-1	1/30/2014 14:27	1/30/2014 14:27	1/30/2014 14:27	37	35	DAHDI/1-1		ANSWERED

**Figure 184: Downloaded CDR File Sample - Source Channel and Dest Channel 1**

DAHDI means it is an analog call, FXO or FXS.

For UCM6202, DAHDI/(1-2) are FXO ports, and DAHDI(3-4) are FXS ports.

For UCM6204, DAHDI/(1-4) are FXO ports, and DAHDI(5-6) are FXS ports.

For UCM6208, DAHDI/(1-8) are FXO ports, and DAHDI(9-10) are FXS ports.

**Sample 2:**

call from	call to	context	start time	answer time	end time	call time	talk time	source channel	dest channel	status
609	s	619-from-internal	1/30/2014 14:31	1/30/2014 14:32	1/30/2014 14:32	9	3	SIP/609-00000130	SIP/619-00000151	ANSWERED

**Figure 185: Downloaded CDR File Sample - Source Channel and Dest Channel 2**

"SIP" means it's a SIP call. There are three possible format:

(a) **SIP/NUM-XXXXXX**, where NUM is the local SIP extension number. The last XXXXX is a random string and can be ignored.

(c) **SIP/trunk\_X/NUM**, where trunk\_X is the internal trunk name, and NUM is the number to dial out through the trunk.

(c) **SIP/trunk\_X-XXXXXX**, where trunk\_X is the internal trunk name and it is an inbound call from this trunk. The last XXXXX is a random string and can be ignored.

**Sample 3:**

call from	call to	context	start time	answer time	end time	call time	talk time	source channel	dest channel	status
	s	default	1/30/2014 14:30		1/30/2014 14:37	386	0	DAHDI/pseudo-1665832080		NO ANSWER
	s	default	1/30/2014 14:30		1/30/2014 14:37	390	0	DAHDI/pseudo-1946772436		NO ANSWER

**Figure 186: Downloaded CDR File Sample - Source Channel and Dest Channel 3**

This is a very special channel name. If it shows up, most likely it means a conference call.

There are some other possible values, but these values are almost the application name which are used by the dialplan.

**IAX2/NUM-XXXXXX**: it means this is an IAX call.

**Local/@from-internal-XXXXX**: it is used internally to do some special feature procedure. We can simply ignore it.

**Hangup**: the call is hung up from the dialplan. This indicates there are some errors or it has run into abnormal cases.

**Playback**: play some prompts to you, such as 183 response or run into an IVR.

**ReadExten**: collect numbers from user. It may occur when you input PIN codes or run into DISA

## STATISTICS

CDR Statistics is an additional feature on the UCM6200 which provides users a visual overview of the call report across the time frame. Users can filter with different criteria to generate the statistics chart.



Figure 187: CDR Statistics

Table 100: CDR Statistics Filter Criteria



Trunk Type	Select one of the following trunk type. <ul style="list-style-type: none"> <li>• All</li> <li>• SIP Calls</li> <li>• PSTN Calls</li> </ul>
Call Type	Select one or more in the following checkboxes. <ul style="list-style-type: none"> <li>• Inbound calls</li> <li>• Outbound calls</li> <li>• Internal calls</li> <li>• External calls</li> <li>• All calls</li> </ul>
Time Range	<ul style="list-style-type: none"> <li>• By month (of the selected year).</li> <li>• By week (of the selected year).</li> <li>• By day (of the specified month for the year).</li> <li>• By hour (of the specified date).</li> <li>• By range. For example, 2016-01 To 2016-03.</li> </ul>

## RECORDING FILES

This page lists all the recording files recorded by "Auto Record" per extension/ring group/call queue/trunk, or via feature code "Audio Mix Record". If external storage device is plugged in, for example, SD card or USB drive, the files are stored on the external storage. Otherwise, internal storage will be used on the UCM6200.



**Figure 188: CDR->Recording Files**

- Click on “Delete Selected Recording Files” to delete the recording files.
- Click on “Delete All Recording Files” to delete all recording files.
- Click on  to download the recording file in .wav format.
- Click on  to delete the recording file.
- To sort the recording file, click on the title "Caller", "Callee" or "Call Time" for the corresponding column. Click on the title again can switch the sorting mode between ascending order or descending order.

## API CONFIGURATION

The UCM6200 supports third party billing interface API for external billing software to access CDR and call recordings on the PBX. The API uses HTTPS to request the CDR data and call recording data matching given parameters as configured on the third party application.

Before accessing the API, the administrators need enable API and configure the access/authentication information on the UCM6200 first. The API configuration parameters are listed in the table below.

**Table 101: API Configuration Files**

Enable	Enable/Disable API. The default setting is disabled.
TLS Bind Address	Configure the IP address for TLS server to bind to. "0.0.0.0" means binding to all interfaces. The port number is optional and the default port number is 8443. The IP address must match the common name (host name) in the certificate so that the TLS socket won't bind to multiple IP addresses. The default setting is 0.0.0.0:8443.
TLS Private Key	Upload TLS private key. The size of the key file must be under 2MB. This file will be renamed as 'private.pem' automatically.
TLS Cert	Upload TLS cert. The size of the certificate must be under 2MB. This is the certificate file (*.pem format only) for TLS connection. This file will be renamed as "certificate.pem" automatically. It contains private key for the client and signed certificate for the server.

Username	Configure the Username for API Authentication.
Password	Configure the Password for API Authentication.
Permitted	<p>Specify a list of IP addresses permitted by API. This creates an AIP-specific access control list. Multiple entries are allowed.</p> <p>For example, "192.168.40.3/255.255.255.255" denies access from all IP addresses except 192.168.40.3.</p> <p>The default setting is blank, meaning all IPs will be denied. Users must set permitted IP address before connecting to the API.</p>

For more details on CDR API (Access to Call Detail Records) and REC API (Access to Call Recording Files), please refer the document in the link here:

[http://www.grandstream.com/sites/default/files/Resources/ucm6200\\_cdr\\_rec\\_api\\_guide.pdf](http://www.grandstream.com/sites/default/files/Resources/ucm6200_cdr_rec_api_guide.pdf)





## UPGRADING AND MAINTENANCE

### UPGRADING

The UCM6200 can be upgraded to a new firmware version remotely or locally. This section describes how to upgrade your UCM6200 via network or local upload.


#### UPGRADING VIA NETWORK

The UCM6200 can be upgraded via TFTP/HTTP/HTTPS by configuring the URL/IP Address for the TFTP/HTTP/HTTPS server and selecting a download method. Configure a valid URL for TFTP, HTTP or HTTPS; the server name can be FQDN or IP address.

##### Examples of valid URLs:

firmware.grandstream.com/BETA

The upgrading configuration can be accessed via **Web GUI->Maintenance->Upgrade**.



The screenshot shows a web interface titled "Upgrade Firmware" with a sub-section "Network Upgrade". It contains the following fields:

- Upgrade Via:** A dropdown menu currently set to "HTTP".
- Firmware Server Path:** A text input field containing "fw.ipvideotalk.com/gs".
- Firmware File Prefix:** An empty text input field.
- Firmware File Suffix:** An empty text input field.
- HTTP/HTTPS User Name:** An empty text input field.
- HTTP/HTTPS Password:** An empty text input field.

At the bottom right of the form are two buttons: "Cancel" (grey) and "Save" (orange).

**Figure 189: Network Upgrade**

**Table 102: Network Upgrade Configuration**


Upgrade Via	Allow users to choose the firmware upgrade method: TFTP, HTTP or HTTPS.
Firmware Server Path	Define the server path for the firmware server.
Firmware File Prefix	If configured, only the firmware with the matching encrypted prefix will be downloaded and flashed into the UCM6200.
Firmware File Suffix	If configured, only the firmware with the matching encrypted postfix will be downloaded and flashed into the UCM6200.
HTTP/HTTPS User Name	The user name for the HTTP/HTTPS server.
HTTP/HTTPS Password	The password for the HTTP/HTTPS server.


Please follow the steps below to upgrade the firmware remotely.

- Enter the firmware server path under **web UI->Maintenance->Upgrade**.
- Click on "Save". Then reboot the device to start the upgrading process.
- Please be patient during the upgrading process. Once done, a reboot message will be displayed in the LCD.
- Manually reboot the UCM6200 when it's appropriate to avoid immediate service interruption. After it boots up, log in the web GUI to check the firmware version.

### UPGRADING VIA LOCAL UPLOAD


If there is no HTTP/TFTP server, users could also upload the firmware to the UCM6200 directly via Web GUI. Please follow the steps below to upload firmware locally.

- Download the latest UCM6200 firmware file from the following link and save it in your PC.  
<http://www.grandstream.com/support/firmware>
- Log in the Web GUI as administrator in the PC.
- Go to Web GUI->**Maintenance->Upgrade**, upload the firmware file by clicking on  and select the firmware file from your PC. The default firmware file name is ucm6200fw.bin




**Figure 190: Local Upgrade**

- Click on  to start upgrading.



**Figure 191: Upgrading Firmware Files**

- Wait until the upgrading process is successful and a window will be popped up in the Web GUI.



**Figure 192: Reboot UCM6200**

- Click on "OK" to reboot the UCM6200 and check the firmware version after it boots up.



**Note:**

Please do not interrupt or power cycle the UCM6200 during upgrading process.

## NO LOCAL FIRMWARE SERVERS

Service providers should maintain their own firmware upgrade servers. For users who do not have TFTP/HTTP/HTTPS server, some free windows version TFTP servers are available for download from [http://www.solarwinds.com/products/freetools/free\\_tftp\\_server.aspx](http://www.solarwinds.com/products/freetools/free_tftp_server.aspx)  
<http://tftpd32.jounin.net>

Please check our website at <http://www.grandstream.com/support/firmware> for latest firmware.

Instructions for local firmware upgrade via TFTP:

1. Unzip the firmware files and put all of them in the root directory of the TFTP server;
2. Connect the PC running the TFTP server and the UCM6200 to the same LAN segment;
3. Launch the TFTP server and go to the File menu->Configure->Security to change the TFTP server's default setting from "Receive Only" to "Transmit Only" for the firmware upgrade;
4. Start the TFTP server and configure the TFTP server in the UCM6200 web configuration interface;
5. Configure the Firmware Server Path to the IP address of the PC;
6. Update the changes and reboot the UCM6200.


End users can also choose to download a free HTTP server from <http://httpd.apache.org/> or use Microsoft IIS web server.

## BACKUP

The UCM6200 configuration can be backed up locally or via network. The backup file will be used to restore the configuration on UCM6200 when necessary.

### BACKUP/RESTORE

Users could backup the UCM6200 configurations for restore purpose under Web GUI->**Maintenance->Backup->Local Backup**.

Click on  to create a new backup file. Then the following dialog will show.

**Create New Backup** X

**Choose Backup Files:**

Config File    CDR Records    Recording Files

Fax Files    Voice Mail    Voice Prompt Files

ZeroConfig Storage    All

**Choose Storage Location:**   Local

**File Name \*:**   backup\_2015nov11\_120851



Warning: backing up data files could take long time, and need larger space, please use the SD card, U disk and other external storage devices.

Cancel
Backup

**Figure 193: Create New Backup**

1. Choose the type(s) of files to be included in the backup.
2. Choose where to store the backup file: USB Disk, SD Card or Local.
3. Name the backup file.
4. Click on "Backup" to start backup.

Once the backup is done, the list of the backups will be displayed with date and time in the web page.


Users can download , restore , or delete  it from the UCM6200 internal storage or the external device.

Click on Upload Backup File to upload backup file from the local device to UCM6200. The uploaded backup file will also be displayed in the web page and can be used to restore the UCM6200.



**Figure 194: Backup / Restore**


**Regular Backup File** option allows UCM to perform automatically backup on the user specified time. Regular backup file can only be stored in USB / SD card / SFTP server. User is allowed to set backup time from 0-23 and how frequent the backup will be performed.



**Figure 195: Local Backup**

## DATA SYNC

Besides local backup, users could backup the voice records/voice mails/CDR/FAX in a daily basis to a remote server via SFTP protocol automatically under Web GUI->**Maintenance->Backup->Data Sync**.



**Figure 196: Data Sync**

**Table 103: Data Sync Configuration**

Enable Data Sync	Enable the auto data sync function. The default setting is "No".
Account	Enter the Account name on the SFTP backup server.
Password	Enter the Password associate with the Account on the SFTP backup server.
Server Address	Enter the SFTP server address.
Sync Time	Enter 0-23 to specify the backup hour of the day.



Before saving the configuration, users could click on "Test Connection". The UCM6200 will then try connecting the server to make sure the server is up and accessible for the UCM6200. Save the changes and all the backup logs will be listed on the web page. After data sync is configured, users could also



manually synchronize all data by clicking on **Synchronize All Data** instead of waiting for the backup time interval to come.

## RESTORE CONFIGURATION FROM BACKUP FILE

To restore the configuration on the UCM6200 from a backup file, users could go to Web GUI->**Maintenance->Backup->Local Backup**.

- A list of previous configuration backups is displayed on the web page. Users could click on  of the desired backup file and it will be restored to the UCM6200.
- If users have other backup files on PC to restore on the UCM6200, click on "Upload Backup File" first and select it from local PC to upload on the UCM6200. Once the uploading is done, this backup file will be displayed in the list of previous configuration backups for restore purpose. Click on  to restore from the backup file.



**Figure 197: Restore UCM6200 from Backup File**




### Note:

- The uploaded backup file must be a tar file with no special characters like \*,!,#,@,&,\$,% ^,(,),/, \,space in the file name.
- The uploaded back file size must be under 10MB.

## CLEANER

Users could configure to clean the Call Detail Report/Voice Records/Voice Mails/FAX automatically under Web GUI->**Maintenance**->**Cleaner**.



**Figure 198: Cleaner**

**Table 104: Cleaner Configuration**

Enable CDR Cleaner	Enable the CDR Cleaner function.
CDR Clean Time	Enter 0-23 to specify the hour of the day to clean up CDR.
Clean Interval	Enter 1-30 to specify the day of the month to clean up CDR.
Enable VR Cleaner	Enter the Voice Records Cleaner function.
Choose Cleaner File	Select the files for system automatic clean. <ul style="list-style-type: none"> <li>Recording Files</li> <li>Conference</li> <li>Queue</li> <li>Voicemail</li> <li>Fax</li> </ul>
VR Clean Threshold	Specify the Voice Records threshold from 0 to 99 by using local storage status in percentage.

VR Clean Time	Enter 0-23 to specify the hour of the day to clean up Voice Records.
Clean Interval	Enter 1-30 to specify the day of the month to clean up Voice Records.

All the cleaner logs will be listed on the bottom of the page.

 **Note:**


Cleaner will delete data based on Recording Storage selection. If **USB Disk** is selected, Cleaner will only clean data in USB and local data will leave untouched. If **Enable auto change** is selected and USB disk is connected, Cleaner will only delete data in USB drive. Recordings Storage function can be found under web **UI-> Settings-> Recordings Storage-> Recordings Storage**.

## RESET AND REBOOT

Users could perform reset and reboot under Web GUI->**Maintenance->Reset and Reboot**.

To factory reset the device, select the mode type first. There are two different types for reset.

- User Data: All the data including voicemail, recordings, IVR Prompt, Music on Hold, CDR and backup files will be cleared.
- All: All the configurations and data will be reset to factory default.



**Figure 199: Reset and Reboot**

## SYSLOG

On the UCM6200, users could dump the syslog information to a remote server under Web GUI->**Maintenance**->**Syslog**. Enter the syslog server hostname or IP address and select the module/level for the syslog information.

The default syslog level for all modules is "error", which is recommended in your UCM6200 settings because it can be helpful to locate the issues when errors happen.

Some typical modules for UCM6200 functions are as follows and users can turn on "notic" and "verb" levels besides "error" level.

pbx: This module is related to general PBX functions.

chan\_sip: This module is related to SIP calls.

chan\_dahdi: This module is related to analog calls (FXO/FXS).

app\_meetme: This module is related to conference bridge.



### Note:

Syslog is usually for debugging and troubleshooting purpose. Turning on all levels for all syslog modules is not recommended for daily usage. Too many syslog print might cause traffic and affect system performance.


---

## TROUBLESHOOTING

On the UCM6200, users could capture traces, ping remote host and traceroute remote host for troubleshooting purpose under Web GUI->**Maintenance**->**Troubleshooting**.

### ETHERNET CAPTURE

The captured trace can be downloaded for analysis. Also the instructions or result will be displayed in the web GUI output result.




**Figure 200: Ethernet Capture**

The output result is in .pcap format. Therefore, users could specify the capture filter as used in general network traffic capture tool (host, src, dst, net, protocol, port, port range) before starting capturing the trace.

## IP PING

Enter the target host in host name or IP address. Then press "Start" button. The output result will dynamically display in the window below.



**Figure 201: PING**

## TRACEROUTE

Enter the target host in host name or IP address. Then press "Start" button. The output result will dynamically display in the window below.

**Traceroute**

Target Host:

---

**Output Result**

```

traceroute Diagnostic run!
traceroute to www.google.com (74.125.224.179)
6 * * *
7 ae-81-81.csw3.LosAngeles1.Level3.net (4.69.137.10) 14.700 ms 33.675 ms 14.675 ms
8 ae-1-60.edge1.LosAngeles9.Level3.net (4.69.144.10) 14.000 ms ae-4-90.edge1.LosAngeles9.Level3.net (4.69.144.202) 17.900 ms 11.725 ms
9 GOOGLE-INC.edge1.LosAngeles9.Level3.net (4.53.228.6) 20.625 ms 21.550 ms 14.600 ms
10 64.233.174.238 (64.233.174.238) 13.325 ms 19.450 ms 13.900 ms
11 72.14.236.11 (72.14.236.11) 15.675 ms 15.025 ms 15.275 ms
12 lax02s01-in-f19.1e100.net (74.125.224.179) 13.775 ms 11.925 ms *
Done
          
```


Figure 202: Traceroute

## ANALOG RECORD TRACE

Analog record trace can be used to troubleshoot analog trunk issue, for example, the UCM6200 user has caller ID issue for incoming call from Analog trunk. Users can access analog record trace under web GUI->**Maintenance->Troubleshooting ->Analog Record Trace**.

Here is the step to capture trace:

1. Select FXO or FXS for "Record Ports". If the issue happens on FXO 1, select FXO port 1 to record the trace.
2. Select "Record Direction".
3. Select "Record File Mode" to separate the record per direction or mix.
4. Click on "Start".
5. Make a call via the analog port that has the issue.
6. Once done, click on "Stop".
7. Click on "Download" to download the analog record trace.



**Figure 203: Troubleshooting Analog Trunks**

After capturing the trace, users can download it for basic analysis. Or you can contact Grandstream Technical support in the following link for further assistance if the issue is not resolved.

<http://www.grandstream.com/index.php/support>

## SERVICE CHECK


Enable Service Check to periodically check UCM6200. Check Cycle is configurable in seconds and the default setting is 60 sec. Check Times is the maximum number of failed checks before restart the UCM6200. The default setting is 3. If there is no response from UCM6200 after 3 attempts (default) to check, current status will be stored and the internal service in UCM6200 will be restarted.



**Figure 204: Service Check**

## NETWORK STATUS

In UCM6200 web UI->Maintenance->Troubleshooting->Network Status, the users can view active Internet connections. This information can be used to troubleshoot connection issue between UCM6200 and other services.

Maintenance >> Troubleshooting >> Network Status 

### Network Status

Active Internet Connections (Servers And Established)

Proto	Recv-Q	Send-Q	Local-Address	Foreign-Address	State
tcp	0	0	0.0.0.0:7777	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:5060	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:5061	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:389	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:80	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:8089	0.0.0.0:*	LISTEN
tcp	0	0	192.168.40.151:8089	192.168.40.191:2852	ESTABLISHED
tcp	0	1074	192.168.40.151:8089	192.168.40.191:2849	ESTABLISHED
tcp	0	0	192.168.40.151:8089	192.168.40.191:2848	ESTABLISHED
tcp	0	0	192.168.40.151:8089	192.168.40.191:2851	ESTABLISHED
tcp	0	0	127.0.0.1:52450	127.0.0.1:7777	ESTABLISHED
tcp	0	0	192.168.40.151:8089	192.168.40.191:2850	ESTABLISHED
tcp	0	0	192.168.40.151:8089	192.168.40.191:2845	TIME_WAIT
tcp	0	0	127.0.0.1:7777	127.0.0.1:52450	ESTABLISHED
tcp	0	0	:::389	:::*	LISTEN

Figure 205: Network Status

## REMOTE ACCESS

### SSH ACCESS

SSH switch now is available via web UI and LCD. User can enable or disable SSH access directly from web UI or LCD screen. For web SSH access, please log in UCM6200 web interface and go to **Maintenance->Remote Access->SSH Access**. By default, SSH access is disabled for security concerns. It is highly recommended to only enable SSH access for debugging purpose.






Figure 206: SSH Access

## EXPERIENCING THE UCM6200 SERIES IP PBX

Please visit our website: <http://www.grandstream.com> to receive the most up- to-date updates on firmware releases, additional features, FAQs, documentation and news on new products.

We encourage you to browse our [product related documentation](#), [FAQs](#) and [User and Developer Forum](#) for answers to your general questions. If you have purchased our products through a Grandstream Certified Partner or Reseller, please contact them directly for immediate support.

Our technical support staff is trained and ready to answer all of your questions. Contact a technical support member or [submit a trouble ticket online](#) to receive in-depth support.

Thank you again for purchasing Grandstream UCM6200 series IP PBX appliance, it will be sure to bring convenience and color to both your business and personal life.

**\* Asterisk is a Registered Trademark of Digium, Inc.**

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Regulatory Information

### U.S. FCC Part 68 Statement

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. The unit bears a label on the back which contains among other information a product identifier in the format US: GNIIS00BUCM6202. If requested, this number must be provided to the telephone company.

This equipment uses the following standard jack types for network connection: RJ11C.

This equipment contains an FCC compliant modular jack. It is designed to be connected to the telephone network or premises wiring using compatible modular plugs and cabling which comply with the requirements of FCC Part 68 rules.

The Ringer Equivalence Number, or REN, is used to determine the number of devices which may be connected to the telephone line. An excessive REN may cause the equipment to not ring in response to an incoming call. In most areas, the sum of the RENs of all equipment on a line should not exceed five (5.0).

In the unlikely event that this equipment causes harm to the telephone network, the telephone company can temporarily disconnect your service. The telephone company will try to warn you in advance of any such disconnection, but if advance notice isn't practical, it may disconnect the service first and notify you as soon as possible afterwards. In the event such a disconnection is deemed necessary, you will be advised of your right to file a complaint with the FCC.

From time to time, the telephone company may make changes in its facilities, equipment, or operations which could affect the operation of this equipment. If this occurs, the telephone company is required to provide you with advance notice so you can make the modifications necessary to obtain uninterrupted service.

There are no user serviceable components within this equipment. See Warranty flyer for repair or warranty information.

It shall be unlawful for any person within the United States to use a computer or other electronic device to send any message via a telephone facsimile unless such message clearly contains, in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business, other entity, or individual sending the message and the telephone number of the sending machine or of such business, other entity, or individual. The telephone number provided may not be a 900 number or any other number for which charges exceed local or long distance transmission charges. Telephone facsimile machines manufactured on and after December 20, 1992, must clearly mark such identifying information on each transmitted message. Facsimile modem boards manufactured on and after December 13, 1995, must comply with the requirements of this section.

This equipment cannot be used on public coin phone service provided by the telephone company. Connection to Party Line Service is subject to state tariffs. Contact your state public utility commission, public service commission, or corporation commission for more information.