


**SAMSUNG**

**SAMSUNG DIGIT*all***  
everyone's invited™



**ENGLISH**

## **SAMSUNG CAMERA**

---

### **User's Manual**

# *V5*


Thank you for buying a Samsung Camera.

This manual will guide you through using the camera, including capturing images, downloading images and using the application software. Please read this manual carefully before using your new camera.

# Instructions

2 ~ 9 페이지 D430 공용입니다.

- Use this camera in the following order



- If you use a card reader to copy the images on the memory card to your PC, the images could be damaged. When transferring the images taken with the camera to your PC, be sure to use the supplied USB cable to connect the camera to your PC. Please note that the manufacturer holds no responsibility for loss or damage of images on the memory card due to the use of a card reader.

# Contents

## READY

●Getting to know your camera .....	5	■TELE Zoom .....	27
●About the icons .....	5	■WIDE Zoom .....	27
●Danger .....	6	●Voice memo/ UP button .....	28
●Warning .....	6	■Recording a voice memo .....	28
●Caution .....	7	●Macro/ Down button (Focusing) .....	29
●An FCC warning .....	7	●Focus lock .....	30
●This digital camera can be used for .....	8	●FLASH/ LEFT button .....	31
●Manufacturer's contents .....	10	●Self-timer/ Right button .....	33
●Identification of features .....	11	●MENU/ OK button .....	34
■Front & Top .....	11	●+/- button .....	34
■Back & Bottom .....	11	●LCD button .....	38
■Side/ 5-function button .....	12	●Using the LCD monitor to adjust the camera settings .....	39
■Mode dial .....	12	●How to use the menu .....	40
●Connecting to a Power Source .....	14	●Size .....	41
■Using the AC power adapter (3.3V 2.0A) .....	15	●Quality .....	41
■Using the batteries .....	16	●Metering .....	42
●Instructions on how to use the memory card .....	17	●Continuous shot .....	43
●Inserting the memory card .....	19	●Effect .....	43
●Removing the memory card .....	19	●Sharpness .....	44
		●Scene .....	44

## RECORDING

●LCD monitor indicator .....	20	●Starting play mode .....	45
●Starting the recording mode .....	21	■Playing back a still image .....	45
●Things to Watch Out for When Taking Pictures .....	25	■Playing back a movie clip .....	46
●Using the camera buttons to adjust the camera .....	26	■Playing back a recorded voice .....	46
■POWER button .....	26	●LCD monitor indicator .....	47
■SHUTTER button .....	26	●Using the camera buttons to adjust the camera .....	48
●ZOOM W/ T button .....	26	●Thumbnail/ Enlargement button .....	48
		●Voice memo/ Up button .....	49
		●Play & Pause/ Down button .....	50
		●LEFT/ RIGHT/ MENU/ OK button .....	51

## PLAY

# Contents

●LCD button .....	51	●Shutter sound .....	74
●Delete button .....	52	●Important notes .....	75
●Setting up the play back function using the LCD monitor .....	53	●Warning indicator .....	77
●Starting the slide show .....	54	●Before contacting a service center .....	78
●Protecting images .....	55	●Specifications .....	81
●Deleting images .....	56		
●Resize .....	57		
●Rotating an image .....	58		
●DPOF .....	58		
●DPOF : STANDARD .....	59		
●DPOF : INDEX .....	59		
●DPOF : PRINT SIZE .....	60		
●Copy Picture .....	61		
●PictBridge .....	62		

## SETUP

●Setup menu .....	64	●Software Notes .....	83
●File name .....	65	●System Requirements .....	83
●Auto power off .....	66	●About the software .....	84
●Language .....	67	●Setting up the application software .....	85
●Formatting a memory card .....	67	●Starting PC Mode .....	91
●Setting up the Date/ Time/ Date type .....	68	●Removing the USB Driver for Windows 98SE .....	94
●Imprinting the recording date .....	68	●Removable Disk .....	95
●Sound .....	69	●Removing the removable disk .....	96
●LCD brightness .....	69	●Setting up the USB Driver for MAC .....	97
●Selecting Video out type .....	70	●Using the USB Driver for MAC .....	97
●Quick view .....	71	●Using PhotoImpression .....	98
●Initialization(RESET ALL) .....	71	●Digimax Viewer 2.1 .....	99
●Select card .....	72	●FAQ .....	100
●Connecting an External Device (USB) .....	72		
●Setting up the MYCAM menu .....	73		
●Start up image .....	73		
●Start up sound .....	74		

## SOFTWARE

## Getting to know your camera

Thank you for buying a Samsung Digital Camera.

- Prior to using this camera, please read the user manual thoroughly.
  - When you require After Sales service, please bring the camera and the cause of the camera malfunction (such as Batteries, Memory card etc.) to the A/S center.
  - Please check that the camera is operating properly prior to when you intend to use it (e.g. for a trip or an important event) to avoid disappointment. Samsung camera takes no responsibility for any loss or damages that may result from camera malfunction.
  - Keep the manual in a safe place.
- \* Microsoft, Windows and Windows logo are registered trademarks of Microsoft Corporation incorporated in the United States and/or other countries.
- \* All brand and product names appearing in this manual are registered trademarks of their respective companies.

## About the icons

This manual contains instructions on using this camera that will help you to use this camera safely and correctly. This will help prevent danger and injury to others.



### **DANGER**

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



### **WARNING**

WARNING indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.



### **CAUTION**

CAUTION indicates a potentially hazardous situation, which, if not avoided, may result in a minor or moderate injury.

## Danger

- Do not attempt to modify this camera in any way. This may result in fire, injury, electric shock or severe damage to you or your camera. Internal inspection, maintenance and repairs should be carried out by your dealer or Samsung Camera Service Center.
- Please do not use this product in close proximity to flammable or explosive gases, as this could increase the risk of explosion.
- Should any form of liquid or a foreign object enter the camera, do not use it. Switch off the camera, and then disconnect the power source (batteries or AC Power Adapter). You must contact your dealer or Samsung Camera Service Center. Do not continue to use the camera as this may cause a fire or electric shock.
- Do not insert or drop metallic or inflammable foreign objects into the camera through access points e.g. the memory card slot and battery chamber. This may cause a fire or electric shock.
- Do not operate this camera with wet hands. This could pose a risk of electric shock.

**DANGER**

## Warning

- Do not use the flash in close proximity to people or animals. Positioning the flash too close to your subject's eyes, may cause eyesight damage.
- When taking photographs, never point the lens of the camera directly into very strong light. This may result in permanent damage to your eyesight.
- For safety reasons keep this product and accessories out of reach of children or animals to prevent accidents e.g.:
  - Swallowing batteries or small camera accessories. If an accident should occur, please consult a doctor immediately.
  - There is the possibility of injury from the camera's moving parts.
- Batteries and camera may become hot during prolonged use and it may result in camera malfunction. Should this be the case, allow the camera to sit idle for a few minutes to allow it time to cool.
- Do not recharge non rechargeable batteries. This may cause an explosion.
- Do not leave this camera in places subject to extremely high temperatures, such as a sealed vehicle, direct sunlight or other places of extreme variances in temperature. Exposure to extreme temperatures may adversely affect the camera's internal components and could cause a fire.
- When in use, do not cover the camera or AC Power Adapter. This may cause heat to build up and distort the camera body or cause a fire. Always use the camera and its accessories in a well-ventilated area.

## Caution

- Leaking, overheating, or burst batteries could result in fire or injury.
  - Use batteries with the correct specification for the camera.
  - Do not short circuit, heat or dispose of batteries in fire.
  - Do not insert the batteries with the reverse polarities.
- Remove the batteries when not planning to use the camera for a long period of time.  
Batteries may leak corrosive electrolyte and irreparably damage the camera's components.
- Do not fire the flash while it is in contact with hands or objects.  
Do not touch the flash after using it continuously. It may cause burns.
- Do not move the camera while it is switched on, if you are using the AC Power Adapter.  
After use, always switch off the camera before unplugging the adapter from the wall socket.  
Then make sure that any connector cords or cables to other devices are disconnected before moving the camera. Failure to do so may damage the cords or cables and cause a fire or electric shock.

**CAUTION**


## An FCC warning

- This device has been tested in accordance with the limits of a class B digital device under item 15 of the FCC rules. These limits are designed to provide protection against harmful interference in commercial installation. This equipment generates, absorbs and can emit radio frequency energy. If it is not installed and used in accordance with the instructions, it may cause harmful interference to radio communication.

There is however, no guarantee that interference will not occur in some situations. Should any interference occur when this device is in operation, please try one or more of the following measures.

- Change the location and direction of any aerial.
  - Increase distance between the camera and the affected device.
  - Use a different socket away from the affected device.
  - Please contact a Samsung agent or a radio/TV engineer.
- This device complies with part 15 of the FCC Rules.
  - Changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

## This digital camera can be used for



Printing images using a dedicated printer, DPOF and PictBridge compatible printer or a DPOF-equipped photo lab.  
(refer to page 59)



Viewing images on a TV.  
(refer to page 67)



Down loading image files from camera to computer.  
(refer to page 88)



Taking a picture.  
(refer to page 21)



Editing images on a PC.  
(refer to page 94)



## This digital camera can be used for




Creation of a digital photo album.




Taking a self-portrait and using the image to personalize calendar.



Recording your voice.  
(refer to page 23)



Recording a movie clip.  
(refer to page 23)



You can even create your own unique gift wrap paper by using your digital images.



Inserting images directly into any electronic document.

# Manufacturer's contents

Please check that you have the correct contents before using this product.  
■ marked contents are optional.

Digital Camera



Pouch



AV cable



USB cable



Camera strap



User manual



Product warranty



Software CD




SD memory card



AC adapter  
(SAC-51, DC 5V)



Rechargeable battery



Battery charger  
(SBC-L2)



## Digimax Battery I-Pack : SBP-1103 KIT

Remote control



Battery charger



Rechargeable battery




AC cord




# Identification of features

## Front & Top



## Back & Bottom




\* When using the digital zoom to take a picture, the composition of the picture may be different depending on whether you are using the LCD monitor or the viewfinder. The picture will be taken in the composition of the picture as it appears on the LCD monitor.

# Identification of features

## Side/ 5-function button

V4 16 페이지




## Mode dial

D430 페이지 12


- You can select the desired working mode by using the mode dial located on the back of the camera. This digital camera has 8 recording modes. These are listed below.

### ● AUTO mode



Please select this mode for quick and easy picture taking with minimal user interaction.


### ● PROGRAM mode



Selecting the automatic mode will configure the camera with optimal settings. You can still manually configure all functions except the iris and shutter speed.

## Identification of features


- A/S/M mode



Aperture priority / Shutter priority / Manual mode


The Aperture and Shutter can be set manually in the A/ S/ M mode.

- MySET mode



This mode allows users to save frequently used shooting settings for later use.


- VOICE RECORDING mode



A voice recording can be recorded for as long as the available recording time of the memory capacity allows.(Max : 1 hour)

Voice recording file type : \*.wav

- MOVIE CLIP mode



A movie clip can be recorded for as long as the available recording time of the memory capacity allows.

- Image size : 640X480, 320X240(user selectable)


- Movie clip file type : \*.avi

- NIGHT SCENE mode



This mode is used at night or against a dark background.

- SCENE mode



Use the menu to easily configure optimal settings for a variety of shooting situations including portrait, children, landscape, close-up, sunset, dawn, backlight, fireworks, beach scenes, and snowscape.

## Identification of features

### ■ Self-timer lamp (Based on 10-second Self-timer; see p. 28)

Color	Status	Camera Status
Red	Blinking	- For the first 7 seconds, the LED blinks at 1second intervals. - For the final 3 seconds, the LED blinks quickly at 0.25-second intervals.

### ■ Auto focus indicator lamp

Color	Status	Camera Status
Green	Blinking	Recording Mode (lightly press the shutter button): Not focused PC Mode: Transmitting Data
	On	Recording Mode (lightly press the shutter button): Focused


















### ■ Flash indicator lamp

Color	Status	Camera Status
Red	Blinking	Flash in the process of charging
	ON	Flash ready

### ■ Mode dial lamp

Color	Status	Camera Status
Green	ON	Turned off the LCD with the LCD button. PC Mode: When the USB cable is inserted.

### ■ Mode icons

MODE	AUTO	PROGRAM	A/S/M	MySET	VOICE RECORDING	MOVIE CLIP	NIGHT SCENE	SCENE	PLAY
Icon								SCENE	
MODE	SCENE								
Icon									

## Connecting to a Power Source

- There are two ways in which to provide the camera with power. You can use batteries or alternatively, you can use an AC(100 ~ 250V) Adapter (DC 5V 2.0A).
- We recommend using Ni-MH batteries for a digital camera.(Over 1600mAh, and within a year from the date of manufacture) The batteries are listed below.
 

Non rechargeable batteries	: AA type	- Alkaline, Ni-Mn, Ni-Zn, Lithium
	CR-V3 type	- Lithium
Rechargeable batteries	: AA type	- Ni-MH, Ni-Cd (over 1000mA)
	CR-V3 type	- Digimax Battery I-Pack(SBP-1303)


Manufacturer's rechargeable battery: Digimax Premium Power Pack (SLB-1437)

## INFORMATION

### Important information about battery usage

- It is easy to buy alkaline batteries. However, the duration for using batteries varies in accordance with the battery manufacturer or the photographic conditions.
- When the camera is not used, turn off the camera power.
- Do not recharge the non rechargeable batteries. It may cause an explosion.
- Please remove the batteries if the camera will not be used for long periods. Batteries can lose power over time and are prone to leaking if kept inside the camera.
- We recommend high capacity ALKALINE batteries as manganese batteries cannot deliver sufficient power.
- Low temperatures (below 0 °C) can affect the performance of the batteries and you may experience reduced battery life.
- Batteries will usually recover at normal temperatures.
- Do not use old and new batteries at the same time.
- During extended use of the camera, the camera body may become warm. This is perfectly normal.

### Using the AC power adapter (5V 2.0A)



If you have access to a mains supply, using an AC Adapter (5V 2.0A) allows the camera to be used for long periods of time. Plug the adapter into the connection point (DC IN 5V) on the camera. Remove the batteries from the camera when using an AC adapter.

# Connecting to a Power Source



## DANGER

- Always turn off the power before taking the AC adapter out of the mains supply.
- As with all mains powered devices, safety is important. Ensure that neither the camera nor adapter comes into contact with water or metallic materials.
- Please ensure that you use an AC adapter (5V 2.0A) with the correct specification for the camera. Failure to do so may affect your warranty.


### Using the batteries

: If the camera does not turn on after you have inserted batteries, please check whether the batteries are inserted with the correct polarity(+ and-).

1. Open the battery chamber cover by pushing in the direction of the arrow.




[ Inserting the AA type battery ]






[ Inserting the CR-V3 type battery ]

2. Insert the batteries taking note of the polarity (+ / -).

3. To close the battery chamber cover, push it until it clicks.



■ There are 3 indicators for battery condition that are displayed on the LCD monitor.

Battery indicator			
Battery status	The batteries are fully charged.	Prepare new batteries.	There is no battery capacity. Replace with new batteries.



## Instructions on how to use the memory card

### Maintenance of the memory card

- Be sure to format the memory card (see p. 67) if you are using a newly purchased memory for the first time, if it contains data that the camera cannot recognize, or if it contains images captured with a different camera.
- Turn off the camera power whenever the memory card is being inserted or removed.
- Repeated use of the memory card will eventually reduce the memory card's performance. Should this be the case, you will need to purchase a new memory card.  
Wear and tear on the memory card is not covered by the Samsung warranty.
- The memory card is an electronic precision device.  
Do not bend, drop or subject the memory card to any heavy impact.
- Do not store the memory card in an environment with strong electronic or magnetic fields, e.g. near loud speakers or TV receivers.
- Please do not use or store in an environment where there are extremes in temperature.
- Do not allow the memory card to become dirty or to come into contact with any liquid.  
Should this happen, clean the memory card with a soft cloth.
- Please keep the memory card in its case when not in use.
- During and after periods of extended use, you may notice that the memory card is warm.  
This is perfectly normal.
- Do not use a memory card that is used in another digital camera or memory card reader.
- Do not use a memory card formatted by another digital camera or memory card reader.

### Preserving the memory card data


- If the memory card is subjected to any of the following, the recorded data may become corrupted :
  - When the memory card is used incorrectly.
  - If the power is switched off or the memory card is removed while recording, deleting (formatting) or reading.
- Samsung cannot be held responsible for lost data.
- It is advisable to copy important data onto other media as back-up e.g. floppy disks, hard disks, CD etc.
- If there is insufficient memory available : If you press the shutter button for the shot, a [CARD FULL !] message will appear and the camera will not operate. To optimize the amount of memory in the camera, replace the memory card or delete unnecessary images stored on the memory.

# Instructions on how to use the memory card

## INFORMATION

- If you open the battery chamber cover when the camera power is turned on, the power will turn off automatically.
- Don't remove the memory card when the Auto focus lamp(Green) is blinking as this may cause damage to data in the memory card.

- The camera can use SD Memory Cards and MMC (Multi Media Card).



[ SD(Secure Digital) memory card ]

The SD memory card has a write protect switch that prevents image files from being deleted or formatted.


By sliding the switch to the bottom of the SD memory card, the data will be protected. By sliding the switch to the top of the SD memory card, the data protection will be canceled. Slide the switch to the top of the SD memory card before taking a picture.

- When using a 32MB SD memory card, the specified shooting capacity will be as follows. (These figures are intended as an indication of expected performance). These figures are approximate as image capacities can be affected by variables such as subject matter.


Mode	STILL IMAGE mode						MOVIE CLIP mode	
	2560	2272	2048	1600	1024	640	640x320	320x240
TIFF	2	2	3	5	12	29	-	-
Super fine	13	14	17	28	64	129	-	-
Fine	23	28	33	53	106	201	-	-
Normal	34	40	49	75	139	227	-	-
30FPS	-	-	-	-	-	-	29	
15FPS	-	-	-	-	-	-	45	

## Inserting the memory card


1. Push the power switch to turn the power off. Open the battery cover while pushing it in the direction of the arrow.



2. Have the front of the memory card facing toward the front of the camera (lens) and the card pins toward the back of the camera (LCD monitor), and then push the memory card into the card slot until you hear a click.




3. To close, push the battery chamber cover until you hear a click. If the memory card does not slide in smoothly, do not attempt to insert it by force. Check the direction of insertion, and then insert it correctly.  
Do not insert the memory card the wrong way round. Doing so may damage the memory card slot.



## Removing the memory card


1. Push the power switch to turn the power off.  
Open the battery chamber cover and press the memory card as shown in the image and release.
2. Remove the memory card and close the battery chamber cover.



# LCD monitor indicator

D430 20페이지

















■ The LCD monitor displays information about the shooting functions and selections.



No.	Description	Icons	Page
1	Battery		p.16
2	Recording mode		p.12-13
3	Camera shake warning		p.25
4	Flash		p.31
5	Self-timer		p.33
6	Voice memo		p.28
7	Macro		p.29
8	Metering		p.42
9	Manual focus		
10	Sharpness		p.44
11	Auto focus frame		
12	Date/ Time	2004/03/01 01:00 PM	p.68
13	Exposure compensation		p.36

## LCD monitor indicator


D430 21페이지

14	White Balance	AWB      	p.35
15	ISO	    	
16	RGB	<b>RGB</b>	p.35
17	Image quality	   	p.41
18	Image size/ Continuous shot	2560, 2272, 2048, 1600, 1024, 640	p.41
19	Number of available shots remaining	28	
	Remaining time (Movie clip/ Voice recording)	00:01:30/ 01:00:00	
20	Optical/ Digital Zoom rate		

## Starting the recording mode

### ■ How to use the AUTO mode ( **AUTO** )

1. Insert the batteries. Insert the batteries taking note of the polarity (+ / -).
2. Insert the memory card (p.20).
3. Close the battery chamber cover.
4. Slide the power switch to turn on the camera. (If the date/time that is displayed on the LCD monitor is incorrect, reset the date/time before taking a picture.)
5. Select the AUTO mode by rotating the mode dial.
6. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor.
7. Press the shutter button to capture an image.



[ AUTO mode ]

## INFORMATION

- If the auto focus frame turns to red when you press the shutter button down half way, it means that the camera cannot focus on the subject. Should this be the case, the camera is unable to capture an image clearly.



## Starting the recording mode

### ■ How to use the PROGRAM mode ( **PROG** )

Selecting the automatic mode will configure the camera with optimal settings. You can still manually configure all functions except the iris and shutter speed.

Steps from 1-4 are the same as those for AUTO mode.

5. Select the PROGRAM mode by rotating the mode dial.
6. Press the menu button to configure advanced functions such as image size (p.34), quality (p.41), metering (p.42), number of pictures in sequential shooting (p.34), picture effects (p.34), sharpness (p.34).
7. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor.
8. Press the shutter button to capture an image.



[ PROGRAM mode ]

### ■ How to use the A/S/M mode ( **A/S/M** )


In this mode you can select the shutter speed or aperture value to your preference. Steps from 1-4 are the same as those for AUTO mode.

5. Select the A/S/M mode by rotating the mode dial.
6. Press the menu button and select the [ASM] menu tab.
7. Use the Up/Down buttons to select A (Aperture priority), S (Shutter speed priority), or M (Manual mode).

Press the OK button to confirm.

\* Please see page 40 for details on Aperture and Shutter speed setting

8. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor.
9. Press the shutter button to capture an image.



[ ASM mode ]

## 신규 Starting the recording mode


### ■ How to use the MySET mode ( MySET )

This mode allows users to save frequently used shooting settings for later use. Steps from 1-4 are the same as those for AUTO mode.

5. Select the MySET mode by rotating the mode dial.
6. You can use the menus that appear when you press camera and menu buttons to change the desired camera functions.

The last changed function(s) will automatically be saved as MySET mode.

7. If you rotate the Mode Dial to MySET mode while in another camera operation mode, the camera settings will switch to the settings you changed in Step 6.
8. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor.
9. Press the shutter button to capture an image.



[ MySET mode ]

\* Voice recording, self-timer, and remote controller configurations are not saved.



## D430 23 하단

### ■ How to use the VOICE RECORDING mode ( )

Steps from 1-4 are the same as those for AUTO mode.

5. Select the VOICE RECORDING mode by rotating the mode dial.
6. Press the shutter button to record a voice.
  - Press the shutter button once and voice is recorded for as long as the available recording time(Max : 1 hour) allows. The recording time will be displayed on the LCD monitor. Voice will still be recorded if the shutter button is released.
  - If you wish to stop recording, press the shutter button again.
  - File type : \*.wav

- \* A distance of 40cm between you and the camera (microphone) is the best distance to record sound.
- \* The auto focus indicator lamp(Green) blinks during voice recording.



[ VOICE RECORDING mode ]

## Starting the recording mode



### ■ How to use the MOVIE CLIP mode ( )

Steps from 1-4 are the same as those for AUTO mode.

5. Select the MOVIE CLIP mode by rotating the mode dial.
6. The MOVIE CLIP mode icon and available recording time will display on the LCD monitor.
7. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor. Press the shutter button and movie clips are recorded for as long as the available recording time.  
Movie clips will still be recorded if the shutter button is released. The auto focus lamp(green) will blink during the movie clip recording.
8. If you wish to stop recording, press the shutter button again.

\* Image size and type are listed below.


- Image size : 640x480, 320 x 240(Selectable)
- File type : \*.avi



[ MOVIE CLIP mode ]

### ■ NIGHT SCENE mode ( )

This mode is used at night or against a dark background. Configure the shutter speed by zoom scale (Long Time shutter) with the +/- button. Please see page 45 for a detailed description for Long Time shutter.



[ NIGHT SCENE mode ]



## Starting the recording mode

### ■ How to use the SCENE mode ( SCENE )


Use the menu to easily configure optimal settings for a variety of shooting situations including portrait, children, landscape, close-up, sunset, dawn, backlight, fireworks, beach scenes, and snowscape.

Steps from 1-4 are the same as those for AUTO mode.

5. Select the SCENE mode by rotating the mode dial.
6. Press the menu button and use the Left/Right buttons to select the [SCENE] menu tab.
7. Use the Up/Down buttons to select the desired submenu in Scene mode. Press the OK button to confirm.

Please see page 44 for detailed descriptions for each screen.

8. The current scene icon is displayed at the top left of the LCD.
9. Point the camera towards the subject and compose the image by using either the viewfinder or LCD monitor.
10. Press the shutter button to capture an image.




[ SCENE mode ]

## Things to Watch Out for When Taking Pictures


- Pressing the shutter button down half way

Lightly press the shutter button to confirm focus and flash battery charge. (See page 20)


Press the shutter button all way down to take the picture.



[ Lightly press the shutter button ]



[ Press the shutter button ]


- The available recording time may vary depending on shooting conditions and camera settings.
- When the Flash Off or Slow synchro mode is selected in a low lighting condition, the camera shake warning indicator (  ) may appear on the LCD monitor. In this case, use a tripod, support the camera on a solid surface or change the flash mode to flash shot mode.
- Backlight compensated shots: When taking an outdoor shot, avoid facing the sun, as the image may be dark because of the strong backlight. To take a picture against the sun, please use the [BACKLIGHT] in the scene shooting mode (see page 25), Fill-in flash (see page 40), Spot metering (see page 50), or Exposure compensation (see page 60).
- Avoid obstructing the lens or the flash when you capture an image.
- As there can be some differences between what is seen through the Viewfinder and the resulting image when taken at a range closer than 1.5m, it is recommended that you use the LCD monitor to compose these shots.
- Using the LCD monitor extensively will drain the batteries.  
We recommend turning off the LCD monitor and using the optical viewfinder as often as possible in order to extend battery life.
- Under certain conditions the auto focus system may not perform as expected.
  - When photographing a subject that has little contrast.
  - If the subject is highly reflective or shiny.
  - If the subject is moving at high speed.
  - When there is strong reflected light, or when the background is very bright.
  - When the subject matter has only horizontal lines or the subject is very narrow (such as a stick or flagpole).
  - When the surroundings are dark

## Using the camera buttons to adjust the camera

- The RECORDING(AUTO, PROGRAM, A/S/M, MySET, VOICE RECORDING, MOVIE CLIP, NIGHT SCENE , SCENE) mode function can be set up by using the camera buttons.


### POWER switch

- Used for turning the camera's power on / off.  
Push the power switch to turn the power on
- If there is no operation during the specified time, the camera's power will be turned off automatically to save battery life. **Push the power switch and hold it for 3 seconds to turn the power on without the 'start' sound.**




### SHUTTER button

- Used for taking an image or recording voice in the RECORDING mode.
- In MOVIE CLIP mode : Pressing the shutter button down fully starts the process for recording a movie clip. Press the shutter button once and the movie clip is recorded for as long as the available recording time in the memory allows. If you wish to stop recording, press the shutter button again.
- In STILL IMAGE mode  
Pressing the shutter button down halfway activates the auto focus and checks the condition of the flash.  
Pressing the shutter down fully takes the image and stores the relevant data regarding the shot. If you select voice memo recording, the recording will start after the camera has finished storing the image data.



## ZOOM W/T button

- **Press the W/T buttons to browse between menu tabs in 5 steps while using a menu screen in the Program, A/S/M, or MySET shooting modes.**
- If the menu is not displayed, this button works as the OPTICAL ZOOM or DIGITAL ZOOM button.



# ZOOM W/T button

D430 27페이지

- This camera has a 3X optical zoom and a 4X digital zoom function. Using both will offer a total zoom ratio of 12X.


## ● TELE Zoom

Optical zoom TELE

: Pressing the ZOOM T button. This will zoom into the subject i.e. the subject will appear nearer.

Digital zoom TELE



: When the maximum (3X) optical zoom is selected, pressing the ZOOM T button activates the digital zoom software. Releasing ZOOM T button stops the digital zooming at the required setting. Once the maximum digital zoom (4X) is achieved, pressing the ZOOM T button will have no effect.



## ● WIDE Zoom


Optical zoom WIDE

: Pressing the ZOOM W button. This will zoom out from the subject i.e. the subject will appear further away. Pressing the ZOOM W button continuously will set the camera to its minimum zoom setting i.e. the subject appears at its furthest from the camera.



Digital zoom WIDE

: When the digital zoom is in operation, pressing the ZOOM W button will reduce the digital zooming in steps. Releasing ZOOM W button stops digital zooming. Pressing the ZOOM W button will reduce the digital zoom and then it will continue to reduce the optical zoom until the minimum setting is reached.



## ZOOM W/T button


D430 28페이지

### INFORMATION

- To use the digital zoom the LCD monitor has to be turned on.
- Images taken using the digital zoom may take a little longer for the camera to process. Allow time for this to take place.
- Digital Zoom will not work in Night Scene mode.
- You may notice a decrease in image quality when using the digital zoom.
- You can record with digital zoom in MOVIE CLIP mode; you can use the digital zoom while recording movie clips.
- Do not use the zoom button while recording video, to avoid accidentally recording the clicking sound. Please adjust the zoom before starting to record.
- Take care not to touch the lens to avoid taking an unclear image and possibly causing camera malfunction.  
If the image is dim, turn the camera power off and on again to modify the lens position.
- Take care not to press the lens as this may cause a camera malfunction.
- When the camera is turned on, take care not to touch the camera's moving lens parts as this may cause the resulting image to be dim and unclear.
- Take care not to touch the lens during zoom operation as this may cause damage.

### Voice memo(🗣️)/ UP button

- While the menu is showing, press the UP button to move up the submenu cursor.
- When the menu is not displayed on the LCD monitor, the UP button operates as the voice memo button. You can add your voice-over to a stored still image.
- Recording a voice memo
  1. Rotate the MODE DIAL to select a RECORDING mode with the exception of MOVIE CLIP and VOICE RECORDING modes.
  2. Press the VOICE MEMO(🗣️) button. If the voice memo indicator is displayed on the LCD monitor, the setting is completed.



[ Preparing for Voice Memo ]



[ Recording Voice Memo ]

## Voice memo(🎤)/ UP button

3. Press the shutter button and take a picture. The picture is stored on the memory card.
4. Voice memo will be recorded for ten seconds from the moment the picture is stored.  
In the middle of the sound recording, pressing the shutter button will stop the voice memo.

## INFORMATION


- A distance of 40cm between you and the camera (microphone) is the best distance to record sound.

## MACRO (🌸) / SUPER MACRO (🔍) button

- When the menu is displayed on the LCD monitor, pressing the DOWN button makes the menu cursor move down or changes the sub menu value.
  - When the menu is not displayed on the LCD monitor, the button operates as the MACRO (🌸) / SUPER MACRO (🔍) button. The photography range is 0.06m ~ 0.8m.
- Selecting the MACRO/ SUPER MACRO
    1. Rotate the mode dial to the RECORDING (except SCENE, NIGHT SCENE, VOICE RECORDING) mode.
    2. Press the MACRO button. The macro indicator will be displayed on the LCD monitor.  
Press the MACRO button until the desired MACRO mode indicator displays on the LCD monitor.



[ Selecting the macro mode ]



[ Selecting the super macro mode ]

3. Take a picture with the desired macro mode.

## MACRO (🌱) / SUPER MACRO (🔍) button

- Types of focus modes and focus ranges (W: WIDE, T: TELE)

Types of focus modes	Normal	Macro		Super Macro	
Range	0.8 ~ ∞	W:0.3~0.8m	T:0.5~0.8m	W:0.06~0.3m	T:-

신규  
V4 페이지 39 참고

### INFORMATION

- When the macro or super macro mode is selected, It is possible that camera shake will occur. If this is the case, use a tripod to eliminate this.
- When super macro is selected, the flash mode is changed to Flash off automatically.
- The super macro can be activated only in the wide zoom mode.
- You cannot use the zoom(wide/tele) button in the super macro mode.


- Available focusing method, by recording mode.  
(O: Available, X: Not available, ∞: Infinite Focus)

	📷	P	A/S/M	MySET	📹	📺	SCENE									
							🌿	👤	🏔️	🌸	🍷	🍷	👤	🌌	🌊	
Auto	O	O	O	O	O	O	O	O	∞	X	∞	∞	O	∞	O	
🌱	O	O	O	O	O	X	X	X	X	X	X	X	X	X	X	
🔍	O	O	O	O	O	X	X	X	X	O	X	X	X	X	X	

# Focus lock

430 30p

- To focus on the subject positioned outside of the center, use the focus lock function.
- Using the Focus Lock
  1. Ensure the subject in the center of the autofocus frame.
  2. Press the SHUTTER button halfway. When the green auto lights up, it means the camera is focused on the subject. Be careful not to press the SHUTTER button all the way down to avoid taking an unwanted pictured.
  3. With the SHUTTER button still pressed down only halfway, move the camera to recompose your picture as desired, and then press the SHUTTER button completely to take the picture. If you release your finger from the SHUTTER button, the focus lock function will be canceled.





## FLASH(⚡) / LEFT button 430 31p

■ When the menu is displayed on the LCD monitor, pressing the LEFT(◀) button makes the cursor shift to the left tab.

■ When the menu is not displayed on the LCD monitor, the LEFT button operates as the FLASH (⚡) button.

● Selecting the flash mode

1. Rotate the MODE DIAL to select a RECORDING mode with the exception of MOVIE CLIP and VOICE RECORDING modes.

2. Press the Flash(⚡) button until the desired flash mode indicator displays on the LCD monitor.

3. A flash mode indicator will be displayed on the LCD monitor. Use the correct flash to suit the environment.



[ Selecting the Auto & Red eye reduction flash ]

● Flash range

Unit : m

ISO	AUTOFOCUS		MACRO	
	WIDE	TELE	WIDE	TELE
AUTO	0.8 ~ 3.0	0.8 ~ 2.0	0.3 ~ 0.8	0.5 ~ 0.8

## INFORMATION

- Using the flash frequently will reduce the life of the batteries.
- Under normal operating conditions the charging time for the flash is normally within 7 seconds. If the batteries are weak, the charging time will be longer.
- During the super macro, continuous shot, manual focus (6 to 30cm), movie clip mode, the flash function will not operate.
- Take photographs within the flash range.
- The image quality is not guaranteed if the subject is too close or highly reflective.

# FLASH(⚡) / LEFT button 430 32p



● Flash mode indicator

ICON	Flash mode	Description
	Auto flash	If the subject or background is dark, the camera flash will operate automatically.
	Auto & Red eye reduction	If a subject or background is dark, the camera flash will work automatically and will reduce the red-eye effect by using the red-eye reduction function.
	Fill in flash	The flash fires regardless of available light. The intensity of the flash will be controlled, according to the prevailing conditions. The brighter the background or subject is, the less intense the flash will be.
	Slow synchro	The flash will operate in conjunction with a slow shutter speed in order to obtain the correct exposure. We recommend using a tripod for this function. When you take an image in a condition with poor light, the camera shake warning indicator (  ) will display on the LCD monitor.
	Flash off	The flash does not fire. Select this mode when capturing images in a place or situation where flash photography is prohibited. When you capture an image in a poorly lit condition, the camera shake warning indicator (  ) will display on the LCD monitor.

● Available flash mode, by recording mode

			A/S/M	MySET			SCENE									
	X	O	O	O	X	X	X	X	X	X	X	X	X	X	X	O
	O	O	O	O	X	X	O	O	X	X	X	X	X	X	X	X
	X	O	O	O	X	X	X	X	X	X	X	X	O	X	X	X
	X	O	O	O	X	O	X	X	X	X	X	X	X	X	X	X
	O	O	O	O	X	O	X	X	O	O	O	O	X	O	X	X

# SELF-TIMER / REMOTE button

- When the menu is displayed on the LCD monitor, pressing the RIGHT button makes the cursor shift to the sub menu.
- When the menu is not displayed on the LCD monitor, the RIGHT button operates as the SELFTIMER (  ) / REMOTE (  ) button. This function is used when the photographer would also like to be in the image.
- Selecting the self-timer
  1. Rotate the mode dial to the RECORDING mode.  
 Note that only remote controller shooting is available in the voice recording mode.
  2. Press the SELF-TIMER button until the desired mode indicator displays on the LCD monitor.






[ Selecting the 2sec. self-timer mode ]



[ Selecting the remote mode ]

- Selecting the self-timer mode :  
Pressing the shutter button will allow an interval of ten seconds before the image is taken. After that, the self-timer is cancelled.
- Selecting the remote mode :  
Pressing the shutter button in the remote controller will allow an interval of 2 seconds before the image is taken. In the remote mode, you cannot use the shutter button.

● Self-timer/ remote mode definition

Icon	Mode	Definition
	2s	Pressing the shutter button will allow an interval of 2 seconds before the image is taken.
	10s	Pressing the shutter button will allow an interval of 10 seconds before the image is taken.
	Remote mode	You can take a picture with the remote controller.

# SELF-TIMER / REMOTE button

● Self-timer/ remote mode setting

Mode dial	Setting ( <input type="checkbox"/> marked camera working mode is the default setting.)
AUTO	<input type="checkbox"/> Off → 2s self-timer → 10s self-timer → Remote
PROGRAM	
A/S/M, MySET	
MOVIE CLIP	
NIGHT SCENE, SCENE	
VOICE RECORDING	<input type="checkbox"/> Off → Remote

## INFORMATION

● Self-timer lamp


In 10s self-timer : For the first seven seconds, the LED blinks at one second intervals.  
 For the final three seconds, the LED blinks quickly at 0.25 second intervals.

In 2s self-timer : The LED blinks at 2second intervals

- If you operate the Power switch, Mode dial, and Self-timer button during the self-timer operation, the self-timer function is cancelled.
- Use a tripod to prevent the camera from shaking.

● Remote control range


When you take a picture by using the remote control, refer to the illustrations shown alongside about the remote control range.



## SELF-TIMER / REMOTE button

### ● Changing the remote controller battery


Check the polarity while installing the remote controller batteries. The + polarity must be upward. Contact your dealer or Samsung camera service center to buy the battery.  
The battery type is CR 2025 3V.



## MENU/ OK button

### ■ MENU button

- When you press the MENU button, a menu related to each camera mode will be displayed on the LCD monitor. Pressing it again will return the LCD to the initial display.
- A menu option can be displayed when the following are selected. AUTO, PROGRAM, A/S/M, MySET, MOVIE CLIP, NIGHT SCENE and SCENE. There is no menu available when the VOICE RECORDING mode is selected.



### ■ OK button

- When the menu is displayed on the LCD monitor, this button is used for shifting the cursor to the sub menu or for confirming data.

## INFORMATION

- The menu will not be displayed on the LCD monitor in the following circumstances:
  - When another button is being operated.
  - While image data is being processed. ( when the green LED next to the viewfinder blinks)
  - When there is no battery capacity.
- When the menu is showing on the LCD monitor, it is not possible to operate the shutter button i.e. take an image, simply cancel the menu display by pressing the MENU button.

# MF button

신규

- In dark conditions, the autofocus may not function. If this occurs, press the MF button and you can select manual focus.
- Carefully set the focus, using the MF button for focusing. If the focus is not accurate, the picture may be blurred. Please set manual focusing carefully.
- Use the MF button in A/S/M mode to change the Aperture value and Shutter speed.

## ● Focusing


1. Press the MF button and use the Left/Right buttons to select automatic or manual focusing.
2. The MF bar is displayed if manual focusing is selected.  
Use the Up/Down buttons to set the desired distance.
  - Pressing the UP button : Focus at long range.
  - Pressing the DOWN button : Focus at close range.
3. After setting the manual focus, press the Menu/OK button to confirm.  
The MF bar disappears and the MF icon is displayed in the bottom of the LCD.



[Select Auto Focusing]



[Select Manual Focusing]



[After Setting the Manual Focus]

- Available options for each shooting mode  
(Available: O, Not available: X)

	AUTO	PROGRAM	A/S/M	MySET	VOICE RECORDING	MOVIE CLIP	NIGHT SCENE	SCENE
Auto focus	X	○	○	○	X	○	○	○
Manual focus	X	○	○	○	X	○	○	X

# MF button

신규

## INFORMATION

- The manual focus function is disabled in the AUTO and VOICE RECORDING mode.
- The MF bar is divided into 3 parts according to the photography range.

Part of the MF bar	Photography range
1st part	0.8m ~ 무한대
2nd part	0.3m ~ 0.8m
3rd part (only in wide zoom mode)	0.06m ~ 0.3m

- When the photography range is within 0.06m ~ 0.3m, the flash mode is changed to FLASH OFF automatically.
- The focus value displayed in the LCD while manually focusing is measured from the end of the lens.

■ The MF button is used as described below in A/S/M mode.

● A mode (Aperture priority mode)

1. Press the MF button. Aperture value in the LCD goes red.
2. Use the Left/Right buttons to set the desired Aperture value.
3. During the super macro, continuous shot, manual focus (6 to 30cm), movie clip mode, the flash function will not operate.

- Pressing the MF button: Saves the new aperture value and displays the focus adjust icon (◀AF▶). To set manual focusing, set the distance as shown in page 38.

To set automatic focusing, press the MF button again.

- Pressing the Menu/OK button: The camera goes into shooting mode after saving the new aperture value.

\* Smaller Aperture values make the object sharp but blur the background.

Larger Aperture values make both the object and background sharp.

\* Toggle the MF button in step 1 to select Aperture set (Red) → Focusing (AF Red) → Aperture priority mode (White)



## MF button

신규

### ● S mode(Shutter priority mode)

1. Press the MF button and wait for the shutter speed value in the LCD to go red.
2. Use the Left/Right buttons to set the desired shutter speed value.
3. Press the MF or Menu/OK button to save the selected values.

- Pressing the MF button: Saves the new shutter speed and displays the focus adjust icon ( ◀AF ▶).

To set manual focusing, set the distance as shown in page 38. To set automatic focusing, press the MF button again.

- Pressing the Menu/OK button: The camera goes into shooting mode after saving the new shutter speed.

\* High Shutter speeds can capture a moving object in a still image as if the object is not moving.

Low Shutter speeds can capture a moving object with an 'active' effect.

\* Toggle the MF button in step 1 to select Shutter speed → Focusing ( ◀AF ▶: Red) → Shutter priority mode (White)



### ● M mode (Manual mode): manually set the Aperture value, Shutter speed, and Focusing.

1. Both Aperture value and Shutter speed are displayed in the LCD.

2. Press the MF button and wait for the Aperture value to go red.

3. Use the Up/Down/Left/Right buttons to select the sub menu option.

- Up/Down buttons: select the Aperture value or Shutter speed.

- Left/Right buttons: Change the values

4. Press the MF or Menu/OK button to save the selected values.

- Pressing the MF button: Saves the new aperture value / shutter speed and displays the focus adjust icon ( ◀AF ▶). To set manual focusing, set the distance as shown in page 38. To set automatic focusing, press the MF button again.

- Pressing the Menu/OK button: The camera goes into shooting mode after saving the new aperture value / shutter speed.

\* Both the Shutter speed and Aperture value can be set.

\* Toggle the MF button in step 1 to select Shutter speed/Aperture set (Red) → Focusing ( ◀AF ▶: Red) → Manual shooting mode (White)





## MF button

If the aperture value or shutter speed is out of the limit of application, the value that is displayed on the LCD monitor will show as red. However, you will still be able to take a picture.

Please adjust the shutter speed and aperture value so that the red warning turns white (normal) before taking the picture.



## +/- button

### D430 페이지 34 하단

- You can use the +/- button to adjust the values for the RGB, ISO, white balance, exposure compensation and Long Time shutter speed.


Main menu	Sub menu	Available camera mode
RGB	R (Red), G (Green), B (Blue)	P A/S/M MySET SCENE ( )
ISO	AUTO, 50, 100, 200, 400	P A/S/M MySET
WHITE BALANCE	AUTO, DAYLIGHT, CLOUDY, FLUORESCENT H, FLUORESCENT L, TUNGSTEN, CUSTOM.	P A/S/M MySET SCENE ( )
Exposure compensation	-2.0~0.0~+2.0(0.5EV steps)	P A/S/M MySET SCENE ( )
Shutter speed/ Aperture value	Changed by zoom scale	A/S/M

- RGB : Allows the user to adjust the R (Red), G (Green), and B (Blue) values of the images to be captured.

#### ● Setting RGB Values

### D430 페이지 35 상단

1. Press the +/- button, and then use the UP and DOWN buttons to select the RGB icon ( RGB ).  
The RGB menu bar will appear as shown.
2. Use the UP/ DOWN/ LEFT and RIGHT buttons to select the desired RGB value.
  - Up/Down Button: Navigates between R, G, and B icons.
  - Left/Right Button: Changes value of each icon.
3. When you press the +/- button again, the value you set will be saved and RGB setupmode will end.




## +/- button

Uca3 33 하단

- ISO: You can select the ISO sensitivity when taking pictures.

The speed or specific light-sensitivity of a camera is rated by ISO numbers.

- Selecting an ISO Sensitivity

1. Press the +/- button, and then use the UP button to select the ISO icon(  ). The ISO menu bar will appear as shown.
2. Use the LEFT and RIGHT buttons to select the desired ISO sensitivity value.

- AUTO :

The camera's sensitivity is automatically changed by variables such as lighting value or subject brightness.

- 50, 100, 200, 400 :


You can increase the shutter speed while the same amount of light is present, by increasing the ISO sensitivity. However, the image may be saturated in high luminance. The higher the ISO value, the higher the camera's sensitivity to light is and therefore the greater its capacity to take pictures in dark conditions. However, the noise level in the image will increase as the ISO value increases, making the image appear coarse.


3. When you press the +/- button again, the value you set will be saved and ISO setup mode will end.


D 430 페이지 35

- White balance : The white balance control allows you to adjust the colours to appear more natural looking.


- Selecting a White Balance


1. Press the +/- button, and then use the UP and DOWN buttons to select the white balance icon (  ). The white balance menu bar will appear as shown.
2. Use the LEFT and RIGHT buttons to set the white balance to the desired value. The value you set will be displayed on the LCD monitor.


AUTO       : The camera automatically selects the appropriate white balance settings, depending on the prevailing lighting conditions.


DAYLIGHT       : For taking images outside.

CLOUDY       : For taking images under a cloudy and overcast sky.

Fluorescent H       : For shooting under daylight fluorescent types of three-way fluorescent lighting.


Fluorescent L       : Shooting under white fluorescent lighting.

TUNGSTEN       : For shooting under tungsten (standard light bulb) lighting.

CUSTOM       : Allows the user to set the white balance according to the shooting condition.


Different lighting conditions may cause a colour cast on your images.



3. Press the +/- button again. The value you set will be saved and White Balance setup mode will end.



### ● Using the Custom White Balance

White balance settings may vary slightly depending on the shooting environment. You can select the most appropriate white balance setting for a given shooting environment by setting up the custom white balance.



1. Select the CUSTOM (  ) menu of the White Balance.
2. Place a sheet of white paper in front of the camera so that the LCD monitor shows only white, and then press the SHUTTER button.
3. Your custom white balance value is stored.
  - The custom white balance value will be applied, starting with the next picture you take.
  - The user configured white balance will remain effective until it is overwritten.



[ White paper ]

- Exposure compensation : This camera automatically adjusts the exposure according to the ambient lighting conditions. You can also select the exposure value by using the +/- button.

### ● Compensating Exposure

1. Press the +/- button, and then use the UP and DOWN buttons to select the exposure compensation icon (  ). The exposure compensation menu bar will appear as shown.
  2. Use the LEFT and RIGHT buttons to set the desired exposure compensation factor.
  3. Press the +/- button again. The value you set will be saved and the Exposure Compensation setup mode will close. If you change the exposure value, the exposure indicator (  ) will be displayed on the bottom of the LCD monitor.
- \* A negative exposure compensation value reduces the exposure.  
Note that a positive exposure compensation value increases the exposure and the LCD monitor will appear white or you may not get good pictures.



## +/- button

- Long Time shutter : This camera automatically adjusts the shutter speed and aperture values to the shooting environment. However, in NIGHT SCENE mode, you can set the shutter speed and aperture values to your preference.

- Adjusting the shutter speed and aperture values

1. Select the NIGHT SCENE mode by rotating the mode dial.
2. Press +/- button and Long Time shutter menu (LT, For selecting shutter speed and aperture value) will be displayed.
3. Configure the Long Time shutter value with the up/down/ left/ right button.




- Up/ Down Button: Select the iris / shutter speed  
Left/ Right Button: Change the value. Available iris value options, depending on zoom step will be displayed on the menu.
4. Press the +/- button again. The value you set will be saved and the mode will switch to NIGHT SCENE mode. Press the SHUTTER button to take the picture.

- Aperture values that can be selected for each zoom position are as follows :

Supported Aperture Values: AUTO/F2.8-F11



Supported Shutter Speeds: AUTO/1/2,000 ~ 15S



## LCD button

- You can check the recording status in the LCD monitor.

Toggle the LCD button in shooting mode (except in voice recording and movie clip modes) to display the next LCD information displayed.



- If the LCD monitor is turned off, the mode dial lamp will light up.

## Using the LCD monitor to adjust the camera settings







- You can use the menu on the LCD monitor to set up recording functions. In any mode with the exception of VOICE RECORDING mode, pressing the MENU button displays the menu on the LCD monitor.

### INFORMATION








- The menu will not be displayed on the LCD monitor in the following circumstances:
  - When another button is being operated.
  - While image data is being processed.  
(when the green LED next to the viewfinder blinks)
  - When there is no battery capacity.
- When the menu is showing on the LCD monitor, it is not possible to operate the shutter button i.e. capture an image. To capture an image, simply cancel the menu display by pressing the MENU button.

- The following functions are available, depending on the mode you have selected.

The items indicated by  are default settings.

Menu tab	Main menu	Sub menu	Camera working mode	Page
	SIZE	<span style="background-color: #cccccc;">2560X1920</span>	AUTO PROG A/S/M MySET  SCENE	p.41
		2272X1704		
		2048X1536		
		1600X1200		
		1024X768		
		640X480		
		<span style="background-color: #cccccc;">640X480</span>		
		320X240		
	QUALITY	TIFF	AUTO PROG A/S/M MySET  SCENE	p.41
		S. FINE		
		<span style="background-color: #cccccc;">FINE</span>		
		NORMAL		
		<span style="background-color: #cccccc;">30 1/3초</span>		
		15 1/3초		
				
	METERING	<span style="background-color: #cccccc;">MULTI</span>	PROG A/S/M MySET	p.42
		SPOT		

## Using the LCD monitor to adjust the camera settings

Menu tab	Main menu	Sub menu	Camera working mode	Page
	SHOOTING	SINGLE	<b>AUTO</b> PROG A/S/M MySET	p.43
		2 SHOTS		
		4 SHOTS		
		8 SHOTS		
	EFFECT	NORMAL	PROG A/S/M MySET 	p.44
		B & W		
		SEPIA		
	SHARPNESS	SOFT	PROG A/S/M MySET 	p.44
		NORMAL		
		VIVID		
	A/S/M	A	A/S/M	p.44
		S		
		M		
	SCENE	PORTRAIT	SCENE	p.44
		CHILDREN		
		LANDSCAPE		
		CLOSE-UP		
		SUNSET		
		DAWN		
BACKLIGHT	FIREWORKS	BEACH&SNOW		

\* Menus are subject to change without prior notice.


# How to use the menu

D 430 페이지40 하단

1. Turn on the camera and press the MENU button. A menu for each camera mode appears. However, there is no menu for Voice Recording mode ( ).
2. Use the LEFT and RIGHT buttons to navigate through the menus.



3. Use the UP and DOWN buttons to select a sub menu.




4. Select a sub menu, and then press the OK button. The value you set will be saved and the menu will disappear.

## Size


D430 페이지41 상단

- You can select the image size appropriate for your application.

Mode	STILL IMAGE mode						MOVIE CLIP mode	
Icon	2560	2272	2048	1600	1024	640	640	320
Size	2560X1920	2272X1704	2048X1536	1600X1200	1024X768	640X480	640X480	320X240



[ AUTO mode ]



[ MOVIE CLIP mode ]

## INFORMATION

- The higher the resolution, the lower the number of available shots will be because high resolution images require more memory than lower resolution images.



# Quality


Uca3 39페이지

- You can select the compression ratio appropriate for your application of the captured images.  
The higher the compression ratio, the lower the picture quality.

Mode	STILL IMAGE mode				MOVIE CLIP mode	
Icon	TIFF					
Sub menu	TIFF	S.FINE	FINE	NORMAL	30FPS	15FPS
	tiff	jpeg	jpeg	jpeg	avi	avi



[ AUTO mode ]



[ MOVIE CLIP mode ]


## INFORMATION


- TIFF is the highest quality and NORMAL is the lowest setting.  
Choose the setting appropriate for your needs.
- TIFF format is an uncompressed image file format for an expert. If you take a picture with the TIFF file format, the number of available shots is decreased and the time for recording the image file will be longer because the TIFF file size is bigger than the JPG file format.
- When the TIFF file is being recorded to the memory card, a [PLEASE WAIT!] message will be displayed on the LCD monitor.
- This file format complies with the DCF(Design rule for Camera File system).
- JPEG (Joint Photographic Experts Group): JPEG is the image compression standard developed by the Joint Photographic Experts Group. This type of compression is most commonly used for compressing photos and graphics because it can compress the files efficiently without damaging the data.


## Metering

Uca3 40페이지 상단

- If you cannot obtain suitable exposure conditions, you can change the metering method to take brighter pictures.

MULTI(  ) : Exposure will be calculated based on an average of the available light in the image area. However, the calculation will be biased towards the centre of the image area. This is suitable for general use.

SPOT(  ) : Only the rectangular area in the center of the LCD monitor will be metered for light. This is suitable when the subject in the center is exposed correctly, regardless of the back lighting.



## INFORMATION

- The default metering mode is Multi pattern metering.
- If the subject is not the centre of the focus area, do not use the spot metering as this may result in an exposure error. In this circumstance, rather use exposure compensation.

## Continuous shot

D430 페이지 43 상단

- Select the number of pictures in sequential shooting
  - [SINGLE] : Take one picture only
  - [2, 4, 8 SHOTS] : Take the set number of pictures with one push of the shutter. Continuous shooting mode is cleared after one shooting.



[ PROGRAM mode ]

# Continuous shot

D430 페이지 43 하단

- Available maximum number of continuous shots, by image size/ quality type (Unit : shot)

size \ quality	TIFF	S.FINE	FINE	NORMAL
2560X1920	1	2	2	2
2272X1704	1	2	2	2
2048X1536	1	2	2	2
1600X1200	1	2	2	4
1024X768	1	4	8	8
640X480	1	8	8	8


\* High resolution and picture quality increases file saving time, which increases stand-by time.

\* Select [SHOOTING] menu to inactivate the flash.


\* Changing the image size after continuous shooting will clear the continuous shooting you set.

## Effect

- By using the camera's digital processor, it is possible to add special effects to your images.



[ PROGRAM mode ]



[ MOVIE CLIP mode ]

NORMAL : No effect is added to the image.


B & W : Converts the image to black and white.

SEPIA : Captured images will be stored in a sepia tone (a gradient of yellowish brown colours).

# Sharpness

D430 페이지 44 상단

- You can adjust the sharpness of the picture you want to take. You cannot check the sharpness effect on the LCD monitor before you take a picture, because this function is applied only when the captured image is stored on the memory.




[ PROGRAM mode ]

Sub menu	Icon	Description
SOFT		The edges of the image are softened. This effect is suitable for editing images on your PC.
NORMAL		The edges of the image are sharp. This is suitable for printing.
VIVID		The edges of the image are emphasized. The edges will appear sharp, but noise may occur in the recorded image.

# A/S/M

- In this mode you can select the shutter speed or aperture value to your preference. The menu is available in A, S, and M modes. Please see page 39 and 40 for details of each mode.

1. Rotate the mode dial to the A/ S/ M mode and press the MENU button.
2. Select [ASM] menu by pressing the LEFT/RIGHT button.
3. Select the desired sub menu by pressing the UP/DOWN button.




- A mode (Aperture priority) :  
You can select the aperture value in this mode.  
The camera calculates the best shutter speed automatically to the proper exposure value.
  - S mode (Shutter priority) :  
You can select the shutter speed in this mode. The camera calculates the best aperture value automatically to the proper exposure value.
  - M mode (Manual) :  
You can select the shutter speed and the aperture value in this mode.
4. Press the OK button to save the desired shooting mode.

# Scene


D430 44페이지


- Select the [SCENE] submenu to automatically configure optimal settings, depending on the selected scene. Only available in the Scene Mode.



Sub menu	Icon	Description
PORTRAIT		To take picture of a person.
CHILDREN		Take a still picture of capturing moving children.
LANDSCAPE		Scenery with green woods or blue sky. Portrait with scenery background.
CLOSE-UP		Close-up shooting for small objects such as plants and insects.
SUNSET		Splendor of the setting sun.
DAWN		Daybreak scenes.
BACKLIGHT		Portrait without shadows caused by back light.
FIREWORKS		Firework scenes.
BEACH & SNOW		For ocean, lake, and beach scenes, and snowscapes.

## Starting play mode


- Turn the camera on and select Play mode by pressing the play mode button (  ).  
The camera can now play back the images stored in the memory.
- Push the power switch to turn the camera power on. Press the play mode button once to switch to play mode. Press the play mode button again to switch to shooting mode.
- You can turn the power on with the play mode button. The camera is turned on in play mode. Press the play mode button again to turn the power off. Switch the mode dial to change to another shooting mode while the camera is on.
- You can set up the PLAY mode function by using the camera buttons and LCD monitor.
- If you press PLAY button to switch to Play mode, the camera lens will retract into the camera body for protection of the lens in about 10 seconds.

- Playing back a still image
  1. Select the PLAY mode by pressing the play mode button (  ).

2. The last image stored on the memory is displayed on the LCD monitor.

3. Select an image that you want to play back by pressing the LEFT / RIGHT button.

※ Press and hold the Left or Right button to fast forward the images played.




### INFORMATION


- Manner mode : Pressing the power button for more than 3 seconds changes the buzzer and start-up sound setting to OFF, even though you may have set these to ON.
- Even if the camera's power is off, you can start the play mode by pressing the play mode button.
- Lightly press the shutter button in Play mode to switch to the currently set shooting mode with the mode dial. (Except while playing a paused voice memo or movie clip.)

## Starting play mode

### ■ Playing back a movie clip

Steps from 1-2 are the same as those to play back a still image.

3. Select the recorded movie clip that you want to play back by using the LEFT/RIGHT button. If you select a movie clip, the movie clip indicator (  ) will be displayed on the LCD monitor.


4. Press the play & pause button (  ) to play back a movie clip file.

- To pause a movie clip file while playing it back, press the play & pause button again.

- Pressing the play & pause button again will cause the movie clip file will restart.

- To rewind the movie clip while it is playing, press the LEFT button. To fast forward the movie clip, press the RIGHT button.

- To stop playback of the movie clip, press the play & pause button, and then press the LEFT or RIGHT button.



### ■ Movie clip capture function: capture still images from the movie clip.

● Steps 1-2 are the same as those for playing back a still image.

3. Select the recorded movie clip that you want to play back by using the LEFT/RIGHT button.

4. Press the Play/Pause button to play the movie clip


5. Press the Play/Pause button while playing the movie clip. Then press the Shutter button.

6. The paused movie clip is saved in a new file name.

\* The captured movie clip file has same size as the original movie clip (640X480 or 320X240)



[ Paused ]





[ Press the shutter button ]

## Starting play mode


### ■ Playing back a recorded voice

Steps from 1-2 are the same as those to play back a still image.

3. Select the recorded voice that you want to play back by using the LEFT/RIGHT button. If you select a recorded voice file, the voice indicator (  ) will be displayed on the LCD monitor.

4. Press the play & pause button (  ) to play back a recorded voice file.

- To pause a recorded voice file, while playing it back, press the play & pause button again.
- To resume playback of the voice file, press the play & pause button.
- To rewind the voice file while it is playing, press the LEFT button. To fast forward the voice file, press the RIGHT button.
- To stop playback of the voice file, press the play & pause button, and then press the LEFT or RIGHT button.






# LCD monitor indicator

D430 47페이지

■ The LCD monitor displays information about the shooting conditions.



No.	Description	Icon	Page
1	Battery		p.16
2	Play mode		
3	File Type		
4	Voice memo		p.49
5	Protect indicator		p.55
6	DPOF indicator		p.58
7	Stored image number	9	
8	TIFF file	<b>TIFF</b>	

■ If you press the LCD button, you can check the following recording information:



SIZE	: 2560X1920	Size
AV	: F2.8	Aperture value
TV	: 1/30	Shutter speed
ISO	: 50	ISO sensitivity
FLASH	: OFF	Whether or not the flash is used.
DATE	: 2004/03/01	Recording date

## Using the camera buttons to adjust the camera


- In Play mode, you can use the buttons on the camera to conveniently set up the Play mode functions.



D430 48페이지

### Thumbnail ( ) / Enlargement ( ) button

- You can view multiple pictures, enlarge a selected picture, and crop and save a selected area of an image.


- Thumbnail display

1. While an image is displayed full screen, press the thumbnail button.
2. The thumbnail display will highlight the image that had been showing at the time the thumbnail mode was selected.
3. Press the 5 function button to move to a desired image.
4. To view an image separately, press the enlargement button (  ).



- Image enlargement

1. Select an image that you want to enlarge and press the enlargement button.
2. Different parts of the image can be viewed by pressing the 5 function button.
3. Pressing the thumbnail button will zoom back to the original full sized image.
  - You can tell whether the image displayed is an enlarged view by checking the image enlargement indicator shown at the bottom left of the LCD monitor. (If the image is not an enlarged view, the indicator will not be displayed.) You can also check the area of enlargement.
  - TIFF, Movie clips and WAV files can't be enlarged.
  - If an image is enlarged, a loss of quality may occur.



## Thumbnail( ) / Enlargement( ) button

- The maximum enlargement rate in proportion to the image size.

Image size	2560	2272	2048	1600	1024	640
Maximum enlargement rate	×10	×8.8	×8.0	×6.2	×4.0	×2.5

- Trimming : You can extract part of the image that you want and save it separately.

1. Select an image that you want to enlarge and press the enlargement button.
2. Different parts of the image can be viewed by pressing the 5 function button.
3. Press the MENU button and a message will be displayed as shown alongside.
4. Press the OK button to save the trimmed image with a new file name.



The trimmed image will be displayed on the LCD monitor.

Press the LEFT button to return to the image before it was selected.


- If there is little memory space to save the trimmed image, the image can't be trimmed.

\* Trimming is not available for TIFF images

## Voice ( ) memo / Up button

- When the menu is displayed on the LCD monitor, pressing the UP button makes the menu cursor move up.
- When the menu is not displayed on the LCD monitor, the UP button operates as the voice memo button. You can add your voice to a stored still image.


- Adding a Voice Memo to a Still Image

1. Press the LEFT/ RIGHT button to select an image that you wish to add sound to.
2. Press the voice memo button (  ) and the voice memo indicator will display. The camera is now ready to record a voice memo.




## Voice ( ) memo / Up button D430 50 페이지

3. Press the shutter button to start recording and voice will be recorded to the still image for 10 seconds. While the voice is recording, the recording status window will be displayed as shown alongside.



4. The recording can be stopped by pressing the shutter button again.

5. The (  ) icon will be displayed on the LCD monitor after voice memo recording has finished.


- Voice memos can't be recorded onto movie clip files.
- A distance of 40cm between you and the camera (microphone) is the best distance to record sound.
- The voice memo will be saved in \*.wav format, but has the same file name as the still image to which it corresponds.
- If you add a new voice memo to the still image that already has a voice memo, the existing voice memo will be erased.




## Play & Pause ( ) / Down button

■ In Play mode, the play & pause/ down button works as follows:


- If the menu is displayed  
Press the DOWN button to move from the main menu to a sub menu, or to move down the sub menu cursor.
- If a still image with a voice memo, a voice file, or a movie clip is playing  
In Stop mode : Plays a still image with a voice memo, a voice file, or a movie clip.  
During playback : Temporarily stops playback.  
In Pause mode : Resumes playback



[ Voice recording is stopped ]



[ Voice file is playing ]



[ Voice recording is paused ]

## LEFT/ RIGHT/ MENU/ OK button


■ LEFT / RIGHT/ MENU/ OK buttons activate the following.



- LEFT button : While the menu is showing, press the LEFT button to select the menu tab to the left of the cursor.
- RIGHT button : While the menu is showing, press the RIGHT button to select the menu tab to the right of the cursor, or to move an secondary menu.
- MENU button : When you press the MENU button, the play mode menu will be displayed on the LCD monitor. Pressing it again will return the LCD to the initial display.
- OK button : When the menu is displayed on the LCD monitor, the OK button is used for confirming data that is changed by using the 5 function button.

## LCD button

■ The shooting information will be displayed on the LCD monitor.

The last image stored in the memory is displayed on the LCD monitor by pressing the play mode button.

Pressing the LCD button in the PLAY (  ) mode will change the display as shown below. [Image & Icons] → [Image & Information] → [Image only]



Pressing the LCD button


\* The LCD button is not available for voice recording in play mode.

## Delete ( ) button

D430 52 페이지

■ This deletes images stored on the memory card.

### ● Deleting Images in Play Mode

1. Select an image that you want to delete by pressing the LEFT / RIGHT button and press the DELETE (  ) button.
2. A message will display as shown alongside on the LCD monitor.
3. Press the OK button to delete the image.



### ● Deleting Images in Thumbnail Display Mode

1. Use the Up/Down/Left/Right buttons to select an image to delete.
2. Press the Delete button to display the following message in the LCD monitor.



Press the DELETE button.



3. Press the OK button to delete the image.







## INFORMATION

- Before deleting images from the camera, you should protect ( p.55) or download images ( p.92) to your computer that you wish to keep.

## Setting up the play back function using the LCD monitor

- PLAY mode functions can be changed by using the LCD monitor. In the PLAY mode, pressing the MENU button displays the menu on the LCD monitor. The menus you can set up in Play mode are as follows. To capture an image after setting up the play menu, press the PLAY button.




The items indicated by  are default settings.

Menu tab	Main menu	Sub menu	Secondary menu	Page
	SLIDE	INTERVAL	<span style="background-color: #cccccc;">OFF</span> / 1-10SEC	p. 54
		REPEAT	ON / <span style="background-color: #cccccc;">OFF</span>	
		EFFECT	<span style="background-color: #cccccc;">CANCEL</span> / EFFECT1, 2, 3, 4	
	PROTECT	SELECT	UNLOCK / LOCK	p. 55
		ALL PICS	UNLOCK / LOCK	
	DELETE	SELECT	-	p. 56
		ALL PICS		
	RESIZE	1280X960	-	p. 57
		800X600	-	
		LOGO	-	
	ROTATE	RIGHT	-	p. 58
		LEFT	-	
		UPDOWN	-	
	DPOF	STANDARD	SELECT/ ALL PICS/ CANCEL	p. 58
		INDEX	NO/ YES	
		SIZE	SELECT/ ALL PICS/ CANCEL	

## 신규





# Setting up the play back function using the LCD monitor

This menu is available while the camera is connected to a PictBridge supporting printer (direct connection to the camera, sold separately) with a USB cable.

Menu tab	Main menu	Sub menu	Secondary menu	Page
	IMAGES	ONE PIC	-	p. 54
		ALL PICS	-	
	AUTO SET	YES	-	p. 55
		NO	-	
	CUSTOM SET	SIZE	AUTO	p. 55
			POSTCARD	
			4X6	
			8X10	
			A6	
			A4	
			B5	
		LAYOUT	AUTO	
			FULL	
			1	
			2	
			4	
			6	
			8	
TYPE	AUTO			
	PLAIN			
	PHOTO			
	FASTPHO.			



## Setting up the play back function using the LCD monitor 신규

Menu tab	Main menu	Sub menu	Secondary menu	Page
	CUSTOM SET	QUALITY	AUTO	p. 54
			DRAFT	
			NORMAL	
			FINE	
		DATE	AUTO	
			OFF	
			ON	
		FILE NAME	AUTO	
			OFF	
			ON	
	PRINT	STANDARD	-	p. 55
		INDEX	-	
		CANCEL	-	
	DPOF PRINT	YES	-	p. 55
		NO	-	
	RESET	YES	-	p. 55
		NO	-	

※ Menus are subject to change without prior notice.

## Starting the slide show D 430 54 페이지


- Images can be displayed continuously at pre-set intervals.


You can view the slide show by connecting the camera to an external monitor.

- Configure the interval for the slide show

: Configure the length of time to display each picture in the slide show.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [SLIDE] menu tab.
3. Select the [INTERVAL] sub menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the Up/Down Button to establish the display interval.  
- Slide Show Display Interval : OFF, 1 ~10 seconds
5. Use the Right Button to start the slide show.



Use the Pause (  ) Button to pause and resume the slide show.

To cancel the slide show in the middle of the show, press the Pause button and the LEFT or RIGHT button.

## INFORMATION

- The loading time depends on the image size and quality.
- The slide show will start from an image that was displayed on the LCD monitor.  
The [PWR OFF] function can't be activated.
- While the slide show is playing, only the first frame of an MOVIE file is displayed.

- Configure slide show repeat mode

: Automatically restart the slide show after displaying all pictures.

Steps 1 and 2 are the same as for the [INTERVAL] section.

3. Select the [REPEAT] sub menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the Up/Down Button to select the repeat mode.  
[ON] : The slide show will repeat until turned off.  
[OFF]: The slide show will not repeat after the first showing.
5. Press the OK button to confirm the setting.
6. Press the OK button again and the slide show will start.



## Starting the slide show

D 430 55페이지

- Configure slide show effects: Unique screen effects can be used for the slide show.

Steps 1 and 2 are the same as for the [INTERVAL] section.

3. Select the [EFFECT] sub menu by pressing the UP/DOWN button and press the RIGHT button.

4. Use the Up/Down Button to select the type of effect.

[CANCEL] : Normal display.

[EFFECT 1] : Image is displayed slowly.

[EFFECT 2] : Image is displayed slowly from the center outwards.

[EFFECT 3] : Image moves from the top left.

[EFFECT 4] : The image slides diagonally from top left to bottom right.

5. Press the OK button to confirm the setting.

6. Press the OK button again and the slide show will start.



## Protecting images

- This is used to protect specific shots from being accidentally erased (LOCK). It also unprotects images that have been previously protected (UNLOCK).

- Protecting Images

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [PROTECT] menu tab.

3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

[SELECT] : Selection window for an image to be protected/released is displayed.

- Up/Down/Left/Right : Select an image

- Zoom W/T Button : Protect/release the image

- Menu Button : Your changes will be saved and the menu will disappear.

[ALL PICS] : Protect/release all saved images

- Zoom W/T Button : Protect/release the images

- Menu Button : Your changes will be saved and the menu will disappear.



## Protecting images

D 430 56페이지

- If you protect an image, the protect icon will be displayed on the LCD monitor. (An unprotected image has no indicator)

- An image in LOCK mode will be protected from the delete function or [DELETE] functions, but will NOT be protected from the [FORMAT] function.



## Deleting images

- Of all the files stored in the memory card, the unprotected files in the DCIM subfolder will be deleted. Remember that this will permanently delete unprotected images. Important shots should be stored on a computer before deletion takes place. The startup image is stored in the camera's internal memory (i.e., not on the memory card) and it will not be deleted even if you delete all files on the memory card.

### ● Deleting images

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DELETE] menu tab.

3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

[SELECT]: Selection window for an image to delete is displayed.

- Up/Down/Left/Right: Select an image

- Zoom T Button: Select the image for deletion.

(V mark)

- OK Button: Press the OK Button to display confirmation message

Press the OK Button again to delete V marked images.

[ALL PICS]: Displays confirmation window

Press the OK Button again to delete all unprotected images. If there aren't protected images, all the images are deleted and a [NO IMAGE!] message will display.

4. After deletion, the screen will be changed to the play mode screen.



# Resize

■ Change the resolution (size) of pictures taken. Select [LOGO] to save an image to be the start-up image. The resized image will have a new file name.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [RESIZE] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

[RESIZE] sub menu : 1280X960, 800X600, LOGO



## ● Image Resize Types

Size	1280X960	800X600	LOGO
2560	O	O	O
2272	O	O	O
2048	O	O	O
1600	O	O	O
1024	X	O	O
640	X	X	O

## INFORMATION

- A large sized image can be resized to a smaller sized image, but not vice versa.
- Only still image(JPEG) images can be resized. TIFF, Movie clip(AVI) and Voice recording(WAV) files can't be resized.
- You can change the resolution of only those files compressed in the JPEG 4:2:2 format.
- The resized image will have a new file name. The [LOGO] image is stored not on the memory card but on the internal memory.
- Only one [LOGO] image can be saved. If you save a new [LOGO] image, the existing startup image will be deleted.
- If the memory capacity is insufficient to store the resized image, a [CARD FULL!] message will display on the LCD monitor and the resized image will not be stored.

## Rotating an image

D 430 58페이지


- You can rotate the stored images by 90, 180, or 270 degrees.

You can view a picture in its proper orientation if the picture has been taken with the camera oriented vertically or up-side-down. Once the playback of the rotated picture is finished, it will switch back to the original state.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [ROTATE] menu tab.
3. Select a desired sub menu by pressing the UP/ DOWN button.

[RIGHT] : Rotate picture in a clock-wise direction  
[LEFT] : Rotate picture in a counter-clock-wise direction

[UPDOWN] : Rotate picture 180 degrees



[ Picture after 90 degrees ]  
CW rotation



[ Picture after 90 degrees ]  
CCW rotation



[ Picture after 180 degrees ]  
rotation

4. Press the OK button. The rotated image will be displayed and the menu will disappear.  
If you display the rotated image on the LCD monitor, empty spaces may appear to the left and right of the image.

## DPOF

- DPOF(Digital Print Order Format) allows you to embed printing information on your memory card's DCIM/MISC folder. Select the pictures to be printed and how many prints to make.
- The DPOF indicator will display on the LCD monitor when an image that has DPOF information plays back. Images can then be printed on DPOF printers, or at an increasing number of photo labs.
- This function is not available for Movie clips and Voice recording files.

## DPOF : STANDARD

D 430 59페이지

- This function allows you to embed print quantity information on a stored image.


1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [STANDARD] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.

[SELECT]: Selection window for an image to print is displayed.

- Up/Down/Left/Right: Select an image to print.
- Zoom W/T Button: Select the number of prints.

[ALL PICS] : Configure number of prints for all pictures except movie and voice files.

[CANCEL] : Cancel the print setup.

5. Press the OK button to confirm the setting.  
If an image carries DPOF instructions, the DPOF indicator (  ) will show.



## DPOF : INDEX

- Images (except for movie clips and voice file) are printed as index type.

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [INDEX] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button.

If [NO] is selected : The image will be printed in standard print format.

If [YES] is selected : The image will be printed in index format.

5. Press the OK button to confirm the setting.



# DPOF : PRINT SIZE

D 430 60페이지

- You can specify the print size when printing images stored on the memory card.  
The [SIZE] menu is available only for DPOF 1.1 compatible printers.

## ● Setting the Print Size

1. Press the play mode button and press the menu button.
2. Press the LEFT/ RIGHT button and select the [DPOF] menu tab.
3. Select the [SIZE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



[SELECT] : Selection window for an image to be changed  
printed size is displayed.

- Up/Down/Left/Right : Select an image.
- Zoom W/T Button : Change the print size.
- MENU button : Your changes will be saved and the menu will disappear.

[ALL PICS] : Change print size of all saved images.

- Up/Down/Left/Right : Select an image.
- OK button : Confirm the changed setting.

[CANCEL] : Cancel all of the print size settings.

- \* DPOF [SIZE] secondary menu : CANCEL, 3X5, 4X6, 5X7, 8X10





# PictBridge



신규

- You can use the USB cable to connect this camera to a printer that supports PictBridge (sold separately) and print the stored images directly. Movie clips and voice files cannot be printed. You can set up the following settings from the PictBridge menu.

PRINTER SETUP	: Setting up printing(AUTO SET/CUSTOM SET)
PRINT	: Printing pictures
DPOF AUTO PRINT	: Printing the DPOF files
RESET	: Initializing the PictBridge functions

## ● Connecting the Camera to a Printer

1. Push the power switch to turn the camera power on.
2. In a mode other than Voice Recording mode, press the MENU button.
3. Press the LEFT/ RIGHT button and select [SETUP] menu tab.
4. Select [USB] menu by pressing the UP/ DOWN button and press the RIGHT button.
5. Select [PRINTER] menu by pressing the UP/ DOWN button and press the OK button.
6. Press the menu button twice and the menu will disappear.
7. Use the supplied USB cable to connect the camera to the printer as shown below.
8. Turn on the printer to connect the camera to the printer.



※ If you selected [Computer] in Step 5, when you connect the camera to your printer, the Mode dial lamp(Green) will blink and the connection will not be established. In this case, disconnect the USB cable, and then follow the procedure from Step 2 and onward.

# 신규 PictBridge: Picture Selection

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer. (See p.58)
2. The [IMAGES] menu will appear.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.  
When [ONE PIC] is selected : The PictBridge function will be applied only to the picture currently displayed.  
When [ALL PICS] is selected : The PictBridge function will be applied to all pictures, excluding movie clips and voice files.




## ● Setting the Number of Copies to Print

- Select [ONE PIC] or [ALL PICS]. A screen where you can set the number of copies to print will appear as shown below.



[ When [ONE PIC] is selected ]




[ When [ALL PICS] is selected ]

- Press the Up/Down button to select the number of prints. Maximum 30 prints.
- Use the Left/Right button to select another picture and select the number of prints for another picture.
- After setting the number of prints, press the OK button to save.
- Press the Shutter button to return to the menu without setting the number of prints.

# PictBridge: Print Setting 신규

## ■ AUTO SET

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer.(See p.58)
2. Use the LEFT and RIGHT buttons to select the [AUTO SET] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.  
 [Yes] : All values in the [User Configuration] are automatically changed.  
 [No] : [CUSTOM SET] values are kept.



## ■ You can select the Paper Size, Print Format, Paper Type, Print Quality, Date Print, and File Name Print menus for printed pictures.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.58)
2. Use the LEFT and RIGHT buttons to select the [CUSTOM SET] menu tab.
3. Use the UP and DOWN buttons to select [PRINTER SETUP], and then press the RIGHT button.
4. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.



## ■ The menus you can set up are as follows:

Menu	Function	Sub menu
SIZE	Setting the size of the printing paper	AUTO, POSTCARD, 4x6, 8x10, A6, A4, B5
LAYOUT	Setting the number of pictures to be printed on a sheet of paper	AUTO, FULL, 1, 2, 4, 6, 8
TYPE	Setting the quality of the printing paper	AUTO, PLAIN, PHOTO, FASTPHO.
QUALITY	Setting the quality of the picture to be printed	AUTO, DRAFT, NORMAL, FINE
DATE	Setting whether to print the date	AUTO, OFF, ON
FILE NAME	Setting whether to print the file name	AUTO, OFF, ON

※ Some menu options are not supported in all manufacturer and printer models. If not supported, the menus are still displayed in the LCD, but are not selectable.

※ If the setting values are not changed in the automatic/manual setting, the setting values are automatically kept.

# PictBridge: Printing

Uca3 61 페이지


## ■ Printing Pictures

1. Connect the camera to your printer. The USB menu must be set to [PRINTER] before you connect the camera to the printer.(See p.58)
2. Use the LEFT and RIGHT buttons to select the [ PRINT] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.

[STANDARD] : Print the pictures stored in the memory card in set numbers.


[Index] : Print multiple images on one sheet of paper.

[Cancel] : Cancel the picture printing



4. The screen shown on the right will appear and the picture will be printed. If no picture is selected, the [NO IMAGE!] message will be displayed. If you press the MENU/OK button during printing, printing will be cancel and the menu from Step 2 will appear.

※ Number of pictures in a index print varies depends on the printer used.



## ■ DPOF PRINT : This allows you to directly print the files with DPOF information.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.58)
2. Use the LEFT and RIGHT buttons to select the [ DPOF PRINT] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.

[Yes] : Directly print the file with the DPOF information

[No] : Cancel the printing

※ Depending on the manufacturer and printer model, some menus may not be available.  
With a printer without supporting the DPOF, the menu is still displayed but not available.



## PictBridge : RESET

신규

### ■ Initializes user-changed configurations.

1. Connect the camera to your printer. The [USB] menu must be set to [PRINTER] before you connect the camera to the printer.(See p.58)
2. Use the LEFT and RIGHT buttons to select the [RESET] menu tab.
3. Use the UP and DOWN buttons to select the desired submenu value, and then press the OK button.
  - If [YES] is selected : All print and image settings will be reset.
  - If [NO] is selected : Settings will not be reset.











※ Default print setting varies depending on the printer manufacturer.

For your printer's default setting, refer to the user's guide that came with your printer.

# Setup menu

D430 64 페이지

- In this mode, you can set up basic settings. You can use the setup menu in all camera modes, except Voice Recording mode.  
The items indicated by  are default settings.

Menu tab	Main menu	Sub menu	Secondary menu	Page
	FILE	 RESET		p.65
		SERIES		
	PWR OFF	OFF, 1~  10MIN		p.66
	LANGUAGE	ENGLISH	日本語	p.67
		한국어	P"CKK»...	
		FRANÇAIS	PORTU.	
		DEUTSCH	DUTCH	
		ESPAÑOL	DANSK	
		ITALIANO	SVENSKA	
		简体中文	SUOMI	
		繁體中文	THAI	
	FORMAT	 NO		p.67
		YES		
	D & TIME	04/01/01 13:00		p.68
		 YY/MM/DD		
		MM/DD/YY		
		DD/MM/YY		
	IMPRINT	 OFF		p.68
		DATE		
		D & TIME		
SOUND	OFF		p.69	
	LOW			
	 MEDIUM			
	HIGH			

# Setup menu

D430 65 페이지

Menu tab	Main menu	Sub menu	Secondary menu	Page
SET	LCD	DARK		p.69
		NORMAL		
		BRIGHT		
	VIDEO	NTSC		p.70
		PAL		
	Q. VIEW	OFF, 1, 2, 3SEC		p.71
	RESET	NO		p.71
		YES		
	USB	COMPUTER		p.72
		PRINTER		

\* Menus are subject to change without prior notice.

## File name

■ This function allows the user to select the file naming format.

● Assigning File Names

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [FILE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



[RESET] : After using the reset function, the next file name

will be set from 0001 even after formatting, deleting all or inserting a new memory card.

[SERIES]: New files are named using numbers that follow the previous sequence, even when a new memory card is used, or after formatting, or after deleting all pictures

5. Press the menu button twice and the menu will disappear.

## File name

D430 66페이지

### INFORMATION

- The first stored folder name is 100SSCAM, and the first file name is SV500001.
- File names are assigned sequentially from SV500001 → SV500002 → ~ → SV509999.
- The folder number is assigned sequentially from 100 to 999 as follows: 100SSCAM → 101SSCAM → .... → 999SSCAM.
- The files used with the memory card conform to the DCF(Design rule for Camera File systems) format.

## Auto power off

- This function switches the camera off after a set amount of time in order to prevent unnecessary battery drainage.

### ● Setting Power Off

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [PWR OFF] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



5. Press the menu button twice and the menu will disappear.
- Selecting [OFF] : The power off function will not operate.  
[1~10 MIN] : The power will turn off automatically if not used for the period of time specified.

### INFORMATION

- Even if the batteries or AC adapter are removed and inserted again, the power off setting will be preserved.
- Note that the automatic power off function will not operate if the camera is in PC mode, slide show, playing back a voice recording or movie clip.



## Language

- There is a choice of languages that can be displayed on the LCD monitor. Even if the batteries or AC adapter are removed and inserted again, the language setting will be preserved.

- Setting Language

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [LANGUAGE] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



LANGUAGE sub menu : Korean, English, French, German, Spanish, Italian, T.Chinese, S.Chinese, Japanese, Russian, Portuguese, Dutch, Danish, Swedish, Finnish, Thai.

5. Press the menu button twice and the menu will disappear.

## Formatting a memory card

- This is used for formatting the memory card. If you run [FORMAT] on the memory card, all images, including the protected images, will be deleted. Be sure to download important images to your PC before formatting the memory card.

- Formatting a Memory Card

1. In any mode other than Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [FORMAT] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



If [NO] is selected : The memory card will not be formatted.

Press the menu button twice and the menu display will disappear.

If [YES] is selected : A [PLEASE WAIT!] message appears and the memory card will be formatted. If you ran FORMAT in Play mode, a [NO IMAGE!] message will appear.

## INFORMATION

- Be sure to run [FORMAT] on the following types of memory card.
  - A new memory card, or an unformatted memory card.
  - A memory card that has a file this camera can't recognize or one that has been taken from another camera.
- Always format the memory card using this camera. If you insert a memory card that has been formatted using other cameras, memory card readers, or PCs, you will get a [CARD ERROR!] message.

## Setting up the Date/ Time/ Date type

- You can change the date and time that will be displayed on the captured images and set up the date type.

- Setting Date/Time & Selecting Date Format

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [D&TIME] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP, DOWN, LEFT, and RIGHT buttons to select the desired submenu value, and then press the OK button.



RIGHT button : Selects the year/month / day/hour / minute date type.

LEFT button : Moves the cursor to the [D&TIME] main menu if the cursor is at the first item of the date and time setup. In all other cases, the cursor will be shifted to the left of its current position.

UP and DOWN buttons : Changes the setting value.

- Date type : [YY/MM/DD] / [MM/DD/YY] / [DD/MM/YY]


5. Press the menu button twice and the menu will disappear.

## Imprinting the recording date

- There is an option to include DATE/TIME on still images.

- Date Imprinting

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [IMPRINT] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Use the UP and DOWN buttons to select the desired date imprint type, and then press the OK button.



[OFF]: The DATE & TIME will not be imprinted on the image file.

[DATE] : Only the DATE will be imprinted on the image file.

[D&TIME] : The DATE & TIME will be imprinted on the image file.

5. Press the menu button twice and the menu will disappear.

## INFORMATION

- The Date & Time are imprinted at the bottom right side of the still image.
- The date will be imprinted as a DATE TYPE setting.
- TIME is imprinted in the following way : [Hour : Minute] and hours are shown using the 24 hour clock.
- The imprint function is applied only to still images.

# Sound

D430 69 페이지

- If you set the operation sound to ON, various sounds will be activated for camera startup, when button are pressed, and if there is a card error, so that you can be aware of the camera operation status.

- Setting Operation Sounds

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [SOUND] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.  
[SOUND] sub menu : OFF/ LOW/ MEDIUM/ HIGH
5. Press the menu button twice and the menu will disappear.



# LCD brightness

- You can adjust the LCD brightness.

- Adjusting LCD Brightness

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [LCD] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.  
[LCD] sub menu : DARK, NORMAL, BRIGHT
5. Press the menu button twice and the menu will disappear.




## Selecting Video out type

- The Movie output signal from the camera can be NTSC or PAL.  
Your choice of output will be governed by the type of device (monitor or TV, etc.) to which the camera is connected. PAL mode can support only BDGHI.
- Setting the Video Out Type
  1. In any mode with the exception of Voice Recording mode, press the MENU button.
  2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
  3. Select the [VIDEO] menu by pressing the UP/ DOWN button and press the RIGHT button.
  4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.  
[VIDEO] sub menu : NTSC, PAL
  5. Press the menu button twice and the menu will disappear.



- Connecting to an external monitor  
In RECORDING/ PLAY mode, you can view the stored still images or movie clips by connecting the camera to an external monitor via the A/V cable. When the camera is connected to an external monitor, the LCD monitor will be turned off automatically.



## INFORMATION

- NTSC : U.S.A, Canada, Japan, South Korea, Taiwan, Mexico.
- PAL : Australia, Austria, Belgium, China, Denmark, Finland, Germany, U.K., Holland, Italy, Kuwait, Malaysia, New Zealand, Singapore, Spain, Sweden, Switzerland, Thailand, Norway.
- When using a TV as an external monitor, you will need to select the external or AV channel of the TV.
- There will be a digital noise on the external monitor, but it is not a malfunction.
- If the image is not in the centre of the screen, use the TV controls to centre it.
- When the camera is connected to an external monitor, the menu will be visible on the external monitor and the menu functions are the same as those indicated on the LCD monitor.

## Quick view

D430 71 페이지

- If you enable Quick View before capturing an image, you can view the image you just captured on the LCD monitor for the duration set in the [Q.VIEW] setup. Quick view is possible only with still images.

### ● Setting Quick View

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [Q.VIEW] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.




- 
- 
- 
5. Press the menu button twice and the menu will disappear.  
[OFF] : The quick view function can't be activated.  
[1 ~ 3 SEC] : The captured image is briefly displayed during the selected time.

## Initialization(RESET ALL)

- All camera menu and function settings will be restored to their default values. However, values for DATE/TIME, LANGUAGE, and VIDEO OUT will not be changed.

### ● Initializing the Camera

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [RESET] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



- 
- 
- 
5. Press the menu button twice and the menu will disappear.  
If [NO] is selected : Settings will not be restored to their defaults.  
If [YES] is selected : All settings will be restored to their defaults.

## Connecting an External Device (USB)

■ You can select an external device to which you want to connect the camera using the USB cable.

● Selecting an External Device

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [SETUP] menu tab.
3. Select the [USB] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.



[COMPUTER] : Select this if you want to connect the camera to your PC.


Refer to page 91 for instructions on how to connect the camera to your PC.








[PRINTER] : Select this if you want to connect the camera to your printer.

Refer to page 62 for instructions on how to connect the camera to your printer.

5. Press the menu button twice and the menu will disappear.

## Setting up the MYCAM menu

- You can set up a start up image, start up sound and shutter sound. Every camera working mode (with the exception of Voice recording mode) has the MyCAM menu. The items indicated by  are default settings.

Menu tab	Main menu	Sub menu			Page
		OFF	USER IMAGE	IMAGE 1	
	S.IMAGE				p.73
					
	S.SOUND				p.74
					
SH.SOUND				p.74	
					

\* Menus are subject to change without prior notice.

### Start up image

- You can select the image that is first displayed on the LCD monitor whenever the camera is turned on.
- Setting a Startup Image
  1. In any mode with the exception of Voice Recording mode, press the MENU button.
  2. Press the LEFT/ RIGHT button and select the [MYCAM] menu tab.
  3. Select the [S.IMAGE] menu by pressing the UP/ DOWN button and press the RIGHT button.
  4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
  5. Press the menu button twice and the menu will disappear.



### INFORMATION

- Use a saved image for the start-up image with the [LOGO] in the [RESIZE] menu in the play mode.
- The start-up image will not be deleted by deleting all images or [FORMAT] menu.

## Start up sound

D430 74 페이지

- You can select the sound that is activated whenever the camera is turned on.

- Setting the Startup Sound

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [MYCAM] menu tab.
3. Select the [S.SOUND] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
5. Press the menu button twice and the menu will disappear.




## Shutter sound

- You can select the shutter sound.

- Selecting the Shutter Sound

1. In any mode with the exception of Voice Recording mode, press the MENU button.
2. Press the LEFT/ RIGHT button and select the [MYCAM] menu tab.
3. Select the [SH.SOUND] menu by pressing the UP/ DOWN button and press the RIGHT button.
4. Select a desired sub menu by pressing the UP/ DOWN button and press the OK button.
5. Press the menu button twice and the menu will disappear.





## Important notes

D430 75 페이지

Be sure to observe the following precautions!

- This unit contains precision electronic components. Do not use or store this unit in the following locations.
  - Areas exposed to severe changes in temperature and humidity.
  - Areas exposed to dust and dirt.
  - Areas exposed to direct sunlight or the inside of a vehicle in hot weather.
  - Environments where there is high magnetism or excessive vibration.
  - Areas with high explosives or highly flammable materials.
  
- Do not let the unit come into contact with dust, vinyl goods, or chemicals, such as insecticides, for an extended period of time.
  
- Sand can be particularly troublesome to cameras.
  - Do not let sand get inside the unit when using it on beaches, coastal dunes, or other areas where there is lots of sand.
  - Doing so may result in failure or may permanently render the unit unusable.
  
- Extremes in temperature may cause problems.
  - If the camera is transferred from a cold to a warm and humid environment, condensation can form on the delicate electronic circuitry. If this occurs, turn the camera off and wait for at least 1 hour until all moisture is dispersed. Moisture build up can also occur in the memory card. If this happens, turn off the camera and remove the memory card. Wait until the moisture has dispersed.
  
- Caution on Using the Lens
  - If the lens is subjected to direct sunlight, it could result in discoloration and deterioration of the image sensor.
  - Pay attention not to get fingerprints or foreign substances on the surface of the lens.
  
- If the digital camera is not used for a long period, an electric discharge can occur. It is a good idea to remove the batteries and the memory card if you do not intend using the camera for an extended period of time.

## Important notes

D430 76페이지

- If the camera is exposed to an electronic interference, it will turn itself off to protect the memory card.
  
- Camera Maintenance
  - Use a soft brush (available from photo stores) to gently clean the lens and LCD assemblies. If this does not work, lens-cleaning paper with lens cleaning fluid can be used.
  - Clean the camera body with a soft cloth. Do not allow this camera to come into contact with solvent materials such as benzol, insecticide, thinners etc. This may damage the body shell of the camera and also affect its performance. Rough handling can damage the LCD monitor. Take care to avoid damage and keep the camera in its protective carry case at all times when not in use.
  
- Do not attempt to disassemble or modify the camera.
  
- Under certain conditions, static electricity can cause the flash unit to fire. This is not harmful to the camera and is not a malfunction.
  
- When images are uploaded or downloaded, the data transfer may be affected by static electricity. In this case, disconnect and re-connect the USB cable before trying the transfer again.

## Warning indicator

D430 77페이지

There are several warnings that may appear on the LCD display

Warning indicator	Causes	Remedy
CARD ERROR !	- Memory card error	- Turn off the camera power and turn it on again - Insert the memory card again - Format the memory card (p.67)
CARD FULL !	- There is insufficient memory capacity to take an image	- Insert a new memory card - Delete unnecessary image files to free up some memory
NO IMAGE !	- There are no images stored on the memory card	- Take images - Insert a memory card that is holding some images
NO CARD !	- A memory card is not inserted - The camera can't recognize the memory card	- Insert a memory card - Insert the memory card again - Turn off the camera power and turn it on again
FILE ERROR !	- File error - Memory card error	- Format the memory card - Contact a camera service center
LOW BATTERY !	- There is low battery capacity	- Insert fresh batteries
CARD LOCKED !	- The memory card is locked	- Slide the write protect switch to the top of the memory card
LOW LIGHT !	- When taking pictures in dark places	- Use a tripod and take pictures in Flash Photography mode
SET USB	- [SETUP] configured [USB] and actually connected [USB] do not match.	- Reconfigure [USB] in the [SETUP] menu - Check whether the computer [USB] or printer [USB] is used.

## Before contacting a service center

Please check the following

Symptom	Causes	Remedy
The camera doesn't switch on	<ul style="list-style-type: none"> <li>- There is low battery capacity</li> <li>- An AC Power Adapter is not connected</li> <li>- Batteries are inserted incorrectly with the reverse polarities</li> </ul>	<ul style="list-style-type: none"> <li>- Insert fresh batteries</li> <li>- Connect an AC Power Adapter</li> <li>- Insert the batteries according to the polarity marks (+, -)</li> </ul>
The camera power ceases whilst in use	<ul style="list-style-type: none"> <li>- The batteries are exhausted</li> <li>- The Camera is turned off automatically</li> <li>- The Adapter plug is not connected securely</li> </ul>	<ul style="list-style-type: none"> <li>- Insert fresh batteries</li> <li>- Press the power button to reactivate camera</li> <li>- Remove and re-insert the plug</li> </ul>
Batteries drain quickly	<ul style="list-style-type: none"> <li>- The Camera is being used in low temperatures</li> </ul>	<ul style="list-style-type: none"> <li>- Keep the camera in warm conditions (i.e. inside a coat or jacket) and only remove it in order to take images</li> </ul>
Camera does not take images when pressing the Shutter button	<ul style="list-style-type: none"> <li>- The memory card is not inserted</li> <li>- There is insufficient memory capacity</li> <li>- The memory card has not been formatted</li> <li>- The memory card is exhausted</li> <li>- The camera's power is off</li> <li>- The batteries are exhausted</li> <li>- The memory card is locked</li> <li>- Batteries are inserted incorrectly with the reverse polarities</li> </ul>	<ul style="list-style-type: none"> <li>- After turning the camera off, insert a new memory card</li> <li>- Delete unnecessary image files</li> <li>- Format the memory card (p.67)</li> <li>- Insert a new memory card</li> <li>- Turn the camera power on</li> <li>- Insert fresh batteries</li> <li>- Refer to [CARD LOCKED!] error message (p.77)</li> <li>- Insert the batteries according to the polarity marks (+, -)</li> </ul>
The camera suddenly stops working while in use	<ul style="list-style-type: none"> <li>- The camera was stopped due to a malfunction</li> </ul>	<ul style="list-style-type: none"> <li>- Remove /re-insert batteries and switch the camera on</li> </ul>

## Before contacting a service center

Symptom	Causes	Remedy
The images are unclear	<ul style="list-style-type: none"> <li>- A picture was taken within 0.8 m from the subject without setting an appropriate macro mode</li> <li>- Taking a picture beyond the flash range</li> <li>- The lens is smudged or dirty</li> </ul>	<ul style="list-style-type: none"> <li>- If the subject is closer than 0.8m, select macro shot mode</li> <li>- Take a picture within the flash range</li> <li>- Clean the lens</li> </ul>
The flash does not fire	<ul style="list-style-type: none"> <li>- Flash off mode has been selected</li> </ul>	<ul style="list-style-type: none"> <li>- Dis-engage flash off mode</li> </ul>
Incorrect date and time is displayed	<ul style="list-style-type: none"> <li>- The date and time have been set incorrectly or the camera has adopted the default settings</li> </ul>	<ul style="list-style-type: none"> <li>- Reset the date and time correctly</li> </ul>
The camera buttons do not operate	<ul style="list-style-type: none"> <li>- Camera malfunction</li> </ul>	<ul style="list-style-type: none"> <li>- Remove /re-insert batteries and switch the camera on</li> </ul>
A card error has occurred while the memory card is in the camera.	<ul style="list-style-type: none"> <li>- Incorrect memory card format</li> </ul>	<ul style="list-style-type: none"> <li>- Re-format the memory card (p.67)</li> </ul>
The images don't play back	<ul style="list-style-type: none"> <li>- Incorrect file name (Violation of DCF format)</li> </ul>	<ul style="list-style-type: none"> <li>- Do not change the image file name</li> </ul>

## Before contacting a service center

Symptom	Causes	Remedy
Colour of image is different to the original scene	- White balance setting is incorrect	- Select appropriate White balance
Images are too bright	- Exposure is excessive	- Reset exposure compensation
No image on external monitor	- The external monitor has not been connected properly with the camera - There are incorrect files in the memory card	- Check the connection cables - Insert a memory card that has correct files
When using the PC's explorer, the [Removable Disk] file does not show	- Cable connection is incorrect - The camera is off - There are no batteries, the batteries are exhausted or the AC adapter is not connected. - The operating system is not Windows 98, 98SE, 2000, ME, XP/ Mac OS 9.0~10.2. Alternatively the PC does not support USB - The camera driver is not installed	- Check the connection - Turn the camera on - Insert new batteries or check the adapter connection - Install Windows 98, 98SE, 2000, ME, XP/ Mac OS 9.0~10.2 to PC that supports USB - Install a [USB Storage Driver]

## Specifications

Image Sensor	Type	1/1.8" CCD
	Effective Pixel	Approx. 5.1 Mega-pixel
	Total Pixel	Approx. 5.3 Mega-pixel
Lens	Focal Length	Schneider Lens f = 7.7 ~ 23.1mm (35mm film equivalent : 38~114mm)
	F No.	F2.8 ~ F4.9
	Digital Zoom	Still Image mode : 1.0X ~ 4.0X(0.1 Steps) Play mode : 1.0X ~ 10.0X (depends on image size)
Viewfinder	Optical Viewfinder	Real image optical viewfinder
	LCD Monitor	1.5" color TFT LCD (78,000 dots)
Focusing	Type	TTL auto focus
	Range	Normal : 80cm ~ infinity Macro : 30 ~ 80cm, Super Macro : 6 ~ 30cm (Wide only)
Shutter	Type	Mechanical and Electronic shutter
	Speed	2 ~ 1/2,000 sec. (Manual, Night Mode : 15 ~ 1/2,000 sec.)
Exposure	Control	Program AE, Shutter Priority AE, Aperture Priority AE or Manual Exposure Metering : Multi, Spot
	Compensation	±2EV (0.5EV steps)
	ISO Equivalent	Auto, 50, 100, 200, 400
Flash	Modes	Auto, Auto & Red-eye reduction, Slow sync, Fill-in flash, Flash off
	Range	Wide : 0.3 ~ 3.0m, Tele : 0.3 ~ 2.0m(ISO Auto)
	Recharging Time	Approx. 7 sec.
Sharpness		Soft, Normal, Vivid
Effect		Normal, B&W, Sepia, RGB
White Balance		Auto, Daylight, Cloudy, Fluorescent H, Fluorescent L, Tungsten, Custom
Voice Recording		Voice Recording (max. 1 hours) Voice Memo in Still Image (max. 10 sec.)
Date Imprinting		Date, Date&Time, Off (user selectable)
Shooting	Still Image	Modes : Auto, Program, A,S,M, Night Scene, MySet, Scene * Scene : Portrait, Children, Landscape, Close-up, Sunset, Dawn, Backlight, Fireworks, Beach & Snow Continuous : Single, Continuous Self-timer : 2 sec., 10 sec., Remocon
	Movie Clip	With Audio (recording time : memory capacity dependent) Size : 640x480, 320x240 Frame rate : 30 fps, 15 fps Play mode : 1.0X ~ 4.0X(0.1 Steps) (Captured Image only)
Storage	Media	SD / MMC Card (up to 512MB guaranteed)
	File Format	Still Image : TIFF, JPEG (DCF), EXIF 2.2, DPOF 1.1, PictBridge 1.0 Movie Clip : AVI (MJPEG) Voice : WAV

## Specifications

Storage	Image Size	2560 : 2560x1920      2272 : 2272x1704 2048 : 2048x1536      1600 : 1600x1200 1024 : 1024x768      640 : 640x480
	Capacity (32MB)	2560 : TIFF 2, Super Fine 13, Fine 23, Normal 34 2272 : TIFF 2, Super Fine 14, Fine 28, Normal 40 2048 : TIFF 3, Super Fine 17, Fine 33, Normal 49 1600 : TIFF 5, Super Fine 28, Fine 53, Normal 759 1024 : TIFF 12, Super Fine 64, Fine 106, Normal 139 640 : TIFF 29, Super Fine 129, Fine 201, Normal 227 * These figures are measured under Samsung's standard conditions and may vary depending on shooting conditions and camera settings.
Image Play	Type	Single image, Thumbnails, Slide show, Movie Clip
	Editing	Trimming, Resizing
Interface		Digital output connector : USB 1.1 Audio : Mono Video output : NTSC, PAL (user selectable) DC power input connector : 5.0V
Power Source		Primary battery : 2 x AA alkaline, Lithium, Ni-Mn, Ni-Zn / 1 x CR-V3 Rechargeable battery : 3.7V Li-ion(SLB-1437), 2 x AA Ni-MH, Ni-Cd / 1 x I-Pack (SBP-1103, SBP-1303) AC Adapter * Included power source may vary depending on sales region.
Dimensions (WxHxD)		105.5 x 54.6 x 38 mm
Weight		169.39g (without batteries and card)
Operating Temperature		0 ~40 °C
Operating Humidity		5 ~85%
Software	Camera	Storage Driver (Windows98/98SE/2000/ME/XP, Mac OS 9.0 ~ 10.2)
	DriverApplication	Digimax Viewer, ArcSoft PhotoImpression
Special Features		9 Kinds of Various Scene Modes VGA 30fps Movie Clip AVI capture on Play Mode

\* Specifications are subject to change without prior notice.

\* All trademarks are the property of their respective owners.





SAMSUNG TECHWIN CO., LTD.  
OPTICS & DIGITAL IMAGING DIVISION  
145-3, SANGDAEWON 1-DONG, JUNGWON-  
GU, SUNGNAM-CITY, KYUNGKI-DO, KOREA  
462-121  
TEL : (82) 31-740-8086, 8088, 8090, 8092, 8099  
FAX : (82) 31-740-8398, 8111

SAMSUNG OPTO-ELECTRONICS AMERICA, INC.  
HEADQUARTERS  
40 SEAVIEW DRIVE, SECAUCUS, NJ07094, U.S.A.  
TEL : (1) 201-902-0347  
FAX : (1) 201-902-9342

WESTERN REGIONAL OFFICE  
18600 BROADWICK ST.,  
RANCHO DOMINGUEZ, CA 90220, U.S.A.  
TEL : (1) 310-537-7000  
FAX : (1) 310-537-1566

SAMSUNG OPTO-ELECTRONICS UK LIMITED  
SAMSUNG HOUSE  
1000 HILLSWOOD DRIVE  
HILLSWOOD BUSINESS PARK  
CHERTSEY KT16 OPS U.K.  
TEL : +44 (0) 1932 455300  
FAX : +44 (0) 1932 455325

SAMSUNG OPTO-ELECTRONICS GMBH  
AM KRONBERGER HANG 6  
D-65824 SCHWALBACH/TS., GERMANY  
TEL : (49) 6196 66 53 03  
FAX : (49) 6196 66 53 66

SAMSUNG FRANCE S.A.S.  
BP 51 TOUR MAINE MONTPARNASSE  
33, AV .DU MAINE  
75755, PARIS CEDEX 15, FRANCE  
HOTLINE PHOTO NUMÉRIQUE :  
00 800 22 26 37 27 (Numéro Vert-Appel Gratuit)  
TEL : (33) 1-4279-2282/5  
FAX : (33) 1-4320-4510

SAMSUNG TECHWIN MOSCOW OFFICE  
KORP. 14 37-A LENNINGRADSKY PR-KT  
MOSCOW, 125167, RUSSIA  
TEL : (7) 095-258-9296, 9298, 9299  
FAX : (7) 095-258-9297

TIANJIN SAMSUNG OPTO-ELECTRONICS CO.,LTD.  
7 PINGCHANG ROAD NANKAI DIST., TIANJIN  
P.R CHINA  
POST CODE:300190  
TEL : (86) 22-2761-8867  
FAX : (86) 22-2761-8864

\* Internet address - <http://www.samsungcamera.com/>



The CE Mark is a Directive conformity  
mark of the European Community (EC)

6806-1779