

Congratulations on your purchase of the Lynx 3D computer controlled pistol grip system. Take time to familiarize yourself with these instructions for quick and easy set-ups and fine-tuning adjustments needed at your track. Now, prepare to take a step into a new dimension of control with the Lynx 3D from Hitec RCD!

### **Table of Contents**

Pg. 1) Introduction/ External Switches
Pg. 2) Physical Features/ Reference Guide
Pg. 3) Electronic Features/ Receiver.
Pg. 4) Changing Frequencies RX/ Battery Charging/ Left Hand Operation
Pg. 5) Programming Flow Chart
Pg. 6) Edit Mode Access/ EPA
Pg. 7) Model Reset/ Model Copy/ Model Select
Pg. 8) Timer/ Idle Up
Pg. 9) Anti-Lock Brakes/ Aux. CH.3
Pg. 10) Servo Reversing/ Exponential
Pg. 11) Auto and Standard Dual Rates
Pg. 12) Trims/ Brake Depth/ Steering Wheel Tension
Pg. 13) DSC/ Driving Tips/ Final Thoughts
Pg. 14) Servo Selection Chart

### **External Switches and their Usage.**

---

1. Power switch: Powers the system.
2. Display switch: Allows programming without powering the RF signal. Useful in conjunction with the DSC (direct servo control) feature.
3. Idle up switch: Used with gas or nitro vehicles to increase the idle speed at engine start up.
4. Dual rate switch: Selects between \*auto dual rate (left) and standard dual rate (right).
5. Throttle trim: Adjusts the neutral point of the throttle and brakes.
6. Steering trim: Adjusts the neutral point for the steering.

### **Programming Buttons for LCD Screen**

7. Edit up/down: Accesses the menu when pushed simultaneously and is used in scrolling through the menu to select the area to program.
8. Data inc/dec: Adjusts settings when accessing the menu
9. Aux. +/-: Used for CH3 and changing data in selected menus.

### **Handle Switches**

10. Dual Rate adjust: Selects the amount of travel the steering servo will turn.
11. ATL: Used to adjust the maximum amount of braking that will be applied when the brakes are fully engaged. *(Note: this is also the EPA (end point adjustment) for the brakes)*

### ***Physical Features.***

---

12. Removable transmitter frequency module.
13. External charging jack: Port for charging nicads with the supplied "overnight" charger.
14. Battery door: Access the transmitter nicad battery box.
15. Wrist strap mount: For connecting optional wrist or neck strap.
16. Brake depth adjustment screw: Limits the amount of physical brake lever travel.
17. Wheel tension adjustment screw: Increases or decreases the steering wheel tension.
18. D.S.C. (Direct Servo Control): Controls the receiver directly via the DSC cable.
19. Right/Left hand operation: Transmitter head can be adjusted for right or left hand use.

***(Show picture of Radio and refer to features to numbers above)***

## ***Electronic Features***

---

The following features are described in depth throughout this manual.

- ◆ 3 Channel FM digital proportional system
- ◆ 10 model memory
- ◆ Model copy
- ◆ End Point Adjustment (EPA)
- ◆ Exponential (Steering and Throttle curve)
- ◆ Digital Dual Rate (Two modes)
  1. Standard
  2. Auto (Dual settings per throttle position)
- ◆ ATL Brake (Adjustable Travel Limit)
- ◆ ABS Brakes (Antilock Braking System)
- ◆ Idle up
- ◆ Timer (Up/Down) w/ audible alarm
- ◆ Five position programmable 3<sup>rd</sup> channel
- ◆ Digital trims
- ◆ Audible low battery warning
- ◆ Auto Save

### **DCX Receiver:**

Included in the Lynx 3D system is the most advanced surface-use receiver on the market today. The Hitec RCD, DCX receiver features dual conversion technology that filters the transmitter's signal twice, decreasing the chance of stray RF "noise" causing interference. This "dual conversion" feature produces the best performance possible in even the most demanding conditions.

*Note: When used with an ESC (Electronic Speed Control) the receiver is powered by the ESC through the throttle channel. When used in a vehicle without an ESC, such as a gas or glow engine powered vehicle, the receiver must be powered with an external 4.8v-6.0v battery pack that is plugged into the Bat/DSC channel.*

Channel assignments on the DCX receiver.

- CH1:       Steering
- CH2:       Throttle
- CH3:       Auxiliary
- BAT/DSC:  Battery and DSC (Direct Servo Control)

### **Changing Frequencies**

When using the system in a competition environment it may be necessary to change the systems operating frequency.

#### **Receiver:**

Receiver crystals can be changed within the entire band with no loss of performance. Use only genuine Hitec RCD Dual Conversion receiver crystals in the DCX receiver.

#### **Transmitter:**

The Lynx 3D is equipped with a frequency module and has a crystal plugged into it. You can change between the 27mhz and 75mhz bands by changing the entire module.

### **Transmitter Nicads and Battery Charging:**

The Lynx 3D comes equipped with nicad batteries in the transmitter and an "overnight" charger for your convenience. To charge the batteries simply connect the charger to the charging port in the transmitter case or in the battery box. This can be done while the batteries are in or out of the transmitter. Normal charging time is approximately 12-18 hours. **Caution: Batteries should not be left on charge for longer than 24 hours.**

### **Left Handed Operation:**

The Lynx 3D is capable of converting from right to left handed operation. To do so please refer to the diagram below.

*(Show picture of the radio and which screws need to be removed)*

Now that you have familiarized yourself with the features and functions of the Lynx 3D, lets discuss how to program them. Below is a reference of how the editing menu is laid out.

**Programming Flow Chart:**

*(Show menu flow chart)*

## ***Edit Menu Access:***

To access the edit menu, turn the display or the power switch on, while pushing the "Edit" up/down keys simultaneously. Once you are in the edit menu use the up or down buttons to scroll through the options. To exit the edit menu push the "Edit" up/dn. keys simultaneously, the battery voltage will appear with the model number you are currently using. ***By using the down key the options will appear in the following order.***

### ***EPA: (End Point Adjustment) (Show picture of screen)***

This is the servo end point adjustment for right and left steering, throttle and brakes. To select between channels 1 (Steering) and 2 (Throttle) use the Aux. +/- keys. You can adjust the (+) side as well as the (-) side. To select between the two you must move the steering wheel or trigger slightly until you see the (+/-) symbol change, then adjust as needed. To reset back to the factory default press the "Data" inc/dec buttons simultaneously. *(Note: (-) Ch 2 is also affected by the ATL on the handle.)*

### ***Racer Tip***

#### ***Steering:***

*With the wheels trimmed at neutral set the D/R setting to max (125%), next use the EPA setting to adjust the wheels to maximum right and left without binding the servo. For maximum steering set the EPA a couple of % points higher once the servo hits the stop. This will give you maximum steering.*

#### ***Throttle:***

*The EPA setting is used primarily with gas or nitro vehicles. Pull the trigger and adjust the EPA so the throttle servo opens the barrel of the carburetor to maximum without binding. The brake setting is a little different, remember the ATL adjustment on the handle can adjust the amount of brakes, so the best thing to do is set the EPA at maximum (125%) so the brake does not bind and lock up when applied. Then use the ATL (same setting as the EPA "-" ch2) to fine tune the amount of brake you wish to have when the brake lever is pushed out. **(Important: Always allow the EPA settings to "Auto Save" by letting the voltage re-appear on the screen before proceeding with any other adjustments, this takes approx. 2 seconds.)***

*\*For electric vehicle with ESC you should not need to adjust the "+" setting, it is all done when setting up the ESC. The ATL can still be used to adjust the maximum braking. Set to 125% when setting up the ESC.*

***Model Reset: (Show picture of screen)***

This feature will allow you to reset any model back to the factory default setting. You must select the model to be reset in the model select "SL" screen. Once you have selected the proper model, push the "Data" inc/dec keys simultaneously, there will be an audible "beep" to verify reset.

***Model Copy: (Show picture of screen)***

This feature allows you to copy a pre-existing program to another model number. The model you wish to copy "From" must be selected in the model select "SL" screen. Then using the "Aux." +/- keys you can select the model you wish to copy "To". Once you have selected the proper models push the "Data" inc/dec keys simultaneously and there will be an audible "beep" to verify copy.

***Model Select: (Show picture of screen)***

This feature associates a numbers to the model. The letters "SL" will appear on the screen with a blinking number from 0 – 9. These are your model numbers; they can be adjusted by using the "Aux." +/- keys to select the model you wish to program and use.

***Racer Tip***

*To help remember which model is which number, use a little round sticky dot you can buy at most stationery stores, mark the model number and stick it on top of the receiver.*

***Timer: (Show picture of screen)***

The timer can be selected to count up or down. Leave the setting at zero if you wish to count up. To count down, select the amount of time you wish from 1 – 60 minutes using the “Data” key inc/dec buttons. Once you have selected the time, it can be activated by pressing the “Edit” DN key after you are out of the programming menu.

***Racer Tip***

*You can use the timer two ways, to count up or count down. If you want to see how long your car will run, use the count up setting. If you are looking to simulate race conditions, set it to count down, normally 4 or 5 minutes. There will be an audible tone each minute and a countdown for the last 10 seconds. This way you can tell how the car feels at the end of a simulated race and see if you have the proper gearing. If your car has slowed substantially before or at the end of the countdown, gear down a tooth or two on the motor pinion.*

***Idle Up: (Show picture of screen)***

This feature is typically used with gas and/or nitro powered cars or boats, primarily at start up when the engine is cold. By using the throttle trim with the idle up switch selected to the right, you can select from a 0 – 50% throttle increase.

***Racer Tip***

*The idle-up feature is used primarily with gas or nitro powered vehicles. Start off at 10% and adjust from there. The purpose is to keep a cold engine running, similar to a choke in a real car. Keep it on for about a minute, or until the engine is warmed up. (Note: The idle up can also be used as the primary throttle trim and will not affect the end points like the standard trim. Use this only if you are continually adjusting the drag brake on your vehicle).*

### ***ABS: (Anti-Lock Braking System)(Show picture of screen)***

This feature is advantageous in applications where hard, late braking is required. First you must select the point you want the ABS system to override the standard braking. Move the brake lever to the desired position and push the "Data" inc/dec keys simultaneously. Next use the "Aux." +/- keys to scroll through the ABS menu. Push the (-) key to access the screen to turn the ABS feature on or off. Press the "Data" inc/dec keys simultaneously to turn it on and off. Next you will need to select the braking depth. There will be a small "d" flashing with a %, you can select from 0 – 100% by using the "Data" inc/dec keys. This selects how much movement there is when the servo is pulsating from the ABS. Next you will need to select the "SPd" or the "speed" of the pulse by using the "Data" inc/dec keys, 0 is the fastest and 9 is the slowest. Now use the "Data" inc/dec keys to select the "dly" or delay, this is adjustable from 0 – 9, nine being the longest until the ABS engages.

#### ***Racer Tip***

*ABS is used primarily with gas vehicles but can be used for electric's as well. A good place to start is by setting the depth to 50% and the speed and delay to "5". Experiment with it to find the optimum settings for your particular application*

### ***Auxiliary Channel 3: (Show picture of screen)***

This is the third channel of your three channel radio and can be used for many different applications. There are 5 programmable settings for the Aux. 3<sup>rd</sup> channel. They can be selected by pressing the Aux. +/- keys to access each point. Once you have selected the #, they can be adjusted by using the "Data" inc/dec keys. Continue with all 5 until they are programmed to your needs. If you wish to use less than the five settings you can inhibit #2, 3 or 4 by pressing the "Data" inc/dec keys simultaneously, the screen will read "Inh." to re-activate the inhibited setting just push the "Data" inc/dec keys simultaneously and select the %. To activate the third channel once it is programmed, push the Aux + or – keys to cycle through the points you have programmed.

#### ***Racer Tip***

*The most common use of this function is the manipulation of a remote needle valve adjustment for nitro boats. Lets talk about how to set it up. First you want to determine the neutral position and set this on #3 this will allow you two clicks up and two clicks down. Next, program the settings so you can "lean" or "richen" the motor for fine-tuning the performance. Do not have drastic changes, a few % points are fine. Experiment yourself to find the optimum settings.*

### ***Servo Reversing: (Show picture of screen)***

This is used to change the rotating direction of your servos. Use the "Aux." +/- keys to select channel #1 (*Steering*), #2 (*Throttle*) or #3 (*Aux*). Normal rotation will look like "noR" and reverse will look like "REv". To change these settings you will have to push the "Data" inc/dec key simultaneously.

### ***Exponential: (Show picture of screen)***

This feature is used to change the control travel from linear to non-linear. Use the "Aux" +/- keys to select channel #1 (*Steering*) or #2 (*Throttle*), then use the "Data" inc/dec to select positive (+) or negative (-) Expo. Positive Expo increases the sensitivity and negative Expo decreases it. To reset back to the default, press the "Data" inc/dec buttons simultaneously.

#### ***Racer Tip***

*A very valuable feature, exponential allows you to change the servos travel from proportional to non-proportional. Negative expo desensitizes the initial movement and positive Expo increases the sensitivity. So why should you use it? It all depends on your driving style. Here are a few ideas for why and when to use it.*

##### ***Steering:***

*Negative expo is most commonly used for steering. This makes the vehicle much less "twitchy" and easier to control down the straight-aways. A good starting point is -30%. Remember you still get all the travel, the servo will catch up as the wheel is turned further. If you were to use "+" Expo the wheels would move more for the same amount of steering input. This tends to make the car very sensitive and will tend to oversteer. Try changing these settings yourself to see how it reacts to the different input.*

##### ***Throttle:***

*A good rule of thumb is to use negative Expo for modified motors, this gives a broader power band and positive Expo with stock motors for more punch. Another factor is the track conditions, use negative for loose conditions and positive for high traction. Again, experimenting will give you an idea what works best for your particular application and driving style.*

### ***Auto Dual Rate: (Show picture of screen)***

This feature allows you to select individual high and low speed steering travel. First you must set the throttle position where the rate will switch from #1 to #2. This is done by pulling the trigger to the desired position and pushing the "Data" inc/dec buttons simultaneously. A % will show up on the screen, this is the throttle % where the rate will change from #1 to #2, at this point, if you wish to change it repeat the procedure again. Next, select the travel you wish to associate with the #1 and #2 settings. This is done after you exit the set up menu. Select the dual rate slide switch to the left, adjust the #1 setting then pull the trigger until the #2 appears to adjust the #2 setting. You will use this feature to gain more high or low speed steering according to throttle position. ***(Important: Always allow the D/R settings to "Auto Save" by letting the voltage re-appear on the screen before proceeding with any other adjustments, this takes approx. 2 seconds)***

### ***Racer Tip***

#### ***Auto D/R***

*Unique to the Lynx 3D, Auto Dual Rate can be a big advantage when you need to have more high speed steering than low speed or vice versa. Let's say your car is understeering (Pushing) under power but oversteering (loose) when you let off the throttle entering the corner. With the Auto D/R setting you can select two different rates that will change at the programmable throttle position you select (refer to the programming instructions on how to select settings). You would then select the #1 position to have reduced travel and the #2 position to have more. These positions will be determined with testing to find the optimum setting. Swap the settings on #1 and #2 for a car that oversteers at high speed and understeers at low speed.*

#### ***Standard Dual Rate:***

*A must have for any racer, this feature is adjusted from the digital switch marked D/R on the handle. To distinguish from Auto D/R to standard D/R the dual rate switch on the front of the transmitter must be selected to the right, it will read #3 on the display screen when accessed. Use the dual rates to fine tune the handling of the vehicle by increasing or decreasing steering servo travel. If the vehicle is oversteering (Loose) pull back on the switch to decrease the steering. If it is understeering (Pushing) increase the steering by pushing the switch forward. The percentage of steering will automatically pop up on the LCD screen. You can bump it one percentage point at a time for fine-tuning or hold it down for a more drastic change. Continue to adjust this setting until the vehicle is more controllable and handling the way you want.*

This concludes the programming portion of the set up. Below are a few more tips on the Lynx 3D features that can improve your driving skills.

### Use of Trims:

#### Steering:

Make sure you have the steering trim at or very close to 0% when the horn and wheels are straight. If you change the neutral point too far from center you should re-position the servo horn to center. If the trims and horn are centered and the steering is still off, adjust the linkage to compensate.

#### Throttle:

The trims are a valuable tuning tool and can be adjusted to change the vehicles handling. (-) Trim will add more "drag brake" when the trigger is released, this will give the vehicle more steering entering the corner. Too much "drag brake" will cause the vehicle to oversteer and slow the corner speed. (+) Trim will actually allow the car to creep forward when the throttle is released so you would have to hold the brakes to keep it from moving when stopped. This will give the car less steering when entering a corner but also helps keep the corner speed up. You may have to increase your steering travel to allow you to use this set up. It can be the hot ticket for Touring cars to achieve maximum corner speed! As always test these adjustment yourself for your particular application to see how they affect your vehicle to find the optimum settings.

*(Important: Always allow the trim settings to "Auto Save" by letting the voltage re-appear on the screen before proceeding with any other adjustments, this takes approx. 2 seconds)*

### Brake Depth Adjustment:

This feature adjusts the physical limit the throttle trigger moves in providing the forward and reverse/brake function. It is adjusted by the screw on the outside of the radio opposite the trigger.

**(Show illustration)**

### **Wheel Tension Adjustment:**

This feature adjusts the steering wheel tension. The tension is set in the middle from the factory so it can be increased or decreased as desired.

**(Show illustration)**

### **D.S.C. (*Direct Servo Control*)**

This feature allows the operation of the receiver without transmitting a signal. Connect the DSC cord to the transmitter by plugging it into the jack on the left side of the transmitter face. Then connect the other end of the cord to the receiver in the Bat/DSC slot if using in conjunction with an ESC and to the external slot on the optional switch harness if used with a nicad battery.

### **Driving Tips:**

1. One of the most common problems with new racers is they feel they have to "race" everyone on the track, every turn. Try to focus on your car and your lines only, don't worry about the other guys. "Slower is faster!" Don't overdrive the track, slow down and set up for each corner early.
2. Don't try to hit full throttle out of every turn and hold it as long as possible, this just makes you go slower. Try to be smooth and roll on and off the throttle, don't just "yank" it!
3. Stay off the boards, take a conservative line at least a foot away. Slow down and get a few "clean" laps in and your lap times will be faster!
4. Once you are consistent and not crashing, you can start taking a tighter line and getting on the throttle sooner and braking later to improve your lap times, it's all about timing!
5. Remember one important thing about racing... "You must first finish to finish first!"

**Final Thoughts:**

Many years of experience and research have gone into the development of the Lynx 3D and we are confident it will help you improve your driving. You need to realize the radio is used for "Fine" tuning and will overcome some problems associated with the cars handling but a proper set up on the vehicle first will make going fast a whole lot easier!

