



**AP3x10xN&5x10xN&5x30xN&6x10xN&7x10xN**

# **Hardware Installation and Maintenance Guide**

**Issue**      12  
**Date**        2015-08-05

**Copyright © Huawei Technologies Co., Ltd. 2015. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

## **Trademarks and Permissions**



HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

## **Notice**

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

## **Huawei Technologies Co., Ltd.**

Address: Huawei Industrial Base  
Bantian, Longgang  
Shenzhen 518129  
People's Republic of China

Website: <http://e.huawei.com>

# About This Document

## Intended Audience





This document describes hardware features of AP3x10xN, 5x10xN, 5x30xN, 6x10xN and 7x10xN, and provides basic installation methods.


This document is intended for:

- Network planning engineers
- Hardware installation engineers
- Commissioning engineers
- Onsite maintenance engineers
- System maintenance engineers

## Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 <b>DANGER</b>	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
 <b>NOTICE</b>	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results.  NOTICE is used to address practices not related to personal injury.

Symbol	Description
 <b>NOTE</b>	<p>Calls attention to important information, best practices and tips.</p> <p>NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.</p>

## Change History

Changes between document issues are cumulative. The latest document issue contains all changes made in previous issues.

### Issue 12 (2015-08-05)

This version has the following updates:

Updated the packing list.

### Issue 11 (2015-05-18)

This version has the following updates:

The following information is modified:

- Added the command to check AP running status in V200R006C00.
- Added descriptions about PoE fault troubleshooting.

### Issue 10 (2014-12-05)

This version has the following updates:

The following information is added:

- [1.4 Ordering Information](#).

### Issue 09 (2014-07-30)

This version has the following updates:

The following information is modified:

- Optimized the installation steps.

The following information is added:

- Logging in to the AP using STelnet.

### Issue 08 (2013-04-10)

This version has the following updates:

The following information is added:

- AP5030DN and AP5130DN installation guide
- Note: The network cable cannot exceed 100 meters.

### **Issue 07 (2014-01-15)**

This version has the following updates:

Optimized the manual.

### **Issue 06 (2013-09-30)**

This version has the following updates:

The following information is modified:

- AP's default IP address and login password

### **Issue 05 (2013-06-29)**

This version has the following updates:

The following information is modified:

- Figure for converting SMA connectors to type—N connectors

### **Issue 04 (2013-04-30)**

This version has the following updates:

The following information is modified:

- Figure of the sheet metal mounting brackets delivered with APs

### **Issue 03 (2013-01-30)**

This version has the following updates:

The following information is added:

- Descriptions about power adapters delivered with APs
- Section: Removing an AP

### **Issue 02 (2012-12-31)**

This version has the following updates:

The following information is added:

- Power adapter cable connection figure

### **Issue 01 (2012-10-31)**

Initial commercial release

---

# Contents

---

<b>About This Document.....</b>	<b>ii</b>
<b>1 Indoor AP Overview.....</b>	<b>1</b>
1.1 Device Structure.....	1
1.2 Indicator Description.....	4
1.3 Basic Specifications.....	7
1.4 Ordering Information.....	10
<b>2 AP Installation.....</b>	<b>14</b>
2.1 Preparing for Installation.....	14
2.2 Installation Flowchart.....	15
2.3 Unpacking the Equipment.....	17
2.4 Determining the Installation Position.....	18
2.5 Installing the AP.....	19
2.5.1 Wall Mounting.....	20
2.5.2 Ceiling Mounting.....	22
2.5.3 T-rail Mounting.....	23
2.5.4 Removing an AP.....	24
2.6 Connecting Cables.....	25
2.7 Installing the Security Lock.....	29
2.8 Checking the AP After Installation.....	29
2.9 Powering on the AP.....	30
<b>3 Logging In to the AP.....</b>	<b>31</b>
3.1 Logging In to the AP Through the Console Port.....	31
3.2 Logging In to the AP Using STelnet.....	31
3.3 Logging In to the AP Using Telnet.....	33
3.4 Logging In to the AP Using a Web Client.....	34
<b>4 Hardware Failures.....</b>	<b>35</b>
4.1 A Device Fails to Be Powered On.....	35
4.2 An Optical Interface Cannot Turn Up.....	36
<b>5 Appendix.....</b>	<b>38</b>
5.1 On-site Cable Assembly and Installation.....	38

5.1.1 Cable Assembly Precautions.....	38
5.1.2 Assembling Power Cables.....	39
5.1.3 Assembling Ethernet Cables.....	48
5.1.4 Installing Cable Accessories.....	62
5.1.5 Replacing the Mold of the Crimping Tool.....	77
5.2 Environmental Requirements for Device Operation.....	81
5.2.1 Environmental Requirements for an Equipment Room.....	81
5.2.2 Requirements for Power Supply.....	88
5.3 Equipment Grounding Specifications.....	91
5.3.1 General Grounding Specifications.....	91
5.3.2 Grounding Specifications for an Equipment Room.....	91
5.3.3 Grounding Specifications for Devices.....	91
5.3.4 Grounding Specifications for Communications Power Supply.....	92
5.3.5 Grounding Specifications for Signal Cables.....	93
5.3.6 Specifications for Laying Out Grounding Cables.....	93
5.4 Engineering Labels for Cables.....	94
5.4.1 Introduction to Labels.....	94
5.4.2 Engineering Labels for Optical Fibers.....	102
5.4.3 Engineering Labels for Network Cables.....	105
5.4.4 Engineering Labels for User Cables.....	106
5.4.5 Engineering Labels for Power Cables.....	107
5.5 Guide to Using Optical Modules.....	110
5.6 Fault Tag.....	113

# 1 Indoor AP Overview

## 1.1 Device Structure


Figures in [Table 1-1](#) show the appearance of indoor APs.






### CAUTION


There is a scald warning label attached on some devices, warning you not to touch the device after the device has been operating for a long time.

**Table 1-1** Appearance of indoor APs

Product Model	Appearance
AP3010DN-AGN AP5010DN-AGN AP5010SN-GN AP6010DN-AGN AP6010SN-GN	



Product Model	Appearance
AP5030DN	 <p>The diagram shows the rear panel of the AP5030DN. It features a central display screen and four mounting screws. Below the screen is a port panel with four ports labeled 'Console', 'GE1', 'GE0/PoE', and 'DC 12V'. Callout 1 points to the DC 12V port, callout 2 to a screw on the left side, callout 3 to the Console port, callout 4 to the GE1 port, callout 5 to the GE0/PoE port, callout 6 to the Console port, and callout 7 to a small button on the right side.</p>
AP5130DN	 <p>The diagram shows the rear panel of the AP5130DN, which is similar to the AP5030DN but includes an additional antenna. Callout 10 points to the antenna on the right side. Other callouts (1-7) point to the same ports and components as in the AP5030DN diagram.</p>
AP6310SN-GN	 <p>This diagram provides a close-up view of the port panel for the AP6310SN-GN. It shows a 2.4G antenna (callout 8), a Console port (callout 6), an ETH/PoE port (callout 3), a Default port (callout 2), a DC 12V port (callout 1), and a power symbol (callout 11).</p>



**Table 1-2** describes interfaces on indoor APs.

**Table 1-2** Interfaces on indoor APs

No.	Name	Description
1	DC 12 V	DC power socket: connects a 12 V power adapter to the AP.
2	Default	Reset button: restores factory settings if you hold down the button more than 3s.
3	ETH/PoE	10/100/1000M bit/s interface: connects to the wired Ethernet. The interface can connect to a PoE power supply to provide power for the AP.
4	GE1	10/100/1000M bit/s interface: connects to the wired Ethernet.
5	GE0/PoE	10/100/1000M bit/s interface: connects to the wired Ethernet. The interface can connect to a PoE power supply to provide power for the AP.
6	Console	Console interface: connects to a maintenance terminal for AP configuration and management.
7	Security slot	Connects to a security lock.
8	2.4 GHz antenna port	Connects a 2.4 GHz antenna to the AP.

No.	Name	Description
9	5 GHz antenna port	Connects a 5 GHz antenna to the AP.
10	Dual-band antenna port	Connects a dual-band antenna to the AP.
11	Device ground screw	Connects a ground cable to the AP.

## 1.2 Indicator Description

Indoor AP series products provide a single indicator or multiple indicators.

- The AP3010DN-AGN, AP5010DN-AGN, AP5010SN-GN, AP5030DN, AP5130DN, AP6010DN-AGN, and AP6010SN-GN provide only a single indicator.
- The AP6310SN-GN, AP7110DN-AGN, and AP7110SN-GN provide multiple indicators: SYS indicator, Link indicator, and Wireless indicator.

The following table describes indicators on indoor APs.

### NOTE

- Indicator colors may vary slightly at different temperature.
- After a Fit AP is powered on, you can run the **led off** command on the AC to turn off all AP indicators. To restore the indicators to normal working status, run the **led on** command. Indicators on a Fat AP cannot be turned off using the **led off** command.

### Single indicator and SYS indicator

**Table 1-3** Descriptions about the single indicator and SYS indicator

Type	Color	Status	Description
Default status after power-on	Green	Steady on	The AP is just powered on and the software is not started yet.
Software startup status	Green	Steady on after blinking once	After the system is reset and starts uploading the software, the indicator blinks green once. Until the software is uploaded and started, the indicator remains steady green.
Running status	Green	Blinking once every 2s (0.5 Hz)	<ul style="list-style-type: none"> <li>● The system is running properly, the Ethernet connection is normal, and STAs are associated with the AP.</li> <li>● The system enters the Uboot CLI.</li> </ul>
		Blinking once every 5s (0.2 Hz)	The system is running properly, the Ethernet connection is normal, and no STA is associated with the AP. The system is in low power consumption state.

Type	Color	Status	Description
Alarm	Green	Blinking once every 0.25s (4 Hz)	<ul style="list-style-type: none"> <li>● The software is being upgraded.</li> <li>● After the software is uploaded and started, the AP working in Fit AP mode requests to go online on the AC and maintains this state until it goes online successfully on the AC (before the CAPWAP link is established).</li> <li>● The AP working in Fit AP mode fails to go online on the AC (the CAPWAP link disconnects).</li> </ul>
Fault	Red	Steady on	A fault that affects services has occurred, such as a DRAM detection failure or system software loading failure. The fault cannot be automatically rectified and must be rectified manually.

## Link indicator

**Table 1-4** Descriptions about the Link indicator

Type	Color	Status	Description
LINK	Green	Steady on	The system is running properly, the Ethernet connection is normal, and no data is being transmitted.
ACT	Green	Blinking	The system is running properly, the Ethernet connection is normal, and the AP is transmitting data. The indicator blinks more quickly when more data is being transmitted.

## Wireless indicator

**Table 1-5** Descriptions about the Wireless indicator in traffic volume mode

Color	Status	Description
Yellow/green	Off	Radios are disabled, and no STA is connected to the AP.
Yellow/green	Steady on	The AP has STAs connected to the 2.4 GHz radio or 5 GHz radio, but no data is being transmitted.

Color	Status	Description
Green	Blinking	The AP has STAs connected to the 2.4 GHz radio and is transmitting data. The indicator blinks more quickly when more data is being transmitted.
Yellow	Blinking	The AP has STAs connected to the 5 GHz radio and is transmitting data. The indicator blinks more quickly when more data is being transmitted.
Yellow/green	Blinking alternatively	The AP has STAs connected to both the 2.4 GHz radio and 5 GHz radio. The indicator blinks more quickly when more data is being transmitted.

**Table 1-6** Descriptions about the Wireless indicator in signal strength mode

Color	Status	Description
Yellow/green	Off	The AP is not transmitting or receiving data or the signal strength is extremely low.
	Blinking once every 2s (0.5 Hz)	The AP is transmitting or receiving data normally, and the signal strength is low.
	Blinking green once every 0.25 seconds (4 Hz)	The AP is transmitting or receiving data normally, and the signal strength is medium.
	Steady on	The AP is transmitting or receiving data normally, and the signal strength is high.

 **NOTE**

When the WDS/Mesh function is enabled on an AP, the blinking frequency of its Wireless indicator indicates the receive signal strength on the WDS/Mesh connection by default. After you connect an AP to a WDS/Mesh network, you can run the **wifi-light { signal-strength | traffic }** command on the AC to make the Wireless indicator blinking frequency indicate receive signal strength or service traffic rate.

- **wifi-light signal-strength:**
  - If the Mesh function is enabled on the AP, the blinking frequency of the Wireless indicator reflects the weakest signal strength of all neighboring APs.
  - If WDS is enabled on an AP, the blinking frequency of the Wireless indicator reflects the strength of signals received from a WDS AP.
    - If the AP works in leaf mode, the blinking frequency of the Wireless indicator reflects the strength of signals received from a middle AP.
    - If the AP works in middle mode, the blinking frequency of the Wireless indicator reflects the strength of signals received from a root AP.
    - If the AP works in root mode, the blinking frequency of the Wireless indicator reflects the weakest signal strength of middle APs.
- **wifi-light traffic:** allows the Wireless indicator to reflect the service traffic volume on the radio.

When an AP functions as a Fat AP, the Wireless indicator of the AP can not reflect the signal strength.

The AP6310SN-GN does not support WDS/Mesh functions; therefore, the Wireless indicator of the AP6310SN-GN does not indicate the signal strength.

## 1.3 Basic Specifications

**Table 1-7** Basic specifications of the AP3010DN-AGN, AP5010SN-GN, AP5010DN-AGN, AP6010DN-AGN, and AP6010SN-GN

Item		Description
Technical specifications	Dimensions (H x W x D)	50 mm x 180 mm x 180 mm
	Weight	0.4 kg
	System memory	<ul style="list-style-type: none"> <li>● 256 MB DDR2</li> <li>● 32 MB flash memory</li> </ul>
Power specifications	Power input	<ul style="list-style-type: none"> <li>● DC 12 V ± 10%</li> <li>● PoE power supply: in compliance with IEEE 802.3af/at</li> </ul> <p><b>NOTE</b>                      The AP6010DN-AGN and AP6010SN-GN cannot use the PoE power supply and DC power supply simultaneously.</p>

Item		Description
	Maximum power consumption	<ul style="list-style-type: none"> <li>● AP3010DN-AGN: 9.5 W</li> <li>● AP5010DN-AGN: 9.5 W</li> <li>● AP5010SN-GN: 6.0 W</li> <li>● AP6010DN-AGN: 10.2 W</li> <li>● AP6010SN-GN: 6.5 W</li> </ul> <p><b>NOTE</b> The actual maximum power consumption depends on local laws and regulations.</p>
Environment specifications	Operating temperature and altitude	-60 m to +1800 m: -10°C to +50°C 1800 m to 5000 m: Temperature decreases by 1°C every time the altitude increases 300 m.
	Storage temperature	-40°C to +70°C
	Operating humidity	5% to 95% (non-condensing)
	IP grade	IP31
	Atmospheric pressure	70 kPa to 106 kPa

**Table 1-8** Basic specifications of the AP5030DN and AP5130DN

Item		Description
Technical specifications	Dimensions (H x W x D)	53 mm x 220 mm x 220 mm
	Weight	1.0 kg
	System memory	<ul style="list-style-type: none"> <li>● 256 MB DDR2</li> <li>● 32 MB flash memory</li> </ul>
Power specifications	Power input	<ul style="list-style-type: none"> <li>● DC 12 V ± 10%</li> <li>● PoE power: -48 V DC (in compliance with IEEE 802.3af/at)</li> </ul>
	Maximum power consumption	12.95 W <b>NOTE</b> The actual maximum power consumption depends on local laws and regulations.
Environment specifications	Operating temperature and altitude	-60 m to +1800 m: -10°C to +50°C 1800 m to 5000 m: Temperature decreases by 1°C every time the altitude increases 300 m.
	Storage temperature	-40°C to +70°C

Item		Description
	Operating humidity	5% to 95% (non-condensing)
	IP grade	IP41
	Atmospheric pressure	70 kPa to 106 kPa

**Table 1-9** Basic specifications of the AP6310SN-GN

Item		Description
Technical specifications	Dimensions (H x W x D)	35 mm x 150 mm x 130 mm
	Weight	0.6 kg
	System memory	<ul style="list-style-type: none"> <li>● 128 MB DDR2</li> <li>● 32 MB flash memory</li> </ul>
Power specifications	Power input	<ul style="list-style-type: none"> <li>● DC 12 V ± 10%</li> <li>● PoE power supply: -48 V DC (in compliance with IEEE 802.3af/at)</li> </ul> <p><b>NOTE</b> The AP6310SN-GN cannot use the PoE power supply and DC power supply simultaneously.</p>
	Maximum power consumption	<p>8.3 W</p> <p><b>NOTE</b> The actual maximum power consumption depends on local laws and regulations.</p>
Environment specifications	Operating temperature and altitude	<p>-60 m to +1800 m: -10°C to +50°C</p> <p>1800 m to 5000 m: Temperature decreases by 1°C every time the altitude increases 300 m.</p>
	Storage temperature	-40°C to +70°C
	Operating humidity	5% to 95% (non-condensing)
	IP grade	IP31
	Atmospheric pressure	70 kPa to 106 kPa



**Table 1-10** Basic specifications of the AP7110SN-GN and AP7110DN-AGN

Item		Description
Technical specifications	Dimensions (H x W x D)	45 mm x 200 mm x 200 mm
	Weight	1.0 kg
	System memory	<ul style="list-style-type: none"> <li>● 256 MB DDR3</li> <li>● 32 MB flash memory</li> </ul>
Power specifications	Power input	<ul style="list-style-type: none"> <li>● DC 12 V ± 10%</li> <li>● PoE power: -48 V DC                             <ul style="list-style-type: none"> <li>- AP7110SN-GN: IEEE 802.3af/at</li> <li>- AP7110DN-AGN: IEEE 802.3at</li> </ul> </li> </ul>
	Maximum power consumption	<ul style="list-style-type: none"> <li>● AP7110DN-AGN: 15.7 W</li> <li>● AP7110SN-GN: 8.7 W</li> </ul> <p><b>NOTE</b>                      The actual maximum power consumption depends on local laws and regulations.</p>
Environment specifications	Operating temperature and altitude	-60 m to +1800 m: -10°C to +55°C 1800 m to 5000 m: Temperature decreases by 1°C every time the altitude increases 300 m.
	Storage temperature	-40°C to +70°C
	Operating humidity	5% to 95% (non-condensing)
	IP grade	IP41
	Atmospheric pressure	70 kPa to 106 kPa

## 1.4 Ordering Information

To place an order, contact the Huawei local office.

Part Number	Description
2355829	Assembling Components, AP3010DN-AGN-CN, AP3010DN-AGN Mainframe(11n, General AP Indoor, 2x2 Double Frequency, Built-in Antenna, AC/DC adapter(CN))
2356921	Assembling Components, AP-D4-FAT-S, AP-D4-FAT-S Bundle(Including AP3010DN-AGN-FAT-DC*4, AC/DC adapters(CN))

Part Number	Description
2355547	Assembling Components,AP5010DN-AGN,AP5010DN-AGN Mainframe (11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,No AC/DC adapter)
2355674	Assembling Components,AP5010SN-GN,AP5010SN-GN Mainframe (11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,No AC/DC adapter)
2356281	Assembling Components,AP5010DN-AGN-USA,AP5010DN-AGN Bundle(11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter(US),United States dedicated)
2357629	Assembling Components,AP5010DN-AGN-FAT-DC,AP5010DN-AGN Bundle(FAT AP,11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter)
2357632	Assembling Components,AP5010SN-GN-FAT-DC,AP5010SN-GN Bundle(FAT AP,11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,AC/DC adapter)
2358264	Assembling Components,AP5010DN-AGN-DC,AP5010DN-AGN Bundle (11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter)
2358263	Assembling Components,AP5010SN-GN-DC,AP5010SN-GN Bundle (11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,AC/DC adapter)
2358108	Assembling Components,AP5030DN,AP5030DN Mainframe (11ac,General AP Indoor,3x3 Double Frequency,Built-in Antenna,No AC/DC adapter)
2358109	Assembling Components,AP5030DN-DC,AP5030DN Bundle (11ac,General AP Indoor,3x3 Double Frequency,Built-in Antenna,AC/DC adapter)
02350CPM	Assembling Components,AP5030DN-USA,AP5030DN Bundle (11ac,General AP Indoor,3x3 Double Frequency,Built-in Antenna,AC/DC adapter(US),United States dedicated)
2358560	Assembling Components,AP5030DN-FAT-DC,AP5030DN Bundle(FAT AP,11ac,General AP Indoor,3x3 Double Frequency,Built-in Antenna,AC/DC adapter)
2358561	Assembling Components,AP5130DN,AP5130DN Mainframe (11ac,General AP Indoor,3x3 Double Frequency,External Antenna,No AC/DC adapter)
2358562	Assembling Components,AP5130DN-DC,AP5130DN Bundle (11ac,General AP Indoor,3x3 Double Frequency,External Antenna,AC/DC adapter)

Part Number	Description
2358563	Assembling Components,AP5130DN-FAT-DC,AP5130DN Bundle(FAT AP,11ac,General AP Indoor,3x3 Double Frequency,External Antenna,AC/DC adapter)
2354196	Assembling Components,AP6010DN-AGN,AP6010DN-AGN Mainframe (11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,No AC/DC adapter)
2354197	Assembling Components,AP6010SN-GN,AP6010SN-GN Mainframe (11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,No AC/DC adapter)
2354198	Assembling Components,AP6310SN-GN,AP6310SN-GN,AP6310SN-GN Mainframe(11n,Distributed AP Indoor,Single Frequency,No AC/DC adapter)
2356284	Assembling Components,AP6310SN-GN-USA,AP6310SN-GN Bundle (11n,Distributed AP Indoor,Single Frequency,AC/DC adapter(US),United States dedicated)
2356280	Assembling Components,AP6010DN-AGN-USA,AP6010DN-AGN Bundle(11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter(US),United States dedicated)
2357628	Assembling Components,AP6010DN-AGN-FAT-DC,AP6010DN-AGN Bundle(FAT AP,11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter)
2357631	Assembling Components,AP6010SN-GN-FAT-DC,AP6010SN-GN Bundle(FAT AP,11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,AC/DC adapter)
2358260	Assembling Components,AP6010DN-AGN-DC,AP6010DN-AGN Bundle (11n,General AP Indoor,2x2 Double Frequency,Built-in Antenna,AC/DC adapter)
2358259	Assembling Components,AP6010SN-GN-DC,AP6010SN-GN Bundle (11n,General AP Indoor,2x2 Single Frequency,Built-in Antenna,AC/DC adapter)
2358262	Assembling Components,AP6310SN-GN-DC,AP6310SN-GN Bundle (11n,Distributed AP Indoor,Single Frequency,AC/DC adapter)
2355553	Assembling Components,AP7110DN-AGN,AP7110DN-AGN Mainframe (11n,Enhanced AP Indoor,3x3 Double Frequency,External Antenna,No AC/DC adapter)
2355680	Assembling Components,AP7110SN-GN,AP7110SN-GN Mainframe (11n,Enhanced AP Indoor,3x3 Single Frequency,External Antenna,No AC/DC adapter)

Part Number	Description
02350CVQ	Assembling Components,AP7110DN-AGN-FAT-DC,AP7110DN-AGN Bundle(FAT AP,11n,Enhanced AP Indoor,3x3 Double Frequency,External Antenna,AC/DC adapter)
2356279	Assembling Components,AP7110DN-AGN-USA,AP7110DN-AGN Bundle(11n,Enhanced AP Indoor,3x3 Double Frequency,External Antenna,AC/DC adapter(US),United States dedicated)
2358266	Assembling Components,AP7110DN-AGN-DC,AP7110DN-AGN Bundle (11n,Enhanced AP Indoor,3x3 Double Frequency,External Antenna,AC/DC adapter)
2358265	Assembling Components,AP7110SN-GN-DC,AP7110SN-GN Bundle (11n,Enhanced AP Indoor,3x3 Single Frequency,External Antenna,AC/DC adapter)

# 2 AP Installation

## 2.1 Preparing for Installation

This section describes safety precautions and tool preparations for AP installation.

### Safety Precautions

- Take proper measures to prevent injuries and device damage.
- Place the device in a dry and flat position away from any liquid and prevent the device from slipping.
- Keep the device clean.
- Do not put the device and tools in the aisles.









### CAUTION















Only the qualified personnel are permitted to install and remove the device and its accessories. Before installation and operation, read the safety precautions carefully.

### Tool Preparation

To install indoor APs, prepare tools listed in [Table 2-1](#).

**Table 2-1** Tools

<p>Phillips screwdriver</p> 	<p>Torque screwdriver</p>   3mm/5mm   (M3-M6)	<p>Marker</p> 
---	--	---

<p>Hammer drill (<math>\phi 6</math>)</p> 	<p>Utility knife</p> 	<p>Cable cutter</p> 
<p>Diagonal pliers</p> 	<p>RJ45 crimping tool</p> 	<p>Wire stripper</p> 
<p>Network cable tester</p> 	<p>Multimeter</p> 	<p>Inner hexagon wrench</p> 
<p>Ladder</p> 	<p>Adjustable wrench</p> 	<p>Rubber mallet</p> 
<p>ESD gloves</p> 	<p>Level</p> 	<p>-</p>

## 2.2 Installation Flowchart

The following figure shows the process for installing an indoor AP.

**Figure 2-1** Installation flowchart of the AP3010DN-AGN, AP5010DN-AGN, AP5010SN-GN, AP6010DN-AGN, AP6010SN-GN, AP6310SN-GN, AP7110SN-GN and AP7110DN-AGN





Figure 2-2 Installation flowchart of the AP5030DN and AP5130DN



## 2.3 Unpacking the Equipment

Before unpacking the carton, ensure that the packing carton is intact and not damaged or soaked. Stop unpacking if the equipment is rusted or soggy. Then, investigate causes and contact the supplier.

After unpacking, check items in the carton against the packing list. If any item is missing, contact the supplier or agent.

Usually, the packing list contains the following items.

- AP device
- Power adapter (optional)
- Sheet metal mounting bracket<sup>4</sup>
- 2.4 GHz antenna<sup>1</sup>
- 5 GHz antenna<sup>1</sup>
- Dual-band antenna port<sup>2</sup>
- Expansion screws



- OT terminal<sup>3</sup>
- Quick Start Guide
- Warranty card
- Qualification Card
- MAC address label
- SN label


 **NOTE**

If the AT needs to be powered by an AC power supply, a PoE adapter must be independently purchased.

Pay attention to the following:

1. Three 2.4 GHz antennas and three 5 GHz antennas are contained in the AP7110DN-AGN carton, and three 2.4 GHz antennas are contained in the AP7110SN-GN carton. Cartons of other models do not contain these two types of antennas.
2. Only the AP5130DN carton contains three dual-band antennas.
3. Only the AP6310SN-GN and AP7110 series have OT terminals delivered.
4. Currently, two types of sheet metal mounting brackets are available: sheet metal mounting bracket for the AP5030DN and AP5130DN, which has four mounting holes (see the left figure in [Figure 2-3](#)), and sheet metal mounting bracket for other indoor AP models, which has four mounting screws (see the right figure in [Figure 2-3](#)).

**Figure 2-3** Sheet metal mounting brackets




## 2.4 Determining the Installation Position

When determining the AP installation position, comply with the following rules:

- Try to reduce the number of obstacles, such as walls, between the AP and user terminals.
- Install the AP away from electronic devices that can cause radio interference, such as the microwave oven.
- Install the AP in a hidden position that does not affect daily lives and work of residents.
- Install the AP in a site that is free from leaking or dripping water, heavy dew, and humidity, and take protective measures to prevent water from flowing into the equipment along the cable.

Indoor APs are usually mounted on a wall or ceiling using sheet metal mounting brackets. The installation position is determined by the site survey. There must be at least 200 mm clearance between the cabling end of the AP and the wall. [Figure 2-4](#) shows space requirements.


Figure 2-4 Mounting an AP



## 2.5 Installing the AP

All cables of the AP5030DN and AP5130DN, including network cables, power supply cables, and console cables are routed towards the same direction. Before installing an AP on the mounting bracket, connect cables to the AP first. [Figure 2-5](#) shows cable deployment and AP installation.

Figure 2-5 Cable deployment and AP installation




 **NOTE**

- The AP5030DN and AP5130DN must have cables connected first before installation. Except the two models, the procedures for installing the other models of indoor APs are the same unless otherwise stated. The following figures use the AP7110DN-AGN as an example.
- Remove the protective film on the AP surface before installation to prevent electrostatic discharge.


## 2.5.1 Wall Mounting

Mounting APs on a wall requires sheet metal mounting brackets and expansion screws. The procedures are as follows:


1. Fix the mounting bracket to the wall, adjust the installation position, and use the marker to mark the drilling positions where expansion screws are installed.




2. Use a 6 mm drill bit to drill 25 mm to 30 mm deep holes in the drilling positions. Hammer the expansion tubes into the holes until the expansion tubes are completely embedded into the wall.



3. Fix the mounting bracket to the wall and use the Phillips screwdriver to fasten three expansion screws into the expansion tubes.



4. Align the mounting holes at the rear of the AP with the mounting screws on the mounting bracket and hang the AP on the bracket. Press the AP downwards to secure the AP on the wall.



**NOTE**


The AP5030DN and AP5130DN use a different type of sheet metal mounting bracket than other APs. When installing an AP5030DN or AP5130DN, align the mounting screws at the rear of the AP with the mounting holes on the sheet metal mounting bracket and then press the AP downwards to secure the AP on the bracket.

## 2.5.2 Ceiling Mounting

1. Fix a locking clip at the rear of the AP with two M3x6 screws. The locking clip prevents the AP hung on the mounting bracket from swaying.

**NOTE**


Only the AP6310SN-GN and AP7110 series require the locking clip during their installation.



1. M3x6 screw

2. Locking clip

2. Remove a ceiling tile, determine locations of mounting holes based on the distance between two installation holes on the mounting bracket, use a hammer drill to drill holes on the ceiling tile, and fix the mounting bracket to the ceiling tile.




1. Ceiling tile	2. Adjustable buckle	3. M4x30 screw
-----------------	----------------------	----------------

**NOTICE**

The screws provided for ceiling-mounting of APs are 30 mm long and can be used to fix an AP on a ceiling not thicker than 15 mm. To install APs on thicker ceilings, you need to purchase longer screws.

3. Hang the AP on the mounting screws by aligning the mounting holes at the rear of the AP with the mounting screws on the bracket and push the AP horizontally to secure the AP.



**NOTE**

- Ensure that the AP is correctly installed on the mounting bracket and there must be 200 mm space above and around the AP for maintenance.
- The AP5030DN and AP5130DN use a different type of sheet metal mounting bracket than other APs. When installing an AP5030DN or AP5130DN, align the mounting screws at the rear of the AP with the mounting holes on the sheet metal mounting bracket and then press the AP downwards to secure the AP on the bracket.


### 2.5.3 T-rail Mounting

1. Fix a locking clip at the rear of the AP with two M3x6 screws. For installation methods, see step 1 in Ceiling Mounting.

 **NOTE**


Only the AP6310SN-GN and AP7110 series require the locking clip during their installation.

2. Remove two ceiling tiles around the T-rail, use screws to fix the adjustable buckle to the mounting bracket, hook the adjustable buckle to the T-rail, and secure the screw on the adjustable buckle to fasten the mounting bracket and T-rail.



1. T-rail	2. Adjustable buckle	3. M3x6 screws
-----------	----------------------	----------------

3. Align the mounting holes at the rear of the AP with the mounting screws on the sheet metal mounting bracket and secure the AP on the bracket.



 **NOTE**

- Ensure that the AP is correctly installed on the mounting bracket and there must be 200 mm space above and around the AP for maintenance.
- The AP5030DN and AP5130DN use a different type of sheet metal mounting bracket than other APs. When installing an AP5030DN or AP5130DN, align the mounting screws at the rear of the AP with the mounting holes on the sheet metal mounting bracket and then press the AP downwards to secure the AP on the bracket.


## 2.5.4 Removing an AP

To remove an AP, push the metal reed upward with a screwdriver and use the other hand to pull the AP horizontally (See [Figure 2-6](#)).

 **NOTE**

Only the AP6310SN-GN and AP7110 series require the locking clip during their installation. Therefore, the method of removing an AP by pushing the metal reed upward applies only to the AP6310SN-GN and AP7010 series.

**Figure 2-6** Removing an AP






## 2.6 Connecting Cables


Figures in [Table 2-2](#) show the appearance of indoor APs.

**Table 2-2** Appearance of indoor APs (front view)

Product Model	Appearance
AP3010DN-AGN AP5010DN-AGN AP5010SN-GN AP6010DN-AGN AP6010SN-GN	<p>The diagram shows the front view of an indoor AP. It features a DC 12V port (labeled '6'), an ETH PoE port (labeled '5'), and a Console port. The DC 12V port is highlighted with a yellow warning triangle and the text 'DC 12V'. Below the ports, the text 'DC 12V Default ETH PoE' and 'Console' are visible.</p>



Product Model	Appearance
AP5030DN	 <p>The diagram shows the rear panel of the AP5030DN. It features a central display screen and four circular mounting holes. Below the screen is a port panel with four ports labeled 'Console', 'GE1', 'GE0/PoE', and 'DC 12V'. Callout 5 points to the 'GE0/PoE' port, and callout 6 points to the 'DC 12V' port.</p>
AP5130DN	 <p>The diagram shows the rear panel of the AP5130DN. It features a central display screen and four circular mounting holes. Below the screen is a port panel with four ports labeled 'Console', 'GE1', 'GE0/PoE', and 'DC 12V'. Callout 3 points to the right side of the device, callout 5 points to the 'GE0/PoE' port, and callout 6 points to the 'DC 12V' port.</p>
AP6310SN-GN	 <p>The diagram is a close-up of the port panel of the AP6310SN-GN. From left to right, the ports are: a 2.4G antenna port (callout 2), a Console port, an ETH/PoE port (callout 5), a Default port, a DC 12V port (callout 6), and a power input port (callout 4).</p>



**Table 2-3** describes cable connections of indoor APs.

**Table 2-3** Cable connections of indoor APs

No.	Cable	Description
1	5 GHz antenna cable	Connects a 5 GHz antenna to the AP to send and receive service signals.
2	2.4 GHz antenna cable	Connects a 2.4 GHz antenna to the AP to send and receive service signals.
3	Dual-band antenna	Connects a dual-band antenna to the AP to send and receive service signals.
4	Ground cable	Grounds the AP. The M4 connector of the ground cable is connected to the AP and the M6 connector is connected to the protection ground.
5	Network cable	<ul style="list-style-type: none"> <li>● CAT5E cables or cables of a higher grade are used.</li> <li>● Ensure that the AP is connected to the Ethernet using the Ethernet cable that works properly. If the Ethernet cable is not working properly, for example, RJ45 connectors are short-circuited, the AP may fail to be powered on or fail to work. Before connecting an Ethernet cable to the AP, use the cable test tool to check whether the cable is qualified. If the cable is unqualified, replace it.</li> </ul>

No.	Cable	Description
6	DC power adapter	<ul style="list-style-type: none"> <li>● The AP supports the PoE power supply and DC power supply.</li> <li>● To connect the AP to a DC power source, use the power adapter delivered with the AP; otherwise, the AP maybe damaged.</li> </ul>

 **NOTE**


- Different power adapters are delivered with indoor AP products according to standards in the countries or regions where the AP products are delivered. These countries and regions are identified by the barcode on an AP's nameplate, including: EU (Europe), UK (United Kingdom), CN (China), AU (Australia), US (United States), and USA (the AP is sold only in the U.S).
- The AP products sold in the U.S have a fixed country code US, and the country code change function is disabled.
- When PoE and power adapter power supplies are available, the devices are preferentially powered by the power adapter.

**Pay attention to the following points when installing antennas**

- Antennas of the AP6310SN-GN, AP7110DN-AGN, AP7110SN-GN, and AP5130DN must comply with local laws and regulations.
- Antennas need to be installed by qualified personnel. An AP can only use the antennas delivered with it.
- You need to connect external antennas to the AP7110 series, AP6310SN, and AP5130DN. Exercise caution when bending the antennas. Misoperation may hurt your hands. Adjust the antennas according to signal coverage.

When connecting to RF cables, the requirements of bend radius are: RG-8U RF cable: > 150 mm; 1/2" RF cable: > 50 mm; 7/8" RF cable: > 250 mm. One inch (1") equals 25.4 mm.

- When replacing WA633SNs with AP6310SN-GNs, you need to convert SMA connectors to Type N connectors (see Figure a and Figure b). You can also make new feeder lines matching the connectors of the AP6310SN-GNs (see Figure c).



- When the RF connector of an AP becomes loose, tighten it with a maximum torque of 13 N•m.

**Pay attention to the following points when installing network cables**


- Before connecting an Ethernet cable to the AP, use the cable test tool to check whether the cable is qualified. If the cable is unqualified, replace it.

- Do not connect the service network cable to the console port. Otherwise, the AP may be damaged when the PoE power supply is used.
- Use standard RJ45 connectors on network cables for the AP5010 series.
- Before removing network cables or power cables from an AP5030DN or AP5130DN, remove the AP from the mounting bracket first to prevent damage to the network cables or power cables.
- The cable cannot exceed 100 meters.

## 2.7 Installing the Security Lock

There is a security slot on the AP. You can lock the AP to an immovable object to prevent the AP against theft. The detailed procedures are as follows:

1. Fasten the cable of the security lock to an immovable object around.
2. Insert the security lock into the security slot and lock it.



### NOTE

You need to purchase the security lock separately.

## 2.8 Checking the AP After Installation

**Table 2-4** shows the items to be checked after AP installation is complete.

**Table 2-4** AP installation checklist

No.	Check Item
1	The AP is installed by strictly following the design draft. The installation position meets space requirements, with maintenance space reserved.
2	The AP is securely installed.
3	The power cables and PGND cables are intact and not spliced.
4	Terminals of the power cables and PGND cables are welded or cramped firmly.
5	All power cables or PGND cables are not short-circuited or reversely connected and must be intact with no damage.

No.	Check Item
6	The power cables and ground cables are separated from other cables and bundled separately.
7	The working ground, protection ground, and surge protection ground share the same group of ground bars.
8	Connectors of signal cables are complete, intact, and tightly connected. The signal cables are not damaged or broken.
9	Labels on cables, feeders, or jumpers are clear and correct.

## 2.9 Powering on the AP

Indoor APs support the DC power supply and PoE power supply. You can select the power supply mode as required.

### Checking Before Power-on

After the AP installation is complete, check the following items before powering on the AP:

- The AP is correctly connected to the power adapter if it uses the DC power supply.
- The PoE power supply device is well grounded if the AP uses the PoE power supply.

 **NOTE**

- The AP6010DN-AGN, AP6010SN-GN, and AP6310SN-GN cannot use the PoE power supply and DC power supply simultaneously.
- Do not frequently power on and off an AP.

### Indicator Status

You can check the power-on status by observing indicators on the AP. For details, see [1.2 Indicator Description](#).

# 3 Logging In to the AP

---

## 3.1 Logging In to the AP Through the Console Port

This section describes how to log in to the AP through the console port. After logging in to the AP, you can configure the AP using commands.

1. Connect a PC to the AP using a console cable. Connect the RJ45 connector to the console port of the AP and the DB9 connector to the serial port of a PC.

 **NOTE**

If your PC's operating system provides terminal simulation software (like HyperTerminal in Windows 2000/XP), you do not need to install additional terminal simulation software. If the PC runs on an operating system without terminal simulation software (like Windows 7), install third-party terminal simulation software on the PC by referring to user manual or online help.

2. Start the terminal simulation software, create a connection, select a serial port, and set communication parameters as follows.
  - Bits per second (B): 9600
  - Data bits (B): 8
  - Parity (P): None
  - Stop bits (S): 1
  - Flow control (F): None
3. Press **Enter** until the command line prompt of the user view, such as <Huawei>, is displayed. Then, you enter the user configuration interface. You can run commands to configure the AP. Enter a question mark (?) whenever you need help.

## 3.2 Logging In to the AP Using STelnet

This section describes how to log in to the AP using STelnet. After logging in to the AP, you can configure the AP using commands.

Before logging in to the device through STelnet, complete the following tasks:

- Starting the device properly
- Preparing network cables used to connect device interfaces.

- Configuring the PC's IP address and subnet mask. The IP address must be on the network segment 169.254.0.0/16 but cannot be 169.254.1.1. 169.254.1.100 is recommended. The subnet mask is 255.255.0.0.

**NOTE**

- Ensuring that the IP address 169.254.1.1 and subnet mask 255.255.0.0 have been configured on VLANIF 1 of the device before the delivery, and GE0/0/0 has been added to VLAN 1 by default.
- Before the device is delivered, the STelnet service has been configured on the device. The STelnet interface number is 22, and the default user name and password are respectively **admin** and **admin@huawei.com**.

**Use the SSH client software to log in to the device through STelnet from a terminal. The third-party software PuTTY is used as an example here.**


1. After the device is powered on, connect the PC's network interface to GE0/0/0 of the device using network cables.

**NOTE**

Ping 169.254.1.1 from the PC to check whether the device can be pinged successfully. If the ping operation fails, check whether the PC's IP address is correct or replace the network cable.

2. Use the PuTTY software to log in to the device, enter the device IP address, and select the SSH protocol type.

**Figure 3-1** PuTTY Configuration page



3. Click **Open**. Enter the user name and password at the prompt, and press **Enter**. You have logged in to the device. (The following information is only for reference.)

```
login as: admin
```

```
admin@169.254.1.1's password:
```

```
<Huawei>
```

 **NOTE**

It is recommended that you change the initial user name and password after login.

## 3.3 Logging In to the AP Using Telnet

This section describes how to log in to the AP using Telnet. After logging in to the AP, you can configure the AP using commands.

 **NOTE**

- In V200R005C00 and later versions, upon factory delivery, the Telnet server is disabled. Before connecting to the device through Telnet from a user terminal, make sure that the Telnet service is enabled on the device by the STelnet service.
- The Telnet protocol poses a security risk, and therefore the STelnet protocol is recommended.

1. Connect a PC to the ETH/PoE interface of the AP using a network cable.
2. Configure a static IP address for the PC. The IP address must be in the same network segment as the AP's IP address. After completing the configuration, ping the AP's IP address from the PC. If the ping operation succeeds, the connection is set up successfully. If the ping operation fails, check whether the network cable is faulty.

 **NOTE**

- In V200R002C00 and earlier versions, the IP address 192.168.0.1 and subnet mask 255.255.255.0 have been configured on VLANIF 1 of the AP before the delivery, and GE0/0/1 has been added to VLAN 1 by default.
- In V200R003C00 and later versions, the IP address 169.254.1.1 and subnet mask 255.255.0.0 have been configured on VLANIF 1 of the AP before the delivery, and GE0/0/1 has been added to VLAN 1 by default.
- If the AP working in Fit AP mode is online on the AC, the DHCP server automatically assigns an IP address to the AP. You can remotely log in to the AC on a local terminal and run the following command to check the AP's IP address:
  - For V200R005C30 and earlier versions: **display ap-run-info id ap-id**
  - For V200R006C00: **display ap run-info ap-name ap-name**

3. Enter the command line interface on the PC. For example, in Windows XP, choose **Start > Run** and enter **cmd** in the displayed dialog box.
4. Use Telnet to log in to the AP.
5. Enter the default user name **admin**. The initial password is **admin** in V200R002C00 and earlier versions and is **admin@huawei.com** in V200R003C00 and later versions. If the user view is displayed, you have logged in successfully. You are advised to change the user name and password on your first login.





**NOTE**

You can run the **quit** command to exit from the Telnet window. When the system fails to exit from the Telnet window:

- If you logged in to the AP from an AC or a switch, press **Ctrl+T** to return to the AC or switch view. This operation does not affect AP services.
- If you logged in to the AP from a PC, directly close the Telnet window. This operation does not affect AP services.

## 3.4 Logging In to the AP Using a Web Client

### Pre-configuration Tasks

Before configuring users to log in to the AP using HTTP, complete the following task:

Configure reachable routes between the terminal and the AP.



**NOTE**

- The web management system is enabled on the AP before delivery. The default IP address of the web management system is 169.254.1.1 and the mask is 255.255.0.0. The web management system provides a default user account, with the user name **admin** and password **admin@huawei.com**. You are advised to change the user name and password on your first login. Assign your PC an IP address on the same network segment as the default IP address of the web management system, and connect the PC to the GE interface. Start the web browser on the PC and visit **http://169.254.1.1** to log in to the web management system.
- You can only log in to the FAT AP using the web platform.

### Procedure

- Step 1** Open a web browser on a PC, and enter the management address in the format of **http://169.254.1.1** in the address bar. Ensure that the PC and AC can communicate with each other. Then press **Enter**. Set the language, user name, and password. The HTTPS login URL is displayed in the address box indicating that the system has gone to the HTTPS login page.



**NOTE**

You can also enter **https://IP address** in the address box to log in to the AP using HTTPS. HTTPS ensures security of login information during login and security of data exchanged during subsequent operations.

- Step 2** Click **Login** or press **Enter**. The web system home page is displayed. You can manage and maintain the equipment. For details, see the *Huawei Wireless Access Points Web-based Configuration*.

---End

# 4 Hardware Failures

## 4.1 A Device Fails to Be Powered On

### Fault Description

The SYS indicator of a device is off.

### Possible Causes

Power Supply Mode	Possible Cause
Power supply using a power module	<ul style="list-style-type: none"><li>● The power switch on the device is turned off.</li><li>● The power cable is not securely connected to the device.</li><li>● The power supply unit has failed.<ul style="list-style-type: none"><li>- If the device connects to an external power source, its power adapter may fail.</li><li>- If the device has a built-in power supply, the device itself may be faulty.</li></ul></li></ul>
PoE power supply	<ul style="list-style-type: none"><li>● The power sourcing equipment does not support the PoE function or is faulty.</li><li>● The power sourcing equipment is incorrectly configured (the PoE function is disabled or the power-off time range is improperly set).</li><li>● The line is faulty (the network cable or distribution frame is damaged).</li><li>● The AP is faulty.</li></ul>

## Troubleshooting Procedure

Power Supply Mode	Troubleshooting Procedure
Power supply using a power module	<ol style="list-style-type: none"> <li>1. Check that the power switch is on.</li> <li>2. Check that the power cable is securely connected to the device.</li> <li>3. Check whether the power supply is normal.  Replace the power adapter with a normal one. If the device is powered on, the original power adapter is faulty. Contact Huawei technical support or Huawei agent and ask them to replace the power adapter.</li> <li>4. If the device still cannot be powered on, the device itself is faulty. Contact Huawei technical support or Huawei agent and ask them to replace the device.</li> </ol>
PoE power supply	<ol style="list-style-type: none"> <li>1. Check whether the power sourcing equipment supports PoE or is faulty.</li> <li>2. Check whether the configuration on the power sourcing equipment causes PoE power supply errors, such as the PoE function is disabled or the power-off time range is incorrectly set.</li> <li>3. Check whether the network cable or distribution frame is faulty.</li> <li>4. If the device still cannot be powered on, the device itself is faulty. Contact Huawei technical support engineers or Huawei agent and ask them to replace the device.</li> </ol>

## 4.2 An Optical Interface Cannot Turn Up

### Fault Description

After an optical interface is connected to a remote device through an optical fiber, its LINK indicator is off.

### Possible Causes

- The optical fiber is faulty.
- The optical module on the optical interface cannot meet the requirements.

## Troubleshooting Procedure

1. Replace the optical fiber and optical module and check whether the optical interface can turn Up. Ensure that the optical module meets the following requirements.
2. Determine optical module attributes.
  - The optical module has passed Huawei certification.
  - The transmission speed of the optical module is the same as the interface speed.
  - The wavelength of the optical module is the same as that of the remote optical module.
  - The transmission distance of the optical module is suitable for the actual distance between the two devices.

### NOTE

- The transmission distance of an optical module is 10 km, 15 km, 20 km, 40 km, or 80 km. The optical modules with a longer transmission distance have a higher transmit power. If an optical module with a long transmission distance is used for short-distance transmission, the optical interface cannot turn Up because the transmit power is too high. The high transmit power may even burn the receiver of the remote optical module. To reduce the transmit power in this situation, use an optical attenuator between the optical module and optical fiber.
  - Optical modules with different speeds are available, for example, 155 Mbit/s, 622 Mbit/s, and 1.25 Gbit/s. It is recommended that you use an optical module with the same speed as the optical interface to ensure efficient optical transmission.
3. If the interface remains Down, contact Huawei technical support.

# 5 Appendix

---

## 5.1 On-site Cable Assembly and Installation

### 5.1.1 Cable Assembly Precautions

#### Checking the Appearance of Cables

- If the cable jacket or insulation is visibly dirty, clean it before assembly.
- If the jacket or insulation of a cable has visible damage, irreparable scuffing, or other defects, do not use the cable.
- If the shield layer of a cable is damaged, do not use the cable.
- If the cable jacket or insulation cracks after the cable is bent or twisted, discard this cable and check whether other cables have the same problem. If other cables have the same problem, replace these cables.

#### Checking the Appearance of Connectors

- Do not use connectors with visible defects, damage, rust or scuffing.
- Do not use connectors if their shells or pins have exposed part or uneven plating, or their pins are lost, broken, or bent.
- Do not use connectors that have dirt on their pins or in their jacks or if there are conductors between pins or between pins and the shell.

#### Precautions for Assembly

- Use dedicated tools or tools delivered by Huawei and follow the methods given here during assembly.
- Hold terminals of cables instead of pulling the cables themselves when installing or removing cable components.
- Take the following precautions when cutting or stripping cables:
  - Make cables slightly longer than necessary.

- Coil cables longer than 2 m (6.56 ft) after cutting. Bind and fasten the coils using bundling ropes. The inner diameters of the coils should be larger than 20 times the outer diameters of the cables.
- When stripping the jackets of cables, avoid damaging the shield layers (braid or aluminum foil), insulation, core conductors, and other jackets that do not need to be stripped.
- After assembling cables, cut all visible cross sections of jackets to ensure that the cross sections are arranged neatly.
- Do not touch the core conductors of cables with your hands. Terminate exposed conductors in a timely way after stripping off insulation so that the surface of the conductors does not become oxidized.
- Take the following precautions when crimping and connecting cables or connectors:
  - The terminals and conductors should be connected tightly after they are crimped. They should not be moved or turned.
  - Cut all the exposed copper wires.
  - Try to avoid a second crimping of sleeves.
  - Keep all the conductors clean and aligned.

 **NOTE**

The connectors, cables, and tools provided by different vendors may be different. The figures in this document are for your reference only.


## 5.1.2 Assembling Power Cables

### Assembling the OT Terminal and Power Cable

#### Context

**Figure 5-1** shows the components of an OT terminal and a power cable.

**Figure 5-1** Components of an OT terminal and a power cable




A. Heat-shrinkable tubing      B. Bare crimping terminal      C. Insulation      D. Conductor

## Procedure

- Step 1** Based on the cross-sectional area of the cable conductor, strip a length of insulation coating C to expose the conductor D of length L1, as shown in **Figure 5-2**. The recommended values of L1 are listed in **Table 5-1**.

**Figure 5-2** Stripping a power cable (OT terminal)



### NOTICE

- When you strip a power cable, do not damage the conductor of the cable.
- If the bare crimping terminal is not provided by Huawei, the value of L1 is 1 mm (0.04 in.) to 2 mm (0.08 in.) greater than the value of L.

**Table 5-1** Mapping between the cross-sectional area of the conductor and the value of L1


Cross-Sectional Area of Conductor (mm <sup>2</sup> (in. <sup>2</sup> ))	Value of L1 (mm (in.))	Cross-Sectional Area of Conductor (mm <sup>2</sup> (in. <sup>2</sup> ))	Value of L1 (mm (in.))
1 (0.002)	7 (0.28)	10 (0.015)	11 (0.43)
1.5 (0.002)	7 (0.28)	16 (0.025)	13 (0.51)
2.5 (0.004)	7 (0.28)	25 (0.039)	14 (0.55)
4 (0.006)	8 (0.31)	35 (0.054)	16 (0.63)
6 (0.009)	9 (0.35)	50 (0.077)	16 (0.63)

 **NOTE**

If you are proficient in assembling OT terminals and power cables, you can obtain the value of L1 by comparing the part to be crimped with the power cable.

**Step 2** Put the heat-shrinkable (A) tubing onto the bare crimping terminal, as shown in [Figure 5-3](#).

**Figure 5-3** Putting the heat shrink tubing onto the bare crimping terminal



**Step 3** Put the OT terminal B onto the exposed conductor, and ensure that the OT terminal is in good contact with the insulation coating C, as shown in [Figure 5-3](#).



**NOTICE**

After the conductor is fed into the OT terminal, the protruding part of the conductor, or L2 in [Figure 5-3](#), must not be longer than 2 mm (0.08 in.).


**Step 4** Crimp the joint parts of the bare crimping terminal and the conductor, as shown in [Figure 5-4](#).

 **NOTE**

The shapes of crimped parts may vary with the crimping dies.




**Figure 5-4** Crimping the joint parts of the bare crimping terminal and the conductor (OT terminal)



**Step 5** Push the heat shrink tubing (A) toward the connector until the tube covers the crimped part, and then use a heat gun to heat the tube, as shown in **Figure 5-5**.

**Figure 5-5** Heating the heat shrink tubing (OT terminal)



---

 **NOTICE**

Stop heating the shrink tubing when the connector is securely locked in the shrink tubing. Do not heat the shrink tubing too long as this may damage the insulation coating.

---


----End

## Assembling the JG Terminal and Power Cable

## Context

**Figure 5-6** shows the components of a JG terminal and a power cable.

**Figure 5-6** Components of a JG terminal and a power cable



A. JG terminal B. Heat-shrinkable tubing C. Insulation layer of a power cable D. Conductor of a power cable

## Procedure


**Step 1** Strip a part of the insulation to expose the cable conductor with a length of  $L$ , as shown in **Figure 5-7**. The recommended values of  $L$  are listed in **Table 5-2**.



### NOTICE

- When you strip a power cable, do not damage the conductor of the cable.
- If the bare crimping terminal is not provided by Huawei, you can adjust the value of  $L$  as required.

**Figure 5-7** Stripping a power cable (JG terminal)




**Table 5-2** Mapping between the cross-sectional area of the conductor and the value of L

Cross-Sectional Area of Conductor (mm <sup>2</sup> (in. <sup>2</sup> ))	Value of L (mm(in.))
16 (0.025)	13 (0.51)
25 (0.039)	14 (0.55)
35 (0.054)	16 (0.63)
50 (0.077)	16 (0.63)

**Step 2** Put the heat shrink tubing onto the bare crimping terminal, as shown in **Figure 5-8**.


**Figure 5-8** Putting the heat shrink tubing onto the bare crimping terminal



**Step 3** Put the bare crimping terminal onto the exposed conductor, and ensure that the bare crimping terminal is in good contact with the insulation of the power cable, as shown in **Figure 5-8**.


**Step 4** Crimp the joint parts of the bare crimping terminal and the conductor, as shown in **Figure 5-9**.

**Figure 5-9** Crimping the joint parts of the bare crimping terminal and the conductor (JG terminal)



**Step 5** Push the heat shrink tubing toward the connector until the tube covers the crimped part, and then use a heat gun to heat the tube, as shown in **Figure 5-10**.

**Figure 5-10** Heating the heat shrink tubing (JG terminal)




---End

## Assembling the Cord End Terminal and the Power Cable

### Context

**Figure 5-11** shows the components of a cord end terminal and a power cable.

**Figure 5-11** Components of a cord end terminal and a power cable



A. Cord end terminal

B. Insulation layer of a power cable

C. Conductor of a power cable


### Procedure

- Step 1** Strip a part of the insulation to expose the cable conductor with a length of L1, as shown in **Figure 5-12**. The recommended values of L1 are listed in **Table 5-3**.

 **NOTICE**

When you strip a power cable, do not damage the conductor of the cable.

**Figure 5-12** Stripping a power cable (cord end terminal)



**Table 5-3** Mapping between the cross-sectional area of the conductor and the value of L1


Cross-Sectional Area of Conductor (mm <sup>2</sup> (in. <sup>2</sup> ))	Value of L1 (mm (in.))	Cross-Sectional Area of Conductor (mm <sup>2</sup> (in. <sup>2</sup> ))	Value of L1 (mm (in.))
1 (0.002)	8 (0.31)	10 (0.015)	15 (0.59)
1.5 (0.002)	10 (0.39)	16 (0.025)	15 (0.59)
2.5 (0.004)	10 (0.39)	25 (0.039)	18 (0.71)
4 (0.006)	12 (0.47)	35 (0.054)	19 (0.75)
6 (0.009)	14 (0.55)	50 (0.077)	26 (1.02)

**Step 2** Put the cord end terminal onto the conductor, and ensure that the conductor is aligned with the edge of the cord end terminal, as shown in [Figure 5-13](#).

 **NOTICE**


After the conductor is fed into the cord end terminal, the protruding part of the conductor must not be longer than 1 mm (0.04 in.).

**Figure 5-13** Putting the cord end terminal onto the conductor



**Step 3** Crimp the joint parts of the cord end terminal and the conductor, as shown in [Figure 5-14](#).

**Figure 5-14** Crimping the cord end terminal and the conductor



**Step 4** Check the maximum width of the tubular crimped terminal. The maximum width of a tubular crimped terminal is listed in [Table 5-4](#).

**Table 5-4** Maximum width of a tubular crimped terminal

Cross-Sectional Area of Tubular Terminal (mm <sup>2</sup> (in. <sup>2</sup> ))	Maximum Width of Crimped Terminal W1 (mm(in.))
0.25 (0.0004)	1 (0.04)
0.5 (0.0008)	1 (0.04)
1.0 (0.0015)	1.5 (0.06)
1.5 (0.0023)	1.5 (0.06)
2.5 (0.0039)	2.4 (0.09)
4 (0.006)	3.1 (0.12)

Cross-Sectional Area of Tubular Terminal (mm <sup>2</sup> (in. <sup>2</sup> ))	Maximum Width of Crimped Terminal W1 (mm(in.))
6 (0.009)	4 (0.16)
10 (0.015)	5.3 (0.21)
16 (0.025)	6 (0.24)
25 (0.039)	8.7 (0.34)
35 (0.054)	10 (0.39)

---End


## 5.1.3 Assembling Ethernet Cables

### Assembling the Shielded RJ45 Connector and Ethernet Cable

#### Context

**Figure 5-15** shows the components of an RJ45 connector and a shielded Ethernet cable.

**Figure 5-15** Shielded RJ45 connector and cable




- A. Jacket of connector    B. Metal shell of connector    C. Wire holder of connector    D. Plug of connector  
 E. Jacket of Ethernet cable    F. Shield layer of Ethernet cable    G. Twisted-pair wires    -

#### Procedure

**Step 1** Fit the jacket of the connector onto the Ethernet cable, as shown in **Figure 5-16**.

**Figure 5-16** Fitting the jacket of the connector onto the Ethernet cable




**Step 2** Remove a 30 mm (1.18 in.) long section of the jacket, cut off the nylon twine inside the jacket, and cut a no more than 5 mm (0.20 in.) cleft in the jacket, as shown in [Figure 5-17](#).



### NOTICE

- When you remove a section of the jacket, do not damage the shield layer of the twisted-pair cable.
  - When you remove the shield layer, do not damage the insulation of the twisted-pair cable.
- 


**Figure 5-17** Removing the jacket of a twisted-pair cable (unit: mm (in.))



**Step 3** Fit the metal shell onto the twisted-pair cable. The shield layer is covered by the metal shell, as shown in [Figure 5-18](#).




**Figure 5-18** Fitting the metal shell onto the twisted-pair cable




**Step 4** Fit the metal shell onto the twisted-pair cable until the shield layer is covered completely. Along the edge of the metal shell, cut off the aluminum foil shield layer and ensure that there is no surplus copper wire. The exposed twisted-pair cable is about 20 mm (0.79 in.) long, as shown in [Figure 5-19](#).

**Figure 5-19** Removing the shield layer of a twisted-pair cable (unit: mm (in.))




**Step 5** Lead the four pairs of twisted-pair wires through the wire holder, as shown in [Figure 5-20](#) and [Figure 5-21](#). Ensure that the colored wires are in the correct location in the cable.

**Figure 5-20** Leading wires through the wire holder




**Figure 5-21** Cable locations in a wire holder




**Step 6** Align the four pairs of cables in the holder, as shown in [Figure 5-22](#). The connections between the wires and the pins are shown in [Figure 5-23](#) and listed in [Table 5-5](#).

**Figure 5-22** Four pairs of cables on a wire holder



**Figure 5-23** Connections between wires and pins




**Table 5-5** Connections between wires and pins (using a straight-through cable as an example)

Matching Pins of Wires	Wire Color
1	White-Orange
2	Orange
3	White-Green
4	Blue
5	White-Blue
6	Green
7	White-Brown
8	Brown

**Step 7** Cut off the surplus cables along the lower edge of the wire holder, as shown in [Figure 5-24](#).

**Figure 5-24** Cutting off surplus cables




**Step 8** Put the connector body onto the wire holder and turn the metal shell by 90°, as shown in [Figure 5-25](#).

 **NOTE**


Ensure that the wire holder is in good contact with the connector body.

**Figure 5-25** Putting the connector body onto the wire holder




**Step 9** Push the metal shell toward the connector body until the wire holder and the connector body are engaged completely. Crimp the connector, as shown in [Figure 5-26](#).

**Figure 5-26** Crimping the connector



**Step 10** Push the jacket towards the metal shell until the metal shell is covered. This completes the assembly of one end of the cable, as shown in [Figure 5-27](#).

**Figure 5-27** Pushing the metal shell



**Step 11** To complete the assembly of the other end, repeat [Step 1](#) through [Step 10](#).


---End

## Assembling an Unshielded RJ45 Connector and Ethernet Cable

### Context

[Figure 5-28](#) shows the components of an unshielded RJ45 connector and cable.

**Figure 5-28** Components of an unshielded RJ45 connector and cable



A. Plug of connector

B. Jacket

C. Twisted-pair wires

## Procedure


**Step 1** Remove a 16-mm (0.63 in.) long section of the jacket, as shown in [Figure 5-29](#).



### NOTICE


When you remove the shield layer, do not damage the insulation of the twisted-pair cable.

**Figure 5-29** Removing the jacket of a twisted-pair cable (unit: mm (in.))



**Step 2** Align the four pairs of wires and cut the ends neatly, as shown in [Figure 5-30](#). The connections between the wires and the pins are listed in [Table 5-6](#).

**Figure 5-30** Connections between wires and pins (unit: mm (in.))



**Table 5-6** Connections between wires and pins (using a straight-through cable as an example)

Matching Pins of Wires	Wire Color
1	White-Orange
2	Orange
3	White-Green
4	Blue
5	White-Blue
6	Green
7	White-Brown


Matching Pins of Wires	Wire Color
8	Brown

**Step 3** Feed the cable into the plug, and crimp the connector, as shown in [Figure 5-31](#).

 **NOTE**

When inserting the cable, check from the side or bore of the plug to ensure that the cable is completely seated in the plug.

**Figure 5-31** Crimping the connector



**Step 4** To complete the assembly of the other end, repeat [Step 1](#) through [Step 3](#).

---End

## Checking the Appearance of Contact Strips

### Context

- To ensure proper contact between the crimped wires and the wire conductors, the heights and sizes of the contact strips must be standard and the same.
- The contact strips must be parallel to each other, with an offset of less than  $\pm 5^\circ$ . The top margin of a strip must be parallel to the axis of the connector, with an offset of less than  $\pm 10^\circ$ .
- To ensure conductivity, the surface of the contact strips must be clean.
- The contact strips must be in good contact with the RJ45 socket. The plastic separators must remain intact and be aligned.
- The contact strip blade must extend beyond the ends of the wires. The ends of the wires must be in contact with the edge of the RJ45. The distance between them must be less than 0.5 mm (0.02 in.).

### Procedure

**Step 1** Hold the crimped connector, with the front side facing you, and check whether the contact strips are of the same height. The height should be  $6.02 \pm 0.13$  mm ( $0.237 \pm 0.005$ ). If a measuring tool is not available, you can compare the connector with a standard connector. [Figure 5-32](#) shows an unqualified piece, and [Figure 5-33](#) shows a qualified piece.

 **NOTE**

All unqualified pieces must be crimped again.

**Figure 5-32** Contact strips of different heights



**Figure 5-33** Contact strips of the same height



**Step 2** Hold an RJ45 connector and turn it 45°. Observe the top edges of the metal contact strips. **Figure 5-34** shows an unqualified piece.


**Figure 5-34** Unparallel contact strips of different heights






- Step 3** Check whether the contact strips are clean. If they are not clean and the dirt cannot be removed, replace it with a new RJ45 connector. **Figure 5-35** shows an unqualified piece.

**Figure 5-35** Dirt on a contract strip



- Step 4** Check whether the contact strips and the plastic separators are well aligned and intact. If a separator is skewed and cannot be fixed, replace it with a new RJ45 connector. **Figure 5-36** shows an unqualified piece.

**Figure 5-36** Skewed plastic separators



- Step 5** Hold the connector with the side facing towards you, and check whether you can see the cross-sections of the wires. Ensure that the ends of the wires are in good contact with the edge of the RJ45, and that the contact strip blade extends beyond the ends of the wires and is crimped with the wires. If not, replace the connector. **Figure 5-37** shows an unqualified piece.

**Figure 5-37** Wires not in good contact with the edge of the RJ45



Not in good contact with the edge of the RJ45 trough

---End

## Testing the Connection of Assembled Cables

### Context

Huawei provides two types of Ethernet cables: straight-through cables and crossover cables.

- Straight-through cables are connected in a one-to-one manner. They are used to connect terminals such as a computer or switch to network devices. [Table 5-7](#) lists the connections of core wires in a straight-through cable.

**Table 5-7** Connections of core wires in a straight-through cable

RJ45 Connector 1	RJ45 Connector 2	Core Wire Color	Twisted or Not
2	2	Orange	Twisted
1	1	Orange-White	
6	6	Green	Twisted
3	3	Green-White	
4	4	Blue	Twisted
5	5	Blue-White	
8	8	Brown	Twisted
7	7	Brown-White	

- Crossover cables are connected in a crossover manner. They are used to connect terminals such as two computers or switches. [Table 5-8](#) lists the connections of core wires in a crossover cable.


**Table 5-8** Connections of core wires in a straight crossover cable

RJ45 Connector 1	RJ45 Connector 2	Core Wire Color	Twisted or Not
6	2	Orange	Twisted
3	1	Orange-White	
2	6	Green	Twisted
1	3	Green-White	
4	4	Blue	Twisted
5	5	Blue-White	
8	8	Brown	Twisted

RJ45 Connector 1	RJ45 Connector 2	Core Wire Color	Twisted or Not
7	7	Brown-White	

Figure 5-38 shows the pins of an RJ45 connector.

Figure 5-38 Pins of an RJ45 connector



## Procedure

- Step 1** Feed both connectors of the cable into the ports of the cable tester.
- Step 2** After the connectors are properly inserted, turn on the tester. If the indicators from 1 to G turn on simultaneously, you can infer that the pins work normally and the wires are correctly connected.

 **NOTE**

Turn the switch to the S position to slow down lighting of the indicators so that you can see the indicators more clearly, as shown in Figure 5-39.

Figure 5-39 Testing the conduction and connections of wires



**Step 3** Gently shake the connector and repeat **Step 2** to check whether the metal contact strips are in good contact with the core wires and Ethernet ports, as shown in **Figure 5-40**.

**Figure 5-40** Checking the reliability



The procedure for testing a crossover cable is the same as that for testing a straight-through cable except for the sequence in which the indicators turn on, which depends on the wire connections of a crossover cable.

The Ethernet cable is qualified if the indicators turn on in the following sequence:


At the master (left) section of the tester, the indicators turn on in the sequence of 1-8-G. At the slave (right) section of the tester, the indicators turn on in the sequence of 3-6-1-4-5-2-7-8-G.

If the indicators do not come on in this sequence, the Ethernet cable is unqualified.

**NOTE**

If a tester is not available, you can use a multimeter to perform a simple test, as shown in **Figure 5-41**.

**Figure 5-41** Testing the connection of an Ethernet cable



---End

## 5.1.4 Installing Cable Accessories

### Precautions for Installing Cable Accessories

#### Tools

 **NOTE**

The illustrations in this document may differ from actual situations, but the installation methods are the same. For example, in this document, the adapters of cable connectors have separate interfaces. In the actual situation, the adapters may have interfaces fixed on equipment.

Use dedicated tools provided or specified by Huawei and follow the installation procedure described here.

#### Bending Radius

Unless otherwise specified, bending radius (R) of cables or fibers must meet the requirements listed in [Table 5-9](#).

**Table 5-9** Bending radius of cables or fibers

Cable or Fiber	Bending Radius (R)
Ordinary cable	In normal cases, $R \geq 2d$ . When the cable is connected with a connector, $R \geq 5d$ .
Fiber	$R \geq 40$ mm (1.57 in.); Bending angle $> 90^\circ$

 **NOTE**

The letter d indicates the diameter of a cable or fiber.

#### Precautions for Installation

- Hold terminals of cables instead of pulling the cables themselves when installing or removing cable components.
- Do not insert a connector forcibly when the connector is blocked. Use a dedicated tool to pull out the connector. Install the connector again after you check that the pins are inserted properly.
- Before tightening screws on cable connectors, ensure that the connectors are properly connected to their adapters. Tighten the screw with appropriate force using a flat-head or Phillips screwdriver instead of bare hands or an electric screwdriver. If the screw cannot be screwed into the tapped hole, determine the reason and try again. Do not apply too much force, or the screw or adapter may be damaged.

- When removing densely aligned cables or fiber connectors, use dedicated pliers such as cable-pulling pliers and fiber-pulling pliers.
- Do not twist, bend, stretch, or extrude fibers during installation.
- Cover the idle fiber connectors with dust caps. Remove the dust caps before using the fiber connectors.

## Requirements for Cable Routing

- To protect cables, remove the burrs in the cable through-holes or install protective rings in the holes.
- To ease the connection and to avoid stress, keep cable joints slack. After connecting multiple cables to a connector that has multiple interfaces, keep the cables slack to avoid generating stress.
- Bind or clean cables gently because cable distortion affects signal quality.
- Keep cables away from moveable components such as doors.
- Sharp objects must not touch cable wiring to prevent damage to cables.
- To protect power cables, route power cables of the active and standby power modules separately.


## Installing Power Adapters

## Installing the OT Terminal

### Procedure

- Install an OT terminal.
  1. Align the hole of the OT terminal (conductor upward) with a connecting hole, as shown in [Figure 5-42](#).


**Figure 5-42** Aligning the OT terminal with a connecting hole



### NOTE


When you install an OT terminal, the crimping sleeve is installed as shown in [Figure 5-43](#), where A is correct and B is incorrect.

**Figure 5-43** Installing an OT terminal, showing the orientation of crimping sleeve



2. Place the spring washer and flat washer in turn, mount a matching screw, and fasten it clockwise, as shown in [Figure 5-44](#).

**Figure 5-44** Installing two terminals back to back




## NOTICE

Ensure that the OT terminal is not in contact with other terminals or metal components.

---

3. Move the cable slightly and ensure that it is securely connected, as shown in [Figure 5-45](#).

**Figure 5-45** Installed OT terminal




- Install two OT terminals on a post.


Before you install two OT terminals on a post, ensure that the two terminals can be installed on the post and that the electrical connecting pieces have a large contact area. Two OT terminals can be installed using any of these methods:

- Bend the upper OT terminal at a 45- or 90-degree angle, as shown in [Figure 5-46](#).
- Cross the two terminals, as shown in [Figure 5-47](#).

**Figure 5-46** Bending the upper OT terminal at a 45- or 90-degree angle



**Figure 5-47** Crossing two terminals





---

 **NOTICE**

If the two terminals are different sizes, place the smaller one above the bigger one. A maximum of two terminals can be installed on a post.

---

- To remove an OT terminal, loosen the screw counterclockwise.


----End

## Installing the Cord End Terminal

### Procedure


- Step 1** Hold a cord end terminal upright and place it on a terminal jack, as shown in [Figure 5-48](#). To ensure bump contact and dense connection, place the plain side of the terminal outwards.

**Figure 5-48** Placing a terminal on a terminal jack vertically



- Step 2** Insert the terminal into the jack vertically, and turn the screw clockwise to fasten the terminal, as shown in [Figure 5-49](#).

**Figure 5-49** Feeding the terminal into the jack





## NOTICE

- Ensure that the exposed section of the terminal is less than 2 mm (0.079 in.) in length.
  - Do not press the insulation of the terminal.
  - Insert only one terminal into one jack.
- 

**Step 3** Move the cable slightly and ensure that it is securely connected.

**Step 4** Before you remove a cord end terminal, loosen the screw counterclockwise.

----End


## Installing Ethernet Adapters

### Installing a Shielded Ethernet Connector

#### Procedure


**Step 1** Hold the male and female connectors, with the male connector facing the female connector, as shown in [Figure 5-50](#).

**Figure 5-50** Holding the male and female shielded connectors




**Step 2** Insert the male connector into the female connector, as shown in [Figure 5-51](#).

**Figure 5-51** Feeding the male shielded connector into the female shielded connector




**Step 3** When you hear a click, the cable connector is completely inserted in the port. (The clip on the cable connector pops up to fix the connector in the port.) Pull the connector slightly and ensure that it is securely connected, as shown in [Figure 5-52](#).

**Figure 5-52** Installed shielded Ethernet connector



**Step 4** To remove an Ethernet connector, press the locking key and pull out the connector, as shown in [Figure 5-53](#).

**Figure 5-53** Removing a shielded Ethernet connector




---End

## Installing an Unshielded Ethernet Connector

### Procedure


- Step 1** Hold the male and female connectors, with the male connector facing the female connector, as shown in [Figure 5-54](#).

**Figure 5-54** Holding the male and female unshielded connectors




- Step 2** Feed the male connector into the female connector, as shown in [Figure 5-55](#).

**Figure 5-55** Feeding the male connector into the female unshielded connector




- Step 3** A crisp click indicates that the connector is locked by the locking key. Pull the connector slightly and ensure that it is securely connected. [Figure 5-56](#) shows an installed Ethernet connector.

**Figure 5-56** Installed unshielded Ethernet connector



**Step 4** To remove an Ethernet connector, press the locking key and pull out the connector, as shown in [Figure 5-57](#).

**Figure 5-57** Removing an unshielded Ethernet connector



----End

## Installing Fiber Connectors

## Context

---

### NOTICE

- After you remove the dustproof cap, ensure that the fiber pins are clean and install them as soon as possible.
  - When you disassemble fiber connectors, you must use a dedicated tool if the connectors are densely installed.
- 

## Cleaning Fiber Connectors

### Procedure

- Step 1** Clean the pins of a fiber connector by using lint-free cotton and alcohol.
- Step 2** Clean the pins again by using dust-free cotton. If necessary, clean the pins by using an air gun. Ensure that the pins are free from any fiber or debris.


----End

## Installing an FC Fiber Connector

### Procedure


- Step 1** Remove the dustproof cap of the FC connector and store it for future use.
- Step 2** Align the core pin of the male connector with that of the female connector, as shown in [Figure 5-58](#).

**Figure 5-58** Aligning the male connector with the female connector




- Step 3** Align the male connector with the female connector and gently push the male connector until it is completely seated in the female connector, as shown in [Figure 5-59](#).

**Figure 5-59** Feeding the male connector into the female connector




**Step 4** Fasten the locking nut clockwise and ensure that the connector is securely installed, as shown in [Figure 5-60](#).

**Figure 5-60** Fastening the locking nut



**Step 5** To disassemble an FC fiber connector, loosen the locking nut counterclockwise, and gently pull the male connector, as shown in [Figure 5-61](#).

**Figure 5-61** Disassembling an FC fiber connector




---End

## Installing an LC Fiber Connector

### Procedure

- Step 1** Remove the dustproof cap of the LC fiber connector and store it for future use.
- Step 2** Align the core pin of the male connector with that of the female connector, as shown in [Figure 5-62](#).


**Figure 5-62** Aligning the male connector with the female connector



- Step 3** Align the male connector with the fiber adapter and gently push the male connector until it is completely seated in the fiber connector, as shown in [Figure 5-63](#).




**Figure 5-63** Feeding the male connector into the female connector




**Step 4** A clicking sound indicates that the male connector is locked, as shown in [Figure 5-64](#).

**Figure 5-64** Installed LC connector



**Step 5** To disassemble an LC fiber connector, press the locking nut to release the locking clips from the bore, and gently pull the male connector, as shown in [Figure 5-65](#).

**Figure 5-65** Disassembling an LC fiber connector




---End

## Installing the SC Fiber Connector

### Procedure


- Step 1** Remove the dustproof cap of the SC fiber connector and store it for future use.
- Step 2** Align the core pin of the male connector with that of the female connector, as shown in [Figure 5-66](#).

**Figure 5-66** Aligning the male connector with the female connector




- Step 3** Feed the fiber connector into the female connector, with your fingers holding the shell of the fiber connector (not the pigtail). When you hear a click, the fiber connector is secured by the clips (internal parts, not illustrated in the figure). Pull the fiber connector gently. If the connector does not loosen, the installation is complete. See [Figure 5-67](#).

**Figure 5-67** Installed SC fiber connector



- Step 4** To disassemble an SC fiber connector, hold the shell of the connector (do not hold the fiber) and gently pull the connector in the direction vertical to the adapter. Unlock the male connector, and then separate it from the shell, as shown in [Figure 5-68](#).

**Figure 5-68** Disassembling an SC fiber connector




---End

## Installing an MPO Connector

### Procedure


- Step 1** Remove the dustproof cap of the MPO fiber connector and store it for future use.
- Step 2** Align the core pin of the male connector with that of the female connector, as shown in [Figure 5-69](#).

**Figure 5-69** Aligning the male connector with the female connector




- Step 3** Hold the shell labeled "PUSH" and feed the male connector into the female connector until you hear a clicking sound. The male and female connectors are securely installed, as shown in [Figure 5-70](#).

**Figure 5-70** Installed MPO fiber connector



- Step 4** To disassemble an MPO fiber connector, hold the shell labeled "PULL" and remove the male connector, as shown in [Figure 5-71](#).

**Figure 5-71** Disassembling an MPO fiber connector




----End

## 5.1.5 Replacing the Mold of the Crimping Tool

### Procedure


- Step 1** Hold the handles of a pair of COAX crimping tools. Loosen the two fastening screws counterclockwise, as shown in [Figure 5-72](#).

**Figure 5-72** Loosening two fastening screws




**Step 2** Hold the handles of the COAX crimping tools to open the self-locking mechanism. The jaw of the COAX crimping tools opens automatically, as shown in [Figure 5-73](#).

**Figure 5-73** Pliers jaw opening automatically




**Step 3** Remove the mold from the COAX crimping tools, as shown in [Figure 5-74](#).

**Figure 5-74** Removing the mold from the COAX crimping tools



**Step 4** Place the mold to be installed into the jaw of the COAX crimping tools and align the screw holes, as shown in [Figure 5-75](#).

**Figure 5-75** Installing a new mold in the COAX crimping tool




## NOTICE

Keep the short side of the mold inwards and the long side outwards, with the teeth of the mold aligning from the larger size to the smaller size.


**Step 5** Hold the handles of the COAX crimping tools tightly to match the mold and the jaw completely. Align the screw holes, as shown in [Figure 5-76](#).

**Figure 5-76** Aligning the screw holes




**Step 6** Hold the handles of the COAX crimping tools with one hand. Tighten the two fastening screws clockwise. **Figure 5-77** and **Figure 5-78** shows the mold installed in the COAX crimping tool.

**Figure 5-77** Mold installed in the COAX crimping tool



**Figure 5-78** An installed mold



---End

## 5.2 Environmental Requirements for Device Operation

### 5.2.1 Environmental Requirements for an Equipment Room

#### Requirements for Selecting a Site for an Equipment Room

When designing a project, consider the communication network planning and technical requirements of the equipment. Also consider hydrographic, geological, seismic, power supply, and transportation factors.

Construction, structure, heating and ventilation, power supply, lighting and fire-proof construction of the equipment room should be designed by specialized construction designers to suit the environmental requirements of devices. The equipment room should also follow local regulations concerning the industrial construction, environmental protection, fire safety, and civil air defense. Construction must conform to government standards, regulations, and other requirements.

The equipment room should be located in a place free from high temperature, dust, toxic gases, explosive materials, or unstable voltage. Keep the equipment room away from significant vibrations or loud noises, as well as power transformer stations.

The specific requirements for selecting a site for an equipment room are as follows:

- The room should be located at a distance of at least 5 km (3.11 mi.) from heavy pollution sources such as smelting and coal mines. It should be located at a distance of at least 3.7 km (2.30 mi.) from moderate pollution sources such as chemical, rubber, and galvanization factories. It should be located at a distance of at least 2 km (1.24 mi.) from light pollution sources such as packinghouses and tanyards. If these pollution sources cannot be avoided, ensure that the equipment room is upwind of the pollution sources. In addition, use a high-quality equipment room or protection products.
- The room should be located away from livestock farms, or be upwind of the livestock farms. Do not use an old livestock room or fertilizer warehouse as the equipment room.
- The equipment room must be far away from residential areas. An equipment room that is not far away from residential areas must comply with equipment room construction standards to avoid noise pollution.
- The room should be located far away from industrial and heating boilers.
- The room should be at least 3.7 km (2.30 mi.) away from the seaside or salt lake. Otherwise, the equipment room should be airtight with cooling facilities. In addition, alkalized soil cannot be used as the construction material. Otherwise, equipment suitable for wet conditions must be used.
- The doors and windows of the equipment room must be kept closed to maintain an airtight room.
- Using steel doors to ensure sound insulation is recommended.
- No cracks or openings are allowed on the walls or floors. The outlet holes on the walls or windows must be sealed. Walls must be constructed such that they are smooth, wear-




resistant, dustproof, flame retardant, sound insulated, heat absorptive, and have electromagnetic shielding.

- The air vent of the room should be far from the exhaust of city waste pipes, big cesspools and sewage treatment tanks. The room should be in the positive pressure state to prevent corrosive gases from entering the equipment room and corroding components and circuit boards.
- It is recommended that the room be on or above the second floor. If this requirement cannot be met, the ground for equipment installation in the room should be at least 600 mm (23.62 in.) above the maximum flood level.
- The equipment room should be strong enough to resist winds and downpours.
- The room should be located away from dusty roads or sand. If this is unavoidable, the doors and windows of the equipment room must not face pollution sources.
- Do not place air conditioning vents near the equipment so that they blow directly on the equipment because condensation may be blown into the equipment.
- Do not use decorative materials that contain sulfur in the equipment room.

## Equipment Room Layout

An equipment room usually contains mobile switching equipment, telecommunications equipment, power supply equipment, and other auxiliary equipment. To ensure easy maintenance and management, place the equipment in different rooms. [Figure 5-79](#) shows the layout of the equipment room.

**Figure 5-79** Layout of the equipment room



The general layout principles of the equipment room are as follows:

- It should meet requirements for laying out and maintaining communication cables and power cables.
- It should reduce the cabling distance, which facilitates cable maintenance, reduces potential communication faults, and maximizes efficiency.


## Construction Requirements for the Equipment Room

**Table 5-10** describes the construction requirements for the equipment room.

**Table 5-10** Construction requirements for the equipment room

Item	Requirements
Area	The smallest area of the equipment room can accommodate the equipment with the largest capacity.
Net height	The minimum height of the equipment room should not be less than 3 m (9.84 ft). The minimum height of the equipment room is the net height below overhead beams or ventilation pipes.
Floor	The floor in the equipment room should be semi-conductive and dustproof. A raised floor with an ESD covering is recommended. Cover the raised floor tightly and solidly. The horizontal tolerance of each square meter should be less than 2 mm (0.08 in.). If raised floors are unavailable, use a static-electricity-conductive floor material, with a volume resistivity of $1.0 \times 10^7$ ohms to $1.0 \times 10^{10}$ ohms. Ground this floor material or raised floor. You can connect them to ground using a one megohm current-limiting resistor and connection line.
Load-bearing capacity	The floor must bear loads larger than $150 \text{ kg/m}^2$ ( $0.21 \text{ bf/in.}^2$ ).
Door and windows	The door of the equipment room should be 2 m (6.56 ft) high and 1 m (3.28 ft) wide. One door is enough. Seal the doors and windows with dustproof plastic tape. Use double-pane glass in the windows and seal them tightly.
Wall surface treatment	Paste wallpaper on the wall or apply flat paint. Do not use pulverized paint.
Cable trays	Use cable trays to arrange cables. The inner faces of the cable trays must be smooth. The reserved length and width of the cable trays, and the number, position and dimensions of the holes must comply with the requirements of device arrangement.
Water pipe	Do not pass service pipes, drainpipes, and storm sewers through the equipment room. Do not place a fire hydrant in the equipment room, but place it in the corridor or near the staircase.
Internal partition wall	Separate the area where the equipment is installed from the equipment room door. The partition wall can block some outside dust.
Installation position of the air conditioner	Install air conditioner vents so that the air does not blow directly on equipment.
Other requirements	Avoid the proliferation of mildew, and keep out rodents (like mice).

**Figure 5-80** Internal partition wall inside the equipment room



## Equipment Room Environment

Dust on devices may cause electrostatic discharge and result in poor contact for connectors or metal connection points. This problem can shorten the life span of devices and cause faults.

The equipment room must be free from explosive, conductive, magnetically-permeable, and corrosive dust. [Table 5-11](#) lists the requirement for dust concentration in the equipment room.

**Table 5-11** Requirements for dust particles in the equipment room

Mechanical active material	Unit	Concentration
Dust particle	Particle /m <sup>3</sup>	≤ 3x 10 <sup>4</sup> (no visible dust accumulated on a workbench in three days)
Suspending dust	mg/m <sup>3</sup>	≤0.2
Precipitable dust	mg/m <sup>2</sup> ·h	≤1.5
Description <ul style="list-style-type: none"> <li>● Dust particle diameter ≥ 5 μm</li> <li>● Suspending dust diameter ≤ 75 μm</li> <li>● 75 μm ≤ precipitable dust diameter ≤ 150 μm</li> </ul>		

Take the following measures to meet the requirements:

- Use dustproof materials for ground, wall, and ceiling construction.

- Use screens on the door and windows facing outside. The outer windows should be dust-proof.
- Clean the equipment room regularly and clean the air filter monthly.
- Wear shoe covers and ESD clothing before entering the equipment room.

## Requirements for Corrosive Gases

The room should be free from dusts and corrosive gases, such as SO<sub>2</sub>, H<sub>2</sub>S, and NH<sub>3</sub>. [Table 5-12](#) lists the requirements for the corrosive gas concentration.

**Table 5-12** Requirements for corrosive gas concentration

Chemical active material	Unit	Concentration
SO <sub>2</sub>	mg/m <sup>3</sup>	≤0.20
H <sub>2</sub> S	mg/m <sup>3</sup>	≤0.006
NH <sub>3</sub>	mg/m <sup>3</sup>	≤0.05
Cl <sub>2</sub>	mg/m <sup>3</sup>	≤0.01

Take the following measures to meet the requirements:

- Avoid constructing the room near a place where the corrosive gas concentration is high, such as a chemical plant.
- Ensure the air intake vent of the room is in the prevailing upwind direction from any pollution source.
- Place batteries in different rooms.
- A professional service should monitor the corrosive gas conditions regularly.

## Requirements for ESD Prevention

The absolute value of electrostatic voltage must be less than 1000 V.

Take the following measures to meet this requirement:

- Train operators about ESD prevention.
- Keep the correct humidity level in the equipment room to reduce the impact of static electricity.
- Lay out an ESD floor in equipment rooms.
- Wear ESD shoes and clothing before entering equipment room.
- Use ESD tools, such as wrist straps, tweezers, and pullers.
- Ground all conductive materials in the room, including computer terminals. Use ESD worktables.
- Keep non-ESD materials (such as common bags, foam, and rubber) at least 30 cm (11.81 in.) away from boards and ESD-sensitive components.

## Electromagnetism Requirements for the Equipment Room

All interference sources, inside or outside the equipment room, can cause equipment problems with capacitive coupling, inductive coupling, electromagnetic wave radiation, and common impedance (including grounding system) coupling. Prevent the interference using these approaches:

- Take effective measures against electrical interference from the power supply system.
- Do not use the working ground of the equipment as the same ground for surge protection. Separate them as far as possible.
- Keep the equipment far away from high-power radio transmitters, radar units, and high-frequency and high-current equipment.
- Use electromagnetic shielding if necessary.

## Requirements for Lightning Proof Grounding

**Table 5-13** lists the requirements for lightning proof grounding.

**Table 5-13** Requirements for lightning proof grounding

Item	Requirements
Capital construction	<ul style="list-style-type: none"> <li>● Use reinforced concrete to construct the equipment room.</li> <li>● Install a lightning proof device like a lightning rod outside the room.</li> <li>● The lightning proof ground shares the same grounding body with the protective ground of the room.</li> </ul>
Power cables leading in the equipment room need to be equipped with a surge protector	<ul style="list-style-type: none"> <li>● After the low-voltage power cables are led into the room, install the surge protector for the power cables in the AC voltage stabilizer and the AC power distribution panel (box). Correctly ground the surge protector nearby.</li> <li>● For an equipment room in urban area, install a power supply surge protector with the nominal discharge current of no less than 20 kA. For an equipment room that is built in a suburb and subject to lightning strikes, install a power supply surge protector with the nominal discharge current of more than 60 kA. For an equipment room that is built in a mountain area and subject to frequent lightning strikes, or in a separate high-rise building in a city, install a power supply surge protector with the nominal discharge current of more than 100 kA.</li> <li>● The ground cable of the surge protector should be no longer than 1 m (3.28 ft).</li> </ul>
Grounding for DC power distribution	<ul style="list-style-type: none"> <li>● Connect the DC working ground (positive pole of the -48 V DC power supply or the negative pole of the 24 V DC power supply) with the indoor collective ground cable nearby. The total ground cable should meet the maximum load of the equipment.</li> <li>● The power equipment must have a DC working ground cable, which can connect the power equipment to the collective ground cable of the telecommunication site (or the protective ground bar of the equipment room).</li> </ul>

Item	Requirements
Equipotential connection	<ul style="list-style-type: none"> <li>● Properly ground the devices and auxiliary devices in the room such as mobile base station, transmission, switching equipment, power supply equipment, and cable distribution frame. Connect all PGND cables to the collective protective ground bar. Connect all PGND cables in one equipment room to one protective ground bar.</li> <li>● Apply joint grounding to the working ground and protective ground of devices, which means the two share one grounding network.</li> <li>● The cable tray, rack or shell, metal ventilation pipe, metal door or window of the equipment should be grounded for protection.</li> </ul>
General requirements for grounding	<ul style="list-style-type: none"> <li>● Do not connect the neutral line of the AC power cable with the protective ground of any telecom equipment in the equipment room.</li> <li>● Do not install a fuse or switch on the ground cable.</li> <li>● All ground cables should be as short as possible, and arranged in a straight line.</li> </ul>
Grounding resistance	<ul style="list-style-type: none"> <li>● The grounding resistance must be lower than 1 ohm.</li> <li>● The upper end of the grounding body should be at least 0.7 m (2.30 ft) over the ground. In cold areas, bury the grounding body below the frozen ground.</li> <li>● Measure the grounding resistance periodically to ensure effective grounding.</li> </ul>
Routing of signal cable	<ul style="list-style-type: none"> <li>● Do not arrange the signal cables overhead in the equipment room. All signal cables must be led into the site underground.</li> <li>● Use the cables with a metal jacket or place them into a metal pipe if they come out/in the equipment room.</li> <li>● Ground the idle lines inside the cable in the equipment room.</li> <li>● Signal cables should be deployed on internal walls. Do not deploy outdoor aerial cables.</li> <li>● Keep signal cables away from power cables and surge protection devices.</li> </ul>
Collective ground cable	<ul style="list-style-type: none"> <li>● Use a ground ring or ground bar for the collective ground cable.</li> <li>● Do not use aluminum cables as ground cables. Adopt measures to prevent electrification corrosion when connecting different metal parts together.</li> <li>● Use a copper busbar as the collective ground cable with a cross-sectional area of no less than 120 mm<sup>2</sup> (0.19 in.<sup>2</sup>), or use the galvanized flat steel of the same resistance. Insulate the collective ground cable from the reinforcing steel bars of the building.</li> </ul>
Grounding lead-in	<p>The grounding lead-in should be a maximum of 30 m (98.42 ft) long. Use the galvanized flat steel with cross-sectional area of 40 mm x 4 mm (1.58 in. x 0.158 in.) or 50 mm x 5 mm (1.97 in. x 0.197 in.).</p>

Item	Requirements
Grounding of the cabinet	<ul style="list-style-type: none"> <li>● All the devices including the surge protection device in the cabinet must be connected in an equipotential manner. The ground cables can be aggregated to the ground bar or surge protector socket first, and then the ground bar or surge protector socket can be connected to the ground.</li> <li>● The resistance between the device ground terminals and ground bar cannot exceed 0.1 ohm.</li> <li>● The cabinet can be grounded using the protecting earthing (PE) wire of the electrical network in the building, zinc-coated angle steel, or the main steel bar of the building.</li> <li>● If the cabinet is grounded using the PE wire of the electrical network, use a multimeter to test the grounding status. If the voltage between the PE wire and neutral wire is lower than 5 V and the voltage between the PE wire and live wire is about 220 V, the PE wire is grounded well. If the tested AC voltages are not within the ranges, the cabinet must be grounded in other ways.</li> <li>● The yellow-green ground cable contains multiple copper wires. The cross-sectional area of the ground cable must be no less than 6 mm<sup>2</sup> (0.0093 in.<sup>2</sup>) and the length cannot exceed 3 m (9.84 ft.).</li> <li>● Ground cables cannot be twisted with signal cables.</li> <li>● Antirust and anticorrosion measures must be taken on the ground terminals.</li> <li>● The fiber reinforcing rib can be directly connected to the ground bar of the cabinet. Before wrapping the reinforcing rib with insulation tape, cut a 0.5 m (1.64 ft.) segment from the reinforcing rib. Wrap the reinforcing rib with at least five layers of insulation tape. Keep the reinforcing rib at least 5 cm (1.969 in.) from the cabinet surface.</li> </ul>

## 5.2.2 Requirements for Power Supply

### Requirements for AC Power Supply

An AC power supply system consists of power mains, uninterruptible power supplies (UPSs), and self-supplied electric generators. In addition to meeting the requirements of the server load, the AC power supply must have a simple connection line, safe operation, flexible scheduling, and easy maintenance.

The low-voltage power supply should be 3-phase, 5-wire mode or monophas 3-wire mode. This AC power supply should be 110 V/220 V, with a frequency of 50 Hz.

The UPS should supply the same power and operate at the same phase as the power mains. The switching time between the UPS and mains should be less than 10 ms; otherwise, the networking devices will reboot or reset.

For power distribution capacity in the equipment room, both the working current and fault current of the devices should be considered. Ensure that independent AC power supplies protect

independent devices. Configure the current-carrying capacity of the protection switch of the equipment room for more than that of the devices.

**Table 5-14** lists the voltage range of the AC power supply for the devices.

**Table 5-14** Voltage range of AC power supply

Item	Requirements
AC power capacity to support the devices	-10% to +5% of the rated voltage
AC power capacity to support the power modules and important buildings	-15% to +10% of the rated voltage
Frequency of alternating current	-4% to +4% of the rated value
Voltage wave shape sine distortion	Within 5% of the rated voltage

The automated electric generator must have a standard interface that supports telecommunication protocols, remote telecommunication, monitoring, and control.

AC power cables should meet the following specifications:

- AC neutral should have a conductor with the same cross section as the phase line.
- AC cables should have non-flammable insulation. The layout of AC cables should comply with local regulations. Low-voltage power distribution rooms should comply with local regulations.

## Recommendations for AC Power Supply

The following are recommendations for the AC power supply.

- If the voltage of the power mains that supply power directly to devices exceeds the rated voltage by -10% to 5%, or exceeds the voltage range that devices can support, a voltage regulating device or voltage stabilizing device is required.
- If the mains do not supply power for the device directly, or if the mains voltage exceeds the rated voltage by -15% to 10% or exceeds the input voltage range of the DC power supply, a voltage regulating device or voltage stabilizing device is required.
- A UPS or inverter power supply system is required to provide uninterrupted AC power to support the telecommunication load.
- If abnormalities occur on the mains, telecommunication servers should be equipped with a self-supplied electric generator to support the key telecommunication load. The capacity should be not less than 150% to 200% of the total uninterruptible power supply.
- Storage batteries are usually installed in a parallel connection of two groups. UPS storage batteries are generally installed in one group. The redundancy required for the UPS can rely on concatenation or parallel connection. When an inverter or a UPS is used, the active inverter is determined by the maximum power and a backup inverter is required.



## Requirements for DC Power Supply

The equipment room should receive stable and reliable DC power. Deploy the power equipment near the telecommunications equipment to make the DC feeder as short as possible. To reduce power consumption and installation cost, the loop voltage drop from the battery port to the equipment port should be less than 3.2 V.

- A large-scale enterprise can deploy an independent power supply system on each floor to supply power to the telecommunications equipment room on the respective floor.
- A medium-scale enterprise can use a power room and a battery room for centralized power supply or use distributed power supply systems.
- A small-scale enterprise can deploy an integrated power supply system in its equipment room but must take measures to prevent corrosive gases released from batteries from eroding circuit boards of telecommunications equipment.

**Table 5-15** lists the specifications for the DC power supply.

**Table 5-15** Specifications for the DC power supply

Item	Requirements
DC power capacity to support the surge current	Greater than 1.5 times the rated current
Regulated voltage precision	If the AC input voltage is in the range of 85% to 110% of the rated value, and the load current is in the range of 5% to 100% of the rated value, the output voltage of the rectifier ranges from -46.0 V to -56.4 V, with the regulated voltage precision less than or equal to 1%.
Overshoot amplitude of switch on/off	Integral value of the DC output voltage $\pm 5\%$
Peak noise voltage	$\leq 200$ mV
Dynamic response	The recovery time is less than 200 ms. The overshoot is in the range of the integral value of the DC output voltage $\pm 5\%$ .

## Recommendations for DC Power Supply

The following are recommendations for the DC power supply.

- Use distributed power supply mode. Use multiple DC power supply systems and put power equipment in multiple locations.
- Adopt a standard DC power supply system, and set the output voltage to the communications equipment within the required range.

- Improve reliability of the AC power supply system to reduce the necessary capacity of storage batteries. For small offices, increase the capacity of storage batteries if it is difficult to enhance reliability of the AC power supply system.
- The total capacity of the high-frequency switching rectifier must satisfy the power of the communication loading and battery charging. If there are 10 or fewer active rectifier modules, configure one backup module. If there are more than 10 active modules, configure one backup module for every 10 active modules.
- Install storage batteries in two or more groups. The capacity is determined by the duration for which the storage batteries must supply power. For most offices, the batteries should be able to supply power for at least one hour.

## 5.3 Equipment Grounding Specifications

### 5.3.1 General Grounding Specifications

**Table 5-16** shows the general grounding specifications.

**Table 5-16** General grounding specifications

No.	Description
1	The working ground and protective ground, including the shielded ground and the lightning-proof ground of the cable distribution frame should share the same grounding conductor.
2	The cable trays, shells, metal ventilation pipes, metal doors and windows in the equipment room should be grounded for protection.
3	The metal parts of the equipment which are electrically floating in normal conditions should be grounded for protection.
4	The ground cable must be connected securely to the protective ground bar of the equipment room.
5	Do not use other equipment as part of the ground cable or electrical connection.

### 5.3.2 Grounding Specifications for an Equipment Room

The grounding resistance of a comprehensive communication building should be less than or equal to one ohm. The grounding resistance of an ordinary communication office should be less than five ohms. The grounding resistance in an area where the earth resistance rate is high should be less than 10 ohms.

### 5.3.3 Grounding Specifications for Devices

**Table 5-17** lists the equipment grounding specifications.

**Table 5-17** Equipment Grounding Specifications

No.	Description
1	All communication devices and auxiliary devices (such as mobile base stations, transmission and switching devices, power supply devices) in the equipment room should be grounded for protection. Connect all protective ground for various devices jointly to a general ground bar, and then to the same protective ground bar in the room together with the protective ground (PGND) of the device.
2	The PGND of the equipment is shorted to the copper ground bar provided by the customer. The short-circuiting cable used should be a yellow-green plastic insulated cable with a copper core and a cross-sectional area greater than 25 sq. mm (0.039 sq. in.).
3	There are grounding terminals and grounding lugs at the lower part of the front door, rear door and side panel of the cabinet, connected to the grounding terminals of the cabinet framework through connection cables with cross-sectional area of no less than 1.6 sq. mm (0.002 sq. in.).
4	Ensure that all metal components of the cabinet conduct well. No insulating coating should be sprayed on the connection part of the metal components.
5	Connect the cabinets in the same row by fastening captive screws and gaskets on the top of the cabinets. Do not spray any coating into a rectangular area measuring 30 mm x 50 mm (1.18 in. x 1.97 in.) around the connection hole for a captive bolt. Measures to prevent rust and corrosion must be taken for this area. Zinc electroplating with iridescent yellow chromate conversion coating should be applied to the gasket and nut to ensure good electrical contact.
6	When combining cabinets of the same type, short-circuiting cables are required to connect the ground busbars (if any) of the cabinets. The cross-sectional area of the short-circuiting cable is 6 sq. mm (0.009 sq. in.) and is no more than 300 mm (11.8 in.) long. Connect the two ends of the short-circuiting cable to the ground busbar terminals of neighboring cabinets and fix them firmly.

### 5.3.4 Grounding Specifications for Communications Power Supply

**Table 5-18** shows the grounding specifications for communication power supplies.

**Table 5-18** Grounding specifications for communication power supplies

No.	Description
1	The inlet for the AC power cable at the equipment room should be equipped with a surge protection device (C-level) with a nominal discharge current no less than 20 kA.
2	The protective ground for the power supply and that for communication equipment share the same grounding conductor. If the power supply and the equipment are in the same equipment room, use the same protective ground bar for them if possible.

No.	Description
3	Use a surge protection circuit on the AC power interface.
4	The positive of the -48 V DC power supply or negative pole of the 24 V DC power supply should be grounded at the output of the DC power supply.
5	The working ground and protective ground of the DC power supply equipment should use the same grounding conductor with the protective ground of the switching equipment. If the power supply and equipment are in the same equipment room, use the same protection ground bar for them if possible.
6	Add surge protection on the DC power interface.

### 5.3.5 Grounding Specifications for Signal Cables

**Table 5-19** lists the grounding specifications for signal cables.

**Table 5-19** Grounding specifications for signal cables

No.	Description
1	Equip the cable outdoors with a metal jacket, well grounded at both ends, or connect the ends of the metal jacket to the protective ground bar of the equipment room. For cables inside the equipment room, install surge protection devices at the interface to the equipment. The PGND cable for the surge protection devices should be as short as possible.
2	The incoming and outgoing signal cables to and from the office and unused wires inside the cable should be grounded for protection.
3	The Tone & Data Access (TDA) cable must pass through the Main Distribution Frame (MDF) with surge protective device (SPD) when going out of the office. The cable's shield layer should be connected to the protective ground of the MDF. The MDF should use the same grounding conductor as the cabinet.
4	Do not route signal cables overhead.

### 5.3.6 Specifications for Laying Out Grounding Cables

**Table 5-20** shows the specifications for the ground cable.

**Table 5-20** Specifications for laying out ground cables

No.	Description
1	The grounding wire should not run parallel to or twist around the signal cable.

No.	Description
2	Bury ground underground or arrange them indoors. Do not route ground cables overhead.
3	Do not connect two cables together to extend the PGND cable, or add any switches or fuses.
4	The PGND cable should be an alternating yellow and green plastic insulated one with a copper core.
5	The neutral line of the AC power cable cannot be connected to the protective ground of transmission and communication equipment in the equipment room.
6	A PGND cable should be as short as possible, with a length of no more than 45 m (147.64 ft).

## 5.4 Engineering Labels for Cables

An engineering label serves as an identifier for on-site installation and maintenance after the installation. Labels on the cables facilitate correct and orderly connection of cables, and easy maintenance after installation.

Engineering labels are specialized for power cables and signal cables:

- Signal cables include network cables, optical fibers, and user cables.
- Power cables include the AC power cables and DC power cables.

### NOTE

Fill in labels according to specified requirements to keep consistency of labels in the equipment room. Make a relevant statement in the self-check report.

### 5.4.1 Introduction to Labels

#### Label Materials

Features:


- Thickness: 0.09 mm (0.004 in.)
- Color: chalk white
- Material: polyester (PET)
- Ambient temperature: -29°C (-20.2°F) to +149°C (300.2°F)
- Printed by a laser printer and written with a marker
- Pass UL and CSA authentication

## Type and Structure

### Label for Signal Cables

The label for signal cables is L-shaped with fixed dimensions, as shown in [Figure 5-81](#).

**Figure 5-81** Label for signal cables



To specify more clearly the position of a cable, use the dividing lines on the label. For example, there is a dividing line between the cabinet number and the chassis number, and another one between the chassis number and the slot number. Each dividing line is light blue (Pantone 656c) and 1.5 mm x 0.6 mm (0.06 in. x 0.02 in.).


The cut dotted line helps to fold the label when affixed to the cable, and its size is 1 mm x 2 mm (0.04 in. x 0.08 in.).

The word "TO:" (upside down in the figure) at the lower right corner of the label is used to identify the opposite end of the cable on which the label is affixed.

### Power Cable Label

The label for power cables should be attached to the identification plate on the cable ties that are attached to the cable. The identification plate has an embossed area 0.2 mm x 0.6 mm (0.008 in. x 0.02 in.) around (symmetric on both sides), and the area in the middle is for affixing the label, as shown in [Figure 5-82](#).

Figure 5-82 Power cable label



## Label Printing

The contents can be printed or written on the labels. Printing is recommended for the sake of high efficiency and eye-pleasant layout.

## Template for Printing

You can obtain a template from the Huawei local office to print labels.

The template is made in Microsoft Word. Follow these instructions to use the template:

- You can modify the contents of the template. Do not change settings of centered characters, direction, and fonts.
- If many characters need to be filled in, decrease the font size, but make sure that the printouts are clear and legible.

## Merging Cells in the Template

To merge two or more cells, do as follows:

1. Select **Edit/Select All**.
2. Select **Format/Borders and Shading/Borders**. Select **Box** tab and click **OK**.
3. Drag the mouse to select cells to be merged and select the **Table/Merge Cells**.

## Requirements on the Printer

To print labels, use a laser jet printer of any model. Before printing labels, set up the page and try printing.

1. Try printing on ordinary paper with both sides blank. Place the blank paper over the whole page of the label paper, and check whether the page setup conforms to the label layout.
2. Make sure the printer properties, such as "paper size" and "direction", have been set correctly.
  - If the printout conforms to the sheet of labels, print the labels on the label paper.
  - If the printout does not conform, adjust the page setup and try printing again until the correct printout is produced.


The method for adjusting the page setup is as follows.

1. Select **File/Page Setup**.
2. Select **Layout** and set Header and Footer as 0.
3. Select the **Margins** tab page. Select Left for Gutter Position and adjust the values of Top, Bottom, Left, and Right.

### NOTE

If the warning prompt as shown in [Figure 5-83](#) appears before printing, click **Ignore** to continue the printing.

**Figure 5-83** Warning prompt before printing



After the page setup has been made correctly, save it for future use. This page setup is only necessary the first time you use the template to print the labels.



## Requirements for Feeding the Printer

The label paper consists of two layers and has undergone multiple processing procedures such as printing and cutting. No matter what model of printer you use, feed in the labels one page at a time. To avoid jamming the labels, never use the auto-feed mode.

Feed in the label paper in the correct direction to ensure that the text is printed in a correct position.

## Requirements for the Printed Label

Make sure that the printed labels satisfy the following requirements:

- All the printouts must be on the label, and nothing should be printed on the backing layer of the label page.
- Contents in the cells should be aligned in the center. In a single-line printout, the dividing lines and the word "TO:" should not be covered by printed characters.
- When the cells are merged and the printouts are made in multiple lines, avoid covering the word "TO:" when printing the text. Use the space bar to move the text to the next line.

## Writing Labels

### Writing Tools

To make sure the printouts are clear and legible, use black markers instead of ball-point pens to write the labels.

If no marker is available, black ball-point pens are allowed, although not recommended. Compared with ball-point pens, water-proof markers are better. When writing with a ball-point pen, do not leave the oil on the label, which may contaminate the label and blur the words.

#### NOTE

The delivered marker has two nibs. Use the smaller nib to write the labels.

## Font

For the sake of legibility, use standard block letters and numbers as shown in [Table 5-21](#) (Times New Roman).


**Table 5-21** Standard typeface for handwriting

0	1	2	3	4	5	6	7	8
9	A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	P	Q
R	S	T	U	V	W	X	Y	Z

Determine the size of characters based on the number of letters or digits and ensure that the characters are distinct and tidy.

Placement of text on a label is shown in [Figure 5-84](#).

**Figure 5-84** Placement of text on a label



## Attaching Labels

After printing or writing the label, remove the label from the page and attach it to the signal cable, or the identification plate of the power cable. The methods for attaching labels are described in the following sections.


### Label for Signal Cables

- Choose the place to attach labels.

The label is attached 2 cm (0.79 in.) from the connector on a signal cable. In special cases (for example, to avoid cable bending or affecting other cables), other positions are allowed to attach the labels. The rectangular part with text is attached facing right or downward, as shown in [Figure 5-85](#). The details are as follows:

- The identification card is to the right of the cable in vertical cabling.
- The identification card should be downward when you lay out the cable horizontally.


**Figure 5-85** Text area of the label



- Procedure for attaching labels

[Figure 5-86](#) shows the methods and procedures for attaching labels.

**Figure 5-86** Label for signal cables




## Power Cable Label

Remove the label from the backing page, and attach it to the identification plate on the cable tie. The label should be attached to the rectangular flute on the identification plate, and attached to only one side of the identification plate. The cable ties are bundled at 2 cm (0.79 in.) from the connectors, and other positions are allowed in special circumstances.

Cable ties should be bound on both ends of a cable. After the bundling, the finished identification plate should be on top of the cable in horizontal cabling, or on the right side of the cable in vertical cabling, as shown in [Figure 5-87](#). The details are as follows:

- The identification card is to the right of the cable in vertical cabling.
- The identification card is on the top of the cable in horizontal cabling. Make sure that the label is facing out.

**Figure 5-87** Binding the label for the power cable



## Contents of Engineering Labels

### Contents of Labels for Power Cables


Labels for power cables are affixed on only one side of the identification plates. On the labels, there is information (the part after the word "TO:") about the location of the device on the other end of the cable, like the location of control cabinet, distribution box or power socket.

### Contents of Labels for Signal Cables

The two sides of the label affixed on the signal cable carry information about the location of the ports connected to both ends of the cable. **Figure 5-88** shows the information on both sides of the labels affixed to the signal cables.

- Area 1 contains the location information of the local end of the cable.
- Area 2 (with the word "TO:") contains the location information of the opposite end of the cable.
- Area 3 has been folded up inside the label.

**Figure 5-88** Printed parts on the label for signal cables



Seen from the cabling end of the equipment, the text part of the label is on the right side of the cable. The side with "TO:" that is facing outside carries the location information of the opposite end; and the other side carries the location information of the local end.

In other words, the information in Area 1 at one end is the same as the information in Area 2 at the other end of the cable.

## Precautions for Using Engineering Labels

When using labels, pay attention to the following points:

- When printing, writing, or attaching labels, keep the labels clean.
- Since the label paper is made of moistureproof material, ink-jet printers and ink pens cannot be used to print and write labels.
- Labels should be attached neatly. New-type labels are L-shaped. If they are pasted at incorrect locations or in the incorrect direction, the appearance of the device is affected.
- Power cable ties should be attached in the same positions on power cables, with identification plates on the same side.
- The positions of "up", "down", "left" or "right" are all based on the viewpoint of the engineering person who is working on the label.

### 5.4.2 Engineering Labels for Optical Fibers

These labels are affixed to the optical fibers that connect the optical interfaces on the boards in a chassis, or on the device boxes. There are two types of labels for optical cables:

- One is for the fiber that connects the optical interfaces on two devices.
- The other is for the fiber that connects the device and the ODF.

## Labels for the Optical Fibers Connecting Devices

### Meaning of the Label

**Table 5-22** lists information on both sides of the labels affixed to the optical fibers that connect two devices.

**Table 5-22** Information on labels affixed to the fibers between two devices


Content	Meaning	Example
MN-B-C-D-R/T	MN: cabinet number	M: The cabinet rows from front to back are numbered from A to Z. N: The cabinet columns from left to right are numbered from 01 to 99. For example, A01 is the cabinet in row A and column 01.
	B: chassis number	Numbered in bottom-up order with two digits, for example, 01.
	C: physical slot number	Numbered in top-down and left-right order starting from 01. For example, 01 is the first slot at the top left of the chassis.

Content	Meaning	Example
	D: optical interface number.	Numbered in top-down and left-right order, consistent with the port sequence number on the device.
	R: Receiving interface T: optical transmitting interface	-

## Example of the Label

Figure 5-89 shows a sample label on an optical fiber.

Figure 5-89 Sample label on an optical fiber between two devices



The meaning of the label is listed in Figure 5-89.

- "A01-01-05-01-R" indicates that the local end of the optical fiber is connected to the optical receiving interface 01 in slot 5, chassis 01 in the cabinet in row A, column 01 in the machine room.
- "G01-01-01-01-T" indicates that the opposite end of the optical fiber is connected with optical transmitting interface 01 in slot 01, chassis 01 in the cabinet in row G, column 01 in the machine room.

## Labels for the Optical Fibers Connecting the Device and an ODF

### Meaning of the Labels

Table 5-23 shows information on both sides of labels attached to an optical fiber between a device and an optical distribution frame (ODF).

Table 5-23 Information on labels affixed to a fiber between a device and an ODF


Content	Meaning	Example
MN-B-C-D-R/T	MN: cabinet number	For example, A01.

Content	Meaning	Example
	B: chassis number	Numbered in bottom-up order with two digits, for example, 01.
	C: physical slot number	Numbered in top-down and left-right order starting from 01. For example, 01 is the first slot at the top left of the chassis.
	D: optical interface number.	Numbered in top-down and left-right order, consistent with the port sequence number on the device.
	R: Optical receiving interface T: optical transmitting interface	-
ODF-MN-B-C-R/T	MN: row number and column number of an ODF	M: The cabinet rows from front to back are numbered from A to Z. N: The cabinet columns from left to right are numbered from 01 to 99. For example, G01 is the ODF of row G and column 01.
	B: row number of the terminal device	Range from 01 to 99, for example, 01-01.
	C: column number of the terminal device	
	R: Optical receiving interface T: optical transmitting interface	-

## Example of the Label

Figure 5-90 shows a sample label on an optical fiber.

Figure 5-90 Sample label on an optical fiber between the device and the ODF



Meaning of the label in [Figure 5-90](#)

- "ODF-G01-01-01-R" indicates that the local end of the optical fiber is connected to the optical receiving terminal in row 01, column 01 of the ODF in row G, column 01 in the machine room.
- "A01-01-05-01-R" indicates that the opposite end of the optical fiber is connected to optical receiving interface 1 in slot 05, chassis 01 in the cabinet in row A, column 01 in the machine room.

## 5.4.3 Engineering Labels for Network Cables

### Applicable Ranges

The labels can be applied to Ethernet cables.

### Label Content

[Table 5-24](#) shows the information on both sides of the labels affixed to Ethernet cables.

You can also decide the label content based on the actual environment. If the device is not installed in the cabinet, for example, you can remove the cabinet number.

**Table 5-24** Information on the Ethernet cables

Content	Meaning	Example
MN-B-C-D	MN: cabinet number	For example, A01 is the first cabinet in row A.
	B: chassis number	Numbered in bottom-up order with two digits, for example, 01.
	C: physical slot number	Numbered with two digits in top-down and left-right order. For example, 01.
	D: network port number	Numbered in top-down and left-right orders. For example, 01.
MN-Z	MN: cabinet number	For example, B02 is the second cabinet in row B.
	Z: Location number	Fill in the location number of the terminal device on site. If the cable is connected to a device in a cabinet, specify the serial numbers of the cabinet, the chassis, and the Ethernet interface of the device. For example, B02-03-12. If the cable is connected to the Network Management Station (NMS), specify the specific location of the NMS.



The contents of the labels for network cables connecting hubs and devices or agents and the network cables for other purposes should be specified according to actual connections. The details are as follows:


- For a network cable connecting a hub and device, the label on the hub end should indicate the numbers of the chassis and cabinet where the hub resides, and the serial number on the hub. The label on the device end should indicate the number of the chassis and cabinet where the device is located. If the device is a standalone device, provide the specific position of the device.
- For a network cable connecting a hub and an agent or terminal, the label on the agent or terminal end should contain the serial number of the network interface. The definitions of the cabinet number and chassis number are the same as those described in [Table 5-24](#).
- If the hub is a standalone device without a cabinet or chassis, the label should contain specific location information that identifies the hub.

The serial number on the hub, the network interface number of the agent or terminal, and the location of the standalone device should be specified according to actual connections.

## Label Example

[Figure 5-91](#) shows a sample label on an Ethernet cable.

**Figure 5-91** Sample label on an Ethernet cable



Meaning of the label in [Figure 5-91](#).

- "A01-03-01-01" indicates that one end of the network cable is connected to network interface 01 in slot 01, chassis 03 of the cabinet in row A, column 01 in the equipment room.
- "B02-03-01" indicates that another end of the network cable is connected to network interface 01 in chassis 03 of the cabinet on row B, column 02 in the equipment room. No slot number is given.

## 5.4.4 Engineering Labels for User Cables

Attach labels to both ends of a user cable to indicate the locations of the cable on the device and main distribution frame (MDF).

### Meaning of the Engineering Labels for User Cables

[Table 5-25](#) shows the contents of the labels.


**Table 5-25** Contents of the engineering labels for user cables

Content	Meaning	Example
MN-B-C-D	MN: cabinet number	For example, A01 is the first cabinet in row A.
	B: frame number	Numbered in the bottom-up order with two digits, for example, 03.
	C: physical slot number	Numbered with two digits in top-down and left-right order. For example, 01.
	D: cable number	Numbered with two digits in top-down and left-right order. For example, 01.
MDF-MN-B-C	MN: row number and column number of the MDF	M: The rows of cabinets from front to back are numbered from A to Z. N: The columns of cabinets from left to right are numbered from 01 to 99. For example, G01 is the MDF of Row G and Column 01.
	B: row number of the terminal device	Ranges from 01 to 99, for example, 01-01.
	C: column number of the terminal device	

## Example of the Label

**Figure 5-92** shows a sample label on a user cable.

**Figure 5-92** Sample label on a user cable



The meaning of the label in **Figure 5-92** is as follows:

- "A01-03-01-01" indicates that the local end of the user cable is connected to port 1 in slot 1, chassis 03 of the cabinet in row A, column 01 in the equipment room.
- "MDF-G01-01-01" indicates that the opposite end of the user cable is connected to the terminal in row 01, column 01 of the MDF in row G, column 01 in the equipment room.

## 5.4.5 Engineering Labels for Power Cables

## Engineering Labels for DC Power Cables

These labels are affixed to the DC power cables that provide power supply for cabinets, including the -48 V, PGND, and BGND cables. Here, the DC power cables also include power cables and PGND cables.

The labels for DC power cables are affixed to one side of the identification plates on cable ties. For details of the labels, see [Table 5-26](#).


**Table 5-26** Contents of the label

Content	Meaning
MN(BC)- B--48Vn	MN(BC): BC is written right under MN. B: chassis number, numbered in bottom-up order with two digits, for example, 01.
MN(BC)-B- BGND	N: power socket number, numbered as 1 to 3 in the bottom-up and left-to-right orders.
MN(BC)-B- PGND	On the loaded cabinet side, only MN is used to identify the cabinet. On the power cabinet side, MN identifies the row and column number of the power distribution equipment like a control cabinet and distribution box, and BC identifies the row and column number of the -48 V connector. If there is no row number or column number, or the connector can be identified without them, BC can be omitted. It is unnecessary to identify the row and column number for BGND and PGND.

The label only carries location information about the destination direction of the power cable whereas information about the local end is unnecessary. That is, the label only carries location information about the opposite equipment, the control cabinet, or the distribution box. [Table 5-26](#) lists the information on two -48 V power supplies on the label. The information on other DC voltages, such as 24 V and 60 V should be given in similar methods.

Make sure that labels are affixed in the correct direction. That is, after the cable ties are bundled onto the cable, the identification plates with the labels should face up, and the text on the labels in the same cabinet should be in the same direction. For details, see [Figure 5-93](#).

**Figure 5-93** Example of the labels for DC power cables



The meaning of the label in [Figure 5-93](#) is as follows:

- On the loaded cabinet side, the label "A01/B08--48V2" on the cable indicates that the cable is -48 V DC supply, which is from the eighth connector in row B of -48 V bus bar in the cabinet in row A, and column 1 in the equipment room.
- On the distribution box side, the label "B03--48V2" indicates that the cable is -48 V DC supply, connected to DC power socket 2 in row B, column 03 in the equipment room.

 **NOTE**

In the power distribution box or the first power cabinet of a row in a transmission equipment room, every terminal block on the -48 V connector bar has a numeric identification. For example, in the above label of "A01/B08--48V2", "08" (or sometimes "8") is the numeric identification of the terminal block.

PGND and BGND are two copper bars, on which the terminal blocks are short-circuited. Therefore, it makes no difference which terminal is connected to them. It is only necessary to give the row and column of the power distribution box, instead of giving the specific serial number of the terminal block on the copper bar. For example, if the label on the loaded cabinet side is "A01-BGND", it means that the power cable is a BGND that connects BGND copper bar in the power distribution box in row A, column 01 in the machine room. Information on the labels for PGND cables should be given in a similar way.

## Engineering Labels for AC Power Cables

These labels are affixed to both ends of an AC power cable that provides AC power supply to cabinets, including 110/220 V, PGND, and BGND cables. The 110/220 V AC cables and related PGND and BGND cables are covered with an insulating sheath, so the labels need to contain only the word "AC" and the cabinet numbers.

The labels for AC power cables are affixed to one side of the identification plates on cable ties. For details, see [Table 5-27](#).


**Table 5-27** Label content

Content	Meaning
MN-(B)-ACn	<p>MN: serial number of the cabinet or the socket where the power is led in</p> <p>B: chassis number, numbered in bottom-up order with two digits, for example, 01.</p> <p>n: power port number, numbered as 1 to 3 in bottom-up and left-to-right order.</p> <p>Serial number of the socket where the power is led in: the location of the socket is marked according to the actual situation. If the sockets can be identified by row numbers and column numbers, they can be numbered following the same rule for the cabinets. If the sockets cannot be identified by rows and columns, specify the detailed locations to avoid confusion with other sockets.</p>

The label only carries location information about the opposite equipment and the power socket; information about the local end is unnecessary.

Make sure that labels are affixed in the correct direction. That is, after the cable ties are bundled onto the cable, the identification plates with the labels should face up, and the text on the labels in the same cabinet should be in the same direction, as shown in [Figure 5-94](#).

**Figure 5-94** Labels for AC power cables



Meaning of the label in [Figure 5-94](#).

- On the equipment cabinet side, the label marked "A01-AC1" indicates that the power cable is connected to the first AC power socket of row A and column 01 in the equipment room.
- On the power socket side, the label marked "B01-AC1" indicates that the power cable is connected to the first AC power socket in the cabinet of row B and column 01 in the equipment room.

## 5.5 Guide to Using Optical Modules

### Common Faults of an Optical Module


1. An optical module is not completely installed in position.  
If the optical module is not completely installed in position and the latch boss is not secured, the device cannot identify the optical module. After the optical module works for a long time, it will be ejected under external stress.
2. The optical receptacle on an optical module is contaminated.  
If an optical module is not cleaned or protected properly, contaminants may accumulate on the fiber pin in the optical module. As a result, the coupling efficiency is reduced, optical signals are cut off, or even worse, the surface of the fiber pin is damaged permanently.
3. An optical module is burnt.  
If high-power optical signals (caused by an optical time domain reflectometer or self-loop test) are transmitted through an optical module that is used for long-distance transmission but no optical attenuator is used, the optical power will exceed the overload power of the avalanche photodiode (APD). Then the optical module is burnt.

The preceding faults lead to temporary or long-term cut-off of optical signals; or even cause permanent damages to the optical module, affecting communication services.

## Measures to Prevent a Loosened Optical Module

1. When installing an optical module, insert it in position. If you hear a click or feel a slight shake, it indicates that the latch boss is secured.  
If the latch boss is not secured, the gold finger of the optical module is not in good contact with the connector on the board. In this case, the link may be connected but optical signals will be cut off or the optical module will be loosened when the optical module is shaken or hit.
2. **Figure 5-95** shows the release handle on an optical module when it is open and closed. When inserting the optical module, make sure that the release handle is closed. At this time, the latch boss locks the optical module. After the optical module is inserted, try pulling it out to see if it is installed in position. If the optical module cannot be pulled out, it is secured.

**Figure 5-95** State of the release handle



## Measures to Prevent Receptacle Contamination

1. Cleaning tissues must be prepared on site. You need to clean the optical connector before inserting it in the receptacle. This protects the receptacle against contamination on the surface of the optical connector.


**Figure 5-96** Cleaning optical fibers with special cleaning tissues



### NOTE

- Place at least three cleaning tissues on the work bench. As shown in **Figure 5-96**, wipe the end of an optical connector from left to right or from right to left on a cleaning tissue, and then move the connector end to the unused part of the cleaning tissue to continue.
2. Cover an unused optical module with a protective cap to prevent dust, as shown in **Figure 5-97**.

**Figure 5-97** Installing a protective cap




If no protective cap is available, use fibers to protect the optical module, as shown in [Figure 5-98](#).

**Figure 5-98** Using fibers to protect an optical module



3. Cover unused optical connectors with protective caps, as shown in [Figure 5-99](#), and then lay out fibers on the fiber rack or coil them in a fiber management tray to prevent fibers from being squeezed.


**Figure 5-99** Installing a protective cap on a fiber



4. If a receptacle or an optical connector has not been used for a long time and is not covered with a protective cap, you need to clean it before using it. Clean a receptacle with a cotton swab, as shown in [Figure 5-100](#). Clean an optical connector with cleaning tissues.



**Figure 5-100** Cleaning a receptacle with a cotton swab



---

 **NOTICE**

When cleaning a receptacle, insert the cotton swab and turn it slowly in the receptacle. Do not use too much strength because the receptacle may be damaged.

---

5. If optical signals are lost during the operation of a device, use the preceding method to clean the receptacle or the optical connector. In this manner, the possibility of contamination can be excluded.

## Measures to Prevent an Optical Module from Being Burnt

1. Before using an optical time-domain reflectometer (OTDR) to test the connectivity or the attenuation of optical signals, disconnect the optical fibers from the optical module. Otherwise, the optical module will be burnt.
2. When performing a self-loop test, use an optical attenuator. Do not loosen the optical connector instead of the optical attenuator.

## Precautions

1. The optical connector should be vertically inserted in the receptacle to avoid damages to the receptacle.
2. Fibers must be inserted into optical modules of the corresponding type. That is, multimode fibers must be inserted into multimode optical modules, and single mode fibers must be inserted into single mode optical modules. If a fiber is inserted into an optical module of a different mode, faults may occur. For example, optical signals will be lost.

## 5.6 Fault Tag

*Customer name:	
Address:	
Contact person:	
Tel.:	Fax:
Category*: <input type="checkbox"/> RMA <input type="checkbox"/> Return <input type="checkbox"/> Analysis	



BOM Code	Product Description	Bar Code*	Fault Occurring Date*	Description of the Fault Phenomena*	Category No.*	Software Version*
Reasons for Repairing (Category No.):						
Category No. includes the following eight types: F001 - Wear out damaged (◇ In warranty Period ◇ Out of warranty period) F002 - Deployment damaged F003 - Intransit damaged F004 - Version upgrade F005 - Batch replace F007 - Overdue spare parts inspecting F008 - Others F011 - Running circumstance change						
Note: <ul style="list-style-type: none"> <li>● For optical interface cards returned, the optical interfaces should be covered with protection caps.</li> <li>● In general, the analysis card will not be returned to you. If you have any special requirements, please contact Huawei.</li> <li>● One <b>Fault Tag</b> should be adapted in one return category, such as RMA/Return/Analysis.</li> <li>● The items marked with "*" are the mandatory fields that you must fill in.</li> </ul>						