



# **HUAWEI H215G**

---

**UMTS Mobile Phone**

**USER GUIDE**









# Contents








<b>1 Safety Precautions</b> .....	<b>1</b>
<b>2 Getting Started</b> .....	<b>2</b>
Installing the SIM Card, microSD Card and the Battery.....	3
Charging the Battery .....	3
Your Phone .....	4
Keys and Functions .....	5
Screen Icons.....	7
<b>3 Call Functions</b> .....	<b>9</b>
Making a Call.....	9
Answering a Call .....	10
Speed Dialing.....	10
<b>4 Text Input</b> .....	<b>10</b>
Changing the Text Input Mode .....	10
Entering English and Spanish .....	11
Entering a Number or a Symbol.....	11
<b>5 Contacts</b> .....	<b>11</b>
Creating a Contact .....	11
Searching for a Contact.....	12
Adding Favorites .....	12
Adding a Group .....	12
Assigning Speed Dialing to a Contact.....	12
<b>6 Messaging</b> .....	<b>12</b>
<b>7 Media Applications</b> .....	<b>13</b>
Taking a Picture.....	13
Music Player.....	13
Managing Multimedia Files.....	14
<b>8 Browser</b> .....	<b>14</b>
<b>9 Bluetooth</b> .....	<b>15</b>
<b>10 Security</b> .....	<b>15</b>
Keypad Lock .....	15

Phone Lock .....	16
Master Clear .....	16
Master Reset.....	16
PIN and PUK .....	17
<b>11 TTY Operation .....</b>	<b>17</b>
Configuring the TTY Settings .....	17
Using a TTY.....	18
<b>12 Troubleshooting .....</b>	<b>18</b>
<b>13 Safety information.....</b>	<b>20</b>
<b>14 Legal Notice .....</b>	<b>31</b>
<b>15 For More Help .....</b>	<b>33</b>

# 1 Safety Precautions

Please read the safety precautions carefully to ensure the correct use of your mobile phone.

	Do not crash, throw, or puncture your mobile phone. Avoid the falling, squeezing, and bending of your mobile phone.
	Do not use your mobile phone in a moist environment, such as the bathroom. Prevent your mobile phone from being soaked or washed in liquid.
	Do not switch on your mobile phone when it is prohibited to use phones or when the phone may cause interference or danger.
	Do not use your mobile phone while driving.
	Follow any rules or regulations in hospitals and health care facilities. Switch off your mobile phone near medical apparatus.
	Switch off your mobile phone in aircraft. The phone may cause interference to control equipment of the aircraft.
	Switch off your mobile phone near high-precision electronic devices. The phone may affect the performance of these devices.
	Do not attempt to disassemble your mobile phone or its accessories. Only qualified personnel are allowed to service or repair the phone.

	Do not place your mobile phone or its accessories in containers with a strong electromagnetic field.
	Do not place magnetic storage media near your mobile phone. Radiation from the phone may erase the information stored on them.
	Do not put your mobile phone in a high-temperature place or use it in a place with flammable gas such as a gas station.
	Keep your mobile phone and its accessories away from children. Do not allow children to use your mobile phone without guidance.
	Use only approved batteries and chargers to avoid the risk of explosions.
	Observe any laws or regulations on the use of wireless devices. Respect others' privacy and legal rights when using your wireless device.
	Strictly follow the relevant instructions of this manual while using the USB cable. Otherwise your mobile phone or PC may be damaged.


## 2 Getting Started




### Note

- All the pictures in this guide are provided for your reference only.
- Please read the section "Safety information" before using your phone for safety tips and precautions.


## Installing the SIM Card, microSD Card and the Battery



## Charging the Battery




### Note

- When the battery icon changes to  or the charging animation

becomes static, the battery is fully charged.

- If the battery charge is fully depleted, it may take several minutes for the phone to display the charging icon after the charger is plugged in.

## Your Phone



1 Headset jack

2 Earpiece

3 Screen


4 Speaker

5 Volume key







6 Data/Charger connector


7 Camera

## Keys and Functions
















### Note

In this guide, the navigation keys of the phone are indicated by , ,  and . The left soft key is indicated by , and the right soft key is indicated by .

No.	Press...	To...
1	SEND	<ul style="list-style-type: none"> <li>Dial a number or answer a call.</li> <li>Access <b>Recent Calls</b> in standby mode.</li> </ul>
2		Turn the speaker on or off (press and hold the key for about 3 seconds).






























No.	Press...	To...
3		Press the key and another key to enter the upper character on the other key in editing mode.
4		Switch between "abc/en" mode (lower case), "Abc/En" mode (capitalization of the first letter), and "ABC/EN" mode (upper case) in editing mode.
5		<ul style="list-style-type: none"> <li>• Lock the keypad in standby mode (press and hold the key for about 3 seconds).</li> <li>• Enter the number <b>0</b>.</li> </ul>
6		<ul style="list-style-type: none"> <li>• Switch between <b>Vibration</b> mode and the current profile mode in standby mode (press and hold the key for about 3 seconds).</li> <li>• Enter a space in editing mode.</li> </ul>
7		<ul style="list-style-type: none"> <li>• Access the camera in standby mode (press and hold the key for about 3 seconds).</li> <li>• Access the symbol list in editing mode.</li> </ul>
8		<ul style="list-style-type: none"> <li>• Switch between text input methods in editing mode.</li> <li>• Access the application assigned to the key in standby mode. To assign the application, select <b>Menu &gt; Settings &gt; Phone &gt; Smart Key</b>.</li> </ul>

No.	Press...	To...
9		Start a new line in editing mode.
10		Delete characters in editing mode or delete selected items in an application.
11		Go back to the previous screen.
12	<b>PWR END</b>	<ul style="list-style-type: none"> <li>• Power the phone on or off (press and hold the key for about 3 seconds).</li> <li>• End or reject a call.</li> <li>• Return to standby mode.</li> </ul>
13		Select the option displayed in the lower right corner of the screen.
14		Confirm a selection.
15		<ul style="list-style-type: none"> <li>• Access the functions assigned to the navigation keys in standby mode.</li> <li>• Scroll through a menu.</li> </ul>
16		Select the option displayed in the lower left corner of the screen.

## Screen Icons

Screen icons listed in the following table indicate the current status of your phone. They are provided for your reference only.

Icon	Indicates...
	Signal strength.
	Connected to 3G mobile network.
	3G in use.
	Connected to HSDPA mobile network.
	HSDPA in use.
	Connected to EDGE mobile network.
	EDGE in use.
	Connected to GSM mobile network.
	GSM in use.
	<b>Airplane Mode</b> activated.
	Call in progress.
	Missed call.
	Music player playing in the background.
	New text message received.
	New multimedia message received.

Icon	Indicates...
	A microSD card installed.
	Location on.
	Headset connected.
	Speaker on.
	Alarm clock enabled.
	Bluetooth on.
	<b>Ring</b> ing mode activated.
	<b>Ring</b> ing and <b>Vibration</b> mode activated.
	<b>Silence</b> mode activated.
	<b>Vibration</b> mode activated.
	Battery level.
	Battery charging.

## 3 Call Functions

### Making a Call

1. In standby mode, press the number keys to enter a phone number.



## Note

You can also make a call through your call logs and contacts.

2. Press **SEND** to dial the number.
3. Press **PWR END** to end the call or cancel the dialing.

### Answering a Call

When you receive an incoming call, press **SEND** to answer it or **PWR END** to reject it.

If the **Any Key** answer function is enabled, you can press any key except , **PWR END**,  and the volume key to answer a call.

To set this function, select **Menu > Settings > Call > Answer Mode > Any Key**.

If the **Headset Auto-Answer** function is enabled and a headset is connected to the phone, the phone will automatically answer incoming calls for a pre-defined period. To set this function, select **Menu > Settings > Call > Headset Auto-Answer**.


### Speed Dialing

If the speed dialing numbers are assigned to the number keys, you can press and hold a number key for about 3 seconds in standby mode to speed dial the phone number. Up to 8 speed dialing numbers can be assigned.

For more details, see the section "Contacts" to learn how to assign speed dialing numbers to the contact numbers.

## 4 Text Input

### Changing the Text Input Mode







The current text input mode indicator is displayed in the upper right corner of the text input screen. To switch between the text input modes, press .

You can select **Menu > Settings > Phone > Text Input Settings** to change the input language and enable or disable the predictive input mode.






## Entering English and Spanish

In multi-tap text input mode, press the key labeled with the desired letter to enter the letter on the key.

In predictive input mode:



1. Press each key according to the spelling sequence of the desired word. The phone displays candidate words that may be spelt by the keystroke sequence.
2. Press  or  to scroll to the desired word.
3. Press  or  to enter the desired word, or   to enter the word followed by a space.

## Entering a Number or a Symbol



- In number input mode, press the key labeled with the desired number or symbol to enter it.
- In any text input mode other than the number input mode, press  and then press the number or symbol key to enter the desired number or symbol.
- In any text input mode, press  to display the symbol list. Press  to scroll to the desired symbol. Then press  or  to enter the symbol.

# 5 Contacts




## Creating a Contact

1. Select **Menu > Contacts > Create Contact**.
2. Edit the contact information.
3. Press  or  to save the contact.




## Searching for a Contact

1. Select **Menu > Contacts**.
2. Enter the contact name, or the first several letters of a contact name.
3. Press  and  to scroll to the contact.



## Adding Favorites

1. Select **Menu > Contacts > VIPs > Add VIP**.
2. Press  and  to scroll to the contact.
3. Press  to add the contact into your list of favorites.


## Adding a Group

1. Select **Menu > Contacts > Groups > Add Group**.
2. Edit the group name.
3. Select **Members** and press  to mark the contacts to be included in the group.
4. Press  to save the members.
5. Press  to save the group.

## Assigning Speed Dialing to a Contact

1. Select **Menu > Contacts > Options > Manage Contacts > Speed Dialing**.
2. Select a number from **2 to 9** and press  to confirm.
3. Select a contact from the contact list or enter a number.
4. Press  to save the speed dialing number.

# 6 Messaging

1. Select **Menu > Messages > New Message**.
2. Add recipients by entering the phone numbers, or press  and then select the recipients from the contact list.
3. Edit the message.









## Note

You can select **Options > Insert Object** to add picture, audio or other attachments to the message, and the message will be converted to MMS (Multimedia Message Service) mode automatically.

4. Select **Options > Send** to send the message.






## 7 Media Applications

### Taking a Picture


1. Select **Menu > Multimedia > Camera** or press and hold  for about 3 seconds in standby mode.
2. Press  to configure the camera settings.
  - Press  and  to scroll to an item.
  - Press  to select the item.
  - Press  and  to change the settings.
3. Press  to take a picture.

### Music Player

#### Creating a Playlist






1. Select **Menu > Multimedia > Music Player > Options > Media Library**.
2. Press  (**Refresh**) to refresh the media library.
3. Press  or , and then  to select **Playlist**.
4. Select **Options > Create** to create a new playlist. If there is no playlist, press  (**Create**) to create a playlist.
5. Open the playlist and select **Add** to add songs to the playlist.

#### Playing Music

Select a music file and press  to play it.

While the music is playing:




- Press  to pause or continue playing.
- Press  to play the next song. Press and hold  for about 3 seconds to fast-forward the song.
- Press  to play the previous song. Press and hold  for about 3 seconds to rewind the song.
- Press the volume key to adjust the volume.
- Press **PWR** **END** to exit the music player screen and play music in the background.
- Select **Options** > **Exit** to exit the music player.

## Managing Multimedia Files

You can select **Menu** > **My Folder** to manage multimedia files stored on your phone and microSD card. You can view pictures, set a picture as wallpaper, play music, set an audio clip as ringtone, and send multimedia files via Bluetooth or message.

## 8 Browser

The **Browser** application allows you to access Internet websites and browse web pages.

1. Select **Menu** > **Browser** to open the home page.
2. Select **Options** > **Open New Page**.
3. Enter the Uniform Resource Locator (URL) and press  to access the new web page you desired.




### Note

You can select **Options** > **Settings** to customize the browser settings to suit your web browsing style and configure page content, private data, and security settings.

4. Select **Options** > **Exit Browser** to exit **Browser**.

## 9 Bluetooth

Your phone supports Bluetooth. You can transfer data between your phone and other Bluetooth devices and talk by using a Bluetooth headset.

1. Select **Menu > Settings > Connectivity > Bluetooth**.
2. Select **Bluetooth > On** to enable the Bluetooth function.
3. Select **Search for Devices** to search for available Bluetooth devices.
4. Select the Bluetooth device you want to connect from the list and press  to pair your phone with the desired device.



### Note

- When you pair your phone with the device for the first time, a password is required.
  - A Bluetooth headset is not included in the product package and must be purchased separately. Before using a Bluetooth headset, refer to the user manuals of the relevant devices.
5. When the Bluetooth devices are connected to your phone, you can exchange data between your phone and the other Bluetooth device.


## 10 Security

### Keypad Lock



### Note

When the keypad is locked, you can still press **SEND** to answer a call or make an emergency call.

To lock the keypad, press and hold  for about 3 seconds in standby mode.

To unlock the keypad, press , then .

If the **Auto Keypad Lock** function is enabled, the phone's keypad will automatically lock after being idle in standby mode for a pre-defined period. To set this function, select **Menu > Settings > Phone > Auto Keypad Lock**.

## Phone Lock

The phone lock protects your phone from unauthorized use.

By default, the phone lock is disabled. To enable or disable the phone lock, select **Menu > Settings > Security > Phone Lock**.

Once you enable the phone lock, you must enter the password. The default password to unlock your phone is **000000**, and it can be changed to any numeric string of four to eight digits in length. To change the password, select **Menu > Settings > Security > Change Phone Lock Code**.

## Master Clear

**Master Clear** will restore your phone to its default settings, but does not erase user data.

Select **Menu > Settings > Security > Master Clear**, then enter your phone lock code. The phone will clear all the settings you have configured.



### Note

You can see the section "Phone Lock" to find the default phone lock code, and how to change it. After you **Master Clear** your phone, the phone lock code will be restore to the default one.

## Master Reset

**Master Reset** will restore the phone to its factory settings and passwords, clear user data, and restart the phone. All of your personal data stored on the phone, including your system and

application settings, your call logs and messages stored on the phone, and any applications you have installed will be erased.

1. Select **Menu > Settings > Security > Master Reset**.
2. Read the warning and select **Yes**.
3. Enter your phone lock code. The phone will reset the settings, and then restarts.



#### Note

You can see the section "Phone Lock" to find the default phone lock code, and how to change it. After you reset your phone to its factory settings, the phone lock code will be restored to the default one.

## PIN and PUK

The personal identification number (PIN) protects your SIM card from unauthorized use. If you incorrectly enter the PIN a specified number of times consecutively, the PIN is blocked and your phone prompts you to enter the PIN unblocking key (PUK). If this occurs, enter the PUK to unblock the blocked PIN.

If you incorrectly enter the PUK a specified number of times consecutively, the SIM card will be permanently disabled, and you must contact your service provider for a new SIM card.

Both the PIN and PUK are provided with your SIM card. For details, contact your service provider.

## 11 TTY Operation

The Teletypewriter (TTY) is a typewriting device that is used to communicate over a phone network. By enabling the TTY function and connecting your phone to a TTY device, you can use the TTY device to send or receive messages.

### Configuring the TTY Settings

Select **Menu > Settings > Phone > TTY Settings** to configure

the following TTY settings:

- **TTY OFF:** Use standard voice speaking mode and listening mode.
- **TTY FULL:** Send and receive TTY characters.
- **TTY VCO:** Receive TTY characters but send by speaking into the microphone.
- **TTY HCO:** Send TTY characters but receive by listening to the earpiece.

## Using a TTY

To use the TTY function:

1. Set your phone to TTY mode and connect the TTY device into the headset jack of your phone.
2. Make or answer a call.
3. When the call is set up, use the TTY device to send or receive messages.
4. Press **PWR**  
**END** to end the call.

## 12 Troubleshooting

If you encounter any problem when using your phone, try to rectify the problem according to the following table. If the problem persists, contact the service provider or the dealer.

Problem	Ensure that...
The battery cannot be charged.	The charger is properly connected to your phone and the power socket.

Problem	Ensure that...
The phone cannot be powered on.	<ul style="list-style-type: none"> <li>• The battery power is sufficient.</li> <li>• The battery is properly installed.</li> <li>• Press and hold <b>PWR</b> <b>END</b> for about 3 seconds.</li> </ul>
You cannot make a call except an emergency call.	<ul style="list-style-type: none"> <li>• The phone number is correct.</li> <li>• You are in the network service area.</li> <li>• You have not enabled the call restriction function.</li> </ul>
Bad call quality.	<ul style="list-style-type: none"> <li>• The signal strength is strong enough.</li> <li>• If you are staying indoors, move close to a window.</li> </ul>
During a call, the other side cannot hear your voice.	<ul style="list-style-type: none"> <li>• The microphone is not covered.</li> <li>• If you use a wired headset, make sure connector is fully plugged in.</li> </ul>
The signal strength is not strong enough or your phone is often off line.	Move close to a place with strong signal strength.

Problem	Ensure that...
Your phone displays "No service found", "Service unavailable" or "Network problem".	<ul style="list-style-type: none"> <li>• You are in an area with very weak signal or outside your service provider's network coverage (in a tunnel or surrounded by buildings). If so, move to another area and try again.</li> <li>• Do not utilize the service option without obtaining authorization from your service provider.</li> </ul>
The phone cannot find other Bluetooth devices or fails to send or receive data via Bluetooth.	<ul style="list-style-type: none"> <li>• The Bluetooth function of both devices is turned on.</li> <li>• The distance between the two Bluetooth devices is less than 10 meters.</li> <li>• There are no obstacles between the two devices.</li> <li>• The other Bluetooth device is set to visible.</li> </ul>

## 13 Safety information

This section contains important information about the operation of your device. It also contains information about how to use the device safely. Read this information carefully before using your device.

### Electronic device

Do not use your device if using the device is prohibited. Do not use the device if doing so causes danger or interference with other electronic devices.

## **Interference with medical equipment**

- Follow rules and regulations set forth by hospitals and health care facilities. Do not use your device where prohibited.
- Some wireless devices may affect the performance of hearing aids or pacemakers. Consult your service provider for more information.
- Pacemaker manufacturers recommend that a minimum distance of 15 cm be maintained between a device and a pacemaker to prevent potential interference with the pacemaker. If using a pacemaker, hold the device on the side opposite the pacemaker and do not carry the device in your front pocket.

## **Protecting your hearing when using a headset**

- Using a headset at high volumes may damage your hearing. To reduce this risk, lower the headset volume to a safe and comfortable level.
- Exposure to high volumes while driving may cause distraction and increase your risk of an accident.

## **Areas with flammables and explosives**

- Do not use the device where flammables or explosives are stored (in a gas station, oil depot, or chemical plant, for example). Using your device in these environments increases the risk of explosion or fire. In addition, follow the instructions indicated in text or symbols.
- Do not store or transport the device in containers with flammable liquids, gases, or explosives.

## **Traffic security**

- Observe local laws and regulations while using the device. To reduce the risk of accidents, do not use your wireless device



while driving.

- Concentrate on driving. Your first responsibility is to drive safely.
- Do not hold the device while driving. Use hands-free accessories.
- When you must make or answer a call, pull off the road safely and park the vehicle first.
- RF signals may affect the electronic systems of motor vehicles. For more information, consult the vehicle manufacturer.
- Do not place the device over the air bag or in the air bag deployment area in a motor vehicle. Doing so may hurt you because of the strong force when the air bag inflates.
- Do not use your device while flying in an aircraft or immediately before boarding. Using wireless devices in an aircraft may disrupt wireless networks, present a hazard to aircraft operation, or be illegal.

## **Operating environment**

- Avoid dusty, damp, or dirty environments. Avoid magnetic fields. Using the device in these environments may result in circuit malfunctions.
- Do not use your device during thunderstorms to protect your device against any danger caused by lightning.
- Ideal operating temperatures are 0°C to 35°C. Ideal storage temperatures are -20°C to +70°C. Extreme heat or cold may damage your device or accessories.
- Do not expose your device to direct sunlight (such as on a car dashboard) for prolonged periods.
- To protect your device or accessories from fire or electrical shock hazards, avoid rain and moisture.
- Keep the device away from sources of heat and fire, such as a

heater, microwave oven, stove, water heater, radiator, or candle.

- Do not place sharp metal objects, such as pins, near the earpiece or speaker. The earpiece may attract these objects and result in injury.
- Stop using your device or applications for a while if the device is overheated. If skin is exposed to an overheated device for an extended period, low temperature burn symptoms, such as red spots and darker pigmentation, may occur.
- Do not use your device's camera flash directly in the eyes of people or pets. Otherwise temporary loss of vision or damage to the eyes may occur.
- Do not touch the device's antenna. Otherwise, communication quality may be reduced.
- Do not allow children or pets to bite or suck the device or accessories. Doing so may result in damage or explosion.
- Observe local laws and regulations, and respect the privacy and legal rights of others.

### **Child's safety**

- Comply with all precautions with regard to child's safety. Letting children play with the device or its accessories may be dangerous. The device includes detachable parts that may present a choking hazard. Keep away from children.
- The device and its accessories are not intended for use by children. Children should only use the device with adult supervision.

### **Accessories**

- Using an unapproved or incompatible power adapter, charger or battery may cause fire, explosion or other hazards.

- Choose only accessories approved for use with this model by the device manufacturer. The use of any other types of accessories may void the warranty, may violate local regulations and laws, and may be dangerous. Please contact your retailer for information about the availability of approved accessories in your area.

## **Charger safety**

- For pluggable devices, the socket-outlet shall be installed near the devices and shall be easily accessible.
- Unplug the charger from electrical outlets and the device when not in use.
- Do not drop or cause an impact to the charger.
- If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using it at once. Continued use may lead to electric shocks, short circuits, or fire.
- Do not touch the power cord with wet hands or pull the power cord to disconnect the charger.
- Do not touch the device or the charger with wet hands. Doing so may lead to short circuits, malfunctions, or electric shocks.
- If your charger has been exposed to water, other liquids, or excessive moisture, take it to an authorized service center for inspection.
- Ensure that the charger meets the requirements of Clause 2.5 in IEC60950-1/EN60950-1 and has been tested and approved according to national or local standards.
- Connect the device only to products with the USB-IF logo or with USB-IF compliance program completion.

## **Battery safety**

- Do not connect battery poles with conductors, such as keys,

jewelry, or other metal materials. Doing so may short-circuit the battery and cause injuries or burns.

- Keep the battery away from excessive heat and direct sunlight. Do not place it on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode if overheated.
- Do not attempt to modify or remanufacture the battery, insert foreign objects into it, or immerse or expose it to water or other liquids. Doing so may lead to fire, explosion, or other hazards.
- If the battery leaks, ensure that the electrolyte does not make direct contact with your skins or eyes. If the electrolyte touches your skins or splashes into your eyes, immediately flush with clean water and consult a doctor.
- In case of battery deformation, color change, or overheating while charging or storing, immediately stop using the device and remove the battery. Continued use may lead to battery leakage, fire, or explosion.
- Do not put batteries in fire as they may explode. Damaged batteries may also explode.
- Dispose of used batteries in accordance with local regulations. Improper battery use may lead to fire, explosion, or other hazards.
- Do not allow children or pets to bite or suck the battery. Doing so may result in damage or explosion.
- Do not smash or pierce the battery, or expose it to high external pressure. Doing so may lead to a short circuit or overheating.
- Do not drop the device or battery. If the device or battery is dropped, especially on a hard surface, and may be damaged.

- If the device standby time shortens significantly, replace the battery.
- Use the battery only with a charging system that is IEEE-Std-1725 standard qualified. The use of an unqualified battery or charger may lead to fire, explosion, leakage, or other hazards.
- Replace the battery only with an IEEE-Std-1725 standard qualified battery. The use of an unqualified battery may lead to fire, explosion, leakage, or other hazards.
- Do not disassemble or open, crush, bend or deform, puncture or shred the battery. Otherwise, it may lead to electrolyte leakage, overheating, fire, or explosion.
- Do not solder battery poles or dismantle the battery. Doing so may lead to electrolyte leakage, excessive heat, fire, or explosion.

## **Cleaning and maintenance**

- Keep the device and accessories dry. Do not attempt to dry it with an external heat source, such as a microwave oven or hair dryer.
- Do not expose your device or accessories to extreme heat or cold. These environments may interfere with proper function and may lead to fire or explosion.
- Avoid collision, which may lead to device malfunctions, overheating, fire, or explosion.
- Before you clean or maintain the device, stop using it, stop all applications, and disconnect all cables connected to it.
- Do not use any chemical detergent, powder, or other chemical agents (such as alcohol and benzene) to clean the device or accessories. These substances may cause damage to parts or present a fire hazard. Use a clean, soft, and dry cloth to clean

the device and accessories.

- Do not place magnetic stripe cards, such as credit cards and phone cards, near the device for extended periods of time. Otherwise the magnetic stripe cards may be damaged.
- Do not dismantle or remanufacture the device and its accessories. This voids the warranty and releases the manufacturer from liability for damage. In case of damage, contact an authorized service center for assistance or repair.
- If the device screen is broken in a collision, immediately stop using the device. Do not touch or attempt to remove the broken parts. Promptly contact an authorized service center.

## **Emergency calls**

The availability of emergency calls is subject to your cellular network quality, service provider policy, and local laws and regulations. Never rely solely on your device for critical communications like medical emergencies.

## **Environmental protection**

- The device and its accessories (if included), such as the power adapter, headset, and battery should not be disposed of with household garbage.
- Disposal of the device and its accessories is subject to local regulations. Support proper collection and recycling.

## **FCC Regulatory Compliance**

### **Body worn operation**

The device complies with RF specifications when used near your ear or at a distance of 1.5 cm from your body. Ensure that the device accessories, such as a device case and device holster, are not composed of metal components. Keep the device away from your body to meet the distance requirement.

## **Certification information (SAR)**

This device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).

The SAR limit adopted by the USA is 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported to the FCC for this device type complies with this limit.

The highest SAR value reported to the FCC for this device type when using at the ear is 1.332 W/kg, and when properly worn on the body is 1.179 W/kg.

## **FCC statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Any changes or modifications to this device not expressly approved by Huawei Technologies Co., Ltd. for compliance could void the user's authority to operate the equipment.

### **Hearing Aid Compatibility (HAC) regulations for mobile phones**

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants, digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other components.

Your phone is compliant with FCC HAC regulations (ANSI C63.19). While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise.

Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box. The ratings are not guarantees.



Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.) Hearing devices may also be measured.

Your phone meets the M3/T3 level rating. Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

To ensure that the Hearing Aid Compatibility rating for your device is maintained, secondary transmitters such as Bluetooth and/or

Wi-Fi components must be disabled during a call.

For more information about the FCC Hearing Aid Compatibility please go to <http://transition.fcc.gov/cgb/dro/hearing.html>.

## 14 Legal Notice

**Copyright © Huawei Technologies Co., Ltd. 2013.  
All rights reserved.**

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. and its affiliates ("Huawei").

The product described in this manual may include copyrighted software of Huawei and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders.

### Trademarks and Permissions



, **HUAWEI**, and



are trademarks or

registered trademarks of Huawei Technologies Co., Ltd.

The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by *Bluetooth SIG, Inc.* and any use of such marks by Huawei Technologies Co., Ltd. is under license.

Other trademarks, product, service and company names mentioned may be the property of their respective owners.

### Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by

local network operators or network service providers.

Thus, the descriptions herein may not exactly match the product or its accessories which you purchase.

Huawei reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

## **DISCLAIMER**

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF HUAWEI ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS MANUAL SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

## **Import and Export Regulations**

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary

governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

### **Privacy Policy**

To better understand how we protect your personal information, please see the privacy policy at

<http://consumer.huawei.com/en/privacy-policy/index.htm>.

## **15 For More Help**

Please visit [www.huaweidevice.com/worldwide/support/hotline](http://www.huaweidevice.com/worldwide/support/hotline) for recently updated hotline and email address in your country or region.