

Wonderful Communication, Mobile Life

Welcome to HUAWEI U3317 Mobile Phone from Huawei Technologies Co., Ltd.

HUAWEI U3317 Mobile Phone
User Guide

Notice

Copyright © 2008 Huawei Technologies Co., Ltd.

All Rights Reserved

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks



and HUAWEI are trademarks of Huawei Technologies Co., Ltd. All other trademarks mentioned in this manual are the properties of their respective holders.

Notice

The information in this manual is subject to change without notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements,

information, and recommendations in this manual do not constitute a warranty of any kind, expressed or implied.

Please read the safety precautions carefully to ensure the correct and safe use of your wireless device. For detailed information, refer to the section "Warnings and Precautions".

Huawei Technologies Co., Ltd.

Address:

Administration Building, Huawei Technologies Co., Ltd., Bantian, Longgang District, Shenzhen, P. R. China

Postal Code: 518129

Website: <http://www.huawei.com>

Safety Precautions

Please read the safety precautions carefully to ensure the correct and safe use of your wireless device. For detailed information, refer to the section "Warnings and Precautions".



Do not switch on your phone when it is prohibited to use mobile phones or when the phone may cause interference or danger.



Do not use your phone while driving.



Follow any rules or regulations in hospitals and health care facilities. Switch off your phone near medical apparatus.



Switch off your phone in aircraft. The phone may cause interference to control signals of the aircraft.



Switch off your phone near high-precision electronic devices. The phone may affect the performance of these devices.



Do not attempt to disassemble your phone or its accessories. Only qualified personnel are allowed to service or repair the phone.



Do not place your phone or its accessories in containers with strong electromagnetic field.



Do not place magnetic storage media near your phone. Radiation from the phone may erase the information stored on them.



Do not put your phone in a high-temperature place or use it in a place with flammable gas such as a gas station.



Keep your phone and its accessories away from children. Do not allow children to use your phone without guidance.



Use only approved batteries and chargers to avoid the risk of explosions.



Observe any laws or regulations on the use of wireless device. Respect others' privacy and legal rights when using your wireless device.



Strictly follow the relevant instructions on 60 of this manual while using the USB cable. Otherwise your phone or PC may be damaged.

Table of Contents

Table of Contents 1

Getting to Know Your Phone 1

Packing List	1
Your Phone	2

Getting Started 6

Loading the SIM Card	6
Unloading the SIM Card	7
Charging the Battery	7
Loading/Removing a Memory Card	8
Powering On/Off	9

Call Service 11

Making or Answering Calls	11
Operations During a Voice Call	12
Operations During a Video Call	13
Calls	14

Text Input 15

T9® Input Method	15
Traditional Input Method	16
"123" Numeric Input Method	16
Symbol Input Method	16
Input Different Languages	17

Contacts 18

Making Calls from the Contacts	18
Searching for a Contact	18
Viewing Contacts in Phone/SIM	18
Other Operations	18
Groups	19

Messaging 21

Messages	21
Email	24
Broadcast Inbox	26
Push Inbox	26
Templates	27
Common Phrases	27

TIM Music Store 28

Music player	28
Music Library	28
Playlists	29
Homepage	29
Top 10	29
Launching	29
Search by artist	29
Search by music	29

Organiser & Tools 30

Alarms	30
Calendar	30
STK	31
Task	32
Memo	32
Synchronise	32
Calculator	33
Unit converter	33
Currency converter	34
Voice recorder	34
World time	35

Stopwatch.....	35
Timer	35
Service dial number.....	35
My Files 36	
TIM WAP 37	
TIM WAP	37
Open new page.....	37
Bookmarks	37
Saved pages	37
History	38
Resume	38
Settings	38
Entertainment 39	
TIM Games.....	39
YouTube	39
Camera.....	39
TIM Studio	41
Connections 42	
Bluetooth®	42
USB	44
Settings 47	
Phone settings.....	47
Display settings	48
Message settings	48
Call settings.....	48
Video call	51
Contact settings.....	51

JavaTM settings.....	52
Connectivity	52
Network	52
Security	52

Warnings and Precautions 55

Electronic Device	55
Hospital	55
Storage Environment	56
Children Safety	56
Operating Environment.....	57
Cleaning and Maintenance	57
Environmental Protection.....	58
Emergency Calls.....	58
Battery.....	58
Charger	59
Using the USB Cable.....	60
Certification Information (SAR)	60

Acronyms and Abbreviations 64

Appendix 65

Index 1

1 Getting to Know Your Phone

Your HUAWEI U3317 phone can operate in virtually all countries, automatically switching between WCDMA and GSM networks. U3317 supports WCDMA850 MHz, 2100 MHz and GSM/GPRS/EDGE (GSM900M, DCS1800M, and PCS1900M) networks. This allows you to enjoy communication wherever you use your mobile phone.

Note

The services supported by your phone should be also supported by the network from where you use the phone. For details, please contact your local customer care centre.

- 5 One stereo headset
- 6 One USB data cable
- 7 One FM Transmitter (optional)

Packing List

Your phone package box contains the following:

- 1 One HUAWEI U3317 mobile phone
- 2 One travel charger
- 3 One Li-on battery
- 4 One User Guide


Your Phone



Front View and Back View



Side View






Home Screen



















◆ Icon bar

This area displays the phone status. The following table illustrates the icons that may appear on this bar.

Icon	Description
	The phone is in a call.
	Forwarding all incoming voice calls to line 1.
	Call line 2 is enabled currently.



■ Your Phone


Icon	Description
	Forwarding all incoming voice calls to line 2.
	You have new text messages.
	You have new multimedia messages.
	You have new PUSH messages.
	You have new emails.
	You have new voice mails.
	Indicates signal strength. The more horizontal bars that appear, the stronger the signal.
	The phone is currently in a GSM network.
	The phone is currently in a WCDMA network.
	You are using the roaming service.
	Alarm clock is enabled.

Icon	Description
	Bluetooth is enabled.
	The normal profile is activated.
	The headset is plugged in.
	Your PC connects to the Internet through your phone.
	Indicates power level of the battery.

Introduction to the Menu

Your phone provides an extensive range of functions. You can use these functions by navigating the following menus: Camera, TIM WAP, Contacts, TIM Music Store, Messaging, TIM Studio, TIM Games, YouTube, My Files, Organiser & Tools, Calls and Settings.

- 1** In standby mode, press  to display the main menu.
- 2** Press the scroll key to scroll through the menu, and then press  to select the desired item.

- 3** If the menu contains further submenus, repeat step 2.
- 4** Use the selected function according to the prompts on the screen.
- 5** Select **Back** to return to the previous menu.
Press  to return to the standby mode.

2 Getting Started

Loading the SIM Card

Load your SIM card before using your phone. To use the SIM card properly, please read the following instructions carefully.

Note

- Keep the SIM card out of the reach of children.
- The SIM card and its metal contacts can be easily damaged by scratching or bending. Ensure care when you carry, load or remove it.
- Always disconnect the charger from the phone before loading or removing the SIM card.

To load the SIM card, do as follows:

- 1** Position the card at the card slot entrance, making sure it is facing the same way as shown in the diagram below, with the notched corner at the down right. Then slide in as shown.



- 2** Fit the battery into the battery slot on back of the phone. Press the battery down until it clicks into place.



- 3** Slide the back cover to the phone.



Unloading the SIM Card

Only unload the SIM card and the battery after powering off your phone. Otherwise, your phone may be damaged.

To unload the SIM card:

- 1 Unload the back cover out of the phone.



- 2 Please unload the battery according to the following picture.



- 3 Press the SIM card with one finger and slide it out of the slot.



Charging the Battery

Before charging the battery, please read the following precautions carefully.

Note

- When you charge the battery for the first time, please charge it for a minimum of 12 hours.
- The battery discharges even while not being used. If you have not used it for a long time, please recharge it first.
- The charging time depends on the environmental temperature and the age of the battery.
- The battery can be recharged but eventually wears out. If the battery lasts for a shorter time period than usual after being

■ Loading/Removing a Memory Card

charged normally, replace it with a battery of the same type.

- Do not strike, throw or cause any kind of violent shock to the battery, otherwise liquid leakage, body damage, overheating, explosion or fire may occur.
- Charge the battery by using the charger supplied with your phone.

Charging with a Cable Charger

Before charging the battery with a cable charger, ensure that the battery has been properly loaded into your phone.

To charge the battery, do as follows:

- 1** * Insert the plug of the charger into the connector of the phone as shown in the following figure.
- 2** Plug in the connector of the charger to a power socket.



With the metallic connect downward

Note

- *The plug of the charger is in trapezium shape. Reversely inserting the plug may damage the mobile phone and charger. The connection methods of USB data cable and headset are the same as the charger.
- When the battery power level is very low, the phone makes alert sounds and displays a prompt. When the battery power level is too low, the phone will power off automatically.
- When the battery is being charged, the charging indicator blinks continuously. When the charging indicator stops blinking, it indicates that the battery is full.

Loading/Removing a Memory Card

Your phone supports a memory card (micro-SD) with a capacity up to 2 GB.

- 1** Insert the memory card into the slot, as shown in the following figure.




- 2** To remove a memory card, press the memory card gently. Now the memory card will pop up automatically. Then take it out as shown in the following figure.




Powering On/Off

Powering On

Ensure that the SIM card is in your phone and that the battery has been charged.

Press and hold  to power on your phone.

Powering Off

Press and hold  to power off your phone.

Access Codes

If you have set the phone password and the PIN is **ON**, you have to enter the corresponding access codes when you power on your phone. For setting and changing the access codes, please refer to "Settings/Security Setup" on page 52.

◆ Phone Password

The phone password is used to protect your phone from unauthorized use. The phone password is preset as 0000 for your phone.

◆ PIN

The personal identification number (PIN) code is used to protect your SIM card from unauthorized use. The PIN code is usually provided when you get the SIM card from your server provider. If you have not received a PIN code or if you have forgotten it, contact your local customer care centre.

■ Powering On/Off

◆ PIN2

Some SIM cards provide a PIN2 code. Some special functions such as the "Fixed Dialer Number" are not available until you enter the PIN2 code. At the same time, your SIM card should support these functions.

◆ PUK

To unlock a locked SIM card, you need to enter the PIN Unblocking Key (PUK) code. The PUK code is usually provided when you get the SIM card from server provider. If you have not received a PUK code or if you have forgotten it, contact your local customer care centre.

◆ PUK2


Some SIM cards provide a PUK2 code that is used to unlock a locked PIN2 code. The PUK2 code is usually provided when you get the SIM card from server provider. If you have not received a PUK2 code or if you have forgotten it, contact your local customer care centre.


3 Call Service

Making or Answering Calls

Making a Video Call

You can make a video call to other person whose phone also supports video calls.

- 1 Enter or edit a phone number in one of the following ways:
 - Enter a phone number through the keypad.
 - Select a number from the **Calls** screen.
 - Select a number from the **Contacts** screen.
- 2 Select **Options > Call > Video Call** to dial.
- 3 Press  to end the video call.

Note To delete a wrong number, press  once to delete the digit to the left of the cursor.

Making a Voice Call

- 1 Enter or edit a phone number in one of the following ways:
 - Enter a phone number through the keypad.

- Select a number from the **Calls** screen.
- Select a number from the **Contacts** screen.

2 Press  to dial.

3 Press  to end the call.

Making Voice Calls Using SDN





You can make a voice call through speed dialing. For instructions on assigning speed dialing numbers, refer to "Contacts/Other Operations" on page 18. To make a call by speed dialing number (SDN), press and hold the number key until the phone dials the corresponding phone number.

Answering or Rejecting Calls

You can set the answer mode to **Any key**, **Send key** or **Slide up**. For details, refer to "Settings/Call Settings/Answer Mode".

The following describes how to answer or reject a call in different answer modes:

Operations During a Voice Call

Operation	Description
Answer a call	<ul style="list-style-type: none">If the answer mode is Slide up, slide the phone.If the answer mode is Any key, press any key except .If the answer mode is Send key, press .If the headset is in use, press the control key on the headset.
Reject a call	Press  or select Options > Reject .
End a call	<ul style="list-style-type: none">If the headset is not in use, you can close the phone or press .If the headset is in use, press the control key of the headset.
Reply by message	To send a predefined message to the caller.

Note

When the phone is closed and there is no ongoing call, you can press and hold the camera key to mute the ringtone of an

incoming call. You can also press and hold the volume keys to reject the call.

You can also set the auto answer mode to **Immediate answer**, **Text message** or **Recorded voice**.

For details, refer to “Settings/Call settings/Auto Answer”.

Operations During a Voice Call

Icon Description



: A call is ongoing.



: The call is on hold.

Operations


During a voice call, you can select **Options** to perform the following operations.

- Hold active call/Resume**: To hold or resume the call during a call.
- End**: To end all calls, the active call, the current call or the on hold call.
- Handfree/Earpiece**: To switch between the Handfree and the Earpiece modes during a call.





- Start recording/Stop recording: to recording the voice of the other side during a voice call.
- Other Applications: To access the **Contacts** screen, the **Messaging** screen, the **Calls** screen or the **Calendar** screen.
- Answer/Reject: Your phone allows you to handle two calls simultaneously. During a call, if there is a new incoming call, select **Options** > **Answer** to answer it or select **Options** > **Reject** to reject it.
- Swap: To swap between calls during a 3-party call.
- Conference call/Private call: To switch to the conference call during a 3-party call or to talk with a party privately during a conference call.

Operations During a Video Call



Icon Description

Icon	Description
	Press the up or down scroll key to adjust the brightness.

Operations During a Video Call

Icon	Description
	Press the left or right scroll key to zoom in or zoom out.
	Press the volume keys to adjust the volume.
	Press  to switch between the loud-speaker mode and the earpiece mode.

Operations

During a video call, you can press  to hold the call and send a preset file to the other party. You can press  again to resume the call. Before you use the function, you can preset a file in **settings/video call/Send image**.

During a video call, you can select **Options** to perform the following operations.





- Camera : To allow or forbid the video from your side.
- Audio: To allow or forbid the audio from your side.
- Switch to outer/inner camera: To switch between the main lens and the assistant lens.

■ Calls

- Picture mode: To switch display.
 - Image quality: To set the image quality to fine quality or more smooth.
 - Play file: To play a media file.
 - Handsfree/Earpiece: Switch between the loud-speaker mode and the earpiece mode.
 - Record: To record a video clip. A recorded video clip is saved to the **My Files/Videos** directory.
 - Other Applications: To access the **Contacts** screen, the **Messaging** screen, the **Calls** screen or the **Calendar** screen.
- Call: To make a voice/video call or edit before call.
 - Display mode: You can select **Normal** to display all records or select **Simple** to ignore the duplicated records.
 - Delete: To delete the selected record.
 - Mark/Unmark: To mark/unmark a record or all records.
 - Calls status: To display the information on voice calls, video calls and data services. In the voice call, video call and data page, you can select **Reset** to clear all records.

Calls

The recently dialed calls, received calls and missed calls are saved automatically.

Select **Calls** in the main menu and then press the left/right scroll key to select **All calls** , **Missed** , **Received**  or **Dialed** . Then select **Options** for the following options.

- Send message: To send a message or MMS.
- Save number: To save the numbers of the selected record.