



HUAWEI ME909s Series LTE Module
V100R001

Application Guide

Issue	04
Date	2017-12-11

Copyright © Huawei Technologies Co., Ltd. 2017. All rights reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. and its affiliates ("Huawei").

The product described in this manual may include copyrighted software of Huawei and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders.

Trademarks and Permissions



HUAWEI, HUAWEI, and  are trademarks or registered trademarks of Huawei Technologies Co., Ltd.

LTE is a trade mark of ETSI.

Other trademarks, product, service and company names mentioned may be the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may be limited by local network operators or network service providers.

Thus, the descriptions herein may not exactly match the product or its accessories which you purchase.

Huawei reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

DISCLAIMER

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF HUAWEI ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS MANUAL SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.



About This Document

Revision History

Document Version	Date	Chapter	Description
01	2015-07-30		Creation
02	2015-11-30	5	Updated the chapter Internal Protocol Stack Application Scenarios-TCP/UDP.
		6	Updated the chapter Internal Protocol Stack Application Scenarios-FTP.
		7	Updated the chapter Internal Protocol Stack Application Scenarios-HTTP.
		8	Updated the chapter Internal Protocol Stack Application Scenarios-SMTP.
		9	Updated the chapter Internal Protocol Stack Application Scenarios-FTPS/HTTPS/SMTPS.
03	2016-11-25	10.2.1	Added the NOTE for SSL cipher suites
		11.2.1	Updated the Reference Process
		11.3.1	Updated the Reference Process
		23.1.1	Updated the Differential upgrade flow and Full upgrade flow
04	2017-12-11		Deleted privacy policy

Scope

ME909s-821
ME909s-821 Mini PCIe
ME909s-120
ME909s-120 Mini PCIe



Contents

1 Overview.....	15
1.1 Conventions and Definitions	15
1.1.1 Conventions	15
1.1.2 Definitions	16
1.2 Basic AT Command Processing Principles.....	16
1.2.1 Ports	16
1.2.2 AT Command Processing Mechanism.....	17
1.2.3 Recommended Timeout Mechanism for AT Commands Processed by a Host.....	19
2 Initialization Application Scenarios	21
2.1 Startup Indication ^SYSSTART	21
2.1.1 Reference Process	21
2.1.2 Troubleshooting	21
2.2 Querying Basic Information	22
2.2.1 Reference Process	22
2.2.2 Troubleshooting	22
2.3 Network Service Operations	22
2.3.1 Reference Process	22
2.3.2 Troubleshooting	23
3 Serial Port Configuration Application Scenarios	25
3.1 Overview	25
3.2 Baud Rate Configuration.....	25
3.2.1 Reference Process	25
3.2.2 Troubleshooting	26
3.3 Baud Rate Autonegotiation	26
3.3.1 Reference Process	26
3.3.2 Troubleshooting	27
3.4 DTR Hang Up Data Services	27
3.4.1 Reference Process	27
3.4.2 Troubleshooting	27
3.5 DCD Pin Control.....	28
3.5.1 Reference Process	28
3.5.2 Troubleshooting	28



3.6 Setting Hardware Flow Control	28
3.6.1 Reference Process	28
3.6.2 Troubleshooting	29
4 External Protocol Stack Application Scenarios	30
4.1 Prerequisites	30
4.1.1 Reference Process	30
4.1.2 Troubleshooting	31
4.2 Establishing Data Connections.....	31
4.2.1 Reference Process	31
4.2.2 Troubleshooting	32
4.3 Data Transmission.....	32
4.4 Switch Between Data Mode and Command Mode	34
4.4.1 Reference Process	34
4.4.2 Troubleshooting	34
4.5 Disconnecting Data Service Connections	35
4.5.1 Reference Process	35
5 Internal Protocol Stack Application Scenarios-TCP/UDP	36
5.1 Overview	36
5.2 Initializing Internet Services	36
5.2.1 Reference Process	36
5.2.2 Troubleshooting	37
5.3 Creating a Listen Server.....	37
5.3.1 Reference Process	37
5.3.2 Troubleshooting	38
5.4 Creating TCP/UDP Links.....	38
5.4.1 Reference Process	38
5.4.2 Troubleshooting	39
5.5 Sending Data	39
5.5.1 Reference Process	39
5.5.2 Troubleshooting	41
5.6 Closing TCP/UDP Links	41
5.6.1 Reference Process	41
5.6.2 Troubleshooting	42
5.7 Transparent Transmission Mode	42
5.7.1 Reference Process	42
5.7.2 Troubleshooting	44
5.8 Packet Statistics.....	45
5.8.1 Reference Process	45
5.9 TCP/UDP Link Change Indication.....	45
5.9.1 Reference Process	45
6 Internal Protocol Stack Application Scenarios-FTP	47



6.1 Creating an FTP Control Link	47
6.1.1 Reference Process	47
6.1.2 Troubleshooting	47
6.2 Configuring Data Transmission Mode	48
6.2.1 Reference Process	48
6.3 Configuring FTP Data Channel Mode.....	49
6.3.1 Reference Process	49
6.4 Getting FTP File Size	49
6.4.1 Reference Process	49
6.4.2 Troubleshooting	50
6.5 Downloading File Using "GET" Command in Transparent Mode.....	50
6.5.1 Reference Process	50
6.5.2 Troubleshooting	51
6.6 Downloading File Using "GET" Command in Command Mode.....	51
6.6.1 Reference Process	51
6.7 Download File Using "GET" Command in Buffer Mode	52
6.7.1 Reference Process	52
6.8 Uploading File Using "PUT" Command in Transparent Mode.....	53
6.8.1 Reference Process	53
6.9 Uploading File Using "PUT" Command in Command Mode and Buffer Mode.....	54
6.9.1 Reference Process	54
6.10 FTP Error Codes.....	55
7 Internal Protocol Stack Application Scenarios-HTTP	57
7.1 Creating an HTTP Server Link.....	57
7.1.1 Reference Process	57
7.1.2 Troubleshooting	57
7.2 Configuring Data Transmission Mode	58
7.2.1 Reference Process	58
7.3 Downloading File Using "GET" Command in Transparent Mode.....	58
7.3.1 Reference Process	58
7.3.2 Troubleshooting	59
7.4 Downloading File Using "GET" Command in Command Mode.....	59
7.4.1 Reference Process	59
7.5 Downloading File Using "GET" Command in Buffer Mode	60
7.5.1 Reference Process	60
7.6 Uploading File Using "POST" Command in Transparent Mode.....	61
7.6.1 Reference Process	61
7.7 Uploading File"POST" Command in Command Mode and Buffer Mode.....	61
7.7.1 Reference Process	61
7.7.2 Troubleshooting	63
7.8 HTTP Error Codes.....	64



8 Internal Protocol Stack Application Scenarios-SMTP.....	65
8.1 Creating an SMTP Server Link	65
8.1.1 Reference Process	65
8.1.2 Troubleshooting	65
8.2 Sending Mail Through "emsend" Without Attachment	66
8.2.1 Reference Process	66
8.3 Sending Mail Through "emsend" with Attachment Using 7 bit	66
8.3.1 Reference Process	66
8.4 Sending Mail Through "emsend" with Attachment Using base 64	68
8.4.1 Reference Process	68
8.4.2 Troubleshooting	69
8.5 SMTP Error Codes	69
9 Internal Protocol Stack Application Scenarios-FTPS/HTTPS/SMTPS.....	71
9.1 Creating a Secure Control Link.....	71
9.1.1 Preliminary Operations	71
9.1.2 IP Configuration.....	71
9.1.3 SSL and TLS	72
9.1.4 Certificates	72
9.2 Configuring SSL	72
9.2.1 Reference Process	72
10 SSL Application Scenarios	74
10.1 Initializing Secure Services	74
10.1.1 Reference Process	74
10.1.2 Troubleshooting	75
10.2 Configuring SSL	75
10.2.1 Reference Process	75
10.2.2 Troubleshooting	76
10.3 Managing Certificate/Key	76
10.3.1 Reference Process	76
10.3.2 Troubleshooting	77
10.4 Creating SSL Links	78
10.4.1 Reference Process	78
10.4.2 Troubleshooting	78
10.5 Querying SSL Status	79
10.5.1 Reference Process	79
10.5.2 Troubleshooting	79
10.6 Sending Data	79
10.6.1 Reference Process	79
10.6.2 Troubleshooting	80
10.7 Receiving Data	81
10.7.1 Reference Process	81



10.7.2 Troubleshooting	81
10.8 Closing SSL	82
10.8.1 Reference Process	82
10.8.2 Troubleshooting	82
11 ECM Application Scenarios	83
11.1 Dialing ECM	83
11.1.1 Reference Process	83
11.1.2 Troubleshooting	84
11.2 Querying the Dial-up Connection State.....	85
11.2.1 Reference Process	85
11.2.2 Troubleshooting	85
11.3 Disconnecting the Dial-up Connection.....	85
11.3.1 Reference Process	85
11.3.2 Troubleshooting	86
12 Voice and Supplementary Service Application Scenarios	87
12.1 Pre-configuration.....	87
12.1.1 Reference Process	87
12.2 Voice Call Handling	87
12.2.1 Reference Process	87
12.2.2 Troubleshooting	88
12.3 DTMF Application	89
12.3.1 Reference Process	89
12.3.2 Troubleshooting	89
12.4 ID Presentation.....	90
12.4.1 Reference Process	90
12.4.2 Troubleshooting	92
12.5 Call Forwarding	92
12.5.1 Reference Process	92
12.5.2 Troubleshooting	93
12.6 Call Waiting.....	94
12.6.1 Reference Process	94
12.6.2 Troubleshooting	95
12.7 Call Restriction.....	95
12.7.1 Reference Process	95
12.7.2 Troubleshooting	97
12.8 Debug the Audio Quality.....	98
12.8.1 Reference Process	98
12.8.2 Troubleshooting	99
13 Text Message Application Scenarios.....	100
13.1 Pre-configuration.....	100
13.1.1 Reference Process	100



13.1.2 Troubleshooting	100
13.2 Sending English Text Messages in PDU Format.....	101
13.2.1 Reference Process	101
13.2.2 Troubleshooting	102
13.3 Sending Chinese Character Text Messages in Text Format.....	102
13.3.1 Reference Process	102
13.3.2 Troubleshooting	103
13.4 Receiving Text Messages	103
13.4.1 Reference Process	103
13.4.2 Troubleshooting	105
13.5 Segmenting and Reassembling Long Text Messages	105
13.5.1 Segmenting	105
13.5.2 Reassembling	106
14 Phonebook Application Scenarios	107
14.1 Memory Operations.....	107
14.1.1 Reference Process	107
14.1.2 Troubleshooting	107
14.2 Setting the TE's Character Sets and Reading/Writing Phonebook Entries	108
14.2.1 Reference Process	108
14.2.2 Troubleshooting	109
14.3 Querying User Number	110
14.3.1 Reference Process	110
14.3.2 Troubleshooting	111
15 SIM Operation Application Scenarios.....	112
15.1 PIN Operations.....	112
15.1.1 Reference Process	112
15.1.2 Troubleshooting	113
15.2 CRSM Command	113
15.2.1 Reference Process	113
15.2.2 Troubleshooting	115
16 Sleeping and Waking Up Application Scenarios	116
16.1 Overview	116
16.2 Hardware Interfaces	117
16.3 Sequence Diagram.....	118
16.4 Software Interfaces.....	119
16.4.1 Principle	119
16.4.2 USB Interface.....	121
16.4.3 UART Interface	121
16.4.4 Module Wake-up.....	121
16.4.5 Host Woken up by Module.....	121
16.5 Application Scenarios: System with USB Connection only	123



16.5.1 Hardware Connection	123
16.5.2 Software Procedure	123
16.5.3 Advantages	123
16.6 Application Scenarios: System with USB and WAKEUP_OUT	123
16.6.1 Hardware Connection	124
16.6.2 Software Procedure	124
16.6.3 Advantages	124
16.7 Application Scenarios: System with UART and WAKEUP_OUT/WAKEUP_IN	125
16.7.1 Hardware Connection	125
16.7.2 Software Procedure	125
16.7.3 Advantages	125
16.8 System with Other Connection Methods	126
16.9 Solution to Time-expired USB Reset to Suspended Device	126
17 Thermal Protection Application Scenarios	127
17.1 Pre-configuration	127
17.1.1 Reference Process	127
17.1.2 Troubleshooting	127
17.2 Thermal Protection Process	128
18 Concurrent Service Application Scenarios	129
18.1 Voice Calls and Text Messaging	129
18.1.1 Reference Process	129
18.2 Internal/External Protocol Stacks and Text Messaging	129
18.2.1 Reference Process	130
18.3 Internal/External Protocol Stacks and Voice Calls	131
18.3.1 Reference Process	132
18.4 Other Services	134
19 STK Application Scenarios	135
19.1 Unsolicited Report of STK Proactive Commands	135
19.1.1 Reference Process	135
19.1.2 Troubleshooting	136
19.2 Querying the STK Main Menu	137
19.2.1 Reference Process	137
19.2.2 Troubleshooting	137
19.3 STK Envelope Command	138
19.3.1 Reference Process	138
19.3.2 Troubleshooting	138
20 TTS Application Scenarios	139
20.1 TTS Playing	139
20.1.1 Reference Process	139
20.1.2 Flowchart	140



20.1.3 Troubleshooting	141
21 FOTA Application Scenarios	142
21.1 Overview	142
21.2 FOTA Process.....	143
21.2.1 Upgrade Module Firmware Over Air Through Delta Package.....	143
21.2.2 Procedure for FOTA Implementation.....	143
21.3 Setting FOTA Mode	146
21.3.1 Reference Process	146
21.3.2 Troubleshooting	146
21.4 Setting FOTA Connection Parameters.....	147
21.4.1 Reference Process	147
21.4.2 Troubleshooting	147
21.5 Manually Querying for Upgrade Firmware Version.....	147
21.5.1 Reference Process	147
21.5.2 Troubleshooting	149
21.6 Periodically Querying the Version.....	149
21.6.1 Reference Process	149
21.6.2 Troubleshooting	150
21.7 Manually Downloading the Version	150
21.7.1 Reference Process	150
21.7.2 Troubleshooting	151
21.8 Automatically Downloading the Firmware	152
21.8.1 Reference Process	152
21.8.2 Troubleshooting	152
21.9 Using the Resumable Data Transfer Function.....	153
21.9.1 Reference Process	153
21.9.2 Troubleshooting	153
21.10 Manually Canceling the Download.....	154
21.10.1 Reference Process	154
21.10.2 Troubleshooting	154
21.11 Manually Upgrading the Version.....	154
21.11.1 Reference Process	154
21.11.2 Troubleshooting.....	155
21.12 Automatically Upgrading the Version	155
21.12.1 Reference Process	155
21.12.2 Troubleshooting	156
21.13 Enable or Disable FOTA SMS Auto-Download.....	156
21.13.1 Reference Process	156
21.13.2 Troubleshooting	158
21.14 FOTA Notification Reception Application Scenarios.....	158
21.14.1 Reference Process	158



21.14.2 Troubleshooting	158
21.15 FOTA Process Startup Application Scenarios	159
21.15.1 Reference Process	159
21.15.2 Troubleshooting	160
22 LED Indication Application Scenarios	161
22.1 Overview	161
22.2 LED Setting Operations	162
22.2.1 Reference Process	162
22.2.2 Troubleshooting	163
23 Local Upgrade Application Scenarios.....	164
23.1 Starting the Local Upgrade.....	164
23.1.1 Local Upgrade Flow Chart.....	164
23.1.2 Test Steps	165
23.1.3 Reference Process	169
23.1.4 Troubleshooting	170
23.2 Reporting the Local Upgrade State	170
23.2.1 Reference Process	170
23.2.2 Troubleshooting	170
24 eCall Application Scenarios.....	171
24.1 Performance Specifications for MSD Transmission	171
24.1.1 Prerequisites	171
24.1.2 Timing Methods	171
24.1.3 Performance Specifications.....	172
24.2 AT Command Initiating Port	172
24.3 Precautions for Using ECLPUSH	172
24.4 Method for Improving the eCall Setup Success Rate	172
24.5 Handling Conflicts Between eCall and Other Voice Calls	172
24.6 Manual Initiation of eCall Emergency Calls	172
24.6.1 Reference Process	173
24.6.2 Troubleshooting	174
24.7 Automatic Initiation of eCall Emergency Calls by the Vehicle	174
24.7.1 Reference Process	174
24.7.2 Troubleshooting	176
24.8 Manual Initiation of eCall Test Calls.....	176
24.8.1 Reference Process	176
24.9 Automatic Initiation of eCall Test Calls by the Vehicle.....	177
24.9.1 Reference Process	177
24.10 MSD Update Request to the User	179
24.10.1 Reference Process	179
24.10.2 Troubleshooting	179
24.11 Unsolicited MSD Transmission by the IVS.....	180



24.11.1 Reference Process	180
24.12 Unsolicited Report of eCall Redial Information.....	180
24.12.1 Reference Process	180
24.13 Hanging Up eCall Voice Calls.....	181
25 Netscan Application Scenarios.....	182
25.1 Reference Process	182
25.2 Troubleshooting.....	183
26 Network Monitoring Application Scenarios	184
26.1 Application Background.....	184
26.2 Reference Process	184
26.3 Troubleshooting.....	185
27 Cell Lock Application Scenarios	186
27.1 Application Background.....	186
27.2 Reference Process	186
27.3 Troubleshooting.....	187
28 FREQLOCK Application Scenarios.....	188
28.1 Application Background.....	188
28.2 Reference Process	188
28.3 Troubleshooting.....	190
29 MultiPDP Application Scenarios.....	191
29.1 Solution Overview	191
29.2 Restrictions.....	192
29.3 Example	193
30 Recorder Application Scenarios	194
30.1 Setting Recording Options	194
30.1.1 Reference Process	194
30.1.2 Troubleshooting	194
30.2 Starting Recording.....	195
30.2.1 Reference Process	195
30.2.2 Troubleshooting	195
30.3 Playing Recordings	196
30.3.1 Reference Process	196
30.3.2 Troubleshooting	196
30.4 Writing Recording Data on Other Devices to the Module	196
30.4.1 Reference Process	196
30.4.2 Troubleshooting	197
30.5 Deleting Recording Data of Other Devices from the Module	198
30.5.1 Reference Process	198
30.5.2 Troubleshooting	198



31 Appendix	199
31.1 Relative Documents	199
31.2 Acronyms and Abbreviations	199



1 Overview

This document is intended to provide references for customers to choose appropriate command sequences to start using the ME909s series module (ME909s for short) in a faster manner. This document also contains examples and relevant description.

The ME909s is an industrial module that is designed for automobiles.

Table 1-1 ME909s series module

Product	Bands
ME909s-821 and ME909s-821 Mini PCIe	FDD LTE: Band 1, Band 3, Band 8, all bands with diversity TDD LTE: Band 38, Band 39, Band 40, Band 41, all bands with diversity DC-HSPA+/HSPA+/HSPA/UMTS: Band 1, Band 5, Band 8, Band 9, all bands with diversity TD-SCDMA: Band 34, Band 39 GSM/GPRS/EDGE: 1800 MHz/900 MHz
ME909s-120 and ME909s-120 Mini PCIe	FDD LTE: Band 1, Band 2, Band 3, Band 4, Band 5, Band 7, Band 8, Band 20, all bands with diversity WCDMA/HSDPA/HSUPA/HSPA+: Band 1, Band 2, Band 5, Band 8, all bands with diversity GSM/GPRS/EDGE: 850 MHz/900 MHz/1800 MHz/1900 MHz

This document will be updated based on customers' requirements.


1.1 Conventions and Definitions

1.1.1 Conventions

Convention	Description
<...>	Value range of AT command parameters

Convention	Description
xxxx	Personal Identification Number (PIN), Personal Unlock Key (PUK), or password

1.1.2 Definitions

Term	Definition
Connected	Indicates that a link has been set up between two modules or a module and a terminal.
Registered	Indicates that the module is registered with a UMTS/GSM network.
Module	HUAWEI LTE module
 <p>The diagram illustrates the connection between an application and a mobile network. On the left, an icon of a laptop is labeled 'Application'. A line connects the laptop to a central box labeled 'Mobile equipment'. This box contains several smaller rectangular components. A lightning bolt symbol connects the 'Mobile equipment' box to a cloud icon on the right labeled 'Mobile Network'.</p>	

1.2 Basic AT Command Processing Principles

1.2.1 Ports

The ME909s provides four ports to interact with its host:

- MODEM port: simulated using USB, for AT command interaction and establishing data connection.
Port name: HUAWEI Mobile Connect-3G Modem
- PCUI port: simulated using USB, for AT command interaction only.
Port name: HUAWEI Mobile Connect-3G PCUI Interface
- UART port: physical serial port, for AT command interaction and establishing data connection.
- ECM port: simulated using USB, for establishing communication connection.
Port name: CDC Ethernet Control Model (ECM)

The ME909s also provides a port for debugging:

- DIAG port: simulated using USB, for DIAG (diagnostic) command interaction (mainly used to debug modules at present).

Port name: HUAWEI Mobile Connect-3G Application Interface.

A host controls a module using AT commands. If AT commands are unavailable, a module can be deemed as unavailable.


1.2.2 AT Command Processing Mechanism

A module processes AT commands from the ports (MODEM, PCUI, ECM and UART) in series. An AT command can be processed when and only when the previous AT command processing has been completed. If the module is processing an AT command, a new AT command from the same port will be buffered and other commands from other ports will be buffered until the current AT command is processed.


This rule also applies to COM ports converted from USB ports.

The processing of an AT command starts when the AT command is entered from the TE, and ends when the UE (the module) returns all the results in response the command.

Figure 1-1 AT command processing sequence diagram



Example:



Some special AT commands can be aborted by new AT commands. Such special commands are called abortive commands.

The ME909s supports the following abortive AT commands:

ATD
ATA
AT+CLCK
AT+COPS=?
AT+CLCC
AT+CLIP
AT^IPINIT
AT^IPOPEN
AT^IPSEND
AT^IPSENDEX
AT^IPCLOSE
AT^EMSEND
AT^HTTPCMD
AT^FTPCMD

AT^SSLO
AT^SSLTX
AT^SSLRX

Example:

```
AT+COPS=1,2,23415
OK
```

Before the results of AT+COPS is returned, enter any characters (such as "AT"), the module will terminate the processing of AT+COPS and return **OK**. The entered characters are used to abort the command only .

Some commands can be executed when SIM card is inserted. It would return to SIM failure if SIM card is not inserted. For more information, see Property Description of related AT in [HUAWEI ME909s Series LTE Module AT Command Interface Specification](#).

Example:

```
AT+CREG?
```

```
+CME ERROR: SIM failure          Return to SIM failure if SIM card is not inserted
```

1.2.3 Recommended Timeout Mechanism for AT Commands Processed by a Host

A module processes AT commands in series. Do not send another AT command before the result for the current command is returned or the current command times out (except when the current command is an interruptible AT command). The following table lists AT command timeout durations (starting from the time when an AT command arrives at a port).

Table 1-2 AT command timeout duration

AT Command	Timeout Duration
General AT commands	30s
AT+CMSS/AT+CMGS (used to send text messages)	60s
AT+COPS=? (used to search for networks)	120s

After an AT command times out, it is recommended that the host check whether the module is functioning normally. The following procedure is provided for your reference:

1. The host sends the AT command to the module.
2. If the module returns failure information, go to step 5.
3. If the module returns success information, the module is functioning normally.



4. If the host times out (the host waits for a response for over 30 seconds) three times when waiting for the response from the module, go to step 5. Otherwise go to step 1.
5. The host deems that the current module does not exist or is unavailable. Close the port, stop sending all AT commands, exit the procedure to determine whether the module is normal, and re-search for modules.

2 Initialization Application Scenarios

2.1 Startup Indication ^SYSSTART

2.1.1 Reference Process

Command	Description
	This unsolicited indication is used to notify the TE when the ME is powered on or reset.
^SYSSTART	Indicates that a module is starting.

**NOTE**

^SYSSTART is presented only when a module is starting and will not be presented after a module has started. It is presented in HSUART port, PCUI port and modem port.

2.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
The module presents ^SYSSTART during startup. After that, the module presents ^SYSSTART again.	Indicates that the module has been reset.	If ^SYSSTART is presented repeatedly, send the module to the specified repair center.

2.2 Querying Basic Information

2.2.1 Reference Process

Command	Description
AT+GMR/AT+CGMR	Queries software version.
Software version	Software version. For example: 23.613.61.00.00
OK	
AT+GMI/AT+CGMI	Queries manufacturer identification.
Manufacturer Identification	For example: Huawei Technologies Co., Ltd.
OK	
AT+GMM/AT+CGMM	Queries model identification.
Model identification	For example: ME909s-120
OK	
AT+GSN/AT+CGSN	Queries product IMEI.
IMEI	For example: 865261010004010
OK	

 **NOTE**

The previously listed commands are execution commands and cannot be used to configure settings.

2.2.2 Troubleshooting

None

2.3 Network Service Operations

2.3.1 Reference Process

Command	Description
AT+CFUN?	Queries a module's current mode.
+CFUN: 1	1 indicates online mode.
OK	

Command	Description
AT+CPIN?	Queries whether a module's SIM card is password protected.
+CPIN: READY OK	READY indicates that the SIM card is ready.
AT^HCSQ?	Queries the network's signal strength.
^HCSQ: "WCDMA",30,30,58 OK	
AT+COPS?	Returns the current network selection mode, information about the operator with which the module is registered, and the wireless access standard.
+COPS: "Network status information" OK	For example: +COPS: 1,0,"China Mobile Com",0
AT+COPS=0 OK	Automatically searches for networks.
AT+CREG?	Queries the state of the currently registered network.
+CREG: 0,1 OK	
AT+CREG=1 OK	Sets the +CREG unsolicited indication.

2.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Query the current registered network information about selection mode, operator info and the wireless access standard. AT+COPS?	+CME ERROR: SIM failure	No SIM card is detected. Insert a SIM card.



Scenario	Possible Error Information	Solution
Query the current circuit mode network registered network state. AT+CREG?	+CME ERROR: SIM failure	No SIM card is detected. Insert a SIM card.

3 Serial Port Configuration Application Scenarios

3.1 Overview

All AT commands described in this chapter take effect only when they are send by URAT. If send by other ports (such as USB or CMUX port), they are ineffective.

3.2 Baud Rate Configuration

3.2.1 Reference Process

Command	Description
AT+IPR?	Queries the baud rate currently used by a module.
+IPR: 115200 OK	
AT+IPR=<baud rate>	Sets a module's baud rate. After a new baud rate is specified, the module communicates using the new baud rate.
OK	

NOTE

- If a module's baud rate is too low, its communication speed will be slow.
- At present, the ME909s supports the following baud rates: 300 bit/s, 600 bit/s, 1200 bit/s, 2400 bit/s, 4800 bit/s, 9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, 115200 bit/s, 230400 bit/s, 1000000 bit/s and 3000000 bit/s.
- If the baud rate is not specified, the default value is 0.

3.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Specify a baud rate not supported by a module. AT+IPR=9800	ERROR	Check whether the specified baud rate is within the range of supported baud rates.
If the specified value is a letter, ERROR will be returned. AT+IPR=ABCD	ERROR	Check whether the specified value is a digit.

3.3 Baud Rate Autonegotiation

3.3.1 Reference Process

Command	Description
AT+IPR=0	Switches to baud rate autonegotiation mode when the module is restarted.
OK	
AT/at	Sends the baud rate detection signal. After the module is restarted and switched to baud rate autonegotiation mode, only the "AT" or "at" characters are considered as the baud rate detection signal and can return OK.
OK	

NOTE

- If the parameter of the **AT+IPR** command is set to a value other than 0, the module is switched to fixed baud rate mode, and the host and module communicate with each other at the set baud rate. No baud rate autonegotiation is involved.
- In baud rate autonegotiation mode, only the 9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s rates can be detected. If the host uses a rate other than the listed, the module cannot detect the rate. In this case, a user needs to manually check the host's baud rate and run the **AT+IPR** command to set the module to the same rate for normal communication.
- The baud rate autonegotiation mode is used by default. Before the host communicates with the module, the host sends "AT" or "at" to sync the baud rate.
- To ensure that baud rate autonegotiation is successful, the serial port frame format of the host and module must be 1 start bit+8 data bits+1 stop bit.

3.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
After the module is switched to baud rate autonegotiation mode, "aT" or "At" is sent as the baud rate detection signal.	ERROR	Only the strings "AT" or "at" can be detected as detecting signal, neither "At" nor "aT".

3.4 DTR Hang Up Data Services

3.4.1 Reference Process

Command	Description
AT&D0	Establishes a dial-up connection through a serial port for data services. After this command is executed, data can be transferred properly regardless of any DTR pin voltage changes.
OK	
AT&D2	Terminates a dial-up connection through a serial port for data services. After this command is executed, data services will be ended if the DTR pin voltage settings are invalid.
OK	



NOTE

At present, only **AT&D0** and **AT&D2** are supported. **AT&D1** is not supported.

3.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
The specified value of 1 is not supported by a module. AT&D1	ERROR	At present, only AT&D0 and AT&D2 are supported. AT&D1 is not supported.

3.5 DCD Pin Control

3.5.1 Reference Process

Command	Description
AT&C0	Sets the DCD pin to be always valid regardless of data services.
OK	
AT&C1	Sets the DCD pin to be valid when there are ongoing data services and invalid after data services are disconnected.
OK	

3.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
The specified value of 2 is not supported by a module. AT&C2	ERROR	Unsupported parameter value.
The specified value of a letter is not supported by a module. AT&CA	ERROR	At present, only AT&C0 and AT&C1 are supported. Otherwise, ERROR will be returned.

3.6 Setting Hardware Flow Control

3.6.1 Reference Process

Command	Description
AT+IFC=0,0	Turns hardware flow control off. After hardware flow control is turned off, communication between the UE and the DTC is not restricted by flow control.
OK	
AT+IFC=2,2	Turns hardware flow control on. After hardware flow control is turned on, communication between the UE and the TE is restricted by flow control: Data transmission stops when UE's or TE's buffer level exceeds 80% and resumes when the buffer level is below 20%.
OK	

**NOTE**

- If hardware flow control is enabled, no AT commands can be executed.
- To support hardware flow control, RX, TX, CTS, and RTS pins are all required for the UART port.

3.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
If the specified value exceeds the value range, ERROR will be returned. AT+IFC=4,0	ERROR	The specified value of 4 exceeds the value range. Specify the value as 0 or 2.
If the specified value exceeds the value range, ERROR will be returned. AT+IFC=0,4	ERROR	The specified value of 4 exceeds the value range. Specify the value as 0 or 2.

4 External Protocol Stack Application Scenarios

4.1 Prerequisites

4.1.1 Reference Process

Command	Description
AT+CGDCONT=1,"IP","1234"	Configures PDP contexts. In this example provided in the left column, the APN is 1234. In practice, the APN is provided by your network service provider.
OK	
AT+CGATT?	Obtains PS domain service status.
+CGATT: 1	If 1 is returned, attaching to the PS domain is succeeded.
OK	If OK is returned, the command has been executed successfully.

**NOTE**

External protocol stack supports UART or MODEM ports only. After the pre-configuration is complete, ensure that the desired port is not occupied by other processes.

4.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Query the current GPRS service state: AT+CGATT?	+CGATT: 0 OK	This value indicates the UE does not obtain any PS domain services. Run AT+CGATT=1 to manually attach to the PS domain. If attaching to the PS domain still fails, refer to section 2.3 Network Service Operations.

4.2 Establishing Data Connections

4.2.1 Reference Process

- Process 1

Command	Description
ATD*99#	*99# is the GPRS password. This command is usually used in Windows. The UE switches from command mode to data mode. After the TE starts the PPP negotiation process, the UE automatically performs the actions (including PS domain attaching and PDP activation) required for establishing data connections.
CONNECT xxx	CONNECT indicates that the data service dial-up command is being processed by the module. xxx indicates the data rate, which depends on the network standard and capability level.

- Process 2

Command	Description
AT+CGDATA="PPP",1	This command is equivalent to ATD*99# . This command is usually used in the Android Radio Interface Layer (RIL).
CONNECT	

NOTE

- Using the previously configured profile, the PPP negotiation between the TE and the UE, and the PDP negotiation between the UE and the network, the TE obtains the IP and DNS addresses to establish the routing between the TE and the network.

- When establishing data service connections, the TE must start the PPP negotiation after the UE enters data mode. Otherwise the UE will only enter data mode but will not establish data connections with the network.
- The data mode means: After entering data mode, the UE only transfers data packets between the UE and the network, and will not respond to any AT commands.

4.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Failure to open ports or register with a network	Error xxx: The modem (or other connected device) is in use. Note: xxx is usually a number indicating an error. For example, 633 .	<ol style="list-style-type: none"> 1. Check whether the Modem port is in use. Ensure that the Modem port is not being used by other connections. 2. Check whether the current network is operating normally. Data service connections can be established only when the network is operating normally.

4.3 Data Transmission

1. Data can be transmitted after data service connections are established.
2. According to 3GPP TS 25.306, HSDPA (FDD) terminals are classified into 24 categories. Different categories have different peak data rates. The following table lists common categories and their key parameters.

Common Terminal Category	Maximum Number of Codewords	Soft Channel Size (Bits)	Minimum Transmission Time Interval (TTI)	Modulation Mode	Theoretical Peak Rate (Mbit/s)
Category 8	10	134400	1	QPSK 16QAM	7.2
Category 10	15	172800	1	QPSK 16QAM	14.4
Category 14	15	259200	1	QPSK 16QAM 64QAM	21.6

Common Terminal Category	Maximum Number of Codewords	Soft Channel Size (Bits)	Minimum Transmission Time Interval (TTI)	Modulation Mode	Theoretical Peak Rate (Mbit/s)
Category 16	15	345600	1	QPSK 16QAM MIMO+16QAM Note: 64QAM is not supported.	28.8
Category 18	15	345600	1	QPSK 16QAM 64QAM MIMO+16QAM	28.8
Category 20	15	518400	1	QPSK 16QAM 64QAM MIMO+16QAM MIMO+64QAM	43.2
Category 24	15	518400	1	QPSK 16QAM 64QAM DC	43.2

HSUPA (FDD) terminals are classified into seven categories. The following table lists common categories and their key parameters.

Common Terminal Category	Maximum Number of E-DCH	Minimum SF	Support 2 ms TTI	Modulation Mode	Theoretical Peak Rate (Mbit/s)
Category 5	2	SF2	No	QPSK	2
Category 6	4	SF2	Yes	QPSK	5.76

3. According to the Radio Resource Control (RRC) version, the WCDMA/HSDPA/HSUPA/LTE/DC_HSPA rate in theory are as follows:

WCDMA RRC Version - 3GPP Rel	Downlink Modulation Mode	Uplink Modulation Mode	Downlink Theoretical Peak Rate (Mbit/s)	Uplink Theoretical Peak Rate (Mbit/s)
R99/R4	QPSK	BPSK	0.384	0.384
Rel-5	16QAM+	QPSK	14.4	0.38

WCDMA RRC Version - 3GPP Rel	Downlink Modulation Mode	Uplink Modulation Mode	Downlink Theoretical Peak Rate (Mbit/s)	Uplink Theoretical Peak Rate (Mbit/s)
Rel-6	16QAM	QPSK	14.4	5.76
Rel-7	16QAM	16QAM	28.8	11.52
	64QAM	16QAM	21.6	11.52
Rel-8	64QAM	16QAM	43.2	11.52
	DC-SHDPA+64QAM	16QAM	43.2	11.52
Rel-9	DC-SHDPA+64QAM	DC-SHUPA	84	23

4.4 Switch Between Data Mode and Command Mode

4.4.1 Reference Process

Command	Description
ATD*99#	UE dials up.
CONNECT	
+++	Enters +++ (three plus signs) to switch the data service port from data mode to command mode. The UE can then respond to AT commands and perform corresponding actions.
ATO	Switches the data service port back to data mode so that the UE can continue to transmit data.
CONNECT	

NOTE

- If there are no data links available, the module will not switch back to data mode but remains in command mode.
- If the data link is connected, when the module switches from data mode to command mode, data transmission will be suspended.
- If the data link is connected, when the module switches from command mode to data mode, data transmission will be resumed.

4.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Switch the data service port from data mode to command mode : +++	Failed to switch to command mode.	+++ must be consecutively entered within 0.9s.

4.5 Disconnecting Data Service Connections

4.5.1 Reference Process

- Process 1

Command	Description
+++	
ATH	Before this command is executed at the data service port, the +++ sequence must be sent from the data service port. This command is used to disconnect data service connections. This command is usually used in Windows.
OK	

- Process 2

Command	Description
AT+CGACT=0,1	In Android RIL, after a PPP connection is disconnected, this command is executed to deactivate the PDP context to release the data link and disconnect the data services. The use of this command is the same as that of ATH.
OK	

1. Terminating a data service connection from the TE: the TE sends a PPP Terminate packet to the UE to pull down the DTR signal. The UE disconnects the PPP connection, releases the wireless link resource, pulls down the CD signal, and returns **NO CARRIER**. As a result, the data service connection is disconnected. This method of disconnecting data service connections is usually implemented by the disconnection function of the TE's application.
2. Terminating a data service connection from the UE: The TE sends an AT command to the UE to pull down the DTR signal. After receiving the AT command, the UE releases the connection to the network, pulls down the CD signal, and returns **NO CARRIER**. As a result, the data service connection is disconnected. This mode of disconnecting data service connections requires an AT command interaction tool.
3. When disconnecting data service connections in Android RIL, the module must kill pppd to disconnect PPP connections before using **AT+CGACT=0** to deactivate PDP contexts and release wireless link resources.

5 Internal Protocol Stack Application Scenarios-TCP/UDP

5.1 Overview

In a TCP/UDP link, the module transmits data without encryption. To transmit security data, use either of the following methods:

- Use FTPS, HTTPS, SMTPS, or SSL for transmission instead of unsecured FTP, HTTP, SMTP and TCP. For details, see the application guide.
- Enable the host computer to encrypt the data and transmit the encrypted data in TCP/UDP link.

5.2 Initializing Internet Services

5.2.1 Reference Process

Command	Description
<code>AT^IPINIT="1234","card","card",,2</code>	In this example provided in the left column, the APN is 1234 , and the user name and password are both card . The authentication type is CHAP .
<code>OK</code>	
<code>AT^IPINIT?</code>	Queries the obtained IP and DNS addresses.
<code>^IPINIT: 1,"192.168.70.59","1234","192.168.44.200","192.168.44.201"</code>	
<code>OK</code>	

5.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Query the obtained IP and DNS addresses. AT^IPINIT?	^IPINIT: 0 OK	Initialization has not been performed. Initialize the internal protocol stack and query again.
Initialize the internal protocol stack. AT^IPINIT="1234","card","card"	+CME ERROR: Normal error	Initialization failed. 1. Check that the current network signal strength is good and the parameters are set correctly. 2. Ensure that no IP stack termination command has been executed.
	+CME ERROR: The link has been established already	AT^IPINIT? queries whether the internal protocol stack has been initialized. If the internal protocol stack has been initialized, it does not need to be initialized again. If it has not been initialized, there are ongoing dial-up services. Hang up the dial-up services and re-send AT^IPINIT to start initialization.

5.3 Creating a Listen Server

5.3.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^IPLISTEN="TCP",5000	Creates a TCP server whose listen port number is 5000 (users can specify this number as required). For the method to create UDP servers, refer to the AT command document.
OK	
AT^IPLISTEN?	Queries the information about the server that has been created.
^IPLISTEN: "TCP",5000,5	
OK	

 **NOTE**

- Only one server is supported by the internal protocol stack.
- The internal protocol stack must be initialized before you create a listen server.

5.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create a listen server. AT^IPLISTEN="TCP", 5000	+CME ERROR: The network has not been opened yet	Run AT^IPINIT to initialize the internal protocol stack, and then create the listen server.
	+CME ERROR: The server has been established already	A listen server already exists. Run AT^IPCLOSE=6 to close the existing listen server.
	+CME ERROR: Fail to bind the specified port with server	The local port is in use. Change the port and re-send the command.

5.4 Creating TCP/UDP Links

5.4.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"UDP","192.168.44.33", 5000,5500	Uses a specified IP address to connect to the remote server and establish a UDP link.
OK	
AT^IPOPEN?	Queries link information.
^IPOPEN: 1,"UDP",5500,"192.168.44.33",5000,3,0	
OK	
AT^IPOPEN=1,"TCP","example.com", 80	Uses a specified domain name to connect to the remote server and establish a TCP link.
OK	
AT^IPOPEN?	Queries link information.

Command	Description
<code>^IPOPEN: 1,"TCP",5500,"example.com",80</code>	
<code>OK</code>	

 **NOTE**

- When creating a listen server, the local port number can be ignored. If the port number is ignored, the module will randomly assign a local port number.
- When creating a TCP link, ensure that the remote server has been started.
- The Maximum Segment Size (MSS) for creating TCP links is 1220 bytes. Data larger than the MSS will be segmented into several packets.

5.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create a client link <code>AT^IPOPEN=1,"TCP", 192.168.44.33",5000</code>	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Run <code>AT^IPCLOSE</code> to close the corresponding link. Alternatively, change the link ID and send the command to create the link.
	+CME ERROR: Fail to bind the specified port	Change the local port number, or leave the local port number blank.
Query link information <code>AT^IPOPEN?</code>	OK	No link information is available. Create a link, or accept the link as a server, and then query the link information again.

5.5 Sending Data

5.5.1 Reference Process

Command	Description
<code>AT^IPINIT="1234","card","card"</code>	Initializes the internal protocol stack.
<code>OK</code>	

Command	Description
AT^IPOPEN=1,"TCP","192.168.44.33", 5000,5500	Creates a link.
OK	
AT^IPSEND=1,"31323334"	Sends data. In this example, 31323334 is sent.
^IPSEND: 1 OK ^IPDATA: 1,8,31323334	Data is successfully sent and received.
AT^IPSENDEX=1,0,"31323334"	Sends data in mode 0. In this example, 31323334 is sent.
^IPSENDEX: 1 OK ^IPDATA: 1,8,31323334	
AT^IPSENDEX=1,1,"31323334"	Sends data in mode 1. In this example, 1234 is actually sent.
^IPSENDEX: 1 OK ^IPDATA: 1,4,1234	
AT^IPSENDEX=1,2,<datalen>	Sends data in mode 2.
OK (Wait for the user to enter user data with a length of <datalen>) ^IPSENDEX: 1 OK	



NOTE

- **AT^IPSEND** and mode 0 of **AT^IPSENDEX** can send displayable characters only. Mode 1 and mode 2 of **AT^IPSENDEX** can send all characters.
- In mode 2 of **AT^IPSENDEX** (length restriction mode), except the port that receives data entered by the user, all other ports are unavailable before the user finishes entering the user data.

5.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
Send data using AT^IPSEND AT^IPSEND=1,"data"	+CME ERROR: The network has not been opened yet	Before sending data, initialize the protocol stack or accept the link as a server.
	+CME ERROR: Remain data is sending	The module is exiting transparent transmission mode and cannot send data. Wait until the module completely exits transparent transmission mode.
	+CME ERROR: The link has not been established yet	Before sending data, create a link or accept the link as a server.
	+CME ERROR: Normal error	The module failed to send the data. Ensure that the current network's signal strength is good.
Send data using mode 2 of AT^IPSENDEX AT^IPSENDEX=1,2,<data len>	+CME ERROR: Too many data to be sent	The length of the data entered by the user exceeds the length specified by the command. Ensure that the length of the data is equal to the data length specified by mode 2 of AT^IPSENDEX .

5.6 Closing TCP/UDP Links

5.6.1 Reference Process

Command	Description
AT^IPCLOSE=<link_id>	Closes the specified link, server, or network. For details about the parameters, refer to the related AT command document.
OK	
AT^IPCLOSE?	Queries the current link status.

Command	Description
^IPCLOSE: 1,0,0,0,0 OK	1 indicates that the link is open, and 0 indicates that the link is closed.

5.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
Close the specified link. AT^IPCLOSE=<link_id>	+CME ERROR: Normal error	The command is terminated. Run the AT^IPCLOSE command again.

5.7 Transparent Transmission Mode

5.7.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card" OK	Initializes the internal protocol stack.
AT^IPOPEN=1,"UDP","192.168.44.33",5000,5500 OK	Creates a link.
AT^IPCFL=12,0 OK	Sets the transparent transmission mode to time- and length-based transmission mode.
AT^IPCFL=5,100 OK	Sets the timer for triggering transparent transmission to 10s (100 x 0.1s).
AT^IPCFL=10,1220 OK	Sets the TCP/UDP MSS to 1220 bytes.
AT^IPENTRANS=1 OK	Enables transparent transmission mode.

Command	Description
313233347D5D7D5E7E	<p>Sends user data. User data is sent once the data length reaches the segment length specified by parameter 10 of AT^IPCFL. If the user data length is shorter than the specified length, the data will be sent when the timer set by parameter 5 of AT^IPCFL counts down to 0. For details about the transmission mechanism, refer to the description of AT^IPENTRANS in the AT command document.</p> <p>In this example, the data entered by the user is 313233347D5D7D5E7E in hexadecimal format.</p> <p>The data sent by the module is the original data entered by the user.</p>
313233347D5D7D5E7E	<p>Receives user data in time-based and length-based transmission mode. In this example, the data received by the module is 313233347D5D7D5E7E.</p> <p>The original data received by the module is presented.</p>
+++	Exits transparent transmission mode. For the rules about the +++ sequence, refer to the AT command document.
OK	
AT^IPCFL=12,1	Sets the transparent transmission mode to 7E detection mode.
OK	
AT^IPENTRANS=1	Enables transparent transmission mode.
OK	
AT^IPENTRANS?	Queries the link ID for entering transparent transmission mode from a non-transparent port.
^IPENTRANS: 1	
313233347D5D7D5E7E	<p>Sends data in 7E detection mode (applies to UDP only). In this example, the data that the user wants to send is 313233347D7E in hexadecimal format. Therefore, the user needs to transform 7D to 7D5D and 7E to 7D5E, and adds 7E as the ending characters to the end of the data.</p> <p>After the module recognizes the data packet, the data actually sent by the module is 313233347D7E.</p>

Command	Description
313233347D5D7D5E7E	<p>Receives data in 7E detection mode (applies to UDP only).</p> <p>The data received by the module is 313233347D7E in hexadecimal format. After receiving the data, the module transforms 7D to 7D5D and 7E to 7D5E, and adds 7E as the ending characters to the end of the data before presenting the data to the user.</p>

 **NOTE**

- The transparent transmission mode of the internal protocol stack supports UART only.
- The internal protocol stack allows only one link to enter transparent transmission mode. In addition, before entering transparent transmission mode, ensure that only one link exists at the current physical port. If the module functions as a server, the link can enter transparent transmission mode only when the link is requested by a remote client and accepted by the server.
- The settings (including the time-based and length-based transmission mode and 7E detection mode) of transparent transmission mode must be configured using **AT^IPCFL** before the transparent transmission mode is enabled. For details about how to configure the settings, refer to the AT command document.
- When in transparent transmission mode, the current port cannot be used for reporting.

5.7.2 Troubleshooting

Scenario	Possible Error Information	Solution
Enter transparent transmission mode. AT^IPENTRANS=1	+CME ERROR: Invalid port for transparent mode	This indicates that the link is not established at a UART port. To solve this problem, establish a link from a UART port and set the UART port to enter transparent transmission mode.
	+CME ERROR: More than one link in physical port	There are more than one link. Use AT^IPCLOSE to close other links before entering transparent transmission mode.
	+CME ERROR: The physical port is in listen state and has no client	The module functions as the server but does not accept the link requested by the client. Accept the link before entering transparent transmission mode.

Scenario	Possible Error Information	Solution
Specify the transparent transmission mode using AT^IPCFL . AT^IPCFL=5,10	+CME ERROR: Forbidden operation in transparent mode	AT^IPCFL cannot be used during transparent transmission. Exit transparent transmission mode before running AT^IPCFL .

5.8 Packet Statistics

5.8.1 Reference Process

Command	Description
AT^IPFLOWQ?	Queries packet statistics. In this example, the returned result indicates that 3 bytes of characters are successfully received by and sent from link 1. For details about the parameters, refer to the AT command document.
^IPFLOWQ: 1,3,3,3,3,3 ^IPFLOWQ: 2,0,0,0,0,0 ^IPFLOWQ: 3,0,0,0,0,0 ^IPFLOWQ: 4,0,0,0,0,0 ^IPFLOWQ: 5,0,0,0,0,0 OK	
AT^IPFLOWQ=<linkid>	Clears the traffic statistics on the specified link (<linkid>: 1-5).
OK	
AT^IPFLOWQ=0	Clears the traffic statistics on all links.
OK	

5.9 TCP/UDP Link Change Indication

5.9.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.



Command	Description
OK	
AT^IPLISTEN="TCP",5000	Creates a server.
OK (The client requests to connect to the server.) ^IPSTATE: 1,1,1	The server accepts the link requested by the client.
(The other party of the link closest the link.)	
^IPSTATE: 1,0,0	
(Network connection is broken.)	
^IPSTATE: 1,0,2 ^IPSTATE: 6,0,2 ^IPSTATE: 7,0,2 ^IPSTATE: 0,0,3 ^IPSTATE: 0,0,4	Indications presented without solicitation for broken links, connection to the server, and network connections. The number of current links has reached the supported maximum. New link requests will be rejected. The module rejects new link requests because it functions as the server and is in transparent transmission mode.

6 Internal Protocol Stack Application Scenarios-FTP

6.1 Creating an FTP Control Link

6.1.1 Reference Process

Command	Description
<code>AT^IPOPEN=1,"FTP","192.168.63.41",21,"username","password"</code>	Creates a normal FTP control link, an FTP user is successfully logged in FTP server.
<code>OK</code>	
<code>^IPSRVST: 1,10,230</code>	

 **NOTE**

- Only one FTP service can be enabled at a time. Not concurrent operate with other built-in protocols, including TCP, UDP, etc.
- PDP must be activated.
- Please use FTPS because FTPS have a stronger security level than FTP.

6.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create the link. <code>AT^IPOPEN=1,"FTP","192.168.63.41",21,"username","password"</code>	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Try to open an already established link.

6.2 Configuring Data Transmission Mode

In FTP, data can be transferred (PUT or GET) in three different modes.

- **Transparent transmission mode:**

For GET operation, files will be downloaded from the server and the content will be displayed to the user.

For PUT operation, users shall enter the data to be transferred to the server followed by "+++" to indicate the end of file.

During the data transfer process, we cannot execute other AT commands.

- **Command transmission mode:**

For GET operation, contents of downloaded file from server will be displayed to users through **AT^IPDATA** report.

For PUT operation, users shall enter the data to be transferred using **AT^IPSENDEX** command

During the data transfer process, we can execute any other AT commands than GET and PUT.

- **Buffer mode:**

For GET operation, contents of downloaded file from server will be stored in a buffer.

And an **^IPRCVST** report will be displayed which indicates whether there is data to be read. After that, users need to issue "**AT^IPRCV=<link_id>,<reqReceiveLength>**" to read the data from buffer. For more information on **AT^IPRCV**, please refer AT command document.

The size of the buffer is 65536 bytes.

PUT operation will be similar as in COMMAND TRANSMISSION MODE.

During the data transfer process, we can execute any other AT commands other than GET and PUT.

6.2.1 Reference Process

Command	Description
AT^IPCFL=14,0	Sets data transmission mode to transparent transmission mode.
OK	
AT^IPCFL=14,1	Sets data transmission mode to command transmission mode.
OK	
AT^IPCFL=14,2	Sets data transmission mode to buffer transmission mode.
OK	

The **AT^IPCFL** command is used to set the processing mode for FTP file data. By default, transparent transmission mode will be set. Users can change the data transmission mode as per the need specified in section 6.2 Configuring Data Transmission Mode.

6.3 Configuring FTP Data Channel Mode

6.3.1 Reference Process

Command	Description
AT^FTPCMD=1,PORT	Configures the connection mode in PORT mode for downloading and uploading data.
OK	
AT^FTPCMD=1,PASV	Configures the connection mode in PASV mode for downloading and uploading data. The default mode is PASV mode.
OK	

- In PORT mode, the client creates the control channel and provides the data port number which it will be listening on. The server then creates the data channel with the client provided port.
- In PASV mode, the client creates both control channel and data channel. PASV mode is generally used in scenarios where the server will not be able to setup the data channel; one of the major reasons for this would be the network firewall limitation.

6.4 Getting FTP File Size

6.4.1 Reference Process

Command	Description
AT^FTPCMD=1,FILESIZE,"ftp.txt"	Gets the size of the file.
^FTPCMD: "FILESIZE",25490	
OK	
AT^FTPCMD=1,FILESIZE,"/work/test.txt"	Gets the size of the file.
^FTPCMD: "FILESIZE",34570	
OK	

6.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
File Size Command AT^FTPCMD=1,FILESIZE,"ftp.txt"	+CME ERROR: The link has not been established yet	Make sure that the file size operation link ID is established.
Get File Size for a big file (> 4GB) AT^FTPCMD=1,FILESIZE,"ftp.rar"	ERROR	The file size command will return ERROR if the file size is greater than 4 GB.

6.5 Downloading File Using "GET" Command in Transparent Mode

6.5.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPCFL=14,0	Sets data transmission mode to transparent mode. By default it will be in transparent mode only.
OK	
AT^IPOPEN=1,"FTP","192.168.63.41",21,"username","password"	Creates the link.
OK	
^IPSRVST: 1,10,230	
AT^FTPCMD=1,PORT	Sets the FTP data channel mode to PORT mode for downloading and uploading the data. By default it will be PASV mode.
OK	
AT^FTPCMD=1,GET,"ftp.txt"	Gives the FTP GET command for downloading data.

Command	Description
CONNECT Hello OK ^IPSRVST: 1,11,1	

6.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
AT^FTPCMD=1,GET,"ftp.txt"	+CME ERROR: The link has not been established yet	Make sure that the get operation link ID is established.

6.6 Downloading File Using "GET" Command in Command Mode

6.6.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack
OK	
AT^IPOPEN=1,"FTP","192.168.63.41",21,"username","password"	Creates the link.
OK	
^IPSRVST: 1,10,230	
AT^IPCFL=14,1	Sets data transmission mode to command mode.
OK	
AT^FTPCMD=1,PORT	Sets the FTP data channel mode to PORT mode for downloading and uploading the data. By default it will be PASV mode.
OK	

Command	Description
AT^FTPCMD=1,GET,"ftp.txt"	Gives the FTP GET command for downloading data.
OK	
^IPDATA: 1, 5, Hello	
^IPSRVST: 1,11,1	

6.7 Download File Using "GET" Command in Buffer Mode

6.7.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"FTP","192.168.63.41", 21,,"username","password"	Creates the link.
OK	
^IPSRVST: 1,10,230	
AT^IPCFL=14,2	Sets data transmission mode to buffer mode.
OK	
AT^FTPCMD=1,PORT	Sets the FTP data channel mode PORT for downloading and uploading the data. By default it will be PASV mode. For more information on when to use PORT or PASV mode refer section 6.3 Configuring FTP Data Channel Mode.
OK	
AT^FTPCMD=1,GET,"ftp.txt"	Gives the FTP GET command for downloading data.

Command	Description
OK	
^IPRCVST: 1, 1	
^IPSRVST: 1,11,1	
AT^IPRCV=1,5	Receives the data stored in the buffer.
^IPRCV: 1,5 Hello	
OK	

6.8 Uploading File Using "PUT" Command in Transparent Mode

6.8.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"FTP","192.168.63.41", 21,"username","password"	Creates the link.
OK	
^IPSRVST: 1,10,230	
AT^IPCFL=14,0	Sets data transmission mode to transparent mode.
OK	
AT^FTPCMD=1,PORT	Sets the FTP data channel mode PORT for downloading and uploading the data. By default it will be PASV mode. For more information on when to use PORT or PASV mode refer section 6.3 Configuring FTP Data Channel Mode.
OK	

Command	Description
AT^FTPCMD=1,PUT,"ftp.txt"	Upload the data using this command. After completion of uploading, send +++ to terminate from the server. Any character is forbidden in 900 ms before and after inputting "+++", and it must be less than 900 ms between two '+' input.
CONNECT <Enter the data> <Type "+++" to terminate from the server>	
OK	
^IPSRVST: 1,11,1	

6.9 Uploading File Using "PUT" Command in Command Mode and Buffer Mode

There is no difference in PUT operation of "Command and Buffer mode". In both the mode, **AT^IPSENDEX** is used to enter the data.

6.9.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"FTP","192.168.63.41", 21,"username","password"	Creates the link.
OK	
^IPSRVST: 1,10,230	
AT^IPCFL=14,2	Sets data transmission mode to buffer mode.
OK	
AT^FTPCMD=1,PORT	Sets the FTP data channel mode PORT for downloading and uploading the data. By default it will be PASV mode. For more information on when to use PORT or PASV mode refer section 6.3 Configuring FTP Data Channel Mode.

Command	Description
OK	
AT^FTPCMD=1,PUT,"ftp.txt"	Uploads the data using this command.
OK	
AT^IPSENDEX=1,2,1500,0	It can send maximum 1500 data at a time. The last parameter <eof> is 0 where 0 means user can send more data.
OK <Enter the data> ^IPSENDEX: 1	
OK	
AT^IPSENDEX=1,2,1500,1	It can send maximum 1500 data at a time. The last parameter <eof> is 1, where 1 means end of packet and the file upload will be completed.
OK <Enter the data> ^IPSENDEX: 1	
OK	
^IPSRVST: 1,11,1	
AT^IPCLOSE=1	Closes the link.
OK	

6.10 FTP Error Codes

<state code>	<state code> representative's meaning
100	The server has not responded
110	Restarts the mark reply
120	Prepares in n minutes
125	The connection opens the preparation to transmit
150	Opens the data connection
200	Command Execution Success

<state code>	<state code> representative's meaning
202	Command Execution Failure
211	System Status
212	List Status
213	FILE SIZE
214	Help information
215	Name system type
220	The new client prepared
221	Service closure pilot connection, may withdraw registers
225	The data connection opens, does not have the transmission to be in progress
226	That the closure data connection, requested file operation successfully
227	Enters the passive pattern
230	Successful Login
250	File operation of request completes
257	Setup PATH NAME
331	A user correctness, needs the password
332	When registers needs the account information
350	Next order
421	Cannot provide the service, closes the pilot connection
425	Cannot open the data connection
426	The closure connection, stops transmitting

7 Internal Protocol Stack Application Scenarios-HTTP

7.1 Creating an HTTP Server Link

7.1.1 Reference Process

Command	Description
<code>AT^IPOPEN=1,"HTTP","m2m.example.com",9001</code>	Opens a normal HTTP server link, an HTTP user is successfully logged in HTTP.
OK	

 **NOTE**

- Only one HTTP service can be enabled at a time.
- Before an HTTP service is enabled, Internet configuration and HTTP configuration must be completed.
- Please use HTTPS because HTTPS has stronger security level than HTTP.

7.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create the link. <code>AT^IPOPEN=1,"HTTP", "m2m.example.com",9001</code>	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Try to open an already established link.

7.2 Configuring Data Transmission Mode

7.2.1 Reference Process

Command	Description
AT^IPCFL=14,0	Sets data transmission mode to transparent transmission mode.
OK	
AT^IPCFL=14,1	Sets data transmission mode to command transmission mode.
OK	
AT^IPCFL=14,2	Sets data transmission mode to buffer transmission mode.
OK	

The **AT^IPCFL** command is used to set the data processing mode for HTTP, which is same as FTP. By default, transparent transmission mode will be set. Users can change the data transmission mode as per the need specified in section 6.2 Configuring Data Transmission Mode.

7.3 Downloading File Using "GET" Command in Transparent Mode

7.3.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"HTTP","192.168.63.41",9001	Creates the link.
OK	
AT^IPCFL=14,0	Sets data transmission mode to transparent mode. By default it will be in transparent mode only.
OK	
AT^HTTPCMD=1,GET,"http://192.168.63.41:9001/n_index.txt"	Downloads the file from the HTTP server n_index.txt (In the following example, <link_id>is 1).

Command	Description
CONNECT hello123 OK ^IPSRVST: 1,12,200	

7.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
AT^HTTPCMD=1,GET,"http://m2m.example.com:9001/n_index.html"	+CME ERROR: The link has not been established yet	Make sure that the get operation link ID is established.

7.4 Downloading File Using "GET" Command in Command Mode

7.4.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPCFL=14,1	Sets data transmission mode to command mode
OK	
AT^IPOPEN=1,"HTTP","www.m2m.example.com",9001	Creates the link.
OK	
AT^HTTPCMD=1,GET,"http://m2m.example.com:9001/n_index.txt"	Downloads the file from the HTTP server n_index.txt (In the following example, link ID is 1.

Command	Description
OK ^IPDATA: 1,5,hello123 ^IPSRVST: 1,12,200	

7.5 Downloading File Using "GET" Command in Buffer Mode

7.5.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"HTTP","m2m.example.com",9001	Creates the link.
OK	
AT^IPCFL=14,2	Sets data transmission mode to buffer transmission mode.
OK	
AT^HTTPCMD=1,GET,"http://m2m.example.com:9001/n_index.txt"	Downloads the file from the HTTP server n_index.txt (In the following example, link ID is 1)
OK	
^IPRCVST: 1,1	
AT^IPRCV=1,5	Receives the data stored in the buffer.
^IPRCV: 1, 5 Hello	
OK	

7.6 Uploading File Using "POST" Command in Transparent Mode

7.6.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^IPOPEN=1,"HTTP","m2m.example.com",9001	Creates the link.
OK	
AT^IPCFL=14,0	Sets data transmission mode to online mode.
OK	
AT^HTTPCMD=1,POST,"HTTP://m2m.example.com:448/cgi-bin/textarea.cgi",20,"text/plain"	Uploads the data using this command .If the upload has to be cancelled, then give +++ to terminate.
CONNECT textcontext=hello123 Enter 20 bytes of data <html><head><title>Text Area - Fifth CGI Program</title></head><body><h2>EnteredText Content is hello123</h2></body></html> OK ^IPSRVST: 1, 12,200	

7.7 Uploading File"POST" Command in Command Mode and Buffer Mode

There is no difference in HTTP POST operation of "Command and Buffer mode". In both the mode, AT^IPSENDEX is used to enter the data.

7.7.1 Reference Process

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	

Command	Description
AT^IPOPEN=1,"HTTP","m2m.example.com",9001	Creates the link.
OK	
AT^IPCFL=14,1	Sets data transmission mode to command mode.
OK	
AT^HTTPCMD=1,POST,"HTTP://m2m.example.com:448/cgi-bin/textarea.cgi",20,"text/plain"	Uploads the data content to the post script textarea.cgi .
OK	
AT^IPSEND=1,"textcontext=hello123"	Transmits the data through the link established (in this case, <link_id> is 1).
^IPSEND: 1 OK ^IPSRVST: 1,12,200	
AT^IPSENDEX=1,0,"textcontent=hello123"	Transmits the data through the link established in IPSENDEX Mode 0 (in this case, <link_id> is 1).
^IPSEND: 1 OK ^IPSRVST: 1,12,200	
AT^IPSENDEX =1,2,20,1 textcontext=hello123	Transmits the data through the link established in IPSENDEX Mode 2 (in this case, <link_id> is 1).
^IPSEND: 1 OK ^IPSRVST: 1,12,200	
AT^IPSENDEX=1,1,"74657874636F6E74656E743D68"	Transmits the data through the link established in IPSENDEX Mode 1 (in this case, <link_id> is 1)

Command	Description
^IPSEND: 1 OK ^IPSRVST: 1,12,200	
AT^IPCLOSE=1	Closes the link.
OK	



NOTE

The <textcontent> specifies the corresponding field in the POST Script.

7.7.2 Troubleshooting

Scenario	Possible Error Information	Solution
Close the specified link. AT^IPCLOSE=<link_id>	+CME ERROR: Normal error	The command is terminated. Run the AT^IPCLOSE command again.
Create the link. AT^IPOPEN=1,"HTTP", "m2m.example.com",9001	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Run AT^IPCLOSE to close the corresponding link. Alternatively, change the link ID and send the command to create the link.
	+CME ERROR: Fail to bind the specified port	Change the local port number, or leave the local port number blank.
Query link information. AT^IPOPEN?	OK	No link information is available. Create a link, or accept the link as a server, and then query the link information again.
AT^HTTPCMD=?	^HTTPCMD: (1-5),("GET","POST")	Get the current HTTP command
AT^HTTPCMD=1,GET,"http://m2m.example.com:9001/n_index.html"	+CME ERROR: The link has not been established yet	Run AT^IPOPEN to open the link and then perform the download operation.

Scenario	Possible Error Information	Solution
AT^HTTPCMD=1,POST, "http://m2m.example.com: 9001/cgi-bin/textarea.cgi", 20,"text/index.html"	+CME ERROR: The link has not been established yet	Run AT^IPOPEN to open the link and then perform the upload operation.

7.8 HTTP Error Codes

<state code>	<state code> representative's meaning
200	Operation successful
301	Moved permanently
302	Moved temporarily
401	Requested action requires authorization
403	Forbidden
404	Resource not found
405	Method not allowed on resource
406	Requested representation not accepted
408	Request timed out
410	Requested source is no longer available server
500	Internal server error
501	Requested HTTP operation not supported
505	HTTP version not supported

8 Internal Protocol Stack Application Scenarios-SMTP

8.1 Creating an SMTP Server Link

8.1.1 Reference Process

Command	Description
<code>AT^IPOPEN=1,"smtp","192.168.63.41",25,"m2mtest@m2m.example.com","M2m"</code>	An SMTP user is successfully logged in SMTP.
<code>OK</code>	
<code>^IPSRVST: 1,13,235</code>	

NOTE

- Only one SMTP service can be enabled at a time.
- Before an SMTP service is enabled, Internet configuration and SMTP configuration must be completed.
- Please use SMTPS because SMTPS have a stronger security level than SMTP.

8.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create the link. <code>AT^IPOPEN=1,"smtp","192.168.63.41",25,"m2mtest@m2m.example.com","M2m"</code>	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Try to open an already established link.

8.2 Sending Mail Through "emsend" Without Attachment

8.2.1 Reference Process

Command	Description
AT^IPOPEN=1,"smtp","192.168.63.41",25,"m2mtest@m2m.example.com","M2m"	Creates the link.
OK ^IPSRVST: 1,13,235	
AT^EMSEND=1,"m2mtest@m2m.example.com","test with attachment","utf-8",0	Sends mail without attachment.
> <ENTER THE BODY OF THE MAIL> <Press Ctrl+Z to end input> OK ^IPSRVST: 1,14,250	

8.3 Sending Mail Through "emsend" with Attachment Using 7 bit

8.3.1 Reference Process

Command	Description
AT^IPOPEN=1,"smtp","192.168.63.41",25,"m2mtest@m2m.example.com","M2m"	Creates the link.
OK ^IPSRVST: 1,13,235	
AT^EMSEND=1,"m2mtest@m2m.example.com","test with attachment","utf-8",1,"test.txt"	Sends mail with attachment

Command	Description
<p>> <ENTER THE BODY OF THE MAIL> <Press Ctrl+Z to end input></p> <p>OK</p> <p>^IPSRVST: 1,14,250</p>	
<p>AT^IPSENDEX=1,2,1500,0</p>	<p>It can send maximum 1500 data at a time. The last parameter i.e. <eof> can be 0 and 1, where 0 means user can send more data and 1 means the last data to be send. The Following is an example on how to send 3000 bytes of attachment.</p>
<p>^IPSENDEX: 1</p> <p>OK</p>	
<p>AT^IPSENDEX=1,2,1000,0</p>	<p>Here user has to send 1000 bytes of data. The last parameter is 0, which means not end of file.</p>
<p>^IPSENDEX: 1</p> <p>OK</p>	
<p>AT^IPSENDEX=1,2,500,1</p>	<p>Here user has to send 500 bytes of data. The last parameter is 1, which means end of file.</p>
<p>^IPSENDEX: 1</p> <p>OK</p> <p>^IPSRVST: 1,14,250</p>	

8.4 Sending Mail Through "emsend" with Attachment Using base 64

8.4.1 Reference Process

Command	Description
AT^IPOPEN=1,"smtp","192.168.63.41",25,"m2mtest@m2m.example.com","M2m"	Creates the link.
OK ^IPSRVST: 1,13,235	
AT^EMSEND=1,"m2mtest@m2m.example.com","test with attachment","utf-8",2,"jpgtest.jpg"	Sends mail with attachment using base 64 algorithm.
> <ENTER THE BODY OF THE MAIL> <Press Ctrl+Z to send> OK ^IPSRVST: 1,14,250	
AT^IPSENDEX=1,2, 4,1	It can send maximum 1500 data at a time. The last parameter i.e. <eof> can be 0 and 1, where 0 means user can send more data and 1 means the last data to be send.
^IPSENDEX: 1 OK ^IPSRVST: 1,14,250	
AT^IPCLOSE=1	Closes the link.
OK	

8.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Close the specified link. <code>AT^IPCLOSE=<link_id></code>	+CME ERROR: Normal error	The command is terminated. Run the <code>AT^IPCLOSE</code> command again.
Create the link. <code>AT^IPOPEN=1,"smtp","192.168.63.41",25,, "m2mtest@m2m.example.com", "M2m"</code>	+CME ERROR: The network has not been opened yet	Initialize the internal protocol stack before sending the command to create the link.
	+CME ERROR: The link has been established already	Run <code>AT^IPCLOSE</code> to close the corresponding link. Alternatively, change the link ID and send the command to create the link.
	+CME ERROR: Fail to bind the specified port	Change the local port number, or leave the local port number blank.
Query link information. <code>AT^IPOPEN?</code>	OK	No link information is available. Create a link, or accept the link as a server, and then query the link information again.
<code>AT^SMTPCMD=?</code>	^HTTPCMD: (1-5),("GET","POS")	Get the current HTTP command.
<code>AT^EMSEND=1,"m2mtest@m2m.example.com", "test with attachment", "utf-8",2,"test.txt"</code>	+CME ERROR: The link has not been established yet	Run <code>AT^IPOPEN</code> to open the link and then perform the download operation.

8.5 SMTP Error Codes

<state code>	<state code> representative's meaning
235	Authentication successful
250	Its typical side message is "Requested mail action okay completed": meaning that the server has transmitted a message.
354	The side message can be very cryptic ("Start mail input end <CRLF>.<CRLF>"). It's the typical response to the DATA command.
421	The service is unavailable due to a connection problem: it may refer to an exceeded limit of simultaneous connections, or a more general temporary problem.

<state code>	<state code> representative's meaning
450	"Requested action not taken - The user's mailbox is unavailable". The mailbox has been corrupted or placed on an offline server, or your email hasn't been accepted for IP problems or blacklisting.
451	"Requested action aborted - Local error in processing". Your ISP's server or the server that got a first relay from yours has encountered a connection problem.
452	Too many emails sent or too many recipients: more in general, a server storage limit exceeded.
500	A syntax error: the server couldn't recognize the command.
501	Another syntax error, not in the command but in its parameters or arguments.
502	The command is not implemented.
503	The server has encountered a bad sequence of commands, or it requires an authentication.
504	A command parameter is not implemented.
535	Authentication failure
550	It usually defines a non-existent email address on the remote side.
551	"User not local or invalid address - Relay denied". Meaning, if both your address and the recipient's are not locally hosted by the server, a relay can be interrupted.
552	"Requested mail actions aborted - Exceeded storage allocation": simply put, the recipient's mailbox has exceeded its limits.
553	"Requested action not taken - Mailbox name invalid". That is, there's an incorrect email address into the recipients line.
554	This means that the transaction has failed. It's a permanent error and the server will not try to send the message again.
555	Syntax error

9 Internal Protocol Stack Application Scenarios-FTPS/HTTPS/SMTPS

9.1 Creating a Secure Control Link

9.1.1 Preliminary Operations

Before initializing a secure socket and transmitting data over the secure channel, certain preliminary operations need to be performed which are mentioned below.

9.1.2 IP Configuration

SSL requires IP configurations to be done to access the secure server over which data can be transmitted

- To Configure APN

Run:	AT+CGDCONT=1,"IP","example.com"
Response:	OK

- To check the APN settings

Run:	AT+CGDCONT?
Response:	+CGDCONT: 1,"IP","example.com",,"",0,0 OK

- To get the Signal Strength

Run:	AT+CSQ	
Response:	+CSQ: 28,99 OK	31 is the strongest, 0 is the weakest, and 99 for none.

- To get the registered network

Run:	AT+ COPS?
Response:	+COPS: 0,0,"Terminal MHA Net",2 OK

9.1.3 SSL and TLS

SSL and TLS are cryptographic protocols used over the Internet to provide secure data communication in client server architecture.

9.1.4 Certificates

The SSL module allows the storage of a server certificate. It is assumed that licensed version of SSL contains certificates that will be unique for each device.

9.2 Configuring SSL

9.2.1 Reference Process

FTPS

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables a secure socket.
OK	
AT^SSLCFG=1,30,0,1	Configures the properties of a secure socket.
OK	
AT^IPOPEN=1,"FTPS","192.168.63.41", ,990,,"username","password"	Creates a secure FTP control link, an FTP user is successfully logged in FTP server.
OK	
^IPSRVST:1,10,230	



NOTE

GET and PUT operations are the same as in normal FTP.

HTTPS

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables a secure socket.
OK	
AT^SSLCFG=1,30,0,1	Configures the properties of a secure socket.
OK	
AT^IPOPEN=1,"HTTPS","m2m.example.com",448	Creates a secure HTTP server link, an HTTP user is successfully logged in HTTP server.
OK	



NOTE

GET and POST operations are the same as in normal HTTP

SMTPS

Command	Description
AT^IPINIT="example.com"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables a secure socket.
OK	
AT^SSLCFG=1,30,0,1	Configures the properties of a secure socket.
OK	
AT^IPOPEN=1,"smtps","192.168.63.41",25,,,"m2mtest@m2m.example.com","M2m"	Creates a secure SMTP server link, an SMTP user is successfully logged in SMTP server.
OK	
^IPSRVST: 1,13,235	



NOTE

Sending emails (EMSEND) operation is the same as in normal SMTP.

10 SSL Application Scenarios

10.1 Initializing Secure Services

10.1.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	In this example provided in the left column, the APN is 1234 , and the user name and password are both card .
OK	
AT^SSLEN=1,1,1	Enables SSL
OK	
AT^SSLEN?	Queries SSL enable status and obtained IP.
^SSLEN: 1,1,1,"192.168.200.1"	
OK	
AT^SSLEN=1,0	Disables SSL
OK	
AT^SSLEN?	
^SSLEN: 1,0,1,"0.0.0.0"	
OK	

10.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Disabling SSL AT^SSLEN=0,0	+CME ERROR: Invalid Operation	AT^SSLEN? queries the SSL secure/normal socket enable status. If secure socket is enabled, it is invalid to disable normal socket and vice versa.
Enabling SSL AT^SSLEN=1,1	+CME ERROR: Socket not enabled	Initialization has not been performed. Initialize the internal protocol stack and enable SSL.
	+CME ERROR: Socket already enabled	AT^SSLEN? queries the SSL enable status. If SSL has been enabled, it does not need to be enabled again.

10.2 Configuring SSL

10.2.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL.
OK	
AT^SSLCFG=1,60,0,1	Configures the timeout for TX and RX, cipher suites to be sent and authentication mode.
OK	
AT^SSLCFG?	Queries SSL configurations.
^SSLCFG: 1,10,1,0	
OK	

 **NOTE**

TLS_RSA_WITH_NULL_SHA and TLS_RSA_WITH_NULL_SHA256 have low safety coefficient. It is recommended you choose other encryption algorithms. For details, please see HUAWEI ME909s Series LTE Module AT Command Interface Specification.

10.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create a client link AT^SSLCFG=1,60,0,1	+CME ERROR: Invalid Operation	Initialize the internal protocol stack and enable SSL in secure mode before configuring the secure socket link.
	+CME ERROR: Invalid Operation	It is not possible to configure the socket after opening.

10.3 Managing Certificate/Key

10.3.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL
OK	
AT^SSLMNG=1,1,0,"ca-crt.pem",1,1,"LS0tLS1CRUdJTiBDRVJUSUZJQ0FURS0tLS0tDQotLS0tLUVORCBDRVJUSUZJQ0FURS0tLS0t"	Stores a certificate/key in the file system
OK	
AT^SSLMNG=1,1,2,"ca-crt.pem"	Loads a certificate/key in to library
OK	
AT^SSLMNG=1,1,1,"ca-crt.pem"	Deletes a certificate/key from the file system.
OK	
AT^SSLMNG?	Queries the last SSLMNG operation performed and gives list of certificates present in the file system.

Command	Description
^SSLMNG: 1,ca-crt.pem 0,client-crt.pem 2,client-key.pem 1,2,"ca-crt.pem",2,3 OK	



NOTE

- If more than one client and key certificates are available in the file system, then users need to load the corresponding certificate by using **AT^SSLMNG** command with the <action> as 2 (read data) to succeed the hand shake during socket open.
- **AT^SSLMNG** for action 0 (store data) can store a maximum of 10 certificates (10 each for ca-cert, client cert and client key) in file system beyond which it would display error "Certificate maximum limit reached".
- **AT^SSLMNG** for action 2 (read data) can load a maximum of 10 certificates from buffer/file system during a particular session beyond which it would display error "Certificate maximum limit reached".
- **AT^SSLMNG** query command would display first 10 certificates stored in file system for each type (CA, Client, Private Key) of certificates.
- Usage of <password> parameter is applicable in case of "Load" of "Private Key" during client authentication and it is required to set the password if the private key is encrypted. So this password parameter is an optional parameter.
- If SSL is enabled in ASCII data mode then the buffer should be 1024 bytes of raw data.
- <password> is applicable only if <action> is 2 and when loading the private key with password
- It is not required to give the password in every package, but the last package must contain the correct password.

10.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Manage a certificate AT^SSLMNG=1,1,2,"ca-crt.pem"	+CME ERROR: Invalid Operation	Initialize the internal protocol stack and enable SSL in secure mode.
AT^SSLMNG?	^SSLMNG: OK	After device reset or before any SSLMNG operation is done, if no certificates are present in the file system.

10.4 Creating SSL Links

10.4.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL.
OK	
AT^SSLO=1,"192.168.63.41",9900,1,60	Uses a specified IP address to connect to the remote server and establish a SSL link. For the method to create normal link, refer to the AT command document.
OK	
AT^SSLO=1,"example.com",9900,0,60	Uses a specified domain name to connect to the remote server and establish a SSL link.
OK	
AT^SSLO?	Queries link information.
^SSLO: 1,"192.168.63.41",9900,1,60	
OK	

10.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create a client link AT^SSLO=1,"192.168.63.41",9900,1,60	+CME ERROR: Socket not enabled	Initialize the internal protocol stack and enable SSL before sending the command to create the link.
	+CME ERROR: Socket already connected	Run AT^SSLC to close the current link.
	+CME ERROR: Invalid Operation	Open the connection with the same SSL id used in AT^SSLEN , or disable SSL and enable with the required SSL id.

10.5 Querying SSL Status

10.5.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL.
OK	
AT^SSLO=1,"192.168.63.41",9900,1,60	Creates a secure socket link
OK	
AT^SSLSTAT=1	Queries connections status of secure/normal socket
^SSLSTAT: Secure connection opened	
OK	

10.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
Create a client link AT^SSLO=1,"192.168.63.41",9900,1,60	+CME ERROR: Invalid Operation	Initialize the internal protocol stack and enable SSL before sending the command to create the link.
	+CME ERROR: Invalid Operation	Query the connection status with the same SSL id used in SSLEN, or disable SSL and enable with the required SSL id.

10.6 Sending Data

10.6.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.

Command	Description
OK	
AT^SSLEN=1,1,1	Enables SSL in base64 encoded data mode.
OK	
AT^SSLO=1,"192.168.63.41",9900,1,60	Creates a secure socket link in asynchronous mode
OK	
AT^SSLTX=1,"aGVsbG8=" ,60	Sends data. In this example, base64 encode data of "hello" i.e. "aGVsbG8=" is sent.
OK ^SSLRX: 5 aGVsbG8=	Data is successfully sent and received.
AT^SSLTX=1,"aGVsbG8=" ,60	Sends data in synchronous mode
OK	

 NOTE

- If SSL is enabled in base64 encoded data mode then the buffer should be 768 bytes of raw data.
- If SSL is enabled in ASCII data mode then the buffer should be 1024 bytes of raw data.

10.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
Send data AT^SSLTX=1,"aGVsbG8=" ,60	+CME ERROR: Invalid Operation	Before sending data, initialize the protocol stack and enable SSL.
	+CME ERROR: Socket not connected	Before sending data, create a secure/normal socket link.
	+CME ERROR: Invalid Operation	Send data with the same SSL id used in SSLEN, or disable SSL and enable with the required SSL id.

10.7 Receiving Data

10.7.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL in base64 encoded data mode
OK	
AT^SSLO=1,"192.168.63.41",9900,1,60	Creates a secure socket link in asynchronous mode
OK	
AT^SSLTX=1,"aGVsbG8=",60	Sends data. In this example, base64 encode data of "hello" i.e. "aGVsbG8=" is sent.
OK	Data is successfully sent and received.
^SSLRX: 5 aGVsbG8=	
AT^SSLTX=1,"aGVsbG8=",60	Sends data in synchronous mode
OK	
AT^SSLRX=1,10,60	Receives data in synchronous mode
^SSLRX: 5 aGVsbG8=	
OK	



NOTE

If SSL is enabled in base64 encoded data mode then the length of the received data will differ from displayed received data length, because the received data is in base64 encoded format.

10.7.2 Troubleshooting

Scenario	Possible Error Information	Solution
Send data AT^SSLRX=1,1024,60	+CME ERROR: Invalid Operation	Before receiving data, initialize the protocol stack and enable SSL.
	+CME ERROR: Socket not connected	Before receiving data, create a secure/normal socket link.

Scenario	Possible Error Information	Solution
	+CME ERROR: Invalid Operation	Receive data with the same SSL id used in SSLEN, or disable SSL and enable with the required SSL id.
	+CME ERROR: Invalid Operation	If socket has been opened in asynchronous mode, SSLRX command is not allowed. Open socket in synchronous mode and receive data.

10.8 Closing SSL

10.8.1 Reference Process

Command	Description
AT^IPINIT="1234","card","card"	Initializes the internal protocol stack.
OK	
AT^SSLEN=1,1,1	Enables SSL in base64 encoded data mode
OK	
AT^SSLO=1,"192.168.63.41",9900,1,60	Creates a secure socket link
OK	
AT^SSLC=1	Closes the link
OK	

10.8.2 Troubleshooting

Scenario	Possible Error Information	Solution
Closing socket AT^SSLC=1	+CME ERROR: Invalid Operation	Before closing the socket, initialize the protocol stack and enable SSL.
	+CME ERROR: Socket not connected	Before closing the socket, create a secure/normal socket link.
	+CME ERROR: Invalid Operation	Close the socket with the same SSL id used in SSLO.

11 ECM Application Scenarios

11.1 Dialing ECM

11.1.1 Reference Process

Command	Description
AT^NDISDUP=?	Checks the parameter range supported by the command.
^NDISDUP: (1-11),(0-1) OK	
AT^NDISDUP=1,1,"1234"	Sets up a dial-up connection using the APN provided by the network server. "1234" is an example.
OK	The command is successfully executed.
^NDISSTAT: 1,,,"IPV4"	Reports the dial-up connection state.
AT^NDISDUP=1,1,"4321","huawei","huawei",1	Sets up a dial-up connection using the account, password, and authentication mode provided by the network server.
OK	The command is successfully executed.
^NDISSTAT: 1,,,"IPV4"	Reports the dial-up connection state.
AT^NDISDUP=2,1,"1111"	Sets up the second dial-up connection using the APN provided by the network server. "1111" is an example which is different from "1234".
OK	The command is successfully executed.
^NDISSTAT: 1,,,"IPV4"	Reports the dial-up connection state.

Command	Description
AT^NDISDUP=2,1,"4321","huawei","huawei",1	Sets up the second dial-up connection using the account, password, and authentication mode provided by the network server.
OK	The command is successfully executed.
^NDISSTAT: 1,,,"IPV4"	Reports the dial-up connection state.

The process of obtaining the IP address:

1. After the dial-up is successful, the module will establish the DHCP service automatically.
2. The PC driver will get the dial-up state and send <net_ready> state to the network manage.
3. The network manager sends the DHCP service discover.
4. The module responses the service discover, and then sends the IP and DNS address which is obtained from the PDP active process to the network managing device.

11.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
AT^NDISDUP=1,1,"1234"	+CME ERROR: 10 +CME ERROR: SIM not inserted	No SIM card is detected. Insert a SIM card.
AT^NDISDUP=1,1,"4321","huawei","huawei",1	OK ^NDISSTAT: 0,29,,,"IPV4"	NDISEND indicates the failure reason during the dial-up. 29 indicates that the authenticated information is not correct.
AT^NDISDUP=1,1,"abcd"	OK ^NDISSTAT: 0,33,,,"IPV4"	NDISEND indicates the failure reason during the dial-up. 33 indicates that request service is not subscribed. In this case, the network don not support this APN "abcd".

11.2 Querying the Dial-up Connection State

11.2.1 Reference Process

Command	Description
AT^NDISSTATQRY=1	Queries the first dial-up connection state.
^NDISSTATQRY: 0,,,"IPV4" OK	Reports the connection is not set up.
^NDISSTATQRY: 1,,,"IPV4" OK	Reports the connection is set up.
AT^NDISSTATQRY=2	Queries the second dial-up connection state.
^NDISSTATQRY: 0,,,"IPV4" OK	Reports the connection is not set up
^NDISSTATQRY: 1,,,"IPV4" OK	Reports the connection is set up.

11.2.2 Troubleshooting

None

11.3 Disconnecting the Dial-up Connection

11.3.1 Reference Process

Command	Description
AT^NDISDUP=1,0	Disconnects the first dial-up connection.
AT^NDISDUP=2,0	Disconnects the second dial-up connection.
OK	The command is successfully executed.
^NDISSTAT: 0,0,,,"IPV4"	IPv4 changes from the connected state to the disconnected state.



11.3.2 Troubleshooting

None

12 Voice and Supplementary Service Application Scenarios

12.1 Pre-configuration

12.1.1 Reference Process

Command	Description
AT^CPCM=0,0,0,0,0 or AT^CPCM=2,0,0,0,0	Sets the PCM voice channel as the master mode. Sets the PCM voice channel as the slave mode. (Only the MASTER_PRIM mode and the SLAVE mode are supported.)
OK	
AT^SMUT=0	Unmutes the receive channel.
OK	

12.2 Voice Call Handling

12.2.1 Reference Process

Command	Description
ATD13912345678;	User 1 makes a voice call to 13912345678.

Command	Description
OK ^ORIG: 1,0 ^CONF: 1 RING	User 1 presents the ^ORIG indication. User 2 receives the indication.
ATA	User 2 answers the call.
OK ^CONN: 1,0 ^CONN: 1,0	User 2 presents the ^CONN indication. User 1 presents the ^CONN indication.
AT+CHUP	User 1 hangs up
OK ^CEND: 1,6,29,16 (User 2) ^CEND: 1,6,104,16	User 1 presents ^CEND to indicate that it has ended the call. User 2 presents ^CEND to indicate that it has ended the call.

12.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND .	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.

12.3 DTMF Application

12.3.1 Reference Process

Command	Description
ATD10086;	The user dials 10086.
OK	
^ORIG: 1,0	
^CONF: 1	
^CONN: 1,0	Indicates that the call is connected.
AT+VTS=1	Following the voice instructions, sends a DTMF tone to select option 1 to enter the sub-option of querying the local area to which the module belongs.
OK	
AT+VTS=3	Sends a DTMF tone to select option 3.
OK	
AT+CHUP	The user hangs up.
OK	
^CEND: 1,6,29,16	Indicates that user ends the call.

12.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND .	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.

12.4 ID Presentation

12.4.1 Reference Process

- Caller ID presentation:

Command	Description
AT+CLIP=1	User 1 enables the calling line identification presentation (CLIP) indication.
OK	
AT+CLIP?	User 1 queries the CLIP indication.
+CLIP: 1,1	
OK	
ATD13903710616;	User 2 calls user 1 whose number is 13903710616.
OK	
^ORIG: 1,0	User 2 presents the ^ORIG indication.
^CONF: 1	User 2 presents the ^CONF indication.
(User 1)	User 1 presents the +CLIP indication.
RING	
+CLIP: "+8613903702766",1 45,,0	User 1 presents the +CLIP indication every 5 seconds. User 2's number is 13903702766.
...	

 **NOTE**

All the previous actions can be performed only when user 1 has subscribed to CLIP.

- Caller ID presentation restriction:

Command	Description
AT+CLIP=1	User 1 enables the CLIP indication.
OK	
AT+CLIR?	User 2 queries the calling line identification restriction (CLIR).
+CLIR: 0,1	User 2 subscribes to permanent CLIR.
OK	
ATD13903710616;	User 2 calls user 1 whose number is 13903710616.

Command	Description
OK	
^ORIG: 1,0	User 2 presents the ^ORIG indication.
^CONF: 1	User 2 presents the ^CONF indication.
(User 1)	User 1 presents the +CLIP indication.
RING	User 1 presents the +CLIP indication every 5 seconds.
+CLIP: "",128,,,1	

 **NOTE**

All the previous actions can be performed only when user 1 has subscribed to CLIP and user 2 has subscribed to permanent CLIR.

Command	Description
AT+CLIP=1	User 1 enables the CLIP indication.
OK	
AT+CLIR=2	User 2 has subscribed to CLIR.
OK	
AT+CLIR?	User 2 queries the CLIR.
+CLIR: 2,4	
OK	
ATD13903710616;	User 2 calls user 1 whose number is 13903710616.
OK	
^ORIG: 1,0	User 2 presents the ^ORIG indication.
^CONF: 1	User 2 presents the ^CONF indication.
(User 1)	User 1 presents the +CLIP indication.
RING	
+CLIP: "+8613903702766",145,,,0	User 1 presents the +CLIP indication every 5 seconds. User 2's number is 13903702766.

12.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND.	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.

12.5 Call Forwarding

12.5.1 Reference Process

Command	Description
AT+CCFC=0,3,"13903710453",129,1	User 1 subscribes to the service of forwarding all calls to user 3 whose number is 13903710453.
OK	
AT+CCFC=0,2	User 1 queries the CCFC status.
+CCFC: 1,1,"+8613903710453",145,,,	
OK	
ATD13903702766;	User 2 calls user 1 whose number is 13903702766.
OK	
(User 3) RING	Instead of user 1, user 3 presents the ring indication.

 **NOTE**

The previous actions are based on call forwarding without any restrictions. Those actions can be performed only after the user has subscribed to the call forwarding service.

Command	Description
AT+CCFC=1,3,"13903710453",129,1	User 1 subscribes to the service of forwarding busy calls to user 3 whose number is 13903710453.
OK	

Command	Description
AT+CCFC=0,2	User 1 queries the CCFC status.
+CCFC: 1,1,"+8613903710453",145,,, OK	
(User 1) ATD13903711234;	User 1 calls user 4 (13903711234), and user 4 answers the call.
OK ^ORIG: 1,0 ^CONF: 1 ^CONN: 1,0	
(User 2) ATD13903702766;	User 2 calls user 1
OK ^ORIG: 1,0 ^CONF: 1	
(User 3) RING	Forwards the call when busy. User 3 presents the Ring indication, while user 1 presents no indications.



NOTE

The previous actions are based on call forwarding without any restrictions. Those actions can be performed only after the user has subscribed to the call forwarding service.

12.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND .	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.
The user has not subscribed to the call forwarding service.	Network reject	Subscribe to the call forwarding service.

12.6 Call Waiting

12.6.1 Reference Process

Command	Description
AT+CCWA=1,1,1	The User 1 activates the call waiting function and enables the +CCWA indication.
OK	
(User 1) ATD13903702766;	The User 1 calls User 2.
OK	
(User 2) ATA	The User 2 answers the call.
OK	
^CONN: 1,0	The User 2 presents ^CONN: 1,0.
(User 1) ^CONN: 1,0	Then User 1 presents ^CONN: 1,0.
(User 1) AT+CHLD=2	The User 1 maintains the call between the convener and User 2.
OK	
(User 1) ATD13903710453;	The User 1 calls User 3.
OK	
(User 3) ATA	The User 3 answers the call.
OK	
^CONN: 1,0	The User 3 presents ^CONN: 1,0.
(User 1) ^CONN: 2,0	Then User 1 presents ^CONN: 2,0.
(User 1) AT+CLCC	The User 1 queries the call status.

Command	Description
+CLCC: 1,0,1,0,0,"13903702766",129 +CLCC: 2,0,0,0,0,"13903710453",129	
OK	



NOTE

- The previous actions are based on call hold without any restrictions. Those actions can be performed only after the user has subscribed to the call hold service.
- User 1 number: 13903710616.
- User 2 number: 13903702766.
- User 3 number: 13903710453.

12.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND.	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.
The user has not subscribed to the call waiting or call holding service.	+CME ERROR: network rejected request	Subscribe to the required service.

12.7 Call Restriction

12.7.1 Reference Process

Command	Description
AT+CPWD="AO","0000","1111"	Modifies the call restriction password.
OK	
(User 1) AT+CLCK="AO",1,"1111",1	User 1 activates the barring of all outgoing calls (BAOC) service.
OK	
(User 1) AT+CLCK="AO",2	User 1 queries the BAO service.

Command	Description
+CLCK: 1,1 OK	The returned result indicates that the BAOC service has been activated.
(User 1) ATD13903710453;	User 1 calls user 2.
OK ^ORIG: 1,0 ^CONF: 1 ^CEND: 1,0,100,21	User 1 returns OK . User 1 presents the ^ORIG indication. User 2 presents no indication.
(User 1) AT+CLCK="AO",0,"1111",1	User 1 deactivates the BAOC service.
OK	
(User 1) ATD13903710453;	User 1 calls user 2.
OK ^ORIG: 1,0 ^CONF: 1 (User 2) RING	User 1 returns OK . User 1 presents the ^ORIG indication. User 1 presents the ^CONF indication. User 2 presents the ring indication.
(User 1) AT+CLCK="AI",1,"1111",1	User 1 activates BAIC service.
OK	
(User 1) AT+CLCK="AI",2	User 1 queries the BAIC service.
+CLCK: 1,1 OK	User 1 returns the response indicating that the BAIC service is deactivated.
(User 2) ATD13903710426;	User 2 calls user 1.

Command	Description
OK ^ORIG: 1,0 ^CONF: 1 ^CEND: 1,0,100,21	User 2 returns OK User 2 presents the ^ORIG indication. User 2 presents the ^CONF indication. User 2 presents the ^CEND indication. User 1 presents no indication.
(User 1) AT+CLCK="AI",0,"1111",1	User 1 deactivates the BAIC service.
OK	
(User 2) ATD13903710426;	User 2 calls user 1.
OK ^ORIG: 1,0 ^CONF: 1 (User 1) RING	User 2 returns OK User 2 presents the ^ORIG indication. User 2 presents the ^CONF indication. User 1 presents the ring indication.

 **NOTE**

- The user must subscribe to the call restriction service provided by the network operator. The right to use the call restriction service can be guaranteed or canceled by the operator only.
- User 1 number: 13903710426.
- User 2 number: 13903710453.

12.7.2 Troubleshooting

Scenario	Possible Error Information	Solution
Make a voice call when no network is found.	Presents ^CEND .	Make the call after the network is found.
The PIN is not authenticated.	+CME ERROR: SIM PIN required	Enter the correct PIN.

12.8 Debug the Audio Quality

12.8.1 Reference Process

Command	Description
AT+CMIC=5	Sets the microphone gain to 5.
OK	
AT+CLVL=5	Sets the speaker gain to 5.
OK	
AT^NSSWITCH=1	Enables noise suppression.
OK	
AT^STN=1	Enables sidetone.
OK	
AT^ECHOEX=1,320,0,86,4096	Enables echo suppression.
OK	
AT^PCMFR="010001000D004800C2FF F3FEC1FFB6FF2DFEE9FC20F931FC3 DFACBE8CE0FFF7F000000000000000 00000000000000000000000000000000 001000000D001C00A0FF83FF6400AAF FD6F999FBB400A9FB1EE2DFEA2A2B FF7F0000000000000000000000000000 00000000000000000000"	Sets frequency response.
OK	

NOTE

- Make sure the modem's microphone and speaker gains are appropriate. If the gain is too small, the volume will be low. If the gain is too large, saturated distortion will occur. To adjust the uplink and downlink gains, both the codec's and modem's gains must be set.
- It is recommended that noise suppression be enabled.
- Sidetone is the playback of what's input by the modem's microphone through the modem's speaker. It is recommended that sidetone be enabled in headset mode and disabled in handsfree mode.
- It is recommended that echo suppression be enabled. (By default, the modem provides better echo suppression in handsfree mode than in headset mode.)
- If the uplink or downlink voice tone is distorted, use input and output devices and codec to run **AT^PCMFR** to adjust the modem's frequency response settings.



12.8.2 Troubleshooting

Scenario	Possible Error Information	Solution
AT^NSSWITCH, AT^STN, AT^ECHOEX, and AT^PCMFR failed to be set.	Presents Error.	The setting is available only when the modem is not in a call.

13 Text Message Application Scenarios

13.1 Pre-configuration

13.1.1 Reference Process

Command	Description
AT+CPMS=?	Queries the types of supported storage.
+CPMS: ("SM"),("SM"),("SM") OK	
AT+CPMS="SM","SM","SM"	For details about the parameters, refer to HUAWEI ME909s Series LTE Module AT Command Interface Specification . It is recommended to keep the three types of storage consistent.
+CPMS: 3,40,3,40,3,40 OK	
AT+CPMS?	Queries the current storage type, used storage space and maximum storage capacity.
+CPMS: "SM",3,40,"SM",3,40,"SM",3,40 OK	

13.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one	+CME ERROR: SIM PIN required	Enter the correct PIN.

Scenario	Possible Error Information	Solution
of the previous commands.	+CMS ERROR: 500	SIM card initialization has not completed. Try again later.
	ERROR	Unsupported storage.

13.2 Sending English Text Messages in PDU Format

13.2.1 Reference Process

Command	Description
AT+CMGF=0	Sets the message format to PDU format. (For details about the structure of a PDU packet, refer to the 3GPP TS 23.040)
OK	
AT+CMGS=21 >0891683108608805F911000B8131097 30137F1000FF07EDF27C1E3E9701 \0x1A	Sends a text message using PDU of 21 bytes in length (excluding the service center number 0891683108608805F9). The message content is "message". Presses ctrl+z (0x1A) to stop entering message content and send the message.
+CMGS: 4 OK	The message is successfully sent. <TP-MR> is returned. For details about <TP-MR>, refer to the 3GPP TS 23040.
AT+CMGS=10 >0891683108608805F911000B8131097 30137F10008FF0677ED6D88606F \0x1A	Sends a text message using PDU of 20 bytes in length (excluding the service center number 0891683108608805F9). The message content is "短消息". Presses ctrl+z (0x1A) to stop entering message content and send the message.
+CMGS: 5 OK	The message is successfully sent.

13.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	+CMS ERROR: 500	The text message cannot be sent because of network errors, incorrect service center number, or other errors. Resend the message.
	+CMS ERROR: 304	Incorrect PDU packet content.

13.3 Sending Chinese Character Text Messages in Text Format

13.3.1 Reference Process

Command	Description
AT+CMGF=1	Sets the message format to Text format.
OK	
AT+CSMP=,,0,8	Sets the data coding scheme to UCS2.
OK	
AT+CSCA="8613800688509",145	Sets the service center number.
OK	
AT+CSCS="UCS2"	Sets the TE's character set to UCS2 encoding.
OK	
AT+CMGS="00310033003300310032003300340035003600370038" > 534E4E3A \0x1A	Sends the message to the destination address "13312345678" that must be enclosed in double quotation marks. The message content is the UCS2 codes for the Chinese characters "华为". Presses ctrl+z (0x1A) to stop entering message content and send the message.
+CMGS: 6	The message is successfully sent.
OK	
AT+CSMP=,,0,0	Sets the data coding scheme to GSM 7bit.

Command	Description
OK	
AT+CSCS="GSM"	Sets the TE's character set to GSM 7bit encoding.
OK	
AT+CMGS="13312345678" >huawei \0x1A	Sends the message to the destination address "13312345678" that must be enclosed in double quotation marks. The message content is the GSM 7bit codes for the "huawei". Presses ctrl+z (0x1A) to stop entering message content and send the message.
+CMGS: 7 OK	The message is successfully sent.

13.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	+CMS ERROR: 305	The message content does not comply with the encoding scheme specified by AT+CSMP.
	+CMS ERROR: INVALID TXT Param	The message content specified by AT+CMGS is invalid.

13.4 Receiving Text Messages

13.4.1 Reference Process

Command	Description
AT+CNMI=2,1,0,0,0	Stores the message on the SIM card or ME, and presents the new message indication.
OK +CMTI: "SM",4	Presents the storage and location without solicitation.



Command	Description
AT+CNMI=1,2,0,0,0	Receives and directly presents the message instead of storing it.
OK +CMT: "+8613312345678",,"12/05/05,18:10:36+00" huawei ^SMMEMFULL: "SM"	Directly presents the message instead of storing it. In this example, the message is in Text mode. In PDU mode, PDU packets are presented. Presents an indication, without solicitation, when the message storage is full.
AT+CMGR=4	Reads the message stored in index 4.
+CMGR: "REC UNREAD","+8613312345678",,"12/05/17,16:13:08+00" huawei OK	
AT+CMGL="ALL"	In Text mode, lists all the messages in the current storage.
+CMGL: 2,"REC READ","+8613903710742",,"12/05/17,16:12:30+00" test1 +CMGL: 3,"REC READ","+8613903710742",,"12/05/17,16:13:08+00" test2 OK	
AT+CMGL=0	In PDU mode, lists all the received unread messages.
+CMGL: 1,0,,25 0891683108608805F9040D91683109730147F200002150716172350005F4F29C4E03 OK	
AT+CMGD=1	Deletes the messages stored in index 1.
OK	
AT+CMGD=1,4	Deletes all the messages in the current storage.
OK	

13.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	ERROR	In Text mode, run AT+CMGL=4 (number), or in PDU mode, run AT+CMGL="ALL" (string), and ERROR is returned.
	+CMS ERROR: 500	During SIM card initialization, run AT+CMGL or AT+CMGD to read or delete a message, and an error is returned.

13.5 Segmenting and Reassembling Long Text Messages

13.5.1 Segmenting

In PDU mode, text messages can be encoded using GSM 7-bit, 8-bit or UCS2. The GSM 7-bit encoding scheme is used to encode common ASCII characters, compressing every 8 characters into 7 characters. The GSM 8-bit encoding scheme is usually used to encode data such as pictures and ringtones. The UCS2 encoding scheme is used to encode Unicode characters. According to the existing 3GPP protocols, the size of the user data contained a PDU is 140 bytes. Therefore, the maximum number of characters contained in a single message is 160, 140 and 70 for the GSM 7-bit, 8-bit, and UCS2 encoding schemes respectively. If the number of characters contained in a text message exceeds the maximum number, the message will be segmented into several messages. An English letter, a Chinese character, or a byte of data is considered as a character.

According to the existing 3GPP protocols, after a long text message is segmented, the number of characters that each message segment can contain is as follows:

- GSM 7-bit encoding: 153 characters
- GSM 8-bit encoding: 134 characters
- UCS2 encoding: 67 characters

The number of available characters per segment is lower, because each segment must contain segmentation information.

The storage space occupied by a character is as follows:

- GSM 7-bit encoding: 7 bits
- GSM 8-bit encoding: 8 bits
- UCS2 encoding: 16 bits


The storage space occupied by a segment of a long text message is as follows:

- GSM 7-bit encoding: 153 bits x 7 = 1071 bits

- GSM 8-bit encoding: $134 \text{ bits} \times 8 = 1072 \text{ bits}$
- UCS2 encoding: $67 \text{ bits} \times 16 = 1072 \text{ bits}$

For all the three encoding schemes, a short message occupies a maximum of 1120 bits (160×7 , 140×8 , or 70×16) in the storage. If a text message's size is larger than 1120 bits, the message is a long message.

Figure 13-1 Relationships between character sets



Relationships between character sets

13.5.2 Reassembling

The host applications can reassemble the segments of a long text based on the following:

- The protocol header in the user data (TP-UD) of a PDU (see the 3GPP TS 23.040 9.2.3.24.1)
- The sender's number contained in each segment
- The interval between two segments' receiving time (The interval between the two neighboring segments' receiving time is less than 60 seconds, and the maximum interval between the first and the last segments' receiving time is 24 hours.)

14 Phonebook Application Scenarios

14.1 Memory Operations

14.1.1 Reference Process

Command	Description
AT+CPBS=?	Queries the current storage type.
+CPBS: ("SM","EN","ON") OK	
AT+CPBS="SM"	Sets the current storage type to "SM".
OK	
AT+CPBS?	
+CPBS: "SM",241,250 OK	241 indicates that 241 entries have been stored in the storage. 250 indicates that the maximum storage capacity of the current storage ("SM") is 250 entries.

14.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	+CME ERROR: SIM busy	Phonebook initialization has not completed. Try again later.
	+CME ERROR: SIM PIN required	Enter the correct PIN.
	+CME ERROR: SIM PUK required	Enter the correct PUK.

14.2 Setting the TE's Character Sets and Reading/Writing Phonebook Entries

14.2.1 Reference Process

Command	Description
AT+CSCS=?	Queries the character sets supported by the UE.
+CSCS: ("IRA","GSM","UCS2") OK	
AT+CSCS?	Queries the current character set.
+CSCS: "IRA" OK	
AT+CPBR=1	Reads the first phonebook entry. The TE character set is the International Reference Alphabet (IRA). The content of the first entry's name field is "HUAWEI".
+CPBR: 1,"0123456789",129,"HUAWEI" OK	
AT+CSCS="UCS2"	Sets the TE's character set to UCS2 alphabet.
OK	
AT+CPBW=1,"0123456789",129,"004800550041005700450049"	The character set is the UCS2 alphabet. The content of the phonebook entry's name field is 004800550041005700450049, which is "HUAWEI" in the IRA.
OK	
AT+CPBR=1	Reads the first phonebook entry. The TE character set is UCS2 alphabet. The content of the first entry's name field is 004800550041005700450049, which is "HUAWEI" in the IRA.
+CPBR: 1,"0123456789",129,"004800550041005700450049" OK	

Command	Description
AT+CPBR=<index1>,<index2>	Reads all entries stored in locations between index 1 and index 2 (including index 1 and index 2).
+CPBR: <index1>,<number>,<type>,<text> +CPBR: <index>,<number>,<type>,<text> +CPBR: <index2>,<number>,<type>,<text> OK	

14.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	+CME ERROR: SIM busy	Phonebook initialization has not completed. Try again later.
	+CME ERROR: SIM PIN required	Enter the correct PIN.
	+CME ERROR: SIM PUK required	Enter the correct PUK.
Error information is returned when writing an entry into the phonebook.	+CME ERROR: dial string too long	Check that the phone number is not too long.
Error information is returned in response to one of the previous commands.	+CME ERROR: invalid index	Check that the location index and phone number type are valid.
Error information is returned when writing an entry into the phonebook.	+CME ERROR: invalid characters in dial string	The phone number to be written into the phonebook contains invalid characters. Delete the invalid characters and try again.
Execute the following command after the storage is full. AT+CPBW=1,"0123456789",129,"004800550041005700450049"	+CME ERROR: memory full	The storage is full. Delete some entries and try again.
Error information is returned in response to one of the previous commands.	+CME ERROR: SIM busy	Phonebook initialization has not completed. Try again later.

Scenario	Possible Error Information	Solution
	+CME ERROR: SIM PIN required	Enter the correct PIN.
	+CME ERROR: SIM PUK required	Enter the correct PUK.
Read the specified phonebook entries in the current storage locations. AT+CPBR=<index1>	+CME ERROR: invalid index	The index is invalid. Check that index 1 is within the supported range.
Read the phonebook entries within the specified range in the current storage locations. AT+CPBR=<index1>,<index2>	+CME ERROR: invalid index	The index is invalid. Check that index 1 and index 2 are within the supported range and that index 1 is not greater than index 2.
No phonebook entries are found in the current storage locations. AT+CPBR=<index1>	+CME ERROR: not found	No entries are found in the storage locations in index 1. Check that there have been entries successfully written into these locations.
No phonebook entries within the specified range are found in the current storage locations. AT+CPBR=<index1>,<index2>	+CME ERROR: not found	No entries are found in the storage locations between index 1 and index 2. Check that there have been entries successfully written into these locations.

14.3 Querying User Number

14.3.1 Reference Process

Command	Description
AT+CPBS="ON"	
OK	
AT+CPBW=1,"+8613987654321",145,"CC"	Sets the subscriber number step1.
OK	
AT+CPBW=2,"123",129,"USER"	Sets the subscriber number step2.
OK	



Command	Description
AT+CNUM	Queries the subscriber number.
+CNUM: "CC","+8613987654321",145 +CNUM: "USER","123",129	
OK	

14.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
Error information is returned in response to one of the previous commands.	+CME ERROR: SIM busy	Phonebook initialization has not completed. Try again later.
	+CME ERROR: SIM PIN required	Enter the correct PIN.
	+CME ERROR: SIM PUK required	Enter the correct PUK.

15 SIM Operation Application Scenarios

15.1 PIN Operations

15.1.1 Reference Process

Command	Description
AT+CLCK="SC",1,"<pwd>"	Enables PIN authentication. (<pwd> specifies the PIN.)
OK	
AT+CPIN="<pwd>"	Requests the PIN after the module restarts.
OK	
AT+CPWD="SC","<oldpwd>", "<newpwd>"	Changes the PIN (<newpwd> will be the new PIN).
OK	

 **NOTE**

- After PIN authentication is enabled using **AT+CLCK**, the module must be restarted for the change to take effect.
- Either **AT^CPIN** or **AT+CPIN** can be used to authenticate the PIN.
- In general cases, three incorrect PIN entry attempts in succession will lock the PIN, and 10 attempts will lock the PUK. If the PIN is locked, a PUK is required to unlock the PIN. If the PUK is locked, the SIM card will be unusable and cannot be recovered.

15.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
Enable PIN authentication. AT+CLCK="SC",1,"<pwd>"	+CME ERROR: operation not allowed	If PIN authentication has been enabled, it cannot be enabled again. Check whether PIN authentication has been enabled.
Enter the PIN. AT+CPIN="<pwd>"	+CME ERROR: incorrect password	Enter the correct PIN. The original PIN is provided by the operator.
	+CME ERROR: SIM PUK required	Incorrect PINs have been entered three times and the SIM card is blocked. Run AT+CPIN="<PUK>","<pwd>" to enter the PUK to unblock the SIM card. The PUK is provided by the operator and cannot be changed by users. If incorrect PUKs are entered 10 times, the SIM card will be permanently blocked.
Change the PIN. AT+CPWD="SC","<oldpwd>","<newpwd>"	+CME ERROR: incorrect password	<oldpwd> must be the current PIN. Like the PIN authentication, if incorrect PINs are entered three times, the PUK will be required. If incorrect PUKs are entered 10 times, the SIM card will be permanently blocked.

15.2 CRSM Command

15.2.1 Reference Process

Command	Description
AT+CRSM=176,12258,0,0,10	Reads the file EFiccid with a transparent structure. (12258 is 0X2FE2, the EF _{ICCID} file's FID).

Command	Description
+CRSM: 144,0,"<record>" OK	After the command is processed successfully, the EF _{ICCID} file's content (<record>) is returned.
AT+CRSM=178,28476,1,4,176,,"7F10"	Uses an absolute path to read the first entry from the EF _{SMS} file on the SIM card's DF _{TELECOM} folder.
+CRSM: 144,0,"<record>" OK	<record> is the content of the first entry. The length of <record> is 176 bytes.
AT+CRSM=192,12258	Gets response of EF _{ICCID} .
+CRSM: 144,0,"<response>" OK	<response> is the response data of EF _{ICCID} . For details about <response>, refer to the ETSI TS 102.221 protocol.
AT+CRSM=214,28421,0,0,2,"0012"	Updates the content of the transparent structure EF _{LI} file on the SIM card.
+CRSM: 144,0,"" OK	Updates succeeded.
AT+CRSM=220,28476,1,4,176,"1111","7F10"	Updates the content of the linear fixed structure EF _{SMS} file on the SIM card.
+CRSM: 144,0,"" OK	Updates succeeded.
AT+CRSM=242	Obtains the current directory information.
+CRSM: 144,0,"<status>" OK	<status> indicates the current directory status.

 **NOTE**

- To read or update a file, appropriate commands must be used according to the file's structure type (for details, refer to the description of file properties in the 3GPP TS 31.102 protocol). For transparent structure files, use 176 (Read Binary) and 214 (Update Binary). For linear fixed structure files, use 178 (Read Record) and 220 (Update Record).
- If <pathid> is not contained in the command, the module will prefer to access the files with the same FID in the current directory.
- Files can be accessed only when the access criteria are met. Otherwise the SIM card will return PSWs indicating that the access authentication failed. If an EF file's read privilege is PIN protected and the module does not have the PIN authenticated, PSWs indicating that the access authentication failed will be returned after the AT+CRSM command is used to read the EF file.

- To use the **AT+CRSM** command to access the file content on the SIM card, the parameters contained in the command must strictly meet the requirements in the ETSI TS 102.221 and 3GPP TS 31.102 protocol. For detailed requirements, refer to the protocol.

15.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
Update the content of the linear fixed structure EF _{SMS} file on the SIM card. AT+CRSM=178,12258,0,0,10	+CRSM: 105,129,"" OK	The status word (SW) indicates a Read command error occurred. Files with a transparent structure should be read using 176 (READ BINARY).
Update the content of the linear fixed structure EF _{SMS} file on the SIM card. AT+CRSM=220,28476,1,4,176,"1111","7F10"	+CRSM: 105,130,"" OK	The PSW indicates that the security conditions were not met. To update the EF _{SMS} file, the correct PIN is required.

16 Sleeping and Waking Up Application Scenarios

16.1 Overview

As an embedded component in the host, the module also consumes power, which increases the power consumption of the integrated product. Therefore, the most important task of power management is to reduce the power consumption of the integrated product by enabling the module's sleep mode when necessary.

The host and the module need to wake each other up from sleep if communication is required. Therefore, another task of power management is to provide a wake-up control mechanism for the host and module.

Power management involves three parts: the host system software (including the USB driver/GPIO driver/sleep mechanism functions), connection hardware between the host and module, and the module's software wake-up mechanism.

This chapter is mainly concerned with the module's software wakeup mechanism, including the wake-up principle, how USB related events impact on the waking up of the module and remotely waking up the module, and how the module remotely wakes up the host.

This chapter briefly describes the power management related connection hardware between the host and module.

This chapter does not describe the host system software. For example, if the host runs on a Windows or Mac system, Huawei will provide a USB driver program corresponding to the module. If the host runs on an Android system, Huawei will provide [Guide to Kernel Driver Integration in Linux for Huawei Modules](#) for users to configure the USB-based wakeup function of the module.

This document describes typical module application scenarios. A host can be designed based on the actual system features and the application scenarios of the module to reduce power consumption of both the module and integrated product.

After the host is designed as recommended by this document, the module's power consumption and the whole unit's power consumption can meet the performance requirements. For details, see related description in the product manual.

16.2 Hardware Interfaces

The module communicates with the host using mainly USB. For details about pins related to power management, see Table 16-1.

For corresponding interface numbers, reference design, and sequence diagram for the pins, see Hardware Guide for each product.

Table 16-1 Power management related pins

Interface	Pin Name	Input/Output	Description
WAKEUP_OUT	Output	When a wake-up source (see section 16.4.5 Host Woken up by Module) arrives, these pins output a high-level-voltage pulse lasting for 1s during which if other wake-up sources arrive, the module will ignore the later wake-up requests. In other words, the module will not output a second pulse during this 1s.	Figure 16-1
WAKEUP_IN	Input	When the pin carries a high-level voltage, the states of the module are as follows: The module will be prohibited to enter sleep mode if the module is awake. The module will be woken up if the module is in sleep mode. When the pin carries a low-level voltage, the module is allowed to enter sleep mode. (By default, the pin is set to INPUT/PD, which is, the software detects a low-level voltage on the pin when the pin is not connected.)	Figure 16-2
SLEEP_STATUS	Output	Indicates the state of the module. When the pin carries a high-level voltage, the module is in working mode. When the pin carries a low-level voltage, the module is in sleep mode.	Figure 16-3

16.3 Sequence Diagram

Figure 16-1 WAKEUP_OUT output sequence






Figure 16-2 WAKEUP_IN input sequence



About the vote, see section 16.4.1 Principle.

Figure 16-3 SLEEP_STATUS output sequence




16.4 Software Interfaces

16.4.1 Principle

The module runs on a multi-task software system. The sleep task is granted with the lowest priority and assigned to detect whether the module can enter sleep mode. Other tasks (such as the RF, SIM card and USB) have voting rights. They vote to decide whether the module can enter sleep mode. When no other tasks are running, the sleep task is executed. If the sleep task detects that all other tasks agree on the module's sleep, the module enters sleep mode, as shown in Figure 16-4. At this time, the baseband chip reduces the work frequency, and the RF enters the Discontinuous Reception (DRX) mode.

Figure 16-4 Currency state when the module is in sleep mode




For more information about the module's sleep procedure, see Figure 16-5

 **NOTE**

The module's sleep mode is different from working mode or flight mode set using the **AT+CFUN** command. The RF will be turned off when the module enters LPM mode using the command **AT+CFUN=0** while the RF will enter DRX mode without being turned off when the module is in sleep mode. For more details, refer to [HUAWEI ME909s Series LTE Module AT Command Interface Specification](#).

The module enters sleep mode automatically when the sleep task detects that all other tasks agree on the module's sleep. The sleep period of the module depends on the current working state and circumstance. The period may last for several seconds, or up to several minutes.

Figure 16-5 Sleep procedure



16.4.2 USB Interface

USB is an important communication channel between the module and the host. According to the USB protocol, normally a hub or a root hub periodically sends Start of Frame (SOF) data packages (one data package per ms using full-speed USB and one package per 125 μ s using high-speed USB). Through this mechanism, USB always votes to stop the module from entering sleep mode.

When the USB driver provided by Huawei detects that the module and the host have not exchanged data in 5 seconds, the USB driver will enable the port's suspend feature, stopping SOF data packages being sent and suspending the USB controller. This enables the USB to vote to agree the module's sleep.



NOTE

If the USB driver used is developed by users or is integrated with external application, ensure that the USB driver supports the USB suspend features (including selective suspend and global suspend, as defined in the USB standard.)

16.4.3 UART Interface

UART is an important communication channel between the module and the host. If the host uses UART (a TTL level Interface), it can connect to the module's UART directly. If the host uses RS232, it can connect to the module's UART through a conversion chip such as MAX232.

16.4.4 Module Wake-up

RF periodically wakes up the module based on the DRX cycle (depending on the actual configuration of the network system), as shown in Figure 16-4.

Other aperiodic events include:

1. The host sends data using USB or pulls WAKEUP_IN up.
2. Changes on the network, for example, an incoming call, an incoming text message, a signal change, a network working mode change, a network search, an IP data package (when a dial-up network connection is set up).
3. Software system events such as a timer
4. Abnormal events, for example, an antenna drops or a SIM card becomes loose.

16.4.5 Host Woken up by Module

Wake-up Source

A wake-up source is a module event that can wake up the host, for example, an incoming voice call, a text message, data (PPP data, TCP/UDP data from the network), and unsolicited messages.

Remotely Waking up the Host Using USB

When the host is in sleep mode and the USB controller is in suspended mode, if the module needs to send data to the host (for example, a wake-up source has arrived), the module sends a remote wake-up signal that lasts 3 ms to inform the host to start USB resume (as shown in Figure 16-6). To complete the procedure, the following conditions must be met:

1. The USB controller on the host supports USB remote wake-up and can wake up the host.

2. The USB driver enables or disables remote wake-up by executing SET_FEATURE and CLEAR_FEATURE commands. Therefore, remote wake-up must be enabled on the USB driver before USB enters suspended mode.
3. When the host receives the remote wake-up signal from the module, the host needs to send a full speed K signal that lasts at least 20 ms. When the USB controller resumes, the host must send the SOF token within 3 ms from the startup of the idle state. Otherwise, the module enters suspended mode again, as shown in Figure 16-6.

Figure 16-6 USB resume time sequence




Figure 16-7 Successful procedure of remote wake-up

Transfer	F	S	Control	ADDR	ENDP	bRequest	wValue	wIndex	wLength	Time	Time Stamp	
5			SET	3	0	SET_FEATURE	DEVICE_REMOTE_WAKEUP	0x0000	0	3.519 ms	8 . 897 431 766	
Packet			Suspend							12.022 sec	8 . 900 949 650	
Packet			Resume							21.000 ms	20 . 923 255 382	
Packet			Resume EOP							1.333 us	36.727 ms	
6			GET	3	0	GET_STATUS	0x0000	USB 2.0 Standard Status	2	0x0002	1.162 ms	20 . 960 983 366
7			SET	3	0	CLEAR_FEATURE	0x0001	0x0000	0	12.352 ms	20 . 982 145 182	

WAKEUP_OUT Waking up the Host

The module will output a 1s pulse using WAKEUP_OUT as shown in Figure 16-1 when a wake-up source arrives. The host wakes itself up after detecting the level change.

Remote Wake-up Configuration

The power consumption of the host increases if it is frequently woken up. The host can configure the module's wake-up sources using AT^WAKEUPCFG and AT^CURC command so as to reduce the power consumption.

The **AT^WAKEUPCFG** command can be used to choose wake-up sources and the wake-up channel (USB or WAKEUP_OUT). The **AT^CURC** command can choose unsolicited messages. For more details, refer to AT Command Interface Specification.

16.5 Application Scenarios: System with USB Connection only

A host runs in Android system, with support for USB suspend, USB remote resume, voice calling, and text messages.

16.5.1 Hardware Connection

The host connects to the module using USB.

16.5.2 Software Procedure

Command	Description
AT^WAKEUPCFG=?	Queries the parameter range of AT^WAKEUPCFG .
^WAKEUPCFG: (0-1),(0-3),(0-31) OK	
AT^WAKEUPCFG=1,2,15	Configures the module to make sure that incoming calls, text messages, data, and unsolicited messages can remotely wake up the host using USB.
OK	
AT^CURC=?	Queries the parameter range of AT^CURC .
^CURC: (0-1) OK	

16.5.3 Advantages

With software configuration, while the system requirements (calling and text messages) are met, the number of times the host is woken up by unsolicited messages, and consequently the power consumption, are reduced.

16.6 Application Scenarios: System with USB and WAKEUP_OUT

A host runs in Android system, with support for text messages, but not USB remote resume or voice calling.

16.6.1 Hardware Connection

The host must connect to the module using USB and WAKEUP_OUT pins

16.6.2 Software Procedure

Command	Description
AT^WAKEUPCFG=?	Queries the parameter range of AT^WAKEUPCFG .
^WAKEUPCFG: (0-1),(0-3),(0-31) OK	
AT^WAKEUPCFG=1,1,14	Configures the module to make sure that text messages, data, and unsolicited messages can remotely wake up the host using the WAKEUP_OUT pin.
OK	
AT^CURC=?	Queries the parameter range of AT^CURC .
^CURC: (0-1) OK	
AT^SLEEPCFG=?	Queries the parameter range of AT^SLEEPCFG .
^SLEEPCFG: (0-1) OK	
AT^SLEEPCFG=0,3000	Configures the delay time for module to report unsolicited indication to host since the 1s high-level-voltage wakeup pulse through WAKEUP_OUT pin.
OK	

16.6.3 Advantages

A solution is provided for systems not supporting USB remote resume.

With software configuration, while the system requirements (calling and text messages) are met, the number of times the host is woken up by unsolicited messages, and consequently the power consumption, are reduced.

16.7 Application Scenarios: System with UART and WAKEUP_OUT/WAKEUP_IN

A host is constructed based on a single-chip microcomputer. There is no user interface. The host supports UART and text messages. After receiving a text message, the host decodes it and takes corresponding actions.

16.7.1 Hardware Connection

The host must connect to the module using the UART and WAKEUP_OUT/WAKEUP_IN pins.

16.7.2 Software Procedure

Command	Description
AT^WAKEUPCFG=?	Queries the parameter range of AT^WAKEUPCFG.
^WAKEUPCFG: (0-1),(0-3),(0-31)	
OK	
AT^WAKEUPCFG=1,1,2	Configures the module to make sure that text messages can remotely wake up the host by WAKEUP_OUT.
OK	
AT^CURC=?	Queries the parameter range of AT^CURC.
^CURC: (0-1)	
OK	
AT^SLEEPCFG=?	Queries the parameter range of AT^SLEEPCFG.
^SLEEPCFG: (0-1)	
OK	
AT^SLEEPCFG=1,8	Configures the delay time for module to enter sleep mode since no data are transmitted through UART.
OK	

16.7.3 Advantages

This solution enables module to enter sleep mode for saving energy when no data are transmitted through UART. With software configuration, the host can wake up the module using WAKEUP_IN PIN.

16.8 System with Other Connection Methods

If the host can be connected to the module only using UART, refer to the hardware guide. If the host can connect to the module using USB/WAKEUP_OUT, and can support USB remote. For details about the software procedure, refer to the earlier sections while considering the host system feature.



NOTE

The host should not be allowed to enter sleep mode when the host connects to the module using the UART RXD pin only. Because the module does not support UART remote wake-up, handshake is not implemented and consequently data on the UART will be lost when the host is in sleep mode.

16.9 Solution to Time-expired USB Reset to Suspended Device

To wake up a device in suspended state, host will send a reset message to the USB port of device and device should finish processing this message in time. Device in suspended state will stop its USB clock to meet the power requirements. It may take some time to let the clock settle to a level of operation where it is able to perform the reset detection and handshake with enough precision. In totally it takes device about 8-10 ms to finish reset operation.

Some USB bus controller of host has very strict limitation to the reset time. If suspended device can not finish reset operation in time, it will cause wake-up operation failure. To avoid this issue, most of the USB bus controller will send another reset message to device while reset operation spends too much time. In general, no more implementation is required.

If USB bus controller does not send the second reset message even if device in suspended state cannot meet the time requirement, the second reset message could still be sent by modifying the kernel driver of USB hub of host.

For host with Linux kernel, modify the source code of kernel driver like this:

In function `hub_port_init` (locates in `/system/kernel/drivers/usb/core/hub.c`), call function `hub_port_reset` once more to send one more reset message.

Before:

```
/* Reset the device; full speed may morph to high speed */  
/* FIXME a USB 2.0 device may morph into SuperSpeed on reset. */  
retval = hub_port_reset(hub, port1, udev, delay, false);
```

After:

```
/* Reset the device; full speed may morph to high speed */  
/* FIXME a USB 2.0 device may morph into SuperSpeed on reset. */  
(void)hub_port_reset(hub, port1, udev, RESET_DELAY, false);  
retval = hub_port_reset(hub, port1, udev, delay, false);
```

The value of **RESET_DELAY** indicates the time delay in millisecond of 2 reset operations and it should have a value 15 at least.

17 Thermal Protection Application Scenarios

17.1 Pre-configuration

17.1.1 Reference Process

Command	Description
^THERM: 2	When the temperature is higher than the warning temperature protection threshold for three consecutive times, the module reports to the host.
^THERM: 1	When the temperature is higher than the temperature protection threshold of turning off RF for three consecutive times, the module enables thermal protection: The module turns off its RF, and reports to the host.
^THERM: 0	When the temperature is lower than the temperature protection hysteresis threshold of turning off RF for three consecutive times, the module disables thermal protection: turns on its RF and reports to the host.
^THERM: 3	When the temperature is lower than the warning temperature protection hysteresis threshold for three consecutive times, the module reports to the host.

17.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
When the module temperature is higher than the threshold of turning off RF in running.	^THERM: 1 RF turns off.	Find the temperature rising factor, and solve or improve it.

17.2 Thermal Protection Process

- When the module's temperature is lower than 107°C, the module works normally.
- When the module's temperature reaches 107°C, the module enables thermal protection: turns off its RF and presents the **^THERM: 1** indication. When the module's temperature is lower than 92°C, the module disables thermal protection: turns on its RF transmission, and presents the **^THERM: 0** indication.



NOTE

- During an emergency call, if thermal protection is enabled, the module will not present an indication and will not take thermal protection actions: turning off its RF until emergency call is ended.
- After thermal protection of turning off RF is enabled, users cannot make emergency calls.
- Thermal protection is designed to protect the module from being damaged by excessively high temperatures. To work in high temperature environments, both the module and its peripheral components must be able to resist the same temperature.

18 Concurrent Service Application Scenarios

18.1 Voice Calls and Text Messaging

On a GSM or WCDMA network, the module uses the same wireless channel to establish voice calls and send text messages. Therefore, when the module provides voice call and text messaging services at the same time, it may fail to make the voice call or the message may be delayed.

18.1.1 Reference Process

Command	Description
ATD13912345;	Makes a voice call to 13912345 from the module.
OK	
^ORIG: 2,0	
AT+CMSS=0	Sends the text message before the voice call is connected.
OK	The voice call is hung up because the user is busy.
^CEND: 1,0,100,17	
+CMSS: 36	

 **NOTE**

When a voice call has been connected, text messages can be sent without conflicting with the voice call.

18.2 Internal/External Protocol Stacks and Text Messaging

WCDMA networks support concurrent internal/external protocol stack services and text messaging.

When data is transmitted using the external protocol stack, text messages can be sent through only the ports on which no data is being transmitted.

When the internal protocol stack is in use, text messages can be sent through all ports in non-transparent transmission mode and through only the USB in transparent transmission mode.

Table 18-1 Ports available to text messaging during data services

	Service Port	Message Sending Port	Message Receiving Port
External protocol stack application	MODEM	PCUI, UART	PCUI, UART
	UART	PCUI, MODEM	PCUI, MODEM
Internal protocol stack application	UART (transparent transmission mode)	MODEM, PCUI	MODEM, PCUI
	MODEM (transparent transmission mode)	UART, PCUI	UART, PCUI

18.2.1 Reference Process

Command	Description
AT^IPOPEN=1,"TCP","192.168.44.33",7000,6000	Establishes a TCP link at the module's UART port.
OK ^IPDATA: 1,1024,No.6:**...**	The module transmits data through the UART port.
AT+CMSS=0	The module sends text messages through the PCUI port.
+CMSS: 48 OK (UART) ^IPDATA: 1,1024,No.7:**...** ^IPDATA: 1,1024,No.8:**...** +CMTI: "SM",4 ^IPDATA: 1,1024,No.9:**...**	The module can send text messages without interrupting the data transmission through the UART. After receiving text messages, the module presents them through all ports (the format of the text messages is set by AT+CNMI).



CAUTION

On GSM/GPRS networks, data transmission using the internal/external protocol stack services will be suspended when text messages are sent and will be resumed after the text messages are sent.

Command	Description
AT^IPOPEN=1,"TCP","192.168.44.33",7000,6000	Establishes a TCP link at the module's UART port.
OK ^IPDATA: 1,1024,No.6:**...**	The module transmits data continuously.
AT+CMSS=0	The module sends text messages through the PCUI port.
+CMSS: 48 OK +CMT: "+8613912345",,"12/01/01,12:00:00+00" 1234 (UART) ^IPDATA: 1,1024,No.7:**...** ^IPDATA: 1,1024,No.8:**...**	The data transmission through the UART port is suspended for the text messaging service through the PCUI port. The data transmission will be resumed after the messages are sent or received.

18.3 Internal/External Protocol Stacks and Voice Calls

WCDMA networks support concurrent internal/external protocol stack services and voice calls.

GSM/GPRS networks offer limited support for concurrent internal/external protocol stack services and voice calls.

First Service	Concurrent Service	Service State
Internal protocol stack	MO voice call	Suspend data transmission through the UART port until a voice call is hung up.
	MT voice call	Huawei's extended AT command AT^DVCFG can be used to configure the priorities of the internal protocol stack service and MT voice call.

First Service	Concurrent Service	Service State
External protocol stack	MO voice call	Suspend data transmission through the MODEM port until a voice call is hung up.
	MT voice call	
Voice calls	Internal protocol stack	Data connections through the UART port cannot be established (executing AT^IPINIT fails).
	External protocol stack	Data connections can be established through the MODEM port, but data cannot be transmitted until the voice call is hung up.



NOTE

Settings configured by **AT^DVCFG** take effect immediately and are effective only in transparent transmission mode of the internal protocol stack services.

18.3.1 Reference Process

Command	Description
(UART) AT^IPOPEN=1,"TCP","192.168.44.33",7000,6000	Establishes a TCP link at the module's UART port.
OK ^IPDATA: 1,536,No.51:*****...	The module transmits data in non-transparent transmission mode.
	(Another party calls the module.)
(all ports) RING RING	Data transmission through the UART port is suspended, and all ports present the Ring indication.
(PCUI) AT+CHUP	
OK ^CEND: 1,0,102,17	After the call is hung up, data transmission through the UART port is resumed. Packets received/transmitted when data transmission is suspended will not be lost.
(UART) ^IPDATA: 1,536,No.52:*****...	
(UART) AT^IPENTRANS=1	The module enters transparent transmission mode to transmit data continuously.



Command	Description
OK No.230:*****...	
	(An MT call comes in)
(PCUI) RING RING	By default, voice calls have priority over data transmission (which is set by AT^DVCFG=0). Data transmission through the UART port is suspended, and the USB (PCUI and MODEM) ports present Ring indications.
(PCUI) AT+CHUP	
OK ^CEND: 1,0,102,17 (UART) No.231:*****...	After the voice call is hung up, resumes data transmission through the UART port.
(PCUI) AT^DVCFG=1	Sets data transmission to have priority over voice calls.
OK (UART) No.240:*****...	The module transmits data in transparent transmission mode.
	(An MT call comes in)
(PCUI) ^CEND: 1,0,29,16 (UART) No.241:*****...	The module suspends data transmission through the UART port, hangs up the incoming call automatically, presents the ^CEND indications through the USB (PCUI and MODEM) ports, and resumes the data transmission through the UART port.
(UART) +++	The module exits transparent transmission mode to transmit data continuously.
OK ^IPDATA: 1,536,No.61:*****...	
	(An MT call comes in)
(all ports) RING RING	Data transmission through the UART port is suspended, and all ports present the Ring indication. AT^DVCFG=1 is invalid in non-transparent transmission mode.

Command	Description
(PCUI) AT+CHUP	
OK ^CEND: 1,0,102,17 (UART) ^IPDATA: 1,536,No.62:*****...	After the call is hung up, data transmission through the UART port is resumed. Packets received/transmitted when data transmission is suspended will not be lost.

18.4 Other Services

Configuration operations (initialization and serial port configuration), phonebook operations, and PIN operations can be performed when the module is not in sleep mode, no matter the module is idle or processing services, because no interaction between the module and the network is required.

Especially, if the module is processing internal/external protocol stack services, operations such as configuration, phonebook and PIN operations must be performed at ports that are not used to provide data services.

Table 18-2 Ports available to configuration, phonebook and PIN operations when the module is processing data services

	Service Port	Ports Available to Configuration, Phonebook and PIN Operations
External protocol stack application	MODEM	PCUI, UART
	UART	PCUI, MODEM
Internal protocol stack application	UART	MODEM, PCUI

19 STK Application Scenarios

19.1 Unsolicited Report of STK Proactive Commands

19.1.1 Reference Process

Command	Description
AT^STSF=1,2	Activates the STK interface function, set the STK interface to 3GPP standard mode.
OK	
+CUSATP: "D081A2810301250082028182850F80005 500530049004D53615E9475288F0A11807 CBE54C163A883508F0A318059296C149 88462A58F0A3280822A73ED67E58BE28 F0A338051FA884C630753578F0A34804F 53575B5FEB8BAF8F0C518065B095FB6 5E9665A62A58F0A5280624B673A97F34 E508F0A5380624B673A96058BFB8F0A5 480624B673A90AE7BB18F0A558077ED4 FE152A974068F0C5680624B673A84254 E1A5385"	Content of the SET UP MENU proactive command. The string should be interpreted according to the ETSI TS 102.223. The protocol states that the command type is determined by the 7th byte if the string length is greater than 127 bytes, and the 6th byte if the string length is 127 bytes or less. In the provided example, the 7th byte is 25, which indicates SET UP MENU.
AT+CUSATT="810301250082028281830 100"	The CAT client uses the AT command to respond to the proactive command. This string means "command performed successfully".
OK	

NOTE

- STK activation and deactivation still take effect after the device is restarted.
- <proactive_command > and <terminal_response> consist of the full BER-TLV data object as defined in 3GPP TS 31.111.
- For ME909s, STK proactive commands can be divided into three categories:

Category 1: proactive commands that must be processed by the CAT client, including DISPLAY TEXT, GET INKEY, GET INPUT, PLAY TONE, SELECT ITEM, SET UP MENU, LANGUAGE NOTIFICATION, and LAUNCH BROWSER.

Category 2: proactive commands processed by the module (the CAT client is still notified), including SEND SHORT MESSAGE, SEND SS, SEND USSD, SET UP EVENT LIST, and REFRESH.

Category 3: other proactive commands that are processed by the module (the CAT client is not notified).

- Only commands of categories 1 and 2 are reported using the +CUSATP interface.
- Only terminal responses to commands of category 1 can be delivered using the AT interface.

19.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
The SIM card has sent an STK proactive command, but the module does not unsolicited report it to the CAT client.	None	AT^STSF=1,2
Module reports proactive command and then the CAT client responds to the proactive command by delivering terminal response command. AT+CUSATT="<terminal_response>"	+CME ERROR: SIM PIN required	Unblock the PIN before delivering the terminal response.
	+CME ERROR: SIM busy	Wait until the SIM card initialization is complete before delivering the terminal response.
Module reports proactive command and then the CAT client responds to the proactive command by delivering terminal response command. AT+CUSATT="<terminal_response>"	ERROR	<ol style="list-style-type: none"> 1. Use AT^STSF? to check whether STK has been activated and the interface has been set to 3GPP standard mode. If yes, proceed to the next step. 2. Check whether the proactive command reported needs to be processed by the CAT client. If yes, proceed to the next step. 3. Check whether <terminal_response> complies with the 3GPP TS 31.111 protocol. If yes, proceed to the next step. 4. Check whether the terminal response is delivered more than 2 minutes and 5 seconds after the proactive command is reported. If yes, the module does not receive terminal responses sent from the CAT client.

19.2 Querying the STK Main Menu

19.2.1 Reference Process

Command	Description
AT^CUSATM?	Checks the content of SET UP MENU .
^CUSATM: "D081A2810301250082028182850F80005500530049 004D53615E9475288F0A11807CBE54C163A883508 F0A318059296C14988462A58F0A3280822A73ED67 E58BE28F0A338051FA884C630753578F0A34804F5 3575B5FEB8BAF8F0C518065B095FB65E9665A62A 58F0A5280624B673A97F34E508F0A5380624B673A 96058BFB8F0A5480624B673A90AE7BB18F0A5580 77ED4FE152A974068F0C5680624B673A84254E1A5 385" OK	Content of SET UP MENU

 **NOTE**

- This command is not specified in the standard interface protocol but is introduced to prevent the main menu information from being lost because **SET UP MENU** is sent too quickly.
- If the SIM card does not deliver **SET UP MENU**, then **^CUSATM: ""** will be returned after the main menu is queried.

19.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
The CAT client queries Content of SET UP MENU. AT^CUSATM?	ERROR	AT^STSF=1,2
	+CME ERROR: SIM PIN required	Unblock the PIN before delivering the command.

19.3 STK Envelope Command

19.3.1 Reference Process

Command	Description
AT+CUSATE="D30782020181900156"	Delivers the envelope command MENU SELECTION .
+CUSATE: "",0 OK	The SIM card's response to the envelope command. For details, see the below notes.

 **NOTE**

- **<envelope_command>** and **<envelope_response>** consist of the full BER-TLV data object as defined in 3GPP TS 31.111.
- **<envelope_response>** is the SIM card's response to the envelope command. It may be empty.
- **<busy>** indicates the SIM card status. If **<busy>** is **0**, the SIM card is normal and the envelope command has been processed. If **<busy>** is **1**, the SIM card is busy. The envelope command can be resent when the SIM card is idle. If **<busy>** is **2**, the SIM card is faulty. Check the SIM card and do not resend the envelope command until the SIM card has been fixed.

19.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
The CAT client delivers the envelope command. AT+CUSATE="<envelope_command>"	ERROR	AT^STSF=1,2
	+CME ERROR: SIM PIN required	Unblock the PIN before delivering the envelope command.
	+CME ERROR: SIM busy	Wait until the SIM card initialization is complete before delivering the envelope command.
	ERROR	Check whether <envelope_command> complies with the 3GPP TS 31.111 protocol.

20 TTS Application Scenarios

20.1 TTS Playing

Parameters in TTS (Text to Speech) commands are restored to their default values every time the module is powered back on after a restart or power failure. The parameter settings are saved to the internal memory.

When enabled, TTS converts GBK character or Unicode strings into voice, which is played through the voice channel. If TTS is disabled or a voice call comes in, voice is not played.

During a voice call, TTS voice is played on the receiving end.

Concurrent TTS operations are not supported. The current TTS operation must stop before a new one is conducted.

20.1.1 Reference Process

Command	Description
AT^TTSCFG=0,1	Enables TTS.
OK	
AT^TTS=1,"CED2C3C7CAC7C4A3BFE9D7E9A1A3"	Plays voice.
OK	
AT^TTS=0	Stops TTS playing forcibly.
OK	Reports the end of TTS playing.
^AUDEND: 2,1	


NOTE

- The character string to convert to speech must be hexadecimal and GBK encoded or Unicode encoded. The maximum length is 1200 (for Chinese) or 500 (for Italian) bytes and the number of bytes must be an integer multiple of 2 (for Chinese) or 4 (for Italian) (0 is excluded).
- Before **^AUDEND** is executed, **AT^TTS=1,<text>** is not available.
- TTS-related AT commands cannot be executed on modules that do not support TTS.

- When TTS voice is played, **ERROR** will be returned when **AT^TTSCFG** set command is executed.
- TTS maintains the lowest priority in the voice channel. If any audio function (such as recording, incoming call ringtone, and DTMF) requires the voice channel, TTS voice will not be played.
- "-" is pronounced "至" in Chinese, eg: "500-300=200" is pronounced "500 至 300=200".

20.1.2 Flowchart

Figure 20-1 Process for playing TTS voice





20.1.3 Troubleshooting

Scenario	Possible Error Information	Solution
<code>AT^TTS=1,"C4E3BAC3"</code>	+CME ERROR: operation not allowed	<ul style="list-style-type: none">• Solution 1: Run <code>AT^TTSCFG=0,1</code> to enable TTS.• Solution 2: End the current call, recording, and playback tasks.

21 FOTA Application Scenarios

21.1 Overview

While version query and downloads for FOTA upgrades can be conducted during an IP stack service, FOTA upgrades cannot.

FOTA upgrades and voice calls are mutually excluded. Version query and downloads for FOTA upgrades can be conducted during a voice call only when the module is used on a 3G or 4G network.




NOTE

Please use FTPS because FTPS have a stronger security level than FTP.

21.2 FOTA Process

21.2.1 Upgrade Module Firmware Over Air Through Delta Package

Figure 21-1 Upgrade module firmware over air through delta package




NOTE

Update file downloads may incur data usage fees charged by the operator.

21.2.2 Procedure for FOTA Implementation

This section describes the workflow of HUAWEI Module FOTA feature.

Figure 21-2 FOTA data flow



NOTE

If the module is powered off during the firmware installing progress, after the module is restarted, the firmware will resume installing at the last point.

Reference Process

After customer application received SMS or socket command to perform FOTA upgrade.

Command	Description
AT+GMR	Queries the module's software version
12.815.01.03.00	
OK	
AT^FOTACFG="1234","", "",2	Configures APN
OK	
AT^FOTAMODE=0,0,1,1	Sets FOTA mode
OK	

Command	Description
AT^FOTASTATE?	
^FOTASTATE: 10 OK	Indicates that the FOTA state is idle.
AT^FOTADET	Starts to detect
OK ^FOTASTATE: 11 ^FOTASTATE: 12,12.815.01.04.00,79114,"Support send sms background"	Gets the module's new version "12.815.01.04.00"
AT^FOTADL=1	Starts to download the new version and upgrade.
OK ^FOTASTATE: 30	The download progressing of the FW delta file.
AT^FOTADLQ	Queries file download.
^FOTADLQ: 1,"FIRMWARE1",0,17471680 OK ^FOTASTATE: 40 ^FOTASTATE: 50 ^FOTASTATE: 90	Indicates that FW delta file is completely downloaded. Indicates that FW is ready to update. After few minutes, FW is successfully upgraded.
AT+GMR	Queries the module's software version after the upgrade.
12.815.01.04.00 OK	The software version has been changed.

21.3 Setting FOTA Mode

21.3.1 Reference Process

Command	Description
AT^FOTAMODE=?	Checks the parameter range supported by the command.
^FOTAMODE: (0-1),(0-1),(0-1),(0-1),(1-65535)	
OK	
AT^FOTAMODE?	Queries the current settings.
^FOTAMODE: 0,0,0,1,7	
OK	
AT^FOTAMODE=1,1,1,1,15	Configures FOTA mode as auto query, auto download, auto upgrade, and resumable data transfer enabled. And the auto query cycle is set to 15 days.
OK	

 **NOTE**

- Parameter settings are all saved upon power-off.
- All parameters will be restored to their default values after the upgrade.

21.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Error command parameters	The parameter is incorrectly set.

21.4 Setting FOTA Connection Parameters

21.4.1 Reference Process

Command	Description
AT^FOTACFG="cmnet","","",2	Sets the APN to cmnet and authentication mode to CHAP . Leaves the user name and password blank. These parameters should be set according to the contracted values.
OK	
AT^FOTACFG?	Queries the current settings.
^FOTACFG: "cmnet","","",2	
OK	

21.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The operation is not supported.
An error message is returned.	+CME ERROR: Error command parameters	The parameter is incorrectly set.

21.5 Manually Querying for Upgrade Firmware Version

21.5.1 Reference Process

Command	Description
AT^FOTACFG="cmnet","","",2	Configures the PDP context. For example, sets the APN to cmnet (the value of APN is provided by the network server) and authentication mode to CHAP.
OK	
AT^FOTAMODE=0,0,0,1	Configures FOTA mode as manual query, manual download, manual upgrade, and resumable data transfer enabled.
OK	

Command	Description
AT^FOTASTATE?	Queries the current FOTA state.
^FOTASTATE: 10 OK	Indicates that the FOTA state is idle.
AT^FOTADET	Check for updates. Ensures that the module is registered with a valid network before you run this command.
OK ^FOTASTATE: 11 ^FOTASTATE: 12,12.815.01.04.00,79114,"Support send sms background"	Returns OK (success) or return +CME ERROR (failure). Reports that the query operation is in process. Reports information about the new version, including the version number, size of the file to be downloaded, and change description.
AT^FOTASTATE?	Queries the current FOTA state.
^FOTASTATE: 12 OK	Indicates that a new version is found.
AT^FOTADL=0 OK	Deletes the detected new version.
AT^FOTASTATE?	Queries the current FOTA state.
^FOTASTATE: 10 OK	Indicates that the FOTA state is idle.
AT^FOTADET	Checks for updates after deleting the new version on the server.
OK ^FOTASTATE: 11 ^FOTASTATE: 14	Reports that no new version is found.

 **NOTE**

- Version detection is allowed only if the FOTA state is idle.
- If the module is undergoing the PS data service or IPStack service, the FOTA service cannot be initiated, including version detection, download, and upgrade.

- The parameter <description> of the **^FOTASTATE** command is a string composed of ASCII characters. This parameter is used to describe the changed items of the new version. The parameter contains a maximum of five records, each containing up to 255 characters. Records are separated by semicolon.

21.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: FOTA is in collision state	Check whether the PS data service or IPStack service is going on, or use AT^FOTASTATE? command to check whether the FOTA state is idle.
An error message is returned.	+CME ERROR: Previous command is not complete	Wait for the previous command to be completely executed.
An error message is returned.	+CME ERROR: SIM PIN required	Use the PIN to unlock the SIM card.
The module reports a query failure.	^FOTASTATE: 13,<error_code>	Upon a query failure, the module restores the FOTA state to idle and deletes the downloaded files.

21.6 Periodically Querying the Version

21.6.1 Reference Process

Command	Description
AT^FOTAMODE=1,0,0,1,7	Configures FOTA mode as auto query, auto download, auto upgrade, and resumable data transfer enabled and the query cycle to seven days.
OK	The command is successfully executed.
	The module automatically checks for updates when the query time arrives.
^FOTASTATE: 11	Reports that the query operation is in process.
^FOTASTATE: 12,12.815.01.04.00,79114,"Support send sms background"	Reports information about the new version.

 **NOTE**

- Periodical query is based on either of the two timekeeping modes: network timekeeping or local timekeeping. If network timekeeping is unavailable, local timekeeping is used. Local timekeeping may not be accurate.
- Local timekeeping is affected by **AT+CCLK** command. Upon a power-off event, the CCLK value changes to "2000/01/06,08:00:00". After you choose to use local timekeeping and change the CCLK value, the query operation cannot be carried out at the correct time.
- It is recommended to detect the FOTA state when the host powers on. There are two options if the value is 12 (that is, there is a new version):
 - Download this new version. Note that this new version may not be the latest one. It may be the version that is queried previously.
 - Clear the previous versions. And then detect the new version again, which is the latest version in the server.

21.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
Auto query is in use.	No query operation is initiated when the query time arrives.	<ul style="list-style-type: none"> • Check whether the FOTA state is idle or not. If not, change the FOTA state to idle by using the AT^FOTADL=0 command. • Check whether the PS data service or IPStack service is going on or not. If the service is going on, terminate it.

21.7 Manually Downloading the Version

21.7.1 Reference Process

Command	Description
AT^FOTASTATE?	Queries the current FOTA state.
^FOTASTATE: 12 OK	Indicates that a new version is found.
AT^FOTADL=1	Runs this command to manually download the version or to resume data transfer.
OK	The command is successfully executed.
^FOTASTATE: 30	Reports the download is in process.
AT^FOTADL=2	Runs this command to manually download Pause.

Command	Description
OK ^FOTASTATE: 31	The command is successfully executed. Reports that the download is pending. If the resumable data transfer mode is disabled, the command will return "+CME ERROR: Operation not supported".
AT^FOTADL=1	Runs this command to manually download the version or to resume data transfer.
OK ^FOTASTATE: 30	The command is successfully executed. Reports that the download is in process.
AT^FOTADLQ	Queries the download progress.
^FOTADLQ: 1,"IMAGE",1324,1324 ^FOTADLQ: 2,"XNV",47104,77778 OK	Returns that the IMAGE file size is 1324 bytes, and 1324 bytes have been downloaded. The XNV file size is 77778 bytes, and 47104 bytes have been downloaded.
^FOTASTATE: 40	Reports that the version is completely downloaded and passes the MD5 verification.
AT^FOTADL=?	Queries the parameters supported by the command.
^FOTADL: (0-2) OK	Returns the supported parameters. 0: not to download. 1: download. 2: download pause.

 **NOTE**

- Version download is allowed only if the FOTA state is **12** (new version detected) and **31** (download pending).
- The prerequisites for version download and query are:
 - Module registered with a valid network.
 - No ongoing PS data service or IPStack service.

21.7.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The command is incorrect.
An error message is returned.	+CME ERROR: SIM PIN required	Use the PIN to unlock the SIM card.

Scenario	Possible Error Information	Solution
An error message is returned.	ERROR	The command is executed in incorrect FOTA state. Ensure that the FOTA state is 12 or 31 before you run the command.
The module reports a download failure.	^FOTASTATE: 20,<error_code>	Upon a download failure, the module restores the FOTA state to idle and deletes the downloaded file. For error codes, see HUAWEI ME909s Series LTE Module AT Command Interface Specification .

21.8 Automatically Downloading the Firmware

21.8.1 Reference Process

Command	Description
AT^FOTAMODE=0,1,0,1	Configures auto download mode.
OK	
AT^FOTADET	Runs this command to manually check for upgrades.
OK	
^FOTASTATE: 11	Reports that the query operation is in process.
^FOTASTATE: 12,12.815.01.01.00,79102,"Support send sms background"	Reports that a new version is found and information about the new version.
^FOTASTATE: 30	Automatically download the new version and reports that the download is in process.
^FOTASTATE: 40	Reports that the version is completely downloaded and passes the MD5 verification.

21.8.2 Troubleshooting

None

21.9 Using the Resumable Data Transfer Function

21.9.1 Reference Process

Command	Description
AT^FOTAMODE=0,0,0,1	Enables resumable data transfer.
OK	
AT^FOTASTATE?	Queries the FOTA state.
^FOTASTATE: 31	Indicates that the download is pending.
OK	
AT^FOTADL=1	Resumes the transmission from the break point.
OK	
^FOTASTATE: 30	Reports that the download is in process.
^FOTASTATE: 40	Reports that the download is complete.

 **NOTE**

If resumable data transfer is disabled, the download pending due to network disconnection or TCP link break-off will be regarded as a download error.

21.9.2 Troubleshooting

Scenario	Possible Error Information	Solution
The function of resumable data transfer is disabled, and the network or TCP link is disconnected.	^FOTASTATE: 20,18 Or other download error	The module deletes the downloaded file and restores the FOTA state to idle.
The function of resumable data transfer is enabled, and the module is powered off.	^FOTASTATE: 31	The module prompts that the download can be resumed.

21.10 Manually Canceling the Download

21.10.1 Reference Process

Command	Description
AT^FOTADL=1	Initiates the version download.
OK	
^FOTASTATE: 30	Reports that the download is in process.
AT^FOTADL=0	Cancels the download, deletes the downloaded file, and restores the FOTA state to idle.
OK	The command is successfully executed.
AT^FOTASTATE?	
^FOTASTATE: 10	Reports that the operation to cancel the download is complete. The FOTA state is idle.
OK	

21.10.2 Troubleshooting

None

21.11 Manually Upgrading the Version

21.11.1 Reference Process

Command	Description
AT^FOTASTATE?	
^FOTASTATE: 40	Reports that the download is complete.
OK	
AT^FWUP	Runs this command to manually start the upgrade.
OK	The command is successfully executed.
^FOTASTATE: 50	Reports that the upgrade starts. The module restarts, and then starts the upgrade.
^FOTASTATE: 90	Reports that the upgrade succeeds.

 **NOTE**

- The module restarts several times during the upgrade. Ensure that during this process, the module is powered on. Do not send AT commands during the upgrade.
- If the upgrade fails, the module enters forcible loading mode, you can perform any of the following:
 1. One-click upgrade from devices running Windows (full upgrade using the .exe file)
 2. Upgrade from devices that run Android or Linux using **UpdateWizard** (full upgrade using the .bin file)
 3. Local upgrade no matter the host having the operation system or not (for details, see section 23 Local Upgrade Application Scenarios).

21.11.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Previous command is not complete	Wait for the previous command to be completely executed.
An error message is returned.	+CME ERROR: FOTA is in collision state	<ol style="list-style-type: none"> 1. Check whether the PS data service or IPStack service is going on. 2. Check that the FOTA state is not 40 (download is complete).
The module reports an upgrade failure.	^FOTASTATE: 80,<error_code>	The module automatically changes the FOTA state to idle and deletes the downloaded file. You can use the AT^FOTADL=0 command to set the FOTA state to idle manually. For error codes, see HUAWEI ME909s Series LTE Module AT Command Interface Specification .

21.12 Automatically Upgrading the Version

21.12.1 Reference Process

Command	Description
AT^FOTAMODE=0,1,1,1	Configures FOTA mode as auto download and auto upgrade.
OK	
AT^FOTADET	Checks for upgrades.

Command	Description
OK	Returns information about the new version.
^FOTASTATE: 11	
^FOTASTATE: 12,12.815.01.02.00,79114,"Support send sms background"	Automatically download the version.
^FOTASTATE: 30	
^FOTASTATE: 40	Reports that the version is completely downloaded and passes the MD5 verification.
^FOTASTATE: 50	Reports that the module is ready for the upgrade.
^FOTASTATE: 90	Reports that the upgrade succeeds.
AT^FOTASTATE?	Queries the FOTA state.
^FOTASTATE: 10	The FOTA state changes to idle after the upgrade.
OK	

21.12.2 Troubleshooting

None

21.13 Enable or Disable FOTA SMS Auto-Download

21.13.1 Reference Process

Command	Description
AT^FOTASMSCFG=1	Enables FOTA SMS auto-download.
OK	

Command	Description
^FOTASMS ^FOTASTATE: 11 ^FOTASTATE: 12,12.815.01.02.00,79114,"Support send sms background" ^FOTASTATE: 30 ^FOTASTATE: 40 ^FOTASTATE: 50 ^FOTASTATE: 90	<p>Returns information about the new version.</p> <p>Automatically download the version.</p> <p>Reports that the version is completely downloaded and passes the MD5 verification.</p> <p>Reports that the module is ready for the upgrade. Reports that the upgrade succeeds.</p>
AT^FOTASTATE?	Queries the FOTA state.
^FOTASTATE: 10 OK	The FOTA state changes to idle after the upgrade.
AT^FOTASMSCFG=0	Disables FOTA SMS auto-download.
OK ^FOTASMS	
AT^FOTAP=1	The host decides that an upgrade is required.
OK	
^FOTASTATE: 11 ^FOTASTATE: 12,12.815.01.02.00,79114,"Support send sms background" ^FOTASTATE: 30 ^FOTASTATE: 40 ^FOTASTATE: 50 ^FOTASTATE: 90	<p>Returns information about the new version.</p> <p>Automatically download the version.</p> <p>Reports that the version is completely downloaded and passes the MD5 verification.</p> <p>Reports that the module is ready for the upgrade. Reports that the upgrade succeeds.</p>

Command	Description
AT^FOTASTATE?	Queries the FOTA state.
^FOTASTATE: 10 OK	The FOTA state changes to idle after the upgrade.



NOTE

- If FOTA SMS auto-download is enabled and **AT^FOTAP** is not received within 10 seconds after **^FOTASMS** is reported, the module automatically downloads the new version.
- When FOTA SMS auto-download is disabled, after **^FOTASMS** is reported, the module downloads the new version only if it receives **AT^FOTAP=1**.
- Enables FOTA SMS auto-download may incur data usage fees charged by the operator.

21.13.2 Troubleshooting

None

21.14 FOTA Notification Reception Application Scenarios

21.14.1 Reference Process

Command	Description
^FOTASMS	This command is used by the module to report to the host computer when receiving an update request so the host computer can decide whether to perform the update.



NOTE

- After receiving an update request, the module sends the **^FOTASMS** command three times (once every four seconds; this frequency may change) within 10 seconds to the host computer.
- If the module receives "OK" or does not receive any response from the host computer within 10 seconds, the module starts an FOTA process.
- If the host computer returns "REJ" within 10 seconds, the process ends.

21.14.2 Troubleshooting

None

21.15 FOTA Process Startup Application Scenarios

21.15.1 Reference Process

Command	Description
AT^FOTAP=1	The host computer needs to accept an FOTA update request.
OK	
AT^FOTAMODE?	Queries the mode settings.
^FOTAMODE: 0,1,1,1,7 OK	Sets the download mode and update mode to automatic and enable resumable data transfer. The settings are not saved to the NV.
AT^FOTACFG?	Queries dial-up connection profile settings for FOTA.
^FOTACFG: "1234","hwtest","hwtest",2 OK	
^FOTASTATE: 11 ^FOTASTATE: 12,25.635.65.00.01,19553132,1 add 1;2 del;3 mod;4 add 2;5 add 3	Reports that the query operation is in process. Reports information about the new version, including the version number, size of the file to be downloaded, and update description.
AT^FOTASTATE?	Queries the FOTA status.
^FOTASTATE: 12 OK ^FOTASTATE: 30 ^FOTASTATE: 40 ^FOTASTATE: 50	A new version is detected. Reports that the download is in process. Reports that the download is complete. Reports that the update starts.

NOTE

- Query the message-driven FOTA flag byte. If the flag byte is 0, a FOTA process is active. Stop the process to forcibly recover the FOTA state to idle. If the flag byte is 1, the last message-driven FOTA update is still in progress. In this case, query the FOTA state and wait for message to push the state machine to the next state.
- If no new version is detected (state 14), the process ends.
- If the attempt to check for or download updates fails, the module makes another attempt every half an hour within 24 hours until the attempt succeeds or the number of attempts reaches 48.

- If the module fails to check for updates within 24 hours, it saves the flag byte that indicates a detection failure.
- When implementing the FOTA service, the host computer sends the **AT^FOTADL=0** command, and the module performs the update as if it received a FOTA notification and removes the message-driven FOTA flag byte.
- If the module detects the flag byte next time it is powered back on, it attempts to check for updates again. If the attempt succeeds, it sets message-driven FOTA flag byte to **0**. If the attempt fails, it removes the message-driven FOTA flag byte, and the FOTA state recovers to idle.

21.15.2 Troubleshooting

Scenario	Possible Error Information	Solution
The command returns an error message.	+CME ERROR: FOTA is in collision state	Use the AT^FOTASTATE command to check whether the data service or IP stack service is used or whether FOTA state is idle.
The command returns an error message.	+CME ERROR: Previous command is not complete	Wait for the previous command to be completely executed.
The command returns an error message.	+CME ERROR: SIM PIN required	Use the PIN to unlock the module.
The module reports a query failure.	^FOTASTATE: 13,<error_code>	Upon a query failure, the module recovers the FOTA state to idle and deletes the downloaded files. See the AT command guide for error codes.

22 LED Indication Application Scenarios

22.1 Overview

LED indicates the MT's current state. Table 22-1 shows the Huawei default LED program, including LED mode to different states.

Table 22-1 HUAWEI default LED program

LED MODE	SERVICE STATE
Permanently off	Off line
100 ms on/100ms off/100 ms on/1700ms off	Power on Initialization
100 ms on/100ms off/100 ms on/1700ms off	Register fail and no service
100 ms on/100ms off/100 ms on/1700ms off	Connect to no service area
100 ms on/1900 ms off	Register on WCDMA
Permanently on	Connect on WCDMA
Permanently on	Transmit data on WCDMA
Permanently on	Connect on HSPA
Permanently on	Transmit on HSPA



NOTE

LED ON indicates LED GPIO is high and LED OFF indicates LED GPIO is low.

22.2 LED Setting Operations

22.2.1 Reference Process

Command	Description
AT^LEDCTRL=?	Checks the parameter range supported by the command.
^LEDCTRL: (0-2),00000FFF,(0-1),(1-100),(1-100),(1-100),(1-100) OK	
AT^LEDCTRL?	Queries the current LED program, 1 indicates adapting Huawei default program.
^LEDCTRL: 1 OK	
AT^LEDCTRL=0 OK	Turns off LED function.
AT^LEDCTRL=1 OK	Configures Huawei default program.
AT^LEDCTRL=2,00000001,0 OK	Configures that offline state LED mode is Permanently off.
AT^LEDCTRL=2,00000001,1,10, 10 OK	Configures that offline state LED mode is single flash and cycle time is 2s (1s on/1s off).
AT^LEDCTRL=2,00000001,1,1,1, 1,17 OK	Configures that offline state LED mode is double flash and cycle time is 2s (0.1s on/0.1s off/0.1s on/1.7s off).
AT^LEDCTRL=2,0000000F,1,1,1, 1,17 OK	Configures that offline, power on initialization, register fail no service and connect to no service state LED mode are double flash. Cycle time is 2s (0.1s on/0.1s off/0.1s on/1.7s off).
AT^LEDCTRL=2,00000400,1 OK	Configures that register successful on WCDMA, connect and transmit state LED mode are Permanently on.

Command	Description
AT^LEDCTRL=2,3FFFFFFF,1	Configures that all service state LED mod are Permanently on.
OK	

 **NOTE**

- After LED mode is configured, it will take effective immediately. We suggest to configure all the LED modes corresponding to its service states. If one LED mode does not configure, the corresponding service state will adapt LED MODE to Permanently OFF.
- By default, the blinking function of modules is disabled.

22.2.2 Troubleshooting

None


23 Local Upgrade Application Scenarios

23.1 Starting the Local Upgrade

23.1.1 Local Upgrade Flow Chart


Differential Upgrade Flow

Figure 23-1 Differential upgrade flow



Full Upgrade Flow

Figure 23-2 Full upgrade flow



23.1.2 Test Steps

Tools and Test Steps

This section takes the increment upgrade flow for an example, and the test is taken on Windows system with Hyper Terminal tool.


 **NOTE**

- The Hyper Terminal tool supports 1K-Xmodem protocol transfer files.
- Use Minicom instead of Hyper Terminal on a Linux system.


Step 1 Open the Hyper Terminal tool and choose the PCUI port number. (In this document, the PCUI port is **COM25**.)




Step 2 Set the parameters of the COM25 port, the baud rate is 115200 bit/s.




Step 3 Run the `AT^FWLOAD=1` command, and launch a differential upgrade.



Step 4 Choose the file which will be sent to the module and choose the **1K Xmodem** protocol.




Step 5 Begin to transfer the local file to the module flash.



Step 6 After finishing the file transmission, start the upgrade. And the module will reset automatically to finish the upgrade.

If the upgrade is successful, the module will return **^FWLSTATE: 90**.

If the upgrade comes across some errors, the **^FWLSTATE** will give an error code.



----End

Requirement of the AP

The AP (Application Processor) is required to have 4KB RAM at least (used to store the cache data). If AP only needs to support the differential upgrade, AP FLASH memory must be larger than 3 MB. (If two firmware versions have much difference, the size of the differential package will be greater than 3 MB.)

If AP needs to support the full upgrade, or both the differential upgrade and the full upgrade, AP FLASH memory must be larger than 35 MB. (The full size of ME909s firmware upgrade files is 35 MB.)

1. AP should be able to access and load the upgrade files.
2. AP should have a file transmission tool, this tool need to support 1K-Xmodem protocol.

Finding the PCUI port on Android and Linux System

Step 1 Enter `/sys/bus/usb/drivers/option`, and look out the following types of folders.

```
root@mbb-Lenovo:/sys/bus/usb/drivers/option# ls
1-2:2.2 1-2:2.3 1-2:2.4 1-2:2.5 1-2:2.6 bind module uevent unbind
```

Step 2 Enter these folders, and view the `bInterfaceProtocol` value.

```
root@mbb-Lenovo:/sys/bus/usb/drivers/option# cd 1-2\;2.4
root@mbb-Lenovo:/sys/bus/usb/drivers/option/1-2:2.4# ls
bAlternateSetting bInterfaceSubClass ep_86 subsystem
bInterfaceClass bNumEndpoints interface supports_autosuspend
bInterfaceNumber driver modalias ttyUSB2
bInterfaceProtocol ep_04 power uevent
```

If the `bInterfaceProtocol` value is `12`, the port is PCUI.

```
root@mbb-Lenovo:/sys/bus/usb/drivers/option/1-2:2.4# cat bInterfaceProtocol
12
```

----End

23.1.3 Reference Process

Command	Description
<code>AT^FWLOAD=0</code>	Starts the full upgrade.
<code>></code> <code>C</code>	
<code>AT^FWLOAD=1</code>	Starts the differential upgrade.
<code>></code> <code>C</code>	

 **NOTE**

- After the module reports 'C', the host transmits the upgrade package to the module using the Xmodem or 1K_Xmodem protocol.
- Interfaces supported by the module:
- Full upgrade: serial ports (baud rate: current baud rate of the module), PCUI port (baud rate: 115200 bit/s) and modem port (baud rate: 115200 bit/s).
- Differential upgrade: serial ports (baud rate: current baud rate of the module), PCUI port (baud rate: 115200 bit/s) and modem port (baud rate: 115200 bit/s).
- The full upgrade takes for long time, so the differential upgrade is recommended.

23.1.4 Troubleshooting

If using the full upgrade by the PCUI port, after the module is restarted, the PCUI port number may be changed. So you need to find the corresponding port, and then send the local upgrade package.

23.2 Reporting the Local Upgrade State

23.2.1 Reference Process

Command	Description
AT^FWLOAD=0	
> C	
The board restarts, and the upgrade starts.	
^FWLSTATE: 90	Reports that the local upgrade succeeds.

 **NOTE**

After the data have been transmitted completely and successfully, the MT will not send **OK** to the TE.

23.2.2 Troubleshooting

If a power failure occurs during the upgrade, the upgrade process must be repeated.

24 eCall Application Scenarios

24.1 Performance Specifications for MSD Transmission

24.1.1 Prerequisites

To measure the time required for an eCall to transmit the minimum set of data (MSD), ensure that the following prerequisites are met:

- Network: Huawei laboratory network
- Network conditions: optimal conditions (error-free radio channel, GSM FR codec, and FR AMR 12.2 kbit/s mode)
- Call type: emergency calls
- In-vehicle system (IVS)'s modulation mode: fast modulator
- Module: The IVS and Public Safety Answering Point (PSAP) modules, which use the V3R3 chip by Hisilicon.

According to the 3GPP TS 26.267 protocol, the IVS can modulate the MSD using a fast or robust modulator. The MSD's frame duration is 1320 ms when using a fast modulator and 2320 ms when using a robust modulator. The MSD transmission duration varies depending on the MSD's data frame duration.

The MSD transmission performance specifications described in this document apply to fast modulators only. When tested on a Huawei laboratory network and the signals are strong, the IVS does not switch to a robust modulator. If the IVS uses a robust modulator, further analysis must be performed.

24.1.2 Timing Methods

There are two methods to measure the time required to transmit the MSD using eCall:

- When an eCall is initiated, the IVS transmits the SEND frame to the PSAP. Timing starts when the IVS begins to send the first SEND frame and ends when the IVS receives the second HLACK frame from the PSAP.
- When an eCall is in progress, the IVS does not send the SEND frame if the PSAP requires the IVS to resend the MSD. Timing starts when the IVS receives the first START frame and ends when the IVS receives the second HLACK frame from the PSAP.

The MSD transmission time required for both timing methods is the same.

24.1.3 Performance Specifications

Perform the eCall session in the test environment described in section 24.1.1 Prerequisites, and use the timing method described in section 24.1.2 Timing Methods. The time required for the MSD transmission is between 4 and 40 seconds under the following situations:

- The PSAP is set to PUSH mode.
- The PSAP is set to PULL mode.
- The PSAP requires the IVS to resend the MSD. This includes scenarios as follows:
 - The MSD is transmitted, and the voice call is in progress.
 - The PSAP hangs up the eCall voice call and calls back the IVS within 12 hour.
 - The eCall voice call is ended unexpectedly due to a network fault, and the PSAP calls back the IVS within 12 hour.

24.2 AT Command Initiating Port

It is recommended that AT commands for initiating an eCall, monitoring the eCall's unsolicited report of the voice call and MSD transmission status, and ending the eCall are executed using the UART port.

24.3 Precautions for Using ECLPUSH

The **AT^ECLPUSH** command can be executed only in non MSD transmission state. (It cannot be executed when ALACK transmission is not complete.)

24.4 Method for Improving the eCall Setup Success Rate

To improve the eCall setup success rate and make sure eCalls have the highest priority, use the dedicated eCall port to initiate eCalls. For example, if you initiate an eCall through this port during network search, the search will be terminated and the eCall will be set up.

24.5 Handling Conflicts Between eCall and Other Voice Calls

eCalls have the highest priority. When an eCall is initiated, the module disconnects other voice calls automatically. During an eCall, no other voice calls (including an eCall) can be initiated or answered, ensuring the correct transmission of MSD data.

24.6 Manual Initiation of eCall Emergency Calls

Users can manually initiate eCall emergency calls. As emergency calls do not send the number to the network side, **AT^ECLSTART** does not require a third parameter to specify the called number in this case. Even if a third parameter is provided, it will not be used.

Command	Description
AT^ECLSTOP	The user must send AT^ECLSTOP to end the eCall. This is an asynchronous AT command. Returning OK does not mean the eCall is ended. The eCall is ended when ^CEND is unsolicitedly reported.
OK ^CEND: 1, 28, 29, 16	The eCall ending request is sent to the eCall module. The IVS hangs up the voice call.

24.6.2 Troubleshooting

Scenario	Possible Error Information	Solution
The MSD is updated when an eCall is initiated and the MSD transmission is in progress.	ERROR	Set the MSD after ^ECLSTAT: 3,4000 is reported or the eCall ends.
An eCall is initiated while another one is already in progress.	ERROR	Wait until the ongoing eCall ends. Only one eCall can be processed at a time.

24.7 Automatic Initiation of eCall Emergency Calls by the Vehicle

eCall emergency calls can be initiated when the vehicle sensor detects a collision. As emergency calls do not send the number to the network side, **AT^ECLSTART** does not require a third parameter to specify the called number in this case. Even if a third parameter is provided, it will not be used.

24.7.1 Reference Process

Command	Description
AT^ECLCFG=0,0,1	Sets the MSD retrieving mode to transparent, unmutes the speaker on the IVS side, and enables the eCall redial function.
OK	

Command	Description
OK ^ORIG: 1,0 ^CONF: 1 ^CONN: 1,0 ^ECLSTAT: 0 ^ECLSTAT: 1 ^ECLREC: "2014/10/17,01:51:05+32",0 ^ECLREC: "2014/10/17,01:51:05+32",0 ^ECLREC: "2014/10/17,01:51:06+32",0 ^ECLREC: "2014/10/17,01:51:06+32",0 ^ECLREC: "2014/10/17,01:51:07+32",0	<p>The eCall initiation request is sent to the eCall module.</p> <p>The eCall module initiates a voice call to the PSAP.</p> <p>The ringback tone is played.</p> <p>The voice call is answered.</p> <p>The IVS starts transmitting data frames to the PSAP.</p> <p>The PSAP confirms that the MSD is received. The IVS and PSAP switch to a normal voice call.</p> <p>The IVS receives the ALACK message from the PSAP.</p>
AT^ECLSTOP	The user must send AT^ECLSTOP to end the eCall. This is an asynchronous AT command. For more information, see section 24.6 Manual Initiation of eCall Emergency Calls.
OK ^CEND: 1, 28, 29, 16	<p>The eCall ending request is sent to the eCall module.</p> <p>The IVS hangs up the voice call.</p>

24.9 Automatic Initiation of eCall Test Calls by the Vehicle

The vehicle can automatically initiate a test call using eCall. The tested number is specified by the third parameter of **AT^ECLSTART**. In this case, a third parameter of **AT^ECLSTART** must be provided.

24.9.1 Reference Process

Command	Description
AT^ECLCFG=0,0	Sets the MSD retrieving mode to transparent, and unmute the speaker on the IVS side.

24.11 Unsolicited MSD Transmission by the IVS

24.11.1 Reference Process

Command	Description
AT^ECLSTART=0,0,"13903702987",0	After the call is set up, the IVS remains in PULL mode, and does not send MSD data to the PSAP actively.
OK ^ORIG: 1,0 ^CONF: 1 ^CONN: 1,0	After the command is executed, the IVS enters voice call state.
AT^ECLPUSH	The IVS triggers an MSD transmission request in unsolicited mode.
OK ^ECLSTAT: 0	After receiving the transmission request from the PSAP, the IVS transmits MSD data to the PSAP.

24.12 Unsolicited Report of eCall Redial Information

24.12.1 Reference Process

Command	Description
AT^ECLSTART=0,0	
ERROR ^ECLREDIAL: 0 ^ECLREDIAL: 1	 eCall redial starts. eCall redial fails.

24.13 Hanging Up eCall Voice Calls

To properly hang up eCall voice calls, use **AT^ECLSTOP**, which hangs up eCall voice calls (including the call initiated by the IVS and the callback by the PSAP) and deactivates eCall, so that the eCall session is terminated.

When the IVS deems that an eCall session needs to be terminated, the IVS must send **AT^ECLSTOP** to stop the eCall, even when the eCall voice call is hung up by the PSAP, so that to deactivate eCall from MT call waiting mode.



NOTE

IVS must not use **AT+CHLD** and **AT+CHUP** to hang up voice calls initiated by eCall. Although **AT+CHLD** and **AT+CHUP** can be used to hang up the call when eCall initiates a voice call, this method is incorrect. The call is hung up by the PSAP or the abnormal network, then the eCall module will enter MT call waiting mode. Therefore, all answered incoming calls within the next 12 hour will be deemed as eCall voice calls, and users will be requested to update the MSD.

25 Netscan Application Scenarios

25.1 Reference Process

Command	Description
AT^NETSCAN=2,-110	Gets the information about the two strong frequencies of the current network in GSM (default). The information includes frequency, cell reselection coefficient, location area code, MCC, MNC, base station code, and signal strength.
^NETSCAN: 15,,,4,460,09,5,-64 ^NETSCAN: 31,,,6,460,09,2,-100 OK	
AT^NETSCAN=2,-110,1	Scans WCDMA frequencies.
^NETSCAN: 9675,,,2513,234,15,0,-64,100190,800000 ^NETSCAN: 10688,,,A530,460,01,0,-77,1614A4E,400000 OK	
AT^NETSCAN=2,-110,2	Scans TDSCMA frequencies.
^NETSCAN: 10104,,,A734,460,00,0,-74,1D10231,1,55 ^NETSCAN: 10736,,,A777,460,00,0,-84,1D10414,1,40 OK	
AT^NETSCAN=2,-110,3	Scans LTE frequencies.
^NETSCAN: 39250,,,2799,460,00,0,-81,E201,8000000000,,66 ^NETSCAN: 38350,,,2799,460,00,0,-88,B501,4000000000,,487 OK	
AT^NETSCAN=?	Returns the range of parameters.

Command	Description
^NETSCAN: (1-20),(-110 - -47),(0-3)	
OK	

 **NOTE**

- The **AT^NETSCAN** command can be executed no matter whether the module has a SIM card or not.
- To avoid a potential conflict with normal module operations, it is strongly recommended that you not use this command such as "incoming call", "periodic location update", "periodic routing area update" etc..
- The **AT^NETSCAN** command is executed within a maximum of two minutes. During this time, if an AT command or a character is send from the same port, the **AT^NETSCAN** command will be aborted in 15s. Then other AT command can be run.
- After the lock function is enabled using **AT^FREQLOCK**, the module will only scan the locked frequency points. Therefore, if the frequency lock function has been enabled and then **AT^NETSCAN** is sent, **ERROR** will be returned.
- In WCDMA mode, using **AT^NETSCAN** to scan TD-SCDMA frequencies is not supported. As well, using **AT^NETSCAN** to scan WCDMA frequencies is not supported in TD-SCDMA mode.

25.2 Troubleshooting

Scenario	Possible Error Information	Solution
AT^NETSCAN=2,-110	+CME ERROR: operation not allowed	Disable the current data service, or wait a few seconds when the SIM card is busy.
AT^NETSCAN=2,-110	+CME ERROR: operation not allowed	Wait a moment or move to a place with good reception.
AT^NETSCAN=2,-110	OK	There is no GSM network.

26 Network Monitoring Application Scenarios

26.1 Application Background

If the network signal reception does not meet service requirements, use network monitoring to obtain information about the serving cell and neighboring cells. You can then use related functions to switch to an available neighboring cell to have a better service experience.

26.2 Reference Process

Command	Description
AT^MONSC	Obtains the information about the serving cell.
^MONSC: GSM,001,01,2,522,63,0,1,-66,99,0	
OK	
AT^MONNC	
^MONNC: GSM,1,124,0,0,1,-79	
OK	

The **AT^MONSC** command queries the parameters of the serving cell. If the module is using a WCDMA network, the command returns the following information depending on the state:

- In non-Dedicated state, the command returns the parameters of the resident cell.
- In Dedicated state, the command returns the parameters of the cell whose signal is the strongest among the active set.

The **AT^MONNC** command queries the parameters of the neighboring cells. If the module is using a WCDMA network, the command returns the following information depending on the state:

- In non-Dedicated state, the command returns the parameters of neighboring WCDMA cells.
- In Dedicated state, the command returns the parameters of all the cells, including the cells in the active set, cells in the monitored set, and neighboring cells.

After the module receives a system message from the serving cell, it measures the parameters of the neighboring cells based on the neighboring cell information contained in the message and the network status.

The number of measured neighboring cells depends on the serving cell. The maximum number of measured neighboring cells vary by standard. For details, see the AT command document.

26.3 Troubleshooting

Scenario	Possible Error Information	Solution
AT^MONSC	ERROR	The module has not camped on any cells. Run this command after the module camps on a cell.
AT^MONNC	ERROR	The module has not camped on any cells. Run this command after the module camps on a cell.
AT^MONNC	^MONNC: NONE OK	No neighboring cell is configured for the module's serving cell, or neighboring cell measurement is not available in the current network condition. Run this command a few comments later.

27 Cell Lock Application Scenarios

27.1 Application Background

The cell lock function restricts the region where services can be used. Currently, the services are the data service, voice service, and short message service (SMS).

27.2 Reference Process

Command	Description
AT^CELLLOCK=?	Obtains the value range.
^CELLLOCK: (0-1),(0-1),("0000"- "FFFF"),("00000000"- "FFFFFFFF"),("00000000"- "FFFFFFFF")("00000000"- "FFFFFFFF") OK	
AT^CELLLOCK?	Queries the activation status of cell lock.
^CELLLOCK: 0 OK	Cell lock is disabled.
AT^CELLLOCK=1,0,"00C3","00000001" "	Locks the module to cell 00000001 in the location area 00C3 in GSM mode.
OK	
AT^CELLLOCK=1,1,"00B3","00000001" "	Locks the module to cell 00000001 in the location area 00B3 in WCDMA mode.
OK	
AT^CELLLOCK?	Queries the activation status of cell lock.

Command	Description
<code>^CELLLOCK: 1,0,"00C3","00000001"</code> <code>^CELLLOCK: 1,1,"00B3","00000001"</code> <code>OK</code>	The module is locked to cell 00000001 in the location area 00C3 in GSM mode, and cell 00000001 in the location area 00B3 in WCDMA mode.

**NOTE**

- The cell lock settings take effect immediately. When the module is not in the region specified in the LAC+CI list, the module cannot initiate data, voice, and SMS services. Still, the module can receive voice calls initiated and short messages sent by the network.
- When cell lock is enabled and the module leaves or is outside the locked region, the module automatically disconnects the active dial-up connection.

27.3 Troubleshooting

None

28 FREQLock Application Scenarios

28.1 Application Background

The FREQLock function restricts the frequency of the cell from which the module receives services.

When this function is enabled, the module cannot perform inter-frequency reselection or handover, reducing the module's power consumption.

When this function is enabled and the module leaves the locked serving cell, the module cannot use any service network.

- In GSM mode, FREQLock can be used to lock the module to a specific frequency.
- In WCDMA mode, FREQLock can be used to lock the module to a specific frequency and primary scrambling code.
- In TD-SCDMA mode, FREQLock can be used to lock the module to a specific frequency and scrambling code.
- In LTE mode, FREQLock can be used to lock the module to a specific frequency and physical cell ID.

When the module is only locked to a specific frequency, it can reselect and switch to a cell with the same frequency.

28.2 Reference Process

Command	Description
AT^FREQLock?	Queries the activation status of FREQLock.
^FREQLock: 0,"01" ^FREQLock: 0,"02" ^FREQLock: 0,"03" ^FREQLock: 0,"04" OK	FREQLock is disabled in GSM, WCDMA, TD-SCDMA and LTE modes.

Command	Description
AT^SYSCFGEX="01",3FFFFFFF,1,2,7FFFFFFFFFFFFFFF,,	Sets the system mode to GSM only.
OK	
AT^FREQLOCK=1,"01",54,"01",,	Locks the module to frequency 54 at GSM 900 MHz.
OK	The command is executed successfully. If the specified frequency is not available in the current network environment, the module enters no service state.
AT^SYSCFGEX="02",3FFFFFFF,1,2,7FFFFFFFFFFFFFFF,,	Sets the system mode to WCDMA only.
OK	
AT^FREQLOCK=1,"02",10738,,,	Locks the module to frequency 10738 in WCDMA mode.
OK	
AT^FREQLOCK=1,"02",10738,,30,	Locks the module to frequency 10738 in WCDMA mode, with the scrambling code of 30.
OK	
AT^FREQLOCK?	Queries the FREQLock settings.
^FREQLOCK: 1,"01",54,"01",, ^FREQLOCK: 1,"02",10738,,30, ^FREQLOCK: 0,"03" ^FREQLOCK: 0,"04"	The module is locked to frequency 54 at GSM 900 MHz and frequency 10738 in WCDMA mode, with the scrambling code of 30.
OK	

 **NOTE**

- If you use **AT^FREQLOCK** to restrict the module to a frequency that is in a network mode different from the current network mode, the module does not automatically switch to that frequency. In this case, run **AT^SYSCFGEX** to set the system mode before running **AT^FREQLOCK**.
- In GSM, TD-SCDMA and LTE mode, FREQLock does not affect list search. In WCDMA mode, when FREQLock is enabled, list search only returns the cell information of the locked frequency.
- When FREQLock is enabled, running **AT^NETSCAN** command returns **ERROR**.
- When the module is being used for voice or data service, it will switch to the locked cell once it is locked to a cell other than the current serving cell. If the switch fails, manually switch the module to the locked cell when the module is idle.




28.3 Troubleshooting

Scenario	Possible Error Information	Solution
The number of input parameters or the parameter value is invalid.	ERROR	Refer to the AT command document.
The specified frequency and frequency band in GSM mode do not match, or the specified frequency in WCDMA is invalid.	ERROR	Set the frequency and scrambling code again.


29 MultiPDP Application Scenarios

29.1 Solution Overview

The module provides the MultiPDP function to allow multiple concurrent dial-up connections. With this function, the host computer can set up an ECM or modem dial-up connection while using the IPStack and FOTA services. In addition, when the IPStack, FOTA, and ECM or modem dial-up connections use the same APN, they can share a bearer. The host computer uses AT commands to initiate dial-up connections for different services.



When multiple host computers run AT commands to use the same APN to initiate dial-up connections for different services, the connections share a bearer.



29.2 Restrictions

- Only one PPP dial-up connection is supported.
- Only one IPStack connection is supported.
- If the number of concurrent PDP connections exceeds 3, the connection performance may be affected.
- You can use any values except 3 and 5 in the 0-11 range as the CIDs of ECM and modem dial-up connections.

The following table lists the restrictions when a bearer is shared.

	FOTA	IPStack	MODEM	ECM
FOTA	NA ^[3]	Y ^[1]	Y	Y
IPStack	Y	NA	Y	Y
MODEM	Y	Y	NA	N ^[2]
ECM	Y	Y	N	NA



NOTE

[1]: Y: Yes

[2]: N: No

[3]: NA: Not Applicable

When a bearer is shared, the protocol, local IP address, local IP port, remote IP address, and remote IP port used for the ECM or modem dial-up connection service is the same as those for the FOTA or IPStack service. As a result, the service to which the ports are allocated cannot be determined.

When a bearer is shared, services cannot be used at the same time. To use multiple services at the same time, customers' development is required.

29.3 Example

1. Power on the module.
2. After the host computer uses APN 1 for the IPStack service, the module establishes a PDP bearer and reports **OK** to the host.
3. After the host uses APN 2 to set up an ECM dial-up connection, the module establishes a PDP bearer, and the dial-up connection is set up.
4. After the host uses APN 3 to perform FOTA download and query, the module establishes a PDP bearer, and the download and query are performed.
5. The host computer attempts to disconnect the FOTA service. After the module initiates PDP context deactivation, the service is disconnected successfully without affecting the IPStack and ECM services.
6. The host computer attempts to disconnect the IPStack service. After the module initiates PDP context deactivation, the service is disconnected successfully without affecting the ECM service.
7. The host computer uses APN 1 for the IPStack service. The module reports OK to the host computer and does not initiate PDP context deactivation. The IPStack and ECM services share a bearer and both can work properly.
8. The host computer disconnects the IPStack service. The module reports OK to the host computer and does not initiate PDP context deactivation. The ECM service is not affected.

30 Recorder Application Scenarios

30.1 Setting Recording Options

30.1.1 Reference Process

Command	Description
AT^RECCFG=0,3	Sets the DSP sampling and compression format to 3 (AMR).
OK	
AT^RECCFG?	Obtains the current settings.
^RECCFG: 0,3 ^RECCFG: 1,5 OK	

30.1.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The operation is not supported.

30.2 Starting Recording

30.2.1 Reference Process

Command	Description
AT^AUDREC=1,"REC1.AMR"	Starts recording and save the recordings to the REC1.AMR file in the flash memory.
OK	
AT^AUDREC=0	Suspends the recording.
OK	
^AUDEND: 0,0,412	The recording ends, and ^AUDEND is reported.
AT^AUDREC=1,"RAM"	Starts recording and save the recordings to the RAM file in the RAM.
OK	
^AUDEND: 0,1,61440	The recording ends because the storage is full, and ^AUDEND is reported.



NOTE

- If recording files are stored in the RAM, the value of <file_name> is "RAM" by default. If recording files are stored in the flash memory, the value of <file_name> can be "REC1.AMR", "REC2.AMR", "REC3.AMR", "REC4.AMR", or "REC5.AMR", which are all capital letters.
- The flash memory can store 5 files whose total size must not exceed 300 KB (The actual recording time may vary with sampling rates).The recording stops when the size of recordings reaches 300 KB.
- The RAM memory cannot exceed 60 KB (The actual recording time may vary with sampling rates). The recording stops when the size of recordings reaches 60 KB.
- If <op> is set to 1 or 2, <file_name> cannot be left blank. If <op> is set to 0 or 3, <file_name> is not configurable.

30.2.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Error command parameters	The parameter is incorrectly set.
An error message is returned.	+CME ERROR: memory full	There is no free space for recording data storage.

30.3 Playing Recordings

30.3.1 Reference Process

Command	Description
AT^AUDREC=1,"REC1.AMR"	Starts playing data in the REC1.AMR file.
OK ^AUDEND: 1,1	The recording ends, and ^AUDEND is reported.
AT^AUDREC=1,"REC1.AMR"	Starts playing data in the REC1.AMR file.
OK	

 **NOTE**

If the recording you want to play is saved in RAM, make sure it is not read before you play it. Once read, the recording is automatically deleted.

30.3.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The operation is not supported.

30.4 Writing Recording Data on Other Devices to the Module

30.4.1 Reference Process

Command	Description
AT^FILEIO=2,"REC1.AMR",1,1,3,"AD2A3AB12BAD2A3AB12BAD2A3AB12B"	Writes the first packet to the module. (The file name indicates the file storage location, and the file type field is neglected here. There are three packets in total, and the first packet is written here.)
^FILEIO: 1,15 OK	The first packet is written.
AT^FILEIO=2,"REC1.AMR",1,2,3,"AD2A3AB12BAD2A3AB12BAD2A3AB12B"	Writes the second packet.

Command	Description
^FILEIO: 2,15 OK	The second packet is written.
AT^FILEIO=2,"REC1.AMR", 1,,3,3,"AD2A3AB12BAD2A3A B12BAD2A3AB12B"	Writes the third packet.
^FILEIO: 3,15 OK	The third packet is written.
AT^FILEIO=1,"REC1.AMR", 1,,0,100	Reads the 100-byte content in the REC1.AMR file in the flash memory.
^FILEIO: 15,15 "AD2A3AB12BAD2A3AB12B AD2A3AB12B" OK	The content in the REC1.AMR file is returned.



NOTE

- If the file to be read does not exist, an error is returned.
- If data is stored in the RAM, after a segment of data is read, it will be automatically deleted.
- If data is stored in RAM, the offset value must be set to 0. Otherwise, ERROR is returned.
- If the file to be deleted does not exist, OK is returned.
- The host sends 0x32 to the module, the module will just save 0x32. But **AT^FILEIO** needs to display the data, all characters will be encoded to ASCII. The ASCII codes of '3' and '2' are respectively "33" and "32", so the content of **AT^FILEIO** is 0x33 0x32. And the maximum length of each packet is 512 byte, if you need to write 300 KB data to the module, the host should totally send 600 packets.
- When **AT^FILEIO** is used to write data, the data must have AMR file header. If not, the module will consider the data is illegal and response **+CME ERROR: 65290** (amr file header lost).

30.4.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The operation is not supported.
An error message is returned.	+CME ERROR: memory full	There is no free space for recording data storage.
An error message is returned.	+CME ERROR: Error command parameters	The parameter is incorrectly set.

30.5 Deleting Recording Data of Other Devices from the Module

30.5.1 Reference Process

Command	Description
AT^FILEIO=3,"REC1.AMR"	Deletes the content from the REC1.AMR file in the flash memory.
OK	

**NOTE**

The recording data written to the module has the same file name as the module's recordings. Therefore, this command will also delete the recordings with the same name on the module.

30.5.2 Troubleshooting

Scenario	Possible Error Information	Solution
An error message is returned.	+CME ERROR: Operation not supported	The operation is not supported.

31 Appendix

31.1 Relative Documents

1. HUAWEI ME909s Series LTE Module AT Command Interface Specification
2. 3GPP TS 22.004 General on supplementary services
3. 3GPP TS 23.040 Technical realization of the Short Message Service (SMS)
4. 3GPP TS 24.008 Mobile radio interface Layer 3 specification; Core network protocols; Stage 3
5. 3GPP TS 27.005 Equipment (DTE-DCE) interface for Short Message Service (SMS) and Cell Broadcast Service (CBS)
6. 3GPP TS 27.007 AT command set for User Equipment (UE)
7. 3GPP TS 29.002 Mobile Application Part (MAP) specification
8. 3GPP TS 31.102 Universal Subscriber Identity Module (USIM) application
9. ETSI TS 102.221 Smart Cards; UICC-Terminal interface; Physical and logical characteristics

31.2 Acronyms and Abbreviations

Table 31-1 List of Abbreviations

Acronym or Abbreviation	Expansion
3GPP	Third Generation Partnership Project
APN	Access Point Name
AT	Attention
CS	Circuit Switched (CS) domain
DCE	Data Circuit Equipment
DTE	Data Terminal Equipment
FTP	File Transfer Protocol
GPRS	General Packet Radio Service



Acronym or Abbreviation	Expansion
GSM	Global System for Mobile Communications
HTTP	Hyper Text Transfer Protocol
IMEI	International Mobile Equipment Identity
IP	Internet Protocol
IVS	In-Vehicle System
ME	Mobile Equipment
MS	Mobile Station
MSD	Minimum Set of Data
PDP	Packet Data Protocol
PDU	Protocol Data Unit
PIN	Personal Identity Number
PPP	Point-to-Point Protocol
PUK	PIN Unblocking Key
PS	Packet Switched (PS) domain
PSAP	Public Safety Answering Point
QoS	Quality of Service
RSSI	Receive Signal Strength Indicator
SCA	Service Center Address
SIM	Subscriber Identity Module
SMS	Short Message Service
SMTP	Simple Mail Transfer Protocol
SSL	Secure Socket Layer
TE	Terminal Equipment
TLS	Transport Layer Security
UE	User Equipment
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USIM	Universal Subscriber Identity Module
WCDMA	Wideband CDMA



Table 31-2 Phonebook-related abbreviations

Abbreviation	Full Name
SM	SIM phonebook
EN	SIM emergency number
ON	SIM own numbers