



HUAWEI MC850/MC851 Media Phone

User Guide



HUAWEI

HUAWEI MC850/MC851 Media Phone
V100R001

User Guide

Issue	02
Date	2010-05-07
Part Number	803004

Huawei Technologies Co., Ltd. provides customers with comprehensive technical support and service. Please feel free to contact our local office or company headquarters.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: <http://www.huawei.com>

Email: terminal@huawei.com vcsupport@huawei.com


Copyright © Huawei Technologies Co., Ltd. 2010. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders under licenses.

Trademarks and Permissions



HUAWEI, **HUAWEI**, and  are trademarks or registered trademarks of Huawei Technologies Co., Ltd.

Other trademarks, product, service and company names mentioned are the property of their respective owners.

Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and may not be activated or may be limited by local network operators or network service providers. Thus the descriptions herein may not exactly match the product or its accessories you purchase.

Huawei Technologies Co., Ltd reserves the right to change or modify any information or specifications contained in this manual without prior notice or obligation.

NO WARRANTY

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO CASE SHALL HUAWEI TECHNOLOGIES CO., LTD BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

Import and Export Regulations

Customers shall comply with all applicable export or import laws and regulations and will obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

Contents

1 Safety Precautions	1
2 Product Overview	4
3 Preparations Before Use	7
3.1 Package Contents	7
3.2 Getting Started	8
3.3 Installing the Media Phone.....	10
3.4 Connecting to External Storage Devices	14
3.5 Powering On the Media Phone.....	15
4 Basic Operations	16
4.1 Home Screen	16
4.2 Input Methods	17
5 Call Features	20
5.1 Call Types	20
5.2 Making a Call.....	20
5.3 Answering a Call.....	21
5.4 Viewing Missed Calls	22
5.5 Operations During a Call.....	22
6 Phonebook	27
6.1 Accessing the Phonebook.....	27
6.2 Managing Groups.....	28

6.3 Searching for a Contact	30
6.4 Viewing the Memory of the Phonebook	30
6.5 Exporting and Importing a Phonebook	31
7 Call Log	32
7.1 Accessing the Call Log Screen	32
7.2 Viewing the Details of a Call Record	33
7.3 Making a Call from the Call logs	33
7.4 Deleting a Call Record	33
7.5 Adding a Number in the Call Log to an Existing Contact	34
7.6 Adding a Number in the Call Log to a New Contact	34
8 Information Browsing	35
8.1 Accessing or Exiting the Screen for Browsing	35
8.2 Playing Multimedia Files on the Media Phone	35
8.3 Playing Live Programs	38
8.4 Playing On-Demand Programs	39
8.5 Adjusting the Volume	41
9 Photo Frame	42
9.1 Viewing One Picture	43
9.2 Playing Pictures in Presentation Mode	43
9.3 Setting Photo Frame-Related Parameters	43
9.4 Importing Pictures	44
10 Other Functions	45
10.1 Tools	45
10.2 Viewing Equipment Information	46

10.3 Managing Files	47
11 User Settings	48
11.1 Setting Sound	48
11.2 Setting Sleep Mode	48
11.3 Setting the Network	49
11.4 Setting Wallpaper	53
11.5 Setting Date and Time	53
11.6 Setting Language	54
11.7 Setting Keypad Tone	54
11.8 Setting the Output Standard	54
11.9 Checking the Network Status	55
11.10 Managing Handsets	56
11.11 Managing the Telnet Connection	56
12 Handset Registration	57
12.1 Registering a Cordless Handset	57
12.2 Deregistering a Cordless Handset	58
13 Cordless Handset	59
13.1 Layout	59
13.2 Icons on the LCD	61
13.3 Preparations Before Use	61
13.4 Function of Making an External Call	62
13.5 Function of Making an Internal Call	63
13.6 Call Answering	64
13.7 Input Methods	64

13.8 Operations During a Call	65
13.9 Phonebook	66
13.10 Call Log	67
13.11 Configuration of Frequently Used Functions	68
13.12 Display Setting	71
13.13 Other Basic Settings	73
14 Software Upgrade.....	76
14.1 Automatic Upgrade.....	76
14.2 Manual Upgrade	76
15 Troubleshooting.....	77
16 Technical Specifications.....	80

1 Safety Precautions

For safety purposes, carefully read through these safety precautions and observe them during operation.

Basic Requirements

- Keep the device dry during storage, transportation, and operation of the device.
- Prevent collision of the device during storage, transportation, and operation of the device.
- Do not attempt to dismantle the device by yourself. In case of any fault, contact the appointed maintenance center for assistance or repair.
- Without prior written consent, no organization or individual is permitted to make any change to the structure or safety and performance design of the device.
- While using the device, observe all applicable laws, directives and regulations, and respect the legal rights of other people.

Environment Requirements

- Place the device in a well-ventilated place. Do not expose the device to direct sunlight.
- Keep the device clean, free of dust and stain.
- Do not place the device near a water source or in a damp area.
- Place the device on a stable surface.
- Do not place any object on the top of the device. Reserve a minimum space of 10 cm at the four sides of the device for heat dissipation.
- Do not place the device on or near inflammable materials such as foam.
- Keep the device away from heat source or fire, such as a radiator or a candle
- Keep the device away from any household appliances with strong magnetic field or electromagnetic field, such as microwave oven, refrigerator, or mobile phone.

Operation Requirements

- Do not allow children to play with the device or accessories. Swallowing the accessories may be fatal.
- Use the accessories such as the power adapter provided or authorized only by the manufacturer.

- Make sure that the device does not get wet. If water gets into the device, disconnect the power supply immediately and unplug all the cables connected to the device, such as the power cable, telephone cable, and then contact the appointed maintenance center.
- The power supply of the device must meet the requirements of the input voltage of the device.
- Before plugging or unplugging any cable, shut down the device and disconnect the power supply.
- While plugging or unplugging any cable, make sure that your hands are dry.
- Do not step on, pull, or overbend any cable. Otherwise, the cable may be damaged, leading to malfunction of the device.
- Do not use old or damaged cables.
- Keep the power plug clean and dry, to prevent electric shock or other dangers.
- During lightning, disconnect the device from the power supply, and unplug all the cables connected to the device, such as the power cable, telephone cable, to avoid lightning strike.
- If the device is not used for a long time, disconnect the power supply and unplug the power plug.
- In any of the following cases, stop using the device immediately, disconnect the power supply, unplug the power plug and other cables: smoke, sound, or smell is emitted from the device. Contact the appointed maintenance center for repair.
- Make sure that no object (such as metal shavings) enters the device through the heat dissipation vent.
- Do not scratch or abrade the shell of the device. The shed painting may lead to skin allergy or malfunctions of the device. If the shed painting material drops into the host, a short circuit may occur.
- Stop the USB device before removing it.

Cleaning Requirements

- Before cleaning the device, stop using it, disconnect the power supply, and unplug all the cables connected to the device, such as the power cable, telephone cable.
- Do not clean the device shell with any cleaning solution or cleanser spray. Use a piece of soft cloth to clean the device shell.

LCD Usage Requirements

- Do not expose the LCD surface to direct sunlight.
- Do not press, scratch, or beat the LCD, or place heavy objects on top of it.

- Do not stare at the display screen for a long time. This may harm your eyes or blur your vision.

LCD Cleaning Requirements

- According to the instructions given in the attached manual, use a piece of soft cloth to remove dust from the surface of the LCD.
- Do not clean the screen with volatile solvent, such as alcohol, benzene or dilution agent. Do not touch the screen with rubber or plastic material for a long time. This will deteriorate the surface gloss of the LCD.

Environmental Protection

Do not dispose the abandoned device in a garbage can. You need to dispose it according to the local regulations on disposing of device packing materials, exhausted battery and abandoned device, and support the recycling activity.

EU regulatory conformance



Hereby, Huawei Technologies Co., Ltd., declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.huaweidevice.com/certification.

2 Product Overview

Thanks for choosing the HUAWEI MC850/MC851 media phone (hereinafter referred to as the media phone).

This media phone meets your diversified requirements of broadband services perfectly.

The handset and the handset cord are available in the package of the MC851.

The digital cordless handset is available in the package of the MC850.

Novel Appearance and Structure

- **Integrated and streamlined appearance**

The color combination of the media phone, which is harmonious with home furnishings, reflects modernity and superior quality. Equipped with a high fidelity (hi-fi) speaker on the rear panel and a rotatable support whose rotating shaft is seamlessly integrated with the panel, the media phone is appealing and has a sleek appearance.

- **7-inch full touchscreen with an adjustable inclination angle**

The media phone boasts a 7-inch touchscreen with its resolution of 800×480 pixels. With embedded digital photo frame, player, and browser, the media phone provides you with perfect pictures, video, and information display. The touchscreen of the media phone is adjustable. You can change the angle between the touchscreen and the vertical direction from 0° to 35° by adjusting the support to five positions. Thus, the media phone can be used comfortably.

- **3-megapixel HD camera**

The media phone provides a built-in 3-megapixel high-definition (HD) camera that can record video clearly, thus meeting the requirements of video calls and service expansion in the future. The camera is specially designed, and can rotate at a 90° angle downward to hide itself or a 30° angle upward. Thus, the captured range is expanded and your privacy is protected.

Multiple Available Services and Functions

- **Making and receiving video calls and IP calls**

Even though your relatives and friends are thousands of miles away, the media phone enables you to feel the warmth that "a distant land is as near as in the neighborhood."

- **Modern functions of a digital photo frame**

The media phone supports the functions of a digital photo frame. You can play the pictures stored on the local memory of the media phone, an external universal serial bus (USB) device, a microSD card, or a MultiMediaCard (MMC) in presentation

mode. A picture with up to 10-megapixel resolution and 16 mega colors can be decoded properly.

- **One-touch web access**

The media phone provides shortcut icons on the desktop. Thus, you can directly access the portal Web site customized by the operator. The full-screen touch-sensitive browser enables you to browse contents as desired by touching the corresponding Web-site links.

- **Playing streaming media**

The media phone provides an embedded media player. By working with the streaming media system of the operator, the media player can be used to play streaming media programs customized on the relevant Web site. In addition, you can perform operations, such as fast-forwarding, rewinding, pausing, and playing a program, through the touchscreen or the remote control.

- **Playing multimedia files on the media phone**

You can play the multimedia files stored on the internal or external memory of the media phone, such as photos, audio clips, and video clips.

- **Digital cordless handset**

The digital cordless handset of the media phone can be used to dial external numbers. It provides an embedded phonebook and a large color liquid crystal display (LCD) with a user-friendly graphical user interface (GUI), which facilitates user operations.

- **Large-capacity storage of contacts and call records**

The media phone provides an embedded phonebook. A maximum of 2000 contacts can be saved to the phonebook and four numbers that include the mobile phone number, home number, office number, and fax number can be saved to each contact. In this case, detailed information about each contact can be saved. You can sort the contacts in the phonebook in alphabetical order, which facilitates the use of the phonebook. The media phone also supports the function of saving call records. A maximum of 100 dialed numbers, 100 received numbers, and 100 missed call numbers can be saved.

The media phone supports the phonebook synchronization. You can import phonebooks from multiple storage devices, such as a USB device or a microSD card, to the media phone or export the phonebook from the media phone to multiple storage devices.

- **Managing groups**

The media phone supports group management. You can create up to 20 groups, and then add contacts to different groups, which facilitates the search for contacts.

- **Multiple network access modes**

The media phone supports two modes for accessing an IP network. You can access an IP network through the Ethernet interface or Wi-Fi. When the Ethernet interface is used for network access, you can set a fixed IP address or configure the media

phone to obtain an IP address dynamically through the Dynamic Host Configuration Protocol (DHCP) or the Point-to-Point Protocol over Ethernet (PPPoE), thus meeting different networking requirements. When the Wi-Fi is used for network access, you can set a fixed IP address or configure the media phone to obtain an IP address dynamically through DHCP or the Point-to-Point Protocol (PPP).

User-Friendly Man-Machine Interaction

- **Full touchscreen**

The media phone provides a full touchscreen which is easy to use and a GUI with simple and self-explanatory icons.

- **Soft keyboard and handwriting mode**

The media phone provides an embedded soft keyboard. You can enter Chinese, English, and symbols through the soft keyboard by using the stylus. In addition, the soft keyboard is a full QWERTY keyboard that is easy to use. Apart from the soft keyboard, the media phone supports the handwriting mode. If you are not used to the soft keyboard, you can use the handwriting mode for text entry.




- The difference between the MC850 and the MC851 is as follows: The MC850 provides a digital cordless handset while the MC851 provides a handset with a cord.
- Unless otherwise specified, the functions described in this document apply to both the MC850 and the MC851.


3 Preparations Before Use

3.1 Package Contents


Once you have unpacked the package, check that you have all the following product components:




Base unit (one)



Network cable (one)




Telephone cable (one)




Power adapter (one)



Digital cordless handset (one, with one rechargeable battery, for the MC850)




Handset (one, for the MC851)



Handset cord (one, for the MC851)



User guide (one)









Audio cable (one)

3.2 Getting Started

Front Panel of the Base Unit


The following figure shows the front panel of the base unit.














No.	Item	Description
1		Camera. You can rotate the camera to adjust the angle.
2		Home key. Press to display the home screen.
3		Back key. Press to return to the previous screen.
4		Navigation keys. Press to highlight an item on the touchscreen. OK key. Press to confirm your operation or selected option.
5		Sleep key. Press to switch to sleep mode.
6	-	Remote control signal receiver used to receive the remote control signals.
7	-	Power-on indicator used to indicate whether the media phone is powered on or off. Event indicator used to indicate the equipment status.

Rear Panel and Side Panel of the Base Unit

The following figures show the rear and side panels of the base unit.




No.	Item	Description
1	-	Stylus used to select elements on the touchscreen and input information.
2 and 3	 USB 1  USB 2	USB ports used to connect USB devices.
4	 SD/MMC OPEN	Card slot for a microSD Card or an MMC.
5	 TEL	Telephone interface used to connect a common telephone.
6	 PC	PC interface used to connect to a computer. When a computer is connected to the media phone through this interface, the media phone functions as a hub in the network.
7	 LAN	LAN interface used to connect to a network access device.
8	 VIDEO OUT	Video output interface used to connect to the external equipment (such as a television) and then output videos.

No.	Item	Description
9	  ---+12V; 1.5A	Power adapter interface used to connect to external power.
10	-	Power button. Press to power on or off the media phone.
11		Volume control keys. Press to adjust the volume of the sound.
12	-	Stereo sound speaker.
13	-	Support used to adjust the inclination angle of the base unit.
14		Headset jack.

3.3 Installing the Media Phone

Connecting Cables

The following figure shows the cable connections.





- Before connecting the power adapter, ensure that all the cables are connected properly and that the media phone is powered off.
- Use the power adapter provided with the media phone for the connection.


To connect the cables, do as follows based on the preceding figure:

- Step 1** Connect the handset to the base unit with the handset cord. (When you are connecting cables for the MC850, skip this step.)
- Step 2** Connect the LAN interface on the media phone to an external network interface (such as the network interface on the rear panel of the home gateway) with the network cable.
- Step 3** Connect the TEL interface on the media phone to an external telephone interface with the telephone cable.
- Step 4** Connect the $+ \text{Ⓢ} -$ power interface on the media phone to the alternating current (AC) power socket with the power adapter.

Installing the Battery

A digital cordless handset is provided with the MC850. Install the battery before using your handset.

The following figure shows how to install the battery.




To install the battery, do as follows:

- Step 1** Slide the battery cover down to remove it.
- Step 2** Insert the battery into the battery compartment.
- Step 3** Plug the battery connector into the receptacle in the battery compartment.
- Step 4** To replace the battery cover, slide the cover up until it snaps in place.


Placing the Media Phone

The support located on the rear panel of the media phone is rotatable. You can rotate it to a proper angle based on your actual requirement.




When rotating the support, do not exert too much strength to prevent any damage to the support.

If you are using the MC850, after you arrange the base unit properly, place the digital cordless handset directly on the base unit, as shown in the following figure.



If you are using the MC851, after you arrange the base unit properly, place the handset directly on the base unit, as shown in the following figure.



Connecting to a Wi-Fi Network




The media phone supports two modes for accessing a broadband network: through a wired network or through a wireless network. By using the Wi-Fi function, you can access a broadband network through a wireless network.

Before accessing the Wi-Fi network, check the following:

- Your network access device (such as a home gateway) supports the Wi-Fi function and allows access of wireless devices.
- Between the media phone and the wireless access device to be connected, there is no obstacle and the distance is within the coverage of the Wi-Fi signals of the device.



After accessing the Wi-Fi network, you will see an icon indicating the Wi-Fi signal strength in the status bar on the top of the touchscreen. The following table describes the icons for signal strengths.


Icon	Description
	Wi-Fi signal: strong  weak
	There is no Wi-Fi signal.

3.4 Connecting to External Storage Devices

The media phone provides interfaces for connecting to external storage devices, such as a USB device, a SIM card, an MMC, and a microSD card. You can import media files and phonebooks from the storage devices to the media phone or export media files or the phonebook from the media phone to the storage devices.

Connecting to a USB Device


To connect a USB device to the media phone, insert the USB device to a USB port on the rear panel of the media phone, as shown in the following figure.



- When you are inserting a USB device, ensure that the connector of the device is aligned with the port of the base unit. Otherwise, the device may fail to be inserted.
- To avoid any damage to the USB device, do not place the base unit horizontally after the device is inserted and ensure that no external forces are applied to the device.

Installing a microSD Card or an MMC

The following figure shows how to install an MMC and a microSD card.



To install an MMC, or a microSD card, do as follows:


Step 1 Open the SD/MMC cover on the rear panel of the media phone.

Step 2 Slide the MMC or microSD card in the corresponding card slot (the microSD card needs to be inserted into a card holder before being slid in the card slot.)

To remove an MMC or a microSD card, push it in the slot and then release it. After the card ejects, take it away. If you fail to take away the card barehanded after it ejects, use a small tool such as tweezers.

3.5 Powering On the Media Phone

Connect the power adapter, and then press the power button on the rear panel of the media phone, as shown in the following figure. When the power-on indicator is on, it indicates that the media phone is powered on properly.



4 Basic Operations





4.1 Home Screen








1: Status bar (in which the status icons are displayed)

Descriptions of Status Icons in the Status Bar

The following table lists the status icons and their descriptions in the status bar on the top of the home screen.




Icon	Description
	The network cable is disconnected. Please check whether the network cable is connected to the LAN interface on the base unit properly.
	The network cable is connected properly and the network connection is being set up, or the network cannot be accessed. Please check whether the network settings are correct.
	The network connection is proper. The media phone is not registered with a server.
	There is a missed call. Tap the icon to display the Missed screen.


Icon	Description
	A cordless handset or multiple cordless handsets registered with the base unit are in a call.
	A microSD card is inserted.
	A USB device is connected. The digit on the icon indicates the USB port (USB1 or USB2) to which the USB device is connected.
	The Wi-Fi network is connected. The number of vertical bars on the icon indicates the Wi-Fi signal strength. The more the vertical bars, the stronger the signals.
	The network is set to be accessed through Wi-Fi in the network settings, but no Wi-Fi signal is detected.

4.2 Input Methods

The media phone provides input methods for upper-case letters, lower-case letters, digits, and symbols. In addition, the media phone supports the handwriting mode.





After you select a text box (except on the screen for entering numbers), the icon of the current input method is highlighted in blue at the bottom of the screen. By default, the input method for lower-case letters is highlighted in blue, as shown in the following

figure. Tap , , and  to switch the input method to the handwriting mode, the input method for lower-case letters, and the input method for digits and symbols respectively.




The icons below the text box enable you to switch between different input methods. Select the icon corresponding to the input method you want to highlight the icon in blue. **Write** indicates the handwriting mode. **abc** indicates the input method for lower-case letters. (To switch to the input method for upper-case letters, tap **Aa**.) **123,.** indicates the input method for digits and symbols.

Handwriting Mode


When you are using the handwriting mode, you can enter text directly by tapping the touchscreen using the stylus or your finger. When the icon of the handwriting mode is highlighted in blue () below the text box, candidate Chinese characters will appear automatically on the screen. You can tap  or  to go to the previous or the next page, and tap  to delete the character immediately to the left of the cursor.

Input Method for Letters


Tap  below the text box to highlight the icon in blue. In this way, the input method is switched to the one for lower-case letters.

When you are using the input method for lower-case letters, you can perform the following operations:

- Tap the button that carries the letter you want to enter.

- Tap  on the left side of the onscreen keyboard to switch between the upper case and the lower case.

Input Method for Digits and Symbols

Tap  to highlight the icon in blue. In this way, the input method is switched to the one for digits and symbols.

When you are using the input method for digits and symbols, tap the button that carries the digit or symbol you want to enter.

Mini Keyboard

If text to be entered contains only lower-case letters, digits, or symbols, you can use the mini keyboard provided with the media phone. On the mini keyboard, you can tap

 to delete a character and  to hide the mini keyboard.



5 Call Features

5.1 Call Types

You can use the media phone to make audio or video calls.


Call Type	Features	Usage
Video call	During a video call, you can hear and see the video of the other party.	This function can be used after the network cable is connected and the media phone is registered successfully.
Audio call	During an audio call, you can only hear the other party.	This function can be used after the network cable is connected and the media phone is registered successfully.

5.2 Making a Call


Making a Call by Dialing

If you know the number of the other party, to make a call, perform either of the following operations:

Using the Handset

Press the number keys on the handset to enter the number you want to call, and then press .

Using the Base Unit


Access the home screen, tap  to display the dialer screen, enter the number you want to call, and then tap **Video Call** or **Audio Call** as required.

Making a Call from the Phonebook

If a contact is saved to the phonebook, you can call the contact from the phonebook.

To access the phonebook, you can use either of the following two methods:



- On the home screen, tap  .
- On the dialer screen, tap **Contacts**.


On the **Contacts** screen, find the contact you want to call. For details, see "Searching for a Contact" on page 30. And then tap **Audio Call** or **Video Call** as required.

Making a Call from the Call Log

If you want to dial a number saved in the call log, such as missed calls, you can make the call from the **Call Log** screen.

To access the call log, you can use either of the following methods:



- On the home screen, tap  .
- On the dialer screen, tap **Call Log**.

The screens accessed by using different methods are slightly different. For details, see "Accessing the Call Log Screen" on page 32.


Enter the number you want to call on the screen and then tap **Audio Call** or **Video Call** as required.

Calling a Handset

You can use the base unit to call any of the registered handsets.

To call a handset, do as follows:




- Step 1** Tap  on the home screen to display the dialer screen.
- Step 2** Tap **Interphone** to display the **Select Interphone** screen.
- Step 3** Select the handset you want to call, and then tap **Select**.
- Step 4** Wait for the call to be answered.

5.3 Answering a Call


The media phone rings when a call is received.

If you have subscribed to the calling number identification service, the calling number appears on the screen. (If the calling number is saved to the phonebook, the name and the number of the calling party appear on the screen.)


Answering a Video Call

- To answer a video call in video mode, tap **Video** on the touchscreen.
- To answer a video call in audio mode, do any of the following:
 - If you are using a MC850 handset, press  on the handset.
 - If you are using a MC851 handset, pick up the handset.
 - If you want to answer an incoming call in hands-free mode, tap **Audio** on the touchscreen.
- To reject an incoming call, tap **Reject** on the touchscreen.
- To mute ringing, tap **Mute** on the touchscreen. The incoming call will not be rejected when the ringtone is muted.

Answering an Audio Call


- To answer an audio call, do any of the following:
 - If you are using a MC850 handset, press  on the handset.
 - If you are using a MC851 handset, pick up the handset.
 - If you want to answer an incoming call in hands-free mode, tap **Accept** on the touchscreen.
- To reject an incoming call, tap **Reject** on the touchscreen.
- To mute the ringtone, tap **Mute** on the touchscreen. The incoming call will not be rejected when the ringtone is muted.



5.4 Viewing Missed Calls

If there is any missed call, the icon  will appear on the home screen. You can tap the icon to display the screen for missed calls and view details. You can perform many operations on that screen. For details, see "Call Log" on page 32.

5.5 Operations During a Call

The following table lists the icons and their descriptions on the screen for calling.

Icon	Description
	The media phone is in hands-free mode.

Icon	Description
	The speaker is muted.
	The microphone is muted.

During a call, you can either tap the screen or press a button on the right side of the base unit to display the menu bar for call-related operations. Tap **Full screen** to switch the layout into full screen. The menu bar hides automatically if you do not perform any operations for a certain period of time.

Easy Switch

The media phone provides the service of easy switch. During a call, you can switch between a video call and an audio call.



The service of easy switch requires the support from the local service provider. Therefore, before using this function, contact your service provider to check whether the service of easy switch is supported.

Switching a Video Call to an Audio Call

Tap **Audio** to switch the video call to an audio call.

Switching an Audio Call to a Video Call

During an audio call, you can tap **Video** to initiate a video call or tap the corresponding button to answer the video call.

Switching a Call on the Cordless Handset to a Video Call


If you are in an IP call using the cordless handset, you can answer only a video call. The voice is still processed through the handset after the video call is set up. To initiate a video call, you need to initiate a three-party conference with a media phone as a participant. For details, see steps 1 to 3 of "Switching Cordless-Handset Speaking Mode to Hands-free Mode" in "Turning On/Off the Hands-free Function During a Call" on page 24. After the switch, tap **Video** to initiate a video call.



- For details about how to enable the voice to be processed through the base unit after you answer a video call, see "Switching Cordless-Handset Speaking Mode to Hands-free Mode" in "Turning On/Off the Hands-free Function During a Call" on page 24.
- After you answer a video call, if you do not switch the voice processing to the base unit, the call will be hung up once you put down the handset.

Adjusting the Volume of the Speaker During a Call





During a call, you can adjust the volume of the speaker by either pressing  on the right-side panel of the base unit or tapping **Vol+** or **Vol-** on the menu bar for call-related operations. Then, the touchscreen of the base unit displays the effect of the volume adjustment.

Turning On/Off the Hands-free Function During a Call



During a call, you can tap **Handsfree** to turn on or off the hands-free function.

Switching Between Handset Speaking and Hands-free Modes for the MC851

When you are in a call using the handset, you can tap **Handsfree**, and then put down the handset to turn on the microphone and the speaker. The media phone is then in hands-free mode. The icon  then appears on the screen.

When the media phone is in hands-free mode, you can pick the handset to speak through the handset. The icon  then appears on the screen.

Switching Cordless-Handset Speaking Mode to Hands-free Mode


During a call, you can tap Cordless-Handset icon, such as , to switch to the hands-free mode. The icon  then appears on the screen.

Switching Hands-free Mode to Cordless-Handset Speaking Mode

For details, see "Transfer a Call" on page25.

Switching Between Local Video and Remote Video During a Call

During a video call, you can switch between the local video and the remote video.



Three-party calling

During a call, you can call the cordless handset to set up a three-party call.

To set up a three-party call, do as follows:

- Step 1** During the call, tap **Interphone**.
- Step 2** Choose the handset as required.
- Step 3** Tap **Three-party calling**.
- Step 4** Wait for the call to be answered.



To set up a three-party call on a cordless handset, see "Setting up a Three-Party Calling" on page 64.

Transfer a Call

During a call, you can transfer the call to the handset.

To transfer the call to the handset, do as follows:

- Step 1** During the call, tap **Interphone**.

Step 2 Choose the handset as required.

Step 3 Tap **Transfer**.

Step 4 Wait for the call to be answered.



To switch a call on the cordless handset to that on the base unit, see "Performing Call Transfer" on page 64.

Full Screen


During a video call, you can switch the layouts on the screen. Specifically, the following layouts are provided:

- **Full screen:** With this layout, the video is displayed in full screen, and the menu gets hidden automatically. Tapping the screen can enable opening the menu.
- **4:3:** With this layout, the video is presented, along with the menu on the right of the screen, with the proportion of the video to the menu being 4:3 on the screen.
- **Initial size:** With this layout, the video is displayed according to the original video proportion, and the menu gets hidden automatically. Tapping the screen can enable opening the menu.

Turning On/Off the Dialer During a Call

Sometimes you may need to dial a number during a call. For example, during the call to a bank for querying information, you may need to dial numbers by following the instructions of the IVR announcement. In that case, tap **Dialer** on the menu bar for call-related operations to display the dialer window. Then enter the number as required, and then tap either **Close** in the dialer window or **Dialer** on the menu bar for call-related operations to exit the dialer window.

Turning On/Off the Microphone

During a call, you can tap **Mic Off** to turn off the microphone. The icon  then appears on the screen, and the other party of the call cannot hear you.

To turn on the muted microphone, tap **Mic On**. The icon  then disappears.

Switching Between Day Mode and Night Mode

During a call, you can tap **Night mode**, then when ambient light is low, the screen automatically reduces brightness.



In the night mode, tap **Day mode**, the screen brightness according to a fixed display.

6 Phonebook





6.1 Accessing the Phonebook

You can save up to 2000 contacts to the phonebook of the media phone. In addition, you can save up to four numbers to each contact.

To access the phonebook, you can choose any of the following methods:

- Tap  on the home screen.
- Tap  on the home screen to display the list of functions, and then tap **Contacts**.

The following table lists the icons and their descriptions in the phonebook.

Icon	Description
	Mobile phone number
	Home number
	Office number
	Fax number

Creating a Contact

To create a contact, do as follows:

- Step 1** Access the **Contacts** screen, and then tap **New**.
- Step 2** On the **New** screen, tap the **Name** text box.
- Step 3** Enter the contact name.
- Step 4** Tap **OK** to save the name and exit.
- Step 5** On the **New** screen, tap the group drop-down list, and then select a group. (See "Managing Groups" on page 28.)
- Step 6** Tap the text box corresponding to the number type as required (mobile, home, office, or fax).

- Step 7** Tap digits to enter the number.
- Step 8** Tap **OK** to save the number and exit.
- Step 9** Tap **Save** to complete the operations for creating a contact.

Editing a Contact

If you want to edit a contact, for example, to delete a number of the contact, do as follows:

- Step 1** Access the **Contacts** screen, and then find the contact whose information you want to change (for details, see "Searching for a Contact" on page 30).
- Step 2** Tap **Detail**.
- Step 3** On the **Detail** screen, tap **Edit**.
- Step 4** Change the information of the contact on the **Edit** screen. For details, see "Creating a Contact" on page 27.
- Step 5** Tap **Save** to complete the operations for changing information of the contact.

Deleting One Contact

To delete one contact, do as follows:

- Step 1** Access the **Contacts** screen, and then find the contact you want to delete (for details, see "Searching for a Contact" on page 30).
- Step 2** Tap **Detail**.
- Step 3** On the **Detail** screen, tap **Delete**.
- Step 4** Tap **Yes** on the displayed dialog box to complete the operations for deleting the contact.

Deleting All the Contacts

To delete all the contacts, do as follows:

- Step 1** Access the **Contacts** screen, and then tap **Options**.
- Step 2** On the **Options** screen, tap **Delete All**.
- Step 3** Tap **Yes** on the displayed dialog box to complete the operations for deleting all the contacts.

6.2 Managing Groups

The media phone provides the management function for contact groups. You can create up to 20 groups, and then add contacts to different groups.

The default group **Blacklist** in the media phone cannot be deleted. You can change the ringtone for the group, but not the group name. If there is an incoming call from a contact in the blacklist group, you will not receive prompts to answer the call, and the caller is prompted that you are busy.


Creating a Group

To create a group, do as follows:

- Step 1** Access the **Contacts** screen, tap **Options**, and then tap **Group**.
- Step 2** On the **Group** screen, tap **New**.
- Step 3** On the **New** screen, tap the **Group name** text box to enter a name for the group you want to add (for details, see "Input Methods" on page 17).
- Step 4** Tap **OK** to save the name.
- Step 5** Tap the **Ringtone** drop-down list to choose a ringtone for the group.
- Step 6** Tap **Save** to save the settings.

Editing a Group

To edit a group, do as follows:

- Step 1** Access the **Contacts** screen, tap **Options**, and then tap **Group**.
- Step 2** On the **Group** screen, scroll to the group to be edited by using the scroll bar on the right, and then tap **Edit**.
- Step 3** On the **Edit** screen, tap the **Group name** text box.
- Step 4** Tap  to delete the original group name, and then enter a new name for the group (for details, see "Input Methods" on page 17).
- Step 5** Tap **OK** to save the changed name.
- Step 6** Tap the **Ringtone** drop-down list to change the ringtone for the group.
- Step 7** Tap **Save** to save the settings.

Deleting a Group

To delete a group, do as follows:

- Step 1** Access the **Contacts** screen, tap **Options**, and then tap **Group**.
- Step 2** On the **Group** screen, scroll to the group to be deleted by using the scroll bar on the right, and then tap **Delete**.
- Step 3** Tap **Yes** on the displayed dialog box to complete the operations for deleting the group.



Deleting a group will not delete the contacts in the group.

Changing the Group to which a Contact Belongs

To change the group to which a contact belongs, do as follows:

- Step 1** Access the **Contacts** screen, and then find the contact that you want to add to a group (for details, see "Searching for a Contact" on page 30).
- Step 2** Tap **Edit**.
- Step 3** Tap the **Group** drop-down list to select the group to which you want to add the contact.
- Step 4** Tap **Save** to save the settings.

6.3 Searching for a Contact

To search for a contact, you can choose either of the following methods:

Searching Directly

Access the **Contacts** screen, and then use the scroll bar on the right to find the required contact. This method can be used when the number of contacts in the phonebook is not large.

Search by Keywords

- Step 1** Access the **Contacts** screen, and then tap the text box on the top of the screen. A mini keyboard then appears on the screen.
- Step 2** Enter the characters of the name of the required contact (for details, see "Mini Keyboard" on page 19).
- Step 3** The entered text then leads you to the required contact which is highlighted.

6.4 Viewing the Memory of the Phonebook


Access the **Contacts** screen, tap **Options**, and then tap **Memory Status**.

6.5 Exporting and Importing a Phonebook

You can import a phonebook from an external storage device (such as a USB device, a microSD card, or an MMC) to the media phone or export the phonebook from the media phone to an external storage device.


Importing a Phonebook

To import records to the phonebook, do as follows:

- Step 1** Tap  on the home screen to display the list of functions.
- Step 2** Tap **Import/Export** to display the **Import/Export** screen.
- Step 3** Tap **Copy From** to display the **Select Device** screen.
- Step 4** Select the external storage device where the phonebook to be imported is saved, and then tap **Select** to display the **Select Import Mode** screen.
- Step 5** Choose an import mode. If you tap **Overwrite**, the existing phonebook on the media phone will be deleted. If you tap **Add**, the existing records in the phonebook will remain unchanged.
- Step 6** Tap **Select** to complete the operations for importing a phonebook.

Exporting a Phonebook

To export a phonebook, do as follows:



- Step 1** Tap  on the home screen to display the list of functions.
- Step 2** Tap **Import/Export** to display the **Import/Export** screen.
- Step 3** Tap **Copy To** to display the **Select Device** screen.
- Step 4** Select an external storage device to save the phonebook, and then tap **Select**.
- Step 5** If a phonebook already exists in the external storage device, a dialog box asking you "Overwrite?" appears. If you tap **Yes**, the phonebook is then exported. If you tap **No**, the exporting is not completed.

7 Call Log

The call log includes missed calls, received calls, and dialed numbers.




7.1 Accessing the Call Log Screen

To access the call log screen you can use either of the following methods:



- On the home screen, tap  to display the **Call logs** screen.
- On the home screen, tap  to display the dialer screen. Then tap **Call logs** to display the **Call logs** screen.

The screens accessed by using the preceding two methods are slightly different. The numbers on the **All** screen are classified into three categories. By tapping **Missed**, **Answered**, and **Dialed** on the top of the screen, you can view the details of missed calls, received calls, and dialed numbers respectively. The numbers on the **Call logs** screen are sorted in time sequence but not by categories.

The following table lists the icons and their descriptions on the **All** screen.

Icon	Description
	Missed call
	Received call
	Dialed number

The following table lists the icons and their descriptions on the **Call Log** screen.

Icon	Description
	IP call
	Video call

7.2 Viewing the Details of a Call Record

To view the details of a call record, you can choose either of the following methods:

Viewing Directly

- Step 1** Access the **Call Log** screen, and then scroll to the number whose details you want to view by using the scroll bar on the right.
- Step 2** Tap the required number to display the **Detail** screen and view the details.

Viewing by Types

- Step 1** Access the **Call logs** screen, tap **All**, **Missed**, **Answered**, or **Dialed** as required, and then use the scroll bar on the right to scroll and view the numbers.
- Step 2** Tap the required number to display the **Details** screen and view the details.

7.3 Making a Call from the Call logs

To make a call from the call log, do as follows:

- Step 1** Access the **Call logs** screen or the corresponding screen for a specific type of calls.
- Step 2** Tap **Video Call** or **Audio Call** to choose the call type, and then make a call.

7.4 Deleting a Call Record

Deleting One Call Record

To delete one call record, do as follows:

- Step 1** Access the screen for the specific type of the call.
- Step 2** Use the scroll bar on the right of the screen to scroll and select the number.
- Step 3** Tap the required number, and then tap **Delete**.
- Step 4** In the displayed dialog box, tap **Yes**.

Deleting All the Call Records

To delete all the call records, do as follows:

- Step 1** Access the screen for a specific type of calls.

Step 2 Tap **Options** to display the **Options** screen.

Step 3 Tap **Delete All**.

Step 4 In the displayed dialog box, tap **Yes**.

7.5 Adding a Number in the Call Log to an Existing Contact

To add a number in the call log to an existing contact, do as follows:

Step 1 Access the screen for a specific type of calls, and then use the scroll bar on the right to scroll and select the number.

Step 2 Tap **Save**, and then tap **Update** to display the **Update** screen.

Step 3 Use the scroll bar on the right of the screen to scroll and select the contact against whom you want to add the number.

Step 4 Tap **OK** to confirm the selected contact and display the **Add to original entry** screen.

Step 5 Tap the **Type** drop-down list to choose a type for the number.

Step 6 Tap **Save**.

7.6 Adding a Number in the Call Log to a New Contact

To add a number in the call log to a new contact, do as follows:

Step 1 Access the screen for a specific type of calls, and then use the scroll bar on the right to scroll and select the number.

Step 2 Tap **Save**, and then tap **New** to display the **New entry** screen.

Step 3 Tap the **Name** text box.

Step 4 Enter a name for the contact (for details, see "Input Methods" on page 17).

Step 5 Enter the number of the contact (for details, see "Input Methods" on page 17).

Step 6 Tap the **Type** drop-down list to choose a type for the number.

Step 7 Tap the **Group** drop-down list to choose a group for the contact.


Step 8 Tap **Save**.


8 Information Browsing

8.1 Accessing or Exiting the Screen for Browsing

On the media phone, you can browse the customized web pages provided by operators to view information, watch live programs, and schedule on-demand audio-visual programs.

To access the screen for browsing, you can use either of the following methods:

Tap  on the home screen.

To return to the home screen, press  on the base unit.



This service is provided by service providers. For details, please contact your service provider.

8.2 Playing Multimedia Files on the Media Phone

On the media phone, you can play multimedia files (including videos and music) stored on the phone, a USB device, a microSD card, and an MMC.

The media phone supports the following file formats:

- MP3
- WAV
- AVI
- MP4












AVI and MP4 are two video formats that support the following encoding combinations: H264 + MP3, MPEG4 + MP3, H264 + AAC, and MPEG4 + AAC.

During the playback of the multimedia file, you can tap the touchscreen to display the menu for playback control, as shown in the following figure.




The following table lists the icons and their functions on the screen.

No.	Icon	Description
1		It indicates that the playing is paused.
		It indicates that the playing is stopped.
		It indicates that the playing is finished.
2	-	It indicates the current volume. You can drag the bar to adjust the volume.
3		It indicates that the speaker is muted.
		It indicates that the speaker is not muted.
4	-	It indicates the total duration of the file.
5		It is used to go back to the upper-level menu.
6		It is used to display the file list. You can select a file from the list to play.
7		It is used to switch the playing mode between full screen and part screen. This icon functions only when the file is a video. When the audio file is playing, this icon is in gray and does not respond to your tapping.
8		It is used to play all the files in the file list, but not in a repetitive way.
		It is used to repeat the playing of the current file.


No.	Icon	Description
		It is used to play the current file for once.
		It is used to play all the files in the file list in an order repetitively.
9		It is used to start playing the next file in the file list.
10		It is used to start playing the previous file in the file list.
11		It is used for fast-forwarding by 20 seconds.
12		It is used for rewinding by 20 seconds.
13		It is used to stop playing.
14		It is used to start playing.
		It is used to pause playing.
15	-	It is the playing progress bar. The blue part indicates the content that has been played. You can drag the end of the progress bar on the touchscreen to a specific point from which you want the playing starts.
16	-	It indicates how long the current file has been played.

Starting the Player on the Main Screen

To start the player, tap  on the home screen. If the player starts for the first time, it plays all the music files in the local folder. Otherwise, it plays the music that was played when the player was shut down last time.

Starting the Player in the File Manager

To start the player in the file manager, do as follows:

- Step 1** Insert a USB device to the **USB1** or **USB2** port on the roller of the rear panel of the base unit.
- Step 2** Insert a microSD card or an MMC to the SD/MMC interface on the top of the rear panel of the base unit.
- Step 3** Tap  on the home screen to display the list of functions. Then tap **My Files** to view files including music, pictures, and videos stored on the phone,

USB device, microSD card, or MMC. (For details, see "Managing Files" on page 47.)



If you want to view only the local files, perform **Step 3**.

8.3 Playing Live Programs






To play live programs, you require the support from local service providers. Therefore, before watching the live programs, you need to contact your service provider to check whether this service is activated.

When watching a live program, you can tap the screen to display the menu for playback control, as shown in the following figure.



The following table lists the icons and their functions on the screen.

No.	Icon	Description
1	-	It indicates the current volume. You can drag the bar to adjust the volume.
2		It indicates that the speaker is muted.
		It indicates that the speaker is not muted.
3		It is used to go back to the upper-level menu.
4		It indicates that the current audio channel is the left audio channel.
		It indicates that the current audio channel is the right audio channel.

No.	Icon	Description
		It indicates that the current audio channel is dual audio channels.
5		It is used to switch the playing mode between full screen and part screen.
6		It is used to switch to the next channel (only for IPTV programs).
7		It is used to switch to the previous channel (only for IPTV programs).
8		It is used to return to the customized home page.



8.4 Playing On-Demand Programs













The service of playing on-demand programs requires support from local service providers. Therefore, before watching on-demand programs, you need to contact your service provider to check whether this service is activated.

When watching an on-demand program, you can tap the screen to display the menu for playback control, as shown in the following figure.




The following table lists the icons and their functions on the screen.

No.	Icon	Description
1		It indicates that the playing is paused.
		It indicates that the playing is stopped.

No.	Icon	Description
		It indicates that the playing is finished.
2	-	It indicates the current volume. You can drag the bar to adjust the volume.
3		It indicates that the speaker is muted.
		It indicates that the speaker is not muted.
4	-	It indicates the total duration of the program.
5		It is used to stop playing.
6		It indicates that the current audio channel is the left audio channel.
		It indicates that the current audio channel is the right audio channel.
		It indicates that the current audio channel is dual audio channels.
7		It is used to switch the playing mode between full screen and original size screen. This icon functions only when the file is a video. When the audio file is playing, this icon is in gray and does not respond to your tapping.
8		It is used to fast forward a program at a 2x/4x/8x/16x/32x rate.
9		It is used to fast rewind a program at a 2x/4x/8x/16x/32x rate.
10		It is used to start playing.
		It is used to pause playing.
11	-	It is the playing progress bar. The blue part indicates the content that has been played. You can drag the end of the progress bar on the touchscreen to a specific point from which you want the playing starts.
12	-	It indicates how long the current program has been played.


8.5 Adjusting the Volume











During the playback of files, you can adjust the volume by either pressing  on the right panel of the base unit or dragging the volume bar in the menu for playback control on the screen.



9 Photo Frame

The media phone supports the functions of a digital photo frame, which enables you to view the pictures stored on the memory of the media phone, a USB device, a microSD card, or an MMC, or to play the pictures in presentation mode.




The following table lists the icons and their functions on the screen.

No.	Icon	Description
1	-	It indicates the sequence number of the current picture and the total number of pictures in the folder.
2		It is used to go back to the upper-level menu.
3		It is used to set parameters associated with playing pictures in presentation mode. For details about the setting, see "Setting Photo Frame-Related Parameters" on page 43.
4		This icon is not available in presentation mode. When you are viewing a picture, you can use this icon to delete the picture.
5		It is used to set the current picture as wallpaper.
6		It is used to rotate the current picture counterclockwise by 90°.
7		It is used to rotate the current picture clockwise by 90°.
8		It is used to switch to the previous picture.
9		It is used to switch to the next picture.


No.	Icon	Description
10		It is used to pause playing.
		It is used to start playing.

9.1 Viewing One Picture

To view one picture, do as follows:

- Step 1** Tap  on the home screen to display the list of functions.
- Step 2** Tap **My Files** to display the **My Files** screen.
- Step 3** Tap the required folder on the phone or an external storage device.
- Step 4** Find the required picture, and then tap **View** at the bottom of the screen to view the picture.

9.2 Playing Pictures in Presentation Mode

Tap  on the home screen to play all the pictures stored on the base unit of the media phone in presentation mode, as shown in the following figure.

9.3 Setting Photo Frame-Related Parameters

To view one picture, do as follows:

- Step 1** On the **Phone Settings** screen, tap **Next**.
- Step 2** Tap **Album** to display the **Album** screen.
- Step 3** Tap the **Play mode** drop-down list to select a mode in which the photos are played.
- Step 4** Tap the **Interval** drop-down list to set the duration for which each photo is to stay in the frame.
- Step 5** Tap **Save** to save the settings and exit.

9.4 Importing Pictures

You can import pictures from external storage devices (such as a USB device, a microSD card, and an MMC) to the media phone. For details, see "Managing Files" on page 47.

10 Other Functions

10.1 Tools

You can use the calendar and alarm functions, calibrate the touchscreen, and watch local video clips.

To access the more functions screen, tap  on the home screen to display the list of functions.

Alarm

On the **Alarm** screen, you can enable or disable the alarm function. After enabling the alarm function, you need to set the alarm time and the alarm ringtone.


To set the alarm time and the alarm ringtone as follows:

- Step 1** On the more functions screen, press **Alarm** to display the **Alarm** screen.
- Step 2** Tap the **Alarm** drop-down list to choose whether the alarm function should be enabled.
- Step 3** Select **On**, and then set the alarm time in the **Time** drop-down list and the alarm ringtone in the **Tone** drop-down list.
- Step 4** Tap **Save** to save the settings.

Touchscreen Calibration

The touchscreen of the media phone has been calibrated before delivery and can be used properly. Once you find that the touchscreen does not respond to the tapping correctly, you can re-calibrate the screen.



- The touchscreen calibration must be correct, or it will affect the subsequent operation on the touchscreen. If the calibration error during the operation, you should choose not save the data.
- After accessing the more functions screen, you are recommended to press  to select the menu item and start the calibration. Avoid operations on the touchscreen to ensure that the calibration effect is not affected.
- If you do not tap the touchscreen to save the settings within 20 seconds after calibration of five points is complete, the calibration will not take effect.


To calibrate the touchscreen, do as follows:

Step 1 On the more functions screen, select **Screen Calibration** to start the calibration.

Step 2 Use the stylus to tap the central point of the cursor as prompted.

Step 3 Calibrate five points, and then tap the touchscreen to save the settings.

Watching Local Video Clips

Tap  on the home screen, or tap **Camera** on the **Toolbox** screen, to view the shooting effect of the local camera.


On the screen for local video clips, tap **16:9** to view the clip in full screen. When the clip is played in full screen, tap **4:3** to view the clip in part screen. Tap **Exit** to return to the **Toolbox** screen.

10.2 Viewing Equipment Information

If the media phone is faulty, check its status, and then contact technical engineers for help.

On the **Phone Information** screen, you can view the server with which the media phone is registered, version information, and network status.

To view equipment information, do as follows:

Step 1 Tap  to display the list of functions.


Step 2 Tap **Phone Info.** to display the **Phone Info.** screen.

Step 3 Tap **Next** to display the next screen.

- Step 4** Tap **Version** to view the version information of different components of the media phone.

10.3 Managing Files



Tap  on the home screen to display the list of functions. Then tap **My Files** to display the **My Files** screen. On that screen you can manage the files stored in the internal memory of the base unit (namely, the local folder) as well as files on the external storage devices (such as a USB device, a microSD card, and an MMC) that are connected to the base unit.

Managing Files in the Internal Memory

On the **My Files** screen, tap **Local** to access the files.

The files on the media phone are stored in the three folders named **Music**, **Pictures**, and **Videos** according to their file type. You can delete one file or all files in a folder. You can also perform other operations based on the type of the folder.

- For **Music** and **Videos** folders, you can play a selected file or all files in those folders.
- For the **Pictures** folder, you can view a selected picture or play all the pictures in presentation mode.

Managing Files on External Storage Devices

Folders displayed on the **My Files** screen may be USB1, USB2 or others, subject to the connected external storage devices and the used interfaces. Tap the corresponding folder to access the device.


You can import a file or all files in the folder to the internal memory of the base unit. You can also perform other operations based on the type of the folder.

- For music and video folders, you can play one file or all files in those folders.
- For the picture folder, you can view a selected picture or play all the pictures in presentation mode.




The free memory of the local folder is about 400 MB. When the memory is insufficient, no file can be imported.

11 User Settings


You can customize the settings of the media phone. Tap  on the home screen to display the list of functions, and then tap **Settings** to display the **Phone Settings** screen.

11.1 Setting Sound

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, highlight Sound, and then tap Sound to display the Sound screen. (2) Use the stylus or your finger to drag the scroll bar to adjust Handsfree volume and Ringtone volume. (3) Tap the Ringtone drop-down list to choose a ringtone. (4) Tap Save to save the settings and exit. 	

11.2 Setting Sleep Mode

On the **Sleep Mode** screen, you can set the duration of the backlight. If no operation is performed within this specified duration, the media phone turns off the backlight automatically. To turn on the backlight, you can pick up the handset, tap on the touchscreen, or press a key. An incoming call can also turn on the backlight.

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, select Sleep Mode to display the Sleep Mode screen. (2) Tap the Sleep after drop-down list to set duration of the backlight. (3) Tap Save to save the settings and exit. 	

11.3 Setting the Network

When the media phone is connected to a network, you can set the network type and the access mode based on your requirement.



The network settings are associated with the authentication of the media phone. Therefore, do not change the settings if not required. Otherwise, you may not be able to use the services properly.

The media phone supports the following network types:

- When you use the network cable to access a broadband network, select **Ethernet**.
- When you use Wi-Fi to access a broadband network, select **Wi-Fi**.

The Wi-Fi type is classified into two modes:

- **Basic mode:** The access point is selected by searching in the wireless network.
- **Point-to-point mode:** The access point is selected by entering the SSID.




If you want to set a WEP key for the access point, you need to tap **Advanced**, and then **Set WEP Key**, to set the WEP key. The WEP key must be same as the parameters of the access point, or you will fail to access the Wi-Fi.

Each network type supports the following three access modes:


- **Static IP:** In this mode, set a fixed IP address for the media phone based on the IP address of the access gateway. As the gateway support the routing function, no dial-up connection is required for network access.
- **Advantage:** The IP address of the media phone is fixed and thus maintenance is easy.
- **Disadvantage:** When the gateway settings are changed, you need to reset the network parameters of the media phone.
- **DHCP:** The access gateway assigns an IP address automatically to the media phone. To access the network, the gateway needs to activate the DHCP service and support the routing function. No dial-up connection is required for network access.
- **Advantages:** The operations are easy and the network parameters of the media phone do not need to be reset when the gateway setting is changed.
- **Disadvantage:** The IP address of the media phone is not fixed.

- **PPPoE**: When the access gateway is in bridge mode, a dial-up connection is required. Therefore, when you use this mode, you need to contact your service provider for the account and password of the dial-up connection.
- **Advantage**: The broadband network is exclusively occupied by the media phone, and thus the bandwidth is stable.

Accessing the Network Through the Ethernet Interface

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Network to display the Network screen. (2) Tap the Network type drop-down list, and then tap Ethernet. (3) Tap Set, and then the Access mode drop-down list to select an access mode (generally DHCP). (4) Tap Save to save the setting for the access mode and exit. (5) Tap Save to save the network settings and exit. (6) To enable the new settings to take effect, tap Yes in the displayed dialog box. 	 <p>The top screenshot shows the 'Network' settings screen. The 'Network type' is set to 'Ethernet' and the 'Access mode' is set to 'DHCP'. There is a 'Set' button next to the 'Access mode' label. At the bottom, there are 'Save' and 'Back' buttons.</p> <p>The bottom screenshot shows the 'Network' settings screen with the 'Access mode' drop-down menu open. The menu options are 'DHCP', 'Static IP', 'DHCP', and 'PPPoE'. The 'DHCP' option is currently selected. At the bottom, there are 'Save' and 'Back' buttons.</p>


Accessing a Network Through Wi-Fi in Point-to-Point Mode

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Network to display the Network screen. (2) Tap the Network type drop-down list, and then tap Wi-Fi. (3) Tap the Infra drop-down list, and then tap Adhoc. (4) Tap Set to display the Network screen. (5) Set the parameters of the static IP address. (6) Tap Save to save the setting for the access mode and exit. (7) Tap the SSID text box, and then enter the SSID of the access point. (8) Tap Save to save the network settings and exit. (9) To enable the new settings to take effect, tap Yes in the displayed dialog box. 	 <p>The top screenshot shows the 'Network' settings screen with 'Network type' set to 'Wi-Fi' and 'Access mode' set to 'Static IP'. The SSID is 'rte'. The bottom screenshot shows the 'Network' settings screen with 'Access mode' set to 'Static IP' and the following parameters: IP address: 192.168.1.144, Subnet mask: 255.255.255.0, Gateway: 192.168.1.1, Primary DNS: 0.0.0.0, and Secondary DNS: 0.0.0.0.</p>


Accessing a Network Through Wi-Fi in Basic Mode

Procedure	Screen
<p>(1) On the Phone Settings screen, tap Network to display the Network screen.</p> <p>(2) Tap the Network type drop-down list, and then tap Wi-Fi.</p> <p>(3) Tap Set, and then the Access mode drop-down list to select an access mode (generally DHCP).</p> <p>(4) Tap Save to save the setting for the access mode and exit.</p> <p>(5) If you want to set a WEP key for the access point, you need to tap Advanced, and then Set WEP Key, to set the WEP key.</p> <p>(6) Notes: If you know the access point, tap Add AP to enter the parameters of the access point of the Wi-Fi manually, and then tap Connect.</p> <p>(7) Tap Scan to scan the accessible access point.</p> <p>(8) Select a access point and tap Connect. Input the password if needed.</p> <p>(9) Tap Save to save the network settings and exit.</p> <p>(10) To enable the new settings to take effect, select Yes in the displayed dialog box.</p>	

11.4 Setting Wallpaper

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Wallpaper to display the Wallpaper screen. (2) Scroll through the wallpapers and select the one you want. (3) Tap Save to save the settings and exit. 	


11.5 Setting Date and Time

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Date & Time to display the Date & Time screen. (2) Tap the Time zone drop-down list to select a time zone. (3) Tap the Date text box. Edit the time, and then tap OK. (4) Tap the Date format drop-down list to select the format in which you want the date to be displayed. (5) Set Time in the same way you set Date. (6) Tap the Time format drop-down list to select the format in which you want the time to be displayed. (7) Tap Save to save the settings and exit. 	




If your service provider enables the network clock service, the media phone displays the date and time updated by the network server.

11.6 Setting Language


Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Language to display the Language screen. (2) Tap the option button before the language in which you want the screens to be displayed. (3) Tap Save to save the setting and exit. 	

11.7 Setting Keypad Tone

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Next. (2) Tap Keypad Tone to display the Keypad Tone screen. (3) Tap the option button as required to enable or disable the keypad tone. (4) Tap Save to save the setting and exit. 	


11.8 Setting the Output Standard

The media phone provides video output interfaces, enabling you to connect the media phone to external equipment (such as a television) with video cables and output videos to the external equipment. You need to set the output standard according to the type of the external equipment.


Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Next. (2) Tap Video Output Standard to display the Video Output Standard screen. (3) Tap the option button as required to set the output standard. (4) Tap Save to save the setting and exit. 	

11.9 Checking the Network Status


The media phone provides the function of checking the network status. You can use it to send data packets to a specific IP address and check whether the media phone is connected to the network to which the IP address belongs.

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Next. (2) Tap PING to display the PING screen. (3) Tap the Address text box to enter the IP address you want to test. (4) Tap PING and then wait for the result. 	

11.10 Managing Handsets

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Next. (2) Tap Interphone Status to display the Interphone Status screen. (3) Tap the handset which needs to be deregistered, and then tap Release to deregister the handset. (4) Tap Register to start the registration. 	

11.11 Managing the Telnet Connection

Procedure	Screen
<ol style="list-style-type: none"> (1) On the Phone Settings screen, tap Next. (2) Tap Security to display the Security screen. (3) If you want to enable the connection through telnet, select Enable telnet. Otherwise, clear Enable telnet. (4) Tap Save to save the setting and exit. 	

12 Handset Registration

The MC850 provides a digital cordless handset. Though the MC851 does not provide a digital cordless handset, it can be used along with cordless handsets as well. Before using the cordless handset, you need to register it with the base unit.

12.1 Registering a Cordless Handset


You can register up to five cordless handsets to your base unit. The media phone assigns a number to each handset according to the registration order of the handsets. For example, the number assigned to the first handset that is registered is 1, and the number 1 is displayed on the LCD of that handset. The registration code is **1590**.




The registration code cannot be changed. Ensure that you store the registration code properly as only those who have access to the code can register a handset.

To register a handset, do as follows:

Step 1 Access the handset registration menu as follows:

1. In standby mode, press **MENU** to display the main menu.
2. Press  repeatedly to select **Handset** on the screen, and then select **Select**.
3. Press the up or down navigation key to select **Register**, and then select **Select**.

Step 2 Enable the registration function on the base unit as follows:

1. Tap  on the home screen to display the list of functions.
2. Tap **Settings** to display the **Phone Settings** screen.
3. Tap **Next** to the next screen and tap **Interphone Status** to display the **Interphone Status** screen.
4. Tap **Register**.

Step 3 Perform the registration operations on the handset as follows:

1. Press the up or down navigation key to select the number of the base unit with which you want the handset to register, and then select **Select**. If there is only one base unit, select base number 1. If searching for a base

- unit that is ready for registration is successful, a serial number is displayed on the LCD of the handset.
2. Select **Select** to confirm your selection.
 3. Enter the registration code 1590, and then select **Select**.

If the registration is successful, the handset will return to the standby mode and the handset number (for example, 1) will be displayed on the LCD of the handset.




A handset can be registered with up to four base units. A base unit can be used with up to five handsets. The base unit can be accessed by only one handset at a time.

12.2 Deregistering a Cordless Handset

If necessary, you can deregister a handset.

Deregistering a Cordless Handset on the Base Unit


To deregister a handset on the base unit, do as follows:






- Step 1** Tap  on the home screen to display the list of functions.
- Step 2** Tap **Settings** to display the **Phone Settings** screen.
- Step 3** Tap **Next** to the next screen and tap **Interphone Status** to display the **Interphone Status** screen.
- Step 4** Select the number of the handset that you want to deregister.
- Step 5** Tap **Release** to deregister the handset. A message saying **NOT SUB** is displayed on the LCD of the deregistered handset.








13 Cordless Handset

13.1 Layout

The following figure shows the cordless handset.











No.	Item	Function
1	-	Color LCD.
2/13	 	Left soft key and right soft key. Press to perform the functions indicated by the text immediately over them (on the bottom of the LCD).
3		On/Off/End key. Press when the handset is off to turn it on. Press and hold when the handset is on to turn it off. In menu mode, press softly to cancel your current operation and return to the standby mode. During a call, press softly to end the call.
4	 	Use to enter digits or symbols under different circumstances.

No.	Item	Function
5		Pound key. Press to enter # or switch between different input methods.
6		Mute key. Press to mute the microphone.
7		Internal call key. Use to make an internal call or transfer an external call.
8	-	Microphone.
9	-	Charger pins.
10		Speaker key. Press during a call to use the hands-free function.
11		Star key. Press and hold to turn on or off the keypad lock function.
12		Dial key. Press to answer or make a call.
14		<p>Navigation keys. Use the up or down navigation key to select items. During text editing, use the left or right navigation key to move the cursor.</p> <p>In standby mode:</p> <ul style="list-style-type: none"> • Press the right navigation key softly for the list of dialed numbers. • Press the up navigation key softly for the list of missed calls. • Press the down navigation key softly for Phonebook. <p>In a call:</p> <ul style="list-style-type: none"> • Press the up navigation key softly to increase the earpiece volume. • Press the up navigation key softly to decrease the earpiece volume.
15	-	Earpiece.
16	-	Speaker.
17	-	Battery cover.

13.2 Icons on the LCD


Varied icons appear in different modes on the LCD. The following table lists the icons and their descriptions.

Icon	Description
	It indicates the signal strength. The more the vertical bars, the stronger the signal.
	It indicates that the handset is in use.
az	It indicates that the current input method is for lower-case letters.
AZ	It indicates that the current input method is for upper-case letters.
0-9	It indicates that the current input method is for digits.
	It indicates the battery charge level.
ZZ	It appears on the LCD in standby mode if you have enabled the sleep mode.
	It indicates that the alarm function is enabled.
	It indicates that the microphone is muted.
	It indicates that the hands-free function is enabled.
	It indicates that you have missed one or more calls. This icon disappears after you view the missed calls.
	It indicates that the keypad is locked.

13.3 Preparations Before Use


Powering On/Off

Before powering on the handset, ensure that the battery is installed. For details, see "Installing the Battery" on page 11.

- The handset is automatically powered on when you place it on the desk stand.
- When the handset is off, press  softly to turn on the LCD.

- To power off the handset, press and hold  until a message saying **Goodbye!** appears.



- Release  when the message saying **Goodbye!** appears, or the handset may be restarted.
- Nothing appears on the LCD if the battery power is very low. You need to fully charge the handset before using it.

Charging the Handset Battery





Before using the handset for the first time, fully charge it for 15 hours continuously.

To charge the handset, place it on the desk stand.

During the charging, the bars inside the  icon are displayed on the LCD scroll.

Locking the Handset Keypad

To lock the keypad, press and hold  in standby mode until the icon  appears on the LCD.

To unlock the keypad, press and hold  again until the icon  disappears from the LCD.

When you lock the keypad, all the keys except the **ACCEPT** key are locked. In that case, when a call comes in, you can answer the call by selecting **ACCEPT**. When the call ends, the keypad is locked again.

13.4 Function of Making an External Call


Making a Call by Dialing

You can dial numbers with up to 25 digits. If the number has over 16 digits, the LCD automatically switches to a smaller font in order to accommodate the whole number. You can view the number you are dialing and modify it when necessary before dialing.



To make a call by dialing, do as follows:

Step 1 Enter a phone number in standby mode. Check the number on the LCD.

Step 2 If you make a mistake in entering the number, modify it by using the left navigation key.

Step 3 When the number is correctly entered, press  to dial it out.

Redialing

Your handset allows you to quickly call the last dialed number. Pick up the handset and press  to make a call. Then select **Select** or press  to dial the last dialed number.

13.5 Function of Making an Internal Call

Calling a Handset

You can call a handset from the base unit. This is useful to locate a handset or call the current handset holder.

Access the dialer screen, tap **Interphone**, and then select the handset you want to call in the **Select Interphone** screen. The handset then rings.

Press any key on the handset to stop the calling.



If a call comes in while the handset is being called, the handset stops the calling and starts ringing to notify you of the incoming call.


Making an Internal Call


If you register more than one handset with a base unit, you can have a conversation between two handset holders or between holders of a handset and the base unit.

To make an internal call, do as follows:

Step 1 Pick up the handset, and then press . The LCD then shows "INT X ->" (X is the handset number).

Step 2 Press the number of the handset you want to call. The called handset then starts to ring. If you want to call the base unit, press **0**.




Step 3 The called party can press  to answer the call.

Step 4 To end the call, press .


Performing Call Transfer


If you register more than one handset with a base unit, you can transfer an external call between the registered handsets.

To transfer an external call to the Media Phone or between the registered handsets, do as follows:

- Step 1** When you are connected to an external call, press  and the number of the handset to which you want to transfer the call.
- Step 2** After the called handset rings, the holder can press  to answer the call.
- Step 3** If you want to cancel the transfer before the called handset answers, press  on your handset.

Setting up a Three-Party Calling


To transfer a call from the handset to the base unit, press **0** after you press . Before the base unit answers the call, the conversion between the handset and the external

party is suspended. After the base unit answers the call, press  for over two seconds or **CONFER** on the handset to set up a three-party conference call.

For details about how to set up a three-party call on the base unit, see "Three-party calling" on page 25.

13.6 Call Answering

When a call is received, the handset rings and a message saying "Incoming call" appears on the LCD. If the incoming call can be identified, the number of the caller also appears on the LCD.

To answer the call, press  or select **ACCEPT**. If the handset is on the base unit and you have enabled the Auto Answer function (for details about how to enable the function, see "Performing Auto Answer" on page 74), you can pick the handset to answer the call without pressing any keys. During the conversion, the LCD shows the duration of the call.

13.7 Input Methods

The handset provides input methods for upper-case letters, lower-case letters, and digits.

After you select a text box (except on the screen for entering numbers), you can press



to switch the default input method to the input method for upper-case letters, lower-case letter, or digits.

To enter text, press the corresponding number keys on which the character you want to enter is located. Press a number key once to select the first character on the key. Press the key twice to select the second character on the key. Select other characters in the same way. Once you press a key, the associated characters appear on the bottom of the LCD.

To enter a symbol, press **1**, and then press the left or right navigation key to select the symbol as required, and then select **Select** for confirmation.



- Press the Clear key to delete the character immediately on the left side of the cursor.
- To enter a character twice or two characters that are located on the same key, after you enter a character, wait until the cursor moves automatically to the next space to enter a second character.

13.8 Operations During a Call

Turning On/Off the Hands-free Function During a Call

During a call, to turn on the hands-free function, turn on the speaker on the handset.





- To turn on the speaker, press during a call. The icon then appears on the LCD.
- To turn off the speaker, press again. The icon then disappears from the LCD.

Adjusting the Volume During a Call

During a call, you can press the up or down navigation key to adjust the volume of the earpiece or the speaker. The icon on the LCD indicates the current volume. The more the blue bars, the louder the volume. When the last bar becomes red, the volume is the loudest.

Muting a Call

During a call, you can mute the microphone so that the other party on the other end of the line cannot hear you. This function allows you to have a private conversation with someone near you.


- To mute the microphone, press  during a call. The icon  then appears on the LCD.
- To unmute the microphone, press  again. The icon  then disappears from the LCD.

13.9 Phonebook

Creating a Contact

Using the Contact menu


Step 1 Press **MENU** in standby mode.

Step 2 Press  repeatedly to select **Contacts**, and then select **Select**.

Step 3 Press the up or down navigation key to select **New contact**, and then select **Select**.

Step 4 Enter a name that you want to use. For the method of entering a name, see "Input Methods" on page 64.

Step 5 Press the down navigation key to move the cursor to the number field, and then enter the phone number.

Step 6 Press the down navigation key to highlight the line with the icon , and then press the left or right navigation key to select a ringtone to accompany the number. Every time you select a ringtone, the handset sings the ringtone accordingly.

Step 7 Use the same method to select the wallpaper. Then select **SAVE** to save the settings.

Directly entering the phone number in standby mode

Enter a phone number in standby mode, and then select **SAVE**. Then perform Step 4 to Step 7 described in "Using the Contact menu."



When you are entering the number in step 1, you can also press the right navigation key to insert one or more dialing pauses and store them in the phonebook as well.

13.10 Call Log

The call log includes missed calls, received calls, and dialed numbers.

Accessing the Call Log Screen

To access the call log screen, do as follows:

Step 1 In standby mode, press **MENU** to display the main menu.

Step 2 Press  repeatedly to select **Call logs**, and then select **Select** to display the screen for the call log.

Viewing the Details of a Call Record

To view the details of a call record, do as follows:


Step 1 On the screen for the call log, press the up or down navigation key to select a call category (missed calls, received calls, and dialed numbers), and then select **Select** or press **OK**.


Step 2 Press the up or down navigation key to select the number whose details you want to view, and then select **Select** or press **OK**.

Making a Call from the Call Log

To make a call from the call log, do as follows:

Step 1 On the screen for the call log, press the up or down navigation key to select a call category, and then select **Select** or press **OK**.


Step 2 Press the up or down navigation key to select the number you want to call, and then press  to dial the number out.

Step 3 To end the call, press .

Adding a Number from the Call Log to the Phonebook

To add a number from the call log to the phonebook, do as follows:

Step 1 Select the number you want to add. Select **Select** or press **OK** to view the details of the number, and then select **Select** or press **OK**.

- Step 2** Highlight **Add to contacts**, and then select **Select** to display the screen for editing.
- Step 3** Enter a name that you want to use. For the method of entering a name, see "Input Methods" on page 64.
- Step 4** Press the down navigation key to move the cursor to the number field, and then check the phone number.
- Step 5** Press the down navigation key to highlight the ringtone type on the right of the icon , and then press the left or right navigation key to select a ringtone to accompany the number. Every time you scroll to a ringtone, the handset sings the ringtone accordingly.
- Step 6** Use the same way to select the wallpaper. Then select **SAVE** to save the settings.

Deleting a Call Record

To delete a call record, do as follows:


- Step 1** Select the number you want to delete. Select **Select** or press **OK** to view the details of the number, and then select **Select** or press **OK**.
- Step 2** Press the down navigation key to move the cursor to highlight **Delete**, and then select **Select** to delete the selected number.
- Step 3** Press the down navigation key to move the cursor, and then select **Delete All** to delete all the numbers of a category.

13.11 Configuration of Frequently Used Functions

Setting Sound

Setting the Ringtone Type and the Ringtone Volume

To set the ringtone type and the ringtone volume, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Sound**, and then select **Select** or press **OK**.
- Step 3** Select **Select** to select **VOIP ringtone**. You can also press the down navigation key to select **PSTN ringtone** or **INT ringtone**, and then select **Select**.


- Step 4** Press the left or right navigation key to select the ringtone you like.
- Step 5** Select **Select** to save the setting for ringtone type and proceed to set the volume.
- Step 6** Press the left or right navigation key to set the ringtone volume based on your requirement.
- Step 7** Select **Select** to save the settings and return to the upper-level menu.



If you turn the ringer off, when there is an incoming call, only the incoming call message appears on the LCD.


Setting Key Tone

To set the key tone, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Sound**, and then select **Select** or press **OK**.
- Step 3** Press the down navigation key to select **Key tone**, and then select **Select**.
- Step 4** Press the up or down navigation key to select **ON** to enable the function or **OFF** to disable the function. Then select **Select**.


Setting the Power off Tone

To set the power off tone, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Sound**, and then select **Select** or press **OK**.
- Step 3** Press the down navigation key to select **Power off tone**, and then select **Select**.
- Step 4** Press the up or down navigation key to select **ON** to enable the function or **OFF** to disable the function. Then select **Select**.

Setting the Charging Tone

To set the charger tone, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Sound**, and then select **Select** or press **OK**.

- Step 3** Press the down navigation key to select **Charging tone**, and then select **Select**.
- Step 4** Press the up or down navigation key to select **ON** to enable the function or **OFF** to disable the function. Then select **Select**.




For normal use, you are recommended to enable the charger tone so that you can receive alerts it when the handset is not charged properly.

Setting the Alarm Clock

Enabling the Alarm Function

To enable the alarm function, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Alarm**, and then select **Select** or press **OK**.
- Step 3** Press the down navigation key to select **Alarm**, and then select **Select**.
- Step 4** Press the up or down navigation key to select **ON**, and then select **Select**.
- Step 5** Press the number keys to enter the alarm time in the format of HH:MM.
- Step 6** Select **Select** to save the setting and proceed to set the ringtone type.
- Step 7** Press the left or right navigation key to select the ringtone you like.
- Step 8** Select **Select** to save the setting and return to the upper-level menu.
- Step 9** When the alarm rings, press any key to turn it off.


Disabling the Alarm Function

To disable the alarm function, perform Step 1 to Step 3 of the previous paragraph, select **OFF**, and then select **Select**.

Sleep Mode

If the sleep mode function is enabled, the ringtone volume automatically switches to the lowest volume level during the period of the time you set. This function allows you to be free from any disturbance at night.


To enable the sleep mode function, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Alarm**, and then select **Select** or press **OK**.

- Step 3** Press the down navigation key to select **Sleep mode**, and then select **Select**.
- Step 4** Press the up or down navigation key to select **ON**, and then select **Select**.
- Step 5** Enter the start time and end time of the sleep mode.
- Step 6** Press **OK** to save the settings and return to the upper-level menu.


Setting Date Format

To set the date format, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Date and time**, and then select **Select** or press **OK**.
- Step 3** Press the down navigation key to select **Date format**, and then select **Select**.
- Step 4** Select the date format you prefer, and then select **Select** to save the setting and return to the upper-level menu.

Setting Time Format


To set the time format, do as follows:


- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Date and time**, and then select **Select** or press **OK**.
- Step 3** Press the down navigation key to select **Time format**, and then select **Select**.
- Step 4** Select the time format you prefer, and then select **Select** to save the setting and return to the upper-level menu.

13.12 Display Setting

Adjusting Display Contrast

To adjust the display contrast, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select **Display**, and then select **Select** or press **OK**.
- Step 3** Select **Select** again to select **Contrast**. The current setting appears on the display.

Step 4 Press  to adjust the contrast level, and then select **Select**.

Setting Wallpaper

To set the wallpaper, do as follows:

Step 1 In standby mode, press **MENU** to display the main menu.

Step 2 Press  repeatedly to select **Display**, and then select **Select** or press **OK**.

Step 3 Press the up or down navigation key to select **Wallpaper**, and then select **Select**. The current setting appears on the LCD.

Step 4 Press the navigation key to select the wallpaper you prefer, and then select **Select**.

Setting Background Color

To set the background color, do as follows:

Step 1 In standby mode, press **MENU** to display the main menu.

Step 2 Press  repeatedly to select **Display**, and then select **Select** or press **OK**.

Step 3 Press the up or down navigation key to select **Background col.**, and then select **Select**. The current setting appears on the LCD.

Step 4 Press the navigation key to select the background you prefer, and then select **Select**.

Setting Handset Name

To set a name for a handset, do as follows:


Step 1 In standby mode, press **MENU** to display the main menu.

Step 2 Press  repeatedly to select **Display**, and then select **Select** or press **OK**.

Step 3 Press the up or down navigation key to select **Handset name**, and then select **Select**.

Step 4 Press the up or down navigation key to select **ON**, and then select **Select**.

Step 5 Enter the name (with up to 15 characters) you want to assign to the handset, and then select **Select**.

Step 6 Press  to return to the standby mode. You will see the name and the number of the handset on the LCD.



To disable this function, access the **Handset name** menu, select **OFF**, and then select **Select**.

13.13 Other Basic Settings

Flash Signal

When the line is engaged, you can press the left soft key to send the flash signal. This key is used to access special services (such as call waiting and conference) which may be available on your network. For further details, please contact your service provider. In addition, if you are connected to an extension of a switchboard (PABX), you can use the left soft key to transfer a call to another extension.

To transfer a call, or use the preceding special services, press the left soft key while the line is engaged.

Pause During Dialing


The pause function may be required when you access an interactive voice response system or make an international call.

When you are dialing a number and need to insert a pause, press the right navigation key for once. Each time you press the key, it leads to a pause of three seconds.

Basic Setting of the Handset

To access the screen for basic setting, do as follows:

Step 1 In standby mode, press **MENU** to display the main menu.

Step 2 Press  repeatedly to select the **Handset** icon, and then select **Select** or press **OK** on the keypad.

Changing the Handset PIN

When restoring a parameter to its default value, you need to enter the handset PIN. To change the handset PIN, do as follows:

Step 1 On the screen for basic setting of the handset, highlight **PIN code**, and then select **Select** for once.

Step 2 Press the number keys to enter the current PIN code (preset to 1590), and then press **OK**.

Step 3 Enter the new four-digit PIN you want to use, and then press **OK**.

- Step 4** Enter the new PIN again for confirmation, and then press **OK** to save the setting and exit.

Performing Auto Answer

With this function, you can answer a call by picking the handset from the base unit without pressing any key.


To enable the auto answer function, do as follows:

- Step 1** On the screen for basic setting of the handset, press the up or down navigation key to select **Auto answer**, and then select **Select**.
- Step 2** Press the up or down navigation key to select **ON** to enable the function or **OFF** to disable the function. Then select **Select**.

Setting the Dialing Mode

For PSTN calls, in order to provide compatibility with other telephone systems, your handset can be set to either tone dialing or pulsing dialing.

To set the dialing mode, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select the **Base** icon, and then select **Select**.
- Step 3** Enter the current base unit PIN (preset to 1590), and then press **OK**.
- Step 4** Press the up or down navigation key to select **Dialing mode**, and then select **Select**.
- Step 5** Press the left or right navigation key to select **DTMF** (tone dialing) or **PULSE** (pulsing dialing), and then select **Save** to save the setting.

Restoring Default Settings


If you restore default settings, you will lose all the data (for example, numbers and names in the phonebook and call records in the call log) and the parameters previously set by you will be restored to their default values. Therefore, you are recommended to back up important data before restoring default settings.

You can restore default settings of the base unit and any of the handsets.

Restoring Default Settings of the Handset

To restore default settings of the handset, do as follows:


- Step 1** In standby mode, press **MENU** to display the main menu.

- Step 2** Press  repeatedly to select the **Handset** icon, and then select **Select**.
- Step 3** Press the up or down navigation key to select **Reset handset**, and then select **Select**.
- Step 4** Enter the current handset PIN (preset to 1590) as prompted, and then press **OK**. When the display shows "Reset?", press **OK** for confirmation.

Restoring Default Settings of the Base Unit

On the handset you can restore the base unit parameters associated with the communication between the base unit and the handset to their default values. This operation does not affect other settings of the base unit.

To restore default settings of the base unit, do as follows:

- Step 1** In standby mode, press **MENU** to display the main menu.
- Step 2** Press  repeatedly to select the **Base** icon, and then select **Select**.
- Step 3** Enter the current base unit PIN (preset to 1590) as prompted, and then press **OK**.
- Step 4** Press the up or down navigation key to select **Base Reset**, and then select **Select**.
- Step 5** When the LCD shows "B Reset?", press **OK** for confirmation.

14 Software Upgrade




During the upgrade, do not disconnect the power supply.

14.1 Automatic Upgrade

If your service provider provides automatic updates, then when the new software version is released, your media phone will start a free upgrade period within 24 hours. The screen will pop up a "being upgraded" message, the media phone will automatically upgrade the software version.

14.2 Manual Upgrade

The media phone can detect and download the latest software by accessing the network server.

Step 1 Tap  on the home screen to display the list of functions.

Step 2 Tap **Settings** to display the **Settings** screen.

Step 3 Tap Online Upgrade.


The media phone detects the latest version. If your software is not the latest one, a dialog box appears asking you whether the software needs to be upgraded.

Step 4 Perform operations as prompted, and then wait until the upgrade is completed.



- The media phone can complete the upgrade automatically. You are not recommended to upgrade the software manually.
- Automatic or manual upgrade mode is determined by your service provider. For details, consult your service provider.
- During the upgrade, you cannot make or answer calls. Wait patiently until the upgrade is completed.
- After the upgrade, you may need to restart the system. Perform the operations as prompted.

15 Troubleshooting

Symptom: After you press , there is an off-hook tone. But after you pick up the handset, there is no off-hook tone.

Possible cause: The handset is not connected properly (applicable to the MC851).

Symptom: During a call, you cannot hear the other party.

- The microphone of the other party may be turned off.
- The volume of your speaker may be adjusted to **0**. (For details, see "Setting Sound" on page 48.)

Symptom: During a video call, you cannot view the video of the other party or the other party cannot view your video.

- The camera may be rotated to the bottom.
- The environment is too dark.

Symptom: During a call, the other party cannot hear you.

- Your microphone may be turned off.
- The volume of the speaker of the other party may be adjusted to **0**. (For details, see "Adjusting the Volume of the Speaker During a Call" on page 24.)

Symptom: After the network is accessed through Wi-Fi, an icon indicating that the connection has failed appears in the status bar on the home screen.

- The media phone may be out of range of the wireless signal. View the icon indicating the Wi-Fi signal strength in the status bar to see whether there is any signal.
- If the Wi-Fi signal is strong, the possible cause may be that the Wi-Fi parameters are set incorrectly. Please check the network access parameters. (For details, see "Setting the Network" on page 49.)

Symptom: After the network is accessed through Wi-Fi, lagging, pausing, or erratic display of the video occurs during playing of IPTV videos.

- The quality of the Wi-Fi signal may be poor. Check the AP setting or set **Network type** to **Ethernet**. (For details, see "Setting the Network" on page 49.)
- If the preceding operation does not solve the problem, contact your service provider for help.

Symptom: The handset cannot be powered on.

- The battery may be discharged or not installed properly. Check whether the battery is installed properly. If the handset still cannot be powered on, charge the handset on the base unit for a few minutes, and then remove the handset and

power it on.

- The battery is damaged. If the preceding operations do not solve the problem, contact your service provider to replace the battery.

Symptom: The handset can be powered on properly, but cannot access the base unit.

- The base unit may be powered off or the power connection may be faulty. Check whether the base unit works properly.
- Perhaps the handset has not been registered with the base unit or the registration information is lost. In this case, re-register the handset with the base unit. (For details, see "Registering a Cordless Handset" on page 57.)

Symptom: The handset works and accesses the base unit properly, but no dial tone is heard.

The connection of cables may be faulty. Check whether the network cable is connected properly.

Symptom: The handset works properly, but no number can be dialed.

Perhaps you have set the dialing mode of the handset to **DTMF**, but your line does not support this mode. Select the pulsing dialing. (For details, see "Setting the Dialing Mode" on page 74.)

Symptom: The handset works properly, but you hear beeps during calls.

The battery power is too low. Check the battery power and charge the battery when necessary.

Symptom: There are noise interferences in the calls when you are using the handset.

The handset may be too far from the base unit. Try getting closer to the base unit with which the handset is registered. If multiple base units are available, you can also try registering the handset to the base unit that is closer to the handset.

Symptom: The handset works properly, but does not ring upon incoming calls.

The volume of the ringtone is set to off. Try setting the ringtone to a higher volume.

Symptom: The handset can only receive calls and the keypad does not respond to your operations properly.

The keypad may be locked. Try unlocking the keypad. (For details, see "Locking the Handset Keypad" on page 62.)

Symptom: The battery efficiency is very low.

- The charging pins may be not clean. Try cleaning them.
- The battery life may have reached its end. Contact your service provider to replace the battery.

Symptom: The call disconnects automatically once you use the service of easy switch.

Your service provider may not support the service. Please contact your service provider.

Symptom: An error message is displayed when you import files from an external device to the local folder.

The memory of the base unit is not sufficient. Make sure that the size of the files to be imported does not exceed 400 MB.

Symptom: The media files stored on an external device cannot be played on the base unit.

The format of the media file may not be supported by the player in the media phone. (For details, see "Playing Multimedia Files on the Media Phone" on page 35.)

Symptom: A file stored on the external devices cannot be played fully.

The format of the file may not be supported by the media phone.

Symptom: The alarm does not ring.

The volume level may be set to **0**.

Symptom: The external storage device cannot be identified.

The media phone supports only the USB flash drive and the microSD card, and it does not support using other devices as USB devices.

Symptom: A message saying **NOT SUB** or **Searching** is displayed on the LCD of the handset.

The handset is not properly registered to the media phone, please re-register. (For details, see "Handset Registration" on Page 57.)



If you encounter faults that cannot be rectified, please contact your service provider for help.

16 Technical Specifications

Category	Item	Parameter
Compliant standards	Communication standard	SIP 2.0
	Video standard	H.263, H.264
	Audio standard	G.711A, G.711 μ
	Network standards	TCP/IP, UDP, RTP, RTCP, DHCP, Telnet, DNS, PPPoE, HTTP, SNTP, RTSP
LCD	Size	7-inch color TFT LCD with a touchscreen supporting handwriting input and stylus operations
	Resolution	800 × 480 dot matrix and truecolor with 16.7 million colors
Camera	Resolution	≥ 3 megapixels
	Closest focus range	30mm
	Visual angle	50° to 70°
	Rotatable angle	It can rotate at a 30° angle upward or a 90° angle downward (privacy mode).
Environmental requirements	Working temperature	0°C to 40°C
	Working humidity	10% to 80%, non-condensing
	Storage temperature	-40°C to +70°C
Electric features	Working voltage	100–240 V AC, 12 V and 2 A DC
	Working frequency	50 Hz to 60 Hz
	Entire-device power consumption	< 15 W
	Power consumption of the device in standby mode	< 2 W
Physical specifications	Dimensions (L × W × H)	About 269.2 mm × 135.2 mm × 72.4 mm
	Weight	< 900 g

HUAWEI TECHNOLOGIES CO., LTD.

Huawei Industrial Base

Bantian, Longgang

Shenzhen 518129

People's Republic of China

www.huawei.com

Part Number: 803004