

REMOTE THERMO

MODEL: RMR232PHA
USER'S MANUAL

INTRODUCTION

Congratulations on your purchase of the RMR232PHN/RMR232PHU, an In-Out Thermometer with Radio-Controlled Clock and a Photo Frame attached.

The basic package comes with the following:

- Main unit (RMR232PHN/RMR232PHU).
- Remote thermo sensor unit
- Blue and metallic grey exchangeable front key panels.


The main unit shows the indoor temperature, calendar clock and temperatures collected and transmitted by the remote unit.

The main unit is also capable of keeping track of the maximum and minimum temperature measured. No wire installation is required and the RMR232PHN/RMR232PHU operates at 433MHz.

As for the calendar clock, it is radio-controlled. It automatically synchronizes its current time and date when it is brought within an approximate 1500km radius of the radio signal generated from Frankfurt, Germany (DCF77). (MSF 60 for UK Version)

You can also set the calendar clock manually when it is off range. Other features include five-language display and two-minute crescendo daily alarm.

MAIN FEATURES: MAIN UNIT



A THREE-LINE DISPLAY

Facilitates easy reading of remote and indoor temperatures and calendar clock

B RADIO RECEPTION SIGNAL

Indicates the condition of radio reception

C MEMORY [MEM] BUTTON

Recalls the maximum or minimum temperature of main and remote unit

D UP [▲] BUTTON

Advances the value of a setting

E [MODE/SET] BUTTON

Toggles the display modes and confirms entry while setting the values for display

F DOWN [▼] BUTTON

Decreases the value of a setting

G ALARM [(••)] BUTTON

Displays the alarm time or sets the alarm status

H FRONT PANEL

Exchangeable front panel with clip-on design

I [UNLOCK] BUTTON

Unlock the photo frame drawer

J PHOTO FRAME DRAWER

Holds photo in position.

K PHOTO FRAME COVER

Protects photo from finger prints and other damages

L [RESET] BUTTON

Returns all settings to default values

M [°C/°F] BUTTON

Selects between degree Centigrade (°C) and Fahrenheit (°F)

N BATTERY COMPARTMENTS

Accommodates two UM3 or "AA" size 1.5V alkaline batteries


O TABLE STAND

For standing the main unit on a flat surface

P WALL-MOUNT RECESSED HOLE

For mounting the main unit on a wall

MAIN FEATURES: REMOTE UNIT



A LED INDICATOR

Flashes when the remote unit transmits a reading

B BATTERY COMPARTMENT

Accommodates two UM-3 or AA-size 1.5V batteries


C BATTERY DOOR

D WALL-MOUNT RECESSED HOLE

Supports the remote until in wall-mounting

BATTERY INSTALLATION: MAIN UNIT

1. Slide open the battery compartment door.
2. Install 2 alkaline batteries (UM3 or "AA" size 1.5V) strictly according to the polarities shown.



BEFORE YOU BEGIN

For best operation,

1. Insert batteries for remote units before doing so for the main unit.
2. Place the main unit as close as possible next to the remote unit, reset the main unit after installing batteries. This will ensure easier synchronization between the transmission and reception of signals.
3. Position the remote unit and main unit within effective transmission range, which, in usual circumstances, is 20 to 30 meters.


Note that the effective range is vastly affected by the building materials and where the main and remote units are positioned. Try various set-ups for best result.

Though the remote units are weather proof, they should be placed away from direct sunlight, rain or snow.

3. Press the [RESET] button.
4. Replace the battery compartment door.


BATTERY INSTALLATION: REMOTE UNIT

1. Remove the screws on the battery compartment.



2. Install 2 alkaline batteries (MU-3 or "AA" size 1.5 V) strictly according to the polarities shown.
3. Replace the battery compartment door and secure its screws.

2. Lift and open the photo frame cover.



3. Align and place the photo on the velvet surface.




LOW BATTERY WARNING


When it is time to replace batteries, the respective low-battery indicator will show up on the indoor or outdoor temperature display.

HOW TO INSERT A PHOTO

1. Push the [UNLOCK] button to unlock and take out the photo frame drawer.



4. Close the photo frame cover and replace it back to the main unit.





COMPATIBLE PHOTO SIZES

Three different standard sizes of photo can be placed in the photo frame:

- 8 x12 cm (3.15" x 4.72")
- 9 x13 cm (3.54" x 5.12")
- 10 x15 cm (3.94" x 5.9")

HOW TO USE THE TABLE STAND OR WALL MOUNTING

The main unit has a table stand which can support the unit on a flat surface. Or you can mount the unit on a wall using the recessed screw hole.

As for the remote unit, you can place it on a flat surface or mount the unit on a wall using the recessed screw hole.

Main unit

Wall-mount





Table Stand



Wall-mount





Table Stand



HOW TO EXCHANGE FRONT KEY PANEL

The package comes with one grey and one blue exchangeable front panels.



GB


THE RESET BUTTON

This button is only used when the unit is operating in an unfavorable way or malfunctioning. Use a blunt stylus to hold down the button. All settings will return to their default values.

GETTING STARTED

Once batteries are in place for the remote unit, they will start transmitting temperature readings at 78-second intervals.

The main unit will also start searching for signals for about four minutes once batteries are installed. Upon successful reception, the outdoor temperature will be displayed on the top line and the indoor temperature on the second line. The main unit will automatically update its readings at about 78-second intervals.



If no signals are received, blanks " " will be displayed and the kinetic wave icon will show "⚡". Press [▲] and [▼] simultaneously to enforce another search for about 4 minutes. This is useful in synchronizing the transmission and reception of the remote and main units.

HOW TO CHECK REMOTE AND INDOOR TEMPERATURES

The indoor temperature is shown on the second line of the display. The outdoor temperature is shown on the top line of the display. The kinetic wave display on the outdoor temperature indicates if the reception of the remote unit is in good order.

If no readings are received from the remote unit for more than four minutes, blanks " " will be displayed until further readings are successfully searched. Check if the remote unit is sound and secure. You can wait for a little while or press [▲] and [▼] simultaneously to enforce an immediate search.

If the temperature goes above or below than the temperature measuring range of the main unit or the remote unit (stated in specification), the display will show "HHH" or "LLL".

HOW TO READ THE KINETIC WAVE DISPLAY

The kinetic wave display shows the signal receiving status of the main unit. There are three possible forms:



The unit is in searching mode.	•
Temperature readings are securely registered.	•
No signals.	•

If that fails, check:

1. The remote unit is still in place.
2. The batteries of both the remote unit and main unit. Replace as necessary.

Note: When the temperature falls below freezing point, the batteries of outdoor units will freeze, lowering their voltage supply and the effective range.

3. The transmission is within range and path is clear of obstacles and interference. Shorten the distance when necessary.

MAXIMUM AND MINIMUM TEMPERATURES

The maximum and minimum recorded indoor and outdoor temperatures will be automatically stored in memory. To display them, press [MEM] once to display the maximum temperature and again the minimum temperature. The respective indicators, [MAX or MIN] will be displayed.

To clear the memory, hold down [MEM] for two seconds. The maximum and minimum temperatures will be erased. If you press [MEM] now, the maximum and minimum temperatures will have the same values as the current ones until different readings are recorded.

DISCONNECTED SIGNALS

If without obvious reasons the display of the outdoor temperature goes blank, press [▲] and [▼] to enforce an immediate search.

TRANSMISSION COLLISION

Signals from other household devices, such as door bells, home security systems and entry controls, may interfere with those of this product and cause temporarily reception failure. This is normal and does not affect the general performance of the product. The transmission and reception of temperature readings will resume once the interference recedes.

NOTE ON °C AND °F

The unit of temperature display can be selected by pressing °C / °F button repeatedly.


GB

CALENDAR CLOCK DISPLAY MODES

The clock and the calendar share the same section of the display. The calendar is displayed in a day-month format.



CLOCK MODE



CALENDAR MODE

Each press on the [MODE] button will toggle the display between clock and calendar mode.

ABOUT RADIO RECEPTION

The RMR232PHN/RMR232PHU is designed to automatically synchronize its calendar clock once it is brought within range of the Frankfurt DCF77 radio signal.(MSF for UK Version)

When the RMR232PHN/RMR232PHU is within range, its radio-control mechanism will override all manual settings unless auto-reception of radio signal has been deactivated.

When the unit is receiving radio signal, the radio reception signal will start to blink. A complete reception generally takes about 2 to 10 minutes, depending on the strength of the radio signal.

When the reception is complete, the radio reception signal will stop blinking. The strength of the reception for the last full hour will be indicated.

	- Strong
	- Weak
	- No Reception
	- Receiving

For better reception, place the clock away from metal objects and electrical appliances to minimize interference.

If you wish to disable the auto-reception feature, press the [▼] button for two seconds. The radio reception signal will disappear. The unit will not respond to radio signals.

To enable the feature again, press the [▲] button for two seconds. The radio reception signal will start blinking to initiate reception automatically.

HOW TO SET THE CALENDAR CLOCK MANUALLY

To set the clock manually, hold [**MODE/SET**] for two seconds in clock display mode. The 12-hr or 24-hr display will blink. Use [**▲**] or [**▼**] to select 12 hour or 24 hour format.

Press [**MODE/SET**] to confirm. Repeat the same procedure to set the hour, minutes, year, month, day and display language. During the setting, press and hold [**▲**] or [**▼**] will increase or decrease the value rapidly.

Note that the date is displayed in DAY-MONTH format. For display language, you can choose among English (E), German (D), French (F), Italian (I) and Spanish (S).

Language	Day-of-the-week						
	Monday	Tuesday	Wed.	Thursday	Friday	Saturday	Sunday
English (E)	Mo	Tu	We	Th	Fr	Sa	Su
German (D)	Mo	Tu	Mi	Do	Fr	Sa	So
French (F)	Lu	Ma	Me	Je	Ve	Sa	Di
Italian (I)	Lu	Ma	Me	Gi	Ve	Sa	Do
Spanish (S)	Lu	Ma	Mi	Ju	Vi	Sa	Do


If there is an item you do not wish to change, simply press [**MODE/SET**] to bypass the item.

When you are done, press [**MODE/SET**] to exit. The display will return to the clock mode.

HOW TO SET AND ARM THE ALARM

This unit is equipped with a Daily Crescendo Alarm. To set the alarm,

1. Press [**(*)**] once to display alarm time. If the alarm is deactivated, the time will be displayed as [-:-].
2. Press [**(*)**] for two seconds. The hour digits will blink.
3. Enter the hour using [**▲**] or [**▼**].
4. Press [**(*)**]. The minute digits will blink.
5. Enter the minutes using [**▲**] or [**▼**].
6. Press [**(*)**] to exit.

The alarm  icon will be displayed indicating the alarm is now armed. You can arm or disarm an alarm by pressing the [**(*)**] button repeatedly. Press [**MODE/SET**] to return to clock display mode.

When an alarm is armed, it will go off at the set time.

HOW TO STOP AN ALARM

When the alarm goes off, press any key on the unit to stop the alarm sound.

GB

PRECAUTIONS

This product is engineered to give you years of satisfactory service if you handle it carefully. Here are a few precautions:

1. Do not immerse the unit in water.
2. Do not clean the unit with abrasive or corrosive materials. They may scratch the plastic parts and corrode the electronic circuit.
3. Do not subject the unit to excessive force, shock, dust, temperature or humidity, which may result in malfunction, shorter electronic life span, damaged battery and distorted parts.
4. Do not tamper with the unit's internal components. Doing so will invalidate the warranty on the unit and may cause unnecessary damage. The unit contains no user-serviceable parts.
5. Only use fresh batteries as specified in the user's manual. Do not mix new and old batteries as the old ones may leak.
6. Always read the user's manual thoroughly before operating the unit.
7. Note: No rechargeable batteries should be used in this product. Only use the type of battery as specified.

SPECIFICATIONS

Temperature Measurement

Main unit

Indoor Temperature measurement

Proposed operating range : -5.0°C to +50.0°C

Temperature resolution : 0.1°C
(0.2°F)

Remote unit

Proposed operating range : -20.0°C to +60.0°C
(-4.0°F to 140.°F)

Temperature resolution : 0.1°C
(0.2°F)

RF Transmission Frequency : 433 MHz

No. of Remote unit : 1

RF Transmission Range : Maximum 30 meters

Radio Controlled Clock

Main time set and synchronized by Radio Signal DCF77 for Continental/ Central Europe (MSF for UK)
12/24 h display with hh : mm
Date Format : Day : Month
Day of week selectable in 5 language (E, F, D, I, S)
2-minute crescendo alarm

Power

Main unit : use 2 pcs UM3 or "AA"
1.5V alkaline battery

Remote sensing unit : use 2 pcs UM-3 or "AA"
1.5V alkaline battery

Weight

Main unit : 350g (without battery)
Remote sensing unit : 46g (without battery)

Dimension

Main unit : 180(L) x 178(W) x 28(T)
mm
Remote sensing unit : 89(L) x 44(W) x 21(T)
mm

NOTE ON COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operations.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving unit.
- o Increase the separation between the equipment.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer of an experienced radio/TV technician for help.

Company Name : Oregon Scientific, Inc.

Address : 19861 SW 95th Place, Tualatin, Oregon 97062, USA

Website Address: www.oregonscientific.com

Name and model number of the product: Remote Thermo RMR232PHA

CAUTION

- The content of this manual is subject to change without further notice.
- Due to printing limitation, the displays shown in this manual may differ from the actual display.
- The contents of this manual may not be reproduced without the permission of the manufacturer.

CB

CUSTOMER ASSISTANCE

Should you require assistance regarding this product and its operation, please contact our customer care department at 800-853-8883 or via email at helpme@oscientific.com.

WARRANTY

This product is warranted to be free of manufacturing defects for a period of 1 year from date of retail purchase. Defective product should be directed to the place of retail purchase for exchange.

Should this not be possible, contact our customer care department for assistance and a return material authorization. No returns may be made without a return authorization. Please retain your retail receipt as you may be asked to provide a copy of it for proof of date purchased. This warranty does not cover product subjected to abuse, misuse, accidental damage or tampering. Upon return of the defective product, Oregon Scientific will at its discretion, replace the product with either a new or a tested reconditioned product. Should the product be out of warranty, the consumer may purchase directly from Oregon Scientific a replacement at reasonable cost plus shipping and handling.