




1 Package Contents



AP




2 screws



Install Guide


If any item is incorrect, missing, or damaged, please keep the original package and contact your reseller for immediate replacement.

2 LED Status




LED	Color	Status	Description
PWR	Green	Solid	The device is connected to power supply
		Blinking	The device is functioning correctly
		Off	Power is not supplied to the device or the device is malfunctioning

3 Network Topology




4 Hardware Install

1. Connect the Ethernet cable and phone cable in the wall jack to the device as seen in the figure below (Note: Make sure you leave a proper length of Ethernet cable, say, 5-8cm, inside the jack.)



2. You can access Internet via a wired or wireless connection. Also you can charge your terminal devices using the equipped USB port and connect your telephone to the RJ11 port on the device.




300M Wireless Access Point Install Guide


© 2015 IP-COM Networks Co., Ltd. All rights reserved. This documentation (including pictures, images, and product specifications, etc.) is for reference only. To improve internal design, operational function, and/or reliability, IP-COM reserves the right to make changes to the products described in this document without obligation to notify any person or organization of such revisions or changes.

5 Configure PC (Windows 7 is used as an example below.)

A. Click **Start>Control Panel>Network and Internet>Network and Sharing Center.**




B. Click **Local Area Connection->Properties.**




Tip
System Requirement: PC with installed IE8 or higher or Google Web browser

C. Double click **Internet Protocol Version 4(TCP/IPv4).**



D. Configure your PC IP address: 192.168.0.X(2-253); Subnet mask: 255.255.255.0, and then click **OK** twice to exit.




6 Configure AP


A. Launch a web browser, say, IE. In the address bar, input 192.168.0.254 and press "Enter". Enter the login user name and password (Both are "admin" by default) and click Login.




1. WEP-802.1x




B. LAN Setup: Click **LAN Setup** and configure the address mode, LAN IP address, subnet mask, gateway and DNS Server addresses.




2. WPA-PSK, WPA2-PSK



C. Wireless: Click **Wireless -> Basic** and configure SSID, and security settings (Security settings are explained below).



3. WPA, WPA2



If your computer is set to a static or fixed IP address (This is uncommon), change it to **Obtain an IP address automatically** and **Obtain DNS Server automatically**. See 5 Configure PC.

FAQs

Q: I cannot access the device's web manager when entering 192.168.0.254 in my browser. What should I do?

1. Make sure your PC's IP address is set to 192.168.0.x (where x can be any integer between 2 and 253).
2. Try a different browser or delete your existing browser's cache and cookies.
3. Try a different PC.
4. Restore the device to factory defaults (see the following question) and retry.

Q: How do I reset the device to factory defaults?

A: Press the reset button on the device with a needle for 7 seconds and the device will restore to its factory defaults and then restart automatically.

⚠ Note:

All settings will be restored to factory defaults once you pressed the reset button. You will then need to reconfigure the device for specific purposes.



CE Mark Warning
This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. This device complies with EU 1999/5/EC.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.
FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



SHENZHEN IP-COM NETWORKS CO., LTD.
Tower E3, No. 1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052
Phone: (86 755) 27655089
Email: marketing@ip-com.com.cn
Info@ip-com.com.cn
Skype: IP-COM Support
Website: www.ip-com.com.cn