





ANNEX 8 TO TEST REPORT # EMCC-010133BC, 2002-12-13

USER MANUAL

EQUIPMENT UNDER TEST:

Trade Name: i-CARD Interrogator

i-Card3 Model No.: Serial No.: none

Equipment Category: Transceiver

Manufacturer: **IDENTEC SOLUTIONS AG**

Address: Millennium Park 2 A-6890 Lustenau

Austria

Phone: +43-5577-87 387-0 Fax: +43-5577-87 387-15

E-mail: r.gantner@identecsolutions.at

RELEVANT STANDARD: 47 CFR Part 15.249


EMCC DR. RAŠEK Moggast 72-74 91320 Ebermannstadt Germany





PC i-CARD III User's Guide

December 12, 2002



IDENTEC SOLUTIONS AG Millennium Park 2 A-6890 Lustenau Austria

Tel: +43 (0) 5577 87387 - 0 Fax: +43 (0) 5577 87387 - 15 www.identecsolutions.com



Proprietary Notice

This document contains confidential information proprietary to IDENTEC SOLUTIONS and may not be used or disclosed to other parties in whole or in part without prior written authorization from IDENTEC SOLUTIONS.

Disclaimer and Limitation of Liability

IDENTEC SOLUTIONS AG and its affiliates, subsidiaries, officers, directors, employees and agents provide the information contained in this Manual on an "as-is" basis and do not make any express or implied warranties or representations with respect to such information including, without limitation, warranties as to non-infringement, reliability, fitness for a particular purpose, usefulness, completeness, accuracy or currentness. IDENTEC SOLUTIONS AG shall not in any circumstances be liable to any person for any special, incidental, indirect or consequential damages, including without limitation, damages resulting from use of or reliance on information presented herein, or loss of profits or revenues or costs of replacement goods, even if informed in advance of the possibility of such damages.

Trademarks

"IDENTEC SOLUTIONS", "Intelligent Long Range", "ILR" and the stylized "i" are registered trademarks and "i-Q", "i-D", "i-CARD", "i-PORT", "i-LINKS", "Solutions. It's in our name." are trademarks of IDENTEC SOLUTIONS, Inc. and/or IDENTEC SOLUTIONS AG.

Copyright Notice

Copyright © 2002 IDENTEC SOLUTIONS. All rights reserved.

No part of this document may be reproduced or transmitted in any form by any means, photographic, electronic, mechanical or otherwise, or used in any information storage and retrieval system, without the prior written permission of IDENTEC SOLUTIONS.

Radio Frequency Compliance Statement

IDENTEC SOLUTIONS AG. is the responsible party for the compliance of the following devices:

| MODEL: | i-PORT | i-CARD III | i-D TAGS | i-Qxx TAGS |
|---------|---------------|-----------------|-------------|-----------------|
| FCC ID: | O2E-ILR-IPORT | 004-ILR-ICARD3- | OO4-ILR-ID2 | OO4-ILR-IQ8T or |
| | | | | OO4-ILR-IQR |
| CANADA: | 35381032062A | Pending | 3538A 12112 | 35381021756A or |
| | | _ | | 35381021825 |
| EUROPE: | CE 0678(!) | CE 0678(!) | CE 0678(!) | CE 0682(!) |

The user(s) of these products are cautioned to only use accessories and peripherals approved, in advance, by IDENTEC SOLUTIONS. The use of accessories and peripherals, other than those approved by IDENTEC SOLUTIONS, or unauthorized changes to approved products, may void the compliance of these products and may result in the loss of the user(s) authority to operate the equipment.

Operation is subject to the following conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference, including interference that may cause undesired operation of the device.

FCC Compliance (i-CARD III / NA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communication. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Compliance (i-CARD III / NA)

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada.

European Notification according R&TTE Directive (i-CARD III / EU)

This equipment complies to Art. 6.4 of R&TTE Directive (1999/5/EC) and can be used in the following European countries:

Belgium, Denmark, Finland, France, Germany, Ireland, Luxembourg, Netherlands, Austria, Portugal, Sweden, Spain, United Kingdom, Norway, Switzerland.

European Notification according R&TTE Directive (i-CARD III / EU / I)

This equipment complies to Art. 6.4 of R&TTE Directive (1999/5/EC) including national restrictions in Italy according ERC/REC 70-03 Annex 1 Band I and can be used in above noted European countries and Italy.

Table of Contents

| 1.0 Overview | 6 |
|---|----|
| 1.1 Functionality | 6 |
| 1.2 Components | 6 |
| 2.0 Installation | 7 |
| 2.1 Hardware | 7 |
| 2.2 Software | 7 |
| 2.2.1 Windows 98/ Windows 2000/Windows ME | 8 |
| 2.2.2 Windows NT/Windows CE | 9 |
| 3.0 Usage | 9 |
| Appendix A: Technical Specifications | 10 |

1.0 Overview

This guide explains how to install and operate the PC version of the i-CARD III when using a laptop or desktop computer.

1.1 Functionality

The i-CARD III is IDENTEC SOLUTIONS' Intelligent Long Range (ILR®) radio frequency mobile interrogator in a type II PC Card format. The PC i-CARD III is easily integrated into portable or laptop computers and is used in conjunction with i-LINKS (or other ILR® software) to read and write data to tags. The flexibility of an interrogator on a PC Card allows for easy integration of ILR® into enterprise systems and permits combination with other technologies such as bar code and wireless LAN.

The PC i-CARD III is available in a FCC compliant version (i-CARD III/NA) and two European versions (i-CARD III / EU and i-CARD III / EU / I) to communicate in a global market. The signal propagation characteristics of the UHF radio band used by ILR® technology provide long-range communication and high-speed transmission rates for reliable data exchange.

Computers with a PC i-CARD III can communicate to tags at a distance of up to 10 meters (33 feet). The i-CARD III communicates with the entire i-Q active tag product line including i-Q8, i-Q8T, i-Q32, and i-Q32T tags. The European versions are also compatible with the i-D tag product line.

The installation and usage instructions for the PC i-CARD III are identical for all versions.

1.2 Components

The i-CARD III resembles a standard PC card with one addition: an external antenna. On the exposed end of the i-CARD III, there are an MMCX antenna connector, a 15-pin serial connector (not used in the PC version of the i-CARD III) and 3 status LEDs indicating *Transmit*, *Receive* and *RF Carrier Detect*. These LEDs are operational after appropriate ILR® software is installed (i.e. i-LINKS).



Note: The current version only supports a quarter wavelength antenna available under P/N 887124 from IDENTEC SOLUTIONS and equivalent internal antennas for hand helds.

Figure 1: i-CARD III Components



2.0 Installation

The PC i-CARD III is easy to install—simply attach the antenna, insert the i-CARD III into the desired computer and install the necessary hardware driver for the specific operating system. The following sections describe each of these steps in detail.



Note: The hardware driver only needs to be installed the first time an i-CARD III is inserted into a computer or when performing an upgrade to the driver.

2.1 Hardware

To install the external antenna, grasp its base and insert it into the antenna connector until it locks into place.

Figure 2: Antenna Installation



To remove the antenna, grasp the base firmly and remove carefully to avoid damage.

2.2 Software

The computer being used for i-CARD III operations must be running one of the following operating systems: Windows NT/98/ME/2000/CE.

To install the i-CARD III, perform the following steps:

- 1. Insert the ILR® Installation Disk (either floppy disk or CD) into the computer that will operate the i-CARD III.
- 2. Insert the i-CARD III into the PC card slot of the desktop or laptop computer. An installation wizard will start immediately after the i-CARD III is inserted.
- 3. Complete the wizard instructions and refer to the following sections for additional instructions specific to each operating system:

| ction: |
|--------|
| 1 |
| 2 |
| 2 |
| 3 |
| 4 |
| |



Note: A *readme.txt* file is available for each operating system on the **ILR® Installation Disk** and contains the same instructions that are described in the following sections.

2.2.1 Windows 98/ Windows 2000/Windows ME

The following section describes how to install the device driver on Windows 98, Windows 200 and Windows ME. When the i-CARD III is inserted into the PC slot, an installation wizard begins automatically and the following screen appears:



Select the Search for a suitable driver for my device option and click Next.

Selecting a search location depends on the type of **ILR® Installation Disk** you received. If you received a floppy disk, the search location is the **A:** drive. If you received a CD, the search location is the **D:** drive.

For a search location, select the *Floppy Disk Drives* option, and click *Next*. Click the *Browse* button to copy drivers from your **ILR® Installation Disk**:



Using the *Browse* dialog box, select the $\drivers\Windows\ 98$ folder. Select the *i-CARD III.inf* file, then click OK.



Note: The driver used for Windows ME is the same as Windows 98 and is stored in the subfolder *Windows 98* on the **ILR® Installation Disk**.

The hardware driver is loaded and a confirmation screen appears. This screen verifies that the installation has completed successfully. Click *Next* to complete the installation.

The hardware driver installation is now complete.

2.2.2 Windows NT/Windows CE

For these intallations please see Readme-file on Distribution Disk.



Note: When the installation is finished you must power off your handheld device and power it back on to complete the driver initialization.

3.0 Usage

After completing the i-CARD III installation, please refer to the user's guide of the applicable software to continue with the system implementation.

The i-CARD III can be used in conjunction with a variety of software applications, such as i-DEMO, i-LINKS and other ILR® custom applications.

4.0 Application program rules

Due to national restrictions not all parameter values are valid in each version of the i-CARD III. Programmers of application software are strongly recommended to read the documentation which comes with the development package.



Note: When trying to set an operation mode or output power which is not allowed in the national version the i-CARD III returns with an error code. Please refer to the library manual.

According to ERC/REC70-03 a maximum duty cycle of 1% (i-Q- tags) and 10% (i-D- tags) is allowed in Europe. Due to the protocol used on the RF link this means no restrictions for interactive operation. However in continuously running applications the application programmer must ensure observance of these rules. For details please see the documentation which comes with the development package.

To minimize spurious radiation consecutive scans must be separated by pauses with a length of at least 0.2 seconds. Again this is no restriction for interactive application as a scan is typically followed by manual selection of a tag in a list which normally lasts longer than this required time.

Appendix A: Technical Specifications

Type II PC i-CARD III

| Compatibility ILR® tags | i-Q xx /EU (i-CARD III/EU, i-CARD III/EU/I, mode 2) |
|---|---|
| 0 11 31 | i-Q xx /NA (i-CARD III/NA, mode 4) |
| | i-D (i-CARD III/EU, i-CARD III/EU/I, mode 1) |
| Performance | |
| Read range (adjustable) | 10 m (33 ft) |
| Write range (adjustable) | 10 m (33 ft) |
| Read rate (ID only) | 100 tags/s |
| Read rate | 35 tags/s @ 128 bit data reading |
| Multiple tag handling | Up to 2,000 tags in the read zone |
| Communication | |
| Frequency Downlink | 868.350 MHz (i-CARD III/EU, i-CARD III/EU/I, mode 2 |
| | 869.525 MHz (i-CARD III/EU, i-CARD III/EU/I, mode 1 |
| | 916.500 MHz (i-CARD III/NA, mode 4) |
| Frequency Uplink | 868.350 MHz (i-CARD III/EU, i-CARD III/EU/I, |
| | modes 1,2) |
| Cantification | 916.500 MHz (i-CARD III/NA, mode 4) |
| Certification | EN 330 220 (EU); FCC part 15 (US); Industry Canada |
| Number of antennas | 1 |
| Output power | Up to 0 dBm (i-CARD III/EU, i-CARD III/EU/I, i-CARD III/NA, modes 2,4)) |
| | Up to 24 dBm (i-CARD III/RU, mode 1) |
| | Up to 14 dBm (i-CARD III/EU/I, mode 1) |
| Sensitivity | -85 dBm (high sens.), -45 dBm (low sens.) |
| CPU | os dem (mgh sens.), 43 dem (low sens.) |
| Hardware drivers for different O/S | Windows NT/98/ME/2000/CE, PALM OS |
| Program memory | 2 MB Flash |
| User Interfaces | |
| Parallel interface | PCMCIA |
| Serial interface | RS-232 |
| Number of status indications | 3 LEDs |
| Electrical | |
| | |
| Input power | 5 V DC ± 5% |
| Input power Power consumption | 25 mA (operating) 300 mA (maximum pulse) |
| Input power Power consumption Standards / Safety | |
| Input power Power consumption Standards / Safety Environmental | 25 mA (operating) 300 mA (maximum pulse) CE |
| Input power Power consumption Standards / Safety Environmental Operating temperature | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range Storage temperature | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) -40°C to +80°C (-40°F to +176°F) |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range Storage temperature | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range Storage temperature Humidity Physical | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) -40°C to +80°C (-40°F to +176°F) 90% non-condensing |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range Storage temperature Humidity Physical Dimensions | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) -40°C to +80°C (-40°F to +176°F) 90% non-condensing Standard Type II PC Card |
| Input power Power consumption Standards / Safety Environmental Operating temperature Option ext. temperature range Storage temperature Humidity Physical | 25 mA (operating) 300 mA (maximum pulse) CE -20°C to +60°C (-4°F to +140°F) -40°C to +80°C (-40°F to +176°F) -40°C to +80°C (-40°F to +176°F) 90% non-condensing |