

\$50.00

USER'S GUIDE

MCP CAB RADIO A53470

August 2009

DOCUMENT NO. COM-00-09-08 VERSION A

Safetran Systems Corporation, California Division 10655 7th Street, Cucamonga, California 91730 1-800-793-SAFE

Copyright © 2009 Safetran Systems Corporation, All rights reserved

PROPRIETARY INFORMATION

SAFETRAN SYSTEMS CORPORATION has a proprietary interest in the information contained herein and, in some instances, has patent rights in the systems and components described. It is requested that you distribute this information only to those responsible people within your organization who have an official interest.

This document, or the information disclosed herein, shall not be reproduced or transferred to other documents or used or disclosed for manufacturing or for any other purpose except as specifically authorized in writing by **SAFETRAN SYSTEMS CORPORATION**.

TRANSLATIONS

The manuals and product information of **SAFETRAN SYSTEMS CORPORATION** are intended to be produced and read in English. Any translation of the manuals and product information are unofficial and can be imprecise and inaccurate in whole or in part. **SAFETRAN SYSTEMS CORPORATION** does not warrant the accuracy, reliability, or timeliness of any information contained in any translation of manual or product information from its original official released version in English and shall not be liable for any losses caused by such reliance on the accuracy, reliability, or timeliness of such information. Any person or entity that relies on translated information does so at his or her own risk.

WARRANTY INFORMATION

SAFETRAN SYSTEMS CORPORATION warranty policy is as stated in the current Terms and Conditions of Sale document. Warranty adjustments will not be allowed for products or components which have been subjected to abuse, alteration, improper handling, or installation, or which have not been operated in accordance with Seller's instructions. Alteration or removal of any serial number or identification mark voids the warranty.

SALES AND SERVICE LOCATIONS

Technical assistance and sales information on **SAFETRAN** products may be obtained at the following locations:

SAFETRAN SYSTEMS CORPORATION	
2400 NELSON MILI	LER PARKWAY
LOUISVILLE, KENTU	JCKY 40223
TELEPHONE:	(502) 618-8800
FAX:	(502) 618-8810
SALES & SERVICE:	(800) 626-2710
WEB SITE:	http://www.safetran.com

SAFETRAN SYSTEMS CORPORATION CALIFORNIA DIVISION 10655 7th STREET CUCAMONGA, CALIFORNIA 91730 TELEPHONE: (909) 532-5300 CUSTOMER SERVICE: (800) 793-7233 TECHNICAL SUPPORT: (800) 793-7233 FAX: (909) 532-5400

FCC RULES COMPLIANCE

The equipment covered in this manual has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC PART 90 AND PART 101 REQUIREMENTS

This device contains a radio transceiver which operates under Parts 90.210 and 101.101 of the FCC rules in a licensed part of the radio spectrum. It is the user's responsibility to obtain required licensing and authorization to operate this device. Qualified personnel must perform service or repairs to the radio portion of this device. Any unauthorized modification to the radio module, shielding, or antenna system may void the user's authority to operate this device.



RF EXPOSURE WARNING



All antenna installation and servicing is to be performed by qualified technical personnel only. When servicing or working at distances closer than 10 feet (3.05 meters), ensure the transmitter has been disabled. Depending upon the application and the gain of the antenna, the total composite power could exceed 200 watts EIRP. The antenna location should be such that only qualified technical personnel can access it, and under normal operating conditions no other person can come in contact or approach within 10 feet (3.05 meters) of the antenna.

This device complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation Human Exposure) Standard, 2003
- ANATEL, Brasil Regulatory Authority, Resolution 256 (April 11, 2001)

NOTES, CAUTIONS, AND WARNINGS

Throughout this manual, notes, cautions and warnings may be used to direct the reader's attention to specific information. Use of the three terms is defined as follows:

NOTE

Generally used to highlight certain information relating to the topic under discussion.

CAUTION

APPEARS IN UPPERCASE TYPE AND REFERS TO PROPER PROCEDURES OR PRACTICES WHICH IF NOT STRICTLY OBSERVED, WILL RESULT IN DAMAGE TO THE EQUIPMENT. CAUTIONS TAKE PRECEDENCE OVER NOTES AND ALL OTHER INFORMATION, EXCEPT WARNINGS.

WARNING

HIGHLIGHTED IN BOLD, UPPERCASE TYPE AND APPLIES TO SAFE AND RELIABLE OPERATION OF SAFETRAN EQUIPMENT. WARNINGS ALWAYS TAKE PRECEDENCE OVER NOTES, CAUTIONS, AND ALL OTHER INFORMATION.

Refer all questions to Safetran Customer Service.

ELECTROSTATIC DISCHARGE (ESD) PRECAUTIONS

Static electricity can damage electronic circuitry, particularly low voltage components such as the integrated circuits commonly used throughout the electronics industry. Therefore, procedures have been adopted industry-wide which make it possible to avoid the sometimes invisible damage caused by electrostatic discharge (ESD) during the handling, shipping, and storage of electronic modules and components. Safetran has instituted these practices at its manufacturing facility and encourages its customers to adopt them as well to lessen the likelihood of equipment damage in the field due to ESD. Some of the basic protective practices include the following:

- Ground yourself before touching card cages, modules, or components.
- Remove circuit boards (modules) from card cages by the ejector lever only.
- Handle circuit boards by the edges only.
- Never physically touch the circuit board contact fingers or allow these fingers to come in contact with an insulator (e.g., plastic, rubber, etc.).
- When not in use, place circuit boards in approved static-shielding bags, contact fingers first. Remove circuit boards from static-shielding bags by grasping the ejector lever or the edge of the board only. Each bag should include a caution label on the outside indicating static-sensitive contents.
- Cover workbench surfaces used for repair of electronic equipment with static dissipative workbench matting.
- Use integrated circuit extractor/inserter tools designed to remove and install electrostaticsensitive integrated circuit devices such as PROMs (OK Industries, Inc., Model EX-2 Extractor and Model MOS-40 Inserter (or equivalent) are highly recommended).
- Utilize only anti-static cushioning material in equipment shipping and storage containers.

For information concerning ESD material applications, please contact the Safetran California Division Technical Support Staff in Ranch Cucamonga, California. ESD Awareness Classes and additional ESD product information are also available through the Technical Support Staff.

TABLE OF CONTENTS

SECTION

<u>TITLE</u>

	PROPF	RIETARY INFORMATION	ii
	TRAN	SLATIONS	ii
	WARR	ANTY INFORMATION	ii
	SALES	AND SERVICE LOCATIONS	ii
	FCC R	ULES COMPLIANCE	iii
	FCC P	ART 90 AND PART 101 REQUIREMENTS	iii
	RF EXI	POSURE WARNING	iii
	NOTE	5, CAUTIONS, AND WARNINGS	iv
	ELECT	ROSTATIC DISCHARGE (ESD) PRECAUTIONS	V
	GLOSS	5ARY	xi
1 - 11	NTRODU	CTION	1-1
1.1	OVER	/IEW	1-1
1.2	EQUIP	MENT DESCRIPTION	1-2
1.3	INDIC	ATORS AND CONNECTORS	1-4
	1.3.1	Pin-outs for Client Ports J1	1-5
	1.3.2	Pin-outs for Client Port J2	1-5
	1.3.3	Pin-outs for Echelon® and Isolated I/O	1-6
	1.3.4	Pin-outs Diag Port (DB-9)	1-6
	1.3.5	Radio Diag Port	1-7
	1.3.6	Pin-outs for Power	1-7
1.4	LOGIC	BOARD 53076	1-8
1.5	SPECIF	FICATIONS	1-9
1.6	ORDE	RING INFORMATION	
	1.6.1	Cab Radio Ordering Information	
	1.6.2	Cab Radio Mating Connector Ordering Information	
2 - II	ISTALLA	TION AND SET UP	2-1
2.1	INSTA	LLATION	2-1
	2.1.1	Grounding	2-2
	2.1.2	MCP Cab Radio Cabinet	2-2
	2.1.3	Cable Installation	2-3
	2.1.3.1	J1 Client Cable	2-3
	2.1.3.1	.1 Ferrite Installation Procedure	2-4
	2.1.3.2	Echelon® and Isolated I/O Connection	2-4
	2.1.3.3	8 Antenna Connection	2-5
	2.1.3.4	Power Connection	2-6
2.2	XCMM	IAINT SOFTWARE	2-6
	2.2.1	Radio Settings	2-7
	2.2.2	Site Settings	2-7
	2.2.3	Lontalk® (Echelon®) Network Configuration	2-8

	2.2.4 P	ort Information	2-8
3 - OP	PERATION		3-1
3.1	OVERVIEV	V	3-1
3.2	CAB RADI	O FREQUENCY CONTROL	3-3
3.3	radio me	ESSAGES	3-3
	3.3.1 T	emporary Speed Restriction (TSR)	3-3
	3.3.2 Ir	nterlocking Status	3-4
3.4	POSITIVE	TRAIN CONTROL	3-4
4 - SE	RVICE		4-1
4.1	OVERVIEV	V	4-1
4.2	MCP DIAG	GNOSTICS	4-1
	4.2.1 C	pening XCMMAINT	4-1
	4.2.2 S	electing File	4-2
	4.2.3 U	Init Configuration	4-2
	4.2.4 T	erminal Mode	4-3
	4.2.4.1	Terminal Mode Commands	4-4
	4.2.4.1.1	AL en/ds - Alarm Logging	4-4
	4.2.4.1.2	DCP - Display Codeplug	4-5
	4.2.4.1.3	DDC - DC Configuration Values	4-6
	4.2.4.1.4	VER - Firmware Hardware Codeplug Version Information	4-7
	4.2.4.1.5	BSTAT - Active Base Station Status	4-7
	4.2.4.1.6	CSTAT - Communication Statistics	4-8
	4.2.4.1.7	HSTAT - HDLC Statistics	4-9
	4.2.4.1.8	MSTAT - Manufacturer Statistics	4-9
	4.2.4.1.9	LOG - Display Log	4-10
	4.2.4.1.10	SL - Status Log	4-10
	4.2.4.1.11	TIMERS - Display Timer Configurations	4-11
	4.2.4.1.12	TEST restart - MCP Self-Test	4-11
	4.2.4.1.13	SERV - Service Command	4-12
	4.2.4.1.14	CHAN - Change Channel (SERV Mode Only)	4-12
	4.2.4.1.15	ERT - Error Rate Test (SERV Mode Only)	4-13
	4.2.4.1.16	PTT en/ds - Push To Talk (SERV Mode Only)	4-15
	4.2.4.1.17	SIMP en/ds - Simplex Command (SERV Mode Only)	4-16
	4.2.4.1.18	Exit SERV Mode	4-16
	4.2.4.2	Bit Map Display	4-17
	4.2.4.3	Read DC Configuration from Unit	4-18
	4.2.4.4	Read Codeplug from Unit	4-18
	4.2.4.5	Upload Codeplug to Unit	4-19
	4.2.4.6	Upload DC Configuration to Unit	4-19
	4.2.4.7	Upload Logic to Unit	4-19
	4.2.4.8	Upload Labels to Unit	4-20
	4.2.4.9	Radio Diagnostics	4-20
	4.2.4.9.1	Activation of Radio Diagnostics Port	4-20
	4.2.4.10	Radio Configuration Software	4-21

4.2.4.10.1	Opening Radio Configuration Software	. 4-22
4.2.4.10.2	Open Com Port	. 4-22
4.2.4.10.3	Radio Information	. 4-23
4.2.4.10.4	Radio Settings	. 4-23
4.2.4.10.5	Options	. 4-24
4.2.4.10.6	Main Menu	. 4-24
4.2.4.10.7	Diagnostic Maintenance and Calibration	. 4-25
4.2.4.10.8	Auto-Configure	. 4-26
4.2.4.10.9	Programming Transmit Frequency	. 4-30
4.2.4.10.10	Programming a Receive Frequency	. 4-31
4.2.4.10.11	Setting Transmit Power Level	. 4-31
4.2.4.10.12	Program Time-out Timer Delay	. 4-32
4.2.4.10.13	Program Loopback Code	. 4-32
4.2.4.10.14	Program Diagnostic Mode Level	. 4-33
4.2.4.10.15	Program CTS Delay	. 4-33
4.2.4.10.16	Program PTT Delay	. 4-33
4.2.4.10.17	Switched Carrier Mode	. 4-33
4.2.4.10.18	Program Modem Type	. 4-33
4.2.4.10.19	Program Emphasis	. 4-33
4.2.4.10.20	Program Owner's Name	. 4-33
4.2.4.10.21	Program Owner's Message	. 4-33
4.2.4.10.22	Program Soft Carrier Dekey Delay	. 4-33
4.2.4.10.23	Program Squelch Tail Eliminator	. 4-34
4.2.4.10.24	Program TX Level	. 4-34
4.2.4.10.25	Program RX Level	. 4-34
4.2.4.10.26	Closing MDS Configuration Software	4-34

LIST OF FIGURES

FIGURE NUMBER

<u>TITLE</u>

PAGE

Figure 1-1	A53470 MCP Cab Radio	1-1
Figure 1-2	Cab Radio Block Diagram	1-2
Figure 1-3	Cab Radio Views	1-3
Figure 1-4	Indicators and Connectors	1-4
Figure 1-5	Radio Diag Port Pin-out	1-7
Figure 1-6	Logic Board Access Panel	1-8
Figure 2-1	Pem Nut Locations	2-1
Figure 2-2	Mounting Dimensions	2-1
Figure 2-3	Chassis Grounding Screws	2-2
Figure 2-4	Cable Installation	2-3
Figure 2-5	Installing Ferrite Filter on Data Cable	2-4
Figure 2-6	Completed Ferrite Installation	2-4
Figure 2-7	XCMMAINT Software - Version Verification	2-6
Figure 2-8	XCMMAINT Software - Radio Settings	2-7
Figure 2-9	XCMMAINT Software - Site Settings	2-7
Figure 2-10	XCMMAINT Software - Lontalk® Network Configuration	2-8
Figure 2-11	XCMMAINT Software - Port Information	2-8
Figure 3-1	Locomotive Configuration	3-1
Figure 3-2	Typical Network Configuration	3-2
Figure 3-3	Cab Radio Frequency Control	3-3
Figure 3-4	Temporary Speed Restriction Example	3-3
Figure 3-5	Interlocking Status	3-4
Figure 3-6	PTC Display	3-4
Figure 4-1	Opening XCMMAINT	4-1
Figure 4-2	Filename Select	4-2
Figure 4-3	Opening Screen	4-2
Figure 4-4	Terminal Mode	4-3
Figure 4-5	Terminal Mode - Help Screen	4-3
Figure 4-6	Display Alarms	4-4
Figure 4-7	Display Codeplug Contents	4-5
Figure 4-8	Display DC Configuration	4-6
Figure 4-9	Version Identification	4-7
Figure 4-10	Base Station List	4-7
Figure 4-11	Communication Statistics	4-8
Figure 4-12	HDLC Statistics	4-9
Figure 4-13	Manufacturer Statistics	4-9
Figure 4-14	View Log	4-10
Figure 4-15	Status Log	4-10
Figure 4-16	Timer Status	4-11

Figure 4-17	MCP Self-test	4-11
Figure 4-18	Service (SERV) Mode	4-12
Figure 4-19	Change RX/TX Channel	4-12
Figure 4-20	Error Rate Test Screens	4-13
Figure 4-21	PTT - Push To Talk Command	4-15
Figure 4-22	Simplex and Normal Mode Displays	4-16
Figure 4-23	Exit SERV Mode	4-16
Figure 4-24	Bitmap Display	4-17
Figure 4-25	Read DC Configuration from Unit	4-18
Figure 4-26	Read Codeplug from Unit	4-18
Figure 4-27	Activation of Radio Diagnostics Port	4-20
Figure 4-28	Exit XCMMAINT	4-21
Figure 4-29	Configuration Software - Opening Screen	4-22
Figure 4-30	Configuration Software - Open Comm Port	4-22
Figure 4-31	Configuration Software - Radio Information Tab	4-23
Figure 4-32	Configuration Software - Radio Settings Tab	4-23
Figure 4-33	Configuration Software - Radio Options	4-24
Figure 4-34	Configuration Software - Main Menu	4-24
Figure 4-35	Configuration Software - Main Menu - Diag. Maint. & Calib	4-25
Figure 4-36	Configuration Software - Diagnostic Maintenance and Calibration	4-25
Figure 4-37	Configuration Software - Auto-Configure Current Radio	4-26
Figure 4-38	Configuration Software - Auto Configure Utility	4-27
Figure 4-39	Configuration Software - Auto Configure Programming Example	4-29
Figure 4-40	Configuration Software - Program Transmit Frequency	4-30
Figure 4-41	Configuration Software - Program Receive Frequency	4-31
Figure 4-42	Configuration Software - Setting Transmit Power Level	4-32
Figure 4-43	Closing the MDS Configuration Software	4-34

LIST OF TABLES

TABLE NUMBER

<u>TITLE</u>

PAGE

Table 1-1	Pin-outs J1 Client Port	1-5
Table 1-2	Pin-outs J2 Client Port	1-5
Table 1-3	Pin-out for Echelon® and Isolated I/O	1-6
Table 1-4	Pin-out for Diag Port	1-6
Table 1-5	Pin-outs for Power Connector	1-7
Table 2-1	Length vs. Loss in Coaxial Cable at 960 MHz	2-5

AAR:	Association of American Railroads - An organization that establishes uniformity and standardization among different railroad systems.
ABM:	Asynchronous Balance Mode – Used as an identifier for a HDLC protocol.
ADM:	Asynchronous Disconnect Mode – Used as an identifier for a HDLC protocol.
AEI:	Automatic Equipment Identification - Equipment installed at sites along the track to read and report train consist information.
ARES:	Advanced Railroad Electronics System - Made by Rockwell International as an alternative to AAR ATCS.
ATCS:	Advanced Train Control System - A set of standards compiled by the AAR for controlling all aspects of train operation.
BCP:	Base Communications Package - Defined by the ATCS specifications as the transmitter / receiver base station and associated processors to handle communications between mobile and central office equipment.
BER:	Bit Error Rate - Expresses the quality of a communications in the number of errors per bits sent.
BPSK:	Binary Phase Shift Keying - A method of modulating a carrier signal to carry two bits of information in every cycle.
CBT:	<u>Common Base Technology</u> – A term referring to product design using a modular based approach.
CC:	<u>Cluster Controller</u> - An ATCS ground network node responsible for the control of BCP's.
CPC:	<u>Central Protocol Converter</u> - Modular component of Safetran's R/Link™ Radio Control System that converts CTC code line control and indication message data to ATCS-compatible data.
CRC:	<u>Cyclic Redundancy Check</u> - The CRC on a data packet is normally calculated and appended to the data so that the receiver can verify that no data was lost or corrupted during transit.

CMSA/CA:	<u>Carrier-Sense-Multiple-Access/Collision Avoidance</u> - A scheme for allowing multiple transmitters sharing a single medium to cooperatively timeshare with a minimum of overlap and interference.
стс:	Central Traffic Control System
CTS:	<u>Clear To Send</u>
dB:	Abbreviation for decibel. The standard unit for expressing transmission gain or loss and relative power levels. Decibels indicate the log ratio of power output to power input.
dBi:	Abbreviation for decibels referenced to an isotropic (unipole) antenna.
dBm:	Abbreviation for decibels above (or below) one milliwatt.
DCE:	Data Communications Equipment - A device that merely transports but does not originate or consume data.
DEVICE:	Specific to the Contents Listing, MCF Approval Listing, and Diagnostic Terminal Utility, a device represents the smallest possible breakdown of an ATCS address which may identify a Virtual Circuit, cut section, signal SAT, module, etc.
DTE:	Data Terminal Equipment - Any device (printer, terminal, PC, host computer) that originates or consumes data over a transmission facility.
EIA:	<u>Electronics Industries Association</u> - A standards organization in the U.S. specializing in the electrical and functional characteristics of interface equipment.
ECP:	Emergency Control Protocol
ERP:	<u>Effective Radiated Power</u> - The product of the antenna power (transmitter power less transmission-line loss) times either the antenna power gain or the antenna field gain squared.
FEP:	<u>Front End Processor -</u> An ATCS ground network node responsible for providing network access to ground host and terminal users (provides network interfacing).

FIFO:	<u>First In, First Out</u> - A buffer or shift register configured so that the first data queued is the first data de-queued - i.e. the sequence is preserved.
FSK:	<u>Frequency Shift Keying</u> - A baseband modulation technique that conveys digital information over analog facilities by associative discrete logical states with pre-defined frequencies.
GENI (F):	Genesys Field Protocol
GENI (O):	Genesys Office Protocol
HAYES AT COMMAND:	A set of commands defined by the Hayes Corporation for the control and configuration of modems.
HDLC:	High-level Data Link Control - A serial protocol for exchanging synchronous information.
IP:	Internet Protocol - ISO Model Layer 3 (network) protocol that performs proper routing of packets.
LAN:	Local Area Network - A limited network where the data transfer medium is generally wires or cable.
LINK MARGIN:	The amount of received signal strength beyond the receiver threshold reserved to compensate for normal signal fluctuations.
LSB:	Least Significant Bit of a binary number (having the lowest numerical weight)
MCP/WCP:	<u>Mobile/Wayside Communications Package</u> - The radio and associated processor used by mobile and wayside ATCS compatible equipment to communicate to the central office.
MCP:	Mobile Communications Package - The radio and associated processor used by mobile ATCS compatible equipment to communicate to the central office.
MCS:	Harmon Protocol
MSB:	Most Significant Bit of a binary number (having the greatest numerical weight)
NUL:	<u>Null</u> – Used as an identifier for a HDLC protocol.

NULL MODEM:	A cable or other device that connects two DTE devices directly by emulating the physical connections of a DCE (the Transmit output of each DTE is connected to the Receive input of the other DTE).
POL	Polled – Used as an identifier for a HDLC protocol.
RCI:	Receive Clock In
RS232:	EIA interface standard between DTE and DCE, employing serial binary data interchange.
RS422:	EIA interface standard that extends transmission speeds and distances beyond RS232, employing a balanced-voltage system with a high level of noise immunity.
RSSI:	<u>Received Signal Strength Indication</u> - A numerical value indicating the relative strength of received carrier.
RTS:	Ready To Send
RTU:	<u>Remote Terminal Unit</u> - Also known as Field Code Unit or Code Unit. Used to perform non-vital I/O under control of a central office unit.
RXD:	Receive Data
SCS:	Safetran Code System
SSI:	Signal Strength Indicator - A measure of the relative strength of an incoming RF signal when it was received by a BCP.
SSR:	<u>Spread Spectrum Radio</u> - A transmitter/receiver that uses a method of radio transmission in which the transmitted energy is evenly spread over the complete bandwidth of the radio, resulting in small RF signature.
TCI:	Transmit Clock In
тсо:	Transmit Clock Out

TCP/IP:	Transmission Control Protocol/Internet Protocol - The Internet protocol used to
	connect a world-wide internetwork of universities, research laboratories,
	military installations, organizations, and corporations. The TCP/IP includes
	standards for how computers communicate and conventions for connecting network and routing traffic.
TVD.	
UDP:	<u>User Datagram Protocol</u> - A transport protocol used primarily for the transmission of network management information. Not as reliable as TCP.

WIU: Wayside Interface Unit

This Page Intentionally Left Blank

SECTION 1 INTRODUCTION

1 - INTRODUCTION

1.1 OVERVIEW

The Mobile Communications Package (MCP) Cab Radio 53470 is a ruggedized unit for on board applications (e.g., locomotive) of the Safetran 53411 Wayside Communications Package (WCP). Mil-spec type connectors are used for power and I/O client ports. A two piece metal housing encapsulates the components.





1.2 EQUIPMENT DESCRIPTION

The 53470 Cab Radio consists of a UHF radio and 30 watt RF power amplifier. The Safetran 53076 Logic Board serves as an interface between the radio and the I/O data as well as a control head for radio operation. Mil-spec Client I/O ports A Type-N RF connector is provided for an external antenna. Diagnostic ports are panel mounted for the radio (RJ-11) and the logic card (DB-9).



Figure 1-2 Cab Radio Block Diagram

Three LEDs have been extended from the logic card to the cabinet front panel for RF Transmit, RX Receive, and Power/Health Check indications. Other indicators and switches used on the WCP CPU-II are accessible via a panel on the side of the unit.



FRONT

Figure 1-3 Cab Radio Views

1.3 INDICATORS AND CONNECTORS



Figure 1-4 details the indicators and connectors on the 53470 Cab Radio.

Figure 1-4 Indicators and Connectors

INDICATOR/CONNECTOR	DESCRIPTION
RX LED (Green)	Illuminates when signal is being received.
TX LED (Red)	Illuminates when transmitter is active.
Power/Health LED (Green)	Illuminates when power is on and flashes at 1 Hz
	indicating good health.
Antenna	Type-N RF connector for external antenna.
Power	Mil-Spec 4-pin male connector for 12 VDC input power.
Client Port 1	Mil-Spec 15-pin male connector for Data I/O
Client Port 2	Mil-Spec 15-pin male connector for Data I/O
Echelon®/Opto I/O	Mil-Spec 10-pin male connector for Echelon® I/O
Radio Diagnostics	RJ-11 connector for connection of computer to radio
	internal diagnostics using applicable software.
Logic Board Diagnostics	DB-9 female connector for connection to the Logic Board
	diagnostic program for set up Logic Control functions.

1.3.1 Pin-outs for Client Ports J1

The following is the pin-out description for the J1 Client Port.

Pin	Signal Name	I/O	Description
В	TXCO1-	0	Tx Clock -
С	TXCO+	0	Tx Clock +
D	TXD1-	0	Tx Data -
E	TXD1+	0	Tx Data +
F	RXC1-	I	Rx Clock -
G	RXC1+	I	Rx Clock +
Н	RXD1-	I	Rx Data -
J	RXD1+	I	Rx Data +
Р	Shield	-	-
R	Ground	-	-
A, K, L, M, N	Not Used	-	-

Table 1-1 Pin-outs J1 Client Port

1.3.2 Pin-outs for Client Port J2

The following is the pin-out description for the J2 Client Port.

Pin	Signal Name	I/O	Description
В	TXCO2-	0	Tx Clock -
С	TXCO2+	0	Tx Clock +
D	TXD2-	0	Tx Data -
E	TXD2+	0	Tx Data +
F	RXC2-	I	Rx Clock -
G	RXC2+	I	Rx Clock +
Н	RXD2-	I	Rx Data -
J	RXD2+	I	Rx Data +
Р	Shield	-	-
R	Ground	-	-
A, K, L, M, N	Not Used	-	-

Table 1-2Pin-outs J2 Client Port

1.3.3 Pin-outs for Echelon® and Isolated I/O

The following is the pin-out description for the Echelon® and Isolated I/O port.

Pin	Signal Name	I/O	Description
A	IA	I	General Purpose Input
В	IB	I	General Purpose Input
С	OC	0	General Purpose Output
D	OD	0	General Purpose Output
E	ECH 1A	I/O	Echelon Twisted Pair Not Polarity Sensitive
F	ECH 1B	I/O	Echelon Twisted Pair Not Polarity Sensitive
G, H, J, K	Not Used	-	-

Table 1-3 Pin-out for Echelon® and Isolated I/O

1.3.4 Pin-outs Diag Port (DB-9)

The following is the pin-out description for the DB-9 Diag Port.

Table 1-4	Pin-out for	Diag Port
-----------	-------------	------------------

Pin	Signal Name	I/O	Description
1	Chassis Ground	-	Chassis Ground
2	TXD	0	RS-232 Transmit Data
			RS-232 Voltage Levels
3	RXD	I	RS-232 Receive Data
			RS-232 Voltage Levels
5	Digital Ground	-	Digital Ground
7	CTS	I	Clear To Send
			RS-232 Voltage Levels
8	RTS	0	Request To Send
			RS-232 Levels
4, 6, and 9	Not Used	-	-

1.3.5 Radio Diag Port

The following is the pin-out description for the Radio Diag Port.



Figure 1-5 Radio Diag Port Pin-out

1.3.6 Pin-outs for Power

The following is the pin-out description for the Power connector.

Table 1-5 Pin-outs for Power Con

Pin	Signal Name	I/O	Description
В	Batt/Pwr-	-	Battery/Power-
D	Batt/Pwr+	-	Battery/Power+

1.4 LOGIC BOARD 53076

The Cab Radio 53076 Logic Board is the control interface that directs data flow and controls the radio operations. An access panel on the side of the cab radio enclosure for setup and servicing. Normal operation does not require access to the Logic Board. The access panel has a gasket seal out dirt and moisture. Figure 1-6 displays the Logic Board indicators and controls used for setup and troubleshooting.



Figure 1-6 Logic Board Access Panel

1.5 SPECIFICATIONS

PRIMARY POWER	
Input Voltage:	13.8 VDC Nominal (11.5 to 16.0 VDC)
Input Isolation:	Non-isolated
Power Consumption:	Rx: 400 mA @ 12V
	Tx @ 30 W: 10.8A @ 12V
Reverse Polarity Protection	Diode across primary input
PHYSICAL	
Dimensions:	11.25 inches (28.58 centimeters) wide
	4.25 inches (10.80 centimeters) high
	9.75 inches (24.77 centimeters) deep
	10.75 inches (27.31centimeters) deep (with handle)
Package Weight:	12 pounds (5.44 kilograms)
ENVIRONMENTAL	
Operating Temperature Range:	-22 °F to +140 °F (-30 °C to +60 °C)
Humidity:	95% @ 40° C non-condensing
TRANSMITTER	
Frequency Range:	800-960 MHz
Modulation Type:	Binary CPFSK
Audio Input Level:	-20 dBm to +5 dBm
Carrier Power	
Transmitter Exciter:	Maximum 5 Watts (+37 dBm)
Power Amplifier:	Maximum 30 Watts (+45 dBm)
Duty Cycle:	Continuous
Output Impedance:	50 ohms
Frequency Stability:	1.5 ppm, - 30 ° C to +60° C
Channel Spacing:	12.5 kHz
Spurious & Harmonic:	-65 dBc per EIA test specification
Intermodulation	-40 dBc
lime-out limer:	1-255 seconds (30 seconds default)
Iransmitter:	Data Activated or RTS
Response Time:	5 ms
Maximum FM modulation	±2.5 KHZ
FUL Emission Designators	ΕΣΙΛΙΟΣΥ/ΤΟΝ-Τ (δυδ-940 MHZ)

RECEIVER

Туре:	Double conversion super-heterodyne
Frequency Range:	800-960 MHz
Frequency Stability:	±1.5 ppm, -30° C to +60° C
Sensitivity:	12 dB SINAD @ -110 dBm
Spurious & Image Rejection:	70 dB Minimum
Inter-modulation Response	
Rejection:	65 dB Minimum per EIA specification
Selectivity:	65 dB Minimum, 12.5 kHz channel
Bandwidth:	12.5 kHz
Desensitization:	65 dB Minimum, 12.5 kHz channel
Bit-Error Rates:	1200 bps: 1 x 10-6 @ -110 dBm
	4800 bps: 1 x 10-6 @ -110 dBm
	9600 bps: 1 x 10-6 @ -108 dBm

POWER AMPLIFIER

Frequency	
Forward:	896.5-898 MHz
Reverse:	935.5-937 MHz
Carrier Power (5 watts drive):	30 watts
Forward Gain:	8 dB
Forward Gain Variation	
Over Operating Temperature:	±0.25 dB
Input VSWR (50 ohms):	1.5:1 Typical, 2:1 Maximum
PTT Delay:	10 µS Maximum
PTT Logic (Forward Path Select):	0.8 V Maximum
PTT Logic (Reverse Path Select):	2.8 V Minimum to 5.5 V Maximum
RF Rise/Fall Time:	1 µS
RF Rise/Fall Time: RF Input Level:	1 µS 20 watts Maximum
RF Rise/Fall Time: RF Input Level: Duty Factor:	1 μS 20 watts Maximum 20%
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration:	1 μS 20 watts Maximum 20% 5 Minutes
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics:	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics: Spurious:	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc 60 dBc
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics: Spurious: Maximum VSWR	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc 60 dBc Infinite
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics: Spurious: Maximum VSWR Reverse Insertion Loss:	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc 60 dBc Infinite 2.0 dB Maximum
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics: Spurious: Maximum VSWR Reverse Insertion Loss: Reverse Amplitude Variation:	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc 60 dBc Infinite 2.0 dB Maximum ±0.25 dB Maximum
RF Rise/Fall Time: RF Input Level: Duty Factor: Transmit Duration: Harmonics: Spurious: Maximum VSWR Reverse Insertion Loss: Reverse Amplitude Variation: Reverse Amplitude Variation	1 μS 20 watts Maximum 20% 5 Minutes 60 dBc 60 dBc Infinite 2.0 dB Maximum ±0.25 dB Maximum

1.6 ORDERING INFORMATION

The following is ordering information for the MCP Cab Radio and optional cabling.

1.6.1 Cab Radio Ordering Information

	Safetran Order Number
Description	
MCP Cab Radio	9000-53470-0001

1.6.2 Cab Radio Mating Connector Ordering Information

Description	Quantity Included	Safetran Order Number
10-pin I/O Port mating connector	0	Z701-00061-3116
		(Mfg. Part No. MS3116F12-10S-SR)
15-pin Client Port mating connector	0	Z714-9024-3116
		(Mfg. Part No. MS3116F14-15SR)
4-pin Power mating connector and	0	9000-26697-0001
power Cable 3 ft		
4-pin Power mating connector and	0	9000-26697-0002
power Cable 5 ft		
4-pin Power mating connector and	0	9000-26697-0003
power cable 10 ft		

This Page Intentionally Left Blank

SECTION 2 INSTALLATION AND SETUP

2 - INSTALLATION AND SET UP

2.1 INSTALLATION

The MCP Cab Radio is equipped with four (4) #10-32 pem nuts to secure the unit to a wall or shelf as shown in Figure 2-1.



Figure 2-1 Pem Nut Locations

Figure 2-2 displays the pem nut dimensions in addition to the dimensions of the MCP Cab Radio cabinet. Provide ample space for installation of the power, antenna, and client port connectors



Figure 2-2 Mounting Dimensions

2.1.1 Grounding

A grounding screw is located on each side of the unit as shown in Figure 2-3. The radio must be grounded to the locomotive chassis to avoid undesired ground loops with peripheral equipment connected to the MCP Cab Radio and maintain lightening and power transients.



Figure 2-3 Chassis Grounding Screws

2.1.2 MCP Cab Radio Cabinet

<u>NOTE</u>

Tighten all cabinet screws by hand. Do not use power screw drivers or over-tighten screws. Ensure all screws are in place and secure to maintain physical and electrical seal.

The MCP Cab Radio is secured with two screws on the front and rear and three screws on each side with the front screw on each side equipped for grounding the cabinet. It is important to not to over tighten these screws. Use of power screw drivers is not advised.

2.1.3 Cable Installation

The MCP Cab Radio uses Mil-spec type twist connectors for Client ports, Echelon®/Opto-I/O, and Power. The MCP Cab Radio is equipped with an N-Type RF connector for connecting the external antenna to the radio. In most applications, Client Port J1, Antenna, and Power will be used as shown in Figure 2-4.



Figure 2-4 Cable Installation

2.1.3.1 J1 Client Cable

The J1 Client Cable interfaces the MCP Cab Radio to the locomotive on-board computer (or other peripheral equipment if used in another application). The default protocol for this port is RS-422 or as configured in the unit's codeplug. A ferrite filter is required on the J1 Client Cable to eliminate EMI/RFI interference. Use the following procedure to install the filter on to the data cable.

2.1.3.1.1 Ferrite Installation Procedure

1. Using the ferrite filter provided with the MCP Cab Radio (Fairrite Model 0431164181), open the ferrite case and loop the data cable through the filter so the cable goes through the filter core twice as shown in Figure 2-5. Mount the ferrite filter as close to the connector as possible. Figure 2-6 shows the completed ferrite filter installation.



Figure 2-5 Installing Ferrite Filter on Data Cable



Figure 2-6 Completed Ferrite Installation

2.1.3.2 Echelon® and Isolated I/O Connection

A 10-pin mil-spec connector provides an Echelon® I/O connection and two (2) isolated inputs and outputs.

2.1.3.3 Antenna Connection

WARNING

ALL ANTENNA INSTALLATION AND SERVICING IS TO BE PERFORMED BY QUALIFIED TECHNICAL PERSONNEL ONLY. WHEN SERVICING OR WORKING AT DISTANCES CLOSER THAN 3.05 METERS, ENSURE THE TRANSMITTER HAS BEEN DISABLED. DEPENDING UPON THE APPLICATION AND THE GAIN OF THE ANTENNA, THE TOTAL COMPOSITE POWER COULD EXCEED 200 WATTS EIRP. THE ANTENNA LOCATION SHOULD BE SUCH THAT ONLY QUALIFIED TECHNICAL PERSONNEL CAN ACCESS IT, AND UNDER NORMAL OPERATING CONDITIONS NO OTHER PERSON CAN COME IN CONTACT OR APPROACH WITHIN 10 FEET (3.05 METERS) OF THE ANTENNA.

The MCP Cab Radio is equipped with an N-Type antenna connector. Selection of an antenna feed line is important. A high quality low-loss cable should be used. Poor quality cable will result in power losses that may reduce the range and reliability of the radio system. Table 2-1 shows the losses that will occur when using various types and lengths of cable at 960 MHz Cable length should be kept as short as possible to minimize signal loss.

Cable Type	10 Feet (3.05 Meters)	50 Feet (15.24 Meters)	100 Feet (30.48 Meters)	500 Feet (152.4 Meters)
RG08A/U	0.51 dB	2.53 dB	5.07 dB	25.35 dB
1/2 inch HELIAX	0.12 dB	0.76 dB	1.15 dB	7.55 dB
7/8 inch HELIAX	0.08 dB	0.42 dB	0.83 dB	4.15 dB
1-1/4 inch HELIAX	0.06 dB	0.31 dB	0.62 dB	3.10 dB
1-5/8 inch HELIAX	0.05 dB	0.26 dB	0.52 dB	2.60 dB

Table 2-1Length vs. Loss in Coaxial Cable at 960 MHz

2.1.3.4 Power Connection

The input power is connected via the Safetran part number 9000-26697-000X, which includes a mil-spec 4-pin connector and 14 AWG cable in 3 foot, 5 foot and 10 foot lengths. Ensure the polarity of the connection to the power source is correctly polarized. The MCP Cab Radio is equipped with reverse polarity protection.

2.2 XCMMAINT SOFTWARE

MCP Cab Radios are pre-configured at the factory per user specifications. No further configuration is required. The following information is provided for reference purposes. Refer to the Service portion of this manual (Section 4) for detailed features of this software utility. To review configuration setup parameters, the Safetran XCMMAINT Version 1.18.00 or later software is used. Older versions of the XCMMAINT software do not include the MDS radio information.

NOTE

When upgrading a MCM II to version 1.18.00 from a version older than 1.17.30, also upgrade the Debugger from version 1.00 to 2.00 to enable the MCM II to operate properly.

Verify the proper version software is installed by clicking on **"Version"**. A dialog box will appear with the software information as shown in Figure 2-7.

GA XEMMAINT.EXE	
File Edit Online Help Version FILE: C: XCM500 MCP.XCM Site Settings - Radio Settings Site Settings Type: MDS Usage: MCP Channel: Min:01 Max:06 Def:02 Invert: TX:Yes Rssi: Scale: 009/025 Badio Case-137 dB Beacontime: Enable Sinula Sinula Beacontime: Local mader: Enable Sinula	Disable Disable pp: No tion: No
Node T 01 A 03 U 05 U 07 U Logic CRC: 90909 Enable Ladder Logic File: Esc to exit Corp. 03 Oct 2007 08:42:29	CRC: CØ4B
Deliver on Reset: No Port-Protocol Baud Clock-Level-CTS-TXC-FLG-Timer-Usage-LL-PL-ID J1 HDLC ADM ,09600,SYNC, RS422,No, Int,No, 00200 OBC N N S J2 HDLC ADM ,09600,ASYNC,RS232,No, Int,No, 00200 OBC N N S Lon Not Used Subnet: 01 Subnode:01 DC1 Not Used WIU CRC: D397 DC2 Not Used WIU	Link/Max 001/001 001/001

Figure 2-7 XCMMAINT Software - Version Verification

2.2.1 Radio Settings

Figure 2-8 displays the MDS Radio Settings.

\bigcirc		AINT.EXE			
2	File	Edit	t (Online	Help
	PILE:	C:\XCM	500\MCP	.XCM	
	Type:	MDS	Usage:	MCP	
(3)	Chann	el:	Min:01	Max:06	Def:02
4	Rssi:	Scale:	009/02	Base:-	137 dB
5	Radio	Gain:	IN: 10	24 Out:	1664
6				Lont	alk-Netu



- ✤ 1 Type: MDS
- ✤ 2 Usage: MCP or BCP
- ✤ 3 Channel: Min: 01 Max: 06 Def: 02
- ✤ 4 Invert: TX: YES or NO RX: YES or NO
- ✤ 5 Rssi: Scale: 009/025 Base: -137 dB
- ✤ 6 Radio Gain: In: 1024 Out: 1664 Note: Default settings are in BOLD.

2.2.2 Site Settings

Figure 2-9 displays the default Site Settings for the MCP Cab Radio.



- ✤ 1 –Local Addr: 7.55A.A5A.AA1.A1.A1 Disable
- ✤ 2 FEPCC Addr: 2.AAA.AAAA Disable
- ✤ 3 Enable Code App: NO
- ✤ 4 Enable Simulation: NO
- 5 Enable Ladder Logic: NO
 Note: Default settings are in BOLD.

2.2.3 Lontalk® (Echelon®) Network Configuration

Figure 2-10 displays the Lontalk® (Echelon®) Network Configuration. The MCP Cab Radio uses Node 01 only in this application.





- ✤ 1 –Node 01: A53105/A53408 XCM
- ✤ 2 Nodes 02-10: Unused
- ✤ 3 Deliver on Reset: NO

Note: Default settings are in BOLD.

2.2.4 Port Information

Figure 2-11 Displays the Port information of the MCP Cab Radio. In this application only J1 and J2 are used with J1 set up in a RS-422 configuration and J2 in a RS-232 configuration.

(2)	J1	HDLC ADM	.09600,	SIOCK-L	S422,No	Int,No	,00200	-Usage OBC	-LL- N	-PL- N	-1D	-Link/Max- 001/001
		Not Used	Subnet:	01 Su	13232, NO 1500de : 01 1397	L	,00200	OBC	N.,		3	001/001
3	DC2	Not Used	ŴĨŬ									
4												
5												

Figure 2-11 XCMMAINT Software - Port Information

- 1 J1: HDLC ADM, 09600, SYNC, RS-422, No, Int, No, 00200 OBC N N S 001/001
- 2 J2: HDLC ADM, 09600, ASYNC, RS-232, No, Int, No, 00200 OBC N N S 001/001
- 3 Lontalk®: Not Used Subnet: 01 Subnode: 01
- 4 DC1: Not Used WIU
- 5 DC2: Not Used WIU

Note: Default settings are in BOLD.
SECTION 3 OPERATION

3 - OPERATION

3.1 OVERVIEW

The MCP Cab Radio operates transparently in conjunction with the locomotive on-board computer. The Cab Radio receives and transmits information between the ATCS base and wayside stations to the locomotive on-board computer using the six ATCS UHF frequency pairs authorized for data communications. A typical locomotive configuration is shown in Figure 3-1.



Figure 3-1 Locomotive Configuration

A typical network configuration is displayed in Figure 3-2, showing the control center network connection to field wayside stations which in turn communicate with the locomotive.



Figure 3-2 Typical Network Configuration

3.2 CAB RADIO FREQUENCY CONTROL

The locomotive cab radio generates an ATCS address and receives frequency assignments from the MCP client via the locomotive on-board computer. The radio broadcasts data packets to establish available links. The radio will continue this process until a link or links have been established. In the event all links are lost, the radio reverts to the broadcast process until a link is established. When entering another railway's territory the on-board computer will signal the MCP client to change frequencies if applicable. Figure 3-3 displays a typical frequency change process.



Figure 3-3 Cab Radio Frequency Control

3.3 RADIO MESSAGES

The MCP Cab Radio can handle a variety of messages between the ATCS center and the Locomotive. The radio communicates with the network using the High Level Data Link Control (HDLC) protocol and is linked to the locomotive on-board computer using a RS-422 link.

3.3.1 Temporary Speed Restriction (TSR)

Temporary Speed Restriction (TSR) orders are sent from the base station and received by the MCP can sent to the on-board computer. Data derived from GPS, transponders, and wayside station established the locomotive location, thus enabling the on-board computer to advise the locomotive's location in reference to the TSR boundaries. Figure 3-4 displays a TSR example.



TEMPORARY SPEED RESTRICTION BOUNDARY

Figure 3-4 Temporary Speed Restriction Example

3.3.2 Interlocking Status

Interlocking Status is sent from the base station and received by the MCP is sent to the on-board computer. In some cases (i.e. dark territory), remote control interlocks can be controlled from the locomotive cab. The MCP can serve as a primary or secondary communication source. Figure 3-5 displays an example of an interlock status exchange.



Figure 3-5 Interlocking Status

3.4 POSITIVE TRAIN CONTROL

As Positive Train Control systems develop, the MCP Cab Radio will play a key role. Data gathered from wayside sources can be combined with other data sources and displayed on the locomotive console.

Q <u>uantum</u> Englowering inc				11-02 8
		î	Here Free D 231.72 - 231.87 - 1 C Argueta C Market Alleged C Argueta C Market Alleged C Argueta C Market Alleged C C Argueta C Market Alleged C C Argueta C Market Alleged	2 14 246.52 340 Claw 2 Amed c.6.52 2007em 25.22 2007em 25.22 2007em
	8835 9270 5 6836 9270 5 5036	5032	CHI2 COMPARED CONTROL	10322 122 - 20 <u>5035</u> STOP
				Train Sentinel

Figure 3-6 PTC Display

SECTION 4 SERVICE

4 - SERVICE

4.1 OVERVIEW

Routine service of the MCP Cab Radio is performed by qualified personnel as specified by standard railroad or agency standards and procedures. The Logic Board information is accessed via the 9-pin Diagnostic Port on the face of the Cab Radio unit. Diagnostic testing of the UHF Radio is performed using the RJ-11 Radio Diagnostic port and Radio Configuration software for the MDS UHF Radio. The Logic Board is accessible via a service panel on the side of the unit.

NOTE

Testing and service of the radio component must be performed by qualified technical personnel as defined in FCC Rules, Part 90 and Part 101.

4.2 MCP DIAGNOSTICS

Diagnostic of the MCP are performed using the User Diagnostic port which is a DB-9 connector mounted on the front panel of the unit connected to a PC or Laptop computer using the Safetran XCMMAINT software.

4.2.1 Opening XCMMAINT

Open the XCMMAINT software by opening the XCMMAINT.EXE file. The opening screen in Figure 4-1 will appear.



Figure 4-1 Opening XCMMAINT

4.2.2 Selecting File

Hit the **ENTER** key to display the available configuration files. If a Codeplug file has been saved for the unit being tested use the **ARROW KEYS** to highlight the appropriate file. Hit the **ENTER** key to load the file. If the codeplug file is not available or to view a programmed unit press ESC to enter the default screen. Section 4.2.4.4 details how to read the Codeplug information in the unit.

🔤 C:\XCM500\;	CMMAINT.EXE	
	MCMMaint 1.18.00 (c) Safetran Systems Corp. 03 Oct 2007	
.xcm	Enter Filename C:\XCM500.XCM CM_LUI~1.XCM LCLPANEL.XCM LOCALLCL.XCM MDSTEST.XCM MDSTST1.XCM WCP2MDST.XCM\	
	•	

Figure 4-2 Filename Select

4.2.3 Unit Configuration

The opening screen will display the configuration of the MCP. Changes should not be initiated unless the unit is being updated our reconfigured. Changing these settings may render the unit inoperable.

EN XCMMAINT.EXE	
File Edit Online Hel	lp Version
FILE: C:\XCM500\MCP.XCM	
- Radio Settings	Site Settings
Type: MDS Usage: MCP	Local Addr: 7.55A.A5A.AA1.A1.A1 Disable
Channel: Min:01 Max:06 Def:	2 FEPCC Addr: 2.AAA.AA.AAAA Disable
Invert: IX:Yes XX: Yes	Radio CKG (2686 Enable Code Hpp: No
Padio Cain: In: 1024 Out: 1664	Logic CPC :0000 Enable Logic: No
naulo Gali. 10. 1024 Out. 1004	Logic File:
Lontalk	etwork-Configuration
Node Type Description	Node Type Description CRC: C04B
01 A53105/A53408 XCM	02 Unused
03 Unused	04 Unused
05 Unused	06 Unused
07 Unused	08 Unused
09 Unused	10 Unused
Dell'son or Decete No.	
Post-Protocol-Raud-Clock-Leur	1-CTS-TYC-FLC-Time wells age -LL-PL-LD-Link/May-
J1 HDLC ADM 09600 SYNC RS43	22 No. Int No. 99299 OBC N N S 991/991
J2 HDLC ADM 09600 ASYNC RS2	2 No Int No 00200 OBC N N S 001/001
Lon Not Used Subnet: 01 Subno	de:01
DC1 Not Used WIU CRC: D39	7
DC2 Not Used WIU	

Figure 4-3 Opening Screen

4.2.4 Terminal Mode

The terminal mode opens a utility application to review various logs as well as make desired changes to the logic board and view basic radio functions. Type **ALT-O**, the drop menu will appear, highlight **TERMINAL** and press **ENTER** to start the terminal mode.

🐼 XCMMAINT.EXE			
File Edit	Online Help	Version	
FILE: C:\XCM500\M — Radio Settings U Type: MDS Usag B Channel: Min: R Invert: TX:Y R Rssi: Scale: 009/ W Radio Gain: In: W	erminal itmap Display ead DC Conf. from Ur ead Codeplug from Ur rite Codeplug to Un rite DC Conf. to Un rite Logic to Unit	Site Settings ddr: 7.55A.A5A.AA1.A1.A1 Disable ddr: 2.AAA.AA.AAAA Disable nit RC :2686 Enable Code App: No it me: Enable Simulation: No RC :0000 Enable Ladder Logic: No ile:	
Node Type De Ø1 A53105/A5340 Ø3 Unused Ø5 Unused Ø7 Unused Ø7 Unused Ø9 Unused	rite Labels to Unit 8 XCM 02 04 06 10	Figuration Type Description CRC: CO Unused Unused Unused Unused Unused	94B
Deliver on Reset: Port-Protocol-Bau J1 HDLC ADM ,096 J2 HDLC ADM ,096 Lon Not Used Subn DC1 Not Used WIU DC2 Not Used WIU	No d—Clock-Level-CTS- 00,SYNC,RS422,No,1 00,ASYNC,RS232,No,1 et:01 Subnode:01 CRC: D397	XC-FLG-Timer-Usage-LL-PL-IDLink/Ma nt,No ,00200 OBC N N S 001/00 nt,No ,00200 OBC N N S 001/00	0X- 01 01

Figure 4-4 Terminal Mode

The Terminal mode opens with a blank screen. Hit the **ENTER** key and an asterisk (*) will display. Type **HELP** for a list of available commands as displayed in Figure 4-5.

File Online Upload	
*	
*	
*HELP	
Display Codeplug Contents - DCP	
Display DC Configuration - DDC	
Display Client List - CL	
Enter Service Mode - SERV	
Version Identification - VER	
Base Station List - BSIHI	
Communication Statistics - CSIHI	
HDLC STATISTICS - HSIHI	
nanuracturer statistics – nsini	
Hiarn Logging $-H_{\rm L}$ (clrus)	
Chew log – Log Chew	
Key on Debug Radio – DTT Cen/ds>	
Radio Simpley Operation - SIMP (an/de)	
COS status - COS (en/ds)	
Enter Channel Number - CHAN (number)	
Send Local Message - LOCAL (label) (message)	
Self Test - TEST <1=cold / 0=warm>	
Patch Codeplug - PCP <location> <new_value></new_value></location>	
Disable Tracing Mechanism - MOND <layer> <pre> <pre> </pre></pre></layer>	
Enable Tracing Mechanism - MONE <layer> <port> <link/></port></layer>	
Send Mobile Message - SEND <layer> <pre> <pre> <pre> <pre> </pre> </pre> </pre></pre></layer>	
Error Rate Test - ERT <mode> <layer> <port> <full report=""> <pattern< td=""><td>></td></pattern<></full></port></layer></mode>	>
Enable / Disable SWI - SWI en/ds	
Enable / Disable LADL - LADL en/ds	
Program Codeplug - FPROG	
Show HW/SW Dersion Info - SCT	
Reset RSSI Statistics - RSSI	-
RESET NUS/SB7600 RIFRESEI 1=MGS reset, 2=SB reset, 3=SB prog, other	r=r
PFP Status - PFP	
Ting Status – TIMGIP address, Client num (01)	
Set Date DTF (uean) (month) (dau)	
Set Jate Diff (Jours) (Willing (Use and)	
* THE CHURY CHIRCE/ Second/	
OST	

Figure 4-5 Terminal Mode - Help Screen

4.2.4.1 Terminal Mode Commands

4.2.4.1.1 AL en/ds - Alarm Logging

Alarm logging is initially enabled. When the command is first entered, all alarms and their respective states are displayed. After alarm logging is enabled, any subsequent changes to any of the alarms are displayed individually as they occur. If the command is re-entered to enable logging, the display reflects the present state of the alarms.

S XCMMAINT.EXE	
File Online Upload	
×	
*	
Kadio Hiarm Off	
AI HIAFW OFF	
R3 Alarm Off	
Codeplug Alarm Off	
Cos Without Data Alarm Off	
Modulator Alarm Off	
Ground Contact Alarm Off	
Codefail Alarm Off	
Mobile Channel Usage Hlarm Uff	
0/D Hawduaya 0 Jawm Off	
Lon L/F Alarm Off	
External Ø Alarm Off	
External 1 Alarm Off	
External 2 Alarm Off	
External 3 Alarm Off	
External 4 Alarm Off	
External 5 flarm off	
External 7 Alarm Off	
External 8 Alarm Off	
External 9 Alarm Off	
Port Contact Ø Alarm On	
Port Contact 1 Alarm On	
Port Hardware 0 Hlarm Off	
Port Taken 0 Alaym Off	
Port Token 1 Alarm Off	
*	
MC0 00/00/00 00:01:12 Port Contact 1 Alarm On	

Figure 4-6 Display Alarms

The following alarms are monitored by the function:

RADIO ALARM	The entire radio has failed
RADIO PA ALARM	Radio power amplifier failure
RADIO POWER ALARM	Radio is operating on battery power
CODEPLUG ALARM	Codeplug CRC comparison failure or write failure
COS WITHOUT DATA ALARM	The RF channel has been asserted without data for
	longer than the allowable time limit
MODULATOR ALARM	The RF modulator has failed
GROUND CONTACT ALARM	Ground contact was not established at start up
ANALOG TO DIGITAL CONVERTER ALARM	The A/D converter selftest has failed
MOBILE CHANNEL USEAGE ALARM	Generated by the BCP when a MCP violates channel
	usage restrictions
OUT OF COVERAGE ALARM	Contact with ground network has been lost
EXTERNAL ALARM	External alarm (0 through 3) generated by parallel
	input lines
PORT CONTACT ALARM	Alarm (0 through 3) indicating loss of contact with
	client at the remote end of the link
PORT HARDWARE FAIL	Alarm (0 through 3) indicating hardware failure of a
	client link port

4.2.4.1.2 DCP - Display Codeplug

Enter **DCP** and press **ENTER** to display codeplug values currently programmed into the unit. The contents of the codeplug are displayed as bytes in hex format. The leftmost column is the location of the first value on that line. The locations of the other values on that line are offset from the first position.

en C:\XC	M500\XC	MMA	INT.E	XE														_ D >
File	On 1 :	ine		Սթ۱	oad	l												
*																		
*																		
*																		
*DCP																		
Codepl	ug Valu																	
\$0000	FF 01	75	5A I	A5	AA -	A1	A1	A1	00	00	00	00	00	00	00			
\$0010	00 00	00	01	00	00	17	70	00	00	00	00	00	00	17	70			
50020	20 00	AA	AA I	AA I	NN.	NN	00	02	01	01	01	01	01	<u>01</u>	01			
20030	01 01	4.7	ט בט המכי	01 00	01 66	47	10	01	01	01	01	01	01	15	00			
50040	00 00	01 01	FO I	00 00	00 00	<u>й</u> 2	89	00	00	03	00 N4	00	00	01	70			
Š ЙЙ6Й	00 00	0 5	14	йй	йй	й <u>5</u>	DC	йй	йй	йŻ	ñĉ.	йй	йй	йй	ŚŘ.			
\$0070	00 00	00	ÎÊ I	00 1	ØØ -	01	F4	00	00	03	E8	FF	FF	FF	FF			
\$0080	00 00	03	E8	00	05	00	06	28	AA.	AA.	99	99	00	00	ØA			
\$0090	01 00	00	00	00	00	05	DC	00	00	00	00	00	00	00	00			
\$00A0	00 00	00	00	00	00	12	CØ	38	40	04	00	06	80	00	00			
200B0	00 01	00	00	00	82	NN NN	00	90	10	NN	NN	NN.	50	NN.	NN.			
20000	00 01	00	שט סס	ישט	68	00	00	10	50	00	00	05	40	FF ØØ	FF ØØ			
SOODO	00 96	00	en -	10 I	<u>п</u> п	00	00	ū.	64	00	00	00	04	00	0 5			
SOOFO	01 06	02	ññ i	ññ i	йй	йй	йй	89	йÂ	Ø 9	19	FF	FF	FF	02			
\$0100	00 00	02	58	00	01	FF	FF	00	06	02	01	20	06	01	FF			
\$0110	FF FF	00	00	00	C8	00	00	02	58	00	01	FF	FF	00	06			
\$0120	08 01	20	07	01	FF	FF	FF	00	00	00	<u>C8</u>	00	00	17	70			
50130	01 01	FF	FF	00	12	00	00	00	00	00	FF	FF	FF	FF	FF			
50140	FF FF	00	01 00	00	23	00	25	00	27	90	FF	00	FF	5E	NN NN			
20120	00 00	00	90 95	00 ' 00 '	99 97	00	RE -	00	00	00	04	00 4E	56	56	EE.			
ŠØ170	F6 FE	йй	ดัด	йй	ด้ด่	10	AE.	90	ЕЙ	22	54	ЙЙ	F6	40	41			
\$0180	71 41	ØD	01	00	ÖÖ -	00	00	00	õõ	02	00	ØØ.	00	00	00			
\$0190	00 00	2E	ED	00	00	17	70	FF	FF	00	00	00	00	23	28			
\$01A0	00 00	00	0C	AA I	AA	AA	AA	AA.	00	00	ØA	00	00	00	00			
\$01B0	01 03	03	00	00	00	00	00	00	00	00	00	00	00	26	86			
SUICU	FF FF	FF PP	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF			
20110	PP PP	FF FF	FF . RR .	FF . 00 -	rr 15_	FF FF	FF FF	FF FF	FF FF	FF FF	FF	FF	FF	FF	FF			
SO1 FO	FF FF	FF	FF	FF	FF_	FF	FF_	FF	FF	FF	FF	FF	FF	2F	C8			
*							· · ·					_	<u> </u>					
MCØ 00	/00/00	00:	02:	23	Sen	it (Code	թlug	ĵ Va	alue	es t	o I	lost	;				

Figure 4-7 Display Codeplug Contents

4.2.4.1.3 DDC - DC Configuration Values

Enter **DDC** and press **ENTER** to display the DC Configuration of the unit. The DC Configuration is displayed as bytes in hex format. The leftmost column is the location of the first value on that line. The locations of the other values on that line are offset from the first position.

en C:	\XCM	1500)/XC	MMA	INT.	.EXE														- 🗆 ×
File	0	()n 1 ·	ine		lln]	load	1												
*DDC				2110		0 0 1														
DC C	onf	im	reat	tior	n Ua	alue	1 24													
SOOP	10	ดดั	ØØ	ØØ	28	ØØ	28	ОО	ØA	00	56	ИЙ	5A	ØØ	61	ØØ	Ø5			
\$001	Ø	00	5A	00	4B	00	19	00	05	00	07	07	00	94	10	10	00			
\$002	0	00	08	07	ØØ	00	08	07	00	00	08	07	00	00	08	07	00			
\$003	10	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$004	0	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$005	0	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$006	0	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$007	10	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$008	10	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$009	0	00	08	07	00	00	08	07	00	00	08	07	00	00	08	07	00			
\$00A	0	00	08	07	00	00	FF	01	ØA	00	00	00	00	00	00	00	00			
\$00I	30	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
\$000	:0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
\$00I	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
\$00I	0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
\$00F	10	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
\$010	90	00	00	00	2A	00	28	00	ØA	00	5A	00	5A	00	61	00	05			
\$011	0	00	41	00	4B	00	19	00	05	54	07	07	00	00	08	07	00			
SØ1 2	20	ØЙ	08	07	ØЙ	ØЙ	08	02	ØØ	ØЙ	08	02	ØЙ	ØЙ	08	07	NN			
5013	2	00	08	02	00	NN	08	92	NN	90	80	97	90	00	80	07	00			
5014	No.	90	80	07	00	00	80	97	NN	00	80	97	00	00	08	07	00			
5015	No.	00	08	07	00	00	80	207	00	90	80	07	00	00	08	07	00			
2016	0	00	98	97	00	00	80	97	00	90	80	97	00	00	08	07	00			
2017	2	00	08	07	00	00	08	87	00	90	08	07	00	00	08	07	00			
2010		00	00	87	00	00	00	87	00	90	00	87	00	00	08	07	00			
2017		00	00	07	00	00	00	84	00	00	00	00	00	00	00	07	00			
201H	10	00	00	66	00	00	00	00	00	00	00	00	00	00	00	00	60			
2011	50	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
CO1 T	10	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	60			
EQ1 I	70	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	66			
6011	10	00	00	00	00	A A	00	00	00	66	00	00	00	00	00	00	66			
5020	เดี	38	0 D	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
×		3.0																		
MCØ	00,	/00/	/00	00	28	:42	Ser	nt]	DC C	Confi	iguı	rat:	ion	Ua:	lues	s te	o Host	ŧ		

Figure 4-8 Display DC Configuration

4.2.4.1.4 VER - Firmware Hardware Codeplug Version Information

Type VER and press ENTER to view the Version information of the installed codeplug.



Figure 4-9 Version Identification

4.2.4.1.5 BSTAT - Active Base Station Status

The **BSTAT** command will display active base stations heard by the MCP. Stations are removed from the list after a period of inactivity.



Figure 4-10 Base Station List

4.2.4.1.6 CSTAT - Communication Statistics

es C:\XCM500\XCMMAINT.EXE	_ 🗆 ×
File Online Upload	
*CSTAT	
Minutes of operation: 35	
RF Logical Channel Stats	
Received: 00000 00000 00000 00000 00000 00000 0000	
00000 00000 00000 00000 00000 00000 0000	
Sent: 00000 00000 00000 00000 00000 00000 0000	
00000 00000 00000 00000 00000 00000 0000	
Retries: 00000 00000 00000 00000 00000 00000 0000	
Failures: 00000 00000 00000 00000 00000 00000 0000	
⊎ี่cr`oบไλ: ถุกถุกกุ กลักถุก กลักถุก กุกถุกกุ กุกถุกกุ ถุกถุกกุ ถุกถุกกุ	
Port Stats Prt 0 Prt 1 RF	
Frames Sent: 00000 00000 00000	
Frames Received: 00000 00000 00025	
Contact Failure: 00001 00000	
PIOW CONTROL ENTERED: 0 RECOVERIES: 0 RE-RECOVERIES: 0	
NF Stats: Evene Currer 00025 Placks Cast, 00000 Placks Paculd, 00005	
Prane syncs. 00035 blocks sent. 00000 blocks kecv u. 00075	
ha beletted. 00007 ha corrected. 00001	
Padio	
Chappel Chapges: 00001 PTT: 00000	
SSI Curvent: -109 dB Maximum: -132 dB Minimum: -0 dB	
*	
MCA AA/AA/AA AA: Sent DC Configuration Values to Host	

The **CSTAT** command opens a screen with communications statistics.

Figure 4-11 Communication Statistics

The following data is displayed on the Communications Statistics screen:

MINUTES OF OPERATION	The number of the unit has been operational
TOTAL RECEIVED	The number of datagrams received on the respective
	logical channels 0 through F.
TOTAL SENT	The number of datagrams sent on the logical channels
	0 through F.
TOTAL RETRIES	The number of datagrams retransmitted on the even
	logical channels
TOTAL FAILED	The number of datagrams that were not successfully
	sent on the even logical channels
TOTAL ACK ONLY	The number of ACK only datagram that were sent on
	the even logical channels
CONTACT FAILURE	The number of contact failures that have occurred on
	client port 0, client port 1, and the RF link respectively
FLOW CONTROL	The number of times flow control was entered, the
	number of times recovery procedures were performed,
	and the number of times re-recovery procedures were
	performed
SSI	The current value in the SSI for the last datagram
	received, the maximum SSI value is the highest
	received, and the minimum is the lowest SSI received

4.2.4.1.7 HSTAT - HDLC Statistics

Type **HSTAT** to display the HDLC information as shown in Figure 4-12

💌 C:\XCM	500\XCM	MAINT.EX	E							
File	Onlin	ie Ur	pload							
¥										
*										
*HSTAT										
HDLC St	atistic	s:								
Europe	Port Ø	Peau	Enamo	Cont	Page	Enamo	Cont	Peau		
INRO	00000	aaaaa	CORM	ANANA	aaaaa	FRAME	GOGOG	aaaaa	CRC ann	00000
III	ANNAN	ййййй	IIA	ййййй	ааааа	DMZDISC	ааааа	ййййй	T1	ааааа
RNR	00000	00000	REJ	00000	00000	Frames	00000	00000	Överrun	00000
ADM z-t	okens Ø	0000								
Bytes	000001	6182 0	00000032	0					Abort	00000
Heap av	ail/tot	al \$26	73C/\$314	61 (78;	<>> He	ap link d	count	004		
Glient	Port 1		D	0	D	D	0+			
Frame	Sent	Recv	Prame	Sent	Recv	Frame FDMD	Sent	Recv	CDC	00000
INFO	000000	000000	SHDF1	00000	00000	DMZDISC	00000	000000	Ti GNG EFF	00000
RNR	00000	000000	RE.I	00000	aaaaa	Enames	00000	00000	0uewww	00000
ADM z=t	okens Ø	пайай	iii.o	00000	00000	Trancs	00000	00000	overnun	00000
Butes	000003	5134 0	00000055	Ø					Abort	00000
Heap av	ail/tot	al \$26	73C/\$314	61 (78;	() He	ap link d	count	004		
*										
MC0 00/	00/00 0	10:28:4	2 Sent D	C Conf:	igurati	on Value:	s to Ho	ist		

Figure 4-12 HDLC Statistics

4.2.4.1.8 MSTAT - Manufacturer Statistics

The **MSTAT** command opens a screen that lists manufacturer statistics.



Figure 4-13 Manufacturer Statistics

4.2.4.1.9 LOG - Display Log

Type **LOG** command to view the System Log. Use the **<F>** key to move forward, **<S>** key to go to the start of the log, and the **<E>** key to shift to the end of the log. Press the **ESC** key to exit the log and return to the main screen.

C:\XCM500\XCMMAINT.EXE	
File Online Upload	
*	
¥	
*	
Log display - hit ESC to exit	
End ******	
MC0 09/07/24 00:39:34 Sent DC Configuration Values to Host	
MC0 00/00/00 00:00:04 MCP Cold reset	
MC0_00/00/00/00:00:10 Port \$100: mode=1_9600 timer=200 usage=6 config=2	
NC0 00/00/00 00:00:10 FHW mode enabled	
MC0 00/00/00 00-00-12 FUL and enabled	
MCG 00/00/00 00:00:12 MDS Radio RX/TX channel change 2 successful	
MCO 00/00/00 00:00:17 Logic Pass-Through operation enabled	
MC0 00/00/00 00:01:11 Alarm dump created	
MC0 00/00/00 00:01:11 Port Contact 0 Alarm On	
MC0 00/00/00 00:01:12 Alarm dump created	
MC0 00/00/00 00:01:12 Port Contact 1 Hlarm Un	
MCG 00/00/00 00-27-32 Sent DC Configuration Values to Host	
MC0 00/00/00 00:28:42 Sent DC Configuration Values to Host	
Enter ESC to guit, (B)ack, (F)orward, (S)tart, (E)nd	
MC0 00/00/00 00:28:42 Sent DC Configuration Values to Host	

Figure 4-14 View Log

4.2.4.1.10 SL - Status Log

Type **SL** command and press **ENTER**. The status logging is initially disabled. When the command is first entered to enable status logging (**SL en**), the status summary is displayed. After status logging is enabled, any subsequent state changes are displayed as they occur. If the command is reentered to enable status logging, the summary reflects the present status of the MCP. The **SL ds** command disables the status log.

EX XCMMAINT.EXE	
File Online	Upload
×	
*	
*	
*SL	
Radio PTT - OFF	
Radio Channel : 2	
Serial Mode - Port	0 : HDLC - ADM
Serial Mode - Port	1 : HDLC - ADM
¥	
*	
<u>.</u>	
*	
*	
*	
¥	
*	
Č.	
2	
*	
MC0 00/00/00 00:01	:12 Port Contact 1 Alarm On

Figure 4-15 Status Log

4.2.4.1.11 TIMERS - Display Timer Configurations

ex C:\XC	M500\XCMMAINT	.EXE						_ 🗆 ×
File	Online	Upload						
*								
*								
2								
*TIMERS	8							
Timer:	0 - Delay	0.58	Instance	b76 Tasl	6			
Timer:	4 - Delay	9.62	Instance	10b Tasl	: 3			
Timer:	5 - Delay	29.62	Instance	2c Tasl	: 3			
Timer:	6 - Delay	35.01	Instance	3 Tasl	: 3			
Timer	24 - Delay	4.98	Instance	U Tasl	: 11			0.40
limer	26 - Delay	8.08	Instance	664 Tasl	12	repeat	every	0.10
Timer.	30 - Delay	0.07	Instance	644 Taol	14			
Timer:	51 - Delau	9.41	Instance	10h Tasl	6	reneat	everv	10.00
*	or borny			100 100		ropour	oron y	10100
×								
×								
*								
*								
<u>*</u>								
*								
×								
MCØ 00,	/00/00 00:28	:42 Sent	DC Configu	ration Value	s to	Host		

Type the **TIMERS** command and press **ENTER** to list the current configuration of the logic timers.

Figure 4-16 Timer Status

4.2.4.1.12 TEST restart - MCP Self-Test

The TEST command resets the MCP and performs a series of diagnostic tests before returning to operational status. The TEST command has two arguments:

- 0 (warm) Perform the self-tests while the MCP remains operational
- 1 (cold) Resets the MCP and the power-up sequence is performed including the self-tests.

IN C:\XCM500\XCMMAINT.EXE	
File Online Upload	
τ.	
Safetran MCM II 68302 Debugger Version 2.00	
Booting from Diagnostic ROM	
Copyright Motorola Canada Ltd.	
MCM-II Firmware Version 01.17.md Feb 05. 2009	
Built Feb 06 2009 16:27:19 w/ compiler version 5.0J	
KOM KAMOK CODEPLUG OK	
MODULATOROK	
RADIOOK	
HDLC PORT 1 OK	
DC PORTOK	
TESTS COMPLETE	
MC0 00/00/00 00:00:20 Radio Alarm Off	

Figure 4-17 MCP Self-test

4.2.4.1.13 SERV - Service Command

The **SERV** (Service) command activates certain functions and disables others for service purposes. The MCP performs functions controlled by the testport; all other functions are disabled. Once in the service mode, it is necessary to reset the MCP to return to the operational mode. Resetting of the MCP is accomplished using the **TEST** command. The following functions are activated with the MCP in the Service Mode.

- CHAN Change channel number
- ERT Perform error rate test
- PTT en/ds Key/De-key radio
- SIMP en/ds Enable/disable simplex mode

To place the MCP Cab Radio in the Service (SERV) mode type **SERV** and press **ENTER** as shown in Figure 4-18.

🛋 XCMMA	INT.EXE		
File	Online	Upload	
*			
*			
*			
*SERU			
¥			
×			
*			



4.2.4.1.14 CHAN - Change Channel (SERV Mode Only)

The CHAN command changes channels between the programmed channel pairs stored in the radio. Type the command followed by the desired channel number (e.g. CHAN 2) and the screen will acknowledge the channel change as shown in Figure 4-19

×									
*									
*CHF	IN 2								
2									
÷.									
MCØ	00/00/00	00:30:23	MDS	Radio	RX/TX	channel	change	2 successful	
-									



CH. No.	Base to Mobile (RX) Frequency	Mobile to Base (TX) Frequency
1	935.8875 MHz	896.8875 MHz
2	935.9375 MHz	896.9375 MHz
3	935.9875 MHz	896.9875 MHz
4	936.8875 MHz	897.8875 MHz
5	936.9375 MHz	897.9375 MHz
6	936.9875 MHz	897.9875 MHz

The ATCS frequency pairs have been programmed into the radio codeplug as follows:

4.2.4.1.15 ERT - Error Rate Test (SERV Mode Only)

The Error Rate Test (**ERT** command) allows communication links to be tested and error rate figures to be calculated. The unit must be in the service (SERV) mode to operate. Type **SERV** and press **ENTER** to activate the service mode.



Figure 4-20 Error Rate Test Screens

The ERT command has the following arguments:

Mode	- 1 2 3 4	Type of Loopback Mode = open (NO) loopback = digital loopback = analog loopback = open loop with RTS asserted (for wireline modem only)
Layer	- 1 2	Allows user to specify layer = physical layer - allows a bit error rate test to be done (For RF Channel Only) = datalink layer - allows message error rate testing to be done
Port	- \$100 \$101 \$300	Allows user to specify port number = Client Port 0 (wireline modem port on BCP) = Client Port 1 (spare port on BCP) = RF Channel
Pattern	-	Byte pattern to send (hex or ASCII). If not defined, a default pattern is used.

The results will be displayed at the bottom of the screen as shown in Figure 4-20. The definitions below detail the test results displayed.

100 0000000000000000000000000000000000	MCØ	00/00/00	01:20:16	Port:	300	sent:	43328	received:	61	error:	6877	BER:	0.001
--	-----	----------	----------	-------	-----	-------	-------	-----------	----	--------	------	------	-------

PORT	-	The port for which these results apply
SENT	-	The number of patterns generated by this unit
RECEIVED	-	The number of patterns correctly received by this unit
ERROR	-	The number of patterns received that do not match the generated pattern; except for RF Channel (port \$300) physical layer (layer 1) ERT commands, where this represents the number of bit errors.
BER	-	The ratio of the total error bit count over the total received bit count (i.e., [total bit errors] / [total bits received]). This calculation applies to RF channel physical layer (layer 1) ERT commands only

4.2.4.1.16 PTT en/ds - Push To Talk (SERV Mode Only)

The **PTT** command allows the user to key and dekey the radio. To verify the result of the PTT command, Status Logging (SL command) must be enabled. If the radio is already in the requested state, the command is ignored. The command remains in effect until explicitly changed. The result is displayed on the bottom of the screen as shown in Figure 4-21. The MCP transmitter time-out timer will automatically de-key the radio if allowed to expire. To rekey the MCP in this case, the radio must be first de-keyed using the de-key command (**PTT ds**), then the radio can be keyed using the key command (**PTT en**).



Figure 4-21 PTT - Push To Talk Command

4.2.4.1.17 SIMP en/ds - Simplex Command (SERV Mode Only)

The SIMP command enables or disables the MCP radio simplex mode of operation. In the normal mode, one frequency is used for transmit and another frequency is used for receive. In the simplex mode, the normal mode receive frequency is also used for transmit. The radio is initially in the normal mode. When the MCP is in the out-of-coverage (fallback) mode, it will revert to simplex mode operation to allow direct RF-user to RF-user communication. There is no direct indication that this command has been executed. However, the simplex/normal mode status may be monitored by executing the Status Logging (SL) command. When the radio is keyed, simplex operation is indicated in the radio PTT state field as displayed in Figure 4-22.



Figure 4-22 Simplex and Normal Mode Displays

4.2.4.1.18 Exit SERV Mode

Once in the service mode, it is necessary to reset the MCP to return to the operational mode. Resetting of the MCP is accomplished using the **TEST** command. Type **TEST** and press **ENTER** the MCP will perform a cold start and return to normal operation.

G XCMMAINT.EXE	
File Online Upload	
* *TEST	
Safetran MCM II 68302 Debugger Version 2.00	
Booting from Diagnostic ROM	
Safetran MCM II 68302 Debugger Version 2.00	
Booting from Diagnostic ROM Copyright Motorola Canada Ltd. Copyright Safetran Systems Corporation. MCM-II Firmware Version 01.17.38 Jun 24, 2009 Built Jun 24 2009 14:41:42 w/ compiler version 5.0J ROM RAMOK CODEPLUGOK MODULATOROK RADIOOK HDLC PORT 0OK HDLC PORT 1OK DC PORT 1OK LON PORTOK TESTS COMPLETE	
MCO 00/00/00 00:00:20 Radio Alarm Off	

Figure 4-23 Exit SERV Mode

4.2.4.2 Bit Map Display

This entry displays the Bitmap screen, figure 6-10, which is an online dynamic display of the logic state of any physical inputs or outputs associated with the WCP CPU II via ladder logic. The logic state of all internal bit fields are displayed as well. When properly configured I/O modules are installed on the local Echelon® LAN, the current state of their inputs and outputs can be determined using this screen.

<u>Terminal</u>
Bitmap Display 🗧
Read DC Conf. from Unit
Read Codeplug from Unit
Write Codeplug to Unit
Write DC Conf. to Unit
Wwite Logic to Unit
Wwite Labels to Unit
WFICE DADEIS CO ONIC

ev C:\XCM	1500\XCMMA	AINT.EXE						
File	Online		Address	I 0001	<.>			
I 0001	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
10065	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
10129	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
10193	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
R0001	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
R0065	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
RØ129	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
R0193	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00001000
00001	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
00065	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
00129	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
00193	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
E0001	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
E0065	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
E0129	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
E0193	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
Input	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
Rxved	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000010
Outpt	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
Ecout	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000

Figure 4-24 Bitmap Display

4.2.4.3 Read DC Configuration from Unit

By selecting this function and pressing **ENTER**, the configuration of the DC port of the MCP is read. The **Receiving data** popup box will display briefly as the data is read. The main edit screen will be updated to reflect the configuration data that is read.

CX XO	MMAINT.EXE						
File	e Onli	ու Սր	load				
*							
			Bece	iving Cod	enlug Data		
					~~~~~		
		212121212121					
MCØ	00/00/00	00:05:10	Sent DC	Configura	tion Value	s to Host	

Figure 4-25 Read DC Configuration from Unit

# 4.2.4.4 Read Codeplug from Unit

By selecting this function and pressing **ENTER**, the Codeplug portion of the MCP configuration data is read. This is a 512-byte data array that stores all the user-modifiable MCP configuration information. The **Receiving data** popup box (see above) will display briefly as the data is read. The main edit screen is updated to reflect the codeplug data that is read.





Figure 4-26 Read Codeplug from Unit

# 4.2.4.5 Upload Codeplug to Unit

The **sending data** popup box will display briefly as codeplug data is written. By selecting this function and pressing **ENTER**, all the configuration data appearing on the main edit screen will be written to the WCP CPU II non-volatile memory.



# CAUTION

EXISTING CODEPLUG DATA IN THE WCP CPU WILL BE OVERWRITTEN AND IRRETRIEVABLY LOST.

# 4.2.4.6 Upload DC Configuration to Unit

By selecting this function and pressing **ENTER**, the DC configuration data on the main edit screen (**DC1**) will be written to MCP.

The **Sending data** popup box may display briefly while the data is being uploaded.

Sending data ... 60%



This function uploads compiled ladder logic to the MCP if the following conditions are met:

- 1. Appropriate ladder logic has been compiled
- 2. The name of the logic file generated has been entered on the main edit screen (in the Site Settings section). The file extension is omitted.

After the upload sequence is complete, the WCP CPU II calculates a CRC value for the ladder logic. If this CRC value does not match the CRC embedded in the logic file, the process aborts with the WCP CPU II unchanged.



Terminal Bitmap Display Read DC Conf.

[erminal

itmap

Display

from

from

to Unit

Unit Unit

Unit



# 4.2.4.8 Upload Labels to Unit

By selecting this function and pressing **ENTER**, the tokenized label file associated with the ladder logic is uploaded to the WCP CPU II. The conditions for uploading are the same as for the logic upload described above. The label file and the logic file are generated by the logic compiler and will have the same base filename (with different extensions). As a result, it is only necessary to specify the base filename in the **Logic File** field on the main edit screen.

Terminal
Bitmap Display Read DC Conf. from Unit
Read Codeplug from Unit Write Codeplug to Unit
Write DC Conf. to Unit Write Logic to Unit
Write Labels to Unit

# 4.2.4.9 Radio Diagnostics

The MCP Cab Radio is equipped with a RJ-11 Radio Diagnostics port on the front panel. This port communicates with the MDS Radio directly and enables configuration of the radio as well as provide current configuration information. Radio Diagnostics requires the use of MDS Radio Configuration software (Part Number: 03-3156A01, Rev 2.4.0 or later) and a DB-9 to RJ-11 cable as described in Section 1.3.5 of this manual.

### WARNING

RADIO DIAGNOSTICS MUST BE PERFORMED BY QUALIFIED PERSONNEL IN ACCORDANCE WITH FCC RULES AND REGULATIONS. FAILURE TO COMPLY MAY RESULT INTERFERENCE TO OTHER EQUIPMENT AND MAY VOID USERS AUTHORITY TO OPERATE THIS DEVICE.

### 4.2.4.9.1 Activation of Radio Diagnostics Port

In normal operation the RJ-11 port is not active. To activate the Radio Diagnostic port it is necessary to place the MCP Cab Radio in the service mode using the XCMMAINT software. Type SERV to and press ENTER to activate the Service Mode. To activate the Radio Diagnostic Port type MDSDISC and press ENTER as shown in Figure 4-27.

* *		
*SERU		
*		
MC0 00/00/00 00:01:12 Por	t Contact 1 Alarm On	

# Figure 4-27 Activation of Radio Diagnostics Port

It is necessary to exit the XCMMAINT program before the Radio Diagnostic port will become active. Note it is necessary to exit the XCMMAINT program by type **ALT-F**, the pull down menu will appear. Highlight **EXIT** using the ARROW keys or a mouse and press **ENTER** as shown in Figure 4-28.



Figure 4-28 Exit XCMMAINT

# 4.2.4.10 Radio Configuration Software

The MDS Radio Configuration Software is provided on CD media and it will be required to install the software on the PC being used to configure the radio.

# WARNING

RADIO CONFIGURATION MUST BE PERFORMED BY QUALIFIED PERSONNEL IN ACCORDANCE WITH FCC RULES AND REGULATIONS. FAILURE TO COMPLY MAY RESULT INTERFERENCE TO OTHER EQUIPMENT AND MAY VOID USERS AUTHORITY TO OPERATE THIS DEVICE. PRIOR TO ALTERING ANY CONFIGURATION PARAMETERS ENSURE ANY CHANGES ARE COMPATIBLE WITH THIS APPLICATION.

# 4.2.4.10.1 Opening Radio Configuration Software

With the software installed, open the application. The opening screen will appear as shown in Figure 4-29.



Figure 4-29 Configuration Software - Opening Screen

# 4.2.4.10.2 Open Com Port

The software must open the communication port between the computer and the radio and read this information from the radio. Click YES on the pop-up window to open a direct line to the radio as shown in



# Figure 4-30 Configuration Software - Open Comm Port

### 4.2.4.10.3 Radio Information

The Information tab displays the Radio Information and User Information as shown below.

📆 Radio Configurati	on Software			_ 🗆 🗙
System Radio x790	Network-wide (	CommPort Prin	it Help	
Status - Radio Pollir	ng is finished , p	press F2 to re	fresh.	
Information	Sett	ings	Options	Network-Wide
RADIO INFORMAT	TION			
Radio Series Alarm Status Diag. Port Diag. Level	9710B (Inter-ope NO ALARMS PR CODE: 0000 000 CONNECTED TO Standard Loopba	rable) ESENT )0 D RJ11 ack		
Supply Voltage Regulator V. PLL Lock V. Temperature	13.3 v 5.7 v n/a +26 C			
USEN INFORMAT Serial Number Model Number Hardware Rev. Software Rev. Owner's Name Owner's Message	01871184 9710BXN1801C Not Programmed 1.9.1 21Jul2006	9		



# 4.2.4.10.4 Radio Settings

The Settings tab displays the current radio settings programmed into the radio.

Radio Configuration S	oftware		
ystem Radio x790 Net	work-wide CommPort	Print Help	
tatus - Radio Polling is	finished, press F2 t	o refresh.	
		~	~
Information	Settings	Options	Network-Wide
	1		
NADIO SETTINOS	J		
Time Out Timer	30 secs (ON)		
Soft Carrier Dekey	2 ms		
Squelch Tail Eliminato	r OFF		
CTS Delay	10 ms		
PTT Delav	Oms		
Loopback Code	1184		
Data Hate/Format	Not Applicable		
Power Control	37 dBm		
RADIO SETTINGS	]		
Modem Tune	NONE		
Frequency	TX 896 93750 MHz		
	RX 935.93750 MHz		
Emphasis	OFF		
DATA Key Mode	n/a		
Switched Carrier	OFF		
Buffer Mode	n/a		
Tx. Audio Level	-20 dBm		
Rx. Audio Level	-10 dBm		

Figure 4-32 Configuration Software - Radio Settings Tab

### 4.2.4.10.5 Options

📆 Radio Configuration 9	oftware		_ 🗆 🗡
System Radio x790 Ne	twork-wide CommPort P	int Help	
Status - Radio Polling is	s finished , press F2 to	efresh.	
Information	Settings	Options	Network-Wide
AUTHORIZED RAD	O OPTIONS		
Diagnostics : - Remote : DFF Master : OFF Premium Options: ON MPT1411 : ON 1200 Baud : ON 4800 Baud : ON 9600 Baud : ON			

The Options tab displays the authorized radio options available.

Figure 4-33 Configuration Software - Radio Options

#### 4.2.4.10.6 Main Menu

Using the task bar click on **RADIO** to bring up the Main Menu.



Figure 4-34 Configuration Software - Main Menu

# 4.2.4.10.7 Diagnostic Maintenance and Calibration

Click on Diagnostic Maintenance and Calibration selection from the Main Menu as shown in Figure 4-35.







The following window opens displaying current radio status.

Figure 4-36 Configuration Software - Diagnostic Maintenance and Calibration

The Indicators and Controls on the Diagnostic Maintenance and Calibration window are as follows:

Transceiver Voltages	This area shows the level of two voltages inside the transceiver. The input source voltage and the regulated radio voltage used by the transceiver components.			
<b>Received Signal Strength Indicator</b> This area shows the approximate strength (in dB				
(RSSI)	of the signal being received.			
Power Output Indicator	This area shows the power output (in dBm) of the			
	transceiver when the unit is in the transmit mode.			
Temperature Indicator	This thermometer displays the internal temperature			
	of the radio in degrees Celsius.			
Transmit Power Adjustment	This slider adjusts the output of the radio.			
Frequency Adjustment	This slider fine-adjusts the TX-RX frequencies.			
RTU Reset	Used with the Remote Terminal Unit (RTU). Click			
	the button to set pin 15 High or Low.			

# 4.2.4.10.8 Auto-Configure

Click on **RADIO** in the task bar and bring up the Main Menu. Highlight **Auto-Configure Current Radio** to bring up the Auto-Configure window.



Figure 4-37 Configuration Software - Auto-Configure Current Radio

The Auto-Configure window will appear and starts the utility. This feature allows management, storage, uploading, and downloading of transceiver parameter files. New settings may be entered in to the New Settings column. Pressing the Program Settings To Radio button will transfer the information to the radio. Pressing the Cancel button will abort the procedure. Click on the Transfer Current to Settings button will populate the New Settings column with the Current Radio Settings



Figure 4-38 Configuration Software - Auto Configure Utility

The Auto Configure Utility components are as follows:



- Load Radio Settings from File This selection opens a standard dialog box to open a transceiver paramenter file that has been stored on the computer. Notice the default suffix name is .RFP which is an abbreviation for Radio Parameter File.
- Save Radio Settings to File This selection opens a standard dialog box to save a transceiver parameter file that has to be stored on the computer. Notice the default filename suffix is RPF which is an abbreviation for Radio Parameter File.
- **Exit Screen** This function exits the Auto Configure Utility and returns control of the software to the Main Window.

### Auto Configure Programming Example

Refer to Figure 4-39 for screen examples. To program a new transmit frequency check the box [1] to the left of Tx Frequency in the Function column. Enter the desired transmit frequency in the Tx Frequency box [2] in the New Settings Column. Press the **Program Settings to Radio** button. The button will indicate programming and the parameter box will turn yellow [2]. In the event the parameter did not successfully program, the parameter box in the new settings column [3] will turn red. Check the parameter and verify it is within an acceptable range for the radio. In this example the frequency was entered wrong and is out of the range of the radio and has alarmed by turning the box red. Re-enter the parameter and press the **Program Settings to Radio** button. The button will indicate programming and the parameter box [2] will turn yellow. If the programming was successful the parameter box [4] will turn green. Click the **OK** button or use the **File** drop menu to exit the utility.



YELLOW	A parameter box turns yellow during the transfer process.
RED	A parameter box that turns red indicates the parameter has not successfully transferred to the radio. Verify the parameter has been entered correctly and is within the proper limits.
GREEN	A parameter box that turns green indicates the transfer process has been successful.

### Figure 4-39 Configuration Software - Auto Configure Programming Example

### 4.2.4.10.9 Programming Transmit Frequency

Using the Radio Main Menu select the Program Transmit Frequency entry as shown in Figure 4-40. A dialog box will appear with the current frequency listed and a box to enter the new frequency. Enter the new frequency and click the Program button. An error window will appear in the event the entry is not valid.

📆 Radi	o Configuration S	oftware				_ 🗆 🗙
System	Radio x790 Net	work-wide:	CommPort	Print	Help	
Status	Diagnostic Maint	enance and	l Calibration	əfr	esh.	
	Auto-Configure	Current Rad	dio	F	Options	Network-Wide
	Performance Da	ta for x710	В			
Badic	Enter Password					
Alarm	Enter Authorizal	tion Code(s)	)			
Diag.	Program Transm	nit Frequenc	У			
Diag.	Program Receive	e Frequency	/			
Suppl	Program Power	Control				
Regu	Program Time O	ut Timer		• I -		
PLL L	Program Data R	ate/Format				
Temp	Program Loopba	ack Code				
	Program Diagno	stic Mode Le	evel	• I -		
035	Program CTS De	ay				
Seria	Program PTT De	lay				
Mode	Switched Carrier	r Mode		• I -		
Hards	Program Modem	Туре		• I -		
Softw	Program Empha:	sis		• I -		
Uwne	Program Owner	's Name				
Uwne	Program Owner	's Message				
	Program Soft Ca	arrier Dekey	Delay			
	Program Squelch	n Tail Elimina	itor	•		
	Program Tx. Lev	/el				 
and the second	Program Rx. Lev	vel				

💘 Program Transmit Frequency	X
Current Tx. Frequency 896.93750 MHz.	
Enter a new Tx. Freq MHz.	
Cancel Program	



# 4.2.4.10.10 Programming a Receive Frequency

Using the Radio Main Menu select the Program Receive Frequency entry as shown in Figure 4-41. A dialog box will appear with the current frequency listed and a box to enter the new frequency. Enter the new frequency and click the Program button. An error window will appear in the event the entry is not valid.

🃆 Radi	o Configuration Software			
System	Radio x790 Network-wide Comm	Port Print	Help	
Status	Diagnostic Maintenance and Calibra	tion 🎦	esh.	
	Auto-Configure Current Radio	Ē	Options	Network-Wide
PAD	Performance Data for x710B			
Radic	Enter Password			
Alarm	Enter Authorization Code(s)			
Diag.	Program Transmit Frequency			
Diag.	Program Receive Frequency			
Suppl Regu PLL L Temp USE Serial	Program Time Out Timer Program Time Out Timer Program Data Rate/Format Program Loopback Code Program Diagnostic Mode Level Program CTS Delay Program PTT Delay	•		
Mode	Switched Carrier Mode	-		
Hards Softw Owne Owne	Program Modem Type Program Emphasis Program Owner's Name Drogram Owner's Name	;		
Colorido	Program Coviner's Message Program Soft Carrier Dekey Delay Program Squelch Tail Eliminator Program Tx. Level Program Rx. Level	,		

🛍 Program Receive Frequency						
Current Rx. Frequency 935.93750 MHz.						
Enter a new Rx. Freq MHz.						
Cancel Program						

Figure 4-41 Configuration Software - Program Receive Frequency

Using the Radio Main Menu select the Program Power Control entry as shown in Figure 4-40. A dialog box will appear, enter the desired power level and press the OK button. The default setting for this application is full power (37 dBm).

🍟 Radio	Configuration Software			_ 🗆 ×
System	Radio ×790 Network-wide CommPort	Prin	: Help	
Status	Diagnostic Maintenance and Calibration	2	resh.	
	Auto-Configure Current Radio	F	Options	 Network-Wide
BAI	Performance Data for x710B	T		
Time	Enter Password			
Soft (	Enter Authorization Code(s)			
CTS I PTT I	Program Transmit Frequency Program Receive Frequency Program Power Control			
Loopi Data Powe RAI Mode Frequ Emph DATA Switc Buffe T.x. A R.x. A	Program Time Out Timer Program Data Rate/Format Program Loopback Code Program Diagnostic Mode Level Program CTS Delay Program CTS Delay Switched Carrier Mode Program Modem Type Program Comphasis Program Owner's Name Program Owner's Massage Program Owner's Message Program Soft Carrier Dekey Delay Program Squekh Tail Eliminator Program Tx. Level Program Rx. Level	• •		
Progra	m Power Control			×
Enter F	Power Control setting from 20	)-37	dBm.	OK Cancel
37				

Figure 4-42 Configuration Software - Setting Transmit Power Level

#### 4.2.4.10.12 Program Time-out Timer Delay

This selection allows the Time-Out Timer (TOT) delay to be programmed

#### 4.2.4.10.13 Program Loopback Code

This selection allows the loopback code to be programmed. Default in this application is 1184.
## 4.2.4.10.14 Program Diagnostic Mode Level

This menu item allows selection of the appropriate level of diagnostics support. The transceiver must be configured for the diagnostics mode selected. This application uses **Standard Loopback** for the default setting.

## 4.2.4.10.15 Program CTS Delay

This selection allows the CTS (Clear to Send) delay to be programmed. Default for this application is **10 milliseconds**.

# 4.2.4.10.16 Program PTT Delay

This selection allows the PTT (Push to Talk) delay to be programmed. The default for this application is set at **0**.

#### 4.2.4.10.17 Switched Carrier Mode

This setting selects the Switched Carrier Mode. Default in this application is Off.

## 4.2.4.10.18 Program Modem Type

The selection allows selection of the modem type. Default in this application is **None**.

#### 4.2.4.10.19 Program Emphasis

This menu item selects Emphasis. This application has the default set to Off.

#### 4.2.4.10.20 Program Owner's Name

This selection allows a name (up to 27 characters) to be programmed for identification purposes.

#### 4.2.4.10.21 Program Owner's Message

This selection allows a 27 character message to be programmed.

#### 4.2.4.10.22 Program Soft Carrier Dekey Delay

This selection allows the Soft Carrier Dekey Delay (SCD) duration to be programmed. Default in this application is **2 milliseconds**.

### 4.2.4.10.23 Program Squelch Tail Eliminator

On and OFF pop-up choices allow the Squelch Tail Eliminator (STE) to be enabled (ON) or disabled (OFF). Default for this application is **Disabled (OFF)**.

#### 4.2.4.10.24 Program TX Level

The TX Audio Level sets the input level (in dBm) on the TX audio input line for analog functionality. Choosing a fixed input level means that the TX audio signal will be scaled to the optimum peak frequency deviation over the air. This means if a TXLEVEL is set to -10 dBm and the input signal is actually -20 dBm, then the modulated signal will have a low peak deviation. The AUTO mode will check the input TX audio signal's peaks and scale the signal accordingly so that the peak deviation is the desired value. Default in this application is **-17 dBm**.

#### 4.2.4.10.25 Program RX Level

The RX Audio Level sets the output level (in dBm) on the RX audio output line. Default in this application is **-5 dBm**.

#### 4.2.4.10.26 Closing MDS Configuration Software

To close the MDS Configuration Software, click on the System pull-down menu. Select End Program and click the selection. Allow the program to close the diagnostic port connections. Power down and restart the Cab Radio to restore normal operation.





**NOTES** 



# Safetran Systems Corporation 2400 Nelson Miller Parkway Louisville, Kentucky 40223 (502) 618-8800

## Safetran Systems Corporation

California Division 10655 7th Street Rancho Cucamonga, California 91730 (909) 532-5300

Safe Transportation Systems That Work Every Time