

Instruction Manual

Model: SC330



General Information

Congratulations on your purchase of JETHRO SC330

Please read this information for better handling the phone, we assume no liability for result from improper handling.

We are constantly trying to improve our products and service. Therefore Jethro reserve the right to modify any of the products changes and improvements described in this document without prior notice.

The contents of this user manual are presented "as is". Jethro takes no guarantee for the accuracy of completeness of the contents of this user manual. There maybe slight variations of the images in the user manual and the phone type, there serve as examples please refer to the phone. Some features are dependent on network operators, for more information please contact your network operator.

Please check the supplied accessories, determine whether the below listed accessories are all available, if one of the component is missing or damaged, please contact your dealer where you purchase the phone.

Jethro SC330 contents:

- 1 Telephone (SC330)
- ➤ 1 Charging Station (SC330)
- 1 Charger (SC330)
- 1 Battery (SC330)
- ➤ 1 USB Cable (SC330)
- ➤ 1 User Guide (SC330)

IC ID: 11350ASC330 FCC ID: 2AAWJSC330

General Information

If the font is too small for you to read, please view a larger version user manual on our website.

See the product support page on our website: www.jethroshop.com

Device Code:

With this code, unauthorized persons can prevent using the phone.

The factory default Code is: 0000

PIN-Code:

The network operator provides this with the SIM card to prevent the use of the card by unauthorized persons.

You can enable / disable or change the PIN code.

Table of Contents

| My Phone9 |
|-------------------------------------|
| LED Description11 |
| Getting Started11 |
| What is a SIM card? |
| Inserting the SIm card and Micro SD |
| card12 |
| Inserting the battery14 |
| Charging the battery15 |
| Turning on or off the phone16 |
| Standby16 |
| Screen (Home screen)17 |
| Screen Symbols |
| Headset/Bluetooth Modes19 |
| Menu Function19 |
| Quick access functions20 |
| Call Functions20 |
| Call20 |
| |
| Call using the phone book21 |
| Answering a call22 |
| Functions during a call23 |
| Hands-free:24 |
| Menu25 |
| Phonebook26 |
| Access your phone numbers26 |
| New Contact26 |
| Edit a contact27 |

| Delete all contacts from the phonebook or |
|---|
| SIM card27 |
| Copy all contacts from the phonebook or |
| SIM card27 |
| Speed Dial28 |
| Direct M1 M228 |
| Messages29 |
| Write messages29 |
| Text input29 |
| Inbox30 |
| Draft31 |
| Outbox31 |
| Sent messages30 |
| Voice mail31 |
| SMS settings32 |
| Calls33 |
| |
| Call list |
| Extras34 |
| Alarm clock34 |
| Tasks34 |
| Calculator35 |
| Calendar35 |
| Services36 |
| Multimedia36 |
| Camera36 |
| Photograph36 |
| Image settings37 |
| Image Viewer37 |
| FM Radio36 |
| 111144410111111111111111111111111111111 |

| | File Manager | 38 |
|----|------------------------------|----------|
| | Copy images to your computer | 39 |
| Se | ettings | |
| | Profile (Sound) | |
| | sos | |
| | SOS Alarm | |
| | SOS Number | |
| | SOS SMS | |
| | Phone settings | |
| | Time and date | |
| | Language | |
| | Display | 43 |
| | LED Mode: | |
| | LCD backlight: | |
| | Call settings | |
| | Caller ID: | |
| | Call waiting: | |
| | Call forwarding: | |
| | Call barring: | |
| | Line switch: | 45 |
| | Call time reminder: | |
| | Answer mode: | |
| | Advanced settings: | |
| | Last number redial: | 7J 15 |
| | Network settings | |
| | Network selection: | |
| | | |
| | Security settings | |
| | SIM-Security | |
| | Phone security: | 4/ |

| Connections | 47 |
|--------------------------------|--------|
| Bluetooth | 47 |
| Restore factory settings | 49 |
| Specification | 49 |
| Troubleshooting | |
| Battery | |
| Phone | 56 |
| Safety instructions | |
| Road safety: | |
| Operating environment: | |
| Electroinc devices: | |
| Pacemaker: | |
| Hearing aids: | |
| Other medical devices: | |
| Labelled sites: | |
| Hazardous locations: | 63 |
| Vehicles: | 64 |
| Information | |
| Information about the certific | cation |
| (FCC): | 64 |
| Limitation of liability: | |
| Contact us | |

My phone



Figure SC330

| 1 | Direct dial button M1 M2 | |
|---|--|--|
| 2 | Left menu key / main menu | |
| 3 | Green call button / call list | |
| | Call in standby mode / Ok button | |
| 4 | * Button Press this key in standby mode to enter the following characters: * /+ | |
| | | |
| | /P / W. | |

| 6 | Camera button | | |
|----|--------------------------------------|--|--|
| 7 | Microphone | | |
| 8 | Right menu button / call in standby | | |
| | mode of the Phonebook | | |
| 9 | Power button (press and hold 3 | | |
| | seconds), ending a call, reject call | | |
| 10 | 2-way navigation | | |
| | Arrow button (up): Invoke the SMS | | |
| | Message in standby mode | | |
| | Arrow button (down): Call the photo | | |
| | contacts in standby mode | | |
| 11 | # Key / Pound | | |
| | In the standby mode, by long | | |
| | pressing enable / disable the silent | | |
| | mode. | | |
| | In the edit mode: change the input | | |
| | method | | |
| 12 | Emergency call key button | | |
| 13 | Polyphonic speaker | | |
| 14 | Micro USB charger connection | | |
| 15 | Volume key / Flashlight | | |
| | By long press volume button 19 to | | |
| | activate / deactivate the flashlight | | |
| 16 | Connection for Headset (3.5mm) | | |

LED description

| White LED | Flashlight | |
|-----------|--|--|
| Red LED | Low battery (flashing) / charging mode (lights up) | |
| Green LED | Call, missed call or unread message | |



Getting started

What is a SIM card?

Each mobile phone requires a SIM card (subscriber identity module). Without the SIM card you can not make phone calls. The SIM card is a microprocessor which stores their data and contacts. Deal with a map so carefully, and take caution when inserting or removing the card. Keep SIM cards out of the reach of small children.

Insert the SIM card and micro SD card

- The phone must be switched off and unplugged from charger.
- Remove the battery cover on the back of the phone.



- If the battery in the device, please remove it.
- See 2 cards holders: top left for the SIM card and the bottom right for the micro SD card.
- Push the SIM car carefully into the SIM card slot (1). Ensure that the Gold contacts of the card facing down and beveled corner is.
- Carefully slide the micro SD card into the SD micro SD card holder (2) and then lock them.



Insert the battery

- Align the golden contacts of the battery with corresponding contacts of the phone.
- 2. Press on the other end of the battery until it locks in place.
- Slide the battery door so far on the unit up until it clicks into place.



Charging the battery

There are two ways to charge the battery of the SC330:

- A. Charging station
- B. Charger
- Insert the connector of the charger in the phone.
- Connect the charger to the main socket.
- Charging the battery can take several hours. If the phone's battery ran out, it may take awhile until the charge indicator appears on the display.
- If the phone is turned on, charge indicator will appear on the display. The indicator will no longer flash when battery is fully charged.
- Disconnect the charger from the socket and from the device if charging is not required

Note: The initial charge for the battery should be at least 12 hours.

Turn on or off the phone

Make sure that the SIM card is in the phone and the battery is charge.

- 1. Press *red button* 2-3 seconds to switch the phone on.
- The PIN-code is active if the phone asks you the PIN code, please enter it and confirm with OK.
- Please select your language and confirm with OK.
- Press rote Taste 2-3 seconds to turn off the phone.

You can only call emergency number without a valid SIM card.

Note: If the PIN code entered incorrectly 3 times, the phone will ask you the PUK code that you have received it together with the SIM card.

Standby

If the phone is not used for a short period of time, the telephone will switch to standby mode automatically. Press any key to exit this mode.

Screen (home screen)

| 1 | 2 | 3 |
|---|---|---|
| | 4 | |
| | 5 | |
| 6 | | |
| 7 | | 8 |

- 1. Signal strength
- 2. Symbols
- 3. Battery status
- 4. Network operators
- 5. Time
- 6. Date
- 7. Menu
- 8. Phonebook

Screen symbols



Signal strength:

The vertical bars show the strength oft he reception of the carrier.



This symbol appears when you received a new message.



SIM card has an unread message.

This sign blinks when the Inbox is full. You must delete some messages so that you can receive new messages.



Headphones

This symbol is displayed when a headset is plugged in.



Missed calls

This sign will be shown if you have missed calls.



Incoming call alert

Only ringing.
Silent mode and vibrate.
Vibrate and ring



Call forwarding

This symbol appears when all calls are forwarded.



Alarm clock

This symbol is displayed when the alarm is switched on.



Bluetooth

This symbol appears when the Bluetooth is turned on.



Battery meter

This character changers color depending on the status of the battery.



Headset/Bluetooth mode

When headset is connected (includes a Bluetooth headset), you can answer the cal by pressing the key on the headset.

Menu function

In the home screen, press the left menu button (\square) to enter *main menu*, press the (\square) to access the *contacts*.

Quick access functions.

Use the 2 key navigation button to enter quick access to following functions:

| Button | Function |
|----------------|----------------|
| Arrow key up | SMS messages |
| Arrow key down | Photo contacts |

Call features

Call

- Enter the phone number including the area code, and press the green button. International calls: enter before the area code + sign by pressing of * and the country (or regional) a preset. (If necessary, omit the 0 before the area code).
- Press right menu key delete to delete the number to the left of the cursor.
- Press the green button to call the number.

Call using the phone book

If contacts in the phonebook is stored, you can make a call using the phone book.

- 1. To enter the phone book, press *right menu button* in standby mode.
- 2. Use arrow keys to scroll up and down to the desired telephone number.
- 3. Press the *green button* to call the number.
- Press the <u>red button</u> to cancel or end the call.

Call by using the Photo contacts

Press down arrow key in standby mode. Here you have the option to select up to 8 Photo contacts, use the Arrow keys to navigate to the photo you want to contact and then press the Call button (green button)

The picture appears in the photo contact directory. To assign an image to this contact, perform the following steps: Create photo contact

- Press down arrow key in standby mode to enter the photo contact menu.
- 2. Use the arrow keys to scroll.

- To edit a photo contact, press the left menu button (Edit / option), select Edit and confirm with the left menu key (OK).
- In the first line, you give a name to the contact.
- In the second row, enter the telephone number.
- 6. In the third line, press the *left menu button* "Options" and add a photo.
- By file: Select an image that you already saved.
- After you edited the contact, press the right menu button (Back), to save you confirm with the left menu key (Jab).

Important: For a photo contact screen, please use the resolution specifically specified "Photo contacts" in the camera settings.

Note: to store pictures you need a micro SD memory card up to 16 GB. (Not included in the accessories)

Answer a call

If you receive a call and the phone rings or vibrate, you will see the number of the name on the display.

- 1. If you want to take the call, press the *green button* and *OK*.
- You have the possibility to answer the call automatically by flipping open the phone, please refer to the following menu item:

Settings-call setting-answer mode: select "**Cover answer**" then press the right menu button (Done)

- 3. If you want to reject the call, press the *red button*.
- 4. You can switch the incoming call silent by pressing any button.

Functions during a call

The following functions available by pressing the *Options* Button during a phone call:

Call hold:

Place call in the queue.

End the call*:

End call.

New call:

To make another call.

Phone book:

To enter the phone book.

Call list:

Show the call list

Messages:

To access the messages.

Mute:

To switch microphone off / on

Key tone:

Turn the keypad tones on / off.

Note: The * marked functions must have SIM card inserted. For more information, please contac the network operator.

Hands-free:

You can enable / disable the hands-free function during the telephone by pressing the right menu button.

Menu

1 Phone book 4 Extras 1 Contacts 1 Alarm clock 2 Add new contact 2 Events 3 Speed dial 3 Calculator 4 Direct dial 4 Services 5 Photo contacts 5 Multimedia 6 Settings 1 Camera 2 Releases 2 Viewing images 3 FM radio 1 Write SMS 4 File Manager 2 Input 3 Designs 6 Settings 4 Output 1Profiles 5 Sent messages (Sound settings) 6 Delete messages 2 SOS settings 7 SMS settings 3 Phone settings 3 Calls 4 Call settings 1 Missed calls 5 Network settings 2 Dialed calls 6 Security settings 3 Received calls 7 Connections 4 Call logs 8 Factory setting

restore

Phonebook

You can store up to 250 phone numbers in your SC330, and save up to 250 phone numbers in your SIM card.

Access to your phone numbers

You have two ways to get to contacts:

- Press the right menu button in standby mode.
- Press the left menu button in standby mode then select Phone book and confirm with OK

Note: Symbolizes a SIM card entry

Symbolizes a phone entry

New contact

- Select Add new contact in Phone book menu.
- Select memory place: SIM card or Phone.

SIM card contact: It can only store Name and Number.

Phone contact: It can store Name, Number and Caller ring tone.

To save the *Contact*, press *Options* and *Save*.

Edit a contact

- 1. Choose a name, press *Options* and select *Edit* then confirm with *OK*.
- After edit the entries, in order to save the changes, press Options and select Save and confirm with OK

Delete all contacts from phonebook or SIM card

- Select Main menu Phone book and press OK
- 2. Select Settings and press OK
- 3. Select Delete all contact and press OK
- Select From SIM or From phone and press OK
- Press OK another time to confirmt eh deletion.

Copy all contacts from phonebook or SIM card

- Select Main menu Phone book and press OK
- Select settings and press OK
- 3. Select Copy contacts and press OK
- 4. Select From Phone or From SIM and press OK
- press OK another time to confirm the copying.

Speed dial

- Select Main menu Phone book and press OK
- 2. Select Speed dial and press OK

You can use the *Speed dial* function when speedial is switched on.

Total of 8 numbers can be stored as speed dials. (key #2- key #9)

- 1. Select Set number and press OK.
- Select the desired number (2-9) and press Options.
- 3. To edit, press *Edit*.
- Select the desired name from the phone book and press OK (the desired name must already be saved under contacts).

Press the desired speed dial number (2-9) 2 seconds in standby mode and the assigned number will be dialed.

Direct M1 M2

 Select Menu - Phone book and press OK

2. Select Direct numbers and press OK

Here you can see and edit the M1 und M2Numbers

Press the M1 or M2 button in the standby mode to dial the stored phone number.

Messages

You can send and receive *SMS* messages. however, it may depend on your network operator. Please contact your network operator for more information.

Write messages

- 1. Select Menu, Messages and press OK
- 2. Press Write message

Text input

The following functions are available:

- Press 0 to add a space
- Press the * The button to add special characters, using " " Arrow keys "you can navigate to the desired symbols"
- Press the arrow keys to move the cursor left or right.
- Press the right menu button to delete.
- · Press and hold right menu button to

delete all letters.

 Press the # Button to switch between small, capitalization and word recognition: DE, de, 123 and make sure that the icon top left of the display.

After you the message is complete, press *Options* and select *Send to.*

Here have the possibility that Send to one or add more Contacts

Other options:

You can see the number of written letters on the right top of the screen.

More options:

Insert symbol, input method, use details and Save.

Inbox

In this menu you can read new or already read *messages*.

Depending on the mode, the phone vibrates or rings and the Green LED will flash if you get a new *messages* in standby mode, you can also see this icon on the screen.

Press the Option for following functions:

Delete, Reply, Call sender, Forward, Advanced and Save.

Note: If the message memory is full, If flashes in standby mode, please delete some messages to reveive new ones.

Draft

In *Draft* you will see your saved SMS messages.

Outbox

In Outbox store unsent messages.

Sent message

In this menu you can see already sent messages.

The following functions are available: Forward, delete, use number, copy to SIM or phone* and Move to SIM card or the phone*.

*This option is dependent on where the text has been stored.

Voice mail

The voice message is a network feature. When a voice message is received, the icon of a new message appears on the screen of your phone.

- 1. Select Menu, messages and press OK
- Select SMS settings and press OK
- 3. Select SIM and press OK
- 4. Select Voice mail and press OK
- 5. < Empty > selects 1 and press Options.
- 6. Select Select or Edit.
- Choose Edit to give your voicemail a Name and enter the Voicemail retrieval number in Number.

In standby mode: Press and hold the number 1 and your phone will call the stored *Voice mail*.

Note: This service must be supported by the network operator.

SMS Setting

- 1 Select Menu, messages and press OK
- 2 Select *SMS settings* and press *OK* You can define SMS settings.

The following functions are available:

SIM (profile settings):

You can make settings include the communication Central number (SMSC) (operator-dependent) and other SMS.

Memory status:

This option displays the SMS memory status of your SIM card and your phone.

Save sent messages:

An or turn off storing the sent messages

Preferred store:

Select the location for the SMS *Phone* or *SIM*

Calls

Call list

Your phone stores list for Missed calls, dialed calls and received calls

The latest entries are top of the list.

With Options provide the following

functions are available:

Viewing, call; send SMS to the black list, save in the phone book and Delete.

Delete call logs:

Can the logs by *Default, selected* and *received* singly or also *all* Delete call logs.

Extras

Alarm clock

Up to 5 alarm clocks can be made.

To set the alarm:

- Select an alarm and press Edit. You can set the alarm with follow options: Status on/off (M1 or M2), Time, Repeat as well as the Alarm tone.
- After the alarm clock is set, press button Save.
- When the alarm sounds, press Stop to stop this or the Snooze Button. In this case, which is snooze alarm clock and after about 5 minutes sound again.

Tasks

Here you can enter events.

Add tasks:

Press Add then enter the required details and press save.

In the are you following Options available: Ads delete overdue add, edit, delete, delete all and Display.

Calculator

With this function, you can use your mobile phone as a calculator. The Calculator controls the basic arithmetic functions.

Features:

- Type the number (1 to 0).
- Press # for a decimal point.
- Use the arrow keys for: +, -
- Use the M1 M2 keys for: x, ÷
- Press left menu button for: =
- Press right menu button for delete Calendar
- 1 Select Menu, Extras and press OK
- 2 Select Calendar and press OK

Press down arrow, up arrow, M1 and M2 Keys in the calendar navigate the date.

By pressing the left menu button (Options), you can view, view all, and add

Event, delete event, jump to date, Go to Today, Go to weekly view and change Week start.

Services

This is service depends on network operators.

Multimedia

Camera

Press the Camera button!

Photograph

Align the camera lens on a position or an object and press the *Camera* button to take a photo. After taking the photo, the picture will be displayed and automatically stored.

Note: to store pictures you need a micro SD memory card up to 16 GB. (Not included in the accessories)

With *Options* following options available: *Image Viewer:*

Displaying the stored photos (in JPG format). You can view the photos on *Bluetooth* send and receive.

The following functions are available under them *Options* available: *Ads, send, use, rename, delete, memory* and *Image information.*

Camera settings:

Set of Anti-flickering, scene mode, white balance and Delay time.

Image settings:

Set Image size, and Image quality.

Restore settings:

Restores the default setting.

The following functions are available in photo mode:

Image Viewer

Displaying the stored photos in JPG format. You can view the photos and sent via *Bluetooth*.

The following functions are available under Options: View, send, use, rename, delete, sort, storage and Image information.

FM Radio

With this function, you can hear FM radio. The following buttons are available in FM mode:

| Taste | Functions |
|--------------------|---------------------|
| M1 | Previous channel |
| M2 | Next channel search |
| Arrow key up / # | Increase volume |
| Arrow key down / * | Decrease volume |

The options include:

Channel list:

Playback, editing, or delete the stored channels.

Manual search:

Manual channel search.

Automatic search:

Automatic search.

Store current channel.

Stores the transmitter you are listening

File Manager

- Select Menu, Multimedia and press OK
- Select File Manager and press OK

Use the file manager to manage your files and folders in the phone memory and memory card.

Open:

To display the contents in the selected folder

New Folder:

To create a new folder.

Rename

To rename a folder.

Delete:

To delete a folder.

Copy images to your computer
To copy the images that you have made
with the SC330 camera on the computer,
proceed as follows:

- Connect the phone with the help of the included micro USB cable to the computer.
- Then a menu will appear on the phone select Mass storage and confirm OK
- 3. The computer shows the phone as Removable disk detected.
- Now you can normally edit the data with the help of Windows Explorer or copy to your computer.

Note: The pictures are located in the folder "Photos"

Settings

Profiles (sound)

- 1. Choose menu, settings and press OK
- 2. Choose profiles and press OK

Display the profile mode list including: **General, silent, meeting, outdoor**. Select the mode and call up the option

menu: Enable:

Profile mode.

Edit: Adjust ringer and other desired sounds

Reset: Reset to default settings.

Following sound settings are available:

Signal type, call type, ringtone, ringtone volume, messages, call volume, key tone, keypad volume, power on, power off and System alert (sound system for error messages, weak battery etc.).

SOS

The SOS function is a simple feature that can save lives in the decisive moment. You can store a total of 5 SOS contacts and SMS. You must save these contacts

first, in case of an emergency when you press the emergency call key on the back of the phone, these numbers will be called in sequence. During the emergency call a warning signal will be issued, so the person knows that it is an emergency and it sends an emergency SMS to all stored numbers! If the first number is not reached, the next number is dialed automatically, etc.

If no emergency number is stored or your phone card is empty or you are in a foreign network (E.g. roaming not enabled), you can still choose 911 or other emergency numbers with the digit keys.

Will be accepted the SOS call switches the hands-free telephone.

Note:

- Want to stop the alarm, must press the right menu button or the SOS button.
- When using a pre-paid SIM card: Make sure you always have sufficient credit on your pre-paid SIM card as private emergency numbers without sufficient balances are not elected.
- Usually the international emergency call 911 can still be called outside of

the network provider's home network.

Note: If you want to store emergency numbers such as rescue, police, fire service etc. as emergency number, you would need to check before this with the respective institution. Assumes no liability for any costs incurred, if you mistakenly call.

SOS

- 1. Choose Menu, settings and press OK
- 2. Choose SOS and press OK

SOS Alarm

You can turn the SOS alarm on and off

SOS numbers (contacts)

You can save up to maximum of 5 SOS numbers and its calling order.

SOS SMS

When SOS call started but not accepted, pre-prammed SOS text is sent to the SOS numbers. The text can be changed.

Phone settings

1 Select *Menu*, *Settings* and press *OK* 2 Select *Phone settings* and press *OK* The following menu items are available:

Time & date
Set Time zone, date, Time and Format.

Language

In this menu you can set the display language Preferred input method In this menu, you can define your preferred input method (DE, de, 123).

Display

Wallpaper image:

Choose wallpaper

Display:

Turn the display on / off.

LED mode:

You can turn the LED light on, off or on Night mode (off 8:00 pm-08:00 am)

LCD backlight:

Adjust the brightness and illumination time of the display

Call settings

- 1. Select Menu, Settings and press OK
- 2. Select Call settings press OK

Depending on the network operator, you may use the following services:

Caller ID:

Here you can set whether suppress your number or is visible to the called party.

Call waiting:

You will be informed during a conversation, when another call comes in. Press the left menu button to receive the call. The first call is in the other direction, if you do not preclude the call - wish to press the hook button.

Call forwarding:

With this network service, you can redirect incoming calls to another specify phone number. Multiple calls can be forwarded at the same time.

Call barring:

With this network service, you can restrict your phone calls.

Line switch:

You should use two numbers on one SIM card (operator service) so you can switch this function between the two phone numbers.

Call time reminder:

It sounds a signal tone during the call because you can determine.

Answer mode:

Choose the way that they want to take a call forward

Advanced settings:

Black list:

In this menu you can add phone numbers in the *Black list* to block incoming call from these numbers.

Last number redial:

Activates the automatic redial if the calling user is not available.

Network settings

1 Select Menu, Settings and press OK
 2 Select Network settings and press OK
 Depending on the network operator, you can use the following services:

Network selection:

You can choose between automatic or manual *Network selection chooses*.

Security settings

- 1. Select Menu, Settings and press OK
- 2. Select Phone settings and press OK

The following functions are available:

SIM security

PIN lock: You can turn the SIM lock on/off with knowing the current PIN-Code of the SIM card; you can change the PIN code for the SIM card at any time.

Change PIN/PIN2: To change the password, enter the current password and then the new password for: PIN or PIN2

Note: 3x failed entering the correct current SIM PIN-code will lock SIM card, and will be asked for PUK number to unlock it. Please contact network operator for your PUK number. The SIM card PIN-code is NOT the phone factory default code.

Phone security:

Phone lock: You can turn the phone lock on/off with knowing the current PIN-Code of the Phone

Change password: To change the password, enter the current password and new password then confirm again.

Note: The factory default code is: 0000.

Connectivity

- 1. Select Menu, Settings and press OK
- 2. Select *Connectivity* and press *OK* The following menu item is available:

Bluetooth

With Bluetooth, you can connect your phone to a compatible Bluetooth device. The following functions are available:

Power:

Press the left menu button the Bluetooth function on / off switch.

Visible:

You can set your phone so that other Bluetooth devices can detect it.

My devices:

In this menu, you can use a connection already detected Bluetooth devices.

Search audio device:

In this menu you can here connect to Bluetooth enabled audio accessory – ensure

My name:

Change the Bluetooth device name. *Advanced:*

In this menu you can choose: Audio path, and my address see the MAC address of your phone.

Search the Bluetooth audio device:

- 1. Press to start device to search for other Bluetooth *OK*.
- 2. You select from the desired device and press *Pairing*.
- Connect to other Bluetooth devices built on do you need a Password. Confirm the password with OK.

In Options you will find the following functions: Connect, delete, rename, authorize and Delete all

Restore factory settings

With this function you can reset the phone settings to the factory-set configuration.

You must enter the password to restore factory settings. The default password is: 0000.

Specification

| Quad-Band network: | WCDMA 850/1900Mhz GSM 850/900/1800/1900Mhz |
|-----------------------|---|
| Battery | Li-ion 800mAh |
| Size: | 101 x 50.5 x 19.5 mm |
| Standby time: | <250 hours* |
| Talk time: | <480 minutes* |
| raik time: | <480 minutes** |

^{*} The battery life depends on SIM card, network, applied settings, use and the environment.

Troubleshooting

If problems or irregularities occur during the use of the phone, read the information in the following table. If a particular problem cannot be solved by the following information, please contact the customer service via email: Jethro@jethroshop.com

Phone will not turn on:

- Check whether the battery is correctly in the phone.
- Check the battery status, charge 24 h long the battery or swap it if necessary from (6 months warranty).
- Check that the PIN code has been entered correctly.
- If the PIN-code 3 x false the SIM card is blocked and you need the PUK code (please contact your network operator for your PUK code).

SIM card error:

 Dirt on the contact areas of the SIM card? Clean the contact areas of the

- SIM card. *Do not use water.
- SIM card is not properly inserted.
 Insert the SIM card properly.
- SIM card does not work or is damaged?
 Let your network operator replace the SIM card.

Network connection cannot be established:

- Poor reception? Embark on an open place or, if you are in an enclosed space, near the window.
- You are out of range of the cellular network. For information about the network coverage, Please contact your network operator.
- SIM card is not valid. Contact your network provider.

Bad voice quality:

- Bad network connection quality on the part of the operator? Press the stop button and select again. You will possibly need to switch to a network connection or phone line with better quality.
- Poor quality of local telephone line?
 Press the stop button and select again. You will possibly a network

- connection or phone line with better quality.
- Try to turn volume louder.

Outgoing calls cannot be done:

- Check the phone number and try again.
- Have you activated the function call barring? If yes please disable all.
- Check whether the SIM card in the network is registered.
- Check that is enough credit on your SIM card.

You cannot receive incoming calls:

- Check whether the SIM card in the network is registered.
- Check if the phone is turned on.
- Check the signal strength
- Have you activated the function call barring? If yes please disable all.

Send SMS not working

- Please check the SMSC number (communication Central) under the following menu item:
 - "Messages settings SMS settings SIM SMSC address": here the communication Central number of your carrier should be.

Display is black or white:

- Check the battery status, charge the battery or replace it.
- Check the background image.
 - Did the phone get wet?

Locked:

 Check that if the PIN code has been entered correctly. If the PIN code has been entered incorrectly 3 times, the SIM card will be blocked and you will need the PUK code to unlock it: (please contact your network operator for your PUK code).

Tip: If particular problems could not be solved by the information, please visit our Web site www.jethroshop.comm and choose the product page of your phone and read the FAQ (frequently asked questions) or contact customer service. Note: Please do not try to repair the phone yourself.

Battery

- Your phone is powered by a rechargeable battery.
- Note that a new battery only reaches its full capacity, after two or three times complete charge cycles! The battery can be charged several hundred times until eventually discharged. When the operating time (talk and standby time) compared to the normal operating time is much shorter, you should buy a new battery. Unplug the charger from the mains and from the device if it is not required. If the battery is completely discharged, it may take a few minutes until the charge indicator in the display appears, or you can make calls
- Use only batteries and Chargers approved by the phone manufacturer. If you do not use the charger, pull the mains plug out of the socket. Leave the battery no longer than a week in the charger, since an excessive charge may shorten its

- lifetime.
- A fully charged battery with the time discharge itself when not in use.
- Extreme temperatures have a negative influence on the performance of your battery.
- Use the battery only for its intended purpose. Never use damaged Chargers or batteries.
- Do not short-circuit the battery. An accidental short-circuit can occur by a metallic object of the plus and minus pole of the battery is connected directly together. Shortcircuiting the terminals may damage the battery or the connecting object.
- Throwing batteries in a fire will cause danger of explosion! Batteries may also explode if they are damaged.
 Dead batteries must be disposed properly.
- Do not attempt to open the batteries or to destroy. Liquid leaking from a battery, you make sure the battery fluid does not contact your skin or in the eyes. If there was a contact, clean the skin or eyes immediately with water, or consult a doctor
 - Dispose of batteries according to the

- regulatory requirements (E.g. with regard to recycling). Never dispose of batteries in the household waste.
- Keep temperatures between 15 ° C and 25 ° C. The phone with a cold or warm battery not may work temporarily, even when the battery is fully charged. The performance is varying especially at temperatures below the freezing point.

Phone

If you follow the suggestions below, you can prevent any warranty obligations, and you can enjoy your product for many years.

 Please use only original accessories or accessories that are approved by the mobile phone manufacturer. The use of accessories without permission can lead to poor performance, damage the phone or harm even your body and interfere with appropriate local telecommunications equipment.

- Please switch off your mobile phone before you clean it. Use for this purpose damp or antistatic cloth, no chemicals or cleaning lotions, which can damage the phone.
- Because the mobile phone capable of generating electromagnetic fields, you should put never found near magnetic objects, such as a computer or a hard disk.
- Interference is generated using the mobile phone in the vicinity of certain electronic devices such as TV, telephone, radio and computer.
- Never leave your mobile phone in the Sun or in an environment with strong radiation because high temperatures considerably shorten the life of electronic components.
- Keep the phone dry, because liquids may damage the circuit.
- Never somewhere abut the phone with strong force and do not drop it.
 Violent actions of this sort can damage the circuit.
 - Please close any incompatible devices on the phone.
- Do not attempt disassemble the phone or its battery.

- Keep the mobile phone with a flammable or explosive material.
- Never try to charge the phone, without previously having inserted the battery.
- Do not paint your phone. By the color, moving parts may stick and prevent the proper operation.
- To disconnect the unit from the mains, pull the power cord from the mains socket. Therefore, you must position the device so that an unhindered access to the mains socket is always ensured; so that you can immediately remove the mains plug in an emergency situation. To prevent fire hazard, disconnect always unplug after each use of the device from the AC outlet.

In the same way, all instructions apply to phone, battery, charger, and all accessories. If any of these items not working properly, take it to your dealer. The staff will assist you and repair or replace the unit if necessary.

Safety instructions

Read these simple guidelines. Failure to follow of these rules can have dangerous consequences or violate regulations.



Do Not switch on the phone when the use of the mobile phones is forbidden.

It may come to errors or could cause hazard.



Traffic safety

Never use the phone in your hand while driving



Switch off in aircraft

Mobile phones can cause interference in aircraft.



Switch off in hospitals

Follow all rules and regulations. Switch off the phone near medical equipment.



Turn off at gas stations

In the vicinity of petrol stations and other places with explosive goods, the mobile phone is switch off.



Interference

Wireless phone can cause errors, which could affect performance.

Road safety:

Never use a phone in your hand while driving a vehicle. Always secure the phone in its holder; place the phone on the passenger seat or in a place where it can break loose in a collision or sudden stop. Remember: road safety always has priority!

Operating environment:

Don't forget to observe the special regulations in an area, and always turn off the phone when the use of mobile phones is prohibited

Or if the phone causes interference or dangerous situations can arise.

Always keep the unit in its normal operating positions.

Parts of the phone are magnetic. Metal parts may be attracted to the phone, and persons with hearing aid should not hold the phone to the ear with the hearing aid. Always secure the phone in its holder as metal parts may be attracted to the listener. Bring no credit cards or other magnetic data carriers in the vicinity of the phone because it contained data this can be deleted.

Electronic devices:

The most modern electronic equipment is shielded from RF (radio frequency) signals. However, it can happen that certain electronic devices against the RF signals from your mobile phone are shielded.

Hearing aids:

Some digital mobile phones can cause errors with some hearing aids. If such problems you can contact the service provider.

Other medical devices:

Operation of radio transmitting equipment, including cellular phones, can interfere with the function of inadequately

shielded medical devices under certain circumstances. If you need information about the sufficient shielded against external RF energy or have any questions, consult a physician or the manufacturer of the medical device. Switch off your phone in health care facilities when you are prompted by signs, posters or other written arrangements. Hospitals or health care facilities, devices be used under circumstances that could be sensitive to external RF energy.

Labelled sites:

Labeled sites:

Turn off wherever your telephone, where appropriate requests are suspended.

Hazardous locations:

Switch off your phone in hazardous locations, and act according to the directions and instructions. In such places, a spark can trigger an explosion or cause a fire, where you can get hurt or come even to death. We recommend the users turn off the phone at service stations. Users are reminded the need to observe restrictions on the use of radio equipment in fuel depots (storage and distribution

areas), chemical plants or where blasting. Places where explosion hazard exists are often but not always clearly marked. This includes, for example, the below deck on ships; Environments of pipes and tanks in which chemicals are; Vehicles that are powered by liquefied petroleum gas (such as propane or butane);

Places where chemicals or particles, such as grain, dust or metal powders, are located in the air; as well as any other place, where usually are advised to turn off your vehicle engine.

Vehicles:

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles (E.g. electronic fuel injection systems, electronic ABS systems (anti-lock-systems), electronic speed control systems, air bag systems) affect

For your vehicle information, please contact your vehicle manufacturer or its representative. You should also ask for the manufacturers of devices that were subsequently fitted in your vehicle.

Information

Information about the IC Caution.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le

brouillage est susceptible d'en compromettre le fonctionnement.

certification (FCC):

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur particular installation. Τf equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

This device was tested for typical bodyworn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

Limitation of liability:

- JETHRO declines all responsibility for injury-related, indirect, special, resulting from an accident or unavoidable, as the predictable viewed or not viewed can be.
- We reject all responsibility and liability for losses caused by natural disasters (such as earthquake, flood, etc.) or other incident or accident (including deliberate or accidental misuse by the manufacturer in the framework of these accidents or other unusual circumstances) that lie outside of our liability.

More information

If you have any questions or want to get more information about one of our devices in experience, please check our Web site www.jethroshop.com or contact us at Email: Jethro@jethroshop.com

Contact us:

Jethro Trading Ltd. 4152 Meridian Street STE105 #602 Bellingham, WA United States Toll Free: 1-888-509-6199



Company website: www.jethroshop.com

IC ID: 11350ASC330 FCC ID: 2AAWJSC330

Tested to comply

with FCC certification V.3.0