



ELECTRIC TOY: Not recommended for children under 1½ years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

Kawasaki® ZX-7

Owner's Manual with Assembly Instructions

Please read this manual and save it with your original sale's receipt.

For Model 78410

Tools needed for assembly: Phillips Screwdriver, Slotted Screwdriver, Hammer, Safety Scissors.

Use only with Power Wheels® Type H Battery, Power Wheels® 25 Amp Fuse and Power Wheels® Type H 6 Volt Charger (all included).

Throughout this manual you will find important messages in the form of **WARNINGS, CAUTIONS, and NOTES.**

 **WARNING**

WARNING – SIGNALS SOMETHING THAT COULD HURT YOUR CHILD OR YOU. The message explains the hazard and how you can avoid it.

 **WARNING**

- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Keep small parts and plastic bags out of children's reach. Dispose of plastic bags properly.
- Adult supervision is required. Children do not have the judgement necessary to avoid many accidents. Be sure that children operating this vehicle can do so safely and that they are supervised at all times.
- Improper use of this vehicle could lead to a serious or fatal accident. Allow children to play with the **Kawasaki® ZX-7** only when you have determined that they can do so safely. Follow all instructions to help your child enjoy this vehicle as safely as possible.
- Never use on or dangerously close to steps, inclines greater than 10°, roadways, bodies of water, low obstructions or in the dark.
- Always wear shoes or sneakers when operating this vehicle.
- Never allow more than one rider.
- The rider should sit on the seat when the vehicle is in motion.
- Observe the maximum weight limit of 50 lbs.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.
- The battery must be handled by adults only.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in serious injury. Read the cautions on the back panel of the battery.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the vehicle until you have replaced the worn or damaged part.

 **CAUTION**

CAUTION – SIGNALS SOMETHING THAT
COULD DAMAGE THE VEHICLE.

The message explains the risk and
how you can avoid it.

NOTE – Is used to highlight
useful information.

 **CAUTION**

- Do not operate the vehicle for the first time until you have inserted the 25 amp fuse into the battery and charged the battery for at least 18 hours. Never charge the battery longer than 30 hours.
- After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
- Use the charger indoors only.
- Read and follow the Battery Care instructions on page 26. Failure to follow the Battery Care instructions may permanently damage your battery and will void your warranty.
- To avoid damaging the motor and gears, do not overload the vehicle.
 - Never allow more than one child on the vehicle at one time.
 - Do not exceed the maximum weight capacity of 50 lbs.
 - Do not tow anything behind the **Kawasaki® ZX-7**. The extra weight may overload the vehicle.
- Avoid operating the vehicle in wet or snowy conditions, and do not spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture in the motor or electrical switches can cause them to corrode, and could cause switch failure.
- Avoid operating the vehicle on grass, sand, loose dirt or gravel. Sand, loose dirt and gravel in the electrical switches or motor can cause them to jam, and could cause switch failure. Use the **Kawasaki® ZX-7** on asphalt, cement or other hard surfaces.

Table of Contents

A	Message to Parents	.4
B	Important Information	.5
C	Parts	.6
D	Parts Diagram	.8
E	Parts List	.9
F	First-Time Battery Charging	.10
G	Assembly	.12
H	Battery Installation	.21
I	Charging the Battery	.24
J	Battery Handling/Care/Disposal	.26
K	Rules for Safe Driving	.27
L	How to Operate Your Vehicle	.28
M	Questions and Answers	.29
N	Problems and Solutions Guide	.30
O	Statement of Limited Warranty	.35
P	Authorized Service Centers	.35

A

Message to Parents

Thank you for purchasing the Power Wheels® **Kawasaki® ZX-7!** For over 30 years, Power Wheels® has manufactured high-quality, battery-powered vehicles for children. Our goal is to provide your child with an enjoyable and safe driving experience. To help achieve this goal, it is extremely important that you read this entire manual and share the appropriate information with your child.

The **Kawasaki® ZX-7** requires adult assembly. Please set aside at least 30 minutes for assembly. Read the assembly instructions carefully and identify all parts before assembly. Refer to the Parts Section beginning on page 6 for parts identification. Save all packaging material until assembly is complete to ensure that no parts are discarded.

In the unlikely event that parts are missing or damaged or if you have any questions about your Power Wheels® vehicle, please call our Consumer Affairs toll-free service lines, open from 8 AM to 6 PM (EST) Monday through Friday.

Please call us at 1-800-348-0751.

Trained customer service representatives are available to take your call in English or French.

¿Habla Español? Si usted tiene alguna pregunta ó necesita asistencia llame gratis 1-800-348-0755 para los Estados Unidos. Tenemos representantes que hablan español para atender su llamada. Este manual tambien disponible en Espanol.

We also have a nationwide Authorized Service Center network – with over 300 Authorized Service Centers. Our Authorized Service Centers will repair or replace parts under warranty at no charge. For vehicles beyond warranty, our Authorized Service Centers will perform repairs for a minimal charge. For the Authorized Service Center nearest you, please see the Authorized Service Center listing beginning on page 35.

B


Important Information

- Carefully read this manual for important safety information and operating instructions before using your vehicle.
- Please complete and return the enclosed Vehicle Registration Card, or call **1-800-348-0751** to register your vehicle by phone.
- The **Kawasaki® ZX-7** is designed for use by children 1½- 4 years.
- Adult assembly is required.
- This vehicle uses a Power Wheels® Type H battery with a Power Wheels® 25 amp fuse and a Power Wheels® Type H 6 volt charger (120 VAC 60 HZ 28W with an output of 6 VDC 1200 mA). **Do not** substitute any other battery, fuse or charger.
- **Before first-time use, charge the battery for at least 18 hours. Never charge the battery longer than 30 hours.**
- After the first charge, charge the battery a minimum of 18 hours after each use. Never charge the battery longer than 30 hours.
- Do not run down the battery completely before charging.
- Leaving the battery in a discharged condition will ruin it.
- Charge the battery before storing your vehicle.
- Charge the battery at least once per month, even if the vehicle has not been used.
- Do not store the battery in temperatures above 75° F or below -10° F.
- Even with proper care, the battery will not last forever. The life of the battery depends on how well you follow the Battery Care instructions and the total number of hours the battery is used. Please refer to the Battery Handling/Care/Disposal instructions on page 26 for detailed information about battery care.
- To purchase a Power Wheels® Type H battery, Power Wheels® 25 amp fuse or a Power Wheels® Type H 6 volt charger, please contact:
 - the store where your vehicle was purchased.
 - an Authorized Service Center (see Authorized Service Center list beginning on page 35).
 - Power Wheels® Consumer Affairs at **1-800-348-0751**.
- While the battery is charging, the charger may become warm to the touch. This is normal, and does not indicate a problem.
- The **Kawasaki® ZX-7** is suitable for use on asphalt, cement or other hard surfaces. To prevent damage to the motor and switches, do not operate the vehicle on loose dirt, gravel or sand.
- The **Kawasaki® ZX-7** is not designed for use on grass or hills. For best traction, use only on asphalt, cement, or other flat, hard surfaces.
- To prevent damage to electrical components, store the **Kawasaki® ZX-7** inside or under a protective cover during snowy or rainy weather. Do not leave the **Kawasaki® ZX-7** out in the rain or let your child wash it with soap and water.
- The **Kawasaki® ZX-7** has a special circuit-breaker in the wiring to protect the motor and electrical system. If the vehicle is put under extreme load (driving on rough surfaces, too much weight, climbing too steep of an incline), the circuit-breaker will shut the electrical system down for up to 20 seconds. If the system repeatedly shuts down, the driving conditions may be too demanding (ie: too steep or too much weight).
- Metal parts have been coated with a lubricant to protect them during shipment. Wipe all metal parts with a paper towel to remove any excess lubricant.


C

Parts


If you experience a problem with this product, or are missing a part, please call us at **1-800-348-0751**, rather than return this product to the store.
Please save all packaging material until assembly is complete to ensure that no parts are discarded.




Dashboard




6 Volt Charger




Small Parts Bag




Hand Grips - 2




Shock Set - 1




Microphone




Headlight Lens Set




Battery Retainer



Fender



Windshield



Hubcap - 2

Not Shown:
Literature Bag

Parts



Cap Nut - 3*




Radio Knob - 2



Handlebar Plug - 2




Wheel Bushing - 2




Gas Cap



25 Amp Fuse - 2*



Key Assembly




#8 x 1 1/2" Screw - 4



#8 x 7/8" Screw



#8 x 3/4" Screw - 4



#6 x 3/8" Screw - 2

All Screws Shown
Actual Size

*For your convenience, an extra 25 amp fuse and cap nut have been included.




Right Handlebar




Left Handlebar




Front Axle




Front Wheel




Vehicle Body



Fairing




Seat



6 Volt Battery

Not Shown: Label Sheets

Parts Diagram



Kawasaki® ZX-7

FOR MODEL 78410
6 VOLT

E

Parts List

Note: The parts listed below are not all consumer assembled. Consumer assembled parts are shown on pages 6 and 7 and are highlighted in bold type below.

Item No.	Description	Part No.	Qty.	Parts Not Shown
1	Battery	80008-0110	1	#6 - 20 x 1" Screw for Swivel Bracket 80006-0034 1
2	25 amp Fuse	80014-0070	1	1 1/4" Screw for Flex Plate 80006-0022 2
3	Wheel Driver Screw	80006-0017	1	Handlebar Plugs 80047-0026 2
4	Foot Switch	80014-0022	1	Literature Bag 80034-0772 1
5	Motor/Gearbox Assembly	74780-0640	1	Adhesive Harness Clip 80023-0088 1
6	Wiring Harness	80064-0083	1	Main Decal Sheet 80017-0458 1
7	Driver	80001-0247	1	Paper Decal Sheet 80017-0457 1
8	Windshield	80063-0068	1	Headlight Decal Sheet 78410-0300 1
9	Lens Cover Set	80030-0074	1	
10	.354 Retainer w/Body	80047-0104	2	
11	7/16" Washer	80061-0039	2	
12	1 1/2" Screw	80006-0175	5	
13	Handgrip	80028-0016	2	
14	Right Handlebar	80029-0020	1	
15	Shock Set	80001-0435	1	
16	Front Axle	80025-0027	1	
17	.437 Retainer w/Body	80047-0106	4	
18	Front Hubcap	80033-0077	2	
19	Wheel Spacer	80009-0060	5	
20	Front Wheel	80062-0036	1	
21	Footboard Cover	80023-0033	1	
22	Foot Pedal w/Spring Clip	80041-0004	1	
23	Rear Wheel	80062-0047	2	
24	Rear Hubcap	80033-0076	2	
25	Motor Cover	80039-0052	1	
26	Rear Axle	80046-0090	1	
27	Axle Spacer Tube	80052-0012	1	
28	Body	80005-0340	1	
29	Trunk Lid	80001-0511	1	
30	Battery Retainer	80047-0022	1	
31	7/8" Screw	80006-0173	1	
32	Seat	80067-0064	1	
33	Gas Cap	80001-0512	1	
34	Pivot Pin	80006-0027	1	
35	Left Handlebar	80029-0041	1	
36	Key Housing	80001-0281	1	
37	Fairing	80063-0122	1	
38	Microphone	80038-0009	1	
39	3/8" Screw	80006-0171	2	
40	Dash	80016-0047	1	
41	Swivel Bracket	80007-0005	1	
42	3/4" Screw	80006-0172	4	
43	Fender	80022-0065	1	
44	Motor	80039-0043	1	
45	Drive Gear Metal	80026-0098	1	
46	Gearbox	80026-0056	1	
47	Lock Fastener	80001-0622	1	
48	Motor Bolt	80006-0052	2	
49	Flex Plate	80001-0305	1	
50	Rectangular Wheel Bushing	80009-0052	2	
51	1" Screw	80006-0032	1	
52	Radio Knobs	80045-0025	2	

F

First-Time Battery Charging

We recommend that you begin charging your battery before beginning assembly of your vehicle. **Your new battery must be charged for at least 18 hours before using your vehicle for the first time.**



WARNING


- The battery must be handled by adults only.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the charger or the vehicle until you have replaced the worn or damaged part.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.



CAUTION


- Do not operate the vehicle for the first time until you have inserted a 25 amp fuse into the battery and charged the battery for at least 18 hours. Never charge the battery longer than 30 hours.
- Read and follow the Battery Care instructions on page 26. Failure to follow the Battery Care instructions may permanently damage your battery and may void your warranty.
- Use the charger indoors only.

First-Time Battery Charging




1

- Insert the 25 amp fuse into the battery.



2

- Squeeze the Lock-In™ connector tabs on the charger connector and plug it into the battery connector.



3

- Plug the charger into a standard 120 volt wall outlet.
Note: If power flow to the wall outlet is controlled by a switch, make sure the switch is "ON".
- Before first time use, charge the battery for **at least 18 hours**. Never charge the battery longer than 30 hours.
Note: The battery must be upright while charging.

G



Assembly

Do Not Omit Any Steps. Please set aside at least 30 minutes for assembly.




WARNING

- Children can be harmed by small parts, sharp edges and sharp points in the vehicle's unassembled state, or by electrical items. Care should be taken in unpacking and assembly of the vehicle. Children should not handle the battery or other parts, or help in assembly.
- Keep small parts and plastic bags out of children's reach. Dispose of plastic bags properly.



1

- Position a handlebar plug against the top end of a handlebar.
- Moisten a hand grip with warm water.
- Slide the hand grip onto the end of the handlebar.
- Repeat this procedure to attach the other handlebar plug and handgrip to the other handlebar.




2

- Stand the vehicle body on its rear wheels.
- Slide the left handlebar through the holes in the left side of the swivel bracket.

Please Note: The left handlebar is marked "L"; the right handlebar is marked "R".

Assembly




3




#8 x $\frac{3}{4}$ " Screw – 2
Shown Actual Size

- Align the screw holes in the left side of the swivel bracket with the screw holes in the left handlebar.
- Insert two #8 x $\frac{3}{4}$ " screws into the left handlebar.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.
- Repeat steps 2 and 3 to assemble the right handlebar to the vehicle body.



4


- Apply labels to the dashboard as shown.
- Make sure the areas where the labels will be applied are clean and dry.
- For best adhesion, avoid applying labels more than once.



5

- Snap the key assembly and radio knobs into the dashboard.
- Please Note:** Gently squeeze the tabs on the radio knobs together before inserting the knobs into the dashboard.
- Insert the microphone cord through a hole in the dashboard, as shown. Make sure the end of the microphone cord forms a "T" behind the dashboard so that it stays secure in the dashboard.

Assembly




6



#8 x 1 1/2" Screw - 2
Shown Actual Size


- Lay the vehicle body on its belly.
- Fit the dashboard onto the top of the swivel bracket.
- Align the screw holes in the dashboard and swivel bracket.
- Insert two #8 x 1 1/2" screws into the dashboard.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.




7

- Insert the four tabs on the underside of the windshield into the holes in the fairing.
- Press firmly on the windshield to fit the tabs into the holes.

Assembly




8



#6 x $\frac{3}{8}$ " Screw – 2
Shown Actual Size

- Turn the fairing over.
- Insert two #6 x $\frac{3}{8}$ " screws into the holes in the two long windshield tabs.
- Tighten each screw with a Phillips screwdriver. Do not over-tighten.




9



#8 x $1\frac{1}{2}$ " Screw – 2
Shown Actual Size


- Stand the vehicle body on its rear wheels.
- Fit the fairing onto the front of the swivel bracket.
- Align the screw holes in the front of the fairing with the holes in the swivel bracket.
- Insert two #8 x $1\frac{1}{2}$ " screws into the fairing.
- Tighten the screws with a Phillips screwdriver. Do not over-tighten.

Assembly





10

- Fit the fender onto the ends of the handlebars.
- Slide the fender up the handlebars to the fairing.



11

- Fit one end of the front axle into a cap nut.
- Tap the front axle with a hammer to secure the cap nut on the front axle.




12

- Remove the rubber bands from the shock sets and dispose of the rubber bands.
- Using safety scissors, cut the four shock set halves from the runner. Carefully trim excess plastic and dispose of the runner and all excess plastic.
- Sort the shock halves into inner shock halves and outer shock halves.


Please Note: The inner shock halves have an extension.

Assembly




13

- Fit and hold an inner shock half to the inside of a handlebar.
- Fit and hold an outer shock half to the outside of the same handlebar.
- Make sure the top ends of the shock halves fit into the fender.



14


- Slide the front axle through the hole in the shock halves and handlebar.



15


- Fit a wheel bushing into the hole in the center of the front wheel.
- Repeat this procedure to fit the remaining wheel bushing into the hole on the other side of the front wheel.

Assembly




16

- Fit and hold the hubcaps to each side of the front wheel.
- Make sure the posts on the inside of the hubcaps fit into the indentations on the front wheel, so that the hubcaps lay flat against the wheel.



17


- Position the front wheel between the handlebars.
- Slide the front axle through the front wheel.



18


- Fit and hold an inner shock half to the inside of the exposed handlebar.
- Fit and hold an outer shock half to the outside of the same handlebar.
- Make sure the top ends of the shock halves fit into the fender.

Assembly




19

- Slide the front axle through the handlebar.
- Fit the remaining cap nut on the end of the front axle.
- Support the front axle and tap the cap nut with a hammer to secure it on the end of the front axle.



20


- Position the vehicle upright.
- Apply headlight labels to the fairing as shown.
- Make sure the areas where the labels will be applied are clean and dry.
- For best adhesion, avoid applying labels more than once.



21

- Align the "L" on the left headlight lens with the "L" in the left headlight on the fairing.
- Insert the tabs on the headlight lens into the slots in the fairing.
- Press firmly to snap the headlight lens into the fairing.
- Repeat this procedure to assemble the right headlight lens (marked "R") to the fairing.

Assembly





22

- Snap the gas cap into the vehicle body.



23

- Insert the tabs on the front of the seat into the vehicle body.
- Lower the seat.



24

Proper label application will help to keep the labels looking their best!

- Wash your hands before applying the labels.
- Make sure the areas where the labels will be applied are clean and dry. Wipe your vehicle with a clean, soft, **dry** cloth to remove any dust or oils.
- For best results, avoid applying a label more than once.
- Apply the labels as shown in the illustrations.
- After applying a label, rub the label firmly with a dry cloth to make sure the label is adhered to your vehicle.


One-time assembly is now complete.

Important Note: Please carefully read the owner's information in this manual and teach your child about proper vehicle operation and rules for safe driving before allowing him to drive this vehicle.

H


Battery Installation

Important Note: Use only a Power Wheels® Type H 6 volt battery with a Power Wheels® 25 amp fuse installed. Use of any other battery or fuse will damage your vehicle. Make sure that you charge the battery for at least 18 hours before operating your vehicle for the first time. After first time use, charge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours. Failure to follow these instructions may damage your battery and will void your warranty.




1

- Lift the seat to access the battery compartment.



2

- Place the battery upright in the battery compartment. **Make sure the battery connector extends towards the rear of the vehicle.**
- Make sure a Power Wheels® 25 amp fuse in good condition is installed in the battery.



3

- Insert the ends of the battery retainer into the holes in the battery compartment.

Battery Installation

4





#8 x $\frac{7}{8}$ " Screw – 1
Shown Actual Size

- Lower the battery retainer over the top of the battery.
- Insert a #8 x $\frac{7}{8}$ " screw through the battery retainer and into the battery compartment.


5

- Squeeze the tabs on each side of the motor harness connector.
- Plug the battery connector into the motor harness connector.

Please Note: If the battery connector will not plug into the motor harness connector, turn it over and try again! Do not force the battery connector into the motor harness connector.




Battery Installation



6

- Lower the seat.

Note: Make sure the tabs on the lock fastener are aligned with the notches in the lock fastener opening.




7

- Rotate the lock fastener $\frac{1}{4}$ turn using a slotted screwdriver to lock the battery compartment.
- To make sure the lock fastener is locked, insert the blade of the screwdriver under the back of the seat and push down on the screwdriver handle. The seat should not lift.

Charging the Battery

WARNING

- The battery must be handled by adults only.
- Never allow children to charge the battery. Battery charging must be done by adults only. A child could be injured by the electricity involved in charging the battery.
- Use of the wrong type battery, fuse or charger could cause a fire or explosion, resulting in serious injury.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped could result in serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage or excessive wear is detected, do not use the vehicle until you have replaced the worn or damaged parts.
- Never alter this vehicle or its electrical system in any way. Alterations could cause a fire resulting in injury and could also ruin the electrical system.
- Never add unauthorized parts to the vehicle or use substitute parts. Use only specified Power Wheels® replacement parts.







CAUTION

- Read and follow the Battery Care instructions on page 26. Failure to follow the Battery Care instructions may permanently damage your battery and will void your warranty.
- Use the charger indoors only.

Charging the Battery

Important Note: The battery must be upright while charging. You do not have to remove the battery from the vehicle to charge it.



1

- Rotate the lock fastener on the seat back $\frac{1}{4}$ turn using a slotted screwdriver to unlock the battery compartment.
- Lift the seat to access the battery.
- Use pliers to remove the fuse from the battery.
- Visually examine the fuse to make sure it is not blown. If the fuse has blown, replace it with a new Power Wheels® 25 amp fuse.
- Reinsert the fuse into the battery before charging. The battery will not charge if a 25 amp fuse in good condition is not inserted into the battery.

2

- Squeeze the tabs on the motor harness connector to unplug it from the battery connector.

3

- Squeeze the tabs on the charger connector to plug it into the battery connector **1**.
- Plug the charger into a standard 120 volt wall outlet **2**.
- Note:** If power to the outlet is controlled by a wall switch, make sure the switch is "ON".
- Charge the battery a minimum of 18 hours. Never charge the battery longer than 30 hours. Overcharging or undercharging the battery may shorten battery life and decrease vehicle running time.
- Once the battery is charged, reconnect the battery connector and motor harness connector and lower the seat.
- Note:** Remember to lock the lock fastener to prevent children from accessing the batteries.

J

Battery Handling/Care/Disposal

WARNING

- The battery must be handled by adults only.
- Never permit a child to handle the battery. The battery is heavy and contains sulfuric acid (electrolyte), and if dropped, could result in a serious injury. Read the cautions on the back panel of the battery.
- Never lift or carry the battery by the wires or connector. This can damage the battery and possibly cause a fire. Lift and carry the battery by the case only.

CAUTION

- Carefully read the Battery Care instructions to obtain the best battery life. Failure to follow the Battery Care instructions may damage your battery and will void your warranty.

Handling

If a battery leak develops:

- Avoid contact with the leaking acid.
- Place the damaged battery in a plastic bag. See information below for proper disposal.

If acid comes in contact with skin or eyes:

- Flush with cool water for at least 15 minutes.
- Call a physician.

If acid is internally ingested:

- Give water, milk of magnesia or egg whites immediately.
- Never give emetics or induce vomiting.
- Call a physician.

Disposal

- The sealed lead-acid battery must be collected, recycled or disposed of in an environmentally sound manner.
- Do not dispose of the lead-acid battery in your regular, household trash. The incineration, landfilling or mixing of a sealed lead-acid battery with household trash is prohibited by law in most areas.
- Return the battery to a federal or state approved lead-acid battery recycler, such as a Power Wheels® Authorized Service Center or a local seller of automotive battery. In Minnesota, call 1-800-348-0751 if further disposal information is required. Contact your local waste management officials for other information regarding the environmentally sound collection, recycling and disposal of lead-acid batteries.

Care

- Charge a new battery for at least 18 hours before first use. Never charge the battery longer than 30 hours. Overcharging or undercharging the battery may shorten battery life and decrease vehicle running time.
- After the first charge, charge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
- Charge the battery after each use, regardless of how long the vehicle was used.
- The battery must be upright while charging.
- Do not allow the battery to run down completely before charging.
- Charge the battery before storing the vehicle.
- Charge the battery at least once per month, even if the vehicle has not been used.
- Leaving the battery in a discharged condition will ruin it.
- Do not store the battery in temperatures above 75° F or below -10° F.
- Prevent the battery from moving freely inside the battery compartment. Always use the battery retainer to secure the battery in the battery compartment.
- Examine the battery, charger and their connectors for excessive wear or damage each time you charge the battery. If damage is detected, do not use the charger or the battery until you have replaced the worn or damaged part.
- Charging the battery without a fuse or with a blown fuse will not damage the battery, but the battery will not charge. Check the fuse to make sure it is in good condition each time you charge the battery.

K

Rules for Safe Driving

WARNING

- Adult supervision is required. Children do not have the judgement necessary to avoid many accidents. Be sure that children operating this vehicle can do so safely and that they are supervised at all times.
- Never use on or dangerously close to steps, inclines greater than 10°, roadways, bodies of water, low obstructions or in the dark.
- Always wear shoes or sneakers when operating this vehicle.
- Never allow more than one rider.
- The rider should sit on the seat when the vehicle is in motion.
- Improper use of this vehicle could lead to a serious or fatal accident. Allow children to play with the **Kawasaki® ZX-7** only when you have determined that they can do so safely. Follow all instructions to help your child enjoy this vehicle as safely as possible.

CAUTION

- To avoid damaging the motor and gears, do not overload the vehicle.
 - Never allow more than one child on the vehicle at one time.
 - Do not exceed the maximum weight capacity of 50 lbs.
 - Do not tow anything behind the **Kawasaki® ZX-7**. The extra weight may overload the vehicle.
- Avoid operating the vehicle in wet or snowy conditions, and do not spray the vehicle with a hose. Do not wash the vehicle with soap and water. Water or moisture in the motor or electrical switches can cause them to corrode, and could cause switch failure.
- Avoid operating the vehicle on sand, loose dirt or gravel. Sand, loose dirt and gravel in the electrical switches or motor can cause them to jam, and could cause switch failure. Use the **Kawasaki® ZX-7** on asphalt, cement or other hard surfaces.

Teach Safety Rules to Children


While children can quickly develop the skill necessary to drive this vehicle, it is important to remember that their judgment skills are still very immature. Unsupervised driving by children can lead to serious injury. Before children use the **Kawasaki® ZX-7**, an adult should carefully evaluate the driving area as well as the children's skill level and ability to drive this vehicle safely. Children are not always able to recognize or anticipate hazards, even when they have been taught about them. There is no acceptable substitute for adult supervision.

Teach appropriate safety rules to your child before you allow her to operate this vehicle. These rules should also be reviewed with neighborhood children or other playmates who want to drive or ride in this vehicle.

1. Do not allow any child to drive the vehicle in the street or near moving (motorized) vehicles.
2. Do not allow any child to drive near bodies of water (such as pools or creeks), obstructions (such as furniture, low tree limbs or play equipment), or drop-offs (such as stairs or decks).
3. Do not allow any child to drive the vehicle in the dark. A child could encounter unexpected obstacles and have an accident. Operate the vehicle only in the daytime or in a well-lit area.
4. Teach your child to avoid driving on steep inclines or slopes. Restrict your child's driving to areas that are fairly level with gentle inclines or slopes of no more than 10°.
 - While driving down a steep slope, the vehicle may gain unsafe speed, even if the foot pedal is released to stop.


Rules for Safe Driving

- While driving across a steep slope, the vehicle may tilt and tip over. The wheels could lose traction causing the vehicle to slip.
- While driving up a steep incline, the motor may stop and the vehicle could roll backwards at an unsafe speed.





5. Operate this vehicle with one rider seated on the seating area. A child who is not sitting on the seat or who is standing on the vehicle could fall off or cause a tip-over. A child could be seriously injured.
6. Always wear shoes or sneakers when operating this vehicle.
7. Never put anything near any moving parts. Rotating parts such as the motor, gear boxes and wheels can snag fingers, hair, etc., causing serious injury. Do not allow operation of the vehicle when it is on its side or in an upside-down position.

8. Do not operate the vehicle near flammable vapors (gasoline, paint thinner, acetone, liquid wax, etc.). The vehicle's electrical switches, like most electrical switches, emit an internal spark when first turned on. The presence of flammable liquids or vapors could cause an explosion or a fire. Keep all flammable products in tightly sealed containers and away from the vehicle.
9. Do not allow a child to operate the vehicle without proper adult supervision. To prevent unsupervised use of the vehicle, disconnect the motor harness from the battery.
 - Rotate the lock fastener $\frac{1}{4}$ turn with a slotted screwdriver to unlock the battery compartment.
 - Raise the seat to access the battery.
 - Squeeze the tabs on the motor harness connector to unplug the battery connector from the motor harness connector.
 - Lower the seat and rotate the lock fastener $\frac{1}{4}$ turn with a slotted screwdriver to lock the battery compartment.



L

How to Operate your Vehicle



- Press down on the foot pedal to drive.
- Lift your foot from the foot pedal to stop. Your **Kawasaki® ZX-7** has a patented, electronic braking system that automatically stops the vehicle when your child's foot is lifted from the pedal.
- Help your child practice steering and stopping so that he knows how far and how quickly to turn the handlebars, and how to stop easily.

M

Questions and Answers

Q. How often do I need to charge the battery?

A. Charge the battery for a minimum of 18 hours after each use of the vehicle or whenever the vehicle begins to slow down. When the vehicle is not in regular use, charge the battery at least once a month until normal use is resumed.

Q. How much riding time should I get after charging the battery?

A. You should get from one to three hours of riding time per charge. The riding time is affected by:

- the driving surface,
- passenger weight,
- the charge of the battery,
- whether the vehicle is used intermittently or continuously,
- condition of the electrical switches and connectors,
- the temperature.

Q. What is the life expectancy of the battery?

A. Battery life will vary depending on how well you follow the Charging and Battery Care instructions. It's also affected by the total number of hours the battery is used. Average battery life is one to three years.

Q. Does the fuse have to be inserted into the battery when I'm charging?

A. Yes! The battery must have a good fuse installed when charging and during use. If the fuse is missing, blown or if you are using the wrong type of fuse, the battery will not charge.

Q. How can I tell if the fuse is blown?

A. Use pliers to remove the fuse from the battery and compare the fuse to the illustration on page 25.

Q. How can I tell if the charger is working?

A. There is no sure way to tell if your charger is working unless you have a volt meter. If you suspect there is a problem with your charger, contact your local Power Wheels® Authorized Service Center. They can test your charger for you.

Q. How and when should I store my vehicle?

A. During snowy or rainy weather, the vehicle should be stored inside or under a protective cover. Remember to charge the battery at least once per month while your vehicle is not in regular use.

Q. How should I care for my vehicle?

The vehicle can be wiped down with a soft, dry cloth. For a shiny finish, you can wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not use automotive wax. Do not use soap and water or spray the vehicle with a hose.

To ensure that your vehicle stays in good operating order, we recommend that you periodically have your vehicle checked by a Power Wheels® Authorized Service Center. See page 35 for the list of Authorized Service Centers or call 1-800-348-0751 for the location of the Authorized Service Center nearest you.

Q. If I have a problem that I can't solve myself, what should I do?

A. Power Wheels® has over 300 Authorized Service Center locations. They can repair vehicles under warranty, or out of warranty, or sell you the proper parts for you to do the repair work. These service centers have factory-trained personnel, and use only genuine Power Wheels® replacement parts. If there is not an Authorized Service Center in your area, please call Power Wheels® Consumer Affairs toll-free at: **1-800-348-0751**.

N

Problems and Solutions Guide

IMPORTANT! If you experience a problem with your vehicle, first check the Problems and Solutions Guide below. If you still experience a problem, please contact Power Wheels® Consumer Affairs, toll-free at **1-800-348-0751** between 8 AM and 6 PM (EST) Monday through Friday. Or, contact your local Power Wheels® Authorized Service Center. For the location nearest you, please refer to the Authorized Service Center list beginning on page 35.

Problem	Possible Cause	Solution
Vehicle does not run	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
		Check all connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse before charging. For best performance, do not use substitute parts.
	Blown fuses	Make sure that the fuse in the battery is in good condition. Replace a blown fuse with a Power Wheels® 25 amp fuse. For best performance, do not use substitute parts.
	Loose wire or loose connectors	Check all wires and connectors. Make sure the battery connector is tightly plugged into the motor harness connector.
	Dead battery	If your battery is old or if you have not followed Battery Care instructions, your battery may be dead. If you are unsure whether or not the battery is dead, you can have it tested at your local Power Wheels® Authorized Service Center.
	Electrical switch damage	The electrical switches can become corroded due to exposure to water or moisture, or can jam due to loose dirt, sand or gravel. Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
Motor damage	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.	

Problems and Solutions Guide

Problem	Possible Cause	Solution
Vehicle was running but suddenly stopped	Loose wire or loose connectors	Check all wires and connectors. Make sure the battery connector is tightly plugged into the motor harness connector.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Blown fuse	Make sure that the fuse in the battery is in good condition. Replace a blown fuse with Power Wheels® 25 amp fuse. For best performance, do not use substitute parts.
	Vehicle is overloaded	Make sure you do not overload the vehicle by allowing more than 1 rider at one time, by exceeding the 50 lbs. maximum weight capacity, or by towing objects behind the vehicle. If the vehicle is overloaded, it will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Reduce the load on the vehicle to prevent additional automatic shut-downs.
	Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.
Short run time (Less than 1 hour in high speed; less than 3 hours in low speed)	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
		Check all wires and connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".
	Overcharged battery	Do not charge the battery longer than 30 hours.
	Battery is old and will not accept full charge	Even with proper care, rechargeable batteries do not last forever. Average battery life is 1 to 3 years depending on vehicle use and use conditions. Replace the battery with a Power Wheels® Type H 6 volt battery. For best performance, do not use substitute parts.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.

Problems and Solutions Guide

Problem	Possible Cause	Solution
Vehicle runs sluggishly	Undercharged battery	Charge the battery. A new battery should have been charged for at least 18 hours before using the vehicle for the first time. After first-time use, recharge the battery for at least 18 hours after each use. Never charge the battery longer than 30 hours.
		Check all connectors. Make sure the battery connector is tightly plugged into the charger connector, and that the charger is plugged into the wall.
		Make sure power flow to the wall outlet is "ON".
	Battery needs charging	After approximately 3 hours of constant use, the battery needs charging.
	Wrong type or improperly installed fuse	Make sure that the battery has a properly installed Power Wheels® 25 amp fuse installed before charging. For best performance, do not use substitute parts.
	Battery is old and will not accept full charge	Even with proper care, a rechargeable battery will not last forever. Average battery life is 1 to 3 years depending on the vehicle use and use conditions. Replace the battery with a Power Wheels® Type H 6 volt battery. For best performance, do not use substitute parts.
	Vehicle is overloaded	Make sure you do not overload the vehicle by allowing more than 1 rider at one time, exceeding the 50 lbs. maximum weight capacity, or by towing objects behind the vehicle. If the vehicle is overloaded, it will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Reduce the load on the vehicle to prevent additional automatic shut-downs.
Driving conditions are too stressful	Use only on gentle inclines or slopes of 10° or less. Extreme temperatures can also affect run time. If the driving conditions are too stressful, the vehicle will automatically shut down. The vehicle will reset itself after approximately 20 seconds. Adjust the driving conditions to prevent additional automatic shut-downs.	

Problems and Solutions Guide

Problem	Possible Cause	Solution
Sometimes the vehicle doesn't run, but other times it does	Loose wire or connector	Check all wires around the motor and all connectors to make sure they are tight.
	Motor or electrical switch damage	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
When the foot pedal is pressed, the vehicle won't run without a push	Loose wire or connector	Check all wires around the motor and all connectors to make sure they are tight.
	"Dead Spot" on motor	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
Vehicle constantly blows fuses	Wrong type of fuse used	Make sure a Power Wheels® 25 amp fuse is properly installed in the battery. For best performance, do not use substitute parts.
Loud clacking or grinding noise from a motor-gearbox	Broken gears	Contact your local Power Wheels® Authorized Service Center for diagnosis and repair.
Charger gets warm during use	It is normal for some chargers to get warm during use and is not reason for concern. Some chargers do not get warm during use.	No action required.
		If your charger does not get warm during use, it does not mean that it is not working properly.
Battery makes a sizzling or gurgling noise when charging	It is normal for some batteries to make noise and swell slightly while charging and is not reason for concern. Some batteries do not make noise or swell while charging.	No action required.
		If your battery does not make noise or swell slightly during charging, it does not mean that it is not accepting the charge.

If, after reviewing the Problems and Solutions Guide, the vehicle still fails to operate, please contact your nearest Authorized Service Center (see page 35) or contact Power Wheels Consumer Affairs toll-free at **1-800-348-0751**.

Helpful Hint: For faster service when calling Consumer Affairs, completely charge the battery before calling and have the following available by the phone:

- vehicle,
- vehicle model number (see sticker in battery compartment),
- vehicle production run number (see sticker in battery compartment),
- Phillips screwdriver, slotted screwdriver and needle-nose pliers with plastic or rubber handles,
- extra Power Wheels® 25 amp fuses are helpful.

O

Statement of Limited Warranty

90-day limited warranty for the Power Wheels® Ride-On Toy Vehicle

A 6-month battery warranty applying only to those 6-volt battery which was included by Power Wheels®, with the Power Wheels® vehicle when originally purchased.

This limited warranty covers the Power Wheels® ride-on vehicle and the 6-volt battery, purchased from Power Wheels® by the original purchaser, against defects in materials and workmanship.

This warranty covers normal use and does not cover the Power Wheels® vehicle or battery if damaged by unreasonable use, neglect, accident, abuse, misuse, improper service or other causes not arising out of defects in materials or workmanship. Evidence of any attempt at consumer repair will void this warranty. This warranty does not cover, and is intended to exclude, any liability on the part of Power Wheels®, whether

under this warranty or implied by law or any indirect or consequential damages for breach of warranty. Some states do not allow the exclusion or limitation so this limitation may not apply to you.

Should you need service or assistance with your vehicle during the warranty period, DO NOT RETURN THE VEHICLE TO THE STORE. Power Wheels® has provided a nationwide network of Authorized Service Centers. Please refer to the list in this manual. Power Wheels® is continually expanding our Authorized Service Center network. If there is not an Authorized Service Center in your area, please call Consumer Affairs for information, 1-800-348-0751.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

PLEASE SAVE YOUR ORIGINAL SALE'S RECEIPT.

P

Authorized Service Centers

We are continually expanding our Authorized Service Center Network. Please check this listing for the Authorized Service Center nearest you. If there is not one in your area, please call Power Wheels® Consumer Affairs at 1-800-348-0751.

ALABAMA

BIRMINGHAM - Frigid Service & Sales, 701 Graymont Ave. North, 35203, (205) 323-5831
BIRMINGHAM - Frigid Service & Sales, 1861 Centerpoint Rd., 35215, (205) 853-3952
BIRMINGHAM (HOMEWOOD) - D & R Appliance Company, 154 West Valley Ave., 35209, (205) 942-3959
CULLMAN - Robert G. Werner Company, 1115 4th Street S.W., 35055, (205) 734-5673
DECATUR - Peddler II, 1000 B Beltline Road, 35603, (205) 350-1044
DOTHAN - Bill's Appliance Service, 208 Bic Road, P.O. Box 1192, 36303, (334) 792-7746
DOUGLAS - Brown Hardware, Highway 75, 35964, (205) 593-6086
HUNTSVILLE - C & G Appliance, 307 Jordan Lane, 35805, (205) 837-4551
MOBILE - Foster's Appliance Repair, 1660 South Beltline Hwy., 36693, (205) 666-2670
MONTGOMERY - Acme Service Co., 2603 Highland Ave., 36107, (205) 264-2456, (800) 285-2160
TUSCALOOSA (NORTHPORT) - Frigid Service & Sales, 2813 Lurleen B. Wallace Blvd., 35476, (205) 339-3624

ALASKA

ANCHORAGE - Ken's Electronics Service, 360 E. International, Ste. 8, 99518, (907) 562-3443

ARIZONA

GLENDALE - Elliott Electric Appliance Service, 6242 N. 43rd Avenue, 85301, (602) 937-2613
SCOTTSDALE - Elliott Electric, 7515 E. McDowell Road, 85257, (602) 946-7487

ARKANSAS

FT. SMITH - Bromley Appliance Service, 614 North 10th Street, 72901, (501) 782-9646
JONESBORO - Best Sewing & Vacuum & Repair, 2235 S. Caraway Road, 72401, (501) 935-4739, (800) 844-4739
LITTLE ROCK - C & W Tool Repair, 1303 W. Markham, 72201, (501) 374-1911
ROGERS - Kressel's Vacuum & Repair, 115 North 5th Street, 72756, (501) 636-7894
STUTTGART - Davis Lumber Company, 301 East Michigan, 72160, (501) 673-3601

CALIFORNIA

BAKERSFIELD - Southwest TV, 6300 White Lane, Suite B, 93309, (805) 397-4940
CONCORD - California Electric Service Center, 1170-G Burnett Avenue, 94520, (510) 827-1011
COVINA - California Electric Service Center, 612 Shoppers Lane, 91723, (818) 915-4935
DUBLIN - California Electric Service Center, 6759 Sierra Court, Suite B, 94568, (510) 551-3390
FONTANA - California Electric Service Center, 9794 Sierra Avenue, 92335, (909) 355-2500
FORT JONES - Ft. Jones Frontier Hardware, 11911 Main Street, 96032, (916) 468-2266
FRESNO - Valley Small Appliance, 4005 E. Ashlan Avenue, 93726, (209) 224-5530
FULLERTON - California Electric Service Center, 1208 E. Ash Avenue, 92631-5020, (714) 870-0900
LOS ALAMITOS - California Electric Service Center, 11284 Los Alamitos Blvd., 90720, (310) 430-2668
MERCED - Moosehead Electronics, 920 W. 18th Street, 95340, (209) 723-4712
MISSION VIEJO - California Electric Service Center, 23725 Via Fabricante, Unit B, 92691, (714) 586-9440
OAKLAND - California Electric Service Center, 1139 E. 12th Street, 94606, (510) 834-1050
OXNARD - Terry's Inc., The Clean-up Store, 1237 Saviers Road, 93033, (805) 487-9401, (800) 845-3223
PASADENA - California Electric Service Center, 2594 E. Colorado Blvd., 91107, (818) 792-3194
SACRAMENTO - California Electric Service Center, 1821 "O" Street, 95814, (916) 443-5711
SAN CARLOS - California Electric Service Center, 990 Industrial Road, Suite 102, 94070, (415) 593-6696,
SAN DIEGO - California Electric Service Center, 3430 El Cajon Blvd., 92104, (619) 283-6488
SAN FRANCISCO - California Electric Service Center, 1090 Bryant Street, 94103, (415) 431-8494
SAN JOSE - California Electric Service Center, 783 The Alameda, 95126, (408) 295-1723
SANTA ANA - California Electric Service Center, 2025 South Main Street, 92707, (714) 641-0529
SANTA ROSA - Hardisty's Inc., 710 Farmers Lane, 95405, (707) 545-0535
STOCKTON - California Electronics, 929 North Yosemite Street, 95203, (209) 466-5432
TEMECULA - California Electric Service Center, 41715 Enterprise Circle North, Suite 101, 92590, (909) 695-5445,
VAN NUYS - California Electric Service Center, 14753 Oxnard Blvd., 91411, (818) 997-8855
WEST LOS ANGELES - California Electric Service Center, 2314 S. Westwood Blvd., 90064, (310) 475-2532
YUCAIPA - Aire-Rite Heating & A/C, 34724 Yucaipa Blvd., 92399, (909) 797-2788

Authorized Service Centers

COLORADO

COLORADO SPRINGS - Nelson Appliance Repair, Inc., 1220 E. Fillmore, 80907, (719) 635-1928
DENVER - Appliance Service, 4262 Lowell Blvd., 80211, (303) 458-1109, (800) 631-0941 (CO, WY only)
DENVER (ENGLEWOOD) - Appliance Service, 3932 S. Broadway, 80110, (303) 781-1227 (800) 553-1864
GRAND JUNCTION - V & L Appliance Service, 809 North Avenue, 81501, (970) 243-3360

CONNECTICUT

HARTFORD (BLOOMFIELD) - Philips Consumer Electronics, 1294 Blue Hills Avenue, 06002, (203) 726-9612, (800) 862-2225
HARTFORD - Hartford Element & Appliance Service, 1500 Albany Avenue, 06112, (860) 246-7424, (800) 787-7977
NEW HAVEN (HAMDEN) - New Haven Appliance Service Center, 1627 Dixwell Avenue, 06514, (203) 288-6229
SHELTON - Jeff's Appliance, Inc., 500A Howe Avenue, 06484, (203) 924-8997
STAMFORD - Appliance Servicenter of Stamford, 15 Cedar Heights Road, 06905, (203) 322-7656
WATERBURY - P.J. Appliance Repair, 935 South Main Street, 06706, (203) 757-1014

DELAWARE

DOVER - Del-Mar Appliance of Delaware, 230 South Governors Avenue, 19904, (302) 674-2414, (800) 858-3424
WILMINGTON - Lyons Hardware, Inc., 2021 Kirkwood Highway, 19805, (302) 995-1260

FLORIDA

ATLANTIC BEACH - First Coast Repair, 25 Seminole Road, 32233, (904) 246-4616
GAINESVILLE - Authorized Appliance Service Co., 2614 S.W. 34th Street, 32608, (904) 375-3886
HIALEAH - S-O Service Co., 925 Hialeah Drive, 33010, (305) 887-6275
HOLLY HILL - Ormond Element, 1668 Ridgewood Avenue, 32117, (904) 677-3497
JACKSONVILLE - Authorized Appliance Service Co., 6120-5 Powers Avenue, 32217, (904) 737-5312
LAKE CITY - S&S Mowers Sales & Service, Route 10, Box 9161, Hwy 47 South & MacFarland Ave., 32055, (904) 755-9375
LAKELAND - Electric Shaver & Small Appliance, 4243 S. Florida Avenue, 33813, (813) 644-4690
NORTH FORT MYERS - Family Hardware, 13817 N. Cleveland Ave., 33903, (813) 995-6161
OCALA, Vacuums, Inc., 3535 S.E. Maricamp Road, #103, 34471, (904) 694-2247
ORLANDO - Philips Consumer Electronics, 2452 Sand Lake Road, 32809, (407) 857-8998, (800) 942-6128
ORLANDO - Pine Hills Appliance Svc. Co., 6100-4 W. Colonial Drive, 32808, (407) 299-1271
ORLANDO - Southern Electric Co., 510 N. Parramore Avenue, 32801, (407) 841-8824, (800) 940-8824
PANAMA CITY, Callaway Vacuum & Sewing, 221 N. Tyndal Prkwy., 32404, (904) 763-6333
PENSACOLA - Foster's Appliance Repair, 3836 North Davis Highway, 32503, (904) 432-8853
POMPANO BEACH - Authorized Appliance Service Co., 2171 N. Dixie Highway, 33060, (305) 941-2038
POMPANO BEACH - Philips Consumer Electronics, 2099 W. Atlantic Blvd., 33069, (305) 978-0467, (800) 635-6488
PORT ST. LUCIE - Hoppe's Authorized Vac & Appliance, 6735 S. Federal Way, 34592, (407) 464-0102
ROCKLEDGE - Neelco Do-It Center, 400 Barton Blvd., 32955, (407) 639-1400
SARASOTA - Sunray Small Appliances, 8371 N. Tamiami, 34243, (941) 358-9999, (800) 895-5655
SEBRING - Sebring Do-It Center, 305 U.S. 27 North, 33870, (813) 385-2785
SPRING HILL - Crowder Bros Hardware, 5350 Spring Hill Dr., 34606, (904) 686-4743
ST. PETERSBURG - Keystone Electric, 4604 Central Avenue, 33711, (813) 321-1124
STUART - Appliance Doctors, 3166 S.E. Dixie Highway, 34997, (407) 287-6437
SUNRISE - Muller Appliance Service, 2620 N. University Drive, 33322, (305) 749-5460

TALLAHASSEE - Prescott's Ace Hardware, 4831 Kerry Forest Parkway, 32308, (904) 668-3389
TAMPA - Authorized Appliance Service Co., Dibbs Plaza, 4119 Gunn Hwy., Unit 8, 33624, (813) 968-6638
VERO BEACH - Hoppe's Authorized Vac & Appliance, 1872 Commerce Avenue, 32960, (407) 562-4466
WEST PALM BEACH - Satisfaction TV Video Service, Inc., 1701-05 Kirk Road, 33406, (407) 439-3733

GEORGIA

ATLANTA - Georgia Service Center, 5366 Buford Hwy., 30340, (770) 455-1716, (800) 455-1715
ATLANTA (MARIETTA) - Philips Consumer Electronics, 200 N. Cobb Parkway, Bldg. #100, Suite 120, 30062, (770) 795-0085
AUGUSTA - A & A Appliance Parts & Service, 1708 Walton Way, 30904, (706) 733-5163
BRUNSWICK - Arco Hardware & Supply, 3711 Community Road, 31520, (912) 267-0771
COLUMBUS - Burrell's National Appliance Service, 1728 Warm Springs Road, 31904, (706) 327-0523
MACON - Capitol Cycle Company, 1090 Washington Avenue, 31201, (912) 745-3946
SAVANNAH - Hagins Appliance Service, 3 West Victory Drive, 31405, (912) 233-8372
TIFTON - Western Auto, 354 S. Main St., 31794, (912) 382-5767

HAWAII

HONOLULU - McCully Bicycle & Sporting Goods, 932 Hausten Street, 96826, (808) 946-1192
WAILUKU (MAUI) - Tom's Appliance Sales & Service, 891 Eha Street, 96793, (808) 244-6278
WAIPAHU - Waipahu Bicycle, 94-320 Depot Street, 96797, (808) 671-4091

IDAHO

BOISE - Boise Appliance, 1503 Main Street, 83702, (208) 343-0102

ILLINOIS

CHAMPAIGN - Appliance Parts & Service, 905 Francis, 61821, (217) 355-0220
CHICAGO - Chicagoland Bicycle, 10126 S. Western Ave., 60643, (312) 445-0811
CHICAGO (BERWYN) - Brand Service Center, 6739 West Cermak, 60402, (708) 749-4315
CHICAGO (DOWNER'S GROVE) - Authorized Appliance Service Co., 1644 W. Ogden Avenue, 60515, (708) 852-1550, (800) 829-1798
CHICAGO (MORTON GROVE) - Brand Service Center, Inc., 5618 Dempster Street, 60053, (708) 965-5900
JACKSONVILLE - Rexx Battery Specialists, 847 South Main Street, 62650, (217) 245-2713
NASHVILLE - Kesel Hardware, 173 West St. Louis, 62263, (618) 327-8957
NILES - Household Appliance Sales & Serv., 7411 N. Milwaukee Ave., 60714, (708) 647-8250, (800) 572-6826, Fax (708) 647-2214
PEORIA - Brand Service Center, 6926-I North University Street, Tanglewood Center, 61614, (309) 691-7588
ROCKFORD - Sun Appliance Sales & Service, 3112 N. Rockton Avenue, 61103, (815) 964-3866
SPRINGFIELD - Bannon Electronics, 1224 N. Franklin, 62702, (217) 523-0313
WAUKEGAN - Brand Service Center, 2850 Belvidere Road, 60085, (708) 244-5800

INDIANA

EVANSVILLE - Electro Hygiene Co., 1614 South Kentucky, 47714, (812) 425-2671
FT. WAYNE - Don's Harware, 5701 Coventry Lane, in the Village of Coventry, 46804, (219) 436-2278
FT. WAYNE - Sun Appliance Service & Sales, 3523 N. Anthony Blvd., 46805, (219) 482-1702
HAMMOND - Brand Service Center, Inc., 6347 Indianapolis Blvd., 46320, (219) 844-0920
INDIANAPOLIS - Brand Service Center, 1827 N. Meridian Street, 46202, (317) 924-1386
INDIANAPOLIS - Sullivan Hardware Do-It Center, 7021 N. Keystone, 46220, (317) 255-9230
MUNCIE - Joef's Appliance Service, 4405 N. Old State Road 3, 47303, (317) 286-2896

NEW ALBANY - Wells Hardware, Inc., 1011 Vincennes Street, 47150, (812) 944-4523
SOUTH BEND - Ray's TV and Appliance, 60717 US 31 South, 46614, (219) 291-1630
SOUTH BEND (OSCEOLA) - AAA Appliance Service Co., 11868 Lincoln Way West, 46561, (219) 679-4981
TERRE HAUTE - Alex TV & Appliance Sales & Service, 924 South 8th Street, 47802, (812) 232-8786

IOWA

BETTENDORF - K & K True Value Hardware, 1818 Grant Street, 52722, (319) 359-4473
CEDAR RAPIDS - Stalker Electric, Inc., 110 3rd Ave. SW, 52404, (319) 364-5646
DES MOINES - Quality Appliance Repair Center, 1417 Walnut Street, 50309, (515) 288-0108
DUBUQUE - Shaver's Plus, 11 Bluff Street, 52001, (319) 556-4442
SIoux CITY - Millard Television Inc., 1419 Hamilton Blvd., 51103, (712) 258-3435

KANSAS

COLBY - Gavon's Electronics, 1870 South Range, 67701, (913) 462-6601
JUNCTION CITY - R/C Hobbies, 115 W. 7th Street, 66441, (913) 238-1877
KANSAS CITY (OVERLAND PARK) - Mar-Beck Appliance Service Co., 8471 West 95th Street, 66212, (913) 642-1557
WICHITA - Alan Appliance Service, Inc., 1300 E. Central, 67214, (316) 262-7228, (800) 290-7228

KENTUCKY

GREENVILLE - Malone Lumber Do-It Center, 204 W. Depot Street, 42345, (502) 338-3252
LEXINGTON - Factory Electronics, 2422 Palumbo Drive, 40509, (606) 269-7341
LEXINGTON (VERSAILLES) - Deaver's Hardware, 221 N. Main St., 40383, (606) 873-7396
LOUISVILLE - Maury's Fluorescent & Appliance Service, 1521 Bardstown Road, 40205, (502) 456-1671
MADISONVILLE - Kuester's Hardware, N. Main St., Martin Mall, 42431, (502) 825-2818
OWENSBORO - Kuester's Hardware, 1210 Carter Road, 42301, (502) 685-4916
PADUCAH - Hank Brothers True Value, 3101 Lone Oak Rd., 42003, (502) 554-4001

LOUISIANA

BATON ROUGE - Home Appliance Service, Inc., 10781 Florida Blvd., 70815, (504) 272-7727
LAFAYETTE - Cullen's Playland, 4498 Johnston Street, 70503, (318) 981-2929
LAKE CHARLES - Capitol Schwinn Cyclery, 722 E. Prien Lake Road, 70605, (318) 474-9090
NEW ORLEANS (METAIRIE) - Le Jouet, Inc., 1700 Airline Hwy., 70001, (504) 837-0533
SHREVEPORT - Shreveport Shaver and Appliance, 9750 St. Vincent, Burt Kouns Ind. Loop, 71106, (318) 865-5088, (800) 349-7722
WEST MONROE - West Monroe Small Appliance Repair, 1300 N. 7th Street, Suite F, 71291, (318) 323-5088

MAINE

BANGOR - Adco Surgical Supply Co., 1292 Hammond St., 04401, (207) 942-5273
PORTLAND - Colonial Electronics, Inc., 259 St. John Street, 04102, (207) 774-6666

MARYLAND

BALTIMORE (ELLCOTT CITY) - Clark Do-It Center, 10325 Baltimore National Pk., 21042, (410) 313-8100
BALTIMORE (TOWSON) - Duran Service Company, 8741 Mylander Lane, 21286, (410) 321-9033
EASTON - Easton Schwinn Cyclery, 723 Goldsboro Street, 21601, (410) 822-7433
GAITHERSBURG - Waters Appliance Service, 216 E. Diamond Avenue, 20877, (301) 258-7500, (800) 225-5009
SALISBURY - Cycle and Sports Outlet, 2505 N. Salisbury Blvd., 21801, (410) 860-0400
TANEYTOWN - MacHenry Services, 68 Frederick Street, 21787, (410) 756-6659, (800) 276-1301
WASHINGTON D.C. (BELTSVILLE) - Philips Consumer Electronics, 10800 Rhode Island Avenue, 20705, (301) 595-5330, (800) 438-9647

Authorized Service Centers

OKLAHOMA

OKLAHOMA CITY - Brand Service Center, 538 N. Pennsylvania Avenue, 73107, (405) 235-0583
TULSA - H.L. Moss, Inc., 1714 E. 15th Street, 74104, (918) 744-1305, (800) 248-5948

OREGON

PORTLAND - Oregon Appliance 2137 East Burnside Street, 97214, (503) 235-6681,

PENNSYLVANIA

ALTOONA - Frye's Sweeper & Sewing Center, Inc., 1400 Valley View Boulevard, 16602, (814) 943-5001, (800) 640-1308
HARRISBURG - C.A. Juillard, Inc., 2301 North Seventh Street, 17110, (717) 233-3488, (800) 633-3488
JOHNSTOWN - Cambria True Value Hardware, West Hills Square, Goucher Street, 15905, (814) 255-4752
KINGSTON - Vac-Way Appliance & Service, 595 Market Street, 18704, (717) 288-4508
MOSCOW - Vac-Way Appliance & Service, RR #6 Box 6237, 18444, (717) 842-4668
MOSCOW - Vac-Way Appliance & Service, RR #6 Box 6237, 18444, (717) 842-4668
ORANGEVILLE - Hess Do-It Center & Market, Route 487, Box 4 M, 17859, (717) 683-5162
PHILADELPHIA - Appliance Care/Service Corp., 6407 Rising Sun Ave., 19111, (215) 725-3112
PHILADELPHIA (COLLINGDALE) - J.F. Kenney Electric, 920 MacDade Boulevard, 19023, (610) 534-7373
PITTSBURGH - Ferry Electric Service Co., 7498 McKnight Road, 15237, (412) 364-3403
PITTSBURGH - Ferry Electric Service Co., 140 Clairton Blvd., 15236, (412) 653-6004
READING - Electric Repair Co., 502-504 North 9th Street, 19604, (610) 376-5444, (800) 422-8171 (PA only)
SCRANTON - Vac-Way Appliance and Service, 601 Cedar Avenue, 18505, (717) 343-1121
SHAMOKIN DAM - Willard Battery Outlet, 138 S. Old Trail, 17876, (717) 743-5383
TROY - Hoover hardware, 9 Canton, 16947, (800) 251-2156, (717) 297-3445
WASHINGTON - Murphy Family Inc., 585 East National Pike, 15301, (412) 225-0324
WILKES-BARRE - Walter Hardware DO-IT Center, 57 N. Welles Street, 18702, (717) 823-1406
YORK - Parcel Plus, 2549 E. Market Street, York Market Place, 17402, (717) 757-1875

PUERTO RICO

HATILLO - Tropical Parts Service, P.O. Box 1335, Road 130 KM 8.5, 00659, (809) 898-6474
MAYAGUEZ - Cardona Appliance Service, 8 San Vicente St., 00680, (809) 832-8366
MAYAGUEZ - Melendez Home Appliance Repair, Calle Post 319 Sur, 00680, (809) 832-5225
PONCE - Ferreteria Vivian, Centro Comercial, Los Caobos #7, 00731, (809) 840-0677
PUERTO NUEVO - Buckeye Service, 1013 Jesus T. Pinero Avenue, 00920, (809) 782-6175

RHODE ISLAND

PROVIDENCE - Marshall Electric Co., 200 Broad Street, 02903, (401) 331-4482

SOUTH CAROLINA

CHARLESTON HEIGHTS - Dorchester Electric Service, 3575 Dorchester Avenue, 29405, (803) 747-5221
COLUMBIA - Authorized Appliance Servicenter, 1811 Taylor Street, 29202, (803) 254-8414
FLORENCE - The Hobby Center of Florence, 919-C South Cashua, 29501, (803) 664-9226
GREENWOOD - Bikes & Boards & Mopeds, 203A Montague Avenue, 29646, (803) 229-2453
SPARTANBURG - Boiling Springs Hardware, 3124 Boiling Springs Rd, 29303, (803) 578-1852
VARNVILLE - P&S Small Engine & Variety Shop, 105 Carolina Avenue, West, 29944, (803) 943-9141

TENNESSEE

CHATTANOOGA - Light Electric Co., 732 East 11th Street, 37403, (615) 267-9224
KNOXVILLE - Authorized Appliance Service Center, 1206 North Central Street, 37917, (615) 524-3376
KNOXVILLE - Phillips Consumer Electronics, 6700 D Papermill Road, Papermill Plaza, 37919, (615) 584-6614, (800) 821-1767
MEMPHIS - Camp Electric Co., 647 Madison Avenue, 38103, (901) 527-7543, (800) 238-7345
NASHVILLE - Webb's Appliance Service Center, Inc., 1519 Church Street, 37203, (615) 329-4079, (800) 899-4079

TEXAS

ABILENE - Metro Small Appliance Service Co., 141 S. Clyde, 79605, (915) 672-1853
AMARILLO - Reid's Appliance Service, Inc., 906 Georgia, 79102, (806) 373-8812
ANTHONY - Villarreal & Sons Elec., 512 S. Third Street, 79821, (915) 886-3362
AUSTIN - Harrell Supply and Service, Inc., 5435 Burnet Road, 78756, (512) 451-6464, (800) 332-7250 (TX only)
AUSTIN - Harrell Supply and Service, Inc., 1409 West Oltorf, 78704, (512) 442-5966
AUSTIN (ROUND ROCK) - Harrell Supply, 907c Interstate Highway 35, 78664, (512) 388-0866
CORPUS CHRISTI - Brand Service Center, 2751 S. Staples Street, 78404, (512) 854-1851
DALLAS - Pearsol Appliance Co., 3127 Main Street, 75226, (214) 939-0930
DALLAS - All Type Sales and Service Co., Inc., 2835 Irving Blvd., 75207, (214) 638-1170, (800) 717-1170
DALLAS (GARLAND) - Pearsol Appliance Co., 2406 South Jupiter Road, 75041, (214) 840-0622, (800) 527-7385
FT. WORTH - Ft. Worth Shaver and Appliance Center, 1012 West 7th Street, 76102, (817) 335-9970
HOUSTON - Brand Service Center, 5727 Richmond Avenue, 77057, (713) 782-8910, (800) 705-2929
HOUSTON - Brand Service Center, 1970 FM 1960, 77090, (713) 537-7795
LAREDO - Rubio Electric, 1719 San Bernardo, 78040, (210) 722-3908
LONGVIEW - Toys and Things, 918 NW Loop 281, 75604, (903) 759-3939
LUBBOCK - Minter's, 4409 50th Street, 79414, (806) 799-3170
LUFKIN - STS Audio and Video, 1505 South First Street, 75901, (409) 639-4529
MC ALLEN - All-In-One Repair Shop, 2313 Lark Avenue, 78504, (210) 682-8858
MIDLAND - Midland Tool Specialty, 918 South Main, 79701, (915) 682-4647, (800) 499-0755
PASADENA - Larry's TV Service, 3520 Fairmont Parkway, 77504, (713) 998-0122, (800) 244-0281
ROMA - True Value Hardware, 1004 E. Highway 83, (210) 849-1322
SAN ANTONIO - Brand Service Center, 7065 San Pedro Avenue, 78216, (210) 344-8577
SEYMOUR - Western Auto, 211 N. Main Street, 76308, (817) 888-3980
TEMPLE - Master Tech Repairs, 2819 West Avenue North, 76504, (817) 773-8991
WICHITA FALLS - Burke's Appliance Service, 2410 10th Street, 76309, (817) 723-6211

UTAH

OREM - The Mending Shed, 1735 South State Street, 84058, (801) 225-8012, (800) 339-9297
SALT LAKE CITY - Appliance Service Center, Inc., 210 East 6th South, 84111, (801) 328-9703

VERMONT

RUTLAND - Appliance Service Center Ltd., 152 Woodstock Avenue, 05701, (802) 773-8917

VIRGINIA

HARRISONBURG (PENN LAIRD) - J.L. Maintenance & Repair, Inc., Route 1, Box 183, 22846, (703) 289-9844, (800) 296-9844
NEWPORT NEWS - Commonwealth Electric Shaver Sales & Service, Inc., 10105 Jefferson Ave., 23605, (804) 595-6712
NORFOLK - Commonwealth Electric Shaver Sales & Service, Inc., 6612 E. Virginia Beach Blvd., 23502, (804) 461-4475
ROANOKE - Commonwealth Shaver & Appliance Service, 5524 Williamson Road, NW, 24012, (703) 366-6038
VIENNA - Appliance Fix-It, 8455 Tyco Road, 22182, (703) 893-1234
WINCHESTER - Battery Mart of Winchester, Inc., 1 Battery Dr., 22601, (703) 655-0065
WOODBRIIDGE - Baker's Appliance, 13314 Occoquan Road, 22191, (703) 690-3214

WASHINGTON

SEATTLE - Ajax Electric, 2911 First Avenue South, 98134, (206) 622-9945
SEATTLE (BELLEVUE) - Action Small Appliance Service, 1500 145th Place, SE, 98007, (206) 643-9806
SPOKANE - SPARCO, West 45 2nd Avenue, 99204, (509) 624-8965
SPOKANE - SPARCO, N. 1119 Pines Rd., 99206, (509) 922-9666

WEST VIRGINIA

BECKLEY - Jerry's Detectors, Vacuum & Appl. Svc., 411 Second Street, 25801, (304) 253-3521
CHARLESTON - Sneed's Vacuum & Sewing Center, 2614 7th Avenue, 25312, (304) 744-3670, (800) 245-8048 (WV only)
HARRISVILLE - Western Auto, 1107 E. Main St., 26362, (304) 643-2226
HUNTINGTON - Mike's Appliance and Service, 212 20th Street, 25703, (304) 522-0737, (800) 244-9152
MARTINSBURG - Battery Mart, 1161-3 Winchester Avenue, 25401, (304) 267-7033, (800) 464-7918
WHEELING - Fast Service Center, 1058 Main Street, 26003, (304) 232-5561 (800) 874-4090

WISCONSIN

APPLETON - G/Tech Electric Tool & Housewares Service, 600 W. College Ave., 54911, (414) 739-6064, (800) 400-6064
LACROSSE - Paul's Shaver Service, 1224 Caledonia Street, 54603, (608) 782-6291
MADISON (MONONA) - Kiefer's Shaver and Appliance, 4511 Monona Drive, 53716, (608) 221-3322
MAUMETTE - Della Do-It Center, W 1536 Highway 41, 54143, (715) 732-1768
MILWAUKEE - Brand Service Center, 3707 North 92nd Street, 53222, (414) 461-0440
MILWAUKEE - Brand Service Center, 6000 W. Oklahoma Street, 53219, (414) 541-4340