

Contents

For safety

CHAPTER 1 OVERVIEW.....	1
1.1 Introduction -----	1
1.2 Organization of This Manual -----	1
CHAPTER 2 USING RADAR FOR THE FIRST TIME.....	2
2.1 What is radar? -----	2
2.2 Characteristics of Radar Wave -----	3
2.3 Terms Specific to Radars -----	6
CHAPTER 3 INSTALLATION.....	9
3.1 Checking Inventory-----	9
3.2 Checking Power Supply Voltage -----	10
3.2.1 Power Supply Requirement -----	10
3.2.2 Fuse Replacement-----	10
3.3 Where to install the Scanner -----	11
3.3.1 Scanner unit-----	11
3.3.2 Display unit -----	11
3.3.3 Shifting away from obstacles-----	12
3.4 Installing Scanner Unit -----	13
3.5 Installing Antenna Unit -----	15
3.6 Installing Display Unit-----	15
3.7 Connecting Cables-----	16
3.7.1 Interconnecting cable (RA51 Radome scanner)-----	16
3.7.2 Interconnecting cable (RA52/53/54/55 Open scanner) -----	18
3.7.3 Grounding wire-----	19
3.7.4 Power supply cable -----	20
3.8 Adjustment -----	20
3.9 Connecting External Equipment to Display Unit-----	21
3.10 Countermeasure for Electromagnetic Interference -----	21
3.11 When Discarding Your Radar -----	22
CHAPTER 4 FUNCTIONS AND NAMES.....	23
4.1 Key layout -----	23
4.2 Rear panel-----	24
4.3 Radar screen (Single screen) -----	24
4.4 Radar screen (Dual screen) -----	25
4.5 Radar screen (All PPI screen) -----	25
4.6 Radar screen (All PPI/PPI screen)-----	26
4.7 Navigation screen -----	26

CHAPTER 5 OPERATION	27
Basic operation of Radar-----	27
5.1 Powering ON and OFF -----	27
5.2 Adjusting contrast and brilliance of the screen, and key-backlight-----	27
5.3 Basic Operations-----	28
5.3.1 Turning On and Off-----	28
5.3.2 Transmitting-----	28
5.3.3 Adjusting contrast and brilliance of the screen, and key-backlight-----	28
5.3.4 Changing the range scale (RANGE UP, RANGE DOWN)-----	28
5.3.5 Automatic adjustment (AUTO)-----	29
5.3.6 Sensitivity adjustment (GAIN)-----	29
5.3.7 Removing Sea clutter (STC)-----	30
5.3.8 Removing rain and snow clutter (FTC)-----	30
5.3.9 Man Over Board (MOB)-----	30
5.4 Soft Key Functions-----	31
5.4.1 Bearing measurement (EBL1)-----	31
5.4.2 Bearing measurement (EBL2)-----	31
5.4.3 Distance measurement (VRM1)-----	31
5.4.4 Distance measurement (VRM2)-----	31
5.4.5 Measuring the angle between two points (FL EBL2)-----	31
5.4.6 Measuring the distance between two points (FL VRM2)-----	32
5.4.7 Changing the Soft Key function grouping (NEXT)-----	32
5.4.8 Temporarily erasing heading marker (HDG OFF)-----	33
5.4.9 Using parallel cursor (///CSR)-----	33
5.4.10 Establishment of the indication of the RANGE RINGS (RINGS)-----	33
5.4.11 Variable range function (VAR RNG)-----	33
5.4.12 Changing the display modes (MODE)-----	33
5.4.13 Guard Zone (GZ)-----	33
5.4.14 Off Center (OFF-C)-----	33
5.4.15 Setting the SLEEP mode (SLEEP)-----	34
5.4.16 Tuning adjustment (TUNE)-----	34
5.4.17 Echo expansion (ST)-----	34
5.4.18 Displaying track of targets (TRACK)-----	35
5.4.19 Enlarging a selected area (ZOOM)-----	35
5.4.20 Increasing transmitter average power (S/L)-----	35
5.4.21 Switching the screen (SEL WIN)-----	35
5.4.22 Reversing the screen color (PICTURE)-----	36
5.4.23 Change to PPI screen (PPI)-----	36
5.4.24 Change to SEMI3D/PPI screen (SEMI3D)-----	36
5.4.25 Change to PPI/PPI screen (PPI/PPI)-----	36
5.4.26 Change to PPI/NAV screen (PPI/NAV)-----	36
5.4.27 Change to ALL PPI screen (ALL PPI)-----	37
5.4.28 Change to ALL PPI/PPI screen (ALL PPI2)-----	37
5.5 MENU Operation -----	38
List of MENU -----	38
5.5.1 Mark Menu -----	39
5.5.1.1 Bearing measurement (EBL1)-----	39
5.5.1.2 Determining distance (VRM1)-----	39
5.5.1.3 Bearing measurement (EBL2)-----	40
5.5.1.4 Determining distance (VRM2)-----	40
5.5.1.5 Measuring the distance between two points (VRM2, FL VRM2)-----	40
5.5.1.6 Measuring the angle between two points (EBL2, FL EBL2)-----	40
5.5.1.7 Erasing the heading marker temporarily (HDG OFF)-----	41
5.5.1.8 Using parallel cursors (///CSR)-----	41

5.5.1.9	Establishment of the indication of the RANGE RINGS (RINGS) -----	41
5.5.1.10	Variable range function (VAR RNG)-----	42
5.5.1.11	Output the position of the cursor location to another NMEA device (TARGET) -----	42
5.5.1.12	Determine the distance and bearing to a marker (+MK LINE) -----	42
5.5.2	Nav (Navigation) Menu -----	44
5.5.2.1	Changing display mode (MODE) -----	44
5.5.2.2	Guard Zone (GZ) -----	44
5.5.2.3	Off centering the screen display (OFF-C) -----	45
5.5.2.4	Setting the SLEEP function (SLEEP) -----	45
5.5.2.5	Activating Automatic Tracking Aid (ATA) -----	46
5.5.3	Echo Menu -----	47
5.5.3.1	Sensitivity adjustment (GAIN) -----	47
5.5.3.2	Removing Sea clutter (STC)-----	47
5.5.3.3	Removing rain and snow clutter (FTC) -----	48
5.5.3.4	Adjusting receiver tuning (TUNE) -----	48
5.5.3.5	Echo expansion (ST) -----	48
5.5.3.6	Displaying track of targets (TRACK)-----	49
5.5.3.7	Enlarging a selected area (ZOOM) -----	49
5.5.3.8	Increasing average transmitter power (S/L) -----	50
5.5.4	SETUP Menu -----	51
5.5.4.1	Selecting the screen display (WINDOW)-----	51
	Funtions Available On Each Screen-----	51
	Screen Modes and Operations -----	52
(a)	PPI Screen-----	52
(b)	PPI/SEMI3D Screen-----	52
(c)	PPI/PPI Screen-----	52
(d)	PPI/NAV Screen-----	53
(e)	ALL PPI Screen -----	53
(f)	ALL PPI/PPI Screen-----	53
(g)	MOB Screen-----	53
5.5.4.2	Switching screens on PPI/PPI screen (SEL WIN)-----	54
5.5.4.3	Reversing the screen (PICTURE)-----	54
5.5.4.4	Slave Display Operation-----	54
5.5.4.5	Fault Diagnosis by Self Check (SYSTEM CHECK)-----	54
5.5.4.6	Changing the custom setting (CUSTOM) -----	56
5.5.4.6.1	Changing the settings of the soft keys (KEY ASSIGN)-----	56
5.5.4.6.2	Changing the settings in PRESET1 screen -----	58
5.5.4.6.3	Changing the settings in PRESET2 screen -----	60
	HOLD function -----	61
5.5.4.6.4	Changing the content of priority for NMEA input (NMEA PRESET)-----	62
5.5.4.6.5	Initial adjustment settings (ADJUSTMENT) -----	62
(1)	Adjusting the distance (TIMING ADJ)-----	62
(2)	Adjusting the angle (HEAD ADJ)-----	63
(3)	Adjusting tuning circuit (TUNING CAL)-----	63
(4)	Adjusting the antenna height (ANTENNA)-----	64
(5)	Setting automatic GAIN circuit (GAIN)-----	65
(6)	Setting automatic STC circuit (STC) -----	65
(7)	Setting HARBOR STC circuit (HARBOR)-----	66

CHAPTER 6 MAINTENANCE AND INSPECTION 67

CHAPTER 7 TROUBLESHOOTING	69
7.1 Fault Diagnosis by Self-check -----	69
7.2 Inspecting Each Part -----	69
CHAPTER 8 PRODUCT SPECIFICATIONS	71
8.1 General -----	71
8.2 Scanner Unit -----	72
8.3 Display Unit-----	73
8.4 External Interface -----	74
8.5 Standard set-----	74
8.6 Options-----	75
8.7 External dimensions and weight -----	75
8.8 External connection and function -----	75
APPENDIX	76
1. RA51 GENERAL SYSTEM DIAGRAM -----	76
2. RA52 GENERAL SYSTEM DIAGRAM -----	76
3. RA53 GENERAL SYSTEM DIAGRAM -----	77
4. RA54 GENERAL SYSTEM DIAGRAM -----	77
5. RA55 GENERAL SYSTEM DIAGRAM -----	78
6. INTERCONNECTION DIAGRAM -----	79
OUTLINE DRAWING DISPLAY UNIT	
RA51 OUTLINE DRAWING SCANNER UNIT	E43BG11000
RA52 OUTLINE DRAWING SCANNER UNIT	23W72647
RA53/54 OUTLINE DRAWING SCANNER UNIT	E38BG52000
RA55 OUTLINE DRAWING SCANNER UNIT	E38BG62000
FLUSH MOUNT PROCEDURE	E48BG10000
	E43BG11020

INDEX

RB715A TEMPLATE OF SCANNER MOUNTING HOLES (ACTUAL SIZE)