USER MANUAL

Es-Link KCU2000



Korea One Telecommunication Technology, Inc Before you begin

This manual of Es-Link KCU2000 ADSL Modem designed for general user is

included from introduction to installation of ES-LINK KCU2000.

Before starting, you should read this manual carefully for the successful processing.

For further information, contact the customer service in KOTT

E-mail: Info@kott.co.kr

Copyright(C) 2001 by Korea One Telecommunication Technology

All Rights Reserved. Reproduction or media conversion by any means is protected by copyright and may only occur with prior written permission of KOTT

Table of contents

1. Introduction	5	
Es-Link KCU2000 Modem Introduction Es-Link KCU2000 Specifications		6
2. Setting Driver		7
Setting Driver	8	

For Windows 98(98SE)	8	
For Windows 2000	11	
Checking the installation of Modem	14	4
Configuring VPI / VCI	16	
3. Internet Access		18
3-1. PPPoE Protocol	19	
Installing EnterNet 300	19	
Installation in Win 98(98SE)/2000		19
3-2. Connecting to Internet	24	
Installing with EnterNet 300	24	
3-3. PPPoA Protocol	27	
Installing and connecting in Windows 98(98SE)		27
Installing and connecting in Windows 2000		32
4. Remove Modem Driver		37
Windows 98(98SE)	38 40	
Product Warranty	42	

1. Instruction

- Es-Link Es-Link KCU2000 Modem Instruction
- Es-Link Es-Link KCU2000 Modem Specifications

Es-Link KCU2000 Modem Instruction

The Es-Link KCU2000 low-power USB-based ADSL chipset and PC driver solution is optimized to address the growing demand for high-speed Internet access. The Es-Link KCU2000 is a controllerless solution that is fully compliant with both the full-rate ADSL (G.992.1 and G.dmt) and the 'splitterless' G.lite (G.992.2) standards. It uses Conexant solution.

The Es-Link KCU2000 modem is an always on high-speed broadband connection to the Internet. Using existing twisted pair telephone lines, ADSL technology provides data rates over 100 times the speed of a traditional analog modem, without an interruption in telephone service. With up to 8 Mbps downstream and 1 Mbps upstream data transfer rates, ADSL is the ideal solution for high-bandwidth applications such as access to a corporate network, Internet access, and video on-demand.

Es-Link KCU2000 Modem Specifications

Size	9Cm * 12Cm
Chip set	Conexant Chipset
Interface Standards	USB
	ANSI T1.413 Issue2
Protocol	ITU-T G.992.1 (G.DMT)
	ITU-T G.992.2 (G.Lite)
Transmission Speed	Full-rate Downstream 8Mbps, upstream 1Mbps
Transmission Specu	G.Lite Downstream 1.5Mbps,Upstream 512Kbps
Transmission Distance	18,000ft(approximately 5.5 Km)
Transmission standards	Full PPP (RFC 2364),Multi Protocol (RFC 1483)

2. Setting Driver

- Setting Driver
- For Windows 98(98SE)
- For Windows 2000
 - Checking the Modem Installation.
 - Configuring VPI / VCI

Setting Driver

If you want to use a modem in a PC, driver must be installed firstly.

Before you start this chapter, prepare driver diskette provided with a modem and check your PC OS(Operating system) and setup.

Es-Link KCU2000 is compliant with PnP(Plug and Play) and easy to install.

Put the modem in a PC and turn it on as previous chapter, and Windows will recognize modem automatically.

For Windows 98(98SE)

1. Turn on the PC. Click "Next"



2. Click "Next" after checking <Search for the best driver for your device (Recommended)> chosen.



3. Check <Specify a location> and find a installing driver from Browse.



4. Click "Next" after checking <Location of driver>



5. Click "Finish"



For Windows 2000

1. Turn on the PC. Click "Next"



2. Click "Next" after checking <Search for a suitable driver for my device (Recommended)> chosen



3. Check < Specify a location > and click "Next".



4. Click "OK" after selecting a location of driver from "Browse"



5. Click "Next"



6. Click "Yes"



7. Click "Finish". Now the software installation has completed.



8. Click "Yes"



Checking the Modem Installation

If you want to check that you have setup completely Es-Link KCU2000 ADSL Modem driver, follow the next procedures.

1. Click on the "Start -> Settings -> Control Panel" button on the desktop if your PC get restarted.



2. Check Conexant AccessRunner Icon made



3. Double-click on "System" icon on the control panel



4. Click "Device Manager"

System Properties		<u> </u>
General Device Manager Hard	ivere Profiles Performance System:	1
	Microroft Windows 98 Second Edition 4.10.2222A	
	Regivered to: JH-SUH KDTT 50578-026-6304672-27457	
	Computer: Ger kindintel Pentumi(1111 Processo) 64.0MB RAM	
		Cancel

5. Double-click Network adapters.

 View devices by 	Appe C S	Real devices by g	onnection
Computer			
E P CDRDM			
In the Usk drives			
The Display add	options:		
IN Ca Hard disk a	controllere		
H 22 Keyboard			
In 🛄 Monitore			
IB-5 Moure			
😑 💷 Network a	clappers		and the second se
	ent Abcestiftung	e USB ADSL LA	 Adaptet
and District	A Tala9 and and F	D.D F. Adamte	OUTSPO
H- V Potr CDA	(a.LPT)	THE MORE	1011 01-00
ret 🔤 System der	vices		
IR By Universal S	Seriel Bure control	lor v	
the second second	1		1

VPI / VCI Setting

- 1. Click AccessRunner on the control panel
- 2.



2. Press 'Alt+C'from <Conexant AccessRunner ADSL LAN Adapter>

ma j			
DSL Lee Information	10 C		
	-	10	
	e	100	
	ADSL Conve	ation Established	
ADSL Connection	Information		
Bytes Received	0	Bytee Transmitted	8.495
Receive Fiate	7616 ktoko/o	Transmit Flater	EBR khite/s
			[Interaction]
Driver 5/S/CVento	n 14.12.088 (910	10)	
63			
@ 2 cor	EXANT	C	nokard Sectors . In

3. The control panel configuring VPI and VCI appears. You can do VPI and VCI setting now by DSLAM devices.

AutoLog Cornection General Project Laws	Line Letens	STH Made Live Statistics	na 201 Datation AALLIVA Stokerica
Protocol Setup	COAH Longiture #	HALDiage	TRUP
ATMYSLIE GOLESSIERDOROD	Annual General D	Same Car	
Website Faith I downline WP11	D	1	
Visual Const Identifies (VCI)	a a	-	- 40
Aggregate (hisnos/Gatus			
Encaptureron Hode (1+3)	NULL OVER AT MULL CONF	P FFC1401	-
Maranan PacketLongh Finantin [1500 [1500	Post Call Fals PDP	t [Less Hate	2
		[Aao	<u> </u>

4. Enter VPI and VCI values as the table . Click Apply and OK. Now you have completed VPI and VCI setting configuration.

	Alcatel	Cisco	Lucent	Nokia	Erricsson	Samsung
VPI	?	?	?	?	?	?
VCI	?	?	?	?	?	?

By DSLAM Devices VPI / VCI value

* ? : Please check the values of VPI, VCI respectfully to the local ADSL service providers.

3. Internet Access

3-1. PPPoE Protocol

Installing EnterNet 300
 Installation in Windows 98(98SE)/2000

3-2. Connecting to Internet

• Connecting with EnterNet300

3-3. PPPoA Protocol

- Installing and Connecting in Windows 98(98SE)
- Installing and Connecting in Windows 2000

3-1. PPPoE Protocol

Installing EnterNet 300

EnterNet 300 is the client program which can service high-speed network through PPPoE (Point to Point Protocol over Ethernet) protocol such as ADSL

PPPoE protocol helps limits of static IP which make user identification or access easy and DHCP (Dynamic Host Control Protocol), and NAT (Network Address Translation) function overcome to the Internet Service Providers. That is to say, user identification and IP is given to the subscriber who has Ethernet interface as analog phone user.

Installation in Windows 98(98SE)/2000

- 1. Check if there is TCP/IP and MS network client before installing. Choose <Start->Settings->Control Panel> on the desk top. Double-click <Network> on the "Control Panel" window
- 2.On <Network> window, check that <client for Microsoft Network> and <TCP/IP> were added to <The following network components are installed > under <Network components> directory.
- 3. Click OK if Microsoft Network Client and TCP/IP are added, close "Network" window, and finish all programs which you were processing.

4. Insert the CD for PPPoE setup provided with Es -Link KCU2000 to the CD-ROM Drive. Run setup.exe file under <Windows> folder from CD



Windows setting file from PPPoE setup CD

5. While EnterNet 300 Setup program is preparing the installation, you can see the next Setup screen



6. You can see the <Welcome> window. Click Next.



Strat screen of EnterNet 300 Setup

7. Click Yes after you read all<Software License Agreement> window.

The set of th	the following License a agreement.	: Agreement, Pi	es: the PAGE DO	White to se
IND USER SOFTWA	RE LICENSE AGRE	EMENT		3
IMPORTANT PLEAS THIS IS ALEGAL AS purchase here 2000 ON WARPANTIES AT YOU ARE AGREEING	E READ THIS SOFT EFULLY BEFORE II REEMENT BETWEI 9 ("YOUR SERVICE ND LIABLITY, BY IN 1 TO BECOME BOU	IWARE LICENS INSTALLING OR EN YOU AND [2 PROVIDER 11 ISTALLING OR ND BY THE TEI	E AGREEMENT USING THIS SO 00005 meet lege IT CONTAINS LI USING THIS SO RMS AND COND	THIS FTWARE Inene of NITATIONS FTWARE. TIONS SET
USE THIS SOFTWAR	U DO NOT AGREE	TO THESE TEP	MS.DO NOT INS	STALL OF
UUT HEREIN, IFYO USE THIS SOFTWAR 1. LICENSE GRANT non-transferable licens documentation provide	U DONOT ABREE IE. Your Service Provic ie (hie 'Licence') to ed to you in electroni	TO THESE TEP ler grants to you use the accomp is form (collective	MS.DO NOT INS a ron-exclusive. arving software a dy the "Software"	nd I on the
DUT HEREIN, IFYO, USE THIS SOFTWAR 1. LICENSE GRANT non-transferable licens documentation provide Do you accept all the to will close. To install En	U DO NOT AGREE IE Your Service Provic le (the "Ucence") to ed to you'n electroni error of the precedin terNet 300, you'mus	TO THESE TEP use the accomp is form (collectiving d Licence Agree M accept this ag	MS, DB NOT MS a ran-exclusive, anying software a dy fre "Saftware" meni? If you cho reament.	nd 1 on the ose No, Setup

8. When <Choose Destination Location> window is appeared as the following Screen, a folder to install EnterNet 300 can be located. <C:\ProgramFiles\NTS\EnterNet 300> is the basic destination folder. After choosing the folder, click Next.



9. The following screen is showing the process of the copy of EnterNet 300 file to the chosen folder.

EnterNet 300 Setup	NUC

EnterNet 300 File Copying Screen

10. After the copy has finished, <Setup Complete> window comes. Check <Yes, I want to restart my computer now> to run EnterNet300 properly and click Finish.