



KYOCERA
Tomorrow is rising.

S4000

user guide

S4000 User Guide

This manual is based on the production version of the Kyocera S4000 phone. Software changes may have occurred after this printing. Kyocera reserves the right to make changes in technical and product specifications without prior notice. The products and equipment described in this documentation are manufactured under license from QUALCOMM Incorporated under one or more of the following U.S. patents:

4,901,307 5,109,390 5,267,262 5,416,797 5,506,865
5,544,196 5,657,420 5,101,501 5,267,261 5,414,796
5,504,773 5,535,239 5,600,754 5,778,338 5,228,054
5,337,338 5,710,784 5,056,109 5,568,483 5,659,569
5,490,165 5,511,073

The Kyocera Wireless Corp. ("KWC") products described in this manual may include copyrighted KWC and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for KWC and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the KWC products may not be modified, reverse engineered, distributed or reproduced in any manner not permitted by law.

Furthermore, the purchase of the KWC products shall not be deemed to grant—either directly or by implication, estoppel, or otherwise—any license under the copyrights, patents, or patent applications of KWC or any third party software provider, except for the normal, non-exclusive royalty-free license to use that arises by operation of law in the sale of a product.

Kyocera is a registered trademark of Kyocera Corporation. Brick Attack and Race 21 are trademarks of Kyocera Wireless Corp. QUALCOMM is a registered trademark of QUALCOMM Incorporated.

Openwave is a trademark of Openwave Systems Incorporated. eZiText is a registered trademark of Zi Corporation. TransFlash is a trademark of SanDisk Corporation. Bluetooth trademarks are owned by Bluetooth SIG, Inc. and used by Kyocera Wireless Corp. under license.

All other trademarks are the property of their respective owners.

Copyright © 2008 Kyocera Wireless Corp.
All rights reserved.

Ringer Tones Copyright © 2000-2008
Kyocera Wireless Corp.

82-K6572-1EN, Rev. 001

FCC notice

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Kyocera Wireless Corp. (KWC) supplied and approved standard case CV90-P0321-01 and premium case CV90-P0323-01.

Other accessories used with this device for body-worn operations must not contain any metallic components and must provide at least 15mm separation distance including the antenna and the user's body.

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured to not exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of

comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.*

Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified by the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

Body-worn measurements differ among phone models, depending upon availability of accessories and FCC requirements. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model

phone is on file with the FCC and can be found under the Display Grant section <http://www.fcc.gov/oet/ea/> after searching on the FCC ID: OVFKWC-K33B04.

Additional information on SAR can be found on the Cellular Telecommunications and Internet Association (CTIA) web-site at www.wow-com.com.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Bluetooth® Certification

For information about S4000 Bluetooth Certification, visit the Bluetooth Qualification Program Web site at qualweb.bluetooth.org.

Caution

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and user's authority to operate the equipment.

Optimizing your phone's performance

Use the guidelines in this guide to learn how to optimize the performance and life of your phone and battery.

Air bags

If you have an air bag, DO NOT place installed or portable phone equipment or other objects over the air bag or in the air bag deployment area. If equipment is not properly installed, you and your passengers risk serious injury.

Medical devices

Pacemakers—Warning to pacemaker wearers: Wireless phones, when in the 'on' position, have been shown to interfere with pacemakers. The phone should be kept at least six (6) inches away

from the pacemaker to reduce risk.

The Health Industry Manufacturers Association and the wireless technology research community recommend that you follow these guidelines to minimize the potential for interference.

- Always keep the phone at least six inches (15 centimeters) away from your pacemaker when the phone is turned on.
- Do not carry your phone near your heart.
- Use the ear opposite the pacemaker.
- If you have any reason to suspect that interference is taking place, turn off your phone immediately.

Hearing aids—Some digital wireless phones may interfere with hearing aids. In the event of such interference, you may want to consult your service provider or call the customer service line to discuss alternatives.

Other medical devices—If you use any other personal medical device, consult the manufacturer of the device to determine if it is adequately shielded from external RF energy. Your physician may be able to help you obtain this information.

In health care facilities—Turn your phone off in health care facilities when instructed. Hospitals and health care facilities may be using equipment that is sensitive to external RF energy.

Potentially unsafe areas

Posted facilities—Turn your phone off in any facility when posted notices require you to do so.

Aircraft—FCC regulations prohibit using your phone on a plane that is in the air. Turn your phone off or switch it to Airplane Mode before boarding aircraft.

Vehicles—RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer of the device to determine if it is adequately shielded from external RF energy.

Blasting areas—Turn off your phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres—Turn off your phone when you are in any area with a potentially explosive atmosphere. Obey all signs and instructions. Sparks in such areas could cause an explosion or fire, resulting in bodily injury or death. Areas with a potentially explosive atmosphere are often, but not always, clearly marked.

They include:

- fueling areas such as gas stations
- below deck on boats
- transfer or storage facilities for fuel or chemicals
- vehicles using liquefied petroleum gas, such as propane or butane
- areas where the air contains chemicals or particles such as grain, dust, or metal powders
- any other area where you would normally be advised to turn off your vehicle engine

Using phone with care

Use only in normal position (to ear). Avoid dropping, hitting, bending, or sitting on the phone.

Avoiding magnetic environments

Keep the phone away from magnets which can cause improper functioning of the phone.

Keeping phone dry

Keep the phone dry. Damage can result if the phone gets wet. Water damage is not covered under warranty.

Resetting the phone

If the screen seems frozen and the keypad does not respond to keypresses, reset the phone by completing the following steps:

1. Remove the battery door.
2. Remove and replace the battery.

If the problem persists, return the phone to the dealer for service.

Accessories

Use only Kyocera-approved accessories with Kyocera phones. Use of any unauthorized accessories may be dangerous and will invalidate the phone warranty if said accessories cause damage or a defect to the phone.

Radio Frequency (RF) energy

Your telephone is a radio transmitter and receiver. When it is on, it receives and sends out RF energy. Your service provider's network controls the power of the RF signal. This power level can range from 0.006 to 0.6 watts. In August 1996, the U.S. Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. These guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies in the following reports:

- ANSI C95.1 (American National Standards Institute, 1992)
- NCRP Report 86 (National Council on Radiation Protection and Measurements, 1986)
- ICNIRP (International Commission on Non-Ionizing Radiation Protection, 1996)

Your phone complies with the standards set by these reports and the FCC guidelines.

E911 mandates

Where service is available, this handset complies with the Phase I and Phase II E911 Mandates issued by the FCC.

Hearing Aid Compatibility (HAC)

Some mobile phones and hearing devices (hearing aids and cochlear implants), when used together, result in buzzing, humming, or whining noises detected by the user. Some hearing devices are

more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. The ratings are not guarantees and results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings—Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings—Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you choose the proper rating for your mobile phone. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

For more information about hearing aid compatibility, visit the FCC's Consumer & Governmental Affairs Bureau Web site at www.fcc.gov/cgb/dro.

Battery and charger specifications

Charger	Input	Output
CE90-R2093	100-240 VAC / 50/60 Hz	5V 350mA
CV90-R2672	100-240 VAC / 50/60 Hz	4.5V 1.2A
CV90-R274A	100-240 VAC / 50/60 Hz	4.5V 600mA
Standard Battery (5mm):		
CV90-K3880 3.7V / 790 mAh		

Kyocera Wireless Corp.

www.kyocera-wireless.com

To purchase accessories, visit

www.kyocera-wireless.com/store

Draft

TABLE OF CONTENTS

1	Getting Started	1	Searching contacts	23	
	Phone battery	1	Contacts count	23	
	Phone overview	2	7	Media Gallery	24
	Main menu	6		Accessing folders	24
	Basic navigation	6		Browsing images	24
	Guide conventions	7		Browsing sounds	24
2	Basic Functions	8	8	Settings	25
	Powering up	8		Menu options	25
	Making phone calls	8		Bluetooth®	26
	Answering phone calls	8		Sounds	28
	Ending phone calls	9		Display	29
	Verifying your phone number	9		Convenience	31
	Activating voice dialing	9		Accessories	33
3	Call Features	10		Voice Features	34
	Volume control	10		Network	36
	Hold call	10		Security	38
	Speed dialing	10		Phone information	39
	1-Touch dialing	10	9	Messaging	40
	Voicemail	11		Text messages	40
	Data and fax calls	11		Multimedia messages	41
	Roaming calls	11		Erase messages	44
	Emergency services	12		Working with messages	44
	Airplane mode	12		Message settings	46
4	Text Entry	13	10	Camera	49
	Text entry modes	13		Taking a picture	49
	Text entry quick reference	14		Camera mode options	49
5	Recent Calls	16		Camera indicators and icons	50
	Call lists	16	11	Tools	51
	Call timers	17		Voice memo	51
6	Contacts	18		Scheduler	51
	Viewing Contacts list	18		Alarm clock	53
	Adding contacts	18		Tip calculator	54
	Working with contacts	19		Calculator	54
	Contact groups	22		Timer	55

Stopwatch	55
World clock	55
12 Browser	56
Launching Browser	56
Using Web menu options	56
Searching for Web site	57
Using bookmark	57
Checking Browser Alerts	57
Web Alert	57
13 Downloads	58
Using Downloads	58
Downloading an application	58
Opening an application	59
Viewing application details	59
Removing an application	59
Disabling an application	59
Checking available memory	59
14 Voice Commands	60
Voice dial list	60
Voice commands	60
15 Getting Help	62
Customer support	62
Qualified service	63
Phone accessories	63
Become a product evaluator	63
16 Consumer Limited Warranty	64
Index	66

Phone battery

Installing the battery

To install the battery:

1. With the back of the phone facing you, locate the side notches at the top of the phone.
2. Slide your fingernail into one of the notches to unsnap the back cover.
3. Place the battery in the phone casing with the metal contacts toward the top of the phone.
4. Fit the bottom of the back cover into the shape at the bottom of the battery well.
5. Press the back cover until it snaps into place.




Note: To remove the battery, make sure the phone is turned off.

Charging the battery



You must have at least a partial charge in the battery to make or receive calls.

To charge the battery:

1. Connect the AC adapter to the jack on the bottom of the phone.
2. Plug the adapter into a wall outlet.



The battery icon in the upper-right corner of the screen shows whether the phone is:

- Charging (animated icon)
- Partially charged 
- Fully charged 

Warning: The battery does not charge if you are in a call while it is connected to an AC adapter.

Recharging the battery

You can safely recharge the battery at any time, even if it has a partial charge.

Battery care

General safety guidelines

- Do not disassemble or open the battery.
- Do not crush, bend, deform, puncture, or shred the battery.
- Do not attempt to insert foreign objects into the battery.
- Do not immerse the battery or expose it to water or other liquids. Even if a battery appears to dry out and operate normally,

internal parts can slowly corrode and pose a safety hazard.

- Always keep the battery between 15°C and 25°C (59°F and 77°F). Do not expose the battery to extremes of temperature, fire, or other hazards such as a cooking surface, iron, or radiator.
- Never use any damaged battery.
- Only use the battery for its intended phone.
- Only use the battery with a qualified charger. Use of an unqualified battery charger may present a risk of fire, explosion, leakage, or other hazard. If you are unsure about whether a charger is qualified, contact customer support.
- Do not short-circuit the battery or allow metallic conductive objects—such as keys, coins, or jewelry—to contact the battery's terminals.
- Replace the battery only with another qualified battery. Use of an unqualified battery may present a risk of fire, explosion, leakage, or other hazard. If you are unsure about whether a replacement battery is compatible, contact customer support.
- Promptly dispose of used batteries in accordance with local regulations and recycle if possible. Do not dispose as household waste.
- Supervise all battery usage by children.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a

hard surface, an internal short-circuit can occur and pose a safety hazard. If you suspect battery damage, take it to a service center for inspection.

- Improper battery use may result in fire, explosion, or other hazard.

Common causes of battery drain

- Playing games or using the Web.
- Keeping backlighting on.
- Operating in digital mode when far away from a base station or cell site.
- Using data cables or accessories.
- Operating when no service is available, or service is available intermittently.
- High earpiece and ringer volume settings.
- Repeating sound, vibration, or lighted alerts.

Phone overview


Getting to know your phone

The following illustration shows the phone in open position.


1. Earpiece speaker.
2. Home screen.
3. Navigation key scrolls through lists and text entry fields and accesses shortcuts from the home screen.
4. Left softkey accesses menus and functions.
5. Back key returns you to the previous screen and erases characters in text entry.

6. **Send** key starts or answers a call. Press once to display the All calls list and twice to redial the last number dialed. Press and hold to activate voice command.
7. **Keypad** for entering numbers, letters, or symbols.
8. **Shift *** key changes the text mode in text entry.
9. **0 Next** key cycles through word choices during text entry.
10. **OK** key selects a menu item, or accesses the main menu at the home screen.
11. **Right softkey** accesses the contacts list and other menu options.
12. **Speakerphone** key activates the speakerphone and answers incoming calls.
13. **End** key turns the phone on and off, ends a call or browser session, and returns you to the home screen.
14. **Space #** key enters a space during text entry. Press and hold to activate or deactivate Silent mode.

15. Microphone.



The following illustration shows the phone in closed position. With the phone closed, the keys are locked to prevent accidental key presses.











1. Jack for hands-free headset only (sold separately).
2. Indicator light.
3. Volume key for raising or lowering speaker volume.
4. External screen for displaying time, caller ID, signal, and battery strength.
5. Jack for AC adapter (included) and data cable (sold separately).
6. Camera key for activating camera mode.
7. External speaker.

Warning: Inserting an accessory into the incorrect jack damages the phone.




Common keys

The following list the frequently-pressed keys. Throughout this user guide, these keys are referred as follows:

-  Navigation key
-  OK key
-  Left softkey
-  Right softkey
-  Send key (also referred to as the Call or Talk key)
-  End key (also referred to as the Power key)
-  Back key
-  Speakerphone key

Screen icons

These icons may appear on your phone's screen:

-  The phone is operating in IS95 digital mode.
-  The phone is operating in IS2000 (1X) digital mode.
-  The phone is receiving a signal. You can make and receive calls. Fewer bars indicate a weaker signal.



A call is in progress.



The phone has a standard speed data connection.



The phone is not receiving a signal. You cannot make or receive calls.



Content is DRM protected.



Data service is available and active on your phone. Check with your service provider for availability.



(blinking) The phone is sending high-speed data.



(blinking) The phone is receiving high-speed data.



Data service is available, but the phone is dormant.



Bluetooth wireless technology is enabled (On).



Bluetooth wireless technology is disabled (Off).



The phone is roaming outside of its home service area.



New text message.



New voice message.



New voice and text message.



The phone is set to light up instead of ring.



The phone is set to vibrate or to vibrate and then ring.



The speakerphone is on.



Position location is set to your service provider and to emergency services.



Position location is set to emergency services only.



The phone is in camera mode.



Flash on.



The phone is set to auto answer.



The phone is in privacy mode, accessing a secure Web site or with files locked.



The alarm clock is set.



The battery is fully charged. The more black bars, the fuller the charge.



The phone is in video mode.

Main menu

The contents of the main menu are as follows:

Recent Calls

All
Incoming
Outgoing
Missed
Erase Call List
Call Timer

Contacts

View All
Add New
View Groups
Speed Dial List
Voice Dial List
Contacts Count

Media Galley

Images
Sounds

Settings

Bluetooth
Sounds
Display
Convenience
Voice Features
Accessories
Network
Security
Phone Info

Messaging

New Text Msg
New Pic Msg
Voicemail
Inbox
Sent Msgs
Outbox
Saved Msgs
Drafts
Msg Settings
Erase Msg

Camera

Launches the Camera

Tools

Voice Memo
Scheduler
Alarm Clock
Tip Calculator
Calculator
Timer
Stopwatch
World Clock

Browser

Launches the Browser

Downloads

MobileShop
Settings
Help

Note: The menu items on your phone can change depending on the services provided. Check with your service provider.

Basic navigation

You press your phone keys to access the various menus and other features of your phone. Some of the basic frequently-used keys are as follows:

- **Left softkey:** Selects items that appear on the lower left of the display. At the home screen, you can select **Menu**.
- **Right softkey:** Selects items that appear on the lower right of the display. At the home screen, you can select **Contacts**.
- **OK key:** Selects a menu item.
- **Navigation key:** Scrolls through menus and options. You can access the following shortcuts from the home screen.
 - Press and hold left to launch Browser.
 - Press and hold right to record a voice memo.
 - Press and hold up to access the custom menu.
 - Press and hold down to view recent calls list.
- **Back key:** Returns to the previous menu level.

- **End/Power key:** Returns to the home screen.

Guide conventions

In this guide the following conventions are used when describing phone features.

Select means to press the left or right softkey, or the **OK** key to select an item on the display. For example, “select **Menu**” tells you to physically press the left softkey to choose **Menu** from the display.

Press means to press a phone key. For example, “press the **Send** key to make a phone call” tells you to press the **Send** key on your phone.

Scroll means to press the **Navigation** key to move through a list on the display. For example, “scroll through your **Contacts** list to choose a contact” means to press the **Navigation** key up or down to scroll through the list on the display.

The greater than symbol “>” tells you to select an option from a menu or list. For example, “**Menu > Settings**” means to:

1. At the home screen, press the left softkey to select **Menu**.
2. Scroll to the **Settings** option.
3. Press the **OK** key to select **Settings**.

2 BASIC FUNCTIONS

This section explains basic functionality of your phone. For more detailed explanations of your phone's features, refer to the later chapters.

Powering up

To turn on your phone, press and hold the **End** key and wait until the phone display lights up.

To turn off your phone, press and hold the **End** key until the phone turns off.

Making phone calls

Make sure you are in an area where a signal can be received. Look for the signal strength icon on the home screen. The more bars you see in this symbol, the stronger the signal. If there are no bars, move to where the signal strength is better.

When the phone has been idle for a while with no signal, it changes to power save mode. When you see “Power Save” on your phone's screen, press any key to return to normal operating mode.

You can make a phone call in one of the following ways.

Call using numbers

At the home screen:

1. Enter a phone number.
2. Press the **Send** key.

Call using contacts

At the home screen:

1. Select **Contacts** to open your Contacts list.
2. Highlight a contact and press the **Send** key.

Call using voice commands

You can use voice commands to call a contact from your voice dial list or to dial a phone number. For more information, see “Voice Commands” on page 60.

Redial a number

At the home screen:

1. Press the **Send** key once to open your call history.
2. Highlight a phone number or contact and press the **Send** key.

Tip: To redial the last number called, received or missed, press the **Send** key twice.

Answering phone calls

When a call comes in, the phone rings, vibrates, or lights up. The phone number of the caller also appears if it is not restricted. If the number is stored in your Contacts list, the contact's name appears.

There are several ways you can answer a phone call:

Answer using earpiece

Press the **Send** key or any key with Any Key Answer enabled. For more information, see “Any key answer” on page 33.

Answer using speakerphone

Press the **Speakerphone** key.

Answer using flip

You can set the phone to answer immediately when you open the flip. This feature does not apply to incoming data or fax calls. For more information, see “Open to answer” on page 33.

Ending phone calls

To end a phone call, press the **End** key or close the flip.

Verifying your phone number

To verify your phone number, select **Menu > Settings > Phone Info > Build Info**.

Activating voice dialing

At the home screen:

1. Press and hold the **Send** key.
2. Follow the prompts.

For more information, see “Voice Commands” on page 60.

3 CALL FEATURES

This chapter describes call features such as volume, holding calls, speed dialing, and other features.

Volume control

You have several ways to control the volume of your phone.

Adjust volume during a call

To adjust the earpiece volume during a call, press the **Volume** key up or down.

Use the speakerphone

Your phone has a built-in speakerphone. To turn on the speakerphone, press the **Speakerphone** key.

The speakerphone icon appears on the home screen when the speakerphone is on.

To turn off the speakerphone, press the **Speakerphone** key again.

Note: If you press the **Speakerphone** key during an incoming call, you will answer the call.

Silence an incoming call

Press the **Volume** key to silence an incoming call, especially if you set the phone to answer immediately when you open the flip. For more information, see “Open to answer” on page 33.

With the flip open, you can also press the **End** key or select **Silence** to silence the phone without answering the call. To silence the phone and answer the call, press the **End** key and then press the **Send** key.

Warning: In the absence of voicemail, this feature drops the call.

Hold call

Use this feature to place incoming calls on hold until you are ready to answer them. See “Hold call” on page 32.

Speed dialing

Use the Speed Dial feature to assign a one- or two-digit shortcut to a contact. Before you can use speed dialing, you must save a phone number as a contact and assign a speed dial location to it. See “Contact number” on page 19.

To call a contact that has a speed dial location.

1. Enter the one- or two-digit speed dial location.
2. Press the **Send** key.

1-Touch dialing

This feature is the fastest way to speed dial a contact that has a speed dial location. See “1-Touch dialing” on page 31.

Voice mail

Configure your voicemail

Before your phone can receive voicemail messages, you must set up a password and record a personal greeting with your service provider. When you have set up your voicemail, all unanswered calls to your phone are automatically transferred to voicemail, even if your phone is in use or turned off.

1. Press and hold the 1 key.
2. Follow the system prompts to create a password and record a greeting.

Check voicemail

When a voice message is received, your screen displays a notification along with a voicemail message icon at the top of your screen. The symbol flashes if the message is urgent. If you see a notification:

1. Select **Call** to call your voicemail number.
2. Follow the system prompts to retrieve the message.

Note: To clear the screen without checking messages, select **Ignore**.

If you see only the voicemail message icon:

1. Select **Menu > Messaging > Voicemail**.
2. If you have set up your voicemail, select **Call** to call your voicemail number.

3. Follow the system prompts to retrieve the message.

Set voicemail alert

You can set the phone to beep or vibrate every five minutes to remind you that you have voicemail. For more information, see “Alerts” on page 46.

Data and fax calls

Your phone may be able to receive certain data or faxes. See “Data and fax calls” on page 36.

Roaming calls

Control roaming calls

You can restrict your phone from making a call when roaming. See “Roam option” on page 37.

Set roaming alert

You can set the phone to alert you when you roam outside of your home service area. See “Roaming service alert” on page 36.

Set roam ringer

You can set a ringer to indicate when an incoming call is subject to roaming charges. See “Roam ringer” on page 28.

Set call guard

You can set the phone to warn you before you answer or place a call while roaming. See “Roam call alert” on page 37.

Emergency services

Call emergency service

You can call an emergency code, even if your phone is locked or your account is restricted.

When you call, your phone enters Emergency mode. This enables the emergency service exclusive access to your phone to call you back, if necessary. To make or receive regular calls after dialing the code, you must exit this mode.

To dial an emergency code:

1. Enter your 3-digit emergency code.
2. Press the **Send** key.

Note: Regardless of your 3-digit emergency code (911, 111, 999, 000, etc.), your phone operates as described.

Exit emergency services

When you have completed the emergency call:

1. Select **Exit**.
2. Select **Exit** again to confirm your choice.

Note: To determine who has access to your location, see “Location” on page 37.

Airplane mode


While in an airplane, you can set your phone to Airplane mode where your phone does not emit RF signals. See “Airplane mode” on page 31.

4 TEXT ENTRY

You can enter letters, numbers, and symbols in contacts, text messages, and your banner.???

Text entry modes

The current text entry mode (and capitalization setting, when applicable) are indicated by icons.



The text entry screen has the following features:

1. The number of remaining characters you can type. Allowed length of messages can vary depending on your service.
2. Text entry fields.
3. Current capitalization setting.
4. Current text entry mode.

There are six text entry modes:

- **Insert QuickText:** quick text mode.
- **Case Change:** case change mode.
- **Normal Alpha:** normal alpha mode.
- **Rapid Entry:** rapid entry mode.

- **Numbers Only:** numbers only mode.
- **Add Symbol:** symbol mode.

Note: The mode you start in depends on the task you are doing. For example, when entering a phone number, you are in numbers only mode. When entering a name for a contact, you are in normal alpha mode.

Enter numbers

- To enter a number while in numbers only mode, press a number key once.
- To enter a number while in normal alpha or rapid mode, press and hold a number key until the number appears on the screen.

Enter words letter by letter

1. Press a key once for the first letter, twice for the second letter, and so on.
2. Wait for the cursor to move right and enter the next letter.

Note: To enter a space, press the **Space #** key.

Enter words quickly

When you press a series of keys using rapid mode, your phone checks its dictionary and guesses at the word you are trying to spell.

1. For each letter of the word you want, press the key once. For example, to enter the word "any" press the 2 > 6 > 9 keys.

2. If the word doesn't match what you want, press the 0 **Next** key to check other word matches.
3. When you see the word you want, press the **Space #** key.

Enter symbols

While entering text in normal alpha mode, you can enter symbols by pressing the 1 key until you see the symbol you want. Using this method, you have access to the following symbols:

. @ ? ! - , & : ' "

To access the full set of symbols:

1. From the text entry screen, select **Options > Add Symbol**.
2. Scroll up or down to view the list of symbols.
3. Press the number key corresponding to the symbol to enter it.

Change default text entry mode

You can change the default text entry mode when creating a text message. For more information, see "Default text" on page 47.

Change modes

Sometimes you need to change modes. For example, to enter numbers in an email address while in normal alpha mode, you must change to numbers only mode, enter the numbers, and then change back to normal alpha mode to complete the address.

To change text entry modes, press and hold the **Shift *** key until the icon for your desired mode appears at the top of the screen. You can also select **Options** and a different mode.

Capitalization

You can change capitalization at any time while entering text. Simply press the **Shift *** key to choose upper or lower case while in normal alpha mode.

Text entry quick reference

This table gives instructions for entering letters, numbers, and symbols.

To..	Do this...
Enter a letter	Use normal alpha mode and press a key until you see your desired letter. For more options, see “Text entry modes” on page 13.
Enter a number	Use numbers only mode and press a key. For more options, see “Text entry modes” on page 13.
Enter a symbol	In either normal alpha mode, press the 1 key until you find your desired symbol. For more options, see “Text entry modes” on page 13.
Enter a space	Press the Space # key.
Erase a character	Press the Back key.
Erase all characters	Press and hold the Back key.
Move cursor right or left	Scroll left or right.
Move cursor up or down	Scroll up or down.
Change text entry modes	Press and hold the Shift * key.
Capitalize any letter	In normal alpha mode, press the Shift * key. Choose uppercase.
Lowercase any letter	In normal alpha mode, press the Shift * key. Choose lowercase.
Initial caps	In normal alpha mode, press the Shift * key. Choose sentence case.
Select soft options on screen	Press the appropriate left or right softkey.

5 RECENT CALLS

Call lists

Details on the calls you made, received, or missed are stored in the Recent Calls list and are identified by the following icons:



Outgoing call



Incoming call



Missed call (flashing)

View recent calls

1. Select **Menu > Recent Calls** and one of the following:
 - **All** displays all calls made or received.
 - **Incoming** displays calls answered.
 - **Outgoing** displays calls made.
 - **Missed** displays calls received, but not answered.
2. Highlight a recent call.
3. Press the **Send** key to call the number or select **Options** and one of the following:
 - **Save** creates a new contact or **View** displays the contact details.
 - **Send Text Msg** sends a text message to the number.

- **Send Picture Msg** sends a multimedia message to the number.
- **Erase Record** deletes the call from the call list.

Note: If the phone number is classified as “secret,” you must enter your four-digit lock code to access it.

Missed calls

When you have missed a call, “Missed Call” appears on your screen. You can do one of the following:

- To clear the screen, select **OK**.
- To view the call details, select **Calls** and press the **OK** key.
- To return the call, select **Calls** and press the **Send** key.

Set alert for missed calls

You can set an alert to beep every five minutes after you have missed a call. See “Alerts” on page 46.

Erase call list

You can erase your phone's call lists.

1. Select **Menu > Recent Calls > Erase Call List > All, Incoming, Outgoing, or Missed**.
2. Select **Yes**.

Call timers

For more information, see “Minute alert” on page 33.

View call timers

To track the number and duration of calls made and received on your phone, select **Menu >**

Recent Calls > Call Timer and one of the following:

- **All** tracks all calls you have made and received. You cannot reset this timer.
- **Recent** tracks all calls you have made and received since you last reset this timer. To reset this timer to zero, select **Reset**.
- **Home** tracks calls you have made and received in your home service area since you last reset this timer. To reset this timer to zero, select **Reset**.
- **Roam** tracks calls you have made and received while roaming since you last reset this timer. To reset this timer to zero, select **Reset**.
- **Incoming** tracks calls you have received since you last reset this timer. To reset this timer to zero, select **Reset**.
- **Outgoing** tracks calls you have made since you last reset this timer. To reset this timer to zero, select **Reset**.

Time your calls

Your phone can alert with a short beep ten seconds before each minute passes during a call.

6 CONTACTS

Use your phone's Contacts list to store information about a person or company. Each contact entry can have up to six phone numbers, two email addresses, two Web addresses, two street addresses, and a space for notes.

Viewing Contacts list

To view existing contacts in your phone, select **Menu > Contacts > View All**. Your Contacts list is listed alphabetically.

Tip: You can also select **Contacts** from the home screen to view the directory.

Scroll to a contact and do one of the following:

- Press the **Send** key to call the highlighted contact.
- Press the **OK** key to view the highlighted contact's details.
- Select **New** to add a new contact.
- Select **Options** and choose one of the following:
 - **Call** to make a call.
 - **Send Text Msg** to send a text message.
 - **Send Pict Msg** sends a multimedia message.
 - **View Contact** to view contact details.
 - **Edit Contact** to edit contact details.
 - **Erase Contact** to erase the contact.
 - **Send as vCard** to send contact as a vCard.

- **Send All** to send all contacts via Bluetooth.
- **Contacts Menu** to access your contacts.

Adding contacts

Add contact from home screen

To add a contact to your Contacts list:

1. From the home screen, enter a phone number to save (including the area code).
2. Select **Save > Save New Contact**.
3. Enter a name for the contact. For more information, see “Text Entry” on page 13.
4. Enter additional phone numbers, email addresses, Web addresses, and notes, if needed. Scroll up or down to move through the contact fields.
5. When you are done entering the information, select **Save**.

Add contact from contacts menu

To add a contact to your Contacts list:

1. Select **Menu > Contacts > Add New**.
2. Enter a name for the contact. When you are done, scroll down to move to the next field. For more information, see “Text Entry” on page 13.
3. Enter a primary number for the contact.

4. Enter additional phone numbers, email addresses, Web addresses and note, if needed. Scroll up or down to move through the contact fields.
5. When you are done entering information, select **Save**.
4. Edit or add phone numbers, email addresses, Web addresses, and notes. Scroll up or down to move through the contact fields.
5. When you are done entering the information, select **Save**.

Add code or extension

When you save the phone number of an automated service, you may include a pause to stop dialing, where you can wait to dial an extension.

1. From the home screen, enter a phone number.
2. Select **Options** and a type of pause:
 - **Time Pause** causes the phone to stop dialing for two seconds.
 - **Hard Pause** causes the phone to stop dialing until you select **Options > Release** while making the call.
3. Enter the remaining numbers.
4. Complete the contact and select **Save**.

Working with contacts

Contact details

To edit the details of an existing contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, select **Edit**.

Contact name

To work on the name of an existing contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to the contact name.
4. Select **Options** and one of the following:
 - **Ringer** assigns a specific ringer to the contact.
 - **Picture** assigns a specific picture to the contact.
 - **Erase Contact** deletes the entire contact.
 - **Send as vCard** sends the contact as a vCard.

Contact number

To work on the number of an existing contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to a contact number.
4. Select **Options** and one of the following:
 - **Call** calls the contact.

- **Send Text Msg** sends a text message.
- **Send Pict Msg** sends a multimedia message.
- **Prepend** displays the contact's detail screen for you to change the number (adding an area code) or other data of the contact.
- **Add Speed Dial** adds the number to your speed dial list.
- **View Number** displays the number.
- **Erase Number** deletes the number from the contact.
- **Secret/Not Secret** makes the number secret, hiding it from the screen until you enter the lock code.
- **Primary Number** makes this number the primary number for the contact.
- **Send as vCard** sends the contact as a vCard.
- **Add to Group** adds the number to the business, personal, or custom group.

Contact email address

To work on the email address of an existing contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to 'a contact email address.

4. Select **Options** and one of the following:
 - **Send Text Msg** sends a text message.
 - **Send Pict Msg** sends a multimedia message.
 - **View Address** displays the email address.
 - **Add to Group** adds the email address to the business, personal, or custom group.
 - **Erase Address** deletes the email address from the contact.
 - **Secret/Not Secret** makes the email address secret, hiding it from the screen until you enter the lock code.
 - **Send as vCard** sends the contact as a vCard.

Contact Web address

To work on the Web address of an existing number.

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to a contact Web address.
4. Select **Options** and one of the following:
 - **Launch Web** launches the Browser and goes to the Web address.
 - **Send Pict Msg** sends a multimedia message.
 - **View Web** displays the Web address.

- **Erase Web** deletes Web address from the contact.
- **Secret/Not Secret** makes the Web address secret, hiding it from the screen until you enter the lock code.
- **Send as vCard** sends the contact as a vCard.

Contact street address

To work on the street address of an existing number:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to a contact street address.
4. Select **Options** and one of the following:
 - **View Address** displays the street address.
 - **Erase Address** deletes street address from the contact.
 - **Secret/Not Secret** makes the street address secret, hiding it from the screen until you enter the lock code.
 - **Send as vCard** sends the contact as a vCard.

Contact note

To work on the note of an existing number:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.

3. At the contact's detail screen, scroll to the contact note.
4. Select **Options** and one of the following:
 - **View Note** displays the note.
 - **Erase Note** deletes the note from the contact.
 - **Secret/Not Secret** makes the note secret, hiding it from the screen until you enter the lock code.
 - **Send as vCard** sends the contact as a vCard.

Assign ringer

To assign a ringer to a contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to the contact name.
4. Select **Options > Ringer > Assign Ringer** and a ringer from the list. Scroll to play the ringers.

Assign picture

To assign a picture to a contact:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, scroll to the contact name.

4. Select **Options > Picture** and one of the following:
 - **Assign Picture** assigns a picture to the contact. Select **Camera Images** or **Images > Saved Images** or **Caller IDs** to choose what kind of picture to assign.
 - **Unassign Picture** removes the assigned picture from the contact.
 - **Take Picture Now** activates camera mode.

Note: With Mobile Phone Tools (MPT) for Kyocera you can transfer digital pictures to your phone. To purchase MPT or other accessories visit www.kyocera-wireless.com/store.

Assign number type

After you assign a number type, an icon appears in front of the contact number.

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. At the contact's detail screen, select **Edit**.
4. Press down twice to scroll to the number type dropdown and press the **OK** key.
5. Select **General**, **Work**, **Home**, **Mobile**, **Pager** or **Fax**. The appropriate icon appears next to the number in your phone lists.
6. Select **Save**.

Send a vCard

To send contact information as a message:

1. Select **Menu > Contacts > View All**.
2. At the Contacts list, select a contact.
3. Select **Options > Send as vCard** and one of the following:
 - **via MMS**
 - **via Bluetooth**
 - **To Printer**
4. Complete the appropriate task to send the contact information.

Contact groups

You can assign your contacts to groups. Your phone comes with two default groups, **Business** and **Personal**. You can also create your own groups.

1. Select **Menu > Contacts > View Groups**.
2. Select **New**.
3. Enter a name for the group, and select **Next**.
4. Select the contacts from the list provided. A check mark appears next to each selection you make. You can also remove checkmarks.
5. After selecting your desired contacts, select **Done**.

Your new group appears the next time you view your groups.

Use groups

1. Select **Menu > Contacts > View Groups**.
2. At the Groups list, scroll to a group.
3. Select **Options** and one of the following:
 - **View** displays the group details.
 - **Edit** enables editing the group.
 - **Erase** deletes the group.
 - **Send Text Msg** sends a text message.
 - **Send Pict Msg** sends a multimedia message.
 - **Send as vCard** sends the group as a vCard.

Customize groups

1. Select **Menu > Contacts > View Groups**.
2. At the Groups list, select a group.
3. Select **Options** and one of the following:
 - **Ringer** assigns a ringer to the group.
 - **Picture** assigns a picture to the group.
 - **Erase** deletes the group.
 - **Edit** enables editing the group.

Searching contacts

To find a phone number or contact, you can search the Contacts list, check the Frequent List, or use Fast Find.

Contacts list

To search your Contacts list, select **Menu > Contacts** and one of the following:

- **View All** lists the entire Contacts list.
- **View Groups** lists the existing groups.
- **Speed Dial List** or **Voice Dial List** shows the contacts on the specified list.

You can also use the **Contacts** shortcut from the home screen to view the Contacts list. To quickly get down the list, enter the first letter of the contact. You can skip to that letter of the alphabet.

Frequent list

With Frequent List enabled, you can see 15 of your most frequently called contacts. For more information, see “Frequent list” on page 33.

Fast find

With Fast Find enabled, you can press one or two keys to view close matches of the number. For more information, see “Fast find” on page 32.

Contacts count

To check the status of the stored contacts on the phone (with a maximum of 500), select **Menu > Contacts > Contacts Count**.

7 MEDIA GALLERY

Your phone stores images and sounds, and displays those files on the phone's screen.

Accessing folders

To access the folders where your phone stores media files, select **Menu > Media Gallery** and one of the following:

- **Images** contains image files that are preloaded, downloaded, saved or created.
- **Sounds** contains sound files that are preloaded, downloaded, saved or created.

Browsing images

To browse the Images folder:

1. Select **Menu > Media Gallery > Images** and one of the following:
 - **Camera Images** displays the images captured with your phone camera.
 - **Saved Images** displays the images available.
 - **Wallpapers** displays the wallpapers available.
 - **Screensavers** displays the screen savers available.
 - **Caller IDs** displays the pictures you can assign as caller IDs.

2. Depending on your selection, you can select **View** or **Options** to complete your desired task.

Browsing sounds

To browse the Sounds folder:

1. Select **Menu > Media Gallery > Sounds** and one of the following:
 - **Saved Sounds** displays the sounds available.
 - **Ringers** displays the ringers available.
 - **Voice Memos** contains the voice memos you have made.
2. At the folder list, highlight a file.
3. Depending on your selection, you can select **Send**, **Assign**, **Play**, or **Options** to complete your desired task.???

Menu options

The contents of the Settings menu are as follows:

Bluetooth

- On/Off
- My Devices
- Settings

Sounds

- Ringers
- Ringer Mode
- Volume
- Flip Sounds
- Pwr On/Off
- Key Sounds

Display

- Wallpaper
- Screensaver
- Main Menu View
- My Banner
- My Ticker
- Backlighting
- Brightness
- Language
- Time/Date Format

Convenience

- Airplane Mode
- Auto-Hyphen
- 1-Touch Dialing
- Auto Redial
- Hold Call
- Fast Find
- Frequent List
- Missed Call Alert
- Minute Alert
- Open to Answer
- Any Key Answer

Voice Features

- Automatic Add
- Expert Mode
- Display Results
- Digit Lengths
- Voice Answer
- Voice Wake-Up
- Voice Training

Accessories

- Headset Sounds
- Auto-Answer
- Pwr Backlighting
- Com Port Speed
- TTY Device
- Hearing Aid

Network

- Data/Fax Calls
- Privacy Alert
- Voice Privacy
- Roam/Svc Alert
- Roam Option
- Set Phone Line
- Web Alert
- Roam Call Alert
- Location

Security


- Lock Phone
- Limit Calls
- Emergency Numbers
- Erase Contacts
- New Lock Code

Phone Info

- Build Info
- Icon Keys

Note: Some features are not available on all phones. Check with your service provider.

Bluetooth®

The Bluetooth® wireless technology on your phone enables wireless connectivity with accessories such as portable or installed hands-free car kits, headsets, handsets, computers, PC cards and adapters, PDAs, and speakers. You must use a Bluetooth wireless technology device (compatible with Class 2 Bluetooth wireless technology, version 1.2) in order to use this phone wirelessly. Bluetooth wireless technology accessories have the  symbol. For additional information on carrier-supported profiles and third-party accessory compatibility for Bluetooth wireless technology, visit www.kyocera-wireless.com/support.

Turning Bluetooth on

You must turn on your phone's Bluetooth feature to use it with Bluetooth devices. Select **Menu > Settings > Bluetooth > On/Off** and one of the following:

- **On Visible** allows other devices to find your phone.
- **On Invisible** hides your phone for all devices except those listed in your My Devices.
- **Off** prohibits your phone from being used with any Bluetooth device. To prolong battery life, it is recommended to set **Bluetooth to Off** when you are not using it.

When you turn on Bluetooth the first time, you are prompted to do a device search. Then you can pair with a device.

Pairing

You must first “pair” your phone with the Bluetooth wireless technology enabled device to allow your phone to communicate with it. Refer to the following instructions for setting up Bluetooth wireless technology in conjunction with the user guide provided with your Bluetooth device.

1. Select **Menu > Settings > Bluetooth > On/Off > On Visible** or **On Invisible**.
2. Prepare the Bluetooth device (Bluetooth accessory) for pairing as described in the other device's user guide.
3. Select **Menu > Settings > Bluetooth > My Devices > Find New**. Your phone then searches and detects visible Bluetooth wireless technology enabled devices in the vicinity.
4. With devices found, select **Add** to see the list.
5. Highlight your desired device and select **Add**.
Note: When pairing is initiated from another Bluetooth device, you are prompted to accept or reject the pairing.
6. If necessary, enter the password provided in the Bluetooth device's user guide and select **OK**.

Your phone waits for the device's response. With the password accepted, the device shows in **My Devices**.

Using Bluetooth

Before you can use the Bluetooth wireless technology functions of your phone, you must get your phone ready to communicate with a device. This is called “connecting.”

Connecting to a device

To connect your phone to an audio Bluetooth device:

1. Select **Menu > Settings > Bluetooth > My Devices**.
2. At the device list, highlight a device and select **Connect**.

A notification appears confirming the connection. You can now use the device with your phone.

Disconnecting from a device

To disconnect your phone from an audio Bluetooth device:

1. Select **Menu > Settings > Bluetooth > My Devices**.
2. At the device list, highlight a device and select **Disconnect**.

Device list options

You can change or review the information about each device you paired with your phone.

1. Select **Menu > Settings > Bluetooth > My Devices**.
2. Highlight your desired device.
3. Select **Options** and one of the following:
 - **Rename** to rename the device.
 - **Delete** to remove the device from your phone if you are no longer going to use it.
 - **Services** to view a description of the device (such as Headset, Handsfree, Object Push, and Serial Port).

Bluetooth settings

You can set how your phone interacts with Bluetooth devices. Select **Menu > Settings > Bluetooth > Settings** and one of the following:

- **My Name** changes the name of your phone for other devices it is paired with to identify.
- **Visible Duration** sets the time your phone remains visible to other devices.
- **Services** shows the list of the Bluetooth wireless technology service protocol supported by your phone.
- **OBEX Authentication** enables or disables OBEX authentication.

Sounds

Your phone has several settings that control the sound. You can select from a variety of ringers and control the volume.

Ringers

You can change the ringer for your phone. You can also assign ringers for different tasks.

Ringer types

Your phone has multiple ringers you can choose to use for all incoming calls, incoming business calls, and incoming personal calls.

1. Select **Menu > Settings > Sounds > Ringers > Ringer Type, Business Ringer, or Personal Ringer.**
2. Select a ringer. (Scroll down the list to hear the ringers.)

Roam ringer

Your phone can alert you to roaming calls with a specific ringer. Select **Menu > Settings > Sounds > Ringers > Roam Ringer > Enabled.**

Ringer mode

Your phone is set to make sounds when you receive calls, press keys, navigate through menus, and receive alerts (such as new messages).

You can silence all sounds and set the phone to vibrate or light up when you receive calls and alerts.

Select **Menu > Setting > Sounds > Ringer Mode** and one of the following:

- **Normal Sounds** rings for the incoming call or alert (in effect, returning phone to a non-silent mode).
- **Vibrate Only** vibrates for the duration of the incoming call or other alerts.
- **Vibe Then Ring** vibrates for the first 10 seconds and then rings for the remainder of the incoming call alert.
- **Lights Only** lights up for the duration of the incoming call or other alerts.

You can also press and hold the **Space #** key (or the **Volume** key???) to toggle between **Vibrate Only mode** and **Normal Sounds mode.**

Note: The phone rings when attached to an external power source (such as a charger), even if all sounds have been silenced.

Volume

You can control the volume of your phone's features.

Volume controls

To control the volume of the phone's ringer, speakerphone, earpiece, and keypad:

1. Select **Menu > Settings > Sounds > Volume > Ringer Volume, Spkrphone Volume, Earpiece Volume, or Key Volume.**
2. Scroll right to increase the volume or left to decrease the volume.

3. Press the **OK** key to save.

Smart volume

To automatically adjust the volume during a call, based on surrounding noise levels, select **Menu > Settings > Sounds > Volume > Smart Volume > Enabled**.

Flip sounds

To assign specific sounds for when your phone's flip opens or closes:

1. Select **Menu > Settings > Sounds > Flip Sounds > Flip Open** or **Flip Closed**.
2. Select a sound. (Scroll down the list to hear the sounds.)

Power on/off

Your phone plays a sound when powering on and off. Select **Menu > Settings > Sounds > Pwr On/Off > Enabled**.

Key Sound

To choose the sound the phone makes when you press its keys, select **Menu > Settings > Sounds > Key Sound > Tone, Click, or Off**.

Display

Wallpaper

You can select a wallpaper for your phone's home screen. Select **Menu > Settings > Display > Wallpaper** and one of the following options:

- Scroll to select a wallpaper.
- Select **Options > View** to see the enlarged picture.
- Select **Options > Saved Images** to select an image from your images folder.
- Select **Options > Camera Pictures** to select a picture taken with your phone's camera.
- Select **Options > Details** to view the file details.

Screensaver

Screensavers appear on the home screen, activated 10 seconds after the last keypress. Incoming calls and alerts override the screensavers. Select **Menu > Settings > Display > Screensaver** and one of the following options:

- Scroll to select a screensaver.
- Select **Options > View** to see the enlarged picture.
- Select **Options > Saved Images** to select an image from your images folder.
- Select **Options > Camera Pictures** to select a picture taken with your phone's camera.
- Select **Options > Details** to view the file details.

Main menu view

To display menus in various formats, select **Menu > Settings > Display > Main Menu View** and one of the following:

- **Grid** displays icons of each menu item, with its name at the bottom of the screen.
- **List** displays a list of each menu item.

The next time you select **Menu** from the home screen, you see the menu style you selected.

My banner

The banner is the personal label for your phone, which appears on the home screen above the time and date. To change your banner:

1. Select **Menu > Settings > Display > My Banner**.
2. Select **Edit** and press the **Back** key to clear the current banner.
3. Enter your new text (no more than 14 characters) and select **Save**.

My ticker

The ticker is the personal label for your phone. To change your ticker:

1. Select **Menu > Settings > Display > My Ticker**.
2. Select **Options > Edit** and press the **Back** key to clear the current ticker.
3. Enter your new text and select **Save**.

Backlighting

Your screen lights up while you are in a call or when you press a key on the keypad. The backlight automatically turns off when the phone is inactive.

Set backlight duration

You can set the length of time that bright backlighting remains on. Select **Menu > Settings > Display > Backlighting > Duration** and one of the following:

- **Disabled** turns backlighting off.
- **7 seconds, 15 seconds, or 30 seconds (default)** turns backlighting on for a set time after your last keypress.
- **7 sec/in call, 15 sec/in call, or 30 sec/in call** turns backlighting on for the duration of a call, and for a set time after your last keypress.

Note: The “in call” settings drain the battery more quickly.

Power save mode

You can activate the power save mode to dim the backlight and conserve battery life. The power save mode sets the backlight of the phone to the lowest level. Select **Menu > Settings > Display > Backlighting > Pwr Save Mode > On**.

Brightness

To change the brightness of the display:

1. Select **Menu > Settings > Display > Brightness**.

2. Scroll to change the brightness.
3. Press the **OK** key to save.

Language

Your phone can display alternative languages. Select **Menu > Settings > Display > Language** and a language.

Time and date format

Your phone can display different time/date formats. Select **Menu > Settings > Display > Time/Date Format** and a format.

Convenience

Your phone has several settings that may make your phone more convenient to use.

Airplane mode

While in an airplane, it is normally required that you turn off your mobile phone because it emits RF signals that interfere with air traffic control. In Airplane mode, however, your phone does not emit RF signals. You cannot make or receive calls, send text messages, or use the browser, but you can play games, use the Scheduler, set the clock, and make emergency calls to the designated emergency numbers. Please check with uniformed personnel before operating your phone in Airplane mode.

To set your phone to Airplane mode, select **Menu > Settings > Convenience > Airplane Mode > OK > Enabled**.

If you turn on Airplane mode, you can also set the time and date manually.

Auto-hyphen

Auto-hyphenation, when enabled, automatically inserts hyphens into your phone numbers to be consistent with the U.S. dialing plan, such as 1-222-333-4444. Select **Menu > Settings > Convenience > Auto-Hyphen > Enabled**.

1-Touch dialing

The 1-Touch Dialing feature is the fastest way to call a speed dial location. To call a contact with speed dial, press and hold the speed dialing location.

Note: If it is a two-digit number, press the first digit briefly, then press and hold the second digit. For example, if the speed dialing location is 15, press 1 briefly, then press and hold 5.

To use 1-Touch dialing, you must enable 1-Touch dialing on your phone and have a speed dial location assigned to a contact.

To enable 1-touch dialing, select **Menu > Settings > Convenience > 1-Touch Dialing > Enabled**.

Auto redial

Use this setting to select whether to enable your phone to repeat a call when the called number is busy or there is no answer. Select **Menu > Settings > Convenience > Auto Redial > Enabled or Disabled**.

Hold call

The Hold Call feature enables you to place incoming calls on hold until you are ready to answer them.

Note: The Hold Call feature does not work with the Open to Answer feature enabled. See “Open to answer” on page 33.

Enable hold call feature

1. Select **Menu > Settings > Convenience > Hold Call > Enabled.**

If you have not recorded a hold message, you need to record one, such as “Please hold. I’ll answer in a minute.”

2. Record the message twice, as prompted.
3. Select **Save** to save the message or **Options** and one of the following.
 - **Play** to replay your message.
 - **Re-Record** to record your message again.
 - **Exit** to exit.

The next time a call comes in, you can place it on hold.

Place a call on hold

You can place a call on hold once you have enabled this feature.

Note: If you are already on a call and you receive another call, you cannot place the incoming call on hold. With no call waiting enabled, the call goes to voicemail.

When a call comes in, do the following:

1. Select **Hold Call** to place the caller on hold and play your recorded hold message.
2. Select **Answer** to speak to the caller on hold or **End Call** to hang up without speaking.

Change the hold message

1. Select **Menu > Settings > Convenience > Hold Call > Re-Record Msg.**
2. Record the message twice, as prompted.
3. Select **Save** to save the message or **Options** and one of the following.
 - **Play** to replay your message.
 - **Re-Record** to record your message again.
 - **Exit** to exit.

Fast find

With Fast Find enabled, you can press one or two keys to view close matches of the number you are looking for.

1. From the home screen, press the keys corresponding to the letters of the name you want to find. A matching contact or speed dial entry appears.
2. Scroll to your desired contact and press the **Call** key to call the number.

To enable Fast Find, select **Menu > Settings > Convenience > Fast Find > Enabled.**

Frequent list

From the home screen, select **Contacts**. The last 15 of your most frequently called contacts appear with the Frequent List enabled. Scroll past the double line to view the entire Contacts list.

To enable Frequent List, select **Menu > Settings > Convenience > Frequent List > Enabled**.

Missed call alert

Your phone can alert you after you missed a call. Select **Menu > Settings > Convenience > Missed Call Alert** and one of the following:

- **Disabled** turns off the sound alert.
- **Vibrate, Beep, Freeway, Game, Bloop, Winner, or Zilofon** sets the phone to alert you once when a new message is received.
- **Vibrate & Remind, Beep & Remind, Freeway & Remind, Game & Remind, Bloop & Remind, Winner & Remind, or Zilofon & Remind** sets the phone to notify you once when a new message is received and then notify you again every five minutes. To stop a reminder alert, select **Ignore**.

Minute alert

Your phone can alert with a short beep ten seconds before each minute passes during a call. Select **Menu > Settings > Convenience > Minute Alert > Enabled**.

Open to answer

This feature enables you to answer a call by opening the flip. Select **Menu > Settings > Convenience > Open to Answer > Enabled**.

Any key answer

To set the phone to answer calls when you press any key, select **Menu > Settings > Convenience > Any Key Answer > Enabled** (to answer calls with any key except the **End, Back, or Navigation** key).

Accessories

This section describes settings that affect accessories you use with your phone.

Headset sounds

With a headset attached to your phone, you can play the ringer through the headset or phone speaker.

Select **Menu > Settings > Accessories > Headset Sounds** and one of the following.

- **Out of phone rings** from the phone speaker.
- **Out of headset rings** from the headset.

Auto answer

With a headset or hands-free kit attached to your phone, you can set the phone to answer automatically.

Select Menu > Settings > Accessories > Auto-Answer > After 5 Seconds. The phone automatically answers after 5 seconds.

Power backlighting

You can set backlighting to remain on when using an external power source, such as the AC adapter, with the phone.

Note: Power backlighting may not be available with the optional desktop charger or other accessories.

Select Menu > Settings > Accessories > Pwr Backlighting and one of the following.

- **Normal** sets power backlighting to normal.
- **Always On** keeps power backlighting with an accessory.

Tip: Use the power backlighting as a night light when traveling.

Com port speed

The Com Port Speed sets the data rate at which your phone connects to a laptop or PC. Select Menu > Settings > Accessories > Com Port Speed and a speed.

There may be a higher charge for making calls using high-speed data in areas where 1X service is available. Check with your service provider for details.

TTY device

You can connect the phone to a teletype (TTY) device for the hearing impaired.

Note: Enable TTY only when using the phone with a TTY device.

1. Connect the TTY device to the phone.
2. Enter ##889 with your keypad and select **TTY** or select Menu > Settings > Accessories > TTY Device.
3. At the notification, select **OK**.
4. Select **TTY On** to connect or **TTY Off** to not connect.

Hearing aid

Enable your phone to operate with a T-coil Hearing Aid device. Select Menu > Settings > Accessories > Hearing Aid > OK > Enabled.

Note: Enable Hearing Aid only when using your phone with a T-coil Hearing Aid device.

Voice Features

The following features enable you to customize the voice commands.

Automatic add

By default, your phone automatically enables voice dialing for each new contact you add to your Contacts list as long as the contact name contains at least one alphabet but no more than five words or components. You can select Menu > Settings > Voice Features > Automatic Add >

Disabled to disable the voice dialing for new contacts.

Expert mode

The expert mode enables you to speak the command after you hear a tone instead of speaking a command following the initial voice prompts. Select **Menu > Settings >**

Voice Features > Expert Mode and one of the following:

- **Normal** sets phone to default voice prompts.
- **Expert** sets phone to sound tones instead of voice prompts.

Display results

The display results enables your phone to show either one voice recognition candidate or up to three ones. Select **Menu > Settings > Voice Features > Display Results** and one of the following:

- **Single Best** presents you only one voice recognition result.
- **Three Best** presents you up to three voice recognition results.

Digit lengths

Use the digit lengths to determine whether to limit your dialed numbers to North American numbers or any numbers. Select **Menu > Settings >**

Voice Features > Digit Lengths and one of the following:

- **North American** recognizes only digit strings of lengths that correspond to valid North American dialing numbers of 7-digits, 10-digits, or 1+10-digits to improve accuracy.
- **Permit All** allows any digit strings of 4 to 14 digit lengths.

Voice answer

You can use your voice to answer a call when using a hands-free accessory.

Enable voice answer

Select **Menu > Settings > Voice Features > Voice Answer > With Accessory** to enable answering calls with an accessory.

Note: To use the voice answer feature, you must have the **Auto-Answer** feature disabled (see “Auto answer” on page 33), the **Out of headset** option selected (see “Headset sounds” on page 33), and the phone set to **Normal Sounds** (see “Ringer mode” on page 28).

Use voice answer

When you receive an incoming call, the phone prompts “Incoming call, answer?”. If the caller is recognized as a contact entry in your phone, the phone prompts “Incoming call from (Name), answer?”. Say “Yes” to answer or “No” to silence the alert without answering.

Voice wake-up

You can activate voice dialing by saying “wake up” twice. Select **Menu > Settings > Voice**

Features > Voice Wake-Up > With Accessory to enable calls with an accessory.

To wake up the phone:

1. Say “Wake Up” and listen for a tone.
2. Say “Wake Up” again until you hear two tones.

If the phone does not recognize your Wake Up command, see “Voice training” on page 36.

Voice training

You can train your phone to recognize specifically your voice for numbers. Use voice training only when you find your voice not recognized with acceptable accuracy.

If your phone is having trouble recognizing your voice, select **Menu > Settings >**

Voice Features > Voice Training > OK > Train Numbers. Follow the prompts for each number until training is complete.

Network

Data and fax calls

Your phone may be able to receive certain data or faxes, depending on the system sending the information. You cannot receive voice calls while the phone is in data/fax mode.

To receive data or faxes, you must connect the phone to a laptop or PC and switch the phone from voice mode to data/fax mode.

Note: To purchase a cable, visit www.kyocera-wireless.com/store.

To enable data/fax mode, select **Settings > Network > Data/Fax Calls** and one of the following:

- **Voice Only** turns data/fax mode off.
- **Fax, next call** or **Data, next call** sets the phone to data/fax mode for the next incoming call or the next ten minutes.
- **Fax, until off** or **Data, until off** sets the phone to data/fax mode until the phone is turned off.

Privacy Alert

You can set your phone to alert you when enhanced digital CDMA privacy is lost or regained. Select **Menu > Settings > Network > Privacy Alert > Enabled**.

Voice privacy

You can also set your phone to use enhanced digital CDMA privacy. Select **Menu > Settings > Network > Voice Privacy > Enhanced**.

Roaming service alert

Use this setting if you want the phone to alert you when you roam outside of your home service area.

Select **Menu > Settings > Network > Roam/Svc Alert** and one of the following:

- **Disabled** turns roaming service alert off.
- **When no svc** alerts you with three tones decreasing in pitch when service is lost and three tones increasing in pitch when service is acquired again.
- **On roam change** alerts you with two decreasing tones when roaming service is acquired and three increasing tones when home area service is acquired again.
- **On any change** alerts you with three increasing tones if there is a change in roaming service or three decreasing tones if the phone loses service.

Roam option

You can restrict your phone from making a call when roaming. Select **Menu > Settings > Network > Roam Option > Automatic** (allows roaming) or **No Roaming** (disallows roaming).

Set phone line

Your phone can have two service accounts, or phone lines, associated with it. Each phone line has its own phone number. Select **Menu > Settings > Network > Set Phone Line** and one of the two lines.

When you are using one line, you cannot receive calls from the other. It would be as if the phone were “off” for that number. Your voicemail,

however, still takes messages. All contacts and settings are shared for both lines.

Note: You must first establish a second phone line with your service provider. Once established, a second phone number becomes available in the menu for selection.

Web alert

You can set an alert to confirm the start or exit of the browser. Select **Menu > Settings > Network > Web Alert** and one of the following:

- **At Start** prompts you when you start a session.
- **At End** prompts you when you end a session.
- **Both** prompts you when you start or end a session.
- **No Prompts** sets no prompts.

Roam call alert

You can set the phone to warn you before you answer or place a call while roaming. Select **Menu > Settings > Network > Roam Call Alert > Call Prompt**.

The phone emits a distinctive ring to indicate when you are roaming during a call. To accept or place a call while roaming, you must press 1.

Note: Call Prompt is disabled when the phone is in Emergency Mode.

Location

This setting enables you to share your location information with network services other than

emergency services (for example, 911, 111, 999 and 000) in areas where service has been implemented.

This feature works only when your phone is in digital mode. You do have the option of turning off the locator to emergency services.

Select **Menu > Settings > Network > Location** and one of the following.

- **911 Only** (default) shares your position information only with emergency services when you call your 3-digit emergency code.
- **Location On** shares your position information, in addition to emergency services.

Security

This section describes all the features involved in securing your phone and preventing access to personal information. All security features are shielded by a four-digit lock code.

Lock phone

When your phone is locked, you can call only emergency numbers or your service provider's customer service number. You can still receive incoming calls.

1. Select **Menu > Settings > Security**.
2. Enter your four-digit lock code.
3. Select **Lock Phone** and one of the following:
 - **Never** leaves the phone always unlocked.

- **On power up** locks the phone every time you turn it on.
- **Now** locks the phone immediately.

Do the following to unlock the phone:

1. From the home screen, select **Unlock**.
2. Enter your four-digit lock code.

Limit calls

You can limit the calls that can be made from your phone to emergency numbers, your contacts, and your service provider's numbers.

1. Select **Menu > Settings > Security**.
2. Enter your four-digit lock code.
3. Select **Limit Calls** and one of the following:
 - **No Limit:** does not limit calls.
 - **Limit Outgoing** limits outgoing calls while incoming calls still work.
 - **Limit All** limits both incoming and outgoing calls.

Emergency numbers

The emergency numbers feature enables you to specify three personal phone numbers you can call when the phone is locked.

1. Select **Menu > Settings > Security**.
2. Enter your four-digit lock code.
3. Select **Emergency Numbers**.
4. Select an **Unassigned** slot.
5. Enter the number and select **Done**.

You can view these numbers only when entering them for the first time.

To make a call to an emergency number from a locked phone, you must dial the number (including area code) exactly as it was stored in Emergency Numbers.

Erase contacts

You can erase all entries from your Contacts list.

1. Select **Menu > Settings > Security**.
2. Enter your four-digit lock code.
3. Select **Erase Contacts** and one of the following:
 - **No** exits without erasing contacts.
 - **Yes** erases all contacts. A confirmation prompt appears to verify your decision.
4. Select **Yes** to confirm.

New lock code

The lock code is typically 0000 or the last 4 digits of your phone number. To change your lock code from the default provided by the service provider:

1. Select **Menu > Settings > Security**.
2. Enter your four-digit lock code.
3. Select **Lock Code**.
4. At the confirmation, select **Yes**.
5. Enter a new four-digit code.
6. Re-enter your new lock code.

Phone information

You can access information regarding your phone. Select **Menu > Settings > Phone Info** and one of the following:

- **Build Info** shows specific software and hardware information.
- **Icon Key** shows the icons used by your phone.

9 MESSAGING

This chapter describes how to send, receive, and erase messages from your phone. For information on voicemail messages, see “Voicemail” on page 11.

Note: The features and menus described in this chapter may vary depending on services available in your area. Check with your service provider for details and possible usage charges.

Text messages

You can only send text messages to phones capable of receiving them or to email addresses.

Create a text message

1. Select **Menu > Messaging > New Text Msg.**
2. At the **Send To** field, enter a recipient's phone number or email address by either:
 - Select **Options > Recent List, Recent Calls, Contacts or Groups** to access your stored contacts.
 - Enter a new address manually. See “Text Entry” on page 13.

You can message up to ten recipients at once. Use comma or spaces to separate addresses. If you select stored contacts, this is done automatically. Scroll down to move to the next field when done.

3. At the **Message** field, enter the message.

4. Select **Send**.

Include QuickText and other extras

During text entry, you can insert prewritten text (QuickText), symbols, or contacts.

1. From the text entry screen, select **Options** and one of the following:
 - **Insert QuickText** inserts prewritten text from a list.
 - **Add Symbol** inserts a symbol. Press the corresponding number to select a symbol.
2. Complete your message.
3. Select **Send**.

Use text message options

When you are ready to send a text message, you have several options for how and when you want it received.

1. After composing your message, select **Options** and one of the following:
 - **Save Message** saves the message to the **Drafts** folder.
 - **Save QuickText** saves your composed message as a prewritten message.
 - **Settings > Msg Receipt > Request** alerts you when a recipient has received your message.

- **Settings > Set Priority > Normal** or **Urgent** sets the message priority.
 - **Settings > Callback Number** sets your callback number. Enter a number and select **OK**.
 - **Settings > Send Later > Immediate** or **Set Time** specifies the time to send the message.
 - **Settings > Validity Period > Set Time** sets a defined expiration time limit for a message.
2. After selecting options, select **Close**.
 3. Complete your message.
 4. Select **Send**.

Retrieve a text message

When a text message is received, your phone displays a notification and the message icon appears at the top of your screen. The message icon flashes if the message is urgent. Urgent messages are also marked in the **Inbox**.

Message notifications

If you see a message notification, select **Inbox** to view messages. Scroll to a message and select **View** to open it.

To clear a message notification, select **Ignore**.

Message icons

If you see the message icon, select **Menu > Messaging > Inbox**. Scroll to a message and select **View** to open it.

View a text message

The options available when viewing a text message may vary. Check with your service provider.

1. Select **Menu > Messaging > Inbox**.
2. Select a message to view. If the message is long, scroll down to view entire message.
3. Select **Reply** to create a response message or **Options** and one of the following:???

 - **Erase** deletes the message.
 - **Forward** forwards the message.
 - **Reply with Copy** replies to the message with a copy of the original attached.
 - **Save Message** saves the message to the **Saved** folder.
 - **Save QuickText** saves the message text as preset text, which can be inserted into other messages. Graphics are not saved.
 - **Lock** protects the message from accidental deletion.
 - **Sender** displays the sender information.

Note: If a graphic is too large or incorrectly formatted and is not received with the message, an icon appears.

Multimedia messages

You can only send multimedia messages to phones that are capable of receiving them or to email addresses. Multimedia messages have a predetermined character and file size limit. When you reach the character and file size limit for a

single multimedia message, you must edit the message to meet the size limitation.

Note: Multimedia messaging is not available on all phones. Check with your service provider.

Create a multimedia message

1. Select **Menu > Messaging > New Pic Msg.**
2. At the **To**, **CC** (to send a copy of the message), and **BCC** (to send a blind copy) fields, do one of the following to enter the recipient's phone number or email address. Scroll down to move to the next field when done.
 - Select **Options > Recent List, Recent Calls, Contacts, or Groups** to access your stored contacts.
 - Enter the phone number or email address manually. See “Text Entry” on page 13.

Note: You can message up to ten recipients at once. Use a comma or spaces to separate addresses. (If you select stored contacts, your phone does this automatically.)

3. At the **Subject** field, enter a subject. Scroll down to move to the next field when done.
4. At the **Message** field, enter a message. Scroll down to move to the next field when done.
5. At the **Image** field, select **Options** and one of the following to attach a file:
 - **Take a picture** to instantly take a photo and attach it.

- **Media Gallery** to attach an existing file from **Camera Pictures** or **Images**.

Scroll down to move to the next field when done.

6. At the **Sound** field, select **Options** and one of the following to attach a file:
 - **Record Sound** to instantly record a sound and attach it.
 - **Media Gallery** to attach an existing file from **Saved Sounds, Ringers** or **Voice Memos**.
7. Select **Send**.

Use multimedia message options

When you are ready to send a multimedia message, you have several options for how and when you want it received.

1. While composing your message, select **Options** and one of the following:
 - **Insert Contacts** adds contacts to your message.
 - **Insert QuickText** adds prewritten text to your message.
 - **Preview Message** plays your message.
 - **Save Message** saves the message to the draft folder.
 - **Add Address** adds additional recipients to your message.
 - **Save Address** saves a recipient's address to your phone if it is new.

- **Settings** sets the various message settings such as **Msg Receipt**, **Set Priority**, **Send Later**, and **Slide Interval**.
2. After setting options, press the **Back** key to return to the message window if necessary.
 3. Complete your message.
 4. Select **Send**.

Retrieve a multimedia message

There are two modes for receiving a multimedia message on your phone: **Auto Retrieve** (default) and **Prompt**???

Auto retrieve mode

When a message is received, it is automatically downloaded onto your phone. A notification appears when a new message has been downloaded to your phone. Select one of the following:

- **View** opens the message.
- **Later** saves the message for you to view later.

Note: If a message is received during a call, the phone downloads the message approximately one minute after the last key is pressed.

Prompt mode

When a multimedia message is received, it is not automatically downloaded onto your phone. A notification appears when a new message is available for download. Select one of the following:

- **Yes** downloads and opens the message.

- **Erase** deletes the message.
- **Retrieve Later** sends the message to the Inbox for you to download and view later.

Note: If a multimedia message is received during a call, the phone displays a notification after the call ends.

View a multimedia message

When a multimedia message is received, the **message icon** appears at the top of your screen. The **message icon** flashes if the message is urgent. All **notifications** or messages are stored in the **Inbox** regardless of your **Auto Retrieve** settings???

1. Select **Menu > Messaging > Inbox**.
2. Select **View** to read a message. If the message is long, scroll down to view the entire message.
3. Select **Reply** to create a response message or **Options** and one of the following:
 - **Mute/U nmute** enables or disables silencing the message.
 - **Erase** deletes the message.
 - **Forward** forwards the message without showing the original address, graphic, sound, and text fields.
 - **Lock Msg** avoids erasing the message accidentally.
 - **Message Info** displays the message information (priority, sender, subject, time sent and received, and message size).

- **Replay** plays the message again from the beginning.
- **Done** exits the message.
- **Save Picture** saves the picture embedded in the message.
- **Save Sound** saves the sound embedded in the message.
- **Save Address** extracts email addresses, phone numbers, and/or URLs from the sender information and message body.
- **Save QuickText** saves the text in the message to the QuickText list.
- **Call** calls the message sender.
- **Save Message** saves the message to the Saved Folder.

Note: The options available to you may vary. Check with your service provider.

Erase messages

It is a good idea to erase old messages to free up memory in your phone.

You can erase messages as you send or read them, erasing them one at a time or all at once.

Erase a single message

1. Select **Menu > Messaging > Inbox, Sent Msgs, Outbox, Saved Msgs, or Drafts**.
2. Scroll to the message you want to erase.
3. Select **Options > Erase**.

4. At the notification, select **Yes** to erase the message.

Note: You can erase a scheduled message from the Outbox, but you cannot cancel delivery of the message.

Erase all messages

1. Select **Menu > Messaging > Erase Msg > Inbox, Outbox, Sent Msgs, Saved Msgs, Drafts or All**.

To erase messages from all folders, select **All**.

2. At the notification, select **Yes** to erase the messages.

Working with messages

This section provides some tips about messaging with your phone.

Unable to send messages

You may not be able to send or receive messages if your phone's memory is nearly full, or if digital service is not available at the time. To free up memory, erase old messages. See "Erase messages" on page 44.

Appended messages

If you go over the character limit for a single message, the phone may automatically append an empty segment to your message to make space.

Important: Your service provider charges you for each message segment.

When you start a message, the maximum character limit appears once you are in the message entry field. This number counts down as you enter characters, until it reaches 0.

If you continue to enter text after this counter reaches 0, a message segment may be appended. When you reach the message size limit, you are prompted to edit the message or alerted that the message is being appended.

Note: Appended messages may not be available on all phones. Check with your service provider.

Receive incoming calls while creating messages

If you receive a call while creating a message you will receive a notification. You can do the following:

- Select **Ignore** to not answer the call but return to the message screen.
- Press the **Send** key to answer the call and save the message to the Drafts folder.

Complete messages in Drafts folder

To continue composing a message in the Drafts folder:

1. Select **Menu > Messaging > Drafts** and the message you want to complete.
2. Select **Edit**.
3. Complete your message.

4. Select **Send**.

View messages in Sent folder

To view messages in the Sent folder, select **Menu > Messaging > Sent Msgs**.

Scroll through the list of messages. One of the following indicators may appear next to each message:



The scheduled message was sent and delivered as scheduled. You cannot cancel delivery of the message.



The message has been received.



The message has never been sent or has not been sent since it was last modified. You can cancel delivery of the message.



The message has been sent to more than one recipient.

View failed or pending messages

Failed or pending messages are stored in your Outbox folder. To view messages in the Outbox folder, select **Menu > Messaging > Outbox**. Your list of failed or pending messages appears with the following symbols.



The message is pending and will be sent when possible. You can cancel delivery of the message.



The message cannot be sent because service is not available. An alert appears on your phone if the message cannot be sent.

Message settings

Messaging settings help configure your phone's text message settings.

Alerts

Choose your alerts for voicemail, pages, or messages.

1. Select **Menu > Messaging > Msg Settings > Alerts > Msg Alert, Page Alert, or Voicemail Alert.**
2. Select an alert.

Note: If you select an alert with an **& Remind**, the phone notifies you once when receiving a new message and notifies you again every five minutes. To stop a reminder alert, select **Ignore**.

Signature

The signature you create is included at the end of all outgoing messages, but does not appear in the message creation screen.

1. Select **Menu > Messaging > Msg Settings > Signature.**
2. Enter your signature in the text field.
3. Select **OK** to save the signature.

Note: The characters in the signature are included in the total character count of the message.

Edit Quick Text

Your phone comes with prewritten messages (preset text), such as "Please call me," which you can insert into the body of a text message. You can edit these messages or create new ones. Your phone stores up to 40 preset text messages, with up to 100 characters per message.

1. Select **Menu > Messaging > Msg Settings > Edit Quick Text** and one of the following:???

 - Scroll to a preset text message and select **Edit**.
 - Select **New Msg** to create a new preset text message.

2. Enter or edit the text.
3. Select **Save**.

Note: You can also save a message you have written or received as preset text.

Auto retrieve

To set your phone to automatically retrieve multimedia messages, select **Menu > Messaging > Msg Settings > Auto retrieve** and one of the following:

- **Disable** turns off auto retrieve. You are prompted before any multimedia messages are download.
- **Enable** turns on auto retrieve.

Hide or show CC/BCC

To show or hide the CC and BCC fields when you compose a multimedia message, select **Menu > Messaging > Msg Settings > Hide CC/BCC** or **Show CC/BCC**.

Callback number

Set a callback number to let recipients know where to call you back.

1. Select **Menu > Messaging > Msg Settings > Callback Number**.
2. Enter number in the text field.
3. Select **OK** to save the number.

Save to sent

To set your phone to automatically save outgoing messages to the **Sent Msgs** folder, select **Menu > Messaging > Msg Settings > Save to Sent** and one of the following:

- **Disabled** does not save the outgoing messages.
- **Prompt** allows you to choose whether to save your message when you send it.
- **Enabled** saves all outgoing messages to the **Sent Msgs** folder.

Auto-erase

You can set your phone to erase message automatically when memory is needed for incoming messages.

Select **Menu > Messaging > Msg Settings > Auto-Erase** and one of the following:

- **Disabled** erases no messages.
- **Inbox Msgs** erases old messages in your Inbox when memory is needed.
- **Sent Msgs** erases old messages in the **Sent Msgs** folder when memory is needed.
- **Both** erases old messages in both your **Inbox** and **Sent** folder when memory is needed.

Default text

You can change the default text entry mode when creating a text message. This setting applies only to the **Message** field, not the **Send To** field.

Select **Menu > Messaging > Msg Settings > Default Text** and one of the following:

- **Normal Alpha** to enter text letter by letter.
- **Rapid mode** enter text with word recognition.

Text message receipt

You can request a notification when a recipient has received your text message. Select **Menu > Messaging > Msg Settings > Text Msg Receipt > Request**.

Picture message receipt

You can request a notification when a recipient has received your picture message. Select **Menu > Messaging > Msg Settings > Pic Msg Receipt > Request**.


Voicemail number

Set the number your phone calls to retrieve voicemail. Often your voicemail number is automatically programmed by your service provider.

1. Select **Menu > Messaging > Msg Settings > Voicemail Number**.
2. Select **Edit**.
3. Enter the voicemail number. Use **Options > Time Pause** or **Hard Pause** to enter pauses.
4. Select **Save**.

Multimedia message reply

To set whether to reply to a multimedia message with a multimedia or text message, select **Menu > Messaging > Msg Settings > Pic Msg Reply** by **> Text Msg** or **Pic Msg**.



10 CAMERA

The following are some tips for you to operate your phone's camera:

- You cannot activate the camera while on an active call or while browsing files in the media gallery.
- Once the camera is active, the home screen acts as the viewfinder.
- If you get a “Low memory” error, check your resolution and quality compression settings.
- If there is no activity within 45 seconds after you turn your camera on, the camera quits and returns to the previous launch point.
- Menu settings and options can only be accessed when the camera is active.

Taking a picture

To take a picture:

1. Activate the camera in one of the following ways:
 - Press the **Camera** key until the camera screen appears.
 - Select **Menu > Camera**.
2. Focus on the image using the phone's display as a viewfinder.
3. Take a picture in one of the following ways:
 - Press the **OK** key.
 - Press the **Camera** key.
 - Select **Capture**.

Note: The picture is saved to your Camera Pictures folder.

4. Select **Send** to create a multimedia message or **Erase** to delete the picture from your phone.
5. Press the **End** key to exit camera mode.

Camera mode options

You can set up how your camera takes pictures.

While in camera mode, select **Options** and one of the following:

- **Settings** displays the following camera settings you may set up prior to taking a picture:
 - **Resolution** sets the horizontal and vertical number of pixels for the picture.
 - **Self Timer** sets up a countdown timer to automatically take a picture when the timer expires. When set, the camera beeps from 3 seconds down to the time the shutter automatically snaps the picture (unavailable for Multishot mode).
 - **Date/Time** prints the date and time on the picture (not for 160x120 resolution).
 - **Multishot** takes up to six multiple pictures with the **Camera** key pressed and held. A tone plays each time a picture is taken.

A second tone plays when the final picture is taken.

- **Shutter Sound** sets the sound used when the camera takes a picture.
- **White Balance** adjusts the camera for different lighting.
- **Color Tone** sets the color tone of the picture.
- **Picture Quality** sets the picture compression. The higher the compression, the better the detail of the picture (higher pixel rate). When set to **High**, the picture file size is larger, using more memory.
- **Brightness** adjusts the brightness of the image in the home screen LCD.
- **Camera Images** displays all pictures taken with your phone's camera.
- **Last picture** displays the most recently taken picture.
- **Frames** adds a frame or a stamp to your picture. A frame or stamp cannot be removed once it has been used in a picture. The picture resolution changes to 160x120 while taking pictures with **Frames** enabled. The resolution returns to the original setting with **Frames** disabled.

Note: The following settings revert to the default setting each time you enter and exit the camera application: **Self Timer** and **MultiShot**.

Camera indicators and icons

The camera may display the following on screen indicators and icons.

Note: Numbers in the top right corner indicate the number of snapshot remaining. Numbers in the bottom left corner indicate the resolution setting for pictures.



Flash is on.



Camera is in camera mode.



Multishot feature is on.



Self-timer feature is on



Camera zoom mode is ready.

11 TOOLS

Your phone comes with tools and games. Some of the games or tools described here may not be available on your phone.

If you receive an incoming call while you are playing a game, the game is paused and exited. You can return to play once the call alert ends. Games do not remain paused if the phone is turned off or loses power.

Voice memo

The Voice Memo tool enables you to record and play back audio memos.

Record voice memos

To record new voice memos, do the following:

1. Select **Menu > Tools > Voice Memo > Record New**.
2. Say your voice memo. Select **Stop** when you are done.
3. Select **Save** to save your memo.

If an incoming call is received while you are recording a memo, the memo is saved and the incoming call screen appears.

Review voice memos

To play and use voice memos, do the following:

1. Select **Menu > Tools > Voice Memo > Recorded Memos**.

2. At the file list, highlight a file.
3. Select **Play** to play the memo or select **Options** and one of the following:
 - **Send** creates a message with the memo attached.
 - **Erase** deletes the memo.
 - **Lock / UnLock** prevents erasing the memo accidentally.
 - **Rename** renames the memo.
 - **Details** displays the details of the file.
 - **Erase All** deletes all memos stored.

Scheduler

The Scheduler enables you to schedule events and set reminder alerts.

Create an event

1. Select **Menu > Tools > Scheduler > Add New Event**.
2. At the Event Name field, enter a name. Scroll down to move to the next field when done.
3. At the Type field, choose an event. Press the **OK** key and select a choice from the list.
4. At the Date field, modify the date, if needed. Press **OK** to change the date.
 - Scroll left or right to move between the month, day and year fields.

- Scroll up or down to change the month, day and year.

Press the **OK** key to save the date and move to the next field.

5. At the Time field, modify the time, if needed. Press **OK** to change the time.
 - Scroll left or right to move between the hour, minute and AM/PM fields.
 - Scroll up or down to change hour, minute and AM/PM.

Press the **OK** key to save the time and move to the next field.

6. At the Duration field, modify the duration of event, if needed. Press **OK** to change the duration.
 - Scroll left or right to move between the hour and minute fields.
 - Scroll up or down to change the hour and minute.

Press the **OK** key to save the duration and move to the next field.

7. At the Priority field, choose a priority. Press the **OK** key and select a choice from the list.
8. At the Reminder field, choose a reminder. Press the **OK** key and select a choice from the list.
9. At the Reminder Sound field, choose a reminder sound alerts. Press the **OK** key and select a choice from the list.

10. At the Silent Mode field, press the **OK** key and select off to leave on normal sounds or **During Event** to place the phone in silent mode during the duration of the event.

11. At the Recurring Event field, make the event recurring, if needed. Press the **OK** key and select a choice from the list.

12. Select **Save** to save the event.

View events

You can view the events saved to the scheduler.

View by date

1. Select **Menu > Tools > Scheduler** and one of the following:
 - **View Month** displays the current month. Days with events are highlighted. Scroll the calendar. Press the **OK** key to select a date.
 - **View Day** displays the current date. Scroll right or left to move to another date.
 - **Go to Date** chooses a specific date. Scroll left or right to move between the month, day and year fields. Scroll up or down to change month, day and year. Press **OK** to select the date.
2. At the day view, do one of the following:
 - Select an existing event to view the event detail.

- Scroll to a time and select **Add New** to create a new event.
 - Select **Options > Go to Today** to return to the current date.
 - Select **Options > Go to Date** to select a specific date.
 - Select **Options > Erase all Events** to delete all event for that date.
- **Send** creates a message containing the event.
 - **Copy** creates an event with the existing event information.

View by list

1. Select **Menu > Tools > Scheduler > View All Events**.
2. At the event list, select one of the following:
 - Scroll to an event and select **View** to display the event detail.
 - Select **Options > Sort by Time** to sort events by time.
 - Select **Options > Sort by Type** to sort events by type.
 - Select **Options > Sort by Priority** to sort events by priority.
 - Select **Options > Erase All Events** to delete all events.

Modify an event

You can modify existing events.

From the event detail screen, you can select **OK** to return to the previous screen or **Options** and one the following:

- **Edit** edits the event.
- **Erase** deletes the event.

Scheduler settings

You can change the default settings of your scheduler.

Select **Menu > Tools > Scheduler > Settings** and one the following:

- **Scheduler Hours** changes the work day.
- **Auto Delete** deletes events automatically.
- **Priority** prioritizes new events.
- **Reminder** assigns reminders for new events.
- **Reminder Sound** assigns sound alerts for new event reminders.
- **Silent Mode** sets the phone to silent mode for new events.

Alarm clock

You can set up to four alerts with your phone's three alarm clocks and one quick alarm.

Note: The alert occurs only if the phone is on.

Set the alarm clocks

1. Select **Menu > Tools > Alarm Clock**.
2. Scroll to one of the alarms and select **Set**.
3. At the Alarm Time field, modify the time, if needed. Press **OK** to change the time.
 - Scroll left or right to move between the hour, minute and AM/PM fields.

- Scroll up or down to change the hour, minute and AM/PM.

Press the **OK** key to save the time and move to the next field.

4. At the Alarm Sound field, choose a sound. Press the **OK** key and select a choice from the list.
5. At the Recurring field, make the alarm recurring, if needed. Press the **OK** key and select a choice from the list.
6. At the Alarm Note field, enter a note. Press the **OK** key.
7. Select **Save** to set the alarm(s).

When the alarm rings, select **Off** to turn off the alarm or **Snooze** to silence the alarm for 10 minutes.

Tip: Opening the flip turns off the alarm.

Set the quick alarm

1. Select **Menu > Tools > Alarm**.
2. Highlight the quick alarm and select **Set**.
3. At the Time field, select a time option. A notification shows the quick alarm is on.

When the quick alarm rings, select **Off** to turn off the alarm or **Reset** to set the quick alarm again.

Tip calculator

The Tip Calculator helps you calculate how much tip to include with a bill.

1. Select **Menu > Tools > Tip Calculator**.

2. Enter the amount of your bill and select **Next**.
3. Select the percentage amount to tip. The new bill amount is shown.
4. Select **Done** to return to menu or **Split** to split the bill.
To split the bill enter number of guests and select **Next**. The new bill amount with splits is shown. Select **Done** to return to menu.

Calculator

The Calculator can perform basic mathematical operations.

1. Select **Menu > Tools > Calculator**.
2. Enter the first number.
3. Select mathematical operation.
 - Scroll left to multiply.
 - Scroll right to divide.
 - Scroll up to add.
 - Scroll down to subtract.

The chosen operation is highlighted.

4. Enter the second number. Press the **OK** key to perform the operation. The result is shown.
5. Select **Exit** to return to menu or **Options** and one of the following:
 - **M+** adds displayed result to the value stored in memory.
 - **MR** displays currently stored value on the screen.

- MC clears value currently stored in memory.

Timer

The Timer counts down for the specified time, and beeps when that amount of time has elapsed.

1. Select **Menu > Tools > Timer > Set**.
2. At the Set Timer, enter the time length.
 - Scroll left or right to move between the hours, minutes and seconds fields.
 - Scroll up or down to change the hours, minutes and seconds.
3. If needed, select **Sound** and one of the sounds to change the sound.
4. To work the timer, select the following options:
 - **Start** begins the countdown.
 - **Stop** pauses the countdown.
 - **Reset** clears the timer.

When the countdown is complete, select **Off** to silence the alarm.

Stopwatch

The Stopwatch counts time for you.

1. Select **Menu > Tools > Stopwatch**.
2. To work the stopwatch, select the following options:
 - **Start** begins counting.
 - **Stop** pauses counting.
 - **Reset** clears the stopwatch.

Press the **Back** key to return to the menu.

World clock

The world clock enables you to check times in cities around the world in relation to your local time.

Set the world clock

1. Select **Menu > Tools > World Clock**.
The world clock menu displays your local date and time on the first line.
2. Scroll left or right to select a different time zone, or up and down to view other cities on the same time zone.

Search the world clock

From the world clock menu, you can search by city or country.

1. Select **Menu > Tools > World Clock > Options > Search City or Search Country**.
2. Enter the first letter(s) of your desired city or country.
3. Select the city or country from the list.

12 BROWSER

You can use your phone to browse the Internet if you have obtained phone Internet services from your service provider and if over-the-air Internet access is available in your area.

Note: You cannot receive incoming calls while you are using Browser.

Launching Browser

At the home screen:

1. Select **Menu** > **Browser**.

A message about airtime fees appears every time you start the browser.

For more information about how airtime is charged, contact your service provider.

2. Select **OK** to continue.

If this is the first time you have connected to the Internet, a message informs you that security is not yet enabled for your Web Browser.

3. Select **Yes** to enable security.

When you are connected, a browser home page appears. It has a list of bookmarks and some Web menu options at the bottom of the screen. The lock icon appears in a secure session. An underline and an arrow indicate that there is more text. Scroll down to view more text. Press the **Back** key to return to the previous screen.

4. To choose a site, highlight the link and select **Go**.
5. When you have finished using the Internet, press the **End** key to exit.

Using Web menu options

The following options may appear during a Web session.

- **Home** returns you to the main Browser window, or **home page**.
- **Mark Site** saves the current location as a **bookmark** for easy access.
- **Bookmarks** displays a list of your saved Web sites.
- **Setup** gives you options for changing how information is displayed.
 - **Show URL** displays the entire URL.
 - **About Openwave** displays information about your Browser version.
 - **Encryption** should not be used unless you are instructed to do so by your service provider.
 - **UPLink** selects a different browser server. You can use this option if you have more than one Browser account.
 - **Restart** restarts the Browser.

Searching for Web site

How you search for a Web site depends on your service provider. For more information, contact your service provider.

Using bookmark

At the home screen:

1. Select **Menu** > **Browser**.
2. Select **OK** to accept browser fees.
3. From your Web home page, select **Bookmarks**. A list of bookmarks appears.
4. Enter the number corresponding to the bookmark you want and press the **OK** key.

Checking Browser Alerts

Alerts received from a Web site are sent to your Browser Alerts folder. To check them:

1. Select **Menu** > **Messages** > **Browser Alerts**.
This action launches the browser inbox.
2. Select **OK** to accept browser fees.
3. Select an alert and follow the prompts.

Web Alert

You can set a prompt to confirm the start or exit of the Browser.

Select **Menu** > **Settings** > **Network** > **Web Alert** and one of the following:

- **At Start** to set a prompt when you start a session.
- **At End** to set a prompt when you end a session.
- **Both** to set a prompt when you start or end a session.
- **No Prompts** for no prompts.

Your Kyocera phone has the added ability to download and manage applications through the **Downloads** menus.

Downloads provides you with the full range of applications and services from the Internet: Email, games, relevant news, and much more.

For more information about **Downloads** capabilities and application pricing, contact your service provider.

Using Downloads

You connect to the server, download applications, and then manage them as you like. When you choose an application, you can choose a **demo**, various limited use options, or the **full version**—all varying in price. If you choose a **demo**, **Downloads** notifies you when it has expired. If you choose a priced version, the amount goes to your phone bill. The **MobileShop** also notifies you if you're running out of memory. **At that point**, you can either disable an application or remove it completely.

With applications loaded, you can update to newer versions as they become available.

Downloading an application

To download an application:

1. At the home screen, select **Menu > Downloads > MobileShop > Catalog**. When connected to the server, a list of application types appears under the **MobileShop** menu.
2. Select an application type. A full list of applications of your selected type appears. New applications have an arrow on the left.
Note: Long titles scroll left as you highlight them.
3. Select an application. A list of usages appears. One or more usages may be available with the cost specified for each.
4. Select a usage. A confirmation message appears.
5. Select **Yes** to confirm. The application is downloaded to your phone.
Note: Download times vary.
6. To open the application now, select **Yes**. You can also select **No** to return to the **Downloads** menu, where you see a link to your new application.
Note: Your connection to the application server automatically ends after 30 seconds, unless you connect again to download more applications. Press the **End/Power** key to

end the connection. Closing the flip does not end your connection.

Opening an application

Downloaded applications are stored under the **Downloads** menu. Each application comes with its own unique icon to help you identify it easily.

1. At the home screen, select **Menu > Downloads**.

Note: The **Downloads** icon always remains at the top of this menu. Downloaded applications are listed after.

2. Highlight and select the icon for the application you want to open.

Viewing application details

You can get information about the size of an application and how many uses it has left before it runs out.

1. At the home screen, select **Menu > Downloads > Settings > Manage Apps**.
2. Select the application you want details for.

Removing an application

To remove an application:

1. At the home screen, select **Menu > Downloads > Settings > Manage Apps**.
2. Select the application and **Remove**.
3. Select **Yes** to confirm your choice.

Note: If you remove an application, it is removed completely from your phone. If you want to use it again, you must pay for it again. If you want to free up space on your phone, we recommend you disable the application.

Disabling an application

If you are running out of memory and want to download more applications without completely removing those you have paid for, you can simply disable them. Thus, you can re-download an application to use it again without paying for it again.

1. At the home screen, select **Menu > Downloads > Settings > Manage Apps**.
2. Select the application and **Lock App**.
3. Select **Yes** to confirm your choice.

Note: The application is still listed in the **Downloads** menu. The icon looks like an empty box.

Checking available memory

The amount of available memory depends on the number of applications you downloaded.

1. At the home screen, select **Menu > Downloads > Settings > Manage Apps**. The amount of memory left shows at the bottom of the screen.
2. For more detailed memory information, select **System Info**.

14 VOICE COMMANDS

You can call a contact, dial a phone number, access menus, or find contact information from your voice dial list using voice commands.

Note: You cannot use voice recognition to end a call; you must press the **End** key when the flip is open.

Voice dial list

To call or find a contact using voice dial, you must add the contact to your voice dial list. The contact name must not have more than five words or components for voice recognition.

Add contacts

To add a contact to your voice dial list:

1. Select **Menu > Contacts > Voice Dial List**.
2. At the contact list, highlight a contact and press the **OK** key. A check mark appears next to a name when voice dialing is active. Check each name you want to use with voice dialing.
3. Select **Save**.

Remove contacts

To add a contact to your voice dial list:

1. Select **Menu > Contacts > Voice Dial List**.
2. At the contact list, highlight a check marked contact and press the **OK** key. No check

mark appears next to a name when voice dialing is inactive. Uncheck each name you want to remove from voice dialing.

3. Select **Save**.

Voice commands

Start voice commands

1. Press and hold the **Send** key to initiate voice commands. The phone prompts, “Say a command”.
2. Say one of the following commands and follow the voice prompts.
 - “**Contact <name>**” calls a contact on your voice dial list.
 - “**Dial Number <#>**” calls by speaking the digits of the phone number.
 - “**<shortcut name>**” sends you to a menu item.
 - “**Find Contact**” allows you to find a contact from your voice dial list.

Call a contact name

1. If you haven’t already done so, add the person you want to call to the Voice Dial List. See “Voice dial list” on page 60.
2. From the home screen, press and hold the **Send** key. The phone prompts, “Say a command”.

3. Say “Contact” and the name of the person you want to call.

The phone prompts, “Please repeat” or “Say a name” if it does not recognize the name. If the name you spoke matches a contact in the Voice Dial List, the phone prompts: “Name, correct?” Say “Yes” to make the call, “No” to select a similar name, or “Cancel” to cancel the phone call.

If the phone finds multiple voice tags that sound like the name you said, the phone lists the names and asks you to verify which name to call. Say “Yes” when you hear the correct name or “No” when you hear an incorrect one.

4. Press the **End** key to end the call.

Call a number

1. From the home screen, press and hold the **Send** key. The phone prompts, “Say a command”.
2. Say “Dial number” and then speak the digits of the number you want to call. If you pause, the phone prompts you, “Did you say <number>” or “Say a number” if it does not recognize the name. Say “Yes” to make the call or “No” to cancel the phone call.
3. Press the **End** key to end the call.

Use shortcuts

1. From the home screen, press and hold the **Send** key. The phone prompts, “Say a command”.
2. Say the name of the menu item you want to access or say “Shortcut” to view a list of menu items. The phone prompts, “Say one of the shortcuts”.
3. Say the name of the menu item you want to access.

Find contacts

You can use voice commands to find contact information for contacts in your Voice Dial List.

1. From the home screen, press and hold the **Send** key. The phone prompts, “Say a command”.
2. Say “Find contact”. The phone prompts, “Say a name”.

The phone prompts, “Please repeat” or “Say a name” if it does not recognize the name. If the name you spoke matches a contact in the Voice Dial List, the phone prompts: “Name, correct?” Say “Yes” to make the call, “No” to select a similar name, or “Cancel” to cancel the search.

Customer support

Your service provider's customer support department may be accessible directly from your phone when you dial a number, such as *611 (check with your service provider). They can answer questions about your phone, phone bill, call coverage area, and specific features available to you, such as call forwarding or voicemail.

For questions about the phone features, refer to the materials provided with your phone, or visit www.kyocera-wireless.com.

For additional questions, you may contact the Kyocera Wireless Corp. Customer Care Center in any of the following ways:

- Web site: www.kyocera-wireless.com.
- Email: phone-help@kyocera-wireless.com.
- Phone: 1-800-349-4478 (U.S. and Canada) or 1-858-882-1401.
- Customer support phone numbers are also available in the following countries:

Argentina:	0-800-666-0052
Australia:	1-800-507-000
Brazil:	0-800-55-2362
Chile:	800-43-1212

Colombia:	01-800-700-1546
India:	Toll free#: 1-600-121214 Toll#: 0124-284-5000
Mexico:	001-866-650-5103
New Zealand:	0-800-990-100
Panama:	001-800-51-934
Puerto Rico:	1-866-664-6443
Venezuela	0-800-100-2640

Before requesting support, please try to reproduce and isolate the problem. When you contact the Customer Care Center, be ready to provide the following information:

- The name of your service provider.
- The actual error message or problem you are experiencing.
- The steps you took to reproduce the problem.
- The phone's mobile equipment identifier (MEID).

Note: To locate the MEID, select **Menu > Settings > Phone Info > Build Info** and scroll down to **MEID**: for the 11-digit number. If your phone uses an electronic service number (ESN), **ESN**: replaces **MEID**..

Qualified service


If the problem with your phone persists, return the phone with all accessories and packaging to the dealer for qualified service.

Phone accessories

To shop for phone accessories, visit www.kyocera-wireless.com/store. You may also call us at 800-349-4188 (U.S.A. only) or 858-882-1410.

Become a product evaluator

To participate in the testing and evaluation of Kyocera Wireless Corp. products, including cellular or PCS phones, visit beta.kyocera-wireless.com.



16 CONSUMER LIMITED WARRANTY

Kyocera Wireless Corp. (“KYOCERA”) offers you a limited warranty that the enclosed product or products (the “Product”) will be free from defects in material and workmanship for a period that expires one year from the date of sale of the Product to you, provided that you are the original end-user purchaser of the Product and provided that your purchase was made from an authorized supplier. Transfer or resale of a Product will automatically terminate warranty coverage with respect to that Product. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Product.

KYOCERA shall, at its sole and absolute discretion, either repair or replace a Product (which unit may use refurbished parts of similar quality and functionality) if found by KYOCERA to be defective in material or workmanship, or if KYOCERA determines that it is unable to repair or replace such Product, KYOCERA shall refund the purchase price for such Product, provided that the subject Product (i) is returned, with transportation prepaid, to a KYOCERA authorized service center within the one year warranty period, and (ii) is accompanied by a proof of purchase in the form of a bill of sale or receipted invoice which evidences that the subject Product is within the one year warranty period (“Proof of Purchase”).

After the one year warranty period, you must pay all shipping, parts and labor charges.

This limited warranty does not cover and is void with respect to the following: (i) any Product which has been improperly installed, repaired, maintained or modified; (ii) any Product which has been subjected to misuse (including any Product used in conjunction with hardware electrically or mechanically incompatible or used with accessories not approved by KYOCERA), abuse, accident, physical damage, abnormal operation, improper handling, neglect, exposure to fire, water or excessive moisture or dampness or extreme changes in climate or temperature; (iii) any Product operated outside published maximum ratings; (iv) cosmetic damage; (v) any Product on which warranty stickers or Product serial numbers have been removed, altered, or rendered illegible; (vi) cost of installation, removal or reinstallation; (vii) signal reception problems (unless caused by defects in material and workmanship); (viii) damage the result of fire, flood, acts of God or other acts which are not the fault of KYOCERA and which the Product is not specified to tolerate, including damage caused by mishandling, shipping and blown fuses; (ix) consumables (such as fuses); or (x) any Product which has been opened, repaired, modified or altered by anyone other than KYOCERA or a KYOCERA authorized service center.

USE ONLY KYOCERA APPROVED ACCESSORIES WITH KYOCERA PHONES. USE OF ANY UNAUTHORIZED ACCESSORIES MAY BE DANGEROUS AND WILL INVALIDATE THE PHONE WARRANTY IF SAID ACCESSORIES CAUSE DAMAGE OR A DEFECT TO THE PHONE.

KYOCERA SPECIFICALLY DISCLAIMS LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, PUNITIVE, EXEMPLARY, AGGRAVATED, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF, WHETHER FORESEEABLE OR UNFORESEEABLE OF ANY KIND WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, UNANTICIPATED BENEFITS OR REVENUE, ANTICIPATED PROFITS ARISING OUT OF USE OF OR INABILITY TO USE ANY PRODUCT (FOR EXAMPLE, WASTED AIRTIME CHARGES DUE TO THE MALFUNCTION OF A PRODUCT) OR CONTRIBUTION OR INDEMNITY IN RESPECT OF ANY CLAIM RELATED TO A PRODUCT.

REPAIR OR REPLACEMENT OF A DEFECTIVE PRODUCT OR REFUND OF THE PURCHASE PRICE RELATING TO A DEFECTIVE PRODUCT, AS PROVIDED UNDER THIS WARRANTY, ARE YOUR SOLE AND EXCLUSIVE REMEDIES FOR BREACH OF THE LIMITED WARRANTY, AND SUBJECT TO THIS WARRANTY, THE PRODUCTS ARE APPROVED AND ACCEPTED BY YOU "AS IS". KYOCERA MAKES NO OTHER WARRANTIES, REPRESENTATIONS OR CONDITIONS OF ANY KIND, ORAL OR VERBAL, EXPRESS OR IMPLIED,

STATUTORY OR OTHERWISE, WITH RESPECT TO THE PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. NO DEALER, DISTRIBUTOR, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION OR ADDITION TO THIS WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction.

For warranty service information, please call the following telephone number from anywhere in the continental United States and Canada: 1-800-349-4478 or 858-882-1401.

Please call or write for the location of the Kyocera Wireless Corp. authorized service center nearest you and for procedures for obtaining warranty service.

INDEX

Numerics

1-touch dialing, 31

A

accessories, 63

headsets, 33

settings, 33

T-coil hearing aid, 34

TTY device, 34

adding

contacts, 18

extensions, 19

voice dial list, 60

airplane mode, 31

alarm clock, 53

alert

privacy, 36

web, 57

alerts

browser, 37

messages, 46

minute, 33

missed call, 33

pages, 46

roaming calls, 37

roaming service, 36

vibrating, 28

voicemail, 46

appended messages, 44

auto receive mode

multimedia message, 43

auto redial, 31

auto retrieve, 46

auto save, 47

Auto view, 46

auto-erase, 47

auto-hyphenation, 31

automatic add, 34

Access Apps, 58

B

backlighting

power, 34

settings, 30

banner, 30

battery

caring, 1

charging, 1

installing, 1

recharging, 1

Bluetooth, 26

connecting to other devices,

27

pairing, 26

settings, 27

turning on, 26

BREW apps, 58

brightness, 30, 50

browser

alerts, 37

business ringers, 28

C

calculator, 54

calendar, See scheduler

call lists

erasing, 16

viewing, 16

call timers, 17

callback number, 47

text message, 41

callers IDs, 24

calls

call lists, 16

data, 36

emergency, 12

ending, 9

fax, 36

holding, 32

limiting, 38

roaming, 11

silencing, 10

voice commands, 60

camera, 49

color tone, 50

indicators and icons, 50

multiple pictures, 49

options, 49

resolution, 49

self timer, 49

settings, 49

shutter sound, 50

taking picture, 49

white balance, 50

capitalization, 14

changing modes, text entry, 14

color tone, 50

com port speed, 34

contacts, 18

adding, 18

adding to a group, 20

assign number type, 22

assign picture, 19, 21

assign ring, 19, 21

- calling numbers, 19
 - customizing, 19
 - directory, 18
 - editing, 18, 19
 - email addresses, 20
 - erase, 19
 - erasing, 20, 39
 - fast find, 32
 - frequent list, 33
 - groups, 22
 - memory, 23
 - notes, 21
 - primary number, 20
 - searching, 23
 - secret, 20, 21
 - send as vCard, 19, 22
 - sending as a vCard, 18
 - sending text message, 20
 - speed dial list, 20
 - street addresses, 21
 - viewing all, 18
 - voice search, 61
 - web addresses, 20
- contacts list, 18
- convenience settings, 31
- convention
 - using this guide, 7
- countdown timer, 55
- creating
 - groups, 23
- customer support, 62
- customizing contacts, 19
- D**
- data
 - calls, 36
- default text mode, changing, 47
- dialing
 - 1-touch, 31
 - speed, 10
 - voice list, 60
- digit lengths, 35
- directory, contacts, 18
- display
 - backlighting, 30
 - banner, 30
 - brightness, 30
 - language, 31
 - main menu, 30
 - screensavers, 29
 - settings, 29
 - ticker, 30
 - time/date format, 31
- display results, 35
- download, 58
- downloading
 - application, 58
- drafts folder, 45
- E**
- earpiece, 9
 - volume, 28
- editing contacts, 19
- email addresses, 20
- emergency
 - calls, 12
 - numbers, 38
- entering
 - letters, 13
 - numbers, 13
 - symbols, 14
 - text, 14
- erasing
 - contacts, 39
 - multimedia messages, 44
- evaluation, product, 63
- expert mode, 35
- F**
- faxes, 36
- flip
 - answering calls, 33
- folders
 - draft, 45
 - images, 24
 - inbox, 41
 - multimedia, 24
 - sent, 45
- frame, 50
- frequent list, 33
- G**
- games, 51
 - downloading, 58
- groups, 22
 - assign picture, 23
 - assign ringer, 23
 - creating, 23
 - erase, 23
 - sending multimedia message, 18, 20, 23
 - sending text message, 23
- H**
- hands-free
 - auto answer, 33
- headsets
 - auto answer, 33
 - sounds, 33
- help, getting, 62
- hold calls, 32
- I**
- icons, 4, 39

- text message, 41
- images
 - browsing, 24
 - saved, 24
- incoming calls, 16
- indicators and icons
 - camera, 50
- K**
- key
 - navigation, 6
- keypad
 - sounds, 29
 - volume, 28
- keys
 - frequently used, 4
- L**
- language, 31
- left softkey, 6
- lights only alerts, 28
- limiting calls, 38
- location information, 37
- lock code, 39
- lock message
 - multimedia message, 43
- locking
 - phone, 38
 - text messages, 41
- M**
- main menu, 6, 30
- memory, 59
- menu
 - Web, 56
- menus
 - main, 6
 - main view, 30
 - settings, 25
- messages
 - alerts, 46
 - appended, 44
 - auto-erase incoming, 47
 - callback number, 47
 - completing, 45
 - default text mode, 47
 - incoming calls, 45
 - multimedia message, 41
 - quicktext, 46
 - settings, 46
 - signature, 46
 - text messages, 40
 - unable to send, 44
- minute alerts, 33
- missed call
 - alert, 33
- missed calls, 16
 - deal with, 16
- MobileShop, 58
- modes
 - airplane, 31
 - ringers, 28
 - text entry, 13
- multimedia, 24
- multimedia message
 - auto receive mode, 43
 - creating, 42
 - forwarding, 43
 - locking, 43
 - options, 42
 - prompt mode, 43
 - retrieving, 43
 - saving picture, 44
 - sent, 45
 - viewing, 43
 - viewing options, 43
- multimedia messages
 - auto save, 47
 - CC/BCC fields, 47
 - reply to setting, 48
- multiple, 49
- multishot, 49
- N**
- navigation key, 6
- network
 - location information, 37
- network settings, 36
- notes, contacts, 21
- notifications
 - text messages, 41
- O**
- open to answer, 33
- Outbox, 45
- outgoing calls, 16
- P**
- pages alerts, 46
- pairing, 26
- personal ringers, 28
- phone
 - answering calls, 8
 - codes, 19
 - extensions, 19
 - icons, 4
 - making calls, 8
 - overview, 2
 - turning on and off, 8
- phone information, 39
- phone line
 - setting, 37
- picture
 - multiple, 49
 - saving, 44

- picture messages
 - request receipt, 47
- power
 - backlighting, 34
 - on and off sounds, 29
- prepend, 20
- primary number, 20
- priority
 - text message, 41
- privacy alert, 36
- prompt mode
 - multimedia message, 43
- Q**
- quick alarm, 54
- quicktext, 46
- R**
- rapid entry, 13
- receipt request
 - picture messages, 47
 - text messages, 47
- recent calls, 16
- redial, 31
- redialing, 8
- replying
 - multimedia messages, 48
 - text messages, 41
- resolution, 49
- restrict roaming, 37
- right softkey, 6
- ringers, 24, 28
 - business, 28
 - mode, 28
 - personal, 28
 - roam, 28
 - silent mode, 28
 - type, 28
- volume, 28
- roaming
 - call alerts, 37
 - restrict, 37
 - service alerts, 36
- S**
- scheduler, 51
 - creating events, 51
 - modifying events, 53
 - settings, 53
 - viewing events, 52
- screensavers, 24, 29
- searching
 - contacts list, 23
 - fast find, 32
 - voice commands, 61
 - world clock, 55
- security
 - emergency numbers, 38
 - erasing contacts, 39
 - limiting calls, 38
 - lock code, 39
 - locking phone, 38
 - settings, 38
- sent folder, 45
- setting
 - alarm clock, 53
 - quick alarm, 54
 - world clock, 55
- settings
 - accessories, 33
 - Bluetooth, 27
 - convenience, 31
 - display, 29
 - menu, 25
 - messages, 46
 - network, 36
 - phone information, 39
 - scheduler, 53
 - security, 38
 - sounds, 28
 - shutter sound, 50
 - signature, 46
 - smart sound, 29
 - software
 - build information, 39
 - software build, 39
 - sounds
 - browsing, 24
 - flip closed, 29
 - flip open, 29
 - keypad, 29
 - ringers, 28
 - saved, 24
 - settings, 28
 - silence all, 28
 - volume, 28
 - speakerphone, 9, 10
 - volume, 28
 - speed
 - com port, 34
 - dialing, 10
 - stopwatch, 55
 - support, customer, 62
 - symbols, 14
 - T**
 - T-coil hearing aid, 34
 - teletype, 34
 - text entry, 13
 - capitalization, 14
 - changing modes, 14
 - current mode, 13

- default mode, 47
- letters, 13
- numbers, 13
- quick reference, 14
- rapid entry, 13
- text messages
 - creating, 40
 - erasing, 44
 - forwarding, 41
 - icon, 41
 - locking, 41
 - notification, 41
 - options, 40
 - quicktext, 40
 - replying, 41
 - request receipt, 40, 47
 - retrieving, 41
 - saving, 40, 41
 - send later, 41
 - sender information, 41
 - set priority, 41
 - validity period, 41
 - viewing, 41
- ticker, 30
- time calls, 33
- timer, 55
- tip calculator, 54
- tools, 51
 - alarm clock, 53
 - calculator, 54
 - scheduler, 51
 - stopwatch, 55
 - timer, 55
 - tip calculator, 54
 - voice memo, 51
 - world clock, 55
- turning on and off, 8

V

- validity period
 - text message, 41
- vibrating call alerts, 28
- viewing contacts, 18
- voice
 - dial list, 60
 - memos, 24
 - privacy, 36
- voice answer, 35
- voice commands, 34, 60
 - calling contacts, 60
 - calling numbers, 61
 - find contacts, 61
 - shortcuts, 61
- voice dial list, 60
- voice dialing
 - adding contacts, 60
 - removing contacts, 60
- voice memos, 51
 - erasing, 51
 - locking, 51
 - playing, 51
 - recording, 51
 - sending, 51
- voice recognition, 60
- voice training, 36
- voice wake-up, 36
- voicemail, 11
 - alerts, 46
 - number, 48
- volume, 28
 - adjusting, 10
 - earpiece, 28
 - keypad, 28
 - ringers, 28
 - smart sound, 29

- speakerphone, 28
- W**
- wallpaper, 29
- wallpapers, 24
- web
 - addresses, 20
 - alert, 57
 - alerts, 37
 - browser, 56
 - menu, 56
- web apps, downloading, 58
- white balance, 50
- world clock, 55
- searching, 55

Draft

Kyocera Wireless Corp.
www.kyocera-wireless.com
82-K6572-1EN, Rev. 001