



# Magnetek Material Handling Engineered MLTX Transmitter

---

Remote Crane Controls

---

## Instruction Manual



---

Telemotive

TCENGLTX-0 Rev. B March 2006

Part Number: 178-00840

©Copyright 2006 Magnetek Material Handling

©2006 MAGNETEK MATERIAL HANDLING

All rights reserved. This notice applies to all copyrighted materials included with this product, including, but not limited to, this manual and software embodied within the product. This manual is intended for the sole use of the persons to whom it is provided, and any unauthorized distribution of the manual or dispersal of its contents is strictly forbidden. This manual may not be reproduced in whole or in part by any means, whatsoever, without the expressed written permission of MAGNETEK.

# **Table of Contents**

Your New Radio Remote & Service Phone Numbers	p.2
1.1–1-13.3 Warnings, Cautions and Notes	p.3-9
2-1. Power “ON-OFF” Switch	p.10
2-2. E-STOP	p.10
2-3. Motion Push Buttons, Joysticks or Levers	p.10
2-4. Transmitter LED Indicator	p.10
2-5. Time-Out Timer	p.10
2-6. Key Switch (For Part 15 models not using active ESTOP, keyswitch disables power to transmitter circuitry only)	p.10
2-7. MLTX Transmitter Board Set-up Information	p.11
2-8. Setting Access Code (For units with no external code plug only)	p.11
2-9. Programming Switches	p.12
2-10. To Check Out Data	p.12
2-11. Battery Monitor	p.12
2-12. Analog Voltage Reference	p.12
2-13. Transmit LED	p.12
2-14. Batteries	p.12
2-15. Changing the Channel on the Part 15 Synthesized Transmitter	p.12
2-16. Channel and Frequency Designating by Count	p.13-14
2-17. Changing the Channel on the Part 90 VHF Synthesized Transmitter	p.14
2-18. Replacement Parts	p.15

## Your New Radio Remote

Thank you for your purchase of Magnetek's Telemotive® brand MLTX Radio Remote Crane Control. Magnetek has set a whole new standard in radio-remote performance, dependability, and value with this unique new line of belly box transmitters. Without a doubt, our Telemotive MLTX is the ultimate solution for having precise, undeterred, and safe control of your material.

If your product ever needs modification or service, please contact one of our representatives at the following locations:

### U.S. Service Information

For questions regarding service or technical information, contact **1-866-MAG-SERV (1-866-624-7378)**.

Magnetek Material Handling  
N49 W13650 Campbell Drive  
Menomonee Falls, WI 53051

**Telephone:** 800-288-8178

**Website:** [www.magnetekmh.com](http://www.magnetekmh.com)  
**e-mail:** [info@magnetekmh.com](mailto:info@magnetekmh.com)

### Fax Numbers

*Main:* 800-298-3503  
*Sales:* 262-783-3510  
*Service:* 262-783-3508

### For Canada Service Information Contact Berlet Electronics:

Phone: 1-905-564-2710  
Fax: 1-905-564-2755

**1-1. Warnings, Cautions And Notes**  
**Throughout this document WARNING, CAUTION and NOTE statements have been deliberately placed to highlight items critical to the protection of personnel and equipment.**

**WARNING** – A warning highlights an essential operating or maintenance procedure, practice, etc. which if not strictly observed, could result in injury or death of personnel, or long term physical hazards. Warnings are highlighted as shown below:



**CAUTION** – A caution highlights an essential operating or maintenance procedure, practice, etc. which if not strictly observed, could result in damage to, or destruction of equipment, or loss of functional effectiveness. Cautions are highlighted as shown below:




**NOTE** – A note highlights an essential operating or maintenance procedure, condition or statement. Notes are shown as below:

**NOTE**  
WARNINGS, CAUTIONS AND NOTES SHOULD NEVER BE DISREGARDED.

The safety rules in this section are not intended to replace any rules or regulations of any applicable local, state, or federal governing organizations. Always follow your local lock out and tag out procedure when maintaining any radio equipment. The following information is intended to be used in conjunction with other rules or regulations already in existence. It is important to read all of the safety information contained in this section before installing or operating the Radio Control System.

**1-2. Critical Installation Considerations**





## WARNING

THE DIRECT OUTPUTS OF THIS PRODUCT ARE NOT DESIGNED TO INTERFACE DIRECTLY TO TWO STATE SAFETY CRITICAL MAINTAINED FUNCTIONS, I.E., MAGNETS, VACUUM LIFTS, PUMPS, EMERGENCY EQUIPMENT, ETC. A MECHANICALLY LOCKING INTERMEDIATE RELAY SYSTEM WITH SEPARATE POWER CONSIDERATIONS MUST BE PROVIDED. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY OR DEATH AND DAMAGE TO EQUIPMENT.

### 1-3. General

Radio controlled overhead cranes and other material handling equipment operate in several directions. They are large, bulky pieces of equipment that efficiently handle heavy loads at high speeds. Quite frequently, the equipment is operated in areas where people are working on the floor below. The crane operator must exercise extreme caution at all times. Workers must constantly be alert to avoid accidents. The following rules have been included to indicate how your careful and thoughtful actions may prevent injuries, damage to equipment, or even save a life. If radio controlled material handling equipment is operated from the cab, special care must be taken to secure the transmitter. Refer to section titled Section 1-9. Boarding The Crane for specific safety rules.

### 1-4. Persons Authorized To Operate Radio Controlled Cranes

Only properly trained persons designated by management should be permitted to operate radio controlled cranes.

Radio controlled cranes should not be operated by any person who cannot read or understand signs, notices and operating instructions that pertain to the crane.

Radio controlled cranes should not be operated by any person with insufficient eyesight or hearing, or any person who may be suffering from a disorder or illness, or is taking any medication that may cause loss of crane control.

### 1-5. Training Checklist For Crane Operators

Anyone being trained to operate a radio controlled crane should possess, as a minimum, the following knowledge and skills before operating the crane:

1. The operator should have knowledge of hazards pertaining to crane operation.
2. The operator should have knowledge of the safety rules for radio controlled cranes.
3. The operator should have the ability to judge distance of moving objects.
4. The operator should have knowledge of the radio transmitter.
5. The operator should know how to properly test limit switches.
6. The operator should know, where authorized, instructions for plugging motions.
7. The operator should have knowledge of the use of crane warning lights and alarms.
8. The operator should have knowledge of observing crane signal lights.
9. The operator should be trained to avoid striking any obstructions.
10. The operator should have knowledge of the proper clearance of lifts or hooks before moving bridge or trolley.
11. The operator should have knowledge of the proper storage space for the radio control box when not in use.
12. The operator should be trained in transferring the radio control box to another person.
13. The operator should be trained how and when to report unsafe or unusual operating conditions.
14. The operator should be trained how to exhibit caution in approaching bridge or trolley bumpers.
15. The operator should know equipment capacity.
16. The operator should be trained in making lifts below floor level.

17. The operator should be trained in making side pulls.

18. The operator should know how to keep himself and other people clear of lifts and to avoid "pinch" points.

19. The operator should know cable and hook inspection procedures.

20. The operator should know procedures for testing hoist, trolley, and bridge brakes.

21. The operator should know and follow the local Lock Out and Tag Out procedures.

### **1-6. Operating Area**

Aisles between equipment, stock, etc., should be free of obstructions so the crane operator can move freely. These aisles should be a minimum of three feet (one meter) wide, or meet local regulations.

Crane operators should always position themselves for the best view of the crane they are controlling. The crane should never be operated blindly. The operator should stay as close to the crane load as possible. Operators should never position themselves in a "pinch" point.

### **1-7. Transmitter Unit**

Transmitter switches should never be mechanically blocked ON or OFF for any crane motion. When not in use turn the transmitter OFF. A secure storage space should be provided for the transmitter unit and the transmitter unit should always be placed there when not in use. This precaution will prevent unauthorized people from operating the crane.

Spare transmitters should be stored in a secure storage space and only removed from the storage space after the current transmitter in use has been turned OFF, taken out of the service area and secured.

### **1-8. Operating The Crane**

#### **1-8.1. Pre-operation Test**

At the start of each work shift, or when a new operator takes control of the crane, operators shall do, as a minimum, the following steps before making lifts with any crane or hoist:

Test the upper-limit switch. Slowly raise the unloaded hook block until the limit switch trips. When checking limit switches the hoist should

be centered over an area free of personnel and equipment.

Visually inspect the hook, load lines, trolley, and bridge as much as possible from the operator's station. In most instances this will be the floor of the building.

The bridge and trolley brakes should be tested. On transmitter units equipped with two or more speeds use the "lowest" speed when testing braking devices.

When lifting maximum loads the crane operator should test the hoist brakes by raising the load a few inches from the floor. If the brakes do not hold, the load should immediately be lowered to the floor.

If provided, test the lower-limit switch.

Test all warning devices.

Test all direction and speed controls for both bridge and trolley travel.

Test all bridge and trolley limit switches, where provided, if operation will bring the equipment in close proximity to the limit switches.

Test the transmitter emergency stop.

Test the hoist brake to verify there is no drift without a load.

If any crane or hoist fails any of the above tests notify the supervisor and lock out and tag out for repair.

#### **1-8.2. General Rules For Operation**

Consult the crane manufacturer and local and governmental regulations for complete rules of operation. In general the following rules apply to remotely controlled cranes:

The limit switches should never be used as a regular stopping device. They are intended to be protective devices.

Do not make lifts in excess of the equipment rated capacity.

The bridge and trolley should be centered directly over the load when the load is raised. This will prevent swinging when making lifts.

A crane designed for this purpose and only with supervisor permission should make side pulls.

When a lift is being made, the crane operator should not be positioned in the line of travel. The crane or hoist should be operated from a position either to the side or opposite from the direction of travel.

When raising or lowering a load, proceed slowly and make certain the load is under control. Tag lines should be used for handling unusual lengths or bulky loads. Remove slack from chains or slings gradually. Make certain all personnel are clear before making a lift.

The crane operator should keep all body parts away from the lift and should never be positioned under the lift.

Do not make a lift or move a load if anyone is in a location where they could be struck by the crane or the load.

If the crane operator is being assisted, the crane should not be moved until the assistant signals they are clear of the crane and its load.

When a load is hanging from the crane hook and the crane is being moved, the crane operator should sound all warning devices frequently.

Loads should not be carried over workers heads. If a worker is in the path of crane travel, the crane operator should stop the crane and clear the area before proceeding.

User/operator should never bump into runway stops or other cranes.

When moving the crane, the crane operator should be sure that the hook block and attachments or cables will not catch on nearby equipment. Slings, chains, or cables should never be dragged along the floor.

Unless required for operator safety, gloves should not be worn when operating the transmitter unit.

All loose materials or parts should be removed from the load before starting the lift.

The crane operator should always hoist lifts high enough to clear all equipment and workers.

The crane operator should never permit anyone to ride on the load or hook except when authorized by the supervisor.

When another crane on the same runway is stationary with a load hanging, the crane operator should maintain a safe distance between the stationary crane and the one under their control.

Never leave suspended loads unattended. In an emergency, if the crane is inoperative and a load suspended, notify the supervisor immediately, barricade and post signs on the floor beneath crane and load.

If power to the crane is removed, the crane operator should turn the transmitter unit OFF and keep it OFF until power is restored.

If the crane fails to respond properly, the crane operator should stop operation, turn the transmitter unit OFF and immediately report the condition to their supervisor.

Outdoor cranes, which are subject to movement by wind, should be securely anchored when left unattended. If the crane is equipped with bridge brakes, the parking brake should be set immediately.

#### **1-9. Boarding The Crane**

The crane should not be boarded without permission of the supervisor.

The crane operator should turn off the transmitter and take it with them when boarding the crane.

If more than one person is boarding the crane, one person should be made responsible for ensuring all personnel are off the crane before the system is returned to operation.

#### **1-10. Crane Maintenance And Repair**

Qualified personnel must maintain a regularly scheduled crane inspection (i.e., such as monthly). During this crane inspection the functionality and safety of the crane remote control must also be tested. The inspection shall include, but not be limited to items listed in Section 1-12. Condition of The Radio Controlled Crane. Consult the crane manufacturer and local and governmental regulations for recommended inspection intervals and proper inspection procedures. Problems noted during this inspection must be repaired before using the crane or the remote control.

Minor repairs include routine maintenance, such as greasing, cleaning and control troubleshooting. All other repairs should be considered major. If the repair crew consists of



several people, one person should be designated as the repair crew leader. (see responsibilities below). If the repair crew consists of only one person, that person has the following responsibilities:

For minor repairs, warning signs should be placed on the floor beneath the crane or suspended from the crane. For major repairs, the floor area below the crane should be roped off.

When major repairs are to take place, all persons operating other cranes on the same or adjacent runways, must be notified prior to starting repairs. Notification should include the nature of the repair, safeguards provided, and movement limitations while repairs are in progress.

When practical, radio controlled cranes which cannot be moved during repairs, must be protected against being bumped into by other cranes on the runway. Cranes under repair should have bumpers installed on the exposed side or sides of the crane. They should be placed as far away as possible. Indicate the location of the bumpers by placing red lights clearly visible to other crane operators traveling on the same runway. When it is not possible to use bumpers, place red lights in a location that is clearly visible to other crane operators traveling on the same runway. This will indicate that there is a restricted travel zone. All crane operators on the same runway must be informed of the repair effort and thoroughly instructed to what their operations are limited to and informed they will be notified when repairs are completed.

If any hazard involving the repairmen exists when there is a runway adjacent to the crane under repair, the adjacent runway should be blocked off as described above. When it is necessary to continue crane operation on the adjacent runways, warning lights must be installed and visible to the operators of cranes on those runways. All cranes should come to a complete stop prior to entering the restricted area and should proceed through this area only after receiving permission from a signal person designated for this purpose. Access of persons to and from the crane being repaired should be under control of the repair crew leader.

When boarding the crane, the transmitter should be turned OFF and the transmitter should remain with the repair crew leader. The leader should board the crane first, open and lock out the main

switch, and then signal the other members of the crew it is safe to board the crane.

If work on the crane is to be done in areas not protected by standard handrails, the repair crew should wear approved safety belts.

All tools and equipment should be moved onto the crane by the use of hand lines. The tools and equipment should be adequately secured to the hand lines.

If it is necessary to have the crane control circuits energized, all power circuits for crane movement must be opened prior to energizing the control circuits.

During repairs and before moving the crane all personnel and tools should be moved to a safe spot.

Headroom is at a minimum in some crane cabs and on some crane walkways. Exercise caution when boarding or working on cranes. Wear hard hats whenever possible.

When repairs are finished, all personnel, tools and repair equipment should be removed before energizing the crane circuits.

#### **1-11. Using The Crane As A Work Platform**

When the crane is to be used as a stationary work platform, follow all rules provided in Section 1-10. Crane Maintenance and Repair. When it is necessary for the crane to be moved from time to time, the crane operator should board the crane with the transmitter unit. The crane operator should ensure all personnel working on the crane are in a secure position before moving the crane to the next workstation. It should also be the crane operator's responsibility to ensure the main switch is open and locked down before work is resumed.



## WARNING

THE CRANE OPERATOR SHOULD NOT ATTEMPT TO REPAIR ANY OF THE ITEMS STATED BELOW. THE CRANE CONDITION SHOULD BE REPORTED TO THE SUPERVISOR. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY OR DEATH AND DAMAGE TO EQUIPMENT.

### 1-12. Condition Of The Radio Controlled Crane

If the crane fails to respond properly, the crane operator(s) should notify their supervisor. When serious conditions are noticed (conditions that make the crane unsafe to operate), the crane operator should shut down the crane immediately and the supervisor should be notified. The following is a list of some of the items that should be included in the report (See the crane manufacturer for specifics and possible additional items):

Condition of hoisting cable and hook block (broken strands, clipped sheave wheels, etc.).

Condition of brakes (hoist, trolley, and bridge). (No bluing, rivets on shoes showing, glazing, etc.).

Condition of trolley and rail stops.

Condition of bridge structure.

Condition of festoon system.

Broken welds in any part of the crane structure.

Proper fluid levels and lubrication.

Condition of bridge and trolley stops.

Carbon dust or signs of burning on the covers of motors.

Indication of fluid, oil or grease leaks.

Condition of rail sweeps.

Walkways require handrails and ladders are sturdy, in place and not loose.

Protective guards are in place for all moving parts.

Alignment of bridge (screeching or squealing wheels indicate bridge is out of line).

Broken, cracked, or chipped rails on trolley or runway.

Condition of limit switches.

Condition of electrical and mechanical control (electrical or mechanical defects which cause faulty operation such as uncommanded stopping or starting of any crane motions, warning devices, lights, or auxiliary functions).

Condition of gears (grinding or squealing may indicate foreign materials in gear teeth or a lack of lubrication).

All controls, especially E-STOPS, are in place and in working order.

Frequent relay tripping of power circuits.

Mechanical parts loosened by vibration (loose rivets, covers, bolts, etc.).

Uneven riding (worn or damaged wheels).

Condition of collector shoes or bars.

Condition of warning or signal lights and horns. (Burned out or broken).

### 1-13. Batteries



## WARNING

KNOW AND FOLLOW PROPER BATTERY HANDLING, CHARGING AND DISPOSAL PROCEDURES. IMPROPER BATTERY PROCEDURES CAN CAUSE BATTERIES TO EXPLODE OR DO OTHER SERIOUS DAMAGE. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY OR DEATH AND DAMAGE TO EQUIPMENT.

### **1-13.1. Battery Handling**

Use only batteries approved by Telemotive for the specific product.

Do not dispose of a battery pack in fire. It may explode.

Do not attempt to open the battery pack.

Do not short circuit battery.

For intrinsically safe environments only use specified Telemotive intrinsically safe batteries.

Keep the battery pack environment cool during charging operation and storage, (i.e., not in direct sunlight or close to a heating source).

### **1-13.2. Battery Charging**

For those transmitters equipped with battery chargers, please familiarize all users with the instructions of the charger before attempting to use.

Use only Telemotive approved chargers for the appropriate battery pack.

Do not attempt to charge non-rechargeable battery packs.

Avoid charging the battery pack for more than 24 hours at a time.

Do not charge batteries in a hazardous environment.

Do not short charger.

Do not attempt to charge a damaged battery.

Do not attempt to use a battery that is leaking, swollen or corroded.

Charger units are not intended for outdoor use. Use only indoors.

### **1-13.3. Battery Disposal**

Before disposing of batteries consult local and governmental regulatory requirements for proper disposal procedure.



## CAUTION

Before operating the transmitter, familiarize yourself with all safety information in this manual and any other local, state, or federal rules or regulations already in existence.

### **2-1. Power “ON-OFF” Switch (Turns transmitter and receiver ON and OFF)**

With the key switch (optional) engaged, pressing the ON/OFF push-button switch (Part 15) starts the transmitter, pushing it again starts the receiver. Or toggling the ON/OFF toggle switch (Part 90) turns the transmitter and the receiver ON. If the transmitter is ON the BATT MONITOR light is ON or flashing. Pushing the ON/OFF button again (Part 15), or resetting the toggle switch to OFF (Part 90), will turn the transmitter and receiver OFF.

### **2-2. E-STOP (For Emergency Stopping only)**

When depressed, the MCR relay is opened, the receiver shuts down, and power to the equipment is immediately stopped. Under normal operating conditions, **the E-STOP must be raised.** The transmitter must be turned OFF and ON again to restore normal operation. Use the E-STOP for emergency stopping only, not for normal system shut down. The E-STOP will not function with the optional key switch turned OFF.

### **2-3. Motion Push Buttons, Levers**

To activate motor functions, press and hold the push-button or lever that corresponds to the desired motion. The extent to which the push-button or lever is pushed, dictates the speed of the motor function.

### **2-4. Transmitter LED Indicator**

The transmitter LED (red) indicates the transmitter is on, or transmitting, or has a low battery voltage. A slow flash rate indicates the unit is ON. A rapid flash rate indicates the unit is transmitting (when a function or control is activated). If the battery goes below a safe level, the LED will not light. Replace battery soon.

### **2-5. Time-Out-Timer**

Unless this function is disabled, the transmitter will turn itself OFF if not used for 15 minutes.

### **2-6. Key Switch. (For Part 15 Models not using active E-STOP, disables power to transmitter circuitry only)**

For models so equipped, turning the key OFF and removing it will disable the transmitter. If the key switch is turned OFF with the transmitter and receiver on, the key switch must be turned ON again to use the ON/OFF push button or E-STOP. Turning the key switch to ON enables power to the transmitter unit, but does not activate the transmitter controls or turn ON the receiver. The ON/OFF push button must be pushed to turn the transmitter and receiver ON or OFF. Under normal procedures it is recommended that the unit be turned OFF with the ON/OFF push button before turning OFF the key switch.

## 2-7. MLTX Transmitter Board Setup Information.

The MLTX Transmitter Board is shown in Figure 2-7. Refer to paragraphs 1-2 through 1-10 for servicing procedures.




Figure 2-7. MLTX Transmitter Board

## 2-8. Setting Access Code (for units with no external code plug only)

The access code is set at the factory and should not be changed unless absolutely necessary. If a spare transmitter unit is used, the receiver unit access code should be changed to match the access code of the spare transmitter unit. For Part 15 systems the access codes are printed on a white label on the outside of any transmitter and may be matched to "A" and "B" on the receiver CPU Board without having to open the transmitter housing.

Switch SW2 (B) in the transmitter must match switch S4 (B) on the receiver CPU Board and switch SW1 (A) in the transmitter must match switch S5 (A) on the CPU Board.

For Part 90 systems the 12 bit access code is assigned starting with position A1 through A8 then B1 through B4. For 8 bit access codes, switch B is not used. See system documentation for the Part 90 access code.

If the codes do not match, you will get an error light DS9 on the CPU Board while transmitting.

## 2-9. Programming Switches

The programming switches in SW3 (C) controls the following features: *(These only apply to units originally programmed to utilize these features).*

External Code Plug Enable – Switch SW3 (C) – position 1 turn “ON” to enable external code plug.

Processor to send Software ID to PC Enable – Switch SW3 (C) – position 6 turn “ON” to allow special software to be enabled to read the software ID. (Only Magnetek authorized personnel has the ability to view.)

Tilt Switch Enable – Switch SW3 (C) – position 7 turn “ON” to enable the Tilt Switch.

Time-Out-Timer Disable – Switch SW3 (C) – position 8 turn “ON” to disable the transmitter time-out timer.

## 2-10. To Check Data.

- 1). For data input use the Data pin on the RF Module.
- 2). Use the RF SW pin on the RF Module for an External Trigger input.
- 3). Use test point TP2, for Ground.

## 2-11. Battery Monitor

Set to 5.8 Volts by R6 and R8 (not adjustable.)

## 2-12. Analog Voltage Reference

V+ (TP3) factory is adjusted with RPOT2. V- (TP1) factory is adjusted with RPOT2.

## 2-13. Transmit LED

This flashing red LED flashes rapidly during transmit, slowly when unit is ON and turns out when battery is low.



## 2-14. Batteries

Two batteries are available, a disposable alkaline battery (9V, BT113-0), a rechargeable NiMH (7.2V, BT114-0), and a rechargeable NiMH (12V, BT115-0). The charger for the BT114-0 and BT115-0 is E10757-0. You can attach up to two E10757-1 (piggyback chargers) to the E10757-0 charger. The typical recharge time for a completely discharged battery is approximately three hours. While NiMH batteries give improved performance over NiCAD, any rechargeable battery will give its best performance if the battery is fully discharged before recharging. Please follow local regulations for the disposal of any battery product.

## 2-15. Changing the Channel on the Part 15 Synthesized Transmitter

The channel can be changed by removing the logic board from the bottom housing. Locate the rotary switches on the RF Transmitter Board (see Figure 2-15 MLTX Synthesizer Board). The rotary switch nearest the corner of the board is the “ones” place-value selection (0-9). The rotary switch near the middle of the board is the “tens” place-value selection (10, 20, and 30).

**Figure 2-15 MLTX Synthesizer Board**



**2-16. Channel and Frequency Designations by Count**

Indicator Count	Channel Designator	Actual Frequency
01.	AK01	439.8 MHz
02.	AK02	439.6 MHz
03.	AK03	439.4 MHz
04.	AK04	439.2 MHz
05.	AK05	439.0 MHz
06.	AK06	438.8 MHz
07.	AK07	438.6 MHz
08.	AK08	438.4 MHz
09.	AK09	438.2 MHz
10.	AK10	438.0 MHz
11.	AK11	437.8 MHz
12.	AK12	437.6 MHz
13.	AK13	437.4 MHz
14.	AK14	437.2 MHz
15.	AK15	437.0 MHz
16.	AK16	436.8 MHz
17.	AK17	436.6 MHz
18.	AK18	436.4 MHz
19.	AK19	436.2 MHz
20.	AK20	436.0 MHz
21.	AKA00	433.125 MHz
22.	AKA01	433.325 MHz
23.	AKA02	433.525 MHz
24.	AKA03	433.725 MHz
25.	AKA04	433.925 MHz
26.	AKA05	434.125 MHz

**Compliance Statement (Part 15.19)**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**Warning (Part 15.21)**



Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This portable transmitter with its antenna complies with FCC's RF exposure limits for general population/uncontrolled exposure.


Indicator Count	Channel Designator	Actual Frequency
27.	AKA06	434.325 MHz
28.	AKA07	434.525 MHz
29.	AKA08	434.725 MHz
30.	AK38	432.4 MHz
31.	AK50	430.0 MHz

### 2-17. Changing the channel on the Part 90 VHF Synthesized Transmitter

The Part 90 VHF transmitter can be programmed for up to four different channels. The pre-programmed channels can be changed by moving the jumper to another channel. Please refer to the label on the transmitter board for the frequency of each channel.



Channel Jumper





## 2-18. Replacement Parts

If your transmitter ever needs repair, we always recommend that you contact Magnetek for service. If you need to refer to a parts list please refer to your transmitter's drawing that was included in the shipment of your transmitter. If you have trouble locating the drawing, the latest version is available on our web site at [www.magnetekmh.com](http://www.magnetekmh.com). For replacement batteries, chargers and hardware, please see the following drawings.

