

Q-Model Service Manual



Safety Notices

As you work on a Q-Series Ice Machine, be sure to pay close attention to the safety notices in this manual. Disregarding the notices may lead to serious injury and/ or damage to the ice machine.

Throughout this manual, you will see the following types of safety notices:

Warning PERSONAL INJURY POTENTIAL

Do not operate equipment that has been misused, abused, neglected, damaged, or altered/modified from that of original manufactured specifications.

A Warning

Text in a Warning box alerts you to a potential personal injury situation. Be sure to read the Warning statement before proceeding, and work carefully.

⚠ Caution

Text in a Caution box alerts you to a situation in which you could damage the ice machine. Be sure to read the Caution statement before proceeding, and work carefully.

Procedural Notices

As you work on a Q-Series Ice Machine, be sure to read the procedural notices in this manual. These notices supply helpful information which may assist you as you work.

Throughout this manual, you will see the following types of procedural notices:

Important

Text in an Important box provides you with information that may help you perform a procedure more efficiently. Disregarding this information will not cause damage or injury, but it may slow you down as you work.

NOTE: Text set off as a Note provides you with simple, but useful, extra information about the procedure you are performing.

We reserve the right to make product improvements at any time. Specifications and design are subject to change without notice.

Attend A Manitowoc Factory Service School

- Improve Your Service Techniques
- Network with Your Peers
- 4 1/2 Days of Intensive Training on Manitowoc Ice Machines
- Extensive "Hands On" Training on a Variety of Equipment
- Breakfast, Lunch and Hotel Room Included with Tuition
- Contact Your Distributor or Manitowoc Ice, Inc. for Details

OR

Visit Our Website at www.manitowocice.com for School Dates

MANITOWOC ICE, INC.

2110 South 26th Street P.O. Box 1720 Manitowoc, WI 54221-1720 Phone: (920) 682-0161 Service Fax: (920) 683-7585 Web Site - www.manitowocice.com

> © 2003 Manitowoc Ice, Inc. Litho in U.S.A.

Table of Contents

Section 1		
General Information		
	Model Numbers	1-1
	How to Read a Model Number	1-1
	Ice Cube Sizes	1-1
	Model/Serial Number Location	1-2
	Warranty Coverage	1-3
	General	1-3
	Parts	1-3
	Labor	1-3
	Exclusions	1-3
	Authorized Warranty Service	1-3
Section 2		
Installation Instruction	ons	
	General	2-1
	Ice Machine Dimensions	2-1
	Q320/Q370/Q420 Ice Machines	2-1
	Q200 – Q1000 Ice Machines	2-2
	Q1300/Q1600/Q1800 Ice Machines	2-2
	Q1300/Q1600/Q1800 Ice Machines (Cont.)	2-3
	Ice Storage Bin Dimensions	2-3
	S170/S400/S570 Ice Storage Bins	2-3
	S320/S420 Ice Storage Bins	2-3
	S970 Ice Storage Bins	2-4
	Remote Condenser Dimensions	2-4
	JC0495/JC0895/JC1095/JC1395	2-4
	JC1895	2-4 2-5
	Location of Ice Machine Stocking Two Ice Machines on a Single Storage Rin	2-5 2-5
	Stacking Two Ice Machines on a Single Storage Bin	2-5
	Leveling the Ice Storage Bin	2-6
	Air-Cooled Baffle	2-6
	Electrical Service	2-7
	General	2-7
	Voltage	2-7
	Fuse/Circuit Breaker	2-7
	Minimum Circuit Ampacity	2-7
	Self-Contained Electrical Wiring Connections	2-9
	Self Contained Ice Machine	
	115/1/60 or 208-230/1/60	2-9
	Self Contained Ice Machine	
	208-230/3/60	2-9
	Self Contained Ice Machine	
	230/1/50	2-9
	For United Kingdom Only	2_0

Part No. 80-1100-3

	Remote Electrical Wiring Connections	2-10
	Remote Ice Machine	
	With Single Circuit Model Condenser	
	115/1/60 or 208-230/1/60	2-10
	Remote Ice Machine	
	With Single Circuit Model Condenser	
	T	2-10
	Remote Ice Machine	-10
	With Single Circuit Model Condenser	
		2-10
	- 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2-11
	11.7	2-11
	Water Inlet Lines	2-11
	Drain Connections	2-11
	Cooling Tower Applications	
	(Water-Cooled Models)	2-11
	·	2-12
	· · · · · · · · · · · · · · · · · · ·	2-13
	Remote Ice Machines	
		2-13
		_
	••••••	2-14
		2-14
		2-15
		2-16
	• • • • • • • • • • • • • • • • • • • •	2-16
	Remote Receiver Service Valve	2-16
	Remote Ice Machine Usage with Non-Manitowoc Multi-Circuit Condensers	2-17
	Warranty	2-17
	· · · · · · · · · · · · · · · · · · ·	2-17
		2-17
		2-17
		2-17
		2-1 <i>7</i> 2-17
		2-1 <i>1</i> 2-17
	•	
	3 · · · · · · · · · · · · · · · · · · ·	2-18
		2-19
	Additional Checks for Remote Models	2-19
Section 3		
Maintenance		
	Component Identification	3-1
	Component Identification	-
	Operational Checks	3-2
	General	3-2
	Water Level	3-2
	Ice Thickness Check	3-2
	Harvest Sequence Water Purge	3-3
	Cleaning the Condenser	3-3
	Air-Cooled Condenser	3-3
	Water-Cooled Condenser	
	and Water Regulating Valve	3-4
	Interior Cleaning and Sanitizing	3-5
	General	3-5
	Manitowoc's Patented Cleaning or Sanitizing Technology	3-5
	Marinowoo 3 r atented Oleaning of Samilizing reciniology	J-J

2 Part No. 80-1100-3

	AlphaSan"	3-5
	Cleaning Procedure	3-6
	Sanitizing Procedure	3-7
	Procedure To Cancel A Cleaning Or	2.7
	Sanitizing Cycle After It Has Started	3-7 3-8
	Removal of Parts For Cleaning/Sanitizing	3-9
	Water Treatment/Filtration	3-14
	General	3-14
	Filter Replacement Procedure	3-14
	Removal from Service/Winterization	3-15
	General	3-15
	Self-Contained Air-Cooled Ice Machines	3-15
	Water-Cooled Ice Machines	3-15
	Remote Ice Machines	3-15
	AuCS" Accessory	3-15
Section 4		
Ice Machine Sequenc	e of Operation	
	Self-Contained Air- and Water-Cooled	
	Q200/Q280/Q320/Q370/Q420/Q450/Q600/Q800/Q1000/Q1300/Q1600/Q1800 .	4-1
	Initial Start-Up or Start-Up After Automatic Shut-Off	4-1
	Freeze Sequence	4-1
	Harvest Sequence	4-2
	Automatic Shut-Off	4-2
	Remote	
	Q450/Q600/Q800/Q1000/Q1300/Q1600/Q1800	4-3
	Initial Start-Up or Start-Up After Automatic Shut-Off	4-3 4-3
	Freeze Sequence	4-3 4-4
	Automatic Shut-Off	4-4
Section 5	line Orange of Operation	
water System ice ilia	king Sequence of Operation	
	Initial Start-Up or Start-Up After Automatic Shut-Off	5-1
	Freeze Cycle	5-1
	Water Inlet Valve Safety Shut-Off	5-1
	Harvest Cycle	5-2
	Automatic Shut-Off	5-2
Section 6		
Electrical System		
	Energized Parts Charts	6-1
	Self-Contained Air- And Water-Cooled Models	6-1
	Initial Start-Up or Start-Up After Automatic Shut-Off	6-1
	Remote Models	6-2
	1. Initial Start-Up or Start-Up After Automatic Shut-Off	6-2
	Wiring Diagram Sequence of Operation	6-3
	Self-Contained Models	6-3
	Remote Models	6-10

Wiring Diagrams	6-17
Wiring Diagram Legend	6-17
Q200/Q280/Q320 - Self Contained - 1 Phase With Terminal Board	6-18
Q280/Q370 - Self Contained - 1 Phase Without Terminal Board	6-19
Q320 - Self Contained - 1 Phase Without Terminal Board	6-20
Q420/Q450/Q600/Q800/Q1000 - Self Contained -	
1 Phase With Terminal Board	6-21
Q420/Q450/Q600/Q800/Q1000 - Self Contained -	
1 Phase Without Terminal Board	6-22
Q800/Q1000 - Self Contained - 3 Phase With Terminal Board	6-23
Q800/Q1000 - Self Contained - 3 Phase Without Terminal Board	6-24
Q1300/Q1800 - Self Contained - 1 Phase With Terminal Board	6-25
Q1300/Q1600/Q1800 - Self Contained - 1 Phase Without Terminal Board .	6-26
Q1300/Q1800 - Self Contained - 3 Phase With Terminal Board	6-27
Q1300/Q1600/Q1800 - Self Contained - 3 Phase Without Terminal Board .	6-28
Q450/Q600/Q800/Q1000 - Remote - 1 Phase With Terminal Board	6-29
Q450/Q600/Q800/Q1000 - Remote - 1 Phase Without Terminal Board	6-30
Q800/Q1000 -Remote - 3 Phase With Terminal Board	6-31
Q800/Q1000 - Remote - 3 Phase Without Terminal Board	6-32
Q1300/Q1800 - Remote - 1 Phase With Terminal Board	6-33
Q1300/Q1600/Q1800 - Remote - 1 Phase Without Terminal Board	6-34
Q1300/Q1800 - Remote - 3 Phase With Terminal Board	6-35
Q1300/Q1600/Q1800 - Remote - 3 Phase Without Terminal Board	6-36
Component Specifications and Diagnostics	6-38
Main Fuse	6-38
Bin Switch	6-38
Compressor Electrical Diagnostics	6-40
PTCR Diagnostics	6-41
ICE/OFF/CLEAN Toggle Switch	6-44
Control Board Relays	6-44
Electronic Control Board	6-45
Ice Thickness Probe (Harvest Initiation)	6-47
How The Probe Works	6-47
Harvest/Safety Limit Light	6-47
Freeze Time Lock-In Feature	6-47
Maximum Freeze Time	6-47
Ice Thickness Check	6-47
Diagnosing Ice Thickness Control Circuitry	6-48
Water Level Control Circuitry	6-50
Water Level Probe Light	6-50
Water Inlet Valve Safety Shut-Off	6-50
Freeze Cycle Circuitry	6-50
Harvest Cycle Circuitry	6-50
Diagnosing Freeze Cycle Potable Water Level Control Circuitry	6-51
Diagnosing An Ice Machine That Will Not Pun	6-54

4 Part No. 80-1100-3

Section 7 Refrigeration System

Sequence of Operation	7-1
Self-Contained Air or Water -Cooled Models	7-1
Remote Models	7-3
Q1300/Q1600/Q1800 Refrigeration Tubing Schematics	7-6
Operational Analysis (Diagnostics)	7-8
General	7-8
Before Beginning Service	7-9
Ice Production Check	7-9
Installation/Visual Inspection Checklist	7-10
Water System Checklist	7-10
Ice Formation Pattern	7-11
Safety Limits	7-13
Analyzing Discharge Pressure	
During Freeze or Harvest Cycle	7-17
Analyzing Suction Pressure	
During Freeze Cycle	7-18
Single Expansion Valve Ice Machines -	
Comparing Evaporator Inlet and	
Outlet Temperatures	7-20
Harvest Valve Temperature Check	7-21
Discharge Line Temperature Analysis	7-22
How to Use the Refrigeration System	
Operational Analysis Tables	7-24
Refrigeration System Operational Analysis Tables	7-25
Harvest Pressure Regulating	
(H.P.R.) System	7-27
Headmaster Control Valve	7-29
Pressure Control Specifications and Diagnostics	7-31
Fan Cycle Control	7-31
High Pressure Cut-Out (HPCO) Control	7-31
Cycle Time/24 Hour Ice Production/Refrigerant Pressure Charts	7-32
Q200 Series	7-32
Q280 Series	7-33
Q320 Series	7-34
Q370 Series	7-35
Q420/450 Series	7-36
Q450 Series	7-37
Q600 Series	7-37
Q800 Series	7-39
Q1000 Series	7-40
Q1300 Series	7-42
Q1600 Series	7-43
Q1800 Series	7-44

Refrigerant Recovery/Evacuation and Recharging
Normal Self-Contained Model Procedures
Normal Remote Model Procedures
System Contamination Clean-Up
Replacing Pressure Controls Without
Removing Refrigerant Charge
Filter-Driers
Total System Refrigerant Charges
Refrigerant Definitions
Refrigerant Re-Use Policy
HFC Refrigerant Questions and Answers

6 Part No. 80-1100-3

Section 1 General Information

Model Numbers

This manual covers the following models:

Self-Contained Air-Cooled	Self-Contained Water-Cooled	Remote
QR0320A	QR0321W	
QD0322A	QD0323W	
QY0324A	QY0325W	
QR0420A	QR0421W	
QD0422A	QD0423W	
QY0424A	QY0425W	
QR0200A	QR0201W	
QD0202A	QD0203W	
QY0204A	QY0205W	
QR0280A	QR0281W	
QD0282A	QD0283W	
QY0284A	QY0285W	
QD0372A	QD0373W	
QY0374A	QY0375W	
QR0450A	QR0451W	QR0490N
QD0452A	QD0453W	QD0492N
QY0454A	QY0455W	QY0494N
QR0600A	QR0601W	QR0690N
QD0602A	QD0603W	QD0692N
QY0604A	QY0605W	QY0694N
QR0800A	QR0801W	QR0890N
QD0802A	QD0803W	QD0892N
QY0804A	QY0805W	QY0894N
QR1000A	QR1001W	QR1090N
QD1002A	QD1003W	QD1092N
QY1004A	QY1005W	QY1094N
QR1300A	QR1301W	QR1390N
QD1302A	QD1303W	QD1392N
QY1304A	QY1305W	QY1394N
	QD1603W	QD1692N
	QY1605W	QY1694N
QR1800A	QR1801W	QR1890N
QD1802A	QD1803W	QD1892N
QY1804A	QY1805W	QY1894N


NOTE: Model numbers ending in 3 indicate a 3-phase

unit. Example: QY1804A3


▲ Warning PERSONAL INJURY POTENTIAL

Do not operate equipment that has been misused, abused, neglected, damaged, or altered/modified from that of original manufactured specifications.

How to Read a Model Number



Ice Cube Sizes



 Regular
 Dice
 Half Dice

 1-1/8" x 1-1/8" x 7/8"
 7/8" x 7/8" x 7/8"
 3/8" x 1-1/8" x 7/8"

 2.86 x 2.86 x 2.22 cm
 2.22 x 2.22 x 2.22 cm
 0.95 x 2.86 x 2.22 cm

Part No. 80-1100-3

General Information Section 1

Model/Serial Number Location

These numbers are required when requesting information from your local Manitowoc distributor, or Manitowoc Ice, Inc.

The model and serial number are listed on the MODEL/ SERIAL NUMBER DECAL affixed to the ice machine, remote condenser and storage bin.




Figure 1-1. Model/Serial Number Location

1-2 Part No. 80-1100-3

Section 1 General Information

Warranty Coverage

GENERAL

The following Warranty outline is provided for your convenience. For a detailed explanation, read the warranty bond shipped with each product.

Contact your local Manitowoc Distributor or Manitowoc Ice, Inc. if you need further warranty information.

Important

This product is intended exclusively for commercial application. No warranty is extended for personal, family, or household purposes.

PARTS

- Manitowoc warrants the ice machine against defects in materials and workmanship, under normal use and service for three (3) years from the date of original installation.
- 2. The evaporator and compressor are covered by an additional two (2) year (five years total) warranty beginning on the date of the original installation.

LABOR

- 1. Labor required to repair or replace defective components is covered for three (3) years from the date of original installation.
- 2. The evaporator is covered by an additional two (2) year (five years total) labor warranty beginning on the date of the original installation.

EXCLUSIONS

The following items are not included in the ice machine's warranty coverage:

- 1. Normal maintenance, adjustments and cleaning.
- Repairs due to unauthorized modifications to the ice machine or use of non-standard parts without prior written approval from Manitowoc Ice, Inc.
- Damage caused by improper installation of the ice machine, electrical supply, water supply or drainage, or damage caused by floods, storms, or other acts of God.
- 4. Premium labor rates due to holidays, overtime, etc.; travel time; flat rate service call charges; mileage and miscellaneous tools and material charges not listed on the payment schedule. Additional labor charges resulting from the inaccessibility of equipment are also excluded.
- 5. Parts or assemblies subjected to misuse, abuse, neglect or accidents.
- Damage or problems caused by installation, cleaning and/or maintenance procedures inconsistent with the technical instructions provided in this manual.
- This product is intended exclusively for commercial application. No warranty is extended for personal, family, or household purposes.

AUTHORIZED WARRANTY SERVICE

To comply with the provisions of the warranty, a refrigeration service company qualified and authorized by a Manitowoc distributor, or a Contracted Service Representative must perform the warranty repair.

General Information Section 1

THIS PAGE INTENTIONALLY LEFT BLANK

1-4 Part No. 80-1100-3

Section 2 Installation Instructions


General


Refer to Installation Manual for complete installation guidelines.

Important

Failure to follow these installation guidelines may affect warranty coverage.

Ice Machine Dimensions Q320/Q370/Q420 ICE MACHINES








Ice Machine	Dimension H
Q320	21.5 in (54.6 cm)
Q370	21.5 in (54.6 cm)
Q420	26.5 in (67.3 cm)

Q200 - Q1000 ICE MACHINES

Q1300/Q1600/Q1800 ICE MACHINES








SELF CONTAINED WATER-COOLED	10.50" (26.67 cm) 9.00" (22.86 cm)
	2.88" (7.32 cm)
	10.38" (26.37 cm)

Ice Machine	Dimension H
Q200 – Q280	16.5 in (41.9 cm)
Q450	21.5 in (54.6 cm)
Q600	21.5 in (54.6 cm)
Q800	26.5 in (67.3 cm)
Q1000	29.5 in (74.9 cm)


Ice Machine	Dimension H
Q1300/Q1600	29.5 in (74.9 cm)
Q1800	29.5 in (74.9 cm)

2-2 Part No. 80-1100-3

Q1300/Q1600/Q1800 ICE MACHINES (CONT.)




Ice Storage Bin Dimensions \$170/\$400/\$570 ICE STORAGE BINS




Bin Model	Dimension A	Dimension B
S170	29.5 in (74.9 cm)	19.1 in (48.5 cm)
S400	34.0 in (86.3 cm)	32.0 in (81.3 cm)
S570	34.0 in (86.3 cm)	44.0 in (111.7 cm)

S320/S420 ICE STORAGE BINS



Bin Model	Dimension A	Dimension B
S320	34.0 in (86.3 cm)	32.0 in (81.3 cm)
S420	34.0 in (86.3 cm)	44.0 in (111.7 cm)

S970 ICE STORAGE BINS




A Warning

All Manitowoc ice machines require the ice storage system (bin, dispenser, etc.) to incorporate an ice deflector.


The Q1300, Q1600 and Q1800 series ice machines require adding Manitowoc Ice Deflector Kit K00139 when installing with non-Manitowoc ice storage systems.

Prior to using a non-Manitowoc ice storage system with other Manitowoc ice machines, contact the manufacturer to assure their ice deflector is compatible with Manitowoc ice machines.

Remote Condenser Dimensions JC0495/JC0895/JC1095/JC1395



JC1895



2-4 Part No. 80-1100-3

Location of Ice Machine

The location selected for the ice machine must meet the following criteria. If any of these criteria are not met, select another location.

- The location must be free of airborne and other contaminants.
- The air temperature must be at least 35°F (1.6°C), but must not exceed 110°F (43.4°C).
- The location must not be near heat-generating equipment or in direct sunlight.
- The location must not obstruct air flow through or around the ice machine. Refer to the chart below for clearance requirements.

Q1300/Q1600/ Q1800	Self-Contained Air-Cooled	Water-Cooled and Remote
Top/Sides	24" (61 cm)	8" (20.3 cm)
Back	12" (30.5 cm)	5" (12.7 cm)

Q370	Self-Contained Air-Cooled	Water-Cooled
Top/Sides	12" (30.5 cm)	5" (12.7 cm)
Back	5" (127 mm)	5" (12.7 cm)

All other Q models	Self-Contained Air-Cooled	Water-Cooled and Remote
Top/Sides	8" (20.3 cm)	8" (20.3 cm)
Back	5" (12.7 cm)	5" (12.7 cm)

There is no minimum clearance required. This value is recommended for efficient operation and servicing only. Q1600 is not available as an air-cooled model.

The ice machine must be protected if it will be subjected to temperatures below 32°F (0°C). Failure caused by exposure to freezing temperatures is not covered by the warranty. See "Removal from Service/Winterization" on Page 3-14.

Stacking Two Ice Machines on a Single Storage Bin

A stacking kit is required for stacking two ice machines. Installation instructions are supplied with the stacking kit.

Q450/Q600/ Q800/Q1000	Stacked Self-Contained Air-Cooled	Stacked Water-Cooled and Remote*
Top/Sides	16" (40.64 cm)	5" (12.70 cm)
Back	5" (12.70 cm)	5" (12.70 cm)
Q1300/Q1600/ Q1800		
Top/Sides	48" (121.92 cm)	24" (60.96 cm)
Back	12" (30.48 cm)	12" (30.48 cm)

^{*}There is no minimum clearance required. This value is recommended for efficient operation and servicing only. Q1600 is not available as an air-cooled model.

Ice Machine Heat of Rejection

Series	Heat of Rejection		
Ice Machine	Air Conditioning	Peak	
Q320	4,600	6,200	
Q370	3,900	5,950	
Q420	7,000	9,600	
Q200	3,800	5,000	
Q280	3,800	6,000	
Q450	7,000	9,600	
Q600	9,000	13,900	
Q800	12,400	19,500	
Q1000	16,000	24,700	
Q1300	24,000	35,500	
Q1600	24,000	35,500	
Q1800	36,000	50,000	

B.T.U./Hour

Because the heat of rejection varies during the ice making cycle, the figure shown is an average.

Ice machines, like other refrigeration equipment, reject heat through the condenser. It is helpful to know the amount of heat rejected by the ice machine when sizing air conditioning equipment where self-contained aircooled ice machines are installed.

This information is also necessary when evaluating the benefits of using water-cooled or remote condensers to reduce air conditioning loads. The amount of heat added to an air conditioned environment by an ice machine using a water-cooled or remote condenser is negligible.

Knowing the amount of heat rejected is also important when sizing a cooling tower for a water-cooled condenser. Use the peak figure for sizing the cooling tower

Leveling the Ice Storage Bin

- 1. Screw the leveling legs onto the bottom of the bin.
- 2. Screw the foot of each leg in as far as possible.

The legs must be screwed in tightly to prevent them from bending.

- 3. Move the bin into its final position.
- 4. Level the bin to assure that the bin door closes and seals properly. Use a level on top of the bin. Turn each foot as necessary to level the bin.

NOTE: An optional caster assembly is available for use in place of the legs. Installation instructions are supplied with the casters.




Figure 2-1. Leveling Leg and Foot

Air-Cooled Baffle

The air-cooled baffle prevents condenser air from recirculating. To install:

- Remove the back panel screws next to the condenser.
- 2. Align the mounting holes in the air baffle with the screw holes and reinstall the screws.




Figure 2-2. Air Baffle

2-6 Part No. 80-1100-3

Electrical Service GENERAL

A Warning

All wiring must conform to local, state and national codes.

VOLTAGE

The maximum allowable voltage variation is ±10% of the rated voltage at ice machine start-up (when the electrical load is highest).

A Warning

The ice machine must be grounded in accordance with national and local electrical codes.

FUSE/CIRCUIT BREAKER

A separate fuse/circuit breaker must be provided for each ice machine. Circuit breakers must be H.A.C.R. rated (does not apply in Canada).

MINIMUM CIRCUIT AMPACITY

The minimum circuit ampacity is used to help select the wire size of the electrical supply. (Minimum circuit ampacity is not the ice machine's running amp load.)

The wire size (or gauge) is also dependent upon location, materials used, length of run, etc., so it must be determined by a qualified electrician.

Installation Instructions

Table 2-1. Q320/370/420 Ice Machines

	Voltage	Air-Co	Air-Cooled		Cooled
Ice Machine	Phase Cycle	Maximum Fuse/ Circuit Breaker	Minimum Circuit Amps	Maximum Fuse/ Circuit Breaker	Minimum Circuit Amps
	115/1/60	15	11.2	15	10.5
Q320	208-230/1/60	15	4.8	15	4.2
	230/1/50	15	5.2	15	4.7
	115/1/60	20	12.9	20	12.2
Q370	208-230/1/60	15	6.2	15	5.8
	230/1/50	15	6.2	15	5.8
	115/1/60	20	12.3	20	11.4
Q420	208-230/1/60	15	7.8	15	7.4
	230/1/50	15	6.3	15	5.9

Table 2-2. Q200 - Q1000 Ice Machines

	Valtana	Air-Cooled		Water Cooled		Remote	
Ice Machine F	Voltage Phase Cycle	Maximum Fuse/Circuit Breaker	Minimum Circuit Amps	Maximum Fuse/Circuit Breaker	Minimum Circuit Amps	Maximum Fuse/Circuit Breaker	Minimum Circuit Amps
	115/1/60	15	11.6	15	10.9	N/A	N/A
Q200	208-230/1/60	15	5.4	15	4.8	N/A	N/A
	230/1/50	15	5.2	15	4.9	N/A	N/A
	115/1/60	20	12.6	20	11.7	N/A	N/A
Q280	208-230/1/60	15	5.7	15	5.2	N/A	N/A
	230/1/50	15	5.7	15	5.2	N/A	N/A
	115/1/60	20	12.8	20	11.9	20	13.6
Q450	208-230/1/60	15	7.8	15	7.4	N/A	N/A
	230/1/50	15	6.1	15	5.7	N/A	N/A
0000	208-230/1/60	15	9.2	15	8.7	15	9.3
Q600	230/1/50	15	9.2	15	8.8	15	9.4
	208-230/1/60	20	12.1	20	11.4	20	11.9
Q800	208-230/3/60	15	8.9	15	8.2	15	8.9
	230/1/50	20	12.0	20	10.6	20	11.2
	208-230/1/60	20	14.3	20	13.2	20	14.2
Q1000	208-230/3/60	15	9.8	15	8.8	15	9.9
	230/1/50	20	15.6	20	14.2	20	14.6
	208-230/1/60	30	19.5	30	18.1	30	19.8
Q1300	208-230/3/60	20	13.1	20	11.6	20	12.7
Q1300	230/1/50	30	15.7	30	14.3	30	14.7
	380-415/3/50	N/A	N/A	N/A	N/A	15	7.3
	208-230/1/60	N/A	N/A	30	17.2	30	18.2
04600	208-230/3/60	N/A	N/A	20	11.0	20	12.0
Q1600	230/1/50	N/A	N/A	N/A	N/A	N/A	N/A
	380-415/3/50	N/A	N/A	N/A	N/A	N/A	N/A
	208-230/1/60	40	28.1	40	26.7	40	26.9
04000	208-230/3/60	20	15.5	20	14.1	20	13.9
Q1800	230/1/50	40	23.3	40	21.9	40	22.2
	380-415/3/50	N/A	N/A	N/A	N/A	15	9.1

2-8 Part No. 80-1100-3

Self-Contained Electrical Wiring Connections


Warning

These diagrams are not intended to show proper wire routing, wire sizing, disconnects, etc., only the correct wire connections.


All electrical work, including wire routing and grounding, must conform to local, state and national electrical codes.

Though wire nuts are shown in the drawings, the ice machine field wiring connections may use either wire nuts or screw terminals.


SELF CONTAINED ICE MACHINE 115/1/60 OR 208-230/1/60



SELF CONTAINED ICE MACHINE 208-230/3/60



SELF CONTAINED ICE MACHINE 230/1/50



For United Kingdom Only

As the colours of the wires in the mains lead of the appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

- The wire which is coloured green and yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth ground symbol or coloured green or green and yellow.
- The wire coloured <u>blue</u> must be connected to the terminal which is marked with the letter N or coloured black.
- The wire coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Remote Electrical Wiring Connections


A Warning

These diagrams are not intended to show proper wire routing, wire sizing, disconnects, etc., only the correct wire connections.


All electrical work, including wire routing and grounding, must conform to local, state and national electrical codes.

Though wire nuts are shown in the drawings, the ice machine field wiring connections may use either wire nuts or screw terminals.


REMOTE ICE MACHINE WITH SINGLE CIRCUIT MODEL CONDENSER 115/1/60 OR 208-230/1/60



REMOTE ICE MACHINE WITH SINGLE CIRCUIT MODEL CONDENSER 208-230/3/60 OR 380-415/3/50



REMOTE ICE MACHINE WITH SINGLE CIRCUIT MODEL CONDENSER 230/1/50



2-10 Part No. 80-1100-3

Water Supply and Drain Requirements WATER SUPPLY

Local water conditions may require treatment of the water to inhibit scale formation, filter sediment, and remove chlorine odor and taste.

Important

If you are installing a Manitowoc water filter system, refer to the Installation Instructions supplied with the filter system for ice making water inlet connections.

WATER INLET LINES

Follow these guidelines to install water inlet lines:

- Do not connect the ice machine to a hot water supply. Be sure all hot water restrictors installed for other equipment are working. (Check valves on sink faucets, dishwashers, etc.)
- If water pressure exceeds the maximum recommended pressure, obtain a water pressure regulator from your Manitowoc distributor.
- Install a water shut-off valve for both the ice making and condenser water lines.
- Insulate water inlet lines to prevent condensation.

DRAIN CONNECTIONS

Follow these guidelines when installing drain lines to prevent drain water from flowing back into the ice machine and storage bin:

- Drain lines must have a 1.5 inch drop per 5 feet of run (2.5 cm per meter), and must not create traps.
- The floor drain must be large enough to accommodate drainage from all drains.
- Run separate bin and ice machine drain lines.
 Insulate them to prevent condensation.
- Vent the bin and ice machine drain to the atmosphere. Do not vent the condenser drain on water-cooled models.

Cooling Tower Applications (Water-Cooled Models)

A water cooling tower installation does not require modification of the ice machine. The water regulator valve for the condenser continues to control the refrigeration discharge pressure.

It is necessary to know the amount of heat rejection, and the pressure drop through the condenser and water valves (inlet and outlet) when using a cooling tower on an ice machine.

- Water entering the condenser must not exceed 90°F (32.2°C).
- Water flow through the condenser must not exceed 5 gallons (19 liters) per minute.
- Allow for a pressure drop of 7 psi (48 kPA) between the condenser water inlet and the outlet of the ice machine.
- Water exiting the condenser must not exceed 110°F (43.3°C).

WATER SUPPLY AND DRAIN LINE SIZING/CONNECTIONS

⚠ Caution

Plumbing must conform to state and local codes.

Location	Water Temperature	Water Pressure	Ice Machine Fitting	Tubing Size Up to Ice Machine Fitting
Ice Making	33°F (0.6°C) Min.	20 psi (137.9 kPA) Min.	3/8" Female	3/8" (9.5 mm) minimum
Water Inlet	90°F (32.2°C) Max.	80 psi (551.5 kPA) Max.	Pipe Thread	inside diameter
Ice Making			1/2" Female	1/2" (12.7 mm) minimum
Water Drain			Pipe Thread	inside diameter
Condenser	33°F (0.6°C) Min.	20 psi (137.9 kPA) Min.	Q1300/Q1600/Q1800 -	1/2" Female Pipe Thread
Water Inlet	90°F (32.2°C) Max.	150 psi (1034.2 kPA) Max.	All Others - 3/8" F	Female Pipe Thread
Condenser			1/2" Female	1/2" (12.7 mm) minimum
Water Drain			Pipe Thread	inside diameter
Bin Drain			3/4" Female	3/4" (19.1 mm) minimum
Bill Blaili			Pipe Thread	inside diameter




Figure 2-3. Typical Water Supply Drain Installation

2-12 Part No. 80-1100-3

Remote Condenser/Line Set Installation

Ice Machine	Remote Single Circuit Condenser	Line Set*
Q490	JC0495	RT-20-R404A
Q690	JC0895	RT-35-R404A
Q890		RT-50-R404A
Q1090	JC1095	
Q1390	JC1395	RL-20-R404A
Q1690	JC1695	RL-35-R404A
Q1890	JC1895	RL-50-R404A

*Line Set	Discharge Line	Liquid Line
RT	1/2" (1.27 cm)	5/16" (.79 cm)
RL	1/2" (1.27 cm)	3/8" (.95 cm)

Air Temperature Around the Condenser				
Minimum Maximum				
-20°F (-28.9°C)	120°F (49°C)			

REMOTE ICE MACHINES REFRIGERANT CHARGE

Each remote ice machine ships from the factory with a refrigerant charge appropriate for installation with line sets of up to 50' (15.25 m). The serial tag on the ice machine indicates the refrigerant charge.

Additional refrigerant may be required for installations using line sets between 50' and 100' (15.25-30.5 m) long. If additional refrigerant is required, an additional label located next to the Model/Serial Numbers decal states the amount of refrigerant to be added.

IMPORTANT EPA CERTIFIED TECHNICIANS				
If remote line set length is between 50' and 100' (15.25-30.5 m), add 1.5 lb. (24 oz) (0.68 kg) of refrigerant to the nameplate charge.				
Tubing length:				
Refrigerant added to nameplate:				
New total refrigerant charge:				

Figure 2-4. Typical Additional Refrigerant Label

If there is no additional label, the nameplate charge is sufficient for line sets up to 100' (30.5 m). (See the chart below.)

WARNING Potential Personal Injury Situation

The ice machine contains refrigerant charge. Installation of the line sets must be performed by a properly trained and EPA certified refrigeration technician aware of the **dangers** of dealing with refrigerant charged equipment.

Ice Machine	Nameplate Charge	Refrigerant to be Added for	Maximum System Charge		
ice wachine	(Charge Shipped in Ice Machine)	50'-100' Line Sets	(Never Exceed)		
Q490	6 lb. (96 oz.)	None	6 lb. (96 oz.)		
Q690	8 lb. (128 oz.)	None	8 lb. (128 oz.)		
Q890	8 lb. (128 oz.)	None	8 lb. (128 oz.)		
Q1090	9.5 lb. (152 oz.)	None	9.5 lb. (152 oz.)		
Q1390	12.5 lb. (200 oz.)	1.5 lb. (24 oz)	14 lb. (224 oz.)		
Q1690	15 lb. (240 oz.)	2.0 lb. (32 oz)	17 lb. (272 oz.)		
Q1890	15 lb. (240 oz.)	2.0 lb. (32 oz)	17 lb. (272 oz.)		

GENERAL

Condensers must be mounted horizontally with the fan motor on top.

Remote condenser installations consist of vertical and horizontal line sets between the ice machine and the condenser. When combined, they must fit within approved specifications. The following guidelines, drawings and calculation methods must be followed to verify a proper remote condenser installation.

⚠ Caution

The 60 month compressor warranty (including the 36 month labor replacement warranty) will not apply if the remote ice machine is not installed according to specifications.

This warranty also will not apply if the refrigeration system is modified with a condenser, heat reclaim device, or other parts or assemblies not manufactured by Manitowoc Ice, Inc., unless specifically approved in writing by Manitowoc Ice, Inc.

GUIDELINES FOR ROUTING LINE SETS

First, cut a 2.5" (6.35 cm) circular hole in the wall or roof for tubing routing. The line set end with the 90° bend will connect to the ice machine. The straight end will connect to the remote condenser.

Follow these guidelines when routing the refrigerant lines. This will help insure proper performance and service accessibility.

- Optional Make the service loop in the line sets (See Figure 2-5). This permits easy access to the ice machine for cleaning and service. Do not use hard rigid copper at this location.
- Required Do not form traps in the refrigeration lines (except the service loop). Refrigerant oil must be free to drain toward the ice machine or the condenser. Route excess tubing in a supported downward horizontal spiral (See Figure 2-5). Do not coil tubing vertically.
- 3. Required Keep outdoor refrigerant line runs as short as possible.




Figure 2-5. Routing Line Sets

2-14 Part No. 80-1100-3

CALCULATING REMOTE CONDENSER INSTALLATION DISTANCES

Line Set Length

The maximum length is 100' (30.5 m).

The ice machine compressor must have the proper oil return. The receiver is designed to hold a charge sufficient to operate the ice machine in ambient temperatures between -20°F (-28.9°C) and 120°F (49°C), with line set lengths of up to 100' (30.5 m).

Line Set Rise/Drop

The maximum rise is 35' (10.7 m).

The maximum drop is 15' (4.5 m).

♠ Caution

If a line set has a rise followed by a drop, another rise cannot be made. Likewise, if a line set has a drop followed by a rise, another drop cannot be made.

Calculated Line Set Distance

The maximum distance is 150' (45.7 m).

Line set rises, drops, horizontal runs (or combinations of these) in excess of the stated maximums will exceed compressor start-up and design limits. This will cause poor oil return to the compressor.

Make the following calculations to make sure the line set layout is within specifications.

- Insert the measured rise into the formula below.
 Multiply by 1.7 to get the calculated rise.
 (Example: A condenser located 10 feet above the ice machine has a calculated rise of 17 feet.)
- Insert the measured drop into the formula below.
 Multiply by 6.6 to get the calculated drop.
 (Example. A condenser located 10 feet below the ice machine has a calculated drop of 66 feet.)
- 3. Insert the **measured horizontal distance** into the formula below. No calculation is necessary.
- 4. Add together the **calculated rise**, **calculated drop**, and **horizontal distance** to get the **total calculated distance**. If this total exceeds 150' (45.7 m), move the condenser to a new location and perform the calculations again.

Maximum Line Set Distance Formula

Step 1.Measured Rise (35' [10.7 m] Maximum)______ x 1.7= ______ Calculated RiseStep 2.Measured Drop (15' [4.5 m] Maximum)_____ x 6.6= _____ Calculated DropStep 3.Measured Horizontal Distance (100' [30.5 m] Maximum)______ Horizontal DistanceStep 4.Total Calculated Distance 150' (45.7 m)______ Total Calculated Distance




Figure 2-6. Combination of a Rise and a Horizontal Run




Figure 2-7. Combination of a Drop and a Horizontal Run




Figure 2-8. Combination of a Rise, a Drop and a Horizontal Run

LENGTHENING OR REDUCING LINE SET LENGTHS

In most cases, by routing the line set properly, shortening will not be necessary. When shortening or lengthening is required, do so before connecting the line set to the ice machine or the remote condenser. This prevents the loss of refrigerant in the ice machine or condenser.

The quick connect fittings on the line sets are equipped with Schraeder valves. Use these valves to recover any vapor charge from the line set. When lengthening or shortening lines, follow good refrigeration practices and insulate new tubing. Do not change the tube sizes. Evacuate the lines and place about 5 oz (143g) of vapor refrigerant charge in each line.

CONNECTING A LINE SET

- Remove the dust caps from the line set, condenser and ice machine.
- Apply refrigeration oil to the threads on the quick disconnect couplers before connecting them to the condenser.
- 3. Carefully thread the female fitting to the condenser or ice machine by hand.
- Tighten the couplings with a wrench until they bottom out.
- 5. Turn an additional 1/4 turn to ensure proper brassto-brass seating. Torque to the following specifications:

Liquid Line	Discharge Line
10-12 ft lb.	35-45 ft lb.
(13.5-16.2 N•m)	(47.5-61.0 N•m)

6. Check all fittings for leaks.

REMOTE RECEIVER SERVICE VALVE

The receiver service valve is closed during shipment. Open the valve prior to starting the ice machine.

- 1. Remove the top and left side panels.
- 2. Remove the receiver service valve cap.
- 3. Backseat (open) the valve.
- 4. Reinstall the cap and panels.




Figure 2-9. Backseating the Receiver Service Valve

2-16 Part No. 80-1100-3

Remote Ice Machine Usage with Non-Manitowoc Multi-Circuit Condensers

WARRANTY

The sixty (60) month compressor warranty, including thirty six (36) month labor replacement warranty, **shall not apply** when the remote ice machine is not installed within the remote specifications. The foregoing warranty shall not apply to any ice machine installed and/or maintained inconsistent with the technical instructions provided by Manitowoc Ice, Inc. Performance may vary from Sales specifications. Q-Model ARI certified standard ratings only apply when used with a Manitowoc remote condenser.

If the design of the condenser meets the specifications, Manitowoc's <u>only</u> approval is for full warranty coverage to be extended to the Manitowoc manufactured part of the system. Since Manitowoc does <u>not</u> test the condenser in conjunction with the ice machine, Manitowoc will not endorse, recommend, or approve the condenser, and will not be responsible for its performance or reliability.

Important

Manitowoc warrants only complete new and unused remote packages. Guaranteeing the integrity of a new ice machine under the terms of our warranty prohibits the use of pre-existing (used) tubing or condensers.

HEAD PRESSURE CONTROL VALVE

Any remote condenser connected to a Manitowoc Q-Model Ice Machine must have a head pressure control valve #836809-3 (available from Manitowoc Distributors) installed on the condenser package. Manitowoc will not accept substitute "off the shelf" head pressure control valves.

∴ Caution

Do not use a fan cycling control to try to maintain discharge pressure. Compressor failure will result.

FAN MOTOR

The condenser fan must be **on** during the complete ice machine freeze cycle (do not cycle on fan cycle control). The ice maker has a condenser fan motor circuit for use with a Manitowoc condenser. It is recommended that this circuit be used to control the condenser fan(s) on the multi-circuit condenser to assure it is on at the proper time. **Do not exceed the rated amps for the fan motor circuit listed on the ice machine's serial tag.**

INTERNAL CONDENSER VOLUME

The multi-circuit condenser internal volume must not be less than or exceed that used by Manitowoc (see chart on Page 2-18). Do not exceed internal volume and try to add charge to compensate, as compressor failure will result.

CONDENSER AT

 ΔT is the difference in temperature between the condensing refrigerant and entering air. The ΔT should be 15 to 20°F (-9.4 to -6.6°C) at the beginning of the freeze cycle (peak load conditions) and drop down to 12 to 17°F (-11.1 to -8.3°C) during the last 75% of the freeze cycle (average load conditions).

REFRIGERANT CHARGE

Remote ice machines have the serial plate refrigerant charge (total system charge) located in the ice maker section. (Remote condensers and line sets are supplied with only a vapor charge.)

Never add more than nameplate charge to ice machine for any application.

QUICK CONNECT FITTINGS

The ice machine and line sets come with quick connect fittings. It is recommended that matching quick connects (available through Manitowoc Distributors) be installed in the multi-circuit condenser, and that a vapor "holding" charge (5 oz.) of proper refrigerant be added to the condenser prior to connection of the ice machine or line set to the condenser.

NON-MANITOWOC MULTI-CIRCUIT CONDENSER SIZING CHART

Ice Machine	Refriç	gerant	Heat of F	Rejection	Cond	ernal denser ne (cu ft) Design Pressure		Quick Connect Stubs- Male Ends		Head Pressure Control
Model	Туре	Charge	Average Btu/hr	Peak Btu/hr	Min	Max	Fiessule	Discharge	Liquid	Valve
Q450	R-404A	6 lbs.	7,000	9,600	0.020	0.035	500 psig	coupling	coupling	Manitowoc
Q600	R-404A	8 lbs.	9,000	13,900	0.045	0.060	safe working pressure	P/N 83-6035-3	P/N 83-6034-3	P/N 83-6809-3
Q800	R-404A	8 lbs.	12,400	19,500	0.045	0.060]			
Q1000	R-404A	9.5 lbs.	16,000	24,700	0.065	0.085	2,500 psig	mounting	mounting	
Q1300	R-404A	14 lbs. ¹	24,000	35,500	0.085	0.105	burst pressure	flange P/N	flange P/N	no substitutes
Q1600	R-404A	17 lbs. ¹	36,000	50,000	0.130	0.170		ire 83-6006-3 83	83-6005-3	Jubalitutes
Q1800	R-404A	17 lbs.	36,000	50,000	0.130	0.170				

Amount reflects additional R-404A refrigerant added to nameplate charge for 50' to 100' line sets, to ensure proper operation at all ambient conditions. Q1300 has 1.5 lbs. additional R-404A. Q1600 and Q1800 has 2.0 lbs. additional R-404A




Figure 2-10. Typical Single Circuit Remote Condenser Installation

2-18 Part No. 80-1100-3

Installation Check List	Are the ice machine and bin drains vented?
Is the Ice Machine level?	Are all electrical leads free from contact with
Has all of the internal packing been removed?	refrigeration lines and moving equipment?
Have all of the electrical and water connections been made?	Has the owner/operator been instructed regarding maintenance and the use of Manitowoc Cleaner and Sanitizer?
Has the supply voltage been tested and checked against the rating on the nameplate?	Has the owner/operator completed the warranty registration card?
Is there proper clearance around the ice machine for air circulation?	Has the ice machine and bin been sanitized?
Has the ice machine been installed where ambient temperatures will remain in the range of 35° - 110°F (1.7° - 43.3°C)?	Is the toggle switch set to ice? (The toggle switch is located directly behind the front panel).
Has the ice machine been installed where the incoming water temperature will remain in the range of 33° - 90°F (0.6° - 32.2°C)?	Is the ice thickness control set correctly? (Refer to Operational Checks on page 3-4 of this manual to check/set the correct ice bridge thickness).
Is there a separate drain for the water-cooled	Additional Checks for Remote Models
condenser?	Has the receiver service valve been opened?
Is the water trough drain plug installed? (The drain plug is taped to the top of the water pump).	Does the remote condenser fan operate properly after start-up?
	Has the remote condenser been located where ambient temperatures will remain in the range of -20° - 120°F (-6.6 - 49°C).
	Is the line set routed properly?

THIS PAGE INTENTIONALLY LEFT BLANK

2-20 Part No. 80-1100-3

Section 3 Maintenance

Component Identification




Figure 3-1. Component Identification (Typical Q450 Shown)

Maintenance Section 3

Operational Checks

GENERAL

Manitowoc ice machines are factory-operated and adjusted before shipment. Normally, new installations do not require any adjustment.

To ensure proper operation, always follow the Operational Checks:

- when starting the ice machine for the first time
- · after a prolonged out of service period
- · after cleaning and sanitizing

NOTE: Routine adjustments and maintenance procedures are not covered by the warranty.

WATER LEVEL

The water level sensor is set to maintain the proper water level above the water pump housing. The water level is not adjustable.

If the water level is incorrect, check the water level probe for damage (probe bent, etc.). Repair or replace the probe as necessary.




Figure 3-2. Water Level Probe

ICE THICKNESS CHECK

The ice thickness probe is factory-set to maintain the ice bridge thickness at 1/8" (3.2 mm).

NOTE: Make sure the water curtain is in place when performing this check. It prevents water from splashing out of the water trough.

- 1. Inspect the bridge connecting the cubes. It should be about 1/8" (3.2 mm) thick.
- If adjustment is necessary, turn the ice thickness probe adjustment screw clockwise to increase bridge thickness, counterclockwise to decrease bridge thickness.

NOTE: Turning the adjustment 1/3 of a turn will change the ice thickness about 1/16" (1.5 mm).




Figure 3-3. Ice Thickness Check

3. Make sure the ice thickness probe wire and the bracket do not restrict movement of the probe.

3-2 Part No. 80-1100-3

Section 3 Maintenance

HARVEST SEQUENCE WATER PURGE

The harvest sequence water purge adjustment may be used when the ice machine is hooked up to special water systems, such as a de-ionized water treatment system.

Important

The harvest sequence water purge is factory-set at 45 seconds. A shorter purge setting (with standard water supplies such as city water) is not recommended. This can increase water system cleaning and sanitizing requirements.

- The harvest sequence water purge may be set to 15, 30, or 45 seconds.
- During the harvest sequence water purge, the water fill valve energizes and de-energizes by time. The water purge must be at the factory setting of 45 seconds for the water fill valve to energize during the last 15 seconds of the water purge. If it is set to less than 45 seconds, the water fill valve will not energize during the water purge.




Figure 3-4. Water Purge Adjustment

Cleaning the Condenser

📤 Warning

Disconnect electric power to the ice machine and the remote condenser at the electric service switch before cleaning the condenser.

AIR-COOLED CONDENSER

(SELF-CONTAINED AND REMOTE MODELS)

A dirty condenser restricts airflow, resulting in excessively high operating temperatures. This reduces ice production and shortens component life. Clean the condenser at least every six months. Follow the steps below.

⚠ Caution

The condenser fins are sharp. Use care when cleaning them.

 The washable aluminum filter on self-contained ice machines is designed to catch dust, dirt, lint and grease. This helps keep the condenser clean. Clean the filter with a mild soap and water solution.




Figure 3-5. Self-Contained Air-Cooled Filter

 Clean the outside of the condenser (bottom of a remote condenser) with a soft brush or a vacuum with a brush attachment. Clean from top to bottom, not side to side. Be careful not to bend the condenser fins.

Continued on next page ...

Maintenance Section 3

- 3. Shine a flashlight through the condenser to check for dirt between the fins. If dirt remains:
 - A. Blow compressed air through the condenser fins from the inside. Be careful not to bend the fan blades.
 - B. Use a commercial condenser coil cleaner.
 Follow the directions and cautions supplied with the cleaner
- 4. Straighten any bent condenser fins with a fin comb.




Figure 3-6. Straighten Bent Condenser Fins

Carefully wipe off the fan blades and motor with a soft cloth. Do not bend the fan blades. If the fan blades are excessively dirty, wash with warm, soapy water and rinse thoroughly.

If you are cleaning the condenser fan blades with water, cover the fan motor to prevent water damage.

WATER-COOLED CONDENSER AND WATER REGULATING VALVE

Symptoms of restrictions in the condenser water circuit include:

- · Low ice production
- · High water consumption
- · High operating temperatures
- · High operating pressures

If the ice machine is experiencing any of these symptoms, the water-cooled condenser and water regulating valve may require cleaning due to scale build-up.

The cleaning procedures require special pumps and cleaning solutions. Follow the manufacturer's instructions for the specific cleaner being used.

3-4 Part No. 80-1100-3

Section 3 Maintenance

Interior Cleaning and Sanitizing GENERAL

Clean and sanitize the ice machine every six months for efficient operation. If the ice machine requires more frequent cleaning and sanitizing, consult a qualified service company to test the water quality and recommend appropriate water treatment or installation of AuCS® accessory (Automatic Cleaning System). If required, an extremely dirty ice machine may be taken apart for cleaning and sanitizing.

Use only Manitowoc approved Ice Machine Cleaner (part number 94-0546-3) and Sanitizer (part number 94-0565-3). It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling. Read and understand all labels printed on bottles before use.

⚠ Caution

Do not mix Cleaner and Sanitizer solutions together. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling.

A Warning

Wear rubber gloves and safety goggles (and/or face shield) when handling ice machine Cleaner or Sanitizer.

MANITOWOC'S PATENTED CLEANING OR SANITIZING TECHNOLOGY

Manitowoc Ice Machines include technology that allows the initiation and completion of a cleaning or sanitizing cycle at the flip of a switch. This cycle will permit cleaning or sanitizing of all surfaces that come in contact with the water distribution system. Periodic maintenance must be performed that includes sanitizing the bin (or dispenser) and adjacent surface areas, which cannot be contacted by the water distribution system.

This technology will also allow initiation and completion of a clean or sanitize cycle, after which the ice machine automatically starts ice making again.

Refer to the cleaning or sanitizing procedure for complete details.

The AuCS Accessory can be set to automatically start and finish a clean or sanitize cycle every 2, 4, or 12 weeks. This accessory monitors ice-making cycles and initiates a cleaning or sanitizing cycle automatically. Refer to Automatic Cleaning System (AuCS) Accessory for further details.

ALPHASAN®

The goal of AlphaSan® is to keep the plastic surfaces of an ice machine cleaner, by reducing or delaying the formation of bio-film. The active ingredient in AlphaSan® is the element silver in the form of silver ions (Ag+). AlphaSan® slowly releases silver ions via an ion exchange mechanism. When AlphaSan® is compounded directly into a plastic part, a controlled release of silver ions from the surface is regulated to maintain an effective concentration at or near the surface of the plastic ice machine part. AlphaSan's® unique ability to effectively control the release of silver not only protects against undesired discoloration of the plastic, but also will last the life of the plastic part. Although AlphaSan® helps prevent bio-film build up it does not eliminate the need for periodic cleaning and maintenance. AlphaSan® has no adverse effect on the taste of the ice or beverage.

Maintenance Section 3

CLEANING PROCEDURE

Ice machine cleaner is used to remove lime scale or other mineral deposits. It is not used to remove algae or slime. Refer to the section on Sanitizing for removal of algae and slime.

Step 1 Set the toggle switch to the OFF position after ice falls from the evaporator at the end of a Harvest cycle. Or, set the switch to the OFF position and allow the ice to melt off the evaporator.

Never use anything to force ice from the evaporator. Damage may result.

Step 2 To start cleaning, place the toggle switch in the CLEAN position. The water will flow through the water dump valve and down the drain. The Clean light will turn on to indicate the ice machine is in the Cleaning mode.

Step 3 Wait about one minute or until water starts to flow over the evaporator.

Step 4 Add the proper amount of Manitowoc Ice Machine Cleaner to the water trough.

Model	Amount of Cleaner
Q200 Q280 Q320 Q370	3 ounces (90 ml)
Q420 Q450 Q600 Q800	5 ounces (150 ml)
Q1000 Q1300	9 ounces (270 ml)
Q1600 Q1800	

Step 5 The ice machine will automatically time out a ten minute cleaning cycle, followed by six rinse cycles, and stop. The Clean light will turn off to indicate the Cleaning mode is completed. This entire cycle lasts approximately 25 minutes.

Step 6 When the cleaning process stops, move the toggle switch to OFF position. Refer to "Sanitizing Procedure" on the next page.

Step 7

- A. The ice machine may be set to start and finish a cleaning procedure then automatically start ice making again.
- B. You must wait about one minute into the cleaning cycle (until water starts to flow over the evaporator) then move the switch from CLEAN to ICE position.
- C. When the cleaning cycle is completed, an ice making sequence will start automatically.

Important

After the toggle switch is moved to the ICE position, opening the curtain switch will interrupt the cleaning sequence. The sequence will resume from the point of interruption when the curtain switch closes.

3-6 Part No. 80-1100-3

Section 3 Maintenance

SANITIZING PROCEDURE

Use sanitizer to remove algae or slime. Do not use it to remove lime scale or other mineral deposits.

Step 1 Set the toggle switch to the OFF position after ice falls from the evaporator at the end of a Harvest cycle. Or, set the switch to the OFF position and allow the ice to melt off the evaporator.

⚠ Caution

Never use anything to force ice from the evaporator. Damage may result.

A Warning

Disconnect electric power to the ice machine (and dispenser if applicable) at the electric switch box before proceeding.

Step 2 Refer to Removal of Parts For Cleaning/ Sanitizing and remove ice machine parts.

Step 3 Mix a solution of water and sanitizer.

Solution Type	Water	Mixed With
Sanitizer	4 gal. (15 l)	3 oz (90 ml) sanitizer

Step 4 Use the sanitizing solution and a sponge or cloth to sanitize (wipe) all parts and interior surfaces of the ice machine. Sanitize the following areas:

- A. Side walls
- B. Base (area above water trough)
- C. Evaporator plastic parts
- D. Bin or dispenser

Step 5 Rinse all sanitized areas with clear water.

Step 6 Install the removed parts, restore power and place toggle switch in the ice position.

Maintenance Section 3

AUTOMATIC CLEANING SYSTEM (AuCS®)

This accessory monitors ice making cycles and initiates cleaning (or sanitizing) procedures automatically. The AuCS® Accessory can be set to automatically clean or sanitize the ice machine every 2, 4, or 12 weeks.

⚠ Caution

Refer to the AuCS® Accessory Installation - Use and Care Manual for complete details on the installation, operation, maintenance and cautionary statements of this accessory.

Automatic Operation

The following occurs when the toggle switch is in the ICE position:

- The ice machine control board counts the number of ice harvest cycles.
- The AuCS® accessory interrupts the ice making mode and starts the cleaning (or sanitizing) mode when the harvest count equals the "Frequency of Cleaning" setting of the AuCS®.
- When the automatic cleaning (or sanitizing) cycle is complete (approximately 25 minutes), ice making resumes automatically, and the "Harvest Count" is reset to zero.

Important

Opening the curtain switch will interrupt the cleaning or sanitizing sequence. The sequence will resume from the point of interruption when the curtain recloses.

Manual Start Operation

Step 1 Set the toggle switch to the OFF position after ice falls from the evaporator at the end of a Harvest cycle. Or, set the switch to the OFF position and allow the ice to melt off the evaporator.

♠ Caution

Never use anything to force ice from the evaporator. Damage may result.

Step 2 To start the automatic cleaning system, move the toggle switch to the CLEAN position. The water will flow through the water dump valve and down the drain. The Clean light will turn on to indicate the ice machine is in the Self Cleaning mode. The AuCS® then automatically adds cleaner or sanitizer to the ice machine.

Step 3 The ice machine will automatically time out a ten minute cleaning or sanitizing cycle, followed by six rinse cycles, (de-energize the Clean light) and stop. This entire cycle lasts approximately 25 minutes.

Step 4 After the cleaning or sanitizing cycle stops, move the toggle switch to ICE position.

Step 5

- A. The ice machine may be set to start and finish a cleaning or sanitizing cycle, then automatically start ice making again.
- B. You must wait about one minute into the cleaning cycle (until water starts to flow over the evaporator), then move the toggle switch from CLEAN to ICE position.
- C. When the cleaning or sanitizing cycle is completed, the clean light will turn off and an ice making sequence will start automatically.

3-8 Part No. 80-1100-3

Section 3 Maintenance

REMOVAL OF PARTS FOR CLEANING/SANITIZING

 Turn off the water supply to the ice machine at the water service valve.

A Warning

Disconnect electric power to the ice machine at the electric switch box before proceeding.

Remove the water curtain and the components you want to clean or sanitize. See the following pages for removal procedures for these parts.

A Warning

Wear rubber gloves and safety goggles (and/or face shield) when handling Ice Machine Cleaner or Sanitizer.

Soak the removed part(s) in a properly mixed solution.

Solution Type	Water	Mixed With
Cleaner	1 gal. (4 l)	16 oz (500 ml) cleaner
Sanitizer	4 gal. (15 l)	1 oz (30 ml) sanitizer

4. Use a soft-bristle brush or sponge (NOT a wire brush) to carefully clean the parts.

∕ Caution

Do not mix Cleaner and Sanitizer solutions together. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling.

∴ Caution

Do not immerse the water pump motor in the cleaning or sanitizing solution.

- 5. Use the solution and a brush to clean the top, sides, and bottom evaporator extrusions; the inside of the ice machine panels; and the entire inside of the bin.
- 6. Thoroughly rinse all of the parts and surfaces with clean water.
- 7. Install the removed parts.

NOTE: Incomplete rinsing of the ice thickness probe or water level probe may leave a residue. This could cause the ice machine to malfunction. For best results, brush or wipe the probes off while rinsing it. Thoroughly dry the probes before installing them.

8. Turn on the water and electrical supply.

Maintenance Section 3

Water Dump Valve

The water dump valve normally does not require removal for cleaning. To determine if removal is necessary:

- 1. Locate the water dump valve.
- 2. Set the toggle switch to ICE.
- 3. While the ice machine is in the freeze mode, check the dump valve's clear plastic outlet drain hose for leakage.
 - A. If the dump valve is leaking, remove, disassemble and clean it.
 - B. If the dump valve is not leaking, do not remove it. Instead, follow the "Cleaning Procedure" on **Page 3-5**.

Follow the procedure below to remove the dump valve.

A Warning

Disconnect the electric power to the ice machine at the electric service switch box and turn off the water supply before proceeding.

- 1. If so equipped, remove the water dump valve shield from its mounting bracket.
- Lift and slide the coil retainer cap from the top of the coil.
- Note the position of the coil assembly on the valve for assembly later. Leaving the wires attached, lift the coil assembly off the valve body and the enclosing tube.
- 4. Press down on the plastic nut on the enclosing tube and rotate it 1/4 turn. Remove the enclosing tube, plunger, and plastic gasket from the valve body.

NOTE: At this point, the water dump valve can easily be cleaned. If complete removal is desired, continue with step 5.




Figure 3-7. Dump Valve Removal

Important

The plunger and the inside of the enclosing tube must be completely dry before assembly.

NOTE: During cleaning, do not stretch, damage or remove the spring from the plunger. If it is removed, slide the spring's flared end into the plunger's slotted top opening until the spring contacts the plunger spring stop.

- 5. Remove the valve body.
- 6. Remove the tubing from the dump valve by twisting the clamps off.
- 7. Remove the two screws securing the dump valve and the mounting bracket.




Figure 3-8. Dump Valve Disassembly

3-10 Part No. 80-1100-3

Section 3 Maintenance

Water Pump

A Warning

Disconnect the electric power to the ice machine at the electric service switch box and turn off the water supply.

1. Disconnect the water pump power cord.




Figure 3-9. Water Pump Removal

- 2. Disconnect the hose from the pump outlet.
- 3. Loosen the screws securing the pump mounting bracket to the bulkhead.
- 4. Lift the pump and bracket assembly off the screws.

Ice Thickness Probe

 Compress the side of the ice thickness probe near the top hinge pin and remove it from the bracket.




Figure 3-10. Ice Thickness Probe Removal

NOTE: At this point, the ice thickness probe can easily be cleaned. If complete removal is desired, continue with step 2 below.

A Warning

Disconnect the electric power to the ice machine at the electric service switch box.

2. Disconnect the wire lead from the control board inside the electrical control box.

Ice Thickness Probe Cleaning

- 1. Mix a solution of Manitowoc ice machine cleaner and water (2 ounces of cleaner to 16 ounces of water) in a container.
- Soak ice thickness probe in container of cleaner/ water solution while disassembling and cleaning water circuit components (soak ice thickness probe for 10 minutes or longer).
- 3. Clean all ice thickness probe surfaces including all plastic parts (do not use abrasives). Verify the ice thickness probe cavity is clean. Thoroughly rinse ice thickness probe (including cavity) with clean water, then dry completely. Incomplete rinsing and drying of the ice thickness probe can cause premature harvest.
- 4. Reinstall ice thickness probe, then sanitize all ice machine and bin/dispenser interior surfaces.

Maintenance Section 3

Water Level Probe

1. Loosen the screw that holds the water level probe in place. The probe can easily be cleaned at this point without proceeding to step 2.

A Warning

Disconnect the electrical power to the ice machine at the electrical disconnect before proceeding.

If complete removal is required, disconnect the wire lead from the control board inside the electrical control box.




Figure 3-11. Water Level Probe Removal

Water Inlet Valve

The water inlet valve normally does not require removal for cleaning. Follow the instructions below to determine if removal is necessary.

- Set the ICE/OFF/CLEAN switch to OFF. Locate the water inlet valve (in the compressor area of the ice machine). It pours water into the water trough.
- When the ice machine is off, the water inlet valve must completely stop water flow into the machine. Watch for water flow. If water flows, remove, disassemble and clean the valve.
- 3. When the ice machine is on, the water inlet valve must allow the proper water flow through it. Set the toggle switch to ON. Watch for water flow into the ice machine. If the water flow is slow or only trickles into the ice machine, remove, disassemble, and clean the valve.

Follow the procedure below to remove the water inlet valve.

Warning

Disconnect the electric power to the ice machine at the electric service switch box and turn off the water supply before proceeding.

- 1. Remove the valve shield if necessary.
- Remove the filter access screws that hold the valve in place.

NOTE: The water inlet valve can be disassembled and cleaned without disconnecting the incoming water supply line to the ice machine.

- 3. Remove, clean, and install the filter screen.
- 4. If necessary, remove the enclosure tube access screws to clean interior components.




Figure 3-12. Water Inlet Valve Removal




Figure 3-13. Exploded View of Water Inlet Valve

3-12 Part No. 80-1100-3

Section 3 Maintenance

Water Distribution Tube

 Disconnect the water hose from the distribution tube.




Figure 3-14. Water Distribution Tube Removal

- Loosen the two thumbscrews which secure the distribution tube.
- 2. Lift the right side of the distribution tube up off the locating pin, then slide it back and to the right.

Do not force this removal. Be sure the locating pin is clear of the hole before sliding the distribution tube out.

- 3. Disassemble for cleaning.
 - A. Twist both of the inner tube ends until the tabs line up with the keyways.
 - B. Pull the inner tube ends outward.




Figure 3-15. Water Distribution Tube Disassembly

Water Curtain

1. Gently flex the curtain in the center and remove it from the right side.




Figure 3-16. Water Curtain Removal

2. Slide the left pin out.

Maintenance Section 3

Water Treatment/Filtration

GENERAL

Local water conditions may require the installation of a water treatment system to inhibit scale formation, filter out sediment, and remove chlorine taste and odor. Consult your local distributor for information on Manitowoc's full line of NSF®-certified Tri-Liminator® filtration systems.

FILTER REPLACEMENT PROCEDURE

Tri-Liminator® systems include a pre-filter and a primary filter. For maximum filtration efficiency, replace the primary filter cartridge every six months. If the filter gauge reading drops below 20 psig prior to six months usage, replace the pre-filter first.

1. Turn off the water supply at the inlet shutoff valve.




Figure 3-17. Typical Tri-Liminator® Water Filtration System

2. Depress the pressure release button to relieve the pressure.

- 3. Unscrew the housing from the cap.
- 4. Remove the used filter cartridge from the housing and discard it.
- 5. Remove the O-ring from the housing groove. Wipe the housing groove and the O-ring clean.
- 6. Lubricate the O-ring with petroleum jelly.
- 7. Press the O-ring into the housing groove.
- 8. Insert a new filter cartridge into the housing. Make sure it slips down over the housing standpipe.
- 9. Screw the housing on to the cap and carefully hand-tighten it.

♠ Caution

Hand-tighten only. Do not overtighten. Do not use a spanner wrench.

- 10. Repeat steps 3-9 for each filter housing.
- 11. Turn on the water supply to allow the housing and filter to slowly fill with water.
- 12. Depress the pressure release button to release trapped air from the housing.
- 13. Check for leaks.

3-14 Part No. 80-1100-3

Section 3 Maintenance

Removal from Service/Winterization

GENERAL

Special precautions must be taken if the ice machine is to be removed from service for an extended period of time or exposed to ambient temperatures of 32°F (0°C) or below.

If water is allowed to remain in the ice machine in freezing temperatures, severe damage to some components could result. Damage of this nature is not covered by the warranty.

Follow the applicable procedure below.

SELF-CONTAINED AIR-COOLED ICE MACHINES

- Disconnect the electric power at the circuit breaker or the electric service switch.
- 2. Turn off the water supply.
- 3. Remove the water from the water trough.
- 4. Disconnect and drain the incoming ice-making water line at the rear of the ice machine.
- Blow compressed air in both the incoming water and the drain openings in the rear of the ice machine until no more water comes out of the inlet water lines or the drain.
- 6. Make sure water is not trapped in any of the water lines, drain lines, distribution tubes, etc.

WATER-COOLED ICE MACHINES

- 1. Perform steps 1-6 under "Self-Contained Air-Cooled Ice Machines."
- 2. Disconnect the incoming water and drain lines from the water-cooled condenser.
- Insert a large screwdriver between the bottom spring coils of the water regulating valve. Pry upward to open the valve.




Figure 3-18. Pry Open the Water Regulating Valve

4. Hold the valve open and blow compressed air through the condenser until no water remains.

REMOTE ICE MACHINES

- 1. Move the ICE/OFF/CLEAN switch to OFF.
- 2. "Frontseat" (shut off) the receiver service valves.

 Hang a tag on the switch as a reminder to open the valves before restarting.
- 3. Perform steps 1-6 under "Self-Contained Air-Cooled Ice Machines."

AUCS® Accessory

Refer to the AuCS® Accessory manual for winterization of the AuCS® Accessory.

Maintenance Section 3

THIS PAGE INTENTIONALLY LEFT BLANK

3-16 Part No. 80-1100-3

Section 4 Ice Machine Sequence of Operation

Self-Contained Air- and Water-Cooled Q200/Q280/Q320/Q370/Q420/Q450/Q600/Q800/Q1000/Q1300/Q1600/Q1800

INITIAL START-UP OR START-UP AFTER AUTOMATIC SHUT-OFF

1. Water Purge

Before the compressor starts, the water pump and water dump solenoid are energized for 45 seconds, to completely purge the ice machine of old water. This feature ensures that the ice making cycle starts with fresh water.

The harvest valve(s) is also energized during water purge, although it stays on for an additional 5 seconds (50 seconds total on time) during the initial refrigeration system start-up.

2. Refrigeration System Start-Up

The compressor starts after the 45 second water purge, and it remains on throughout the entire Freeze and Harvest Sequences. The water fill valve is energized at the same time as the compressor. It remains on until the water level sensor closes for 3 continuous seconds, or until a six-minute time period has expired. (See "Water Inlet Valve Safety Shutoff," **Page 6-50**.) The harvest valve(s) remains on for 5 seconds during initial compressor start-up and then shuts off.

At the same time the compressor starts, the condenser fan motor (air-cooled models) is supplied with power throughout the entire Freeze and Harvest Sequences. The fan motor is wired through a fan cycle pressure control, therefore it may cycle on and off. (The compressor and condenser fan motor are wired through the contactor. As a result, anytime the contactor coil is energized, the compressor and fan motor are supplied with power.)

FREEZE SEQUENCE

3. Prechill

The compressor is on for 30 seconds prior to water flow, to prechill the evaporator.

4. Freeze

The water pump restarts after the 30 second prechill. An even flow of water is directed across the evaporator and into each cube cell, where it freezes. The water fill valve will cycle on and then off one more time to refill the water trough.

When sufficient ice has formed, the water flow (not the ice) contacts the ice thickness probe. After approximately 7 seconds of continual water contact, the harvest sequence is initiated. The ice machine cannot initiate a harvest sequence until a 6 minute freeze lock has been surpassed.




Figure 4-1. Freeze Sequence (Typical Q450 Shown)

Continued on next page ...

HARVEST SEQUENCE

5. Water Purge

The water pump continues to run, and the water dump valve energizes for 45 seconds to purge the water in the sump trough. The water fill valve energizes (turns on) and de-energizes (turns off) strictly by time. The water fill valve energizes for the last 15 seconds of the 45-second water purge. The water purge <u>must be at the factory setting</u> of 45 seconds for the fill valve to energize during the last 15 seconds of the Water Purge. If set at less than 45 seconds the water fill valve does not energize during the water purge.

After the 45 second water purge, the water fill valve, water pump and dump valve de-energize. (Refer to "Water Purge Adjustment" on **Page 3-3** for details.) The harvest valve also opens at the beginning of the water purge to divert hot refrigerant gas into the evaporator.

6. Harvest

The harvest valve(s) remains open and the refrigerant gas warms the evaporator causing the cubes to slide, as a sheet, off the evaporator and into the storage bin. The sliding sheet of cubes swings the water curtain out, opening the bin switch. The momentary opening and reclosing of the bin switch terminates the harvest sequence and returns the ice machine to the freeze sequence (Step 3 - 4.)




Figure 4-2. Harvest Sequence (Typical Q450 Shown)

AUTOMATIC SHUT-OFF

7. Automatic Shut-Off

When the storage bin is full at the end of a harvest sequence, the sheet of cubes fails to clear the water curtain and will hold it open. After the water curtain is held open for 7 seconds, the ice machine shuts off. The ice machine remains off for 3 minutes before it can automatically restart.

The ice machine remains off until enough ice has been removed from the storage bin to allow the ice to fall clear of the water curtain. As the water curtain swings back to the operating position, the bin switch re-closes and the ice machine restarts (steps 1 - 2), provided the 3 minute delay period is complete.




Figure 4-3. Automatic Shut-Off (Typical Q450 Shown)

4-2 Part No. 80-1100-3

Remote Q450/Q600/Q800/Q1000/Q1300/Q1600/Q1800

INITIAL START-UP OR START-UP AFTER AUTOMATIC SHUT-OFF

1. Water Purge

Before the compressor starts, the water pump and water dump solenoid are energized for 45 seconds, to completely purge the ice machine of old water. This feature ensures that the ice making cycle starts with fresh water.

The harvest valve and harvest pressure regulating (HPR) solenoid valves also energize during water purge, although they stay on for an additional 5 seconds (50 seconds total on time) during the initial refrigeration system start-up.

2. Refrigeration System Start-Up

The compressor and liquid line solenoid valve energize after the 45 second water purge and remain on throughout the entire Freeze and Harvest Sequences. The water fill valve is energized at the same time as the compressor. It remains on until the water level sensor closes for 3 continuous seconds, or until a six-minute time period has expired. (See "Water Inlet Valve Safety Shutoff," **Page 6-50**.). The harvest valve and HPR solenoid valves remain on for 5 seconds during initial compressor start-up and then shut off.

The remote condenser fan motor starts at the same time the compressor starts and remains on throughout the entire Freeze and Harvest Sequences. (The compressor and condenser fan motor are wired through the contactor, therefore, anytime the contactor coil is energized, the compressor and fan motor are on.)

FREEZE SEQUENCE

3. Prechill

The compressor is on for 30 seconds prior to water flow, to prechill the evaporator.

4. Freeze

The water pump restarts after the 30 second prechill. An even flow of water is directed across the evaporator and into each cube cell, where it freezes. The water fill valve will cycle on and then off one more time to refill the water trough. (See **Page 4-1**.)

When sufficient ice has formed, the water flow (not the ice) contacts the ice thickness probe. After approximately 7 seconds of continual water contact, the harvest sequence is initiated. The ice machine cannot initiate a harvest sequence until a 6 minute freeze lock has been surpassed.




Figure 4-4. Freeze Sequence (Typical Q450 Shown)

Continued on next page ...

HARVEST SEQUENCE

5. Water Purge

The water pump continues to run, and the water dump valve energizes for 45 seconds to purge the water in the sump trough. The water fill valve energizes (turns on) and de-energizes (turns off) strictly by time. The water fill valve energizes for the last 15 seconds of the 45-second water purge. The water purge <u>must be at the factory setting</u> of 45 seconds for the fill valve to energize during the last 15 seconds of the Water Purge. If set at less than 45 seconds the water fill valve does not energize during the water purge.

After the 45 second water purge, the water fill valve, water pump and dump valve de-energize. (Refer to "Water Purge Adjustment" on **Page 3-3** for details.) The harvest valve(s) and HPR solenoid valve also open at the beginning of the water purge.

6. Harvest

The HPR valve and the harvest valve(s) remain open and the refrigerant gas warms the evaporator causing the cubes to slide, as a sheet, off the evaporator and into the storage bin. The sliding sheet of cubes swings the water curtain out, opening the bin switch. The momentary opening and re-closing of the bin switch terminates the harvest sequence and returns the ice machine to the freeze sequence (Step 3 - 4.)




Figure 4-5. Harvest Sequence (Typical Q450 Shown)

AUTOMATIC SHUT-OFF

7. Automatic Shut-Off

When the storage bin is full at the end of a harvest sequence, the sheet of cubes fails to clear the water curtain and will hold it open. After the water curtain is held open for 7 seconds, the ice machine shuts off. The ice machine remains off for 3 minutes before it can automatically restart.

The ice machine remains off until enough ice has been removed from the storage bin to allow the ice to drop clear of the water curtain. As the water curtain swings back to the operating position, the bin switch re-closes and the ice machine restarts (steps 1 - 2) provided the 3 minute delay period is complete.




Figure 4-6. Automatic Shut-Off (Typical Q450 Shown)

4-4 Part No. 80-1100-3

Section 5 Water System Ice Making Sequence of Operation

NOTE: The sequence of operation is the same for selfcontained and remote models.

INITIAL START-UP OR START-UP AFTER AUTOMATIC SHUT-OFF

 Before the ice machine starts, the water pump and water dump solenoid are energized for 45 seconds to purge old water from the water trough. This ensures that the ice-making cycle starts with fresh water. The water fill valve energizes after the 45second water purge, and remains on until the water level probe is satisfied.

FREEZE CYCLE

To pre-chill the evaporator, there is no water flow over the evaporator for the first 30 seconds of the freeze cycle. 3. The water pump starts after the 30-second pre-chill. An even flow of water is directed across the evaporator and into each cube cell.

During the first 45 seconds of the Freeze Cycle, the water fill valve cycles on and off as many times as needed to refill the water trough.

After the 45 seconds, the water fill valve cycles on and off one more time to refill the water trough. The water fill valve then remains off for the duration of the Freeze Cycle.

WATER INLET VALVE SAFETY SHUT-OFF

This feature limits the water inlet valve to a six-minute on time. Regardless of the water level probe input, the control board automatically shuts off the water inlet valve if it remains on for 6 continuous minutes.




Figure 5-1. Water Flow Over the Evaporator

HARVEST CYCLE

- 4. The water pump and water dump solenoid are energized for 45 seconds to purge the water from the water trough. The water fill valve energizes for the last 15 seconds of the 45-second purge cycle, to flush sediment from the bottom of the water trough.
- 5. After the 45-second purge, the water pump and water dump valve de-energize.

AUTOMATIC SHUT-OFF

There is no water flow during an automatic shut-off.




Figure 5-2. Water Flow Down the Drain

5-2 Part No. 80-1100-3

Section 6 Electrical System

Energized Parts Charts

SELF-CONTAINED AIR- AND WATER-COOLED MODELS

		Contro	l Board Rel	ays		Con	tactor	
Ice Making	1	2	3	4	5	5A	5B	Length
Sequence Of Operation	Water Pump	Water Fill Valve	Harvest Valve(s)	Water Dump Valve	Contactor Coil	Com- pressor	Condenser Fan Motor	Of Time
START-UP ¹ 1. Water Purge	On	Off	On	On	Off	Off	Off	45 Seconds
2. Refrigeration System Start-Up	Off	On	On	Off	On	On	May Cycle On/Off	5 Seconds
FREEZE SEQUENCE 3. Pre-Chill	Off	May cycle On/ Off during first 45 sec.	Off	Off	On	On	May Cycle On/Off	30 Seconds
4. Freeze	On	Cycles On, then Off 1 more time Locked Out After Six Minutes	Off	Off	On	On	May Cycle On/Off	Until 7 sec. water contact with ice thickness probe
HARVEST SEQUENCE 5. Water Purge	On	30 sec. Off, 15 sec. On	On	On	On	On	May Cycle On/Off	Factory-set at 45 Seconds
6. Harvest	Off	Off	On	Off	On	On	May Cycle On/Off	Bin switch activation
7. AUTOMATIC SHUT-OFF	Off	Off	Off	Off	Off	Off	Off	Until bin switch re-closes

^{1.} Initial Start-Up or Start-Up After Automatic Shut-Off

Condenser Fan Motor

The fan motor is wired through a fan cycle pressure control, therefore, it may cycle on and off.

Harvest Water Purge

The circuit board has an adjustable water purge in the harvest cycle. This permits a 15, 30 or 45 second purge cycle.

Auto Shut-Off

The ice machine remains off for 3 minutes before it can automatically restart. The ice machine restarts (steps 1-2) immediately after the delay period, if the bin switch recloses prior to 3 minutes.

Safety Timers

The control board has the following non-adjustable safety timers:

FREEZE SEQUENCE

- The ice machine is locked into the freeze cycle for the first 6 minutes, not allowing the ice thickness probe to initiate a harvest sequence.
- The maximum freeze time is 60 minutes, at which time the control board automatically initiates a harvest sequence (steps 5-6).

HARVEST SEQUENCE

The maximum harvest time is 3-1/2 minutes, at which time the control board automatically terminates the harvest sequence. If the bin switch is open, the ice machine will go to automatic shut-off (step 7). If the bin switch is closed, the ice machine will go to the freeze sequence (steps 3-4).

REMOTE MODELS

		Cont	rol Board Rel	ays		Cont	actor	
	1	2	3	4	5	5A	5B	
Ice Making Sequence Of Operation	Water	er Water Fill	a. Harvest Valve(s)	Water	a. Contactor Coil	Com-	Condenser	Length Of Time
C por a morn	Pump	Valve	b. HPR Solenoid	Dump Valve	b. Liquid Line Solenoid	pressor	Fan Motor	
START-UP ¹ 1. Water Purge	On	Off	On	On	Off	Off	Off	45 Seconds
2. Refrigeration System Start-Up	Off	On	On	Off	On	On	On	5 Seconds
FREEZE SEQUENCE 3. Pre-Chill	Off	May cycle On/Off during first 45 sec.	Off	Off	On	On	On	30 Seconds
4. Freeze	On	Cycles On, then Off 1 more time Locked Out After Six Minutes	Off	Off	On	On	On	Until 7 sec. water contact with ice thickness probe
HARVEST SEQUENCE 5. Water Purge	On	30 sec. Off, 15 sec. On	On	On	On	On	On	Factory-set at 45 Seconds
6. Harvest	Off	Off	On	Off	On	On	On	Bin switch activation
7. AUTOMATIC SHUT-OFF	Off	Off	Off	Off	Off	Off	Off	Until bin switch re- closes

^{1.} Initial Start-Up or Start-Up After Automatic Shut-Off

Auto Shut-Off

The ice machine remains off for 3 minutes before it can automatically restart. The ice machine restarts (steps 1-2) immediately after the delay period, if the bin switch recloses prior to 3 minutes.

Harvest Water Purge

The circuit board has an adjustable water purge in the harvest cycle. This permits a 15, 30 or 45 second purge cycle.

Safety Timers

The control board has the following non-adjustable safety timers:

FREEZE SEQUENCE

- The ice machine is locked into the freeze cycle for the first 6 minutes, not allowing the ice thickness probe to initiate a harvest sequence.
- The maximum freeze time is 60 minutes, at which time the control board automatically initiates a harvest sequence (steps 5-6).

HARVEST SEQUENCE

 The maximum harvest time is 3-1/2 minutes, at which time the control board automatically terminates the harvest sequence. If the bin switch is open, the ice machine will go to automatic shut-off (step 7). If the bin switch is closed, the ice machine will go to the freeze sequence (steps 3-4).

6-2 Part No. 80-1100-3

Section 6 Electrical System

Wiring Diagram Sequence of Operation

SELF-CONTAINED MODELS

Initial Start-Up or Start-Up After Automatic Shut-Off

1. WATER PURGE

Before the compressor starts, the water pump and water dump solenoid are energized for 45 seconds to purge old water from the ice machine. This ensures that the ice-making cycle starts with fresh water.

The harvest valve(s) is also energized during the water purge. In the case of an initial refrigeration start-up, it stays on for an additional 5 seconds (50 seconds total).




Figure 6-1. Self-Contained — Water Purge

Table 6-1. Self-Contained Models

	1. Water Purge (45 Seconds)			
Toggl	e Switch	ICE		
Bin S	witch	Closed		
Contr	ol Board Relays	•		
#1	Water Pump	Closed / ON		
#2	Water Fill Valve	Open / OFF		
#3	Harvest Solenoid	Closed / ON		
#4	Water Dump Valve	Closed / ON		
#5	Contactor Coil	Open / OFF		
	Compressor	OFF		
	Condenser Fan Motor	OFF		
Safety	Controls (Which could stop ice machine operation)	•		
	High Pressure Cut-Out	Closed		
	Main Fuse (On Control Board)	Closed		

2. REFRIGERATION SYSTEM START-UP

The compressor starts after the 45second water purge, and it remains on throughout the Freeze and Harvest cycles.

The water fill valve is energized at the same time as the compressor. It remains on until the water level sensor closes for 3 continuous seconds.

The harvest valve(s) remains on for the first 5 seconds of the initial compressor start-up.

At the same time the compressor starts, the condenser fan motor (aircooled models) is supplied with power. It continues to be supplied with power throughout the Freeze and Harvest cycles.

The fan motor is wired through a fan cycle pressure control, and may cycle on and off. (The compressor and the condenser fan motor are wired through the contactor. Any time the contactor coil is energized, these components are supplied with power.)




Figure 6-2. Self-Contained — Refrigeration System Start-Up

Table 6-2. Self-Contained Models

	2. Refrigeration System Start Up (5 Seconds)		
Toggl	e Switch	ICE	
Bin S	witch	Closed	
Contr	ol Board Relays	<u> </u>	
#1	Water Pump	Open / OFF	
#2	Water Fill Valve	Closed / ON	
#3	Harvest Solenoid	Closed / ON	
#4	Water Dump Valve	Open / OFF	
#5	Contactor Coil	Closed / ON	
	Compressor	ON	
	Condenser Fan Motor	ON	
Safety	Controls (Which could stop ice machine operation)	•	
	High Pressure Cut-Out	Closed	
	Main Fuse (On Control Board)	Closed	

6-4 Part No. 80-1100-3

Section 6 Electrical System

Freeze Sequence

3. PRE-CHILL

To pre-chill the evaporator, the compressor runs for 30 seconds prior to water flow.

The water fill valve remains on until the water level sensor closes for three continuous seconds.




Figure 6-3. Self-Contained — Pre-Chill

Table 6-3. Self-Contained Models

	3. Pre-Chill (30 Seconds)			
Toggl	e Switch	ICE		
Bin S	witch	Closed		
Contro	ol Board Relays	<u> </u>		
#1	Water Pump	Open / OFF		
#2	Water Fill Valve	Closed / ON		
#3	Harvest Solenoid	Open / OFF		
#4	Water Dump Valve	Open / OFF		
#5	Contactor Coil	Closed / ON		
	Compressor	ON		
	Condenser Fan Motor	ON		
Safety	Controls (Which could stop ice machine operation)	<u> </u>		
	High Pressure Cut-Out	Closed		
	Main Fuse (On Control Board)	Closed		

4. FREEZE

The water pump starts after the 30second pre-chill. An even flow of water is directed across the evaporator and into each cube cell, where it freezes.

After six minutes the water inlet valve is locked out and can not add additional water.

When sufficient ice has formed, the water flow (not the ice) contacts the ice thickness probes. After approximately 7 seconds of continual contact, a harvest cycle is initiated.

NOTE: The ice machine cannot initiate a harvest cycle until a 6-minute freeze lock has expired.




Figure 6-4.

Self-Contained — Freeze

Table 6-4. Self-Contained Models

	4. Freeze (Until 7 Seconds of Water Con	tact with Ice Thickness Probe)
Toggle Switch ICE		
Bin Sv	vitch	Closed
Contro	ol Board Relays	
#1	Water Pump	Closed / ON
#2	Water Fill Valve	Cycles ON then OFF
#3	Harvest Solenoid	Open / OFF
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Closed / ON
	Compressor	ON
	Condenser Fan Motor	ON
Safety	Controls (Which could stop ice machine operation)	•
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

6-6 Part No. 80-1100-3

Section 6 Electrical System

Harvest Sequence

5. WATER PURGE

The water pump continues to run, and the water dump valve energizes for 45 seconds to purge the water in the sump trough. The water fill valve energizes (turns on) and deenergizes (turns off) strictly by time. The water fill valve energizes for the last 15 seconds of the 45-second water purge. The water purge must be at the factory setting of 45 seconds for the fill valve to energize during the last 15 seconds of the Water Purge. If set at less than 45 seconds, the water fill valve does not energize during the water purge.

After the 45 second water purge, the water fill valve, water pump and dump valve de-energize. (Refer to "Water Purge Adjustment" on **Page 3-3** for details.) The harvest valve also opens at the beginning of the water purge to divert hot refrigerant gas into the evaporator.




Figure 6-5.

Self-Contained — Water Purge

Table 6-5. Self-Contained Models

	5. Water Purge (45 S	econds)
Toggl	e Switch	ICE
Bin S	witch	Closed
Contr	ol Board Relays	<u> </u>
#1	Water Pump	Closed / ON
#2	Water Fill Valve	Cycles OFF then ON
#3	Harvest Solenoid	Closed / ON
#4	Water Dump Valve	Closed / ON
#5	Contactor Coil	Closed / ON
	Compressor	ON
	Condenser Fan Motor	ON
Safety	Controls (Which could stop ice machine operation)	•
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

6. HARVEST

The harvest valve(s) remains open, allowing refrigerant gas to warm the evaporator. This causes the cubes to slide, as a sheet, off the evaporator and into the storage bin.

The sliding sheet of cubes swings the water curtain out, opening the bin switch. This momentary opening and closing of the bin switch terminates the Harvest Cycle and returns the ice machine to the Freeze Cycle (steps 3-4).




Figure 6-6. Self-Contained — Harvest

Table 6-6. Self-Contained Models

	6. Harvest (Until Bin Switch Activation)			
Toggle	e Switch	ICE		
Bin Sv	vitch	Closed		
Contro	ol Board Relays	·		
#1	Water Pump	Open / OFF		
#2	Water Fill Valve	Open / OFF		
#3	Harvest Solenoid	Closed / ON		
#4	Water Dump Valve	Open / OFF		
#5	Contactor Coil	Closed / ON		
	Compressor	ON		
	Condenser Fan Motor	ON		
Safety	Controls (Which could stop ice machine operation)	<u> </u>		
	High Pressure Cut-Out	Closed		
	Main Fuse (On Control Board)	Closed		

6-8 Part No. 80-1100-3

Section 6 Electrical System

Automatic Shut-Off

7. AUTOMATIC SHUT-OFF

If the storage bin is full at the end of a harvest cycle, the sheet of cubes fails to clear the water curtain and holds it open. After the water curtain is held open for 7 seconds, the ice machine shuts off.

The ice machine remains off until enough ice is removed from the storage bin to allow the sheet of cubes to drop clear of the water curtain. As the water curtain swings back to the operating position, the bin switch closes and the ice machine restarts (steps 1-2).

NOTE: The ice machine must remain off for 3 minutes before it can automatically restart.




Figure 6-7. Self-Contained — Automatic Shut-Off

Table 6-7. Self-Contained Models

	7. Automatic Shut-Off (Until I	Bin Switch Closes)
Toggl	e Switch	ICE
Bin S	witch	Open
Contr	ol Board Relays	
#1	Water Pump	Open / OFF
#2	Water Fill Valve	Open / OFF
#3	Harvest Solenoid	Open / OFF
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Open / OFF
	Compressor	OFF
	Condenser Fan Motor	OFF
Safety	Controls (Which could stop ice machine operation)	
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

REMOTE MODELS

Initial Start-Up Or Start-Up After Automatic Shut-Off

1. WATER PURGE

Before the compressor starts, the water pump and water dump solenoid are energized for 45 seconds to purge old water from the ice machine. This ensures that the ice-making cycle starts with fresh water.

NOTE: The harvest valve and harvest pressure regulating (HPR) solenoid valve are also energized during the water purge. In the case of an initial refrigeration start-up, they stay on for an additional 5 seconds (50 seconds total).




Figure 6-8. Remote — Water Purge

Table 6-8. Remote Models

	1. Water Purge (45 Seconds)		
Toggle Switch			
Bin Switch		Closed	
Contro	ol Board Relays	•	
#1	Water Pump	Closed / ON	
#2	Water Fill Valve	Open / OFF	
#3	Harvest Solenoid	Closed / ON	
	Harvest Pressure Regulating (HPR) Solenoid	Closed / ON	
#4	Water Dump Valve	Closed / ON	
#5	Contactor Coil	Open / OFF	
	Liquid Line Solenoid	De-energized	
	Compressor	OFF	
	Condenser Fan Motor	OFF	
Safety	Controls (Which could stop ice machine operation)	·	
	High Pressure Cut-Out	Closed	
	Main Fuse (On Control Board)	Closed	
		,	

6-10 Part No. 80-1100-3

Section 6 Electrical System

2. REFRIGERATION SYSTEM START-UP

The compressor, remote condenser fan motor and liquid line solenoid valve energize after the 45-second water purge, and remain on throughout the Freeze and Harvest cycles.

The water fill valve is energized at the same time as the compressor. It remains on until the water level sensor closes for 3 continuous seconds.

The harvest valve and harvest pressure regulating (HPR) solenoid valve remain on for the first 5 seconds of the initial compressor start-up.

NOTE: (The compressor and the condenser fan motor are wired through the contactor. Any time the contactor coil is energized, these components are supplied with power.)




Figure 6-9. Remote — Refrigeration System Start-Up

Table 6-9. Remote Models

2. Refrigeration System Start-Up (5 Seconds)		
Toggl	Toggle Switch ICE	
Bin Switch		Closed
Contr	ol Board Relays	·
#1	Water Pump	Open / OFF
#2	Water Fill Valve	Closed / ON
#3	Harvest Solenoid	Closed / ON
	Harvest Pressure Regulating (HPR) Solenoid	Closed / ON
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Closed / ON
	Liquid Line Solenoid	Energized
	Compressor	ON
	Condenser Fan Motor	ON
Safety	Controls (Which could stop ice machine operation)	·
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

Freeze Sequence

3. PRE-CHILL

To pre-chill the evaporator, the compressor runs for 30 seconds prior to water flow.

NOTE: The water fill valve remains on until the water level sensor closes for three continuous seconds.




Figure 6-10. Remote — Pre-Chill

Table 6-10. Remote Models

	3. Pre-Chill (30 Seconds)		
Toggle Switch ICE Bin Switch Close		ICE	
		Closed	
Contr	ol Board Relays	<u> </u>	
#1	Water Pump	Open / OFF	
#2	Water Fill Valve	Closed / ON	
#3	Harvest Solenoid	Open / OFF	
	Harvest Pressure Regulating (HPR) Solenoid	Open / OFF	
#4	Water Dump Valve	Open / OFF	
#5	Contactor Coil	Closed / ON	
	Liquid Line Solenoid	Energized	
	Compressor	ON	
	Condenser Fan Motor	ON	
Safety	Controls (Which could stop ice machine operation)		
	High Pressure Cut-Out	Closed	
	Main Fuse (On Control Board)	Closed	

6-12 Part No. 80-1100-3

Section 6 Electrical System

4. FREEZE

The water pump starts after the 30second pre-chill. An even flow of water is directed across the evaporator and into each cube cell, where it freezes.

After six minutes the water inlet valve is locked out and can not add additional water.

When sufficient ice has formed, the water flow (not the ice) contacts the ice thickness probes. After approximately 7 seconds of continual contact, a harvest cycle is initiated.

NOTE: The ice machine cannot initiate a harvest cycle until a 6-minute freeze lock has expired.




Figure 6-11. Remote — Freeze

Table 6-11. Remote Models

4. Freeze (Until 7 Seconds of Water Contact with Ice Thickness Probe)		
Toggle Switch Bin Switch		ICE
		Closed
Contr	ol Board Relays	·
#1	Water Pump	Closed / ON
#2	Water Fill Valve	Cycles / ON then OFF
#3	Harvest Solenoid	Open / OFF
	Harvest Pressure Regulating (HPR) Solenoid	Open / OFF
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Closed / ON
	Liquid Line Solenoid	Energized
	Compressor	ON
	Condenser Fan Motor	ON
Safety	y Controls (Which could stop ice machine operation)	·
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

Harvest Sequence

5. WATER PURGE

The water pump continues to run, and the water dump valve energizes for 45 seconds to purge the water in the sump trough. The water fill valve energizes (turns on) and deenergizes (turns off) strictly by time. The water fill valve energizes for the last 15 seconds of the 45-second water purge. The water purge must be at the factory setting of 45 seconds for the fill valve to energize during the last 15 seconds of the Water Purge. If set at less than 45 seconds the water fill valve does not energize during the water purge.

NOTE: After the 45 second water purge, the water fill valve, water pump and dump valve de-energize. (Refer to "Water Purge Adjustment" on **Page 3-3** for details.) The harvest valve and HPR solenoid also open at the beginning of the water purge to divert hot refrigerant gas into the evaporator.




Figure 6-12. Remote — Water Purge

Table 6-12. Remote Models

	5. Water Purge (45 Seconds)		
Toggl	Toggle Switch ICE		
Bin Switch		Closed	
Contr	ol Board Relays	·	
#1	Water Pump	Closed / ON	
#2	Water Fill Valve	Cycles / OFF then ON	
#3	Harvest Solenoid	Closed / ON	
	Harvest Pressure Regulating (HPR) Solenoid	Closed / ON	
#4	Water Dump Valve	Closed / ON	
#5	Contactor Coil	Closed / ON	
	Liquid Line Solenoid	Energized	
	Compressor	ON	
	Condenser Fan Motor	ON	
Safety	Controls (Which could stop ice machine operation)	·	
	High Pressure Cut-Out	Closed	
	Main Fuse (On Control Board)	Closed	

6-14 Part No. 80-1100-3

Section 6 Electrical System

6. HARVEST

The harvest valve(s) and HPR solenoid valve remain open, allowing refrigerant gas to warm the evaporator. This causes the cubes to slide, as a sheet, off the evaporator and into the storage bin.

The sliding sheet of cubes swings the water curtain out, opening the bin switch. This momentary opening and closing of the bin switch terminates the Harvest Cycle and returns the ice machine to the Freeze Cycle (steps 3-4).




Figure 6-13. Remote — Harvest

Table 6-13. Remote Models

6. Harvest (Until Bin Switch Activation)		
Toggle Switch Bin Switch		ICE
		Closed
Contr	ol Board Relays	·
#1	Water Pump	Open / OFF
#2	Water Fill Valve	Open / OFF
#3	Harvest Solenoid	Closed / ON
	Harvest Pressure Regulating (HPR) Solenoid	Closed / ON
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Closed / ON
	Liquid Line Solenoid	Energized
	Compressor	ON
	Condenser Fan Motor	ON
Safety	Controls (Which could stop ice machine operation)	
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

Automatic Shut-Off

7. AUTOMATIC SHUT-OFF

If the storage bin is full at the end of a harvest cycle, the sheet of cubes fails to clear the water curtain and holds it open. After the water curtain is held open for 7 seconds, the ice machine shuts off.

The ice machine remains off until enough ice is removed from the storage bin to allow the sheet of cubes to drop clear of the water curtain. As the water curtain swings back to the operating position, the bin switch closes and the ice machine restarts.

NOTE: The ice machine must remain off for 3 minutes before it can automatically restart.




Figure 6-14. Remote — Automatic Shut-Off

Table 6-14. Remote Models

7. Automatic Shut-Off (Until Bin Switch Closes)		
Toggle Switch		ICE
Bin Switch		Open
Contro	ol Board Relays	
#1	Water Pump	Open / OFF
#2	Water Fill Valve	Open / OFF
#3	Harvest Solenoid	Open / OFF
	Harvest Pressure Regulating (HPR) Solenoid	Open / OFF
#4	Water Dump Valve	Open / OFF
#5	Contactor Coil	Open / OFF
	Liquid Line Solenoid	De-energized
	Compressor	ON
	Condenser Fan Motor	ON
Safety	Controls (Which could stop ice machine operation)	
	High Pressure Cut-Out	Closed
	Main Fuse (On Control Board)	Closed

6-16 Part No. 80-1100-3

Wiring Diagrams

The following pages contain electrical wiring diagrams. Be sure you are referring to the correct diagram for the ice machine which you are servicing.

A Warning

Always disconnect power before working on electrical circuitry.

WIRING DIAGRAM LEGEND

The following symbols are used on all of the wiring diagrams:

* Internal Compressor Overload

(Some models have external compressor overloads)

** Fan Motor Run Capacitor

(Some models do not incorporate fan motor run capacitor)

TB Terminal Board Connection

(Terminal board numbers are printed on the actual terminal board)


() Wire Number Designation

(The number is marked at each end of the wire)

-->>- Multi-Pin Connection

(Electrical Box Side) —>>— (Compressor Compartment Side)


Q200/Q280/Q320 - SELF CONTAINED - 1 PHASE WITH TERMINAL BOARD




SV1654

6-18 Part No. 80-1100-3

Q280/Q370 - SELF CONTAINED - 1 PHASE WITHOUT TERMINAL BOARD




Q320 - SELF CONTAINED - 1 PHASE WITHOUT TERMINAL BOARD




6-20 Part No. 80-1100-3

Q420/Q450/Q600/Q800/Q1000 - SELF CONTAINED - 1 PHASE WITH TERMINAL BOARD




Q420/Q450/Q600/Q800/Q1000 - SELF CONTAINED - 1 PHASE WITHOUT TERMINAL BOARD




6-22 Part No. 80-1100-3

Q800/Q1000 - SELF CONTAINED - 3 PHASE WITH TERMINAL BOARD




Q800/Q1000 - SELF CONTAINED - 3 PHASE WITHOUT TERMINAL BOARD

CAUTION: DISCONNECT POWER BEFORE WORKING
ON ELECTRICAL CIRCUITRY.
DIAGRAM SHOWN DURING FREEZE CYCLE
SEE SERIAL PLATE FOR VOLTAGE




6-24 Part No. 80-1100-3

Q1300/Q1800 - SELF CONTAINED - 1 PHASE WITH TERMINAL BOARD




Q1300/Q1600/Q1800 - SELF CONTAINED - 1 PHASE WITHOUT TERMINAL BOARD




6-26 Part No. 80-1100-3

Q1300/Q1800 - SELF CONTAINED - 3 PHASE WITH TERMINAL BOARD




Q1300/Q1600/Q1800 - SELF CONTAINED - 3 PHASE WITHOUT TERMINAL BOARD




SV3008

6-28 Part No. 80-1100-3

Q450/Q600/Q800/Q1000 - REMOTE - 1 PHASE WITH TERMINAL BOARD




Q450/Q600/Q800/Q1000 - REMOTE - 1 PHASE WITHOUT TERMINAL BOARD




6-30 Part No. 80-1100-3

Q800/Q1000 -REMOTE - 3 PHASE WITH TERMINAL BOARD




Q800/Q1000 -REMOTE - 3 PHASE WITHOUT TERMINAL BOARD




6-32 Part No. 80-1100-3

Q1300/Q1800 - REMOTE - 1 PHASE WITH TERMINAL BOARD




Q1300/Q1600/Q1800 - REMOTE - 1 Phase Without Terminal Board




6-34 Part No. 80-1100-3

Q1300/Q1800 - REMOTE - 3 PHASE WITH TERMINAL BOARD



Q1300/Q1600/Q1800 - REMOTE - 3 PHASE WITHOUT TERMINAL BOARD



6-36 Part No. 80-1100-3

THIS PAGE INTENTIONALLY LEFT BLANK

Component Specifications and Diagnostics

MAIN FUSE

Function

The control board fuse stops ice machine operation if electrical components fail causing high amp draw.

Specifications

The main fuse is 250 Volt, 7 amp.

Check Procedure

A Warning

High (line) voltage is applied to the control board (terminals #55 and #56) at all times. Removing the control board fuse or moving the toggle switch to OFF will not remove the power supplied to the control board.

1. If the bin switch light is on with the water curtain closed, the fuse is good.

A Warning

Disconnect electrical power to the entire ice machine before proceeding.

2. Remove the fuse. Check the resistance across the fuse with an ohm meter.

Reading	Result
Open (OL)	Replace fuse
Closed (O)	Fuse is good

BIN SWITCH

Function

Movement of the water curtain controls bin switch operation. The bin switch has two main functions:

1. Terminating the harvest cycle and returning the ice machine to the freeze cycle.

This occurs when the bin switch is opened and closed again within 7 seconds during the harvest cycle.

2. Automatic ice machine shut-off.

If the storage bin is full at the end of a harvest cycle, the sheet of cubes fails to clear the water curtain and holds it open. After the water curtain is held open for 7 seconds, the ice machine shuts off. The ice machine remains off until enough ice is removed from the storage bin to allow the sheet of cubes to drop clear of the water curtain. As the water curtain swings back to the operating position, the bin switch closes and the ice machine restarts, provide the three-minute delay has expired.

Important

The water curtain must be ON (bin switch(s) closed) to start ice making.

Specifications

The bin switch is a magnetically operated reed switch. The magnet is attached to the lower right corner of the water curtain. The switch is attached to the evaporator-mounting bracket.

The bin switch is connected to a varying D.C. voltage circuit. (Voltage does not remain constant.)

NOTE: Because of a wide variation in D.C. voltage, it is not recommended that a voltmeter be used to check bin switch operation.

6-38 Part No. 80-1100-3

Check Procedure

- 1. Set the toggle switch to OFF.
- 2. Watch the bin switch light on the control board.
- Move the water curtain toward the evaporator. The bin switch must close. The bin switch light "on" indicates the bin switch has closed properly.

Move the water curtain away from the evaporator. The bin switch must open. The bin switch light "off" indicates the bin switch has opened properly.

OHM Test

- Disconnect the bin switch wires to isolate the bin switch from the control board.
- 2. Connect an ohmmeter to the disconnected bin switch wires.
- 3. Cycle the bin switch open and closed numerous times by opening and closing the water curtain.

NOTE: To prevent misdiagnosis:

- Always use the water curtain magnet to cycle the switch (a larger or smaller magnet will affect switch operation).
- Watch for consistent readings when the bin switch is cycled open and closed (bin switch failure could be erratic).

Water Curtain Removal Notes

The water curtain must be on (bin switch closed) to start ice making. While a freeze cycle is in progress, the water curtain can be removed and installed at any time without interfering with the electrical control sequence.

If the ice machine goes into harvest sequence while the water curtain is removed, one of the following will happen:

- Water curtain remains off:
 When the harvest cycle time reaches 3.5 minutes and the bin switch is not closed, the ice machine stops as though the bin were full.
- Water curtain is put back on:
 If the bin switch closes prior to reaching the 3.5-minute point, the ice machine immediately returns to another freeze sequence prechill.

COMPRESSOR ELECTRICAL DIAGNOSTICS

The compressor will not start or will trip repeatedly on overload.

Check Resistance (Ohm) Values

NOTE: Compressor windings can have very low ohm values. Use a properly calibrated meter.

Perform the resistance test after the compressor cools. The compressor dome should be cool enough to touch (below 120°F/49°C) to assure that the overload is closed and the resistance readings will be accurate.

SINGLE PHASE COMPRESSORS

- 1. Disconnect power from the cuber and remove the wires from the compressor terminals.
- The resistance values must be within published guidelines for the compressor. The resistance values between C and S and between C and R, when added together, should equal the resistance value between S and R.
- 3. If the overload is open, there will be a resistance reading between S and R, and open readings between C and S and between C and R. Allow the compressor to cool, then check the readings again.

THREE PHASE COMPRESSORS

- Disconnect power from the cuber and remove the wires from the compressor terminals.
- 2. The resistance values must be within published guidelines for the compressor. The resistance values between L1 and L2, between L2 and L3, and between L3 and L1 should all be equal.
- 3. If the overload is open, there will be open readings between L1 and L2, between L2 and L3, and between L3 and L1. Allow the compressor to cool, then check the readings again.

Check Motor Windings to Ground

Check continuity between all three terminals and the compressor shell or copper refrigeration line. Scrape metal surface to get good contact. If continuity is present, the compressor windings are grounded and the compressor should be replaced.

Determine if the Compressor is Seized

Check the amp draw while the compressor is trying to start.

COMPRESSOR DRAWING LOCKED ROTOR

The two likely causes of this are:

- · Defective starting component
- Mechanically seized compressor

To determine which you have:

- 1. Install high and low side gauges.
- 2. Try to start the compressor.
- 3. Watch the pressures closely.
 - A. If the pressures do not move, the compressor is seized. Replace the compressor.
 - B. If the pressures move, the compressor is turning slowly and is not seized. Check the capacitors and start relay.

COMPRESSOR DRAWING HIGH AMPS

The continuous amperage draw on start-up should not be near the maximum fuse size indicated on the serial tag.

The voltage when the compressor is trying to start must be within ±10% of the nameplate voltage.

Diagnosing Capacitors

- If the compressor attempts to start, or hums and trips the overload protector, check the starting components before replacing the compressor.
- Visual evidence of capacitor failure can include a bulged terminal end or a ruptured membrane. Do not assume a capacitor is good if no visual evidence is present.
- A good test is to install a known good substitute capacitor.
- Use a capacitor tester when checking a suspect capacitor. Clip the bleed resistor off the capacitor terminals before testing.

6-40 Part No. 80-1100-3

PTCR DIAGNOSTICS

What is a PTCR?

A PTCR (or Positive Temperature Coefficient Resistor) is made from high-purity, semi-conducting ceramics.

A PTCR is useful because of its resistance versus temperature characteristic. The PTCR has a low resistance over a wide (low) temperature range, but upon reaching a certain higher temperature, its resistance greatly increases, virtually stopping current flow. When the source of heat is removed, the PTCR returns to its initial base resistance.

In severe duty cycles, it can be used to repeatedly switch (virtually stop) large currents at line voltages.

PTCR's have been used for many years in millions of HVAC applications. In place of using the conventional start relay/start capacitor, a simple PTCR provides the starting torque assistance to PSC (Permanent Split Capacitor) single-phase compressors, which can equalize pressures before starting.

Compressor Start Sequence

PTCR's provide additional starting torque by increasing the current in the auxiliary (start) winding during starting. The PTCR is wired across the run capacitor (in series with the start winding).

- 1. It is important for the refrigerant discharge and suction pressures to be somewhat equalized prior to the compressor starting. To assure equalization of pressures the harvest valve (and HPR valve on remotes) will energize for 45 seconds prior to compressor starting. The harvest valve (and HPR valve on remotes) remains on for an additional 5 seconds while the compressor is starting.
- When starting the compressor, the contactor closes and the PTCR, which is at a low resistance value, allows high starting current to flow in the start winding.
- The current passing through the PTCR causes it to rapidly heat up, and after approximately .25-1 second it abruptly "switches" to a very high resistance, virtually stopping current flow through it.
- 4. At this point the motor is up to speed and all current going through the start winding will now pass through the run capacitor.
- 5. The PTCR remains hot and at a high resistance as long as voltage remains on the circuit.
- 6. It is important to provide time between compressor restarts to allow the PTCR to cool down to near its initial temperature (low resistance). When the contactor opens to stop the compressor, the PTCR cools down to its initial low resistance and is again ready to provide starting torque assistance. To assure the PTCR has cooled down, during an automatic shut-off, the Q model ice machines have a built-in 3-minute off time before it can restart.

Q-Model Automatic Shut-Off and Restart

When the storage bin is full at the end of a harvest cycle, the sheet of cubes fails to clear the water curtain and will hold it open. After the water curtain is held open for 7 seconds, the ice machine shuts off. To assure the PTCR has cooled, the ice machine remains off for 3 minutes before it can automatically restart.

The ice machine remains off until enough ice has been removed from the storage bin to allow the ice to fall clear of the water curtain. As the water curtain swings back to operating position, the bin switch closes and the ice machine restarts, provided the three-minute delay period is complete.




Figure 6-15. During Start-Up (First .25 - 1.0 Seconds)




Figure 6-16. After Start-Up (Current Flows Through Run Capacitor)

Troubleshooting PTCR's

WHY A GOOD PTCR MAY FAIL TO START THE COMPRESSOR

The PTCR must be cooled before attempting to start the compressor, otherwise the high starting torque may not last long enough.

For example, if the PTCR is properly cooled, say 60°F (15.6°C) when the compressor starts, it will take .25 to 1.0 seconds before its temperature reaches 260°F (126.6°C), and current flow is stopped.

If the PTCR is still warm, say 160°F (71.1°C) when the compressor starts, it will take only .125 to .50 seconds before its temperature reaches 260°F (126.6°C), and current flow is stopped. This decreased time may be insufficient to start the compressor.

A good PTCR may be too hot to operate properly at start-up because:

- The ice machine's 3-minute delay has been overridden. Opening and closing the service disconnect or cycling the toggle switch from OFF to ICE will override the delay period.
- The control box temperature is too high. Though rare, very high air temperatures (intense sunlight, etc.) can greatly increase the temperature of the control box and its contents. This may require a longer off time to allow the PTCR to cool.
- The compressor has short-cycled, or the compressor overload has opened. Move the toggle switch to OFF and allow the compressor and PTCR to cool.

Continued on next page \dots

6-42 Part No. 80-1100-3

There are other problems that may cause compressor start-up failure with a good PTCR in a new, properly wired ice machine.

 The voltage at the compressor during start-up is too low.

Manitowoc ice machines are rated at $\pm 10\%$ of nameplate voltage at compressor start-up. (Ex: An ice machine rated at 208-230 should have a compressor start-up voltage between 187 and 253 volts.)

 The compressor discharge and suction pressures are not matched closely enough or equalized.

These two pressures must be somewhat equalized before attempting to start the compressor. The harvest valve (and HPR valve on remotes) energizes for 45 seconds before the compressor starts, and remains on 5 seconds after the compressor starts. Make sure this is occurring and the harvest valve (and HPR solenoid) coil is functional before assuming that the PTCR is bad.

CHECKING THE PTCR

A Warning

Disconnect electrical power to the entire ice machine at the building electrical disconnect box before proceeding.

1. Visually inspect the PTCR. Check for signs of physical damage.

NOTE: The PTCR case temperature may reach 210°F (100°C) while the compressor is running. This is normal. Do not change a PTCR just because it is hot.

- 2. Wait at least 10 minutes for the PTCR to cool to room temperature.
- 3. Remove the PTCR from the ice machine.
- Measure the resistance of the PTCR as shown below. If the resistance falls outside of the acceptable range, replace it.

Model	Model Manitowoc Cera-Mite Part Number Part Numb		Room Temperature Resistance
Q200			
Q280			
Q320	8505003	305C20	22-50 Ohms
Q420			
Q450			
Q600			
Q800	8504993	305C19	18-40 Ohms
Q1000			
Q1300			
Q1600	8504913	305C9	8-22 Ohms
Q1800			




Figure 6-17. Manitowoc PTCR's 8505003 & 8504993




Figure 6-18. Manitowoc PTCR 8504913

ICE/OFF/CLEAN TOGGLE SWITCH

Function

The switch is used to place the ice machine in ICE, OFF or CLEAN mode of operation.

Specifications

Double-pole, double-throw switch. The switch is connected into a varying low D.C. voltage circuit.

Check Procedure

NOTE: Because of a wide variation in D.C. voltage, it is not recommended that a volt meter be used to check toggle switch operation.

- 1. Inspect the toggle switch for correct wiring.
- Isolate the toggle switch by disconnecting all wires from the switch, or by disconnecting the Molex connector and removing wire #69 from the toggle switch.
- Check across the toggle switch terminals using a calibrated ohm meter. Note where the wire numbers are connected to the switch terminals, or refer to the wiring diagram to take proper readings.

Switch Setting	Terminals	Ohm Reading
	66-62	Open
ICE	67-68	Closed
	67-69	Open
	66-62	Closed
CLEAN	67-68	Open
	67-69	Closed
	66-62	Open
OFF	67-68	Open
	67-69	Open

4. Replace the toggle switch if ohm readings do not match all three switch settings.

CONTROL BOARD RELAYS

Function

The control board relays energize and de-energize system components.

Specifications

Relays are not field replaceable. There are five relays on the control board:

Relay	Controls
#1	Water Pump
#2	Water Inlet Valve
#3	Harvest Valve / HPR Valve (Remotes)
#4	Water Dump Valve
#5	Contactor (Self-Contained) Contactor / Liquid Line Solenoid (Remotes)

6-44 Part No. 80-1100-3

ELECTRONIC CONTROL BOARD




Figure 6-19. Control Board

General

Q-Model control boards use a dual voltage transformer. This means only one control board is needed for both 115V and 208-230V use.

Safety Limits

In addition to standard safety controls, such as the high pressure cut-out, the control board has built-in safety limits.

These safety limits protect the ice machine from major component failures. For more information, see "Safety Limits" on **Page 7-13**.

Inputs

The control board, along with inputs, controls all electrical components, including the ice machine sequence of operation. Prior to diagnosing, you must understand how the inputs affect the control board operation.

Refer to specific component specifications (inputs), wiring diagrams and ice machine sequence of operation sections for details.

As an example, refer to "Ice Thickness Probe" on the next page for information relating to how the probe and control board function together.

This section will include items such as:

- How a harvest cycle is initiated
- How the harvest light functions with the probe
- Freeze time lock-in feature
- Maximum freeze time
- Diagnosing ice thickness control circuitry

6-46 Part No. 80-1100-3

Ice Thickness Probe (Harvest Initiation) HOW THE PROBE WORKS

Manitowoc's electronic sensing circuit does not rely on refrigerant pressure, evaporator temperature, water levels or timers to produce consistent ice formation.

As ice forms on the evaporator, water (not ice) contacts the ice thickness probe. After the water completes this circuit across the probe continuously for 6-10 seconds, a harvest cycle is initiated.




Figure 6-20. Ice Thickness Probe

HARVEST/SAFETY LIMIT LIGHT

This light's primary function is to be on as water contacts the ice thickness probe during the freeze cycle, and remain on throughout the entire harvest cycle. The light will flicker as water splashes on the probes.

The light's secondary function is to continuously flash when the ice machine is shut off on a safety limit, and to indicate which safety limit shut off the ice machine.

FREEZE TIME LOCK-IN FEATURE

The ice machine control system incorporates a freeze time lock-in feature. This prevents the ice machine from short cycling in and out of harvest.

The control board locks the ice machine in the freeze cycle for six minutes. If water contacts the ice thickness probe during these six minutes, the harvest light will come on (to indicate that water is in contact with the probe), but the ice machine will stay in the freeze cycle. After the six minutes are up, a harvest cycle is initiated. This is important to remember when performing diagnostic procedures on the ice thickness control circuitry.

To allow the service technician to initiate a harvest cycle without delay, this feature is not used on the first cycle after moving the toggle switch OFF and back to ICE.

MAXIMUM FREEZE TIME

The control system includes a built-in safety which will automatically cycle the ice machine into harvest after 60 minutes in the freeze cycle.

ICE THICKNESS CHECK

The ice thickness probe is factory-set to maintain the ice bridge thickness at 1/8" (3.2 mm).

NOTE: Make sure the water curtain is in place when performing this check. It prevents water from splashing out of the water trough.

- 1. Inspect the bridge connecting the cubes. It should be about 1/8" (3.2 mm) thick.
- If adjustment is necessary, turn the ice thickness probe adjustment screw clockwise to increase bridge thickness, or counterclockwise to decrease bridge thickness.

NOTE: Turning the adjustment 1/3 of a turn will change the ice thickness about 1/16" (1.5 mm).




Figure 6-21. Ice Thickness Check

Make sure the ice thickness probe wire and the bracket do not restrict movement of the probe.

Ice Thickness Probe Cleaning

- Mix a solution of Manitowoc ice machine cleaner and water (2 ounces of cleaner to 16 ounces of water) in a container.
- Soak ice thickness probe in container of cleaner/ water solution while disassembling and cleaning water circuit components (soak ice thickness probe for 10 minutes or longer).
- 3. Clean all ice thickness probe surfaces including all plastic parts (do not use abrasives). Verify the ice thickness probe cavity is clean. Thoroughly rinse ice thickness probe (including cavity) with clean water, then dry completely. Incomplete rinsing and drying of the ice thickness probe can cause premature harvest.
- 4. Reinstall ice thickness probe, then sanitize all ice machine and bin/dispenser interior surfaces.

DIAGNOSING ICE THICKNESS CONTROL CIRCUITRY

Ice Machine Does Not Cycle Into Harvest When Water Contacts The Ice Thickness Control Probe

Step 1 Bypass the freeze time lock-in feature by moving the ICE/OFF/CLEAN switch to OFF and back to ICE. Wait until the water starts to flow over the evaporator.

Step 2 Clip the jumper wire leads to the ice thickness probe and any cabinet ground.




Figure 6-22. Step 2

Step 2 Jumper wire connected from probe to ground			
Monitoring of Harvest Light	Correction		
The harvest light comes on, and 6-10 seconds later, ice machine cycles from freeze to harvest.	The ice thickness control circuitry is functioning properly. Do not change any parts.		
The harvest light comes on but the ice machine stays in the freeze sequence.	The ice thickness control circuitry is functioning properly. The ice machine is in a six-minute freeze time lock-in. Verify step 1 of this procedure was followed correctly.		
The harvest light does not come on.	Proceed to Step 3, below.		

Step 3 Disconnect the ice thickness probe from the control board at terminal 1C. Clip the jumper wire leads to terminal 1C on the control board and any cabinet ground. Monitor the harvest light.




Figure 6-23. Step 3

Step 3 Jumper wire connected from control board terminal 1C to ground		
Monitoring of Harvest Light	Correction	
The harvest light comes on, and 6-10 seconds later, ice machine cycles from freeze to harvest.	The ice thickness probe is causing the malfunction.	
The harvest light comes on but the ice machine stays in the freeze sequence.	The control circuitry is functioning properly. The ice machine is in a six-minute freeze time lock-in (verify step 1 of this procedure was followed correctly).	
The harvest light does not come on.	The control board is causing the malfunction.	

6-48 Part No. 80-1100-3

Ice Machine Cycles Into Harvest Before Water Contact With The Ice Thickness Probe

Step 1 Bypass the freeze time lock-in feature by moving the ICE/OFF/CLEAN switch to OFF and back to ICE. Wait until the water starts to flow over the evaporator, then monitor the harvest light.

Step 2 Disconnect the ice thickness probe from the control board at terminal 1C.




Figure 6-24. Step 2

Step 2 Disconnect probe from control board terminal 1C.			
Monitoring of Harvest Light Correction			
The harvest light stays off and the ice machine remains in the freeze sequence.	The ice thickness probe is causing the malfunction. Verify that the Ice Thickness probe is adjusted correctly.		
The harvest light comes on, and 6-10 seconds later, the ice machine cycles from freeze to harvest.	The control board is causing the malfunction.		

Water Level Control Circuitry

WATER LEVEL PROBE LIGHT

The water level probe circuit can be monitored by watching the water level light. The water level light is on when water contacts the probe, and off when no water is in contact with the probe. The water level light functions any time power is applied to the ice machine, regardless of toggle switch position.




Figure 6-25. Freeze Cycle Water Level Setting

During the freeze cycle, the water level probe is set to maintain the proper water level above the water pump housing. The water level is not adjustable. If the water level is incorrect, check the water level probe for damage (probe bent, etc.). Repair or replace the probe as necessary.

WATER INLET VALVE SAFETY SHUT-OFF

In the event of a water level probe failure, this feature limits the water inlet valve to a six-minute on time. Regardless of the water level probe input, the control board automatically shuts off the water inlet valve if it remains on for 6 continuous minutes. This is important to remember when performing diagnostic procedures on the water level control circuitry.

FREEZE CYCLE CIRCUITRY

Manitowoc's electronic sensing circuit does not rely on float switches or timers to maintain consistent water level control. During the freeze cycle, the water inlet valve energizes (turns on) and de-energizes (turns off) in conjunction with the water level probe located in the water trough.

During the first 45 seconds of the Freeze Cycle:


- The water inlet valve is on when there is no water in contact with the water level probe.
- The water inlet valve turns off after water contacts the water level probe for 3 continuous seconds.
- The water inlet valve will cycle on and off as many times as needed to fill the water trough.

After 45 seconds into the Freeze Cycle:

The water inlet valve will cycle on, and then off one more time to refill the water trough. The water inlet valve is now off for the duration of the freeze sequence.

HARVEST CYCLE CIRCUITRY

The water level probe does not control the water inlet valve during the harvest cycle. During the harvest cycle water purge, the water inlet valve energizes (turns on) and de-energizes (turns off) strictly by time. The harvest water purge adjustment dial may be set at 15, 30 or 45 seconds.



NOTE: The water purge **must be at the factory setting** of 45 seconds for the water inlet valve to energize during the last 15 seconds of the Water Purge. If set at 15 or 30 seconds the water inlet valve will not energize during the harvest water purge.

6-50 Part No. 80-1100-3

DIAGNOSING FREEZE CYCLE POTABLE WATER LEVEL CONTROL CIRCUITRY

Problem: Water Trough Overfilling During The Freeze Cycle

Step 1 Start a new freeze sequence by moving the ICE/ OFF/CLEAN toggle switch to OFF, then back to ICE.

Important

This restart must be done prior to performing diagnostic procedures. This assures the ice machine is not in a freeze cycle water inlet valve safety shut-off mode. You must complete the entire diagnostic procedure within 6 minutes of starting.

Step 2 Wait until the freeze cycle starts

(approximately 45 seconds, the freeze cycle starts when the compressor energizes) then connect a jumper from the water level probe to any cabinet ground.

Important

For the test to work properly you must wait until the freeze cycle starts, prior to connecting the jumper wire. If you restart the test you must disconnect the jumper wire, restart the ice machine, (step 1) and then reinstall the jumper wire after the compressor starts.




Figure 6-26. Step 2

Step 2 Jumper wire connected from probe to ground			
Is water flowing into the water trough?	The Water Level Light is:	The Water Inlet Valve Solenoid Coil is:	Cause
no	on	De-Energized	This is normal operation. Do not change any parts.
yes	on	De-Energized	The water inlet valve is causing the problem.
yes	off	Energized	Proceed to step 3.

Continued on next page ...

Problem: Water Trough Overfilling During The Freeze Cycle (continued)

Step 3 Allow ice machine to run. Disconnect the water level probe from control board terminal 1F, and connect a jumper wire from terminal 1F to any cabinet ground.

Remember if you are past 6 minutes from starting, the ice machine will go into a freeze cycle water inlet valve safety shut-off mode, and you will be unable to complete this test. If past 6 minutes you must restart this test by disconnecting the jumper wire, restarting the ice machine, (step 1) and then reinstalling the jumper wire to terminal 1F, after the compressor starts.




Figure 6-27. Step 3

Step 3 Jumper wire connected from control board terminal 1F to ground			
Is water flowing into the water trough?	The Water Level Light is:	The Water Inlet Valve Solenoid Coil is:	Cause
no	on	De-Energized	The water level probe is causing the problem. Clean or replace the water level probe.
yes	off	Energized	The control board is causing the problem.
yes	on	De-Energized	The water fill valve is causing the problem.

6-52 Part No. 80-1100-3

Section 6 Electrical System

Problem: Water Will Not Run Into The Sump Trough During The Freeze Cycle

Step 1 Verify water is supplied to the ice machine, and then start a new freeze sequence by moving the ICE/ OFF/CLEAN toggle switch to OFF then back to ICE.

Important

This restart must be done prior to performing diagnostic procedures. This assures the ice machine is not in a freeze cycle water inlet valve safety shutoff mode. You must complete the entire diagnostic procedure within 6 minutes of starting.

Step 2 Wait until the freeze cycle starts (approximately 45 seconds, the freeze cycle starts when the compressor energizes), and then refer to chart.

Step 2 Checking for normal operation				
Is water flowing into the water trough?	•		Cause	
yes	off	Energized	This is Normal Operation don't change any parts	
no	on or off	Energized Or De-Energized	Proceed to step 3	

Step 3 Leave the ice machine run, then disconnect the water level probe from control board terminal 1F.

Important

For the test to work properly you must wait until the freeze cycle starts, prior to disconnecting the water level probe. If you restart the test you must reconnect the water level probe, restart the ice machine, (step 1) and then disconnect the water level probe after the compressor starts.




Figure 6-28. Step 3

Step 3 Disconnect water level probe from control board terminal 1F				
Is water flowing into the water trough?				
yes	off	Energized	The water level probe is causing the problem.	
			Clean or replace the water level probe.	
no	off	Energized	The water inlet valve is causing the problem.	
no	on or off	De-Energized	The control board is causing the problem.	

Electrical System Section 6

Diagnosing An Ice Machine That Will Not Run

A Warning

High (line) voltage is applied to the control board (terminals #55 and #56) at all times. Removing control board fuse or moving the toggle switch to OFF will not remove the power supplied to the control board.


Step	Check	Notes
1	Verify primary voltage supply to ice machine.	Verify that the fuse or circuit breaker is closed.
2	Verify the high-pressure cutout is closed.	The H.P.C.O. is closed if primary power voltage is present at terminals #55 and #56 on the control board.
3	Verify control board fuse is OK.	If the bin switch light functions, the fuse is OK.
4	Verify the bin switch functions properly.	A defective bin switch can falsely indicate a full bin of ice.
5	Verify ICE/OFF/CLEAN toggle switch functions properly.	A defective toggle switch may keep the ice machine in the OFF mode.
6	Verify low DC voltage is properly grounded.	Loose DC wire connections may intermittently stop the ice machine.
7	Replace the control board.	Be sure Steps 1-6 were followed thoroughly. Intermittent problems are not usually related to the control board.

NOTE: Refer to wiring diagram on Page 6-55 for component and sequence identification.

6-54 Part No. 80-1100-3

Section 6 Electrical System

Q0420/Q0450/Q0600/Q0800/Q1000 - SELF CONTAINED - 1 PHASE WITH TERMINAL BOARD



Electrical System Section 6


THIS PAGE INTENTIONALLY LEFT BLANK

6-56 Part No. 80-1100-3

Section 7 Refrigeration System

Sequence of Operation

SELF-CONTAINED AIR OR WATER -COOLED MODELS



SV1569

Figure 7-1. Self-Contained Prechill and Freeze Cycle (Models Q200/Q280/Q320/Q370/Q420/Q450/Q600/Q800/Q1000)

Prechill Refrigeration Sequence

No water flows over the evaporator during the prechill. The refrigerant absorbs heat (picked up during the harvest cycle) from the evaporator. The suction pressure decreases during the prechill.

Freeze Cycle Refrigeration Sequence

The refrigerant absorbs heat from water running over the evaporator surface. The suction pressure gradually drops as ice forms.




Figure 7-2. Self-Contained Harvest Cycle (Models Q200/Q280/Q320/Q370/Q420/Q450/Q600/Q800/Q1000) Harvest Cycle Refrigeration Sequence

Hot gas flows through the energized harvest valve, heating the evaporator. The harvest valve is sized to allow the proper amount of refrigerant into the evaporator. This specific sizing (along with the proper system refrigerant charge) assures proper heat transfer, without the refrigerant condensing and slugging the compressor.

7-2 Part No. 80-1100-3

REMOTE MODELS




Figure 7-3. Remote Pre-Chill and Freeze Cycle (Models Q450/Q600/Q800/Q1000)

Prechill Refrigeration Sequence

No water flows over the evaporator during the prechill. The refrigerant absorbs heat (picked up during the harvest cycle) from the evaporators. The suction pressure decreases during the prechill.

Freeze Cycle Refrigeration Sequence

The refrigerant absorbs heat from the water running over the evaporator surface. The suction pressure gradually drops as ice forms.

The headmaster control valve maintains discharge pressure in ambient temperatures below 70°F (21.1°C). (See "Headmaster Control Valve" on **Page 7-30**.)




Figure 7-4. Remote Harvest Cycle (Models Q450/Q600/Q800/Q1000)

Harvest Cycle Refrigeration Sequence

Hot gas flows through the energized harvest valve, heating the evaporator. The harvest valve is sized to allow the proper amount of hot gas into the evaporator. This specific harvest valve sizing, along with the harvest pressure regulating (H.P.R.) system, assures proper heat transfer, without the hot gas condensing to liquid and slugging the compressor.

The harvest pressure regulating (H.P.R.) valve helps maintain the suction pressure during the harvest cycle. (See "H.P.R. System" on **Page 7-27**.)

7-4 Part No. 80-1100-3




Figure 7-5. Remote Automatic Shut-Off (Models Q450/Q600/Q800/Q1000)

Automatic Shut-Off

The compressor and liquid line solenoid valve are deenergized simultaneously when the contactor contacts open.

During the off cycle, the check valve prevents refrigerant from migrating back into the high side, and the liquid line solenoid prevents refrigerant from migrating back into the low side. This protects the compressor from refrigerant migration during the off cycle, preventing refrigerant slugging upon start-up.

Q1300/Q1600/Q1800 REFRIGERATION TUBING SCHEMATICS




Figure 7-6. Q1300/Q1600/Q1800 Self-Contained Air- or Water-Cooled Models

NOTE: The refrigeration sequence for self-contained dual expansion valve ice machines is identical to self-contained single expansion valve ice machines. See **Pages 7-1** and **7-2** for sequence of operation.

7-6 Part No. 80-1100-3




Figure 7-7. Q1300/Q1600/Q1800 Remote Models

NOTE: The refrigeration sequence for remote dual expansion valve ice machines is identical to remote single expansion valve ice machines. See **Pages 7-3**, **7-4** and **7-5** for sequence of operation.

Operational Analysis (Diagnostics) GENERAL

When analyzing the refrigeration system, it is important to understand that different refrigeration component malfunctions may cause very similar symptoms.

Also, many external factors can make good refrigeration components appear bad. These factors can include improper installation, or water system malfunctions such as hot incoming water supply or water loss.

The following two examples illustrate how similar symptoms can result in a misdiagnosis.

 An expansion valve bulb that is not securely fastened to the suction line and/or not insulated will cause a good expansion valve to flood. If a service technician fails to check for proper expansion valve bulb mounting, he may replace the expansion valve in error.

The ice machine now functions normally. The technician erroneously thinks that the problem was properly diagnosed and corrected by replacing the expansion valve. Actually, the problem (loose bulb) was corrected when the technician properly mounted the bulb of the replacement expansion valve.

The service technician's failure to check the expansion valve bulb for proper mounting (an external check) resulted in a misdiagnosis and the needless replacement of a good expansion valve.

An ice machine that is low on charge may cause a good expansion valve to starve. If a service technician fails to verify the system charge, he may replace the expansion valve in error.

During the replacement procedure, recovery, evacuation and recharging are performed correctly. The ice machine now functions normally. The technician erroneously thinks that the problem was properly diagnosed and corrected by replacing the expansion valve.

The service technician's failure to check the ice machine for a low charge condition resulted in a misdiagnosis and the needless replacement of a good expansion valve.

When analyzing the refrigeration system, use the Refrigeration System Operational Analysis Table. This table, along with detailed checklists and references, will help prevent replacing good refrigeration components due to external problems.

7-8 Part No. 80-1100-3

BEFORE BEGINNING SERVICE

Ice machines may experience operational problems only during certain times of the day or night. A machine may function properly while it is being serviced, but malfunctions later. Information provided by the user can help the technician start in the right direction, and may be a determining factor in the final diagnosis.

Ask these questions before beginning service:

- When does the ice machine malfunction? (night, day, all the time, only during the freeze cycle, etc.)
- When do you notice low ice production? (one day a week, every day, on weekends, etc.)
- Can you describe exactly what the ice machine seems to be doing?
- · Has anyone been working on the ice machine?
- Is anything (such as boxes) usually stored near or on the ice machine which could obstruct airflow around the machine?
- During "store shutdown," is the circuit breaker, water supply or air temperature altered?
- Is there any reason why incoming water pressure might rise or drop substantially?

ICE PRODUCTION CHECK

1

The amount of ice a machine produces directly relates to the operating water and air temperatures. This means an ice machine in a 70°F (21.1°C) room with 50°F (10.0°C) water produces more ice than the same model ice machine in a 90°F (32.2°C) room with 70°F (21.1°C) water.

. Determine the ice machine operating	g conditions:
Air temp. entering condenser:	
Air temp. around ice machine:	o
Water temp. entering sump trough:	°

- Refer to the appropriate 24 Hour Ice Production Chart. (These charts begin on Page 7-33.) Use the operating conditions determined in Step 1 to find published 24 hour ice production:
- 3. Perform an actual ice production check. Use the formula below.

1.	Freeze Time	+	Harvest Time	=	Total Cycle Time
2.	1440 Minutes in 24 Hours	÷	Total Cycle Time	=	Cycles Per Day
3.	Weight of One Harvest	Х	Cycles Per Day	=	Actual 24 Hour Ice Production

Important

Times are in minutes.

Example: 1 min., 15 sec. converts to 1.25 min. (15 seconds ÷ 60 seconds = .25 minutes)

Weights are in pounds.

Example: 2 lb., 6 oz. converts to 2.375 lb. $(6 \text{ oz.} \div 16 \text{ oz.} = .375 \text{ lb.})$

Weighing the ice is the only 100% accurate check. However, if the ice pattern is normal and the 1/8" thickness is maintained, the ice slab weights listed with the 24 Hour Ice Production Charts may be used.

- 4. Compare the results of step 3 with step 2. Ice production is normal when these numbers match closely. If they match closely, determine if:
 - another ice machine is required.
 - more storage capacity is required.
 - relocating the existing equipment to lower the load conditions is required.

Contact the local Manitowoc distributor for information on available options and accessories.

INSTALLATION/VISUAL INSPECTION CHECKLIST

Possible Problem	Corrective Action
Ice machine is not level	Level the ice machine
Improper clearance around top, sides and/or back of ice machine	Reinstall according to the Installation Manual
Air-cooled condenser filter is dirty	Clean the condenser filter and/or condenser
Ice machine is not on an independent electrical circuit	Reinstall according to the Installation Manual
Water filtration is plugged (if used)	Install a new water filter
Water drains are not run separately and/or are not vented	Run and vent drains according to the Installation Manual
Remote condenser line set is improperly installed	Reinstall according to the Installation Manual

WATER SYSTEM CHECKLIST

A water-related problem often causes the same symptoms as a refrigeration system component malfunction.

Example: A water dump valve leaking during the freeze cycle, a system low on charge, and a starving TXV have similar symptoms.

Water system problems must be identified and eliminated prior to replacing refrigeration components.

Possible Problem	Corrective Action
Water area (evaporator) is dirty	Clean as needed
Water inlet pressure not between 20 and 80 psi	Install a water regulator valve or increase the water pressure
Incoming water temperature is not between 35°F (1.7°C) and 90°F (32.2°C).	If too hot, check the hot water line check valves in other store equipment
Water filtration is plugged (if used)	Install a new water filter
Water dump valve leaking during the freeze cycle	Clean/replace dump valve as needed
Vent tube is not installed on water outlet drain	See Installation Instructions
Hoses, fittings, etc., are leaking water	Repair/replace as needed
Water fill valve is stuck open	Clean/replace as needed
Water is spraying out of the sump trough area	Stop the water spray
Uneven water flow across the evaporator	Clean the ice machine
Water is freezing behind the evaporator	Correct the water flow
Plastic extrusions and gaskets are not secured to the evaporator	Remount/replace as needed
Water does not flow over the evaporator (not trickle) immediately after the prechill	Clean/replace water level probe as needed

7-10 Part No. 80-1100-3

ICE FORMATION PATTERN

Evaporator ice formation pattern analysis is helpful in ice machine diagnostics.

Analyzing the ice formation pattern alone cannot diagnose an ice machine malfunction. However, when this analysis is used along with Manitowoc's Refrigeration System Operational Analysis Table, it can help diagnose an ice machine malfunction.

Improper ice formation can be caused by any number of problems.

Example: An ice formation that is "extremely thin on outlet" could be caused by a hot water supply, a dump valve leaking water, a faulty water fill valve, a low refrigerant charge, etc.

Important

Keep the water curtain in place while checking the ice formation pattern to ensure no water is lost.

1. Normal Ice Formation

Ice forms across the entire evaporator surface.

At the beginning of the freeze cycle, it may appear that more ice is forming on the intlet of the evaporator than on the outlet. At the end of the freeze cycle, ice formation on the outlet will be close to, or just a bit thinner than, ice formation on the intlet. The dimples in the cubes at the outlet of the evaporator may be more pronounced than those on the intlet. This is normal.

The ice thickness probe must be set to maintain the ice bridge thickness at approximately 1/8". If ice forms uniformly across the evaporator surface, but does not reach 1/8" in the proper amount of time, this is still considered normal.

2. Extremely Thin at Evaporator Outlet

There is no ice, or a considerable lack of ice formation on the outlet of the evaporator (tubing outlet).

Examples: No ice at all on the outlet of the evaporator, but ice forms on the intlet half of the evaporator. Or, the ice at the outlet of the evaporator reaches 1/8" to initiate a harvest, but the intlet of the evaporator already has 1/2" to 1" of ice formation.




Figure 7-8. Extremely Thin Ice Formation at Evaporator Outlet

3. Extremely Thin at Evaporator Inlet

There is no ice, or a considerable lack of ice formation on the intlet of the evaporator (tubing inlet). Examples: The ice at the outlet of the evaporator reaches 1/8" to initiate a harvest, but there is no ice formation at all on the intlet of the evaporator.




Figure 7-9. Extremely Thin Ice Formation at Evaporator Inlet

4. Spotty Ice Formation

There are small sections on the evaporator where there is no ice formation. This could be a single corner, or a single spot in the middle of the evaporator. This is generally caused by loss of heat transfer from the tubing on the back side of the evaporator.




Figure 7-10. Spotty Ice Formation

5. No Ice Formation

The ice machine operates for an extended period, but there is no ice formation at all on the evaporator.

Important

The Q1300 Q1600 and Q1800 model machines have left and right expansion valves and separate evaporator circuits. These circuits operate independently from each other. Therefore, one may operate properly while the other is malfunctioning.

Example: If the left expansion valve is starving, it may not affect the ice formation pattern on the entire right side of the evaporator.




Figure 7-11. Q1300/Q1600/Q1800 Evaporator Tubing

7-12 Part No. 80-1100-3

SAFETY LIMITS

General

In addition to standard safety controls, such as high pressure cut-out, the control board has two built in safety limit controls which protect the ice machine from major component failures. There are two control boards with different safety limit sequences. Original production control boards have a black micro-processor. Current production and replacement control boards have an orange label on the control board microprocessor.

Safety Limit #1: If the freeze time reaches 60 minutes, the control board automatically initiates a harvest cycle.

Control Board with black microprocessor

If 3 consecutive 60-minute freeze cycles occur, the ice machine stops.

Control Board with orange label on microprocessor.

If 6 consecutive 60-minute freeze cycles occur, the ice machine stops.

Safety Limit #2: If the harvest time reaches 3.5 minutes, the control board automatically returns the ice machine to the freeze cycle.

Control Board with black microprocessor

If three consecutive 3.5 minute harvest cycles occur, the ice machine stops.

Control Board with orange label on microprocessor.

If 500 consecutive 3.5 minute harvest cycles occur, the ice machine stops.

Safety Limit Indication

Control Board with Black Microprocessor

When a safety limit condition is exceeded for 3 consecutive cycles the ice machine stops and the harvest light on the control board continually flashes on and off. Use the following procedures to determine which safety limit has stopped the ice machine.

- 1. Move the toggle switch to OFF.
- 2. Move the toggle switch back to ICE.
- 3. Watch the harvest light. It will flash one or two times, corresponding to safety limits 1 and 2, to indicate which safety limit stopped the ice machine.

After safety limit indication, the ice machine will restart and run until a safety limit is exceeded again.

Control Board with Orange Label


When a safety limit condition is exceeded for 3 consecutive cycles the control board enters the limit into memory and the ice machine continues to run. Use the following procedures to determine if the control board contains a safety limit indication.

- 1. Move the toggle switch to OFF.
- 2. Move the toggle switch back to ICE.
- 3. Watch the harvest light. If a safety limit has been recorded, the harvest light will flash one or two times, corresponding to safety limit 1 or 2.

When a safety limit condition is exceeded (6 consecutive cycles for Safety Limit #1 or 500 cycles for Safety Limit #2) the ice machine stops and the harvest light on the control board continually flashes on and off. Use the following procedures to determine which safety limit has stopped the machine.

- Move the toggle switch to OFF.
- 2. Move the toggle switch back to ICE.
- Watch the harvest light. It will flash one or two times, corresponding to safety limit 1 or 2 to indicate which safety limit stopped the ice machine.

After safety limit indication, the ice machine will restart and run until a safety limit is exceeded again.



Analyzing Why Safety Limits May Stop the Ice Machine

According to the refrigeration industry, a high percentage of compressors fail as a result of external causes. These can include: flooding or starving expansion valves, dirty condensers, water loss to the ice machine, etc. The safety limits protect the ice machine (primarily the compressor) from external failures by stopping ice machine operation before major component damage occurs.

The safety limit system is similar to a high pressure cutout control. It stops the ice machine, but does not tell what is wrong. The service technician must analyze the system to determine what caused the high pressure cutout, or a particular safety limit, to stop the ice machine.

The safety limits are designed to stop the ice machine prior to major component failures, most often a minor problem or something external to the ice machine. This may be difficult to diagnose, as many external problems occur intermittently.

Example: An ice machine stops intermittently on safety limit #1 (long freeze times). The problem could be a low ambient temperature at night, a water pressure drop, the water is turned off one night a week, etc.

When a high pressure cut-out or a safety limit stops the ice machine, they are doing what they are supposed to do. That is, stopping the ice machine before a major component failure occurs.

Refrigeration and electrical component failures may also trip a safety limit. Eliminate all electrical components and external causes first. If it appears that the refrigeration system is causing the problem, use Manitowoc's Refrigeration System Operational Analysis Table, along with detailed charts, checklists, and other references to determine the cause.

The following checklists are designed to assist the service technician in analysis. However, because there are many possible external problems, do not limit your diagnosis to only the items listed.

7-14 Part No. 80-1100-3

Safety Limit #1

Refer to page 7-13 for control board identification and safety limit operation.

Control Board with Black Microprocessor - Freeze Time exceeds 60 minutes for 3 consecutive freeze cycles

or

Control Board with Orange Label on Microprocessor - Freeze time exceeds 60 minutes for 6 consecutive freeze cycles.

Possible Cause	Check/Correct
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10
Water system	Low water pressure (20 psi min.)
	High water pressure (80 psi max.)
	High water temperature (90°F/32.2°C max.)
	Clogged water distribution tube
	Dirty/defective water fill valve
	Dirty/defective water dump valve
	Defective water pump
Electrical system	Ice thickness probe out of adjustment
	Harvest cycle not initiated electrically
	Contactor not energizing
	Compressor electrically non-operational
Restricted condenser	High inlet air temperature (110°F/43.3°C max.)
air flow (air-cooled models)	Condenser discharge air recirculation
	Dirty condenser filter
	Dirty condenser fins
	Defective fan cycling control
	Defective fan motor
Restricted condenser water flow (water-cooled models)	Low water pressure (20 psi min.)
	High water temperature (90°F/32.2°C max.)
	Dirty condenser
	Dirty/defective water regulating valve
	Water regulating valve out of adjustment
Refrigeration system	Non-Manitowoc components
	Improper refrigerant charge
	Defective head pressure control (remotes)
	Defective harvest valve
	Defective compressor
	TXV starving or flooding (check bulb mounting)
	Non-condensables in refrigeration system
	Plugged or restricted high side refrigerant lines or component

SAFETY LIMIT NOTES

- Because there are many possible external problems, do not limit your diagnosis to only the items listed in this chart.
- A continuous run of 100 harvests automatically erases the safety limit code.
- The control board will store and indicate only one safety limit – the last one exceeded.
- If the toggle switch is moved to the OFF position and then back to the ICE position prior to reaching the 100-harvest point, the last safety limit exceeded will be indicated.
- If the harvest light did not flash prior to the ice machine restarting, then the ice machine did not stop because it exceeded a safety limit.

Safety Limit #2

Refer to page 7-13 for control board identification and safety limit operation.

Control Board with Black Microprocessor - Harvest time exceeds 3.5 minutes for 3 consecutive harvest cycles.

or

Control Board with Orange Label on Microprocessor - Harvest time exceeds 3.5 minutes for 500 consecutive harvest cycles.

Possible Cause	Check/Correct
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10
Water system	Water area (evaporator) dirty
	Dirty/defective water dump valve
	Vent tube not installed on water outlet drain
	Water freezing behind evaporator
	Plastic extrusions and gaskets not securely mounted to the evaporator
	Low water pressure (20 psi min.)
	Loss of water from sump area
	Clogged water distribution tube
	Dirty/defective water fill valve
	Defective water pump
Electrical system	Ice thickness probe out of adjustment
	Ice thickness probe dirty
	Bin switch defective
	Premature harvest
Refrigeration system	Non-Manitowoc components
	Water regulating valve dirty/defective
	Improper refrigerant charge
	Defective head pressure control valve (remotes)
	Defective harvest pressure control (HPR) valve (remotes)
	Defective harvest valve
	TXV flooding (check bulb mounting)
	Defective fan cycling control

SAFETY LIMIT NOTES

- Because there are many possible external problems, do not limit your diagnosis to only the items listed in this chart.
- A continuous run of 100 harvests automatically erases the safety limit code.
- The control board will store and indicate only one safety limit – the last one exceeded.
- If the toggle switch is moved to the OFF position and then back to the ICE position prior to reaching the 100-harvest point, the last safety limit exceeded will be indicated.
- If the harvest light did not flash prior to the ice machine restarting, then the ice machine did not stop because it exceeded a safety limit.

7-16 Part No. 80-1100-3

ANALYZING DISCHARGE PRESSURE DURING FREEZE OR HARVEST CYCLE

Procedure

1.	Determine the ice machine of	operating o	conditions:
	Air temp. entering condense Air temp. around ice machin Water temp. entering sump	е	
2.	Refer to Operating Pressure being checked. (These char		
	Use the operating conditions find the published normal dis		•
	Freeze Cycle	Harvest C	ycle

3. Perform an actual discharge pressure check.

	Freeze Cycle PSIG	Harvest Cycle PSIG
Beginning of Cycle		
Middle of Cycle		
End of Cycle		

4. Compare the actual discharge pressure (step 3) with the published discharge pressure (step 2).

The discharge pressure is normal when the actual pressure falls within the published pressure range for the ice machine's operating conditions.

Freeze Cycle Discharge Pressure High Checklist

Possible Cause	Check/Correct
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10
Restricted condenser air flow (air-cooled models)	High inlet air temperature (110°F/43.3°C max.)
	Condenser discharge air recirculation
	Dirty condenser filter
	Dirty condenser fins
	Defective fan cycling control
	Defective fan motor
Restricted condenser water flow (water-cooled	Low water pressure (20 psi min.)
models)	High inlet water temperature (90°F/32.2°C max.)
	Dirty condenser
	Dirty/defective water regulating valve
	Water regulating valve out of adjustment
Improper refrigerant charge	Overcharged
	Non-condensables in system
	Wrong type of refrigerant
Other	Non-Manitowoc components in system
	High side refrigerant lines/component restricted (before mid-condenser)
	Defective head pressure control valve (remote models)

Freeze Cycle Discharge Pressure Low Checklist

Possible Cause	Check/Correct
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10
Improper refrigerant charge	Undercharged
	Wrong type of refrigerant
Water regulating valve (water-cooled condensers)	Out of adjustment
	Defective
Other	Non-Manitowoc components in system
	Defective head pressure control valve (remote models)
	Defective fan cycle control

NOTE: Do not limit your diagnosis to only the items listed in the checklists.

ANALYZING SUCTION PRESSURE DURING FREEZE CYCLE

The suction pressure gradually drops throughout the freeze cycle. The actual suction pressure (and drop rate) changes as the air and water temperatures entering the ice machine change. This affects freeze cycle times.

To analyze and identify the proper suction pressure drop throughout the freeze cycle, compare the published suction pressure to the published freeze cycle time. "Operating Pressure" and "Freeze Cycle Time" charts can be found later in this section.

NOTE: Analyze discharge pressure before analyzing suction pressure. High or low discharge pressure may be causing high or low suction pressure.

Procedure

Step	Exa	ample Usii	ng QY045	4A Mode	l Ice Mach	nine
4 Determine the ice machine energing	Air temp. en	tering cond	lenser:			90°F/32.2°C
Determine the ice machine operating conditions.	Air temp. ard	Air temp. around ice machine:				80°F/26.7°C
Conditions.	Water temp.	entering w	ater fill va	lve:		70°F/21.1°C
2A. Refer to "Cycle Time" and "Operating Pressure" charts for ice machine model being checked. Using operating conditions from Step 1, determine published freeze cycle time and published freeze cycle suction pressure.	Published freeze <u>13.7 - 14.1</u> r	•	e: Pu	ıblished fr	eeze cycle <u>55-36</u> P	suction pressure: SIG
		Published	Freeze C	ycle Time	(minutes)	
		1 3	5	7 9	12 14	
2B. Compare the published freeze cycle time and published freeze cycle suction pressure. Develop a chart.	_	++	-	 	++	_
	Pub	55 52 olished Free	48 4 eze Cycle		38 36 Pressure (p	
3. Perform an actual suction pressure check at the beginning, middle and end of the freeze cycle. Note the times at which the readings are taken.	Beginning of freeze cycle: Middle of freeze cycle: End of freeze cycle:			59 PSIG at 1 minute 48 PSIG at 7 minutes 40 PSIG at 14 minutes		
4. Compare the actual freeze cycle suction pressure (Step 3) to the published freeze cycle	Time Into Freeze Cycle	Publi: Pres			tual ssure	Result
time and pressure comparison (Step 2B).	1 minutes	55 P	SIG	59	PSIG	High
Determine if the suction pressure is high, low	7 minutes	44 P	SIG	48	PSIG	High
or acceptable.	14 minutes	36 P	SIG	40	PSIG	High

7-18 Part No. 80-1100-3

Freeze Cycle Suction Pressure High Checklist

Possible Cause	Check/Correct
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10
Discharge pressure	Discharge pressure is too high, and is affecting low side (See "Freeze Cycle Discharge Pressure High Checklist" on Page 7-16)
Improper refrigerant charge	Overcharged
	Wrong type of refrigerant
Other	Non-Manitowoc components in system
	H.P.R. solenoid leaking
	harvest valve stuck open
	TXV flooding (check bulb mounting)
	Defective compressor

Freeze Cycle Suction Pressure Low Checklist

Possible Cause	Check/Correct	
Improper installation	See "Installation/Visual Inspection Checklist" on Page 7-10	
Discharge pressure	Discharge pressure is too low, and is affecting low side (See "Freeze Cycle Discharge Pressure Low Checklist" on Page 7-16)	
Improper refrigerant charge	Undercharged	
	Wrong type of refrigerant	
Other	Non-Manitowoc components in system	
	Improper water supply over evaporator (See "Water System Checklist" on page 7-10)	
	Loss of heat transfer from tubing on back side of evaporator	
	Restricted/plugged liquid line drier	
	Restricted/plugged tubing in suction side of refrigeration system	
	TXV starving	

NOTE: Do not limit your diagnosis to only the items listed in the checklists.

SINGLE EXPANSION VALVE ICE MACHINES -COMPARING EVAPORATOR INLET AND OUTLET TEMPERATURES

NOTE: This procedure will not work on the dual expansion valve Q1300 Q1600 and Q1800 ice machines.

The temperatures of the suction lines entering and leaving the evaporator alone cannot diagnose an ice machine. However, comparing these temperatures during the freeze cycle, along with using Manitowoc's Refrigeration System Operational Analysis Table, can help diagnose an ice machine malfunction.

The actual temperatures entering and leaving the evaporator vary by model, and change throughout the freeze cycle. This makes documenting the "normal" inlet and outlet temperature readings difficult. The key to the diagnosis lies in the difference between the two temperatures five minutes into the freeze cycle. These temperatures must be within 7° of each other.

Use this procedure to document freeze cycle inlet and outlet temperatures.

- 1. Use a quality temperature meter, capable of taking temperature readings on curved copper lines.
- 2. Attach the temperature meter sensing device to the copper lines entering and leaving the evaporator.

Important

Do not simply insert the sensing device under the insulation. It must be attached to and reading the actual temperature of the copper line.

- 3. Wait five minutes into the freeze cycle.
- Record the temperatures below and determine the difference between them.
- 5. Use this with other information gathered on the Refrigeration System Operational Analysis Table to determine the ice machine malfunction.

Inlet Temperature

Difference
Must be within 7° at 5
minutes into freeze cycle

7-20 Part No. 80-1100-3

HARVEST VALVE TEMPERATURE CHECK

NOTE: This procedure requires checking both harvest valves on dual expansion valve Q1300 and Q1800 ice machines.

General

A harvest valve requires a critical orifice size. This meters the amount of hot gas flowing into the evaporator during the harvest cycle. If the orifice is even slightly too large or too small, long harvest cycles will result.

A too-large orifice causes refrigerant to condense to liquid in the evaporator during the harvest cycle. This liquid will cause compressor damage. A too-small orifice does not allow enough hot gas into the evaporator. This causes low suction pressure, and insufficient heat for a harvest cycle.

Refer to the Parts Manual for proper valve application. If replacement is necessary, Use only "original" Manitowoc replacement parts.

Harvest Valve Analysis

Symptoms of a harvest valve remaining partially open during the freeze cycle can be similar to symptoms of either an expansion valve or compressor problem. The best way to diagnose a harvest valve is by using Manitowoc's Ice Machine Refrigeration System Operational Analysis Table.

Use the following procedure and table to help determine if a harvest valve is remaining partially open during the freeze cycle.

- 1. Wait five minutes into the freeze cycle.
- 2. Feel the inlet of the harvest valve(s).

Important

Feeling the harvest valve outlet or across the harvest valve itself will not work for this comparison.

The harvest valve outlet is on the suction side (cool refrigerant). It may be cool enough to touch even if the valve is leaking.

3. Feel the compressor discharge line.

A Warning

The inlet of the harvest valve and the compressor discharge line could be hot enough to burn your hand. Just touch them momentarily.

4. Compare the temperature of the inlet of the harvest valves to the temperature of the compressor discharge line.

Findings	Comments
The inlet of the harvest valve is cool enough to touch and the compressor discharge line is hot.	This is normal as the discharge line should always be too hot to touch and the harvestharvest valve inlet, although too hot to touch during harvest, should be cool enough to touch after 5 minutes into the freeze cycle.
The inlet of the harvest valve is hot and approaches the temperature of a hot compressor discharge line.	This is an indication something is wrong, as the harvest valve inlet did not cool down during the freeze cycle. If the compressor dome is also entirely hot, the problem is not a harvest valve leaking, but rather something causing the compressor (and the entire ice machine) to get hot.
Both the inlet of the harvest valve and the compressor discharge line are cool enough to touch.	This is an indication something is wrong, causing the compressor discharge line to be cool to the touch. This is not caused by a harvest valve leaking.

DISCHARGE LINE TEMPERATURE ANALYSIS

General

Knowing if the discharge line temperature is increasing, decreasing or remaining constant can be an important diagnostic tool. Maximum compressor discharge line temperature on a normally operating ice machine steadily increases throughout the freeze cycle. Comparing the temperatures over several cycles will result in a consistent maximum discharge line temperature.

Ambient air temperatures affect the maximum discharge line temperature.

Higher ambient air temperatures at the condenser = higher discharge line temperatures at the compressor.

Lower ambient air temperatures at the condenser = lower discharge line temperatures at the compressor.

Regardless of ambient temperature, the freeze cycle discharge line temperature will be higher than 160°F (71.1°C) on a normally operating ice machine.

Procedure

Connect a temperature probe on the compressor discharge line with-in 6" of the compressor and insulate.

Observe the discharge line temperature for the last three minutes of the freeze cycle and record the maximum discharge line temperature.

Discharge Line Temperature Above 160°F (71.1°C) At End Of Freeze Cycle:

Ice machines that are operating normally will have consistent maximum discharge line temperatures above 160°F (71.1°C).

Discharge Line Temperature Below 160°F (71.1°C) At End Of Freeze Cycle

Ice machines that have a flooding expansion valve will have a maximum discharge line temperature that decreases each cycle.

Verify the expansion valve sensing bulb is 100% insulated and sealed airtight. Condenser air contacting an incorrectly insulated sensing bulb will cause overfeeding of the expansion valve.

Verify the expansion valve sensing bulb is positioned and secured correctly.

7-22 Part No. 80-1100-3

THIS PAGE INTENTIONALLY LEFT BLANK

HOW TO USE THE REFRIGERATION SYSTEM OPERATIONAL ANALYSIS TABLES

General

These tables must be used with charts, checklists and other references to eliminate refrigeration components not listed on the tables and external items and problems which can cause good refrigeration components to appear defective.

The tables list five different defects that may affect the ice machine's operation.

NOTE: A low-on-charge ice machine and a starving expansion valve have very similar characteristics and are listed under the same column.

NOTE: Before starting, see "Before Beginning Service" on **Page 7-9** for a few questions to ask when talking to the ice machine owner.

Procedure

Step 1 Complete the "Operation Analysis" column.

Read down the left "Operational Analysis" column.

Perform all procedures and check all information listed.

Each item in this column has supporting reference material to help analyze each step.

While analyzing each item separately, you may find an "external problem" causing a good refrigerant component to appear bad. Correct problems as they are found. If the operational problem is found, it is not necessary to complete the remaining procedures.

Step 2 Enter check marks ($\sqrt{}$) in the small boxes.

Each time the actual findings of an item in the "Operational Analysis" column matches the published findings on the table, enter a check mark.

Example: Freeze cycle suction pressure is determined to be low. Enter a check mark in the "low" box.

Step 3 Add the check marks listed under each of the four columns. Note the column number with the highest total and proceed to "Final Analysis."

NOTE: If two columns have matching high numbers, a procedure was not performed properly and/or supporting material was not analyzed correctly.

Final Analysis

The column with the highest number of check marks identifies the refrigeration problem.

COLUMN 1 - HARVEST VALVE LEAKING

A leaking harvest valve must be replaced.

COLUMN 2 - LOW CHARGE/TXV STARVING

Normally, a starving expansion valve only affects the freeze cycle pressures, not the harvest cycle pressures. A low refrigerant charge normally affects both pressures. Verify the ice machine is not low on charge before replacing an expansion valve.

- Add refrigerant charge in 2 to 4 oz. increments as a diagnostic procedure to verify a low charge. If the problem is corrected, the ice machine is low on charge. Find the refrigerant leak.
 - The ice machine must operate with the nameplate charge. If the leak cannot be found, proper refrigerant procedures must still be followed Change the liquid line drier. Then, evacuate and weigh in the proper charge.
- 2. If the problem is not corrected by adding charge, the expansion valve is faulty.

On dual expansion valve ice machines, change only the TXV that is starving. If both TXV's are starving, they are probably good, and are being affected by some other malfunction, such as low charge.

COLUMN 3 - TXV FLOODING

A loose or improperly mounted expansion valve bulb causes the expansion valve to flood. Check bulb mounting, insulation, etc., before changing the valve. On dual expansion valve machines, the service technician should be able to tell which TXV is flooding by analyzing ice formation patterns. Change only the flooding expansion valve.

COLUMN 4 - COMPRESSOR

Replace the compressor and start components. To receive warranty credit, the compressor ports must be properly sealed by crimping and soldering them closed. Old start components must be returned with the faulty compressor.

7-24 Part No. 80-1100-3

REFRIGERATION SYSTEM OPERATIONAL ANALYSIS TABLES



Q, J and B Model Single Expansion Valve

Manifowo(* This table must be used with charts, checklists and other references to eliminate refrigeration components not listed on the table and external items and problems, which can cause good refrigeration components to appear defective.

Operational Analysis	1	2	3	4
Ice Production	Air-Temperature Entering Condenser Water Temperature Entering Ice Machine Published 24 hour ice production Calculated (actual) ice production NOTE: The ice machine is operating properly if the ice fill patterns is normal and ice production is within 10% of charted capacity.			
				ion is within 10% of charted
Installation and Water System	All installation and water relate	ed problems must be corrected	before proceeding with chart.	
Ice Formation Pattern	Ice formation is extremely thin on outlet of evaporator -or-	lce formation is extremely thin on outlet of evaporator -or-	Ice formation normal -or- Ice formation is extremely	Ice formation normal -or- No ice formation on entire
	No ice formation on the entire evaporator	No ice formation on entire evaporator	thin on inlet of evaporator -or- No ice formation on entire evaporator	evaporator
Safety Limits			σναροιαιοι	
Refer to "Analyzing Safety Limits" to eliminate all non- refrigeration problems.	Stops on safety limit: 1	Stops on safety limit: 1	Stops on safety limit: 1 or 2	Stops on safety limit: 1
Freeze Cycle Discharge Pressure 1 minute Middle End			igh or low discharge pressure p	
into cycle				
Freeze Cycle Suction Pressure		and/or components not listed of	low suction pressure problem con this table before proceeding.	
1 minute Middle End	Suction pressure is High	Suction pressure is Low or Normal	Suction pressure is High	Suction pressure is High
Wait 5 minutes into the freeze cycle. Compare temperatures of evaporator inlet and evaporator outlet. Inlet ° F (° C) Outlet ° F (° C) Difference ° F (° C)	Inlet and outlet within 7° of each other	Inlet and outlet not within 7° of each other -and- Inlet is colder than outlet	Inlet and outlet within 7° of each other -or- Inlet and outlet not within 7° of each other -and- Inlet is warmer than outlet	Inlet and outlet within 7° of each other
Wait 5 minutes into the freeze cycle. Compare temperatures of compressor discharge line and harvest valve inlet.	The harvest valve inlet is Hot -and- approaches the temperature of a Hot compressor discharge line.	The harvest valve inlet is Cool enough to hold hand on -and- the compressor discharge line is Hot.	The harvest valve inlet is Cool enough to hold hand on -and- the compressor discharge line is Cool enough to hold hand on.	The harvest valve inlet is Cool enough to hold hand on -and-the compressor discharge line is Hot .
Discharge Line Temperature Record freeze cycle discharge line temperature at the end of the freeze cycle°F (°C)	Discharge line temperature 160°F (71.1°C) or higher at the end of the freeze cycle	Discharge line temperature 160°F (71.1°C) or higher at the end of the freeze cycle	Discharge line temperature less than 160°F (71.1°C) at the end of the freeze cycle	Discharge line temperature 160°F (71.1°C) or higher at the end of the freeze cycle
Final Analysis Enter total number of boxes checked in each column.	Harvest Valve Leaking	Low On Charge -Or- TXV Starving	TXV Flooding	Compressor

7-25 Part No. 80-1100-3



Q and J Model Dual Expansion Valve

This table must be used with charts, checklists and other references to eliminate refrigeration components not listed on the table and external items and problems, which can cause good refrigeration components to appear defective.

Operational Analysis	1	2	3	4	
Ice Production	Air-Temperature Entering Condenser				
	Water Temperature Ent	Water Temperature Entering Ice Machine			
		production			
	Calculated (actual) ice				
		e is operating properly if			
	and ice formation patte	rn is normal and ice prod	duction is within 10% of	charted capacity.	
Ice Formation Pattern	Ice formation is	Ice formation is	Ice formation normal	Ice formation normal	
Left side	extremely thin on	extremely thin on	-or-	-or-	
	outet of one side of	outlet of one or both	Ice formation is	No ice formation on	
Right side	evaporator	sides of evaporator	extremely thin on inlet	entire evaporator	
	-Or-	-Or-	of one side of		
	No ice formation on	No ice formation on	evaporator		
	one side of	entire evaporator	-or- No ice formation on		
	evaporator		entire evaporator		
Safoty limits	Stone on enfaty limits	Stone on sofety limit	· · · · · · · · · · · · · · · · · · ·	Stone on cofety limits	
Safety limits Refer to "Analyzing Safety	Stops on safety limit:	Stops on safety limit:	Stops on safety limit: 1 or 2	Stops on safety limit:	
Limits" to eliminate problems	'	'	1 01 2		
and/or components not listed					
on this table					
Freeze Cycle	If discharge pressure	is High or Low refer to	a freeze cycle high or lo	l w discharge pressure	
DISCHARGE pressure			or components not listed		
	F	•	eding.		
1 minute Middle End		,	3		
into cycle					
Freeze Cycle	If suction pressure is H	igh or Low refer to a fre	eze cycle high or low su	ction pressure problem	
SUCTION pressure			nents not listed on this ta		
	Suction pressure is	Suction pressure is	Suction pressure is	Suction pressure is	
Beginning Middle End	High	Low or Normal	High	High	
Harvest Valve	One harvest valve	Both harvest valve	Both harvest valve	Both harvest valve	
Wait 5 minutes into the freeze	inlet is Hot	inlets are	inlets are Cool	inlets are Cool	
cycle.	-and-	Cool enough	enough	enough	
Compare temperatures of	approaches the	to hold hand on	to hold hand on	to hold hand on	
compressor discharge line	temperature of a Hot	-and-	-and-	-and-	
and both harvest valve inlets.	compressor	the compressor	the compressor	the compressor	
	discharge line.	discharge line is Hot.	discharge line is	discharge line is Hot.	
			Cool enough		
			to hold hand on.		
Discharge Line Temperature	Discharge line	Discharge line	Discharge line	Discharge line	
Record freeze cycle discharge	temperature	temperature	temperature	temperature	
line temperature at the end of	160°F (71.1°C)	160°F (71.1°C)	less than	160°F (71.1°C)	
the freeze cycle	or higher	or higher	160°F (71.1°C) at the end of the	or higher at the end of the	
	at the end of the	at the end of the	freeze cycle	freeze cycle	
°F (°C)	freeze cycle	freeze cycle	ii eeze cycle	ii ccze cycle	
Final Analysis	Harvest Valve	Low On Charge	TXV Flooding	Compressor	
Enter total number of boxes	Leaking	-Or-			
checked in each column.		TXV Starving			

7-26 Part No. 80-1100-3

HARVEST PRESSURE REGULATING (H.P.R.) SYSTEM


Figure 7-13. H.P.R. Valve

Remotes Only

GENERAL

The harvest pressure regulating (H.P.R.) system includes:


 Harvest pressure regulating solenoid valve (H.P.R. solenoid). This is an electrically operated valve which opens when energized, and closes when deenergized.



SV1427

Figure 7-12. H.P.R. Solenoid

Harvest pressure regulating valve (H.P.R. valve).
 This is a non-adjustable pressure regulating valve which modulates open and closed, based on the refrigerant pressure at the outlet of the valve. The valve closes completely and stops refrigerant flow when the pressure at the outlet rises above the valve setting.



FREEZE CYCLE

The H.P.R. system is not used during the freeze cycle. The H.P.R. solenoid is closed (de-energized), preventing refrigerant flow into the H.P.R. valve.

HARVEST CYCLE

During the harvest cycle, the check valve in the discharge line prevents refrigerant in the remote condenser and receiver from backfeeding into the evaporator and condensing to liquid.

The H.P.R. solenoid is opened (energized) during the harvest cycle, allowing refrigerant gas from the top of the receiver to flow into the H.P.R. valve. The H.P.R. valve modulates open and closed, raising the suction pressure high enough to sustain heat for the harvest cycle, without allowing refrigerant to condense to liquid in the evaporator.

In general, harvest cycle suction pressure rises, then stabilizes in the range of 75-100 psig (517-758 kPA).

Exact pressures vary from model to model. These can be found in the "Operational Refrigerant Pressures" charts, beginning on **Page 7-32**.

7-28 Part No. 80-1100-3

HPR DIAGNOSTICS

Steps 1 through 4 can be quickly verified without attaching a manifold gauge set or thermometer.

All questions must have a yes answer to continue the diagnostic procedure.

1. Liquid line warm?

(Body temperature is normal)

If liquid line is warmer or cooler than body temperature, refer to headmaster diagnostics.

2. Ice fill pattern normal?

Refer to "Ice Formation Pattern" if ice fill is not normal.

3. Freeze time normal?

(Refer to Cycle Times/Refrigerant Pressures/24 Hour Ice Production Charts)

Shorter freeze cycles - Refer to headmaster diagnostics.

Longer freeze cycles - Refer to water system checklist, then refer to Refrigeration Diagnostic Procedures.

4. Harvest time is longer than normal and control board indicates safety limit #2?

(Refer to Cycle Times/Refrigerant Pressures/24 Hour Ice Production Charts)

Connect refrigeration manifold gauge set to the access valves on the front of the ice machine, and a thermometer thermocouple on the discharge line within 6" of the compressor (insulate thermocouple).

 Establish baseline by recording suction and discharge pressure, discharge line temperature and freeze & harvest cycle times. (Refer to section 7 "Operational Analysis" for data collection detail).

- Freeze cycle Head Pressure 220 psig or higher?
 If the head pressure is lower than 220 psig refer to headmaster diagnostics.
- Freeze cycle Suction Pressure normal?
 Refer to analyzing suction pressure if suction pressure is high or low.
- 8. Discharge line temperature is 160°F (71.1°C) or higher at end of freeze cycle?
 - If less than 160°F (71.1°C) check expansion valve bulb mounting and insulation.
- 9. Harvest cycle suction and discharge pressures are lower than indicated in the cycle times/refrigerant pressures/24 hour ice production chart?
 - Replace Harvest Pressure Regulating system (HPR Valve and HPR solenoid valve).

HEADMASTER CONTROL VALVE

Manitowoc remote systems require headmaster control valves with special settings. Replace defective headmaster control valves only with "original" Manitowoc replacement parts.

Operation

The R404A headmaster control valve is non adjustable.

At ambient temperatures of approximately 70°F (21.1°C) or above, refrigerant flows through the valve from the condenser to the receiver inlet. At temperatures below this (or at higher temperatures if it is raining), the head pressure control dome's nitrogen charge closes the condenser port and opens the bypass port from the compressor discharge line.

In this modulating mode, the valve maintains minimum head pressure by building up liquid in the condenser and bypassing discharge gas directly to the receiver.

Diagnosing

- Determine the air temperature entering the remote condenser.
- Determine if the head pressure is high or low in relationship to the outside temperature. (Refer to the proper "Operational Pressure Chart" later in this section.) If the air temperature is below 70°F (21.1°C), the head pressure should be modulating about 225 PSIG.
- 3. Determine the temperature of the liquid line entering the receiver by feeling it. This line is normally warm; "body temperature."
- 4. Using the information gathered, refer to the chart below.

NOTE: A headmaster that will not bypass, will function properly with condenser air temperatures of approximately 70°F (21.1°C) or above. When the temperature drops below 70°F (21.1°C), the headmaster fails to bypass and the ice machine malfunctions. Lower ambient conditions can be simulated by rinsing the condenser with cool water during the freeze cycle.

Symptom	Probable Cause	Corrective Measure
Valve not maintaining pressures	Non-approved valve	Install a Manitowoc Headmaster control valve with proper setting
Discharge pressure extremely high; Liquid line entering receiver feels hot	Valve stuck in bypass	Replace valve
Discharge pressure low; Liquid line entering receiver feels extremely cold	Valve not bypassing	Replace valve
Discharge pressure low; Liquid line entering receiver feels warm to hot	Ice machine low on charge	See "Low on Charge Verification" on Page 7-31

7-30 Part No. 80-1100-3

LOW ON CHARGE VERIFICATION

The remote ice machine requires more refrigerant charge at lower ambient temperatures than at higher temperatures. A low on charge ice machine may function properly during the day, and then malfunction at night. Check this possibility.

If you cannot verify that the ice machine is low on charge:

- Add refrigerant in 2 lb. increments, but do not exceed 6 lbs.
- 2. If the ice machine was low on charge, the headmaster function and discharge pressure will return to normal after the charge is added. Do not let the ice machine continue to run. To assure operation in all ambient conditions, the refrigerant leak must be found and repaired, the liquid line drier must be changed, and the ice machine must be evacuated and properly recharged.
- 3. If the ice machine does not start to operate properly after adding charge, replace the headmaster.

FAN CYCLE CONTROL VS. HEADMASTER

A fan cycle control cannot be used in place of a headmaster. The fan cycle control is not capable of bypassing the condenser coil and keeping the liquid line temperature and pressure up.

This is very apparent when it rains or the outside temperature drops. When it rains or the outside temperature drops, the fan begins to cycle on and off. At first, everything appears normal. But, as it continues raining or getting colder, the fan cycle control can only turn the fan off. All the refrigerant must continue to flow through the condenser coil, being cooled by the rain or low outside temperature.

This causes excessive sub-cooling of the refrigerant. As a result, the liquid line temperature and pressure are not maintained for proper operation.

Pressure Control Specifications and Diagnostics

FAN CYCLE CONTROL

(Self-Contained Air-Cooled Models Only)

Function

Cycles the fan motor on and off to maintain proper operating discharge pressure.

The fan cycle control closes on an increase, and opens on a decrease in discharge pressure.

Specifications

Model	Cut-In (Close)	Cut-Out (Open)
Q200/Q280 Q320/Q370/Q420 Q450/Q600	250 psig ±5	200 psig ±5
Q800/Q1000 Q1300/ Q1800	275 psig ±5	225 psig ±5

Check Procedure

- 1. Verify fan motor windings are not open or grounded, and fan spins freely.
- 2. Connect manifold gauges to ice machine.
- 3. Hook voltmeter in parallel across the fan cycle control, leaving wires attached.
- 4. Refer to chart below.

At:	Reading Should Be:	Fan Should Be:
above cut-in	0 volts	running
below cut-out line voltage		off

HIGH PRESSURE CUT-OUT (HPCO) CONTROL

Function

Stops the ice machine if subjected to excessive highside pressure.

The HPCO control is normally closed, and opens on a rise in discharge pressure.

Specifications

Cut-out: 450 psig ±10

Cut-in: Manual or automatic reset (Must be below 300 psig to reset).

Check Procedure

- 1. Set ICE/OFF/CLEAN switch to OFF, (Manual reset HPCO reset if tripped).
- 2. Connect manifold gauges.
- 3. Hook voltmeter in parallel across the HPCO, leaving wires attached.
- On water-cooled models, close the water service valve to the water condenser inlet. On self-contained air-cooled and remote models, disconnect the fan motor.
- 5. Set ICE/OFF/CLEAN switch to ICE.
- No water or air flowing through the condenser will cause the HPCO control to open because of excessive pressure. Watch the pressure gauge and record the cut-out pressure.

A Warning

If discharge pressure exceeds 460 psig and the HPCO control does not cut out, set ICE/OFF/CLEAN switch to OFF to stop ice machine operation.

Replace the HPCO control if it:

- Will not reset (below 300 psig)
- Does not open at the specified cut-out point

7-32 Part No. 80-1100-3

Cycle Time/24 Hour Ice Production/ Refrigerant Pressure Charts

Q200 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering					
Condenser °F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	11.5-13.5	13.8-16.1	15.2-17.8		
80/26.7	13.8-16.1	15.6-18.2	17.0-19.8	1.0-2.5	
90/32.2	16.1-18.7	18.6-21.6	20.5-23.8	1.0-2.5	
100/37.8	19.8-23.0	23.6-27.4	25.5-29.6		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	270	230	210		
80/26.7	230	205	190		
90/32.2	200	175	160		
100/37.8	165	140	130		

Based on average ice slab weight of 2.44 - 2.81 lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	Cycle
Entering Condenser °F/°C	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	195-260	60-28	120-190	85-110
70/21.1	195-260	60-28	120-190	85-110
80/26.7	210-270	65-28	160-190	90-110
90/32.2	240-290	70-30	190-210	100-120
100/37.8	270-330	70-35	220-240	120-140
110/43.3	310-390	85-40	250-270	120-150
Suction pressu	ure drops grad	ually through	out the freeze	cycle

Q200 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Around Ice	Water	Water Temperature °F/°C		
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	11.5-13.5	12.8-15.0	14.5-16.9	
80/26.7	12.0-14.1	13.5-15.7	15.2-17.8	1-2.5
90/32.2	12.6-14.7	14.1-16.5	16.1-18.7	1-2.5
100/37.8	13.1-15.4	14.8-17.3	17.0-19.8	
Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	270	245	220		
80/26.7	260	235	210		
90/32.2	250	225	200		
100/37.8	240	215	190		

Based on average ice slab weight of 2.44 - 2.81 lb Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Water Tem		°F/°C	
Consumption	50/10.0	70/21.1	90/32.2	
Gal/24 hours	240 480 2100			
Water regulating valve set to maintain 230 PSIG discharge pressure				

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle	
Around Ice Machine °F/°C	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	
50/10.0	225-235	60-28	170-200	90-110	
70/21.1	225-235	60-28	170-200	90-110	
80/26.7	225-240	60-28	175-205	90-110	
90/32.2	225-245	65-30	175-205	90-115	
100/37.8	225-250	70-32	180-210	90-115	
110/43.3	225-260	75-34	185-215	90-120	
Suction press	Suction pressure drops gradually throughout the freeze cycle				

Q280 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Entering	Water	Harvest			
°F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	10.6-12.5	11.8-13.8	12.6-14.7		
80/26.7	11.5-13.5	12.8-15.0	13.8-16.1	1.0-2.5	
90/32.2	12.6-14.7	14.1-16.5	15.2-17.8	1.0-2.5	
100/37.8	14.5-16.9	16.5-19.3	18.0-21.0		
Time and improved	!		1	!	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	90/32.2			
70/21.1	290	265	250		
80/26.7	270	245	230		
90/32.2	250	225	210		
100/37.8	220	195	180		

Based on average ice slab weight of 2.44 - 2.81 lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle			
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG			
50/10.0	195-250	60-20	150-190	70-90			
70/21.1	195-250	60-20	150-190	70-90			
80/26.7	220-280	60-26	180-220	70-90			
90/32.2	250-310	66-30	190-220	80-100			
100/37.8	280-350	70-32	220-250	80-110			
110/43.3	310-390	85-40	250-270	80-120			
Suction pressu	re drops grad	lually throughous	Suction pressure drops gradually throughout the freeze cycle				

Q280 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Around Ice	10/	Harvest			
	Water	Temperature	e °F/°C		
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	10.6-12.5	12.0-14.1	12.3-14.4		
80/26.7	10.8-12.7	12.3-14.4	13.8-16.1	1-2.5	
90/32.2	11.0-13.0	12.6-14.7	14.1-16.5	1-2.5	
100/37.8 11.3-13.2 12.8-15.0 14.5-16.9					
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Around Ice Machine °F/°C	50/10.0 70/21.1 90/32.				
70/21.1	290	260	255		
80/26.7	285	255	230		
90/32.2	280	250	225		
100/37.8	275	245	220		

Based on average ice slab weight of 2.44 - 2.81 lb

Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Water Temperature °F/°C			
Consumption	50/10.0	70/21.1	90/32.2	
Gal/24 hours	250 490 3400			
Water regulating valve set to maintain 230 PSIG discharge pressure				

Operating Pressures

Air Temp.	Freeze	Freeze Cycle		t Cycle
Around Ice Machine °F/°C	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	225-235	60-28	190-200	75-90
70/21.1	225-235	60-28	190-200	80-90
80/26.7	225-240	60-28	190-200	80-90
90/32.2	225-245	62-28	190-200	80-90
100/37.8	225-250	62-30	190-200	80-90
110/43.3	225-260	64-32	195-205	80-95
Suction pressure drops gradually throughout the freeze cycle				

7-34 Part No. 80-1100-3

Q320 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Harvest		
Condenser °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	12.2-13.9	13.1-14.9	14.2-16.2	
80/26.7	13.6-15.5	14.8-16.8-	16.1-18.4	1-2.5
90/32.2	16.1-18.4	17.7-20.2	19.7-22.3	1-2.5
100/37.8	19.7-22.3	22.0-25.0	25.0-28.3	
Times in minute	25			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	310	290	270		
80/26.7	280	260	240		
90/32.2	240	220	200		
100/37.8	200	180	160		

Based on average ice slab weight of 2.94 - 3.31lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	
50/10.0	200-250	50-36	150-180	75-90	
70/21.1	200-250	50-36	160-190	80-100	
80/26.7	220-280	50-36	170-200	90-110	
90/32.2	230-320	54-38	180-220	90-120	
100/37.8	270-360	56-40	200-250	95-140	
110/43.3	280-380	58-42	210-260	95-150	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q320 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Around Ice		Harvest		
	Water	Temperature	e °F/°C	
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	12.6-14.4	13.6-15.5	15.4-17.6	
80/26.7	13.1-14.9	14.2-16.2	16.1-18.4	1-2.5
90/32.2	13.6-15.5	14.8-16.8	16.9-19.2	1-2.5
100/37.8	14.2-16.2	15.4-17.6	17.7-20.2	
Times in minute	20			

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	300	280	250	
80/26.7	290	270	240	
90/32.2	280	260	230	
100/37.8	270	250	220	

Based on average ice slab weight of 2.94 - 3.31 lb Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Water Temperature °F/°C			
Consumption	50/10.0	90/32.2		
Gal/24 hours	270 560 3200			
Water regulating valve set to maintain 230 PSIG discharge pressure				

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	225-235	50-36	160-180	80-110
70/21.1	225-235	50-36	170-190	85-115
80/26.7	225-240	50-36	170-200	85-115
90/32.2	225-250	50-36	170-210	90-120
100/37.8	225-260	52-36	170-210	90-120
110/43.3	225-265	54-36	175-215	95-125
Suction pressure drops gradually throughout the freeze cycle				

Q370 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Temperatur _e	e °F/°C	Harvest
°F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	10.3-11.7	11.7-13.4	12.6-14.4	
80/26.7	11.3-12.9	12.6-14.4	13.9-15.8	1-2.5
90/32.2	12.9-14.7	13.9-15.8	15.4-17.6	1-2.5
100/37.8	14.5-16.5	16.1-18.4	17.3-19.7	
Times in minute	98			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	360	320	300	
80/26.7	330	300	275	
90/32.2	295	275	250	
100/37.8	265	240	225	
Based on average ice slab weight of 2.94 - 3.31lb				

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	200-250	60-34	145-165	75-95
70/21.1	215-250	60-36	150-170	85-100
80/26.7	250-290	65-38	165-185	90-110
90/32.2	260-330	70-40	175-195	100-120
100/37.8	300-380	80-41	195-220	130-150
110/43.3	310-390	80-42	200-225	135-155
Suction pressu	re drops grad	lually through	out the freeze	cvcle

Q370 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Around Ice	Freeze Time Water Temperature °F/°C			Harvest
Machine °F/°C	50/10.0 70/21.1 90/32.2			Time
70/21.1	10.3-11.7	11.0-12.5	12.2-13.9	
80/26.7	10.6-12.1	11.3-12.9	12.6-14.4	1-2.5
90/32.2	11.0-12.5	11.7-13.4	13.1-14.4	1-2.5
100/37.8	11.3-12.9	12.2-13.9	13.6-15.5	
Times in minutes				

24 Hour Ice Production

Air Temp. Around Ice	Water Temperature °F/°C					
Machine °F/°C	50/10.0 70/21.1 90/32					
70/21.1	360	340	310			
80/26.7	350	330	300			
90/32.2	340	320	290			
100/37.8	330	310	280			
Based on average ice slab weight of 2.94 - 3.31lb						

Condenser Water Consumption	90/32.2 Air Temperature Around Ice Machine Water Temperature °F/°C				
Consumption	50/10.0	70/21.1	90/32.2		
Gal/24 hours	220 490 3700				
Water regulating valve set to maintain 230 PSIG discharge pressure					

Operating Pressures

Air Temp.	Freeze Cycle		Harvest Cycle		
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	
50/10.0	225-235	60-32	150-170	85-100	
70/21.1	225-235	60-33	150-170	85-105	
80/26.7	225-240	65-36	155-175	90-110	
90/32.2	225-240	68-38	155-175	90-110	
100/37.8	235-260	75-40	175-200	100-120	
110/43.3	240-265	85-40	185-205	105-125	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

7-36 Part No. 80-1100-3

Q420/450 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Freeze Time			Harvest
Condenser	Water	Temperature	e °F/°C	Time
°F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	9.7-11.4	10.9-12.8	12.0-14.0	
80/26.7	10.9-12.8	12.3-14.4	13.3-15.6	1-2.5
90/32.2	12.3-14.4	14.1-16.5	15.5-18.0	1-2.5
100/37.8	14.5-17.0	16.5-19.2	18.3-21.3	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	530	480	440		
80/26.7	480	430	400		
90/32.2	430	380	350		
100/37.8	370	330	300		

Based on average ice slab weight of 4.12 - 4.75lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze Cycle		Harvest Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	195-260	45-30	150-170	75-90
70/21.1	200-260	47-33	165-180	80-100
80/26.7	230-265	50-35	165-185	80-100
90/32.2	260-290	55-36	190-210	90-110
100/37.8	290-340	60-38	215-235	105-125
110/43.3	195-260	45-30	235-255	125-140
Suction pressu	ire drops grad	lually through	out the freeze	cycle

Q420/450 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Around Ice	Water	Temperature	e °F/°C	Harvest
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	9.9-11.7	11.4-13.4	12.6-14.8	
80/26.7	10.1-11.9	11.7-13.7	13.0-15.2	1-2.5
90/32.2	10.4-12.2	12.0-14.0	13.3-15.6	1-2.5
100/37.8	10.6-12.5	12.3-14.4	13.7-16.0	
Times in minute	29			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	520	460	420	
80/26.7	510	450	410	
90/32.2	500	440	400	
100/37.8	490	430	390	

Based on average ice slab weight of 4.12 - 4.75 lb. Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine				
Water Consumption	Water Temperature °F/°C				
Consumption	50/10.0	70/21.1	90/32.2		
Gal/24 hours	400 740 2400				
Water regulating valve set to maintain 230 PSIG discharge pressure					

Operating Pressures

Air Temp.	Freeze Cycle		Harvest Cycle	
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	235-245	50-35	165-180	85-100
70/21.1	235-245	50-35	165-180	85-100
80/26.7	235-245	50-35	165-180	85-100
90/32.2	235-245	52-35	165-180	85-100
100/37.8	235-245	52-35	165-185	85-100
110/43.3	240-250	55-36	165-185	85-100
Suction pressure drops gradually throughout the freeze cycle				

Q450 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Harvest		
°F/°C	50/10.0	70/21.1	90/32.2	Time
-20/-28.9 to 70/21.1	10.6-12.5	12.0-14.0	13.3-15.6	
80/26.7	10.9-12.8	12.3-14.4	13.7-16.0	405
90/32.2	11.1-13.1	12.6-14.8	14.1-16.5	1-2.5
100/37.8	12.0-14.0	13.7-16.0	15.5-18.0	
110/43.3	13.3-15.6	15.5-18.0	17.6-20.6	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2	
-20/-28.9 to 70/21.1	490	440	400	
80/26.7	480	430	390	
90/32.2	470	420	380	
100/37.8	440	390	350	
110/43.3	400	350	310	

Based on average ice slab weight of 4.12- 4.75lb

Regular cube derate is 7%

Ratings with JC0495 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle				
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG				
-20/-28.9 to 50/10.0	225-245	50-32	175-190	85-100				
70/21.1	230-250	50-32	175-190	85-100				
80/26.7	240-260	52-32	180-195	85-100				
90/32.2	245-270	54-35	185-200	85-100				
100/37.8	280-310	57-37	190-205	90-105				
110/43.3	290-325	64-39	190-205	95-110				
Suction pressu	re drops grad	lually through	Suction pressure drops gradually throughout the freeze cycle					

Q600 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Temperature	e °F/°C	Harvest
°F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	7.1-8.4	7.8-9.2	8.6-10.1	
80/26.7	7.8-9.2	8.6-10.1	9.5-11.2	1-2.5
90/32.2	8.6-10.1	9.5-11.2	10.4-12.2	1-2.5
100/37.8	9.5-11.2	10.6-12.5	12.0-14.0	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	690	640	590		
80/26.7	640	590	540		
90/32.2	590	540	500		
100/37.8	540	490	440		

Based on average ice slab weight of 4.12- 4.75lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	
50/10.0	195-260	42-22	155-180	75-95	
70/21.1	220-290	44-22	160-185	85-100	
80/26.7	220-305	52-22	160-190	90-110	
90/32.2	250-325	52-23	175-195	95-115	
100/37.8	280-355	54-30	195-210	95-125	
110/43.3	300-385	56-32	200-225	100-135	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

7-38 Part No. 80-1100-3

Q600 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.		Freeze Time)	
Around Ice	Water	Harvest		
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	7.4-8.7	8.2-9.7	9.5-11.2	
80/26.7	7.5-8.9	8.4-9.9	9.7-11.4	1-2.5
90/32.2	7.8-9.2	8.7-10.3	9.9-11.7	1-2.5
100/37.8	7.9-9.4	8.9-10.5	10.1-11.9	
Times in minute	25			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	670	610	540	
80/26.7	660	600	530	
90/32.2	640	580	520	
100/37.8	630	570	510	

Based on average ice slab weight of 4.12 - 4.75 lb Regular cube derate is 7%

Condenser Water	90/32.2 Air Temperature Around Ice Machine Water Temperature °F/°(ine	
Consumption	50/10.0 70/21.1 90/32.2			
Gal/24 hours	600 1250 6800			

Water regulating valve set to maintain 230 PSIG discharge pressure

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle	
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
50/10.0	225-235	46-25	140-184	80-102	
70/21.1	225-235	46-26	148-184	82-104	
80/26.7	225-235	48-26	154-186	86-108	
90/32.2	225-240	48-26	154-190	86-108	
100/37.8	225-245	50-28	162-194	86-112	
110/43.3	225-250	52-28	165-200	86-115	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q600 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Water Temperature °F/°C		
°F/°C	50/10.0	70/21.1	90/32.2	Time
-20/-28.9 to 70/21.1	7.9-9.4	8.9-10.5	9.5-11.2	
80/26.7	8.0-9.4	9.0-10.6	9.6-11.3	1-2.5
90/32.2	8.1-9.5	9.1-10.7	9.7-11.4	
100/37.8	8.4-9.9	9.5-11.2	10.1-11.9	
110/43.3	8.9-10.5	10.1-11.9	10.9-12.8	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	r 50/10.0 70/21.1		90/32.2	
-20/-28.9 to 70/21.1	630	570	540	
80/26.7	625	565	535	
90/32.2	620	560	530	
100/37.8	600	540	510	
110/43.3	570	510	480	

Based on average ice slab weight of 4.12- 4.75 lb
Regular cube derate is 7%
Ratings with JC0895 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
-20/-28.9 to 50/10.0	220-250	42-26	152-170	75-100	
70/21.1	225-260	44-26	155-172	82-100	
80/26.7	245-265	46-26	156-174	82-100	
90/32.2	250-265	48-26	157-174	84-100	
100/37.8	265-295	52-26	158-176	84-100	
110/43.3	300-335	52-28	158-176	84-105	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q800 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Harvest		
°F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	8.9-10.2	9.7-11.1	10.3-11.9	
80/26.7	9.3-10.7	10.2-11.7	10.9-12.5	1-2.5
90/32.2	10.3-11.9	11.4-13.1	12.3-14.1	1-2.5
100/37.8	12.1-13.8	13.3-15.2	14.4-16.5	
Times in minutes				

24 Hour Ice Production

Air Temp.	Wate	°F/°C	
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2
70/21.1	800	740	700
80/26.7	770	710	670
90/32.2	700	640	600
100/37.8	610	560	520

Based on average ice slab weight of 5.75- 6.50 lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Freeze Cycle		t Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
50/10.0	220-280	31-18	135-180	65-90	
70/21.1	220-280	32-18	140-180	70-90	
80/26.7	225-280	36-20	140-180	70-95	
90/32.2	260-295	38-22	150-200	80-100	
100/37.8	300-330	40-24	210-225	80-100	
110/43.3	320-360	44-26	210-240	85-120	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q800 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Around Ice	Water	Temperature	e °F/°C	Harvest	
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	8.7-10.1	9.5-11.0	10.9-12.5		
80/26.7	8.9-10.2	9.7-11.1	11.0-12.7	1-2.5	
90/32.2	9.0-10.3	9.8-11.3	11.2-12.9	1-2.5	
100/37.8	9.1-10.5	10.0-11.5	11.4-13.1		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	810	750	670		
80/26.7	800	740	660		
90/32.2	790	730	650		
100/37.8	780	720	640		

Based on average ice slab weight of 5.75- 6.50lb Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine				
Water Consumption	Water Temperatur		°F/°C		
Consumption	50/10.0	70/21.1	90/32.2		
Gal/24 hours	640 1420 6000				
Water regulating valve set to maintain 230 PSIG discharge pressure					

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle	
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
50/10.0	225-235	33-20	160-185	65-85	
70/21.1	225-235	34-20	165-185	70-85	
80/26.7	225-235	34-20	165-185	70-85	
90/32.2	225-235	36-22	165-185	70-85	
100/37.8	225-235	36-22	165-185	70-85	
110/43.3	225-240	38-24	170-190	75-90	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

7-40 Part No. 80-1100-3

Q800 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Entering	Water	Water Temperature °F/°C			
°F/°C	50/10.0	70/21.1	90/32.2	Time	
-20/-28.9 to 70/21.1	9.5-11.0	10.6-12.2	11.6-13.4		
80/26.7	9.7-11.1	10.8-12.4	11.9-13.6	405	
90/32.2	9.8-11.3	11.0-12.6	12.1-13.8	1-2.5	
100/37.8	10.6-12.2	11.9-13.6	13.2-15.1		
110/43.3	11.9-13.6	13.4-15.4	14.7-16.9		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Wate	°F/°C	
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2
-20/-28.9 to 70/21.1	750	685	630
80/26.7	740	675	620
90/32.2	730	665	610
100/37.8	685	620	565
110/43.3	620	555	510

Based on average ice slab weight of 5.75- 6.50lb

Regular cube derate is 7%

Ratings with JC0895 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Air Town Freeze Cycle		e Harvest Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG
-20/-28.9 to 50/10.0	220-250	30-22	180-200	65-90
70/21.1	225-250	32-22	190-200	70-90
80/26.7	240-260	33-22	190-205	70-90
90/32.2	255-265	34-22	195-205	70-90
100/37.8	275-295	38-24	200-210	70-90
110/43.3	280-320	40-26	200-225	75-100
Suction pressu	ure drops grad	lually through	out the freeze	cycle

Q1000 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Entering	Water	Water Temperature °F/°C			
°F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	9.9-10.6	10.6-11.4	11.3-12.2		
80/26.7	10.2-11.0	11.2-12.0	11.9-12.8	1-2.5	
90/32.2	10.9-11.7	11.9-12.8	12.8-13.7	1-2.5	
100/37.8	12.1-13.0	13.2-14.1	14.2-15.2		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	980	920	870		
80/26.7	950	880	830		
90/32.2	900	830	780		
100/37.8	820	760	710		

Based on average ice slab weight of 7.75 - 8.25lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Freeze Cycle		t Cycle	
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
50/10.0	220-280	38-18	135-180	65-90	
70/21.1	220-280	40-18	140-180	70-90	
80/26.7	225-280	42-20	140-180	70-95	
90/32.2	260-295	42-22	150-200	80-100	
100/37.8	300-330	42-24	210-225	80-100	
110/43.3	320-360	44-24	210-240	85-120	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q1000 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Around Ice	Water Temperature °F/°C			Harvest
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	10.0-10.7	10.6-11.4	12.1-13.0	
80/26.7	10.1-10.9	10.8-11.6	12.3-13.2	1-2.5
90/32.2	10.2-11.0	10.9-11.7	12.5-14.3	1-2.5
100/37.8	10.4-11.1	11.0-11.8	12.6-14.4	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	970	920	820	
80/26.7	960	910	810	
90/32.2	950	900	800	
100/37.8	940	890	790	

Based on average ice slab weight of 7.75- 8.25lb Regular cube derate is 7%

Condenser Water	90/32.2 Air Temperature Around Ice Machine Water Temperature °F/°C					
Consumption						
Consumption	50/10.0	70/21.1	90/32.2			
Gal/24 hours	750 1500 6200					
144		1 1 . 1 . 200 DOIG !! 1				

Water regulating valve set to maintain 230 PSIG discharge pressure

Operating Pressures

e Pres	tion sure SIG	Dische Press	sure IG	Suction Pressure PSIG
36-	-18	160-	185	65-85
38-	-18	165-	185	70-85
5 40-	-18	165-	185	70-85
5 40-	-20	165-	185	70-85
5 40-	-20	165-	185	70-85
) 42-	-20	170-	190	75-90
	5 40 5 40	5 40-20 5 40-20	5 40-20 165- 5 40-20 165-	5 40-20 165-185 5 40-20 165-185

Q1000 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Freeze Time Water Temperature °F/°C			Harvest
Condenser °F/°C	50/10.0	70/21.1	90/32.2	Time
-20/-28.9 to 70/21.1	10.5-11.3	11.3-12.2	12.1-13.0	
80/26.7	10.7-11.5	11.5-12.3	12.3-13.2	4.0.5
90/32.2	10.8-11.6	11.6-12.5	12.5-13.4	1-2.5
100/37.8	11.5-12.3	12.5-13.4	13.4-14.3	
110/43.3	12.3-13.2	13.4-14.3	14.4-15.5	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2	
-20/-28.9 to 70/21.1	930	870	820	
80/26.7	915	860	810	
90/32.2	906	850	800	
100/37.8	860	800	750	
110/43.3	810	750	700	

Based on average ice slab weight of 7.75- 8.25lb
Regular cube derate is 7%
Ratings with JC1095 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
-20/-28.9 to 50/10.0	220-250	40-22	180-200	65-90
70/21.1	225-250	40-22	190-200	70-90
80/26.7	240-260	42-22	190-205	70-90
90/32.2	255-265	44-22	195-205	70-90
100/37.8	275-295	44-24	200-210	70-90
110/43.3	280-320	46-26	200-225	75-100
Suction pressu	re drops grad	lually through	out the freeze	cycle

7-42 Part No. 80-1100-3

Q1300 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Freeze Time Water Temperature °F/°C			Harvest
Condenser	water	Time		
°F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	9.4-10.5	9.9-11.1	10.9-12.2	
80/26.7	9.9-11.1	10.6-11.8	11.6-12.9	1-2.5
90/32.2	11.0-12.3	11.5-12.8	12.8-14.2	1-2.5
100/37.8	12.3-13.7	13.2-14.7	14.7-16.3	
Times in minute	es	•	•	

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	1320	1260	1160		
80/26.7	1260	1190	1100		
90/32.2	1150	1110	1010		
100/37.8	1040	980	890		

Based on average ice slab weight of 10.0- 11.0 lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG
50/10.0	220-280	40-20	140-170	65-80
70/21.1	220-280	40-20	145-170	70-80
80/26.7	220-280	42-22	150-185	70-80
90/32.2	245-300	48-26	160-190	70-85
100/37.8	275-330	50-26	160-210	70-90
110/43.3	280-360	52-28	165-225	75-100
Suction pressu	ure drops grad	lually through	out the freeze	cycle

Q1300 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			Harvest
Around Ice	Water	Water Temperature °F/°C		
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	9.0-10.1	9.8-10.9	11.4-12.6	
80/26.7	9.1-10.1	9.8-11.0	11.6-12.9	1-2.5
90/32.2	9.2-10.3	10.0-11.2	12.0-13.3	1-2.5
100/37.8	9.4-10.5	10.1-11.3	12.2-13.6	
Times in minute	25			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2	
70/21.1	1370	1280	1120	
80/26.7	1360	1270	1100	
90/32.2	1340	1250	1070	
100/37.8	1320	1240	1050	

Based on average ice slab weight of 10.0 - 11.0 lb Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Wate	Water Temperature °F/°C		
Consumption	50/10.0	70/21.1	90/32.2	
Gal/24 hours	1150 2220 7400			
Water regulating valve set to maintain 240 PSIG discharge pressure				

Operating Pressures

Air Temp.	Freeze	Freeze Cycle		t Cycle
Arround Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	235-245	40-18	150-180	70-80
70/21.1	235-245	40-18	150-180	70-80
80/26.7	235-245	40-20	150-180	70-80
90/32.2	235-250	42-20	150-180	70-80
100/37.8	235-255	44-20	150-180	70-80
110/43.3	240-265	46-20	150-180	70-80
Suction pressure drops gradually throughout the freeze cycle				

7-43 Part No. 80-1100-3

Q1300 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Entering	Water	Water Temperature °F/°C			
°F/°C	50/10.0	70/21.1	90/32.2	Time	
-20/-28.9 to 70/21.1	9.9-11.1	10.9-12.2	11.7-13.0		
80/26.7	10.0-11.2	11.0-12.3	11.1-12.4	405	
90/32.2	10.1-11.3	11.1-12.4	10.7-11.9	1-2.5	
100/37.8	10.8-12.0	11.8-13.2	12.8-14.2		
110/43.3	11.7-13.0	12.9-14.3	13.8-15.4		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	denser 50/10.0 70/21.1		90/32.2	
-20/-28.9 to 70/21.1	1260	1160	1090	
80/26.7	1250	1150	1140	
90/32.2	1240	1140	1180	
100/37.8	1170	1080	1010	
110/43.3	1090	1000	940	

Based on average ice slab weight of 10.0- 11.0 lb Ratings with JC1395 condenser, dice or half dice cubes

Operating Pressures

Air Tomp	Freeze Cycle		Harves	t Cycle		
Air Temp. Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG		
-20/-28.9 to 50/10.0	220-250	40-22	135-170	75-95		
70/21.1	240-260	40-22	140-180	80-95		
80/26.7	240-270	41-22	140-190	80-95		
90/32.2	250-290	42-22	140-200	80-95		
100/37.8	280-320	46-22	140-210	80-95		
110/43.3	310-360	48-24	140-220	85-100		
Suction pressu	ure drops grad	Suction pressure drops gradually throughout the freeze cycle				

Q1600 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.					
Entering	Water	Temperature	e °F/°C	Harvest	
°F/°C	50/10.0	70/21.1	90/32.2	Time	
70/21.1	7.2-8.1	8.0-9.0	8.9-9.9		
80/26.7	7.3-8.2	8.1-9.1	9.2-10.2	1-2.5	
90/32.2	7.4-8.2	8.2-9.1	9.6-10.7		
100/37.8	7.4-8.3	8.4-9.4	9.7-10.8		
Times in minute	Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	1650	1510	1390		
80/26.7	1635	1500	1350		
90/32.2	1625	1490	1300		
100/37.8	1620	1450	1290		
70/21.1	1650	1510	1390		
Based on average	Based on average ice slab weight of 13.0 -14.12 lb				

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Water Temperature °F/°C 50/10.0 70/21.1 90/32.2			
Consumption				
Gal/24 hours	1400 2235 6500			
Water regulating valve set to maintain 240 PSIG discharge pressure				

Operating Pressures

Air Temp.	Freeze	Freeze Cycle		t Cycle	
Entering Condenser °F/°C	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	
-20/-28.9 to 50/10.0	235-245	48-24	145-170	70-90	
70/21.1	235-265	52-26	150-175	70-90	
80/26.7	235-270	52-26	150-175	75-95	
90/32.2	235-280	52-28	155-180	75-95	
100/37.8	240-285	52-28	155-180	80-100	
110/43.3	240-290	54-28	155-185	80-100	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

7-44 Part No. 80-1100-3

Q1600 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Water Temperature °F/°C		
°F/°C	50/10.0	70/21.1	90/32.2	Time
-20 to 70 -29 to 21.1	7.5-8.4	8.2-9.2	9.0-10.1	
90/32.2	8.0-8.9	8.6-9.6	9.2-10.3	1 - 2.5
100/37.8	8.4-9.3	9.2-10.2	9.7-10.8	
110/43.3	9.2-10.3	10.0-11.2	10.4-11.6	
Times in minute	es			

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C			
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2	
-20 to 70	1600	1478	1370	
-29 to 21.1	1000	1476	1370	
90/32.2	1523	1425	1340	
100/37.8	1460	1350	1290	
110/43.3	1343	1250	1213	

Based on average ice slab weight of 13.0- 14.12lb Ratings with JC1895 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
-20 to 50/-29 to 10.0	220-255	52-26	100-120	70-85
70/21.1	250-270	56-28	110-120	75-90
80/26.7	250-275	56-28	110-120	75-90
90/32.2	255-285	56-28	110-120	80-90
100/37.8	270-310	56-30	115-130	80-95
110/43.3	305-350	58-32	120-135	80-100
Suction pressu	ure drops grad	lually through	out the freeze	cycle

Q1800 SERIES

Self-Contained Air-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water Temperature °F/°C			Harvest
°F/°C	50/10.0 70/21.1 90/32.2			Time
70/21.1	8.5-9.3	9.4-10.3	9.9-10.9	
80/26.7	9.0-9.9	9.8-10.8	10.5-11.5	1-2.5
90/32.2	9.6-10.5	10.4-11.5	11.1-12.2	1-2.5
100/37.8	10.6-11.6			
Times in minutes				

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	1880	1720	1640		
80/26.7	1780	1650	1560		
90/32.2	1690	1570	1480		
100/37.8	1550	1440	1350		

Based on average ice slab weight of 13.0 - 14.12lb Regular cube derate is 7%

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
50/10.0	220-280	40-20	155-190	60-80
70/21.1	220-280	40-20	160-190	65-80
80/26.7	230-290	42-20	160-190	65-80
90/32.2	260-320	44-22	185-205	70-90
100/37.8	300-360	46-24	210-225	75-100
110/43.3	320-400	48-26	215-240	80-100
Suction pressu	ure drops grad	lually through	out the freeze	cycle

Q1800 SERIES

Self-Contained Water-Cooled

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Around Ice	Water	Temperature	e °F/°C	Harvest
Machine °F/°C	50/10.0	70/21.1	90/32.2	Time
70/21.1	8.7-9.6	9.6-10.5	10.8-11.9	
80/26.7	9.0-9.9	9.6-10.6	10.8-11.9	1-2.5
90/32.2	9.1-10.1	9.7-10.7	10.9-12.0	1-2.5
100/37.8	9.2-10.1 9.8-10.7 11.1-12.1			
Times in minute	25			

rimes in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Around Ice Machine °F/°C	50/10.0	70/21.1	90/32.2		
70/21.1	1840	1690	1520		
80/26.7	1780	1680	1520		
90/32.2	1760	1670	1510		
100/37.8	1750	1660	1490		

Based on average ice slab weight of 13.0- 14.12lb Regular cube derate is 7%

Condenser	90/32.2 Air Temperature Around Ice Machine			
Water Consumption	Water Temperature °F/°C 50/10.0 70/21.1 90/32.2			
Consumption				
Gal/24 hours	2000 2670 7750			
Water regulating	Water regulating valve set to maintain 240 PSIG discharge pressure			

Water regulating valve set to maintain 240 PSIG discharge pressure

Operating Pressures

Air Temp.	Freeze	Cycle	Harves	t Cycle	
Around Ice Machine °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharg e Pressure PSIG	Suction Pressure PSIG	
50/10.0	235-245	36-20	170-190	65-80	
70/21.1	235-245	38-20	170-190	65-80	
80/26.7	235-245	40-20	170-190	65-80	
90/32.2	235-250	42-22	175-190	65-80	
100/37.8	235-255	44-22	175-190	65-80	
110/43.3	235-260	46-22	175-190	65-80	
Suction pressu	Suction pressure drops gradually throughout the freeze cycle				

Q1800 SERIES

Remote

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Freeze Time Water Temperature °F/°C			Harvest
Condenser °F/°C	50/10.0	Time		
-20/-28.9 to 70/21.1	9.1-10.0	9.8-10.8	10.7-11.7	
80/26.7	9.3-10.2	10.1-11.1	10.9-12.0	405
90/32.2	9.5-10.5	10.3-11.4	11.1-12.2	1-2.5
100/37.8	10.1-11.1	11.1-12.2	11.9-13.0	
110/43.3	11.0-12.1			
Times in minute	es			

24 Hour Ice Production

Air Temp.	Wate	Water Temperature °F/°C		
Entering Condenser °F/°C	50/10.0	70/21.1	90/32.2	
-20/-28.9 to 70/21.1	1770	1650	1540	
80/26.7	1735	1615	1510	
90/32.2	1700	1580	1480	
100/37.8	1620	1480	1400	
110/43.3	1500	1380	1320	

Based on average ice slab weight of 13.0 - 14.12lb Regular cube derate is 7% Ratings with JC1895 condenser, dice or half dice cubes

Operating Pressures

Air Temp.	Freeze Cycle		Harves	t Cycle
Entering Condenser °F/°C	Discharg e Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG
-20/-28.9 to 50/10.0	220-250	38-24	160-180	60-80
70/21.1	220-260	40-24	170-180	60-80
80/26.7	250-270	48-24	175-190	70-90
90/32.2	250-280	50-24	180-200	80-90
100/37.8	270-300	52-28	205-215	80-95
110/43.3	300-350	54-28	205-230	80-100
Suction pressu	ure drops grad	lually through	out the freeze	cycle

7-46 Part No. 80-1100-3

Refrigerant Recovery/Evacuation and Recharging

NORMAL SELF-CONTAINED MODEL PROCEDURES

Refrigerant Recovery/Evacuation

Do not purge refrigerant to the atmosphere. Capture refrigerant using recovery equipment. Follow the manufacturer's recommendations.

Important

Manitowoc Ice, Inc. assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

Important

Replace the liquid line drier before evacuating and recharging. Use only a Manitowoc (O.E.M.) liquid line filter drier to prevent voiding the warranty.

CONNECTIONS

- Suction side of the compressor through the suction service valve.
- 2. Discharge side of the compressor through the discharge service valve.

SELF-CONTAINED RECOVERY/EVACUATION

- 1. Place the toggle switch in the OFF position.
- 2. Install manifold gauges, charging cylinder/scale, and recovery unit or two-stage vacuum pump.




Figure 7-14. Recovery/Evacuation Connections

- 3. Open (backseat) the high and low side ice machine service valves, and open high and low side on manifold gauges.
- 4. Perform recovery or evacuation:
 - A. Recovery: Operate the recovery unit as directed by the manufacturer's instructions.
 - B. Evacuation prior to recharging: Pull the system down to 250 microns. Then, allow the pump to run for an additional half hour. Turn off the pump and perform a standing vacuum leak check.

NOTE: Check for leaks using a halide or electronic leak detector after charging the ice machine.

5. Refer to Charging Procedures.

Self-Contained Charging Procedures

Important

The charge is critical on all Manitowoc ice machines. Use a scale or a charging cylinder to ensure the proper charge is installed.

1. Be sure the toggle switch is in the OFF position.




Figure 7-15. Charging Connections

- 2. Close the vacuum pump valve, the low side service valve, and the low side manifold gauge valve.
- 3. Open the high side manifold gauge valve, and backseat the high side service valve.
- 4. Open the charging cylinder and add the proper refrigerant charge (shown on nameplate) through the discharge service valve.
- 5. Let the system "settle" for 2 to 3 minutes.
- 6. Place the toggle switch in the ICE position.
- 7. Close the high side on the manifold gauge set. Add any remaining vapor charge through the suction service valve (if necessary).

NOTE: Manifold gauges must be removed properly to ensure that no refrigerant contamination or loss occurs.

- 8. Make sure that all of the vapor in the charging hoses is drawn into the ice machine before disconnecting the charging hoses.
 - A. Run the ice machine in freeze cycle.
 - B. Close the high side service valve at the ice
 - Open the low side service valve at the ice machine.
 - D. Open the high and low side valves on the manifold gauge set. Any refrigerant in the lines will be pulled into the low side of the system.
 - E. Allow the pressures to equalize while the ice machine is in the freeze cycle.
 - F. Close the low side service valve at the ice machine.

Remove the hoses from the ice machine and install the caps.

7-48 Part No. 80-1100-3

NORMAL REMOTE MODEL PROCEDURES

Refrigerant Recovery/Evacuation

Do not purge refrigerant to the atmosphere. Capture refrigerant using recovery equipment. Follow the manufacturer's recommendations.

Important

Manitowoc Ice, Inc. assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

Important

Replace the liquid line drier before evacuating and recharging. Use only a Manitowoc (O.E.M.) liquid line filter drier to prevent voiding the warranty.

CONNECTIONS

Important

Recovery/evacuation of a remote system requires connections at four points for complete system evacuation. See the drawing on next page.

Make these connections:

- Suction side of the compressor through the suction service valve.
- Discharge side of the compressor through the discharge service valve.
- Receiver outlet service valve, which evacuates the area between the check valve in the liquid line and the pump down solenoid.
- Access (Schrader) valve on the discharge line quickconnect fitting, located on the outside of the compressor/evaporator compartment. This connection evacuates the condenser. Without it, the magnetic check valves would close when the pressure drops during evacuation, preventing complete evacuation of the condenser.

NOTE: Manitowoc recommends using an access valve core removal and installation tool on the discharge line quick-connect fitting. This permits access valve core removal. This allows for faster evacuation and charging, without removing the manifold gauge hose.

REMOTE RECOVERY/EVACUATION

- 1. Place the toggle switch in the OFF position.
- 2. Install manifold gauges, charging cylinder/scale, and recovery unit or two-stage vacuum pump.
- 3. Open (backseat) the high and low side ice machine service valves.
- 4. Open the receiver service valve halfway.
- 5. Open high and low side on the manifold gauge set.
- 6. Perform recovery or evacuation:
 - A. Recovery: Operate the recovery unit as directed by the manufacturer's instructions.
 - B. Evacuation prior to recharging: Pull the system down to 250 microns. Then, allow the pump to run for an additional hour. Turn off the pump and perform a standing vacuum leak check.

NOTE: Check for leaks using a halide or electronic leak detector after charging the ice machine.

7. Refer to Charging Procedures.




Figure 7-16. Recovery/Evacuation Connections

7-50 Part No. 80-1100-3

Remote Charging Procedures

- 1. Be sure the toggle switch is in the OFF position.
- 2. Close the vacuum pump valve, the low and high side service valves (frontseat), and the low side manifold gauge valve.
- Open the charging cylinder and add the proper refrigerant charge (shown on nameplate) into the system high side (receiver outlet valve and discharge lines quick-connect fitting).
- 4. If the high side does not take the entire charge, close the high side on the manifold gauge set, and backseat (open) the low side service valve and receiver outlet service valve. Start the ice machine and add the remaining charge through the low side (in vapor form) until the machine is fully charged.
- 5. Ensure all vapor in charging hoses is drawn into the machine, then disconnect the manifold gauges.

NOTE: Backseat the receiver outlet service valve after charging is complete and before operating the ice machine. If the access valve core removal and installation tool is used on the discharge quick-connect fitting, reinstall the Schraeder valve core before disconnecting the access tool and hose.

- 6. Run the ice machine in freeze cycle.
- 7. Close the high side service valve at the ice machine.
- 8. Open the low side service valve at the ice machine.
- 9. Open the high and low side valves on the manifold gauge set. Any refrigerant in the lines will be pulled into the low side of the system.
- 10. Allow the pressures to equalize while the ice machine is in the freeze cycle.
- 11. Close the low side service valve at the ice machine.
- 12. Remove the hoses from the ice machine and install the caps.




Figure 7-17. Remote Charging Connections

7-52 Part No. 80-1100-3

SYSTEM CONTAMINATION CLEAN-UP

General

This section describes the basic requirements for restoring contaminated systems to reliable service.

Important

Manitowoc Ice, Inc. assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

Determining Severity Of Contamination

System contamination is generally caused by either moisture or residue from compressor burnout entering the refrigeration system.

Inspection of the refrigerant usually provides the first indication of system contamination. Obvious moisture or an acrid odor in the refrigerant indicates contamination.

If either condition is found, or if contamination is suspected, use a Total Test Kit from Totaline or a similar diagnostic tool. These devices sample refrigerant, eliminating the need to take an oil sample. Follow the manufacturer's directions.

If a refrigerant test kit indicates harmful levels of contamination, or if a test kit is not available, inspect the compressor oil.

- Remove the refrigerant charge from the ice machine.
- 2. Remove the compressor from the system.
- 3. Check the odor and appearance of the oil.
- 4. Inspect open suction and discharge lines at the compressor for burnout deposits.
- 5. If no signs of contamination are present, perform an acid oil test.

Check the chart below to determine the type of cleanup required.

Contamination/Cleanup Chart			
Symptoms/Findings	Required Cleanup Procedure		
No symptoms or suspicion of contamination	Normal evacuation/recharging procedure		
Moisture/Air Contamination symptoms			
Refrigeration system open to atmosphere for longer than 15 minutes	Mild contouring tion along up proceedure		
Refrigeration test kit and/or acid oil test shows contamination	Mild contamination cleanup procedure		
Leak in water-cooled condenser			
No burnout deposits in open compressor lines			
Mild Compressor Burnout symptoms			
Oil appears clean but smells acrid	Mild contamination cleanup procedure		
Refrigeration test kit or acid oil test shows harmful acid content	Mild contamination cleanup procedure		
No burnout deposits in open compressor lines			
Severe Compressor Burnout symptoms			
Oil is discolored, acidic, and smells acrid	Severe contamination cleanup procedure		
Burnout deposits found in the compressor and lines, and in	Joevere contamination cleanup procedure		
other components			

Mild System Contamination Cleanup Procedure

- 1. Replace any failed components.
- 2. If the compressor is good, change the oil.
- 3. Replace the liquid line drier.

NOTE: If the contamination is from moisture, use heat lamps during evacuation. Position them at the compressor, condenser and evaporator prior to evacuation. Do not position heat lamps too close to plastic components, or they may melt or warp.

Important

Dry nitrogen is recommended for this procedure. This will prevent CFC release.

- 4. Follow the normal evacuation procedure, except replace the evacuation step with the following:
 - A. Pull vacuum to 1000 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psi.
 - Pull vacuum to 500 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psi.
 - C. Change the vacuum pump oil.
 - D. Pull vacuum to 250 microns. Run the vacuum pump for 1/2 hour on self-contained models, 1 hour on remotes.

NOTE: You may perform a standing vacuum test to make a preliminary leak check. You should use an electronic leak detector after system charging to be sure there is no leak.

- 5. Charge the system with the proper refrigerant to the nameplate charge.
- 6. Operate the ice machine.

Severe System Contamination Cleanup Procedure

- 1. Remove the refrigerant charge.
- 2. Remove the compressor.
- Disassemble the harvest solenoid valve. If burnout deposits are found inside the valve, install a rebuild kit, and replace manifold strainer, TXV and harvest pressure regulating valve.
- Wipe away any burnout deposits from suction and discharge lines at compressor.
- 5. Sweep through the open system with dry nitrogen.

Important

Refrigerant sweeps are not recommended, as they release CFC's into the atmosphere.

- 6. Install a new compressor and new start components.
- Install a suction line filter-drier with acid and moisture removal capability (P/N 89-3028-3). Place the filter drier as close to the compressor as possible.
- 8. Install an access valve at the inlet of the suction line drier.
- 9. Install a new liquid line drier.

Continued on next page ...

7-54 Part No. 80-1100-3

10. Follow the normal evacuation procedure, except replace the evacuation step with the following:

Important

Dry nitrogen is recommended for this procedure. This will prevent CFC release.

- A. Pull vacuum to 1000 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psi.
- B. Change the vacuum pump oil.
- Pull vacuum to 500 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psi.
- D. Change the vacuum pump oil.
- E. Pull vacuum to 250 microns. Run the vacuum pump for 1/2 hour on self-contained models, 1 hour on remotes.

NOTE: You may perform a standing vacuum test to make a preliminary leak check. You should use an electronic leak detector after system charging to be sure there is no leak.

- 11. Charge the system with the proper refrigerant to the nameplate charge.
- 12. Operate the ice machine for one hour. Then, check the pressure drop across the suction line filter-drier.
 - A. If the pressure drop is less than 1 psi, the filterdrier should be adequate for complete cleanup.
 - B. If the pressure drop exceeds 1 psi, change the suction line filter-drier and the liquid line drier. Repeat until the pressure drop is acceptable.
- Operate the ice machine for 48-72 hours. Then, remove the suction line drier and change the liquid line drier.
- 14. Follow normal evacuation procedures.

REPLACING PRESSURE CONTROLS WITHOUT REMOVING REFRIGERANT CHARGE

This procedure reduces repair time and cost. Use it when any of the following components require replacement, and the refrigeration system is operational and leak-free.

- Fan cycle control (air-cooled only)
- Water regulating valve (water-cooled only)
- High pressure cut-out control
- · High side service valve
- · Low side service valve

Important

This is a required in-warranty repair procedure.

- 1. Disconnect power to the ice machine.
- Follow all manufacturer's instructions supplied with the pinch-off tool. Position the pinch-off tool around the tubing as far from the pressure control as feasible. (See the figure on next page.) Clamp down on the tubing until the pinch-off is complete.

A Warning

Do not unsolder a defective component. Cut it out of the system. Do not remove the pinch-off tool until the new component is securely in place.

- 3. Cut the tubing of the defective component with a small tubing cutter.
- 4. Solder the replacement component in place. Allow the solder joint to cool.
- 5. Remove the pinch-off tool.
- Re-round the tubing. Position the flattened tubing in the proper hole in the pinch off tool. Tighten the wingnuts until the block is tight and the tubing is rounded. (See the drawing on next page.)

NOTE: The pressure controls will operate normally once the tubing is re-rounded. Tubing may not re-round 100%.




Figure 7-18. Using Pinch-Off Tool

7-56 Part No. 80-1100-3

FILTER-DRIERS

The filter-driers used on Manitowoc ice machines are manufactured to Manitowoc specifications.

The difference between Manitowoc driers and off-theshelf driers is in filtration. Manitowoc driers have dirtretaining filtration, with fiberglass filters on both the inlet and outlet ends. This is very important because ice machines have a back-flushing action which takes place during every harvest cycle.

These filter-driers have a very high moisture removal capability and a good acid removal capability.

The size of the filter-drier is important. The refrigerant charge is critical. Using an improperly sized filter-drier will cause the ice machine to be improperly charged with refrigerant.

Listed below are the recommended O.E.M. field replacement driers:

Model	Drier Size	End Connection Size	Part Number
Self-Contained Air and Water Cooled Q200 /Q280/Q320 Q370/Q420/Q450 Q600/Q800/Q1000	UK-032S	1/4"	89-3025-3
Remote Air Cooled Q450/Q600 Q800/Q1000	UK-083S	3/8"	89-3027-3
All Condenser Type Q1300/Q1600 Q1800	UK-083S	3/8"	89-3027-3
Suction Filter	UK-165S	5/8"	89-3028-3
Suction Filter used when cleaning up severely contaminated systems			

Important

Driers are covered as a warranty part. The drier must be replaced any time the system is opened for repairs.

TOTAL SYSTEM REFRIGERANT CHARGES

Important

This information is for reference only. Refer to the ice machine serial number tag to verify the system charge. Serial plate information overrides information listed on this page.

Series	Version	Charge	
Q200	Air-Cooled	18 oz.	
	Water-Cooled	15 oz.	
Q210	Air-Cooled	15 oz	
	Water-Cooled	11 oz	
Q280	Air-Cooled	18 oz	
	Water-Cooled	15 oz	
Q320	Air-Cooled	20 oz.	
	Water-Cooled	16 oz.	
Q370	Air-Cooled	20 oz.	
	Water-Cooled	17 oz.	
Q420/Q450	Air-Cooled	24 oz.	
	Water-Cooled	22 oz.	
	Remote	6 lb.	
	Air-Cooled	28 oz.	
Q600	Water-Cooled	22 oz.	
	Remote	8 lb.	
Q800	Air-Cooled	36 oz.	
	Water-Cooled	25 oz.	
	Remote	8 lb.	
Q1000	Air-Cooled	38 oz.	
	Water-Cooled	32 oz.	
	Remote	9.5 lb.	
Q1300	Air-Cooled	48 oz.	
	Water-Cooled	44 oz.	
	Remote	12.5 lb. *	
Q1600	Water-Cooled	46 oz.	
	Remote	15 lb.*	
Q1800	Air-Cooled	56 oz.	
	Water-Cooled	46 oz.	
	Remote	15 lb.*	

*For remote line sets with lengths between 50' and 100' refer to chart on Page 2-13

NOTE: All ice machines on this list are charged using R-404A refrigerant.

REFRIGERANT DEFINITIONS

Recover

To remove refrigerant, in any condition, from a system and store it in an external container, without necessarily testing or processing it in any way.

Recycle

To clean refrigerant for re-use by oil separation and single or multiple passes through devices, such as replaceable core filter-driers, which reduce moisture, acidity and particulate matter. This term usually applies to procedures implemented at the field job site or at a local service shop.

Reclaim

To reprocess refrigerant to new product specifications (see below) by means which may include distillation. A chemical analysis of the refrigerant is required after processing to be sure that product specifications are met. This term usually implies the use of processes and procedures available only at a reprocessing or manufacturing facility.

Chemical analysis is the key requirement in this definition. Regardless of the purity levels reached by a reprocessing method, refrigerant is not considered "reclaimed" unless it has been chemically analyzed and meets ARI Standard 700 (latest edition).

New Product Specifications

This means ARI Standard 700 (latest edition). Chemical analysis is required to assure that this standard is met.

7-58 Part No. 80-1100-3

REFRIGERANT RE-USE POLICY

Manitowoc recognizes and supports the need for proper handling, re-use, and disposal of, CFC and HCFC refrigerants. Manitowoc service procedures require recapturing refrigerants, not venting them to the atmosphere.

It is not necessary, in or out of warranty, to reduce or compromise the quality and reliability of your customers' products to achieve this.

Important

Manitowoc Ice, Inc. assumes no responsibility for use of contaminated refrigerant. Damage resulting from the use of contaminated, recovered, or recycled refrigerant is the sole responsibility of the servicing company.

Manitowoc approves the use of:

1. New Refrigerant

· Must be of original nameplate type.

2. Reclaimed Refrigerant

- Must be of original nameplate type.
- Must meet ARI Standard 700 (latest edition) specifications.

3. Recovered or Recycled Refrigerant

- Must be recovered or recycled in accordance with current local, state and federal laws.
- Must be recovered from and re-used in the same Manitowoc product. Re-use of recovered or recycled refrigerant from other products is not approved.
- Recycling equipment must be certified to ARI Standard 740 (latest edition) and be maintained to consistently meet this standard.
- Recovered refrigerant must come from a "contaminant-free" system. To decide whether the system is contaminant free, consider:
 - Type(s) of previous failure(s)
 - Whether the system was cleaned, evacuated and recharged properly following failure(s)
 - Whether the system has been contaminated by this failure
 - Compressor motor burnouts and improper past service prevent refrigerant re-use.
 - Refer to "System Contamination Cleanup" to test for contamination.

4. "Substitute" or "Alternative" Refrigerant

- Must use only Manitowoc-approved alternative refrigerants.
- Must follow Manitowoc-published conversion procedures.

HFC REFRIGERANT QUESTIONS AND ANSWERS

Manitowoc uses R-404A and R-134A HFC refrigerants with ozone depletion potential (ODP) factors of zero (0.0). R-404A is used in ice machines and reach-in freezers and R-134A is used in reach-in refrigerators.

- 1. What compressor oil does Manitowoc require for use with HFC refrigerants?
 - Manitowoc products use Polyol Ester (POE) type compressor oil. It is the lubricant of choice among compressor manufacturers.
- 2. What are some of the characteristics of POE oils? They are hygroscopic, which means they have the ability to absorb moisture. POE oils are 100 times more hygroscopic than mineral oils. Once moisture is absorbed into the oil, it is difficult to remove, even with heat and vacuum. POE oils are also excellent solvents, and tend to "solvent clean" everything inside the system, depositing material where it is not wanted.
- 3. What do these POE oil characteristics mean to me?

You must be more exacting in your procedures. Take utmost care to prevent moisture from entering the refrigeration system. Refrigeration systems and compressors should not be left open to the atmosphere for more than 15 minutes. Keep oil containers and compressors capped at all times to minimize moisture entry. Before removing the system charge to replace a faulty component, be sure you have all of the needed components at the site. Remove new system component plugs and caps just prior to brazing. Be prepared to connect a vacuum pump immediately after brazing.

- 4. Are there any special procedures required if a POE system is diagnosed with a refrigerant leak?
 - For systems found <u>with</u> positive refrigerant system pressure, no special procedures are required.
 - For systems found <u>without</u> any positive refrigerant pressure, assume that moisture has entered the POE oil. After the leak is found and repaired, the compressor oil must be changed. The compressor must be removed and at least 95% of the oil drained from the suction port of the compressor. Use a "measuring cup" to replace the old oil with exactly the same amount of new POE oil, such as Mobil EAL 22A.
 - Remember, care must be taken to prevent moisture from getting into the refrigeration system during refrigeration repairs.
- 5. How do I leak-check a system containing HFC refrigerant?
 - Use equipment designed for HFC detection. Do not use equipment designed for CFC detection. Consult leak detection equipment manufacturers for their recommendations. Also, standard soap bubbles will work with HFC refrigerants.
- 6. Does Manitowoc use a special liquid line filter-drier with HFC refrigerants?
 - Yes. Manitowoc uses an ALCO "UK" series filterdrier for increased filtration and moisture removal. During a repair, Manitowoc recommends installing the drier just before hooking up a vacuum pump.

Continued on next page ...

7-60 Part No. 80-1100-3

- 7. Is other special equipment required to service HFC refrigerants?
 - No. Standard refrigeration equipment such as gauges, hoses, recovery systems, vacuum pumps, etc., are generally compatible with HFC refrigerants. Consult your equipment manufacturer for specific recommendations for converting existing equipment to HFC usage. Once designated (and calibrated, if needed) for HFC use, this equipment should be used specifically with HFC refrigerants only.
- 8. Do I have to recover HFC refrigerants?
 Yes. Like other refrigerants, government regulations require recovering HFC refrigerants.
- 9. Will R-404A or R-134A separate if there is a leak in the system?
 - No. Like R-502, the degree of separation is too small to detect.
- 10. How do I charge a system with HFC refrigerant? The same as R-502. Manitowoc recommends charging only liquid refrigerant into the high side of the system.

THIS PAGE INTENTIONALLY LEFT BLANK

7-62 Part No. 80-1100-3

THIS PAGE INTENTIONALLY LEFT BLANK