



Tempest®2400

2-Channel Wireless Intercom Reference Manual





Thank you from Clear-Com

We at Clear-Com want to thank you for purchasing a Tempest® 2400 Wireless Intercom System. We have made every effort to build a reliable, intuitive wireless intercom system that easily interfaces with your existing equipment and provides the same functionality that you expect from your hard-wired intercom equipment.

One of our goals in the design of Tempest was that it should work the way you think it should work – that is, it should be intuitive and similar to other equipment that you may already use. You will be able to begin using your new Tempest Wireless Intercom System with nothing more than the Quick Start Guide. However, to fully benefit from the available features, please read this manual carefully.

We want Tempest to make your job easier and your experience to be positive. To successfully familiarize yourself with the many diverse and powerful features Tempest offers, it is crucial that you acquaint yourself with the manual. Your time spent will help you get the most from your Tempest Wireless Intercom by making setup easy and interfacing to your existing equipment fast.

We are committed to providing you with a high quality product that will deliver years of trouble-free service. Should you experience any problem with your Tempest Wireless equipment, whether it is a warranted problem or service after you have owned the system for several years, we will be there to take care of you.

Thank you for choosing Clear-Com for your wireless intercom needs.

Document Reference

Tempest®2400 Wireless Intercom System 2-Channel Reference Manual

Part Number 810516Z Rev E

Legal Disclaimers

Copyright © 2012 HM Electronics, Inc.

All rights reserved.

Clear-Com and the Clear-Com logo are trademarks or registered trademarks of HM Electronics, Inc. Tempest® is a registered trademark of CoachComm, LLC.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of the agreement.

The product described in this document is distributed under licenses restricting its use, copying, distribution, and decompilation/ reverse engineering. No part of this document may be reproduced in any form by any means without prior written authorization of Clear-Com, an HME Company.

Clear-Com Offices are located in California, USA; Cambridge, UK; Montreal, Canada; and Beijing, China. Specific addresses and contact information can be found on Clear-Com's corporate website:

Website: www.clearcom.com

Clear-Com Contacts

Americas and Asia-Pacific Headquarters

California, United States

Tel: +1.510.337.6600

Email: CustomerServicesUS@clearcom.com

Europe, Middle East, and Africa Headquarters

Cambridge, United Kingdom

Tel: +44 1223 815000

Email: SalesSupportEMEA@clearcom.com

Canada Office

Quebec, Canada

Tel: +1 (450) 653-9669

China Office

Beijing Representative Office

Beijing, P.R.China

Tel: +8610 65811360/65815577

Table of Contents

Important Safety Instructions	1
A/C Power Warning	2
Battery Safety	3
Maintenance and Care	4
Quick Start Guide	6
What You Will Need.....	6
Theory of Operation	8
Accessory Items You May Require	11
BaseStation Overview	12
Front Panel Left.....	12
Front Panel Right	14
Rear Panel Left.....	16
Rear Panel Right.....	17
BeltStation Overview.....	19
Transceiver Controls	22
BaseStation Setup	23
Steps to Setup the BaseStation.....	23
Choose a Location.....	23
Remote Transceiver	28
Setup the Transceiver	28
Configure the BaseStation	30
Using the Front Panel Controls	30
Adjust Sidetone.....	31
Selecting a Frequency Band.....	32
Network Number and Lockout Key.....	33
Set Display Mode to Static or Dynamic.....	35
Name Each Station.....	35
BaseStation Headset Connection and Controls	36
BeltStation Setup	41
Steps to Setup the BeltStations	42
Battery Selection and Installation	42
Charging the Lithium-Polymer Battery	43
Pairing with a BaseStation	44
Seamless Roaming - BeltStation Configuration.....	48
Wireless ISO.....	48
Wired Intercom Interface to the BaseStation	50
Controls	51
4-Wire (Matrix) Intercom Interface	52
2-Wire (Party-Line) Interface	53
Modes of Operation	57
Normal Mode	57
Shared Mode	57
Split Mode	58
Connecting Multiple BaseStations	59
Audio Connections for Multiple BaseStations	60
Accu-Sync.....	62
ZSync Technology.....	63
Master Mode	65
Special RF Considerations with Multiple BaseStations	66
Seamless Roaming.....	68
Pre-Requisites.....	68
Implementation	69
How Do I ...?	70
Remove Batteries from BeltStations	70
Install the Rechargeable Battery.....	70
Charge the Battery.....	70
Install AA Alkaline Batteries	70
Use the 5-Bay Battery Charger.....	70

Navigate the BaseStation Menu	70
Navigate the BeltStation Menu.....	70
Adjust Min/Max BeltStation Volume Levels	71
Configure Stage Announce and SA Relay	71
Configure Relays for Individual BeltStations	72
Use the Transceiver	72
Update the Firmware (with CodeUpdater)	73
Troubleshooting	74
BaseStation	74
BeltStation	76
Tempest Remote Transceiver	77
Tempest Part Numbers	79
2.4 GHz System Specifications	81
BeltStation Specifications	83
Remote Transceiver Specifications	83
Glossary	85
Technical Support	91
Tempest Block Diagram	94
Index	96

Important Safety Instructions

The word “Caution” is the lowest of the three signal words (Caution, Warning and Danger), with “Danger” being the highest. Therefore, whenever the word “Caution” is used, it may be replaced with either of the higher rated signal words: “Warning” or “Danger.”

- a) DANGER – indicates a situation which, when not avoided, results in death or severe injury;
- b) WARNING – indicates a situation which, when not avoided, has the potential to result in death or severe injury;
- c) CAUTION – indicates a situation which, when not avoided, results or has the potential to result in minor injury.

- 1. Read these instructions.**
- 2. Follow all instructions.**
- 3. Heed all warnings.**
- 4. Keep these instructions.**

WARNING – To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Do not use this apparatus near water.

Do not expose the apparatus to dripping or splashing. Do not place objects filled with liquids, such as vases, on the apparatus.

The BaseStation shall be connected to a main socket outlet having a protective earthing connection.

Install the BaseStation so that the appliance coupler (AC power inlet) is readily accessible and operable. Clean only with a dry cloth.

Install in accordance with manufacturer’s instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Do not defeat the safety purpose of the polarizing or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, for example if the power-supply cord has been damaged, liquid has been spilled or objects have fallen into the apparatus, or if the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

A/C Power Warning



Users should exercise extreme care when working with electricity. Additional care should be used when working with electricity outdoors in inclement weather. When working outdoors or near water, always connect the system into a ground-fault interrupting circuit.

There are no user-serviceable parts inside the Tempest BaseStation, Transceiver, or BeltStation. Opening the case may expose dangerous electrical components, and will void the warranty.



ALERT SYMBOL – Indicates important information.



CAUTION SYMBOL – Indicates a potential to damage equipment.



DANGER SYMBOL – indicates a potential safety hazard.

Battery Safety

Battery Transportation

Rechargeable lithium batteries are subject to special regulation by U.S. and International laws, particularly regarding transportation on passenger aircraft. However, individual batteries installed in consumer electronics are not restricted, provided there are only the correct numbers and types of batteries as may be needed to operate the electronic equipment.



Your Tempest Wireless Intercom System includes rechargeable lithium-polymer batteries that power the BeltStations. To ensure that there is no violation of U.S. or International laws, and to ensure your own safety, always:

- Transport rechargeable lithium batteries installed in the equipment they are intended to power.
- Transport spare batteries in a padded case, separated from one another.
- Never transport your rechargeable lithium batteries bundled together.
- Never transport more than 12 lithium batteries in a single package.

Lithium-polymer batteries include a chemistry that is intended to overcome the dangers associated with lithium ion batteries. In addition, the batteries that accompany your Tempest Wireless system include protective circuits to further reduce the possibility of a dangerous reaction associated with charging or discharging beyond safe limits. With reasonable care you can expect many years of safe and reliable power from your batteries.

Tempest batteries are not subject to transport regulations of dangerous goods because they fulfill the following regulatory provisions:

- » ADR 188
- » IATA A45
- » IMDG 188

Battery Storage

Long-term storage of batteries at maximum charge can result in permanent loss of capacity.

For long term storage of batteries, charge/discharge the batteries to approximately 60% of capacity. Batteries stored for longer than one year should be recharged to 60% annually.

Trickle charging is not recommended due to the very low self discharge rate of the batteries.

As with all batteries:

- Do not burn.
- Do not expose batteries to excessive heat such as sunshine, fire or other heat sources.
- CAUTION – Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Properly dispose of used batteries promptly.
- Keep away from children.

Maintenance and Care

Cleaning

Generally, the Tempest Wireless hardware should be cleaned only with a dry cloth. A soft cloth with rubbing alcohol may be used to wipe the units if needed. Never spray solvents or chemicals onto the units.

Because of Tempest's weather resistant design, it is not highly susceptible to dust or airborne contaminants. However, all electronic devices can be susceptible to particulate contamination. If exposed to an extremely dusty environment, contact an authorized Tempest service center for internal cleaning.

Temperature and Humidity

Ideally, all electronics should be stored and used in a controlled environment with moderate temperature and humidity. Tempest components are designed to be very durable, and can tolerate a wide range of environmental conditions.

Install the BaseStation in a location where it will not be exposed to extreme weather conditions. Protect the unit against dust or moisture. Always protect any AC power connections from the elements with safety in mind.

For more extreme environmental conditions, the BaseStation can remain in a secure location with antennas for the BaseStation located remotely and connected by low-loss 50 ohm coax cable, or the optional Remote Transceiver can be used.

The Tempest Remote Transceiver is weather resistant, with gaskets intended to prevent moisture entry from the top and sides. The CAT-5 cable connection on the bottom is not water tight. If it is to be used in an environment subject to blowing rain, snow, fog or high humidity, protect the transceiver with a cover that will not interfere with the RF.

The BeltStations are designed to work wherever people work. While the BeltStation design is weather resistant, the headset XLR connector on the bottom is not watertight. BeltStations should not be submerged in liquids. Protect the battery compartment from water when changing batteries. The battery compartment offers a route to the electronic circuitry.

[This page intentionally left blank]

Quick Start Guide

What You Will Need

BaseStation

- » Power cord
- » One BaseStation antenna
- » 3.5mm male-to-male mini-stereo pairing cable

BeltStations

- » Up to 5 per BaseStation
- » Lithium-Polymer battery and
- » Charger - 1 per BeltStation


Headsets (customer supplied)

- » 1 per BeltStation
- » 1 per BaseStation



1. Connect a whip antenna onto the back of the BaseStation.

Select a suitable location for the BaseStation. Tempest is a radio system, broadcasting and receiving RF signals that are affected by physical and electronic barriers.



The antenna should be located as high as possible and away from all obstructions. When using a whip (omni-directional) antenna, select a location as close as possible to the center of the area you want to cover.

Use alternative antenna options when the BaseStation is in a rack or other metal structure, or stacked with other gear. Remote location antenna placement of up to 1,500 ft. can be achieved using the Tempest Remote Transceiver. See the user manual for more details about antenna placement, recommended cable types, and other antenna options.

2. Connect the power cord and Power On the BaseStation.


3. Install Batteries in BeltStations

Install the Lithium-Polymer battery in each BeltStation. Be certain that the gold contacts on the battery touch the contacts in the battery compartment. The battery is shipped with a partial charge, so charging will be necessary before maximum run time will be achieved.

OR

Insert (3) AA alkaline batteries in the battery compartment. Always replace the battery cover.



To power ON the BeltStation, press and hold the power button for approximately two seconds. The display will indicate "None Selected." Turn the power OFF by holding the power button for four seconds.



4. Pair BeltStations to the BaseStation

Pairing is a programming process that allows a BaseStation and BeltStation to recognize each other.

- » Confirm that the BaseStation is powered ON.
- » Confirm that the BeltStation is powered OFF.
- » Connect the Pairing Cable from the BaseStation to a BeltStation.
- » Power ON the BeltStation and watch the BeltStation display for “Pairing Complete.”
- » BeltStation status will become visible on the BaseStation display.
- » Repeat with each BeltStation.



5. Connect Headsets to BeltStations


Plug a headset into each BeltStation, and the BaseStation if desired.

6. Operation

Select a channel on the BeltStations by pressing the CH A or CH B control.

Press the TALK button. A quick press latches the Talk button for “Hands Free” operation. Press and hold the Talk button for more than two seconds while you talk and the button will release in a Push-To-Talk manner.

Set the volume by rotating the CH A or CH B control.




You may confirm BeltStation operation on the BaseStation Operation screen. There is a section for each BeltStation. In this illustration, each BeltStation is set to talk on channel A and listen on channels A & D, with only three BeltStations in operation.

A headset may be connected to the front of the Base Station. Activate by pressing the TALK button. Select a channel by pressing the volume knob.

Refer to the user manual for detailed instructions regarding:

- » Country limitation on 2.4GHz RF spectrum.
- » Adjusting the Network Number and Lockout Key.
- » Assigning names for equipment.
- » Charging batteries.

Theory of Operation



The above illustrations show the theory of operation for both the 4-channel (dual antenna) and 2-channel (single antenna) models of Tempest. The 2-channel model lacks some of the diversity characteristics found in the 4-channel model. Tempest uses Frequency Hopping Spread Spectrum (FHSS), Time Division Multiple Access (TDMA), and 2xTX technology. For example, on Frequency 1 the BaseStation and each BeltStation take turns broadcasting, each with its own time slot to send audio data (TDMA). The total time for one cycle is 5 milliseconds (1/200 second). The BaseStation and all BeltStations hop (FHSS) to a different predetermined frequency and the same audio data is sent again, but on a new frequency and on a different BaseStation antenna (2xTX). Therefore, each receiver has two opportunities to receive the audio data. Duplicate data is discarded by the receiver and the process starts over with the next packet of audio data.

Tempest is a DSP (Digital Signal Processor) based, full duplex, wireless intercom system. It is a digital, point-to-point communications system, operating in 80MHz of spectrum in the 2.4GHz ISM frequency band. This band allows users to operate with no license requirements in most locations. The world-wide acceptance of the 2.4GHz band makes Tempest ideal for traveling users.

The 2.4GHz band offers many benefits. There are, however, a wide variety of technologies and users competing for clear spectrum in this limited band. Tempest utilizes patented and proprietary technologies to ensure a robust and reliable RF link under a wide variety of physical and RF environments. This level of reliability is the most important attribute of any wireless system.

Tempest utilizes proprietary, Frequency Hopping Spread Spectrum (FHSS) technology that has seven U.S. patents. Multiple BeltStation access is achieved by implementing Time Domain Multiple Access (TDMA) with Frequency Shift Keying (FSK) modulation. Tempest uses an Algebraic Code - Excited Linear Prediction (A-CELP) voice compression algorithm to reduce the bandwidth necessary for transmission and yet maintain the highest possible voice intelligibility. In addition, this algorithm utilizes advanced lost packet masking technology, which greatly reduces the affect of packet loss, possible in all Digital RF transmission schemes. The loss of audio packets is managed by the algorithm to reduce the possibility of detecting a loss of audio.

In the 2.4GHz RF band multipath interference occurs frequently. The Tempest RF scheme is dramatically enhanced with the addition of proprietary 2xTX™ technology that transmits each data packet twice. This technique reduces spectral efficiency by half, but greatly increases audio intelligibility by reducing the Effective Packet Error Rate (EPER) by orders of magnitude.

The system transmits packet data every 5ms and then “hops” or changes frequency. The sequence of frequency changes is controlled by a predetermined hopping pattern. Each hopping pattern is optimized such that any new frequency has a quasi-orthogonal relationship to the last operating frequency. This quasi-orthogonal frequency relationship ensures maximum frequency separation between any two consecutive hops. Because of this, if an interfering source is present in one area of the operational band, and interferes on a particular hop, the next hop will be in a clear area of the spectrum with the best possible chance of transmission success.

With 2xTX technology, each audio packet is transmitted twice, each on one of two consecutive hops. The loss of one packet transmission in a harsh RF environment is common. However, because of the quasi-orthogonal frequency relationship of the consecutive redundant packet transmission, the potential for loss of any single audio packet (2 consecutive data packet transmissions) is dramatically reduced. In addition, each packet transmission is sent out from different antennas. This unique approach enables Tempest to utilize spatial diversity, frequency diversity, time diversity and polarization diversity. The 2-channel product does not operate with spatial or polar diversity due to the fact it uses a single antenna during operation.

Transmission redundancy and the incorporation of various diversity techniques provide an RF system that is robust and reliable under greatly varying operational conditions. Because of this inherent design, Tempest delivers superior operational range and greater levels of interference and multipath fade rejection. Covering extremely large areas or multiple coverage locations can be problematic with traditional wireless intercom systems. Tempest utilizes different roaming features that allow it to “roam” from one coverage zone to another. When a different BaseStation is selected, the hopping pattern and key code of the BeltStation is synchronized to the selected BaseStation and the BeltStation logs into the BaseStation.

Audio latency is a critical factor in all digital systems. The hop duration in Tempest is intentionally kept very short - under 5ms. This short hop duration limits the amount of data that may be lost in any one hop. More importantly, it reduces system latency, which can cause undesirable echo. Total one-way (BeltStation to BaseStation) system latency is less than 50ms.

Even with this short system latency, unwanted and distracting echo will occur when interfacing with hardwired party-line intercom systems unless echo-reduction technology is implemented. Echo is primarily the result of inefficiencies in the conversion of the two-wire signal. This condition exists in analog systems as well, but it does not cause unwanted echo because there is no system latency delay. Tempest uses advanced echo-cancellation algorithms to eliminate this echo.

Wireless intercom systems are often used in high-noise environments that require special design consideration for effective operation. Tempest operates extremely well even in very high ambient noise levels. This is primarily due to specific design criteria which allow Tempest to achieve an audio dynamic range of greater than 94dB. This is more than double that of most other digital wireless communication systems. This design makes Tempest ideal for use at sporting venues, concerts and other events where unwanted noise levels are high.

Tempest offers a host of features and technology to ensure that it performs well in almost all production environments virtually anywhere in the world with no licensing requirements or fees.

What's In The Box

BaseStation

- BaseStation
- AC Power Cord
- (1) Whip Antenna ½ Wave
- Pairing Cable
- USB-A to USB-B Cable
- USB-A to Mini-USB Cable
- Documentation CD
- Quick Start Guide
- BaseSync Cable

BeltStation

- BeltStation
- Lithium-Polymer Rechargeable Battery
- Battery Charger/Power Supply

Remote Transceiver

- Remote Transceiver
- CAT-5 Cable for BaseStation Connection - 15 Feet
- (2) Whip Antenna ½ Wave
- Mounting Bracket
- Screws for Mounting Bracket (2)

Accessory Items You May Require

Headsets

A Headset is required for each user (XLR-4F connectors).

Headsets may use Electret or Dynamic microphones. Most major brand headsets that have the correct XLR-4F connector should be compatible, requiring nothing more than a simple Mic Gain adjustment.



DC Power Input Cable

To power the Tempest BaseStation via DC power (Battery) instead of AC power, you will need to provide a DC Power input Cable.

RF Cable to Remote Antennas

If you plan to remotely locate your antennas to improve antenna positioning and maximize range, you must provide high quality 50 ohm RF cables with RP-TNC connectors.

CAT-5 Cable for Remote Transceiver

If you plan to locate the Remote Transceiver more than 15 feet from the Tempest BaseStation, you will need to provide a longer CAT-5 cable. The maximum CAT-5 cable length recommended is 1,500 feet.

BaseSync DE-9 Cable(s)

If you use multiple BaseStations to use Accu-Sync BaseStation synchronization, you will need to provide one Accu-Sync DE-9 cable per additional BaseStation. You cannot sync Tempest 2.4 GHz and 900 MHz models together.

Connections to the Hardwired Intercom

XLR-3M/F for 2-Wire

If you plan to connect the Tempest BaseStation to external 2-Wire party-line intercom systems, you will need to provide the appropriate 3-PIN XLR cabling.

RJ-45 Connector Cable for 4-Wire

If you plan to connect the Tempest BaseStation to external Clear-Com 4-Wire intercom systems, you will need to provide the appropriate cabling.

RJ-45 to RJ-12 Adapter

If you plan to connect to an RTS 4W system, you will need adapters.

Auxiliary IN/OUT ¼" Tip/Ring/Sleeve Cable

If you plan to connect the Tempest BaseStation to external audio devices via the Auxiliary IN and/or the Auxiliary OUT connectors, you will need to provide the appropriate balanced ¼" TRS cabling.

Stage Announce XLR-3F Cable

If you plan to connect the Tempest BaseStation to an external audio device via the Stage Announce connector, you will need to provide the appropriate XLR-3F cabling.

Relay Access DA-15 Breakout Cable


If you plan to utilize any of the six available relays on the back of the Tempest BaseStation, you will need to provide an appropriate DA-15 breakout cable to access the Stage Announce Relay and Individual Relays.

LAN Connection RJ-45 / CAT-5 Cable

If you plan to connect the Tempest BaseStation to a computer or local area network, you will need to provide the appropriate RJ-45 CAT-5 cabling.

BaseStation Overview

Front Panel Left



1- Local Headset Connector

The 4-PIN XLR male headset connector is compatible with most Dynamic or Electret headsets that have 4-PIN XLR female connectors. This headset connector allows a user to communicate on any one of the two intercom channels. Controls for this connector are located to the immediate right. The mic gain for the Local Headset can be adjusted from the “Set Mic Gain” menu, under the “BaseStation Settings.” (Note: the headset must be purchased separately.)

2- Talk Button and LED

The Talk button works in conjunction with the Local Headset Connector. The Talk button enables or disables the microphone for the local headset. A blue “TALK” LED will illuminate when the mic is enabled. Tempest uses an intelligent latching method for talk buttons. Pressing TALK momentarily will cause the mic button to latch. The blue “TALK” LED will stay lit and the microphone will remain enabled. Pressing and holding TALK will cause the button to act in a momentary fashion. The blue “TALK” LED will remain lit and the microphone will remain enabled only as long as the button is pressed.

3- Call Button

The Call button sends a wired intercom-compatible call signal to any wireless BeltStation and any 2-Wire hardwired intercom device on the intercom channel currently selected for the Local Headset.

4- Mic Kill Button

The Mic Kill button sends a signal to wireless BeltStations that disables Talk buttons that are enabled. This button is for the wireless system only. No Mic Kill signal is sent out to the hardwired intercom. Mic Kill signals from the hardwired intercom are accepted and passed through to the wireless users.

A momentary press and release of the MIC KILL disables any wireless BeltStation Talk button currently enabled on the selected channel, as well as the BaseStation local headset connector. If the Mic Kill button is pressed and held for three seconds, all wireless BeltStation Talk buttons on all channels are disabled. A wireless BeltStation user may enable a Talk button at any time after the Mic Kill button is pressed and released. The “OFF” indicator appears in place of the “TALK” indicator on the BeltStation display and the user will not hear sidetone if both Talk buttons are OFF.

5- Local Headset Channel LEDs

The two Local Headset Channel LEDs labeled A and B indicate the currently selected intercom channel for the BaseStation local headset. Only one channel may be selected at a time. Pressing the Volume control while in Operational Mode cycles the Channel LEDs in order from A to B.

6- Peak LEDs

The two PEAK LEDs indicate when the mic audio from the local headset is reaching a peak level and is about to enter into limiting. These indicators should not be illuminated during normal use. The mic gain for the Local Headset connector can be adjusted from the “Set Mic Gain” menu, under “BaseStation Settings.” Setting the mic gain correctly is critical for quality communication audio.

7- Volume Control

The multipurpose Volume control operates differently depending on the mode of the BaseStation.

In Operational Mode, turning the Volume control adjusts the volume of the local headset. Turning the Volume control clockwise increases the audio level, while turning the control counter-clockwise decreases the level.

Press the Volume control to select the intercom channel to be monitored at the local headset connector. The intercom channel selected for the local headset connector is indicated by the CHAN LEDs located to the left of the Volume control.

In Menu Mode, turn the Volume control to scroll through the menu options of the current menu screen. Pressing the Volume control selects the current menu option and is the same as pressing the Enter button. A menu item is not selected and will not take affect until the Volume control (or the Enter button) is pressed.

8- Menu Button

Pressing MENU while the BaseStation is in Operational mode will enter Menu Mode. The Main Menu screen will be displayed. Once in Menu Mode, pressing the MENU button will act as an escape key and will back out of the current menu screen and move up one level. Pressing MENU while at the Main Menu screen will exit Menu Mode.

9- Enter Button

The Enter (ENT) button on the BaseStation is only used while in Menu Mode. Pressing the ENT button selects the current menu option and is the same as pressing the Volume control. A menu item is not selected and will not take affect until ENT (or the Volume control) is pressed.


10- Buttons 1 - 5

The five buttons below the LCD display, labeled 1 through 5, have multiple uses depending on the mode of the BaseStation. In Operational Mode, the BeltStation that is associated with a BaseStation Slot will appear directly above the corresponding numbered button. Pressing any of the numbered buttons will select the BeltStation Menu screen for the BeltStation that is located in BaseStation Slots 1 through 5. *(Note: These buttons are not active during Operational Mode when in Shared Mode.)*

In Menu Mode, pressing a numbered button selects the menu item with the corresponding number from the current list of menu items. This selection produces the same result as using the Volume control to scroll down to the desired menu item and pressing ENT.


11- LCD

While in Operational Mode, the LCD displays the status of all wireless BeltStations that are currently communicating with the BaseStation including the name of the BeltStation, RF strength, battery level, and other data. The LCD contrast and backlight intensity can be adjusted from the LCD Adjustments menu screen.



BaseStation LCD - Operational Mode

Front Panel Right



The Front Panel Right controls 1 – 7, will normally be used together to configure the Tempest BaseStation for 2-Wire or 4-Wire operation.

1- 2-Wire Intercom Type Slide Switch A&B

The 2-Wire Intercom Type slide switch configure the BaseStation for the type of intercom that will be connected to the corresponding 2-Wire connectors on the rear panel of the BaseStation. Clear-Com, RTS, or BAL (AudioCom) can be selected. This switch only affects 2-Wire operation and not 4-Wire operation. The A&B switch selects the 2-Wire system type for both the A and the B intercom channels.



Select the appropriate 2-Wire switch setting prior to connecting the 2-Wire intercom. Do not switch between 2-Wire types while connected to a 2-Wire system and powered ON. The different voltages in each system may damage equipment.

2- Wired Intercom Channel Select (SEL) Button

The Intercom Channel Select (SEL) button is used to select one of the two intercom channels so that the intercom mode -- 2-Wire or 4-Wire -- and audio input and output levels, may be adjusted.

Pressing the CHAN SEL button puts the BaseStation into Menu Mode and advances to the Intercom Levels screen.

Pressing the CHAN SEL button a second time selects channel A, for the opportunity to select 2-Wire or 4-Wire or no wired connection, and IN and OUT levels can be adjusted (*see 2-Wire/4-Wire Select below.*)

Additional presses advance through the intercom channels, and return to Operational Mode. The intercom channel selected is indicated by the two "CHAN" LEDs located to the immediate right of the SEL button.

Also, in the Aux IN/OUT menu, SEL advances through the channels to adjust the Aux IN and Aux OUT levels.

3- Channel (CHAN) LEDs

In Operational Mode, the two Channel (CHAN) LEDs labeled A and B are always illuminated.

Enter Menu Mode, by pressing the Channel Select (SEL) button ([2] above). In Menu Mode, the Channel LEDs indicate the channel currently selected for adjustment. Only one channel may be selected at a time.

4- 2-Wire/4-Wire Select (SEL) Button

The 2-Wire/4-Wire Select (SEL) button sets the wired intercom mode for each of the two intercom channels. When a channel is selected with the CHAN SEL button, pressing the 2-Wire/4-Wire Select (SEL) button changes the selected intercom mode between 2-Wire, 4-Wire, or no connection.

5- 2-Wire/4-Wire LEDs

The four 2-Wire/4-Wire LEDs indicate the currently selected intercom mode for each of the two intercom channels. If either a 2-Wire or 4-Wire connection has been enabled for a particular intercom channel, the corresponding 2-Wire or 4-Wire LED indicator will be illuminated. When no intercom has been enabled, the corresponding 2-Wire or 4-Wire LED indicators will be OFF.

6- IN Level Control

In Menu Mode, from the Intercom Levels screen, the IN control adjusts the incoming level of the currently selected wired intercom channel, from the hardwired intercom system to the Tempest BaseStation. If 2-Wire is selected, the IN Level control adjusts the incoming level of the 2-Wire signal. If 4-Wire is selected, the IN Level control adjusts the incoming level of the 4-Wire signal. If neither 2-Wire nor 4-Wire is selected, the IN Level control is inactive. In addition to the intercom IN levels, the IN control is used to adjust Aux IN levels.

7- OUT Level Control

In Menu Mode, from the Intercom Levels screen, the OUT level control adjusts the outgoing level of the currently selected wired intercom channel going to the hardwired intercom system from the Tempest BaseStation. If 2-Wire is selected, the OUT Level control adjusts the outgoing level of the 2-Wire signal. If 4-Wire is selected, the OUT Level control adjusts the outgoing level of the 4-Wire signal. If neither 2-Wire nor 4-Wire is selected, the OUT Level control is inactive. In addition to the intercom OUT levels, the OUT control is used to adjust Aux OUT levels.

8- USB Connector

The USB connector is used to update the Tempest BaseStation firmware and is not used in normal operation.


9- Beltpack Program Connector

The Beltpack Program connector is used to pair the BaseStation with BeltStations. To pair the BaseStation with a particular BeltStation, ensure that the BaseStation is powered ON and in Operational Mode (not in Menu Mode). Ensure that the BeltStation is powered OFF. Plug one end of the pairing cable into the BaseStation, and plug the other end of the pairing cable into the BeltStation. Turn the BeltStation power ON by pressing and holding the BeltStation Power ON/OFF switch for two seconds. The pairing process happens automatically and the message "Pairing Complete" will appear on the BeltStation LCD for approximately three seconds when done.

10- Power ON/OFF Switch

The ON/OFF switch is used to turn the BaseStation power (AC or DC) ON and OFF.

Rear Panel Left



1- AC Power Input Connector

The IEC AC Power Input Connector accepts the AC power cord. Use this connector with the supplied AC power cord to power the Tempest BaseStation from AC power between 85 and 260 VAC at 50 – 60 Hertz. The BaseStation will draw approximately 15 Watts (125mA at 120VAC, 65mA at 230VAC).

2- DC Power Input Connector

The DC Power Input Connector accepts a Switchcraft S760 2.1mm x 5.5mm power plug wired as center positive. Use this connector with a user-supplied cable to power the Tempest BaseStation from DC power (battery) between 11 and 32 VDC. The BaseStation will draw approximately 12 Watts (990 mA at 12VDC).


3- Intercom Channel A/B Connectors

The Intercom Channel connectors (A/B) allow the user to connect the Tempest BaseStation to 2-Wire external intercom systems or other Tempest BaseStations. The XLR-3M/F 2-Wire intercom connectors interface with Clear-Com, RTS, Balanced and other compatible intercom systems. The pairs of XLR3-M and XLR-3F are electrically identical.

4- RJ-45 4-Wire Intercom A/B Connectors

The RJ-45 4-Wire Intercom connectors (A/B) interface with 4-Wire intercom systems and devices including Clear-Com matrix systems. This is an intercom audio-only connector and does not support data transfer. The connector is balanced and transformer isolated. Nominal line levels are -18 to +4 dB (IN) and -6 to +10 dB (OUT).

Rear Panel Right



1- SA (Stage Announce) Connector

The SA connector is used to output BeltStation audio to a dedicated audio output. The SA Connector is an XLR-3M connector and accepts a standard XLR-3F. The SA Connector is balanced and transformer isolated. Nominal line level is -12 to +8 dBu. The SA Connector output level can be adjusted under the Wired Intercom Settings menu.

2- Aux IN Connector

The Auxiliary IN Connector is used to supply program or other audio sources to the Tempest BaseStation. The Auxiliary IN Connector is a 1/4" Tip/Ring/Sleeve jack that accepts a standard 1/4" TRS plug. The Auxiliary IN Connector is balanced and transformer isolated. Nominal line level is -15.5 to +4 dBu. Audio supplied to the Aux IN Connector can be assigned to any combination of the four intercom channels with individual levels for each channel at the "Aux In/Out Assignment/Level" menu. While in the Aux In/Out Assignment/Level menu, the front panel CHAN SEL button or the Volume control can be used to advance through the channels, and the IN Level control is used to adjust the Aux IN level. Adjust to the lowest level to restrict audio from a channel.

3- Aux OUT Connector

The Auxiliary OUT Connector is used to supply intercom audio sources from the Tempest BaseStation. The Auxiliary OUT Connector is a 1/4" Tip/Ring/Sleeve jack that accepts a standard 1/4" TRS plug. The Auxiliary OUT Connector is balanced and transformer isolated. Nominal line level is -12 to +8 dBu. Audio supplied from the Auxiliary OUT Connector can be assigned from any combination of the four intercom channels with level control at the "Aux In/Out Assignment/Levels" menu. While in the Aux In/Out Assignment/Level menu, the front panel CHAN SEL button or the Volume control, can be used to advance through the channels, and the OUT Level control is used to adjust the Aux Out level. Adjust to the lowest level to restrict audio from a channel.

4- Base Sync IN Connector

The Accu-Sync, BaseSync IN Connector is used to input an external sync signal that ensures that multiple Tempest BaseStations all transmit and receive at the same time, thus avoiding inter-BaseStation RF interference.

5- Base Sync OUT Connector

The Accu-Sync, BaseSync OUT Connector is used to output a sync signal that ensures that multiple Tempest BaseStations all transmit and receive at the same time, thus avoiding inter-BaseStation RF interference. Any BaseStation that has a BaseSync OUT connection, but does not have a BaseSync IN connection, will generate a sync signal for connected BaseStations.

6- Local Area Network (LAN) RJ-45 Connector

The Local Area Network (LAN) RJ-45 Connector is used to connect the Tempest BaseStation to a user supplied PC running Tempest Desktop Configuration (T-Desk) software. The user can then monitor and/or adjust BaseStation and BeltStation settings via the PC interface. This connection can be made directly or through a Local Area Network (LAN). *See the separate T-Desk User Manual for more information.*

7- Relay Connector

The Relay Connector provides access to all of the relay closure contacts for the Tempest BaseStation. There are six relays including one common Stage Announce relay and five individually assignable relays - one for each of the wireless BeltStations. See the section on "GPO Relay Contacts."

8- Antenna Connector

The Antenna Connector is used to connect the antenna to the Tempest BaseStation. The Antenna Connector is an RP-TNC (Reverse Polarized-TNC) connector. Cables used to attach to this Antenna Connector must be properly terminated with mating RP-TNC connectors and the proper cable type.

9- Remote Transceiver RJ-45 Connector

The Tempest Remote Transceiver RJ-45 connector is used to connect the optional remote transceiver to the Tempest BaseStation. The remote transceiver can be located up to 1,500 feet from the BaseStation.

BeltStation Overview

1- Volume- CH A and CH B

In Operational Mode, turning the Volume control adjusts the volume of the audio. Volume indicators appear on the display during adjustment and are expressed in Decibels (dB).

The Volume control has an option to be set to “Volume Press” where it requires a “press and turn” to adjust the volume level. The “Volume Press” option can be adjusted under the “Set Controls” section of the BeltStation menu.

Pressing the Volume control in “Dual-listen” mode does nothing. In “Single-listen” mode, pressing “CH A” enables channel A, and pressing “CH B” enables channel B. The Volume control has a channel “Delay Switch” option which requires the knob to be pressed and held slightly longer in order to switch from one channel to the other. This feature can be enabled under the “Set Controls” section of the BeltStation menu.

In Menu Mode, turning either Volume control allows the user to scroll the options of the current menu screen. Pressing the Volume control selects the option.



2- Stage Button

The Stage Announce (STAGE) button re-routes the microphone signal of the BeltStation from the selected intercom channel to the BaseStation rear panel Stage Announce (SA) output connector. If desired, when this button is pressed, a momentary relay contact closure is made at the Relay connector. *See the section on GPO Relays.*

Pressing the Stage Announce button automatically enables the microphone, regardless of Talk Button status. The Stage button settings may be adjusted at the Stage Announce menu screen under the “Set Controls” section of the BeltStation menu.

3- MENU Button

Pressing MENU while the BeltStation is in Operational mode will select Menu Mode, and the Main Menu screen will be displayed. Once in Menu Mode, pressing MENU again will act as an escape key and will back out of the current menu screen moving the user up one level. Pressing the MENU button while at the Main Menu screen will exit Menu Mode and return to Operational mode. The menu can be locked via a “Menu Lock” feature per BeltStation.

4- ENTER Button

The ENTER button operates differently depending on the mode of the BeltStation. In Menu Mode, pressing the ENTER button selects the current menu option and is the same as pressing a Volume control. A menu item is not selected until the ENTER button (or Volume control) is pressed.

The ENTER button can also activate Wireless ISO (wireless talk around), providing wireless communication isolated from any connected wired intercom system.


The ENTER button is also one of the buttons that can be assigned to activate a Relay in the BaseStation. It is possible to activate the Relay whenever the Wireless ISO feature is used.

5- LCD

While in Operational Mode, the LCD displays the status of the BeltStation including the name of the currently communicating BaseStation, RF strength, battery level, and other data. The LCD backlight and contrast can be adjusted from the LCD Adjustments menu screen under the LCD/LED section of the BeltStation menu.

6- CALL Button

The CALL Button sends a 2-Wire compatible call signal to any wireless BeltStation and any hardwired intercom device on the intercom channel. The Call signal will be routed to intercom channels indicated by the user's active Talk button(s).



1- Rubberized Access Cover

The Rubberized Access Cover helps prevent dust, dirt and liquid from entering the BeltStation through the USB or the BeltStation pairing connector. Keep this cover securely closed at all times to ensure the best possible seal.

2- USB Mini B Connector

The USB Connector is used to charge the BeltStation with the supplied wall charger. In addition, the USB connect is used to update the firmware of the BeltStation.

3- BeltStation Pairing Connector

The BeltStation Pairing Connector is used to pair the BeltStation with BaseStations using the supplied 1/8" stereo mini connector.

1- Belt Clip

The Belt Clip enables the BeltStation to be worn on the user's belt or other clothing item.

2- Power ON/OFF Button

The Power ON/OFF button is used to turn the BeltStation ON or OFF. Press and hold the Power ON/OFF button for two seconds to turn the BeltStation ON. Press for four seconds to turn the BeltStation OFF.

3- Battery Compartment

The Battery Compartment holds either one Tempest Lithium-Polymer rechargeable battery or (3) standard alkaline AA cells. To remove the battery door, press down on the thumb markings and pull the battery door toward the bottom of the BeltStation. To remove batteries from the battery compartment turn the BeltStation battery side down and tap the bottom of the BeltStation on the palm of your other hand. Please be careful to insert alkaline AA batteries according to the marked polarity. All of the alkaline AA cells face the same direction. If the battery cover does not fit or close properly, the battery may not be inserted correctly.

4- Headset Connector

The 4-pin XLR male headset connector mates with most Dynamic or Electret headsets that have 4-pin XLR female connectors. This Headset connector allows a user to communicate in "Dual-listen" or "Single-listen" mode on either intercom channel.

The mic detect circuit (dynamic/electret) will indicate dynamic when it sees a load of 600Ω or less. It will indicate an electret when it sees 1kΩ or greater. Between 600Ω and 1kΩ is not recommended as it may not accurately detect mic type. If you are using dynamic mics, you should short the input to ground. If you are using electret mics you should open the circuit. This will keep the belt from switching back and forth between modes.



Talk Button A and B



There are two TALK buttons on each BeltStation, one for channel A and the other for channel B. The Talk button enables the microphone signal for the assigned intercom channels.

Tempest uses an intelligent latching method for TALK buttons. Pressing the TALK button momentarily will cause the TALK button to latch. Pressing and holding the TALK button will cause the button to act as a momentary switch.

Talk tones can be enabled or disabled per BeltStation. If enabled, users will here a tone each time the TALK button is pressed.

Channel Indicator LEDs A and B

Each Talk button has two individual LED indicators. Together they surround the Talk button. The LEDs will flash blue to indicate which intercom channel, A or B, has been selected and will illuminate continuously to indicate that "Talk" is enabled on that channel.

The Channel Indicator LEDs will flash red when the microphone signal is reaching a peak level and is entering into limiting.





Bottom view of the transceiver

Transceiver Controls

1- RX LED

The RX LED illuminates when data is being received by the Remote Transceiver. This LED will remain illuminated during normal system operation.

2- TX LED

The TX LED illuminates when data is being sent from the Remote Transceiver. This LED will remain illuminated during normal system operation.

3- SYNC LED

The Sync LED illuminates when the Transceiver Sync signal is present. This LED will remain illuminated during normal system operation.

4- CONFIG LED

The Config LED illuminates only when the BaseStation puts the Remote Transceiver into configuration mode to change settings. This LED should be ON for only a few seconds when first powered ON, and OFF during normal operation.

5- BASESTATION LINK RJ-45 Connector

The BaseStation Link RJ-45 connector is used to connect the Transceiver to the Tempest BaseStation via standard CAT-5 cable with RJ-45 connectors.

6- Power LED

The Power LED illuminates whenever the BaseStation is providing adequate power to the Transceiver over the CAT-5 cable. If the Power LED does not light, the CAT-5 cable may be damaged or too long to deliver adequate power for the Transceiver to operate reliably.

Threaded Mounting Holes


Two Threaded Mounting Holes are provided on the back of the Remote Transceiver for use with the mounting bracket to mount the Transceiver in a convenient location. The mounting holes are #8-32 thread and accept a #8-32 x 3/8" pan head screw.

BaseStation Setup

Steps to Setup the BaseStation

- Choose a location for the BaseStation
- Choose an antenna location and configuration
- Maximize performance
- Configure operation features
 - » Set Frequency Band
 - » Set Network Number and Lockout Key
 - » Name each BaseStation and BeltStation (optional, but encouraged)
 - » Set Static or Dynamic Display
- Configure optional features

Choose a Location



A Tempest BaseStation mounted in an equipment rack with optional cables and mounting hardware.

Tempest is a radio system. Choosing a location for your Tempest BaseStation and the associated antenna is one of the most important factors to ensure proper system operation and achieve maximum operational range. As covered in the *General Information* and *Theory of Operation* section of this manual, broadcasting and receiving RF signals can be greatly affected by physical and electromagnetic barriers.

Following the guidelines below for selecting a suitable BaseStation and antenna location will help to ensure that your system operates properly and achieves the maximum possible operational range.

See the Antenna Configuration section of this manual for details about recommended cable type and other important information about connecting the antenna to the Tempest BaseStation.

BaseStation Location

The location of the BaseStation is important, but it is the location of the antenna that will ensure maximum system performance and operational range. Whenever possible, locate the BaseStation in close proximity to the desired coverage area. If this is not possible consider using the optional Remote Transceiver to achieve optimal antenna positioning. It is not recommended to use RF coaxial cable lengths longer than 25 feet to remote the antenna, as this will degrade system performance and operational range.

- The BaseStation must have a source of electric power available. This can be either AC or battery (DC) power.
- The front panel of the BaseStation must be accessible for configuration.
- The front panel may be used as a communication portal.
- The rear panel must be accessed for making wired system connections.
- The Tempest BaseStation should be in a location that has adequate ventilation and is not subject to extreme temperatures and humidity.
- Avoid areas subject to water or rain.
- Always use a stable and secure platform or rack mount system.

Power Connections

The Tempest BaseStation can be powered from AC or DC power. The front panel ON/OFF switch controls AC and DC power coming into the BaseStation. If AC and DC are both connected, the DC will act as a power supply backup in the event AC power is interrupted.

AC Power Connection

- » Always connect the power cord to the Tempest BaseStation before connecting to the outlet.
- » Only use approved IEC AC power cords.
- » Only use AC power from 85 to 260 VAC at 50 – 60 Hz.

DC Power Connection (Battery)

- » To power the Tempest BaseStation from DC power, you must provide an appropriate DC power input cable.
- » The DC power input jack on the BaseStation is a Switchcraft 722RA.
- » The mating plug is a Switchcraft S760 - 2.1mm x 5.5mm power plug. The connector should be wired as center positive.
- » Always use appropriate wire of an acceptable gauge and length for your application. The minimum recommended wire is 26 gauge at not more than five feet. If 10 feet is required, the minimum gauge would be 24.
- » Only use DC power from 11 to 32 VDC. The Tempest BaseStation will draw approximately 12 Watts (990mA at 12VDC).

Powering ON the BaseStation


Plug in the BaseStation.

Turn the front panel ON/OFF switch to the ON position.

The BaseStation undergoes an initialization cycle. During this power-up cycle, the LEDs flash and the LCD screen updates.

Approximately 4 seconds after turning ON the power switch, you will see a splash screen showing the installed firmware version. The splash screen lasts approximately 6 seconds before advancing to the normal Operation screen. If connected to a Local Area Network, the DHCP settings (IP address, MAC address, etc) will then display until MENU is pressed to escape or until the normal timeout is completed. The system will then display the main Operation screen and will be ready for use.

Antenna Location



Proper antenna location is essential for optimum system performance and maximum range. Antenna positioning is important with all RF systems and in all applications.

Locate the Tempest BaseStation antenna as high as possible for your application to maximize line-of-sight RF operation. Positioning the antenna higher than head level is the minimum acceptable height for most applications. Maintaining line of sight between the BaseStation antenna and the BeltStation(s) is ideal.

When using multiple BaseStations, keep as much space between the antennas as possible, but a minimum of 24 inches is recommended. Increasing the distance between antennas to may help to improve performance.



When rack mounting the Tempest BaseStation or when it is stacked with other equipment, always remote mount antennas or use the Tempest Remote Transceiver to ensure maximum operational range.

If possible, locate the antenna(s) away from any metal obstructions and away from walls or other significant structures, by at least 24 inches.

When using omni-directional (Whip) antennas, always locate the antennas as close to the center of the coverage area as possible. Omni-directional antennas have a circular pattern and radiate RF energy equally in all directions at approximately a 90° angle to the element of the antenna.


Other antenna options are available including directional and higher gain antennas. Please contact your dealer or distributor for more information on optional antennas. Only use approved antennas. Unauthorized antennas may be illegal.

Using more than one BaseStation permits an increase in the number of wireless BeltStations within an area, or by utilizing one of Tempest's roaming features, allows increasing the area covered and even allows for the creation of separate, but adjacent or overlapping coverage areas. The number of BaseStations that can be utilized in a system is limited by RF competition between systems and several other RF conditions. Judicious placement of antennas can help facilitate a large number of wireless BeltStation users on a single system.


Antenna Configurations

Option 1

Install the BaseStation in the center of the area of communication, with antenna installed on the back of the BaseStation, having a clear line of sight in all directions.



When attaching the supplied ½ Wave Omni-directional Whip antenna directly to the back of the BaseStation, always ensure that the antenna is firmly seated, is not cross threaded, and is located away from any metal obstructions. Keep the antenna away from walls or other significant structures by at least 24 inches.




Option 2


Install the BaseStation in a convenient location and use an optional LMR-400, a 50 ohm coax cable up to 25 ft to connect an optional directional antenna. (15 ft of LMR-400 induces about 1 dB of attenuation.) *Note: Directional antennas are subject to legal restrictions in some countries.*

Option 3

Install the BaseStation in an equipment rack (1 RU) and use an optional LMR-195, a 50 ohm coax up to 10 ft to mount the antenna above the equipment rack. (5 ft of LMR-195 coax induces about 1 dB of attenuation.)




To remotely locate antenna always use high quality, low loss, 50 ohm RF cable terminated with an RP-TNC connector for the BaseStation side connection and the appropriate antenna mating connector on the other end. LMR-195 (or equivalent) coaxial cables can satisfactorily be used in lengths up to 10 feet. LMR-400 coaxial cables (or equivalent) can be used at lengths up to 25 feet. Longer RF coaxial cable runs are not recommended due to signal attenuation in the cable.



Option 4

Install the BaseStation in a convenient location and use the Tempest Remote Transceiver connected with CAT 5 cable and RJ-45 connectors to position antennas in the most suitable location. Use omni-directional antennas on the Transceiver or use short lengths of LMR-195 coaxial cable to separate antennas for additional spatial diversity.



Pairs of Directional Antennas must be aimed to cover the same area.

When locating the antenna at distances greater than 25 feet, use the optional Tempest Remote Transceiver. The remote transceiver allows locating antennas up to 1,500 feet away from the BaseStation without the RF signal loss that is associated with using RF cable. The antenna can be mounted directly to the Tempest Remote Transceiver, or they can be separated from the remote transceiver using high quality, low loss, 50 ohm RF cable as listed above. *See the Tempest Remote Transceiver section of this manual for more information on the setup and use of the remote transceiver.*

Remote Transceiver


Setup the Transceiver

- Choose a BaseStation location.
- Choose a Transceiver location.
- Choose an antenna configuration.
- Install CAT-5 cable and connect to the BaseStation and Transceiver.
- Confirm operation by observing the Transceiver LEDs.

The Tempest Remote Transceiver is an optional accessory that allows antennas to be located up to 1,500 feet away from the BaseStation without the RF signal loss that is associated with using long runs of coaxial cable.

The Tempest Remote Transceiver connects to the rear of the BaseStation with standard CAT-5 wiring with RJ-45 connectors. Note that there are two RJ-45 connectors on the back of the BaseStation and they are not interchangeable. The second RJ-45 is for a LAN connection.

- » Install the BaseStation in a convenient location.
- » Install CAT-5 cable so that it is protected from electronic interference as much as possible.
- » Install the Transceiver and antennas in a location that provides the best RF coverage.
- » Connect the CAT-5 cable to the BaseStation and the Transceiver.
- » When the BaseStation detects the presence of the Transceiver, there is a brief automatic configuration process before the Transceiver takes over the radio function from the BaseStation.




There are two RP-TNC antenna connectors on the top of the transceiver, allowing for connection of a two half wave antennas or alternate antenna configurations. Always ensure that the antennas are securely connected for proper system operation.

The Transceiver antenna connectors are made to be water resistant, so outdoor use is acceptable. The cable connections on the bottom of the transceiver are not water tight, so always protect from immersion. In severely blowing rain, it may be prudent to protect with an RF transparent cover such as a Ziploc bag.

Coaxial cable may be used to connect alternative antenna options.

See the Antenna Configuration section.



Pairs of Directional Antennas must be aimed to cover the same area

Maximizing System Performance and Operational Range

Radio waves (especially those at 2.4GHz) can be significantly affected by walls, windows, or other physical barriers. Concrete or metal walls can be of particular concern. Some tinted windows are also significant barriers to RF. Always position antennas to minimize interference from all barriers.

A human body can be a barrier to the radio signal, especially when operating near the limit of the signal's range. If you experience interference, turn the BeltStation toward the BaseStation antenna.

Electronic equipment can generate radio interference. Install the BaseStation antenna away from sources of electrical interference. Be aware of the presence of nearby electronic equipment that may cause interference as you move about while wearing the BeltStation.

Reflected RF signals, called multipath interference can cause intersymbol interference resulting in compromised audio. Multipath interference should be suspected when audio is imperfect and there is no other obvious cause. Typically, intersymbol interference requires a reflection path that is at least a few hundred feet. It is most likely to occur in a large enclosed venue with highly reflective walls or ceiling. If intersymbol interference is suspected, relocate the BaseStation antenna and/or try a directional antenna to help eliminate received reflected signals.

Line-of-sight operation between the BaseStation antenna and the BeltStations will always produce the maximum system performance and operational range. Minimize obstructions between the BaseStation antenna and the BeltStations when possible.

Use an optional directional antenna to improve system performance and operational range. A directional antenna focuses the RF signal into a smaller area. When the BeltStation is located within this focused area of energy, it will have a more powerful signal, which will improve range.

Only use approved antennas. Unauthorized antennas may be illegal.

Configure the BaseStation



BaseStation settings can be configured in two ways: from the BaseStation menu or with the computer interface called “T-Desk” via a LAN connection. While many functions are available through both methods, certain features may only be available through the BaseStation.

Using the Front Panel Controls

The Tempest BaseStation can be configured depending on user preferences and the tasks to be accomplished. The following instructions will help you navigate the front panel and LCD user interface.

See the BaseStation Menu Structure section of this manual for more details of the menu.

The LCD screen is the focal point of the BaseStation functionality. While in Operational Mode, the LCD displays the status of all wireless BeltStations that are currently logged on to the BaseStation. In Menu Mode, the LCD shows the menu items or information.

The function of the Volume control depends upon the current Mode of the BaseStation. In Operational Mode, turning the Volume control adjusts the volume of the audio for the local headset. Press the Volume control to select the channel of the local headset connector.

In Menu Mode, turn the Volume control to scroll through the menu options of the current menu screen. A pointer “>” on the left of the menu indicates the current option. Pressing the Volume control selects the current menu option and is the same as pressing the Enter button (ENT). A menu item is not selected and will not take affect until the Volume control or the ENT button is pressed.

Pressing the MENU button while the BaseStation is in Operational mode will cause the BaseStation to enter Menu Mode. The main menu screen will be displayed. Once in Menu Mode, pressing the MENU button will act as an escape key and will back out of the current menu screen and move up one level. Pressing the MENU button while at the main menu screen will exit Menu Mode and return to Operational Mode.

The ENT button on the BaseStation is only used in Menu Mode. Pressing the ENT button selects the current menu option and is the same as pressing the Volume control. A menu item is not selected and will not take affect until the ENT button or the Volume control is pressed.

The 1 through 5 buttons below the LCD screen have multiple uses depending upon the mode of the BaseStation. In Operational Mode, a BeltStation that is communicating with the BaseStation will appear in a slot directly above a numbered button. Pressing one of the numbered buttons will advance directly to the “BeltStation Settings” menu for that BeltStation.

In Menu Mode, pressing one of the five numbered buttons selects the menu item with the corresponding number from the current list of displayed menu items. This action produces the same result as scrolling with the Volume control to the desired menu item and pressing ENT or the Volume control. To view and select additional menu items, rotate the scroll knob and press ENT to select.

Adjust Sidetone

To demonstrate the use of the controls, this details instructions to adjust the “Sidetone” for the front panel headset connector:

1. Press MENU to enter Menu Mode
2. Rotate the Volume knob and scroll to “BaseStation Settings” on the display
3. Press ENT
4. Scroll to “Sidetone” and press ENT (or the Volume knob) to select

Sidetone value is expressed in Decibels (dB). You will see a level indicator with a numeric value between -30 dB to -6 dB. Speak into the headset microphone at a typical speaking level and adjust the sound of your own voice in your headset. Press Enter to accept the changes.

Press MENU to move up one level in the menu tree. Press MENU repeatedly to exit Menu Mode and return to Operational Mode. If no other items are selected, Menu Mode automatically exits and returns to Operational Mode after about three minutes.



The BaseStation controls may seem to react slowly. Some of the menu controls send a signal to a BeltStation and require a reply from the BeltStation. There is a fraction of a second delay built into some functions of the buttons and knobs. It is possible to press buttons or turn knobs faster than they are permitted to react.

Selecting a Frequency Band

The Tempest 2.4GHz wireless system is approved for license free use in most countries. However, due to differences in radio spectrum regulations, some countries require that 2.4GHz equipment limit or adjust its RF spectrum operation. Always determine if there are country specific frequency restrictions that apply and select the required frequency band as described below. Tempest performs RF frequency adjustment automatically when you select the appropriate frequency band from the “Tech Menu.” *Note: This is a legal requirement in some countries.*

It is only necessary to use this feature if you use Tempest in one of the countries with special frequency requirements. Otherwise, Band 1 is the default and should be used for maximum RF performance.

If the Tempest Wireless system is transported to a country with special requirements, navigate to the Radio Configuration screen in the “Tech Menu” to select the appropriate frequency band from the “Set Band” menu screen in the BaseStation.

After changing the frequency band selection it is necessary to “pair” each BeltStation with the BaseStation so the information can be transmitted from the BaseStation to the BeltStation.

See the “Pairing with BeltStations” section of this manual for more information on pairing.

Band	MHz		MHz	Avoid 802.11 b/g
	Start	End	Width	
1	2400	2480	80	None
2	2400	2450	50	11
3	2423	2473	50	1
4	2431	2480	49	1, 2,
5	2400	2428	28	7, 8, 9, 10, 11
6	2423	2450	27	1, 11
7	2453	2480	27	1, 2, 3, 4, 5, 6, 7

Network Number and Lockout Key

The *Network Number* determines the RF frequency hopping pattern for the BaseStation and its corresponding BeltStations. This is a key operational parameter and is represented by a number between 0 and 42.

When using multiple collocated Tempest BaseStations, it is imperative that Network Numbers are properly coordinated. BaseStations that are synchronized together using the ZSync technology must utilize the same Network Number Group for optimal performance to be achieved. Up to 11 Tempest BaseStations can be utilized in one Network Number Group under ideal conditions (Band 1). For example, a configuration using ZSync and 11 Tempest BaseStations would assign each BaseStation a Network Number (0,1,2,3...10) from the Band 1, Group 1. The chart below outlines each Network Number Group and it's capacity in relation to the frequency band being used.

Band 1	43 Total Channels Available	Collocated Bases	Network Numbers
	Group 1	11	0 - 10
	Group 2	11	11 - 21
	Group 3	11	22 - 32
	Group 4	10	33 - 42
Bands 2, 3, 4	27 Total Channels Available	Collocated Bases	Network Numbers
	Group 1	7	0 - 6
	Group 2	7	7 - 13
	Group 3	7	14 - 20
	Group 4	6	21 - 26
Bands 5, 6, 7	15 Total Channels Available	Collocated Bases	Network Numbers
	Group 1	4	0 - 3
	Group 2	4	4 - 7
	Group 3	4	8 - 11
	Group 4	3	12 - 14

The *Lockout Key* prevents systems with the same Network Number from trying to communicate with each other and is represented by a number between 0 and 255. BaseStations that are collocated within the same installation may have the same Lockout Key as long as the Network Numbers are different. Lockout keys serve as differentiators for systems using the same Network Number. Together, the Network Number and Lockout Key represent more than 11,000 possible combinations to minimize the possibility of inter-system interference.

The Network Numbers and Lockout Keys for Tempest Wireless BaseStations are set to a factory default before leaving the factory. It is always recommended to adjust the Network Number and Lockout Key upon initial set up out of the box. Failure to set a unique Network Number and Lockout Key may result in poor system performance caused by interference from another Tempest Wireless system using the same Network Number and Lockout Key. Because of the requirement to pair every BeltStation to each BaseStation that it will communicate with, it is not possible to manipulate Network Numbers and Lockout Keys at a BeltStation to gain unauthorized access to a communication channel.



Collocated BaseStations must use Network Numbers from the same Network Number Group; failure to do so can lead to poor performance.

Adjusting Network Number and Lockout Key

The Network Number and Lockout Key settings can be adjusted from the BaseStation, under the “Radio Configuration” section of the Tech Menu. Any adjustment to the Network Number and/or Lockout Key will require corresponding BeltStations to be re-paired with updated BaseStation.

- Press MENU and select “BaseStation Settings.”
- Using the Volume control, scroll to and select “Tech Menu.” Proceed through warning.
- Select “Radio Configuration,” then “Network Number.”
- Use the Volume control to adjust the value and press ENT to save.
- Press MENU to escape one level and select “Lockout Key” to adjust the Lockout Key.
- Use the Volume control to adjust the value and press ENT to save.
- Press MENU repeatedly to escape to the Operation screen.



Updating Network Numbers and/or Lockout Keys will require corresponding BeltStations to be re-paired to the updated BaseStation.

Set Display Mode to Static or Dynamic

The *Static* or *Dynamic* selection only affects the order that the BaseStation LCD Operational screen displays BeltStation information. “Static” will be the preferred choice for users who want to ensure that a BeltStation that is logged in will always appear in the same location (slot) on the BaseStation display and are using only one BaseStation.

Dynamic is the default setting. *Dynamic* display mode always displays BeltStations in alpha-numeric order by name, so “Dir” appears before “LitMgr,” which appears before “StgMgr.” BeltStations can change slots depending on which BeltStations are logged in at any given moment. Empty slots are always on the right of the Operation screen. *Dynamic* is the preferred choice for users utilizing iSelect roaming between multiple BaseStations.

On the BaseStation, under “Tech Menu,” in the “Display Slot Assignments” menu, choose *Static* or *Dynamic*.

When selecting *Static* slot assignments, you must also enter the “Base Slot” section of the “Tech Menu” on each BeltStation and assign each BeltStation a different slot (1 – 5). If you have a BeltStation that displays the message “Slot Occupied,” it means two or more BeltStations are assigned to the same slot number.



When operating in Shared Mode, the Tempest BaseStation must be in Dynamic slot assignment.

Name Each Station

Name the BaseStation with a descriptive name. This is especially helpful when iSelect Roaming will be used to roam between BaseStation coverage areas. It is also helpful when the BaseStation or T-Desk is used to monitor and manage the BeltStations. The BaseStation name can include up to 14 characters. Prior to a name being assigned, a hexadecimal serial number is displayed as a default.

The BaseStation name will appear on the banner (top line of the BaseStation display, with white-on-black lettering), on the BeltStation display, and in the BeltStation’s menu under “Select Base.”

The BeltStation will accept 14 characters in the name, but only the first six characters of the BeltStation name can be displayed on the BaseStation Operation screen. If the BeltStation is named “Camera 1,” then “Camera” will be displayed on the BaseStation slot for that BeltStation because of the six character limit. If the BaseStation will be used to monitor and manage the BeltStations, the BeltStation name should be limited to six characters. To name each BaseStation:

1. On the BaseStation press MENU and select “BaseStation Settings,” then “Name BaseStation.”
2. Rotate the Volume control to move the underscore “_” to select the character to be changed.
3. Press ENT and notice the underscore changes to a pointer “^” under the selected character.
4. Rotate the Volume control to scroll through the character list. Press ENT to select the new character. Characters always replace and never insert. *Repeat as needed.*
5. Press ENT to save the new name after all characters are complete. Failure to press ENT to save will clear all changes.
6. Press MENU to escape to the Operation Mode screen.

Naming the BeltStation works the same as naming the BaseStation. On the BeltStation, press MENU and select “Belt Settings,” then “Name BeltStation.” Use the Volume control and the ENT button to select and change characters. Press ENT to save the changes.

BeltStation names can be changed wirelessly from the BaseStation’s menu or from T-Desk when the system is on a local area network.

BaseStation Headset Connection and Controls



The BaseStation headset connection is a functional user communication point, and may also be used for setup and troubleshooting. The Front Panel Headset can communicate on any one of the two intercom channels. Controls for this headset are located just to the right of the connector, and in the menu on the BaseStation Settings screen.

The front panel headset connector is a 4-PIN XLR male. A compatible headset must be provided by the user.

The TALK button enables or disables the microphone for the local headset. A blue LED will backlight the word “TALK” on the TALK button when the mic is enabled. Always keep the microphone disabled (TALK OFF) when not in use.

Tempest uses an intelligent latching method for TALK buttons. Pressing the TALK button momentarily (less than two seconds) will latch the mic button. The blue “TALK” LED will remain lit and the microphone will remain enabled. Pressing and holding the TALK button will cause the button to act in a momentary or push-to-talk fashion, so the blue “TALK” LED will remain lit and the microphone will remain enabled only as long as the button is pressed.

In Operational Mode, turning the Volume control adjusts the volume of the audio of the local headset. Turning the Volume control clockwise increases the audio level while turning the control counter clockwise decreases the level. The Volume control knob is also a push button. Pressing the Volume control cycles the Channel selection and LEDs in order from A to B.

The two Peak LEDs indicate when the mic audio from the local headset is reaching a peak level and is about to enter into limiting. These LEDs should normally be OFF.

Set the Mic Gain for the Local Headset

Set the Mic Gain properly to assure the best audio quality. To set the Mic Gain for the Local Headset:

1. Press MENU to enter Menu Mode.
2. From the Main Menu select “BaseStation Settings,” then “Set Mic Gain.”
3. While at the “Set Mic Gain” screen, talk into the local headset microphone in a louder than normal level and adjust the Volume control until the Peak LED for the selected channel just starts to light at the loudest parts of the audio. Press ENT to accept the changes.

When the Mic Gain is set too high, it is possible to induce feedback or echo. When set too low, words can be clipped by the low level noise gate, or may sound too quiet to other listeners. Headsets by different manufacturers or different models of headsets will require widely varying Mic Gain settings. When setting microphone gain, it is best to err toward a setting that is too low, rather than too high. This will help reduce unwanted echo in the system when that microphone is enabled.

Front Panel Lock

The Front Panel Lock function is intended to minimize the probability of unintentional adjustments to the system. Press MENU, select “BaseStation Settings,” scroll and select “Front Panel Lock,” press 1 or ENT to select *Lock*. Press MENU to exit to the main Operational screen. The buttons and knobs on the front of the BaseStation will not function until unlocked, except for the power switch which will power the unit OFF. When the BaseStation is powered ON, it is always unlocked.

- Press MENU + ENTER to unlock.

Call Function

On the BaseStation front panel, select a channel by pressing the Volume control. Press and hold CALL for as long as you want the Call signal to go out on the channel.

A Call signal will be received by users who are listening on the channel that originated the Call signal.



On the BaseStation, an active Talk button is not required to send a Call signal, and the Call signal is routed to the channel selected for monitoring. On the BeltStation, a Call signal is sent only when the Talk button is enabled, and only on the channel(s) selected for Talk.

Stage Announce (SA)

The Stage Announce (SA) function in the Tempest BaseStation is used to send a wireless BeltStation microphone signal to a dedicated external audio output. When a wireless user presses the STAGE button on the BeltStation, their audio is re-routed from the selected intercom channel(s) and is sent to the BaseStation rear panel SA connector. In addition, a relay closure contact is available on the RELAY connector on the back of the BaseStation. Pressing the STAGE button enables the headset microphone, regardless of the status of the Talk buttons. If enabled, all BeltStations can access this feature.

The Stage Announce output connector is an XLR-3M. The Stage Announce connector is balanced and transformer isolated and outputs nominal line level audio from -12 to +8 dBu. The Stage Announce connector output level can be adjusted at the “Stage Announce” menu screen, under “Wired Intercom Settings.”

In addition, the Stage button may be configured to also control an additional relay assigned to the users BeltStation. See the GPO Relay section for more details.

GPO Relay Contacts

Tempest Wireless provides six General Purpose Output (GPO) contact closures. These GPO contact closures can be used for interfacing with other external devices. The Stage Announce (SA) Relay and the five other GPO Relays, enough for each BeltStation to control one, are available through the DA-15 Relay Connector on the back of the Tempest BaseStation. These relays can only be triggered from the wireless BeltStations.

The SA Relay function in the Tempest BaseStation is activated by the STAGE button on the BeltStation. The SA Relay remains closed as long as the STAGE button is pressed.

The user can reassign the following BeltStation buttons and features to control an individual relay uniquely assigned to that BeltStation:


- » Talk A
- » Talk B
- » Ch A
- » Ch B
- » Stage
- » Enter
- » Call
- » Low Batt 10%

The relay is made when the assigned button is pressed and remains closed for as long as the button is pressed. The individual GPO relay can also be triggered by the low battery level alert of the BeltStation. In this case, the relay is made when the battery level of the BeltStation reaches 10% and remains closed until the battery is replaced or the BeltStation is turned OFF.

All relay contacts can support 1 Amp at 30 VDC. The relay completes a circuit. Tempest does not supply any power to the circuit. Since every user will require a custom application, cables for your RELAY connections will require some bench work.

DA-15 Relay Wiring

PIN	Relay #	PIN	Relay #
1	Relay 1	9	Relay 1
2	Relay 2	10	Relay 2
3	Relay 3	11	Relay 3
4	Relay 4	12	Relay 4
5	Relay 5	13	Relay 5
6	Relay SA	14	Relay SA
7	Not Used	15	Not Used
8	Not Used		



Tempest DA-15 Connector

Active Channel Relay

This mode of relay operation can control how all BeltStations on a particular BaseStation function with respect to relays. When active, any TALK button pressed for a respective channel will close the corresponding relay on the BaseStation. For example, if any TALK button on “Ch A” is pressed then “Relay 1” will close. If TALK is pressed on “CH B” then “Relay 2” is closed, “CH C” for “Relay 3” and “CH D for Relay 4.”

BaseStation “Relay 5” may be assigned to any of the existing relay triggers from any or all BeltStations, and the Stage Relay operates normally. It is not possible to exclude any BeltStation(s) from this mode of relay operation once the BaseStation has been set into this mode.

Auxiliary Output

Audio from the Auxiliary OUT Connector can be assigned from any combination of the two intercom channels with Volume control at the “Aux Out Assignment/Levels” menu. Audio from the Auxillary OUT connector comes only from the wireless users and no audio from the hardwired intercom channels is routed to Auxillary OUT.

While in the “Aux Out Assignment/Level” menu, the front panel Channel Select (SEL) button is used to advance through the channels and the OUT level control is used to adjust the Aux OUT volume. Adjust to OFF to restrict audio from a channel.

Audio levels are expressed in Decibels (dB). The audio range for Aux OUT are:

» Aux Out: -12 dB to +12

The Aux IN and OUT connectors are ¼” Tip/Ring/Sleeve jacks that accept standard ¼” TRS plugs. The Aux IN and OUT connections are balanced and transformer isolated and operate at a nominal line level audio of - 4 to + 8 dBu.

Reset Memory

There are three options to reset memory: *Restore Factory Default*, *Clear Memory*, and *Reset Radio Settings*. Both the BaseStation and each BeltStation have a “Factory Default” option in the “Tech Menu.” Browse to the “Tech Menu,” select “Factory Default,” and choose any of the three options. From the BaseStation, “Restore Factory Defaults” only resets BaseStation defaults. BeltStation factory defaults can be reset in each BeltStation and changes are relayed wirelessly to the BaseStation.

Restore Factory Default

This option will restore all settings to factory defaults except pairings and names.



Be aware that restoring factory defaults will have an immediate effect on volume, sidetone, relay selection, Aux In/Out levels, hardwired intercom levels, and Shared Slot settings, among others.

Clear Memory

Occasionally, it may be desirable to remove all previous settings and user defined names, such as when equipment is transferred to a new project or work site. Clear Memory on a BeltStation will require re-pairing of BeltStations. It may be necessary to select a Frequency Band due to country specific RF requirements, on the BaseStation.




This option will restore all settings to factory defaults and will delete all user defined names. All entries will be deleted and there is no “undo”.

Reset Radio Settings

This is a BaseStation feature only. Selecting this option will only reset the Frequency Band to “1,” the Network Number to “0” and the Lockout Key to “255.” The BeltStation radio settings are determined by the BaseStation.

BaseStation Menu



BeltStation Setup

The BeltStation can be configured in three ways. It can be configured by the BeltStation menu, wirelessly by the BaseStation menu, or using the PC interface called T-Desk. While many functions are available through all three methods, certain features are only available through the BeltStation. See *T-Desk manual for details on configuring by PC*.

Configure the BeltStation by the BeltStation Menu

Using a combination of controls and Menu settings, you can set a variety of levels and options directly from the BeltStation controls. The multipurpose “CH A” and “CH B” controls operate differently depending on the mode of the BeltStation. In Operational Mode, rotating the control adjusts the volume of the audio of the local headset connected into the bottom of the BeltStation. Turning the Volume control clockwise increases the audio level while turning the control counter clockwise decreases the level.

Pressing the “CH A” or “CH B” while in “Dual-listen” mode does nothing. In “Single-listen”, pressing the “CH A” controls enables channel A. Pressing the “CH B” knob enables channel B. The intercom channel selected is indicated by the Channel Indicator LEDs located on the outer edge of each talk button, “TALK A” and “TALK B.”

In Menu Mode, turning either Volume control allows the user to scroll through the menu options of the current menu screen. Pressing either control selects the current menu option and is the same as pressing ENTER. A menu item is not selected and will not take affect until the control, or ENTER, is pressed.

For example, to adjust the Sidetone setting:

- Connect a headset to the BeltStation.
- Press MENU to enter Menu Mode.
- Rotate the Volume knob and scroll to “Set Controls.”
- Press ENTER to select, and scroll to “Sidetone.”
- Press ENTER to select the “Sidetone” adjustment.

Sidetone is expressed in Decibels (dB). You will see a level indicator with a numeric value between -30dB to -6dB. You should speak into the headset microphone at a normal speaking level and adjust the sound of your own voice to a comfortable level by rotating either volume knob to adjust the Sidetone level. When satisfied, press ENTER to save the adjustment. Press MENU to move up one level in the menu tree. Press MENU repeatedly to exit Menu Mode and return to Operational Mode. If no other items are selected, Menu Mode will automatically exit and return to Operation Mode after a few seconds.

For additional information on the available BeltStation menu settings, see the menu tree diagram and details in this manual.

Configure the BeltStation by the BaseStation Interface

Many of the settings of the BeltStation can be adjusted wirelessly from the BaseStation. On the BaseStation, press MENU, select BeltStation Settings, and scroll to the required options. This feature allows the communications engineer to control many of the BeltStation’s functions without the need to remove the BeltStation from the user. As an example, to adjust the Battery Alert on a BeltStation from the BaseStation:

- On the BaseStation, press MENU to enter Menu Mode
- Rotate the Volume knob to scroll to “BeltStation Settings” and press ENT.
- Select the BeltStation to be adjusted and press ENT.
- Scroll to “Battery Alert” and press ENT to select the “Battery Alert” adjustment.

You will see options for ON and OFF. Rotate the “Volume” knob to select your preference and press ENTER to select. Confirm the selection on the BeltStation display. Press MENU to move up one level in the menu tree. Press MENU repeatedly to exit Menu Mode and return to Operational Mode. If no other items are selected, Menu Mode will automatically exit after one minute.

For additional information on the BeltStation menu settings, available from the BaseStation menu, see the BaseStation menu tree diagram in this manual.

BeltStation Setup

Steps to Setup the BeltStations

- Install the battery.
- “Pair” BeltStations to the BaseStation.
- Adjust slot settings as needed.
- Connect a headset.
- Adjust Mic Gain.
- Adjust Sidetone.
- Configure optional features:
 - » Name the BeltStation.
 - » Disable unused functions, channels, and buttons.
 - » Select/disable relay options as needed.
 - » Adjust personal preferences.

Battery Selection and Installation

The Tempest BeltStation Battery Compartment holds either one Tempest Lithium-Polymer rechargeable battery or three standard alkaline AA cells. Lithium-Polymer batteries are the primary power source. High quality alkaline AA cells may be used in situations where Lithium-Polymer batteries are not available or are not charged. One Lithium-Polymer battery comes standard with each Tempest BeltStation. Additional Lithium-Polymer batteries may be purchased. Contact your dealer or distributor to purchase additional batteries. The Lithium-Polymer batteries supplied with your Tempest Wireless system are warranted for 90 days from the date of purchase.



Lithium-Polymer batteries offer up to nine hours of battery life and recharge in approximately 2¾ hours.

Lithium-Polymer batteries ship from the factory with approximately 50% charge. It will not damage the Lithium-Polymer batteries to use them without charging them first. This will, however result in shorter run time until the Lithium-Polymer battery is fully charged. When possible, charge Lithium-Polymer batteries to full capacity to ensure full battery life prior to use.

Using (3) alkaline AA batteries can provide up to four hours of battery life. Use only high quality alkaline AA cells. This will provide enough time to fully charge the Lithium-Polymer battery.


To remove the battery door, press down on the thumb markings and pull the battery door toward the bottom of the BeltStation.

To remove batteries from the battery compartment, turn the BeltStation battery side down and tap the bottom of the BeltStation on the palm of your other hand.

Please be careful to insert alkaline AA batteries according to the marked polarity. All of the alkaline AA cells must be oriented the same direction.

If the battery cover does not close properly, the battery may not be inserted correctly.

Charging the Lithium-Polymer Battery



With the Lithium-Polymer batteries installed in the battery compartment, plug the AC end of the supplied 5VDC Charger/Power Supply into a standard AC wall outlet. Open the rubberized access cover on the side of the BeltStation and plug the USB end of the Charger/Power Supply into the USB connector. The Lithium-Polymer batteries will take approximately 2¼ hours to charge from completely empty to completely full. This time is the same with the BeltStation turned ON or OFF. A new, fully charged battery should power a Tempest BeltStation for approximately nine hours.

Fast charging with the supplied fast charger requires a temperature range of 32° – 113° F.

Batteries can receive more than 500 charge cycles, and continue to maintain more than 70% of their power rating. The Tempest battery indicator will maintain its accuracy as battery life decreases.



Alternatively, remove the Lithium-Polymer rechargeable battery from the BeltStation and insert it into the optional 5-Bay Battery Charger. The Lithium-Polymer batteries will take approximately 2½ hours to charge from completely empty to completely full. See the battery charger manual for additional details.


Power Options

The Tempest BeltStation can be powered by:


- » Supplied Lithium-Polymer battery.
- » AA batteries; it is safe to connect a power supply to a BeltStation with AA batteries installed. It will not harm the BeltStation, but will not charge the AA batteries either.
- » Supplied battery charger / power supply.

BeltStation Power ON/OFF

- The Power ON/OFF button is used to turn the BeltStation ON or OFF.
- Press and hold the Power ON/OFF button for two seconds to turn the BeltStation ON.
- Press and hold for four seconds to turn the BeltStation OFF.



Pairing with a BaseStation



Pair BeltStation to BaseStation:

Confirm that the BaseStation is powered ON and in Operational Mode (not in Menu Mode) and that the BeltStation is powered OFF. Confirm that the BaseStation's Network Number and Lockout Key are adjusted as needed. See the section on Set Network Number and Lockout Key.

Plug one end of the pairing cable into the BaseStation and the other end into the BeltStation.

The pairing cable is a standard 3.5mm (1/8 in.) male to male stereo patch cord.



Turn the BeltStation power ON by pressing and holding the BeltStation Power ON/OFF button for two seconds. The pairing process will begin automatically. Watch for the message "Pairing Complete" to appear briefly on the BeltStation display. The BeltStation will automatically re-initialize.



4-channel and 2-channel BeltStations may be paired to either model BaseStation(s); When a 4-channel BeltStation is paired with a 2-channel BaseStation operation of that BeltStation is limited to channels A/B and can only hear one channel at a time.

Adjust BeltStation Slot

The BaseStation Slot Assignment only affects the order that the BaseStation Operational screen displays the BeltStation information when the BaseStation is in the *Static* display mode. If the BaseStation is routinely used as a communication port or for monitoring BeltStations, it may be more convenient to always have the same user appear in the same position on the BaseStation display. This is a personal preference setting.

In the BaseStation "Tech Menu," choose *Static* or *Dynamic* from the "Display Slot Assignments" screen. *Dynamic*, the default, will work without any adjustment, and always displays BeltStations in alpha-numeric order by name.

Static will be the preferred choice for users who are using only one BaseStation and want to ensure that a BeltStation that is logged in will always appear in the same location (slot) on the BaseStation display. When selecting *Static* slot assignments, you must also enter the Tech Menu for each BeltStation and assign each BeltStation a different slot (1 – 5).

The BaseStation default is for *Dynamic* Slot Assignment. This means that when BeltStations log in to a base, the information about the BeltStations is displayed on the BaseStation LCD screen in alpha-numeric order according to the name of the BeltStation. For example, "Dir" appears before "Light1," which appears before "StgMgr," but they can change slots depending on which BeltStations are turned ON. If the default settings are used, nothing is necessary. If the BaseStation is located in an equipment room and is not routinely used as a communication port or to manage BeltStations, nothing is necessary.

Adjusting so that each BeltStation always appears in the same position of the BaseStation display is a two step process:

1. Advance to the BaseStation's "Display Slot Assignment" section of the "Tech Menu" and select *Static*.
2. In each BeltStation, advance to the "Base Slot" section of the "Tech Menu" and adjust each BeltStation to a different slot (1 – 5). The BeltStation designated to slot 1 will always appear on the far left of the BaseStation display, with slot 2 appearing in the next position to the right, and so on.

In *Static* Mode, if a BeltStation is not turned ON, or is logged out due to being out of range, the BaseStation LCD will display a very obvious "X," making it easy to see at a glance which BeltStations are currently active.

A Multiple BaseStation system that uses iSelect Roaming must choose to use "Dynamic" slots to ensure that BeltStations can move from BaseStation to BaseStation when roaming.

Name Equipment

Name the BaseStation with a descriptive name which will appear on the BeltStation LCD display. This is most helpful when iSelect Roaming will be used to roam between BaseStation coverage areas. The BaseStation name can include up to 14 characters.

Name each BeltStation with a descriptive name. Until the name is changed, a hexadecimal serial number is displayed. The first six characters of the BeltStation name will be displayed on the BaseStation LCD display. Naming is a personal preference option and is not essential.

Personal Preferences

To configure each BeltStation, adjust any of the following to suit individual needs. None of these adjustments are required. *Note that more options are available under the "Set Controls" menu and become visible by scrolling.*

- "Lock Keys" to prevent inadvertent changes.
- "Menu Lock" allows you to lock individual users out of their respective BeltStation menu. Access can only be regained by entering a 3-digit security key code initially set at the BaseStation.
- Disable "Battery Alert" to prevent the battery alert tone in the headset.
- Dim the LCD and LEDs to be less conspicuous in a dark environment.
- Limit talking to push-to-talk mode by selecting *Momentary*. *Latch* is the default.
- Disable the ability to talk on any channel, but allow listening.
- Disable the ability to access any channel not required.
- Adjust minimum and maximum volume levels. In loud environments a higher minimum volume may be desirable, while in quiet environments a lower maximum volume may be preferable.
- Volume controls can be set to "Volume Press" which requires a "press and turn" action to adjust the volume levels. This helps prevent inadvertent adjustments.
- When Stage Announce functionality is enabled in the BaseStation, the STAGE button can be disabled for individual BeltStations.
- The CALL alert can be set to *Audible*, *Vibrate*, *Both* or *Disable*. The default is *Both*. A call signal can be initiated by the CALL button or the TALK button, depending on your preference.
- When relay functionality is enabled in the BaseStation, select the relay to be activated by the BeltStation. Then select the BeltStation trigger that will activate the relay.
- Wireless ISO can be disabled, if desired.

Call Function

There are two call methods available in Tempest. The first uses the CALL button to send call signals to any BeltStation or hardwired user on the active channel. The second method is referred to as “Call On Talk” and uses the BeltStation TALK button to initiate a call signal. However, the “Call On Talk” feature works independently from all other BaseStation call settings and can be used to send call signals through intercom channels to attached radios or matrix.

To enable the CALL button, press MENU, select “Set Controls,” select “Call Button,” and select *Enable*. This is the default setting.

To set the “Call Alert” preference, press MENU, select “Set Controls,” and select “Call Alert.” Choose to receive a call signal alert with an *Audible* tone in the headset, or with a *vibration* of the BeltStation or *Both*. The default setting is *Both*.

To initiate a call, select a channel for talking with the CH A or CH B buttons and activate the TALK button. Press and hold CALL for as long as you want the call signal to go out on the channel. A call signal will be received by users who are listening on the same channel that originates the call signal.

To enable the “Call on Talk” feature, press MENU, select “Set Controls”, then “Talk Buttons”, then “HW Call on Talk”, and select *Enable*. The default setting is *Disable*.



A call signal from the CALL button is sent only when the Talk button is enabled, and only on the channel selected for Talk.

Program Volume Control

Auxiliary IN can be used to bring program or other audio into the Tempest BaseStation. Audio from the Aux IN port is routed only to wireless users and is not routed out to the hardwired system.

Program Volume allows each BeltStation to control the mix of program audio (Aux IN) it receives from the BaseStation.

To enable “Program Volume”, press MENU, then “Set Controls”, then “Program Volume” and select one of three options:

1. Off - the BeltStation receives no program audio.
2. Absolute - the BeltStation receives program audio at a level independent of the intercom levels.
3. Relative - the BeltStation receives program audio at a level relative to the maximum intercom volume setting, regardless of channel. Scroll to the option that applies to your application and press ENTER to save. Your selection will be indicated with a checkmark to the left of the selection.

To adjust the Program Volume on the BeltStation, hold the ENTER button and then turn either of the volume knobs. The display screen will display “Program Vol” and the numeric level of the volume.



When “Relative” is selected, the program volume is relative to the highest level intercom channel on the BeltStation. Thus, when listening to program audio when intercom volume on channel A was at 15 and channel C was at 10, the program volume would be 15. If that intercom level is lowered below 10, then your new program volume would then correspond to channel C’s volume level (10).

Set Mic Gain

Set the Mic Gain properly to ensure the best audio quality. To set the Mic Gain for the BeltStation Headset:

1. Press MENU to enter Menu Mode. From the Main Menu, select “Set Controls,” then “Mic Gain.”
2. While at the Mic Gain screen, talk into the headset microphone at a louder than normal level and adjust the Volume control until the PEAK LEDs just start to light at the loudest parts of the audio. Press ENT to accept the changes.

Mic Gain can be set in the BeltStation without activating the Talk button. This allows private mic gain adjustment during live events. The Mic Gain can be set for each BeltStation from the T-Desk application.

When the Mic Gain is set too high, it is possible to induce feedback or echo. When set too low, words can be clipped by the low level noise gate or sound too quiet to other listeners. Headsets by different manufacturers or different models of headsets will require widely varying Mic Gain settings. When setting microphone gain, it is best to err toward a setting that is too low, rather than too high. This will help reduce unwanted echo in the system when that microphone is enabled.

iSelect Roaming – Selecting a BaseStation

Installations with multiple BaseStation coverage zones often require users to move from one work zone to another throughout the day. One of the ways Tempest handles these transitions is with iSelect™ On-Command Roaming. Using iSelect, a user can easily change their communication from one BaseStation to another BaseStation in just a few seconds.

- Confirm that the BeltStation has been paired with all required BaseStations.
- Confirm that there is an available slot on the desired BaseStation. If no slot is open, power OFF one of the connected BeltStations, wait for 15 seconds, and proceed.
- Press MENU and select “Select Base.” Scroll to the desired BaseStation and press ENTER. Press MENU to exit.

Tempest Wireless BeltStations remember the last 64 BaseStations to which they have been paired.

Seamless Roaming - BeltStation Configuration

Installations with multiple BaseStation coverage zones often require users to move from one work zone to another throughout the day. Unlike iSelect Roaming, Seamless Roaming allows users to roam freely from one zone to another without any manual adjustment on their part. The BeltStation will decide when it is time to change from one coverage zone to another.

- Confirm that the BeltStation has been paired to all the required BaseStations in the designated coverage zones.
- Set up each BeltStations Roaming Group. Press MENU, select “Roaming,” then “Roaming Group,” and then scroll to and select each BaseStation that should be included in the group. To select, press ENT when cursor is next to BaseStation name. Up to 16 BaseStations may be selected.
- To enable roaming, Press MENU, select “Roaming,” then “Roaming Group,” and select *Enable Roaming*. This will enable the BeltStation to roam to all selected BaseStations. When not enabled, the BeltStation will operate as a normal BeltStation on one single BaseStation.
- To disable roaming, simply select a single BaseStation from the list.

The Roaming Bias adjusts the parameters that determine when a BeltStation will seek out a new BaseStation. A BeltStation’s roaming decision is driven by a combination of link quality and time. It is recommended that Medium, (the default setting), be used in most cases when setting up the system.

To Adjust the Roaming Bias (if needed), press MENU, select “Roaming,” and set Roaming Bias to one of the following:

- *High*: Looks more frequently for other BaseStations in the Roaming Group.
- *Medium*: Default setting for Seamless Roaming
- *Low*: Looks less frequently for other BaseStations in the Roaming Group.


Wireless ISO

Wireless ISO (isolate), sometimes referred to as wireless talk-around is a wireless-only intercom feature that allows communication among wireless BeltStations only. When a wired intercom system is connected, Wireless ISO communicates through the wireless portion of the system only. The BaseStation front panel headset does not receive ISO audio.

Wireless ISO is enabled by default and is **available only on channel A**. It is activated by pressing and holding ENTER. ENTER enables the headset mic regardless of the “TALK A” button.

Wireless ISO only operates in Operational mode. It does not operate in Menu mode.


BeltStation Menu



Wired Intercom Interface to the BaseStation

Each of Tempest's two hardwired intercom channels can interface with a 4-Wire matrix intercom or a 2-Wire party-line intercom. Tempest supports a 4-Wire intercom interface to most major digital matrix intercom systems and other intercom 4-Wire devices. Tempest also interfaces with 2-Wire intercom systems including Clear-Com, RTS, and AudioCom (BAL) systems, as well as compatible brands. Each Tempest intercom channel can interface with one intercom system at any given time.


While it is possible that both 2-Wire and 4-Wire systems may be connected to the same intercom channel simultaneously, they cannot function at the same time, and this arrangement has the potential to cause undesirable operational complications, so is not recommended.



Tempest BaseStation Wired Configuration Controls for Connection to Wired Intercom Systems

These controls will normally be used together to configure the Tempest BaseStation for 2-Wire or 4-Wire operation.

- CHAN A has been set for no wired intercom connection – the LEDs are OFF.
- CHAN B is set for Clear-Com 2-Wire intercom connection. The upper slide switch is in the middle position and the 2-Wire LED aligned with CHAN B is illuminated.



Tempest BaseStation LCD display for IN and OUT adjustment

Use the IN and OUT controls to adjust the levels on the selected channel.
In this diagram, Channel A, 2-Wire levels are selected for adjustment

Controls



The 2-Wire Intercom Type Select Switch determines the type of 2-Wire intercom that may be connected to the corresponding 2-Wire connectors on the rear panel of the BaseStation. Clear-Com, RTS, or BAL (AudioCom) can be selected. These switches only affect 2-Wire operation and do not control 4-Wire operation. The CHAN A&B switch selects the 2-Wire system type for both the A and the B intercom channels.

Always set the 2-Wire Intercom Type Select Switches prior to connecting the 2-Wire intercom to the back of the Tempest BaseStation. Never change the switch setting while connected to a wired intercom system. Failure to follow this procedure could damage the Tempest BaseStation or the 2-Wire hardwired system.




The Intercom Channel Select (SEL) button selects one of the two intercom channels to allow selection of 2-Wire or 4-Wire functionality and to allow the intercom audio IN and OUT levels to be adjusted.

Pressing the Intercom Channel Select button once selects Menu Mode on the BaseStation and displays the Intercom Levels screen on the LCD display. A second press selects channel A. The intercom channel selected is indicated by one of the two CHAN LEDs located to the right of the CHAN SEL button and on the LCD screen. Additional presses of the CHAN SEL button advances through the remaining intercom channels. The next press of the CHAN SEL button will exit Menu Mode and will cause all of the LEDs to be illuminated.



The 2-Wire/4-Wire Select (SEL) button selects the connection mode for operation of each of the two intercom channels. Pressing the 2-Wire/4-Wire Select (SEL) button changes the selected intercom mode between 2-Wire, 4-Wire or no wired connection. In Operational Mode, the four 2-Wire/4-Wire LEDs indicate the currently selected hardwired intercom connection mode for each of the intercom channels: 2-Wire, 4-Wire, or no wired intercom connection.



The IN and OUT controls adjust the intercom volume level coming in to the Tempest BaseStation from the hardwired intercom system or out to the hardwired intercom from the BaseStation. In addition, these knobs adjust Aux IN/OUT levels.

To adjust the levels, press the CHAN SEL button to enter Menu mode, CHAN SEL again to advance to the desired channel and rotate the IN or OUT controls. Note that the LCD display indicates the currently selected levels.

Intercom Channel volume levels are expressed in Decibels (dB):

- » 2-Wire IN: -13.5 to +10.5 2-Wire OUT: -10.5 to +7.5
- » 4-Wire IN: -18 to +4 4-Wire OUT: -6 to +12


4-Wire (Matrix) Intercom Interface

4-Wire intercom systems use two pairs of wires to carry one full duplex channel of intercom audio - one pair for send and the second pair for receive. In addition to intercom audio, most systems have separate data lines that carry system data from the matrix to the remote devices. The Tempest 4-Wire connection is an audio-only interface to 4-Wire systems. Data can be present on the input cable but no data is utilized in the Tempest BaseStation.

Steps to Configure a 4-Wire Intercom Connection

- Select 4-Wire connection for the appropriate channels.
- Make the physical connections with RJ-45s to the Tempest BaseStation and the 4-Wire system.
- Configure the 4-Wire system to recognize the Tempest Wireless system.
- Adjust IN/OUT volume levels between the Tempest Wireless System and the 4-Wire system as needed.

Connect the 4-Wire intercom system to the desired channel RJ-45 jack on the rear panel of the Tempest BaseStation. Select the 4-Wire setting as described in “Wired Intercom Configuration Controls.” That is all that is necessary for Tempest to be ready to communicate with the 4-Wire system. Perform any necessary configuration for the 4-Wire intercom System and the communication link should be complete.




The top RJ-45 jack is for Channel A and the bottom RJ-45 jack is for Channel B.

You may choose to adjust the IN/OUT levels on the front of the BaseStation if the volume level between the systems is not acceptable.

Wiring schemes vary and it is important to ensure that the cable is wired correctly for proper system operation. Tempest utilizes RJ-45 jacks for 4-Wire connection to the BaseStation. Only two pairs of wires are utilized - one to send audio and one to receive audio. A standard CAT-5 patch cable can be used to connect between the matrix and the Tempest system.

Tempest 4-Wire / RJ-45 Connection

Pin #	Use
1	No Connection
2	No Connection
3	Audio Output (+)
4	Audio Input (+)
5	Audio Input(-)
6	Audio Output (-)
7	No Connection
8	No Connection



2-Wire (Party-Line) Interface

2-Wire party-line intercom systems carry one or two (depending on the system type) channels of full duplex intercom audio, plus system power and other information on a single XLR-3M cable (2 wires and a ground). Each 2-Wire intercom type has a different wiring scheme and unique line characteristics. It is imperative to have the rear panel connections and the front panel settings adjusted correctly for audio to pass correctly between the systems.

Steps to Configure a 2-Wire Intercom Connection

- Adjust the Intercom Type Slide Switches to appropriate manufacturer compatible setting- RTS, Clear-Com, Bal.
- Select 2-Wire connection for the appropriate channels.
- Make the 3-pin XLR physical connections to the Tempest BaseStation and the 2-Wire system.
- Null the system.
- Adjust IN/OUT volume levels between the Tempest Wireless System and the 2-Wire system.

Always confirm that the 2-Wire intercom system is functioning properly before connecting the Tempest Wireless system. Test each wired communication station before connecting the wireless system. Confirm operation of the wireless system before connecting to the wired system.

After the slide switch is set correctly, the appropriate channels are set for 2-Wire operation, the XLR cable connections are made, and power is provided by the 2-Wire system or Master Mode, then audio will pass between Tempest and the wired system.

Audio may develop an echo that is heard in the wireless BeltStations until the system is nulled. The echo should not prevent communication but is undesirable. The volume levels into or out from Tempest may need adjusting so that relative volumes are the same.

Echo Cancellation Menu

In the BaseStation's Tech Menu is a selection for "Echo Cancellation" (ECAN). This refers to software that assists in removing echo from 2-Wire intercom connections. Hardware connections need to be optimized with the null procedure to minimize echo in the physical link so that the software can remove any residual echo.

In the Tech menu, "Echo Cancellation" is "ON" by default, but is only enabled for channels that are selected for operation with a 2-Wire intercom and have a physical connection to a 2-Wire system. See "Nulling" Section of this manual.

If a 2-Wire intercom is never utilized in a system, ECAN can be turned "OFF" to ensure that it cannot create undesirable effects. This should not be necessary, though, and it is recommended that you keep ECAN "ON" at all times.

ECAN is disabled while the BaseStation's Auto-Null or Manual Null menu screens are active, to ensure that the hardware is optimized for echo reduction. When ECAN is enabled, it requires up to 10 seconds of active audio to achieve maximum efficiency. Brief loud active audio can help accelerate efficiency.

Auto-Null Explained

In 2-Wire intercom systems, inefficiencies in the hybrid circuitries that combine or separate the send and receive audio signals onto the same pair of wires inherently cause echo. Within analog systems the echo is not noticeable, but when connected to an extremely sensitive digital system, the echo becomes more problematic.

In order to minimize echo resulting from connection to an external 2-Wire system, it is necessary to optimize the hardware of the hybrid circuitry in the Tempest BaseStation. Tempest provides a user initiated AUTO-NULL feature that automatically optimizes the 2-Wire interface. Nulling only impacts 2-Wire hardwired intercom connections.

Auto-Null sends a tone to each of the 2-Wire intercom channel connections. The Tempest Wireless BaseStation DSP monitors the echo and adjusts the line characteristics (Resistance and Capacitance) to optimize the interface to the external 2-Wire system. When Auto-Null is initiated, all of the functions of the BaseStation including communication are interrupted. The Auto-Null process takes approximately 10 seconds. Intercom levels may need to be adjusted after the 2-Wire intercom lines have been nulled.



During Auto-Null, wired intercom users will hear the nulling tones and communication will be interrupted. It is recommended that this feature should be used only during setup and not during live events.

Auto-Null Procedure

Turn OFF all TALK buttons on both the wired and wireless systems. Since Tempest monitors a self generated tone to adjust the null characteristics, any sounds entering through either the wired or wireless intercom systems will interfere with the nulling process. When the Auto-Null or Manual Null menu screens are accessed, Tempest sends a Mic Kill signal to all wireless BeltStations, but the wired communication stations will need to be turned OFF individually, or a hardwired Mic Kill signal will need to be initiated.

On the Tempest BaseStation press MENU to open the Main Menu. Rotate the Volume Control to scroll through the menu options to the “Wired Intercom Settings” and select “Auto-Null.” Select “Null Now” to start the Auto-Null process. Normal functions will be interrupted for about 10 seconds during the Auto-Null process. Progress of the null process can be observed on the BaseStation LCD display.

The BaseStation display will indicate “Auto-Null Complete” once the Auto-Null process is completed. Press MENU to escape to the Operational screen.

Activate Auto-Null for new connections or whenever the 2-Wire system changes significantly, such as when additional wired belt packs are added or removed, or when cable lengths are changed significantly.

Test for Echo

Talk into the wireless system for at least 10 seconds to test for echo. Echo Cancellation (ECAN) software is disabled in the Auto-Null and Manual Null screens to ensure the best hardware null. Press MENU to exit the nulling menu screen, and to enable ECAN. When ECAN is first enabled, it requires up to 10 seconds for it to achieve convergence. There will usually be some noticeable echo during the first few seconds of testing, but it will diminish over time as the ECAN software converges to an inaudible level. Brief louder active audio can help accelerate efficiency.



If multiple BaseStations are connected by 2-Wire intercom connections, each BaseStation must be nulled separately. Null one BaseStation at a time.

Manual Null

Generally, Auto-Null will adequately control the inherent echo caused by the 2-wire hybrid circuitry. However, “Manual Null” is available if there is residual echo.

If echo persists after testing for at least 30 seconds:

1. Turn OFF all TALK buttons on wireless and wired equipment. Since Tempest analyzes a tone to adjust the Null characteristics, any sounds entering through the wired or wireless systems will interfere with the nulling process.
2. Press MENU and advance to the “Manual Null” screen.
3. Press CHAN SEL to advance to the desired channel.
4. Rotate the “IN” knob to adjust the “RBAL” null value until the “Amplitude” is minimized.
5. Rotate the “OUT” knob to adjust the “CBAL” value until the “Amplitude” is minimized.
6. Repeat the “RBAL” and “CBAL” adjustment. The repeat process and order of adjustment of the process is important because the “CBAL” adjustment is most effective when the “RBAL” is close to its absolute minimum.
7. Once the best null is achieved, turn the “IN” knob clockwise to add six to the “RBAL” value. For example, if the minimum “RBAL” value is 123, adjust to 133.
8. Exit the Manual Null screen. Test for echo for at least 10 seconds. It will take up to 10 seconds for echo cancellation software to achieve maximum efficiency.

If the echo is not acceptable, use the IN knob to adjust the “RBAL” null value up one and test again. If necessary, turn the “RBAL” value down two and test again. Continue with this trial and error method until the echo is minimized.

Manual Null requires each channel to be nulled individually. Return to the Null Screen and press CHAN SEL to advance to the next channel. Repeat for all channels.

Other Causes of Echo




Please be aware that echo can be caused by several sources. A type of echo referred to as acoustic echo can be caused by another user’s headset, but is inaudible to that user. Have other users turn OFF their TALK button and determine if the echo stops. Acoustic echo is minimized by software resident in each BeltStation. Acoustic echo may be mitigated by decreasing the mic gain, sidetone or volume on the headset causing the echo. Occasionally, it is necessary to replace headsets that continually cause unacceptable echo.

If a user removes his headset, the Mic may detect and repeat the sound from the earpiece. Whenever a headset is removed, always turn OFF the Talk function.

2-Wire Wiring Schemes

Wiring schemes vary, and it is important to ensure that the cables are wired correctly for proper system operation. When Tempest is configured for a particular manufacturer's system, Tempest routes the signal to internal circuitry that conforms to the requirements of that system. The 3-pin XLR connectors on the back of the Tempest BaseStation can have very different characteristics depending on the setting of the slide switch, as can be seen in the table below.

3-Pin Wiring Scheme and Line Characteristics

 <p>MALE</p>	<p>Clear-Com</p> <p>1 COMMON 2 POWER 3 AUDIO</p>	<p>Input Impedance 200Ω Output Level 1.0 Vrms Bridging Impedance >10 kΩ Call Signaling: Send 12 ±3 VDC Receive 4 VDC Min Power voltage 30.0 VDC</p>
 <p>MALE</p>	<p>AudioCom</p> <p>1 COMMON 2 AUDIO(-) & POWER 3 AUDIO(+) & POWER</p>	<p>Input Impedance 300Ω Output Level 1.0 Vrms Bridging Impedance >10 kΩ Call Signaling: Send 20 kHz ±100 Hz, 5 mVrms Receive 20 kHz ±800 Hz, 100 mVrms Power voltage 24.0 VDC</p>
 <p>MALE</p>	<p>RTS</p> <p>1 COMMON 2 AUDIO 1 & POWER 3 AUDIO 2</p>	<p>Input Impedance 200Ω Output Level 0.775 Vrms Bridging Impedance >10kΩ Call Signaling: Send 20 kHz ±100 hz, 240 mVrms Receive 20 kHz ±800 Hz, 100 mVrms Power voltage 28.0 VDC</p>

Note for 2-Wire RTS Users: RTS TW (2-Wire) systems support two intercom channels on a single XLR cable. When connecting an RTS TW system, only one cable is required for two intercom channels. When set to RTS mode, both of the 3-PIN XLR connectors (2 male and 2 female) for channels A&B are paralleled together. RTS intercom channel 1 is placed on Tempest intercom channel A, and RTS channel 2 is placed on channel B. **Note for 2-Wire Clear-Com and Balanced (Audiocom) Users:** For Clear-Com and Balanced 2-Wire intercoms, use the A and B male or female 3-pin (XLR-3M/F) connectors on the rear panel to connect up to two intercom channels. The male and female connectors for each channel are loop-through connections and are the same point electrically. Each channel of a Clear-Com or Balanced 2-Wire system requires one separate cable for connection to one Tempest channel.

Modes of Operation

Tempest Wireless BaseStations offer 3 modes of operation: Normal, Shared, and Split Mode. The mode of operation can be set by going into menu mode on the BaseStation. Press MENU and select “Mode Settings,” then “Operational Mode.”


Note: In addition to the BaseStation, the BeltStations must be set into “Shared” mode to use with either Shared or Split modes of operation.

Normal Mode

In Normal mode, users can have up to 5 BeltStations (per BaseStation). All BeltStations in this mode are in the standard operating mode, giving the user control of the channels on which they operate and dual listen/talk functionality at any given time.

- » Each BeltStation has dedicated anytime talk back capability.
- » BeltStation talk buttons may be operated in either momentary or latching mode.
- » Sidetone may be set individually for each BeltStation from -6dB to -30dB.
- » Full BeltStation telemetry is available real-time at the BaseStation and T-Desk; these settings can be adjusted from the BaseStation and/or T-Desk.

Normal BaseStation Mode




Shared Mode

The Shared mode utilizes only BeltStations set into “shared” mode via the BeltStation menu. This mode allows an unlimited number of BeltStations to listen, but only 5 shared BeltStations can talk (in momentary mode) at any given time; however, they can control the channels in which they operate.

- » BeltStations are inherently full duplex (talk/listen at the same time); “Shared BeltStations” are physically no different than a normal BeltStation.
- » Shared BeltStations operate in momentary talk mode; no more than 5 talk paths may be used at any given time.
- » Each BeltStation is capable of features such as Stage Announce, Wireless ISO, and Relays; however, each action utilizes one of the five available talk paths so long as it is triggered.
- » Shared BeltStations are unable to provide telemetry to the BaseStation or T-Desk, thus no BeltStation settings can be adjusted from the BaseStation or T-Desk.
- » Volume of the BeltStation that is actively talking is dynamically reduced to minimize the effect of echo.


Shared BaseStation Mode



Split Mode

In Split mode, users are operating in a combination of Normal and Shared mode. This mode offers the use of 4 BeltStations (per BaseStation) that utilize the standard anytime talk back capability and allows an unlimited number of “shared” BeltStations to listen and talk on the final slot. In this mode, shared BeltStations have no control over which channel they operate on. The channel is designated at the BaseStation.


- » Unlimited number of (shared) BeltStations may be used in addition to the 4 BeltStations operating in Normal mode; BeltStations are inherently full duplex (talk/listen at the same time) and are physically no different than a BeltStation operating in Normal mode.
- » Shared BeltStations operate in momentary talk mode; only one shared BeltStation may utilize the talk function at any given time.
- » Each BeltStation is capable of features such as Stage Announce, Wireless ISO, and Relays; however, each action takes up the only shared talk path so long as it is triggered.
- » Shared BeltStations are unable to provide telemetry to the BaseStation or T-Desk, thus no BeltStation settings can be adjusted from the BaseStation or T-Desk.
- » Volume of the BeltStation that is actively talking is dynamically reduced to minimize the effect of echo.



Feature or Function	Normal	Split Mode	Shared Mode
Number of Fully-Registered BeltStations (FRB)*	up to 5	up to 4	None
Number of shared belts	None	Unlimited	Unlimited
Number of talk-back paths	1 per belt	1 per Belt FRB / 1 for all shared	5 for all Belts
Full-duplex audio	Yes	Yes	Yes
Talk button may be set to latch	Yes	Yes FRB / No shared	No
Channel selectable at BeltStation	Yes	Yes FRB / No shared	Yes
Dual listen/talk	Yes	Yes FRB / No shared	Yes
Locally generated sidetone in BeltStation	Yes	Yes FRB / No shared	No
Individual sidetone adjust per BeltStation	Yes	Yes FRB / No shared	No
BeltStation sidetone heard via return audio	No	No FRB / Optional shared	Optional
Dip in BeltStation listen level when talking	No	No FRB / Yes shared	Yes
BeltStation LCD shows BaseStation name	Yes	Yes	Yes
BeltStation LCD shows RF signal strength	Yes	Yes	Yes
Receive call	Yes	Yes	Yes
Initiate Call	Yes	Yes FRB / Yes shared, uses talk-back	Yes, uses 1 talk-back per
Stage announce audio / relay	Yes	Yes FRB / Yes shared, uses talk-back	Yes, uses 1 talk-back per
Wireless ISO	Yes	Yes FRB / Yes shared, uses talk-back	Yes, uses 1 talk-back per
Relay operation	Yes	Yes FRB / Yes shared, uses talk-back	Yes, uses 1 talk-back per
Adjust BeltStation settings from BaseStation / T-Desk	Yes	Yes FRB / No shared	No
Telemetry info from BeltStation on BaseStation & T-Desk	Yes	Yes FRB / Only when Belt talks	Only when Belt talks

*Fully-Registered BeltStations (FRB) are BeltStations that operate in anytime talk back and listen functionality and offer full telemetry to and from the BaseStation.

Connecting Multiple BaseStations



Tempest BaseStations may be used together to form large wireless systems, and may include external wired intercom systems. Intercom audio for any or all channels can be linked across multiple BaseStations. Audio from one BaseStation can be passed via a 2-Wire connection to another BaseStation, if they are to share a single channel of audio. Through this method, many complex combinations of intercom channels can be achieved.

All RF devices have the potential to cause interference. Therefore, Tempest offers two synchronization options, Accu-Sync™ and ZSync™, that are designed to minimize potential interference when using multiple BaseStations.

Accu-Sync is included with every Tempest BaseStation and uses the Accu-Sync connections on the back of the BaseStation to synchronize multiple BaseStations together. See the Accu-Sync section on for more information on using Accu-Sync.

Zero Sync (ZSync) technology has been developed to enable Tempest's Seamless Roaming feature as well as greatly enhance the performance of non-roaming multi-BaseStation Tempest installations. The ZSync technology provides a more sophisticated form of BaseStation synchronization over the older Accu-Sync technology. To utilize ZSync technology either a Zero Sync Generator or a Parallel Zero Sync Generator is necessary to act as the source of the ZSync signal. These devices are sold separately. All Tempest BaseStations continue to support and provide Accu-Sync synchronization signals. It is, however, strongly recommended that ZSync technology be used whenever there is a multiple BaseStation configuration.

Tempest includes a Master Mode which provides required audio power when only Tempest BaseStations are linked without external intercom. See the Master Mode section.



If intercom channels are connected across multiple BaseStations without connection to an active 2-Wire intercom, one of the BaseStations must be placed into Master Mode.

A multi-base system will generally utilize Tempest Remote Transceivers to distribute the wireless signal, sometimes extending the number of users by overlapping the wireless coverage area, and sometimes extending the wireless range with the iSelect Roaming feature. In this application, always try to separate antennas by at least 10 feet whenever possible.



If multiple BaseStations are linked on a common audio channel, each BaseStation must be nulled separately. Null one BaseStation at a time.

A 4-Wire matrix intercom system may be configured to connect to multiple Tempest BaseStations so that all share the same channels. Configure each BaseStation individually as described in 4-Wire (Matrix) Intercom Interface. The following information relates to multiple BaseStation configurations without a matrix system.

Steps to Configure a Multiple BaseStation System

- Locate and configure antennas to minimize RF interference.
- Make Accu-Sync or ZSync connections.
- Make 2-Wire Connections.
- Configure for the appropriate 2-Wire connections.
- Null each BaseStation.
- Adjust IN/OUT levels if necessary.

Audio Connections for Multiple BaseStations

When using multiple Tempest BaseStations, it is often desirable to share the same communication channels across some or all BaseStations. To accomplish this, 2-Wire intercom connections must be made between the BaseStations.

It is advisable to configure the Accu-Sync option prior to making the audio connections.

There are two specific modes of operation when using this feature.

When an external hardwired intercom system is NOT present:

Tempest is designed to use any connected 2-Wire intercom system's power source and termination to power the BaseStation's internal hybrid circuitry. When no hardwired system is present, Tempest uses a feature called Master Mode to power and terminate this circuitry. Audio will not be shared among the BaseStations until one of the linked BaseStations is set to Master Mode.

Master Mode only functions when there is no 2-Wire hardwired intercom system connected. If there is a hardwired intercom connected to any channel of any of the shared Tempest BaseStations, Master Mode will automatically disengage and only channels connected to the hardwired intercom system will continue to be shared.

In Master Mode, the number of Tempest BaseStations that can be linked is only limited by RF factors, which is impacted by antenna location and other environmental factors. Widely distributed antennas may permit up to 10 BaseStations to be linked.



The 2-Wire Intercom Type Select Switch on the Tempest BaseStation front panel must be set to "ClearCom" for Master Mode to function.

Using the 3-PIN XLR male or female connectors on the back of the BaseStation, connect the intercom channels of each BaseStation that will share audio.

Set any one of the BaseStations to Master Mode "On." It is only necessary to set one BaseStation to Master Mode. Master Mode settings are found at the "Set Base as Master" screen under the "Multi-Base Settings" of the Main Menu.

Once one BaseStation is in Master Mode, audio will be shared among all BaseStations that are connected to that intercom channel. Lines must be nulled for proper operation.

When an external 2-Wire hardwired intercom system IS present:


Set the 2-Wire Intercom Type Select Switch to the proper type and select 2-Wire mode. Connect the hardwired intercom to the BaseStation. In this configuration, each connected Tempest BaseStation intercom channel will receive power and termination from the wired intercom system. The Tempest BaseStation functions as an additional wired belt-pack from the perspective of the connected 2-Wire system.

Connect either male or female (male and female connectors are electrically identical) 3 pin XLR from the 2-Wire intercom channel to be shared, to the BaseStation that will use the intercom channel. Loop to other BaseStations as needed. Repeat for all channels to be shared. See the Wired Intercom Interface section in this manual for more information about connecting to external wired intercom systems.



When using an external 2-Wire hardwired connection, only channels that are connected to a wired intercom will be able to share audio between BaseStations.

Accu-Sync



Three BaseStations Accu-Synced

Accu-Sync provides a common timing signal between connected BaseStations. This signal ensures that transmission cycles for all Accu-Synced BaseStations occur simultaneously. This synchronized transmission eliminates the negative RF effect called desensing. See the following section, “Special RF Considerations for Multiple BaseStations,” for more information on connecting multiple BaseStations.

When two or more Tempest BaseStations are to be operated in the same location, connecting the BaseStations via the BaseSync connector on the back of the BaseStation, minimizes potential RF interference between BaseStations. The more BaseStations there are in close proximity to each other, the more important it is to use Accu-Sync.

One BaseStation must always act as the sync source when using Accu-Sync. The sync source is any BaseStation that does not have a BaseSync cable plugged into the BaseSync IN connector. Always ensure that one, and only one BaseStation has an open (no connection) BaseSync IN connector.


When a BaseStation does not have a BaseSync cable plugged into the BaseSync IN connector, that BaseStation uses an internally generated timing pulse to control its own transmission cycle.

When a BaseStation has a BaseSync cable plugged into the BaseSync IN connector, that BaseStation uses the external sync signal (timing pulse) to control its transmission cycle.

The BaseSync cable is a DE-9F To DE-9M wired straight through on pins 1-5. The maximum distance a BaseSync cable can be is 1,500 feet (457.2 m).



Never connect Accu-Sync cables between 2.4GHZ and 900MHz Tempest models.



BASESYNC IN

Accu-Sync - DE-9 Connector

ZSync Technology

Zero Sync (ZSync) technology has been developed to enable Tempest's Seamless Roaming feature as well as greatly enhance the performance of non-roaming multi-BaseStation Tempest installations. The ZSync technology provides a more sophisticated form of BaseStation synchronization over the older Accu-Sync technology. To utilize ZSync technology either a Zero Sync Dongle or a Parallel Zero Sync Generator is necessary to act as the source of the ZSync signal. These devices are sold separately. All Tempest BaseStations continue to support and provide Accu-Sync synchronization signals. It is, however, strongly recommended that ZSync technology be used whenever there is a multiple BaseStation configuration.

With traditional Accu-Sync technology, BaseStation transmit/receive cycles are coordinated so that all of the BaseStations are transmitting at the same time. This prevents one transmitter from desensing nearby receivers. Traditional Accu-Sync does not, however, coordinate anything in the frequency domain. ZSync technology combats turn-on to turn-on variation by providing a zero sync reference that coordinates the hopping patterns of all connected BaseStations. ZSync technology ensures that, in addition to transmit/receive timing, there is a fixed relationship between all of the BaseStation's radio frequencies every time the system is powered up irrespective of random time variation in power-up sequences. Assuming that the Network Numbers for the BaseStations have been set properly, there will be virtually no unit to unit interference even with up to 11 BaseStations in a system when using ZSync. This is true for roaming as well as non-roaming applications.

In addition, in roaming configurations, ZSync allows the BaseStations to know exactly what frequency a given BaseStation is operating on at any given time. This allows for very fast detection and switching from one BaseStation to another. The use of ZSync technology is required for all roaming applications.

Pre-Requisites

- All Tempest Wireless equipment (roaming or non-roaming) must have Radio firmware version 1.18 or higher to fully utilize ZSync. Tempest equipment with radio versions below 1.18 will still utilize the Accu-Sync portion of the ZSync signal, but will not gain the added benefits.
- All Tempest BaseStations to be used in a roaming application must have the same ZSync reference. For more information on roaming applications see the section on Seamless Roaming in this manual.



Allow up to one minute for all of the BaseStations to see the zero sync reference in the ZSync signal and thus become "zero synced" with all of the other BaseStations. Prior to this time the BaseStations are likely not fully coordinated.

Zero Sync Hop Dongle

The Zero Sync Hop Dongle (ZSync "dongle") provides a precise, zero reference synchronization signal to each connected Tempest 2.4GHz BaseStation. This signal aligns the hopping patterns and transmit/receive times of all connected BaseStations to produce the best possible multi-base, collocated RF performance.

The ZSync dongle connects to the BaseSync IN port of the first collocated BaseStation. Each additional BaseStation is then daisy-chained via the BaseSync ports of each sequential BaseStation. If any BaseStation loses power in this configuration, all remaining sequential BaseStations will not receive the ZSync signal. Therefore, the ZSync dongle is best utilized in installations where all BaseStations are in use and/or powered on at all times.


Parallel Zero Sync Generator

The Tempest Parallel Zero Sync Generator (PSG) provides a precise, zero reference synchronization signal to each connected Tempest 2.4GHz BaseStation. This signal aligns the hopping patterns and transmit/receive times of all connected BaseStations to produce the best possible multi-base, collocated RF performance.

A single Tempest Parallel Zero Sync Generator supports up to 12 Tempest 2.4GHz BaseStations using the 12 isolated Sync Out DE-9 connectors on the rear panel of the PSG. Each BaseStation is connected directly to the Parallel Zero Sync Generator via a DE-9 extension cable in a star configuration. The connection is made from a PSG Sync Out DE-9F to each BaseStation's Base Sync In DE-9M connector. This allows each BaseStation to receive the proper synchronization signal completely independent of the condition or presence of any of the other BaseStations.

If more than 12 Tempest 2.4GHz BaseStations are required, a second Parallel Zero Sync Generator may be added. In this case the two PSGs must be connected together utilizing the Sync Out DE-9F connector on the first PSG to a Sync In DE-9M on the rear panel of the second PSG. This will allow the synchronization of up to 23 Tempest 2.4GHz BaseStations.

Parallel Sync Generator
(Single Zone)



The ZSync technology is only applicable to 2.4GHz Tempest models.

Master Mode

Master Mode is a Tempest BaseStation function that allows multiple BaseStations to share audio without the presence of an external hardwired intercom system power supply. Master Mode provides the necessary system termination to the 2-Wire hybrid circuitry in each of the Tempest BaseStations, so that common audio transfer can take place. Each BaseStation in a linked system provides its own power for audio. Either a single channel or both channels can be linked.

The only limit to the number of BaseStations that can be linked to share an audio channel is the impact of multiple RF sources in close proximity. As the number of BaseStations goes up and they begin to compete for RF spectrum, the range will begin to decrease. See the section on Accu-Sync and the section on Antenna Location, to minimize the effect of RF competition.

It is necessary to use Master Mode when two or more Tempest BaseStations will be linked to share audio, and an external hardwired intercom system is NOT present to provide power. When an external 2-Wire intercom system is connected to Tempest, the external 2-Wire intercom system provides the required power and system termination and Master Mode is automatically disabled.

On the BaseStation that will be set to Master Mode, set the 2-Wire Intercom Type Select slide switch to the Clear-Com position. Master Mode only works in Clear-Com mode. If "RTS" or "BAL" is selected, an attempt to set the BaseStation as master will result in an error message. If the slide switch is changed from Clear-Com to RTS or BAL, Master Mode will turn OFF, and it will be necessary to return to the "Multi-Base Setting" menu to re-enable Master Mode.

On slave BaseStations, set the slide switch to Clear-Com.

On each BaseStation, set the shared intercom channel(s) to the 2-Wire mode. Master Mode only works for channels selected for 2-Wire connection.

Connect the appropriate intercom channel(s) of each BaseStation that will share audio using the 3-pin XLR male and female connectors on the back of the BaseStation.

Complete all settings and connections before activating Master Mode. Set one BaseStation to Master Mode. Master Mode settings are found at the "Set Base as Master" screen under the "Multi-Base Settings" main menu selection. It is only possible to set one BaseStation as Master. The words "Master Mode" appear in the top line of the BaseStation display, to the right of the BaseStation name, when Master Mode is active. An attempt to set a second BaseStation as master, will result in an error message. It does not matter which BaseStation in a linked series is set to Master Mode.

Slave BaseStations – those not set as master – detect the master BaseStation as a Clear-Com connection.

An attempt to set a BaseStation to Master Mode while connected to a 2-Wire system, will result in an error message. If a BaseStation has "Set Base As Master" first turned ON, and an external hardwired intercom system is connected later, the Tempest BaseStation will turn OFF Master Mode.

The "Set Base As Master" setting will remain ON through a power cycle.

Special RF Considerations with Multiple BaseStations

Whenever multiple Tempest BaseStations are operated together in close proximity, special consideration must be taken to ensure proper system operation and maximize operational range.

See the Antenna Location section of this manual for more information on antenna placement.

See the Antenna Configuration section of this manual for details about recommended cable type and other important information about connecting your antennas to your Tempest BaseStation.

See the Accu-Sync or ZSync sections for more information on using synchronizing multiple Tempest BaseStations.

Up to 11 BaseStations may be used in simultaneous operation in close proximity to each other with proper synchronization and antenna placement, under ideal conditions. Closely spaced antennas will cause adverse system performance and will reduce operational range.



Never Sync between 2.4GHz and 900MHz Tempest models; ZSync is only compatible with 2.4GHz Tempest models.



When two or more Tempest BaseStations are to be operated in the same location, utilizing the Accu-Sync or ZSync technology can significantly increase system performance and operational range.

Maximum Number of Collocated Systems

Factors that affect the maximum number of systems that may be collocated in any given location include:

- The existence and extent of harmful interference caused by in-band external radiators.
- Number of BaseStations.
- Number of BeltStations per BaseStation.
- Whether or not Accu-Sync or ZSync is being employed.
- Physical location of BaseStation antennas (either on BaseStations or on Transceivers).
- Physical location of the BeltStations.
- Specific hopping patterns selected.
- Environment (wide open, reflective, through walls...).

Favorable system conditions include:

- Locations with little or no interference from other 2.4GHz devices will provide the best opportunity for a large number of collocated systems.
- Proper use of Accu-Sync or ZSync resolves potential desensing issues.
- Antennas of any particular system should be separated from every other system's antennas by at least 10 feet (3 meters) for best collocated system performance.
- BeltStations operating at similar distances from their respective BaseStation antennas provide the best opportunity for satisfactory performance of a large number of collocated systems.
- Network Number configuration should be set up to ensure each system's hopping patterns are configured properly. See the section on Network Number for more information.
- Environment can play a big role in RF system performance. Every location is different and has its own unique set of challenges. Generally speaking, locations with very long paths to very reflective surfaces tend to be the most difficult for digital wireless communication systems due to the prevalence of inter-symbol interference.

With all factors listed above being favorable, a maximum of 11 Tempest systems, each with five BeltStations (in Normal Mode), may be collocated with minimal or no user-perceived impact on system range or performance.

The addition of one or more adverse conditions will limit the number, effectiveness and range of collocated systems in any given environment proportionally to the extent of the adverse condition(s).

Seamless Roaming

Tempest Seamless Roaming is a powerful feature that allows a BeltStation to automatically seek-out and move to a different BaseStation than the one it is currently on, with no user intervention. This feature can provide increased coverage area, and system flexibility for those users who need it. Because all of the roaming decision making takes place within the BeltStation, individual BeltStations can be set to roam or not to roam, and programmed to BaseStations they desire to roam between. Tempest Seamless Roaming is able to be used with any Tempest BaseStation Mode (Normal, Shared, or Split) provided that all the BaseStations in a particular “Roaming Group” are in the same mode. This section seeks to give a basic overview of Tempest Seamless Roaming. More complex examples and suggested implementations will be covered in the Tempest Roaming Guide.

Pre-Requisites

Hardware

- Two or more BaseStations (Remote Transceiver optional)
- All BaseStations, BeltStations, and Remote Transceivers must be equipped with radio version 1.18 or higher.
- Seamless Roaming is dependent on the ZSync technology. All BaseStations in a “Roaming Group” must be connected to the same ZSync source (either a Zero Sync Dongle or a Parallel Zero Sync Generator)
- All BaseStations within a “Roaming Group” must have their Network Numbers in the same Network Number Group.
See the section for Network Number Groups in this manual for more information.

Firmware

- All BaseStations and BeltStations must have system firmware version 3.0 or higher.

Verifying Settings

BaseStation

To verify Radio and Firmware versions within the BaseStation, press MENU, select “BaseStation Settings,” scroll to “Tech Menu” (proceed through warning), select “Diagnostic Mode,” and select “System Information.

- Radio Version - This needs to be 1.18 or higher
- PIC - This must be 3.00.00 or higher
- DSP Version - This must be 3.00.00 or higher

BeltStation

To verify Radio and Firmware versions within the BaseStation, Press MENU, select “Belt Settings,” scroll to “Tech Menu” (proceed through warning), select “Diagnostics,” and select “Sys Information. *Note: There is no PIC Version in the BeltStation.*

- Radio Version - This needs to be 1.18 or higher
- DSP Version - This must be 3.00.00 or higher

Remote Transceiver


Remote Transceivers are not required for Seamless Roaming implementation, but if they are being utilized they MUST meet the same radio pre-requisite of version 1.18 or higher that a BaseStation requires. To verify, plug in the Remote Transceiver to the rear of the BaseStation, then press MENU, select “BaseStation Settings,” scroll to “Tech Menu” (proceed through warning), select “Diagnostic Mode,” and select “System Information.

- Radio Version - This needs to be 1.18 or higher


Coverage Planning

Placing your antennas for Tempest Seamless Roaming follows the same basic rules of any multi-BaseStation Tempest wireless system with one exception. The antennas do not need to be located in the same physical location. For example, let's look at a two BaseStation system utilizing two Remote Transceivers:

A venue has two large rooms separated by a hallway. Each room needs Tempest coverage and the ability for users to work and move freely from room to room. *Note: Up to 11 BaseStations can be utilized with Seamless Roaming providing 11 overlapping coverage areas.*



Placing one BaseStation's Remote Transceiver in the center of one room, and placing the second BaseStation's Remote Transceiver in the center of the other room will provide coverage for both of those spaces.



By adjusting the location of the two Remote Transceivers closer to one another, the area of overlapping coverage can be increased. In this case, providing better coverage for the hallway in between the two rooms.

Implementation

BaseStation Configuration

- Verify ALL the BaseStations in the system configuration are properly connected to the same ZSync source, and assure that source is receiving power. See the ZSync section of this manual for more information on ZSync technology.
- Verify ALL BaseStations have Network Numbers within the same Network Number group (i.e. 0,1,2,3...10 or 11, 12, 13, 14...20.) See the section on Network Number groups in this manual for more information.
- Verify ALL BaseStations in a Roaming Group are set with the same Lockout Key
- Verify ALL BaseStations in a Roaming Group are operating in the same operational mode: Normal, Shared or Split.
- Verify ALL BaseStations have the same audio sources across all used channels (if desired); if the BaseStations are not connected to an external hardwired system, assure that one BaseStation is in Master Mode. See the Master Mode section of this manual for more information.

BeltStation Configuration

- Using a pairing cable, pair all BeltStations to each BaseStation they are intended to roam with.
- Set up each BeltStations Roaming Group (up to 16 BaseStations may be selected per BeltStation)
- Enable Roaming on each BeltStation; when roaming is not enabled, a BeltStation will operate as normal on a single BaseStation.
- Adjust Roaming Bias setting (if needed). See the section on BeltStation Setup in this manual for more information on adjusting Roaming Bias in Seamless Roaming.

How Do I ...?

Remove Batteries from BeltStations

Remove the battery cover from the back of the BeltStation by pressing lightly on the thumb grooves and sliding towards the bottom. Hold the BeltStation in one hand with the battery compartment facing downward over the open palm of your other hand. Firmly tap the BeltStation against the palm of your open hand and the battery will fall into your open hand. Follow the same procedure for AA batteries.

Install the Rechargeable Battery

The gold battery contacts must mate with the contacts in the battery compartment. If the battery is not properly seated, the cover will not close easily.

Charge the Battery

Connect the plug-in battery charger (included with BeltStation) to a standard wall outlet and to the Mini-USB connector on the BeltStation. This connector is located under the rubberized access cover on the side of the BeltStation. The batteries will charge from completely empty to a full charge in about 2¼ hours. The batteries will not overcharge. The BeltStation remains functional during charging.

Install AA Alkaline Batteries

Remove the battery cover on back of BeltStation. Insert (3) AA alkaline batteries according to the polarization shown inside the battery compartment. Replace the battery cover. All batteries install with the positive terminal toward the side with Mini-USB charger connector.

Use the 5-Bay Battery Charger

Plug charger into local AC power source and place up to five rechargeable, Lithium-Polymer batteries into the charger. Charging is complete when the indicator turns green. Re-charge time is 2½ hours and the charge provides approximately nine hours of operation

Navigate the BaseStation Menu

Press MENU to open the Main Menu. MENU also functions as an Escape key. Turn the Volume control to scroll through the menu. To select, press ENT or press the Volume control. The keys numbered 1 through 5 under the LCD screen take you directly to the corresponding BeltStation menu. If no entry is made within 3 minutes, the display will automatically return to the Operation Screen.

Navigate the BeltStation Menu

Press MENU to open the Main Menu. MENU also functions as an Escape key. Turn the Volume control to scroll through the menu. To select, press ENT or press the Volume control. If no entry is made within a few seconds, the display will automatically return to the Operation Screen.

Adjust Min/Max BeltStation Volume Levels

From the BeltStation:

- To set the Minimum volume, press MENU, select “Set Controls,” then “Volume Limit” and “Min Volume.” Use the Volume knob to adjust the level and press ENTER to save the new setting.
- To set the Maximum volume, advance to “Volume Limit” as above, and then “Max Volume.” Use the Volume knob to adjust the level and press ENTER to save the new setting.

From the BaseStation:

- Select the number key 1 through 5 that corresponds to the BeltStation desired and select “Volume Limit.”
- To set the Minimum volume setting, select “Min Volume.” Use the Volume/Scroll knob to adjust the level and press ENTER to save.
- To set the Maximum volume setting, select “Max Volume.” Use the Volume/Scroll knob to adjust the level and press ENTER to save.

Configure Stage Announce and SA Relay

From the BeltStation:

- To set Stage Announce, press MENU; select “Set Controls;” select “Stage Announce;” select “Momentary.” This is the default setting.
- To set SA Relay, press MENU; select “Set Controls;” select “Stage Announce;” Select “SA Relay Enable.” This is the default setting.

From the BaseStation:

- To set Stage Announce, select the numbered key 1 through 5 that corresponds to the BeltStation desired.
- Select “Stage Announce,” select “S/A Audio,” select *Momentary*.
- Press MENU to go up one level in the menu.
- Select “Stage Announce” to set “SA Relay” and select *SA Relay Enable*.
- The STAGE button is always *Momentary* when enabled.

Configure Relays for Individual BeltStations

From the BeltStation:

- Press MENU; select “Set Controls,” select “Select Relay.” Note that there are more options under “Set Controls” than fit on the screen. Scroll to the bottom of the screen and scroll one more detent to see the “Select Relay” option. Select one of the relays: *Relay 1* thru *Relay 5*. When a relay is selected a check mark will be visible beside the selection.
- To activate the relay, a “Relay Button” must be triggered. To select a “Relay Button,” one of the relays must already have been selected. To select a “Relay Button,” Press MENU, select “Set Controls,” select “Relay Button,” select one of the trigger options.
- If TalkA or Talk B is selected to activate the relay, the relay will remain closed whenever the button is selected for active talk.
- If Ch A or Ch B is selected to activate the relay, the relay will remain closed whenever channel A or B is selected.
- If STAGE, ENTER, or CALL is selected to activate the relay, the relay will remain closed whenever the button is pressed, for as long as the button is held.
 - » If STAGE is selected to activate the relay, and if Stage Announce Audio is enabled, and if the Stage Announce Relay is enabled, all three functions will operate simultaneously.
 - » If ENTER is selected to activate the relay, and if Wireless ISO is enabled, both functions will operate simultaneously while in Operational mode. When in Menu mode, ENTER only functions as an Enter button.
 - » If CALL is selected to activate the relay, and the CALL feature is enabled, both functions will operate simultaneously.

From the BaseStation:

- Select the numbered key 1 through 5 that corresponds to the BeltStation desired. Scroll to and choose “Select Relay.” Select one of the relays *Relay 1* thru *Relay 5*.
- Press MENU to go up one level back to the menu.
- Scroll to and select “Relay Button;” select an option to trigger the relay.

Since every user will require a custom application, cables for your RELAY connections will require some bench work with a soldering iron.

Use the Transceiver

Choose an optimum location for the Tempest Remote Transceiver and antenna.

Using standard CAT-5 cable, connect the Transceiver to the BaseStation RJ-45 connector labeled TRANSCEIVER.

The “Power” LED on the Transceiver will light if the BaseStation is powering the unit. If the “Power” LED does not illuminate when connections are made and the BaseStation is ON, the CAT-5 cable may be too long to deliver adequate power to the Transceiver.




Local BaseStation whip antenna is disabled when the remote transceiver is connected.

Update the Firmware (with CodeUpdater)

Tempest firmware updates are released periodically, and equipment should be updated to maximize optimal system performance. Staying up to date with the latest firmware ensures that your system is equipped with the newest features and enhancements that Tempest has to offer.

Tempest uses a proprietary program, CodeUpdater, to update firmware in the BaseStation and the BeltStation. Tempest CodeUpdater can automatically detect what firmware is currently installed on a unit and indicate whether a later version is available. *Note: You must have internet access on your PC for CodeUpdater to accurately detect the latest released versions available.*



Connecting Your BeltStation for Updating:

- Be sure the BeltStation is powered OFF.
- Plug in your USB programming cable to your computer first.
- Push and hold the CALL button on the front of the BeltStation and plug in the USB cable to the side USB-A connector on the BeltStation. The BeltStation will power ON automatically. Do not release the CALL button until the BeltStation display message appears.

Connecting Your BaseStation for Updating:

- Be sure the BaseStation is powered OFF.
- Plug in your USB programming cable to your computer and into the front USB-B on the BaseStation.
- Push and hold the MIC KILL button on the BaseStation front panel and then power ON. Do not release the MIC KILL button until the BaseStation display message appears.

Updating Firmware:

- Open Tempest CodeUpdater on your PC.
- Connect the device. CodeUpdater will list the model of the equipment connected next to device.
- You may be prompted to update Bootloader firmware. If so, it is highly recommended that you do update it. When updating the Bootloader, it is very important that you not interrupt the update. Be sure USB cable is securely connected before starting the upgrade process. Interrupting the update may require the device to be returned to the factory for re-programming. It is highly recommended that you not use a wireless connection when updating the bootloader. *Note: If you update the Bootloader you will have to re-connect your device to initialize the process again.*
- The “Current Version” of firmware will display in CodeUpdater along with the “Latest Version” available (if applicable). *Note: The PIC firmware version is only applicable to the BaseStation firmware.*
- If an update is available check the box under “Upgrade Selection” and click the <Upgrade> button.
- Repeat these steps as needed for each Tempest unit.

Troubleshooting

BaseStation

Limited RF range

BaseStation antenna or transceiver should be located as high as possible. Locating the BaseStation antenna above head level is critical for optimizing performance and range.

- Confirm that BaseStation antenna or transceiver are in an appropriate location and orientation.
- Confirm that antenna or transceiver are not close to any metal structures or racks; locate the BaseStation and BaseStation antenna or transceiver away from potentially interfering devices.
- Ensure that antenna connections are securely made. If using coaxial cable to remotely locate antennas, the cable must be a low loss 50 ohm coax, not more than 25 feet long.
- If you are using multiple Tempest BaseStations in close proximity to each other, Accu-Sync should be used to achieve maximum performance; in addition, set the Network Number for each BaseStation at least four numbers apart.

Cannot hear one or more channels of hardwired intercom

- Set the Front panel headset to monitor the intercom channel in question. Ensure that the Talk button is enabled for the front panel headset. Turn the headset volume up to a comfortable listening level to hear your own voice in your headset.
- Confirm that the channel is working wirelessly, from the BaseStation to a BeltStation.
- Confirm that the wired system is working correctly, separately from the Tempest Wireless system.
- If using a 2-Wire external wired intercom system, make sure that the 2-Wire Intercom Type Select Switch on the front of the BaseStation is in the appropriate position for the type of hardwired system you are using.
- Ensure that the correct 2-Wire or 4-Wire LED is lit for the intercom channel that you are using. If neither the 2-Wire nor the 4-Wire LED is lit, or if the wrong LED is lit for the hardwired intercom type you wish to use, no external intercom audio will be present.
- Adjust the IN and OUT level for the appropriate intercom channel to achieve the desired audio levels.
- Ensure that all external 2-Wire or 4-Wire hardwired intercom connections have been properly made on the back of the BaseStation.
- If all connections are made correctly with all front panel controls properly set, and there is still no external hardwired intercom audio present in the Tempest system, substitute another cable (3-pin XLR for 2-Wire or RJ-45 for 4-Wire) making sure that it is connected properly to both the external hardwired system and the Tempest BaseStation.

Headset microphone sounds distorted or cuts off parts of words

If the microphone gain is set too low for the specific headset microphone being used, the audio coming from that microphone may sound choppy or clip off the first part of words or sounds.

If the microphone gain is set too high for the specific headset microphone being used, the audio coming from that microphone may sound distorted at higher audio levels. In this case the peak LED will light almost continuously when audio is present.

No audio passing when not using an external hardwired intercom system and Tempest BaseStations are sharing intercom channels.

- Confirm that no wired intercoms are connected to the system.
- Confirm a 3-pin XLR cable connection for each channel to be shared, between each of the BaseStations.
- Set the BaseStation 2-Wire Intercom Type Select Switch to the Clear-Com position.
- Select 2-Wire for the relevant channels. Set only **one** of the Tempest BaseStations to Master Mode.



Audio can only be passed from one BaseStation to another in the "Clear-Com mode" unless actually connected to another type of wired intercom system. Connecting any wired intercom to any BaseStation will automatically disable Master Mode and disconnect all shared channels that do not have a wired intercom connected.

No audio passing when using an external hardwired intercom system and Tempest BaseStations are sharing intercom channels.

- Confirm a 3-pin XLR cable connection for each channel to be shared, between each of the BaseStations.
- Set the BaseStation 2-Wire Intercom Type Select Switch to the appropriate position.
- Select 2-Wire for the relevant channels.
- For each channel to be shared, connect the wired intercom to one of the BaseStations.



When connecting any shared BaseStations to any wired intercom system, only channels connected to the wired system can be shared.

BeltStation

BeltStation will not power up

- Confirm that battery(ies) is (are) installed correctly.
- When using a Lithium-Polymer rechargeable battery, ensure that the battery is fully charged.
- When using alkaline AA batteries, ensure that batteries are fresh and are all facing the same way. Note the illustration in the battery compartment section.
- Press and hold the Power button on the back of the BeltStation for two seconds to power ON.

BeltStation will not pair with BaseStation

- Confirm that the BaseStation you are pairing with is powered ON and in Operational Mode, and the BeltStation is powered OFF. Connect the pairing cable from the BaseStation to the BeltStation. Turn the BeltStation power ON. The pairing process takes approximately four seconds.
- If pairing is successful, the message “Pairing Complete” will appear on the BeltStation LCD for approximately five seconds and the BeltStation name will appear in the first available slot on the BaseStation LCD. The BaseStation name will appear on the BeltStation LCD. If pairing is not successful no message will appear.
- If pairing is not successful, try to pair a different BeltStation with the BaseStation. If neither of the BeltStations will pair, substitute a new Pairing cable.
- If successful pairing any BeltStation with the BaseStation, try the following procedure on the BeltStation that will not pair:
 - » Restore memory settings to Factory Defaults by pressing MENU
 - » Select “Belt Settings,” select “Tech Menu,” press ENTER to proceed
 - » Select “Set Defaults,” select *Restore Factory Defaults*, press ENTER to confirm and press MENU to exit
- If still not successful, repeat the above procedure but select *Clear Memory* to delete all memory settings, pairings, and user settings. See “*Factory Defaults*” section for more detail.
- If no BeltStation will pair with the BaseStation, reset the BaseStation memory to “Factory Defaults”.
- The final option is to select “Clear Memory” to fully reset the BaseStation. All BeltStation pairings will be lost with the “Clear Memory” option. See “*Factory Defaults*” section for more detail.

BeltStation will not log into BaseStation

- Confirm that the BeltStation is powered ON and has a battery with ample charge.
- Confirm that the proper BaseStation is selected on the BeltStation’s “Select Base” menu.
- Confirm that there is an available slot on the BaseStation.
- Check *Static* and *Dynamic* slot display settings on the BaseStation. If *Static* is selected check the BeltStation slot assignment.
- Determine if any BeltStation is logged onto the BaseStation.
- Re-pair the BeltStation to the BaseStation.
- Attempt to log into another BaseStation, if available.
- Follow the memory reset procedure under “Factory Defaults.”

Buttons on the BeltStation do not function

A number of buttons on the BeltStation can have alternate functions that the user can select.

If a button on the BeltStation is not working as expected, re-confirm all settings and any alternate function assignment in the menu. The button may have been reassigned wirelessly from the BaseStation or by T-Desk. Confirm that the function is available for use. If the reassignment involves any GPO, confirm that menu selection, the connections, and the equipment functionality.

Call Function does not work properly

- Check to make sure that the CALL function is enabled.
- Confirm that a TALK button is enabled for the channel that you wish to call.
- A Call signal will be received by the BeltStation only on the channel(s) that are currently being monitored.



When connecting any shared BaseStations to any wired intercom system, only channels connected to the wired system can be shared. A BeltStation CALL signal is sent only when the Talk button is enabled.

Stage Announce (SA) function does not work properly

The Stage button has two separate functions. Optionally, it controls the shared Stage relay contact on the back of the BaseStation.

- » When you press the STAGE button it reroutes the BeltStation user's microphone to the SA output on the back of the BaseStation.
- » When pressing the STAGE button, if there is no audio present at the SA, confirm that the Stage Announce function is enabled in the BeltStation.
- » If the SA relay does not close, ensure that the Stage Relay is enabled in the BeltStation. If problems persist, confirm the operation with another BeltStation.

Tempest Remote Transceiver

Remote Transceiver RX or TX LEDs do not light

While the Transceiver is properly connected to the BaseStation, turn the BaseStation Power Switch to the OFF position. Wait for 30 seconds and turn the BaseStation Power Switch back to the ON position. This should initialize the Remote Transceiver. The Config LED should light momentarily and then go out. Once the Config LED goes out the Remote Transceiver TX LED should light. If there are BeltStations communicating to the BaseStation through the Remote Transceiver the RX LED should light as well.



To manually re-initialize the Transceiver, power OFF the BaseStation for at least 15 seconds and power the BaseStation back ON, with the Transceiver connected.

Default Settings

BaseStation Defaults	BeltStation Defaults
Headset Sidetone: -18 dB	Headset Sidetone: -18 dB
Headset MIC gain: +6 dB / +22 dB	Headset MIC gain: +6 dB / +22 dB
<ul style="list-style-type: none"> • Electret: +6 dB 	<ul style="list-style-type: none"> • Electret: +6 dB
<ul style="list-style-type: none"> • Dynamic: +22 dB 	<ul style="list-style-type: none"> • Dynamic: +22 dB
LCD Contrast: 30	Low Battery Alert: Enable
LCD Backlight Brightness: 80	LCD Back Light: Enable
LED Brightness: 40	Talk LED: Medium
Headset Talk Button: Latch	Talk Buttons: Latch
Set Base as Master: OFF	Security: Disable
Front Panel Lock: OFF	Lock Keys: OFF
Wired intercom levels In/Out:	Volume Limits:
<ul style="list-style-type: none"> • 2-Wire: -1.5 dB (IN) / -1.5 dB (OUT) 	<ul style="list-style-type: none"> • Min Volume: OFF (0)
<ul style="list-style-type: none"> • 4-Wire: -9 dB (IN) / +3 dB (OUT) 	<ul style="list-style-type: none"> • Max Volume: 25
Aux In/ Out: OFF	Call Alert: Both
S/A Audio: -12 dB	Call Button: Enable
S/A Relay: Enable	Select Relay: None selected
Security: Disable	Relay Button: None selected
Frequency Band: 2400-2480Mhz	S/A Audio: Momentary
Display Slot Assignment: Dynamic	S/A Relay: Enable
TCP/IP Mode: DHCP Client	Wireless ISO: Enable
Echo Cancellation: ON	Volume Press: Disable
Mic Kill Settings: Enable All	Talk Tones: Enable
Call Settings: Enable All	Delay Switch: Disable

Tempest Part Numbers

Model Number (Clear-Com Part Number)	Description
Tempest® 2.4 GHz Series BaseStations	
TMB44524INCC (CM-244)	Tempest® 2.4 GHz 4 channel, full feature base station. Features two RP-TNC RF antenna ports, Remote Transceiver port, 2-wire, 4-wire, Stage Out, Aux IN, Aux OUT, relay cluster, Sync IN, Sync OUT, USB, LAN, Belt Prog port and AC & DC power inputs. Supports up to 5 wireless BeltStations (in Normal Mode) and an unlimited number of Shared BeltStations. Comes with AC power cord, USB cable, 1/8" stereo mini programming cable, two whip antennas and T-Desk software.
TMB22524INCC (CM-222)	Tempest® 2.4 GHz 2 channel, full feature base station. Features one RP-TNC RF antenna ports, Remote Transceiver port, 2-wire, 4-wire, Stage Out, Aux IN, Aux OUT, relay cluster, Sync IN, Sync OUT, USB, LAN, Belt Prog port and AC & DC power inputs. Supports up to 5 wireless BeltStations (in Normal Mode) and an unlimited number of Shared BeltStations. Comes with AC power cord, USB cable, 1/8" stereo mini programming cable, two whip antennas and T-Desk software.
Tempest® 2.4 GHz Series BeltStations	
TMR42524INCC (CP-242)	Tempest® 2.4 GHz 4 channel, dual-listen wireless BeltStations. Features stage announce, call, remote mic kill, vibrate alert, internal antenna, 4-PIN male XLR, program port and USB connector. Comes with 2000mAh Li-Poly rechargeable battery and wall charger.
TMR22524INCC (CP-222)	Tempest® 2.4 GHz 2 channel, dual-listen wireless BeltStations. Features stage announce, call, remote mic kill, vibrate alert, internal antenna, 4-PIN male XLR, program port and USB connector. Comes with 2000mAh Li-Poly rechargeable battery and wall charger.
Tempest® 2.4 GHz Series Transceivers	
TMA-RMTCVR-01 (CCT-RT)	Tempest FX® 2.4 GHz Remote Transceiver. Allows remote transmit/receive function with no loss of RF signal. Connects to compatible BaseStation via standard CAT-5 RJ45 cable. Power is provided down the CAT-5 cable for up to 1500 feet (450 meters). Comes with 15 ft (4.5 m) CAT-5 cable, mounting bracket assembly and two whip antennas
Tempest® Series 5-Bay Battery Chargers	
TMA-BCHRG-05A (T-BC5)	5-bay battery charger for charging Lithium-Polymer batteries outside of the BeltStation
Rechargeable Li-Poly Batteries	
TMA-BAT-02 (T-LP1)	Tempest® 3.6VDC, 2000mAh rechargeable Lithium-Polymer battery
Tempest® Accessories	
PC-ANT-2dBO	2 dBi Omni-Directional whip antenna with RP-TNC connector
PC-ANT-EXTDIR	9 dBi Directional corner reflector antenna with N connector
TMA-MB9DBANT	Mounting bracket for 9 dBi corner reflector antenna for use with any 5/8" stud
TMA-DMB5/8	Mounting bracket with two 5/8" studs for use with two 9 dBi corner reflector antennas PC-ANT-EXTDIR, two 5/8" stud mounting brackets TMA-MB9DBANT and two RP-TNC to N 4 foot cables PC-ANTCABLE. Requires one Bogen "C" clamp BOG-C1575B. Comes with two screws, #10-32 X 1/2" Phillips Pan Head, to attach "C" clamp.
BOG-C1575B	Bogen "C" clamp for use with Mounting Bracket TMA-DMB5/8. Also attaches directly to Remote Transceiver using two user supplied #8-32 X 3/8" Phillips Flat Head screws. Bogen number C1575B
PC-ANTCABLE-20	RP-TNC to N coaxial low loss RF cable 20 feet in length
PC-ANTCABLE-10	RP-TNC to N coaxial RF cable 10 feet in length
PC-ANTCABLE	RP-TNC to N coaxial RF cable 4 feet in length
TMA-USBCHRG	Tempest® 5 VDC Wall charger with Mini-USB connector, US blades
TMA-USBCHRG-02	Tempest® 5 VDC Wall charger with Mini-USB connector, Multi-blade
00001398	USB to Mini-USB cable 6 foot in length
CX-WB-CAB15	RJ45 Ethernet cable 15 foot in length
00001390	USB A to USB B cable 6 foot length
CX-PRGM-CAB	1/8" to 1/8" stereo mini pairing cable 6 foot in length
00001700	Tempest® BeltStation battery cover

System Features

- All digital, frequency hopping spread spectrum technology - no frequency coordination needed
- 2.4GHz offers World-Wide operation with no licensing requirements in most world-wide locations
- 2xTX™ transmission voice data redundancy technology
- Accu Sync™ timing system for improved performance with multiple BaseStations
- ZSync Technology for improved performance with multiple BaseStations covering multiple coverage zones
- iSelect™ On-Command roaming
- Seamless Roaming allows users to move freely from one coverage zone to another
- Two intercom channels and up to 5 full duplex BeltStations per BaseStation in Normal Mode
- Configure up to 10, 2.4GHZ BaseStations with 25 full duplex BeltStations in a single system when operating in Normal Mode
- An unlimited number of BeltStations per BaseStation in Shared and Split Mode
- BeltStations can access both intercom channels in “Dual-listen” or “Single-listen” mode
- Weather resistant BeltStations
- BeltStations can send and receive “Call Alert” signal from wired intercom systems
- Silent vibrate mode on BeltStations
- Both “Stage Announce” and GPO Relay function available for each BeltStation
- Talk switches can be de-latched via the Mic Kill feature from either the BaseStation or the hardwire intercom
- Auxiliary audio input and output
- Program Volume control allows user to set volume of incoming program audio
- LAN control interface
- Electret or Dynamic Mic auto select
- Multiple antenna connection options
- Compatible with Clear-Com®, RTS®, Telex®, and other 2-Wire and 4-Wire intercom systems

2.4 GHz System Specifications

RF Frequency	2400 to 2480 Hz
RF Scheme	FHSS with TDMA
Effective Radiated Power	100mW using 2dBi antenna
Receiver Sensitivity	-93 dBm for 10 BER
Radio Certification	FCC Part 15.247, ETS 300.328 rules, Canadian RSS-210, license free
Transmission Range	1,000 feet under ideal conditions (500 ft to 900 ft typical)
Audio Dynamic Range	>94dB
Audio Frequency Response	300Hz–3.8KHz with proprietary audio voice shaping System Latency Less than 50ms direct

BaseStation Specifications

Intercom Audio Channels	2
Full Duplex BeltStations per BaseStation	5
Half-Duplex, Shared BeltStations per Base	Unlimited
Number of Antenna Ports per BaseStation	1
Antenna Connector Type	RP TNC
Number of Synchronized BaseStations	11
Maximum Range of BaseSync Cable	3,000 ft (914.4 m)
BaseStation/BeltStation Pairing	Via supplied Mini-jack/cable
Programming Port	USB
Stage Announce and GPO Closures	6 relays via DA-15
2-Wire Intercom Interface	2 channels via XLR 3F with XLR 3M loop thru
2-Wire Compatibility	Clear Com, RTS, and Balanced compatible
4-Wire/Matrix Connection	2 ports via RJ 45
Aux Input	¼" 3 conductor jack accepts -15.5 to +4 dB, balanced, transformer isolated
Aux Output	¼" 3 conductor jack nominal -12 to +8 dB, balanced, transformer isolated
Stage Announce Output	XLR 3M, nominal -12 to +8 dB, balanced, Transformer isolated
Front Panel Headset	4-pin male connector
Microphone Type	Dynamic or Electret, auto selected
Front Panel LCD Display	240 x 64 resolution 32 level grayscale
Dimensions (inches)	1 RU unit, H 1.75" x W 19.0" x D 12"
Weight	10.5 lbs
Power Input	AC: 85–264 VAC at 50–60 Hertz, 15 Watts DC: 11–32 VDC, 12 Watts
Operating Environment	-20° to 50° C (-4° to 122° F) 10% to 90% Humidity

BeltStation Specifications

Intercom Audio Channels	2
Simultaneous Listen Paths	True Dual Listen
Headset Connector	4 pin male
Microphone Type	Dynamic or Electret, auto selected
LCD Display	102 x 80 pixels
Antenna	Internal +2 dBi patch
Charger	Input 100 240V, 0.3A, 50 60Hz, Output 5V, 1.25A
Battery Charging	Via supplied charger
Battery Life, Rechargeable Lithium-Polymer	Up to 9+ hours
Charge time for Lithium Polymer battery	2¾ hours in the BeltStation or 2½ hours in the 5 bay charger (from empty)
Optional Power	3 Standard AA alkaline cells
Battery Life, Alkaline batteries	Approximately 4 Hours
Dimensions (inches)	H 6.1" x W 4.0" x D 1.75"
Weight (with Lithium-Polymer battery)	14.3 oz
Operating Environment	-20° to 50° C (-4° to 122° F) 10% to 90% Humidity

Remote Transceiver Specifications

Maximum Distance, Base to Transceiver	1,500 ft (457.2 m), powered from the BaseStation
Connection to BaseStation	CAT-5 standard wiring
BaseStations Supported per Transceiver	1
Number of Antenna Ports per Transceiver	2
Antenna Connector Type	RP TNC
Supplied Antenna	Whip antenna (2)
Dimensions with Antennas (inches)	H 12" x W 3.7" x D 1.7"
Weight	11 oz
Operating Environment	-20° to 50° C (-4° to 122° F); 10% to 90% Humidity

[This page intentionally left blank]

Glossary

2-Wire or TW: A type of intercom system characterized by audio signals transmitted and received on the same pair of wires at the same time. The connector usually associated with 2-Wire or TW is a 3-pin XLR.

4-Wire: A type of intercom system characterized by audio signals transmitted on one pair of wires and received on a different pair of wires.

2xTX: Tempest Wireless proprietary technology that wirelessly transmits duplicate audio data packets from two antennas, a fraction of a second apart and on different frequencies, to minimize the possibility of lost data packets.

Accu-Sync: Tempest Wireless technology that synchronizes transmission timing for up to 10 BaseStations to prevent interference.

Auto-Null: A process that automatically optimizes the BaseStation 2-Wire, intercom interface hybrid to match the line characteristics of the external 2-Wire system.

AUX IN: Inputs program or other audio sources into the Tempest BaseStation to one or more intercom channels. The Auxiliary IN connector is a ¼" Tip/Ring/Sleeve jack that accepts a standard ¼" TRS plug.

AUX OUT: Outputs intercom audio from one or more intercom channels to an external system. The Auxiliary OUT connector is a ¼" Tip/Ring/Sleeve jack that accepts a standard ¼" TRS plug.

Banner: The top line of the BaseStation display, with white-on-black lettering. Usually the banner is the title of a menu screen.

Call Alert: A feature of intercom belt packs intended to visually and/or audibly alert users to a communication transmission.

Channel: A duplex communication path to transmit and receive voice communication.

Desensing or receiver desensitization: Desensing occurs when a transmitter is operating in close, physical proximity to a receiver, even if that transmitter is not on or near the receiver's operating frequency.

Receiver desensitization occurs because receivers must maintain critical voltage and current levels throughout the front-end stages and a strong (i.e. physically close) transmitter can cause these levels to vary greatly. As these levels widely fluctuate, the receiver performance will be greatly degraded. Increasing the physical distance between transmitter and receiver will decrease desensing. The greater the frequency separation between the two, the less the receiver performance will be affected.

Dual Listen: This BeltStation feature permits an operator to simultaneously listen to two channels.

Frequency Hopping, Spread Spectrum (FHSS): Radio technology that utilizes many frequencies in quick succession, intended to minimize the probability of radio frequency interference.

Full Duplex: Simultaneous two-way conversations (i.e. telephone communication).

GPIO: General Purpose Input Output – a simple device control method.

Half Duplex: Two-way conversations, one-way at a time, such that one person cannot interrupt the other (i.e. walkie-talkie).

IFB: Interrupted Feedback, or Interrupted Fold-Back - The IFB system connects control room personnel such as the director, or producer with the performers or “talent.” The performer wears a small earpiece that carries the program sound unless the director or another member of the production team interrupts the program sound with special instructions through the IFB.

iSelect On-Command Roaming: Permits the BeltStation user to select the BaseStation appropriate for the current location or activity.

License Free: The 2.4 GHz ISM band is approved for non-licensed use in virtually every country. It is the responsibility of the user to ensure that the system is operated in accordance with local laws and regulations.

Lithium-polymer battery: A rechargeable battery that provides long lasting, reliable power, with a minimum of space and weight, utilizing lithium based chemistry in a stable polymer.

Loop -Thru Connectors: Allow multiple BaseStations to share a common channel.

Master BaseStation: A Tempest BaseStation that powers the 2-Wire Hybrid circuitry in itself and up to 9 additional BaseStations across the looped-thru shared channel. The Master BaseStation provides power and line termination.

Mix Minus Signal: A mix of all audio that the BeltStation user needs to hear, minus the audio coming from the BeltStation itself.

Pairing: A programming process that allows a BaseStation and BeltStation to recognize each other.

Seamless Roaming: Allows BeltStations to roam freely from one coverage zone to another without additional adjustments to the user settings such as with iSelect Roaming..

Slot: One of five time intervals in the FHSS TDMA RF schema. Each BeltStation occupies a slot. Also, one of the five display locations on the BaseStation LCD screen.

Stage Announce: A Tempest system feature that permits connection of the BaseStation to a public address system (PA), and allows a BeltStation user to be heard through the PA. The option includes a relay that can be used to activate the PA system.

Status Screen: Normal operational mode screen on the BaseStation or BeltStation LCD display.

T-Desk Software: Software, used to configure and monitor the Tempest Intercom System with a computer over a Local Area Network.

Time Domain Multiple Access (TDMA): Radio technology that takes advantage of the relatively slow speed of sound and much faster speed of RF, to create the illusion of multiple simultaneous transmissions.

Tempest BaseStation: The control station for a group of Tempest Wireless Intercom BeltStations with the ability to interface with most commonly used wired intercom systems.

Tempest BeltStation: An intercom user station, designed to be worn on the user's belt in conjunction with a headset that provides a dedicated communication link and freedom of movement.

Tempest Remote Transceiver: An accessory used with the Tempest BaseStation to locate the antennas apart from the BaseStation without RF signal loss or attenuation.

ZSync: ZSync technology provides a more sophisticated form of BaseStation synchronization over the older Accu-Sync technology. To utilize ZSync technology either a Zero Sync Dongle or a Parallel Zero Sync Generator is necessary to act as the source of the ZSync signal.

USB Connections:



FCC Information

This unit has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Commensurate with EIRP limits specified in FCC Rules 15.247b, this device may not be used with antennas that exceed 9dB of gain in multi-point applications.

Contains Transmitter Module FCCID: HSW-2492

Important FCC and Safety Information

I. Digital Device Statement

A. Tempest BaseStations and wireless BeltStations have been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the Rules and Regulations of the U.S. Federal Communications Commission (the FCC) . Tempest products are marketed as Class A digital devices. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

B. This equipment generates, uses, and can radiate radio-frequency energy. If not installed and used in accordance with all instructions, it may cause harmful interference to radio communications.

C. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

II. Intentional Radiator Statement

A. Tempest BaseStations and wireless BeltStations each employ a modular, low-power radio transceiver module that operates pursuant to Part 15 of the FCC's Rules. The module's FCC Identifier is HSW-2492.

B. Operation is subject to the following conditions:

1. A Tempest system may not cause harmful interference to other users of the radio spectrum.

2. Upon notification by a representative of the FCC that a Tempest system is causing harmful interference, use of the system must be suspended. Operation must not resume until the condition causing the harmful interference has been corrected.

and

3. A Tempest system must accept any interference received, including interference that may cause undesired operation.

C. Tempest Wireless BeltStations contain an internal antenna that is not user replaceable Tempest BaseStations must be used only with approved antennas either the standard 4" Rubber Whip Antenna supplied with every Tempest BaseStations, with the 9bBi Directional Corner Reflector Antenna that is available as an option or another approved antenna. Use of any non-approved antenna, or any modification to any part of a Tempest unit, violates the Tempest System's warranty, and also constitutes a violation of the FCC's Rules and Regulations and of § 302 of the Communications Act of 1934, as amended.

D. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

III. RF-Exposure Statement

A. The FCC has adopted limits on the exposure to radio-frequency energy from devices such as the Tempest system. The FCC adopted these limits by drawing upon the efforts of independent scientific organizations that have engaged in periodic evaluations of the scientific literature. The FCC's standards are intended to assure the safety of all persons, regardless of age or health.

B. Tempest has been designed and manufactured to comply with the FCC's exposure limits. When used with approved antennas, and when used in accordance with all instructions, the Tempest system complies with those exposure limits.

C. Tempest BeltStations have been designed to be worn and used in close proximity to the human body.... what the FCC calls a "portable" use. The BeltStation unit complies with FCC exposure limits for portable use.

D. To ensure compliance with FCC exposure limits, no person must come closer than 26 cm (ten inches) from either the standard 4" Rubber Whip Antenna, the optional Directional 4" Corner Reflector Antenna, or other approved antenna whichever is used with the Tempest BaseStation.

Limited Warranty

This document details the Clear-Com Standard Limited Warranty for all new products for sale within all regions with the exception of Military, Aerospace, and Government (MAG).

EXCEPT AS SET FORTH HEREIN (“LIMITED WARRANTY”), CLEAR-COM MAKES NO OTHER WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT OF THIRD PARTY RIGHTS, OR FITNESS FOR A PARTICULAR PURPOSE, ALL OF WHICH ARE EXPRESSLY DISCLAIMED.

- I. **Standard Limited Warranty.** Clear-Com warrants its products, including supplied accessories, against defects in material or workmanship for the time periods as set forth below provided it was purchased from an authorized Clear-Com dealer or distributor.
- a) Pursuant to this Limited Warranty, Clear-Com will, at its option:
 - i) repair the product using new or refurbished parts, or;
 - ii) replace the product with a new or refurbished product.
 - b) Remedies: In the event of a defect, the rights detailed in 1 (a) are your exclusive remedies. For purposes of this Limited Warranty, “refurbished” means a product or part that has been returned to its original specifications.
 - c) Standard Warranty Period (by Product):
 - i) All Clear-Com brand systems and products, including belt packs, have a Limited Warranty of two years, with the exception of;
 - 1) Cables, accessories, components & consumable items have a Limited Warranty of 90 days.
 - 2) Any Clear-Com product that has been classified as obsolete at the time of sale has a Limited Warranty of 90 days from sales and will be replaced with the same product or a sales credit will be issued, at the sole discretion of Clear-Com.
 - 3) Headsets, handsets, microphones, and associated spare parts, as well as UHF wireless IFB products, have a Limited Warranty of one year.
 - 4) UHF WBS Analog wireless intercom systems have a Limited Warranty of three years.
 - 5) All software products, including Concert (Client and Server), ECS, Production Maestro and Logic Maestro are warranted for one year and shall substantially conform to published specifications. The media on which the Software is furnished is warranted to be free of defects in material and workmanship (under normal use) for a period of one year.
 - 6) Any Clear-Com products that are listed within the last time buy period have the same Limited Warranty for their type 1.i 1 - 1.i.5 as above.
 - d) Any Clear-Com product that is repaired or supplied as a replacement under the terms of this Limited Warranty shall inherit the remaining warranty period from the original product.
 - e) Standard Warranty Period Start Date
 - i) Dealer / Distributor Sales: In view of Dealer or Distributor stocking practices, the Standard Warranty Period for products sold through Dealers or Distributors will commence from the Clear-Com invoice date and will include an automatic extension of three months. Any valid warranty claim within the Standard Warranty Period as determined by the Clear-Com invoice date will be covered without further supporting evidence. All warranty claims after this date must be supported by the Customer’s proof of purchase that demonstrates the product is still within the Standard Warranty Period (as detailed in Section 1.c.i above, plus the automatic three month extension) from their purchase date.
 - ii) Direct Sales: The Standard Warranty Period will commence from the date the product was shipped from Clear-Com to the Customer. The Standard Warranty Period start date for contracts that include commissioning will be the date of the Site Acceptance Test (SAT) or one month from conclusion of the commissioning project, whichever is earlier.

f) Invalidation of Warranty

- i) This Limited Warranty shall be invalidated if the product's outer case has been opened and internal modifications have been made or damage has occurred, or upon the occurrence of other damage or failure not attributable to normal wear and tear. Authorized modifications with Clear-Com's express written permission will not invalidate the warranty.

g) Software Updates

- i) Software Updates are released periodically to correct discovered program bugs. During the Warranty Period, software updates are available to Customers free of charge.

h) Software Upgrades

- i) Software Upgrades include new Features and/or Functional Enhancements and are not included as part of the Standard Warranty but may be purchased at the published rates.
- ii) Note: In the absence of a Software Update containing a program correction and no available workaround to mitigate the problem, at the discretion of Service, Sales, Engineering, or Product Management, the Customer may be provided a Software Upgrade under warranty.

II. **Exclusions.** Services do not cover damage or failure caused by any occurrence beyond Clear-Com's reasonable control, including without limitation acts of God, fire, flooding, earthquake, lightning, failure of electric power or air conditioning, neglect, misuse, improper operation, war, government regulations, supply shortages, riots, sabotage, terrorism, unauthorized modifications or repair, strikes, labor disputes or any product failure that Clear-Com determines is not a result of failure in the Services provided by Clear-Com. Further Services excluded from this Agreement include: services required due to errors or omissions in Customer purchase orders; installation or maintenance of wiring, circuits, electrical conduits or devices external to the products; replacement or reconditioning of products which, in Clear-Com's opinion cannot be reliably maintained or properly serviced due to excessive wear or deterioration; Customer's failure to maintain the installation site in accordance with the environmental specifications of the products; or service on products removed from the location originally specified by Customer and/or reinstalled without the prior written approval of Clear-Com. Customer will pay Clear-Com's then current published charges to restore such Covered Products to a condition eligible for further service under this Agreement. Clear-Com shall be excused from and shall not be liable for any failure or delay in performance under this Agreement due to the foregoing or any causes beyond its reasonable control.

III. **Limitation of Liability.** IN NO EVENT WILL CLEAR-COM BE LIABLE UNDER THIS AGREEMENT FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION LOST PROFITS), REGARDLESS OF THE FORM OF ACTION, EVEN IF ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES.

IV. **Assignment.** Neither party may assign this Agreement or any portion thereof without the prior written consent of the other, except in the event of a merger, sale of all or substantially all of the assets or other corporate reorganization.

V. **Ownership of replaced parts or product.** All replaced parts or products become the property of Clear-Com.

VI. **Entire Agreement.** This Agreement constitutes the entire agreement between the parties with respect to the subject matter hereof, and supersedes all prior or contemporaneous proposals, oral or written, and all other communications between them relating to the subject matter of this Agreement.

Technical Support

In order to ensure that your experience with Clear-Com and our World Class products is as beneficial, effective and efficient as possible, we would like to define the policies and share some “best practices” that can accelerate any problem solving processes which we may find necessary and to enhance your customer service experience. Our Technical Support, Return Material Authorization, and Repair Policies are set forth below. These Policies are subject to revision and constantly evolve in order to address our Customers’ and the Market’s needs. Accordingly these are provided by way of guidance and for information only and may be changed at anytime with or without Notice.

TECHNICAL SUPPORT POLICY

- a) Telephone, online, and e-mail technical support will be provided by the Customer Service Center free of charge during the Warranty Period.
- b) Technical support will be provided free of charge for all software products under the following conditions:
 - i) The application, operating, and embedded software is installed on a product covered by Clear-Com’s Limited Warranty, and:
 - 1) The software is at the current release level; or,
 - 2) The software is one (1) version removed from current.
 - ii) Older versions of software will receive “best-effort” support, but will not be updated to correct reported bugs or add requested functionality.
- c) For Technical Support:
 - i) North and South America, (incl. Canada, Mexico, and the Caribbean) & US Military:
Hours: 0800 - 1700 Pacific Time
Days: Monday - Friday
Tel: +1 510 337 6600
Email: Support@Clearcom.com
 - ii) Europe, the Middle East and Africa:
Hours: 0800 - 2000 Central European Time
Days: Monday - Friday
Tel: +49 40 853 999 700
Email: TechnicalSupportEMEA@clearcom.com
 - iii) Asia-Pacific:
Hours: 0800 - 1700 Pacific Time
Days: Monday - Friday
Tel: +1 510 337 6600
Email: Support@Clearcom.com
- d) Email Technical Support is available for all Clear-Com branded products free of charge for the life of the product, or two years after a product has been classified as obsolete, whichever comes first. To log or update a request, send an email to: Support@Clearcom.com.
- e) Support for Distributor and Dealer Sales
 - i) Distributors and Dealers may utilize the Customer Service Centers once a system has been installed and commissioned. Clear-Com Systems and Applications Engineers will provide support to the Distributor from the pre-sales stage through to satisfactory installation for new system purchases. Customers will be encouraged to contact their Dealer or Distributor with their installation and technical support enquires rather than using the Customer Service Centers directly.

f) Support for Direct Sales

- i) Customers may utilize the Customer Service Centers once a system has been installed and commissioned by Clear-Com Systems and Applications Engineers, or in the case of project installations, once the Project Team has completed the hand-over to the Support Centers.


RETURN MATERIAL AUTHORIZATION POLICY

- a) Authorizations: All products returned to Clear-Com or a Clear-Com Authorized Service Partner must be identified by a Return Material Authorization (RMA) number.
- b) The Customer will be provided with an RMA number upon contacting Clear-Com Sales Support as instructed below.
- c) The RMA number must be obtained from Clear-Com via phone or email prior to returning product to the Service Center. Product received by the Service Center without a proper RMA number is subject to return to the Customer at the Customer's expense.
- d) Damaged equipment will be repaired at the Customer's expense.
- e) Returns are subject to a 15% restocking fee.
- f) Advance Warranty Replacements (AWRs);
- i) During the first 30 days of the Standard Warranty Period: Once the equipment fault has been verified by Clear-Com or its authorized representative, Clear-Com will ship a new replacement product. The Customer will be provided with an RMA number and be required to return the faulty equipment within 14 days of receipt of the replacement or will be invoiced for the list price of a new product.
- ii) During days 31-90 of the Standard Warranty Period: Once the equipment fault has been verified by Clear-Com or its authorized representative, Clear-Com will ship a like-new, fully refurbished replacement product. The Customer will be provided with an RMA number and be required to return the faulty equipment within 14 days of receipt of the replacement or will be invoiced for the list price of a new product.
- iii) To obtain an RMA number or request an AWR:
- 1) North and South America, Asia-Pacific, and US Military:
- Hours: 0800 - 1700 Pacific Time*
Days: Monday - Friday
Tel: +1 510 337 6600
Email: SalesSupportUS@Clearcom.com
- 2) Europe, the Middle East and Africa:
- Hours: 0800 - 1700 GMT + 1*
Days: Monday - Friday
Tel: + 44 1223 815000
Email: SalesSupportEMEA@Clearcom.com
- iv) Note: AWRs are not available for UHF WBS Analog wireless intercom systems. UHF WBS Analog wireless intercom systems out-of-box failures must be returned to Clear-Com for repair.
- v) Note: Out-of-box failures returned after 90 days will be repaired and not replaced unless approved by Clear-Com Management.
- vi) Note: AWRs are not available after 90 days of receipt of product unless an AWR Warranty Extension is purchased at the time of product purchase.
- vii) Note: Shipping charges, including duties, taxes, and insurance (optional), to Clear-Com's factory are the responsibility of the Customer.
- viii) Note: Shipping AWRs from Clear-Com is at Clear-Com's expense (normal ground or international economy delivery). Requests for expedited shipping (E.g. "Next-Day Air"), customs duties, and insurance are the responsibility of the Customer.


REPAIR POLICY

- a) Repair Authorizations: All products sent to Clear-Com or a Clear-Com Authorized Service Partner for repair must be identified by a Repair Authorization (RA) number.
- b) The Customer will be provided with an RA number upon contacting Clear-Com Customer Services as instructed below.
- c) The RA number must be obtained from Clear-Com via phone or email prior to returning product to the Service Center. Product received by the Service Center without a proper RA number is subject to return to the Customer at the Customer's expense.
- d) Return for Repair
 - i) Customers are required to ship equipment at their own cost (including transportation, packing, transit, insurance, taxes and duties) to Clear-Com's designated location for repair.
 - 1) Clear-Com will pay for the equipment to be returned to the Customer when it is repaired under warranty.
 - 2) Shipping from Clear-Com is normal ground delivery or international economy.
 - 3) Requests for expedited shipping (E.g. "Next-Day Air"), customs duties, and insurance are the responsibility of the Customer.
 - ii) Clear-Com does not provide temporary replacement equipment ("loaner") during the period the product is at the factory for repair. Customers should consider a potential prolonged outage during the repair cycle, and if required for continuous operations purchase minimum spare equipment required or purchase an AWR Warranty Extension.
 - iii) No individual parts or subassemblies will be provided under warranty, and warranty repairs will be completed only by Clear-Com or its Authorized Service Partners.

Tempest Block Diagram



Tempest Block Diagram continued



Index

Symbols

2-Wire 53
2-Wire - Configure 53
3-Pin Wiring Scheme 56
4-Wire 51
5-Bay Battery 70

A

Accu-Sync 62
AC Power Input Connector 16
Antenna Configuration 26
Antenna - Location 25
Audio Connections for Multiple BaseStations 60
Auto-Null 53

B

Basestation 12
BaseStation - Call Function 37
Basestation - Configure 30
BaseStation - Controls 12, 36
BaseStation - Echo Cancellation Menu 53
BaseStation - Front Panel Controls 30
BaseStation - Front Panel Lock 37
BaseStation - Front Panel Right 14
Basestation - Headsets 36
BaseStation - Location 23
BaseStation - Pairing 44
BaseStation - Rear Panel Left 16
BaseStation - Rear Panel Right 17
BaseStations - Audio Connections 60
BaseStations - Connecting Multiple 57
Basestation - Setup 23
BaseStation - Stage Announce 37
Battery 3
Battery - Charging 43, 70
Battery - Install 70
Battery - Remove 70
Battery Selection 42
Belt Clip 20
BeltStation 70
BeltStation - Configure 41
BeltStation - Menu 49
BeltStation - Overview 49
BeltStation - Power On/Off 43
BeltStation - Seamless Roaming 48
Beltstation Slot - Adjust 44
Block Diagram 94
Button - Mic Kill 12
Button - Talk 12

C

Call Button 12
Call Function 37

Call Function - BaseStation 46
Charging 43
Cleaning 4
CodeUpdater 73
Connector - Antenna 18
Connector - Aux In 17
Connector - Aux OUT 17
Connector - Base Sync IN 17
Connector - Base Sync OUT 17
Connector - Local Area Network (LAN) RJ-45 18
Connector - Relay 18
Connector - Remote Transceiver RJ-45 18
Connector - Stage Announce 17

D

DB-15 Relay Wiring 38
DC Power Input Connector 16
Default Settings 78
Display Mode 35

E

Echo Cancellation Menu - BaseStation 53
Echo Test 54

F

Features 80
Firmware - Update 73
Frequency Band - Selecting 32

G

GPO Relay Contacts 38

H

Headsets 11

I

iSelect 35, 45, 47, 59, 86

L

LEDs - Headset Channel 12
LEDs - Peak 12
LED - Talk Button 12
Lockout Key 33
Loop -Thru Connectors: 86

M

Maintenance 4
Master BaseStation: 86
Master Mode 63
Mic Gain 36
Mic Kill Button 12
Modes of Operation 57

N

Name Equipment 45
Network Number 33
Normal Mode i, 57, 67, 79, 80
Null Manual 54

P

Pairing: 86
Pairing - BaseStation 44
Power Connections 23
Powering On the BaseStation 24
Power On/Off - BeltStation - 43
Power Options 43
Preferences 45
Program Volume Control 46

Q

Quick Start Guide 5

R

Remote Transceiver - Trouble Shooting 77
RF Considerations 66
Roaming
 iSelect 47
 Seamless 68
Roaming Group 68–95

S

Safety 1
Seamless Roaming 68
Shared Mode i, 13, 35, 57, 58
Sidetone 31
Slot 86
Specifications 81
Specifications - Basestation 82
Specifications - BeltStation 83
Split Mode i, 57, 58, 80
Stage Announce 37, 71, 86
Station - Naming 35
Sync
 Accu-Sync 62
 ZSync 63

T

Talk Button 12
T-Desk Software 86
Transceiver Controls 22
Transceiver - Setup 28
Transceiver - Using 72

W

Warranty 89
Wireless ISO 48

Z

ZSync 63

[This page intentionally left blank]

[This page intentionally left blank]



www.clearcom.com