


**METTLER TOLEDO**

**Weighing terminal IND429**

**Weighing terminal IND429xx**

**Compact scales BBA429**





Congratulations on choosing the quality and precision of METTLER TOLEDO. Proper use according to this Operating Manual and regular calibration and maintenance by our factory-trained service team ensures dependable and accurate operation, protecting your investment. Contact us about a ServiceXXL agreement tailored to your needs and budget.

We invite you to register your product at [www.mt.com/productregistration](http://www.mt.com/productregistration) so we can contact you about enhancements, updates and important notifications concerning your product.

# Table of contents

	Page
<b>1 Introduction .....</b>	<b>5</b>
1.1 Safety instructions for the explosion protected weighing terminal IND429xx .....	5
1.2 Safety instructions for non-explosion-protected devices .....	6
1.3 Disposal .....	7
1.4 Use in hygienically sensitive areas .....	7
1.5 Description .....	8
1.6 Commissioning .....	12
<b>2 Operation .....</b>	<b>15</b>
2.1 Switching on and off .....	15
2.2 Zeroing / Zero point correction .....	15
2.3 Simple weighing .....	15
2.4 Weighing with tare .....	16
2.5 Dynamic weighing .....	17
2.6 Printing results .....	18
2.7 Cleaning .....	18
2.8 Testing of weighing terminal and scale/display of the ID code (only for weighing terminals with IDNet interface) .....	19
<b>3 Settings in the menu .....</b>	<b>20</b>
3.1 Operating the menu .....	20
3.2 Overview .....	22
3.3 Scale settings (SCALE) – analog .....	25
3.4 Scale settings (SCALE) – IDNet .....	27
3.5 Application settings (APPLICATION) .....	29
3.6 Terminal settings (TERMINAL) .....	29
3.7 Configuring interfaces (COMMUNICATION) .....	30
3.8 Diagnosis and printing out of the menu settings (DIAGNOS) .....	34
<b>4 Interface description .....</b>	<b>35</b>
4.1 SICS interface commands .....	35
4.2 TOLEDO Continuous mode .....	37
4.3 MMR interface commands .....	39
<b>5 Event and error messages .....</b>	<b>42</b>
<b>6 Technical data and accessories .....</b>	<b>44</b>
6.1 Technical data .....	44
6.2 Accessories .....	48

<b>7</b>	<b>Appendix .....</b>	<b>50</b>
7.1	Safety checks .....	50
7.2	Tests for utilisation in hygienically sensitive areas .....	50
7.3	Working to GMP (Good Manufacturing Practice) .....	51
7.4	Tables of geo values .....	51
7.5	FCC .....	54
<b>8</b>	<b>Index .....</b>	<b>55</b>

# 1 Introduction

## 1.1 Safety instructions for the explosion protected weighing terminal IND429xx



The device fulfils Device category 3 and is approved for operation in Zone 2 (gases) and Zone 22 (dusts) hazardous areas.

There is an increased risk of injury and damage when used in hazardous areas.

Special care must be taken when working in such hazardous areas. The code of practice is oriented to the "Safe Distribution" concept drawn up by METTLER TOLEDO.

### Competence

- ▲ The device, accompanying weighing platforms and accessories may only be installed, maintained and repaired by authorized METTLER TOLEDO service personnel.
- ▲ The mains connection may only be connected or disconnected by the owner's electrician.

### Ex approval

- ▲ For the exact specification please refer to the statement of conformity.
- ▲ No modifications may be made to the terminal and no repair work may be performed on the modules. Any weighing platform or system modules that are used must comply with the specifications contained in the installation instructions. Non-compliant equipment jeopardizes the safety of the system, cancels the Ex approval and renders any warranty or product liability claims null and void.
- ▲ The cable glands must be tightened so that a strain relief of  $\geq 20$  N per mm cable diameter is ensured.
- ▲ When connecting external devices, always observe the maximum permissible connected loads, refer to the installation instructions. It must be ensured that no voltages are fed into the device than it itself provides. The interface parameters have to fulfil the standard.
- ▲ Peripheral devices without an Ex approval may only be operating in non-hazardous areas. It must be ensured that no voltages are fed into the device than it itself provides. In addition the maximum permissible connected loads have to be observed, refer to the installation instructions. The interface parameters have to fulfil the standard.
- ▲ The safety of the weighing system is only guaranteed when the weighing system is operated, installed and maintained in accordance with the respective instructions.


- Ex approval**
- ▲ Also comply with the following:
    - the instructions for the system modules,
    - the regulations and standards in the respective country,
    - the statutory requirement for electrical equipment installed in hazardous areas in the respective country,
    - all instructions related to safety issued by the owner.
  - ▲ Before initial start-up and following service work, check the explosion protected weighing system for the proper condition of all safety-related parts.
- Operation**
- ▲ Prevent the build-up of static electricity. Therefore:
    - always wear suitable working clothes when operating or performing service work on the system,
    - do not rub or wipe off the keyboard surface with a dry cloth or glove.
  - ▲ Do not use protective hoods.
  - ▲ Prevent damage to the weighing terminal. Hairline cracks in the keyboard membrane are also considered damage.
  - ▲ If the weighing terminal, accompanying weighing platforms or accessories are damaged:
    - Switch off weighing terminal.
    - Separate the weighing terminal from the mains in accordance with the applicable regulations.
    - Secure the weighing terminal against accidental start-up.
  - ▲ Always charge the storage batteries in a safe zone.
  - ▲ Ensure that the supply voltage at the installation site amounts to 230 V.

## 1.2 Safety instructions for non-explosion-protected devices



- ▲ Do not use the device in an hazardous environment!  
Special devices are available in our range of products for hazardous environments.
- ▲ Ensure that the power socket outlet for the device is earthed and easily accessible, so that it can be de-energized rapidly in emergencies.
- ▲ Ensure that the supply voltage at the installation site lies within in the range of 100 V to 240 V.
- ▲ The safety of the device cannot be ensured if it is not operated in accordance with these operating instructions.
- ▲ Only authorized personnel may open the device.
- ▲ Check the power cable regularly for damage. If it is damaged, disconnect the device immediately from the power supply.
- ▲ Ensure that there is a space of at least 3 cm at the rear in order to prevent the power cable from being bent too strongly.

### 1.3 Disposal



In conformance with the European Directive 2002/96 EC on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of with domestic waste. This also applies to countries outside the EU, per their specific requirements.

→ Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment.

If you have any questions, please contact the responsible authority or the distributor from which you purchased this device.

Should this device be passed on to other parties (for private or professional use), the content of this regulation must also be related.

Thank you for your contribution to environmental protection.

If the device is equipped with a storage battery:

The nickel metal hydride (NiMH) storage battery does not contain any heavy metals. However, it may not be disposed of with the normal refuse.

→ Observe the local regulations on the disposal of materials that are hazardous to the environment.

### 1.4 Use in hygienically sensitive areas

The device is suitable for use in hygienically sensitive areas. It fulfils the following requirements on areas coming into contact with the product (keyboard) and areas not coming into contact with the product (housing, stand):

- Suitability of the materials for contact with foodstuffs
- Continuous bonding joints that do not act on the material
- Smooth, non-porous and flat surfaces that are easy to clean
- Continuous welding seams
- No sharp corners

For further information please refer to Sections 7.2 and 7.3.

## 1.5 Description

### 1.5.1 Weighing terminals IND429 and IND429xx

METTLER TOLEDO weighing platforms can be connected without problems to the weighing terminals.

The weighing terminals are available in two different basic versions: for connecting analog scales or for digital scales with IDNet interface.

Both basic versions are supplied by default with in-built power supply unit and an RS232 interface.

IND429xx is approved for use in hazardous areas of the Category 3.

### 1.5.2 Compact scale BBA429

The compact scale BBA429 consists of a terminal-stand combination that is connected to an analog weighing platform of the PBA430 series.

The compact scale is supplied by default with an in-built power supply unit and an RS232 interface.

### 1.5.3 Additional equipment

The following alternatives are also possible:

- Power supply via in-built storage battery
- Version for external power supply 12 – 24 V DC
- Power supply via an external storage battery (not for IND429xx)
- Additional second communication interface


One of the following options is available as the second communication interface:

- RS232
- RS485/RS422
- Ethernet interface
- USB interface
- Digital I/O
- WLAN




### 1.5.4 Overview

- 1 Keys
- 2 Display
- 3 Measuring data sign





### Weighing terminal connections

- 1 Power supply connection
- 2 Pressure compensation
- 3 Equipotential bonding terminal, only for IND429xx
- 4 COM1 interface
- 5 COM2 interface (optional)
- 6 Antenna for optional WLAN interface
- 7 not assigned
- 8 Scale connection
- 9 Securing plate for the interface connections, only for IND429xx



**Compact scale connections**





- 1** COM1 interface
- 2** COM2 interface (optional)
- 3** Antenna for optional WLAN interface
- 4** Pressure compensation
- 5** Power supply connection
- 6** Scale connection

**1.5.5 Display**



- 1** Notation for weight values with  $e = 10 d$
- 2** Active interface
- 3** Weighing range display
- 4** Charge state of the storage battery, only for devices with storage battery
- 5** Symbol for displaying net values
- 6** Symbol for dynamic weighing
- 7** Weight units
- 8** 7-segment display, 7 digits, with decimal point
- 9** Standstill check (goes out when a stable weight value has been reached)
- 10** Sign
- 11** Notation for modified or calculated weight values, e.g. higher resolution, weight below minimum value

## 1.5.6 Keyboard

### Main functions

Key	Function in the operating mode	Function in the menu
	Switch the terminal on/off; cancel	To the last menu item –End–
	Set scale to zero, delete tare Long keypress at scales with IDNet interface: Display of the ID code and checking of the calibration	Page backwards
	Tare scale, delete tare	Page forwards
	Transfer key Long keypress: Call up menu	Activate menu item Accept selected setting

### Additional functions

Key	Function
	Switch over weight unit
	Delete key

## 1.6 Commissioning

The weighing platform connection to the weighing terminals IND429 / IND429xx as well as the commissioning of the interfaces are described in the "IND4x9 / BBA4x9" installation instructions.

→ Call the METTLER TOLEDO service or carry out commissioning in accordance with the installation instructions.

### 1.6.1 Limited mobility at explosion protected weighing terminal IND429xx



#### CAUTION!

The device may only be operated in Zone 2 and 22 hazardous areas.

- ▲ Protect data and signal cable extensions against inadvertent disconnection.
- ▲ Secure the interface connections on the rear using the interface plate.

### 1.6.2 Labelling for operation in hazardous area

The following signs must be mounted on the device, accompanying weighing platforms and accessories so that they are clearly visible:

- Model plate and the device's model data, manufacturer and serial number
- Safety instructions
- Explosion protection identification
- If appropriate, temperature range

### 1.6.3 Establishing a mains connection at an explosion protected weighing terminal IND429xx



#### CAUTION!

The mains connection may only be connected by the owner's electrician.



#### CAUTION!

The device only operates correctly at a supply voltage of 230 V.

- ▲ Do not under any circumstances connect the device if the voltage value on the rating plate deviates from the local system voltage.
- ▲ Only connect the device to an earthed mains connection.
- ▲ Ensure that equipotential bonding has been implemented.

#### 1.6.4 Establishing a mains connection at non-explosion-protected devices



##### CAUTION!


Before connecting the power supply check whether the voltage value printed on the rating plate agrees with the local system voltage.

▲ Do not under any circumstances connect the device if the voltage value on the rating plate deviates from the local system voltage.

→ Plug the power plug into the power socket.

After it has been connected, the device carries out a self-testing routine. The device is ready to operate when the zero display appears.

#### 1.6.5 Devices with built-in or external storage battery



The operating life depends on the intensity of use, the configuration and the connected scale. For details see Section 6.1.2.

The battery symbol shows the current charge state of the storage battery. 1 segment corresponds to approx. 25% capacity. If the symbol flashes, the storage battery has to be charged. If work is continued during the charging process, the charging time is extended. The storage battery is protected against overcharging.

The charging time of the storage battery amounts to approx. 6 hours. If the device continues to be operated during the charging process, the charging time is extended. The storage battery has a service life of approx. 1,000 charging/discharging cycles.



##### CAUTION!

Explosion hazard!

▲ In the case of explosion protected devices the storage battery may only be charged in a safe area.



##### CAUTION!

Danger of soiling! The charger for the storage battery is not protected to IP69K.

▲ Do not charge the device in humid or dusty rooms.

▲ After the internal storage battery has been charged, close the cover cap of the charging socket at the device.

▲ Close the cover cap of the charging socket again at an external storage battery.

▲ In order to maintain degree of protection IP69K, make sure at devices with an external storage battery that the external storage battery is connected firmly to the device. Ensure that the plug connector of the external storage battery is inserted into the socket outlet of the device until it will go no further.

**Note** The storage battery is also suitable for permanent mains operation.

→ In order to obtain the full nominal capacity we recommend that you discharge the storage battery at regular intervals (approx. every 4 weeks) through normal operation.

### 1.6.6 Devices with external power supply 12 – 24 V DC

#### Explosion protected weighing terminals IND429xx

The device is supplied with a fixed-mounted 2.5 m long connecting cable with open ends.

Connection values: 12 – 24 V DC, max. 800 mA.

#### Non-explosion-protected devices

The device is equipped with a socket for connecting the power supply.

Connection values: 12 – 24 V DC, max. 800 mA.

A connecting cable with open ends is included with the device.



#### CAUTION!

Danger of soiling!

- ▲ In order to maintain degree of protection IP69K, make sure at devices with an external power supply that the connecting cable is connected firmly to the device. Ensure that the plug connector of the connecting cable is inserted into the socket outlet of the device until it will go no further.

### 1.6.7 Verification at partially verified scales

Partially verified scales (scales with first-stage verification) and scales with IDNet interface have to be verified by an authorized office or the METTLER TOLEDO Service.

→ Call the METTLER TOLEDO Service.

**Note** Adjust non-verified analog scales for the maximum precision, refer to Section 3.3.1.


## 2 Operation

### 2.1 Switching on and off

**Switching on** → Press .

The scale conducts a display test. Afterwards the software version identifier is displayed. When the weight display appears, the scale is ready to weigh.

**Note**

If  is pressed for a long time while switching on, the serial number of the device is also displayed after the software version identifier.

**Switching off** → Press .

Before the display goes out, -OFF- appears briefly.

### 2.2 Zeroing / Zero point correction

Zeroing corrects the influence of slight changes on the load plate or minor deviations from the zero point.

**Manual** 1. Unload scale.

2. Press .

The zero display appears.

**Automatic** In the case of scales that cannot be certified, the automatic zero point correction can be deactivated in the menu or the amount can be changed. Verified scales are set fixed to 0.5 d.

As standard, the zero point of the scale is automatically corrected when the scale is unloaded.

### 2.3 Simple weighing


1. Place weighing sample on scale.

2. Wait until the stability monitor  goes out.

3. Read weighing result.

## 2.4 Weighing with tare


### 2.4.1 Taring

→ Place the empty container on the scale and press .

The zero display and the symbol **NET** appear.


The tare weight remains saved until it is cleared.

### 2.4.2 Clearing the tare

→ Unload scale and press .

The symbol **NET** goes out, the zero display appears.

or

→ Press .

The symbol **NET** goes out, the gross weight appears in the display.

If A.CL-tr is activated in the menu under SCALE → tArE, the tare weight is automatically cleared as soon as the scale is unloaded.

### 2.4.3 Automatic taring

#### Prerequisite

A-tArE is activated in the menu under SCALE → tArE, the symbol **T** flashes in the display.

The packaging material must be heavier than 9 display steps of the scale.

→ Place the container or packaging material on the scale.

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.



#### 2.4.4 Chain tare

##### Prerequisite


The tare function CHAI<sub>n</sub>.tr is activated in the menu under SCALE → tArE.

With this function it is possible to tare several times if, for example, cardboard is placed between individual layers in a container.

1. Place the first container or packaging material on the scale and press .

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.


2. Weigh the weighing sample and read/print out the result.

3. Place the second container or packaging material on the scale and press  again.

The total weight on the scale is saved as the new tare weight. The zero display appears.

4. Weigh the weighing sample in the second container and read/print the result.
5. Repeat the last two steps for other containers.

## 2.5 Dynamic weighing


With the dynamic weighing function, it is possible to weigh restless weighing samples such as live animals. If this function is activated, the symbol  appears in the display.

With dynamic weighing, the scale calculates the mean value from 56 weighing operations within 4 seconds.

##### With manual start Prerequisite

AVERAGE → MAnuAL is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

1. Place the weighing sample on the scale and wait until it has stabilized.
2. Press  to start dynamic weighing.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol \*.

3. Unload the scale to be able to start a new dynamic weighing operation.

**With automatic start    Prerequisite**

AVERAGE → AUTO is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

1. Place the weighing sample on the scale.


The scale starts the dynamic weighing automatically.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol \*.

2. Unload the scale to be able to perform a new dynamic weighing operation.

## 2.6 Printing results

If a printer or computer is connected to the scale, the weighing results can be printed out or sent to a computer.

→ Press .

The display contents are printed out or transferred to the computer.

## 2.7 Cleaning

The device conforms to degree of protection IP69K to DIN 40050.

It is suitable for hygienically sensitive areas - see the proofs in Section 7.2.

The device is designed so that it can be cleaned easily. The housing is made of stainless steel 1.4301 (AISI 304), the keyboard of resistant polyester (PE). If required, high-pressure equipment can be used for cleaning.

### Cleaning

- Close open connectors with cap plugs.
- Clean the protective hood of the non-explosion-protected devices separately. The protective hood is dishwasher-proof.
- Replace protective hoods regularly.
- Use a moist cloth for minor soiling.
- Do not use acids, alkaline solutions or strong solvents.
- Observe the following limits when using high-pressure equipment:
  - Max. water temperature 80 °C / 176 °F
  - Max. water pressure 8,000 kPa (80 bars)
  - Min. distance jet nozzle to terminal 50 cm
  - Do not point the jet at one point for longer than 10 seconds
  - Water flow rate not greater than 10 l/min
- Observe all the existing regulations on cleaning intervals and permissible cleaning agents.


**Information on cleaning the weighing platform connected to the weighing terminal**

- Be sure to observe the cleaning instructions for the connected weighing platform. The weighing platform may not be designed for cleaning with high-pressure equipment.


## **2.8 Testing of weighing terminal and scale/display of the ID code (only for weighing terminals with IDNet interface)**

The ID code is increased by 1 at every calibration in case of IDNet scales. For verified scales, the ID code displayed by the weighing terminal must match the ID code on the ID cards. Otherwise, the verification is no longer valid.

### **2.8.1 Displaying the ID code**

1. Unload weighing platform.
2. Press the  key and keep it pressed until the display changes to -----.  
The ID code is then displayed: COdE= . . .

### **2.8.2 Testing the weighing platform and terminal**

- After the ID code is displayed, press the  key again.  
CHE CAL is displayed. The weighing platform is tested.  
After a successful test CAL ok is displayed briefly.  
The terminal then changes to normal operation.

**Note** If a calibration error CAL Err is displayed during testing, repeat the test. If the error is displayed again, inform the METTLER TOLEDO Service.

## 3 Settings in the menu

Settings can be changed and functions can be activated in the menu. This enables adaptation to individual weighing requirements.



The menu consists of 6 main blocks containing various submenus on several levels.

### 3.1 Operating the menu

#### 3.1.1 Calling up the menu and entering the password



The menu differentiates between 2 operating levels: Operator and Supervisor. The Supervisor level can be protected by a password. When the device is delivered, both levels are accessible without a password.

##### Operator menu

1. Press  and keep it pressed until CODE appears.
2. Press  again.


The menu item tErMINL appears. Only the submenu dEVICE is accessible.

##### Supervisor menu

1. Press  and keep it pressed until CODE appears.
2. Enter the password and confirm with .



The first menu item SCALE appears.

##### Note


No supervisor password has been defined when the device is first delivered. Therefore, respond to the password inquiry with  when you call up the menu for the first time. If a password has still not been entered after a few seconds, the scale returns to weighing mode.

##### Emergency password for Supervisor access to the menu

If a password has been issued for Supervisor access to the menu and you have forgotten it, you can still enter the menu:

- Press  3 times and confirm with .

### 3.1.2 Selecting and setting parameters



**Scrolling on one level**

- Scroll forward: Press →T←.
- Scroll back: Press →0←.

**Activating menu items/ accepting selection**

- Press →>←.

**Exiting menu**

1. Press ①.  
The last menu item End appears.
2. Press →>←.  
The inquiry SAVE appears.
3. Confirm inquiry with →>← to save the settings and return to weighing mode.  
-or-  
→ Press →T← to discard changes and return to weighing mode.

**Note** The SCALE menu block depends on the built-in scale interface.

## 3.2 Overview

Factory settings are printed **bold** in the following overview.

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
SCALE (analog)	CAL					25
	dISPLAY	UNIT1	g, <b>kg</b> , oz, lb, t			25
		UNIT2	<b>g</b> , kg, oz, lb, t			
		rESOLU				
		UNt.rOLL	ON, <b>OFF</b>			
	tArE	A-tArE	ON, <b>OFF</b>			25
		ChAIn.tr	<b>ON</b> , OFF			
		A.CL-tr	ON, <b>OFF</b> , 9 d			
	ZErO	AZM	OFF; <b>0.5 d</b> ; 1 d; 2 d; 5 d; 10 d			25
	rEStArt	ON, <b>OFF</b>				26
	FILtEr	VibrAt	LOW, <b>Med</b> , HIGH,			26
		ProCESS	<b>UNIVER</b> , dOSING			
		StAbILI	FASt, <b>StAndrd</b> , PrECISE			
	Min.WEiG	ON/OFF	ON, <b>OFF</b>			26
	rESet	SUrE?				26
SCALE (IDNet)	dISPLAY	UNIT2	<b>g</b> , kg, oz, lb, t			27
		UNt.rOLL	ON, <b>OFF</b>			
	tArE	A-tArE	ON, <b>OFF</b>			27
		ChAIn.tr	<b>ON</b> , OFF			
		A.CL-tr	ON, <b>OFF</b> , 9 d			
	ZErO	AZM	<b>ON</b> , OFF			27
	rEStArt	ON, <b>OFF</b>				27
	FILtEr	VibrAt	StAbLE, <b>nOrMAL</b> , UnStAbL,			28
		ProCESS	FinEFiL, <b>UNIVERs</b> , AbSOLUt			
		StAbILI	ASd=0, ASd=1, <b>ASd=2</b> , ASd=3, ASd=4			
	UPdAtE	Setting possibilities depend on the connected scale				28
	Min.WEiG	ON/OFF	ON, <b>OFF</b>			28
	rESet	SUrE?				28
APPLIC	AVERAGE	<b>OFF</b> , AUtO, MAnuAL				29
	rESet	SUrE?				29

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
tERMINL	dEVICE	SLEEP	OFF, 1 min, 3 min, 5 min, 15 min, 30 min			29
		PWr OFF	OFF, 1 min, 3 min, 5 min, 15 min, 30 min			
		b.LIGHT	ON, OFF, 5 sec, 10 sec, 30 sec, 1 min			
	ACCESS	SUPErVI				30
	rESet	SUrE?				30
COMMUNI	COM 1/COM 2	MoDE	Print			30
			A.Print			
			CONtINU			
			dIALOG			
			MMr			
			MMr.A.SIr			
			CONt.OLd			
			dIAL.OLd			
			dt-b	GROSS	ON, OFF	
				tArE	ON, OFF	
				nEt	ON, OFF	
			dt-G	GROSS	ON, OFF	
				tArE	ON, OFF	
				nEt	ON, OFF	
			COnT-Wt			
			2nd.dISP			
			InSt.Prn			
		PriNtEr	tYPE	ASCII, GA46		31
			tEMPLat	StdArd, tEMPLt1, tEMPLt2		
			ASci.Fmt	LINE.FMt	MULtI SINGLE FIXEd	
				LENGtH	1 ... 24 ... 100	
				SEPArAt	, ; ...	
				Add LF	0 ... 9	




Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
		PARAMeT	bAUd	300 ... <b>2400</b> ... 38400		31
			PARity	7 nonE, 8 nonE, 7 odd, 8 odd, <b>7 EVEN</b> , 8 EVEN		
			H.SHAKE	NO, <b>XONXOFF</b> , nEt 422, nEt 485		
			NEt.Addr	0 ... 31		
			ChECsUM	ON, <b>OFF</b>		
			Vcc	ON, <b>OFF</b>		
		rSt.COMx	SUrE?			
<b>COMMUNI</b>	OPTION	EtH.NET	IP.AddrS, SUBnEt, GAtEWAY			32
		WLAn	IP.AddrS, SUBnEt, GAtEWAY, SIGNAL			
		USb	USb tEst			
		diGiTAL	IN 0 ... 3	<b>OFF</b> , ZErO, tArE, Print, CLear, UNIt		
			OUt 0 ... 3	<b>OFF</b> , StAbLE, bEL.Min, AbV.Min, UndErLd, OVErLd, StAr, ...		
			SEt.Pt 1			
			SEt.Pt 2			
	dEF.PrN	tEMPLt1/ tEMPLt2	LINE 1 ... LINE 8	<b>Not .USED</b> , HEAdEr, GrOSS, tArE, nEt, StArLN, CrLF, F.FEEd		33
<b>DIAGNOS</b>	tEst SC					34
	KboArD					
	dISPLAY					
	SNr					
	LiSt					
	rESEt.AL	SUrE?				




### 3.3 Scale settings (SCALE) – analog

#### 3.3.1 CAL – calibration (adjustment)

This menu item is not available for certified scales.

CAL	<ol style="list-style-type: none"> <li>1. Unload scale.</li> <li>2. Activate menu item CAL with . The scale determines the zero point. – 0 – appears in the display. The calibration weight to be placed on the scale then flashes in the display.</li> <li>3. If necessary, change the weight value displayed with .</li> <li>4. Place the calibration weight on the scale and confirm with .</li> </ol> <p>The scale calibrates with the calibration weight loaded. After calibration is completed, –donE– appears briefly in the display, and the scale automatically returns to weighing mode.</p> <p>In order to achieve particularly high precision, calibrate under full load.</p>
-----	--

#### 3.3.2 DISPLAY – weighing unit and display accuracy

UNIT1	Select weighing unit 1: g, kg, oz, lb, t
UNIT2	Select weighing unit 2: g, kg, oz, lb, t
rESOLU	Select readability (resolution), model-dependent
UNT . rOLL	When UNT . rOLL is switched on, the weight value can be displayed in all available units with  .
Notes	<ul style="list-style-type: none"> <li>• In the case of certified scales individual sub-items of the dISPLAY menu item may not be available or only to a limited extent, depending on the respective country.</li> <li>• On dual-range/dual interval scales, resolutions marked with <b> &lt;-&gt;  1/2</b> are divided up into 2 weighing ranges / intervals, e.g. 2 x 3000 d.</li> </ul>

#### 3.3.3 TARE – tare function

A-tArE	Switching on/off automatic taring
CHAI n . tr	Switching on/off chain tare
A . CL - tr	Switching on/off automatic clearing of the tare weight when the load is removed from scale Possible settings: OFF, ON, 9 d

#### 3.3.4 ZERO – automatic zero update

AZM	On certified scales, this menu item does not appear. Switching on/off automatic zero update and selecting zeroing range. Possible settings: OFF; 0.5 d; 1 d; 2 d; 5 d; 10 d
-----	---

### 3.3.5 RESTART – automatic saving of zero point and tare value

<b>ON/OFF</b>	When the Restart function is activated, the last zero point and tare value are saved. After switching off / on or after a power interruption, the device continues to work with the saved zero point and tare value.
---------------	--

### 3.3.6 FILTER – adaptation to the ambient conditions and the weighing type



<b>VibrAt</b>  LOW  MED  HIGH	Adaptation to the ambient conditions <ul style="list-style-type: none"> <li>• Very steady and stable environment. The scale works very rapidly, but is very sensitive to external influences.</li> <li>• Normal environment. The scale operates at medium speed.</li> <li>• Restless environment. The scale works more slowly, but is insensitive to external influences.</li> </ul>
<b>ProCESS</b>  UNIVER dOSING	Adaptation to the weighing process <ul style="list-style-type: none"> <li>• Universal setting for all weighing samples and normal weighing goods</li> <li>• Dispensing liquid or powdery weighing samples</li> </ul>
<b>StAbILI</b>  FASt StAndrd PrECISE	Adjusting the stability detector <ul style="list-style-type: none"> <li>• The scale operates very fast.</li> <li>• The scale operates at medium speed.</li> <li>• The scale operates with the greatest possible reproducibility.</li> </ul> The slower the scale works, the greater the reproducibility of the weighing results.

### 3.3.7 MIN.WEIG – minimum weight

This menu item appears only if the service technician has saved a minimum weight.


<b>ON/OFF</b>	Switching minimum weight function on/off  If the weight on the scale falls below the stored minimum weight, an * appears on the display in front of the weight indicator.
---------------	---

### 3.3.8 RESET – resetting scale settings to factory settings

<b>SUrE?</b>	Confirmation inquiry <ul style="list-style-type: none"> <li>• Reset the scale settings to factory settings with </li> <li>• Do not reset scale settings with </li> </ul>
--------------	--

### 3.4 Scale settings (SCALE) – IDNet

#### 3.4.1 DISPLAY – weighing unit

<b>UNIT2</b>	Select weighing unit 2: g, kg, oz, lb, t
<b>UNT.rOLL</b>	When UNT.rOLL is switched on, the weight value can be displayed in all available units with  .
Notes	<ul style="list-style-type: none"> <li>In the case of certified scales individual sub-items of the dISPLAY menu item may not be available or only to a limited extent, depending on the respective country.</li> <li>For two-range/two-interval scales, resolutions identified with <b>1&lt;-&gt;1 1/2</b> are divided into the 2 weighing ranges/intervals, for example 2 x 3000 d.</li> </ul>

#### 3.4.2 TARE – tare function

<b>A-tArE</b>	Switching on/off automatic taring
<b>CHAIIn.tr</b>	Switching on/off chain tare
<b>A.CL-tr</b>	Switching on/off automatic clearing of the tare weight when the load is removed from scale Possible settings: OFF, ON, 9 d

#### 3.4.3 ZERO – automatic zero update

<b>AZM</b>	<p>On certified scales, this menu item does not appear.</p> <p>Switching on/off automatic zero update.</p> <p>The effective range of the zero update mode (0.5 d, 1.0 d, 3.0 d) can only be set by service technicians in case of IDNet scales.</p> <p>Factory setting: 0.5 d</p>
------------	---

#### 3.4.4 RESTART – automatic saving of zero point and tare value

<b>ON/OFF</b>	When the Restart function is activated, the last zero point and tare value are saved. After switching off /on or after a power interruption, the device continues to work with the saved zero point and tare value.
---------------	---

### 3.4.5 FILTER – adaptation to the ambient conditions and the weighing type

<b>VibrAt</b>	Adaptation to the ambient conditions
StAbLE	<ul style="list-style-type: none"> <li>Very steady and stable environment. The scale works very rapidly, but is very sensitive to external influences.</li> </ul>
nOrMAL	<ul style="list-style-type: none"> <li>Normal environment. The scale operates at medium speed.</li> </ul>
UnStAbL	<ul style="list-style-type: none"> <li>Restless environment. The scale operates more slowly, but is insensitive to external influences.</li> </ul>
<b>ProCESS</b>	Adaptation to the weighing process
FinEFIL	<ul style="list-style-type: none"> <li>Dispensing of liquid or powdered weighing samples</li> </ul>
UniVERs	<ul style="list-style-type: none"> <li>Universal setting for all weighing modes and normal weighing samples</li> </ul>
AbSOLUt	<ul style="list-style-type: none"> <li>For solid bodies under extreme conditions, e.g. strong vibrations</li> </ul>
<b>StAbILI</b>	<div>ASD = 0      Stability monitoring switched off</div> <div>Only possible for non-verifiable weighing platforms</div> <div>ASD = 1      Rapid display      Good reproducibility</div> <div>ASD = 2      ↑      ↓</div> <div>ASD = 3      ↑      ↓</div> <div>ASD = 4      Slow display      Excellent reproducibility</div>

### 3.4.6 UPDATE – setting the display speed of the weight display

This menu item is only displayed if the UPDATE function is supported by the connected weighing platform.



<b>xx UPS</b>	Selecting the number of updates per second (UPS)
Note	The possible settings depend on the connected weighing platform.

### 3.4.7 MIN.WEIG – minimum weighing-in quantity

This menu item appears only if the service technician has saved a minimum weight.


<b>ON/OFF</b>	Switching minimum weight function on/off If the weight on the scale falls below the stored minimum weight, an * appears on the display in front of the weight indicator.
---------------	---

### 3.4.8 RESET – resetting scale settings to factory settings



<b>SUR?</b>	Confirmation inquiry <ul style="list-style-type: none"> <li>Reset the scale settings to factory settings with </li> <li>Do not reset scale settings with </li> </ul>
-------------	---

### 3.5 Application settings (APPLICATION)

#### 3.5.1 AVERAGE – determining the average weight for an unstable load


<b>OFF</b>	Calculating average weight switched off
<b>AUTO</b>	Calculating average weight with automatic start of the weighing cycle
<b>MANUAL</b>	Calculating average weight with manual start of the weighing cycle via 

#### 3.5.2 RESET – resetting application settings to factory settings





<b>SURE?</b>	<p>Confirmation inquiry</p> <ul style="list-style-type: none"> <li>Reset the application settings to factory settings with </li> <li>Do not reset the application settings with </li> </ul>
--------------	---

### 3.6 Terminal settings (TERMINAL)



#### 3.6.1 DEVICE – sleep mode, energy-saving mode and display backlighting

<b>SLEEP</b>	<p>This menu item only appears on devices in mains operation.</p> <p>When <b>SLEEP</b> is activated, the scale switches off display and backlighting after the time period set when not in use. The display and backlighting are switched on again at the press of a key or if the weight changes.</p> <p>Possible settings: OFF, 1 min, 3 min, 5 min, 15 min, 30 min</p>
<b>PWR OFF</b>	<p>This menu item only appears on devices in battery operation.</p> <p>When <b>PWR OFF</b> is activated, the device switches itself off automatically after approx. 3 minutes when not in use. After this, it must be switched on again using .</p> <p>Possible settings: OFF, 1 min, 3 min, 5 min, 15 min, 30 min</p>
<b>b.LIGHT</b> OFF / 5 sec / ...	<p>Set the background lighting of the display</p> <p>Setting whether and after which time the background lighting is to be switched off. Scales with a storage battery switch the background lighting off automatically by default when no action takes place at the scale for approx. 5 seconds.</p> <p>Possible settings: OFF (switched off), 5 sec, 10 sec, 30 sec, 1 min, ON (switched on)</p>
Notes	<ul style="list-style-type: none"> <li>This menu item is accessible without a Supervisor password.</li> <li>The time specifications are approximate values.</li> </ul>

### 3.6.2 ACCESS – password for Supervisor menu access


<b>SUPeRVI</b> ENTeR.C  rEtYPE.C	Password entry for Supervisor menu access Request to enter password → Enter the password and confirm with  . Request to repeat the password entry → Enter the password again and confirm with  .
Notes	<ul style="list-style-type: none"> <li>The password can consist of up to 4 characters.</li> <li>The key  must not be part of the password. It is required for confirming the password.</li> <li>The key  may only be used in combination with another key.</li> <li>If you enter an impermissible code or make a typing error in the repetition, CODE.Err. appears in the display.</li> </ul>


### 3.6.3 RESET – resetting terminal settings to the factory settings

<b>SURe?</b>	Confirmation inquiry <ul style="list-style-type: none"> <li>Reset terminal settings to the factory settings with .</li> <li>Do not reset the terminal settings with .</li> </ul>
--------------	--

## 3.7 Configuring interfaces (COMMUNICATION)

### 3.7.1 COM1/COM2 -> MODE – operating mode of the serial interface

<b>Print</b>	Manual data output to the printer with  .
<b>A.Print</b>	Automatic output of stable results to the printer (e. g. for series weighing operations)
<b>CONtINU</b>	Ongoing output of all weight values via the interface
<b>dIALOG</b>	Bi-directional communication via MT-SICS commands, control of the scale via PC
<b>MMr</b>	Bidirectional communication via MMR commands, controlling of a scale via a PC, command set compatible to the weighing terminals ID1 and ID3.
<b>MMr.A.SIr</b>	Automatic continuous transmission: a stable or dynamic weight value is transmitted after every measuring cycle.
<b>CONt.OLd</b>	As per CONtINU, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
<b>dIAL.OLd</b>	As per dIALOG, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
<b>dt-b</b> GrOSS tArE nEt	DigiTOL-compatible format. <ul style="list-style-type: none"> <li>Transfer of the gross weight, identified with "B"</li> <li>Transfer of the tare weight</li> <li>Transfer of the net weight</li> </ul>
<b>dt-G</b>	As per dt-b, see above, gross weight identified with "G"

<b>Cont-Wt</b>	TOLEDO Continuous mode
<b>2nd.dISP</b>	For connecting a second display (automatically activates the 5-V voltage supply at Pin 9)
<b>InSt.Prn</b>	Immediate manual data output to the printer with  (not certifiable)

### 3.7.2 COM1/COM2 -> PRINTER – settings for protocol printout



This menu item only appears if the mode "Print" or "A.Print" is selected.

<b>tYPE</b> ASCII GA46	Select the printer type <ul style="list-style-type: none"> <li>• ASCII printer</li> <li>• GA46 printer</li> </ul>
<b>tEmPLat</b> StdArd tEmPLt1 tEmPLt2	Selecting protocol printout <ul style="list-style-type: none"> <li>• Standard printout</li> <li>• Printout in accordance with Template 1</li> <li>• Printout in accordance with Template 2</li> </ul>
<b>ASci.Fmt</b> LINE.Fmt  LENGtH  SEPArAt Add LF	Selecting formats for the protocol printout <ul style="list-style-type: none"> <li>• Line format: MULtI (multiple lines), SINGLE (single lines) or FIXEd (Records are output in single lines. Every record encompasses the number of character that was defined under LENGtH.)</li> <li>• Line length: 0 to 100 characters, is only displayed at the line format MULtI and FIXEd</li> <li>• Separator: , ; . / \ _ and space; appears only with line format SINGLE</li> <li>• Line feed: 0 ... 9</li> </ul>

### 3.7.3 COM1/COM2 -> PARAMET – communication parameters






<b>bAUd</b>	Selecting baud rate: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400 baud
<b>PArity</b>	Selecting parity: 7 none, 8 none, 7 odd, 8 odd, 7 even, 8 even
<b>H.SHAKE</b>	Select handshake: NO, XONXOFF, NET 422 (network operation via the optional RS422/RS485 interface via 4-wire bus, only for COM1), NET 485 (network operation via the optional RS422/RS485 interface via 2-wire bus, only for COM1)
<b>NEt.Addr</b>	Assigning network address: 0 ... 31, only for NET 485
<b>ChECSuM</b>	Activating checksum byte (appears only in TOLEDO Continuous mode)
<b>Vcc</b>	Switching 5 V voltage, e.g. for a bar code reader or the optional interface RS485/422, on/off

### 3.7.4 COM1/COM2 -> RESET COM1/RESET COM2 – resetting serial interface to factory settings

<b>SUre?</b>	<p>Confirmation inquiry</p> <ul style="list-style-type: none"> <li>Reset interface settings to factory settings with </li> <li>Do not reset the interface settings with </li> </ul>
--------------	--

### 3.7.5 OPTION – configuring options

If no option is installed or is not yet configured, N . A . appears in the display.

<b>Eth.NET</b>  IP.AddrS SubNEt GAtEWAY	<p>Configuration of the Ethernet interface</p> <ul style="list-style-type: none"> <li>Enter IP address</li> <li>Enter Subnet address</li> <li>Enter Gateway address</li> </ul>
<b>WLAn</b>  IP.AddrS SubNEt GAtEWAY SIGNAL	<p>Configuration of the WLAN interface</p> <ul style="list-style-type: none"> <li>Enter IP address</li> <li>Enter subnet address</li> <li>Enter gateway address</li> <li>SIG ... shows the signal strength of the WLAN connection as a percentage value.  0 to 25      very weak  26 to 49    weak  50 to 74    good  75 to 100   excellent  Reliable operation requires at least a good signal strength.</li> </ul>
<b>USb</b>  USb tEST	<p>Configuration of the USB interface</p> <ul style="list-style-type: none"> <li>Test of the USB interface. After the test has been passed, rEAdY appears in the display.</li> </ul>
<b>diGiTAL</b>  IN 0 ... 3 OFF ZErO tArE PriNt CLEAr UNIt	<p>Configuration of the digital inputs/outputs</p> <p>Configuring inputs 0 ... 3</p> <ul style="list-style-type: none"> <li>Input not assigned</li> <li>Key </li> <li>Key </li> <li>Key </li> <li>Key </li> <li>Key </li> </ul>













OUT 0 ... 3	Configuring outputs 0 ... 3
OFF	• Output not assigned
StAbLE	• Stable weight value
bEL.Min	• Minimum weight not reached
AbV.Min	• Minimum weight reached or exceeded
UNdErLd	• Insufficient load
OVERLd	• Overload
StAr	• Changed/calculated value
bEL.SP1	• Setpoint 1 not reached
AbV.SP1	• Setpoint 1 reached or exceeded
bEL.SP2	• Setpoint 2 not reached
AbV.SP2	• Setpoint 2 reached or exceeded
SEt.Pt1	Enter value for setpoint 1
SEt.Pt2	Enter value for setpoint 2

### 3.7.6 DEF.PRN – configuring templates

<b>tEMPLt1/tEMPLt2</b>	Selecting Template 1 or Template 2
LINE 1 ... 8	Selecting line
NOT.USEd	• Line not used
HEAdEr	• Line as header. The contents of the header must be defined via an interface command, see Section 4.1.
GrOSS	• Gross weight
tArE	• Tare weight
nEt	• Net weight
StArLN	• Line with ***
CrLF	• Line feed (blank line)
F.FEEd	• Page feed

### 3.8 Diagnosis and printing out of the menu settings (DIAGNOS)

<b>tEst SC</b>  External	Testing the scale This menu item is only displayed at scales with an analog scale interface. Testing scale with external calibration weight 1. The scale checks the zero point. –0– appears in the display. The test weight flashes in the display. 2. If necessary, change the weight value displayed with  . 3. Put the calibration weight on the scale and confirm with  . 4. The scale checks the calibration weight put on them. 5. After the test is completed, the deviation from the last calibration briefly appears in the display, ideally $\Delta = 0.0g$ , after which the scale changes to the next menu item KboArđ.
<b>KboArđ</b>  PUSH 1 ... 6	Keyboard test <ul style="list-style-type: none"> <li>Press the keys       in order. If the key works, the scale changes to the next key.</li> </ul> <b>Note</b> You cannot abort the keyboard test! If you have selected the menu item KboArđ, you must press all keys.
<b>dISPLAY</b>	Display test: The scale displays all functioning segments
<b>SNr</b>	Display of the serial number
<b>List</b>	Printout of a list of all menu settings
<b>rESet.AL</b>  SUrE?	Resetting all menu settings to the factory settings Confirmation inquiry <ul style="list-style-type: none"> <li>Reset all menu settings to the factory settings with .</li> <li>Do not reset the menu settings with .</li> </ul>

## 4 Interface description

### 4.1 SICS interface commands

The device supports the command set MT-SICS (METTLER TOLEDO **S**tandard **I**nterface **C**ommand **S**et). With SICS commands, it is possible to configure, query and operate the scales from a PC. SICS commands are divided up into various levels.

#### 4.1.1 Available SICS commands

	Command	Meaning
<b>LEVEL 0</b>	@	Reset the scale
	I0	Inquiry of all available SICS commands
	I1	Inquiry of SICS level and SICS versions
	I2	Inquiry of scale data
	I3	Inquiry of scale software version
	I4	Inquiry of serial number
	I6	Inquiry of weighing parameters
	S	Send stable weight value
	SI	Send weight value immediately
	SIR	Send weight value repeatedly
	Z	Zero the scale
	ZI	Zero immediately
<b>LEVEL 1</b>	D	Write text into display
	DW	Weight display
	K	Keyboard check
	SR	Send and repeat stable weight value
	T	Tare
	TA	Tare value
	TAC	Clear tare
	TI	Tare immediately

In the case of Levels 0 and 1, these are commands which, if implemented, will function identically with all METTLER TOLEDO scales or weighing terminals.

In addition there are also further interface commands which apply either to the entire product series or to the particular application level. This and further information on the MT-SICS command set may be found in the MT-SICS Manual (Order Number 22 011 459 or at [www.mt.com](http://www.mt.com)) or be obtained by request from your METTLER TOLEDO customer service representative.

#### 4.1.2 Requirements for communication between scale and PC

- The scale must be connected to the RS232, RS485, USB or Ethernet interface of a PC with a suitable cable.
- The interface of the scale must be set to "Dialog" mode, see Section 4.6.1.
- A terminal program must be available on the PC, e.g. HyperTerminal.
- The communication parameters baud rate and parity must be set in the terminal program and on the scale to the same values, see Section 4.6.3.

#### 4.1.3 Notes on network operation via the optional interface RS422/485

Up to 32 scales can be networked with the optional RS422/485 interface. In network operation, the scales must be addressed from the computer before commands can be sent and weighing results received.

Address	Hex	ASCII
0	0x30	0
1	0x31	1
2	0x32	2
...	...	...
9	0x39	9
10	0x3A	:
11	0x3B	;
...	...	...
31	0x4F	0

Description of the steps	Host	Direction	Scale
1. Host addresses the scale, e.g. with the address 3A hex.	<ESC> :	—>	
2. Host sends a SICS command, e.g. SI	SI <CRLF>	—>	
3. The scale confirms receipt of the command and sends the address back		<—	<ESC>:
4. The scale responds to the command and returns control of the bus to the host		<—	S_S___45.02_kg <CRLF>

## 4.2 TOLEDO Continuous mode

### 4.2.1 TOLEDO Continuous commands

In TOLEDO Continuous mode the scale supports the following input commands:

Command	Meaning
<b>P</b>	Printing out the current result
<b>T</b>	Taring of the scale
<b>Z</b>	Zero setting of the display
<b>C</b>	Deleting of the current value

### 4.2.2 Output format in TOLEDO Continuous mode

Weight values are always transferred in TOLEDO Continuous mode in the following format:

1	Status			Field 1						Field 2						17	18
	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
STX	SWA	SWB	SWC	MSD	–	–	–	–	LSD	MSD	–	–	–	–	LSD	CR	CHK
Field 1		Cont-Wt: 6 digits for the weight value that is transferred without comma and unit															
Field 2		Cont-Wt: 6 digits for the tare weight that is transferred without comma and unit															
STX		ASCII character 02 hex, character for "start of text"															
SWA, SWB, SWC		Status words A, B, C, see below															
MSD		Most significant digit															
LSD		Least significant digit															
CR		Carriage Return, ASCII character 0D hex															
CHK		Checksum (2-complement of the binary sum of the 7 lower bits of all the characters sent beforehand incl. STX and CR)															

Status word A								
Function	Selection	Status bit						
		6	5	4	3	2	1	0
Decimal position	X00	0	1			0	0	0
	X0					0	0	1
	X					0	1	0
	0.X					0	1	1
	0.0X					1	0	0
	0.00X					1	0	1
	0.000X					1	1	0
	0.0000X					1	1	1
Numerical increment	X1			0	1			
	X2			1	0			
	X5			1	1			

Status word B	
Function/Value	Bit
Gross/Net: Net = 1	0
Sign: Negative = 1	1
Overload/Underload = 1	2
Movement = 1	3
lb/kg: kg = 1	4
1	5
Power up = 1	6

Status word C				
Function/Value				Bit
kg/lb	g	†	oz	
0	1	0	1	0
0	0	1	1	1
0	0	0	0	2
Print request = 1				3
Extended = 1				4
1				5
Tare manually, only kg = 1				6

### 4.3 MMR interface commands

The device supports the command set MMR (**M**ETTLER **M**ulti**R**ange). This command set is compatible to the weighing terminals ID1 and ID3. For new installations we recommend the SICS command set, refer to Section 4.1.

#### 4.3.1 Available MMR commands

Com- mand	Meaning
AR	Read application block
AW	Write application block
D	Describe display
RO	Switch on the keyboard
R1	Switch off the keyboard
S	Transmit stable weight value
SI	Transmit weight value immediately
SIR	Transmit weight value immediately and repeat
SR	Transmit stable weight value and repeat
SX	Transmit stable data record
SXI	Transmit data record immediately
SXIR	Transmit data record immediately and repeat
T	Taring
U	Switch over weight unit
Z	Setting to zero

### 4.3.2 Syntax and formats

Commands have to be entered as ASCII characters and completed with  $C_{RLF}$ .

The following ASCII characters are available: 20 hex/32 dec ... 7F hex/127 dec.

#### Command format when transmitting weight values

Identification	–	Weight value	–	Unit	Limit
String of characters for specification of command (1 ... 4 characters)	Blank	1 ... 8 digits, Number of digits variable	Blank	1 ... 3 characters, Number of characters variable	$C_{RLF}$

#### Response format when transmitting weight values

Identification	–	Weight value	–	Unit	Limit
String of characters for specification of the response (2 ... 3 characters)	Blank	10 digits, right-justified, fill with blanks	Blank	3 characters, left-justified, fill with blanks	$C_{RLF}$

#### Example

**Tare specification command**     T\_13.295\_kg

**Tare specification response**     TBH\_ \_ \_ \_ 13.295\_kg\_

### 4.3.3 Error messages

Error messages consist of 2 characters and the delimiter  $C_{RLF}$ .

Error message	Meaning	Description
ET	Transmission error	Error in the received bit sequence, e.g. parity error, missing stop bit
ES	Syntax error	The received character string cannot be processed, e.g. command does not exist
EL	Logic error	Command cannot be executed, command is not supported on this application level







#### 4.3.4 Available application blocks

The device disposes of the following application blocks. The numbers of application blocks that can be written are printed in **bold**.

No.	Content
002	Current program number
003	<STX>
004	<ETX>
006	<CR><LF>
007	Gross, 2nd unit
008	Net, 2nd unit
009	Tare, 2nd unit
011	Gross, 1st unit
012	Net, 1st unit
<b>013</b>	Tare, 1st unit
014	Display contents
016	Dynamic weighing

## 5 Event and error messages

Error	Cause	Remedy
Display dark	<ul style="list-style-type: none"> <li>• Back lighting set too dark</li> <li>• No mains voltage</li> <li>• Unit switched off</li> <li>• Mains cable not plugged in</li> <li>• Brief fault</li> </ul>	<ul style="list-style-type: none"> <li>→ Set back lighting (b.LIGHT) brighter</li> <li>→ Check mains</li> <li>→ Switch on unit</li> <li>→ Plug in mains plug</li> <li>→ Switch device off and back on again</li> </ul>
Insufficient load L _ _ _ _ J	<ul style="list-style-type: none"> <li>• Load plate not on the scale</li> <li>• Weighing range not reached</li> </ul>	<ul style="list-style-type: none"> <li>→ Place load plate on the scale</li> <li>→ Set to zero</li> </ul>
Overload r _ _ _ _ 7	<ul style="list-style-type: none"> <li>• Weighing range exceeded</li> </ul>	<ul style="list-style-type: none"> <li>→ Unload scale</li> <li>→ Reduce preload</li> </ul>
_ _ _ _ _	<ul style="list-style-type: none"> <li>• Result not yet stable</li> </ul>	<ul style="list-style-type: none"> <li>→ If necessary, adjust vibration adapter or weigh dynamically</li> </ul>
_ _ n o _ _	<ul style="list-style-type: none"> <li>• Function not permissible</li> </ul>	<ul style="list-style-type: none"> <li>→ Unload scale and set to zero</li> </ul>
r _ _ n o _ 7 L _ _ n o _ J	<ul style="list-style-type: none"> <li>• Zeroing not possible with overload or insufficient load</li> </ul>	<ul style="list-style-type: none"> <li>→ Unload scale</li> </ul>
E r r 6	<ul style="list-style-type: none"> <li>• No calibration</li> </ul>	<ul style="list-style-type: none"> <li>→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode</li> <li>→ Calibrate scale</li> <li>→ Call METTLER TOLEDO Service</li> </ul>
E r r 17	<ul style="list-style-type: none"> <li>• Printout not yet ended</li> </ul>	<ul style="list-style-type: none"> <li>→ End printout</li> <li>→ Repeat required action</li> </ul>
E r r 18	<ul style="list-style-type: none"> <li>• Switching the weighing unit impermissible during dynamic weighing</li> </ul>	<ul style="list-style-type: none"> <li>→ End dynamic weighing</li> </ul>
E r r 30	<ul style="list-style-type: none"> <li>• No IDNet scale found</li> </ul>	<ul style="list-style-type: none"> <li>→ Check connectors and cabling</li> <li>→ Call METTLER TOLEDO service</li> </ul>

Error	Cause	Remedy
	<ul style="list-style-type: none"> <li>Data communication with IDNet scale faulty</li> </ul>	<ul style="list-style-type: none"> <li>→ Remove and plug the power plug back in. In case of battery operation switch the device off and on again</li> <li>→ Call METTLER TOLEDO service</li> </ul>
	<ul style="list-style-type: none"> <li>Restart error</li> </ul>	<ul style="list-style-type: none"> <li>→ Remove and plug the power plug back in. In case of battery operation switch the device off and on again</li> <li>→ Call METTLER TOLEDO service</li> </ul>
	<ul style="list-style-type: none"> <li>Weighing error</li> </ul>	<ul style="list-style-type: none"> <li>→ Remove and plug the power plug back in. In case of battery operation switch the device off and on again</li> <li>→ Call METTLER TOLEDO service</li> </ul>
	<ul style="list-style-type: none"> <li>EAROM checksum error</li> </ul>	<ul style="list-style-type: none"> <li>→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode</li> <li>→ Call METTLER TOLEDO Service</li> </ul>
Weight display unstable	<ul style="list-style-type: none"> <li>Restless installation location</li> <li>Draft</li> <li>Restless weighing sample</li> <li>Contact between weighing pan and/or weighing sample and surroundings</li> <li>Mains fault</li> </ul>	<ul style="list-style-type: none"> <li>→ Adjust vibration adapter</li> <li>→ Avoid drafts</li> <li>→ Weigh dynamically</li> <li>→ Remedy contact</li> <li>→ Check mains</li> </ul>
Incorrect weight display	<ul style="list-style-type: none"> <li>Incorrect zeroing</li> <li>Incorrect tare value</li> <li>Contact between weighing pan and/or weighing sample and surroundings</li> <li>Scale tilted</li> </ul>	<ul style="list-style-type: none"> <li>→ Unload scale, set to zero and repeat weighing operation</li> <li>→ Clear tare</li> <li>→ Remedy contact</li> <li>→ Level scale</li> </ul>

## 6 Technical data and accessories

### 6.1 Technical data

#### 6.1.1 General data

<b>IND429 / IND429xx / BBA429</b>	
Applications	<ul style="list-style-type: none"> <li>• Weighing</li> <li>• Dynamic weighing</li> </ul>
Settings	<ul style="list-style-type: none"> <li>• Resolution can be selected</li> <li>• Weighing unit can be selected: g, kg, oz, lb, t</li> <li>• Taring function: Manual, automatic, next tare</li> <li>• Automatic zero compensation mode during switching on and during operation</li> <li>• Filter for adapting to the environmental conditions (vibration adapter)</li> <li>• Filter for adapting to the weighing mode, e.g. dispensing (weighing process adapter)</li> <li>• Switch-off function, sleep mode for power-operated devices, energy saving mode for storage battery operation</li> <li>• Display illumination</li> </ul>
Display	<ul style="list-style-type: none"> <li>• LCD liquid crystal display, digit height 16 mm, backlighting</li> </ul>
Keyboard	<ul style="list-style-type: none"> <li>• Tactile-touch membrane keypad</li> <li>• Scratch-resistant labelling</li> </ul>
Housing	<ul style="list-style-type: none"> <li>• Stainless steel 1.4301 or AISI 304</li> <li>• For dimensions, see Page 46</li> </ul>
Net weight	<ul style="list-style-type: none"> <li>• IND429/IND429xx with AC power supply unit approx. 2.2 kg</li> <li>• IND429/IND429xx with storage battery approx. 2.8 kg</li> <li>• BBA429-A with AC power supply unit approx. 9.0 kg</li> <li>• BBA429-A with storage battery approx. 9.6 kg</li> <li>• BBA429-BB with AC power supply unit approx. 12.1 kg</li> <li>• BBA429-BB with storage battery approx. 12.7 kg</li> </ul>
Protection type (DIN 40050)	<ul style="list-style-type: none"> <li>• IP69K</li> </ul>

<b>IND429 / IND429xx / BBA429</b>															
Mains connection	<p>Direct connection to power supply (supply voltage fluctuation not exceeding <math>\pm 10\%</math> of the rated voltage)</p> <ul style="list-style-type: none"> <li>• IND429 weighing terminal: Rated voltage 100 ... 240 VAC / 47 ... 63 Hz / 300 mA</li> <li>• IND429xx weighing terminal: Rated voltage 230 VAC <math>\pm 10\%</math> / 47 ... 63 Hz / 300 mA</li> <li>• BBA429 compact scale Rated voltage 100 ... 240 VAC / 47 ... 63 Hz / 300 mA</li> </ul>														
Storage battery operation	<p>Supply at device: 24 VDC / 1.0 A</p> <p>If the supply voltage is interrupted, the scale switches automatically over to storage battery operation</p> <p>For operating life, see Section 6.1.2.</p>														
Ignition protection type IND429xx (to IEC 60079-15)	<ul style="list-style-type: none"> <li>• Hazardous area Zone 2: Device category II 3G EEx nA II T4, Temperature range <math>-10\text{ }^{\circ}\text{C}</math> ... <math>+40\text{ }^{\circ}\text{C}</math> / <math>14\text{ }^{\circ}\text{F}</math> ... <math>104\text{ }^{\circ}\text{F}</math></li> <li>• Hazardous area Zone 22: Device category II 3D IP66 T 70°C</li> </ul>														
Ambient conditions	<table border="0"> <tr> <td>• Application</td><td>in interiors</td></tr> <tr> <td>• Height</td><td>up to 2,000 m</td></tr> <tr> <td>• Temperature range Class III</td><td><math>-10\text{ }^{\circ}\text{C}</math> ... <math>+40\text{ }^{\circ}\text{C}</math> / <math>14\text{ }^{\circ}\text{F}</math> ... <math>104\text{ }^{\circ}\text{F}</math></td></tr> <tr> <td>• Temperature range Class II</td><td><math>0\text{ }^{\circ}\text{C}</math> ... <math>+40\text{ }^{\circ}\text{C}</math> / <math>32\text{ }^{\circ}\text{F}</math> ... <math>104\text{ }^{\circ}\text{F}</math></td></tr> <tr> <td>• Installation/overvoltage category</td><td>II</td></tr> <tr> <td>• Pollution degree</td><td>2</td></tr> <tr> <td>• Relative humidity</td><td>up to max. 80 %, non-condensing</td></tr> </table>	• Application	in interiors	• Height	up to 2,000 m	• Temperature range Class III	$-10\text{ }^{\circ}\text{C}$ ... $+40\text{ }^{\circ}\text{C}$ / $14\text{ }^{\circ}\text{F}$ ... $104\text{ }^{\circ}\text{F}$	• Temperature range Class II	$0\text{ }^{\circ}\text{C}$ ... $+40\text{ }^{\circ}\text{C}$ / $32\text{ }^{\circ}\text{F}$ ... $104\text{ }^{\circ}\text{F}$	• Installation/overvoltage category	II	• Pollution degree	2	• Relative humidity	up to max. 80 %, non-condensing
• Application	in interiors														
• Height	up to 2,000 m														
• Temperature range Class III	$-10\text{ }^{\circ}\text{C}$ ... $+40\text{ }^{\circ}\text{C}$ / $14\text{ }^{\circ}\text{F}$ ... $104\text{ }^{\circ}\text{F}$														
• Temperature range Class II	$0\text{ }^{\circ}\text{C}$ ... $+40\text{ }^{\circ}\text{C}$ / $32\text{ }^{\circ}\text{F}$ ... $104\text{ }^{\circ}\text{F}$														
• Installation/overvoltage category	II														
• Pollution degree	2														
• Relative humidity	up to max. 80 %, non-condensing														
Interfaces	<ul style="list-style-type: none"> <li>• 1 RS232 interface integrated</li> <li>• 1 further optional interface possible</li> </ul>														
Technical data for analog scales	<p>For technical data of the analog scales to be connected to IND429 / IND429xx please refer to the "IND4x9 / BBA4x9" installation instructions.</p> <p>For technical data of the weighing platform used at BBA429 please refer to the PBA430 operating instructions.</p>														

### 6.1.2 Operating life with storage battery


The operating life during storage battery operation differs depending on the intensity of use, the configuration and the connected scale.

The following approximate values apply with activated background lighting and with standard RS232 interface.

Scale	Conditions	Duration
Scale with 1 DMS weighing cell (e.g. BBA429)	10 % operating time 90 % power-off mode	120 h
	Continuous operation	12 h
Scale with 4 DMS weighing cells	10% operating time 90% power-off mode	90 h
	Continuous operation	9 h
K line	10% operating time 90% power-off mode	70 h
	Continuous operation	7 h


Any additional optional equipment reduces the operating life correspondingly.

### 6.1.3 IND429 / IND429xx weighing terminal dimensions



Dimensions in mm

### 6.1.4 BBA429 compact scale dimensions



Dimensions in mm

Model	A	B	C	D	E	F
BBA429-A...	300	102.5	235	240	175	380
BBA429-BB	400	104.5	335	300	235	450

### 6.1.5 Interface connections

The device can be equipped with a maximum of 2 communication interfaces. The following combinations are possible:

	COM1	COM2
Standard	RS232	—
Standard + RS232	RS232	RS232
Standard + RS422/485	RS422/485	RS232
Standard + Ethernet	RS232	Ethernet
Standard + USB	RS232	USB
Standard + Digital I/O	RS232	Digital I/O
Standard + WLAN	RS232	WLAN

## 6.2 Accessories

Designation	Order number
GA46 thermal printer, RS232, 2.5 m cable and connector incl., not for a hazardous area	00 505 471
GA46 thermal printer, RS232, 0.4 m cable and connector incl., not for a hazardous area	00 507 229
GA46-W thermal printer, take-up device/protective hood, RS232, 2.5 m cable and connector incl., not for a hazardous area	00 505 799
GA46-W thermal printer, take-up device/protective hood, RS232, 0.4 m cable and connector incl., not for a hazardous area	00 507 230
Secondary display ADI419 (display without background lighting, stainless steel, IP69K, RS232, 3 m cable incl.), not for a hazardous area	22 013 962
Secondary display ADI419-B (display with background lighting, stainless steel, IP69K, RS232, 3 m cable incl.), not for a hazardous area	22 014 022
RS232 cable for SICS second scale (3 m, 8 pin <-> 9 pin Sub D connector)	22 006 795
RS232 cable for PC (3 m, 8 pin <-> 9 pin Sub D socket)	00 504 376
RS232 mating plug, 8 pin	00 503 756
RS422/RS485 cable (3 m, 6 pin <-> open ends)	00 204 933
RS422/RS485 mating plug, 6 pin	00 204 866
Ethernet 10/100 Base T twisted pair cable (5 m -> 8 pin RJ45)	00 205 247
Ethernet 10/100 Base T twisted pair cable (20 m -> 8 pin RJ45)	00 208 152
USB adapter cable (0.2 m -> USB Series A socket)	22 006 268
USB adapter cable (3 m -> USB Series A socket)	22 007 713
Relay box for digital I/O option, not for a hazardous area	22 011 967
Connection cable Digital I/O option with relay box (10 m)	00 504 458
Digital I/O mating plug, 19 pin	00 504 461
Protective hood for IND4x9 terminals (set with 3 pieces) not for a hazardous area	22 013 963
Protective hood for BBA4x9 compact scales (set with 3 pieces)	22 013 992
Stand, stainless steel, for IND4x9 and PBA430, height 330 mm	22 013 964
Stand, stainless steel, for IND4x9 and PBA430, height 660 mm	22 013 965





<b>Designation</b>	<b>Order number</b>
Stand, stainless steel, for IND4x9 and KA, KB, MA, MB and DB weighing platforms	22 014 836
Bench stand, stainless steel, for IND4x9, suitable for mounting frame 503632 and 504854	22 014 835
Floor stand, stainless steel, for IND4x9	22 014 834
Stand base for floor stand	22 011 982
Wall adapter, stainless steel, for IND4x9, tiltable	22 013 966
Wall bracket, stainless steel, for IND4x9, rotatable and tiltable	22 014 833
GA46 mounting plate, stainless steel, for bench stand, floor stand and wall bracket	22 011 985
External storage battery for BBA4x9, stainless steel, IP69K (without charger)	22 013 988
Charger for version with internal or external storage battery (incl. power cable)	22 014 056

## 7 Appendix

### 7.1 Safety checks

The device has been tested by accredited inspection bodies. It has passed the safety checks listed below and carries the relevant test symbols. Production is subject to production monitoring by the inspection offices.

Country	Test symbol	Standard
Canada USA		CAN/CSA-C22.2 No. 1010.1-92 (für IND429) CAN/CSA-C22.2 No. 1010.1-04 (für BBA429) UL Std. No. 61010A-1
Other countries	<b>CB Scheme</b>	IEC/EN61010-1:2001
EU	<b>ATEX prototype test certificate</b> 	only for IND429xx: EN 60079-15:2003 EN 50281-1-1:1998

### 7.2 Tests for utilisation in hygienically sensitive areas

Weighing terminal IND429 and compact scale BBA429 have been assessed by the EHEDG (European Hygienic Engineering and Design Group) and the NSF (National Sanitation Foundation).

Both institutes certify the fulfilment of the hygienic requirements for easy cleaning (Hygienic Design Criteria).

**EHEDG** The EHEDG is an association of device manufacturers, firms in the foodstuff industry, research institutes and health authorities. It was founded in 1989 with the aim of promoting the hygienically faultless manufacturing and packaging of foodstuffs. A positive expertise of the device by the EHEDG has taken place.

A corresponding report is available on the Internet under [www.mt.com](http://www.mt.com).

**NSF** NSF is an independent NGO founded in 1944 in the USA. Corresponding regulations were published for the use of devices in the foodstuff industry. The device fulfils the NSF criteria C-2 (Special Equipment and/or Devices) for use in the foodstuff industry. The corresponding certificate is available on the Internet under [www.mt.com](http://www.mt.com).

### 7.3 Working to GMP (Good Manufacturing Practice)

Weighing terminal IND429 and compact scale BBA429 were evaluated by the Steinbeis-Transferinstitut Berlin with the following result:

**"The device is excellently suited for GMP working to EC-GMP Guideline Annex 15 and PIC/S Guideline PI 006-1."**

The evaluation encompasses the following points:

- Requirements for surfaces in the pharmaceutical production
- Ability to be cleaned
- Calibration
- Documentation with regard to qualification

The corresponding certificate is available on the Internet under [www.mt.com](http://www.mt.com).

### 7.4 Tables of geo values

For weighing instruments verified at the manufacturer's, the geo value indicates the country or geographical zone for which the instrument is verified. The geo value set in the instrument (e.g. "Geo 18") appears briefly after switch-on or is specified on a label.

Table **GEO VALUES 3000e** shows the geo values for European countries.

Table **GEO VALUES 6000e/7500e** shows the geo values for different gravitation zones.

#### 7.4.1 GEO VALUES 3000e, OIML Class III (European Countries)

Geographical latitude	Geo value	Country
46°22' – 49°01'	18	Austria
49°30' – 51°30'	21	Belgium
41°41' – 44°13'	16	Bulgaria
42°24' – 46°32'	18	Croatia
48°34' – 51°03'	20	Czechia
54°34' – 57°45'	23	Denmark
57°30' – 59°40'	24	Estonia
59°48' – 64°00'	25*	Finland
64°00' – 70°05'	26	
41°20' – 45°00'	17	France
45°00' – 51°00'	19*	
47°00' – 55°00'	20	Germany
34°48' – 41°45'	15	Greece
45°45' – 48°35'	19	Hungary

<b>Geographical latitude</b>	<b>Geo value</b>	<b>Country</b>
63°17' – 67°09'	26	Iceland
51°05' – 55°05'	22	Ireland
35°47' – 47°05'	17	Italy
55°30' – 58°04'	23	Latvia
47°03' – 47°14'	18	Liechtenstein
53°54' – 56°24'	22	Lithuania
49°27' – 50°11'	20	Luxemburg
50°46' – 53°32'	21	Netherlands
57°57' – 64°00'	24*	Norway
64°00' – 71°11'	26	
49°00' – 54°30'	21	Poland
36°58' – 42°10'	15	Portugal
43°37' – 48°15'	18	Romania
47°44' – 49°46'	19	Slovakia
45°26' – 46°35'	18	Slovenia
36°00' – 43°47'	15	Spain
55°20' – 62°00'	24*	Sweden
62°00' – 69°04'	26	
45°49' – 47°49'	18	Switzerland
35°51' – 42°06'	16	Turkey
49°00' – 55°00'	21*	United Kingdom
55°00' – 62°00'	23	

\* factory setting

**7.4.2 GEO VALUES 6000e/7500e OIML Class III (Height ≤1000 m)**

<b>Geographical latitude</b>	<b>Geo value</b>
00°00' – 12°44'	5
05°46' – 17°10'	6
12°44' – 20°45'	7
17°10' – 23°54'	8
20°45' – 26°45'	9
23°54' – 29°25'	10
26°45' – 31°56'	11
29°25' – 34°21'	12
31°56' – 36°41'	13
34°21' – 38°58'	14
36°41' – 41°12'	15
38°58' – 43°26'	16
41°12' – 45°38'	17
43°26' – 47°51'	18
45°38' – 50°06'	19
47°51' – 52°22'	20
50°06' – 54°41'	21
52°22' – 57°04'	22
54°41' – 59°32'	23
57°04' – 62°09'	24
59°32' – 64°55'	25
62°09' – 67°57'	26
64°55' – 71°21'	27
67°57' – 75°24'	28
71°21' – 80°56'	29
75°24' – 90°00'	30

## 7.5 FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to both Part 15 of the FCC Rules and the radio interference regulations of the Canadian Department of Communications. These limits are designed to provide a reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the user manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Cet appareil a été testé et s'est avéré conforme aux limites prévues pour les appareils numériques de class A et à la partie 15 des règlements FCC et à la réglementation des radio-Interférences du Canadian Department of Communications. Ces limites sont destinées à fournir une protection adéquate contre les interférences néfastes lorsque l'appareil est utilisé dans un environnement commercial. Cet appareil génère, utilise et peut radier une énergie à fréquence radioélectrique; il est en outre susceptible d'engendrer des interférences avec les communications radio, s'il n'est pas installé et utilisé conformément aux instructions du mode d'emploi. L'utilisation de cet appareil dans les zones résidentielles peut causer interférences néfastes, auquel cas l'exploitant sera amené à prendre les dispositions utiles pour palier aux interférence à ses propres frais.

## 8 Index

### A

Accessories ..... 48  
 Additional equipment ..... 8  
 Adjustment ..... 25  
 Ambient conditions ..... 45  
 Analog scale ..... 45  
 Applications ..... 44  
 Average ..... 17, 29

### C

Calibration ..... 25  
 Chain tare ..... 17  
 Cleaning ..... 18  
 Compact scale ..... 8  
 Continuous mode ..... 37

### D

Device overview ..... 9  
 Digital I/O ..... 47  
 Dimensions ..... 46, 47  
 Display ..... 10  
 Display accuracy ..... 25  
 Display precision ..... 27  
 Dynamic weighing ..... 17, 29

### E

Error messages ..... 42  
 Ethernet ..... 47  
 Explosion protected weighing  
 terminals ..... 5  
 External power supply .... 8, 14, 49

### F

Filter ..... 26, 28

### H

Hygienically sensitive areas . 7, 18,  
 50

### I

Ignition protection type ..... 45  
 Interface commands  
     MMR ..... 39  
 Interface protocol ..... 37, 39  
 Interfaces  
     Configuring ..... 30  
     Connections ..... 8, 47

### K

Keyboard ..... 11

### M

Mains connection ..... 12, 13, 45

#### Menu

    Application ..... 29  
     Communication ..... 30  
     Diagnosis ..... 34  
     Operation ..... 20  
     Overview ..... 22  
     Scale ..... 25, 27  
     Terminal ..... 29

Menu structure ..... 21

### O

Operator menu ..... 20  
 Options ..... 32

### P

Password ..... 20  
 Power supply ..... 12, 13  
 Protocol ..... 18

### R

#### Reset

    Application ..... 29  
     Interface ..... 32  
     Scale ..... 26, 28  
     Terminal ..... 30  
 RS232 ..... 45, 47  
 RS422 ..... 47  
 RS422/RS485 ..... 36  
 RS485 ..... 47

### S

Safety checks ..... 50  
 Safety instructions ..... 5  
 SICS commands ..... 35  
 Storage battery operation .... 13, 46  
 Supervisor menu ..... 20  
 Switching off ..... 15  
 Switching on ..... 15

### T

#### Tare

    Automatic ..... 16  
     Chain tare ..... 17  
     Clearing ..... 16  
 Terminal settings ..... 29  
 TOLEDO Continuous ..... 37

### U

USB ..... 47

### V

Verification ..... 14

### W

Weighing terminal ..... 8  
 Weighing unit ..... 25, 27  
 WLAN ..... 32, 47

### Z

Zeroing ..... 15



**22013801B**

Subject to technical changes © Mettler-Toledo (Albstadt) GmbH 05/08 Printed in Germany 22013801B

**Mettler-Toledo (Albstadt) GmbH**

D-72458 Albstadt

Tel. ++49-7431-14 0, Fax ++49-7431-14 232

Internet: <http://www.mt.com>