
microlab

Hive **PORTABLE** BLUFTOOTH SPEAKER

Bluetooth



Prior to initial use, please read the manual carefully

Important Safety Instructions



IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.

2. Keep these instructions – The safety and operating instructions should be retained for future references—All warnings on the appliance and in the operating instructions should be adhered to.

- appliance and in the operating instructions appliance and in the operating instructions appliance and in the operating instructions should be adverted to All operating and use instructions should be followed.

 Do not use this apparatus near water The appliance should not be used near water or moisture For example, in a wet basement or near a swimming pool, and the like.

 Gelean only with dry cloth.

 Do not toked any ventilation openings. Install in accordance with the manufacture's instructions. Do not install near any heat sources such as radiators, heat registers, stowes, or other apparatus (including amplifiers) that produce heat.

 Only use attachments/accessories specified by

- heat.

 9. Only use attachments/accessories specified by the manufacturer.

 10. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cartiapparatus combination to avoid injury from
- car/lapparatus combination to avoid injury from tip-over. Unplug the apparatus during lightning storms or when unused for long periods of time. Refer all servicing to qualified personals has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moleture, does not operate normally, or has been dropped.
- WARNING: To reduce the risk of fire or electric warkinios. To reduce the risk of life of electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed.
- on apparatus.

 AUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

 WARNING: The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

Important Safety Instructions



16. This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product' s enclosure that may be of sufficient magnitude to constitute a risk of electric shock. constitute a risk of electric shock. Warning: To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

accompanying the appliance.

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle if responsibly to promote the sustainable reuse of material to the controlled waste disposal, recycle if responsibly to promote the sustainable reuse of material to the sustainable reuse of materials. The product was purchased. They can take this product for environmental safe recycling.

No naked flame sources, such as lighted

- safe recycling.

 18. No naked flame sources, such as lighted candles, should be placed on the apparatus. 19. Replacement parts When replacement parts are required, ensure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other
- Try to install the product near a wall socket or extension cord and shall be easily accessible.
- The highest environmental temperature suitable for this product is 0°C to 35°C for indoor use

FCC and Canada EMC Compliance linfor

device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful to part to 0 the PCC Nules. These limits are designed to provide reasonable protection against naminal interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- · Regrient or relocate the receiving antenna
- Increase the separation between the equipment and received
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Remove all packaging from the unit. Retain the packaging. If you dispose of it please do so according to local regulations

The following items are included:





D26 Speaker



3 5 mm - 3 5 mm Stereo Audio Cable

USB Cable

Features

Portable speaker, you can stream music wirelessly from your phone or MP3 player, It also supports TF card and charging phones. Bulit-in microphone brings you convenience for phone calls. Rechargeable battery and USB powered for prolong use.

- Portable speaker with simple design, perfect for various business occasions
- Bluetooth® wireless technology for free music entertainment
- · Full alluminum and waterproof desian
- USB charging for audio devices Rechargeable li-ion battery
- Supports TF card
- FM radio tuner

Front View ≽II +_ Ф.

Left Side View Right Side View Left Side Power level Charging for indicator audio devices $\| \circ \|$ TF TF card 3.5 mm - 3.5 mm Stereo Audio Cable Recharging

Gaming Mp3\Mp4 Media CD\VCD\DVD PC or devices Media player player Blu-Ray player Notebook

for speaker

Connections Right Side VOLUME + / NEXT TRACK PLAY / PAUSE/ SPEAKERPHONE ▶II-- () • POWER/ VOLUME-/ INPUT MODE LED PREVIOUS SELECT INDICATOR TRACK . Press "O" for 2-3 seconds to turn the speaker on or off. The speaker emits tone and default to Bluetooth mode. Short press to switch the input mode Bluetooth, TF, FM, and AUX in order. Play or Pause . Answering phone calls in Bluetooth mode. Press twice to call the recent contacts Long press 3 seconds to enter Bluetooth pairing mode in Bluetoo ▶II mode Long press to search stations automatically in FM mode In Bluetooth, TF, FM mode, press once for volume increase and twice for nex track +1In Bluetooth, TF, FM mode, press once for volume decrease and twice for previous track Bluetooth pairing: LED blinks white quickly Paired: blinks white slowly Bluetooth mode: illuminates white when phone calls come in TF mode: blinks white(2 times in a

second) FM mode: illuminates white AUX mode: illuminates white

To pair with a Bluetooth device:

- 1. Long press "o" to turn on the speaker. The MODE LED blinks white quickly
- 1. Long press of to turn on the speaker. The MODE LED blinks white quickly and the speaker emits a tone. It will default to *Bluetooth* pairing mode.

 2. Set your *Bluetooth* device to be discoverable so it can discover (detect) the D28 speaker. Lordet the *Bluetooth*. the D26 speaker. Locate the *Bluetooth* device list in the user interface of your
- device.

 3. From the Bluetooth device list, select the device named "D26"

 4. If your *Bluetooth* device prompts you for a passcode, enter digits 0000 (four zeros) and press OK. Some devices also ask you to accept the connection.

 5. Your *Bluetooth* device indicates when pating it complete.
- Your *Bluetooth* device indicates when pairing is complete.
 The MODE LED blinks white slowly and the speaker emits a tone for *Bluetooth* connection complete.
 To disconnect the *Bluetooth* function, switch to another function on the unit or disable the function from your Bluetooth device.
- OR- Press and hold the " ►II " button -OR- Press and hold the "▶II" button for about 3 seconds to clear previous pairing settings. The unit will search for any available Bluetooth enabled devices. Repeat the steps above for
- 8. When the unit is idle for approximately 10 minutes, it will automatically power

TF Card Mode

Insert TF card and turn on the speaker. It will default to Bluetooth pairing mode

Press the " () " button to enter the TF mode. The speaker will blink white slowly and play music in TF card.

The speaker will automatically turn off in 10mins when it is paused and no any audio input in TF and Bluetooth mode.

FΜ

- 1. Press " $oldsymbol{O}$ " button to select FM mode
- 2. Long press " ►II " to search stations automatically and MODE LED blinks white. Stations will be saved and the the LED stops
- blinking after search is completed.

 3. Press twice "♣" or "━" to select the stations.

AUX IN

- 1. Adjust the volume to minimum first to avoid the voice is over.
- 2 Use a 3 5mm to 3 5mm stereo audio cable to connect your PC or other audio device to AUX IN socket.
- Adjust the volume to your desired level by pressing the volume +/- buttons.
- 4. Check that your PC volume level is

Technical Specifications

9Watt RMS
4.5 Watt x 2 RMS
< 0.5% 1W 1KHz
70 Hz - 20 kHz
> 75 dB
> 50 dB
181.6 x 40.2 x 70.7mm

Questions	Solutions
Speaker will not turn on (battery power)	Battery may be in low level or discharged. please recharge it at least half an hour before using.
No Sound	Check if the media player is correctly connected. Check if the Bluetooth connection is correctly paired and connected.
Pairing Failed	Please remove previously paired devices from your audio devices, and then "search for devices" again. Reconnect and try again.
Sound is distorted	Check if the source file is not corrupted, play a different song and test.
Reset	If the speaker makes a noise or buttons are ineffective, please long press the power button for 8-10 seconds to reset the speaker.



www.microlab-global.com Microlab Electronics Co., Ltd Made in China

Disclaimer: All symbols and logos belong to the respective brand holder or registered holder. All specifications and information are subject to changes without further notice. Slight variations and differences might appear between the printed photos and actual product due to product

marks by Microlab Electronic Co., Ltd is under license. Other trademarks and trade names are those of their respective