



Getting Started with the Verification Monitoring Interface (VMI)

v1.0.2, March 2015

Copyright ©2015
Microscan Systems, Inc.
Tel: +1.425.226.5700 / 800.762.1149
Fax: +1.425.226.8250

All rights reserved. The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and/or service Microscan manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Microscan.

Throughout this manual, trademarked names might be used. We state herein that we are using the names to the benefit of the trademark owner, with no intention of infringement.

Disclaimer

The information and specifications described in this manual are subject to change without notice.

Latest Manual Version

For the latest version of this manual, see the Download Center on our web site at:
www.microscan.com.

Technical Support

For technical support, e-mail: helpdesk@microscan.com.

Warranty

For current warranty information, see: www.microscan.com/warranty.

Microscan Systems, Inc.

United States Corporate Headquarters

+1.425.226.5700 / 800.762.1149

United States Northeast Technology Center

+1.603.598.8400 / 800.468.9503

European Headquarters

+31.172.423360

Asia Pacific Headquarters

+65.6846.1214

Contents

PREFACE	Welcome v Purpose of this Guide v What Is VMI? v How Is VMI Different from Standard AutoVISION? vi
CHAPTER 1	Hardware and Software Installation 1-1 What's in the Box 1-2 Mounting and Installing Hardware 1-3 Application Tips 1-5 PC Requirements and Settings 1-6 Modifications Required when Using VMI with a Panel PC 1-7 VMI Installation 1-8 Launching VMI 1-9
CHAPTER 2	The VMI Interface 2-1 The VMI User Interface 2-2 Similarities between VMI and AutoVISION Setup 2-2 Differences between VMI and AutoVISION Setup 2-6 User Access Levels 2-7
CHAPTER 3	Starting VMI and Creating Your First Job 3-1 Starting VMI for the First Time 3-2 Select a Device 3-2 Create a New Job 3-4 Adjust the Image 3-5 Edit the Job 3-7 Save the Job 3-24 Open a Job 3-25
CHAPTER 4	Runtime and Job Monitoring 4-1 VMI Startup Options 4-2 VMI Runtime 4-3 Example VMI Startup Process 4-14

Welcome

Purpose of this Guide

This guide describes how to use Microscan's Verification Monitoring Interface (VMI) to configure and run symbol quality verification applications.

What Is VMI?

The Microscan Verification Monitoring Interface (VMI) Solution provides inline verification grading of 1D barcodes such as ITF-14 on carton board (corrugated cardboard) in a production environment. VMI processing provides a data set that can be used to evaluate print quality based on an ISO grade, to use statistical trending, and to enable printer condition monitoring. An example use case would be the monitoring of print quality to detect a potential clog in a print head. This leads to cost savings for the user because instead of purging the print heads every several print runs, the print heads can be purged only when needed. When a barcode has a grade below a minimum specified value, VMI also provides an output that can be used as a reject signal.

How Is VMI Different from Standard AutoVISION?

The VMI plug-in will modify the standard look and behavior of AutoVISION in the following ways:

- **Security:** Adds four user access levels with password protection to the interface. A password must be entered to exit the run screen and to enter edit mode, load jobs, modify parameters, etc. The security features in VMI are enabled by default and cannot be disabled, whereas they are optional in AutoVISION. Refer to the Security Settings section for more information.
- **Startup Behavior:** VMI will always automatically connect to the device that you selected the last time you ran the software. It will also automatically load the last job that you were using and download it to the camera, and then put the camera into run mode.
- **Verification-Specific Run View:** Replaces the standard **Run** view with a screen that provides Verification specific feedback and logging capabilities.
- **New Job:** When creating a new job in VMI, you don't start with a blank job as in standard AutoVISION; you start with a fully functioning default verification inspection. This job can be modified from its defaults, but the user does not have to understand how to build a verification inspection – it is created automatically.
- **Load Job Validation:** VMI requires valid verification jobs. When loading a job in VMI, the job will be scanned to ensure that it is based on the VMI job template. A standard AutoVISION job will be rejected, even if it has a verification tool in it.
- **Settings Page:** A special settings page is added to the Edit view to encapsulate all of the major Verification settings in once place. Refer to the Settings Page area for more information.

Hardware and Software Installation

This section describes how to install VMI Software and the hardware required for VMI applications.

What's in the Box

VMI (P/N **SLN-000018**) is intended for use with a modified version of Microscan's **Large Linear Verification Kit** (P/N **SLN-000006**), an example of which is shown below. For detailed mounting instructions, refer to the Large Linear Verification Kit Quick Start Guide, entitled *Using the Large Linear Verification Kit*. The guide is located in the [Download Center](#) at www.microscan.com. Bracket assembly instructions can also be found in the Microscan Download Center.



To achieve the most uniform lighting possible in an image, the light should be as far away from the region of interest as possible while maintaining a 45 degree angle and achieving adequate illumination.

For large 1D symbols this may require the light to be on the shorter extrusion and the camera on the longer extrusion as shown in Configuration 2 of the Large Linear Verification Kit Quick Start Guide, entitled *Using the Large Linear Verification Kit*.

Note: If you already have the necessary hardware and do not need to order the SLN-000018 kit, you will need to purchase an AutoVISION Verification and VMI License Upgrade (P/N 98-000217-05).

Required Hardware


Part Number	Qty.	Description
GMV-6800-1038G	1	Vision HAWK C-Mount Smart Camera, WUXGA Mono, AutoVISION+Visionscape+Verification/OCV+VMI
NER-011660301G	1	NERLITE Smart Series MAX 300, Red, Wide, M12 connector
97-000006-01	1	DSP100-24 Power Supply
61-000163-02	1	Ethernet Cable
61-000167-02	1	Camera Power / Signal Cable
61-000186-01	1	Illuminator Power / Signal Cable
User-Supplied	1	Dedicated PC
User-Supplied	1	Ethernet Switch
User-Supplied	1	USB Keyboard
User-Supplied	1	USB Mouse
User-Supplied	1	Ethernet Cable, PC to Ethernet Switch
User-Supplied	1	Power Cable, PC to DSP100-24 Power Supply
User-Supplied	1	Object Detector / Trigger
98-000259-01	1	Lens
98-000218-01	1	Lens Protection Housing
98-000268-01	1	Bracket
98-000265-01	1	Calibration Card with NIST-Traceable Serial Number and Reflectance Data (not included in SLN-000018 kits but available for purchase; Measurement Certificate included with purchase of NIST-Traceable Calibration Card)
98-000265-02	1	Calibration Card (included in all verification kits)

Mounting and Installing Hardware

Hardware Configuration

Item	Part Number	Description
1	GMV-6800-1038G	Vision HAWK C-Mount Smart Camera, WUXGA Mono, AutoVISION +Visionscape+Verification/OCV+VMI
2	NER-011660301G	NERLITE Smart Series MAX 300, Red, Wide, M12 connector
3	97-000006-01	DSP100-24 Power Supply
4	61-000163-02	Ethernet Cable
5	61-000167-02	Camera Power / Signal Cable
6	61-000186-01	Illuminator Power / Signal Cable
7	User-Supplied	Dedicated PC
8	User-Supplied	Ethernet Switch
9	User-Supplied	USB Keyboard
10	User-Supplied	USB Mouse
11	User-Supplied	Ethernet Cable, PC to Ethernet Switch
12	User-Supplied	Power Cable, PC to DSP100-24 Power Supply
13	User-Supplied	Object Detector / Trigger (required for application but not shown below)
14	98-000259-01	Lens
15	98-000218-01	Lens Protection Housing
16	98-000268-01	Bracket
17	98-000265-01	Calibration Card with NIST-Traceable Serial Number and Reflectance Data (not included in SLN-0000018 kits but available for purchase; Measurement Certificate included with purchase of NIST-Traceable Calibration Card)
18	98-000265-02	Calibration Card (included in all verification kits)

Note: Components shown in red are supplied by Microscan. Components shown in black must be supplied by the integrator or end-user.




Hardware Wiring

The following diagram shows the pin assignments of the camera, illuminator, and power supply, and shows how to wire the devices for VMI operation.

The part sensor is not shown. The wiring will vary depending on whether the sensor is configured NPN or PNP. Please see chapter two of the Vision HAWK User Manual for information on connecting a part sensor.

General Details

Inspection Failed and **Trending Alarm** signals are supplied as 24 volt DIO signals. These signals can be used to activate a diverter mechanism, send a notification, stop the line, or a variety of other functions.



Application Tips

If your application includes low-contrast printed barcodes, the minimum edge contrast parameter may be below the required threshold. This will result in failing grades reported by VMI.

Microscan recommends that you follow GS1's solutions for failed minimum edge contrast:

- Variations in ink weight in different parts of a symbol (non-uniformity of ink spread and ink viscosity): Adjust press settings to ensure even inking.
- Show-through of contents: Use more opaque packaging material or print a white underlay prior to printing the symbol.
- Fluctuations in background reflectance (areas of darker material in recycled corrugated substrates, for example): Use a more consistent substrate or one with higher reflectance.
- Excessive ink spread: Apply correct bar width reduction (BWR) when originating the symbol.

It may also be necessary to mount Microscan's MAX Illuminator (NER-011660301G) closer to the target barcode and to use continuous illumination to optimize lighting uniformity. Continuous illumination requires a special cable: Microscan's QX Cordset, Smart Series Illuminator-to-QX-1, Continuous Power (61-000204-01).

PC Requirements and Settings

Minimum PC Requirements

- CPU: Intel ATOM N2600 1.6GHZ Dual Core or Greater
- Minimum RAM: 2 GB
- Minimum One USB and One 100 BaseT Network Connection
- Display Resolution: 1024 x 768
- Hard Drive: 250 GB or More
- Operating System: Windows 7 Professional 32-bit, SP1
- 3.0 Windows Experience Index

Recommended PC Requirements

- CPU: Intel ATOM N2600 1.6GHZ Dual Core or Greater
- RAM: 4 GB or More
- Wireless Network Adapter
- One USB and Two 100 BaseT Network Connections
- Resolution: 1024 x 768
- Hard Drive: 250 GB or More
- Operating System: Windows 7 Professional 32-bit, SP1
- 4.0 Windows Experience Index

Recommended Windows Settings

- Disable Windows Updates.
- Disable screen savers.
- Disable Sleep/Hibernation (found in Power Settings).
- Set the Network Adapter and camera to the same Subnet.
- Auto-hide the taskbar.

Recommended Accessories

- Uninterruptable Power Supply (UPS)
The UPS provides a safety factor that protects your vision inspection system from power outages and brownouts.

Data Archiving

The VMI system can be configured to store images and data on the hard drive. Microscan suggests that you follow your own configuration management standard operating procedures to maintain hard drive space and to archive VMI results.

For optimum performance, use a PC with a Windows Experience Index of 4.0 or higher. At higher production line rates, i.e. higher parts per minute, data and images may be dropped from the collected results if the PC is too busy processing or displaying graphics.

Modifications Required when Using VMI with a Panel PC

The following items may be required when using VMI with a Panel PC. Please review the list and complete all required modifications before running VMI.


- Go into the **BIOS Setup** by pressing the **DEL** key when powering the unit. In BIOS Setup you should see a blue screen with several tabs at the top. Select **Chipset** and then go to **South Bridge Configuration**. In South Bridge Configuration, 5 lines down, you should see a setting called **Restore on AC Power Loss**. Select **Always On** and save settings.
- Connect the PC to the internet and activate Windows.
- Install the touchscreen driver (supplied on the CD if using a BSI Panel PC).
- Install the graphics driver (supplied on the CD if using a BSI Panel PC).
- Go to **Control Panel > Power Options > High Performance > Change Plan Settings > Change Advanced Power Settings** and set the following:
 - **Turn off Hard Disk after 0 Minutes (Never)**
 - **Sleep > Hibernate after 0 Minutes (Never)**
- Right-click **Computer > Properties > Windows Experience Index > Adjust Visual Effects**.
 - **Custom** – Disable everything except the following:
 - Show Shadows under Mouse Pointer
 - Show Shadows under Windows
 - Slide Open Combo Boxes
 - Smooth Edges of Screen Fonts
 - Smooth-Scroll List Boxes
 - Use Drop Shadows for Icon Labels on the Desktop
 - Use Visual Styles on Windows and Buttons
- Right-click the **taskbar**, select **Properties**, and enable **Auto-hide the taskbar**.
- Install Acrobat.
- Disable Windows Update.
- Install AutoVISION.
- Install VMI.

VMI Installation

Important: VMI is a plug-in module that is based on Microscan's AutoVISION software. AutoVISION must be installed before VMI is installed. Each release of VMI is tied to a particular version of AutoVISION. The VMI installer contains logic to ensure that the correct version of AutoVISION is installed using the following table:

AutoVISION Version	VMI Installer Action
Required Version	Installs VMI
Any Other Version	Notifies the user to install the correct version of AutoVISION

- If the correct version of AutoVISION is not installed on your PC, the following message will appear, prompting you to install the correct version of AutoVISION:



Note that the version of AutoVISION shown here is only an example. Each subsequent version of VMI will be tied to a subsequent version of AutoVISION.

- When you have installed the correct version of AutoVISION and VMI, you will see the VMI launch icon on your desktop.



Launching VMI


When you launch VMI, the software will look for your Vision HAWK on the VMI network.



Once communications are established between the Vision HAWK and the network, the following display will show the camera's identifying information:




If you have previously run VMI and the Visionscape Backplane did not close, the following message will appear:



If you see this message and you need to close the Backplane, right-click the Backplane icon and select **Close and Exit AvpBackplane**.

Note however that closing the Backplane is not required, and that VMI will start even if you leave the Backplane open. This example is for information only.



The VMI Interface

This section describes the features of the VMI user interface.

The VMI User Interface

The Verification Monitoring System's user interface is very similar to that of AutoVISION, especially AutoVISION's Verification functionality. AutoVISION is Microscan's standard machine vision interface for jobs of moderate complexity. To learn more about AutoVISION, refer to the *AutoVISION Software User Manual*, which can be found in the [Download Center](#) on the Microscan website.

Similarities between VMI and AutoVISION Setup

The AutoVISION user interface is very similar to the VMI user interface. The primary difference is that AutoVISION features multiple tools while VMI is designed solely for Verification and print quality trending. The Connect and Image tabs are the same between AutoVISION and VMI. Refer to the *AutoVISION Software User Manual* to learn more about connecting to different devices or adjusting camera settings.

The following AutoVISION installation and configuration processes demonstrate the similarity between VMI and AutoVISION.

Select a Device


AutoVISION's **Connect** view allows you to select your device and configure its settings, and to create a new job.

Camera: Vision HAWK C-Mount.

Emulator: The software emulator allows you to work from saved images without hardware.

The Connect menu provides a list of available devices.


Hover the mouse over a device to see its details.



Once a device is selected, you can **Create a New Job**, **Load a Job** from a saved .avp file on your PC, or **Upload Current Job From Device** (your camera).

- **Job:** A completed program, including image acquisition, tools, and reporting.
- **Tool:** A self-contained set of steps used to perform a specific task.


Note: When selecting the Emulator, there is no option to upload a job.




Adjust Camera Settings

Once you have selected your camera or the Emulator and created a new job, you will move to the **Image** view. This view allows you to **Auto Calibrate** the camera, and to manually adjust the camera's **Exposure**, **Gain**, and **Focus**, and also to set the **Lighting Mode (On, Off, or Strobe)**.

Note: If you load a job from your PC or upload a job from the camera, you will automatically move to the **Edit** view.



You can return to the **Connect** view and click the **Modify** button to adjust additional camera settings, such as **TCP/IP** settings, **RS-232** settings, **Ethernet** settings, **Industrial Protocol**, and **AutoVISION button** settings. You can also rename your camera (alphanumeric characters only - [0-9], [a-z], and [A-Z]). Click the **Apply** button when you have adjusted the camera's settings as needed.



VisionHawk

ⓘ Stopped

🔑 License Options

10.10.5.236

⤴ Details

Model	Vision HAWK CWUXGA
Category	SmartCamera
Version	7.0.0.x
Memory	256 MB
Flash	32 MB

IP Address	10.10.5.236
MAC Address	00:0B:43:12:B5:C6
Subnet Mask	255.255.254.0
DHCP	Disabled
Number of serial TCP ports	4
Starting serial TCP Port	49211

Industrial Protocol PROFINET ▼

Serial Port	RS232-1
Baud Rate	115200
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

Auto Button	True
	Send Trigger

Differences between VMI and AutoVISION Setup

VMI is a plug-in module that replaces the Edit and Run views of AutoVISION with a user interface that has been developed for barcode verification and print quality trending.

Microscan strongly recommends that VMI be used only with the Vision HAWK C-Mount Smart Camera. VMI grades barcodes according to ISO standards that state very specific setup requirements. Internal lighting and autofocus, used in other Vision HAWK models, do not allow the necessary setup control. Microscan cannot guarantee satisfactory results when cameras other than the Vision HAWK C-Mount are used.

User Access Levels

VMI enables a Security service that provides four levels of password-protected access. Password protection is enabled by default and cannot be disabled, whereas AutoVISION makes password protection optional. Password protection ensures that vision jobs and settings cannot be changed by unqualified personnel. The four levels of access are:

Operator:

Can only monitor the **Run** view of VMI. Cannot access other screens or change settings.

Supervisor:

Can switch to **Edit** mode and adjust ROI (region of interest) positions, re-train tools, change the selected device, save the current job, or load a different job. The Supervisor cannot modify the parameters of the current job, or add or remove tools.

Engineer:


An Engineer has full access to all settings. They are only restricted from changing passwords.

Administrator:

The Administrator has full access to all settings, including the ability to change the passwords for the various access levels.

Changing the Access Level


VMI will always start up with the access level set to **Operator**, which means you are locked out of configuration settings in the user interface. You can change your access level by clicking the icon highlighted here:



Note that your current access level is always displayed below the key button. Click this button to display the following dialog:



This simple dialog provides a button for the four access levels. The highlighted button shows the current access level. In the example above, the current access level is **Operator**. If you wish to switch to any of the other 3 modes, click that button and you will be asked for the corresponding password. So if you wanted to switch to Engineer, you would click the **Engineer...** button, and:



Enter the password, click **OK**, and if the password is correct, the access level is changed. If incorrect, an error message is displayed and the access level remains unchanged.

The default passwords for the various access levels are as follows:


Access Level	Default Password
Administrator	administrator
Engineer	engineer
Supervisor	supervisor
Operator	(there is no password required for operator access)

Note that once you have entered the password for a particular level, you don't need to enter a password to reduce your access level. For instance, if you currently have Administrator access, you can simply click on the Engineer or Supervisor buttons, and your access level will be reduced instantly without the need to enter a password. You only enter a password when you are increasing your access level.


Important: If the system is inactive for five minutes, the access level will revert to Operator.

Changing Passwords


In order to change the password for any access level, you must be an administrator. If you change your access level to Administrator, the **Change Password...** button at the bottom of the dialog will become enabled:



Clicking **Change Password...** brings up this dialog:



Click the button that corresponds to the access level whose password you wish to modify, and the standard **change password** dialog will be presented:



Click the **Reset all to Default** button, and all passwords will be reverted to the factory defaults, as documented above.

Minimum Access Levels

The VMI plug-in defines what the minimum access level will be for the various regions and features of the AutoVISION user interface, as well as for several of the VMI-specific features. Following is a list of the securable areas within AutoVISION, and what the minimum access level is for each:

Edit View

UI Region/Feature	Minimum Access Level
Edit View	Supervisor
Parameter Page	Engineer
Delete Tool button	Engineer
Toolbox (ability to Add a Tool)	Engineer

Image View

UI Region/Feature	Minimum Access Level
Image View	Engineer

Connect View (Device Selection View)

UI Region/Feature	Minimum Access Level
Connect View	Supervisor
Change job in Flash	Supervisor
Delete a job in Flash	Administrator
Modify Device Settings	Supervisor

Application-Wide Options

UI Region/Feature	Minimum Access Level
Job Save	Supervisor
Job Load	Supervisor
Options dialog	Engineer
Exit the application	Supervisor
Flash a job on the camera	Engineer
Access the Data Navigator	Engineer

VMI Run View

UI Region/Feature	Minimum Access Level
Run View	Operator
Runtime settings dialog	Engineer
Clear counts and graph button	Supervisor
Change Lot Number	Supervisor
Force Trigger button	Engineer

Starting VMI and Creating Your First Job


This section describes how to start VMI and create your first job.

Starting VMI for the First Time


VMI will always try to automatically connect to the last device that you had selected. When you run VMI for the very first time however, you will need to select a device manually. This is done by going to the **Connect** view (just as in standard AutoVISION). Note however that VMI will always startup with an access level of Operator, which means you are locked out of the Connect view. So change your access level to Engineer first (refer to the previous section on Security Settings for the default Engineer password).

Select a Device

Select a smart camera from the dropdown list in the upper left corner of the UI:



Note that your smart camera must have an AutoVISION VMI license in order for it to be selected in VMI:



Devices that don't have a license for VMI will be displayed with the shield icon:




= Licensed




= Not Licensed

If you select an unlicensed device, you will see this screen:




Note the error message in the message bar. You will be locked into this screen; you cannot create jobs or enter the **Run** view. You are presented with a link that you can click on if you wish to request a license upgrade for your camera. Clicking the link will present you with the following dialog:



This is the standard license upgrade dialog from AutoVISION, but in this case, you can use it to request a license for AutoVISION VMI.

Create a New Job

Once you have selected a licensed device, you are presented with the standard options in the **Connect** view:




Click the **Create a New Job** button and a new Verification inspection will be created for you. This is not a blank job as in standard AutoVISION, but is instead a fully configured Verification job. The new job is configured as follows:

- A Verification Tool is inserted.
 - The Good grade tolerance is set to **1.0**.
 - The Fair grade tolerance is set to **0.5**.
- Logic is added to the Verification Tool so that it may also perform the following checks.
 - A height measurement of the symbol.
 - A match string comparison against the decoded data in the symbol.
 - Separate counts are maintained of how many symbols were graded as good, fair and poor.
 - Trend analysis logic.
- The Digital Outputs are automatically set up as follows:
 - Output 1 is assigned to the inspection failed signal.
 - Output 2 is assigned to the Trend Analysis alarm output.
- All data required at runtime is selected for upload.

Adjust the Image

When the job creation is complete you will be taken to the **Image** view. The VMI Image view is the same as that in AutoVISION. Use this view to adjust your lighting and camera focus, gain and exposure settings.




See the next page for [Image Adjustment Guidelines](#).

Image Adjustment Guidelines

Use the following notes as guidance when focusing the camera lens.


- Position a box with a printed barcode in the trigger position in front of the Vision HAWK.
- Go to VMI's **Image** view and turn on live video mode.
- Adjust the lens focus to provide the sharpest focus.
 - It is suggested that the MAX 300 (light) power be disconnected while you perform the focus adjustment. With the light off, the F-stop will need to be fully opened (**1.4**) and the exposure will need to be set between **8,000** and **50,000**. Set the exposure high enough that you can see the barcode and focus the camera lens.
 - After adjusting focus, lock the focus using the locking screws / thumb screw.
 - Reconnect the power cable to the MAX 300 (light).



- Turn off live video mode.
- Adjust the lens F-stop to the dot between **4** and **8** on the lens and tighten the lock screw.
- Set the gain and exposure so that the image is not blurred when capturing an image of a moving part. The barcode should be easily seen in the image.
- Take a new picture to update the image.

Edit the Job

Move to the **Edit** view, and you will see the following:



Note that the access level is set to **Engineer** at this point, and note the **Settings** and **Tools** tabs at the left of the user interface.

Settings Tab

The **Settings** tab provides a high-level view of the most common parameters that you are likely to adjust in your Verification inspection. It allows you to adjust the inspection tolerances, as well as to setup the trend analysis and optional match string check.

The screenshot shows the 'Settings' tab with two sub-tabs: 'Settings' and 'Tools'. The 'Settings' sub-tab is active. The main content is divided into four sections:


- Tolerances:** Contains a 'Grade Tolerance' section with a horizontal scale from 4 (Good) to 1 (Fair). A green box highlights the value '1.0' at the boundary between 1 and 2. A red box highlights the value '0.5' at the boundary between 1 and 2.
- Height Tolerance:** Includes an unchecked checkbox for 'Enable Height Check', a barcode with numbers 1-9, a vertical double-headed arrow, a text box with '0.500', and a red link icon.
- Trend Analysis:** Features a dropdown menu set to 'Check for X fails in Y cycles'. Below it are two input fields: 'Only allow 20 fails...' and '...in last 100 cycles', each with a red link icon.
- Match String:** A text input field with a red link icon.

Tolerances

The **Tolerances** section is used to control the pass/fail state of your verification inspection. The **Grade Tolerance** control is used to set the limit on what grades will be considered **Good**, what grades will be considered **Fair** and what grades will be considered **Poor**. In the example above, grades of **1.0** and above are good, **0.5 – 1.0** are fair, and grades below **0.5** are poor. The sliders can be grabbed and dragged in **0.1** increments in order to adjust the tolerances.


The **Height Tolerance** area allows you to enable a check on the height of the symbol. This check is turned off by default, so click the **Enable Height Check** button if you wish to enable this functionality. The text box in the lower right corner can then be used to set the measured height of the symbol in inches. Symbols that have a measured height below the user-defined tolerance will be rejected.

Important: You must calibrate the Verification Tool in order for Height Check to work. If the Verification Tool is not calibrated, the height value will be logged as **0**.




Trend Analysis

The **Trend Analysis** section can be used to configure VMI to check for simple trends in Verification grading.



The screenshot shows the 'Trend Analysis' configuration window. It features a dropdown menu labeled 'Option' with the selected value 'Check for X fails in Y cycles'. Below this, there are two input fields: 'Only allow' with the value '20' and a red link icon followed by the text 'fails...', and '...in last' with the value '100' and a red link icon followed by the text 'cycles'.


If the selected trend is detected, the job can be configured so that a digital output on the smart camera will turn **ON**. This can be configured by going to the **Tools** tab, selecting the **Inspection Outputs** tool, and looking at the **Digital Output** selections:



The screenshot shows the 'Digital Outputs' configuration window. It contains three output panels: 'Output 1', 'Output 2', and 'Output 3'. 'Output 1' is configured with 'Inspection Failed', a pulse width of 100 ms, 'Mode' set to 'Pulsed', and 'State' set to 'Active High'. 'Output 2' is highlighted with a red circle and configured with 'Verification TrendStatus', 'Mode' set to 'Latched', and 'State' set to 'Active High'. 'Output 3' is currently set to '<Not Connected>'.

Three **Trend Analysis** options are provided:


1. Check for X Fails in Y Cycles (Default):



The screenshot shows a configuration window for the 'Check for X fails in Y cycles' option. At the top, a dropdown menu is set to 'Check for X fails in Y cycles'. Below this, there are two input fields: 'Only allow' with the value '20' and '...in last' with the value '100'. Each input field has a red link icon to its right, indicating that the values can be edited or linked to other settings.

In the above example, the trend status output will turn on if there are ever 20 failures in the last 100 inspections.


2. Consecutive Failures:



The screenshot shows a configuration window for the 'Consecutive Failures' option. At the top, a dropdown menu is set to 'Consecutive Failures'. Below this, there is one input field: 'Max Consecutive Failures' with the value '20'. A red link icon is positioned to the right of the input field.

In the above example, the trend status output will turn on if you receive 20 consecutive rejects.

3. Average Grade over X Cycles:




The screenshot shows a configuration window for the 'Average grade over X cycles' option. At the top, a dropdown menu is set to 'Average grade over X cycles'. Below this, there are two input fields: 'Average last' with the value '100' and 'Avg Grade must be' with the value '3.000'. Each input field has a red link icon to its right, indicating that the values can be edited or linked to other settings.

In the above example, an average grade will be maintained over the last 100 cycles, and if it should ever fall below 3.0, then the trend status output will turn on. Note that you must perform at least 100 inspections before the average will begin to be checked.


Note: A failed Matchcode attempt will fail the overall inspection but has no effect on the grade of the symbol being inspected.

Tools Tab

Switch to the **Tools** tab to see the list of tools that make up your job. This view gives you more granular control over the tool parameters in your inspection.



Note that if you have Engineer access and you switch to the Tools tab, the parameters will become visible on the right side of the view, and the Toolbox will become visible above the image as well:



You can now insert tools into your job if necessary, and adjust all parameters. When the Tools tab is selected, you have the same capabilities as you do in the Edit view of standard AutoVISION.

Additional details about available tools can be found in the **Edit** chapter of the *AutoVISION Software User Manual* ([autovisionmanual.pdf](#), located in **C:\Microscan\Vscope\Documentation** after AutoVISION installation) and also in AutoVISION Help, which can be accessed from the File menu in AutoVISION.

Camera

Allows you to configure camera parameters relating to image capture including **Exposure**, **Gain**, **Trigger**, and **Lighting Mode**.


Important: Changing camera parameters will override any calibration that may have been performed. Re-calibrate after changing camera parameters if calibration is required for your application.

Acquisition Params
Exposure 1147.000
Gain 0.500

Trigger
Trigger Trigger 1
Trigger Polarity Low->High

Lighting Mode
Off

Verification Tool



Verification Settings

The Verification Tool has settings for **Aperture**, **Wavelength**, and **Angle** that must be defined by the user. The aperture is set to **50%** of the cell size by default.

Aperture, Wavelength, and Angle


You must modify the aperture, wavelength, and angle manually before running a verification job. The wavelength of the illumination provided by the MAX 300 is **625 nm**. This value, along with the lighting angle of **45 degrees**, should be included in any formal grading report and should be entered into the **Symbol Quality Verification Tool** in VMI. After calibration, select the required aperture based on the symbol to be graded.

The table below provides a guideline for correct aperture settings for verification to the ISO 15416 standard.

X Dimension (mil) (Narrow Bar Width)	Aperture Diameter (mil)	Aperture Diameter (mm)
$3.93 \leq X < 7.09$	3	0.075
$7.09 \leq X < 13$	5	0.125
$13 \leq X < 26.18$	10	0.250
$26.18 < X$	20	0.500

Note: The Aperture Diameter (mil) refers to the measuring aperture diameter in thousandths of an inch.

An example of how to configure the verification settings for a **30 mil ITF-14** symbol is shown here.




The Verification Settings dialog box is shown with the following configuration:

- Aperture:** Auto 20 mil
- Signal Compensation:**
- Lighting:** Wave Length: 625 Angle: 45
- Setup Notes:**

Calibration


As part of the calibration process, the **Exposure Time** setting of your camera will be adjusted. Use the **Maximum Exposure** value in the Calibration dialog to set the maximum Exposure Time that can be set.



The Calibration dialog box contains the following instructions and settings:

1. Place Calibration Card in front of the Camera.
2. Roughly center the symbol in the image.
3. Enter data from Calibration Card below.
4. Press the 'Calibrate' button.

Uncalibrated



Rmin: Rmax:

Sym 1 Width: Sym 2 Width:

Maximum Exposure:

Calibration Setup


- Go to VMI's **Edit** view, click the **Tools** tab, and select the **Verification** tool.
- Click on the **Calibration** button in the Verification menu and enter the nominal **Rmin**, **Rmax**, **Symbol 1** width and **Symbol 2** width listed on the card.

MICROSCAN CALIBRATION CARD Dimensions and Reflectance			
MEASUREMENT	NOMINAL	ACTUAL (MEASURED)	
Reflectance (Min.)	4%	_____ %	Dark Cell
Reflectance (Max.)	82%	_____ %	Blank Cell
Symbol 1 Width (X)	0.240 IN.	_____ IN.	
Symbol 2 Width (X)	0.480 IN.	_____ IN.	

Standards: AIM DPM, ISO/IEC 15415, ISO/IEC 15416
Calibration is only traceable to NIST standards when serial number and measured values are included.
 SERIAL NUMBER: _____ MICROSCAN P/N: 10-000522-01


This is the standard Calibration Card that is included with all verification kits. Note that it does not include a serial number or measured reflectance data. A NIST-Traceable version of the Calibration Card, which includes a serial number, measured reflectance data, and a Measurement Certificate, is available for purchase. Contact Microscan to purchase the NIST-Traceable Calibration Card with Measurement Certificate. NIST-Traceable serial numbers and measured values are not required for verification unless your particular industry requires them.

- Position the calibration card symbol in the center of the Verification ROI as shown in the image below. This symbol should be centered as closely as possible to be verified as reliably as possible.
 - If the field of view is greater than **4 inches**, use **Symbol 2**, the larger of the two symbols. If less than 4 inches, use **Symbol 1**.
 - Be sure not to have both symbols in the ROI. If both are within the red ROI box, find a small piece of white paper to cover the unneeded symbol.
- Click the **Calibrate** button.



- Microscan strongly recommends that you develop a mechanical assembly or jig that allows accurate, repeatable calibration. If a mechanical assembly to hold the calibration card is not available, it can be helpful to have two people assist in calibration. One person can position the calibration card accurately, and the second person can execute the calibration process in VMI.

Once the camera is calibrated, the Calibration dialog will show the date and time that the calibration was performed.




If calibration fails, check the following items:

- Check that the camera is in sharp focus.
- Adjust the F-stop on the camera lens to make the white area of the calibration card appear light gray as seen in the Calibration window.
- Ensure that verification symbol is contained within the verification tool's region of interest when calibrating.
- Do not have both calibration symbols in the verification tool's region of interest.
- If the camera field of view is greater than 4 inches use the larger calibration symbol for calibration.

Configuration and use of AutoVISION verification is covered in detail in the **Symbol Quality Verification Tool** chapter of the *AutoVISION Software User Manual* ([autovisionmanual.pdf](#), located in **C:\Microscan\Vscape\Documentation** after AutoVISION installation) and also in AutoVISION Help, which can be accessed from the File menu in AutoVISION.

Inspection Outputs




The **Inspection Outputs** tool is used to communicate the results of your inspection to the outside world. You can output results via **Digital I/O**, or as string data sent via the **serial port** or the **Ethernet port** (via **TCP/IP**).

Digital Outputs are commonly used to:

- Indicate the **Inspection Passed** or **Failed** to be used with the reject station;
- Indicate that a **Trending** condition has occurred to stop the production line or to initiate a print head purge.

Digital Outputs



- **Inspection Done:** Pulses the I/O point at the end of each inspection cycle. The length of the pulse is user-configurable. The default pulse length is 50ms.
- **Inspection Passed:** Activates the output if the inspection passes. The pass state can be connected to any tool in the job for output.
- **Inspection Failed:** Activates the output if the inspection fails. The fail state can be connected to any tool in the job for output.

VMI Inspection Results


VMI has many inspection result outputs that provide verification feedback. These outputs are available through the **Data Navigator**, which can be opened by clicking the Microscan Link icon at the upper right of the VMI interface or by typing **Ctrl + D**.

Some of the result outputs are the verification grade, inspection status, barcode data, counters, trending status, and reject codes that represent the reject cause. Use the **Data Navigator** in **Edit** mode to select the outputs you would like available at runtime and assign them to integers, strings, and booleans. Click the Tools button – the top left button in the Data Navigator – to view the tools used in the current job and to select the outputs in those tools to be linked.




ISO 15416 Outputs

Data Navigator ☒



























ISO15416 Verification1


Grade: 0.6/20/640/45

Outputs

Status boolean System1.Insp1.Snapshot1.15416Tool1.Status	True	
Report Grade string System1.Insp1.Snapshot1.15416Tool1.RepGrade	0.6/20/640/45	
Overall Grade (Average Final Grade) double System1.Insp1.Snapshot1.15416Tool1.OverallGrade	0.600	
-- Overall Grade double System1.Insp1.Snapshot1.15416Tool1.PCOvalGrade	0.000	
Good Status boolean System1.Insp1.Snapshot1.15416Tool1.ProCtlGoodSta	False	
Fair Status boolean System1.Insp1.Snapshot1.15416Tool1.ProCtlFairSta	True	
Poor Status boolean System1.Insp1.Snapshot1.15416Tool1.ProCtlPoorSta	False	
Verification Standard string System1.Insp1.Snapshot1.15416Tool1.StdType	ISO/IEC 15416	
Symbology Type string System1.Insp1.Snapshot1.15416Tool1.SymTypeOut	I2-5	
Decoded Text string System1.Insp1.Snapshot1.15416Tool1.SymData	00123456789050	
Calibration Status string System1.Insp1.Snapshot1.15416Tool1.CalStatus	Calibrated 2014-03-20 17:52:49	
Average Edge Determination Grade double System1.Insp1.Snapshot1.15416Tool1.EDgrade	4.000	
Average Decode Grade double System1.Insp1.Snapshot1.15416Tool1.DECgrade	4.000	
Average Contrast Grade double System1.Insp1.Snapshot1.15416Tool1.SCgrade	1.000	
Average Minimum Reflectance Grade double System1.Insp1.Snapshot1.15416Tool1.MRgrade	4.000	

ISO 15416 Outputs (Continued)

Data Navigator		
 		
ISO15416 Verification1 ✓ Grade: 0.6/20/640/45		
(10)Decodability Value (x100)	84	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.DECBscoreAt10</small>		
(10)Quiet Zone Start Value (X-dim)	10.000	
<small>double System1.Insp1.Snapshot1.15416Tool1.QZscore1At10</small>		
(10)Quiet Zone Stop Value (X-dim)	10.000	
<small>double System1.Insp1.Snapshot1.15416Tool1.QZscore2At10</small>		
Rmin (%)	1.000	
<small>double System1.Insp1.Snapshot1.15416Tool1.RMINvalue</small>		
Rmax (%)	34.000	
<small>double System1.Insp1.Snapshot1.15416Tool1.RMAXvalue</small>		
X dimension (mil)	40	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.XdimMil</small>		
X dimension (mm)	0.000	
<small>double System1.Insp1.Snapshot1.15416Tool1.XdimMM</small>		
X dimension (pixel)	9.900	
<small>double System1.Insp1.Snapshot1.15416Tool1.XdimPxls</small>		
Reject Reason	0	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.Perld2.RejectReason</small>		
Reject Message		
<small>string System1.Insp1.Snapshot1.15416Tool1.Perld2.RejectMsg</small>		
Good Grade Count	0	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.Perld2.GoodCount</small>		
Fair Grade Count	1	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.Perld2.FairCount</small>		
Poor Grade Count	1	
<small>int32 System1.Insp1.Snapshot1.15416Tool1.Perld2.PoorCount</small>		
Trend Status	True	
<small>boolean System1.Insp1.Snapshot1.15416Tool1.Perld1.FailRateStatus</small>		

Reject Codes

Many of the outputs are self-explanatory. For example, the good inspections counters are named “Good Grade Count” and are integers. In the case of rejects, there is a reject code (integer) and a reject message (string). The reject codes are defined as follows:

0 = Pass

1 = Improper Verification Tool setup (all the required inputs are not connected)

2 = Verification Tool did not run

3 = No Read

4 = Bad Grade

5 = Height Fail

6 = Match Fail

Ranked Order of Reject Precedence

1 = Improper Verification Tool setup

2 = Verification Tool did not run

3 = No Read

6 = Match Fail

4 = Bad Grade


5 = Height Fail

Trending Status (Boolean)


The item identified as the **Fail Rate** in VMI indicates the current trending status. When this value is set to **0**, the Alarm message is displayed and then reset to **1** when the alarm is cleared.

VMI Inputs

Using the **Data Navigator**, VMI input parameters can be modified at runtime. Click the **Job** button – the second button at the top of the Data Navigator – to view the VMI input parameters. By default, the input parameters are set to be controllable by the VMI user interface.




If the **Link** icon is clicked, the linked value can be changed to a value that can be addressed by a PLC using EtherNet/IP or PROFINET industrial protocols. Once the links to these items are changed from the defaults, the VMI user interface functionality associated with these items will be effectively disabled due to the Link value superseding the user interaction.




Save the Job

Once you have created and edited a job, select **Save** or **Save As** from the **File** menu to save the job. The default job location is **C:\Microscan\Vscape\Jobs**.




You will also be prompted to save your current job if you attempt to close VMI or open another job without first saving the current job.



Open a Job

To open a job when VMI is already open, navigate to the **File** menu and select **Open**. The job file will be retrieved from the default job location **C:\Microscan\Vscape\Jobs**.




Runtime and Job Monitoring

This section describes the features of the VMI runtime interface.

VMI Startup Options

Each time you start VMI, the device to which you were last connected will be selected by default, and the last job you loaded will be reloaded by default. Assuming that the device is selected and that the job is downloaded successfully, VMI will automatically enter the **Run** view. The security access level will be set to **Operator** by default, and you will be locked into the Run view until you change the access level.


Auto Connect behavior can be disabled from the **Engineer** or **Administrator** access levels by selecting **Options** from the **File** menu and disabling the **Auto Connect to Device** option by unchecking the box indicated below. After Auto Connect to Device has been disabled, a user with an access level of **Supervisor** or higher can select the desired camera.



Important: Be sure that the camera is **not** configured to run in **Continuous Mode**. Successful VMI operation requires the camera to be triggered.

VMI Runtime

The runtime view provided by VMI is completely different than that provided by standard AutoVISION. The VMI Runtime is intended to provide feedback and logging capabilities that are specific to a Verification application.



Data Panel

The **Data Panel** on the left side of the **Run** view provides real-time verification data for each inspected part. The Verification Tool analyzes 10 separate scans to arrive at the final grade. The **Scan Data** section of the Data Panel provides details about which parameter had the lowest grade for each scan. If you hover your mouse pointer over an abbreviation in the scan data rows, a popup will appear with the full name of that parameter.

Refer to the *AutoVISION Software User Manual* for comprehensive information about how Symbol Quality Verification works.

Grade (points to 2.6)

ISO Grade (points to 2.6/3.5 pixels/640/90)

Decoded Text (points to 9780672331015)

Shows Worst Grade from Each of 10 Scans (points to Scan Data table)

Click Here to View Full Verification Report (Refer to the "Symbol Quality Verification Tool" chapter in the *AutoVISION Software User Manual* for comprehensive information about Verification Reports.) (points to Report... button)

Count of the Number of Good, Fair, and Poor Grades (points to Grade Counts table)


Verification Parameter Abbreviations

- ED = Edge Determination
- Dec = Decode
- Con = Symbol Contrast
- Mod = Modulation
- MEC = Minimum Edge Contrast
- MR = Minimum Reflectance
- DEF = Defects
- DAB = Decodability
- QZ = Quiet Zone

Good Grades	78
Fair Grades	2
Poor Grades	0

Image and Information Bar

The image is presented for every inspected part when possible (Note that images may be dropped if the camera is sending images faster than the PC can display them). An information bar is positioned just above the image to provide the overall inspection counts, an image ID, and an optional lot number.



Clear Counts Button: You must have Supervisor access or higher to access this button.

Unique ID: This ID is a time stamp that is taken at the moment the image is received from the camera and it is used when logging data and images. The ID uses the following format:

DDD_HHMMSS_mmm

DDD = Day of the Year (1-365)

HH = Hours

MM = Minutes

SS = Seconds

mmm = Milliseconds

Lot Number: This can be any text that you wish, but you must have Supervisor access or higher in order to modify it. This value will be logged for each cycle whenever data logging is enabled. Click the icon shown below to edit the text, and press the enter key when you are done with your edits.



Options Dialog: You must have Engineer access in order for this button to be enabled. Clicking it will open the Runtime Options dialog. Refer to the Runtime Options section for a description of this dialog.

History Panel

This panel is intended to provide some historical perspective on your inspection performance. Two tabs are provided – **Graph** and **Queue**.

Graph

The graph tab shows you a real-time graph of the last 100 grades. 100 is the default, but this can be increased or decreased by going to the **Runtime Options** dialog and adjusting the **X Scale Max** parameter. The contents of the graph will be cleared whenever you clear the counters. The X and Y graph ranges are:


X Graph Max. = 100 – 2,000

Y Graph Max. = 1.0 – 4.0

Queue


The queue tab allows you to look at a queue of the last 10 images and their grades, as well as the unique ID assigned to each.

Note: If the PC is unable to upload the image due to the trigger rate, the grade and unique ID will be displayed without an image.



Runtime Options

The runtime options are only available if you have Engineer access or higher. Open the dialog by clicking the icon in the upper-right corner of the **Run** view:



Log Settings

The options in this tab control the logging behavior of VMI. Both **Data Logging** and **Image Logging** are disabled by default.

Image Logging Enabled: Check this box if you wish to save images to disk.

Log Poor/Failed Images Only: Check this box if you only want to save images for failed inspections.



Image Log Path: Select the folder where images will be saved.

Data Logging Enabled: Check this box if you want to log data for each inspection cycle to a .csv file.

Data Log Path: Select the folder where your data logs should be saved.

Graph Settings

These options control the display of the graph in the **Run** view.



Data Logging Details

When data logging is enabled, data from each inspection cycle will be saved to a .csv file. This comma-separated values file can be opened directly in Microsoft Excel. The file will be named with a time stamp that is generated when the file is first created. The format of the file name is as follows:

VerificationLog_DDD_HHMMSS.csv

DDD = Day of the Year (1-365)

HH = Hours

MM = Minutes

SS = Seconds


Log files are saved in separate folders for each day of the year. The format of the sub-folders is as follows:

M_DD

M = Month

DD = Day of the Month

For example, if you have chosen to log your data to the folder **C:\Data**, and the date today is **January 29th**, then a subfolder named **1_29** will be created under C:\Data, and the log file will be saved there:




The data saved for each cycle is as follows:

Data	Description
Unique ID	The time stamp ID that identifies this inspection cycle.
Date	The date of the cycle.
Time	The time of the cycle.
Lot	The text you enter in the Lot field of the Run view.
Grade	The numeric grade for the cycle.
Aperture	The aperture contained in the data log is the size of the aperture measured in 1/10th of a pixel. For example, an aperture value of 45 in the data log would equal 4.5 pixels.
Decoded Text	The decoded symbol data.
Scan 1 – Scan 10	The worst grade for each scan, and the verification parameter ID (in parentheses) that produced that grade.
Height	The measured height of the symbol in inches. If the Verification Tool is not calibrated, the height value is 0 .
Bar Width	The Narrow Bar Width value expressed in mils. 1 mil = 0.001 inch.
Reject Message	If the cycle fails, this is the message that identifies the reason for the failure.


A sample data log:

ID	Date	Time	Lot	Grade	Aperture	Decoded	Scan 1	Scan 2	Scan 3	Scan 4	Scan 5	Scan 6	Scan 7	Scan 8	Scan 9	Scan 10	Height	BarWidth	Reject Msg
251_145001_982	9/8/2014	2:50 PM		1	50 95070000	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1.513	28.5	
251_145005_230	9/8/2014	2:50 PM		1	50 95070000	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1.513	28.5	
251_145007_258	9/8/2014	2:50 PM		1	50 95070000	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1.501	28.5	
251_145008_666	9/8/2014	2:50 PM		1	50 95070000	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1.505	28.5	
251_145011_559	9/8/2014	2:50 PM		1	50 95070000	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1.571	29.5	
251_145024_996	9/8/2014	2:50 PM		1	50 00123456	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	0.924	40.5	
251_145026_939	9/8/2014	2:50 PM		1	50 00123456	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	0.916	41.5	
251_145030_419	9/8/2014	2:50 PM		1	50 00123456	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	1 (Con)	0.944	40.5	

The active state of data logging is indicated at the bottom of the **Run** view.



Active




Inactive

Image Logging Details


If image logging is enabled, VMI will attempt to save either all images or just failed images (depending on what you selected in the options dialog). When an image is saved, the file name will be set to the unique ID that is displayed at the top of the **Run** view. If logging data, this ID is also saved to the log file for each cycle. This makes it possible to correlate data in the log file with specific images.

Just as with data logging, the images are saved to a separate folder for each day of the year. Please refer to the previous section on Data Logging for a description of how this works. The current state of image logging is indicated at the bottom of the **Run** view:



Trend Alarms at Runtime

If your selected Trend Analysis condition should occur at runtime, an alarm banner will appear:



Click the **Reset Alarm** button to clear the banner, and to reset the trend counts on the camera. Output 2 will turn on when the alarm is triggered, pressing Reset Alarm will not clear Output 2 immediately, but it will clear on the next inspection cycle. The inspection will continue to run even if the trend alarm has been triggered.

Data Archiving

Before you begin to use VMI on a consistent and frequent basis, you should develop standard operating procedures to maintain adequate hard drive space so you can archive your VMI results.

Runtime Scenarios

Bad Height

In this example, the software determines that the code height is too short.

Microscan VMI AutoVISION™: VisionHawk144416 = C:\Microscan\Vscape\Jobs\test2_heightL.vap

File Help [Icons] Reset Pressed Operator

Connect Image Edit Run

VisionHawk14 Running Connected

4.0
4.0/14/640/90
95070000000292

Bad Height: 0.571

Scan Data:

1	4	ED
2	4	ED
3	4	ED
4	4	ED
5	4	ED
6	4	ED
7	4	ED
8	4	ED
9	4	ED
10	4	ED

Report...

Grade Counts:

Good Grades	0
Fair Grades	0
Poor Grades	1

Total: 1 Passed: 0 Failed: 1 ID = 065_051048_857 Lot =


Graph Queue

Process: 148 Graphics: 3 Idle: 94465 PC: Parse: 59 Data Refresh: 3 Log: 18 GC: 0 : Total = 81

VisionHawk144416 | 192.168.0.10 | Vision HAWK CWUXGA | 184 | 1218,1053

Match Failure

In this example, the symbol's decoded data fails to match the user-defined Match String.



No Read

In this example, the software is unable to produce a decode because the field of view is empty.

Microscan VMI AutoVISION™: VisionHawk144416 = C:\Microscan\Vscape\Jobs\ITF-14.avp

File Help Ready To Run

Connect Image Edit Run

VisionHawk14 Running Connected

Operator

MICROSCAN

Total: 1 Passed: 0 Failed: 1 ID = 086_174241_426 Lot =

0.0
0.0/20/640/90
<no read>

Not Decoded

Scan Data:

1	0	ED
2	0	ED
3	0	ED
4	0	ED
5	0	ED
6	0	ED
7	0	ED
8	0	ED
9	0	ED
10	0	ED

Report...

Grade Counts:

Good Grades	0
Fair Grades	0
Poor Grades	0

Graph Queue

Process: 143 Graphics: 3 Idle: 6074 PC: Parse: 39 Data Refresh: 2 Log: 10 GC: 0 Total = 52

VisionHawk144416 | 192.168.0.10 | Vision HAWK CWUXGA | 185 | 1376,1053

Example VMI Startup Process

VMI Startup

The software user interface is an integral part of the VMI solution. The Vision HAWK Smart Camera will only go online after the PC has booted and the software interface has connected to the camera.

PLC Communications

This example shows the communications logic of a PLC starting up and preparing to communicate with a Vision HAWK Smart Camera.

- PLC to wait for Vision HAWK ONLINE (EIP Input Camera Status: bit 0);
- When ONLINE = True, PLC write match string to string 101;
- Wait for trigger, can monitor INSP BUSY (EIP Input Camera Status: bit 8) if desired;
- PLC monitor DATA VALID received (EIP Input Camera Status: bit 11);
- PLC retrieve results (Verification grade, Inspection Status, Barcode data, etc.);
- PLC turn ON, RESET DATA VALID (EIP Output Camera Status: bit 11) to clear DATA VALID;
- PLC turn OFF, RESET DATA VALID (EIP Output Camera Status: bit 11) to clear DATA VALID;
- Wait for next trigger, etc.