


**Nokia Asha 302 User Guide**



555555  
Issue 1





## 2 Contents

<b>Contents</b>	<b>18</b>
<b>Safety</b>	<b>4</b>
<b>Get started</b>	<b>5</b>
Keys and parts	5
Write with the keyboard	6
Messaging key	7
Insert the SIM card and battery	7
Insert a memory card	8
Charge the battery	9
Switch the phone on or off	10
Antenna locations	10
Attach a strap	11
<b>Basic use</b>	<b>11</b>
Access codes	11
Lock the keys	12
Indicators	12
Copy contacts and other stuff from your old phone	13
Change the volume of a call, song, or video	13
Use your phone without a SIM card	14
<b>Calls</b>	<b>14</b>
Make a call	14
Call the last dialled number	14
View your missed calls	14
<b>Contacts</b>	<b>14</b>
Save a name and phone number	14
Use speed dial	15
<b>Write text</b>	<b>15</b>
Write using the keyboard	15
Predictive text input	16
<b>Messaging</b>	<b>17</b>
Send a message	17
Listen to voice messages	17
<b>Personalise your phone</b>	<b>18</b>
About the home screen	18
Add shortcuts to your home screen	18
Personalise your home screen	18
Personalise your phone tones	19
<b>Time management</b>	<b>19</b>
Change the time and date	19
Alarm clock	19
Add an appointment	20
<b>Connectivity</b>	<b>20</b>
Bluetooth	20
USB data cable	21
Connect to a WLAN	22
<b>Music and audio</b>	<b>23</b>
FM radio	23
Media player	25
<b>Camera</b>	<b>26</b>
Take a picture	26
Record a video	26
Send a picture or video	27
<b>Browse the web</b>	<b>27</b>
About the web browser	27
Browse the web	28
Clear your browsing history	28
<b>Keep in touch with your online friends</b>	<b>28</b>
About Social	28
<b>Mail and chat</b>	<b>29</b>
About Mail	29
Send a mail	29
Read and reply to mail	29
About Chat	29
Chat with your friends	30
<b>Nokia Services</b>	<b>30</b>





Availability and costs of Nokia Services	30
Access Nokia Services	30
<b>Phone management</b>	<b>30</b>
Update phone software using your phone	30
Update phone software using your PC	31
Restore original settings	32
Back up your pictures and other content to a memory card	32
<b>Support</b>	<b>32</b>
<b>Product and safety information</b>	<b>33</b>
<b>Index</b>	<b>40</b>





## 4 Safety

### Safety

We invite you to read the instructions on this guide before using the device.

#### SWITCH OFF IN RESTRICTED AREAS



Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.

#### ROAD SAFETY COMES FIRST



Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

#### INTERFERENCE



All wireless devices may be susceptible to interference, which could affect performance.

#### QUALIFIED SERVICE



Only qualified personnel may install or repair this product.

#### KEEP YOUR DEVICE DRY



Your device is not water-resistant. Keep it dry.

#### PROTECT YOUR HEARING




Listen to a headset at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.



**Get started**


**Keys and parts**



- 1 Charger connector
- 2 Headset connector/Nokia AV connector (3.5 mm)
- 3 Micro-USB connector
- 4 Earpiece
- 5 Screen
- 6 Selection key
- 7 Social key
- 8 Call key
- 9 Bluetooth key. Press and hold to access the Bluetooth settings.
- 10 WLAN key. Press and hold to access the WLAN settings.
- 11 Navi™ key (scroll key)
- 12 Selection key
- 13 Messaging key
- 14 End/Power key
- 15 Keyboard




## 6 Get started



- 1 Camera lens. Before using the camera, remove the protective tape from the lens.
- 2 Wrist strap hole
- 3 Loudspeaker
- 4 Memory card slot
- 5 Back cover release latch

### Write with the keyboard





Your phone has a full keyboard.



- 1 Function key. To insert special characters printed at the top of keys, press the function key, and then press the corresponding key. To enter several special characters in a row, press the function key twice. To return to normal mode, press the function key.
- 2 Shift key. To switch between the upper and lower case modes, press the shift key twice. To enter a single upper case letter in lower case mode, or a single lower




case letter in upper case mode, press the shift key, and then press the desired alphabet key.

- 3  Car key. To insert special characters not shown on the keyboard, press the car key, and select the desired character.
- 4  Backspace key. To delete a character, press the backspace key. To delete several characters, press and hold the backspace key.
- 5  Enter key. To move the cursor to the next row or text input field, press the enter key. Additional functions are based on the current context.
- 6  Ctrl key. To copy, cut, or paste selected text, while pressing and holding the ctrl key, press **C**, **X**, or **V**. To select all the text, while pressing and holding the ctrl key, press **A**.

#### Insert a variation of a letter

You can insert, for example, letters with accents. To insert **á**, press and hold the car key, and then press **A** repeatedly, until the desired letter is displayed. The order and availability of letters depends on the selected writing language.

#### Messaging key

To quickly write a mail or message, view your inbox, or start chatting, on the home screen, press the messaging key .

#### Set what happens when you press the key

Select **Menu > Settings and My shortcuts > Messaging key**, and select an option.

#### Insert the SIM card and battery


**Important:** This device is designed to be used with a standard SIM card (see figure) only. Use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card. Please consult your mobile operator for the use of a SIM card that has a mini-UICC cutout.



This phone is intended for use with a BL-5J battery. Always use original Nokia batteries.

- 1 Pull the back cover release latch toward the bottom of the phone, and remove the cover.

## 8 Get started



- 2 If the battery is inserted, lift it out.
- 3 Slide the SIM card holder to unlock it (1), and use your fingernail to lift it. Make sure the contact area would face down when the SIM card holder is lowered (2), insert the SIM card into the holder, and lower the holder (3). Slide the card holder to lock it (4).




- 4 Line up the contacts of the battery and the battery compartment, and insert the battery. To replace the back cover, direct the top locking catches toward their slots, and press down until the cover locks into place.

### Insert a memory card

Use only compatible memory cards approved by Nokia for use with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

Your phone supports memory cards with a capacity of up to 32 GB.





- 1 Open the cover of the memory card slot (1).
- 2 Make sure the contact area of the memory card is facing down, and insert the card (2). Push the card in, until it locks into place.
- 3 Close the cover of the memory card slot (3).

**Remove the memory card**

Push the card in, until it is released, and pull the card out.

**Charge the battery**

Your battery has been partially charged at the factory, but you may need to recharge it before you can switch on your phone for the first time. If the phone indicates a low charge, do the following:



- 1 Connect the charger to a wall outlet.
- 2 Connect the charger to the phone.
- 3 When the phone indicates a full charge, disconnect the charger from the phone, then from the wall outlet.

You do not need to charge the battery for a specific length of time, and you can use the phone while it is charging.




## 10 Get started

If the battery is completely discharged, it may take several minutes before the charging indicator is displayed or before any calls can be made.

If the battery has not been used for a long time, to begin charging, you may need to connect the charger, then disconnect and reconnect it.

### Switch the phone on or off


Press and hold the power key  until the phone vibrates.




You may be prompted to get the configuration settings from your network service provider. For more information on this network service, contact your network service provider.



### Antenna locations




The antenna area is highlighted.



Avoid touching the antenna area while the antenna is in use. Contact with antennas affects the communication quality and may reduce battery life due to higher power level during operation.

**Attach a strap**

Remove the back cover, thread the strap through the hole, and loop the strap around the wrist strap peg.



The strap may be available separately.

**Basic use**

**Access codes**

<p>PIN or PIN2 code (4-8 digits)</p>	<p>You can set your phone to ask for the PIN code when you switch it on. If not supplied with your card or you forget the codes, contact your service provider. If you type in the code incorrectly three times in a row, you need to unblock the code with the PUK or PUK2 code.</p>
<p>PUK or PUK2 code (8 digits)</p>	<p>These are required to unblock a PIN or PIN2 code.</p>
<p>IMEI number (15 digits)</p>	<p>This is used to identify valid phones in the network. The number can also be used to block, for example, stolen phones. You may also need to give the number to Nokia Care services. To view your IMEI number, dial <b>*#06#</b>.</p>



## 12 Basic use

<p>Lock code (security code) (min. 5 digits)</p>	<p>This helps you protect your phone against unauthorised use.</p> <p>You can set your phone to ask for the lock code that you define. The default lock code is 12345.</p> <p>Keep the code secret and in a safe place, separate from your phone.</p> <p>If you forget the code and your phone is locked, your phone will require service. Additional charges may apply, and all the personal data in your phone may be deleted.</p> <p>For more information, contact Nokia Care or your phone dealer.</p>
--	--

### Lock the keys

To avoid accidentally making a call when your phone is in your pocket or bag, lock the keys.

Select **Menu**, and press the function key.

### Unlock the keys

Select **Unlock**, and press the function key.

### Set the keys to lock automatically

- 1 Select **Menu** > **Settings and Device** > **Automatic keyguard** > **On**.
- 2 Define the length of time after which the keys are locked automatically.

### Indicators

	You have unread messages.
	You have unsent, cancelled, or failed messages.
	The keypad is locked.
	The phone does not ring for incoming calls or text messages.
	An alarm is set.
	The phone is registered to the GPRS or EGPRS network.
	A GPRS or EGPRS connection is open.
	The GPRS or EGPRS connection is suspended (on hold).
	The phone is registered to a 3G (UMTS) network.
	The phone is registered to a 3.5G (HSDPA) network.
	Bluetooth is activated.
	WLAN is activated.






- All incoming calls are diverted to another number.
- The currently active profile is timed.
- A headset is connected to the phone.
- The phone is connected to another device, using a USB data cable.

#### Copy contacts and other stuff from your old phone

Want to copy your contacts, calendar, and other stuff from your old compatible Nokia phone, so you can start using your new phone without missing a beat? You can do that, free of charge.



- 1 Switch Bluetooth on in both phones.  
Select **Menu > Settings > Connectivity > Bluetooth > On**.
- 2 Select **Menu > Settings > Sync and backup**.
- 3 Select **Phone switch > Copy to this**.
- 4 Select what you want to copy, then select **Done**.
- 5 Select your old phone from the list.
- 6 If needed, make up a passcode for this connection, and type it into both phones. In some phones, the code may be fixed. For details, see the user guide of your old phone.
- 7 If asked, allow connection and copying requests.

#### Change the volume of a call, song, or video

Scroll up or down.

The built-in loudspeaker allows you to speak and listen from a short distance without having to hold the phone to your ear.

#### Activate the loudspeaker during a call

Select **Loudspeak..**



## 14 Calls

### Use your phone without a SIM card

Do your children want to play with your phone, but you don't want them to accidentally make a call? Some features of your phone, such as games and the calendar, may be used without inserting a SIM card. Features that are dimmed in the menus cannot be used.

### Calls

#### Make a call

- 1 On the home screen, enter the phone number.  
To delete a number, select **Clear**.  
To enter the + character, used for international calls, press +. The + character may not work in all regions. In this case, enter the international access code directly.
- 2 To make the call, press the call key.
- 3 To end the call, press the end key.

#### Call the last dialled number

Trying to call someone, but they are not answering? It is easy to call them again.

- 1 On the home screen, press the call key.
- 2 Go to the number, and press the call key.

#### View your missed calls

Want to see who made the call you missed?

On the home screen, select **View**. The caller's name is displayed, if stored in the contacts list.

Missed and received calls are logged only if supported by the network, and the phone is switched on and within the network service area.

#### Call back the contact or number

Go to the contact or number, and press the call key.

#### View the missed calls later

Select **Menu > Contacts > Log and Missed calls**.

### Contacts

#### Save a name and phone number

Select **Menu > Contacts**.

Select **Add new**, and enter the number and name.



**Add or edit the details of a contact**

- 1 Select **Names** and a contact.
- 2 Select **Options** > **Add detail**.

**Tip:** To add a ringtone or picture for a contact, select the contact and **Options** > **Add detail** > **Multimedia**.

**Use speed dial**

You can quickly call your friends and family when you assign your most-used phone numbers to the number keys of your phone.

Select Menu > **Contacts** > **More** > **Speed dials**.

**Assign a phone number to a number key**

- 1 Go to a number key, and select **Assign**. 1 is reserved for the voice mailbox.
- 2 Enter a number or search for a contact.

**Remove or change a phone number assigned to a number key**

Go to a number key, and select **Options** > **Delete** or **Change**.

**Make a call**

On the home screen, press and hold a number key.

**Deactivate speed dialling**

Select Menu > **Settings and Call** > **Speed dialling**.

**Write text**

**Write using the keyboard**

Your phone has a full keyboard.

**Set the writing language**

Select **Options** > **Writing language** and the desired language. To change the writing language, you can also press the function key, and then press the ctrl key.

**Switch between number and letter mode**

Press the function key repeatedly, until the symbol for the desired input method is displayed.

**Lock number mode**

Press the function key twice. To return to normal mode, press the function key.



## 16 Write text

### Switch between the character cases

Press the shift key.

### Insert a number or character printed at the top right corner of a key

Press and hold the corresponding key.

### Delete a character

Select **Clear**. You can also press the backspace key .

### Insert a special character or symbol

Press the car key, and select the desired symbol. To view more symbols, press the car key again.

### Insert a new line

Press the enter key.

### Insert a space

Press the space key.

### Copy or cut text

Press and hold the shift key, and scroll to highlight a word, phrase, or section of text. Press and hold the ctrl key, and then press **C** (copy) or **X** (cut).

### Paste text

Go to the desired location, press and hold the ctrl key, and then press **V**.

### Predictive text input

Predictive text input is based on a built-in dictionary. Not all languages are supported.

### Activate or deactivate predictive text input

Select **Options** > **More** > **Prediction settings** > **Prediction** > **On** or **Off**.

### Switch between predictive and traditional text input

Press and hold the ctrl key, and then press the space key.  
You can also select and hold **Options**.

### Write text with predictive text input

- 1 Start writing a word, using the character keys. Your phone suggests possible words.
- 2 To confirm a word, press the space key.  
If the word is not correct, scroll through the list of suggested words, and select the desired word.
- 3 Start writing the next word.





**Messaging**

**Send a message**

Keep in touch with your family and friends with text and multimedia messages. You can attach your pictures, videos, and business cards to your message.

Select **Menu** > **Messaging**.

- 1 Select **Create message**.
- 2 Write your message.
- 3 To add an attachment, select **Options** > **Insert object**.
- 4 Select **Send to**.
- 5 To enter a phone number or mail address manually, select **Number or mail**. Enter a phone number, or select **Mail**, and enter a mail address. To select a recipient or a contact group, select **Contacts** or **Contact groups**.
- 6 Select **Send**.

**Tip:** To insert a special character or smiley, select **Options** > **Insert symbol**.

Sending a message with an attachment may be more expensive than sending a normal text message. For more information, contact your service provider.

You can send text messages that are longer than the character limit for a single message. Longer messages are sent as two or more messages. Your service provider may charge accordingly.

Characters with accents, other marks, or some language options, take more space, limiting the number of characters that can be sent in a single message.

If the item you insert in a multimedia message is too large for the network, the device may automatically reduce the size.

Only compatible devices can receive and display multimedia messages. Messages may look different in different devices.

**Listen to voice messages**

When you can't answer, you can divert calls to your voice mailbox and listen to your messages later.

You may need a voice mailbox subscription. For more information on this network service, contact your service provider.

- 1 Select **Menu** > **Messaging** > **More** > **Voice messages and Voice mailbox number**.
- 2 Enter your voice mailbox number, and select **OK**.





## 18 Personalise your phone

- To call your voice mailbox, on the home screen, press and hold **1**.

### Personalise your phone

#### About the home screen

On the home screen, you can:

- See notifications of missed calls and received messages
- Open your favourite applications
- Add shortcuts for different features, such as taking a picture or browsing the web
- View your favourite contacts, and quickly call, text, or send mail to them

#### Add shortcuts to your home screen

Want to open your favourite apps directly from your home screen? You can add shortcuts to your most used features.

- On the home screen, select **Options** > **Personalise view**.
- Select a bar, then select an item, such as a widget, and **Done**.

**Tip:** To remove an app or shortcut from the home screen, select **Options** > **Set as empty**.

#### Change a shortcut on the shortcut widget

- On the home screen, scroll to the shortcut you want to change, then select **Options** > **Change shortcut**.
- Select the desired item from the list.

**Tip:** To change all shortcuts at the same time, select **Select shortcuts**.

#### Personalise your home screen


Want to see your favourite landscape or pictures of your family in the background of your home screen? You can change this wallpaper, and rearrange items on your home screen, to personalise it to your liking.

#### Change the wallpaper

- Select **Menu** > **Settings** and **Display** > **Wallpaper**.
- Select a folder and a picture.  
You can also take a picture with your phone camera, and use that picture.

**Tip:** Download more wallpapers from Nokia Store. For more information, go to [www.nokia.com/support](http://www.nokia.com/support).

To rearrange items on your home screen, replace the shortcuts with new ones.



**Personalise your phone tones**

You can personalise the ringtones and key and warning tones for each profile.

Select **Menu** > **Settings and Tones**.

**Change the ringtone**

Select **Ringtone:** > **Options** > **Change**, and select the ringtone.

**Tip:** Download more ringtones from Nokia Store. To learn more about Nokia Store, go to [www.nokia.com/support](http://www.nokia.com/support).

**Change the volume of the keypad tones**

Select **Keypad tones:**, and scroll left or right.

**Time management****Change the time and date**

Select **Menu** > **Settings and Date and time**.

**Change the time zone when travelling**

- 1 Select **Date & time settings** > **Time zone:**.
- 2 To select the time zone of your location, scroll left or right.
- 3 Select **Save**.

The time and date are set according to the time zone. This makes sure that your phone displays the correct sending time of received text or multimedia messages.

For example, GMT -3 denotes the time zone for Buenos Aires (Argentina), 3 hours west of Greenwich, London (UK).

**Alarm clock**

You can set an alarm to sound at a desired time.

**Set the alarm**

- 1 Select **Menu** > **Apps** > **Alarm clock**.
- 2 Enter the alarm time.
- 3 To repeat the alarm on selected days of the week, first go to **Repeat:**, and scroll left or right to select **On**. Then go to **Repeat days**, scroll right, mark the desired days of the week, and select **Done**.
- 4 To select the alarm tone, go to **Alarm tone**, and scroll left or right.
- 5 To set the length of the snooze time-out period, go to **Snooze time-out:**, and enter the desired time.



## 20 Connectivity

6 Select **Save**.

### Stop the alarm

Select **Stop**. If you let the alarm sound for a minute or select **Snooze**, the alarm stops for the length of the snooze time-out period, then resumes.

### Add an appointment

Save your important appointments to your calendar as meeting entries.

Select **Menu** > **Calendar**.

- 1 Go to the desired date, and select **Options** > **Add new entry**.
- 2 Select **Meeting**, and fill in the fields.

## Connectivity

### Bluetooth


#### About Bluetooth connectivity

Select **Menu** > **Settings** > **Connectivity** > **Bluetooth** > **On**.

You can connect wirelessly to other compatible devices, such as phones, computers, headsets, and car kits.


You can use the connection to send items from your phone, copy files from your compatible PC, and print files with a compatible printer.

Since devices with Bluetooth wireless technology communicate using radio waves, they do not need to be in direct line-of-sight. However, they must be within 10 metres (33 feet) of each other, although the connection may be subject to interference from obstructions such as walls or from other electronic devices.





When your phone is locked, it is only possible to connect to a paired device that has been set to **Auto-connect**.

**Tip:** To quickly access the Bluetooth settings, on the home screen, press and hold the Bluetooth key .

**Note:** There may be restrictions on the use of Bluetooth technology in some countries. For example, in France, you are only allowed to use Bluetooth technology indoors. After 1 July 2012, the restriction on outdoor usage of Bluetooth technology of this product in France is withdrawn by the EU. For more information, contact your local authorities.

#### Send a picture or other content to another device using Bluetooth

Use Bluetooth to send pictures, videos, business cards, and other content created by you to your computer or a friend's compatible phone or device.

- 1 Select the item to send.
- 2 Select **Options** > **Send** > **Via Bluetooth**.
- 3 Select the device to connect to. If the desired device is not displayed, to search for it, select **New search**. Bluetooth devices within range are displayed.
- 4 If the other device requires a passcode, enter the passcode. The passcode, which you can define yourself, must be entered in both devices. The passcode in some devices is fixed. For details, see the user guide of the device.  
The passcode is valid only for the current connection.

The available options may vary.

#### USB data cable

##### Copy content between your phone and a computer

You can use a USB data cable to copy your pictures and other content between your phone and a compatible computer.

- 1 Use a USB data cable to connect your phone to a computer.
- 2 Select from the following modes:
  - Nokia Suite** — Nokia Suite is installed on your computer.
  - Media transfer** — Nokia Suite is not installed on your computer. If you want to connect your phone to a home entertainment system or printer, use this mode.
  - Mass storage** — Nokia Suite is not installed on your computer. The phone is displayed as a portable device on your computer. Make sure a memory card is inserted. If you want to connect your phone to other devices, such as a home or car stereo, use this mode.
- 3 To copy the content, use the file manager of the computer.





## 22 Connectivity


To copy your contacts, music files, videos, or pictures, use Nokia Suite.

### Connect to a WLAN

#### About WLAN connections

Select **Menu** > **Settings** > **Connectivity** > **WLAN**.

Connect to a wireless local area network (WLAN) and manage your WLAN connections.

**Tip:** To quickly access the WLAN settings, on the home screen, press and hold the WLAN key .


**Important:** Use encryption to increase the security of your WLAN connection. Using encryption reduces the risk of others accessing your data.


#### Connect to a WLAN at home

To help save data costs, connect to your home WLAN when you are at home and want to browse the web on your phone.

Select **Menu** > **Settings** > **Connectivity** > **WLAN**.

#### Connect for the first time


- 1 To search for your home WLAN, select **Available WLANs**.
- 2 To connect, select your home WLAN and **Connect**.
- 3 If the WLAN is secured , enter the password.
- 4 If you save your home WLAN, you do not always have to search for it in future. Select **Options** > **Save**.

 indicates a saved WLAN.

#### Connect to your saved home WLAN

- 1 Select **Saved WLANs**.
- 2 Select your home WLAN and **Options** > **Connect**.

#### Disconnect from a WLAN


Select the connected WLAN  and **Disconn..**

#### Connect to a WLAN on the move

Connecting to a WLAN is a handy way of accessing the internet when not at home. Connect to public WLANs in public places, such as a library or internet café.


Select **Menu** > **Settings** > **Connectivity** > **WLAN**.



You need a password to connect to secured WLANs .

- 1 To search for available WLANs, select **Available WLANs**.
- 2 Select a WLAN and **Connect**.
- 3 If the WLAN is secured, enter the password.

**Disconnect from a WLAN**

Select the connected WLAN  and **Disconn..**


**Connect to a hidden WLAN**

Select **Menu > Settings > Connectivity > WLAN**.

You can connect to a hidden WLAN, if you know the name (SSID) and password.

- 1 To search for available WLANs, select **Available WLANs**.
- 2 Select **(Hidden network) > Connect**.
- 3 Enter the name (SSID) and the password.

**Disconnect from a WLAN**

Select the connected WLAN  and **Disconn..**

**Music and audio**

**FM radio**

**About the FM radio**

Select **Menu > Music > Radio**.

You can listen to FM radio stations using your phone - just connect a headset, and select a station.

To listen to the radio, you need to connect a compatible headset to the device. The headset acts as an antenna.



## 24 Music and audio



### **Listen to the radio**

Connect a compatible headset to your phone. The headset acts as an antenna.

Select **Menu > Music > Radio**.

### **Change the volume**

Scroll up or down.

### **Close the radio**

Press the end key.

### **Set the radio to play in the background**

Select **Options > Play in background**.

### **Close the radio when it is playing in the background**

Press and hold the end key.

### **Find and save radio stations**

Search for your favourite radio stations, and save them, so you can easily listen to them later.

Select **Menu > Music > Radio**.

### **Search for the next available station**

Press and hold the scroll key left or right.

### **Save a station**

Select **Options > Save station**.





**Automatically search for radio stations**

Select **Options** > **Search all stations**. For best results, search when outdoors or near a window.

**Switch to a saved station**

Scroll left or right.

**Rename a station**

- 1 Select **Options** > **Stations**.
- 2 Select the station and **Options** > **Rename**.

**Tip:** To access a station directly from the saved station list, press the number key that corresponds to the number of the station.

**Media player**

**Play a song**

Play music stored in the phone memory or on the memory card.

Select **Menu** > **Music** > **My music** and **All songs**.

- 1 Select a song.
- 2 Select **Play**.
- 3 To pause or resume playing, press the scroll key.

**Skip to the beginning of the current song**

Scroll left.

**Skip to the previous song**

Scroll left twice.

**Skip to the next song**

Scroll right.

**Fast-forward or rewind**

Press and hold the scroll key to the right or left.

**Mute or unmute the music player**

Press the ctrl key.

**Close the music player**

Press the end key.



## 26 Camera

### Set the music player to play in the background

Select **Options** > **Play in background**.

### Close the music player when it is playing in the background

Press and hold the end key.

### Play a video

Play videos stored in the phone memory or on the memory card.

Select **Menu** > **Music** > **My music and Videos**.

- 1 Select a video.
- 2 Select **Play**.
- 3 To pause or resume playing, press the scroll key.

### Fast-forward or rewind


Press and hold the scroll key to the right or left.

### Close the media player

Press the end key.

## Camera

### Take a picture

- 1 Select **Menu** > **Photos** > **Camera**.
  - 2 To zoom in or out, scroll up or down.
  - 3 Select .
- The pictures are saved in **Menu** > **Photos** > **My photos**.



### Close the camera

Select **Back**.

### Record a video

Besides taking pictures with your phone, you can also capture your special moments as videos.

Select **Menu** > **Photos** > **Video camera**.

- 1 To switch from image mode to video mode, if necessary, select  > **Video c..**
- 2 To start recording, select .





To zoom in or out, scroll up or down.

- 3 To stop the recording, select .

Videos are saved in **Menu > Photos > My videos**.

#### Close the camera

Press the end key.

#### Send a picture or video

Want to share your pictures and videos with friends and family? Send a multimedia message or send a picture using Bluetooth.

Select **Menu > Apps > Gallery**.

#### Send a picture

- 1 Select the folder containing the picture.
- 2 Select the picture to send.  
To send more than one picture, select **Options > Mark**, and mark the desired pictures.
- 3 Select **Options > Send** or **Send marked** and the desired sending method.

#### Send a video

- 1 Select the folder containing the video.
- 2 Select **Options > Mark**, and mark the video. You can mark several videos to send.
- 3 Select **Options > Send marked** and the desired sending method.

### Browse the web

#### About the web browser

Select **Menu > Internet**.

Catch up on the news, and visit your favourite websites. You can use the web browser to view web pages on the internet.

The web browser compresses and optimises web content for your phone, so you can browse the web more quickly and save on data costs.

To browse the web, you must be connected to the internet.

For availability, pricing, and instructions, contact your service provider.

You may receive the configuration settings required for browsing as a configuration message from your service provider.





## 28 Keep in touch with your online friends

### Browse the web

Select **Menu** > **Internet**.

**Tip:** If you do not have a flat-rate data plan from your network service provider, to save data costs in your phone bill, you can use a WLAN to connect to the internet.

### View your browsing history, featured sites, or your bookmarks

To switch between the History, Featured, and Favourites tabs, scroll left or right.

### Go to a website

Write the address in the address bar.

### Search the internet

Write your search word in the search field. If asked, select your default search engine.

### Go back to a previously visited web page

Open the History tab, then select the web page.

**Tip:** You can download web apps from Nokia Store. When you first open a web app, it is added as a bookmark. For more info, go to [www.nokia.com/support](http://www.nokia.com/support).

### Clear your browsing history

Select **Menu** > **Internet**.

Open the History tab, and select **Options** > **Clear history**.

### Clear stored cookies or text saved in web forms

Select **Options** > **Tools** > **Settings** > **Clear cookies** or **Clear auto-fill**.

## Keep in touch with your online friends

### About Social

Select **Menu** > **Social**, and sign in to your relevant social networking services.

With the Social application, you can enhance your social networking experience. The application may not be available in all regions. When signed in to social networking services, such as Facebook or Twitter, you can do the following: When signed in to social networking services, you can do the following:

- See your friends' status updates
- Post your own status update
- Instantly share pictures you take with the camera





Only those features that are supported by the social networking service are available.

Using social networking services requires network support. This may involve the transmission of large amounts of data and related data traffic costs. For information about data transmission charges, contact your service provider.

The social networking services are third party services and not provided by Nokia. Check the privacy settings of the social networking service you are using as you may share information with a large group of people. The terms of use of the social networking service apply to sharing information on that service. Familiarise yourself with the terms of use and the privacy practices of that service.

## Mail and chat

### About Mail

Select **Menu** > **Mail**.

You can use your phone to read and send mail from your mail accounts from different mail service providers.

If you do not already have a mail account, you can create a Nokia Mail account. For more information, go to [www.nokia.com/support](http://www.nokia.com/support).

### Send a mail

Select **Menu** > **Mail** and a mail account.

- 1 Select **Options** > **Compose new**.
- 2 Enter the recipient's mail address and the subject, and write your message.
- 3 To attach a file, for example, a picture, select **Options** > **Attach** > **Attach file**.
- 4 To take a picture to attach to the mail, select **Options** > **Attach** > **Attach new picture**.
- 5 Select **Send**.

### Read and reply to mail


Select **Menu** > **Mail** and a mail account.

- 1 Select a mail.
- 2 To reply to or forward a mail, select **Options**.

### About Chat

Select **Menu** > **Messaging** > **More** > **Chat**.

You can exchange instant messages with your friends. Chat is a network service. If you do not have a chat account, you can create a Nokia account, and use Nokia Chat.





## 30 Nokia Services

You can leave the Chat application running in the background while you use other features of your phone, and still be notified of new instant messages.

Using services or downloading content may cause transfer of large amounts of data, which may result in data traffic costs.

### Chat with your friends

Select **Menu** > **Messaging** > **More** > **Chat**.

You can sign in to and chat in several services at the same time. You must separately sign in to each service.

You can have ongoing conversations with several contacts at the same time.

- 1 If several chat services are available, select the desired service.
- 2 Sign in to the service.
- 3 In your contacts list, select the contact you want to chat with.
- 4 Write your message in the text box at the bottom of the display.
- 5 Select **Send**.

### Nokia Services

#### Availability and costs of Nokia Services

The availability of Nokia Services may vary by region.

Using services or downloading content may cause transfer of large amounts of data, which may result in data traffic costs.

To learn more, go to [www.nokia.com/support](http://www.nokia.com/support).

#### Access Nokia Services

Select **Menu** > **Apps** > **My apps** and the desired service.

### Phone management

#### Update phone software using your phone

Want to improve the performance of your phone and get application updates and great new features? Update the software regularly to get the most out of your phone. You can also set your phone to automatically check for updates.

#### **Warning:**

If you install a software update, you cannot use the device, even to make emergency calls, until the installation is completed and the device is restarted.



Using services or downloading content may cause transfer of large amounts of data, which may result in data traffic costs.

Before starting the update, connect a charger or make sure the device battery has enough power.

Select **Menu > Settings**.



- 1 Select **Device > Device updates**.
- 2 To display the current software version and check whether an update is available, select **Current sw details**.
- 3 To download and install a software update, select **Downl. device software**. Follow the displayed instructions.
- 4 If the installation was cancelled after the download, select **Install software update**.

The software update may take several minutes. If there are problems with the installation, contact your network service provider.

**Check for software updates automatically**

Select **Automatic SW update**, and define how often to check for new software updates.

Your network service provider may send phone software updates over the air directly to your phone. For more information on this network service, contact your network service provider.

**Update phone software using your PC**

You can use the Nokia Suite PC app to update your phone software. You need a compatible PC, a high-speed internet connection, and a compatible USB cable to connect your phone to the PC.



## 32 Support

To get more info and to download the Nokia Suite app, go to [www.nokia.com/support](http://www.nokia.com/support).

### Restore original settings

If your phone is not working properly, you can reset some settings to their original values.

- 1 End all calls and connections.
- 2 Select **Menu > Settings and Restore factory sett. > Settings only**.
- 3 Enter the security code.

This does not affect documents or files stored on your phone.

After restoring the original settings, your phone switches off and then on again. This may take longer than usual.

### Back up your pictures and other content to a memory card

Want to make sure you will not lose any important files? You can back up your phone memory to a compatible memory card.

Select **Menu > Settings > Sync and backup**.

Select **Create backup**.

### Restore a backup

Select **Restore backup**.

## Support

When you want to learn more about how to use your phone, or if you're unsure how your phone should work, go to [www.nokia.com/support](http://www.nokia.com/support).

Your questions may have been asked before. On the support web pages, select **Frequently asked questions**.

You can also find news on apps, downloads, and other useful info, such as:

- User guides
- Software update info
- Further details about features and technologies, and the compatibility of devices and accessories

If you have an issue, do the following:







- Reboot your phone. Switch off the phone, and remove the battery. After about a minute, replace the battery, and switch on the phone.
- Update your phone software
- Restore the original factory settings

If your issue remains unsolved, contact Nokia for repair options. Before sending your phone for repair, always back up your data, as all personal data in your phone may be deleted.

For additional product support information, see the warranty and reference leaflet included with your Nokia device.

### Product and safety information

#### Network services and costs

Your device is approved for use on the WCDMA/HSPA 850 /900 / 1900 / 2100 and GSM 850 / 900 / 1800 / 1900 MHz networks (RM-813); or WCDMA/HSPA 850 /900 / 1700 / 1900 / 2100 and GSM 850 / 900 / 1800 / 1900 MHz networks (RM-884);. To use the device, you need a subscription with a service provider.

Using network services and downloading content to your device requires a network connection and may result in data traffic costs. Some product features require support from the network, and you may need to subscribe to them.

#### Take care of your device

Handle your device, battery, charger and accessories with care. The following suggestions help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits. If your device gets wet, remove the battery, and allow the device to dry.
- Do not use or store the device in dusty or dirty areas. Moving parts and electronic components can be damaged.
- Do not store the device in high temperatures. High temperatures can shorten the life of the device, damage the battery, and warp or melt plastics.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage electronic circuits.
- Do not attempt to open the device other than as instructed in the user guide.
- Unauthorised modifications may damage the device and violate regulations governing radio devices.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and mechanics.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog moving parts and prevent proper operation.
- Switch off the device and remove the battery from time to time for optimum performance.
- Keep your device away from magnets or magnetic fields.
- To keep your important data safe, store it in at least two separate places, such as your device, memory card, or computer, or write down important information.

During extended operation, the device may feel warm. In most cases, this is normal. If you suspect the device is not working properly, take it to the nearest authorised service facility.





## 34 Product and safety information

### Recycle



When this device has reached the end of its working life, all of its materials can be recovered as materials and energy. To guarantee the correct disposal and reuse, Nokia co-operates with its partners through a program called We:recycle. For information on how to recycle your old Nokia products and where to find collection sites, go to [www.nokia-latinoamerica.com/reciclaje](http://www.nokia-latinoamerica.com/reciclaje), or call the Nokia Contact Center.

Recycle packaging and user guides at your local recycling scheme.

When you cooperate and deliver all these materials to one of the available collection sites, you contribute in helping the environment and help to ensure the health of future generations.

All electrical and electronic products, batteries, and accumulators may contain heavy metals and other toxic substances and must be taken to their respective collection sites at the end of their working life. Under no circumstances should you break open a battery or other related materials. Do not dispose of these products as unsorted municipal waste, as this may cause severe impacts for the environment or human health. All Nokia products are in compliance to the applicable industry international production standards and to all requirements defined by the competent government agencies. For more information on the environmental attributes of your device, see [www.nokia.com/ecoprofile](http://www.nokia.com/ecoprofile).

### About Digital Rights Management

When using this device, obey all laws and respect local customs, privacy and legitimate rights of others, including copyrights. Copyright protection may prevent you from copying, modifying, or transferring pictures, music, and other content.

Content owners may use different types of digital rights management (DRM) technologies to protect their intellectual property, including copyrights. This device uses various types of DRM software to access DRM-protected content. With this device you can access content protected with WMDRM 1.0 and OMA DRM 2.0. If certain DRM software fails to protect the content, content owners may ask that such DRM software's ability to access new DRM-protected content be revoked. Revocation may also prevent renewal of such DRM-protected content already in your device. Revocation of such DRM software does not affect the use of content protected with other types of DRM or the use of non-DRM-protected content.

Digital rights management (DRM) protected content comes with an associated licence that defines your rights to use the content.

If your device has WMDRM-protected content, both the licences and the content are lost if the device memory is formatted. You may also lose the licences and the content if the files on your device become corrupted. Losing the licences or the content may limit your ability to use the same content on your device again. For more information, contact your service provider.

### Batteries and chargers

#### Battery and charger information


Your device is intended for use with a BL-5J rechargeable battery. Nokia may make additional battery models available for this device. Always use original Nokia batteries.

This device is intended for use when supplied with power from the following chargers: AC-11. The exact Nokia charger model number may vary depending on the plug type, identified by E, X, AR, U, A, C, K, B, or N.

The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery.

#### Battery safety

Always switch the device off and disconnect the charger before removing the battery. When you unplug a charger or an accessory, hold and pull the plug, not the cord.





## Product and safety information 35

When your charger is not in use, unplug it from the electrical plug and the device. Do not leave a fully charged battery connected to a charger, as overcharging may shorten the battery's lifetime. If left unused, a fully charged battery will lose its charge over time.

Always keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily.

Accidental short-circuiting can happen when a metallic object touches the metal strips on the battery, for example, if you carry a spare battery in your pocket. Short-circuiting may damage the battery or the connecting object.

Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations. Recycle when possible. Do not dispose as household waste.

Do not dismantle, cut, open, crush, bend, puncture, or shred cells or batteries. If a battery leaks, do not let battery liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help.

Do not modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged.

Use the battery and charger for their intended purposes only. Improper use, or use of unapproved batteries or incompatible chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery or charger is damaged, take it to a service centre for inspection before continuing to use it. Never use a damaged battery or charger. Only use the charger indoors.

### Electrical information of the device

This information applies only in Mexico.

Product	Mobile phone
Supplier	Nokia
Model	302/302.2
Charger	AC-11 The following electrical characteristics apply for NOKIA U chargers only.
Input	100-240 VAC 50-60 Hz 100 mA
Output	5.0 V 450 mA
Rechargeable battery supplier	Nokia
SIM card model	3,7 Vcc

### Additional safety information

#### Make an emergency call

- 1 Make sure the device is switched on.
- 2 Check for adequate signal strength. You may also need to do the following:
  - Insert a SIM card.
  - Deactivate call restrictions you have activated for your device, such as call barring, fixed dialling, or closed user group.
  - Make sure the flight profile is not activated.
- 3 Press the end key repeatedly, until the home screen is displayed.

[www.nokia.com/support](http://www.nokia.com/support)

35





## 36 Product and safety information

- 4 Enter the official emergency number for your present location. Emergency call numbers vary by location.
- 5 Press the call key.
- 6 Give the necessary information as accurately as possible. Do not end the call until given permission to do so.

**! Important:** Activate both cellular and internet calls, if your device supports internet calls. The device may attempt to make emergency calls both through cellular networks and through your internet call service provider. Connections in all conditions cannot be guaranteed. Never rely solely on any wireless device for essential communications like medical emergencies.

### Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

### Medical devices

Operation of radio transmitting equipment, including wireless phones, may interfere with the function of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external radio frequency energy.

### Implanted medical devices

Manufacturers of medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and an implanted medical device, such as a pacemaker or implanted cardioverter defibrillator, to avoid potential interference with the medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device.
- Not carry the wireless device in a breast pocket.
- Hold the wireless device to the ear opposite the medical device.
- Turn the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

### Accessibility solutions

Nokia is committed to making mobile phones easy to use for all individuals, including those with disabilities. For more information, visit the Nokia website at [www.nokiaaccessibility.com](http://www.nokiaaccessibility.com) (in English).

### Hearing

**! Warning:**  
When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.

Some wireless devices may interfere with some hearing aids.

### Nickel

The surface of this device is nickel-free.

### Protect your device from harmful content

Your device may be exposed to viruses and other harmful content. Take the following precautions:

- Be cautious when opening messages. They may contain malicious software or otherwise be harmful to your device or computer.
- Be cautious when accepting connectivity requests, browsing the internet, or downloading content. Do not accept Bluetooth connections from sources you do not trust.





## Product and safety information 37

- Only install and use services and software from sources that you trust and that offer adequate security and protection.
- Install antivirus and other security software on your device and any connected computer. Only use one antivirus application at a time. Using more may affect performance and operation of the device and/or computer.
- If you access preinstalled bookmarks and links to third party internet sites, take the appropriate precautions. Nokia does not endorse or assume liability for such sites.

### Operating environment

This device meets radio frequency exposure guidelines in the normal use position at the ear or at least 1.5 centimetres (5/8 inch) away from the body. Any carry case, belt clip, or holder for body-worn operation should not contain metal and should position the device the above-stated distance from your body.

To send data files or messages requires a quality connection to the network. Data files or messages may be delayed until such a connection is available. Follow the separation distance instructions until the transmission is completed.

### Vehicles

Radio signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection, electronic antilock braking, electronic speed control, and air bag systems. For more info, check with the manufacturer of your vehicle or its equipment.

Only qualified personnel should install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories. Remember that air bags inflate with great force. Do not place your device or accessories in the air bag deployment area.

### Potentially explosive environments

Switch off your device in any area with a potentially explosive atmosphere, for example near gas pumps at service stations. Sparks in such areas could cause an explosion or fire resulting in bodily injury or death. Observe restrictions in fuel service stations, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include areas where you would be advised to turn off your vehicle engine, below deck on boats, chemical transfer or storage facilities and where the air contains chemicals or particles such as grain, dust, or metal powders. You should check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) to determine if this device can be safely used in their vicinity.

### Certification information (SAR)

**This mobile device meets guidelines for exposure to radio waves.**

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network. That amount changes depending on a number of factors such as how close you are to a network base station.

The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 1.11 W/kg.

Use of device accessories may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band. Additional SAR information may be provided under product information at [www.nokia.com](http://www.nokia.com).

Your mobile device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA) and Industry Canada. These requirements set a SAR limit of 1.6 W/kg averaged over one





### 38 Product and safety information

gram of tissue. The highest SAR value reported under this standard during product certification for use at the ear is 1.27 W/kg and when properly worn on the body is 1.01 W/kg.



## DECLARATION OF CONFORMITY



Hereby, NOKIA CORPORATION declares that this RM-813/RM-884 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at [www.nokia.com/global/declaration](http://www.nokia.com/global/declaration) (in English).

For products placed on the market before 1 July 2012, the alert symbol is applicable to indicate the restrictions on use in France for the WLAN functionality. In accordance with EU Decision 2009/812/EC, after 1 July 2012, the alert symbol is no longer applicable for the WLAN functionality within this product and, hence, can be disregarded even if it is still present on the product.

© 2012 Nokia. All rights reserved.

Nokia, and Nokia Connecting People are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited. Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.



Includes RSA BSAFE cryptographic or security protocol software from RSA Security.



Oracle and Java are registered trademarks of Oracle and/or its affiliates.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Nokia is under license.

This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in

compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See <http://www.mpegla.com> (in English).

To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of some features may vary by region. Please contact your operator for more details. The availability of products, features, applications and services may vary by region. For more information, contact your Nokia dealer or your service provider. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited. The availability of Nokia services may vary by region.

## FCC NOTICE

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Your device may cause TV or radio interference (for example, when using a device in close proximity to receiving equipment). If you require assistance, contact your local service facility. Any changes or modifications not expressly approved by Nokia could void the user's authority to operate this equipment.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of devices and the content formats supported. Some services are subject to a separate charge.

555555/Issue 1 EN



## 40 Index

<b>Index</b>	date and time	19
<b>A</b>	<b>E</b>	
access codes	e-mail	29
alarm clock	emergency calls	35
antennas	10	
<b>B</b>	<b>F</b>	
backing up data	factory settings, restoring	32
battery	FM radio	23, 24
— charging	9	
Bluetooth	20, 21	
browser	<b>H</b>	
<i>See web browser</i>	home screen	18
business cards	21	
<b>C</b>	<b>I</b>	
cable connection	IM (instant messaging)	29, 30
Calendar	IMEI number	11
calls	indicators	12
— emergency	internet	
— log	<i>See web browser</i>	
— making	14	
camera	<b>K</b>	
— recording videos	keyboard	6, 15
— sending pictures and videos	keyguard	12
— taking pictures	keys and parts	5, 7
charging the battery	34	
chat services (IM)	29, 30	
clock	19	
connectivity	22	
contacts	<b>L</b>	
— adding	lock code	11
— copying	locking	
— saving	— keys	12
copying content	loudspeaker	13
13, 21		
<b>D</b>	<b>M</b>	
data connections	mail	29
— Bluetooth	— creating	29
— WLAN	— reading and replying to	29
20	— sending	29
22	mailbox	
	— voice	17
	meeting entries	20
	memory card	8
	messages	
	— sending	17





messaging key	7	shortcuts	18
MMS (multimedia message service)	17	SIM card	7, 14
multimedia messages	17	SMS (short message service)	17
music	25	social networks	28
<b>N</b>		software updates	30, 31
Nokia Services	30	speed dialling	15
Nokia support information	32	strap	11
<b>O</b>		support	32
offline profile	14	switching on/off	10
<b>P</b>		<b>T</b>	
personalising your phone	18, 19	taking pictures	
phone		See <i>camera</i>	
— switching on/off	10	text input	6, 15, 16
Phone switch	13	text messages	17
pictures		themes	18
— copying	21	time and date	19
— sending	21, 27	tones	
— taking	26	— personalising	19
PIN codes	11	transferring content	13, 21
powering on/off	10	turning on/off	10
predictive text input	16	<b>U</b>	
profiles		updates	
— personalising	19	— phone software	30, 31
PUK codes	11	USB connection	21
<b>R</b>		<b>V</b>	
radio	23, 24	videos	
recording		— copying	21
— videos	26	— playing	26
restoring data	32	— recording	26
restoring settings	32	— sending	21, 27
ringtones	19	voice messages	17
<b>S</b>		volume	13
searching		<b>W</b>	
— radio stations	24	web browser	27
security code	11	— browsing pages	28
settings		— cookies	28
— restoring	32	WLAN (wireless local area network)	22, 23