



OM-481

132 366T

July 2002

Processes



Stick (SMAW) Welding



MIG (GMAW) Welding

Flux Cored (FCAW) Welding

Submerged Arc (SAW) Welding

Stud Welding




Air Carbon Arc (CAC-A) Cutting and Gouging

Description




Engine Driven Welding Generator

Big Blue[®] 600D



OWNER'S MANUAL



Visit our website at
www.MillerWelds.com

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001 Quality System Standard.

We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide the exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.

Miller offers a Technical Manual which provides more detailed service and parts information for your unit. To obtain a Technical Manual, contact your local distributor. Your distributor can also supply you with Welding Process Manuals such as SMAW, GTAW, GMAW, and GMAW-P.



TABLE OF CONTENTS

WARNING

This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)

WARNING

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The following terms are used interchangeably throughout this manual:

Stick = SMAW
MIG = GMAW

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING	1
1-1. Symbol Usage	1
1-2. Arc Welding Hazards	1
1-3. Engine Hazards	2
1-4. Additional Symbols For Installation, Operation, And Maintenance	3
1-5. Principal Safety Standards	4
1-6. EMF Information	4
SECTION 1 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION	5
1-1. Signification des symboles	5
1-2. Dangers relatifs au soudage à l'arc	5
1-3. Dangers existant en relation avec le moteur	6
1-4. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance	7
1-5. Principales normes de sécurité	8
1-6. Information sur les champs électromagnétiques	8
SECTION 2 – DEFINITIONS	9
2-1. Symbols And Definitions	9
SECTION 3 – SPECIFICATIONS	9
3-1. Weld, Power, And Engine Specifications	9
3-2. Dimensions, Weights, And Operating Angles	10
3-3. Fuel Consumption	10
3-4. Duty Cycle And Overheating	11
3-5. AC Auxiliary Power	11
3-6. Volt-Ampere Curves	12
SECTION 4 – INSTALLATION	13
4-1. Installing Welding Generator	13
4-2. Connecting The Battery	13
4-3. Installing Exhaust Pipe And Rain Cap	14
4-4. Engine Prestart Checks	14
4-5. Connecting To Weld Output Terminals	15
4-6. Selecting Weld Cable Sizes	15
4-7. Remote 14 Receptacle RC3 Information	16
4-8. Terminal Strip 3T Connections	17
SECTION 5 – OPERATING THE WELDING GENERATOR	18
5-1. Front Panel Controls	18
5-2. Example Of Remote Amperage Control	19
SECTION 6 – OPERATING AUXILIARY EQUIPMENT	19
6-1. 120 Volt Duplex GFCI Receptacles	19
6-2. 240 Volt Duplex Receptacle (Optional)	20
SECTION 7 – MAINTENANCE & TROUBLESHOOTING	20
7-1. Routine Maintenance	20
7-2. Maintenance Label	22
7-3. Servicing Air Cleaner	23
7-4. Servicing Fuel And Lubrication Systems	24
7-5. Adjusting Engine Speed	25
7-6. Overload Protection	25
7-7. Checking And Replacing Engine Belt	26
7-8. Servicing Optional Spark Arrestor	26
7-9. Adjusting Overspeed Shutdown Valve	27
7-10. Troubleshooting	28
SECTION 8 – ELECTRICAL DIAGRAM	30
SECTION 9 – RUN-IN PROCEDURE	32
9-1. Wetstacking	32
9-2. Run-In Procedure Using Load Bank	33
9-3. Run-In Procedure Using Resistance Grid	34
SECTION 10 – AUXILIARY POWER GUIDELINES	35
SECTION 11 – PARTS LIST	42
OPTIONS AND ACCESSORIES	
WARRANTY	

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

rom_nd_4/02

1-1. Symbol Usage



Means Warning! Watch Out! There are possible hazards with this procedure! The possible hazards are shown in the adjoining symbols.

▲ Marks a special safety message.

☞ Means "Note"; not safety related.



This group of symbols means Warning! Watch Out! possible ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards

▲ The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.

▲ Only qualified persons should install, operate, maintain, and repair this unit.

▲ During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.


Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.

- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists in inverters after stopping engine.


- Stop engine on inverter and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.


- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Protect yourself and others from flying sparks and hot metal.
- Do not weld where flying sparks can strike flammable material.
- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.



FLYING METAL can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.

1-3. Engine Hazards



FUEL can cause fire or explosion.


- Stop engine and let it cool off before checking or adding fuel.
- Do not add fuel while smoking or if unit is near any sparks or open flames.

- Do not overfill tank – allow room for fuel to expand.
- Do not spill fuel. If fuel is spilled, clean up before starting engine.
- Dispose of rags in a fireproof container.



HOT PARTS can cause severe burns.


- Allow cooling period before maintaining.
- Wear protective gloves and clothing when working on a hot engine.
- Do not touch hot engine parts or just-welded parts bare-handed.



NOISE can damage hearing.


Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



MAGNETIC FIELDS can affect pacemakers.


- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.



STEAM AND HOT COOLANT can burn.


- If possible, check coolant level when engine is cold to avoid scalding.
- Always check coolant level at overflow tank, if present on unit, instead of radiator (unless told otherwise in maintenance section or engine manual).
- If the engine is warm, checking is needed, and there is no overflow tank, follow the next two statements.

- Wear safety glasses and gloves and put a rag over radiator cap.
- Turn cap slightly and let pressure escape slowly before completely removing cap.




MOVING PARTS can cause injury.

- Keep away from fans, belts, and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Stop engine before installing or connecting unit.
- Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
- To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Reinstall panels or guards and close doors when servicing is finished and before starting engine.
- Before working on generator, remove spark plugs or injectors to keep engine from kicking back or starting.
- Block flywheel so that it will not turn while working on generator components.




BATTERY EXPLOSION can BLIND.

- Always wear a face shield, rubber gloves, and protective clothing when working on a battery.
- Stop engine before disconnecting or connecting battery cables or servicing battery.
- Do not allow tools to cause sparks when working on a battery.
- Do not use welder to charge batteries or jump start vehicles.
- Observe correct polarity (+ and -) on batteries.
- Disconnect negative (-) cable first and connect it last.




BATTERY ACID can BURN SKIN and EYES.

- Do not tip battery.
- Replace damaged battery.
- Flush eyes and skin immediately with water.



ENGINE EXHAUST GASES can kill.

- Use equipment outside in open, well-ventilated areas.
- If used in a closed area, vent engine exhaust outside and away from any building air intakes.



ENGINE HEAT can cause fire.

- Do not locate unit on, over, or near combustible surfaces or flammables.
- Keep exhaust and exhaust pipes way from flammables.



EXHAUST SPARKS can cause fire.


- Do not let engine exhaust sparks cause fire.
- Use approved engine exhaust spark arrestor in required areas – see applicable codes.

1-4. Additional Symbols For Installation, Operation, And Maintenance




FALLING UNIT can cause injury.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, trailer, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.




FLYING SPARKS can cause injury.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.




OVERHEATING can damage motors.

- Turn off or unplug equipment before starting or stopping engine.
- Do not let low voltage and frequency caused by low engine speed damage electric motors.
- Do not connect 50 or 60 Hertz motors to the 100 Hertz receptacle where applicable.




OVERUSE can cause OVERHEATING.

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.




STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.




TILTING OF TRAILER can cause injury.

- Use tongue jack or blocks to support weight.
- Properly install welding generator onto trailer according to instructions supplied with trailer.




READ INSTRUCTIONS.

- Use only genuine MILLER replacement parts.
- Perform engine maintenance and service according to this manual and the engine manual.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-5. Principal Safety Standards

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3.

Safe Practices For Occupation And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 1430 Broadway, New York, NY 10018.

Cutting And Welding Processes, NFPA Standard 51B, from National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

1-6. EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Pacemakers:

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.

SECTION 1 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

rom_nd_fre 4/02

1-1. Signification des symboles



Signifie Mise en garde ! Soyez vigilant ! Cette procédure présente des risques de danger ! Ceux-ci sont identifiés par des symboles adjacents aux directives.

▲ Identifie un message de sécurité particulier.

Signifie NOTA ; n'est pas relatif à la sécurité.

1-2. Dangers relatifs au soudage à l'arc

▲ Les symboles présentés ci-après sont utilisés tout au long du présent manuel pour attirer votre attention et identifier les risques de danger. Lorsque vous voyez un symbole, soyez vigilant et suivez les directives mentionnées afin d'éviter tout danger. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les normes de sécurité énumérées à la section 1-5. Veuillez lire et respecter toutes ces normes de sécurité.

▲ L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées.

▲ Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UN CHOC ÉLECTRIQUE peut tuer.

Un simple contact avec des pièces électriques peut provoquer une électrocution ou des blessures graves. L'électrode et le circuit de soudage sont sous tension dès que l'appareil est sur ON. Le circuit d'entrée et les circuits internes de l'appareil sont également sous tension à ce moment-là. En soudage semi-automatique ou automatique, le fil, le dévidoir, le logement des galets d'entraînement et les pièces métalliques en contact avec le fil de soudage sont sous tension. Des matériels mal installés ou mal mis à la terre présentent un danger.

- Ne jamais toucher les pièces électriques sous tension.
- Porter des gants et des vêtements de protection secs ne comportant pas de trous.
- S'isoler de la pièce et de la terre au moyen de tapis ou d'autres moyens isolants suffisamment grands pour empêcher le contact physique éventuel avec la pièce ou la terre.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer et mettre à la terre correctement cet appareil conformément à son manuel d'utilisation et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la terre du cordon d'alimentation – Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Vérifier fréquemment le cordon d'alimentation pour voir s'il n'est pas endommagé ou dénudé – remplacer le cordon immédiatement s'il est endommagé – un câble dénudé peut provoquer une électrocution.
- Mettre l'appareil hors tension quand on ne l'utilise pas.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct – ne pas utiliser le connecteur de pièce ou le câble de retour.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.




Ce groupe de symboles signifie Mise en garde ! Soyez vigilant ! Il y a des risques de danger reliés aux CHOCS ÉLECTRIQUES, aux PIÈCES EN MOUVEMENT et aux PIÈCES CHAUDES. Reportez-vous aux symboles et aux directives ci-dessous afin de connaître les mesures à prendre pour éviter tout danger.

- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.
- Porter un harnais de sécurité quand on travaille en hauteur.
- Maintenir solidement en place tous les panneaux et capots.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.

Une tension DC importante subsiste à l'intérieur des onduleurs après avoir coupé l'alimentation.


- Couper l'alimentation du poste et décharger les condensateurs d'entrée comme indiqué dans la Section Maintenance avant de toucher des composants.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.

- Porter un casque de soudage muni d'un écran de filtre approprié pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.
- Utiliser des écrans ou des barrières pour protéger des tiers de l'éclair et de l'éblouissement; demander aux autres personnes de ne pas regarder l'arc.
- Porter des vêtements de protection constitué dans une matière durable, résistant au feu (laine ou cuir) et une protection des pieds.



LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereuse pour votre santé.


- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser un échappement au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est insuffisante, utiliser un respirateur à alimentation d'air homologué.
- Lire les spécifications de sécurité des matériaux (MSDSs) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyeurs et les dégraissateurs.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et si nécessaire, en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Brancher le câble sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.



DES PARTICULES VOLANTES peuvent blesser les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes.

Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.

- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.




LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz protecteur en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.


- Prévoir une période de refroidissement avant d'effectuer des travaux d'entretien.
- Porter des gants et des vêtements de protection pour travailler sur un moteur chaud.
- Ne pas toucher à mains nues les parties chaudes du moteur ni les pièces récemment soudées.



LE BRUIT peut affecter l'ouïe.


Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.



LES CHAMPS MAGNÉTIQUES peuvent affecter les stimulateurs cardiaques.

- Porteurs de stimulateur cardiaque, restez à distance.
- Les porteurs d'un stimulateur cardiaque doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de gougeage ou de soudage par points.



Si des BOUTEILLES sont endommagées, elles pourront exploser.

Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.


- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Ne pas tenir la tête en face de la sortie en ouvrant la soupape de la bouteille.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Lire et suivre les instructions concernant les bouteilles de gaz comprimé, les équipements associés et les publication P-1 CGA énumérées dans les normes de sécurité.

1-3. Dangers existant en relation avec le moteur



LE CARBURANT MOTEUR peut provoquer un incendie ou une explosion.

- Arrêter le moteur avant de vérifier le niveau de carburant ou de faire le plein.
- Ne pas faire le plein en fumant ou proche d'une source d'étincelles ou d'une flamme nue.
- Ne pas faire le plein de carburant à ras bord; prévoir de l'espace pour son expansion.
- Faire attention de ne pas renverser de carburant. Nettoyer tout carburant renversé avant de faire démarrer le moteur.
- Jeter les chiffons dans un récipient ignifuge.




LA VAPEUR ET LE LIQUIDE DE REFROIDISSEMENT CHAUD peuvent provoquer des brûlures.

- Il est préférable de vérifier le liquide de refroidissement une fois le moteur refroidi pour éviter de se brûler.
- Toujours vérifier le niveau de liquide de refroidissement dans le vase d'expansion (si présent), et non dans le radiateur (sauf si précisé autrement dans la section maintenance du manuel du moteur).
- Si le moteur est chaud et que le liquide doit être vérifié, opérer comme suivant :
- Mettre des lunettes de sécurité et des gants, placer un torchon sur le bouchon du radiateur.
- Dévisser le bouchon légèrement et laisser la vapeur s'échapper avant d'enlever le bouchon.




DES ORGANES MOBILES peuvent provoquer des blessures.

- Ne pas approcher les mains des ventilateurs, courroies et autres pièces en mouvement.
- Maintenir fermés et fixement en place les portes, panneaux, recouvrements et dispositifs de protection.
- Arrêter le moteur avant d'installer ou brancher l'appareil.
- Demander seulement à un personnel qualifié d'enlever les dispositifs de sécurité ou les recouvrements pour effectuer, s'il y a lieu, des travaux d'entretien et de dépannage.
- Pour empêcher tout démarrage accidentel pendant les travaux d'entretien, débrancher le câble négatif (-) de batterie de la borne.
- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Remettre en place les panneaux ou les dispositifs de protection et fermer les portes à la fin des travaux d'entretien et avant de faire démarrer le moteur.
- Avant d'intervenir, déposer les bougies ou injecteurs pour éviter la mise en route accidentelle du moteur.
- Bloquer le volant moteur pour éviter sa rotation lors d'une intervention sur le générateur.




L'EXPLOSION DE LA BATTERIE peut RENDRE AVEUGLE.

- Toujours porter une protection faciale, des gants en caoutchouc et vêtements de protection lors d'une intervention sur la batterie.
- Arrêter le moteur avant de débrancher ou de brancher les câbles de batterie.
- Eviter de provoquer des étincelles avec les outils en travaillant sur la batterie.
- Ne pas utiliser le poste de soudage pour charger les batteries ou des véhicules de démarrage rapide.
- Observer la polarité correcte (+ et -) sur les batteries.
- Débrancher le câble négatif (-) en premier lieu. Le rebrancher en dernier lieu.



L'ACIDE DE LA BATTERIE peut provoquer des brûlures dans les YEUX et sur la PEAU.

- Ne pas renverser la batterie.
- Remplacer une batterie endommagée.
- Rincer immédiatement les yeux et la peau à l'eau.



LES GAZ D'ÉCHAPPEMENT DU MOTEUR peuvent provoquer des accidents mortels.

- Utiliser l'équipement à l'extérieur dans des zones ouvertes et bien ventilées.
- En cas d'utilisation dans un endroit fermé évacuer les gaz d'échappement du moteur vers l'extérieur à distance des entrées d'air dans les bâtiments.



LA CHALEUR DU MOTEUR peut provoquer un incendie.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Tenir à distance les produits inflammables de l'échappement.



LES ÉTINCELLES À L'ÉCHAPPEMENT peuvent provoquer un incendie.


- Empêcher les étincelles d'échappement du moteur de provoquer un incendie.
- Utiliser uniquement un pare-étincelles approuvé – voir codes en vigueur.

1-4. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance




LA CHUTE DE L'APPAREIL peut blesser.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil lui-même ; sans chariot, de bouteilles de gaz, remorque, ou autres accessoires.
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.




LES ÉTINCELLES VOLANTES risquent de provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manoeuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.




LE SURCHAUFFEMENT peut endommager le moteur électrique.

- Arrêter ou déconnecter l'équipement avant de démarrer ou d'arrêter le moteur.
- Ne pas laisser tourner le moteur trop lentement sous risque d'endommager le moteur électrique à cause d'une tension et d'une fréquence trop faibles.
- Ne pas brancher de moteur de 50 ou de 60 Hz à la prise de 100 Hz, s'il y a lieu.



L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Laisser l'équipement refroidir ; respecter le facteur de marche nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.




LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.




UNE REMORQUE QUI BASCULE peut entraîner des blessures.

- Utiliser les supports de la remorque ou des blocs pour soutenir le poids.
- Installer convenablement le poste sur la remorque comme indiqué dans le manuel s'y rapportant.




LIRE LES INSTRUCTIONS.

- Utiliser seulement les pièces de rechange d'origine.
- Effectuer la maintenance et la mise en service d'après le manuel et celui du moteur.



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

1-5. Principales normes de sécurité

Safety in Welding and Cutting, norme ANSI Z49.1, de l'American Welding Society, 550 N.W. Lejeune Rd, Miami FL 33126

Safety and Health Standards, OSHA 29 CFR 1910, du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402.

Recommended Safe Practice for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, norme AWS F4.1, de l'American Welding Society, 550 N.W. Lejeune Rd, Miami FL 33126

National Electrical Code, NFPA Standard 70, de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, de la Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202.

Règles de sécurité en soudage, coupage et procédés connexes, norme CSA W117.2, de l'Association canadienne de normalisation, vente de normes, 178 Rexdale Boulevard, Rexdale (Ontario) Canada M9W 1R3.

Safe Practices For Occupation And Educational Eye And Face Protection, norme ANSI Z87.1, de l'American National Standards Institute, 1430 Broadway, New York, NY 10018.

Cutting and Welding Processes, norme NFPA 51B, de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

1-6. Information sur les champs électromagnétiques

Données sur le soudage électrique et sur les effets, pour l'organisme, des champs magnétiques basse fréquence

Le courant de soudage, pendant son passage dans les câbles de soudage, causera des champs électromagnétiques. Il y a eu et il y a encore un certain souci à propos de tels champs. Cependant, après avoir examiné plus de 500 études qui ont été faites pendant une période de recherche de 17 ans, un comité spécial ruban bleu du National Research Council a conclu: "L'accumulation de preuves, suivant le jugement du comité, n'a pas démontré que l'exposition aux champs magnétiques et champs électriques à haute fréquence représente un risque à la santé humaine". Toutefois, des études sont toujours en cours et les preuves continuent à être examinées. En attendant que les conclusions finales de la recherche soient établies, il vous serait souhaitable de réduire votre exposition aux champs électromagnétiques pendant le soudage ou le coupage.

Afin de réduire les champs électromagnétiques dans l'environnement de travail, respecter les consignes suivantes :

- 1 Garder les câbles ensemble en les torsadant ou en les attachant avec du ruban adhésif.
- 2 Mettre tous les câbles du côté opposé de l'opérateur.
- 3 Ne pas courber pas et ne pas entourer pas les câbles autour de votre corps.
- 4 Garder le poste de soudage et les câbles le plus loin possible de vous.
- 5 Relier la pince de masse le plus près possible de la zone de soudure.

Consignes relatives aux stimulateurs cardiaques :

Les personnes qui portent un stimulateur cardiaque doivent avant tout consulter leur docteur. Si vous êtes déclaré apte par votre docteur, il est alors recommandé de respecter les consignes ci-dessus.

SECTION 2 – DEFINITIONS

2-1. Symbols And Definitions

	Stop Engine		Fast (Run, Weld/Power)		Start Engine		Engine
	Check engine belt		Oil Pressure		Battery		Hourmeter (HM)
	Do Not Switch Under Load		Read Operator's Manual		Certified/Trained Mechanic		Engine Oil
	Check Injectors/Pump		Check Valve Clearance		Fuel		Engine Oil Temperature
	Positive		Negative		Wire Feed		Welding Arc
	Amperes		Volts		Panel/Local		Remote
	On		Direct Current (DC)		Alternating Current		Output
	Stick (SMAW) Welding		Air Carbon Arc Cutting (CAC-A)		MIG (GMAW) Welding		Protective Earth (Ground)
	Circuit Breaker		Temperature		Work Connection		Electrode Connection
	Time		Hours		Seconds		

SECTION 3 – SPECIFICATIONS

3-1. Weld, Power, And Engine Specifications

Welding Mode	Weld Output Range	Rated Welding Output	Maximum Open-Circuit Voltage (Nominal)	Generator Power Rating	Engine	Fuel Capacity
CC/DC	45 – 800 A	600 A, 44 Volts DC, 100% Duty Cycle	95 (80)	Single-Phase, 3 kVA/kW, 26 A, 120 V AC, 60 Hz	Deutz F4L-912 Air-Cooled, Four-Cylinder, 61 HP Diesel Engine	15 gal (57 L)
CV/DC	14 – 44 V					

3-2. Dimensions, Weights, And Operating Angles


Dimensions	
Height	58 (1473 mm)
Width	32 (813 mm)
Depth	68 in (1727 mm)
A	1-1/16 in (27 mm)
B	29-7/8 in (759 mm)
C	6-1/8 in (156 mm)
D	9-3/4 in (248 mm)
E	13-3/4 in (349 mm)
F	28-3/16 in (716 mm)
G	36 in (914 mm)
H	46-1/2 in (1181 mm)
J	50-1/2 in (1283 mm)
K	62-3/8 in (1584 mm)
L	21/32 in (17 mm) Dia. 16 Holes
Weight	
2250 lb (1021 kg)	

▲ Do not exceed operating angles while running or engine damage will occur.


▲ Do not move or operate unit where it could tip.

ST-153 650 angles_1 3/96


3-3. Fuel Consumption



3-4. Duty Cycle And Overheating




100% Duty Cycle At 600 Amperes



Continuous Welding


Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

▲ Exceeding duty cycle can damage unit and void warranty.



sb1.1 8/93 SB-134 397-C

3-5. AC Generator Power




The ac power curve shows the generator power in amperes available at the 120 and 240 volt receptacles.

rsb3.1 2/92 - ST-109 365-C


3-6. Volt-Ampere Curves

The volt-ampere curve shows the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.

A. For Constant Current (CC) Mode




B. For Constant Voltage (CV) Mode




SECTION 4 – INSTALLATION

4-1. Installing Welding Generator




Movement


▲ Do Not Lift Unit From End




Airflow Clearance



Location



Grounding



Electrically bond generator frame to vehicle frame by metal-to-metal contact.

▲ Always securely fasten welding generator onto transport vehicle or trailer and comply with all DOT and other applicable codes.

▲ Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.


▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame



Connect cable from equipment ground terminal to metal vehicle frame. Use #10 AWG or larger insulated copper wire.

install1 7/02 – Ref. ST-800 652 / Ref. ST-800 477-A / ST-158 936-A / S-0854


4-2. Connecting The Battery



▲ Connect Negative (-) Cable Last.




Tools Needed:



ST-153 654-B / Ref. SD-131 784-A / Ref. S-0756-B

4-3. Installing Exhaust Pipe And Rain Cap



▲ Stop engine, and let cool.

- 1 Exhaust Pipe
- 2 Muffler Pipe

Install exhaust pipe over muffler pipe. Secure exhaust pipe to top cover using supplied hardware.


- 3 Rain Cap

Install so cap opens toward front of unit.

▲ Do not blow exhaust toward air cleaner or air intake.

Ref. ST-156 467-C

4-4. Engine Prestart Checks



Check all fluids daily. Engine must be cold and on a level surface.

☞ This unit has a low oil pressure shutdown switch. However, some conditions may cause engine damage before the engine shuts down. Check oil level often and do not use the oil pressure shutdown system to monitor oil level.

Follow run-in procedure in engine manual. If unburned fuel and oil collect in exhaust pipe during run-in, see Section 9.

Fuel

▲ Do not use gasoline. Gasoline will damage engine.

Add fresh diesel fuel before starting engine the first time (see maintenance label for specifications). Fill fuel tank up to 1/2 in. (13 mm) from top to allow room for expansion.

Do not run out of fuel or air enters fuel system and causes starting problems. See engine manual to bleed air from fuel system.

Oil

After fueling, check oil with unit on level surface. If oil is not up to full mark on dipstick, add oil (see maintenance label).

☞ To improve cold weather starting:

Keep battery in good condition. Store battery in warm area off concrete surface.


Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information.


Use correct grade oil for cold weather.


Tools Needed:
 3/8 in

ST-156 467

4-5. Connecting To Weld Output Terminals



Tools Needed:
 3/8, 7/8 in



1 Positive (+) Weld Output Terminals
 2 Negative (-) Weld Output Terminals


For Direct Current Electrode Positive (DCEP), connect work cable to Negative (-) terminal and electrode holder cable to Positive (+) terminal.

For Direct Current Electrode Negative (DCEN), reverse cable connections.

To prevent overheating and damage, two terminals are provided for each polarity in case more than one cable is needed to carry current to a single arc (see Section 4-6). This unit is not designed to supply multiple arcs.

Ref. ST-134 687-B / ST-174 733

4-6. Selecting Weld Cable Sizes*

 Weld Output Terminals ▲ Turn off power before connecting to weld output terminals. ▲ Do not use worn, damaged, undersized, or poorly spliced cables.	Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding***								
	Welding Amperes	100 ft (30 m) or Less		150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)
		10 – 60% Duty Cycle	60 – 100% Duty Cycle	10 – 100% Duty Cycle					
100	4 (20)	4 (20)	4 (20)	3 (30)	2 (35)	1 (50)	1/0 (60)	1/0 (60)	
150	3 (30)	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	3/0 (95)	
200	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	4/0 (120)	
250	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 2/0 (2x70)	
300	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 3/0 (2x95)	
350	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	
400	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	2 ea. 4/0 (2x120)	
500	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 3/0 (3x95)	
600	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)	
700	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)	4 ea. 4/0 (4x120)	
800	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)	4 ea. 4/0 (4x120)	4 ea. 4/0 (4x120)	
900	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)					
1000	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)					

* chart is a guideline and may not suit all applications. If cable overheating occurs (normally you can smell it), use next size larger cable.

**Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.
 () = mm² for metric use


S-0007-E-

***For distances longer than those shown in this guide, call a factory applications representative at 920-735-4505.

4-7. Remote 14 Receptacle RC3 Information

<p>The diagram shows a side view of the Remote 14 Receptacle RC3 with a circular terminal layout. The terminals are labeled A through K. A callout shows a magnified view of the terminal layout. Below the main diagram, two alternative wiring configurations are shown, separated by the word 'OR'. The first configuration shows a power source connected to terminals A and B. The second configuration shows a power source connected to terminals I and J. A reference number 'Ref. ST-800 907-A' is located at the bottom right of the diagram area.</p>		Socket*	Socket Information
		A	24 volts ac. Protected by circuit breaker CB4.
		B	Contact closure to A completes 24 volts ac contactor control circuit.
		I	115 volts ac. Protected by circuit breaker CB3.
		J	Contact closure to I completes 115 volts ac contactor control circuit.
		G	Circuit common for 24 and 115 volts ac circuits.
		C	0 to +10 volts dc output to remote control from min to max of Amperage/Voltage control R1.
		D	Remote control circuit common.
		E	0 to +10 volts dc input command signal from remote control.
		K	Chassis common.
<p>*The remaining sockets are not used.</p>			

4-8. Terminal Strip 3T Connections



▲ Stop engine.

If remote control plug does not fit in receptacle RC3, wire cord directly to terminal strip 3T.

▲ **Do not connect to Remote 14 receptacle RC3 and terminal strip 3T at the same time. Use only one remote control method.**




Open right side door.

- 1 Terminal Strip 3T
- 2 Strain Relief


Connect leads to 3T using terminal information shown in Section 4-7.

Secure cord in strain relief.

Reinstall cover. Close door.




Tools Needed:



Ref. ST-131 784-A / Ref. ST-121 578-D / Ref. S-184 781

SECTION 5 – OPERATING THE WELDING GENERATOR

5-1. Front Panel Controls



ST-134 687-B

- 1 Voltmeter
- 2 Ammeter
- 3 Ampere Range Switch

▲ Do not switch under load.

Use switch to select weld amperage range. For most welding applications, use lowest amperage range possible to help prevent arc outages.

- 4 Amperage/Voltage Control

Control adjusts amperage within range selected by Ampere Range switch. Example: weld output would be 90 A DC with Ampere Range switch in 55 to 125 A DC/CC position and Amperage/Voltage control set at 50 (50% of 55 to 125 A).

- 5 Service Engine Air Cleaner Light

Service engine air cleaner if light goes on (see Section 7-3).

- 6 Amperage/Voltage Control Switch

Use switch to select front panel or remote amperage control (see Section 5-2).

For front panel control, place switch in Panel position. For remote control, place switch in Remote position and connect remote control to Remote 14 receptacle or terminal strip 3T

(see Sections 4-7 and 4-8).

- 7 CC/CV Selector Switch

Use switch to select type of weld output. Use CC for Stick (SMAW) welding and Air Carbon Arc Cutting. Use CV for wire feed processes (MIG, FCAW, SAW). If using CV, place Ampere Range switch in maximum position.

- 8 Output (Contactor) Switch

Use switch to control remote contactor connected to receptacle RC3 or terminal strip 3T (see Sections 4-7 and 4-8).

- 9 Check Cooling System/Alternator Light

▲ Stop engine and check engine belt if light goes on (see Section 7-7).

- 10 Engine Control Switch

Use switch to start engine and stop engine.

In Run position, engine runs at weld/power speed all the time.

To Start: turn Engine Control switch to Start. Release switch when engine starts.

☞ If the engine does not start, let engine come to a complete stop before attempting restart.

To Stop: turn Engine Control switch to Off position. If unit has overspeed shutdown op-

tion, engine stops automatically when speed exceeds normal rpm.

- 11 Engine Hour Meter

- 12 Fuel Gauge

- 13 Battery Ampere Gauge

Use gauge to check amperage output to the battery. The gauge reads near 0 (zero) when the engine is running. If gauge is at a negative number, the battery is discharging.

▲ Stop engine, and do not run until problem is fixed.

- 14 Oil Pressure Gauge/Switch

Use gauge/switch to check oil pressure. Normal operating pressure is about 50 psi (345 kPa). Engine stops if oil pressure is too low.


▲ Do not run engine until problem is fixed.

- 15 Oil Temperature Gauge/Switch

Use gauge/switch to check oil temperature. Normal operating temperature is about 225°F (107°C). Engine stops if oil temperature is too high.


▲ Do not run engine until problem is fixed.

5-2. Example Of Remote Amperage Control




SECTION 6 – OPERATING AUXILIARY EQUIPMENT

6-1. 120 Volt Duplex GFCI Receptacles



6-2. 240 Volt Duplex Receptacle (Optional)



Ref. ST-174 733 / ST-174 757

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

- 1 240 V 15 A AC Duplex Receptacle RC1

Receptacle supplies 60 Hz single-phase power at weld/power speed. Maximum output from this receptacle is 3 kVA/kW.

- 2 120 V 20 A AC Duplex Receptacle GFCI2 (Section 6-1)

- 3 Circuit Breakers CB1 And CB2

CB1 and CB2 protect the 120 V and 240 V receptacles from overload. If CB1 or CB2 opens, the 240 V receptacle and one half of the 120 V receptacle does not work. 120 volts may still be present at the 240 volt receptacle. Press button to reset breaker.

☞ If a circuit breaker continues to open, contact a Factory Authorized Service Agent.

- 4 Total Generator Power Output

Combined output of all receptacles limited to 3 kVA/kW output of the generator.


EXAMPLE: If 10 A is drawn from the 240 V receptacle, only 5 A is available at the 120 V receptacle:

$$(240 \text{ V} \times 10 \text{ A}) + (120 \text{ V} \times 5 \text{ A}) = 3.0 \text{ kVA/kW}$$

SECTION 7 – MAINTENANCE & TROUBLESHOOTING

7-1. Routine Maintenance

Note ☞ Follow the storage procedure in the engine owner's manual if the unit will not be used for an extended period.




Recycle engine fluids.

▲ Stop engine before maintaining.



☞ See also Engine Manual and Maintenance Label. Service engine more often if used in severe conditions.

* To be done by Factory Authorized Service Agent.


🕒 8 h




🕒 50 h




🕒 100 h




Change Oil. See Section 7-4.



Change Oil Filter. See Section 7-4.



Clean And Tighten Battery Connections.




Check air cleaner hoses for cracks and loose clamps.

🕒 200 h




Replace Unreadable Labels.

🕒 250 h




Check And Clean Spark Arrestor. See Section 7-8.

🕒 500 h




Repair Or Replace Cracked Cables.


🕒 1000 h




Blow Out Or Vacuum Inside. During Heavy Service, Clean Monthly.




Service Welding Generator Brushes And Slip Rings. Service More Often In Dirty Conditions.*




Drain Sludge From Fuel Tank. See Section 7-4.



Change Fuel Filters. See Section 7-4.




Check Belt Tension. See Section 7-7.



Check Valve Clearance.*

🕒 3000 h




Clean/Set Injectors.*

7-2. Maintenance Label

DEUTZ F4L912 DIESEL ENGINE

See Engine Manual for complete engine care.
Give Engine Specification and Serial Number when ordering parts.


 **Check daily.**

Recommended Oil API Service Classification CD/CE (or better)

Oil And Filter Change
dirty conditions 100 hours or less normal conditions 125 to 150 hours

Oil Filter Deutz 117-4418, Fleetguard LF4056, Fram PH2842, Hastings P352 or FP352, MILLER 064 677

Oil Capacity 11.5 qt (11 L) or 12 qt (11.4 L) with filter change



* Only with engine oil preheating.








Fuel Capacity 19 gal (72.8 L)

Fuel Grade 1-D or 2-D Cetane No. 45 min.

Primary Fuel Filter/
Water Separator. MILLER 192 744, Fram P1145A



Secondary Fuel Filter MILLER 064 686, Deutz 117-4423, Fram P4102

Fill filter with clean fuel before installing – read instructions on filter.

	<p>Air Filter Service 50 hours or less – see Owner’s Manual</p> <p>Air Filter Element MILLER 020 319, Donaldson P181052, Fram CAK 253</p>		<p>Valve Clearance – Cold</p> <p>Intake 0.006 in (0.15 mm)</p> <p>Exhaust 0.006 in (0.15 mm)</p>
	<p>Battery BCI Group 24</p> <p>Cranking Performance at 0°F (-18°C) 650 Amps</p>		<p>Engine Cooling</p> <p><i>Avoid recirculation of air from hot air exit to blower intake.</i></p> <p>Blower Belt . . . Deutz 223-5256, Gates 7580</p>
	<p>Engine RPM – No Load</p> <p>Weld/Power 1850</p>		<p><i>Have only trained technician maintain injection pump and injectors. AIR, WATER, or GASOLINE will harm the injection system. If engine has run out of fuel or fuel filter is changed, bleeding of air may be required. Check engine manual for proper procedure.</i></p> <p><i>Injectors should be checked annually.</i></p>
	<p>Spark Arrestor Inspection And Service 250 operating hours – see Owner’s Manual</p>		

S-120 629-H

7-3. Servicing Air Cleaner



▲ **Stop engine.**

▲ **Do not run engine without air cleaner or with dirty element. Engine damage caused by using a damaged element is not covered by the warranty.**

☞ *The air cleaner primary element can be cleaned but the dirt holding capacity of the filter is reduced with each cleaning. The chance of dirt reaching the clean side of the filter while cleaning and the possibility of filter damage makes cleaning a risk. Consider the risk of unwarrantable equipment damage when determining whether to clean or replace the primary element.*

*If you decide to clean the primary element, we strongly recommend installing an optional safety element to provide additional engine protection. **Never clean a safety element.** Replace the safety element after servicing the primary element three times.*

Clean or replace primary element if dirty (see note above before cleaning). **Replace** primary element if damaged. Replace primary element yearly or after six cleanings.

- 1 Housing
- 2 Safety Element (Optional)
- 3 Primary Element
- 4 Dust Cap
- 5 Dust Ejector

To clean air filter:


Wipe off cap and housing. Remove cap and dump out dust. Remove element(s). Wipe dust from inside cap and housing with damp cloth. Reinstall safety element (if present). Reinstall cap.

▲ **Do not clean housing with air hose.**


Clean primary element with compressed air only.

Air pressure must not exceed 100 psi (690 kPa). Use 1/8 in (3 mm) nozzle and keep nozzle at least 2 in (51 mm) from inside of element. Replace primary element if it has holes or damaged gaskets.

Reinstall primary element and cap (dust ejector down).



7-4. Servicing Fuel And Lubrication Systems



▲ **Stop engine and let cool.**

- 1 Oil Filter
- 2 Oil Drain Plug
- 3 Secondary Fuel Filter
- 4 Primary Fuel Filter/Water Separator
- 5 Petcock
- 6 Sludge Drain Plug

To change oil and filter:

See engine manual.

To drain water from fuel system:

Open petcock and drain water into metal container. Close petcock when water-free fuel flows.

To replace primary fuel filter/ water separator:

Turn filter counterclockwise. Remove filter.

Apply thin coat of fuel to gasket on new filter. Install new filter and turn clockwise. Bleed air from fuel system according to engine manual.

Inspect fuel line, and replace if cracked or worn.

To replace secondary fuel filter:

See engine manual.

To drain sludge from fuel tank:

Put metal container under drain, and remove sludge drain plug. Re-install plug when done.

▲ **After servicing, start engine and check for fuel leaks.**

▲ **Stop engine, tighten connections as necessary, and wipe up spilled fuel.**

Close doors.



Tools Needed:





7/16 in

7-5. Adjusting Engine Speed



Engine Speed		RPM
Weld/Power		1850



▲ Stop engine.

Engine speeds have been factory set and should not require adjustment. After tuning engine, check engine speeds with a tachometer. See table for proper no load speeds. If necessary, adjust speeds as follows:

- 1 Speed Adjustment Screw
- 2 Locknut

Loosen nut. Start engine.

Turn screw until engine runs at weld/power speed. Tighten locknut.

▲ Stop engine.







Close side door.

Tools Needed:



Ref. ST-134 730-C / Ref. SD-131 784-A

7-6. Overload Protection



▲ Stop engine.

When a fuse or circuit breaker opens, it usually indicates a more serious problem exists. Contact a Factory Authorized Service Agent.

- 1 Circuit Breaker CB3

CB3 protects the 115 volts ac output to Remote 14 receptacle RC3 or terminal strip 3T. If CB3 opens, the 115 volts ac output stops.

- 2 Circuit Breaker CB4

CB4 protects the 24 volts ac output to Remote 14 receptacle RC3 or terminal strip 3T. If CB4 opens, the 24 volts ac stops.

Press button to reset breaker.

- 3 Fuse F (See Parts List)

- 4 Fuse F6 (See Parts List)

Remove screw to open upper front panel access door.


Fuse F protects the magnetic shut-down switch MS1 from damage due to overload. If F opens, the engine stops. Do not run engine until problem is corrected.

Check fuse, and replace if open.

Fuse F6 protects the excitation circuit from damage due to overload. If F6 opens, there will be low/no weld and generator power output.


Check fuse, and replace if open.

Tools Needed:





Ref. 184 780 / Ref. ST-174 733 / ST-156 468

7-7. Checking And Replacing Engine Belt



Tools Needed:



▲ Stop engine, and let cool.

A V-belt drives the engine cooling fan and alternator. To check tightness of belt, proceed as follows:

Remove rear panel.

- 1 Fan Pulley
- 2 Alternator Pulley
- 3 Engine Belt

Place straight edge along top of pulleys. Push down belt as far as it will go, then measure distance from belt to straight edge.

If less than 1/2 in (13 mm), belt is okay. If not okay, adjust belt.

To adjust belt tension:

- 4 Alternator Bracket
- Loosen hex nut on bracket.
- 5 Alternator Pivot Hex Nut

Loosen hex nut. Pivot alternator clockwise until belt is tight. Tighten hex nuts.

Recheck tightness of belt. Readjust if necessary.

To replace belt:


Replace belt if damaged or cracked. Replace belt as follows:

Loosen hex nuts, pivot alternator counterclockwise, and remove belt. Install new belt, pivot alternator clockwise, adjust tightness, and tighten hex nuts. Recheck tightness of new belt after operating engine 15 minutes and again after 20 hours.



Reinstall guard and rear panel.

Ref. ST-134 730-B / SD-131 784-A

7-8. Servicing Optional Spark Arrestor



Tools Needed:



▲ Stop engine and let cool.

- 1 Spark Arrestor
- 2 Cleanout Plug

Remove plug and remove any dirt covering cleanout hole.

- 3 Exhaust Pipe




Start engine, and run at idle speed to blow dirt out cleanout hole. If nothing blows out of hole, briefly cover end of exhaust pipe.

▲ Stop engine and let cool.



Reinstall cleanout plug.

ST-800 463-A / Ref. ST-131 784-A

7-9. Adjusting Overspeed Shutdown Valve



Engine End



▲ Stop engine, and let cool.

The overspeed shutdown valve protects the engine from damage due to high engine speed. If the engine stops, the valve may be closed.

Shutdown speed is between 1950 and 2100 rpm. Use a tachometer to check shutdown speed as follows:

Open right side door and remove rear panel.

- 1 Air Cleaner
- 2 Hose Into Air Cleaner
- 3 Hose Clamp

Loosen clamp and remove hose.

- 4 Plastic Cap
- 5 High Speed Stop Screw
- 6 Lock Nut

Remove plastic cap from screw. Loosen nut. Turn screw out (toward front of engine) several turns.

- 7 Speed Control Lever
- 8 Overspeed Shutdown Valve

Start engine and increase speed by moving lever toward high speed stop screw. Note engine rpm when valve closes and stops engine.

If shutdown speed is not between 1950 and 2100 rpm, adjust as follows:

- 9 Lock Nut
- 10 Valve Adjustment Screw

Loosen nut and turn screw one turn (clockwise to increase and counter-clockwise to decrease shutdown rpm). Tighten nut.

Check shutdown speed and repeat adjustment if needed.


▲ Stop engine.

Turn high speed stop screw in until screw touches lever. Tighten lock nut on screw and reinstall plastic cap.

Install hose and hose clamp. Install rear panel and close side door.


If necessary, adjust engine speed according to Section 7-5

Tools Needed:



3/8 in

7-10. Troubleshooting



A. Welding

Trouble	Remedy	
No weld output.	Be sure Ampere Range switch is not set between positions.	
	Disconnect equipment from generator power receptacles during start-up.	
	Reset circuit breaker CB3 and/or CB4 (see Section 7-6).	
	Place A/V Control switch in Panel position, or place switch in Remote position and connect remote control to Remote A/V Control receptacle RC3 (see Sections 4-7 and 4-8).	
	Place Output (Contactor) switch in On position, or place switch in Remote position and connect remote contactor to optional Remote 14 receptacle RC3 or terminal strip 3T (see Sections 4-7 and 4-8).	
	Check and secure connections to Remote 14 receptacle or terminal strip 3T (see Sections 4-7 and 4-8).	
	Check fuse F6, and replace if necessary (see Section 7-6).	
Have Factory Authorized Service Agent check brushes and slip rings, and circuit boards PC1 and/or PC2.	<p>Check and tighten connections both inside and outside unit.</p> <p>Be sure connection to work piece is clean and tight.</p> <p>Use dry, properly stored electrodes.</p> <p>Remove excessive coils from weld cables.</p> <p>Tighten lead connections to Ampere Range switch.</p> <p>Have Factory Authorized Service Agent check circuit boards PC1 and/or PC2.</p>	
Erratic weld output.		
High or low weld output voltage.		Check engine speed, and adjust if necessary (see Section 7-5).
		Check CC/CV switch position.
		If low weld output, check fuse F6, and replace if necessary (see Section 7-6).
		Have Factory Authorized Service Agent check circuit board PC1.
Wire feeder not operating.	Reset circuit breaker CB3 and/or CB4 (see Section 7-6).	
	Check and secure connections to Remote 14 receptacle or terminal strip 3T (see Sections 4-7 and 4-8).	
	Repair or replace wire feeder.	
No amperage control or voltage control.	Place Amperage/Voltage Control switch in correct position.	
	Check connections to optional Remote 14 receptacle RC3 and terminal strip 3T (see Sections 4-7 and 4-8).	
	Repair or replace remote control device.	
	Have Factory Authorized Service Agent check optional CV regulator board PC2.	
Low CV weld output.	Set Ampere Range switch to highest range.	
Min or max CV weld output only.	Check position of Amperage/voltage control and Amperage/Voltage Control switch.	
	Repair or replace remote control device.	
	Have Factory Authorized Service Agent check optional CV regulator board PC2.	

B. Generator Power Trouble

Trouble	Remedy
No output at 120 volt ac receptacles.	Reset circuit breaker CB1 and/or CB2 (see Section 6-1).
	Check fuse F6, and replace if necessary (see Section 7-6).
	Have Factory Authorized Service Agent check brushes and slip rings.
Low or high generator power output voltage at 120 volt ac receptacles.	Check engine speed, and adjust if necessary (see Section 7-5).
	If low generator power output, check fuse F6, and replace if necessary (see Section 7-6).

C. Engine


Trouble	Remedy
Engine does not start.	Check fuel level (see Section 4-4).
	Check battery, and replace if necessary.
	Check oil level. Engine stops if oil temperature is too high or oil pressure is too low.
	Check fuse F, and replace if necessary (see Section 7-6).
	Check engine battery charging system according to engine service manual.
Engine suddenly stops.	If Check Cooling System/Alternator light is on, check and replace engine belt.
	Check oil level. Engine stops if oil temperature is too high or oil pressure is too low.
	Check fuse F, and replace if necessary (see Section 7-6).
	Check engine speed. Optional overspeed shutdown stops engine if speed exceeds normal rpm (see Section 7-9).
Engine uses oil during run-in period; wetstacking occurs.	Dry engine.
Engine does not stop when Engine Control switch is placed in Off position.	Have Factory Authorized Service Agent check diode D9
Battery discharges between uses.	Clean top of battery with baking soda and water solution; rinse with clear water.
	Recharge or replace battery if necessary.

SECTION 8 – ELECTRICAL DIAGRAM

A	B	C	D	E	F	G	H	J	K
1T	○	○	○	○	○	○	○	○	○
	5	19	30	48	68	69	J		

A	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R	S	T	U
2T	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	47	49	61	62	71	81	82	83										


A	B	C	D	E	G	I	K	J	
3T	○	○	○	○	○	○	○	○	
	131	59	43	18	44	J	102	42	59






S1	OFF	RUN/IDLE	RUN	START
1		X	X	X
2		X		
3				X

X = CLOSED TO "B" TERMINAL

Figure 8-1. Circuit Diagram For Welding Generator


	WARNING
	<ul style="list-style-type: none"> • Do not touch live electrical parts. • Disconnect input power or stop engine before servicing. • Do not operate with covers removed.
ELECTRIC SHOCK HAZARD	
	<ul style="list-style-type: none"> • Have only qualified persons install, use, or service this unit.



SECTION 9 – RUN-IN PROCEDURE

run_in1 8/01

9-1. Wetstacking



▲ Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Welding Generator

Run diesel engines near rated voltage and current during run-in period to properly seat piston rings and prevent wetstacking. See nameplate, rating label, or specifications section in this manual to find rated voltage and current.

☞ Do not idle engine longer than necessary. Piston rings seat faster if engine runs at weld/power rpm, and the welding generator is kept loaded during run-in.


2 Engine Exhaust Pipe

Wetstacking is unburned fuel and oil in the exhaust pipe and occurs during run-in if the engine is run too long at light load or idle rpm.

If exhaust pipe is coated with a wet, black, tar-like substance, dry the engine using one of the following run-in procedures.

See the engine manual for additional engine run-in information.

9-2. Run-In Procedure Using Load Bank



- ▲ **Stop engine.**
- ▲ **Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- ▲ **Keep exhaust and pipe away from flammables.**
- ▲ **Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.**

1 Load Bank

Turn all load bank switches Off. If needed, connect load bank to 115 volts ac wall receptacle or generator auxiliary power receptacle.

2 Welding Generator

Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.


3 Weld Cables

Connect load bank to generator weld output terminals using proper size weld cables with correct connectors. Observe correct polarity.

Start engine and run for several minutes.

Set load bank switches and then adjust generator A/V control so load equals rated voltage and current of generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and load bank meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

 *Check oil level frequently during run-in; add oil if needed.*



After one hour (minimum) place A/V control in minimum position, then turn off load bank to remove load. Run engine several minutes at no load.

- ▲ **Stop engine and let cool.**

4 Engine Exhaust Pipe

Repeat procedure if wetstacking is present.

9-3. Run-In Procedure Using Resistance Grid



- ▲ **Stop engine.**
- ▲ **Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- ▲ **Keep exhaust and pipe away from flammables.**
- ▲ **Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.**

1 Resistance Grid
Use grid sized for generator rated output.
Turn Off grid.

2 Welding Generator
Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.

3 Weld Cables
Connect grid to generator weld output terminals using proper size weld cables with correct connectors (polarity is not important).

4 Voltmeter
5 Clamp-On Ammeter
Connect voltmeter and ammeter as shown, if not provided on generator.

Start engine and run for several minutes.

Set grid switches and then adjust generator A/V control so load equals rated voltage and current of the generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.


☞ *Check oil level frequently during run-in; add oil if needed.*


After one hour (minimum), place A/V control in minimum position, then shut down grid to remove load. Run engine several minutes at no load.

- ▲ **Stop engine and let cool.**
- 6 Engine Exhaust Pipe
Repeat procedure if wetstacking is present.

SECTION 10 – GENERATOR POWER GUIDELINES

10-1. Selecting Equipment







- 1 Generator Power Receptacles – Neutral Bonded To Frame
- 2 3-Prong Plug From Case Grounded Equipment
- 3 2-Prong Plug From Double Insulated Equipment

▲ **Do not use 2-prong plug unless equipment is double insulated.**

gen_pwr 6/02 – Ref. ST-159 730 / ST-800 577

0-2. Grounding Generator To Truck Or Trailer Frame





Electrically bond generator frame to vehicle frame by metal-to-metal contact.

▲ **Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.**


- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #10 AWG or larger insulated copper wire.

▲ **If unit does not have GFCI receptacles, use GFCI-protected extension cord.**

S-0854

10-3. Grounding When Supplying Building Systems



10-4. How Much Power Does Equipment Require?

1 Resistive Load
 A light bulb is a resistive load and requires a constant amount of power.

2 Non-Resistive Load
 Equipment with a motor is a non-resistive load and requires approximately six times more power while starting the motor than when running (see Section 10-8).

3 Rating Data
 Rating shows volts and amperes, or watts required to run equipment.

AMPERES x VOLTS = WATTS

EXAMPLE 1: If a drill uses 4.5 amperes at 115 volts, calculate its running power requirement in watts.

$4.5 \text{ A} \times 115 \text{ V} = 520 \text{ W}$

The load applied by the drill is 520 watts.

EXAMPLE 2: If three 200 watt flood lamps are used with the drill from Example 1, add the individual loads to calculate total load.

$(200 \text{ W} + 200 \text{ W} + 200 \text{ W}) + 520 \text{ W} = 1120 \text{ W}$

The total load applied by the three flood lamps and drill is 1120 watts.

S-0623

10-5. Approximate Power Requirements For Industrial Motors

Industrial Motors	Rating	Starting Watts	Running Watts
Split Phase	1/8 HP	800	300
	1/6 HP	1225	500
	1/4 HP	1600	600
	1/3 HP	2100	700
	1/2 HP	3175	875
Capacitor Start-Induction Run	1/3 HP	2020	720
	1/2 HP	3075	975
	3/4 HP	4500	1400
	1 HP	6100	1600
	1-1/2 HP	8200	2200
	2 HP	10550	2850
	3 HP	15900	3900
Capacitor Start-Capacitor Run	5 HP	23300	6800
	1-1/2 HP	8100	2000
	5 HP	23300	6000
	7-1/2 HP	35000	8000
Fan Duty	10 HP	46700	10700
	1/8 HP	1000	400
	1/6 HP	1400	550
	1/4 HP	1850	650
	1/3 HP	2400	800
	1/2 HP	3500	1100


10-6. Approximate Power Requirements For Farm/Home Equipment

Farm/Home Equipment	Rating	Starting Watts	Running Watts
Stock Tank De-Icer		1000	1000
Grain Cleaner	1/4 HP	1650	650
Portable Conveyor	1/2 HP	3400	1000
Grain Elevator	3/4 HP	4400	1400
Milk Cooler		2900	1100
Milker (Vacuum Pump)	2 HP	10500	2800
FARM DUTY MOTORS	1/3 HP	1720	720
Std. (e.g. Conveyors,	1/2 HP	2575	975
Feed Augers, Air	3/4 HP	4500	1400
Compressors)	1 HP	6100	1600
	1-1/2 HP	8200	2200
	2 HP	10550	2850
	3 HP	15900	3900
	5 HP	23300	6800
High Torque (e.g. Barn	1-1/2 HP	8100	2000
Cleaners, Silo Unloaders,	5 HP	23300	6000
Silo Hoists, Bunk Feeders)	7-1/2 HP	35000	8000
	10 HP	46700	10700
3-1/2 cu. ft. Mixer	1/2 HP	3300	1000
High Pressure 1.8 Gal/Min	500 PSI	3150	950
Washer 2 gal/min	550 PSI	4500	1400
2 gal/min	700 PSI	6100	1600
Refrigerator or Freezer		3100	800
Shallow Well Pump	1/3 HP	2150	750
	1/2 HP	3100	1000
Sump Pump	1/3 HP	2100	800
	1/2 HP	3200	1050

10-7. Approximate Power Requirements For Contractor Equipment

Contractor	Rating	Starting Watts	Running Watts
Hand Drill	1/4 in	350	350
	3/8 in	400	400
	1/2 in	600	600
Circular Saw	6-1/2 in	500	500
	7-1/4 in	900	900
	8-1/4 in	1400	1400
Table Saw	9 in	4500	1500
	10 in	6300	1800
Band Saw	14 in	2500	1100
Bench Grinder	6 in	1720	720
	8 in	3900	1400
	10 in	5200	1600
Air Compressor	1/2 HP	3000	1000
	1 HP	6000	1500
	1-1/2 HP	8200	2200
	2 HP	10500	2800
Electric Chain Saw	1-1/2 HP, 12 in	1100	1100
	2 HP, 14 in	1100	1100
Electric Trimmer	Standard 9 in	350	350
	Heavy Duty 12 in	500	500
Electric Cultivator	1/3 HP	2100	700
Elec. Hedge Trimmer	18 in	400	400
Flood Lights	HID	125	100
	Metal Halide	313	250
	Mercury	1000	
	Sodium	1400	
Submersible Pump	Vapor	1250	1000
	400 gph	600	200
Centrifugal Pump	900 gph	900	500
Floor Polisher	3/4 HP, 16 in	4500	1400
	1 HP, 20 in	6100	1600
High Pressure Washer	1/2 HP	3150	950
	3/4 HP	4500	1400
	1 HP	6100	1600
55 gal Drum Mixer	1/4 HP	1900	700
Wet & Dry Vac	1.7 HP	900	900
	2-1/2 HP	1300	1300

10-8. Power Required To Start Motor



- 1 Motor Start Code
- 2 Running Amperage
- 3 Motor HP
- 4 Motor Voltage

To find starting amperage:

Step 1: Find code and use table to find kVA/HP. If code is not listed, multiply running amperage by six to find starting amperage.

Step 2: Find Motor HP and Volts.

Step 3: Determine starting amperage (see example).

Welding generator amperage output must be at least twice the motor's running amperage.

Single-Phase Induction Motor Starting Requirements

Motor Start Code	G	H	J	K	L	M	N	P
KVA/HP	6.3	7.1	8.0	9.0	10.0	11.2	12.5	14.0

$$\frac{\text{kVA/HP} \times \text{HP} \times 1000}{\text{VOLTS}} = \text{STARTING AMPERAGE}$$


EXAMPLE: Calculate the starting amperage required for a 230 V, 1/4 HP motor with a motor start code of M.

Volts = 230 HP = 1/4 Using Table, Code M results in kVA/HP = 11.2

$$\frac{11.2 \times 1/4 \times 1000}{230} = 12.2 \text{ A} \quad \text{Starting the motor requires 12.2 amperes.}$$

S-0624

10-9. How Much Power Can Generator Supply?



- 1 Limit Load To 90% Of Generator Output

Always start non-resistive (motor) loads in order from largest to smallest, and add resistive loads last.

- 2 5 Second Rule

If motor does not start within 5 seconds, turn off power to prevent motor damage. Motor requires more power than generator can supply.

Ref. ST-800 396-A / S-0625

10-11. Selecting Extension Cord (Use Shortest Cord Possible)



Cord Lengths for 120 Volt Loads

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

Current (Amperes)	Load (Watts)	Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)*					
		4	6	8	10	12	14
5	600			350 (106)	225 (68)	137 (42)	100 (30)
7	840		400 (122)	250 (76)	150 (46)	100 (30)	62 (19)
10	1200	400 (122)	275 (84)	175 (53)	112 (34)	62 (19)	50 (15)
15	1800	300 (91)	175 (53)	112 (34)	75 (23)	37 (11)	30 (9)
20	2400	225 (68)	137 (42)	87 (26)	50 (15)	30 (9)	
25	3000	175 (53)	112 (34)	62 (19)	37 (11)		
30	3600	150 (46)	87 (26)	50 (15)	37 (11)		
35	4200	125 (38)	75 (23)	50 (15)			
40	4800	112 (34)	62 (19)	37 (11)			
45	5400	100 (30)	62 (19)				
50	6000	87 (26)	50 (15)				

*Conductor size is based on maximum 2% voltage drop

Cord Lengths for 240 Volt Loads

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

Current (Amperes)	Load (Watts)	Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)*					
		4	6	8	10	12	14
5	1200			700 (213)	450 (137)	225 (84)	200 (61)
7	1680		800 (244)	500 (152)	300 (91)	200 (61)	125 (38)
10	2400	800 (244)	550 (168)	350 (107)	225 (69)	125 (38)	100 (31)
15	3600	600 (183)	350 (107)	225 (69)	150 (46)	75 (23)	60 (18)
20	4800	450 (137)	275 (84)	175 (53)	100 (31)	60 (18)	
25	6000	350 (107)	225 (69)	125 (38)	75 (23)		
30	7000	300 (91)	175 (53)	100 (31)	75 (23)		
35	8400	250 (76)	150 (46)	100 (31)			
40	9600	225 (69)	125 (38)	75 (23)			
45	10,800	200 (61)	125 (38)				
50	12,000	175 (53)	100 (31)				

*Conductor size is based on maximum 2% voltage drop

SECTION 11 – PARTS LIST





Figure 11-1. Main Assembly



Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 11-1. Main Assembly				
1		Fig 11-2	PANEL, front w/components	1
2		Fig 11-4	CONTROL BOX	1
3		087 341	BUMPER, door 1.000 OD x .750 high rbr	6
4		010 083	HANGER, minerallic No. 6	1
5		026 947	STAND-OFF, insul .250-20 x 1.000 lg	3
		025 248	STAND-OFF, insul .250-20 x 1.250 lg	2
6		118 640	UPRIGHT, front	1
		121 699	SPACER, cover	3
7	Z1	117 270	REACTOR, AC	1
8		131 188	FRAME, mtg reactor	1
9	R3	128 862	RESISTOR, WW adj 375W 50 ohm w/mtg bracket	1
		089 533	BAND, resistor	1
10		118 643	UPRIGHT, center	1
11		017 479	SEAL, weather lift eye	2
12		108 081	TERMINAL PROTECTOR, battery post mtg	2
13		032 453	CABLE, bat neg	1
14		208 353	HOLD DOWN, battery	1
15	BAT	190 896	BATTERY, stor 12 V 650 crk 110 rsv gp 24 low maint	1
16		182 276	CABLE, bat pos	1
17		010 460	STUD, stl .312-18 x 10.000	1
18	CR2	090 104	RELAY, encl 12VDC SPST	1
19		601 851	NUT, stl slflkg hex .625-18	4
20		145 023	BRACKET, mtg strip terminal	1
21	TE4	038 621	BLOCK, term 30A 4P	1
		038 620	LINK, jumper term blk 30A	2
22		145 035	INSULATOR, strip term	1
23		170 550	PANEL, side LH	1
24		+131 688	COVER, top	1
		057 359	BLANK,snap-in nylon .375	4
		190 847	PLUG, protective 3.500 rd cover	1
25		117 486	PIPE, exhaust	1
26		118 073	CAP, rain 3.000 ID	1
27		108 487	LABEL, warning falling equipment can cause serious injury	2
		+131 752	PANEL, engine LH	1
		168 385	LABEL, warning battery explosion can blind	1
28		131 186	PANEL, end engine	1
29		004 130	BRACKET, support door	1
30		147 923	LABEL, warning do not run engine when door is open	2
31		+131 222	DOOR, side	1
		120 629	LABEL, diesel engine maintenance	1
32		119 861	LATCH, paddle series 300 w/lock	1
33		193 050	PANEL, rocker	1
34		170 549	PANEL, side RH	1
35		133 067	HOSE, elb air cleaner	1
36		010 863	CLAMP, hose 2.062-3.000clp dia slftng	4
37	S11	118 067	SWITCH, vacuum air flow elect indicator 12-24VDC	1
38		089 129	PIPE, air cleaner	1
39		133 066	HOSE, elb air cleaner	1
40		045 657	AIR CLEANER, intake (consisting of)	1
		046 544	PRECLEANER	1
41		021 115	BAND, mtg air cleaner	1
42		021 114	CLAMP ASSEMBLY, cup air cleaner	1
43		*020 319	ELEMENT, air cleaner	1
44		021 117	WING NUT ASSEMBLY	1
45		021 116	CAP, dust air cleaner	1
		004 115	BAFFLE, dust cap	1
46		023 313	CLAMP, hose 3.000-3.250clp dia slftng	1
47		601 945	SCREW, cap stl hexhd .625-18 x 4.000	4

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 11-1. Main Assembly (Continued)				
48		071 731	WASHER, flat stl .656 ID x 2.250 OD x .187thk	4
49		116 707	SUPPORT, front engine	1
50		602 246	WASHER, flat stl std .500	4
51		071 730	TUBING, stl .875 OD x 12ga wall x 2.375	4
52		071 890	RETAINER, mount eng/gen	4
53		130 435	ENGINE, deutz dsl elec (consisting of)	1
54		066 271	V-BELT	1
		131 208	STOP, throttle	1
		010 014	CLAMP, stl cush .750dia x .203mtg hole	2
		010 021	CLAMP, stl cush .562dia x .343mtg hole (ground load support)	1
		602 247	WASHER, flat stl sae .500	1
55		159 013	FITTING, pipe stl elbow M 1/2tbg x .500NPT	1
56		159 012	HOSE, oil drain 11.000 3/4 swivel fem 1/2MNPT	1
57		118 452	FITTING, adapter oil drain	1
58		034 116	CLAMP, stl cush .625dia x .468mtg hole	2
59		131 322	SHUTDOWN KIT, rsv type governor	1
60		Fig 11-5	GENERATOR	1
61		166 805	BAFFLE, air manifold exhaust	1
62		132 712	PIPE, muffler extension elb 1.875 OD	1
63		119 797	BAFFLE, air manifold exhaust	1
64		089 351	FITTING, pipe brs plug hexhd 1/2NPT	1
65		134 835	HOSE, SAE .312 ID x .560 OD (order by ft)	11ft
66		172 071	CLAMP, hose .520-.605clp dia slftng	7
67		145 282	FITTING, hose brs barbed elb M 5/16tbg x 1/4NPT	2
68		117 227	BRACKET, mtg fuel filter	1
69		192 744	FILTER, fuel spin-on	1
70		206 297	BASE, fuel filter assy	1
71		092 434	SCREW, stl hexhd .625-11 x 1.250	4
72		039 599	FITTING, brs barbed M 5/16tbg x 1/4NPT	2
73		119 486	TUBE, pick-up fuel	2
74		601 965	SCREW, cap stl hexwhd slflkg .375-16 x 1.000	4
75		+159 014	BASE, (consisting of)	1
76		602 887	FITTING, pipe brs plug hexhd 1/4NPT	1
77		131 189	PANEL, firewall	1
78		131 127	BRACKET, rect RH	1
79	SR3	142 505	RECTIFIER, si 0ph 300A 400PIV	3
80		010 494	BUSHING, snap-in nyl 1.375 ID x 1.750mtg hole	1
81		116 981	BRACKET, rect LH	1
82		131 124	SHIELD, heat lower RH	1
83		131 125	SHIELD, heat lower LH	1
84		131 123	SHIELD, heat upper	1
85	SHUNT	072 426	SHUNT, meter 50MV 1000A	1
86		Deleted		
87		122 354	GUARD, splash fuel	1
88		107 343	GROMMET, rbr neck filter fuel	1
89		024 035	CAP, tank fuel 2 in IPT	1
89		◆134 234	CAP, flame arrestor tank fuel	1
90		Fig 11-3	PANEL, front lower w/components	1
92		134 792	LABEL, warning general precautionary	1
93		+127 304	DOOR, front lower	1
94		602 213	WASHER, lock stl split .375	4
95		601 872	NUT, stl hex jam .375-16	4
96		121 823	LABEL, warning do not lift from this end	1
97		146 358	SENDER, fuel gauge	1
98		167 298	VENT, fuel tank	1

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 11-1. Main Assembly (Continued)


99		118 790	ANGLE, strain relief	1
		089 256	CLAMP, stl cush 1.750dia x .531mtg hole	1
		137 610	BUS BAR, neg term to rectifier	1
		131 243	BUS BAR, pos term to rectifier	1
		131 750	BUS BAR, shunt	1
100		165 785	HOSE, air cleaner 2.500 id	1


+When ordering a component originally displaying a precautionary label, the label should also be ordered.

*Recommended Spare Parts.

◆ Part of 042 185 Optional FA-4 Flame Arrestor – Strainer Fuel Cap.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

 Hardware is common and not available unless listed.



ST-134 500-A


Figure 11-2. Panel, Front w/Components

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 11-2. Panel, Front w/Components (Fig 11-1 Item 1)				
... 1	S3	131 213	SWITCH, range/changeover	1
... 2		118 340	PANEL, front upper	1
... 3	R1	072 462	POTENTIOMETER, w/shaft lock (consisting of)	1
... 4		072 590	LOCK, shaft pot .375-32 x .250dia shaft	1
... 5		Deleted		
... 6	S4,5	011 609	SWITCH, tgl SPDT 15A 125VAC	2
... 7	S6	011 611	SWITCH, tgl DPDT 15A 125V	1
... 8	S1	176 606	SWITCH, ignition 4 posn w/out handle	1
... 9			PLATE, ident control rating (order by model and serial number)	1
... 10		021 385	BOOT, tgl switch lever	3
... 11		119 014	LEVER, switch	1
... 12	FG	118 066	GAUGE, fuel elec 12V neg grd	1
... 13	A1	118 060	METER, amp DC 60-0-60 2.250dia	1
... 14		129 870	GAUGE, pressure oil 25-30 PSI preset	1
		128 829	KIT, oil line 44.000 in 1/8NPT x 10mm	1
... 15		129 837	GAUGE/SWITCH, temp oil mech 250deg setting	1
... 16	HM	118 058	METER, hour 12-24VDC 2.250dia	1
... 17		082 788	HOLDER, light ind only bayonet base	2
... 18	PL1,3	*048 155	BULB, incand flg base 12V	2
... 19		082 789	LENS, light ind red	2
... 20		097 926	KNOB, pointer	1
... 21		010 647	PIN, spring CS .156 x 1.250	1
... 22		090 231	HANDLE, switch range	1
... 23	A2	164 875	METER, amp DC 50MV 0-1K scale 2.5 in	1
... 24	V1	164 872	METER, volt DC 0-100 scale 2.5 in	1
... 25			NAMEPLATE, (order by model and serial number)	1
... 26		022 289	TUBING, stl .312 OD x .187 ID x .437 lg	2
... 27		202 209	SPACER, nylon	3

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.



ST-134 501-B

Figure 11-3. Panel, Front Lower w/Components

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 11-3. Panel, Front Lower w/Components (Fig 11-1 Item 90)				
...	1	038 612	.. TERMINAL ASSEMBLY, pwr output (consisting of)	2
...	2	601 840	.. NUT, brs hex .500-13 jam	4
...	3	601 839	.. NUT, brs hex .500-13 full	2
...	4	038 847	.. BUS BAR, term pwr output	1
...	5	Neg/Pos .. 038 613	.. TERMINAL BOARD, pwr output	1
...	6	038 900	.. STUD, brs .500-13 x 2.250	2
...	7	602 247	.. WASHER, flat stl SAE .500	2
...	8	605 787	.. WASHER, lock stl intl tooth .500	2
...		601 976	.. SCREW, cap stl hexhd .500-13 x 1.500 (bus bar to terminal)	2
...		044 942	.. NUT, locking .500-13 (bus bar to terminal)	2
...	9	C1,2 .. 136 736	.. CAPACITOR	2
...	10	131 122	.. PANEL, front lower	1
...	11	CB1,2 .. +139 266	.. CIRCUIT BREAKER, man reset 1P 15A 250VAC	2
...	12	GFCI1, GFCI2 .. 151 981	.. RECEPTACLE, str dx grd 2p3w 15/20a 125v *5-15r gfi modified	2
...		073 690	.. PLUG, str grd armd 2P3W 15A 125V Arrow Hart 5965V	
...		RC1 .. ♦604 103	.. RECEPTACLE, str dx grd 2P3W 15A 250V	1
...		025 234	.. PLUG, str grd 2P3W 15A 250V Arrow Hart 5666V	
...	13	VR1/R4 .. 046 819	.. SUPPRESSOR	1
...	14	RC3 .. 143 976	.. CONNECTOR w/SOCKETS, (consisting of)	1
...		079 534	.. CONNECTOR, circ skt push-in 14-18ga Amp 66358-6	14
...		134 734	.. CONNECTOR, circ 14 pin plug Amp 213571-2	
...		134 731	.. CONNECTOR, circ pin push-in 14-18ga Amp 213603-1	
...		079 739	.. CONNECTOR, circ clamp str rlf sz 17-20 Amp 206322-2 or	
...		143 922	.. CONNECTOR, circ clamp str rlf sz 17-20 Amp 206070-3	
...	15	020 279	.. CLAMP, stl cush .750dia x .281mtg hole	1
...	16	CB3,4 .. 083 432	.. CIRCUIT BREAKER, man reset 1P 10A 250V	2
...	17	C3 .. 113 142	.. CAPACITOR	1
...	18	C4-11 .. 138 695	.. CAPACITOR	8
...	19	3T .. 038 601	.. BLOCK, term 30A 9P	1
...	20	083 030	.. STUD, brs grd .250-20 x 1.750	1
...	21	010 915	.. WASHER, flat brs .250 ID x .625 OD x .031thk	5
...	22	601 836	.. NUT, brs hex .250-20 jam hvy	3
...	23	010 916	.. CONNECTOR, clamp cable .750	1
...	24		.. PLATE, ident control rating lower (order by model and serial number)	1
...	25	170 391	.. CONNECTOR, circ protective cap	1

+Circuit Breakers (CB1,2) and Receptacle (RC2) remain the same for 042 943 Optional Duplex Receptacle Kit 240V.


♦Part of 042 943 Optional Duplex Receptacle Kit 240V.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 11-4. Control Box (Fig 11-1 Item 2)

...	1	2T	129 939	BLOCK, term 10A 19P	1
...	2		187 013	ENCLOSURE, control box	1
...	3	CR1	052 603	RELAY, encl 110VDC DPDT 10A 120VAC 8 pin flange mtg	1
...	4		020 225	CLAMP, nyl .875 clamp dia x .500 wide	1
...	5	MS1	118 072	SWITCH, magnetic shutdown 12VDC (consisting of)	1
...		F	*048 317	FUSE, mintr gl 14A 32V	1
...	6		122 216	CONNECTOR, blk 15A	2
...	7	1T	098 828	BLOCK, term 10A 10P	1
...	8	SR1	035 704	RECTIFIER, integ 40A 800V	1
...	9	D1, D9	189 701	DIODE/CAPACITOR BOARD	2
...	10	PC2	145 207	CIRCUIT CARD, voltage regulator	1
...		PLG2	115 092	CONNECTOR & SOCKETS, (consisting of)	1
...			113 746	CONNECTOR, rect skt 24-18ga Molex 39-00-0038	8
...	11		134 201	STAND-OFF SUPPORT, PC card	8
...	12	PC1	166 203	CIRCUIT CARD, field current regulator	1
...		PLG1	135 275	CONNECTOR & SOCKETS, (consisting of)	1
...			114 066	CONNECTOR, rect skt 20-14ga Amp 350536-1	15
...	13		603 107	HOSE, nprn slit bk .156 ID x .343 OD (order by ft)	1ft
...	14	SR2	097 353	DIODE/SCR, bridge integ 2SCR 3 diodes	1
...	15		172 731	HOLDER, fuse mintr .250 x 1.250 clip anti-pivot	1
...	16	F6	073 426	FUSE, mintr gl slo-blo 5A 250V	1
...	17	CR6	173 069	RELAY, encl 12VDC SPDT 30A/20A 5 pin flange mtg	1



ST-134 502-B

Figure 11-4. Control Box


*Recommended Spare Parts.


To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

Item No.	Part No.	Description	Quantity
----------	----------	-------------	----------

Figure 11-5. Generator (Fig 11-1 Item 60)

...	1	...	*151 299	.. BRUSH, contact elect clrg .375 x .750	1
...	2	...	188 387	.. BRUSHHOLDER/BACKET ASSEMBLY (consisting of)	1
...	3	...	173 066	.. BRACKET, mtg brushholder	1
...	4	...	600 270	.. HOLDER, brush	1
...	5	...	152 044	.. CAP, holder brush brs	1
...	6	...	013 367	.. LABEL, warning moving parts can cause serious injury	2
...	7	...	+140 096	.. STATOR, gen (consisting of)	1
...	8	...	039 207	.. BAFFLE, air gen	1
...	9	...	083 751	.. ROTOR, gen (consisting of)	1
...	10	...	024 617	.. RING, retaining ext 1.272 shaft x .050thk	1
...	11	...	053 390	.. BEARING, ball rdl sgl row 1.370 x 2.830 x .600	1
...	12	...	083 748	.. FAN, rotor gen	1
...	13	...	180 684	.. STATOR, exciter	1
...	14	...	601 965	.. SCREW, cap stl hexwhd slflkg .375-16 x 1.000	6
...	15	...	173 068	.. ENDBELL, (consisting of)	1
...	16	...	143 220	.. O-RING, 2.859 ID x .139CS	1

 Hardware is common and not available unless listed.



ST-134 503-E

Figure 11-5. Generator

*Recommended Spare Parts.

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

TRUE BLUE® WARRANTY

Effective January 1, 2002

(Equipment with a serial number preface of "LC" or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

Warranty Questions?

Call
1-800-4-A-MILLER
for your local
Miller distributor.

Your distributor also gives
you ...

Service

You always get the fast,
reliable response you
need. Most replacement
parts can be in your
hands in 24 hours.

Support

Need fast answers to the
tough welding questions?
Contact your distributor.
The expertise of the
distributor and Miller is
there to help you, every
step of the way.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor or eighteen months after the equipment is sent to an International distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original main power rectifiers
 - * Inverters (input and output rectifiers only)
2. 3 Years — Parts and Labor
 - * Transformer/Rectifier Power Sources
 - * Plasma Arc Cutting Power Sources
 - * Semi-Automatic and Automatic Wire Feeders
 - * Inverter Power Supplies
 - * Intelligig
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
3. 1 Year — Parts and Labor Unless Specified
 - * DS-2 Wire Feeder
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * Process Controllers
 - * Positioners and Controllers
 - * Automatic Motion Devices
 - * RFCS Foot Controls
 - * Induction Heating Power Sources
 - * Water Coolant Systems
 - * Flowgauge and Flowmeter Regulators (No Labor)
 - * HF Units
 - * Grids
 - * Maxstar 85, 140
 - * Spot Welders
 - * Load Banks
 - * Racks
 - * Running Gear/Trailers
 - * Plasma Cutting Torches (except APT & SAF Models)
 - * Field Options
(NOTE: Field options are covered under True Blue® for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
4. 6 Months — Batteries
5. 90 Days — Parts
 - * MIG Guns/TIG Torches
 - * Induction Heating Coils and Blankets

- * APT, ZIPCUT & PLAZCUT Model Plasma Cutting Torches
- * Remote Controls
- * Accessory Kits
- * Replacement Parts (No labor)
- * Spoolmate Spoolguns
- * Canvas Covers

Miller's True Blue® Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear. (Exception: brushes, slip rings, and relays are covered on Bobcat, Trailblazer, and Legend models.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.





Owner's Record

Please complete and retain with your personal records.

Model Name	Serial/Style Number
------------	---------------------

Purchase Date	(Date which equipment was delivered to original customer.)
---------------	--

Distributor

Address

City

State	Zip
-------	-----



For Service

Call 1-800-4-A-Miller or see our website at www.MillerWelds.com to locate a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

- Welding Supplies and Consumables
- Options and Accessories
- Personal Safety Equipment
- Service and Repair
- Replacement Parts
- Training (Schools, Videos, Books)
- Technical Manuals (Servicing Information and Parts)
- Circuit Diagrams
- Welding Process Handbooks

Contact the Delivering Carrier for:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

Miller Electric Mfg. Co.

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

European Headquarters – United Kingdom

Phone: 44 (0) 1204-593493
FAX: 44 (0) 1204-598066

www.MillerWelds.com

