DIGITAL COLOR PRINTER

MODE

CP-C60DW-WE

OPERATION MANUAL



THIS OPERATION MANUAL IS IMPORTANT TO YOU.

PLEASE READ IT BEFORE USING YOUR DIGITAL COLOR PRINTER.



DIGITAL COLOR PRINTER

Hereby, Mitsubishi Electric Corporation, declares that this digital color printer is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.



INFORMATION

This Class A digital apparatus complies with Canadian ICES-003.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

WARNING:

Use the included AC power cord so as not to interfere with radio and television reception. If you use other cables, it may cause interference with radio and television reception.



CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute the risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



The "Caution, hot surface" symbol indicates that the marked item may be hot and should not be touched.



The "Electro Static Discharge (ESD) warning" symbol indicates that trouble (including equipment malfunction) due to static electricity may occur in certain conditions.



The "OFF/ON" symbol indicates connection to or disconnection from the mains, at least for mains switches.



The "Alternating current" symbol indicates that the equipment is suitable for alternating current only.

CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his or her own expense.


This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WARNING:

In the USA or Canada, use the AC power cord according to the recommendations as below, in order to comply with UL60950-1 and CAN/CSA C22.2 No. 60950-1-03. Connect to the 120 V receptacle of the room or the host equipment.

The AC power cord should be UL or CSA approved and consist of type SVT, size 16 or 18AWG, length 2 m or shorter cord with IEC60320-1/C13 type, 125 V 10 A or higher rating connector and NEMA 5-15 type, 125 V 10 A or higher rating plug. Use the AC power cord as specified above, so as not to interfere with radio and television reception.



If you use other cables, it may cause interference with radio and television reception.

WARNING:


In Europe, use the AC power cord according to the recommendations as below, in order to comply with EN60950-1.

Connect to the 230 V receptacle of the room or the host equipment.

The AC power cord should be VDE approved and consist of core size 0.75 mm² or bigger, length 2 m or shorter cord with IEC60320-1/C13 type, 250 V 10 A or higher rating connector and CEE(7)VII type, 250 V 10 A or higher rating plug.

Use the AC power cord as specified above, so as not to interfere with radio and television reception.

If you use other cables, it may cause interference with radio and television reception.





WARNING:

The socket outlet shall be installed near the equipment and shall be easily accessible.

Note: This symbol mark is for EU countries only.

This symbol mark is according to the directive 2002/96/EC Article 10 Information for users and Annex IV, and/or to the directive 2006/66/EC Article 20 Information for end-users and Annex II.



Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and/or reused.

This symbol means that electrical and electronic equipment, batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste.

If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concentration. This will be indicated as follows: Hg: mercury (0,0005%), Cd: cadmium (0,002%), Pb: lead (0,004%)

In the European Union there are separate collection systems for used electrical and electronic products, batteries and accumulators.

Please, dispose of this equipment, batteries and accumulators correctly at your local community waste collection/recycling centre.

Please, help us to conserve the environment we live in!



PRECAUTIONS FEATURES

PREPARATION

TROUBLE-SHOOTING

CONTENTS

| Contents | 1 |
|--|--------------------------|
| Safety precautions | 2-4 |
| Unpacking | 5 |
| Features and functions Front panel Side and rear panel | 6 |
| Before operation Printer setup procedure Print paper installation Ink ribbon installation Handling of paper / ink ribbon set Connection with USB data signal equipment | 8 9-10 11-12 13 |
| Error messages and countermeasures Indications on the front panel and countermeasures Overcoming paper jams Repairing a torn ink ribbon Before calling for service Instructions for transportation | 15 16 17 |
| Cleaning | 19-20 |
| Specifications | 21 |

SAFETY PRECAUTIONS

In the interest of safety, please observe the following precautions:

POWER REQUIREMENT

This Digital Color Printer is designed to operate on 120 V AC 50/60 Hz in the U.S.A. and Canada, and 220 V - 240 V AC 50/60 Hz in Europe. Never connect to any outlet or power supply having a different voltage or frequency.

WARNING: THIS APPARATUS MUST BE EARTHED.

PROTECTIVE MEASURES

IF ABNORMALITIES ARISE,

Use of the unit during emission of smoke or abnormal sounds (without adopting countermeasures) is dangerous. In such a case, unplug the power cord from the source outlet immediately, and request maintenance service from the sales dealer.

NEVER INSERT ANY OBJECT INTO THE UNIT

Foreign objects of any kind inserted into this unit constitute a safety hazard and can cause extensive damage.

DO NOT PLACE ANYTHING ON THE DIGITAL COLOR PRINTER

Heavy objects placed on the Digital Color Printer can cause damage or obstruct proper ventilation.

PROTECT THE POWER CORD

Damage to the power cord may cause fire or shock hazard. When unplugging, hold by the plug only and remove carefully.

DO NOT PLACE WATER CONTAINERS ON THE UNIT

Do not place flower vases, and other water-holding containers on the device. If, for some reason, water seeps to the inside of the unit, unplug the power cord from the source outlet, and contact the sales dealer. If used without corrective measures, the unit may be damaged.

"In the interest of safety, avoid handling of liquids near the unit."

DO NOT REMOVE THE CABINET

Touching internal parts is dangerous, besides, it may lead to malfunction. Contact the sales dealer to carry out internal checks and adjustments. Before opening the cover for eliminating a jammed paper, etc., be sure to disconnect the power cord plug.

UNPLUG THE POWER CORD DURING A LONG ABSENCE

Turn off the main power switch and unplug the power cord during a long absence.

WHEN TRANSPORTING THE UNIT

When transporting the unit, remove the ink ribbon and print paper from the unit. See "INSTRUCTIONS FOR TRANSPORTATION" on page 18.

WHEN MOVING THE UNIT

Check that the printing unit is closed firmly. And pay attention not to press the OPEN button accidentally. When the printing unit is not closed firmly or you press the OPEN button accidentally, the printing unit may open. It can cause injury or damage.

BE CAREFUL AROUND PRINT PAPER EXIT SLOT

Don't insert your hand or any material into the paper exit slot during printing.

Do not touch the cutter blade inside the paper exit slot.

Otherwise, your finger will be injured.

DO NOT TOUCH THE THERMAL HEAD EXCEPT WHEN CLEANING

Do not touch the thermal head (located inside the unit) except when cleaning.

They are heated to high temperature and may cause burns or injury when touched.

Also, malfunction caused by static electricity may occur.

WHEN PLACING THE PRINT PAPER, KEEP THE PRINT PAPER UPRIGHT

When you put the print paper sideways on a table, etc., it may roll and fall. This may cause injury.

CONNECTION CABLES

Use the provided power cord.

REMOVE THE PAPER STRIP BIN WHEN OPENING OR CLOSING THE DOOR

When you open or close the door with the paper strip bin installed, the bin may be removed and fall. This may cause injury or damage. Also, the chips generated by margin cut may jam at the paper exit slot.

DO NOT LEAVE THE PRINTING UNIT OPEN

When the printer is moved with the printing unit open, it may cause injury or damage.

CLOSE THE PRINTING UNIT FIRMLY

Take care not to pinch your hand when closing the printing unit. When the printing unit is not closed firmly, it may open during transportation and it may cause injury or damage.

DO NOT PUSH DOWN ON THE PRINTING UNIT OR THE DOOR

If you push down on the printing unit or the door when they are open, this unit may fall and it can cause damage or injury.

INSTALLATION LOCATIONS

MAINTAIN GOOD VENTILATION

Ventilation slots and holes are provided on the rear and both sides of this unit. Place the unit on a hard and level surface and keep a space between the unit and the walls to ensure proper ventilation. When putting the unit on the system rack, take a space between the unit and the back and sides of the rack.

SUITABLE LOCATIONS

Avoid shaky places or hot-springs areas where hydrogen sulfide and acidic ions are likely to be generated.

AVOID PLACES WITH HIGH HUMIDITY AND DUST

Do not place the unit at a high humidity and dusty locations. They can cause extensive damage to this unit. Avoid places where the unit is likely to be exposed to oily fumes and vapors.

AVOID PLACES LIKELY TO BE EXTREMELY HOT

Places exposed to direct sunlight, or near heating appliances can attain extremely high temperatures, which may deform the cabinet, or can become a prime cause of damage.

PLACES THE UNIT ON A HORIZONTAL LEVEL

The unit is likely to be affected if it is placed in slanted conditions or in an unstable places.

PROTECT AGAINST DEW FORMATION

In extremely cold regions, if the unit is moved quickly from an extremely cold place to warmer one, dew is likely to be formed. If dew is formed, printing is not possible.

OPERATING AMBIENT TEMPERATURE RANGE

The operating ambient temperature range is 10°C - 35°C (50°F - 95°F) and the humidity of 30% - 80% RH. When using the unit on the system rack, be sure to keep this ambient temperature inside the rack.

Depending on the internal temperature, it may take some time to start printing.

FOR LONG OPERATING LIFE

UNSUITABLE MATERIALS FOR THE DIGITAL COLOR PRINTER

Coat flaking and deformation are likely to occur if the unit is wiped with chemical dusters, benzine, thinner or any other solvent, if rubber or PVC items are left in contact with the unit for extended duration, or if the unit is sprayed with insecticide.

CARE OF THE CABINET

Unplug and clean with a soft cloth slightly moistened with a mild soap and water solution. Allow to dry completely before operating. Never use petroleum base solutions or abrasive cleaners.

HEAD ABRASION

The thermal head, like the video head, wears out. When it is abraded, it becomes hard to print out fine details of the picture. In such a case, it is necessary to replace the thermal head. Consult with the sales dealer for replacing the head.

CONNECTING DEVICES

Read thoroughly "Operating Precautions" of the instruction booklets for the devices connected with the Digital Color Printer. The power cord must be disconnected after printing is over.

CAUTION ON RELOCATING

When transporting this unit, make sure it is not likely to be subjected to impacts. They can be a prime cause for damage. Further, make sure to disconnect the power cord from the power outlet, and the cables from the connected devices.

OTHER CAUTIONS

- Do not pull out nor touch the print paper until printing is completed. It may degrade the print quality or cause an error.
- Dust or other foreign matter adhering to the print paper or the ink cassette, or deformation resulting from exposure to extremely low or high temperatures could cause loss of color, uneven color or lines, or wrinkles in the print images.
- Clean the thermal head and platen roller to keep good print quality whenever you replace the print paper and ink ribbon.
- Depending on the internal temperature, the printer may stop printing temporarily during printing. (The POWER indicator blinks green.) Please wait for the printer to resume printing. Do not touch the print paper.
- Each time printing is completed, remove the prints. If the prints are not removed, a paper jam may occur.
- Empty the paper strip bin frequently to prevent jamming the strips at the print outlet.
- Do not use the printer in a place where a strong wind blows. Otherwise, the print paper may not be fed properly, resulting in the paper jam.

NOTE:

YOUR UNDERSTANDING IS REQUESTED FOR THE LOSS OF IMAGES IN MEMORY DUE TO THE SUDDEN OCCURRENCE OF A MALFUNCTION.


Cautions to prevent the printer from falling

CAUTION -

Falling this printer due to shock or other reasons may cause injury.

For your safety, make sure to secure the printer by the following procedure when you decide the location of installation of the printer.

- 1. Secure the securing band (supplied) to the printer with the screw (supplied).
- Secure the other side of the securing band to the installation location with the round head wood screw (supplied).



UNPACKING

Take the printer out of the box by the following procedures. Make sure to check the accessories.

Open the printer box from the top and remove the top cushion containing the accessories out of the box.

Remove the protective cardboard and then take the accessories out of the cushion.

2 Carefully pull the printer up and out of the box. Pull the printer straight up as shown in the figure.

- NOTE -

Printer weighs about 14 kg. Handle it with care.


3 Unwrap the packing.


Remove the protective materials for transportation such as protective sheet.

Remove the paper strip bin before carrying the printer. Hold the printer by the front and rear handle as illustrated in the drawing.

- CAUTION -


- Do not carry the printer with the paper strip bin attached and by holding the part under the paper strip bin. The paper strip bin may be removed and fall. It may cause injury or damage.
- When the printing unit is not closed firmly or you press the OPEN button accidentally, the printing unit may open. It can cause injury or damage.





CONTENTS


The accessories items are placed in the top cushion. Check all items are included.



These are contained in the printing unit.

Make sure to remove the protective materials from the ink cassette and paper flanges.

FRONT PANEL



1 PAPER STRIP BIN

Holds the paper strips generated by margin cut. Empty the bin frequently to prevent jamming the strips at the print outlet.

NOTE -

Remove the bin before opening the door. If the door is opened with this bin attached, the printer or this bin may be damaged. Do not remove the bin during printing. It may cause a malfunction.

2 CONNECTOR COVER

Do not open the cover during normal use.

ALARM INDICATOR (△)


This indicator illuminates or blinks when a paper jam occurs or the door is open. See page 15.

PAPER RIBBON INDICATOR (□/%)

When an error concerning the ink ribbon or print paper occurs, this indicator illuminates or blinks. See page 15.

OPENING THE DOOR

Pull out the printing unit by pressing the OPEN button and then pull the knob to open the door.



POWER INDICATOR (①)

When the power is turned on, the indicator illuminates. It normally illuminates green, however, blinks or illuminates orange depending on the printer status. See page 15.

6 PRINT OUTLET

The printed paper comes out here.

OPEN BUTTON (△)

Press to release the printing unit out.

(8) **PRINTING UNIT**


Open to load print paper or ink ribbon. Press the ? OPEN button to release the printing unit.

9 DOOR


Open the door to mount print paper.

PAPER STRIP BIN


Hook and pull up the paper strip bin to attach it firmly. Hold and pull the handle on the lower part of paper strip bin to remove.



SIDE AND REAR PANEL



- ① **POWER SWITCH**Use to switch the power ON and OFF.
- ② POWER SOCKET (AC LINE)
 Use to connect the provided power cord. Insert the cord firmly.



- ③ USB TERMINAL
 Use to connect the USB cable.
 See page 14.
- HANDLE FOR TRANSPORTING When carrying the printer, hold this handle and the front upper part of the printer.

PRINTER SETUP PROCEDURE

Before printing, follow the printer setup listed below.

Install the print paper to this printer.

(See pages 9 to 10.)

Install the ink ribbon to this printer.

(See pages 11 to 12.)

Connect the printer to a personal computer.

(See page 14.)

Make sure to close the printing unit when the setup procedure is completed.

PRECAUTIONS

FEATURES

PRINT PAPER INSTALLATION

When you print images with this unit, make sure to use the dedicated paper.

The applicable roll paper to this unit is as follows.


Paper width: 152 mm, inner diameter of core of roll paper: about 59 mm (default setting)

Paper width: 152 mm, inner diameter of core of roll paper: about 51 mm

Before you use the roll paper having the core with the inner diameter of about 51 mm, make sure to remove the attachments on the paper flanges. Keep the removed attachments. They are necessary when you use the print paper having the core with the inner diameter of about 59 mm.

<How to remove attachment>

- 1. Unlock the attachment by turning the ring (light gray) as shown in the figure.
- 2. Remove the attachment while pinching the latches of the paper flange.
- <How to attach attachment>
 - 1. Attach the attachment while pinching the latches of the paper flange.
 - 2. Lock the attachment by turning the ring (light gray) as shown in the figure.



1 Attach the supplied paper flanges to both sides of the print paper.

When you pinch the latches on the paper flange, the stoppers retract into the shaft. Attach the flanges to the print paper with the stoppers retracted.

Make sure that the flanges are attached to the print paper securely, and release the latches.

- NOTE -


- · Take care not to pinch your fingers.
- Do not remove the sticker on the print paper roll yet.
- Do not loosen the paper roll. Any slack in the print paper may degrade the print quality.

- CAUTION -

- · When placing the print paper, keep the print paper upright.
- When you put the print paper sideways, it may roll and fall. This may cause injury.

NOTE -

 Fingerprints or dust on the paper's surface may degrade print quality and cause paper jams.








INCORRECT

CORRECT

- 2 Press the POWER switch on the side panel to turn on the power.
- After the POWER indicator's color has changed from orange to green, press the OPEN button to release the printing unit out.
- 4 Remove the paper strip bin and then pull the knob to open the door.



POWER switch

OPEN button



Make sure the paper roll is firmly installed.


Do not push down on the printing unit or the door.

If you push down on the printing unit or the door when they are open, this unit may fall and it can cause damage or injury.

NOTE -

- Make sure to turn on the power before installing the print paper. Otherwise, a paper jam may occur.
- Load the paper roll slowly into the unit. If it is dropped along the ditches, the unit or accessories may be damaged.





6 Remove the sticker and insert the print paper between the roller and guide as shown right to feed it. When the buzzer sounds, stop the paper feeding.

Remove the sticker before inserting the print paper between roller and guide. Make sure to insert the paper straight.


Buzzer continues to sound until the printing unit is closed.

NOTE

Keep the rollers clean. Dirt on the rollers may produce poor print quality.

NOTE

- When taking the print paper out, pull it up toward you by holding the paper flanges.
- Make sure to turn on the power before replacing the print paper.
- Make sure to eliminate any slack from the print paper. If you carry out the following steps without eliminating the slack, the print paper may be damaged.
- 7 Close the door.



INK RIBBON INSTALLATION

After installing the print paper, install the ink cassette into this unit.

Before installing the ink cassette into this unit, load the ink ribbon in the ink cassette.

It is recommended to clean the thermal head to keep good print quality when you repla


It is recommended to clean the thermal head to keep good print quality when you replace the print paper and ink ribbon.


NOTE -

- · Place the ink cassette on a flat surface, when loading the ink ribbon.
- Select a place that is free of dust when loading the ink ribbon. Dust or dirt settling on the ink ribbon results in poor print quality.
- · Make sure that the shafts of the ink ribbon fit into the ink cassette firmly.

1 Load the ink ribbon in the ink cassette as shown below.

Make sure to load it in the correct position.





Make sure to set the ink ribbon roller to the ditches firmly. Turn the shaft to eliminate any slack.

2 Place the ink cassette containing the ink ribbon in the position as shown in the illustration.


To insert the ink cassette, align the protrusions on both sides of the cassette with the right and left guides inside the printing unit and slide it in a slanting direction.

Mount the ink cassette to the back firmly by holding the handle.

NOTE -

Do not touch the thermal head.

Fingerprints or dust on the thermal head will degrade the print quality.








Do not touch the thermal head right after printing because it is extremely hot. Otherwise you may get burned or injured.

- NOTE -



Note that the thermal head is quite sensitive to static electricity. When you touch the thermal head while carrying static electricity on your body, the thermal head may be damaged.



3 Push the printing unit to close.

Close the printing unit by pushing the right and left sides of the unit from the front with both hands.

When a new paper is loaded and the printing unit is closed with the power turned on, the paper will be automatically fed and cut.




When closing the printing unit, be careful not to get your hands caught between the printer and the printing unit. Otherwise, you may get injured.

NOTE

- When closing the printing unit, push it until a click is heard.
- If the PAPER RIBBON indicator illuminates when the printing unit is closed, the print paper may have not been installed correctly.
 In this case, open the printing unit to make sure that the print paper has been

in this case, open the printing unit to make sure that the print paper has been installed correctly. Then close the printing unit again.

 When the paper roll is reinstalled more than three times, the print paper may be used up earlier than the ink ribbon.



Installation of the print paper and the ink ribbon is completed.

NOTE

• Make sure to replace the print paper and the ink ribbon simultaneously. A large amount of print paper may remain depending on the used condition.

NOTE

- Empty the paper strip bin frequently to prevent jamming the strips at the print outlet. Whenever you replace the paper and ink ribbon, make sure to throw away the paper strips in the paper strip bin.
- Whenever you replace the print paper and the ink ribbon, clean the thermal head and the platen roller. For the cleaning procedures, see "CLEANING" (on pages 19 and 20).

PRECAUTIONS

HANDLING OF PAPER / INK RIBBON SET

■ BEFORE PRINTING

- · Fingerprints or dust on the paper printing surface may produce poor print quality and cause paper jams.
- When the print paper or ink ribbon is abruptly transferred from a cool place to a hot place, vapor or dew is generated
 on the surface, which causes paper jams or degraded print quality. Leave the print paper in the room to stabilize its
 temperature before use.
- If you repeat the PRINT PAPER INSTALLATION procedure more than the designated number of times, the indicated number of prints may not be made. In addition, if you replace the print paper before it is used up, the indicated number of prints may not be made.

■ AFTER PRINTING

- · If the paper absorbs nonvolatile organic solvents (alcohol, ester, ketone, etc.) the print may be discolored.
- Discoloration of prints is accelerated if the print paper comes into contact with soft vinyl chloride such as transparent tape.
- · Avoid storing prints in direct sunlight or places with high humidity.

■ STORAGE OF PAPER / INK RIBBON SET

- Do not store the print paper and ink ribbon in the container made of soft polyvinyl chloride. They may be discolored because of chemical reaction.
- Store the print paper and ink ribbon out of direct sunlight and away from heating appliances in a cool, dark place where the temperature is 5°C to 30°C and the humidity is 20% to 60% RH.


PRECAUTIONS

CONNECTION WITH USB DATA SIGNAL EQUIPMENT

■ CONNECTING TO PERSONAL COMPUTER (EXAMPLE)

Check that the printer is turned on before connecting procedure.

- 1 Turn on the power of a personal computer.
- 2 Connect the printer and a personal computer with a USB cable.



A USB cable is not supplied with this unit. Use the USB 2.0 certified cable of 2 m or less in length.

NOTE -

Refer to the following website to check the printer information. http://www.MitsubishiElectric.co.jp/vcp/

ERROR MESSAGES AND COUNTERMEASURES

INDICATIONS ON THE FRONT PANEL AND COUNTERMEASURES

If, for some reason, printing is not possible or an error occurs during printing, the indicators on the front panel will illuminate or blink. In this case, follow the procedure described below.

| Ö: Steady on ●: Off Ö | : Blinking |
|-----------------------|------------|
|-----------------------|------------|

| ALARM | PAPER RIBBON | POWER | Causes and Countermeasures | Page |
|---|--|-----------------------|---|---------|
| • | • | Ŭ (Orange) | This printer is in standby mode. Connect a USB cable to the printer when not connected. It may take time that the printer is ready to print images after the image data is sent. | 6 14 |
| \ \\\ ● | • | (Green) | The printing unit is open. Close the printing unit. | 6 |
| $egin{array}{c} egin{array}{c} \egin{array}{c} egin{array}{c} \egin{array}{c} \egin{array}$ | \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | (Green) | A paper jam or a problem concerning the ink ribbon occurs. • Refer to "Overcoming paper jams." | 16 |
| • | • | Ğ ● (Green) | The temperature of the thermal head is too high or too low. • Wait until the indication goes off. When the indicator stops blinking, the printer resumes printing automatically. While the printer is working, do not open the door or turn off the power. | 6 |
| • | \\\\\ \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\ | (Green) | The ink ribbon which is not available to this printer is installed. Replace the ink ribbon with a new one. The actual combination of ink ribbon and print paper is inconsistent with the setting made by the personal computer. Open the printing unit and confirm that the actual combination of ink ribbon and print paper is consistent with the setting made by the personal computer. After checking, close the printing unit. | 11-12 |
| • | Ö | Ŭ′ (Green) | The print paper or ink ribbon is not installed. The print paper or ink ribbon is used up. Install new print paper or ink ribbon. | 9-12 |
| Ö | • | ⊖ (Green) | Other errors | 18 |


When the ALARM or the PAPER RIBBON indicator illuminates or blinks, open the door and carry out the above countermeasures.


OVERCOMING PAPER JAMS

- Press the OPEN button to open the printing unit.

 Make sure that the power is turned on before opening the printing unit.
- 2 Remove the ink cassette.








- 5 Cut off the defective part of the print paper with scissors.
 - NOTE -
 - Make sure to cut off the printed part of the print paper. Failure to do this may result in the ink ribbon sticking to the print paper and being torn.
 - Make sure to clean the thermal head and the platen roller. Refer to "CLEANING" (on pages 19 and 20).
- 6 Remove the print paper.

NOTE -

- Remove the slack from the print paper completely. If the door is closed with the print paper slacked, it may cause a paper jam.
- Install the print paper and the ink cassette with the ink ribbon. (Refer to pages 9-13.)
- 8 Close the door.
- 9 Close the printing unit by pushing it.

REPAIRING A TORN INK RIBBON

- 1 Position the ink cassette with the torn ink ribbon on a flat, clean surface.
- 2 Place a piece of transparent adhesive cellophane tape on the center of the ink ribbon.



- 3 Wind the shaft of the ink ribbon in the direction of the arrow so that the cellophane tape is not seen.
- 4 Install the ink cassette in the printer.

BEFORE CALLING FOR SERVICE

For the following symptoms, check the unit again before calling for service.

| Symptom | Check & Remedy |
|---------------------------------|--|
| The power is not turned on. | Is the power cord plug disconnected from the outlet? → Connect the power cord plug to the outlet firmly. → The protective circuit may be working. Turn off the power and wait for about two minutes. Then turn on the power again. |
| The printing unit doesn't open. | Are you turning off the power during printing procedure? → Turn on the power and then open the printing unit. |
| The image is not printed. | Is the PAPER RIBBON indicator or the ALARM indicator illuminating or blinking? → Refer to "Overcoming paper jams." Is the appropriate size of data sent to this unit? → Make sure that the appropriate size of image data is sent to this unit. Is the print paper or the ink ribbon used up? → Check them. Is the printing unit set firmly? → Set the printing unit firmly. → When the indicators keep illuminating or blinking though the above operations are performed, remove the ink ribbon and print paper and reinstall them. |
| An error can not be resolved. | → Turn off and on the power of the printer with the printing unit set firmly. This printer starts initialization. → Press the switch inside of the hole of the front panel with a thin stick or the like for 5 seconds or more. |

INSTRUCTIONS FOR TRANSPORTATION

When transporting this unit for some reason such as repair, follow the instructions below.

1. Use the original packaging.

The genuine package unit may not endure more than one round trip. If the unit is transported with the package unit more than one round trip, it may not be guaranteed.

Purchase another package unit when transporting this unit again.

Pack the unit with the accessories (ink ribbon and print paper) removed.

2. Close the printing unit firmly.

When closing the printing unit, push it until a click is heard.

- CAUTION -

When the printing unit is not closed firmly or you press the OPEN button accidentally, the printing unit may open. It can cause injury or damage.

3. If the ink ribbon, print paper, or ink cassette can not be taken out, consult with your dealer.

THERMAL HEAD CLEANING

- Press the OPEN button to open the printing unit.
- Take the ink cassette out of the printer.

Preparations

Alcohol (ethyl alcohol, etc.) Soft and clean cloth

When lines appear on the printed images, clean the thermal head. Wipe the head cleaning part (as shown right) carefully with cloth dampened with a

small amount of alcohol.

NOTE -

- Do not damage the thermal head.
- When the poor print quality is not corrected even if the head has been cleaned, replacement of the thermal head may be required. Contact your dealer.

CAUTION -



Thermal head is hot right after printing. Wait until the head cools before cleaning the thermal head.


- NOTE -





The thermal head may be damaged if you touch it while static electricity builds up on your body.

- NOTE -

When you clean the thermal head, make sure not to apply excessive force to the peeling roller on the bottom of the thermal head. When the excessive force is applied to the roller, the roller may be deformed, resulting in deterioration of the printing quality.







Peeling roller

PRECAUTIONS

FEATURES

PREPARATION

TROUBLE-SHOOTING

PLATEN ROLLER CLEANING


Preparations

Alcohol (ethyl alcohol, etc.) Soft and clean cloth

Clean the black part of the roller.


Wipe the black part carefully with cloth dampened with a small amount of alcohol.

Wipe the whole roller by turning it.



PAPER FLANGE CLEANING

Clean the parts that contact the print paper sides as shown right. Wipe the parts carefully with cloth dampened with a small amount of alcohol.



| SPECIFICATIONS | | | | |
|-------------------------|--|--|--|--|
| Class | Digital Color Printer | | | |
| Model | CP-C60DW-WE | | | |
| Printing method | Sublimation Dye Thermal Transfer line print 3-color faces progressive printing (yellow, magenta, and cyan) and surface lamination | | | |
| Print's resolution | 300 x 300 dpi (dpi : dots per inch) | | | |
| Dot resolution | 10x15 (4x6") 1218 x 1864 dots 5x15 (2x6") 2 pieces 1218 x 1864 dots 15x20 (6x8") 1864 x 2422 dots 15x15 (6x6") xxxx x yyyy dots | | | |
| Print size | 10x15 (4x6") 102 x 152 mm (without frame) 5x15 (2x6") 51 x 152 mm (without frame) 15x20 (6x8") 152 x 203 mm (without frame) 15x15 (6x6") 152 x152 mm (without frame) | | | |
| Gradations | 256 (8 bits) for each color | | | |
| Supply method | Automatic | | | |
| Interface | Hi-Speed USB (Ver.2.0) | | | |
| Power supply | 100 - 240 V AC 50/60 Hz | | | |
| Power consumption | 5.5 - 2.4 A | | | |
| Operating conditions | Temperature: 10°C - 35°C Humidity: 30% - 80% RH (no dewing) | | | |
| Installation conditions | Operating attitude : Horizontal ±5° | | | |
| Outside dimensions | 275(W) x 373(D) x 242(H) mm | | | |
| Weight | Approx. 14 kg (excluding accessories) | | | |
| Standard accessories | Power cord (for 230 V), Ink cassette (1), Paper flange (1 set), Quick setup guide (1), Paper strip bin (1), Securing band (1), Screw for securing band (2), Washer(1) | | | |

Print size and outside dimensions show typical value. Design and specifications are subject to change without notice.

MITSUBISHI ELECTRIC EUROPE B.V.

Spanish Branch (Barcelona)

Ctra. de Rubí, 76-80 - Apdo. 420 08190-Sant Cugat del Vallés - (Barcelona) Spain Phone +34 93 565 3154 FAX +34 93 589 4388

German Branch

Gothaer Strasse 8, 40880 Ratingen; Postfach 1548, 40835 Ratingen; Germany Phone +49 (2102) 486-9250 FAX +49 (2102) 486-7320

Please contact the nearest Mitsubishi sales branch to get DOC (Declaration of Conformity) of the EC Directive 1999/5/EC.

Manufactured by Mitsubishi Electric (Malaysia) Sdn. Bhd. PLO 32, Kawasan Perindustrian Senai II, 81400 Senai, Johor Darul Takzim, Malaysia