



OTE



OTE DTR100 Setting-up Guide 4bs-tz0000009-e Rev. 01

DTR100 VHF Transceiver for ATC applications

OTE S.p.A.- Via E. Barsanti 8, 50127 – Firenze, Italy

© OTE S.p.A. 2003

All copyright and industrial rights in this document and in the technical knowledge it contains are owned by OTE and/or the third parties rightfully concerned. No part of this document nor any data herein shall be disclosed, reproduced or used for any purpose whatsoever without the prior written consent of OTE as foreseen by the law. Drawings and specifications are subject to change.

All trademarks and registered trademarks are the property of their respective holders.

This document has been prepared to provide technical information on the product concerned. Whilst care has been taken in compiling the material, no responsibility can be accepted for errors or omissions in the text or in associated diagrams or tables. OTE reserves the right to change specifications, performance or features relevant to the product described without notice. Where this document is furnished in association with a quotation, tender or contract, the specifications, features, performance and availability dates which are relevant to such quotation, tender or contract shall be those specified in the schedule(s), specification(s), statement(s) of compliance or other documents specifically prepared for such purpose and shall not be assumed to be those stated or implied within this document.

Information for the guide user:



Before using the equipment, read all of the instructions contained in the manual and read those relative to safety with special care.



Lue käyttöohjeet ja erityisesti turvallisuuteen liittyvät ohjeet ennen laitteen käyttöä.



Alvorens over te gaan tot het gebruik van het apparaat lees met aandacht al de instructies van het handboek en let vooral op die die de veiligheid betreffen.



Alvorens het apparaat in gebruik te nemen lees alle instructies van het handboek en vooral de voorschriften betreffende de veiligheid.



Avant toute utilisation de l'appareil, lire toutes les indications contenues dans le Manuel et avec une attention particulière celles relatives à la sécurité.



Läs alla instruktioner i denna manual innan ni använder apparaten och då särskilt noggrant de anvisningar som gäller säkerheten.



Læs alle de vejledninger, der er indeholdt i manualen med særlig opmærksomhed på de vejledninger, der vedrører sikkerheden, før apparatet tages i brug.



Vor Gebrauch des Geräts alle in dieser Bedienungsanleitung enthaltenen Anweisungen und Vorschriften lesen.

Den Sicherheitsbestimmungen ist dabei besondere Aufmerksamkeit zu widmen.



Πριν χρησιμοποιήσετε τη συσκευή διαβάστε όλες τις οδηγίες που περιέχονται στο εγχειρίδιο και δώστε ιδιαίτερη προσοχή στις οδηγίες ασφαλείας.



Prima di utilizzare l'apparecchiatura leggere tutte le indicazioni contenute nel manuale e con particolare attenzione quelle relative alla sicurezza.



AVISO

Antes de utilizar el equipo leer todas las instrucciones contenidas en el manual, poniendo particular atención a las de seguridad.



AVISO

Antes de utilizar o aparelho, leia todas as instruções que constam no manual e com muita atenção as instruções relativas à segurança.



ПРЕДУПРЕЖДЕНИЕ

Перед эксплуатацией оборудования внимательно прочитайте инструкции данного руководства, в частности, относящиеся к правилам безопасности

تحذير



قبل إستخدام الأجهزة إنتبه لقراءة جميع الارشادات المحتوية في الكتيب وخاصة بالمعلومات الأمنية.

警告



在使用之前，请你一定要阅读说明手册全文，
并请特别注意阅读“有关安全之重要说明”。

Table of contents

1. GENERAL	3
1.1 PURPOSE OF THIS GUIDE.....	4
1.2 INTRODUCTION.....	4
1.3 DECLARATION OF CE MARK CONFORMANCE	5
1.4 ECO-COMPATIBILITY	5
1.5 GUIDE ORGANISATION	5
1.6 GLOSSARY OF ACRONYMS	6
2. SAFETY	11
2.1 SAFETY RECOMMENDATIONS	11
2.2 ESD	15
2.2.1 ESD precautions.....	15
3. OPERATION	19
3.1 OPERATING STATES AND EQUIPMENT ACCESS POINTS.....	19
3.2 DTR100 CONTROL, INDICATORS AND CONNECTORS.....	20
3.2.1 DTR100 front panel connectors.....	22
3.2.2 DTR100 controls and indicators description.....	23
3.2.3 DTR100 Control Panel operating	25
3.2.3.1 About Baseline.....	31
3.2.4 DTR100 measurements environment.....	31
3.3 FREQUENCY INPUT AND DISPLAY FORMATS.....	32
3.4 START-UP PROCEDURE	33
4. SETTING-UP	37
4.1 INTERFACE CONNECTORS	37
4.1.1 Signal and data.....	37
4.1.2 Power and grounding.....	41
4.1.3 Radio frequency.....	42
4.2 SETTINGS AND ADJUSTMENTS.....	43
4.2.1 E&M line interface settings	43
4.2.2 Equipment adjustments	46
4.2.2.1 Reference oscillator monitoring.....	47

List of figures

Figure 1.1 - DTR100 equipment	3
Figure 3.1 - DTR100 devices	20
Figure 3.2 - DTR100 keyboard menu functional block diagram	26
Figure 3.3 - DTR100 setting environment functional block diagram	27
Figure 4.1 - Signal and data connections	37
Figure 4.2 - Power and grounding connections	41
Figure 4.3 - DTR100 radio frequency connections	42
Figure 4.4 - ALB-M dip-switch bank position	43
Figure 4.5 - E line circuit layout	44
Figure 4.6 - M line circuit layout	45

List of tables

Table 3.1 - DTR100 front side devices description	21
Table 3.2 - DTR100 rear side devices description	21
Table 3.3 - DTR100 Headset/Microphone connector pin function	22
Table 3.4 - DTR100 Test Interface connector pin function	23
Table 3.5 - PS module front panel LEDs layout and meaning	23
Table 3.6 - TX/PA module front panel LEDs layout and meaning	23
Table 3.7 - RX module front panel LEDs layout and meaning	24
Table 3.8 - BB module front panel LEDs layout and meaning	24
Table 3.9 - CP module front panel layout and keyboard meaning	24
Table 3.10 - DTR100 display messages	28
Table 3.11 - DTR100 parameters editing	29
Table 3.12 - DTR100 editable parameters	30
Table 3.13 - Baseline format	31
Table 3.14 - Frequency input and display formats	32
Table 4.1 - TELCO connector pin function for DTR100	38
Table 4.2 - DIAG connector pin function	38
Table 4.3 - DATA connector pin function	38
Table 4.4 - CTRL connector pin function	39
Table 4.5 - ANT connector pin function	39
Table 4.6 - GPS I/F connector pin function	39
Table 4.7 - EXT CLOCK connector pin function	40
Table 4.8 - Service port pin function	40
Table 4.9 - E line settings #1	44
Table 4.10 - E line settings #2	44
Table 4.11 - Setting-up procedure for DTR100	46
Table 4.12 - Reference oscillator monitoring procedure	47

Document history

Title: OTE DTR100 – Setting-up Guide		
Document code: 4bs-tz000009-e		
Date	Variations	Rev.
May 2003	First Issue.	01

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

1 - GENERAL

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

1. GENERAL

This section introduces the DTR100 equipment and the guide itself, by describing their tasks, operating modes and scenarios.

The following figure shows the DTR100 layout.



Figure 1.1 - DTR100 equipment

1.1 PURPOSE OF THIS GUIDE

The purpose of this guide is to provide to operators and technical staff the necessary knowledge of the equipment operating, in order to make possible setting-up activity.

Guide user is supposed to have a good skill in telecommunications and RF basics, to understand the given terms and parameters.

Only trained and qualified personnel may operate the equipment. Non-observance of these conditions and the safety instructions can result in personnel injury or in property damage.

1.2 INTRODUCTION

The **DTR100 multimode VHF transceiver** is a state-of the-art communication unit, specifically designed to operate as radio core part of Air Traffic Control ground stations. It may be regarded as an integrated transmitter and receiver device, since the internal transmit and receive sections operate independently.

Thanks to its DSP-based architecture, software-radio approach, and modular design, it allows for easy update and re-configuration.

The equipment has been designed to fulfil operating requirements in any possible system layout.

In the transmitter section, the equipment has outstanding performances in terms of noise radiation and unwanted emissions. These features, together with the high grade of immunity to external interference of the receiver section, allow for meeting considerable co-siting requirements under EMC-critical equipment arrangement.

DTR100 belongs to the latest OTE's ATC third-generation communication systems family, together with the DR100 (VHF receiver), and DT100 (VHF transmitter).

1.3 DECLARATION OF CE MARK CONFORMANCE

The equipment described in this guide has been designed according the following international standards:

Safety:

- CEI EN 60950 (4th edition - 2000) - Safety of information technology equipment.
- CEI EN 60215 (1997-10) - Safety requirements for radio transmitting equipment.

EMC:

- ETSI 301 489-1 (version 1.4.1 - 2002) - Electromagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic compatibility (EMC) standard for radio equipment and services; Part 1: Common technical requirements.
- ETSI 301 489-22 (version 1.2.1 - 2002) - Electromagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 22: Specific conditions for ground based VHF aeronautical mobile and fixed radio equipment.



Any connected device has to comply with the applicable safety standards.

In addition, all installation activities must be performed in such a way to not compromise or lower the equipment degree safety; this must also be taken in account whenever designing system architecture and choosing installation arrangement.

1.4 ECO-COMPATIBILITY

The equipment described in this guide has been designed and realized by following criteria of eco-compatibility, which are also applied to the manufacturing process.

1.5 GUIDE ORGANISATION

This guide is organized into following sections:

- *Section 1 – General.* Introduces the equipment.
- *Section 2 – Safety.* This section gives to operator all necessary information for a correct and safe use of the equipment.
- *Section 3 – Operation.* This section describes all the aspects related to the normal use of equipment, e.g. showing function of each of the front panels controls and indicators.
- *Section 4 – Setting-up.* This section gives an overview of the DTR100 interfaces and describes step-by-step the procedures for the configuration and adjustments of the equipment.

1.6 GLOSSARY OF ACRONYMS

ACRONYM	MEANING
AC	Alternate Current
AF	Audio Frequency
ALB-M	Analogue Line Barrier Minimal
AM-DSB	Amplitude Modulation _ Double Side Band
ATC	Air Traffic Control
AWG	American Wire Gauge
BB	Baseband
BNC	Bayonet Navy Connector (type of RF connector)
CE	Conformité Européene / Certified Europe
CEI	Comitato Elettrotecnico Internazionale
CEI-EN	CEI-European Norm
CP	Control Panel
CW	Continuous Wave
DC	Direct Current
DIN	Deutsches Institut für Normung
DR100	Digital Receiver, OTE 100 series
DSP	Digital Signal Processing/Processor
DT100	Digital Transmitter, OTE 100 series
DTR100	Digital Transceiver, OTE 100 series
EMC	ElectroMagnetic Compliance
EMI	ElectroMagnetic Interference
EN	European Norm
ERM	Electromagnetic compatibility and Radio spectrum Matters
ESD	ElectroStatic Discharge
ETS	European Telecommunications Standard
ETSI	European Telecommunications Standards Institute
GND	Ground
GNSS	Global Navigation Satellite System
GPS	Global Positioning System/Satellite
HMI	Human-Machine Interface
IEC	International Electrotechnical Committee/Commission
IMC	Interface and Management Card
LCD	Liquid Crystal Display

ACRONYM	MEANING
LED	Light Emitting Diode
N	Navy (type of RF connector)
NC	Normally Close
NO	Normally Open
O&M	Operation and Maintenance
OTE	Officine Toscane Elettromeccaniche
PA	Power Amplifier
ppm	Part Per Million
PS	Power Supply (module)
PTT	Push to Talk
RCB	Radio Control Bus
RF	Radio Frequency
RSSI	Received Signal Strength Indicator
RX	Receiver or Reception
SMA	Sub-Miniature A (type of RF connector)
SQL	Squelch (signaling)
TCXO	Temperature-Compensated Crystal Oscillator
TRX	Transceiver
TTL	Transistor - Transistor Logic
TX	Transmitter or Transmission
UTC	Universal Time Coordinated
VCSS	Voice Communication Switching System
VHF	Very High Frequency
VOLMET	Aviation Weather Broadcasts
VSWR	Voltage Standing Wave Ratio
wrt	with respect to

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

2 - SAFETY

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

2. SAFETY

This section of the guide gives all the instructions and warning for a correct and safe use of the equipment. Operators are strongly recommended to respect given indications; non-observance of these instructions can result in personnel injury or in property damage.

2.1 SAFETY RECOMMENDATIONS

Carefully read all the following cautions and warnings before using the equipment.



WARNING

Do not use the equipment for uses different than those indicated in the guide.



WARNING

For correct use of equipment, refer to the relevant section within this guide.



WARNING

Protect the equipment from rainfalls, sprinkling of water and/or other liquids, and from dust.



WARNING

Do not set any object on equipment.



WARNING

Connect the equipment to the equipment room ground bar through dedicated connection, and not through physical contact with other frames.



WARNING

Do not use the equipment if it is not appropriately grounded or if ground is absent.



WARNING

The electric shock can cause the interruption of the natural breathing. An immediate action is necessary in order to restore breathing. It is therefore necessary that the staff be familiarized with the various methods of artificial breathing and cardiac massage. In case of incidents, caused from high tension, an urgent medical aid is necessary to deal the possible effects of the body poisoning caused from burns. In all the cases, proper medical assistance must be requested. It is necessary to make sure that any person who uses or takes care itself of the maintenance of the equipment having parts under dangerous voltages is able of performing artificial breathing, and it is necessary to instruct the staff on first aid measures in case the need arises.



WARNING

Do not use the equipment if the power cable and/or the power supply outlet are damaged.



WARNING

Do not use the equipment if antenna, and/or antenna cable is damaged.



WARNING

Install the equipment following the instructions given in this guide. The equipment must be installed in such a way complies with the national regulations in effect.



WARNING

Wear protection gloves when handling the equipment.



WARNING

When handling the equipment be sure that all internal modules and cards are safely screwed in their position into the chassis.



WARNING

The equipment weight can cause problems during its handling. Take the necessary precautions, e.g. be assisted by another person if necessary.



WARNING

Position the equipment in such a way as to guarantee its correct aeration as well as safe accessibility to the front side controls, and rear side power supply outlets, RF, signal and data connections.



WARNING

Do not position the equipment standing on its rear side, since this can damage rear panel parts.



WARNING

Carry out the maintenance interventions on the equipment following the instructions given in this guide.



WARNING

Follow all accident prevention standards when carrying out maintenance interventions on the equipment.



WARNING

The equipment includes components containing beryllium oxide (beryllia), substance that can be highly toxic if no precautionary measures are undertaken. Pay attention to the beryllium oxide warning label placed on the relevant module(s), and to beryllium oxide warning within this guide. Relevant module(s) cover must not be removed.



WARNING

Disconnect the power supply before carrying out maintenance interventions on the equipment.



WARNING

The PS module does not fully disconnect the equipment from both AC and DC sources, even when front side switches are in OFF position. Part replacement must take place only once that the external AC breaker has been switched OFF, and/or external DC supply has been disconnected.



WARNING

Use only accessories or replacement parts approved by the manufacturer for the equipment.



WARNING

Only authorized technical personnel may carry out maintenance interventions on the equipment.

OTE S.p.A. VIA BARSANTI, 8

50127 FIRENZE ITALY

TELEPHONE +39 05532811

HELP DESK (Italy only) 800 509590

HELP DESK (International) +39 055328142

FAX +39 0554381232

TELEX +39 570276

E-MAIL helpdesk.mobile@marconiselenia.com

The equipment complies with all product specification and the greatest care is taken by the manufacturer so that user safety, as far as the effects of electromagnetic waves on health are concerned, is guaranteed within the limits established by the international specifications.

2.2 ESD

No ESD precautions have to be taken by the operator in the daily use of the equipment. The equipment is designed and manufactured in such a way to not be sensible to electrostatic discharges.

2.2.1 ESD precautions

The equipment includes many electrostatic-sensitive parts that must be handled at a static-safeguarded working area. Furthermore, they must be arranged in static-safeguarded packages, either in the case of storing, or in the case of shipment.

These recommendations should be followed with the maximum care, especially in the case of modules or board extraction and handling.

A static safeguard area may be intended as:

- Grounded static dissipating wrist-strap that drains static charge from the operator wearing it.
- A work surface covered with or composed of a grounded, static-dissipating material that drains electrical charges from devices placed on the surface.

Work surface should provide a standard-size ESD-safeguard snap suitable for snap-stacking wrist-strap connection. It should be used as a convenient ESD caution, whenever handling modules and boards. These recommendations are to be extended also to activity not strictly performed in close equipment surrounding. If removed, replaced, or located inside workshop, any board should be handled by means of convenient ESD cautions.

WARNING Please note that OTE disclaims any responsibility for problems due to poor ESD protection during activity.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

3 - OPERATION

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

3. OPERATION

The purpose of this section is to describe the operational management of the DTR100, specifically control and indicator devices and operating through the control panel facilities

3.1 OPERATING STATES AND EQUIPMENT ACCESS POINTS

The equipment can be set in two different operating states:

- *ON Line state* if the AF line port, located onto the ALB-M rear panel, is used to manage the AF+signaling connection, e.g. carrying PTT input and the TX and RX balanced audio lines.
- *OFF Line state* if the Headset/Microphone connector, located onto the Control Panel front side, is used to manage the AF+signaling connection, e.g. carrying PTT input and the TX and RX audio. In this operating state, the AF line port located onto the ALB-M rear panel is not enabled, this meaning that the equipment can not provide service to an operator located at a remote position. Although full management of equipment audio facility is possible in OFF Line state (e.g. by Headset), this is the typical operating state to be used for activities performed locally.

Concerning O&M functions, the equipment can be managed from the Control Panel (CP) by using the keyboard. It is intended as an easy and immediate access point.

When performing O&M tasks, it is important to note that all equipment functional parameters can be accessed only in OFF Line state. See next chapters for further details about editable parameters.

3.2 DTR100 CONTROL, INDICATORS AND CONNECTORS

Control and indicator devices are located on the front panel of the equipment. The rear panel is devoted to external signal and power connections, with the exception of indication of signaling from remote.

Here below the figure shows the DTR100 front and rear view and the table gives a description of all DTR100 indicators, switches and connectors.




Table 3.1 - DTR100 front side devices description

Ref	Description	Function
1	LEDs (green, red)	PS module status
2	LEDs (green, red)	TX/PA module status
3	LEDs (green, red)	RX module status
4	LEDs (green, red, yellow)	BB module status
5	LCD Display 2x10 digits	Display on Control Panel
6	Switch	ON/OFF AC switch
7	Switch	ON/OFF DC switch
8	Mini-DIN 8-pin connector	Test connector.
9	RP17	Headset/Microphone connector.
10	Four control keys	Keyboard on Control Panel

Table 3.2 - DTR100 rear side devices description

Ref	Description	Function
11	LEDs (green)	PTT and Squelch status indication
12	RJ45 connector (keyed)	AF line and signaling
13	RJ45 connector (DATA)	Data interface (RS232) connector
14	RJ45 connector (CTRL)	Auxiliary control signals I/O connector
15	RJ45 connector (DIAG)	Remote diagnostic interface connector
16	RJ45 connector (ANT)	Ext. antenna switch interface connector
17	9-pin D-type female	Service port
18	SMA-type female connector	External frequency reference input
19	9-pin D-type male	GPS/GNSS input
20	SMA-type female connector	RX module RF input Low sensitivity
21	SMA-type female connector	RX module RF input High sensitivity
22	a: SMA-type female connector b: N-type female connector c: SMA-type female connector	Connections of internal RF switch
23	N-type female connector	RF output
24	6.3 A fuse (slow blow).	VAC protection
25	Standard IEC 320 connector	AC powering
26	20 A fuse (fast acting).	VDC protection
27	GND connection point	Equipment grounding

Ref	Description	Function
28	Plug-in connector	DC powering

3.2.1 DTR100 front panel connectors

Headset/Microphone connector. It is a RP17 12-pin socket; it is located on the front side of Control Panel module and it is used to connect the headset by AF input/output lines and command signal (PTT and EAR_ON).

Table 3.3 - DTR100 Headset/Microphone connector pin function

Pin	Signal	Function
1	MIC AF - VDC	Microphone input ¹
2	GND	Ground
3	PTT	PTT command (active with low level)
4	GND	Ground
5	GND	Ground
6	N.C.	
7	N.C.	
8	Earphone left	Earphone output (stereo earphone, 32 Ohm impedance)
9	GND	Ground
10	Earphone right	Earphone output (stereo earphone, 32 Ohm impedance)
11	Earphone ON	Speaker muting, when the headset is connected
12	N.C.	

¹ Electrete microphone with 2 KOhm nominal impedance, also brings +2.5 VDC.

Test connector. It is a Mini-DIN 8-pin socket; it is located on the Baseband module front panel and it is used for Global Test Interface.

Table 3.4 - DTR100 Test Interface connector pin function

Pin	Signal	Function
1	GND	Ground
2	TEST_SER_RX	RS232 RX line, used for test purpose
3	10 MHz_monitor	Reference clock accuracy monitoring ²
4	GND	Ground
5	TEST_SER_TX	RS232 TX line, used for test purpose
6	GND	Ground
7	N.C.	
8	N.C.	

3.2.2 DTR100 controls and indicators description

The PS module front panel hosts the following controls and indicators:

Table 3.5 - PS module front panel LEDs layout and meaning

LED	Status	Function
Green	ON	TRX ON, operating correctly
	OFF	TRX OFF
Red	ON	PS alarm
	OFF	Operating correctly
Switch	Status	Function
DC Power	ON	Switches the TRX unit ON
	OFF	Switches the TRX unit OFF
AC Power	ON	Switches the TRX unit ON
	OFF	Switches the TRX unit OFF

WARNING The PS module does not fully disconnect the equipment from both AC and DC sources, even when front side switches are in OFF position. PS module should be removed from the equipment only once that the external breaker has been switched OFF, or external DC supply has been disconnected.

The TX/PA module front panel hosts the following controls and indicators:

Table 3.6 - TX/PA module front panel LEDs layout and meaning

LED	Status	Function
Green	ON	TX/PA carrier ON
	OFF	TX/PA OFF
Red	ON	TX/PA Fault
	OFF	Operating correctly

² This is a 500 KHz signal obtained by dividing the internal 10 MHz reference source.

The RX module front panel hosts the following controls and indicators:

Table 3.7 - RX module front panel LEDs layout and meaning

LED	Status	Function
Green	ON	RX carrier over squelch threshold
	OFF	RX in squelch state
Red	ON	RX fault
	OFF	Operating correctly

The BB module front panel hosts the following controls and indicators:

Table 3.8 - BB module front panel LEDs layout and meaning

LED	Status	Function
Green	ON	Connected to AF line ³
	OFF	Not connected to AF line
Red	ON	BB fault
	OFF	Operating correctly
Yellow	ON	Equipment OFF-LINE
	OFF	Equipment ON-LINE

The CP module front panel hosts the following controls and indicators:


Table 3.9 - CP module front panel layout and keyboard meaning

Key	Function
C	cancel
▲	move up
▼	move down
OK	confirm

³ The BB ACTIVE LED ON indicates whether the equipment is connected and managed by the AF line (e.g it becomes OFF if the unit is set OFF-Line).

3.2.3 DTR100 Control Panel operating

The display allows monitoring and management of DTR100 configuration parameters (e.g. frequency, power output level etc.) through keyboard use. Moreover, it shows the alarms (intended as messages indicating a detected failure) coming from DTR100 modules. Following figure shows an example of messages that can be visualized on the display, and the keys use to browse windows.



(*)For further details on setting environment see related figure.

Figure 3.2 - DTR100 keyboard menu functional block diagram




Figure 3.3 - DTR100 setting environment functional block diagram

The following table shows information that can be monitored on display. Press ▲ or ▼ key to browse the windows.

Table 3.10 - DTR100 display messages

Display message	Description
DTR100 Alarms Present	This is the default window when alarms are present.
AM 25 KHz R. F=118.000 C=000	Default window when no alarms are present. It gives information on current frequency, channel and the indication of OFF Line (L) or ON Line (R) state.
Squelch Thr. -107 dBm	Indication of squelch threshold level, set by operator.
RF Output Pwr. 47.0 dBm	Power output level expressed in dBm
Mod. Depth 90%	Modulation index expressed in percentage.
AF Line IN -10.0 dBm	AF input level to get rated modulation index
AF Line OUT -10.0 dBm	AF output level
TCXO Value 105	Indication of the fine-tuning of 10 MHz local frequency reference expressed in steps.
DTR100 FAULT: T R B A I P	This window appears only when alarms are present. Letters are referred to modules (or cards) that produce an alarm.
DTR100 State: ON LINE	This window appears only when no alarms are present.
RS485 Addr 2	This is the address ID on the RS485 connection routed towards an external controller for remote O&M management
Squelch ENABLED	Indication of squelch state (enabled/disabled)
Offset Type: 0 Offset Index: 0	Indication of carrier offset scheme
Activate Measure	This windows allows activating the measurement environment
Baseline 005.003.002.000	Indication of the Baseline (global software release) of the equipment
RACK TYPE ...Stand Alone	Indication of the equipment assigned type; this may be Main or Standby (2 equipment in redundancy scheme) or Stand Alone (single equipment)

Keyboard use allows handling DTR100 configuration parameters. Instructions for handling are given in following table where an example for setting operating mode is shown.

Table 3.11 - DTR100 parameters editing

	Action	Display message
	Default display (browse ▲ or ▼ key to get it)	AM 25 KHz R. F=132.000 C=000
1	Press OK key ⇨	Login to DTR100?
2	Press OK key ⇨	Password: _ _ _ _ _
3	Select password, pressing keys ⇨	Password: _ _ _ _ _
4	Press ▲ or ▼ key to get the desired function (see editable parameter table) ⇨	Set Oper. Mode? AM 25KHz
5	Press OK key ⇨	New Oper. Mode: AM 25KHz
6	Press ▲ or ▼ key until that it is set the desired operating mode (e.g. AM 8.33) ⇨	New Oper. Mode: AM 8.33KHz
7	Press OK key ⇨	Setting....
8	Waiting for setting ⇨	Set Oper. Mode? AM 8.33KHz
9	To exit, press C key. To modify others parameters repeat from action 4.	

The following table lists all control parameters, detailing the possible values, the default and the step values. In addition, table specified whether the relevant parameter can be accessed in following operating states and equipment access points:

CP-OFF Line indicates the operating by Control Panel in OFF Line conditions.

CP-ON Line indicates the operating by Control Panel in ON Line conditions.

Table 3.12 - DTR100 editable parameters

Parameter	Values	Default	Step	CP-OFF Line	CP-ON Line
Operating mode ⁴	AM-DSB 25 KHz AM-DSB 8.33 KHz AM Data	AM-DSB 25 KHz		●	
Frequency	118 to 136.975 MHz	118 MHz	See note ⁵	●	
Frequency to Channel association	Any frequency onto any channel			●	
Channel Number	0 to 119	0	1	●	
Squelch Thr.	-107 to -44 dBm	-107 dBm	1 dB	●	●
Squelch Enabled/Disabled	Enabled/Disabled	Enabled		●	
Output Power	+40 to +47 dBm	+47dBm	0.5 dB	●	
Modulation Depth	0 to 100%	90%	1	●	●
TCXO value	0 to 255	105	1	●	
DTR100 State	ON LINE/OFF LINE	ON LINE		●	●
Loudsp. Vol.	0 to 15	8	1	●	●
Headph. Vol.	0 to 15	8	1	●	●
Loudsp. OnOff	ON/OFF	OFF		●	●
RS485 Address ⁶	UNASSIGNED to 14 ⁷	2	1	●	
Diag 485 ⁸	0 to 255	48	1	●	
AF Line IN	-30 to +10 dBm	-10 dBm	0.5 dB	●	
AF Line OUT	-30 to +10 dBm	-10 dBm	0.5 dB	●	

⁴ When operating in AM-DSB 8.33 KHz mode, it is necessary to select a frequency that is compatible with 25 KHz spacing before selecting any other operating mode. Otherwise, message "setting failed" is displayed. See also relevant table and example.

⁵ The step is according to the operating mode; if AM-DSB 8.33 mode is selected, step is 8.33 KHz. If any other operating mode is selected, step is 25 KHz.

⁶ Physical ID address on the RS485 multi-drop connection for remote O&M management via DIAG port.

⁷ RS485 address 1 and 15 are reserved and can not be used.

⁸ Logical ID address on the RS485 multi-drop connection for remote O&M management via DIAG port.

3.2.3.1 About Baseline

Baseline is an identification 4-fields number indicating the equipment global release. Although this parameter is factory-configured on the proper value, it may be necessary to edit it during the equipment lifetime, e.g. upon software upgrade of any of the internal module or cards.

Baseline format as following example for **Baseline 5.3.2.0**.

Table 3.13 - Baseline format

Index	Ref.	Definition	Note
Index 1	5	Main baseline index	This number identifies the overall equipment hardware, firmware and software configuration
Index 2	3	Major baseline index	This number identifies the functions of the equipment. Changes to this number imply major changes to the functions of the equipment.
Index 3	2	Minor baseline index	This number identifies the functions of the equipment. Changes to this number imply minor changes to the functions of the equipment.
Index 4	0	Fix baseline index	This number identifies the fixes implemented in the equipment.

3.2.4 DTR100 measurements environment

The ▲ and ▼ keys allow to access to the measurements environment. The following list details the measurements that can be shown on the display. . To exit from measurements environment press **C** key, and the default window appears on the display.

Parameter	Unit	Description
Temperature	°C	Current temperature measured within the TX/PA module
VSWR	-	Current VSWR at the RF output ⁹
RF power output	Watts	Current RF power at the RF output ¹⁰
Modulation depth	%	Current modulation depth applied on the radiated carrier ¹¹
RSSI	dBm	Current receive signal strenght indication ¹²

⁹ Not active when not in transmission.

¹⁰ Not active when not in transmission.

¹¹ Not active when not in transmission.

¹² Not active in transmission.

3.3 FREQUENCY INPUT AND DISPLAY FORMATS

DTR100 can operate both 8.33 and 25 KHz frequency spacing.

According to Eurocontrol specification, the following table describes the association between the frequency to be inserted (and displayed by the system), and the effective operating frequency that is set on the equipment.

Table 3.14 - Frequency input and display formats

Spacing (KHz)	Frequency (MHz)	25 KHz mode format	8.33 KHz mode format
25	132.0000	132.000	132.005
8.33	132.0083	-	132.010
8.33	132.0167	-	132.015
25	132.0250	132.025	132.030
8.33	132.0333	-	132.035
8.33	132.0417	-	132.040
25	132.0500	132.050	132.055
8.33	132.0583	-	132.060
8.33	132.0667	-	132.065
25	132.0750	132.075	132.080
8.33	132.0833	-	132.085
8.33	132.0917	-	132.090
25	132.1000	132.100	132.105

3.4 START-UP PROCEDURE

If the equipment is powered only by AC, please refer to the following steps.

- Set ON the external AC breaker or AC power source.
- Set ON the AC switch on PS module.
- Wait until the equipment booting is completed, and the display shows the default window, with operating mode, frequency, etc. If no alarm is present, operate the equipment.

If the equipment is powered by both AC and backup DC, please refer to the following steps.

- Set ON the external AC breaker or AC power source.
- Set ON the external DC breaker or DC power source.
- Set ON the AC switch on PS module.
- Set ON the DC switch on PS module.
- Wait until the equipment booting is completed, and the display shows the default window, with operating mode, frequency, etc. If no alarm is present, operate the equipment.

Please note that the equipment is not serviceable until the start-up phase is completed.

WARNING Do not turn OFF the AC switch when the equipment is operating with both AC and backup DC.

The equipment is designed to be powered with DC only for backup purposes. In case of AC source lack, the PS module is automatically supplied by the backup DC power source, and equipment reduces the RF power output to + 46 dBm (approx. 40 W CW) max.

To power-down the equipment (if powered by both AC and backup DC), operator must before set OFF the DC and AC switch, and then set OFF the DC and AC breakers or power sources.

It is important to note that any maintenance action on the equipment must be done only after switching OFF the external AC and DC breakers.

WARNING The PS module does not fully disconnect the equipment from both AC and DC sources, even when front side switches are in OFF position. Internal modules and/or parts should be removed from the equipment only once that the external AC and DC breakers have been switched OFF, and/or external supply sources have been disconnected.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

4 - SETTING-UP

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

4. SETTING-UP

The purpose of this section is to provide to technical staff information and references required for the setting-up of the equipment.

The procedure to set-up and align the equipment is given.

WARNING Setting-up are intended to be carried out by qualified technical personnel only.

4.1 INTERFACE CONNECTORS

The interface connectors are located on the equipment rear side. Following chapters details pin function of each connector.

4.1.1 Signal and data

Signal and data connections are located on the rear left side of the equipment as shown in the following figure.




Figure 4.1 - Signal and data connections

TELCO connector. This is a 8-pin RJ45 keyed socket, used to connect the AF input/output lines together with PTT and squelch signaling. AF input and output circuits are designed to interface balanced lines, with 600 ohm nominal impedance. The LED indicators may be used as monitoring of E&M signaling activity.

Table 4.1 - TELCO connector pin function for DTR100

Pin	Signal	Function (AM-DSB)	Function (AM-DATA)
1	M-	Squelch signaling to external	Squelch signaling to ACARS modem
2	M+	Squelch signaling to external	Squelch signaling to ACARS modem
3	AF RX +	RX AF balanced audio output	FSK output to ACARS modem
4	AF RX -	RX AF balanced audio output	FSK output to ACARS modem
5	AF TX +	TX AF balanced audio input	FSK input from ACARS modem
6	AF TX -	TX AF balanced audio input	FSK input from ACARS modem
7	E+	PTT signaling from external	PTT command from ACARS modem
8	E-	PTT signaling from external	PTT command from ACARS modem

DIAG connector. This is a 8-pin RJ45 socket, used to connect the RS485 serial data line towards local controller devices.

Table 4.2 - DIAG connector pin function

Pin	Signal	Function
1	N.C.	
2	N.C.	
3	GND	Ground
4	RS485 +	RS485 O&M data to/from external controller
5	RS485 -	RS485 O&M data to/from external controller
6	GND	Ground
7	N.C.	
8	N.C.	

DATA connector. This 8-pin RJ45 socket allows data link between main and standby unit to support changeover features.

Table 4.3 - DATA connector pin function

Pin	Signal	Function (AM-DSB)	Function (AM-DATA)
1	GND	Ground	Ground
2	RS232 TX	RS232 TX data to other DTR	RS232 TX data to controller
3	GND	Ground	Ground
4	RS232 RX	RS232 RX data from other DTR	RS232 RX data from controller
5	GND	Ground	Ground
6	RTS	RTS signal to other DTR	RTS signal to controller
7	GND	Ground	Ground
8	CTS	CTS signal from other DTR	CTS signal from controller

CTRL connector. This is a 8-pin RJ45 socket, used for additional input and output controls and for the summary alarm output. All the input/output signals are handled by optocouplers.

Table 4.4 - CTRL connector pin function

Pin	Signal	Function
1	N.C.	
2	PTT_resp	PTT activation response output (command wire)
3	PTT_resp_ref	PTT activation response output (return wire)
4	Mute_IN	Receiver muting command input (command wire)
5	Mute_IN_ref	Receiver muting command input (return wire)
6	Alarm	Summary alarm status output (command wire)
7	Alarm_ref	Summary alarm status output (return wire)
8	N.C.	

ANT connector. This is a 8-pin RJ45 socket, used to drive an external device for RF coaxial switch handling. Output signal is handled by optocoupler.

Table 4.5 - ANT connector pin function

Pin	Signal	Function
1	N.C.	
2	N.C.	
3	N.C.	
4	SW_ANT	External RF switch drive (command wire)
5	SW_ANT_ref	External RF switch drive (return wire)
6	N.C.	
7	N.C.	
8	N.C.	

GPS I/F connector. This is a D-type 9-pin male, used for interfacing an external GPS/GNSS device to get UTC absolute time reference in VDL modes¹³.

Table 4.6 - GPS I/F connector pin function

Pin	Signal	Function
1	1 pps	1 pps reference pulse from external GPS/GNSS (TTL)
2	GND	Ground
3	N.C.	
4	RS232 TX	RS232 TX data to external GPS/GNSS
5	RS232 RX	RS232 RX data from external GPS/GNSS
6	GND	Ground
7	N.C.	
8	N.C.	
9	GND	Ground

¹³ Not available in current release.

EXT CLOCK input. This is a SMA-type coaxial female, used to get TTL square-wave 10 MHz high-precision clock signal from an external reference, such as high-stability TCXO, or GPS-slaved reference, etc. It allows for increasing the rated frequency accuracy of the equipment up to the reference one.

Table 4.7 - EXT CLOCK connector pin function

Pin	Signal	Function
Center	Clock	10 MHz reference (TTL)
Shield	GND	Shield

Service port. This is a D-type 9-pin female, used for service tasks and audio recording¹⁴.

Table 4.8 - Service port pin function

Pin	Signal	Function
1	+13.5 VDC	+13.5 VDC from PS module ¹⁵
2	RS485 -	Extension of RCB bus (service purposes only)
3	RS485 +	Extension of RCB bus (service purposes only)
4	REC OUT -	Recording balanced audio output
5	REC OUT +	Recording balanced audio output
6	N.C.	
7	N.C.	
8	LDSPK +	For connection of external loudspeaker ¹⁶
9	LDSPK -	For connection of external loudspeaker ¹⁷

¹⁴ 600 ohm balanced line carrying both TX and RX audio, having an output of -10 dBm \pm 3 dB.

¹⁵ Max. current output 500 mA. This output must be used only to power external accessories recommended by OTE, not suitable to power third-part external devices.

¹⁶ Option not available in current release.

¹⁷ Option not available in current release.

4.1.2 Power and grounding

Power and grounding connections are located on the rear right side of the equipment as shown in the following figure.




Figure 4.2 - Power and grounding connections

VDC plug-in. This is the DC supply input connection point, to be used with crimped-plug wires.

AC main. This is an IEC 320 standard socket for AC powering, provided with fuse receptacle. Use only CE-approved power cord.

GND (screw). This is a M3 screw terminal point for connection of grounding cable, located on the rear side of the equipment motherboard.

WARNING The use of a CE-approved power cord is mandatory.

4.1.3 Radio frequency

Radio frequency connections are located on the middle rear side of the equipment as shown in the following figure.




Figure 4.3 - DTR100 radio frequency connections

RX Low sensitivity input (SMA-female). By this port, the receiver is fed by the normal input, having equipment rated sensitivity features.

RX High sensitivity input (SMA-female). By this port, the receiver is fed by the high-sensitivity input, but it is important to note that this connection bypasses the first RX front-end cell, thus having less protection wrt interfering signals, e.g. radiated carrier from co-located transmitters. This input must be used only when the receiver is connected to an external band-pass filter (e.g. cavity filter).

TX/PA output (N-female). This port is the TX/PA direct radio frequency output.

RF switch connectors. The internal RF switch has a normally-closed SMA port (to be used for the receiver section, by fitting the external coaxial SMA-SMA jumper), and a normally-open SMA port (to be used for the transmitter section, by fitting the external coaxial SMA-N jumper). The switch common port is then available on an N-female port, to be connected to the radiating system (or the filtering device, etc).

By using this layout the equipment fully operates as "transceiver", device, in which the transmitter and receive sections share the same radiating system. As factory-default (see the above figure), the equipment is provided with common TX/RX coaxial port (jumpers present), the normally-closed port is routed to the receiver low-sensitivity input.

4.2 SETTINGS AND ADJUSTMENTS

Following chapters detail necessary information for proper setting-up of the equipment, by defining a step-by-step procedure.

Setting-up is intended as the sequence of alignment and configuration actions that must be performed by operator in order to put the equipment in service.

4.2.1 E&M line interface settings

ALB-M card feature dip-switch banks to match AF line interfacing requirements. Line interfacing adjustments concern E line and M line settings.

To perform the setting, the card must be previously removed from the equipment rear side. Following figure shoes dip-switch bank position onto the card (screening cover removed).




Figure 4.4 - ALB-M dip-switch bank position

WARNING Please follow given indications about ESD prevention cares when handling the card.

E line is used to acquire PTT signaling from TELCO line. The circuit design is based on a current detector; the line polarization can be either due to external or internal voltage, as shown in the figure.




Figure 4.5 - E line circuit layout

In the first case, the presence of an external voltage makes the current flow in the loop; in the second configuration ALB-M powers the line and external equipment closes the loop. The proper configuration can be selected setting contacts 1 to 3 of SW01 according to the table.

Table 4.9 - E line settings #1

Line feed	Dip-Switch							
	1	2	3	4	5	6	7	8
Internal voltage	ON	ON	OFF	X	X	X	X	X
External voltage	OFF	OFF	ON	X	X	X	X	X

When external voltage configuration is used, a voltage from 12 to 48 VDC can be applied to E leads. The applied polarity can be positive or negative. Contacts 5 to 8 of SW01 must be set according to external applied voltage value as from configuration given in table below.

Table 4.10 - E line settings #2

Line feed	Dip-Switch							
	1	2	3	4	5	6	7	8
12V (9V to 18V)	X	X	X	X	ON	X	OFF	OFF
12V (220 Ohm)	X	X	X	X	ON	X	ON	OFF
12V (0 Ohm)	X	X	X	X	ON	X	ON	ON
24V (18V to 36V)	X	X	X	X	OFF	ON	OFF	OFF
48V (36V to 60V)	X	X	X	X	OFF	OFF	OFF	OFF

When internal voltage configuration is used, the voltage applied is +12V. Dip-switches 5 and 6 of SW01 are not relevant; only 7 and 8 can be set. Setting on contact 7 reduces the series resistance of about 70% (from 800 Ohm to 220 Ohm). Setting on contact 8 reduces to zero the series resistance. This setting can be useful when using long cables that have a series resistance not negligible¹⁸.

M line is used to send squelch signaling towards remote device through the TELCO line. The circuit design is based on an electronic switch. The line can be interfaced in either "floating" or "common ground" layout




Figure 4.6 - M line circuit layout

In the first case both leads of M line are related to voltage potentials of the external equipment, and are not referred to ALB-M potentials. In the second case, a dedicated wire for return path is not present, but the current loop is anyway closed through isolated ALB-M ground. In this configuration, isolated ALB-M ground and external equipment ground reference must be at the same potential.

When activated, M line interface makes a short circuit on the loop, making current flow¹⁹.

¹⁸ This setting can be useful when using long cabling having a series resistance not negligible (e.g. a connection of 5 Km with AWG24 wire, 0.205 mm² section, has (84Ohm/Km x 5Km) x 2 = 840 Ohm series resistance).

¹⁹ The current flow takes place independently from the line polarity. The residual voltage is 2.5 V @ 20 mA.

4.2.2 Equipment adjustments

The following procedure lists the operating parameters (e.g. frequency, modulation depth, etc) that must be adjusted according to system layout requirements. In any case, further non-mandatory adjustments (e.g. loudspeaker volume, earphone volume, etc) may be done according to user criteria, referring to section § 3 - Operation.

Any setting-up activity must be done only after than installation has been completed, thus also including the connection to any external device and the alignment of ancillary devices (filters, radiating system, etc). Setting-up is listed in following procedure.

Table 4.11 - Setting-up procedure for DTR100

Step	Action	Expected result
1	Switch ON and wait for the end of boot.	After correct booting, control panel displays shows the default windows.
2	Login ²⁰ .	Setting environment menu is active.
3	Set the equipment OFF Line ²¹ .	Once setting is done, control panel display shows OFF Line indication.
4	Set the operating frequency ²² .	Once setting is done, control panel display shows new operating frequency.
5	Set the operating mode (e.g. AM-25 kHz or AM-8.33 kHz).	Once setting is done, control panel display shows new operating mode.
6	Set the equipment RS485 address ²³ .	Once setting is done, control panel display shows new RS485 address.
7	Set the equipment DIAG485 address ²⁴ .	Once setting is done, control panel display shows new DIAG485 address.
8	Set the RF power output.	Once setting is done, control panel display new RF power level.
9	Set the transmission timeout ²⁵ .	Once setting is done, control panel display new transmission timeout figure.
10	Set the maximum modulation depth ²⁶ .	Once setting is done, control panel display new modulation depth figure.
11	Set the TX audio input level ²⁷ .	Once setting is done, control panel display new TX audio input level.

²⁰ The control panel display browsing is detailed into § 3 - Operation. Please refer to the relevant chapter about how getting the desired editable parameters.

²¹ OFF Line condition is necessary, since many parameters can not be edited when in ON Line.

²² The adjustment of the operating frequency and operating mode must be done in conjunction, refer also to § 3 - Operation for details.

²³ This parameter is used to assign a specific physical ID address on the DIAG port, within the RS485 multi-drop connection to an external controller. If no controller for remote O&M activity is present, this setting is not necessary.

²⁴ This parameter is used to assign a specific logical ID address on the DIAG port, within the RS485 multi-drop connection to an external controller. If no controller for remote O&M activity is present, this setting is not necessary.

²⁵ Transmission timeout sets the maximum elapse of time allowed for transmission. At timeout counter expiring, transmission is shut-down. Short timeout values can affect the equipment service by truncate radiated speech. It is also possible to set the PTT Timeout OFF by setting the relevant parameter to 0, thus allowing for continuous transmission operating. Although this setting is not recommended, it can be required for special application (e.g. VOLMET, etc).

²⁶ Setting of maximum modulation depth is anyway referred to a nominal AF input of -10 dBm. Baseband module internal process operates as compressor/limiter device, avoiding modulation rate to override 95% and causing over-modulation phenomena.

²⁷ It operates a gain or attenuation on the TX AF line coming from the VCSS. It must be set according to the expected nominal AF level of the line.

Step	Action	Expected result
12	Set the RX audio output level ²⁸ .	Once setting is done, control panel display new RX audio output level.
13	Set the squelch threshold ²⁹ .	Once setting is done, control panel display shows new squelch threshold.
14	Set the equipment ON Line ³⁰ .	Once setting is done, control panel display shows ON Line indication.
15	Logout ³¹ .	Quit the setting environment menu.

It is important to note that many of the above parameters do not need to be changed from the default settings for a correct operating, and therefore some of the above steps may be ignored.

In example, default value of squelch threshold is -107 dBm. This value allows for correct operating in standard operating condition, and it is not necessary to change it.

4.2.2.1 Reference oscillator monitoring

This adjustment must be done with the equipment ON. The front side test port has a monitoring facility for the internal 10 MHz reference oscillator that has a rated 1 ppm accuracy. When operating in 25 kHz channel spacing mode 5 ppm accuracy is required; when operating in 8.33 kHz channel spacing mode 1 ppm accuracy is required.

On the TEST port, a TTL-level 500 KHz square-wave signal is available, obtained by dividing the internal reference³². As specified, the counter used for the test must have an internal time base stability better than 0.1 ppm (1×10^{-7}); it is recommended to use a counter provided with internal high-stability oven, or slaved to external reference (e.g GPS).

It is necessary to wire a cabling having on the equipment side a Mini-DIN 8-pin male, and having on the frequency counter side the relevant termination (e.g. BNC coaxial). Cabling should be realized preferably with RF-coaxial cable. The pin 3 of the TEST port must be connected to the central conductor of coaxial, while pins 1, 4 or 6 (corresponding to GND) must be connected to the shield. Once realized the cable, the procedure for monitoring and adjustment is given in the following table.

Table 4.12 - Reference oscillator monitoring procedure

Step	Action	Expected result
1	Connect the cabling to the TEST port and to the counter input port.	Frequency counter displays the 500 KHz signal current frequency.
2	Set the equipment OFF Line.	The equipment is OFF Line.
3	Enter in the display menu the setting environment, and scroll the menu until the window <Set Osc. value> is shown.	Current <Set Osc. value> setting figure is displayed.

²⁸ It operates a gain or attenuation on the RX AF line routed to the VCSS. It must be set according to the nominal AF level expected by the line, or connected device.

²⁹ Wrong setting of the squelch threshold may result in no receiving of weak signals.

³⁰ ON Line is the normal operating condition.

³¹ Logout is mandatory for permanently storing of the edited parameters.

³² The frequency accuracy can be monitored and adjusted even by checking the effective frequency precision of the radiated carrier, e.g. by connecting a radio test set on the transmitter RF output.

4	If the equipment is operating in 25 kHz channel spacing mode, and the frequency reference is less accurate than 5 ppm wrt the 500 KHz signal, proceed adjusting the <Set Osc. value> until the desired accuracy is achieved.	Frequency counter displays the 500 KHz signal adjusted frequency.
5	Alternatively to previous step, if the equipment is operating in 8.33 kHz channel spacing mode, and the frequency reference is less accurate than 1 ppm wrt the 500 KHz signal, proceed adjusting the <Set Osc. value> until the desired accuracy is achieved.	Frequency counter displays the 500 KHz signal adjusted frequency.
6	Set the equipment ON Line and disconnect the counter.	The equipment is ON Line.