

APPLICANT MOTOROLA INC.

FCC ID: IHDP56HR2

INSTRUCTION MANUAL

A representative version of the user's manual follows:



**MOTO™** W259

**User's Guide**




# HELLOMOTO

---

Introducing your new MOTO™ W259 wireless phone! It's an easy-to-use music phone with a sleek design that's sure to get attention.

- **My Phone, My Way** – It's your phone — make it that way. Customize your home screen (page 18) with personal pictures, change wallpapers, and use your favorite song as your ringtone.
- **Connect on So Many Levels** – Whether it's with work or friends, stay connected with voicemail (page 36) and messaging (page 35).
- **Rich Music Experience** – Use the music player (page 38) to set your playlist for your morning commute. Insert an optional memory card into the removable memory card slot to save many more songs! Or, use the FM radio (page 37) to listen to your favorite music or news programs.
- **Convenient Extras** – When you are away from your home or desk, make use of handy tools like Phonebook, Calculator, Alarm Clock, Calendar, and others (page 51).
- **Fun** – When you have a little time to spare, play a game (page 54).

Here's a quick anatomy lesson:




Volume Keys

Smart Key

Charge your battery  
& connect to PC.

External Iconic Display



Center Key

Left Soft Key

Music Key

Send Key

Navigation Key

Microphone

Right Soft Key


FM Radio Key

Power/End Key

Listen to music.  
**Note:** Mini-USB  
headsets are not  
supported.

A few menu basics:


### Home Screen





**1** Press & hold the *power key*  until the display lights up, to turn on your phone.



**2** Press the *center key*  to open the **Main Menu**.

### Main Menu



**3** Press the *navigation key*  up/down/ left/right to highlight a menu feature.

**4** Press the *center key*  to select it.

**5** In some list views, such as the Message Inbox or Contacts list, the *menu indicator*  appears at the bottom of the screen, to indicate that menu options are available. Press  to show the menu options.

This is a typical home screen and main menu layout. **Your phone may be a little different.**

Motorola, Inc.  
Consumer Advocacy Office  
1307 East Algonquin Road  
Schaumburg, IL 60196  
[www.hellomoto.com](http://www.hellomoto.com)

**Note:** Do not ship your phone to the above address. If you need to return your phone for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other

countries. Microsoft and Windows are registered trademarks of Microsoft Corporation; and Windows XP is a trademark of Microsoft Corporation. All other product or service names are the property of their respective owners.

© 2008 Motorola, Inc. All rights reserved.

**Caution:** Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

### Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 68000201805-A

# contents

---

<b>menu map</b> .....	7	enter text	19	backlight	31
<b>Use and Care</b> .....	9	side keys	23	<b>calls</b> .....	<b>32</b>
<b>get started</b> .....	<b>10</b>	handsfree	24	redial a number	32
about this guide	10	codes & passwords	24	recent calls	32
SIM card	11	lock & unlock phone	25	return a missed call	33
memory card	11	memory card	25	call waiting	33
battery	12	<b>tips &amp; tricks</b> .....	<b>27</b>	1-touch dial	34
turn it on & off	16	<b>customize</b> .....	<b>28</b>	notepad	34
make a call	16	home screen shortcuts	28	emergency calls	34
answer a call	16	main menu appearance	28	<b>messages</b> .....	<b>35</b>
adjust volume	16	MyMenu	29	send a message	35
change ring alert	16	ring styles & alerts	29	receive a message	36
store a phone number	17	answer options	30	voicemail	36
call a stored phone number	17	wallpaper	30	<b>entertainment</b> .....	<b>37</b>
<b>basics</b> .....	<b>18</b>	screen saver	31	FM radio	37
home screen	18	color setting	31	music library	38
external display	19	display settings	31	WebAccess	42



<b>connections</b> . . . . .	<b>43</b>	<b>Warranty</b> . . . . .	<b>65</b>
cable connections . . . . .	43	<b>Hearing Aids</b> . . . . .	<b>69</b>
<b>other features</b> . . . . .	<b>45</b>	<b>WHO Information</b> . . . . .	<b>70</b>
phonebook . . . . .	45	<b>Registration</b> . . . . .	<b>70</b>
more message features . . . . .	45	<b>Export Law</b> . . . . .	<b>71</b>
more personalizing . . . . .	47	<b>Recycling Information</b> . . . . .	<b>71</b>
call times . . . . .	49	<b>Perchlorate Label</b> . . . . .	<b>72</b>
in call menu . . . . .	50	<b>Privacy and Data Security</b> . . . . .	<b>72</b>
headset . . . . .	51	<b>Driving Safety</b> . . . . .	<b>73</b>
network . . . . .	51	<b>index</b> . . . . .	<b>75</b>
personal organizer . . . . .	51		
advanced calling . . . . .	53		
security . . . . .	54		
fun & games . . . . .	54		
<b>service &amp; repairs</b> . . . . .	<b>55</b>		
<b>SAR Data</b> . . . . .	<b>56</b>		
<b>EU Conformance</b> . . . . .	<b>58</b>		
<b>Safety Information</b> . . . . .	<b>60</b>		
<b>Industry Canada Notice</b> . . . . .	<b>64</b>		
<b>FCC Notice</b> . . . . .	<b>64</b>		

# menu map

## main menu



### Office Tools

- Calculator
- MyMenu
- Alarm Clock
- Stop Watch
- Chat \*
- Dialing Services \*
- Calendar



### Messages

- Create
- Inbox
- Draft
- Outbox
- Quick Notes
- Voicemail
- Browser Msgs
- MMS Templates



### Recent Calls

- Received Calls
- Dialed Calls
- NotePad
- Call Times
- Call Cost \*
- Data Times
- Data Volumes



### WebAccess

- Start Browser
- Web Shortcut
- Go to URL
- Web Session
- Stored Pages
- History
- General Setting

\* Network Dependent



### Personalize

- Home Screen
- Main Menu
- Color Setting
- Greeting
- Wallpaper
- Screen Saver
- Quick Dial\*
- Lock Smart Key



### Games & Apps



### Multimedia

- Pictures
- Music Library
- FM Radio



### Phonebook



### Settings

- (see next page)

This is the standard main menu layout. Your phone's menu may be a little different.

# settings menu



## Ring Style

- Style
- Style Detail



## Call Forward

- Voice Calls
- Fax Calls \*
- Data Calls \*
- Cancel All
- Forward Status



## In Call Setup

- In-Call Timer
- Call Cost Setup \*
- Answer Options
- Call Waiting



## Initial Setup

- Time and Date
- 1-Touch Dial
- Display Settings
- Backlight
- Scroll
- Language
- DTMF
- TTY Setup \*
- Master Reset
- Master Clear
- Format Additional Storage Device
- Status Indicator



## Phone Status

- My Numbers
- Battery Meter



## Headset

- Auto Answer



## Network

- Service Tone
- Call Drop Tone



## Security

- Phone Lock
- Fixed Dial \*
- SIM PIN
- New Passwords

\* Network Dependent

# Use and Care

---

To care for your Motorola phone, please keep it away from:



## liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



## dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



## extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



## cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



## microwaves

Don't try to dry your phone in a microwave oven.



## the ground

Don't drop your phone.

# get started

---

**CAUTION:** Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.

## about this guide

This guide shows how to locate a menu feature as follows:

**Find it:**  >  Recent Calls > Received Calls

This means that, from the home screen:

1 Press the *center key*  to open the main menu.

10 get started

2 Scroll to  **Recent Calls** and press .

3 Scroll to **Received Calls** and press .

**Tip:** Press  or the **Select** soft key to select a highlighted option.

### symbols



This means a feature is network/subscription dependent and may not be available in all areas. Contact your service provider for more information.



This means a feature requires an optional accessory.

# SIM card


Your Subscriber Identity Module (SIM) card contains personal information like your phone number and contacts. It can also contain your voicemail and text message settings.

If you put your SIM card in another phone, that phone uses your phone number.


**Caution:** Don't bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.

**Tip:** Ensure your SIM card is fully inserted into the phone before installing the battery.

1



2




# memory card

You can use a removable microSD memory card (up to 2 GB) with your phone to store and retrieve multimedia objects, such as music and pictures.



**Note:** Your phone supports up to 2 GB microSD memory cards (greater than 1 GB capacity is guaranteed for SanDisk microSD cards only). We recommend that you use Motorola approved memory cards only, such as SanDisk memory cards. Other memory cards may not be compatible with your phone.

To install the memory card, make sure the memory card's metal contacts are facing down. Slide the top of the memory card under the metal band and into the holder. To remove the memory card, slide the card back out of the holder.



**Note:** You must **format a new memory card** before using it for the first time. For instructions, see page 25.

## battery

### battery use & safety

**IMPORTANT: HANDLE AND STORE BATTERIES PROPERLY TO AVOID INJURY OR DAMAGE.** Most battery issues arise from improper handling of

batteries, and particularly from the continued use of damaged batteries.

### DON'Ts

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't let the phone or battery come in contact with water.** Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your carrier or contact Motorola, even if they appear to be working properly.
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your battery near a heat source.** Excessive heat can damage the

phone or the battery. High temperatures can cause the battery to swell, leak, or malfunction. Therefore:

- Do **not** dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
- Avoid leaving your phone in your car in high temperatures.

## DOs

- **Do avoid dropping the battery or phone.** Dropping these items, especially on a hard surface, can potentially cause damage.
- **Do contact your service provider or Motorola if your phone or battery has been damaged from dropping or high temperatures.**

**IMPORTANT: USE MOTOROLA ORIGINAL PRODUCTS FOR QUALITY ASSURANCE AND**

**SAFEGUARDS.** To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a “Motorola Original” hologram.

**Motorola recommends you always use Motorola-branded batteries and chargers.** Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a “Motorola Original” hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and retry charging it;



- If the message remains, contact a Motorola Authorized Service Center.

**Important:** Motorola's warranty does not cover damage to the phone caused by non-Motorola batteries and/or chargers.

**Warning:** Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

## PROPER AND SAFE BATTERY DISPOSAL AND RECYCLING

Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:

- [www.motorola.com/recycling](http://www.motorola.com/recycling)
- [www.rbrc.org/call2recycle/](http://www.rbrc.org/call2recycle/) (in English only)


**Disposal:** Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.




**Warning:** Never dispose of batteries in a fire because they may explode.

## install the battery


1



2




## remove the battery



**Note:** Your battery is intentionally tight fitting to ensure consistent connection.

## charge the battery

Plug the battery charger into your phone and an electrical outlet. Your phone might take several seconds to start charging the battery. The phone shows **Charge Complete** when finished.




## Notes for charging your phone's battery:


- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.


**Tip:** You can also use a PC USB port to charge your phone battery. Before connecting your phone to your PC, download and install the charging software driver from [www.motorola.com/support/W259](http://www.motorola.com/support/W259).

## turn it on & off


**To turn on your phone**, press and hold the *power key*  until the display turns on.


If prompted, enter your four-digit unlock code. Your phone's four-digit **unlock code** is originally set to **1234** or the last four digits of your phone number (see page 24).

**To turn off your phone**, press and hold  for a few seconds.




## make a call


Enter a phone number and press  to make a call.

To hang up, press .



**Tip:** Is your caller saying they can't hear you? Make sure your finger is not covering the microphone (see page 2).

## answer a call

When your phone rings and/or vibrates, open the flip or press  to answer. See page 30 for answer options.

To hang up, press .

## adjust volume

You can adjust the volume during a call by pressing the up or down volume keys on the side of the phone, or by pressing  up or down. To mute a call, press  and select **Mute**.

## change ring alert


**Find it:**  >  **Settings** > **Ring Style**



Available options are **Loud Ring**, **Soft Ring**, **Vibrate**, **Vibrate & Ring**, **Vibrate then Ring** or **Silent** (see page 29).

# store a phone number

You can store up to 500 phone numbers in your

**Phonebook:**

- 1 Enter a phone number in the home screen, and press **Store**.
- 2 Enter a name and other details for the phone number. To select a highlighted item, press .
- 3 Press **Done** to store the number.

To store an email address for a new contact, press  >  **Phonebook** > **[New Entry]** > **New** > **Email**. Enter the name and email address and then press **Done**.

# call a stored phone number

**Find it:**  >  **Phonebook**

- 1 Scroll to the entry.

- 2 Press  to call the entry.

**Shortcut:** In the **Phonebook**, enter the first letters of an entry to get to it quickly.

**Note:** To search for a contact name by typing it in, change the search method to **Find**:


**Find it:**  >  **Phonebook** >  > **Setup** > **Search Method**


# basics

---

See page 2 for a basic phone diagram.


## home screen

When you turn on your phone, the *home screen* appears. To dial a number from the home screen, press number keys and .















**Note:** Your home screen might look a little different.

*Soft key labels* show the current soft key functions. For soft key locations, see page 2.

Press the *navigation key*  up, down, left, or right to select items in the home screen.




Status indicators can appear across the top of the home screen:

indicator	
	Network signal strength.
	You are in a digital coverage area and are roaming off the network.
	You are on a call.
	Battery charge level.
	<b>Style</b> (in <b>Ring Styles</b> ) is set to <b>Loud</b> .
	<b>Style</b> (in <b>Ring Styles</b> ) is set to <b>Soft</b> .

indicator	
	Style (in Ring Styles) is set to <b>Silent</b> .
	Style (in Ring Styles) is set to <b>Vibe and Ring</b> .
	Style (in Ring Styles) is set to <b>Vibe then Ring</b> .
	Style (in Ring Styles) is set to <b>Vibrate</b> .
	New text or multimedia message.
	New voicemail message.

## external display

When the phone flip is closed, the following indicators can appear on the external display:

indicator	
	You have an incoming call.
	New text or multimedia message.
	The battery is charging.

## enter text

Some screens let you use the keypad to enter text, such as when you compose a message:






## set entry modes

Multiple text entry modes make it easy for you to enter names, numbers, and messages:

entry mode	
<b>Primary</b> Secondary	Enter text using a method that you set.
<b>Number</b>	Enter numbers only (see page 23).
<b>Symbol</b>	Enter symbols only (see page 23).

### To assign a Primary or Secondary text entry mode:


- 1 In a text entry screen, press .
- 2 Scroll to **Entry Setup** and press .
- 3 Scroll to **Primary Setup** or **Secondary Setup** and press .

- 4 Scroll to one of the following choices and press




options	
<b>iTAP™</b>	Let the phone predict each word as you press keys.
<b>TAP</b>	Enter letters and numbers by pressing a key one or more times.
<b>Tap Extended</b>	Enter letters, numbers, and symbols by pressing a key one or more times.

### To change the text entry mode

Press  in the text entry screen to change the text entry until the desired mode is displayed.

### To select or edit a text entry mode

Press  in any text entry screen, scroll to and select **Entry Mode**, then scroll to and select the desired entry mode.

## capitalization

Press **0** in any text entry screen to change the text case. These indicators show capitalization status:

indicator	
<b>ab</b>	no capital letters
<b>AB</b>	all capital letters
<b>Ab</b>	capitalize next letter only

## text entry mode indicators

When you select the **Primary** or **Secondary** text entry mode, the following indicators identify the text entry setting:

primary	secondary	
<b>1</b>	<b>2</b>	Tap, no capital letters
<b>1</b> ↑	<b>2</b> ↑	Tap, capitalize next letter
<b>1</b> ↑	<b>2</b> ↑	Tap, all capital letters

primary	secondary	
<b>1</b> □	<b>2</b> □	iTAP™, no capital letters
<b>1</b> ↑	<b>2</b> ↑	iTAP, capitalise next letter
<b>1</b> ↑	<b>2</b> ↑	iTAP, all capital letters

These indicators identify **Numeric** or **Symbol** entry mode:

indicator	
<b>12</b>	number mode
<b>@</b>	symbol mode

## tap method

This is the standard method for entering text on your phone.

Regular **Tap** method cycles through the letters and numbers of the key you press. The **Tap Extended** method cycles through letters, numbers, **and** symbols.



1 Press a key one or more times to cycle through its characters.

2 Repeat the step above to enter all characters.

**Tip:** Press **[\*]** to insert a space.

In a text entry screen you can press **[#]** to switch entry modes. If **Tap** or **Tap Extended** is not available as the **Primary** or **Secondary** entry mode, see page 20.

## iTAP™ method

The iTAP software combines your single key presses into common words, and predicts each word as you enter it. This can be faster than the **Tap** method.

- 1 Press **[Left/Right Arrow]** right or left to scroll through the possible letter combinations, and highlight the combination you want.
- 2 Press **Select** to enter the highlighted combination.

You can press keys to add more letters to the end of the combination.

**or**

Press **[\*]** to enter the highlighted combination and insert a space.

For example, if you press **[7][7][6][4]**, your phone displays the corresponding letter combinations:



Press **Select** to accept **program**.

Press **[Left/Right Arrow]** right or left to see other word suggestions.

## numeric method

In a text entry screen, press **#** to switch entry methods until your phone shows the **12** (numeric) indicator.

Press keypad keys to enter numbers. When finished, press **#** to switch entry modes.

## symbol method

In the text entry screen, press **#** to switch entry methods until your phone shows the **@** (symbol) indicator.

- 1 Press a key one or more times to show possible symbol combinations at the bottom of the screen.
- 2 Scroll left or right to highlight a symbol and press **Select** to enter it.

## delete letters & words

Move the cursor to the right of the text you want to delete and then:

- Press **Delete** to delete one letter at a time.
- Press and hold **Delete** to delete the entire message.

## side keys

### volume keys



Press the volume keys to:

- Turn off an incoming call alert
- Change earpiece or speakerphone volume during a call
- Change volume for a song

## smart key

The *smart key* gives you another way to access a menu item of your choice from the home screen. Also, during music playback, you can use it to pause and resume music.

### To change the menu item accessed by the smart key:

**Find it:**  >  Personalize > Home Screen > Home Keys > Smart Key


## lock side keys

You can lock the side keys when the flip is closed, to prevent accidental key presses when playing music.

### To automatically lock the side keys when the phone is idle and the phone flip is closed:

**Find it:**  >  Personalize > Lock Smart Key > 0 Seconds, 5 Seconds, 10 Seconds, or 30 Seconds

## handsfree

You can use your phone's handsfree speaker to make calls without holding the phone to your ear. To turn the speaker on, during a call, press  > **SPKR ON**. To turn the speaker off, press **SPKR OFF**.

You can also use an optional 2.5mm wired headset to go handsfree.

**Note:** Mini USB headsets are not supported.

## codes & passwords

Your phone's four-digit **unlock code** is originally set to **1234** or to the last four digits of your phone number. The six-digit **security code** is originally set to **000000**.

Your service provider may reset these codes. If not, you should change them to protect your personal information. The unlock code must contain four digits. The security code must contain six digits.

**To change a code or password:**

**Find it:**  >  Settings > Security > New Passwords

**Note:** If you forget your security code, contact your service provider.

## lock & unlock phone

You can lock your phone with a four-digit code to keep others from using it. For more types of locks, see “security” on page 54.

**Note:** You can make emergency calls on a locked phone (see page 34). A locked phone still rings or vibrates for incoming calls or messages, **but you need to unlock it to answer.**

**To lock your phone:**

**Find it:**  >  Settings > Security > Phone Lock > Lock Now  
or Automatic Lock

Enter the four-digit unlock code and press **OK**. Your phone first shows **Phone Locked**, and then shows **Enter Unlock Code** until you unlock the phone.

**To unlock your phone,** enter your four-digit code and press **OK**.

## memory card

You can store multimedia content, such as songs and pictures, on your phone’s internal memory or on an optional memory card.

**Note:** If you download a copyrighted file and store it on your memory card, you can use the file only while the memory card is inserted in your phone. You cannot send, copy, or change copyrighted files.

## format memory card




You will need to format the memory card before using it for the first time. This essential procedure creates

the **Music** and **Picture** directories. If you do not format a memory card before using it for the first time, your phone may not be able to read the contents of the card.

**Caution:** Formatting the memory card **erases all content** on the card.

**Find it:**  >  **Settings** > **Initial Setup**






- 1 Scroll to **Format Additional Storage Device** and press **Select**.
- 2 When prompted, press **Yes** to continue or **No** to cancel formatting.


**Tip:** To access data stored on your microSD memory card, with your phone in the home screen, press  >  **Multimedia** > **Pictures** or **Music Library** and then press  > **Switch Storage Devices**. If there are no files stored on your memory card then your phone will automatically switch to its internal memory.

# tips & tricks

---

From the home screen (page 18), you can use the following shortcuts:

To...	Do this...
<b>play music</b>	Press  to activate the music library.
<b>listen to FM radio</b>	Press  to activate the FM radio.
<b>see recently dialed numbers</b>	Press  .
<b>use feature shortcuts</b>	Press the left and right soft keys or  .
<b>access voicemail</b>	Press and hold the  key to access your voicemail messages.



To...	Do this...
<b>change ring style</b>	Press and hold the  key to change ring styles.

# customize


---

## home screen shortcuts

**Find it:**  >  Personalize > Home Screen > Home Keys



options	
Icons	Show or hide the home screen shortcut icons.
Up, Down, Left, Right	Choose the features that open when you press the navigation key (  ) up, down, left, or right in the home screen.
Left Soft Key	Choose the feature that opens when you press the  <i>left soft key</i> .

### options

**Right Soft Key** Choose the feature that opens when you press the *right soft key*. 

**Smart Key** Choose the feature that opens when you press the *smart key*.


## main menu appearance


**To change your main menu appearance to either icons or a text-based list**, press  >  Personalize > Main Menu > View.


# MyMenu

Create a custom menu of your favorite phone features and tools.

## assign an item to MyMenu

- 1 Press  then scroll to a desired menu or submenu item.

For example, if you want to assign the **Messages** menu to **MyMenu**, scroll to  on the main menu. If you want to assign the **Calculator** function to **MyMenu**, scroll to and select **Office Tools** (on the main menu) then scroll to **Calculator**.

- 2 With the desired option highlighted, press and hold  until the **MyMenu** confirmation appears, then select **Ok**.
- 3 Press **Done** to accept the assigned key number, or scroll to **Key** and press **Change** to assign a different one.

## use MyMenu

**Find it:**  >  **Office Tools** > **MyMenu**



Scroll to the **MyMenu** item you want and press **Enter**.

## ring styles & alerts

Your phone rings and/or vibrates to notify you of an incoming call or to signal certain other events. This ring or vibration is called an *alert*.

### set a style

**Find it:**  >  **Settings** > **Ring Style**




- 1 Select **Style** by pressing .
- 2 Scroll to a ring style and press .

### set alerts

Set alerts for different events, such as getting a message in your inbox or receiving a call.



**Find it:**  >  Settings > Ring Style

- 1 Scroll to *Style Detail* and press .
- 2 Scroll to an alert type and press .
- 3 Scroll to the desired detail setting and press .

**Note:** Your phone plays a sample of each highlighted setting. Ringtones play through the speakerphone, unless you're using a headset.

## answer options

Set your phone to one of the following answer options: **Multi-key On**, **Multi-key Off** or **Open to answer**.



**Find it:**  >  Settings > In Call Setup > Answer Options

## wallpaper

Set a picture as a wallpaper (background) image in your home screen.

**Find it:**  >  Personalize > Wallpaper



**To select a wallpaper image:**

- 1 Scroll to **Picture** and press .
- 2 Scroll to the picture you want and press .

**or**

Select **(None)** to turn off wallpaper.

**To adjust wallpaper image layout:**



- 1 Scroll to **Set Layout** and press .
- 2 Scroll to **Tile**, **Center** or **Fit-to-screen**, and press .

## screen saver

Set a picture as a screen saver image. The screen saver displays when the phone is being charged and there is no activity.

**Find it:**  >  **Personalize** > **Screen Saver**



**To select a screen saver:**

- 1 Scroll to **Type** and select **Animation**.
- 2 Scroll to **Animation** and press .
- 3 Scroll to the animation you want and press .

**or**



Select **(None)** to turn off the screen saver.

**To specify how long your phone must be inactive before it displays the screen saver:**



- 1 Scroll to **Idle Time** and press .
- 2 Select a time period and press .

**Note:** To conserve battery life, turn off the screen saver.



## color setting

To choose a **Color Setting** (or skin) that sets the look and feel of your phone's display, press  >  **Personalize** > **Color Setting**.

## display settings

To select a time period that the display light remains on, press  >  **Settings** > **Initial Setup** > **Display Settings**.

## backlight



To select a time period that the display backlight remains on, press  >  **Settings** > **Initial Setup** > **Backlight**.

# calls

---

To make and answer calls, see page 16.

## redial a number

- 1 From the home screen, press  to see a list of recently dialed calls.
- 2 Scroll to the entry you want to call and press .


## recent calls

Your phone keeps lists of the calls you recently received and dialed, even if the calls didn't connect. The lists are sorted from newest to oldest calls. The oldest calls are deleted as new calls are added.


**Find it:**  >  Recent Calls > Received Calls or Dialed Calls

- 1 Scroll to an entry.

**Note:** A ✓ next to a call means the call connected.

- 2 Press  to call the number.



To see call details (such as time and date), press **View**.

Press  while viewing a list of recent calls to see these options:

option	
Store	Create a phonebook entry.  <b>Note:</b> This option appears only when the number is not stored in your phonebook.

option	
<b>Delete</b>	Delete the entry.
<b>Delete All</b>	Delete all entries in the list.
<b>Show ID/ Hide ID</b>	Show or hide your phone number when making a call.
<b>Send Message</b>	Create a new text message with the number in the <b>To</b> field.
<b>Add Digits</b>	Add digits after the number.
<b>Attach Number</b>	Attach a number from the <b>Phonebook</b> or recent calls lists.

## return a missed call

When you miss a call, your phone plays an alert and shows the *missed call indicator*  and a missed call notification. Press **View** to see the details, and press  to call the number.

To view your missed calls at any time:


**Find it:**  >  **Recent Calls** > **Received Calls**

To hear a voicemail message, see page 36.

## call waiting

If you **receive a second call** while you are already on a call:



- To answer the second call and put the first call on hold, press . To switch between the calls, press **Switch**.
- To send the second call to your voicemail, press **Ignore**.

# 1-touch dial

Your phone can store nine phone numbers that you can call with a single key press. To **store** a 1-touch dial phone number:

**Find it:**  >  Settings > Initial Setup > 1-Touch Dial


To **call** a 1-touch dial phone number, press and hold the single-digit 1-touch dial number from the home screen.

# notepad

The most recent set of digits that you entered are stored in your phone's *notepad* memory.

**To retrieve a number in the notepad:**

**Find it:**  >  Recent Calls > NotePad

Press  to call the number or press **Store** to store the number in your **Phonebook**.

# emergency calls

Your service provider programs emergency phone numbers, (such as 911), that you can call under any circumstances, even when your phone is locked.

**1** Enter the emergency number.

**2** Press .

**Note:** Emergency numbers vary by country. Your phone's pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

# messages

---

You can send and receive SMS/EMS and MMS multimedia messages as well as access your voicemail from the Messages feature. Each message type allows you to attach different objects. The available options are displayed in the **Insert** menu.



**Note:** Your phone can store a maximum of 500 messages.


## send a message

**Find it:**  >  Messages > Create > Create Message


- 1 Select a message type and enter the message text.
- 2 To insert a picture, sound, or other object, press **Insert**.

- 3 When you finish the message, press **OK**. Choose one or more people to send to.
- 4 Press **Send**.


## quick text

Set your home screen to access the  **Quick Text** option so that you can send messages faster.

**Find it:**  >  Personalize > Home Screen > Home Keys > Up, Down, Left, or Right > Quick Txt

After setup you can quickly access the text entry screen by pressing the navigation key direction you set for  **Quick Text**.

## receive a message

When you receive a message, your phone plays an alert and displays the *new message indicator*  and a new message notification. Press **Read** to read the message immediately, or save it in your message inbox for viewing later. To read messages in your message inbox:

**Find it:**  >  Messages > Inbox

Scroll to the message you want to read. Press **Read** to open the message. For MMS messages, your phone shows the media object, then the message.

## voicemail

Your network stores the voicemail messages you receive.



When you **receive** a voicemail message, your phone shows an indicator and **New Voicemail**. Press **Call** to call your voicemail.

**To check your voicemail messages at any time:**

**Find it:**  >  Messages > Voicemail and then press **Call**

**Note:** Your service provider may have assigned speed dial number **1** for calling voicemail and may provide additional information about using voicemail.





# entertainment

---


## FM radio

**Find it:** 


To use the **FM Radio** you need to connect a stereo headset to the 2.5 mm headset jack.

- Press  or  to change the frequency.
- Press the up or down volume keys on the side of the phone, or press  or  up or down to adjust the volume.
- Press **Options > Mute** to mute the radio.

## use the radio presets

- 1** Tune in the desired frequency by pressing  left or right, or press **Options > Scan** to scan for all available radio stations. You can also use the keypad keys to enter a frequency by pressing **Options > Set Frequency**.
- 2** Press and hold a number key to save that number as the preset.

## select a radio preset

- 1** Press **Options > Station Presets** to see a list of all radio presets.
- 2** Press  up or down to select a preset.

**Tip:** If you know the number assigned to the preset station, press the keypad number to select it.



## record FM radio clips

- 1 Press **Options** > **Record**.

**Note:** The maximum recording length is 100 seconds.

- 2 Press **Options** > **Stop Recording** to stop the recording. The clip is saved in  **Multimedia** > **Music Library**.

**Note:** The unauthorised copying of copyrighted materials is contrary to the provisions of the Copyright Law of the United States and other countries. This device is designed solely for copying non-copyrighted materials, materials which you own the copyright, or materials which you are authorised or legally permitted to copy. If you are uncertain about your right to copy any material, please consult your legal advisor.

**Note:** Playback of recorded radio clips is in mono sound format only.

## share a radio station

Share your favorite radio stations with friends:

**Find it:**  > **Options** > **Send Station Info**

Use the message screen to send the station frequency. Your friend can access the station with a single click.

## select the radio output

You can play the radio through a stereo headset or a speaker. Press **Use Headset** or **Use Speaker**.

## music library

Use your phone to play music files of type iMelody, MIDI and MP3:





**Find it:** 



**Note:** Your phone may not play MP3 files that have a bit rate higher than 320 kbps. If you try to download or

play one of these files, your phone may display an error message or ask you to delete the file.

**Tip:** Connect a stereo headset for high quality music playback.

## music library controls



function	
<b>scroll through song list</b>	Before music playback, press  up or down.
<b>play</b>	Press <b>Play</b> .
<b>pause/resume</b>	Press  .
<b>fast forward</b>	Press & hold  right (for at least two seconds).
<b>skip to next song</b>	Press & release  right.

function	
<b>rewind</b>	Press & hold  left (for at least two seconds).
<b>return to last song</b>	Press & release  left.
<b>turn off</b>	Press <b>Back</b> .

**Tip:** When listening to music on the move, use the convenient controls on the side of the phone. The *smart key* plays/pauses music playback and the *volume keys* adjust the volume.

## playlists

### Find it:

- To create a new playlist, press  > **New** > **Playlist** and press **Select**.
- To edit an existing playlist, scroll to the playlist and press  > **Edit**.
- To select and play a playlist, scroll to the playlist and press **Play**.

## music library options

option	
<b>Apply as Ring Tone</b>	Use as a ringtone.
<b>New</b>	<b>Playlist</b> - Create a new playlist. <b>iMelody</b> - Create a custom ringtone.
<b>Details</b>	See information for a song file.

option	
<b>Rename</b>	Rename a song file.
<b>Delete</b>	Delete a song or playlist.
<b>Mark/ Unmark</b>	Mark one or more song files that you want to delete, move, copy, or assign to a category.
<b>Edit</b>	Edit a playlist.
<b>Reorder</b>	Reorder the songs on a playlist.
<b>Setup</b>	<b>Auto Repeat</b> - Repeat the selected song or all songs in the current playlist.
<b>View Free Space</b>	View space remaining on your phone.

## get music

Copy music to your phone's memory card.

### Connect

- 1 With a memory card inserted and your phone in the home screen, insert the USB cable in your phone and your Windows PC.

**Note:** Your phone supports Microsoft® Windows® 2000 and Windows XP™. Other operating systems may not be compatible with your phone.

- 2 On your phone, press **Yes** to connect your phone as a storage device. Name the device "W270 Mobile" and click **Finish**.

**Note:** For USB cable connection details, see page 43.

- 3 Now you've connected, use Microsoft® Media Player or USB drag and drop to copy your music.

### Windows Media Player



- 1 On your Windows PC, open Microsoft Windows Media Player 11.
- 2 On the **Sync** tab, select **More Options**. Under Device, select **W259 Mobile**.
- 3 Select **Properties**, check the "Create folder hierarchy on device" box, and click **OK**.

### USB drag and drop

- 1 Use the My Computer window to find Removable Device.
- 2 Drag and drop your music, photos and other stuff that you want to copy. Two folders are available: **Music** and **Picture**. To help manage your music, you can create more folders in the **Music** folder.
- 3 When you're done, use the **Safely Remove Hardware** feature to finish.

# WebAccess

Use your phone to access Web pages.

**Find it:**  >  WebAccess

## WebAccess controls

option	
<b>Start Browser</b>	Open the Web browser.
<b>Web Shortcut</b>	Access a preset shortcut to a Web page.
<b>Go to URL</b>	Enter a Web page URL.
<b>Web Session</b>	Access a stored Web session.
<b>Stored Pages</b>	Go to a previously stored page.
<b>History</b>	Access a list of recently viewed Web sites.
<b>General Setting</b>	Clear history, reset cache, or clear cookies.

# connections


---

## cable connections



You can use your phone's mini USB port to connect to a computer.

**Note:** Motorola Original™ USB data cables and supporting software may be sold separately. Check your computer to determine which cable you need.



If you use a USB cable connection:

- Be sure to connect the phone to a high-power USB port **on your computer** (not a low-power one, such as the USB port on your keyboard or bus-powered USB hub).

**Note:** If you connect your phone to a low-power USB port, the computer may not recognise your phone.

- Make sure both your phone and the computer are turned on and the phone is in the home screen.

**Note:** When your phone is plugged into a computer and is being used for mass storage, it cannot be used for anything else. To restore the phone to normal use, disconnect it from the PC.

- Your phone supports Microsoft® Windows® 2000 and Windows XP™. Other operating systems may not be compatible with your phone.

Attach the Motorola Original USB cable to the mini USB port on your phone and to an available USB port on your computer. Select **Yes** to connect the phone as a storage device.




**Note:** Selecting **No** will start charging the phone battery.

On your computer:

- 1 Open your “My Computer” window, where your phone’s memory card shows as a “Removable Disk” icon.
- 2 Click on the “Removable Disk” icon to access the memory card.
- 3 If necessary, in the “Removable Disk” (memory card) window, create one or more folders for the files you will copy onto the memory card.

- 4 To copy files between your computer and phone, drag and drop into the appropriate folders.
- 5 When you’re finished, remove the device by selecting the “Safely Remove Hardware” icon at the bottom of your computer screen, then select “USB Mass Storage Devices” and “Stop”.

Use these folders on your memory card for the file types indicated:




- music files (iMelody, MIDI and MP3): **\Music**. To help manage your music, you can also create new folders in the **\Music** folder. 
- picture files (JPG, PNG, or BMP): **\Picture**.

**Note:** The maximum single picture file size is 100kB, at a resolution of 640 x 640 dpi.



# other features

---

## phonebook

features
<b>create entry</b> ⬅ ➡ >  Phonebook > [New Entry]
<b>edit entry</b> ⬅ ➡ >  Phonebook  Scroll to the entry and press ⬅ ➡ > <b>Edit</b> to edit the entry. Scroll up or down and press ⬅ ➡ to edit fields. Press <b>Done</b> to save your changes.
<b>delete entry</b> ⬅ ➡ >  Phonebook  Scroll to the entry and press ⬅ ➡ > <b>Delete</b>

## more message features

features
<b>send text message</b> ⬅ ➡ >  Messages > Create > Create Message > SMS/EMS  Press <b>Insert</b> to view insert options.  You can also select a contact first. Press ⬅ ➡, and select <b>Send Message</b> to compose a message.
<b>use MMS template</b>  Select a multimedia template with preloaded media:  ⬅ ➡ >  Messages > MMS Templates




## features

### view sent messages

 >  Messages > Outbox


Scroll to the message and press **Read**.

Press  to view message options.

### read received messages

 >  Messages > Inbox

Scroll to the message and press **Read**.


Press  to view message options.

### drafts

View messages saved in **Drafts** folder:

 >  Messages > Draft




Scroll to the message and press **Select**.

Press  to view message options.

## features

### erase messages




Delete all messages or only messages from one folder:

 >  Messages, press  > Cleanup Messages

Select **All**, **Text Msg Inbox**, **Browser Msgs**, **Info Services**, **Outbox**, or **Drafts**.

### set up voicemail




 >  Messages, press  > Voicemail  
> Voicemail Setup

### view the message memory status

 >  Messages, press  > Memory Status

# more personalizing

<b>features</b>
<b>ring volume</b> 📶 > ⚙️ Settings > Ring Style > <i>Style Detail</i> > Ring Volume
<b>define answer option</b> 📶 > ⚙️ Settings > In-Call Setup > Answer Options
<b>keypad volume</b> 📶 > ⚙️ Settings > Ring Style > <i>Style Detail</i> > Key Volume
<b>reminders</b> Set your phone to play reminder alerts for unread messages, missed calls, or voicemail messages that you've received: 📶 > ⚙️ Settings > Ring Style > <i>Style Detail</i> > Reminder
<b>set time and date</b> 📶 > ⚙️ Settings > Initial Setup > Time and Date

<b>features</b>
<b>greeting</b> Change the greeting that appears when you turn on your phone: 📶 > 🎨 Personalize > Greeting
<b>change home screen soft key</b>  📶 > 🎨 Personalize > Home Screen > Home Keys > Right Soft Key
<b>text layout</b> Set home screen text to be left justified or centered: 📶 > 🎨 Personalize > Home Screen > Layout
<b>clock view</b> Show an analog clock or digital time readout in the home screen: 📶 > 🎨 Personalize > Home Screen > Clock Set

## features

### menu view

Show the main menu as icons or a text list:



 >  Personalize > Main Menu > View

### show or hide menu icons

Show or hide menu feature icons in the home screen:



 >  Personalize > Home Screen > Home Keys > Icons

### menu language

 >  Settings > Initial Setup > Language

### scroll

Set the scroll bar to stop or wrap around in menu lists:

 >  Settings > Initial Setup > Scroll

## features

### master reset

Reset all options except unlock code, security code, and lifetime timer:

 >  Settings > Initial Setup > Master Reset

To reset all options, you need to enter the **Security Code (000000)**.

## features

### master clear


Reset all options except unlock code, security code, and lifetime timer, and clear all user settings and entries.

**This option erases all user-entered information stored in your phone memory, including Phonebook entries and downloaded files.** Once you erase the information, it cannot be recovered. It resets all options to their factory settings except for the unlock code, security code, and lifetime timer.

 >  Settings > Initial Setup > Master Clear

To reset all options, you need to enter the **Security Code (000000)**.

## call times

**Network connection time** is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

**The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.**

## features





### set in-call timer

 >  Settings > In Call Setup > In-Call Timer


### view call times



 >  Recent Calls > Call Times









Select **Last Call**, **Dialed Calls**, **Received Calls**, **All Calls**, or **Life Time**.

<b>features</b>
<b>view data times</b>  >  Recent Calls > Data Times
<b>view data volumes</b>  >  Recent Calls > Data Volumes





## in call menu

During a call, press  to access the in call menu.



<b>features</b>
<b>access a list of available phone lines</b>  > My Tel Numbers Scroll to a line and press <b>Select</b> .
<b>mute the call</b>  > Mute

<b>features</b>
<b>hold the call</b>  > Hold
<b>make another call</b>   > New call
<b>access list of phonebook contacts</b>  > Phonebook
<b>access list of dialed calls</b>  > Dialed Calls
<b>access list of received calls</b>  > Received Calls
<b>access message menu</b>  > Messages
<b>setup TTY</b>  > TTY Setup



# headset

features
<p><b>auto answer</b> </p> <p>Automatically answer calls when connected to a headset:</p> <p> &gt;  <b>Settings</b> &gt; <b>Headset</b> &gt; <b>Auto Answer</b></p> <p><b>Note:</b> Both mono and stereo headsets are supported for voice only.</p>
<p><b>change volume</b></p> <p>To change headset volume during a call, press up or down on the volume keys on the side of the phone, or press  right or left.</p>

# network

features
<p><b>network settings</b></p> <p>View network information and adjust network settings:</p> <p> &gt;  <b>Settings</b> &gt; <b>Network</b></p>

# personal organizer

features
<p><b>add calendar event</b></p> <p> &gt;  <b>Office Tools</b> &gt; <b>Calendar</b></p> <p>Scroll to the desired day and press <b>Select</b>, then scroll to <b>[New]</b> and press <b>Select</b>.</p>

## features

### view calendar event

View or edit event details:

 >  Office Tools > Calendar

Scroll to the desired day and press **Select**, then scroll to the event and press **View**.


### event reminder

When an event reminder occurs, press **View** to view it. Press **Exit** to dismiss the reminder.

### copy calendar event

Copy a datebook event to another date and/or time:

 >  Office Tools > Calendar

Scroll to the desired day and press **Select**, then scroll to the event and press . Scroll to **Copy** and press **Select**.

## features

### set alarm

 >  Office Tools > Alarm Clock


**Note:** You can set the FM radio as your alarm device by selecting **Alert > Radio** from the **Alarm Details** menu.

### calculator

 >  Office Tools > Calculator

### convert currency

 >  Office Tools > Calculator

Press  and select **Convert Currency**.

# advanced calling

## features

### call forwarding

Set up or cancel call forwarding:



 >  **Settings** > **Call Forward**

Choose **Voice Calls**, **Fax Calls**, or **Data Calls**, then select the type of calls to forward and the phone number to forward the calls to.

### speed dial

Each **Phonebook** entry you store is assigned a unique speed dial number.

 >  **Phonebook** > **[Entry]** > **View**

To speed dial a number, simply enter the speed dial number and press  then .

## features

### quick dial



Set your favorite contact numbers to three Quick Dial options.

 >  **Personalize** > **Quick Dial**

Scroll to the **Quick Dial** option (1, 2 or 3) that you want to set and press **Change**. Press **Browse** > **Phonebook**, **Dialed Calls**, or **Received Calls** to search for the number you need. Press **OK** to accept the selected number.

### DTMF tones

Your phone can send Dual Tone Multi Frequency (DTMF) tones for calling card calls or other automated touch-tone calls.

 >  **Settings** > **Initial Setup** > **DTMF**

Select **Short DTMF** or **Long DTMF**.



# security

## features

### change unlock and security codes

 >  Settings > Security > New Passwords > Unlock Code or Security Code

**Note:** The default code is **1234**.

# fun & games

## features

### play a game


 >  Games & Apps

## features

### manage music

 > Music Library

To play music, scroll to the song title and press **Play**.




To create a playlist, press  > **New** > **Playlist**, press **Select**.

Enter a playlist name and select the audio files.

### manage pictures

 >  Multimedia > Pictures

To view a picture, scroll to the image and press **View**.

**Note:** To access music or pictures stored on your microSD memory card, press  >  Multimedia > Pictures or Music Library, press  > **Switch Storage Devices**. If there are no files stored on your memory card, your phone will automatically switch to its internal memory.

# service & repairs

---

If you have questions or need assistance, we're here to help.

Go to [www.motorola.com/support](http://www.motorola.com/support), where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

# Specific Absorption Rate Data

---

## This model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.<sup>1</sup> Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the

maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 0.50 W/kg, and when worn on the body, as described in this user guide, is 0.64 W/kg. The SAR value for this product in its data transmission mode (body-worn use) is 0.61 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).<sup>2</sup>

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

**<http://www.phonefacts.net>**

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

**<http://www.cwta.ca>**

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

# European Union Directives Conformance Statement


---



Hereby, Motorola declares that this product is in compliance with:

Approval Number from your product's label in the "Search" bar on the Web site.

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [www.motorola.com/rtte](http://www.motorola.com/rtte). To find your DoC, enter the Product



***MOTOROLA***

# Important Safety and Legal Information

# Safety and General Information

---

**This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.**

## Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

## Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

## Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: [www.motorola.com](http://www.motorola.com).

## RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

## Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

## Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using

your mobile device with your implantable medical device, consult your healthcare provider.

## Driving Precautions

The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving.

Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Responsible driving practices can be found in the "Smart Practices While Driving" section in this guide (or separate guide).

## Operational Warnings

Obey all posted signs when using mobile devices in public areas.

## Potentially Explosive Atmospheres







Areas with potentially explosive atmospheres are often, but not always, posted and can include fueling areas, such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.



## Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

## Batteries & Chargers

**Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For**

**more information, see the “battery use & safety” section in the user’s guide.**

## Keep Your Mobile Device and Its Accessories Away From Small Children

These products are not toys and may be hazardous to children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

## Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

## Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are tired.

## Caution About High Volume Usage



**Warning:** Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. To

protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.

- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

For more information about hearing, see our Web site at [www.motorola.com/hearingsafety](http://www.motorola.com/hearingsafety) (in English only).

## Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

[Mar0108]

# Industry Canada Notice to Users

---

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept

any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.5.

## FCC Notice to Users

---

**The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID:xxxxxx on the product label.**

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

# Motorola Limited Warranty for the United States and Canada

---

## What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

## Products and Accessories

Products Covered	Length of Coverage
<b>Products and Accessories</b> as defined above, unless otherwise provided for below.	<b>One (1) year</b> from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
<b>Decorative Accessories and Cases.</b> Decorative covers, bezels, PhoneWrap™ covers and cases.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.

<b>Products Covered</b>	<b>Length of Coverage</b>
<b>Monaural Headsets.</b> Ear buds and boom headsets that transmit mono sound through a wired connection.	<b>Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.
<b>Consumer and Professional Two-Way Radio Accessories.</b>	<b>Ninety (90) days</b> from the date of purchase by the first consumer purchaser of the product.
<b>Products and Accessories that are Repaired or Replaced.</b>	<b>The balance of the original warranty or for ninety (90) days</b> from the date returned to the consumer, whichever is longer.

#### Exclusions

**Normal Wear and Tear.** Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

**Batteries.** Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

**Abuse & Misuse.** Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with

liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

**Use of Non-Motorola Products and Accessories.** Defects or damage that result from the use of non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

**Unauthorized Service or Modification.** Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

**Altered Products.** Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

**Communication Services.** Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

## Software

Products Covered	Length of Coverage
<b>Software.</b> Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	<b>Ninety (90) days</b> from the date of purchase.

### Exclusions

**Software Embodied in Physical Media.** No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

**Software NOT Embodied in Physical Media.** Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

## Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

## What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

## How to Obtain Warranty Service or Other Information

<b>USA</b>	<b>Phones:</b> 1-800-331-6456 <b>Pagers:</b> 1-800-548-9954 <b>Two-Way Radios and Messaging Devices:</b> 1-800-353-2729
<b>Canada</b>	<b>All Products:</b> 1-800-461-4575
<b>TTY</b>	1-888-390-6456
For <b>Accessories</b> and <b>Software</b> , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

## What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS,

ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

**Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.**

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

# Hearing Aid Compatibility with Mobile Phones

---

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.



# Information from the World Health Organization

---

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF

exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int/peh-emf>

## Product Registration

---

Online Product Registration:

[www.motorola.com/us/productregistration](http://www.motorola.com/us/productregistration)

Product registration is an important step toward enjoying your new Motorola product. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions. Registration is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

# Export Law Assurances

---

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation

or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

## Caring for the Environment by Recycling

---



This symbol on a Motorola product means the product should not be disposed of with household waste.

### Disposal of your Mobile Device and Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved

national recycling schemes, and further information on Motorola recycling activities can be found at: [www.motorola.com/recycling](http://www.motorola.com/recycling)

### Disposal of your Mobile Device Packaging and User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

# California Perchlorate Label

---

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

“Perchlorate Material – special handling may apply. See [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate).”

There is no special handling required by consumers.

## Privacy and Data Security

---

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device’s keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device’s security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or

turning it in for recycling. For step-by-step instructions on how to delete all personal information from your device, see the section entitled “master clear” or “delete data” in the user’s guide.

**Note:** For information on backing up your mobile device data before erasing it, go to [www.motorola.com](http://www.motorola.com) and navigate to the “downloads” section of the consumer Web page for “Motorola Backup” or “Motorola Phone Tools.”

- **Understanding AGPS**—To provide location information for emergency calls, certain Motorola mobile devices incorporate *Assisted Global Positioning System* (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user’s location—for example, to provide driving directions. Users

who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at [privacy@motorola.com](mailto:privacy@motorola.com), or contact your service provider.

## Smart Practices While Driving

---

Drive Safe, Call Smart

**Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas -- for example, handsfree use only. Go to [www.motorola.com/callsmart](http://www.motorola.com/callsmart) (in English only) for more information.**

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.

- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.



- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.\*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.\*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.\*

---

\* Wherever wireless phone service is available.

# index

---

## A

alarm clock 52  
alert 29  
answer a call 16  
attach a number 33

## B

backlight 31  
battery  
    charge 15  
    charge indicator light 2  
    install 14  
    level indicator 18  
    remove 15

## C

cable connections 43

cables 43  
calculator 52  
calendar  
    event 51  
    event reminder 52  
    view 52  
    view event 52  
call  
    answer 16  
    end 16  
    make 16  
call a stored phone number 17  
call forwarding 53  
call times 49  
call waiting 33, 34  
calls restrict 53  
capitalize text 21

center key 2  
change ring alert 16  
change volume 51  
charge battery 15  
clear 49  
clear/back key 2  
clock  
    analog 47  
    digital 47  
codes 24, 25  
color setting 31  
controls  
    music library 39  
copy music 41  
currency converter 52

## D

data call  
    volume meters 50  
data times 50  
date 47  
delete text 23  
dial a phone number 16  
dialed calls 32  
display 18  
drafts folder 46  
DTMF tones 53

## E

emergency number 34  
end a call 16  
end key 2, 16  
event  
    calendar 52  
external display 19

## F

FM radio 37  
format memory card 25

## G

games 54  
greeting 47

## H

headset 51  
hold call 50  
home screen 18  
    shortcuts 28  
    soft key indicators 47

## I

in call menu 50  
in call timer 49  
indicator lights 2  
indicators

battery level 18  
message 19  
roaming 18, 19  
signal strength 18, 19  
sound & vibrate on 19  
sounds loud 18  
sounds off (silent) 19  
sounds soft 18  
text entry mode 21  
vibrate on 19  
voice call 18, 19  
install battery 14  
iTAP text entry method 22

## K

keypad volume 47

## L

layout text 47  
lock phone 25

## M

- make a call 16
- manage pictures 54
- manage sounds 54
- master clear 49
- master reset 48
- memory card 11, 25
  - format 25
- menu 28
  - icons, show or hide 48
  - language 48
  - scroll 48
  - show icons or list 48
- menu icons 28
- message indicator 19
- messages
  - drafts 46
  - erase 46
  - MMS 45
  - read 46

- receive 36
- send 35
- text message 45
- text template 45
- view sent message 46

Missed Calls message 33

MMS 45

music player 38

mute 50

MyMenu 29

## N

- navigation key 2, 18
- network settings 51
- new call accept 50
- notepad 34
- numeric entry method 23

## P

- passwords. See codes
- personal organizer 51

- phone lines 50
- phone number call 17
- phone number store 17
- phonebook 17, 33, 45
- pictures 54
- playlists 40
- power key 2, 16
- preset radio stations 37

## Q

- quick text 35

## R

- radio 37
- receive a message 36
- received calls 32
- recent calls 32
- record radio stations 38
- redial 32
- reminders 47
- remove battery 15



- reset 48
- restrict calls 53
- return a call 33
- ring alert 16
- ring style, setting 29
- ring volume 47
- roaming indicator 18, 19

## **S**

- screen saver 31
- security 53, 54
- security codes 24, 54
- send a message 35
- send key 2, 16
- set a style 29
- set alerts 29
- set color 31
- set time & date 47
- shortcuts 27
- signal strength indicator 18, 19
- SIM card 11

- skin 31
- smart key 24
- soft keys 2, 18, 47
- sound & vibrate on indicator 19
- sounds 54
  - loud indicator 18
  - soft indicator 18
- sounds off (silent) indicator 19
- speakerphone, automatic answer 51
- speed dial 53
- storage 25
- store phone number 17
- symbol entry method 23

## **T**

- tap text entry method 21
- template 45
- text delete 23
- text entry 19
  - capitalization 21

- entry mode indicators 21
- text layout 47
- time 47
- tips & tricks 27
- turn on/off 16

## **U**

- unlock
  - code 24, 25
  - phone 25
- USB cables 43
- USB drag and drop 41

## **V**

- vibrate on indicator 19
- voice call indicator 18, 19
- voicemail 36
  - message indicator 36
  - setup 46
- volume 16
  - change 51

keypad 47

ring 47

## **W**

wallpaper 30

WebAccess 42

Windows Media Player 41

U.S. patent Re. 34,976





[www.motorola.com](http://www.motorola.com)

