HOME SCREEN

quick access to the things you need most

QUICK START: HOME SCREEN

The *home screen* gives you all your latest information in one place. It's what you see when you turn on the phone or touch Home (a) from a menu. It's basically like this:



Note: Your home screen might look a little different.

Tip: From the home screen, touch Menu 😁 > **Profiles** to design different home screens for **Work**, **Home**, or **Weekend**. Your changes are stored in each profile.

USE & CHANGE YOUR HOME SCREEN

On your home screen, *shortcuts* are icons that you touch to open your favorite apps, web bookmarks, contacts, or music playlists. *Widgets* show you news, weather, messages, and other updates.

Flick the home screen left or right to open other *panels* of shortcuts and widgets.

- To open something, touch it. Touch Home (a) to return to the home screen.
- To change a widget's settings, open it and then touch Menu B > Settings or touch it and then touch Widget settings.

Tip: For each Messages or Social Networking widget, you can choose the accounts you want to show.

There's more about social networking widgets in "VIEW ACCOUNT UPDATES & FEATURES" on page 12 and "UPDATE YOUR STATUS" on page 11.

 To resize a widget, touch and hold the widget until you feel a vibration, then drag to resize. Arrows appear in the corners of the widget. Drag the arrows to resize.



• To add something or

change your wallpaper, touch and hold an empty spot until you see the **Add to Home screen** menu.

You can add a folder to organize your shortcuts.

 To move or delete something, touch and hold it until you feel a vibration, then drag it to another spot, another panel, or the trash at the top of the screen.

RUNNING MULTIPLE APPS

No need to close an app before opening another one. Your phone runs multiple apps, all at once.

You can open a new app while already running another. Touch Home (a) to return to the home screen. Touch and then touch the app you want. To switch from one running app to another, touch and hold Home (a) to see what apps are already open, then touch the one you want. You can view **Recent**, **All apps**, **Downloaded**, or create a **New group**.

SEARCH

To search, touch Search Q.



NOTIFICATIONS & PHONE STATUS

At the top of the screen, icons on the left notify you about new messages or events. Icons on the right tell you about phone status.

DRMATION

Home screen 9

NOTIFICATIONS

To access a message, email, or meeting reminder directly from the status bar, drag the status bar down and touch the notification.



Tip: To see today's date, touch and hold the status bar at the top of the screen.

STATUS INDICATORS

At the top of the screen, icons on the left notify you about new messages or events (flick the bar down for details). Icons on the right tell you about phone status:

*	Bluetooth™ active	(((Wi-Fi active		
*	GPS active	¥	airplane mode		
	silent mode	3]]}	vibrate mode		
5	microphone mute		speakerphone on		
~	alarm set	all	network (full)		

3G	3G ready	3G ↑∔	3G transferring
5	battery (charging)		battery (full charge)

APP MENU

The app menu shows you all of your applications. To open it from the home screen, touch I. To close it, touch Home (a) or Back (5) You can view **Recent**, **All apps**, **Downloaded** or create a **New group**.

Tip: To find an app in the menu, just touch Search \bigcirc and type the app name.



SOCIAL NETWORKING

my life, your life

YOUR MOTOBLUR ACCOUNT

The first time you turned on your phone, you registered for a MOTOBLUR account that manages your messages, contacts, and more ("**SET UP & GO**" on page 4). You can log into this account from a PC to upload contacts, reset your password, get help, or even locate your phone: <u>www.motorola.com/mymotoblur</u>.

WHAT IS MOTOBLUR?

MOTOROLA **PRO+** with MOTOBLUR is a phone with social skills.

Now, the only service that can sync all your friends, emails, messages, and Facebook™, MySpace, Twitter feeds and happenings with continuous updates and back-ups, along with the ability to remotely locate and wipe your phone if it is ever lost or stolen, just got better.

Introducing the latest MOTOBLUR, MOTOBLUR offers new features that give you more control, including customizable filters that let you view your messages and happenings any way you like, the ability to move and resize preloaded widgets, and new ways to manage your Battery Life and data consumption.

UPDATE YOUR STATUS

After you add a social networking account, you can update and see your current status in a **Social Status** widget on your home screen.

To update your status, just touch your **Social Status** widget and enter text. If you have more than one account, you can use the pull-down menu to limit which accounts are updated. If you don't see a **Social Status** widget, flick your home screen left or right to check all panels.

To add a Social Status widget:

- 1 Touch and hold an empty spot on your home screen to open the **Add to Home screen** menu.
- 2 Touch Motorola widgets > Social Status. The widget appears in the empty spot, and will show your status the next time your phone updates from the network.

ADD ACCOUNT

If you skipped setting up a MOTOBLUR account when you first turned on your phone, you'll need to set up a MOTOBLUR account before you can add other accounts. From your home screen, touch **Set up Blur device** and follow the steps in "**set up & co**" on page 4.

Note: You can add your **Facebook**, **MySpace**, **Twitter**, or other accounts to your phone. If you don't have accounts, you can visit their websites to set them up.

Find it: Menu $\textcircled{\texttt{BD}} > \textbf{Settings} > \textbf{Accounts} > \textbf{Add} \ \textbf{account}$

To sign into your account, use the user name or email and password that you set up on that account (the same as on your PC).

When you sign into social networking accounts, you'll see your friends and contacts in your **Contacts** list, and your status and updates can appear in **Social Status** and **Social Networking** widgets.

Note: Twitter and MySpace messages will always appear as "read" on your phone, but your phone notifies you when you receive a new message. MySpace marks your messages as "read" online.

For email accounts, see "CMAIL™" on page 21.

Tip: To download updates faster, use "wi-Fi" on page 33.

VIEW ACCOUNT UPDATES & FEATURES

After you add a social networking account, you can see and respond to friends' updates with the **Social Networking** widget on your home screen. If you don't see one, set one up in "**widgets**" on page 37.

When you touch the **Social Networking** widget to open an update, you can touch on the social network's icon to open its website.

Note: Your network or other factors might affect the speed of widget updates.

EDIT & DELETE ACCOUNTS

Find it: Menu 🔡 > Settings > Accounts

Touch and hold an account, then touch **Open account** to edit it, or touch **Remove account** to remove it (along with its contacts and messages).

ORMATION

CALLS *it's goo to talk*

QUICK START: CALLS Find it: (III Dialer



Tip: To quickly search for a contact, use the keypad to enter the name.

During a call, your touchscreen goes dark to avoid accidental touches. Touch Menu 📳 to place a call on **Hold**, or to adjust the **Voice quality**.

Tip: You can touch Home (a) or Back (5) to hide the active call display. To reopen it, touch (**[] Dialer**.

MAKE & ANSWER CALLS

To make a call, touch (Dialer, enter a number, then touch .

Tip: To enter an international dialing code, touch and hold **O**. To **Add pause** or **Add wait** after numbers, touch Menu **(**).

To answer a call touch **Answer** or when the screen is locked, drag **(.**) to the right.

To ignore a call touch **Ignore** or when the screen is locked, drag **cont** to the left. If you choose to ignore a call, you can touch **I will call you back in a few minutes** to send the caller a preset text message.

END CALLS

Touch End call.

VOICEMAIL

When you have a new voicemail, ∞ shows at the top of your screen. To hear the voicemail, drag the notifications bar down and touch it, or touch (Dialer > 1 ∞ .

If you need to change your voicemail number, from the home screen touch Menu 📳 > Settings > Call settings > Voicemail settings.

ADD A CONTACT

Find it: (iii) Dialer > phone number > Δ_{\oplus}

RECENT

Find it: 🚺 Dialer > Recent

- To call a number, touch (on the right.
- To send a text message, store the number, add to speed dial, or other options, touch and hold an entry.
- To filter the list, touch the category (like **All calls**) at the top.
- To delete a call from the list, touch and hold the entry, then touch **Remove from list**.
- To clear the list, touch Menu 🔡 > Clear list.

FAVORITES

Find it: 🚺 Dialer > Favorites

- To call a number, touch (on the right.
- To add, or import/export entries touch Menu 🔡.

SPEED DIAL

Find it: 🚺 Dialer > Menu 🔡 > Speed dial setup

- To assign a contact, touch a number. To remove a contact from a speed dial, touch .
- To use the speed dial number, touch (Dialer, then touch and hold the assigned number.

HANDSFREE

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

During a call:

- To use the speakerphone, touch **Speaker**.
- To use a Bluetooth™ device, touch **Bluetooth**.

Dialing and commands: Touch Source Source Commands. To dial, say "Call" and then a contact name or phone number. Or, say a command from the list shown, like "Send Message" or "Go To".

MUTE & HOLD

During a call:

- To mute the current call, touch Mute.
- To put a call on hold, touch Menu 🔡 > Hold.