

Welcome

Welcome to Motorola's world leading mobile communication technology. Motorola's mobile communication equipment are designed and produced in compliance with its strict in-house standards and the international standards. They are subject to the strict quality tests including temperature test, humidity test, dust test, vibration test and drop test. We are sure that you will be highly satisfied with the Motorola products made through these processes.

Thank you again for selecting our products, and hope that you would succeed in your business with your VU20.

- ※ Any content of this manual and any function of this product are subject to change according to situation.
- ※ We suggest that you set your phone to vibration mode at a public place.

Prohibition of illegal modification of IMEI

Removal or change of IMEI (International Mobile Equipment Identity) installed in the mobile phone manufactured and supplied by Motorola, or an attempt to reproduce and enter another IMEI in the mobile phone is strictly prohibited and subject to max. 10-year prison sentence or a fine not exceeding 20 million Won in pursuant of Article 347 of the Criminal Act.

In addition, such an illegal act may damage the software installed in the phone. Therefore, customers are required to use care not to incur any damage due to such an illegal act. The product which is illegally modified is excluded from any free or paid service warranted by Motorola.

For your safety

Read this 'For your safety' carefully in order to secure safety of the user and to prevent damage to property. Please keep this manual in the place which can be accessed at any time by the user.

CAUTION!

- Do not lend your own phone to other person inadvertently.
- Please observe the proprieties in public places.
- For repairs or other alter services, contact our designated service center.
- If your phone has got lost or stolen, immediately report to the relevant telecommunications service provider.
- You are required to refrain from using unauthorized devices.
 - Using chargers, hands-free kits, data communication cables, batteries, or equipment other than genuine ones may deteriorate this product's performance or cause malfunction, external deformation or breakage.
- Use the accessories like an earphone cautiously.
 - If you are exposed to loud sound for long periods of time, damage to your hearing can occur.
- Make it rule to record important data separately.
 - Input data such as telephone numbers for a mobile phone may be corrupted due to user's inadvertence or unexpected problems.
- Make sure not to be in water or moisture.
 - If either mobile phone or battery is immersed in 'water' or 'liquid', the color of immersion-checking label affixed to the mobile phone or battery will be changed.

In the case of malfunction due to such reason, free service warranted by Motorola will be rejected.

※ This product should not be added with any separate equipment that may cause an alteration to its original performance as described on type registration.

User Guide

A manufacturer and an installer cannot provide services for saving lives because this wireless equipment stands a chance of causing radio interference.

To use the mobile phone safely and for a long time,



Make sure to use authentic goods only.

Using an unauthorized battery or charger may shorten a life cycle of the mobile phone or deteriorate its performance.



Be careful not to cause damages to the glass of mobile phone display.

- The LCD may be damaged if it is given a strong impact or is dropped to the ground.
- If the glass gets damaged, please do not touch it by hands, but contact the nearest Motorola service center immediately.



Make sure not to be in water or moisture.

If either mobile phone or battery is immersed in 'water' or 'liquid', the color of immersion-checking label affixed to the mobile phone or battery will be changed.



Do not dry an immersed mobile phone with a heating apparatus.

If you dry an immersed mobile phone or battery with a heating apparatus may cause a mobile phone's explosion and external deformation or failure. Do not turn on the power while the phone is wet. Instead, separate a batter from the phone and contact a service center designated by Motorola.

For your safety

Read this 'For your safety' carefully in order to secure safety of the user and to prevent damage to property. Please keep this manual in the place which can be accessed at any time by the user.

To use the mobile phone safely and for a long time,



Use and keep the phone at room temperature.

If a mobile phone or battery is placed at very hot places (inside a car in summer, an airtight place under the direct sunlight, near the fire, etc), it may run into a danger of explosion fire or external deformation. If it is used and kept at very cold places, it may reduce the capacity and lifetime of the battery.



Keep the mobile phone clean.

- If there are foreign substances on a metal part of a charger or battery-charging contact, the phone may not be charged properly.
- Use smooth cloth to clean the mobile phone. Using chemicals (such as alcohol, benzene, thinner, etc.) for cleaning purpose may cause a fire.



Do not give strong impact to the mobile phone, and do not disassemble or modify it.

Giving a strong impact or dropping the mobile phone or battery may cause the phone to run into failure or explosion. In case of disassembling or modifying the mobile phone inadvertently, a free service will be rejected.



Do not use the phone while charging.

If you use the mobile phone while charging it with a charger or USB data cable, you may have a risk of electric shock or fire. Make sure that you use the phone after separating it from USB data cable or charger.



Use a ground-available outlet for PC power when using an USB data cable.

If you connect the phone with PC (personal computer) via an USB data cable, you may encounter a risk of electric shock depending on the grounding state of the PC power.



Do not place items containing magnetic components.

The magnetic strip such as a credit card, phone card or transportation ticket, can be damaged by the phone.



Make a back-up record of the input information in mobile phone.

- Input information like telephone numbers can be deleted upon user's inadvertency, upgrade, repair or unexpected problem.
- A manufacturer shall not be responsible for any information loss.



Do not hold the antenna when the phone is in use.

If you hold it, it can affect call quality; it also may cause the phone to operate as higher power level than needed and shorten talk and standby times.

For your safety

Read this 'For your safety' carefully in order to secure safety of the user and to prevent damage to property. Please keep this manual in the place which can be accessed at anytime by the user.

To use the mobile phone safely and for a long time,



Keep the phone out of reach of animals or children.

If children or animals suck or bite the mobile phone or battery, they may run into a risk of having an electric shock, explosion, exposure to electromagnetic wave, damaged parts (rubber stopper) stuck in the throat, and suffocation. In case a child use the phone, make sure that they are fully aware of this precaution.



Be careful when you use a necklace or cord for the mobile phone.

Be careful that using a necklace or cord for the mobile phone may cause you to run into dangerous accidents like being caught in train, electric railway or car doors.



Make sure to use authentic goods only.

- Paint or metallic content on the phone may cause an allergic reaction, eczema, itching, swell, and etc.
- If any of the above symptoms occurs, stop using the phone and visit a doctor.



Using the bluetooth



Please be aware that using a bluetooth function may lead to abnormal operation or noise due to radio interference with other devices.

Keep at least 5m distance from a wireless LAN when using the bluetooth. (Bluetooth see, p.127)



Be careful that using the bluetooth function may generate abnormal operation or noise depending on environments.

(Bluetooth see, p.127)

For your safety

Read this 'For your safety' carefully in order to secure safety of the user and to prevent damage to property. Please keep this manual in the place which can be accessed at any time by the user.

Locations for using the mobile phone



Do not use the mobile phone in a potentially explosive atmosphere.

Turn off your phone in a potentially explosive atmosphere like construction sites and military areas. Obey all the instructions and signals posted in a potentially explosive atmosphere. Construction crews often use remote control RF devices to set off explosives.



Do not use the mobile phone in near inflammable materials.

Do not install or use accessories onto your phone in a potentially explosive atmosphere including gas station, gas leak areas, and deck on boats.



Do not use the mobile phone in a prohibited area like air crafts and hospitals.

Using a mobile phone may cause accidents in some aircrafts and hospitals using RF equipment.



Do not use the mobile phone near pacemakers.

- The Health Industry Manufactures Association recommends to keep a minimum of 15 cm (6 inches) from the pacemaker when the phone is switched on.
- Person with pacemaker should always use the phone in the opposite side of the pacemaker and maintain a separation of 15cm or more.



Using the mobile phone while driving



Refrain yourself from using the mobile phone while driving.

- Using the mobile phone in driving a car may cause direct and indirect car accidents.
- Check the laws and regulations on the use of mobile phones in the areas when you drive. Such an act is fined penalties and demerits under the Road Traffic Act.



Do not install a hands-free device near air bag.

An air bag inflates with great force in a moment. Do not leave your phone or set up the hands-free kit near to the air bag. You may be seriously injured when the air bag is activated.

For your safety

Read this 'For your safety' carefully in order to secure safety of the user and to prevent damage to property. Please keep this manual in the place which can be accessed at any time by the user.

Using battery and charger



A battery for charging is consumable.

The repetition of charge/discharge will shorten its service time gradually.



The flicker of the lamp while charging the mobile phone and the battery means that the charge is not processed.

Check the charger to avoid the trouble that may occur to each device.



If the temperature of the phone rises over 45°C while charging the battery, the phone stops charging and switch on the LCD screen and keypad lights.



Mobile phone and battery cover need to be combined at all time.

If not, it may cause malfunction.



In case of separating a battery from the mobile phone, please turn off the power.

If not, it may cause malfunction.



Make sure to use only the TTA-authorized battery.

Using unauthorized charger may cause fatal accidents like degraded battery safety, shorter service life, explosion or fire.



Do not expose the phone direct sunlight or use it in places with high humidity.

Store in the room between 0°C ~ +40°C. It may damage the phone and cause the phone to explode.



Do not place the phone in areas that may get very hot, such as on or near a cooking surface, cooking appliance, iron, or radiator.

It may damage the phone and cause the phone to explode.



Do not permit a battery out of the phone to come in contact with metal objects, such as coins, keys or jewelry.

It may damage the phone and cause the phone to explode.

Menu Table

11	T Service	59~82
2	Sounds	83~90
3	Display	91~98
4	Contents	99~110
5	My Moto	111~144
6	Organizer	145~154
7	Message	155~166
8	Phonebook	167~174
9	Settings	175~184
10	My Moto	45~139

T Service	Roaming.....60
	M Service Center.....61
	T Service.....62
	NATE.....63
	W.....63
	Game Box.....67
	Moreta.....67

Sounds	Ringtone Style.....84
	Download Ringtone.....84
	Vibrate Style.....85
	Call Alert Style.....85
	Volume.....86
	Operation Effects.....87
	Reminder Alerts.....87
	System Alerts.....88
	Time Alert.....88
	My Etiquette.....89

Display	Main Display.....92
	External Display.....93
	Download Wallpaper.....94
	Download Font Mate.....94
	Menu Type.....95
	Screen Design.....96
	Dialing Font.....96
	Backlight Control.....97
	Visual Expression.....97

Contents	Ringtone Box.....100
	Wallpaper Box.....100
	Font Box.....101
	Photo/Movie Album.....101
	MMS Contents Box.....102
	@Playon.....103
	June Contents Box.....105
	Live Box.....108
	VTC Contents Box.....108
	Flashoon Contents Box.....109
	Memory Manager.....109

My Moto	Camera.....112
	Bluetooth.....127
	Subway Map.....134
	Dictionary.....136
	File Viewer.....138
	E-book.....139
	Stopwatch.....139
	Astro/Yoga/Acupress.....140
	USB Mass Storage.....142
Organizer	Morning call/Alarms.....146
	Calendar.....148
	Scheduler.....149
	Memo.....150
	Diary.....151
	Calculator.....152
	World Time.....154

Message	Message Box.....156
	New Message.....160
	Mobile Messenger.....163
	e-mail.....163
	Report spam/Service.....164
	Contents Box.....165
	Settings.....166
Phonebook	Search Number.....168
	Add new Contact.....170
	Edit Group.....171
	Edit Speed Dial.....171
	Call History/Time.....172
	Block Calls.....172
	Memory Usage.....173
	Automatic Backup.....173
	My Number.....174

Settings	Phone Settings.....176
	Call Settings.....177
	NATE Settings.....178
	Powersave.....179
	USIM Setting.....179
	Set Time.....180
	Lock/Password.....181
	언어/Language.....182
	Reset.....183
	Moto Customer Service.....183
	About.....184

External LCD/Touch pad	Contents.....69
	Camera.....114
	Video.....118
	Bluetooth.....127
	Stopwatch.....139
	Recent call history.....45
	External Display.....93

Contents

Prohibition of illegal modification of IMEI	3
Safety precautions	4
Menu table	14

01 Before Using the Phone

01 Components	22
02 Parts of the phone	23
03 Multi-access	26
04 On-screen icons	28
05 Menu move buttons	29
06 USIM card	31
Installing USIM card	31
Removing USIM card	32
07 Battery	33
Install/Remove battery	33
Charging battery	34
Battery status	36
Charging time	36
Operating time	36
Low battery alarm	36

02 Basic Operation

01 Power On/Off	37
Power on	38
Power off	38
02 Video call	39
Before making a video call	39
Using T LIVE	39
Making a video call	41
Answering a video call	42
In-video call functions	42
03 Voice call	45
Placing a voice call	45
Receiving a voice call	47
In-voice call functions	48
04 Menu from the call history list	51
05 Missed calls	52
06 My Menu settings	52
07 Using menu after entering numbers	53

03 Entering Text

01 Entering text mode	56
Writing Korean	56
Writing English and numbers	57
02 Using menu when entering text	58
Emoticons	58

04 T Service

01 Roaming	60
Select system	60
Roaming auto dial	60
02 M Service Center	61
03 T Service	62
04 NATE	63
05 W	63
Mobile Web Internet	64
e-mail	65

04 T Service _continued

Mobile Messenger	65
June video	65
RealTime TV	66
i's box	66
tossi	66
June contents	66
06 Game Box	67
07 Moneta	67
Membership & Life	68
Moneta home	68
Preference	68
08 Melon	69
Melon Contents	70
Music search	70
Melon	72
Preference	73
Melon mp3	74

04 T Service _continued

09 T MAP	76
Before Using T MAP	76
NATE Pedestrian Navigation	78
Emergency Call	78
Register Mobile Security	79
10 WINC(Mobile Address)	80
11 NATE Mobile Homepage	81
12 T Interactive	81

05 Sounds

01 Ringtone Style	84
02 Download Ringtone	84
03 Vibration Style	85
04 Call Alert Style	85

05 Sound _continued

05 Volume	86
06 Operation Effects	87
07 Reminder Alerts	87
08 System Alerts	88
09 Time Alert	88
10 My Etiquette	89

06 Display

01 Main Display	92
Setting Standby Screen	92
02 External Display	93
03 Download Wallpaper	94
04 Download Font Mate	94
05 Menu Type	95

Contents (cont'd)

06 Display _continued

06 Screen Design.....	95
07 Dialing Font.....	96
08 Backlight Control.....	97
09 Visual Expression.....	97

07 Contents

01 Ringtone Box.....	100
02 Wallpaper Box.....	100
03 Font Box.....	101
04 Photo/Movie Album.....	101
Photo Album.....	101
Movie Album.....	102
05 MMS Contents File.....	102
06 @Play On.....	103
07 June Contents Box.....	105
Video Album.....	106
Menu when playing music content.....	107

07 Contents _continued

08 Live Box.....	108
09 Video Chatting Content.....	108
10 Flashoon Content.....	109
11 Managing Memory.....	109

08 My Moto

01 Camera.....	114
Before using camera.....	112
Photo.....	114
Video.....	118
Cyworld.....	118
i's box.....	122
Photo Ch.....	122
Photo Frame.....	123
Printing Service.....	124
Video Coloring/Lettering.....	125

08 My Moto _continued

Reference.....	125
Managing Memory.....	126
Help.....	126
02 Bluetooth.....	127
Before using bluetooth.....	127
Setting bluetooth mode.....	128
Connecting bluetooth device.....	129
Reference.....	132
My device.....	133
03 Subway Map.....	134
View Route Map.....	134
Search Route.....	134
My Route.....	135
Station Info.....	135
Lost Property Office.....	135
Settings.....	135
Help.....	135

08 My Moto _continued

04 Dictionary.....	136
English-Korean.....	136
Korean-English.....	137
My Vocabulary.....	137
My History.....	137
Settings.....	137
05 File Viewer.....	138
06 E-book.....	139
07 Stopwatch.....	139
08 Astro/Yoga/Acupress.....	140
Astrology.....	140
Yoga.....	140
Acupressure Guide.....	141
09 USB Mass Storage.....	142
USB data cable.....	142
Installing External memory.....	143

09 Organizer

01 Moring call/alarms.....	146
Easy alarm.....	146
Moring call.....	147
My alarm.....	147
02 Calendar.....	148
03 Scheduler.....	149
Schedule.....	149
To-do.....	149
Anniversary.....	149
D-day.....	150
Meeting planner.....	150
04 Memo.....	150
05 Diary.....	151
Photo diary.....	151
Diet diary.....	152
06 Calculator.....	152
07 World Time.....	154

10 Message

01 Message Box.....	156
02 New Message.....	160
Using background.....	161
Using Avata.....	161
03 Mobile Messenger.....	163
04 e-mail.....	163
05 Report Spam/Service.....	164
06 Contents Box.....	165
07 Settings.....	166

11 Phonebook

01 Search Number.....	168
Search All.....	168
Group.....	168
Speed Dial.....	168
Number.....	168

Contents (cont'd)

11 Phonebook _continued

02 Add New Contact.....	170
Save by phone.....	170
Save by USIM.....	170
03 Edit Group.....	171
04 Edit Speed Dial.....	171
05 Call History/Time.....	172
06 Block calls.....	172
07 Memory Usage.....	173
08 Automatic Backup.....	173
09 My number.....	175

12 Settings _continued

01 Phone Settings.....	176
Sounds.....	176
Display.....	176
Message.....	176
Camera.....	176

12 Settings _continued

June Setting.....	176
Bluetooth.....	177
T LIVE Settings.....	177
02 Call Settings.....	177
Answer Options.....	177
Auto area code.....	177
Airplane Mode.....	178
Network Settings.....	178
03 NATE Settings.....	178
04 Powersave.....	179
05 USIM Setting.....	179
06 Set Time.....	180
07 Lock/Password.....	181
Phone Lock.....	181
Privacy Lock.....	181
Service Key Lock.....	181
Restrict Call.....	182
Change Password.....	182

12 Settings _continued

08 언어/Language.....	182
09 Reset.....	183
10 Moto Customer Service.....	183
Call Center.....	183
Search Service Center.....	184
Troubleshooting.....	184
11 About.....	184


13 Appendix

01 Accessories.....	186
02 Troubleshooting.....	186
03 Spec and Feature.....	187
04 Authentication label.....	187
05 Specific Absorption Rate.....	188
06 Collecting wasted mobile phones.....	189



1. Components

Before using the phone, make sure that you have received all the components.



2. Parts of the phone

Part names and keys




Note
Push the hold button  down to unlock the external LCD touch pad.

2. Parts of the phone

Part names and keys



Keypad



3. Multi-Access

You can use Message, @Playon, June contents, Motorola features, running function, W, NATE, and voice/video phone.
 E) You can place a voice call while using the internet.



Run Multi-Access

Press Multi-Access button ► Move to select the feature you want ► Select

- When using Message, @Playon, June contents, Motorola features, running function, W, NATE, or Voice/Video call, press to use the multi-access icon on the standby screen.
- Select the function and press .
 - Multi-Access icon displayed on the standby screen.

Note

- When using Multi-Access, Help runs automatically on the standby screen. You can set on/off of viewing Help function.
- When you have turned off Help function, you can press and hold (Left) to view Help again.



- When Multi-Access function is restricted, information window displayed on the screen.
- You can only use Multi-Access functions from the system memory.
 (Except when the function could effect the phone's stability)

Icon description

	Message	Move to message menu, and use various functions. (Message, see p. 156)
	@Playon	Use the short cut key functions in @Playon menu. (@Playon, see p. 103)
	June contents	Move to June contents box and play the downloaded content
	Motorola Functions	Use Organizer [Scheduler(see p. 143), Memo(see p. 140), World Time(see p. 154), Subway Map(see p. 134), Dictionary(see p. 136), Calculator(see p. 152), E-book(see p. 139)].
	Running Functions	Using the current Multi-Access function, check the running functions from the list.
	W	Move to W menu and use the various functions. (W, see p. 63)
	NATE	Connect to NATE or June Contents Box.
	Voice/Video call	Use the recent call history, phonebook, and placing a call functions.


4. On-Screen Icons




	Tells you the strength of the network signal.		Service is not available.
	Voice call or NATE is connected.		The stereo earset is connected.
	Video call is connected.		You have received voice or text message.
	You have received e-mail.		The external memory card is inserted.
	Phone is locked. (Lock all, Priority Lock service)		Bluetooth is being used. (Bluetooth, see p.128)
	The alarm has been set and is on. (Simple alarm, Morning call, My alarm)		Touch pad is locked
	Incoming calls has set to Bell mode.		Etiquette Mode
			Vibrate
			Bell & Vibrate
			Louder
			Mute
			My etiquette mode
	Tells you the status of		
	Full		Low battery
	Charge needed		
	USB cable is connected. (It varies depending on the receive mode selected)		
	You have set the phone as flight mode.		The phone is charging through USB cable or car charger
	The roaming service (general) is being used.		The roaming service (3G) is being used.

5. Menu move buttons


How to use the touch pad menu



How to use the menu displayed on the bottom of the screen




How to move the cursor and select a menu



5. Menu move buttons (Cont'd)


When a scroll bar is displayed




If is displayed on a side of the menu



If is displayed on the screen




If is displayed on the screen



6. USIM card

Insert USIM(Universal Subscriber Identity Module) card supports from SKT in order to use the phone.

Installing USIM card



- 1 Push the battery cover and slide down to open.
- 2 Lift to remove the battery.
- 3 Insert and slide the USIM card into the USIM card holder. Make sure that the USIM card is inserted properly and that the gold contact area on the card is facing downwards.
- 4 Push down and place the battery.
- 5 Slide the battery cover upwards until it snaps back into place.

6. USIM card (cont'd)

Removing USIM card



- 1 Remove the battery cover and the battery. (see p.32)
- 2 Push upward to remove the USIM card.
- 3 Place back the battery and the battery cover properly. (see p.32)

- Emergency call can be made with out the USIM card.
 - Press **[112]** (Right) and enter the emergency number and press **[END]** when USIM card is not in the phone.
- You can use menu on standby screen without USIM card.

Note

- For your privacy, set the USIM card password before you use. (USIM preference, see p.179)
- The metal contact of the USIM card can be easily damaged by scratches.
- Be careful not to lose or transfer the ownership to the other person. The call charge fee and other service fee is charged to USIM holder.
- The battery life can be shorten when using the USIM card with the transportation card.
- Make sure the power is off before you install the USIM card.
- The phone cannot be recognized the USIM card when the power is on.
- For more details about the USIM card, please contact SKT service center.

7. Battery

Installing the battery



- 1 The battery charge terminal and the phone charge terminal should be engaged as shown in the figure.
- 2 Push down the battery until it snaps.
- 3 Place the battery cover to the battery cover home, slide the battery cover upwards until it snaps.

Removing the battery



- 1 Push and slide down the battery cover and lift up from the battery cover home as shown in the figure.
- 2 Hold and lift up the battery removal home as shown in the figure.
- 3 Separate the battery from the phone.


CAUTION

- Make sure the power is off all time when removing the battery.
 - Removing the battery when the power is on could damage your phone.

7. Battery (cont'd)

Charging the battery

- ※ The battery is not fully charged when you purchase it, make sure to charge the battery before using the phone.
- ※ You must use a travel charger or a car charger in order to recharge a completely discharged battery.



1 Charging a battery with a battery charger

- 1) Connect the travel charger cable to the rear port of the battery charger.
- 2) Connect the power cord of the travel charger to an electric outlet, and check if the triangular lamp on the travel charger cable jack flickers in amber (100V~220V).
- 3) Insert the battery to the battery charger socket.
(When inserting or removing a battery to/from the charger, check the direction of the battery release button on the charger.)
- 4) The charging status is displayed on the triangular lamp on the travel charger cable jack.



2 Charging a battery with a charger adapter

- 1) Connect the power cord of the travel charger to an electric outlet, and check if the triangular lamp on the cable jack flickers in amber (100V~220V).
- 2) Connect the travel charger cable jack to the port of the charger adapter.
- 3) Connect the charger adapter cable jack to the charger connector in the right side of the handset.
- 4) The charging status is displayed on the triangular lamp on the travel charger cable jack.
- 5) If the charger lamp flickers while charging the battery with the travel charger, connect the charger adapter to the handset, and then connect the travel charger.



NOTE

Optional travel charger

Travel chargers are not included in the package for conservation of resources. You can purchase one from the shop or a service center.



3 Charging a battery with a USB data cable

- 1) You can charge your phone by connecting it to the PC through a 5PIN USB data cable or a 24PIN USB data cable using a charger adapter.
 - In order to use the charging function with a 5PIN USB data cable, you should have SKT integrated USB driver in your PC.
 - A 5PIN USB data cable supports both the charging and data communication functions.
 - A 24PIN USB data cable using charger adapter only supports the charging function.



NOTE

Display icon when charging

The charging icon is displayed if you charge the battery with a 5 PIN USB data cable or a car charger



The screen when charging the battery while the phone is off



Battery icons when power is off

- Charging is in progress normally / Charging is completed
- The power is disconnected or connected incorrectly (Connect the charger cable again)
- When charging a battery with a travel charger, the charger lamp shows if the battery is fully charged (turns into green from red)