



MOTOROLA
intelligence everywhere™



MOTOMANUAL


V560
GSM

Welcome










Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola V560 GSM wireless phone.



Check It Out!



Feature	Description
Connect to a Personal Area Network	Pair your phone with an access point for a personal area network: ☰ > Settings > Connection > Bluetooth Link > Access Points > [Look For Devices]
Bluetooth® Wireless Pairing	Pair your phone with a Bluetooth® headset, car kit, or computer: ☰ > Settings > Connection > Bluetooth Link > Setup > Power > On , press BACK (⏪), press > Handsfree > [Look For Devices]

Feature	Description
Record Video Clip	Record a video clip: Press  > Multimedia > Videos > (New Video) , point lens at subject, press CAPTURE () to begin recording, press STOP () to stop recording.
Play Video Clip	Play a video clip:  > Multimedia > Videos > <i>video clip</i>
Take Photo	Press  > Multimedia > Camera , point lens at subject, press CAPTURE () to take a photo.
Send Photo	Send a photo to a phone number or email address: Take photo, then press STORE () > Send In Message .
Set Photo as Picture ID	Assign a photo to a phonebook entry to allow picture caller ID: Take photo, then press STORE () > Apply as Phonebook Entry .
Send Multimedia Message	Send a multimedia message with pictures, animations, sounds, and videos:  > Messages > Create Message > New Multimedia Msg



Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2004, 2005.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number: 68XXXXXX95-O

Contents

Safety and General Information	8
European Union Directives Conformance Statement	15
Caring for the Environment by Recycling	16
Getting Started	17
About This Guide	17
Installing the SIM Card	18
Battery Tips	19
Installing the Battery	21
Charging the Battery	22
Turning Your Phone On	23
Turning Your Phone Off	23
Adjusting Volume	24
Making a Call	24
Answering a Call	25
Viewing Your Phone Number	25
Highlight Features	26
Using a Personal Area Network	26
Recording and Playing Video Clips	29
Taking and Sending a Photo	34
Sending a Multimedia Message	36
Using Bluetooth® Wireless Pairing	40
Learning to Use Your Phone	45
Using the Display	45
Using the 5-Way Navigation Key	50
Using Menus	51
Entering Text	53
Using the Smart Key	65

Using the External Display	65
Using the Handsfree Speaker	67
Changing a Code, PIN, or Password	67
Locking and Unlocking Your Phone	68
If You Forget a Code, PIN, or Password	69
Using the Phonebook	70
Setting Up Your Phone	73
Setting a Ring Style	73
Changing the Call Alert	74
Setting the Time and Date	74
Setting a Wallpaper Image	75
Setting a Screen Saver Image	76
Changing Phone Skin	77
Setting a Phone Theme	77
Setting Answer Options	78
Setting Display Brightness	79
Adjusting the Backlight	79
Setting Display Timeout	80
Storing Your Name and Phone Number	80
Calling Features	81
Turning Off a Call Alert	81
Viewing Recent Calls	81
Redialing a Number	83
Using Automatic Redial	83
Returning an Unanswered Call	84
Using the Notepad	84
Putting a Call On Hold or Mute	85
Using Call Waiting	86
Using Caller ID (Incoming Calls)	86
Calling an Emergency Number	87
Dialing International Numbers	87

Calling With 1-Touch Dial	88
Using Voicemail	88
Changing the Active Line	90
Phone Features	91
Main Menu	91
Settings Menu	92
Feature Quick Reference	93
Calling Features	93
Messages	94
Phonebook	95
Personalizing Features	98
Instant Messaging	100
Chat	101
Email	101
Menu Features	102
Special Dialing Features	103
Call Monitoring	104
Handsfree Features	104
Data and Fax Calls	106
Network Features	106
Personal Organizer Features	107
Security	109
News and Entertainment	109
Troubleshooting	112
Specific Absorption Rate Data	113
Index	115

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.¹

Exposure To Radio Frequency (RF) Energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards, always adhere to the following instructions.

External Antenna Care

If your phone has an external antenna, use only the supplied or Motorola-approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and/or may result in non-compliance with local regulatory requirements in your country.

Do NOT hold the external antenna when the phone is IN USE. Holding the external antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline phone.

Body-Worn Operation: Voice Communication

To maintain compliance with RF energy exposure guidelines, if you wear a phone on your body when transmitting voice communications, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this phone, if available. Use of accessories not approved by Motorola may exceed RF energy exposure guidelines.

If you do not use one of the body-worn accessories approved or supplied by Motorola, and are not using the phone held in the normal use position, ensure the phone and its antenna are at least 2.5 centimeters (1 inch) from your body when transmitting.

Data Operation

When using any data feature of the phone, with or without an accessory cable, position the phone and its antenna at least 2.5 centimeters (1 inch) from your body.

Approved Accessories

Use of accessories not approved by Motorola, including but not limited to batteries, antennas, and convertible covers, may cause your phone to exceed RF energy exposure guidelines. For a list of approved Motorola accessories, visit our website at www.motorola.com.

RF Energy Interference/Compatibility

Note: Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Facilities

Turn off your phone in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Aircraft

Turn off your wireless device whenever instructed to do so by airline staff. If your device offers a flight mode or similar feature, consult airline staff about use in flight. If your device offers a feature that automatically turns on the phone, then turn off this feature before boarding an airplane or entering an area where the use of wireless devices is restricted.

Medical Devices

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 centimeters (6 inches) be maintained between a handheld wireless phone and a pacemaker.

Persons with pacemakers should:

- ALWAYS keep the phone more than 15 centimeters (6 inches) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- Give full attention to driving and to the road. Using a phone may be distracting in certain circumstances. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving best practices can be found in the “Wireless Phone Safety Tips” at the end of this guide and/or at the Motorola website:

www.motorola.com/callsmart.

Operational Warnings

For Vehicles With an Air Bag

Do not place a phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Gas or Petrol Stations

Obey all posted signs with respect to the use of radio equipment in gas or petrol stations. Turn off your wireless device if instructed by authorized staff.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere. Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted "Turn off electronic devices." Obey all signs and instructions.

Damaged Products






If your phone or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center to determine if it has been damaged. Do not attempt to dry it with an external heat source, such as a microwave oven.

Batteries and Chargers

Batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become hot. Take care when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola Original™ batteries and chargers.**

Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger, or phone may contain symbols, defined as follows:

Symbol	Definition
	Important safety information will follow.
	Your battery or phone should not be disposed of in a fire.
	Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Your battery or phone should not be thrown in the trash.
	Your phone contains an internal lithium ion battery.

Choking Hazards

Your phone or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your phone and its accessories away from small children.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone. (The flashing-light feature is not available on all products.)

Parents should monitor their children's use of video game or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms

occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation.

To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.

Repetitive Motion Injuries

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders:


- Take a minimum 15-minute break every hour of game playing.
 - If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
 - If you continue to have sore hands, wrists, or arms during or after play, stop playing and see a doctor.
1. The information provided in this document supersedes the general safety information in user's guides published prior to January 28, 2005.

European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (the R&TTE Directive) at www.motorola.com/rtte - to find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the Web site.

Caring for the Environment by Recycling



When you see this symbol on a Motorola product, do not dispose the product with household waste.

Recycling Mobile Phones and Accessories

Do not dispose of mobile phones or electrical accessories, such as chargers or headsets, with your household waste. In some countries or regions, collection systems are set up to handle electrical and electronic waste items. Contact your regional authorities for more details. If collection systems aren't available, return unwanted mobile phones or electrical accessories to any Motorola Approved Service Centre in your region.

Getting Started



CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.



About This Guide



This guide describes the basic features of your phone.

Selecting a Menu Feature

Use the menu system to access your phone's features. This guide shows you how to select a menu feature from the home screen as follows:

Find the Feature  > **Recent Calls** > **Dialed Calls**

This example shows that, from the home screen, you must press the menu key  to open the menu, scroll to and select  **Recent Calls**, then scroll to and select **Dialed Calls**.

Press the 5-way navigation key  to scroll and highlight a menu feature. Press **SELECT** () to select the highlighted menu feature.

Optional Features



This label identifies an optional network, SIM card, or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

Optional Accessories




This label identifies a feature that requires an optional Motorola Original™ accessory.

Installing the SIM Card

Your *Subscriber Identity Module* (SIM) card contains your phone number, service details, and phonebook/message memory.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.



Battery Tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by using non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.





- When charging your battery, keep it near room temperature.
 - When storing your battery, keep it uncharged in a cool, dark, dry place, such as a refrigerator.
 - Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.




Contact your local recycling center for proper battery disposal.

Warning: Never dispose of batteries in a fire because they may explode.


Before using your phone, read the battery safety information in the “Safety and General Information” section included in the gray-edged pages at the back of this guide.

Installing the Battery


1.



2.



3.




Charging the Battery

New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery, as indicated by the following instructions. Some batteries perform best after several full charge/discharge cycles.

Action


- 1 Insert the travel charger plug into your phone with the release tab facing up. Make sure that both of the plug's connector hooks engage to lock the plug in place.
- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
Note: It may take up to 10 seconds for your phone to provide a visible or audible indication that the battery is charging.
- 3 When your phone indicates **Charge Complete**, press the release tab and remove the travel charger.





Tip: You can safely leave the travel charger connected to the phone after charging is complete. This will **not** damage the battery.

Turning Your Phone On


Action

- 1 Open your phone.
- 2 Press and hold the power key  for a few seconds or until the display turns on.




- 3 If necessary, enter your SIM card PIN code and press **OK** () to unlock the SIM card.

Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays **SIM Blocked**.

- 4 If necessary, enter your 4-digit unlock code and press **OK** () to unlock the phone.

Turning Your Phone Off

Action

Press and hold the power key  for 2 seconds to turn the phone off.




Adjusting Volume



Press the up or down volume keys to:



- silence an incoming call alert
- increase or decrease earpiece volume during a call
- increase or decrease ringer volume when the home screen is visible (flip must be open)



Tip: At the lowest volume setting, press the down volume key once to switch to vibrate alert. Press it again to switch to silent alert. Press the up volume key to switch back to vibrate alert, then ring alert.

Making a Call


You must be in the home screen to dial a phone number (see page 45).

Press	To
1 keypad keys	dial the phone number
2 	make the call
3 	end the call and “hang up” the phone when you are finished




Tip: You can also close the phone flip to end the call.

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

When the phone flip is active, open the phone to answer the call. (To activate, press  > **Settings** > **In-Call Setup** > **Answer Options** > **Open to Answer.**)

If the phone flip is **not** active:

Press	To
1  or ANSWER ()	answer the call
2 	end the call and “hang up” the phone when you are finished

Viewing Your Phone Number

To view your phone number from the home screen, press  .

While you are on a call, press  > **My Tel. Numbers.**

Note: Your phone number must be stored on your SIM card to use this feature. To store your phone number on the SIM card, see page 80. If you do not know your phone number, contact your service provider.



Highlight Features



You can do much more with your phone than make and receive calls!

Using a Personal Area Network

You can make and receive calls with your phone using a *personal area network* connection instead of a cellular GSM network connection. To use a personal area network, you must use Bluetooth wireless *pairing* (also called *linking* or *bonding*) to pair your phone with an access point.

Note: Contact your service provider for additional information about using this feature.

Note: Your phone's Bluetooth features and Bluetooth Class 1 power levels are not allowed for outdoor operation in France. To avoid unlawful interference with radio signals, do not use the Bluetooth features in France unless you are indoors.

Pairing With an Access Point



Before you try to pair your phone with an **access point**, make sure the access point device is **on** and **ready** to connect in *pairing* or *bonding*




mode (see the user's guide for the access point). You can pair your phone with only one access point at a time.



Find the Feature

-  > **Settings** > **Connection**
- > **Bluetooth Link**
- > **Access Points**
- > **[Look For Devices]**



Your phone lists the access points within range of the phone.


- 1 Highlight an access point in the list and press **SELECT** ()
- 2 Press **YES** () to pair with the access point.
- 3 Enter the access point passkey and press **OK** ()

When your phone is paired, the Bluetooth indicator  displays in the home screen. After pairing with the access point, the personal area network indicator  displays when you are connected to the personal area network. For more information about the personal area network indicator, see page 47.

Tip: For specific information about an access point device, see the instructions that came with it.

Pairing With Recognized Access Points



Your phone stores the names of previously paired access points, and lists the recognized access points located within range of the phone when you open the **Access Points** menu. If your phone is already paired with an access point, the phone identifies it with an in-use indicator .

To pair with a recognized access point:

Find the Feature

- > Settings > Connection
- > Bluetooth Link
- > Access Points
- > *access point name*



Setting Access Point Priority

You can specify the conditions under which your phone uses a personal area network connection or a GSM network connection to make and receive calls.

Shortcut: From the home screen, press **ACCESS PT.** (+) to set access point priority.

To set the access point priority from the menu:

Find the Feature

- > Settings
- > Access Point Priority

Select one of the following access point priority options:

Option	Description
Access Point Preferred	Your phone automatically connects with an access point when available (default setting).
GSM Preferred	Connect with an available access point only when a GSM network connection is not available.



Option	Description
Access Point Only	Automatically connect with an access point when available. Do not use a GSM network connection.
GSM Only	Do not connect with an available access point.

Note: If Bluetooth power is turned off, your phone automatically turns Bluetooth power on when you set access point priority to **Access Point Preferred**, **GSM Preferred**, or **Access Point Only**. To turn Bluetooth power off, you must set access point priority to **GSM Only**.

Recording and Playing Video Clips

You can record a video clip with your phone, and send it to other wireless phone users in a multimedia message.


Recording a Video Clip

To activate your phone's video camera:

Find the Feature

 > **Multimedia** > **Videos**
> **[New Video]**

The active viewfinder image appears on your display.



Point the camera lens at the video subject, then:

Press	To
1 CAPTURE ()	begin video recording
2 STOP ()	stop video recording
3 STORE ()	view storage options
	If you choose to store the video, continue to step 4.
or	
DISCARD ()	delete the video and return to active viewfinder
4	scroll to Send in Message or Store Only
5 SELECT ()	perform the storage option

Playing a Video Clip


To play a video clip stored on your phone:


Find the Feature


 > **Multimedia** > **Videos**
> *video clip*

The video clip displays in the video clip playback screen.



Press  up or down to pause or play video clip.

Press  left or right to skip to previous or next video clip.



Timer indicates % played.

Press **DETAILS** () to view video clip information.

Press **BACK** () to exit the video player.

Press  to open **Videos Menu**.

Adjusting Video Settings

Press  to open the **Videos Menu** during video recording or playback. The **Videos Menu** can include the following options:



Option	Description
Go To Videos	View video clips stored on your phone.
Send In Message	Insert selected video clip or marked video clips in a new message.
Details	View video clip information.
New	Activate the videocamera to record a new video clip.
Rename	Rename the video clip.
Delete	Delete the selected video clip or all marked video clips.
Move	Move selected video clip or marked video clips to another device, and delete original video(s) from phone memory.
Copy	Copy selected video clip or marked video clips to another device, and leave copy of video(s) on phone.
Mark/Unmark or Mark All/Unmark All	Mark one or more video clips that you want to move, copy, send, or delete.

Option	Description
Categories	Create a new category, or view video clips in a selected category.
Assign To Category	Assign the video clip to a defined category.
Videos Setup	Open the setup menu to adjust video settings.
View Free Space	View memory space available for storing video clips.



Taking and Sending a Photo

To activate your phone's camera:

Find the Feature

 > **Multimedia** > **Camera**

The active viewfinder image appears on your display.

Press  up or down to zoom in or out.

Press  left or right to decrease or increase image brightness.




Photo Storage Space Used

Press **CAPTURE** () to take a photo.

Press **BACK** () to exit the camera application.

Press  to open **Pictures Menu**.



Point the camera lens at the photo subject, then:

Press	To
1 CAPTURE (📷)	take a photo
2 STORE (📷)	view storage options If you choose to store the photo, continue to step 3.
or	
DISCARD (📷)	delete the photo and return to active viewfinder
3 (🔄)	scroll to Send in Message, Store Only, Apply as Wallpaper, Apply as Screen Saver, or Apply as Phonebook Entry
4 SELECT (📷)	perform the storage option



Taking a Self-Portrait

Activate the camera and then press (☰) > **Auto-Timed Capture**. Press (🔄) left or right to set a 5 or 10 second timer delay, then press **START** (📷). Close the flip, and use the mirror to aim the camera lens. When you hear the camera click, open the flip to see your photo.

Adjusting Camera Settings

Press  to open the **Pictures Menu** when the camera is active. The **Pictures Menu** can include the following options:

Option	Description
Go To Pictures	View pictures and photos stored on your phone.
Auto-Timed Capture	Set a timer for the camera to take a photo.
Pictures Setup	Open the setup menu to adjust picture settings.
View Free Space	See how much memory remains for storing pictures.

Sending a Multimedia Message



A *Multimedia Messaging Service* (MMS) multimedia message contains one or more pages with text and embedded media objects (including photos, pictures, animations, sounds, voice records, and video clips). You can send a multimedia message to other wireless phone users, and to email addresses.











Tip: The layout of all pages in a multimedia message is defined by the layout of the first page. To display a media object at the top of the page, insert it in the first half of the

message text. To display a media object at the bottom of the page, insert it in the second half of the message text.

Find the Feature

-  > Messages
- > Create Message
- > New Multimedia Msg







Press	To
1 keypad keys	enter text on the page
2 	open the MMS Menu
3 	scroll to Insert
4 SELECT ()	display a list of items you can insert
5 	scroll to Picture, Voice Record, Sound, Video, New Page, Quick Note, or Contact Info
6 SELECT ()	select the file type
7 	highlight the file you want
8 SELECT ()	insert the file
	To add another page to the message, continue to step 9.
9 	open the MMS Menu to insert a new page
10 	scroll to Insert
11 SELECT ()	display a list of items you can insert



Press	To
12	scroll to New Page
13 SELECT ()	insert a new page after the current page
	Repeat steps 1 to 8 to enter contents for the new page.


When you finish composing the multimedia message:

Press	To
1 OK ()	store the message
2	scroll to a Send To option: Highlight an existing phonebook entry. Or highlight (One Time Entry) to enter one or more phone numbers or email addresses. Or highlight (New Phonebook Entry) to enter a number/address and add it to the phonebook.

Press	To
3 ADD (◀▶)	add a phonebook entry to the list of recipients Repeat steps 2 and 3 to add additional phonebook entries to the list.
or	
SELECT (◀▶)	select [One Time Entry] or [New Phonebook Entry]
4 DONE (◀▶)	store the numbers/addresses
5 	scroll to Subject
6 CHANGE (◀▶)	select Subject
7 keypad keys	enter the subject
8 OK (◀▶)	store the subject
9 CHANGE (◀▶)	select Attachments to attach a file to the message, if desired
10 	scroll to Picture, Sounds, or Video
11 SELECT (◀▶)	select the file type
12 	highlight the file you want
13 SELECT (◀▶)	attach the file
14 BACK (◀▶)	return to the message editor
15 	scroll to Receipt to request a receipt, if desired
16 CHANGE (◀▶)	select Receipt





Press	To
17 ADD (⬠) or REMOVE (⬠)	activate/deactivate the delivery report
18 DONE (⬠)	return to the message editor
19 SEND (⬠)	send the message
or 	view message details, save the message in the drafts folder, or cancel the message

Using Bluetooth® Wireless Pairing

Your phone supports Bluetooth wireless *pairing* (also called *linking* or *bonding*). You can pair your phone with a Bluetooth headset or car kit, or pair your phone with another Bluetooth phone or a computer to exchange and synchronize files.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Note: Your phone's Bluetooth features and Bluetooth Class 1 power levels are not allowed for outdoor operation in France. To avoid unlawful interference with radio signals, do not use the Bluetooth features in France unless you are indoors.

Turning Bluetooth Power On or Off

To turn Bluetooth power on:

Find the Feature

-  > Settings > Connection
- > Bluetooth Link > Setup
- > Power > On



When Bluetooth power is on, your phone can automatically pair with the handsfree device you have used before, when you turn on the device and move it within range of the phone.

Note: To extend battery life, use the above procedure and set Bluetooth power to **Off** when not in use. Your phone will not pair with devices until you set Bluetooth power back to **On** and pair your phone with the devices again.

Pairing With a Headset or Handsfree Device



Before you try to pair your phone with a device, make sure your phone's Bluetooth power is **on** and the device is **on** and **ready** in *pairing* or *bonding* mode (see the user's guide for the device). You can pair your phone with only one device at a time.


Find the Feature

-  > Settings > Connection
- > Bluetooth Link
- > Handsfree
- > [Look For Devices]

If Bluetooth power is turned off, your phone asks if you want to **Temporarily Power On?** the Bluetooth power setting. Press **YES** (☑) to proceed. Alternatively, set **Power** to **On** in the **Setup** menu to turn Bluetooth power on and leave it on.

Your phone lists the devices within range of the phone.

- 1 Highlight a device in the list and press **SELECT** (◊).
- 2 Press **YES** (◊) to pair with the device.
- 3 If necessary, enter the device passkey (such as 0000) and press **OK** (◊).

When your phone is paired, the Bluetooth indicator  displays in the home screen.


Tip: For specific information about a device, see the instructions that came with it.

Copying Objects to Another Device



You can use Bluetooth pairing to copy a media object, phonebook entry, datebook event, or bookmark from your phone to a computer or other device.

Sending a Picture, Sound, or Video

Highlight the media object on your phone that you want to send to the other device, then press  > **Copy**.

Select a recognized device name listed in the **Object Exchange** menu, or **[Look For Devices]** to search for the device to which you want to send the object.











Sending a Phonebook Entry, Datebook Event, or Bookmark

Highlight the item on your phone that you want to send to the other device, then press  > **Send**.





Select a recognized device name listed in the **Object Exchange** menu, or **[Look For Devices]** to search for the device to which you want to send the item.

Advanced Bluetooth® Features



Feature	Description
Make Phone Visible to Other Device	<p>Allow a Bluetooth device to discover your phone:</p> <p> > Settings > Connection > Bluetooth Link > Setup > Find Me</p> 
Pair With Recognized Device	<p>Pair your phone with a recognized handsfree device:</p> <p> > Settings > Connection > Bluetooth Link > Handsfree > <i>device name</i></p> 
Drop Pairing With Device	<p>Highlight the device name and press DROP ().</p> 
Switch to Device During Call	<p>Switch to a headset or car kit during a call:</p> <p> > Use Bluetooth</p> 
Move Multimedia Object to Device	<p>Move a multimedia object to another device:</p> <p>Highlight the object, press  > Move, select the device name.</p> <p>Caution: Moving an object deletes the original object from your phone.</p> 




Feature	Description
Edit Device Properties	<p>Edit the properties of a recognized device:</p> <p>Highlight the device name and press  > Edit.</p> 
Set Bluetooth Options	<p>Set your phone's Bluetooth options:</p> <p> > Settings > Connection > Bluetooth Link > Setup</p> 



Learning to Use Your Phone



See page 1 for a basic phone diagram.



Using the Display

The *home screen* is displayed when you are **not** on a call or using the menu. You must be in the home screen to dial a phone number.



Press the 5-way navigation key  up, down, left, or right to select a menu feature icon. If you select a menu feature by mistake, press  to return to the home screen.

The menu indicator  shows that you can press the menu key  to enter the main menu.


Labels at the bottom corners of the display show the current soft key functions. Press the left soft key  or right soft key  to perform the indicated function.


Notes:


- Your home screen may appear different than shown. For example, the menu feature icons normally are hidden to allow a better view of the wallpaper image. You can still select the menu icons when they are hidden from view. To show or hide menu icons, see page 99.
- Your phone can display an analog or digital clock in the home screen (see page 99).
- Your phone's display normally is visible only when the display backlight is on, or when the display is viewed in direct sunlight. To extend battery life, the backlight turns off automatically when no activity is detected for a specified time. The backlight turns back on when you open the flip or press any key. To set the time that the backlight stays on, see page 79.
- To further extend battery life, you can set the display to turn off (in addition to the backlight) when no activity is detected for a specified time. The display turns back on when you open the flip or press any key. To set the time that the display stays on, see page 80.





The following status indicators can display:





1. Data Indicator – Shows data transmission status. The Bluetooth® indicator  shows when your phone is paired with another device. Other indicators can include:


 = secure packet data transfer

 = unsecure packet data transfer

 = secure application connection


 = unsecure application connection

 = secure *Circuit Switch Data* (CSD) call

 = unsecure CSD call






2. Home Coverage Indicator – The personal area network indicator  flashes when your phone attempts to establish a personal area network connection, and becomes solid when the connection is made. Other indicators can include:



 = *General Packet Radio Service (GPRS)* data connection

 = GPRS PDP context active


 = GPRS packet data available



i

3. Signal Strength Indicator – Vertical bars show the strength of the network connection. You cannot make or receive calls when the no signal indicator  or not transmit indicator  is displayed.



4. Roam Indicator – The roam indicator  shows when your phone is seeking or using another network outside your home network. Other indicators can include:



 = 2.5G home

 = 2.5G roam

 = 2G home


 = 2G roam




5. Active Line Indicator – Shows  to indicate an active call, or  to indicate that call forwarding is on. Indicators for dual-line-enabled SIM cards can include:

 = line 1 active

 = line 2 active

 = line 1 active, call forward on

 = line 2 active, call forward on



6. Messaging Presence Indicator – Shows when instant messaging is active. Indicators can include:

= IM active

= available for IM

= busy

= invisible to IM

= available for phone calls

= offline

When a Java™ application is active, the Java midlet indicator displays in this location.



7. Message Indicator – Displays when you receive a new message. Indicators can include:

= text message

= voicemail message

= voicemail and text message

= IM message

= active chat session

8. Battery Level Indicator – Vertical bars show the battery charge level. Recharge the battery when **Low Battery** displays and the battery alert sounds.

9. Ring Style Indicator – Shows the ring style setting.

= loud ring

= soft ring

= vibrate

= vibrate and ring

= vibrate then ring

= silent






10. Location Indicator – Your phone may be able to send location information to the network during an emergency call. Indicators show when your phone is sending location information:



 = location on


 = location off

Using the 5-Way Navigation Key





Press the 5-way navigation key  up, down, left, or right to scroll through the menu system, highlight menu items, change feature settings, and play games.




Press the *center select* key  in the center of the 5-way navigation key to select a highlighted menu item. The center select key usually performs the same function as the right soft key .



Using Menus










From the home screen, press  to enter the main menu.




Press  to scroll to and highlight a menu feature icon in the main menu. Press **SELECT** () or  to select the highlighted menu feature.





The following icons represent features that may display in the main menu, depending on your service provider and service subscription options.

Menu Icon	Feature	Menu Icon	Feature
	Phonebook		Recent Calls
	Messages		Office Tools
	Games & Apps		Web Access
	Multimedia		IM
	Settings		

Some features require you to select an option from a list:



- Press  to scroll up or down to highlight the option you want.
- In a numbered list, press a number key to highlight the option.

- In an alphabetized list, press a key repeatedly to cycle through the letters on the key and highlight the closest matching list option.
- When an option has a list of possible values, press  left or right to scroll through and select a value.
- When an option has a list of possible numeric values, press a number key to set the value.


Entering Text

Some features require you to enter information.



Scroll down to bottom of list to view more options.

Highlighted option. Press  to scroll to other options.


Press **CHANGE** () to set or edit highlighted option.

Press **CANCEL** () to exit without making changes. **DONE** () displays when you enter or edit information.


Some features let you enter text.

For indicator descriptions, see following section.

Flashing cursor indicates insertion point.



Press  to open sub-menu.

Press **INSERT** () to insert a quick note, picture, or sound.


Press **CANCEL** () to exit without making changes.

Selecting a Text Entry Mode

Multiple text entry modes make it easy for you to enter names, numbers, and messages. The mode you select remains active until you select another mode.

Press  in any text entry screen to select one of the following entry modes:

- | | |
|------------------|---|
| Primary | The primary text entry mode (see below to set). |
| Numeric | Enter numbers only (see page 63). |
| Symbol | Enter symbols only (see page 63). |
| Secondary | The secondary text entry mode (see below to set). |

Alternatively, you can select a text entry mode in any text entry screen by pressing  > **Entry Mode**.


Setting Primary and Secondary Text Entry Modes

You can set different primary and secondary text entry modes, and easily switch between modes when you enter data or compose a message.

Press  > **Entry Setup** in a text entry screen. Select **Primary Setup** or **Secondary Setup**, and choose:

- ITAP** iTAP® software predicts each word as you enter it, to simplify and speed up text entry.
- Tap** Enter letters and numbers by pressing a key one or more times.
- Tap Extended** Enter individual letters, numbers, and symbols by pressing a key one or more times.
- None** Hide the **Secondary** setting if you prefer not to set a secondary text entry mode (only available for **Secondary Setup**).

Using Capitalization

Press  in a text entry screen to change text case. Indicators at the top of the display show the capitalization setting:

abc = no capital letters

ABC = all capital letters

Abc = capitalize next
letter only



Text Entry Mode Indicators

In **Primary** or **Secondary** text entry mode, indicators at the top of the display show the text entry setting:

Primary	Secondary	
1	2	Tap, no capital letters
1↑	2↑	Tap, capitalize next letter only
1↑	2↑	Tap, all capital letters
1	2	iTAP, no capital letters
1↑	2↑	iTAP, capitalize next letter only
1↑	2↑	iTAP, all capital letters




The following indicators identify **Numeric** or **Symbol** entry mode:


123 = numeric mode

@ = symbol mode





Using iTAP® Mode

iTAP mode lets you enter words using one keypress per letter. The iTAP software combines your keypresses into common words, and predicts each word as you enter it.

For example, to enter “the,” you would press   . The iTAP software recognizes that the most common word formed by this keypress combination is “the,” and predicts that “the” is the word you are spelling. Other common words or word fragments that can be spelled by the same keypress combination are presented as alternate choices at the bottom of the display.


If necessary, press  in a text entry screen to switch to **ITAP** mode. An indicator tells you which mode is active (see page 56). If **ITAP** mode is not set as the **Primary** or **Secondary** entry mode, see page 55.

Entering Words i iTAP Mode

Press	To
1 Keypad keys (one press per letter)	show possible letter combinations at the bottom of the display
2  left or right	highlight the combination you want
3  up	accept the predicted word completion, followed by a space
or 	enter the highlighted combination, followed by a space
or SELECT 	select the highlighted combination, with no space
	You can press keypad keys to add more letters at the end of the combination.



For example, if you press    , your phone displays:





If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining characters.

Entering Novel Words in iTAP Mode

You may enter a word that the iTAP software does not recognize. If your word is not shown as a letter combination choice at the bottom of the display:

Action

- 1 Press **DELETE** () one or more times to delete letters, until you see a letter combination at the bottom of the display that matches the start of the word you want to enter.
- 2 Press  left or right to highlight the letter combination.

Action

- 3 Press **SELECT** (⏏) to select the letter combination.
- 4 Continue to enter letters and select letter combinations to spell the word.

Your phone automatically stores the novel word and displays it as an option the next time you enter its letter combination. When the memory space for storing novel words is filled, your phone deletes the oldest words to add new words.

Entering Numbers and Punctuation in iTAP Mode


To enter numbers quickly, press and hold a number key to temporarily switch to numeric mode. Press the number keys to enter the numbers you want. Enter a space to revert to **ITAP** mode.

Press  to enter punctuation or other characters as shown in the “Character Chart” on page 62.

Using Tap Mode





This is the basic text entry mode on your phone.

Tap mode cycles through the letters and number of the key you press. **Tap Extended** mode also cycles through additional symbols as shown in the “Character Chart” on page 62.




If necessary, press  in a text entry screen to switch to **Tap** mode. An indicator shows which mode is active (see page 56). If **Tap** or **Tap Extended** is not set as the **Primary** or **Secondary** entry mode, see page 55.



Tap Mode Text Entry Rules

- Press a keypad key repeatedly to cycle through its characters. For example, you would press  one time to enter “**2**,” two times to enter “**3**,” three times to enter “**4**,” or four times to enter “**5**.”
- After 2 seconds, **Tap** mode accepts the character, and the cursor moves to the next position.
 - The first character of every sentence is capitalized. If necessary, press  down to change the character to lowercase before the cursor moves to the next position.
- Press  to move the flashing cursor to enter or edit message text.
- If you do not want to save your text or text edits, press  to exit without saving.


Entering Words in Tap Mode

	Press	To
1	a keypad key one or more times	select a letter, number, or symbol
2	keypad keys	enter remaining characters
		Tip: Press  right to accept a word completion, or  to insert a space.
3	OK ()	store the text

For example, if you press  one time, your phone displays:

Character displays at insertion point.

Press **DELETE** () to delete last character entered.




After 2 seconds, character is accepted and cursor moves to next position.

Press **OK** () to accept and store text.

When you enter 3 or more characters in a row, your phone may guess the rest of the word. For example, if you enter "prog" your phone might display:

Press  right to accept **program**. Press  to reject it and enter a space after **prog**.
















To enter a different word (such as **progress**), press keys to enter remaining characters.




Character Chart


Use this chart as a guide for entering characters with **Tap Extended** mode.

	. 1 ? ! , @ _ & ~ : ; " - () ' ¿ ¡ % £ \$ ¥ ¤ € + x * / \ [] = > < # §
	a b c 2 ä å á à â ã α β ç
	d e f 3 δ ð é è ê φ
	g h i 4 ģ ĥ î γ
	j k l 5 λ
	m n o 6 ñ ö ø ó ò ô õ ω
	p q r s 7 π β σ
	t u v 8 θ ü ú ù û
	w x y z 9 ξ ψ
	<i>change text case, for capital letters</i>
	<i>enter a space (hold to enter a return)</i>
	<i>change text entry mode (hold for default)</i>

Note: This chart may not reflect the exact character set available on your phone. In an email or Web address editor,  first shows common characters for that editor.




Using Numeric Mode

In a text entry screen, press  to switch entry modes until the numeric indicator **123** displays.

Press the number keys to enter the numbers you want. When you finish entering numbers, press  to switch to another entry mode.

Using Symbol Mode













In a text entry screen, press  to switch entry modes until the symbol indicator **@** displays.


Press	To
1 keypad keys (one press per symbol)	show possible symbol combinations at the bottom of the display
2  left or right	highlight the combination you want
3 SELECT ()	select the highlighted combination You can press keypad keys to add more symbols to the end of the combination.
or 	enter the highlighted combination



Symbol Chart

Use this chart as a guide for entering characters with symbol mode.

	. ? ! , @ _ & ~ : ; " - () ' ¿ ¡ % £ \$ ¥ ¤ €
	@ _ \
	/ : ;
	" & '
	() [] { }
	¿ ¡ ~
	< > =
	\$ £ ¥ ¤ €
	# % *
	+ - x * / = > < # §
	<i>enter a space (hold to enter a return)</i>
	<i>change text entry mode (hold for default)</i>

Note: This chart may not reflect the exact character set available on your phone. In an email or Web address editor,  first shows common characters for that editor.

Deleting Letters and Words


Place the cursor to the right of the text you want to delete, and then:


Action

Press **DELETE** () to delete one letter at a time.

Hold **DELETE** () to delete the entire message.

Using the Smart Key

The *smart key* gives you another way to perform many basic phone functions. It anticipates the next action you are likely to perform. For example, when you highlight a menu item, you can press the smart key to select it. You can use the smart key to make and end calls, turn features on and off, and open your phonebook. The smart key usually performs the same function as the right soft key .



Using the External Display

When the flip is closed, the external display shows time and phone status information. It also displays messages to notify you of incoming calls and other events. You can perform the following functions in the external display.

Setting Phone Ring Style

Press	To
1 volume keys	scroll to Style
2 smart key	select a ring style
3 volume keys	return to the home screen



Returning an Unanswered Call



Your phone keeps a record of your unanswered calls and displays **X Missed Calls** in the external display.

Tip: Because the microphone and earpiece are unavailable when the phone is closed, you must use a headset or other handsfree device with this feature.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Action

- 1 Press the smart key to display the received calls list.

or

Press the volume keys to dismiss the **Missed Calls** message.

-
- 2 If necessary, press the volume keys to scroll through the list and highlight an unanswered call.

-
- 3 If a headset is connected to your phone, press and hold the smart key to call the number.

or

Press the smart key to exit without calling.

Using the Handsfree Speaker

When you activate your phone's integrated handsfree speaker, you can talk to the other party without holding the phone to your ear.

Press **SPEAKER** (📞) to turn the handsfree speaker on or off during a call.

Your phone displays **Spkrphone On** in the home screen. The handsfree speaker remains on until you press **SPEAKER** (📞) again or end the call.

Note: The handsfree speaker is disabled when you connect your phone to a handsfree car kit or headset accessory.

Changing a Code, PIN, or Password

Your phone's 4-digit unlock code is originally set to 1234, and the 6-digit security code is originally set to 000000. Your service provider may reset these codes before you receive your phone.

If your service provider has **not** reset these codes, we recommend that you change them to prevent others from accessing your personal information. The unlock code must contain 4 digits, and the security code must contain 6 digits.

You can also reset your SIM card PIN code, PIN2 code, and/or call barring password if necessary.



To change a code or password:

Find the Feature

 > **Settings** > **Security**
> **New Passwords**

Locking and Unlocking Your Phone

You can lock your phone manually or set the phone to lock automatically whenever you turn it off.


To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, **but you must unlock it to answer.**

You can make emergency calls on your phone even when it is locked (see page 87).

Locking Your Phone Manually

Find the Feature

 > **Settings** > **Security**
> **Phone Lock** > **Lock Now**

	Press	To
1	keypad keys	enter your unlock code
2	OK ()	lock the phone

Unlocking Your Phone

Tip: Your phone's unlock code is originally set to 1234. Your service provider may reset the unlock code to the last 4 digits of your phone number.

At the **Enter Unlock Code** prompt:

Press	To
1 keypad keys	enter your unlock code
2 OK (↵)	unlock your phone

Setting Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature



> **Settings** > **Security**
> **Phone Lock**
> **Automatic Lock** > **On**





Press	To
1 keypad keys	enter your unlock code
2 OK (↵)	activate automatic lock

If You Forget a Code, PIN, or Password

Note: Your phone's 4-digit unlock code is originally set to 1234, and the 6-digit security code is originally set to 000000. Your service provider may reset the unlock code to the last 4 digits of your phone number before you receive your phone.

If you forget your unlock code, try entering 1234 or the last 4 digits of your phone number. If that does not work, do the following at the **Enter Unlock Code** prompt:



Press	To
1 	display the unlock code bypass screen
2 keypad keys	enter your security code
3 OK ()	submit your security code

 **i** If you forget your security code, SIM card PIN code, PIN2 code, or call barring password, contact your service provider.

Using the Phonebook

This section describes basic phonebook operations. For more information about using the phonebook, see page 95.

Storing a Phone Number

Enter a phone number in the home screen, then press **STORE** () to create a phonebook entry with that number. Press **DONE** () to store the number by itself, or fill in the other fields as necessary to complete the entry.

If you assign a **Name** to the phonebook entry, you can select **MORE** to store another number (for example, a work number) for the same **Name**.

Recording a Voice Name

When creating a phonebook entry, scroll to **Voice Name** and press **RECORD** (🗣️). Press and release the voice key and say the entry's name (within 2 seconds). When prompted, press and release the voice key and repeat the name.

Note: This option is not available for entries stored on the SIM card.

Setting a Picture ID for a Phonebook Entry

Press 📖 > **Phonebook** > *entry*, press 📖 > **Edit** > **Picture** > *picture name*.

Also see pages 3 and 34.

Dialing a Number

Press 📖 > **Phonebook**, highlight the phonebook entry, press 📞 to call.



Shortcut: In the phonebook, press a keypad key one or more times to jump to entries that begin with the key's letters.

Voice Dialing a Number


Press and release the voice key, and say the entry's name (within 2 seconds).



Sorting Phonebook Entries

Press  > **Phonebook**, press  > **Setup** > **Sort by**, then select whether you want to sort the phonebook list by **Name**, **Speed No.**, **Voice Name**, or **Email**.

When sorting by name, you can view **All** numbers or just the **Primary** number for each name. To set the primary number for a name, see page 98.

Tip: In **Primary** number view mode, highlight a name and press  left or right to view other numbers associated with the name.

Viewing Entries By Category

Press  > **Phonebook**, press  > **Categories**, then select whether you want to view **All** entries, entries in a predefined category (**Business**, **Personal**, **General**, **VIPs**), or entries in a category you created.

To set the category for a phonebook entry, see page 97.

Setting Up Your Phone

Setting a Ring Style

You can set the following ring style profiles on your phone:

 **Loud**

 **Soft**

 **Vibrate**

 **Vibe & Ring**

 **Vibe then Ring**

 **Silent**

Each profile uses a different set of ring tone alerts or vibration alerts to notify you of incoming calls, text messages, and other events. The **Silent** setting silences your phone until you set another ring style.

To set a ring style:

Find the Feature

 > **Settings** > **Ring Styles**
> **Style** > *style name*

The ring style indicator shows the current ring style setting (see page 49).








Changing the Call Alert

You can change the alert that a ring style uses to notify you of incoming calls or other events. Any changes you make are saved to the ring style profile.

Find the Feature

 > **Settings** > **Ring Styles**
> **Style Detail**

Note: *Style* represents the current ring style. You cannot set an alert for the **Silent** ring style setting.

Press	To
1 	scroll to Calls (scroll to Line 1 or Line 2 for dual-line phones)
2 CHANGE ()	select the event
3 	scroll to the alert you want
4 SELECT ()	select the alert
5 BACK ()	save the alert setting

The ring style profile contains additional settings for other events, and settings for ringer ID, ringer and keypad volume. You can change ring style profile settings as desired to personalize the ring style.

Setting the Time and Date

You must set the time and date to use the datebook.

Find the Feature










 > **Settings** > **Initial Setup**
> **Time and Date**

Setting a Wallpaper Image

Set a photo, picture, or animation as a wallpaper (background) image in your phone's home screen. The wallpaper image appears as a faint watermark in text and menu displays.

Find the Feature

 > **Settings** > **Personalize**
> **Wallpaper**

Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the wallpaper image.
4 SELECT ()	select the image
5 	scroll to Layout
6 CHANGE ()	adjust the image layout
7 	scroll to Center , Tile , or Fit-to-screen Center places the image in the center of the display. Tile fills the display with adjacent copies of the image. Fit-to-screen resizes the image, if necessary, to fit the display.
8 SELECT ()	confirm the layout setting
9 BACK ()	save wallpaper settings



Setting a Screen Saver Image

Set a photo, picture, or animation as a screen saver image. The screen saver image displays when the flip is open and no activity is detected for a specified time. If necessary, the image shrinks to fill the display. An animation repeats for one minute, then the first frame of the animation displays.

Tip: Turn off the screen saver to extend battery life.

Find the Feature



> **Settings** > **Personalize**
> **Screen Saver**

Press	To
1	scroll to Picture
2 CHANGE (open the picture viewer
3 up or down	scroll to a picture/animation Scroll to (None) to turn off the screen saver image.
4 SELECT (select the image
5	scroll to Delay
6 CHANGE (set the delay interval
7	scroll to the inactivity interval that triggers the screen saver
8 SELECT (confirm the delay setting
9 BACK (save screen saver settings



Changing Phone Skin

Change the look and feel of your phone's user interface by selecting a different skin setting.

Find the Feature



> **Settings** > **Personalize**
> **Skin** > *skin*

Your phone displays the new skin.

Setting a Phone Theme



A *phone theme* is of a grouped set of image and sound files with a specific theme (such as a special event or cartoon character) that you can apply collectively to your phone. Phone themes typically include a wallpaper image, screen saver image, and ring tone. Your phone includes several preloaded themes. You can download and install additional themes on your phone.

Downloading a Theme

Note: Normal airtime and/or carrier usage charges apply.

To download a theme from a Web page with the micro-browser, see page 110. When you install the theme, you can instantly apply its screen saver, wallpaper, and ring tone when your phone prompts you to **Apply Theme Now?**

Selecting a Theme

You can apply any of the themes installed on your phone.



Note: If one of a theme's components is not available, then a default setting is applied.

Find the Feature




 > **Multimedia** > **Themes**
> *theme*

Deleting a Theme

You cannot delete the preloaded themes on your phone. To delete one or all of the themes that you have downloaded and installed:

Find the Feature

 > **Multimedia** > **Themes**
> *theme*

Press	To
1 	open the Theme menu
2 	scroll to Delete or Delete All
3 SELECT ()	select the option

Setting Answer Options

You can use additional, alternative methods to answer an incoming call.

Multi-Key

answer by pressing any key





Open to Answer

answer by opening the flip

To activate or deactivate an answer option:

Find the Feature

 > **Settings** > **In-Call Setup**
> **Answer Options**

Press	To
1 	scroll to Multi-Key or Open to Answer
2 CHANGE ()	select the option
3 	scroll to On or Off
4 SELECT ()	confirm the setting

Setting Display Brightness

Find the Feature



> **Settings** > **Initial Setup**
> **Brightness**

Adjusting the Backlight

Set the amount of time that the display and keypad backlights remain on.

Find the Feature



> **Settings** > **Initial Setup**
> **Backlight**

Your phone's display normally is visible only when the display backlight is on, or when the display is viewed in direct sunlight. To extend battery life, the backlight turns off automatically when no activity is detected for a specified time. The backlight turns back on when you open the flip or press any key.



Setting Display Timeout

To further extend battery life, you can set the display to turn off (in addition to the backlight) when no activity is detected for a specified time.

Find the Feature

 > **Settings** > **Initial Setup**
> **Display Timeout**

You can set the display to stay on for 1 or 2 minutes, or set **Off** to disable display timeout.

The display turns back on when you open the flip or press any key.



Storing Your Name and Phone Number



To store or edit your name and phone number information on your SIM card:

Find the Feature

 > **Settings** > **Phone Status**
> **My Tel. Numbers**

Shortcut: Press   from the home screen to view and edit your name and phone number(s).

If you do not know your phone number, contact your service provider.

Calling Features

For basic instructions on how to make and answer calls, see page 24.

Turning Off a Call Alert


You can turn off your phone's incoming call alert before answering the call.

Action

- 1 Press the volume keys to turn off the alert.
- 2 Open the flip (or press the button on a handsfree headset) to answer the call.



Viewing Recent Calls

Your phone keeps lists of incoming and outgoing calls, even for calls that did not connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.





Shortcut: Press  from the home screen to view the dialed calls list.

Find the Feature

 > Recent Calls


Press	To
1 	scroll to Received Calls or Dialed Calls
2 SELECT ()	select the list






Press	To
3 	scroll to an entry Note: ✓ means the call connected.
4 	call the entry's number
or	
VIEW 	view entry details (such as time and date of call)
or	
	open the Last Calls Menu to perform other procedures

The **Last Calls Menu** can include the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Hide ID/Show ID	Hide or show your caller ID for the next call.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent calls lists.

Option	Description
Send Tones	Send the number to the network as DTMF tones. Note: This option displays only during a call.
Talk then Fax	Talk and then send a fax in the same call (see page 106). 



Redialing a Number

Press	To
1 	view the dialed calls list
2 	scroll to the entry you want to call
3 	redial the number

Using Automatic Redial



When you receive a busy signal, your phone displays **Call Failed, Number Busy**.


Press	To
 or RETRY ()	redial the number




When the call goes through, your phone rings or vibrates one time, displays **Redial Successful**, and connects the call.



Returning an Unanswered Call

Your phone keeps a record of your unanswered calls, and displays:

- the missed call indicator 
- **X Missed Calls**, where X is the number of missed calls

	Press	To
1	VIEW ()	display the received calls list
2		select a call to return
3		make the call

Using the Notepad

The most recent set of digits entered on the keypad are stored in your phone's *notepad* memory. This can be a phone number that you called, or a number that you jot down during a call, for later use. To retrieve the number stored in the notepad:

Find the Feature

 > Recent Calls > Notepad



Press

To



call the number

or

STORE (👁)

create a phonebook entry
with the number in the **No.** field

or



open the **Dialing Menu** to attach
a number or insert a special
character

Putting a Call On Hold or Mute

Press

To

> **Hold**

put all active calls on hold

or

> **Mute**

mute all active calls



Using Call Waiting



When you are on a call, an alert tone sounds to indicate that you have received a second call.

Press	To
1	answer the new call
2 SWITCH (switch between calls
or	
LINK (connect the 2 calls
or	
> End Call On Hold	end the call on hold

If necessary, you must turn on call waiting to use the feature. To turn call waiting on or off:

Find the Feature

> **Settings** > **In-Call Setup**
> **Call Waiting**

Using Caller ID (Incoming Calls)



Calling line identification (caller ID) displays the phone number for incoming calls in your phone's external and internal displays.

The phone displays the caller's name (and picture ID, if available) when the name is stored in your phonebook, or **Incoming Call** when caller ID information is not available.




You can also set your phone to play a distinctive ringer ID for specific entries stored in your phonebook. For more information, see page 95.

Calling an Emergency Number


Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Press	To
1 keypad keys	dial the emergency number
2 	call the emergency number

Dialing International Numbers



If your phone service includes international dialing, press and hold  to insert the local international access code (+) for the country from which you are calling. (Inserting + enables your phone to make an international call.) Then press the keypad keys as usual to dial the country code and phone number.





Calling With 1-Touch Dial

To call phonebook entries 1 through 9, press and hold the single-digit speed dial number for one second. (To store phonebook entries on your phone, see page 70.)

You can set 1-touch dial to call the entries in your phone memory phonebook or the SIM card phonebook:

Find the Feature

 > **Settings** > **Initial Setup**
> **1-Touch Dial**

	Press	To
1		scroll to the location you want
2	SELECT 	select the location

Using Voicemail



Voicemail messages that you receive are stored on the network. To listen to your messages, you must call your voicemail phone number.

Note: Your service provider may include additional information about using this feature.


Listening to Voicemail Messages

Find the Feature

 > **Messages** > **VoiceMail**

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store a number.

Receiving a Voicemail Message

When you receive a voicemail message, your phone displays the voicemail message indicator  and the **New VoiceMail** notification.

Press	To
CALL ()	listen to the message

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store a number.

Storing Your Voicemail Number

If necessary, use the following procedure to store your voicemail phone number on your phone. Usually, your service provider has already done this for you.


Find the Feature



> **Messages**



> **VoiceMail Setup**

Press	To
1 keypad keys	enter your voicemail number
2 OK ()	store the number

Note: You cannot store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a phonebook entry for it. Then, you can use the entry to call your voicemail.



Changing the Active Line



Change the active phone line to make and receive calls from your other phone number.

Note: This feature is available only for dual-line-enabled SIM cards.

Find the Feature



> **Settings** > **Phone Status**
> **Active Line**

The active line indicator in the display shows the current active phone line (see page 48).



Phone Features

Main Menu

This is the standard main menu layout. **Menu organization and feature names may vary on your phone.** Not all features may be available on your phone.

Phonebook



Recent Calls

- Received Calls
- Dialed Calls
- Notepad
- Call Times
- Call Cost
- Data Times
- Data Volumes



Games & Apps



Web Access

- Browser
- Web Shortcuts
- Stored Pages
- History
- Go To URL
- Browser Setup
- Web Sessions



Messages

- Create Message
- Email Msgs
- Message Inbox
- Voicemail
- Browser Msgs
- Info Services
- Quick Notes
- Outbox
- Drafts
- MMS Templates



Multimedia

- Videos
- Camera
- Pictures
- Sounds
- Themes
- MotoMixer



IM



Settings

(see next page)



Office Tools

- SIM Apps
- Calculator
- Datebook
- Shortcuts
- Voice Dial
- Voice Records
- Alarm Clock
- Dialing Services
 - Fixed Dial
 - Service Dial
 - Quick Dial
- Chat



Settings Menu



Personalize

- Home Screen
- Main Menu
- Color Style
- Greeting
- Wallpaper
- Screen Saver
- Quick Dial



Ring Styles

- Style
- Style Detail



Connection

- Bluetooth Link
- Sync



Access Point Priority

- Access Point Preferred
- GSM Preferred
- Access Point Only
- GSM Only



Call Forward

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status



In-Call Setup

- In-Call Timer
- Call Cost Setup
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting



Initial Setup

- Time and Date
- 1-Touch Dial
- Display Timeout
- Backlight
- TTY Setup
- Scroll
- Language
- Brightness
- DTMF
- Master Reset
- Master Clear



Phone Status

- My Tel. Numbers
- Credit Info/Available
- Active Line
- Battery Meter
- Other Information



Headset

- Auto Answer
- Voice Dial



Car Settings

- Auto Answer
- Auto Handsfree
- Power-Off Delay
- Charger Time



Network

- New Network
- Network Setup
- Available Networks
- My Network List
- Service Tone
- Call Drop Tone



Security

- Phone Lock
- Lock Application
- Fixed Dial
- Call Barring
- SIM PIN
- New Passwords
- Certificate Mgmt











Java Settings

- Java System
- Delete All Apps
- App Vibration
- App Volume
- App Priority
- App Backlight
- Set Standby App
- DNS IP








Feature Quick Reference

This section helps you locate and use additional phone features that are not described in this guide.







Calling Features

Feature	Description
Conference Call	During a call: Dial next number, press  , press LINK ().
Transfer a Call	During a call:  > Transfer , dial transfer number, press  .
Caller ID (Outgoing)	Hide or show your caller ID phone number for the next outgoing call:  > Settings > In-Call Setup > My Caller ID . > Next Call Only > Hide ID or Show ID
Attach a Number	Dial an area code or prefix for a phonebook number, then:  > Attach Number
Speed Dial	Speed dial and call a phonebook entry: Enter speed dial number, press  , press  .












Feature	Description
Call Forwarding	Set up or cancel call forwarding:  > Settings > Call Forward 
Call Barring	Restrict outgoing or incoming calls:  > Settings > Security > Call Barring 
TTY Calls	Set up your phone for use with an optional TTY device:  > Settings > Initial Setup > TTY Setup  

Messages

Feature	Description
Send Text Message	Send a text message:  > Messages > Create Message > New Short Message 
Send Multimedia Message	Send a multimedia message:  > Messages > Create Message > New Multimedia Msg 
Send Letter	Send a multimedia letter:  > Messages > Create Message > New Letter 




















Feature	Description
Use MMS Template	Open an MMS template with preloaded media:  > Messages > MMS Templates 
Read New Message	Read a new text or multimedia message that you have received: Press READ () when the New Message notification is displayed. 
Read old Messages	Read received messages:  > Messages > Message Inbox Tip: Press  to perform various operations on the message. 
Store Message Objects	Go to a multimedia message page, or highlight an object in a letter, then:  > Store 

Phonebook









Feature	Description
Add New Entry	Add a new entry to the phonebook:  > Phonebook  > New > Phone Number or Email Address





Feature	Description
Dial Number	<p>Call a number stored in the phonebook:</p> <p> > Phonebook, highlight the phonebook entry, press  to call</p>
Voice Dial Number	<p>Voice dial a number stored in the phonebook:</p> <p>Press and release the voice key, and say the entry's name (within 2 seconds).</p>
Set Ringer ID for Entry	<p>Assign a distinctive ringer alert to an entry:</p> <p> > Phonebook > <i>entry</i></p> <p> > Edit > Ringer ID > <i>ringer name</i></p> <p>Note: The Ringer ID option is not available for entries stored on the SIM card.</p> <p>To activate ringer IDs, see page 98.</p>
Set Picture ID for Entry	<p>Assign a photo or picture to a phonebook entry:</p> <p> > Phonebook > <i>entry</i></p> <p> > Edit > Picture > <i>picture name</i></p> <p>Note: The Picture option is not available for entries stored on the SIM card.</p>
Set Picture ID View	<p>View phonebook entries as text list, or with picture caller ID photos:</p> <p> > Phonebook</p> <p> > Setup > View by > <i>view name</i></p>








Feature	Description
Set Category for Entry	Set the category for a phonebook entry:  > Phonebook > <i>entry</i>  > Edit > Category > <i>category name</i> Note: The Category option is not available for entries stored on the SIM card.
Set Category View	Set a phonebook category view:  > Phonebook  > Categories > <i>category view</i>
Set Category Ringer ID	Set a distinctive ring alert (ringer ID) to sound when you receive calls from entries in a specific category:  > Phonebook  > Categories , highlight the category, press  > Edit > Ringer ID . Note: The Ringer ID option is not available for entries stored on the SIM card. To activate ringer IDs, see page 98.
Sort Phonebook List	Set the order in which phonebook entries are listed:  > Phonebook  > Setup > Sort by > <i>sort order</i>





Feature	Description
Set Primary Number or Address	Set the primary number for an entry with multiple numbers:  > Phonebook , highlight the entry, press  > Set Primary > <i>phone number</i> .
Copy Phonebook Entry	Copy a phonebook entry between the phone and SIM card:  > Phonebook , highlight the entry, press  > Copy > Entries > To
Send Phonebook Entry to Another Device	Send a phonebook entry to another phone, computer, or device:  > Phonebook , highlight the entry, press  > Send
Create Group Mailing List	Create a group mailing list as a phonebook entry:  > Phonebook  > New > Mailing List

Personalizing Features








Feature	Description
Activate Ringer IDs	Activate distinctive ring alerts assigned to phonebook entries:  > Settings > Ring Styles > Style Detail > Ringer IDs
Ring Volume	Set ringer volume:  > Settings > Ring Styles > Style Detail > Ring Volume




Feature	Description
Keypad Volume	Set keypad keypress volume:  > Settings > Ring Styles > Style Detail > Key Volume
Reminders	Set reminder alerts for messages that you receive:  > Settings > Ring Styles > Style Detail > Reminders
Clock View	Display an analog clock or digital time readout in the home screen:  > Settings > Personalize > Home Screen > Clock
Menu View	Display the main menu as graphic icons or as a text-based list:  > Settings > Personalize > Main Menu > View
Main Menu	Reorder your phone's main menu:  > Settings > Personalize > Main Menu > Reorder
Show or Hide Menu Icons	Show or hide menu feature icons in the home screen:  > Settings > Personalize > Home Screen > Home Keys > Icons
Change Soft Keys & Menu Icons	Change soft key labels and menu feature icons in the home screen  > Settings > Personalize > Home Screen > Home Keys









Feature	Description
Shortcuts	<p>Create a shortcut to a menu item: Highlight the menu item, then press and hold .</p> <p>Select a shortcut:  > Office Tools > Shortcuts > <i>shortcut name</i></p>

Instant Messaging

Feature	Description
Log In	<p>Log in to instant messaging:  > IM > Log In</p> 
Find Others Online	<p>After you sign on: Select Contact List to see a list of other users.</p> 
Start Conversation	<p>Start a conversation: From your Contact List, highlight a name in Online Contacts, press SEND IM (.</p> 
Open Active Conversation	<p>Open a conversation in progress: From your Contact List, highlight a name in Conversations, press VIEW (.</p> 

Feature	Description
End Conversation	From the conversation display:  > End Conversation 
Log Out	Log out of instant messaging: Select Log Out from the IM Online menu. 

Chat

Feature	Description
Start Chat	Start a new chat session:  > Chat  > New Chat 
Receive Chat Request	When you receive a chat request: Press ACCEPT (◁) or IGNORE (▷). 
End Chat	During a chat session:  > End Chat 

Email

Feature	Description
Send Email Message	Send an email message:  > Messages > Create Message > New Email 



Feature	Description
Read Email Message	Read a new email message that you have received: Press READ (◁).









Menu Features

Feature	Description
Language	Set menu language: ☰ > Settings > Initial Setup > Language
Master Reset	Reset all options <i>except</i> unlock code, security code, and lifetime timer: ☰ > Settings > Initial Setup > Master Reset
Master Clear	Clear all user settings and entries <i>except</i> SIM card information, erase all downloaded pictures and sound files, reset all options <i>except</i> unlock code, security code, and lifetime timer: ☰ > Settings > Initial Setup > Master Clear Caution: Master clear erases all user-entered information (including phonebook and datebook entries) and user-downloaded content (including photos and sounds) stored in your phone's memory. After you erase the information, you cannot recover it.




Special Dialing Features







Feature	Description
Fixed Dial	<p>Turn fixed dialing on or off:  > Settings > Security > Fixed Dial</p> <p>Use the fixed dial list:  > Office Tools > Dialing Services > Fixed Dial</p>
Service Dial	<p>Dial service phone numbers:  > Office Tools > Dialing Services > Service Dial</p>
Quick Dial	<p>Dial preprogrammed phone numbers:  > Office Tools > Dialing Services > Quick Dial</p>
DTMF Tones	<p>Activate DTMF tones:  > Settings > Initial Setup > DTMF</p> <p>Send DTMF tones during a call: Press number keys.</p> <p>Send stored numbers as DTMF tones during a call: Highlight a number in the phonebook or recent calls lists, then press  > Send Tones.</p>



Call Monitoring

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.






The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.

Feature	Description
Call Times	View call timers:  > Recent Calls > Call Times 
In-Call Timer	Display time or cost information during a call:  > Settings > In-Call Setup > In-Call Timer 
Call Cost	View call cost trackers:  > Recent Calls > Call Cost 


Handsfree Features

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain

areas. Always obey the laws and regulations on the use of these products.



Feature	Description
Speaker-phone	Activate a connected external speakerphone during a call: Press SPEAKER (📞) (if available) or 📞 > Spkrphone On . 
Auto Answer (car kit or headset)	Automatically answer calls when connected to a car kit or headset: 📞 > Settings > Car Settings or Headset > Auto Answer 
Voice Dial (headset)	Enable voice dial with headset send/end key: 📞 > Settings > Headset > Voice Dial 
Auto Handsfree (car kit)	Automatically route calls to a car kit when connected: 📞 > Settings > Car Settings > Auto Handsfree 
Power-Off Delay (car kit)	Set the phone to stay on for a period of time after the ignition is switched off: 📞 > Settings > Car Settings > Power-Off Delay 



Feature	Description
Charger Time (car kit)	Charge the phone for a period of time after the ignition is switched off:  > Settings > Car Settings > Charger Time




Data and Fax Calls

Feature	Description
Send Data or Fax	Connect your phone to the device, then place the call through the device application.
Receive Data or Fax	Connect your phone to the device, then answer the call through the device application.
Talk Then Fax	Connect your phone to the device, enter the number, press  > Dialing Menu > Talk Then Fax , then press  to make the call.



Network Features







Feature	Description
Network Settings	View network information and adjust network settings:  > Settings > Network



Personal Organizer Features




Feature	Description
Set Alarm	Set an alarm: ☰ > Office Tools > Alarm Clock
Turn Off Alarm	Turn off alarm: Press DISABLE (◀) or ☰ Set 8-minute delay: Press SNOOZE (▶)
Add New Datebook Event	Add a new event to the datebook: ☰ > Office Tools > Datebook , highlight the day, press ⦿, press ☰ > New
View Datebook Event	View or edit event details: ☰ > Office Tools > Datebook , highlight the day, press ⦿, press VIEW (▶)
Event Reminder	View a datebook event reminder: VIEW (▶) Dismiss an event reminder: EXIT (▶)
Send Datebook Event to Another Device	Send a datebook event to another phone, computer, or device: ☰ > Office Tools > Datebook , highlight the day, press ⦿, highlight the event, press ☰ > Send






Feature	Description
Create Voice Record	Create a voice record: Press and hold voice key, speak into the phone, release voice key. Note: Recording of phone calls is subject to varying State and Federal laws regarding privacy and recording of phone conversations. Always obey the laws and regulations on the use of this feature.
Play Voice Record	Play back a voice record:  > Office Tools > Voice Records > <i>voice record</i>
Calculator	Calculate numbers:  > Office Tools > Calculator
Currency Converter	Convert currency:  > Office Tools > Calculator  > Exchange Rate Enter exchange rate, press OK () enter amount, press  > Convert Currency .











Security





Feature	Description
SIM PIN	Lock or unlock the SIM card:  > Settings > Security > SIM PIN Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays SIM Blocked .
Lock Application	Lock phone applications:  > Settings > Security > Lock Application
Certificate Management	Enable or disable security certificates stored on your phone:  > Settings > Security > Certificate Mgmt

News and Entertainment

Feature	Description
Manage Video Clips	Manage video clips:  > Multimedia > Videos
Manage Pictures	Manage pictures and animations:  > Multimedia > Pictures
Manage Sounds	Manage ring tones and music that you have downloaded or composed:  > Multimedia > Sounds



Feature	Description
Edit Sounds With MotoMixer	Edit MIDI-based sound files that you can use with your phone:  > Multimedia > MotoMixer > [New Mix] or <i>mix file name</i>
Start Micro-Browser	Start a micro-browser session:  > Web Access > Browser 
Download Objects from Web Page	Download a picture, sound, or phone theme from a Web page: Highlight the file, press SELECT (◊), press STORE (◊). Note: Normal airtime and/or carrier usage charges apply. 
Web Sessions	Select or create a Web session:  > Web Access > Web Sessions 
Download Game or Application	Download a Java™ game or application with the micro-browser:  > Web Access > Browser , highlight the application, press SELECT (◊), press DOWNLOAD (◊). Note: Normal airtime and/or carrier usage charges apply. 

Feature	Description
Start Game or Application	Launch a Java game or application:  > Games & Apps , highlight the application, press SELECT (). 
Create Ring Tones	Create ring tones that you can use with your phone:  > Multimedia > Sounds > [New iMelody]



Troubleshooting



If you have questions or need assistance, we're here to help. Go to www.motorola.com/consumer/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

The model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when

tested for use at the ear is 1.02 W/kg, and when worn on the body, as described in this user guide, is 0.50 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

Index

A

- access point connection 26
- accessories 18, 40, 66, 94, 104
- accessory connector port 1
- active line indicator 48
- active line, changing 90
- alarm clock 107
- alert
 - creating 111
 - reminder 99
 - setting 24, 65, 73, 74
 - turning off 24, 81
- animation 36, 75, 76, 109
- answering a call 25, 78
- attach number 82, 93

B

- backlight 79
- barring calls 94
- battery 21, 22
- battery level indicator 49
- battery life, extending 19, 41, 46, 76, 79, 80
- Bluetooth connection
 - indicator 47

Bluetooth wireless 2, 26, 40, 98, 107

bonding. *See* Bluetooth wireless

brightness 79

browser. *See* micro-browser

C

calculator 108

call

alert, turning off 24, 81

answering 25, 78

barring 94

call waiting 86

costs 104

dialing 24, 71, 96

emergency number 87

ending 24, 25

forwarding 94

hold 85

international dialing 87

making 24, 71, 96

mute 85

receiving 25

returning 66, 84

talk then fax 83

timers 104

transferring 93

- call barring password 67
- Call Failed, Number Busy message 83
- call forward indicator 48
- call waiting 86
- caller ID 3, 35, 71, 82, 86, 93, 96
- camera 2, 3, 29, 34, 45
- car kit 104
- center select key 1, 50
- certificate management 109
- character chart 62
- chat 101
- clock 45, 74, 99
- codes 67, 68, 69
- conference call 93
- CSD indicator 47
- cursor 54
- customer support 112

D

- data call 106
- data indicator 47
- date, setting 74
- datebook 107
- dialed calls 81
- dialing a number 24
- dialing a phone number 71, 96, 103

- display
 - backlight 79
 - brightness 79
 - language 102
 - personalizing 99
 - skin 77
 - timeout 80
 - using 45
- download media objects 95, 110
- drafts folder 40
- DTMF tones 83, 103

E

- earpiece volume 24
- email 101
- email address, storing 95
- emergency number 87
- end key 1, 24, 25
- ending a call 24, 25
- Enter Unlock Code message 69, 70
- external display 2, 65

F

- fax call 83, 106
- fixed dial 103
- flip 25, 65, 78
- forwarding calls 94

G

games 110
GPRS indicator 48
group mailing list 98

H

handsfree speaker 2, 67
handsfree use 104
headset 66, 104
Hide ID feature 82
hold call 85
home keys, personalizing
99
home screen 45

I

IM 100
IM indicators 49
in-call indicator 48
Incoming Call message 86
indicators 45, 47, 48, 49,
50, 56, 84, 89
instant messaging. *See* IM
international access code
87
iTAP text entry mode 56

J

Java applications 110
Java midlet indicator 49

K

keypad 78, 99
keys 1, 17, 23, 24, 25, 46,
50, 65, 66, 99

L

language 102
left soft key 1, 46, 99
line, changing 90
linking. *See* Bluetooth
wireless
location indicator 50
lock
application 109
phone 68
SIM card 109
Low Battery message 49

M

making a call 24, 71, 96
master clear 102
master reset 102
menu
entering text 53
icons, changing in home
screen 99
language 102
navigating 51
personalizing 99
selecting feature 52
menu icons 45, 99

menu indicator 45
menu key 1, 17
message 45, 94, 95, 99
message indicator 49
micro-browser 45, 110
missed call indicator 84
Missed Calls message 66,
84
MMS, defined 36
MotoMixer 110
multimedia letter 94
multimedia message 3, 36,
94, 95
music 109, 110
mute call 85
my telephone number 25,
80

N

navigation key 1, 17, 50
network settings 106
notepad 84
number. *See* phone number
numeric entry mode 63

O

object exchange 42, 43
1-touch dial 88
open to answer 78
optional accessory 18
optional feature 18

P

pairing. *See* Bluetooth
wireless
passwords. *See* codes
personal area network 26
personal area network
indicator 48
phone
illustration 1, 2
turning on/off 23
unlocking 68, 69
phone number
active line, changing 90
redialing 83
storing in phonebook 95
storing your number 80
viewing your number 25
phone theme 77
phonebook 45, 70, 82, 88,
93
photo 3, 34, 36, 71, 75, 76,
96, 109
picture 36, 75, 76, 109
picture ID 3, 35, 71, 86, 96
PIN code 67, 109
PIN2 code 67
power key 1, 23
predictive text entry 56

Q

quick dial 103

R

received calls 81
recent calls 81, 82
redial 83
reminders 99
right soft key 1, 46, 99
ring style indicators 49
ring style, setting 24, 65, 73
ring tone 109, 110, 111
ringer ID 96, 97, 98
ringer volume 24, 98
roam indicator 48

S

screen saver 76
security code 67, 69
send key 1, 24, 25
service dial 103
shortcuts 100
Show ID feature 82
signal strength indicator 48
SIM Blocked message 23,
109
SIM card
installing 18
locking 109
PIN code 67, 109
PIN2 code 67
precautions 19

service dial 103
SIM Blocked message
109

skin 77
smart key 1, 65, 66, 99
soft keys 1, 46, 99
song 109, 110
sound 36, 109, 110, 111
speakerphone 104
speed dial 93
Spkrphone On message 67
symbol chart 64
symbol entry mode 63

T

talk then fax call 83
tap text entry mode 59
telephone number. *See*
phone number
text entry 53
text indicators 56
theme 77
time, setting 74
timers 104
transfer a call 93
travel charger 22
troubleshooting 112
TTY device 94

U

unanswered call 66, 84

unlock

 application 109

 phone 68

unlock code 67, 68, 69

V

video clip 3, 29, 36, 109

voice dial 71, 96, 105

voice key 1, 71

voice name, recording 71

voice record 36, 108

voicemail 88

voicemail message indicator

 49, 89

volume

 earpiece 24

 keypad 99

 ringer 24, 98

volume keys 1, 24, 65, 66

W

wallpaper 75

Web pages 110

Web sessions 110

motorola.com