


The **Volume** knob, **DIM** button, **Front/Rear (F/R)** softkey and **Emergency** button remain active on the inactive control head, while all other controls are disabled. Emergency footswitch and VIP inputs remain active on the inactive control head. The VIP input control head is configurable in the CPS and VIP should be attached to the control head selected in the CPS.

**Note:** Only two (2) control heads are supported in the one active mode.



Follow the procedure below to change the command between the two control heads.

**Procedure:**

Press the **Menu Select** button directly below **F/R**.

**OR**

Press the **Menu Select** button preprogrammed user button on the keypad microphone.

## ■ Contacts

---

This feature provides “address-book” capabilities on your radio. Each entry corresponds to an alias (name) or ID (number) that you use to initiate a call.

Contacts manages up to 2,500 contact entries, alphabetically sorted according to entry alias. Each alias can have up to 5 IDs of different call types associated with it.

Additionally, each entry, depending on context (conventional, trunking, or phone), associates with one or more of the four types of calls: Phone Call, Selective Call, Private Call, or Call Alert.

Each entry within Contacts displays the following information:

- Call Alias (Name)
- Call ID (Number)
- Call Type (Icon)
- WACN ID (Astro 25 Trunking IDs only)
- System ID

**Note:** Your radio must be preprogrammed to allow you to add, edit, or delete the contact entries.

Your radio also supports a maximum of 50 call lists. Each list can store up to 100 IDs (numbers).

**Note:** Your radio is preprogrammed with a number of contacts per Call Lists. Check with your dealer or system administrator for more information.

If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

### Making a Private Call from Contacts

**Note:** Your radio must be preprogrammed to allow you to use this feature.

#### **Procedure:**

Use the Options Menu.

- 1 **▶** or **◀** to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS** to the call list. The display shows Contact Alias.
- 3 **▶** or **◀** to the required subscriber alias.
- 4 Press the **Menu Select** button directly below **OPTN**.
- 5 **▶** or **◀** to **CALL** and press the **Menu Select** button directly below **SEL**.
- 6 **▶** or **◀** to select the call type.

- 7 Hold the microphone vertically 1 to 2 inches (2.5 to 5.0 cm) from your mouth.
  - 8 Press the **PTT** button to initiate the call. During the call, the display shows the subscriber alias.
  - 9 Press and hold the **PTT** button to talk. The LED lights up solid red.  
**OR**  
Release the **PTT** button to listen. The LED lights up solid green.
  - 10 If there is no voice activity for a programmed period of time, the call ends.  
**OR**  
The call ends when it reaches the maximum ring time.
- 6 Press the **PTT** button to initiate the call. During the call, the display shows the subscriber alias.
  - 7 Press and hold the **PTT** button to talk. The LED lights up solid red.  
**OR**  
Release the **PTT** button to listen. The LED lights up solid yellow.
  - 8 If there is no voice activity for a preprogrammed period of time, the call ends.  
**OR**  
The call ends when it reaches the maximum ring time.

**OR**

Use the **PTT** button:

- 1 **▶** or **◀** to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS**.
- 3 **▶** or **◀** to the required subscriber alias.
- 4 Press the **Menu Select** button directly below **CNTS**. The display shows Contact Alias.
- 5 Hold the microphone vertically 1 to 2 inches (2.5 to 5.0 cm) from your mouth.

## Adding a New Contact Entry



### Procedure:

- 1 ▶ or ◀ to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.
- 3 ▶ or ◀ to [**NEW CONTACT**] and press the **Menu Select** button directly below **SEL**.
- 4 The display shows **NAME**. Press the **Menu Select** button directly below **EDIT**.  
Use the keypad to enter the name.  
Press ◀ to move one space to the left.  
Press ▶ to move one space to the right.  
Press the **Menu Select** button below **DEL** to delete any unwanted characters.  
Press (\*) to add a space.  
Press (0) to toggle between mixed case mode, uppercase mode, and lowercase mode.  
Press (#) to toggle between numeric and letter mode.
- 5 Press the **Menu Select** button directly below **OK** once you have entered the name.  
**OR**  
Press the **Menu Select** button directly below **CNCL** to return to the previous screen.

- 6 ▶ or ◀ to [**ADD NUMBER**] and press the **Menu Select** button directly below **SEL**. The display shows **TYPE 1 <DEFAULT TYPE>**.
- 7 Press **Menu Select** button directly below **EDIT**.
- 8 ▶ or ◀ to the required channel and press the **Menu Select** button directly below **OK**.
- 9 ▶ or ◀ to **NUMBER 1** and press the **Menu Select** button directly below **EDIT**.  
The display shows **NUMBER 1** and a cursor appears.  
Use the keypad to enter the number.  
Press ◀ to move one space to the left.  
Press ▶ to move one space to the right.  
Press the **Menu Select** button directly below **DEL** to delete any unwanted characters.
- 10 Press the **Menu Select** button directly below **OK** once you have entered the number.  
**OR**  
Press the **Menu Select** button directly below **CNCL** to return to the previous screen.
- 11 Press the **Menu Select** button directly below **DONE** once you have finished.
- 12 The display shows **<ENTRY> STORED**, confirming that the contact entry has been added.
- 13 The radio returns to the main Contacts screen.

## Deleting a Contact Entry



### Procedure:

- 1  or  to **CNTS**.



---

- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.

---

- 3  or  to the entry you want to delete and press the **Menu Select** button directly below **OPTN**.

---

- 4  or  to **DELETE** and press the **Menu Select** button directly below **SEL**. The display shows **<ENTRY> CONFIRM DEL?**.



---

- 5 Select **YES** to delete the entry. The display shows **<ENTRY> DELETED** and the radio returns to the main screen for Contacts.  
**OR**  
Select **NO** to return to the main screen for Contacts.

---

## Adding a Contact to a Call List or Phone List



### Procedure:

- 1  or  to **CNTS**.



---

- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.





---

- 3  or  to the entry you want to add to the call list and press the **Menu Select** button directly below **OPTN**.

---

- 4  or  to **ADD TO CALLST** or **ADD TO PHONLST** and press the **Menu Select** button directly below **SEL**.

---

- 5  or  until the display shows **[AVAILABLE]** and press the **Menu Select** button directly below **ADD** to add as a new entry.  
**OR**  
 or  until the display shows **<ENTRY>** and its associated number and press the **Menu Select** button directly below **RPLC** to replace the existing entry.

---

- 6 The display shows **<ENTRY> ADDED**, confirming the addition of the contact to the list.

---

- 7 The radio returns to the main display for Contacts.

---

## Editing a Contact in a Call List or a Phone List

### Editing an Entry Alias

#### Procedure:

- 1 **▶** or **◀** to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.
- 3 **▶** or **◀** to the entry you want to edit and press the **Menu Select** button directly below **OPTN**.
- 4 **▶** or **◀** to **EDIT** and press the **Menu Select** button directly below **SEL**.
- 5 **▶** or **◀** to the entry alias you wish to change and press the **Menu Select** button directly below **EDIT**.
- 6 A cursor appears.  
Use the keypad to edit the name.  
Press **◀** to move one space to the left.  
Press **▶** to move one space to the right.  
Press the **Menu Select** button below **DEL** to delete any unwanted characters.  
Press **(\*)** to add a space.  
Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.  
Press **(#)** to toggle between numeric and letter mode.

- 7 Press the **Menu Select** button directly below **OK** once you have finished. The display returns to the Edit Contact screen.
- 8 Press the **Menu Select** button directly below **DONE** to save your changes and return to the main screen for Contacts.

### Editing as Entry ID

#### Procedure:

- 1 **▶** or **◀** to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.
- 3 **▶** or **◀** to the entry you want to edit and press the **Menu Select** button directly below **OPTN**.
- 4 **▶** or **◀** to **EDIT** and press the **Menu Select** button directly below **SEL**.
- 5 **▶** or **◀** to the entry ID you wish to change and press the **Menu Select** button directly below **EDIT**.
- 6 A cursor appears.  
Use the keypad to edit the number.  
Press **◀** to move one space to the left.  
Press **▶** to move one space to the right.  
Press the **Menu Select** button below **DEL** to delete any unwanted characters.

Press **\*** to add a space.  
Press **0** to toggle between mixed case mode, uppercase mode, and lowercase mode.  
Press **#** to toggle between numeric and letter mode.

- 7 Press the **Menu Select** button directly below **OK** once you have finished. The display returns to the Edit Contact screen.
- 8 Press the **Menu Select** button directly below **DONE** to save your changes and return to the main screen for Contacts.

## *Editing a Call Type*

### **Procedure:**

- 1 **▶** or **◀** to **CNTS**.
- 2 Press the **Menu Select** button directly below **CNTS**. The entries are alphabetically sorted.
- 3 **▶** or **◀** to the entry you want to edit and press the **Menu Select** button directly below **OPTN**.
- 4 **▶** or **◀** to **EDIT** and press the **Menu Select** button directly below **SEL**.
- 5 **▶** or **◀** to **TYPE** and press the **Menu Select** button directly below **EDIT**.
- 6 **▶** or **◀** to choose from the list of call types given and press the **Menu Select** button directly below **OK** to select.
- 7 The display returns to the Edit Contact screen.
- 8 Press the **Menu Select** button directly below **DONE** to save your changes and return to the main screen for Contacts.

## ■ Scan Lists

Scan lists are created and assigned to individual channels/groups. Your radio scans for voice activity by cycling through the channel/group sequence specified in the scan list for the current channel/group.

Your radio can support up to 200 different scan lists. These lists must be preprogrammed by a qualified radio technician.

### 📄 Viewing a Scan List

#### Procedure:

- 1 **▶** or **◀** to **SCNL**.

---

- 2 Press the **Menu Select** button directly below **SCNL**.

---

- 3 **▶** or **◀** to view the members on the list.

---

- 4 Press the **🏠** to exit the current display and return to the Home screen.

---

### 📄 Editing the Scan List

This feature lets you change scan list members and priorities.

**Note:** The maximum number of members for a trunking priority monitor scan list is 50; for a conventional scan list, 30; and for a talkgroup scan list, 250.

#### Procedure:

- 1 **▶** or **◀** to **SCNL**.

---

- 2 Press the **Menu Select** button directly below **SCNL**. The display shows the lists that can be changed.

---

- 3 **▶** or **◀** to the entry you want to edit.

---

- 4 Press the **Menu Select** button directly below **SEL** to add and/or change the priority of the currently displayed channel in the scan list.  
**OR**  
 Press the **Menu Select** button directly below **DEL** to delete the currently displayed channel from the scan list.  
**OR**  
 Press the **Menu Select** button directly below **RCL** to view the next member of the scan list.


---

- 5 **▶** or **◀** to select more channels to be added or deleted.  
**OR**  
 Use the keypad to go directly to additional channels to be added or deleted.  
**OR**



Use the **Mode Knob** to select additional channels to be added or deleted.

---

- 6 Press  to exit scan list programming and return to the Home screen.
- 



See **Viewing and Changing the Priority Status** on page 50 for more information on how to add and/or change the priority of the currently displayed channel in the scan list.

### Changing the Scan List Status



#### Procedure:

- 1 Long press the preprogrammed **Scan** side button.



---

- 2  or  to the member you want to edit.

---

- 3 Press the  button or press the **Menu Select** button directly below **SEL** once to add the currently displayed channel to the scan list.  
**OR**  
Press the  button or press the **Menu Select** button directly below **SEL**, one or more times to change the scan list status icon of the currently displayed channel.


---

- 4  or  to select more list members whose scan status you want to change.  
**OR**  
Use the keypad to go directly to that scan list member.

#### **OR**

Use the **Mode Knob** to select another scan list member.

---

- 5 Press  to exit scan list programming and return to the Home screen.
-

## 📄 Viewing and Changing the Priority Status

### Procedure:

1 Below the **SEL**, **DEL**, and **RCL** screen, press the **Menu Select** button directly below **SEL** to view and/or change the priority status of the currently displayed channel.

**OR**

Below the **SEL**, **DEL**, and **RCL** screen, press the ✓ button or press the **Menu Select** button directly below **SEL**, one or more times to view and/or change the scan list status icon of the currently displayed channel.

2 A Scan icon indicates that the current channel is in the scan list as a non-priority channel. The LED lights up solid green.

**OR**

A Priority-Two Channel Scan icon indicates that the current channel is in the scan list as the Priority-Two channel. The LED blinks green.

**OR**

A Priority-One Channel Scan icon indicates that the current channel is in the scan list as the Priority-One channel. The LED rapidly blinks green. You hear all traffic on the Priority-One channel, regardless of traffic on non-priority channels.

**OR**

No icon indicates that the current channel is deleted from the scan list.

## ■ Scan

This feature allows you to monitor traffic on different channels by scanning a preprogrammed list of channels.

### 📄 Turning Scan On or Off

#### Procedure:

Press the preprogrammed **Scan** button.

**OR**

Follow the procedure below.

1 ▶ or ◀ to **SCAN**.

2 Press the **Menu Select** button directly below **SCAN**.

3 The display shows **SCAN OFF** if scan is disabled. Press the **Menu Select** button directly below **SCAN** to enable scan.



**OR**

The display shows **SCAN ON** and the scan status icon if scan is enabled. Press the **Menu Select** button directly below **SCAN** to disable scan.

4 The radio returns to the Home screen.

## Turning Scan On While Disregarding the Squelch Code (Conventional Channels Only)

### Procedure:

- 1  or  to **MON**.

---

- 2 Press the **Menu Select** button directly below **MON**.

---

- 3 The brief **MONITOR ON** display indicates that the radio is disregarding the squelch code.

---

*While scanning for activity, you can still receive fleetwide, system-wide, dynamic regrouping, incoming telephone interconnect and Private Conversation/Call Alert calls.*

*Respond to these types of calls as you would normally on the selected channel. However, when scanning different channels while in talkgroup scan, incoming Private Conversation/Call Alert calls may be missed.*

## Transmitting While the Scan is On

### Radio Programmed for Talkback Scan

#### Procedure:

- 1 Press the **PTT** button to transmit on the channel indicated by the display.

---

*The radio does not begin scanning again for a predetermined hang time after you release the **PTT** button, allowing the other party to respond. If the other party responds within the hang time, scanning does not resume until the full hang time expires after they have finished speaking, allowing the conversation to be completed.*


*To transmit on the selected channel if another channel is active, first turn scan off by pressing the **Menu Select** button below **SCAN** momentarily.*

### Radio Programmed for Non-Talkback Scan

#### Procedure:

- 1 Press the **PTT** button at any time to transmit on the selected channel or fixed channel.

---

*To make a Call Alert page, or Private Conversation call while scanning, press either the **Menu Select** button directly below **PAGE** or **CALL**. The call is entered on the selected channel and scanning is halted until the call is exited by pressing  or pressing the **Menu Select** button below either **PAGE** or **CALL**.*

## Deleting a Nuisance Channel

If a channel continually generates unwanted calls or noise (termed a “nuisance” channel), you can temporarily remove the unwanted channel from the scan list.

This capability does not apply to priority channels or the designated transmit channel.

### Procedure:

- 1 When the radio is locked onto the channel to be deleted, **▶** or **◀** to **NUIS**.
- 2 Press the **Menu Select** button directly below **NUIS**.

## Restoring a Nuisance Channel

### Procedure:

To restore the deleted nuisance channel, do **one** of the following:

- Turn scan off, then on.  
**OR**
- Change modes.  
**OR**
- Turn off the radio, and then turn it back on.

*Nuisance mode delete can be disabled by the system administrator.*

## Changing Priorities Status While Scan is On

While the radio is scanning, the dynamic priority change feature allows you to temporarily change any channel in a scan list (except for the Priority-One channel) to the Priority-Two channel.

This change remains in effect until scan is turned off. Scan then reverts to the preprogrammed (original) setting.

### Procedure:

- 1 Press the **Menu Select** button directly below **DYNP** to change the priority of a non-priority channel in the scan list to Priority-Two.
- 2 Press **⏠** momentarily to exit the scan list and resume scanning.

## Restoring Priorities in a Scan List

### Procedure:

To restore the original channel priorities in a scan list, do one of the following:

- Turn scan off, then on.  
**OR**
- Change channels.  
**OR**
- Turn off the radio, and then turn it back on.

## Hang Up (HUB)

To temporarily suspend Scan Mode operation, remove the control head from the Hang Up Box (HUB). You are allowed to use the control head while scan is suspended. However, Priority Member scanning is not suspended. This feature applies to all Scan Lists and Scan Types. Scan is resumed once the control head is returned to the holding clip and the preprogrammed hang time has elapsed.

**Note:** Priority Scan List members are continuously scanned only when the Scan List, **Designated Tx Member** field is set to “Talkback” in the radio programming. Otherwise, all scan mode operation is suspended.

## Call Alert Paging

---

This feature allows your radio to work like a pager.

Even if other users are away from their radios, or if they are unable to hear their radios, you can send them an individual Call Alert page. You can also verify if a radio is active on the system.

Depending on how your radio is programmed, when you make an Enhanced Private Call, the radio either automatically sends a Call Alert page if there is no answer after the maximum ring time, **OR** when you press the **PTT** button.

**Note:** This feature must be preprogrammed by a qualified radio technician.

 **Receiving a Call Alert Page****Procedure:**

When you receive a Call Alert page

- 1 You hear four repeating alert tone and the green LED blinks.  
**OR**  
You hear one alert tone and the green LED blinks if Call Alert Tone Auto Reset is enabled.
- 2 The call received icons blinks and the display shows **PAGE RECEIVED**.
- 3 Press the **PTT** button to answer.  
**OR**  
Press any button to clear the Call Alert page.

See *Making a Talkgroup Call* on page 29 or *Making a Private Call (Trunking Only)* on page 30 for more information.

 **Sending a Call Alert Page**





**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

**Procedure:**

Press the preprogrammed **Quick Access (One-Touch) Call Alert Paging** button to send a page to the preprogrammed ID and proceed to Step 5 of the procedure below.

**OR**

Follow the procedure below.

- 1  or  to **PAGE**.
- 2 Press the **Menu Select** button directly below **PAGE**.
- 3  or  to select the required ID.
- 4 Press the **PTT** button to send the page.
- 5 The display shows **PAGING...<NUMBER>** or **<ALIAS>**.
- 6 If the call alert page is sent successfully, four highpitch tone sounds and the display shows **ACK RECEIVED**.  
**OR**  
If the call alert page is not acknowledged, a low tone sounds and the display shows **NO ACKNOWLEDGE**.
- 7 The radio returns to the Home screen.  
**OR**

Press the **Menu Select** button directly below **OK** to return to the main screen for Contacts.

### OR

Follow the procedure below.

- 1 **▶** or **◀** to **CALL**.
- 2 Press the **Menu Select** button directly below **CALL**.
- 3 **▶** or **◀** to select the required ID, press the **PTT** button to initiate the call.
- 4 If the target radio does not respond after a preprogrammed period of time, the display shows **SEND PAGE?**.
- 5 Press the **Menu Select** button directly below **YES** to send the call alert page.  
**OR**  
Press the **Menu Select** button directly below **NO** to exit the screen without sending the call alert page.
- 6 The display shows **PAGING...<ALIAS>**.
- 7 If the call alert page is sent successfully, a tone sounds and the display shows **ACK RECEIVED**.  
**OR**  
If the call alert page is not acknowledged, a low tone sounds and the display shows **NO ACKNOWLEDGE**.
- 8 The radio returns to the Home screen.  
**OR**

Press the **Menu Select** button directly below **OK** to return to the main screen for Contacts.

### In-Call User Alert

You can enable and disable voice transmission, if needed.

#### Procedure:

- 1 Make sure you are in Home mode where the default zone and mode are being displayed.
- 2 **▶** or **◀** to scroll to the **VMUT**.
- 3 Press the **Menu Select** button directly below **VMUT**.
- 4 Press the **Menu Select** button directly below **VMUT** or the **VMut** preprogrammed button again to turn the feature off and you will be able to hear to normal dispatch calls.

*Pressing the **Menu Select** button directly below **VMUT** or the **VMut** programmed button momentarily toggles between Voice mute on and Voice mute off. **VOICE MUTE ON** shown on the display indicates that the radio is muted to all conventional dispatch calls and affiliated trunking group calls.*

## ■ Emergency Operation

---

The Emergency feature is used to indicate a critical situation.

If the **Orange** button is preprogrammed to send an emergency signal, this signal overrides any other communication over the selected channel.

Your radio supports 5 Emergency modes:

- Emergency Call
- Emergency Alarm
- Emergency Alarm with Call
- Silent Emergency Alarm
- Special Considerations for Emergencies

Check with your dealer or system administrator for more information on the programming of this feature.

Only **one** of the Emergency modes above can be assigned to the preprogrammed **Emergency** button or the **Emergency** footswitch.

**Note:** To exit emergency at any time, press and hold the preprogrammed Emergency button for about a second.

## Sending an Emergency Alarm

This feature allows you to send a data transmission, which identifies the radio sending the emergency, to the dispatcher.

### Procedure:

- 1** Press the preprogrammed **Emergency** button. A tone sounds and the display alternates **EMERGENCY** and the home display.
- 2** A dispatcher acknowledgment **ACK RECEIVED** display follows.  
**AND, Trunking Only:**  
A high-pitched tone indicates that the alarm has been received by the trunked system's central controller.
- 3** Press and hold the emergency button or the **PTT** button to return to normal operation.



## Sending an Emergency Call (Trunking Only)

### Procedure:

- 1 Press preprogrammed **Emergency** button.

---

- 2 A tone sounds and the display alternates **EMERGENCY** and the home display.  
**OR**  
A short low-pitched tone sounds when the selected channel does not support emergency.

---

- 3 Hold the microphone vertically 1 to 2 inches (2.0 to 2.5 cm) from your mouth.

---

- 4 Press and hold the **PTT** button. Speak clearly into the microphone.

---

- 5 Release the **PTT** to end the transmission.

---

- 6 Press and hold the preprogrammed Emergency button until a tone sounds to exit Emergency mode.

---

## Sending an Emergency Alarm with Emergency Call

This feature allows you to send an Emergency Alarm to another radio. Upon acknowledgement, both radios can communicate over a preprogrammed Emergency channel.

If the radio has both emergency call and alarm features enabled, it automatically proceeds to the call mode after the alarm is acknowledged.

### Procedure:

- 1 Press the preprogrammed **Emergency** button to activate the emergency call/alarm feature.

---

- 2 The display alternates **EMERGENCY** and the home display.

---

- 3 A high-pitched tone sounds, indicating that the alarm has been received by the trunked system's central controller. A dispatcher acknowledgment (four high-pitched tones) follows, accompanied by an **ACK RECEIVED** display.

---

- 4 Hold the microphone vertically 1 to 2 inches (2.0 to 2.5 cm) from your mouth.

---

- 5 Press and hold the **PTT** button. Speak clearly into the microphone.

---

- 6 Release the **PTT** to end the transmission.

---

- 7 Press and hold the preprogrammed Emergency button until a tone sounds to exit Emergency mode.

---

*Turning the radio off also cancels the emergency state.*

## Sending a Silent Emergency Alarm

This feature allows you to send an Emergency Alarm to another radio without any audio or visual indicator.

Upon acknowledgement, your radio's microphone is automatically activated, allowing you to communicate with the other radio without pressing the **PTT** button.

This activated microphone state is also known as “**hot mic**”.

**Note:** If you press the PTT button during hot mic, and continue to press it after the hot mic duration expires, the radio continues to transmit until you release the PTT button.

### Procedure:

- 1 Press the preprogrammed **Emergency** button to activate the silent alarm feature.
- 2 Press and hold the emergency button until a tone sounds to exit the silent alarm mode.

*If silent emergency alarm is used with emergency call, pressing the **PTT** button exits the silent mode and initiates the emergency call.*

## Special Considerations for Emergencies

- If you press the emergency button while in a channel that has no emergency capability, a low-pitched tone sounds.
- If the unit is out of the range of the system and/or the emergency alarm is not acknowledged, a tone sounds and the display shows **NO ACKNOWLEDGE**.
- If you press the emergency button, then change to a mode that has no emergency capability, the display shows **NO EMERGENCY** and a continuous low-pitched tone sounds until a valid emergency mode is selected or until the emergency is cancelled.
- When an emergency is active, changing to another mode where emergency is enabled (trunked or conventional) causes an emergency alarm and/or emergency call to be active on the new mode.

## ■ Automatic Registration Service (ARS)

This feature provides an automated data application registration for the radio. When you turn on the radio, the device automatically registers with the server.

Data applications within the fixed network can determine the presence of a device on the system and send data to the device. For example: Text Messaging Service (TMS).

The Automatic Registration Service for the radio consists of two (2) modes:

- ARS Server Mode (default mode)
- ARS Non Server Mode

**Note:** The default ARS mode can be changed by a qualified radio technician using the radio's programming software.

## 📄 Selecting or Changing ARS Mode

### Procedure:

- 1 After the zone you want is displayed, toggle until the display shows the required channel.

**OR**

Press and hold **▶** or **◀** to **CHAN**.

Press the **Menu Select** button directly below **CHAN**.

The display shows the current zone is not blinking, and the channel is blinking.

- 2 **▶** or **◀** or rotate the **Mode Knob** to the required channel.

- 3 In ARS Server Mode, the display shows the User Login Indicator icon, the zone, and **ARSSVR**.

**OR**

In ARS Non-Server Mode, the display shows the User Login Indicator icon, the zone, and **NONSVR**.

**OR**

If the channel or mode selected is unprogrammed, the display shows **UNPROGRAMMED**. Repeat Step 2.

- 4 Press **🏠** to confirm the displayed zone and channel.

## Accessing the User Login Feature

This feature allows you as the user to be associated with the radio. With this association, every data application (Example: Text Messaging Service) takes on a friendly username.

You can still send text messages without logging in as a user. The user login feature only enables the recipient of your message to identify you as the sender by assigning a username to your message.



**Note:** Valid characters for a username entry are capital letters (A – Z), small letters (a – z), numbers (0 – 9), symbols (\*, #, -, /), and the space character.

The maximum length for a username is eight (8) characters. Usernames are not case sensitive in server mode but are case sensitive in non-server mode.

A predefined username may sometimes be invalid because the programming software that is used to set predefined usernames allows you to set usernames comprising of eight (8) characters or more.

## Logging In as a User





### Procedure:

- 1  or  to **USER**.

---
- 2 Press the **Menu Select** button directly below **USER**.

---
- 3 The display shows the User Login screen.

---
- 4 Press the **Menu Select** button directly below **ID**.

---
- 5 A blinking cursor appears beside **ID**. Use the keypad to enter a username using the keypad multi-tap function.  
**OR**  
 or  to scroll through the list of predefined usernames. Press the **Menu Select** button to select a predefined username.  
**OR**  
Press and hold  or  to scroll through the list of predefined usernames at a fast scroll rate. Press the **Menu Select** button directly below **LOGN** to select a predefined username.

---
- 6 If the selected predefined username has more than eight (8) characters, or an invalid character in it, the display momentary shows **INVALID ID**. Repeat Step 5.  
**OR**  
Press the **Menu Select** button directly below **PIN**.

---
- 7 A blinking cursor appears beside **PIN**. Enter your Personal Identification Number (PIN) number.

The maximum PIN length is 4 digits. The PIN number will appear as asterisks.

- 8 Press the **Menu Select** button directly below **LOGN**.
- 9 In ARS server mode, the display shows the User Login Indicator icon, the ID, **IN PPROGRESS** and **CNCL**.  
**OR**  
In ARS non-server mode, the display shows the User Login Indicator icon, the ID, **LOGGED IN** and **LOGT**.  
In non-ARS enabled mode, the display shows **OFFLINE** and **LOGT**.
- 1 If the username is invalid, login fails and the user login failure indicator (IP indicator) icon blinks. The display also momentary shows **LOGIN FAILED**. Repeat step 5.  
**OR**  
If the PIN is invalid, login fails and the user login failure indicator (IP indicator) icon blinks. The display also momentary shows **LOGIN FAILED**. Repeat Step 7.  
**OR**  
Press the **Menu Select** button directly below **CNCL** to cancel the login in progress screen and return to the initial user login screen.  
**OR**  
Wait for the logged in confirmation screen. If the login process is successful, the display shows the successful user login indicator (IP indicator) icon and **LOGGED IN** and **LOGT**.

## **Logging Out**

Once the data application registration is completed, you can log out.

### **Procedure:**

- 1 **▶** or **◀** to **LOGT**.
- 2 Press the **Menu Select** button directly below **LOGT**.
- 3 Display shows the User Login Indicator icon and **CLEAR PRIVATE DATA?**.
- 4 Select **YES** to clear all your private data. The display shows momentary **PRIVATE DATA CLEARED**.  
**OR**  
Select **NO** to keep your private data.

**Note:** Private data refers to all messages in the text messaging Inbox, Draft and Sent folder. The next radio user will be able to access your Inbox, Draft and Sent messages if private data is not deleted.

## ■ Text Messaging Service (TMS)

---

This feature allows you to send and receive text messages. The **maximum** length of characters for a text message is **200**.

There are three (3) types of text messages:

- A new text message (free form message)
- A predefined message (quick text message)
- An edited quick text message

The main menu consists of the following options:

- Inbox
- Compose
- Drafts
- Sent

**Note:** See **Status Icons** on page 18 for more details on the TMS icons and **TMS Menu Options** on page 19 for more details on each menu option.

## 📄 Accessing TMS Feature

**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

Press the **Menu Select** button directly below **BACK** at any time to return to the previous screen.

### **Procedure:**

Press the preprogrammed **Data Feature** button or the **TMS** button to access the TMS feature screen.

### **OR**

Press and hold the preprogrammed **Data Feature** button or the **TMS** button to access the Inbox screen.

### **OR**

Follow the procedure below.

- 1** ▶ or ◀ to **TMS**.

---

- 2** Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.

---

- 3** ▶ or ◀ to scroll through the main menu options.

---

## Composing and Sending a New Text Message

**Note:** During the uppercase and lowercase mode, multi-tapping the keys only scrolls through the letters. For example, **A**->**B**->**C**, **a**->**b**->**c**.

During the num lock mode, except for **1**, pressing the keypad only enters the numeric digits. Subsequent presses of the same key inserts the same digit to the text message (no multi-tap).

### Procedure:

- 1 **▶** or **◀** to **TMS**.

---

- 2 Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.

---

- 3 Press the **Menu Select** button directly below **COMP** to see the compose options.

---

- 4 Press the **Menu Select** button directly below **NEW** to compose a new message.

---

- 5 A blinking cursor appears on the **Compose** screen. Use the keypad to type or edit your message.
  - Press **◀** to move one space to the left.
  - Press **▶** to move one space to the right.
  - Press the **Menu Select** button directly below **DEL** to delete any unwanted characters.
  - Press **(\*)** to add a space.

Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.

Press **(#)** to toggle between numeric and letter mode.

- 6 Press the **Menu Select** button directly below **OPTN** once the message is composed.

---

- 7 **▶** or **◀** to **SEND** and press the **Menu Select** button directly below **SEND** to send.
 

**OR**

**▶** or **◀** to **BACK** and press the **Menu Select** button directly below **BACK** to return to Compose screen if you want to edit the message.

---

- 8 **▶** or **◀** to scroll through the address list and press the **Menu Select** button below **SEL** to select the required address.
 

**OR**

**▶** or **◀** to **[OTHER RECPNT]** and press the **Menu Select** button below **EDIT**.

A blinking cursor appears in the **ENTER ADDRESS** screen. Use the keypad to type the address entry.

Press **◀** to move one space to the left.

Press **▶** to move one space to the right.

Press the **Menu Select** button below **DEL** to delete any unwanted characters.

Press **(\*)** to add a space.

Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.

Press **(#)** to toggle between numeric and letter mode.

9 Press the **Menu Select** button below **SEND** to send the message.

**OR**

Press the **PTT** button to send the message.

---

10 The display shows the **SEND MESSAGE** screen and **SENDING MSG.**

---

11 If the message is sent, a tone sounds and the display shows **MSG SENT.**

**OR**

If the message is not sent, a low tone sounds and the display shows **SEND FAILED.**

---

*If the message fails to send, the radio returns you to the main TMS screen.*

**Note:** You can append a priority status and/or a request reply to your message. See *Using the Priority Status and Request Reply Features* on page 66 for more information.

**Note:** You can also select the **DRFT** option to save your message in the Drafts folder to send it at a later time. See *Accessing the Drafts Folder* on page 70 for more details.

## Sending a Quick Text Message

Quick Text messages are messages that are predefined and usually consist of messages that are used most frequently.

Each Quick Text message has a **maximum** length of 50 characters.

### **Procedure:**

Press the preprogrammed **Quick Text** button and proceed to Step 3.

**OR**

Follow the procedure below.

1  or  to **TMS.**

---

2 Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.



---

3 Press the **Menu Select** button directly below **COMP** to access the compose options.

---

4  or  to **LIST.**

---

5  or  to scroll through the list of messages and press the **Menu Select** button directly below **SEL** to select the required message.

---

6 The message appears on the **Compose** screen, with a blinking cursor at the end of it.  
Use the keypad to edit the message.

Press  to move one space to the left.



Press **▶** to move one space to the right.  
 Press the **Menu Select** button directly below **DEL** to delete any unwanted characters.  
 Press **(\*)** to add a space.  
 Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.  
 Press **(#)** to toggle between numeric and letter mode.

---

**7** Press the **Menu Select** button directly below **OPTN**.

**8** **▶** or **◀** to **SEND** and press the **Menu Select** button directly below **SEL** to send the message.

**9** **▶** or **◀** to scroll through the address list and highlight the required address.

**OR**

**▶** or **◀** to **[OTHER RECPNT]** and press the **Menu Select** button below **EDIT**.

A blinking cursor appears in the **ENTER ADDRESS** screen. Use the keypad to type the address entry.

Press **◀** to move one space to the left.

Press **▶** to move one space to the right.

Press the **Menu Select** button below **DEL** to delete any unwanted characters.

Press **(\*)** to add a space.

Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.

Press **(#)** to toggle between numeric and letter mode.

---

**10** Press the **Menu Select** button below **SEND** to send the message.

**OR**

Press the **PTT** button to send the message.

---

**11** The display shows the screen and **SENDING MSG**.

---

**12** If the message is sent, a tone sounds and the display shows **MSG SENT**.

**OR**

If the message is not sent, a low tone sounds and the display shows **SEND FAILED**.

---

*If the message fails to send, the radio returns you to the main TMS screen.*

**Note:** You can append a priority status and/or a request reply to your message. See **Using the Priority Status and Request Reply Features** on page 66 for more information.

## Using the Priority Status and Request Reply Features

Before sending your message, you can append a priority message and/or a request reply to your message.

### *Appending or Removing a Priority Status to a Text Message*

**Note:** The Priority Message icon on a message does not imply that the message gets higher priority over the other messages when it is being transmitted. It is just an indication that can be embedded into a message to let the receiver know that the message is important.

#### **Procedure:**

After the outgoing message is composed (see **Composing and Sending a New Text Message** on page 63 for more information):

- 1 Press the **Menu Select** button directly below **OPTN**.

---

- 2 Press the **Menu Select** button directly below **IMPT**.  
The priority status icon appears beside the normal message icon on the label bar.

---

- 3 Press the **Menu Select** button directly below **IMPT** again.  
The priority status icon and the normal message icon disappear from the label bar.

---

### *Appending or Removing a Request Reply to a Text Message*

#### **Procedure:**

After the outgoing message is composed (see **Composing and Sending a New Text Message** on page 63 for more information):

- 1 Press the **Menu Select** button directly below **OPTN**.

---

- 2 Press the **Menu Select** button directly below **RQRP**.  
The reply status icon appears beside the normal message icon on the label bar.

---

- 3 Press the **Menu Select** button directly below **RQRP** again.  
The reply status icon and the normal message icon disappear from the label bar.

---

### *Appending a Priority Status and a Reply Request to a Text Message*

#### **Procedure:**

After the outgoing message is composed (see **Composing and Sending a New Text Message** on page 63 for more information):

- 1 Press the **Menu Select** button directly below **OPTN**.

---

- 2 **▶** or **◀** to **IMPT** and press the **Menu Select** button directly below **IMPT** to indicate the message as important.  
**AND**

▶ or ◀ to **RQRP** and press the **Menu Select** button directly below **RQRP** to request for a reply.

---

- 3** The priority status and reply status icons appear beside the normal message icon on the label bar.
- 

### **Removing a Priority Status and a Reply Request from a Text Message**

When an outgoing message is indicated with priority status and reply status icons, follow the procedure below to remove these indicators.

#### **Procedure:**

- 1** Press the **Menu Select** button directly below **OPTN**.

---

- 2** ▶ or ◀ to **IMPT** and press the **Menu Select** button directly below **IMPT** to remove the priority status icon.  
**AND**  
▶ or ◀ to **RQRP** and press the **Menu Select** button directly below **RQRP** to remove the reply status icon.

---

- 3** The priority status, reply status and normal message icons disappear from the label bar.

---

## **Managing Text Messages**

### **Receiving a Text Message**

**Note:** When you receive a message that is flagged with the "Request Reply" icon, you must manually respond to the sender that you have received the message. The system will not automatically send back a notification that the radio has received such message.

#### **Procedure:**

When you receive a message, press and hold the preprogrammed **Data Feature** button or the **TMS Feature** button to access the Inbox and go to Step3.

#### **OR**

Follow the procedure below.

- 1** The new message icon appears and the display momentarily shows **NEW MSG**.

---

- 2** Press the **Menu Select** button directly below **TMS** to access the message.

---

- 3** The display shows alias or ID with the sender of the latest received message on top.

---

## Viewing a Text Message from the Inbox

The Inbox can hold up to thirty (30) messages.

**Note:**   ▶ or ◀ to read the message if fills more than one screen.

### **Procedure:**

Press the preprogrammed **Data Feature** button or the **TMS Feature** button to access the TMS feature screen, and proceed to Step 3.

### **OR**

Press and hold the preprogrammed **Data Feature** button or the **TMS Feature** button to access the Inbox screen and proceed to Step 4.

### **OR**

Follow the procedure below.

- 1   ▶ or ◀ to **TMS**.

---

- 2   Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.

---

- 3   Press the **Menu Select** button below **INBX** to view Inbox feature screen.

---

- 4   The display shows alias or IDs, with the sender of the latest received message.

---

*While on the review message screen, press the **Menu Select** button directly below **RPLY**, **DEL**, or **BACK** to access the option.*

- Select **RPLY** to reply the message.
- Select **DEL** to delete the message.
- Select **BACK** to return to the previous screen.

**Note:**   The icon at the top right corner of the screen indicates the status of the message. See **Text Messaging Service (TMS)** on page 62 for more information.

## **Replying to a Received Text Message**

**Note:** The original date and time stamp, address and message content is automatically appended to the reply message.

### **Procedure:**

- 1 **▶** or **◀** to the required aliases or ID and press the **Menu Select** button below **SEL** to view the message.

---

- 2 Press the **Menu Select** button directly below **RPLY** to reply to a message.

---

- 3 **▶** or **◀** to **NEW** and press the **Menu Select** button directly below **NEW**.  
**OR**  
**▶** or **◀** to **LIST** and press the **Menu Select** button directly below **LIST** for a predefined message.  
**OR**  
**▶** or **◀** to scroll through the list of messages and press the **Menu Select** button directly below **SEL** to select the required message.

---

- 4 A blinking cursor appears on the screen.  
**OR**  
The predefined message appears on the **Compose** screen, with a blinking cursor at the end of it.

---

- 5 Use the keypad to type or edit your message.  
Press **◀** to move one space to the left.

Press **▶** to move one space to the right.

Press the **Menu Select** button below **DEL** to delete any unwanted characters.

Press **(\*)** to add a space.

Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.

Press **(#)** to toggle between numeric and letter mode.

- 6 Press the **Menu Select** button directly below **OPTN** once you have finished writing the message.

---

- 7 **▶** or **◀** to **SEND** and press the **Menu Select** button directly below **SEND** to send the message.

---

- 8 The display shows the **Send Message** screen and **SENDING MSG**.





*Press the **Menu Select** button directly below **BACK** at any time to return to the previous screen.*

**Note:** You can append a priority message and/or a request reply to your message. **Using the Priority Status and Request Reply Features** on page 66 for more information.

## Accessing the Drafts Folder

This folder stores the messages that were saved previously. The Drafts folder can hold up to 10 messages. The oldest draft in the folder is deleted when the 11th message comes in.

### Procedure:

- 1  or  to **TMS**.
- 2 Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.
- 3  or  to **DRFT** and press the **Menu Select** button below **DRFT**.
- 4 The display shows the first draft message.

Press the **Menu Select** button directly below **EDIT**, **DEL**, or **BACK** to access the option.

- Select **EDIT** to edit the message before sending it.
- Select **DEL** to delete the message.
- Select **BACK** to return to the previous screen.

## Managing Sent Text Messages

Once a message is sent to another radio, it is saved in the Sent folder. The most recent sent text message is always added to the top of the Sent list.

The Sent folder is capable of storing a maximum of ten (10) last sent messages. When the folder is full, the oldest text message in the folder is deleted when the 11th message comes in.

## Viewing a Sent Text Message





The icon at the top right corner of the screen indicates the status of the message. See **Text Messaging Service (TMS)** on page 62 for more information.

### Procedure:

Press the preprogrammed **Data Feature** button or the **TMS Feature** button to access the TMS feature screen, and proceed to Step 3.

### OR

Follow the procedure below.

- 1  or  to **TMS**.
- 2 Press the **Menu Select** button directly below **TMS** to access the TMS feature screen.
- 3  or  to **SENT** and press the **Menu Select** button below **SENT**.

Press the **Menu Select** button directly below **OPTN**, **DEL**, or **BACK** to access the option.

- Select **OPTN** to send to the message.
- Select **DEL** to delete the message.
- Select **BACK** to return to the previous screen.

**Note:** The icon at the top right corner of the screen indicates the status of the message. See **Text Messaging Service (TMS) Icons** on page 18 for more information.

### Sending a Sent Text Message

#### Procedure:

- 1 Press the **Menu Select** button directly below **OPTN** while viewing the message.
- 2 **▶** or **◀** to **SEND** and press the **Menu Select** button directly below **SEND** to send the message.
- 3 **▶** or **◀** to scroll through the address list and highlight the required address.  
**OR**  
**▶** or **◀** to **[OTHER RECPNT]** and press the **Menu Select** button below **EDIT**.  
A blinking cursor appears in the **ENTER ADDRESS** screen.  
Use the keypad to type the address entry.  
Press **◀** to move one space to the left.

Press **▶** to move one space to the right.

Press the **Menu Select** button below **DEL** to delete any unwanted characters.

Press **(\*)** to add a space.

Press **(0)** to toggle between mixed case mode, uppercase mode, and lowercase mode.

Press **(#)** to toggle between numeric and letter mode.

- 4 Press the **Menu Select** button below **SEND** or the **PTT** button to send the message.
- 5 The display shows the **Send Message** screen and **SENDING MSG**.
- 6 Press the **Menu Select** button directly below **BACK** to return to the previous screen.

**Note:** You can append a priority message and/or a request reply to your message. See **Using the Priority Status and Request Reply Features** on page 66 for more details.

## **Deleting Text Messages**

### **Procedure:**

From the Inbox, Draft, or Sent screen:

- 1 **▶** or **◀** to scroll through the messages.
- 2 Press the **Menu Select** button directly below **DEL** to view the delete options.
- 3 Press the **Menu Select** button directly below **CURR** to delete the current message.  
**OR**  
Press the **Menu Select** button directly below **ALL** to delete all the messages.

## **Secure Operations**

Secure radio operation provides the highest commercially available level of voice security on both trunked and conventional channels.

Unlike other forms of security, Motorola digital encryption provides signaling that makes it virtually impossible for others to decode any part of an encrypted message.

### **Managing Encryption**

**Note:** Refer to the Key-Variable Loader (KVL) manual for equipment connections and setup.

### **Loading a Single Encryption Key**

#### **Procedure:**

- 1 Attach the KVL to your radio. Upon attaching the KVL, the radio display shows **KEYLOADING**.
- 2 Press the **Menu Select** button below **TARGET**.
- 3 Press the **Menu Select** button below **LOAD**.
- 4 Press the **Menu Select** button below **KEY**.
- 5 **▶** or **◀** to required key.
- 6 Press the **Menu Select** button below **LOAD** to load the key to your radio.



- 7 When the key has been loaded successfully, the radio sounds a short tone for single-key radios.

### **Loading the Group Encryption Keys**

#### **Procedure:**

- 1 Attach the KVL to your radio.
- 2 Press the **Menu Select** button below **TARGET**.
- 3 Press the **Menu Select** button below **LOAD**.
- 4 Press the **Menu Select** button below **GROUP**.
- 5 **▶** or **◀** to required group.
- 6 Press the **Menu Select** button below **LOAD** to load the key to your radio.
- 7 Your mobile radio display shows **KEYLOADING** when it is loading key(s) from KVL.
- 8 When the key has been loaded successfully, the radio sounds an alternating tone for multikey radios.

### **Using the Multikey Feature**

This feature allows the radio to be equipped with as many as 64 different encryption keys and supports the DES-OFB algorithm.

There are two types of multikey:

- **Conventional Multikey** – The encryption keys can be tied (strapped), on a one-per-channel basis, through Customer Programming Software. In addition, you can have operator-selectable keys, operator-selectable keysets, and operator-selectable key erasure. If talkgroups are enabled in conventional, then the encryption keys are strapped to the talkgroups.
- **Trunked Multikey** – If you use your radio for both conventional and trunked applications, you have to strap your encryption keys for trunking on a per-talkgroup or announcement-group basis. In addition, you may strap a different key to other features, such as dynamic regrouping, failsoft, or emergency talkgroup. You can have operator-selectable key erasure.

## **Selecting an Encryption Key (Conventional Only)**

### **Procedure:**

- 1 **▶** or **◀** to **KEY**.

---

- 2 Press the **Menu Select** button directly below **KEY**. The display shows the last user-selected and stored encryption key, and the available menu selections.

---

- 3 **▶** or **◀** to scroll through the encryption keys.  
**OR**  
Use the keypad to enter the number of the desired key.

---

- 4 Press the **Menu Select** button directly below **SEL** to save the newly selected key and return to the Home screen.  
**OR**  
Press **⏠**, the **PTT** button, or the **Menu Select** button directly below **EXIT** to exit.

---

**Note:** If the selected key is erased, a momentary keyfail tone sounds and the display shows **KEY FAIL**.  
**OR**  
If the selected key is not allowed, a momentary illegal key tone sounds and the display shows **ILLEGAL KEY**.

## **Enabling Secure Transmission**

### **Procedure:**

- 1 **▶** or **◀** to **SEC** and Press the **Menu Select** button directly below **SEC**. The display shows **🔒** and the current key if multi-key has been enabled.

---

- 2 Monitor the mode to be sure it is not in use.

---

- 3 Press **PTT** button to transmit.

---

**Note:** If the selected channel is preprogrammed for clear-only operation – when you press the **PTT** button, an invalid mode tone sounds and the display shows **CLEAR TX** only.

The radio does not transmit until you disable the secure mode.

## **Accessing the Secure Feature**

### **Procedure:**

- 1 **▶** or **◀** to **SEC**.

---

- 2 Press and hold the **Menu Select** button directly below **SEC** to display Secure feature screen.

---

- 3 The display shows the **Secure** screen.


---

## **Selecting a Keypad**



This feature allows you to select one or more groups of several encryption keys from among the available keys stored in the radio.

For example, you could have a group of three keys structured to one keypad, and another group of three different keys structured to another keypad; by changing keypads, you would automatically switch from one set of keys to the other.

Every channel to which one of the original keys was tied now has the equivalent new key instead.

**Note:** Press , the **PTT** button, or the **EXIT** menu selection to exit this menu at any time without changing the keypad selection.



### **Procedure:**

- 1  or  to **KSET**.

---

- 2 Press the **Menu Select** button directly below **KSET**.  
The display shows the last user-selected and stored keypad, and the available keypad menu selections.

---

- 3  or  to scroll through the keypads.  
**OR**  
Use the keypad to enter the number of the desired keypad.

---

- 4 Press the **Menu Select** button directly below **SEL** to save the newly selected keypad.

---



- 5 The radio exits keypad selection and returns to the Home screen.

---

## **Erasing the Selected Encryption Keys**

This feature allows you to erase all or selected encryption keys.



### **Procedure:**

- 1  or  to **ERAS**.

---

- 2 Press the **Menu Select** button directly below **ERAS**. The display shows the last user-selected and stored encryption key, and the available menu selections.

---

- 3  or  to the desired encryption key.  
**OR**  
Use the keypad to enter the number of the desired key.

---




- 4 Press the **Menu Select** button directly below **ALL** to delete all keys.  
**OR**  
Press the **Menu Select** button directly below **SNGL** to delete current shown key.  
**OR**  
Press the **Menu Select** button directly below **ABRT** to abort this screen and return to Home screen.

---

## Requesting an Over-the-Air Rekey

This feature, also known as **OTAR**, allows the dispatcher to reprogram the encryption keys in the radio remotely. The dispatcher performs the rekey operation upon receiving a rekey request from the user.

### Procedure:

- 1  or  to **REKY**.
- 2 Press the **Menu Select** button directly below **REKY**.
- 3 Press the **PTT** button to send the rekey request.  
**OR**  
Press the **PTT** button again, or the  or **Emergency** button, to exit the feature and transmit in normal mode.
- 4 If the rekey operation fails, a bad-key tone sounds and the display shows **REKEY FAIL**.

**Note:** The rekey operation failure indicates that your radio does not contain the Unique Shadow Key (USK). This key must be loaded into the radio with the key-variable loader (KVL) before the rekey request can be sent.

Refer to your local key management supervisor for more information.

## The Global Positioning System (GPS)

This feature uses information from the Global Positioning System (GPS) satellites orbiting the Earth to determine the approximate geographical location of your radio, expressed as latitude and longitude. The availability and accuracy of this location information (and the amount of time that it takes to calculate it) varies depending on the environment in which you are using the GPS feature.

For example, GPS location fixes are very difficult to obtain indoors, in covered locations, between high buildings, or in situations where you have not established a clear broad view of the sky.

### Understanding the GPS Feature

The GPS technology uses radio signals from earth orbiting satellites, to establish the location co-ordinates, maximizing your view of clear unobstructed sky is essential for optimum performance.

Where adequate signals from multiple satellites are not available (usually because you cannot establish a view of a wide area of the sky), the GPS feature of your radio will not work. Such situations include but are not limited to:

- In underground locations
- Inside of buildings, trains, or other covered vehicles

- Under any other metal or concrete roof or structure
- Between tall buildings or under dense tree-cover
- In temperature extremes outside the operating limits of your radio

Even where location information can be calculated in such situations, it may take longer to do so, and your location estimate may not be as accurate. Therefore, in any emergency situation, always report your location to your dispatcher.

**Note:** Even where adequate signals from multiple satellites are available, your GPS feature only provides an approximate location, usually within 20 meters from your actual location, but sometimes further away.

Keep in mind that the accuracy of the location information and the time it takes to obtain it varies depending upon circumstances, particularly the ability to receive signals from an adequate number of satellites.

**Note:** The satellites used by the GPS feature are controlled by the U.S. government and are subject to changes implemented in accordance with the Department of Defense GPS user policy and the Federal Radio Navigation Plan. These changes may affect the performance of the GPS feature on your radio.

## Enhancing GPS Performance

Sometimes, the GPS feature may be unable to complete a location calculation successfully. You then see a message indicating that your radio cannot connect to enough visible satellites.

To maximize the ability of your radio to determine a fix, please note the following guidelines:

- For your initial fix, hold the radio in the face position.
- Stay in the open. The GPS feature works best where there is nothing between your radio and a large amount of open sky.

## The Outdoor Location Feature (Using GPS)

This feature allows you to determine your current location using a location menu, as well as your current distance and bearing in relation to another location. Radio location may be requested and reported over-the-air.

Your radio stores up to a maximum of sixty (60) programmable location coordinates, also known as waypoints. When the memory is full, the next waypoints automatically replaces the oldest waypoints in the radio.

The radio also stores four (4) preprogrammed waypoints. These coordinates cannot be deleted.



Programmable Waypoints	Preprogrammed Waypoints
User-configurable location coordinates.	Fixed location coordinates: <ul style="list-style-type: none"> <li>• Home</li> <li>• Emergency</li> <li>• Last Known Location</li> <li>• Destination</li> </ul>
Only the alias is editable, not the coordinates.	The Home and Destination coordinates are editable.
Coordinates can be deleted one at a time, or all at once.	Coordinates cannot be deleted.

**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

## Accessing the Outdoor Location Feature

**Note:** An **ON** menu key may be present on the location menu if it is preprogrammed by the dealer or system administrator.

### Procedure:

- 1  or  to **LOC**.



---

- 2 Press the **Menu Select** button directly below **LOC**. The display shows **LOCATION OFF <LATITUDE>**.

---

- 3 Press the **Menu Select** button directly below **ON** to turn on the GPS. The display shows **PREVIOUS LOC <LATITUDE>**.

---

- 4  or  to check the longitude, time and date of the last successful location fix.

---

- 5 Press the **Menu Select** button directly below **RFSH** to obtain a new location fix.

---

- 6 The top line temporarily displays **PLEASE WAIT** while the new location is being determined. While the new location is being determined, the location signal can be a solid or blinking icon.


---

- 7 Once the location coordinates are fixed, the display shows the current latitude. Toggle to see the longitude, time and date. The location coordinates are updated automatically every five seconds while the location signal is present.

---

- 8 Press the **Menu Select** button directly below **EXIT** to exit the feature and return to the main screen.



**OR**

Press  or the **PTT** button (if preprogrammed) to exit this menu.

---

**OR**



Follow the procedure below to turn off the GPS (This feature is enabled by a qualified radio technician.):

- 1  or  to **LOC**.

---

- 2 Press the **Menu Select** button directly below **LOC**. The display shows **PREVIOUS LOC <LATITUDE>**.



---

- 3  or  to check the longitude, time and date of the last successful location fix.

---

- 4 Press the **Menu Select** button directly below **OPTN**.

---

- 5  or  to **TURN OFF GPS** (if preprogrammed).


---

- 6 Press the **Menu Select** button directly below **SEL** to turn off the GPS. The display shows **LOCATION OFF**.

---

- 7 Press the **Menu Select** button directly below **EXIT** to exit the feature and return to the main screen.

**OR**

Press  or the **PTT** button (if preprogrammed) to exit this menu.

---

*The radio also exits the menu if the emergency button is pressed.*



## Saving a Waypoint

### Procedure:






While in the current location display:

- 1 Press the **Menu Select** button directly below **OPTN**.

---


  - 2  or  to **SAVE AS WAYPT** and press the **Menu Select** button directly below **SEL**.

---

  - 3 A blinking cursor appears in the screen. Use the keypad to type the alias via multi-tap.  
Press  to move one space to the left.  
Press  to move one space to the right.  
Press the **Menu Select** button below **DEL** to delete any unwanted characters.  
Press  to add a space.  
Press  to toggle between mixed case mode, uppercase mode, and lowercase mode.  
Press  to toggle between numeric and letter mode.

---








  - 4 Press the **Menu Select** button directly below **OK** once you are done. The display shows **SAVED AS <WAYPOINT NAME>**.
- OR**
- Press the **Menu Select** button directly below **CNCL** to return to previous screen.
-

- 5 Press  or the **PTT** button (if preprogrammed) to exit this menu.
- 

### **Viewing a Saved Waypoint**

#### **Procedure:**












While in the current location display:

- 1 Press the **Menu Select** button directly below **OPTN**.
  - 2  or  to **WAYPOINTS**.
  - 3 Press the **Menu Select** button directly below **SEL**.
  - 4  or  to desired waypoint.
  - 5 Press the **Menu Select** button directly below **OPTN**. The display shows **VIEW**.
  - 6 Press the **Menu Select** button directly below **SEL**.
  - 7  or  again to view longitude, time and date the waypoint was detected.
  - 8 Press the **Menu Select** button directly below **BACK** to return to previous Waypoint screen.  
**OR**  
Press  or the **PTT** button (if preprogrammed) to exit this menu.
- 

### **Editing the Alias of a Waypoint**


#### **Procedure:**

While in the current location display:

- 1 Press the **Menu Select** button directly below **OPTN**.
- 2  or  to **WAYPOINTS**.
- 3 Press the **Menu Select** button directly below **SEL**.
- 4  or  to desired waypoints.
- 5 Press the **Menu Select** button directly below **OPTN**.
- 6  or  to **EDIT NAME** and press the **Menu Select** button directly below **SEL**.
- 7 A blinking cursor appears in the **Edit Name** screen. Use the keypad to edit the alias.  
Press  to move one space to the left.  
Press  to move one space to the right.  
Press the **Menu Select** button below **DEL** to delete any unwanted characters.  
Press  to add a space.  
Press  to toggle between mixed case mode, uppercase mode, and lowercase mode.  
Press  to toggle between numeric and letter mode.
- 8 Press the **Menu Select** button directly below **OK** once you are done.  
**OR**













Press the **Menu Select** button directly below **CNCL** to return to the Waypoints main screen.

- 9 The display shows <WAYPOINT NAME> UPDATED.
- 10 Press  or the **PTT** button (if preprogrammed) to exit this menu.




### *Editing the Coordinates of a Waypoint*

#### Procedure:

While in the current location display:

- 1 Press the **Menu Select** button directly below **OPTN**.
- 2  or  to **WAYPOINTS** and press the **Menu Select** button directly below **SEL**.
- 3  or  to desired waypoints.
- 4 Press the **Menu Select** button directly below **OPTN**.
- 5  or  to **EDIT LOCATION** and press the **Menu Select** button directly below **SEL**.
- 6 The first number blinks.  
Press  to move to the previous number/coordinates.  
Press  to move to the next number/coordinates.  
Press  or  to change the North (N), South (S), East (E) or West (W) direction.

Press the **Menu Select** button below **EDIT** to change the number/coordinates.

- 7 A blinking cursor appears in the **EDIT LOCATION** screen.  
Press  to move one space to the left.  
Press  to move one space to the right.  
Press the **Menu Select** button below **Del** to delete any unwanted characters.
- 8 Press the **Menu Select** button directly below **OK** once you are done.  
**OR**  
Press the **Menu Select** button directly below **CNCL** to return to the previous screen.
- 9 Press the **Menu Select** button directly below **OK** once you are done with the new coordinates.  
**OR**  
Press the **Menu Select** button directly below **CNCL** to return to the previous screen then skip to step 11.
- 10 The display shows **[HOME] UPDATED** and the radio returns to the Waypoints main screen.  
**OR**  
The display shows **[DESTINATION] UPDATED** and the radio returns to the Waypoints main screen.
- 11 Press  or the **PTT** button (if preprogrammed) to exit this menu.

## **Deleting a Single Saved Waypoint**

### **Procedure:**

While in the current location display:

- 1** Press the **Menu Select** button directly below **OPTN**.

---

- 2** **▶** or **◀** to **WAYPOINTS**.

---

- 3** Press the **Menu Select** button directly below **SEL**.

---

- 4** **▶** or **◀** to desired waypoints.

---

- 5** Press the **Menu Select** button directly below **OPTN**.  
**OR**  
Press the **Menu Select** button directly below **DEL** and then skip to step 7.

---

- 6** **▶** or **◀** to **DELETE** and press the **Menu Select** button directly below **SEL**.

---

- 7** The display shows **<WAYPOINT NAME> CONFIRM DEL?**.

---

- 8** Press the **Menu Select** button directly below **YES** to delete. The display shows **<WAYPOINT NAME> DELETED**.  
**OR**  
Press the **Menu Select** button directly below **NO** to return to previous Waypoint screen.

---

- 9** Press **⏠** or the **PTT** button (if preprogrammed) to exit this menu.

---

## **Deleting All Saved Waypoints**

### **Procedure:**

- 1** Press the **Menu Select** button directly below **OPTN**.

---

- 2** **▶** or **◀** to **WAYPOINTS** and press the **Menu Select** button directly below **SEL**.

---

- 3** **▶** or **◀** to desired waypoints and press the **Menu Select** button directly below **OPTN**.

---

- 4** **▶** or **◀** to **DELETE ALL** and press the **Menu Select** button directly below **SEL**.

---

- 5** The display shows **ALL SAVED WAYP CONFIRM DEL?**.

---

- 6** Press the **Menu Select** button directly below **YES** to delete. The display shows **ALL SAVED WAYP DELETED**.  
**OR**  
Press the **Menu Select** button directly below **NO** to return to previous Waypoint screen.

---

- 7** Press **⏠** or the **PTT** button (if preprogrammed) to exit this menu.

---

## **Measuring the Distance and Bearing from a Saved Waypoint**

### **Procedure:**

While in the current location display:

- 1** Press the **Menu Select** button directly below **OPTN**.

---
- 2** **▶** or **◀** to **DIST FRM HERE** and press the **Menu Select** button directly below **SEL**.

---
- 3** **▶** or **◀** to the required waypoint, and press the **Menu Select** button directly below **SEL**.

---
- 4** The display shows the distance and bearing from the current to the selected coordinates.

---
- 5** Press the **Menu Select** button directly below **BACK** to return to the previous Waypoint screen.  
**OR**  
Press **⏠** or the **PTT** button (if preprogrammed) to exit this menu.

---

## **Using the Location Feature While in Emergency Mode**

When the Emergency feature is activated by pressing the emergency button, the radio exits the Location menu and returns to the home (default) display so that you can see which channel the emergency signal is going out on.

However, you may re-enter the Location menu while still in emergency mode, provided that Silent Emergency has not been activated.

If you have turned Location off using the **ON/OFF** menu key, it automatically turns back on when Emergency is activated.

If there is a solid location signal during Emergency, the current location and the location information received is saved as Emergency and Last Known Location waypoints, respectively.

## ■ Trunking System Controls

---

### 📄 Using the Failsoft System

The failsoft system ensures continuous radio communications during a trunked system failure. If a trunking system fails completely, the radio goes into failsoft operation and automatically switches to its failsoft channel.

The failsoft condition is indicated by a faint beeping tone every nine seconds (radio unsquelched) until the trunking system returns to normal operation.

To continue, in Failsoft, to communicate with other talkgroups, refer to the following procedure.

#### Procedure:

- 1 Rotate the **Mode Knob** to change to a different repeater frequency.
  - 2 Press the **PTT** button to talk, and release the button to listen.
- 

*When the trunking system returns to normal operation, your radio automatically leaves failsoft operation and returns to trunked operation.*

### 📄 Going Out-of-Range

**OUT OF RANGE** when your radio goes out of the range of the system, it can no longer lock onto a control channel.

#### Procedure:

- 1 A low-pitched tone sounds.

#### **AND/OR**

The display shows the currently selected zone/channel combination and **OUT OF RANGE**.

---

- 2 Your radio remains in this out-of-range condition until:  
It locks onto a control channel.

#### **OR**

It locks onto a failsoft channel.

#### **OR**

It is turned off.

---

## SmartZone®

The SmartZone® feature extends communications beyond the reach of a single-trunked site (antenna location) when operating in a SmartZone system. SmartZone units provide expanded wide-area coverage.

SmartZone automatically switches the radio to a different site when the current site signal becomes unacceptable. This usually happens when the vehicle in which the radio is located is driven out of the range of one site, and into the range of another.

Under normal conditions, a SmartZone-enabled radio functions invisibly to the operator. However, the operator does have some manual controls on the Control Head – the **RSSI** menu entry. This button can be used to check, or change, the SmartZone operation.

## Using Site Trunking Feature

If the zone controller loses communication with any site, that site reverts to site trunking.

The display shows the currently selected zone/channel combination and **SITE TRUNKING**.

**Note:** When this occurs, you can communicate only with other radios within your trunking site.

## Locking and Unlocking a Site



This feature allows your radio to lock onto a specific site and not roam among wide-area talkgroup sites. This feature should be used with caution, since it inhibits roaming to another site in a wide-area system.

### Procedure:

Use the preprogrammed **Site Lock/Unlock** button to toggle the lock state between locked and unlocked.

### OR

Follow the procedure below.

- 1  or  to **SITE**.
- 2 Press the **Menu Select** button directly below **SITE**.
- 3 Press the **Menu Select** button directly below **LOCK** to lock the site.  
**OR**  
Press the **Menu Select** button directly below **UNLK** to unlock the site.
- 4 The radio saves the new site lock state and returns to the Home screen.

## Viewing and Changing a Site

This feature allows you to view the number of the current site or force your radio to change to a new one.

### Viewing the Current Site

#### Procedure:

- 1 Press the preprogrammed **Site Search** button.  
**OR**  
▶ or ◀ to **RSSI**.
- 2 The display momentarily shows the name of the current site and its corresponding received signal strength indicator (RSSI).

### Changing the Current Site

#### Procedure:

- 1 Press and hold down the preprogrammed **Site Search** button.  
**OR**  
Press and hold down the **Menu Select** button directly below **RSSI**.
- 2 A tone sounds and the display momentarily shows **SCANNING SITE**.

*When the radio finds a new site, it returns to the Home screen.*

## Trunked Announcement

The announcement capability allows you to make announcements to the entire user group, as well as monitor talkgroup calls and other announcements.

Announcement calls are handled in two different ways, depending on the trunked central controller configuration. The two types are called *ruthless* and *non-ruthless* preemption.

- **Ruthless Preemption:**

When a ruthless preemption announcement call is initiated, the requesting radio begins transmitting immediately. All associated talkgroup calls taking place on other channels are immediately halted, and the radios are steered to the announcement call.

Transmitting radios continue to transmit until the **PTT** button is released, at which time they also unmute for the announcement call. Individual calls (Private Conversation and telephone interconnect) are not affected.

- **Non-Ruthless Preemption:**

When a non-ruthless preemption announcement is initiated, the initiating unit receives a telephone-type busy tone, followed by a call back when all associated talkgroup conversations end.

Once an announcement call is pending, any attempts by other users to initiate a talkgroup call will result in a telephone-type busy tone. These users will not receive a call back until the announcement call is complete.

## Initiating an Announcement

If your radio has been programmed to allow announcement calls:

### Procedure:

- 1 Press the **Mode Knob** to locate the announcement-group mode.

---
- 2 Press the microphone **PTT** button to initiate the announcement.

---

## Utilities

---






### Viewing Recent Calls List

This feature allows you to view the recent incoming and outgoing call information of the following call types:

- Call Alert
- Selective Call
- Private Call
- Phone Call (Outgoing only)

**Note:** The radio can also be preprogrammed to log the radio IDs associated with incoming Dispatch Calls. Check with your dealer or system administrator for more information.

#### Procedure:

- 1  or  to **RCNT**.
  - 2 Press the **Menu Select** button directly below **RCNT** to access the **Recent Calls** feature screen.
  - 3  or  to scroll through the list.
  - 4 Press the **Menu Select** button directly below **BACK** to return to Home screen.  
**OR**  
Press  or the **PTT** button to return to the Home screen.
- 

**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

### Selecting the Power Level

You can select the power level at which your radio transmits. The radio always turns on to the default setting.

**Note:** This feature must be preprogrammed by a qualified radio technician.

#### Settings:

- Select **LOW** for a shorter transmitting distance and to conserve power.
- Select **HIGH** for a longer transmitting distance.

#### Procedure:

Use the preprogrammed **Transmit Power Level Switch** to toggle transmit power level between high and low power.

#### **OR**

Follow the procedure below.

- 1  or  to **PWR**.
  - 2 Press the **Menu Select** button directly below **PWR**.
-



- 3 The display shows **LOW POWER** and the low power icon.  
**OR**  
 The display shows **HIGH POWER** and the high power icon.
- 

### **Selecting a Radio Profile**



This feature allows you to manually switch the visual and audio settings of the radio. The display, backlight, alert tones, and audio settings are defined according to the preprogrammed radio settings of each radio profile.

You can have up to a maximum of twelve (12) radio profiles programmed into your radio by a qualified radio technician.

**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

#### **Procedure:**



Use the preprogrammed **Profile** button and proceed to Step 3.  
**OR**  
 Follow the procedure below.

- 1  or  to **PRFL**.

---

- 2 Press the **Menu Select** button directly below **PRFL** to access the **Profiles** feature screen.

---

- 3  or  to scroll through the menu selections.

---

- 4 Press the **Menu Select** button directly below **SEL** to select the required radio profile.  
**OR**  
 Press the **Menu Select** button directly below **EXIT** to exit the screen without making any changes.

---

- 5 The radio returns to the Home screen. The profile name on the Home screen indicates the current selected radio profile.

---

### **Controlling the Display Backlight**

You can enable or disable the radio's display backlight as needed, if poor light conditions make the display difficult to read.

Depending on how your radio is preprogrammed, you can also maintain a minimum backlight level on the radio's display.

#### **Procedure:**

**Note:** Press the **DIM** button to toggle the backlight off or on.  
**OR**  
 Press any key of the keypad, the **Menu Select** or **Menu Navigation** buttons, or any programmable radio controls or buttons to turn the backlight on.

## Turning Keypad Tones On or Off



You can enable and disable keypad tones if needed.

### Procedure:

Press the preprogrammed **Keypad Mute** button to turn the tones off or on.

### OR

Follow the procedure below.

- 1  or  to **MUTE**.
- 2 Press the **Menu Select** button directly below **MUTE**.
- 3 The display momentarily shows **TONES OFF**, indicating that the keypad tones are disabled.

### OR

The display momentarily shows **TONES ON**, and a short tone sounds, indicating that the keypad tones are enabled.

## Turning Voice Mute On or Off



You can enable and disable voice muting of the affiliated trunking talkgroup or selected conventional channel, if needed.

### Procedure:

Press the preprogrammed Voice Mute button to turn the feature off or on.

### OR

Follow the procedure below.

- 1  or  to **VMUT**.
  - 2 Press the **Menu Select** button directly below **VMUT**.
  - 3 The display momentarily shows **VOICE MUTE OFF**, and a short tone sounds, indicating that the feature is disabled.
- OR**
- The display momentarily shows **VOICE MUTE ON**, and a short tone sounds, indicating that the feature is enabled.

## Using the Time-Out Timer

This feature turns off your radio's transmitter. You cannot transmit longer than the preset timer setting.

If you attempt to do so, the radio automatically stops your transmission, and you hear a talk-prohibit tone.

The timer is defaulted at 60 seconds, but it can be preprogrammed from 3 to 120 seconds, in 15-second intervals, or it can be disabled entirely for each radio mode, by a qualified radio technician.

**Note:** You will hear a brief, low-pitched, warning tone four seconds before the transmission times out.

### Procedure:

- 1 Hold down the **PTT** button longer than the preprogrammed time. You hear a short, low-pitched warning tone, the transmission is cut-off, and the LEDs goes out until you release the **PTT** button.

---

- 2 Release the **PTT** button. The LEDs relight and the timer resets.

---

- 3 Press the **PTT** button to re-transmit. The time-out timer restarts and the red LED lights up.

---

## Using the Conventional Squelch Operation Features

This feature filters out unwanted calls with low signal strength or channels that have a higher than normal background noise.

### 1 Procedure:

▶ or ◀ to **SQL**.

---

### 2 Press the **Menu Select** button directly below **SQL**.

The display shows **SQUELCH XX**, where **XX** is the value for the current squelch.

---

### 3 Press the **Menu Select** button directly below “+” to increase the squelch volume.

#### OR

Press the **Menu Select** button directly below “-” to decrease the squelch volume.

---

### 4 Press to return to the selected channel.

---

## Analog Options

Tone Private Line (PL), Digital Private-Line (DPL), and carrier squelch can be available (preprogrammed) per channel.

Option	Result
Carrier squelch (C)	You hear all traffic on a channel.
PL or DPL	The radio responds only to your messages.

## Digital Options

One or more of the following options may be preprogrammed in your radio. Consult your dealer or system administrator for more information.

Option	Result
Digital Carrier-Operated Squelch (COS)	You hear any digital traffic.
Normal Squelch	You hear any digital traffic having the correct network access code.
Selective Switch	You hear any digital traffic having the correct network access code and correct talkgroup.

## Using the PL Defeat Feature

This feature allows you to override any coded squelch (DPL or PL) that might be preprogrammed to a channel. The radio will also unmute to any digital activity on a digital channel.

### Procedure:

Place the preprogrammed **PL Defeat** switch in the PL Defeat position. You hear any activity on the channel.

### OR

The radio is muted if no activity is present.

**Note:** When this feature is active, the Carrier Squelch status indicator is displayed.

## Using the Digital PTT ID Feature

This feature allows you to the radio ID (number) of the radio from whom you are currently receiving a transmission. This ID, consisting up to a maximum of eight characters, can be viewed by both the receiving radio and the dispatcher.

Your radio's ID number is also automatically sent every time the PTT button is pressed. This is a per-channel feature. For digital voice transmissions, your radio's ID is sent continuously during the voice message.

## Using the Smart PTT Feature (Conventional Only)

Smart **PTT** is a per-personality, programmable feature used in conventional radio systems to keep radio users from talking over other radio conversations.

When smart **PTT** is enabled in your radio, you cannot transmit on an active channel.

If you try to transmit on an active smart-**PTT** channel, you hear an alert tone, and the transmission is inhibited. The LED lights up solid yellow to indicate that the channel is busy.

Three variations of smart PTT are available:

Mode	Description
Transmit Inhibit on Busy Channel with Carrier	You cannot transmit if any traffic is detected on the channel.
Transmit Inhibit on Busy Channel with Wrong Squelch Code	You cannot transmit on an active channel with a squelch code or (if secure-equipped) encryption key other than your own. If the PL code is the same as yours, the transmission is not prevented.
Quick-Key Override	This feature can work in conjunction with either of the two above variations. You can override the transmit-inhibit state by quick-keying the radio. In other words, two PTT button presses within the preprogrammed time limit.

## Accessing General Radio Information

Your radio contains information on the following:

- Radio Information
- IP Display
- Control Assignments


**Note:** If the feature inactivity timer is enabled, your radio automatically exits the feature when your radio is left idle long enough for the time to expire. You will hear the Menu Inactive Exit Tone upon feature exit.

## Accessing Radio Information



This feature displays the following information of your radio:

- Host Version
- Model Number
- Serial Number
- ESN
- Flash Code
- Flash Size
- CH 1 – 4 Version (depending on the number of channel connected)
- KG (Secure Algorithm)
- Memory Size
- Tuning Version
- Processor Version
- RF Band
- Secure Version
- DSP Version
- CHIB Version

- AUX CH Version
- Siren Version
- MCHB Version

**Note:** Press  at any time to return to the Home screen.



**Procedure:**

- 1  or  to **INFO**.

---

- 2 Press the **Menu Select** button directly below **INFO**.




---

- 3  or  to **RADIO INFO** and press the **Menu Select** button directly below **SEL**.

---

- 4 The display shows the Information screen.

---

- 5  or  to scroll through the various information.  
**OR**  
 Press the **Menu Select** button directly below **BACK** to return to previous screen.  
**OR**  
 Press  to exit and return to the home display.

---

### **Viewing IP Information**

This feature displays the device name, IP address, and status of your radio.



**Note:** The device name of your radio is preprogrammed. Check with your dealer or system administrator for more information.

**Procedure:**

Press the preprogrammed Info button and proceed to Step 3.

**OR**



Follow the procedure below.

- 1  or  to **INFO**.




---

- 2 Press the **Menu Select** button directly below **INFO**.

---

- 3  or  to **IP INFO** and press the **Menu Select** button directly below **SEL**.

---

- 4  or  to scroll through the various information.  
**OR**  
 Press the **Menu Select** button directly below **BACK** to return to previous screen.  
**OR**  
 Press  to exit and return to the Home display.



---

## Viewing Control Assignments

This feature displays the programmable radio functions assigned to the controls of your radio for the currently selected channel.

See **Programmable Features** on page 6 for more information on the various programmable features of your radio.



### Procedure:

- 1  or  to **INFO**.




---

- 2 Press the **Menu Select** button directly below **INFO**.

---

- 3  or  to **CONTROL MAP** and press the **Menu Select** button directly below **SEL**.

---

- 4  or  to scroll through the various information.  
**OR**  
Press the **Menu Select** button directly below **BACK** to return to previous screen.  
**OR**  
Press  to exit and return to the Home display.

## Optional External Alarms (Horn and Lights)

All control heads can be equipped for external alarms (horn and lights) that are activated when a Call Alert page, Private Conversation call, or phone call is received.

The radio always powers up with the horn and lights feature enabled.

**Note:** The horn and lights feature must be enabled by a qualified radio technician.

## Non-Permanent Horn and Lights

### Procedure:

- 1 Press the **Menu Select** button directly below **H/L** momentarily. The last selected alarm(s) are enabled, and the display shows the enabled alarm(s) alternating with the selected mode, until it is turned off.

---

- 2 Press the **Menu Select** button directly below **H/L** momentarily to turn off the alarm(s). The display shows **HORN/LITES OFF**.

## **Permanent Horn and Lights**

If Permanent Horn and Lights is enabled, horn and lights will automatically be turned on when the radio powers up.

### **Procedure:**

- 1 Press the **Menu Select** button directly below **H/L** once to turn off the alarm(s).
- 2 Press the **Menu Select** button directly below **H/L** momentarily to enable the last selected alarm(s). The display briefly shows the enabled alarms, and then **reverts back to the selected mode**.

## **Changing the Selected Alarms**

### **Procedure:**

- 1 Press the **Menu Select** button directly below **H/L** until the display shows the required alarm.
- 2 Press the **Menu Select** button directly below the required entry and the display exits to Home screen.

*Press the **Menu Select** button directly below the entry activates the option. Below are the selections available.*

- Select **H+L** to turn on both horn and lights. The display shows **HORN/LITES ON**.
- Select **LGTS** to turn on the lights. The display shows **LIGHTS ON**.
- Select **HORN** to turn on the horn. The display shows **HORN ON**.

*An **OFF** entry is shown at the softkey when one of the features above is active. Selecting the **OFF** deactivates the current active alarm.*



### **Receiving a Call While Alarms are Turned On**

When you receive a call with the Alarms turned on:

#### **Procedure:**

- 1 You hear the vehicle's horn sounds for four seconds, and/or the car lights turn on for 60 seconds.
- 2 The display shows the type of call received (**CALL**, **PAGE**, or **PHONE**) and the selected mode name.

*The time interval can be modified by a qualified radio technician.*

### **Turning Off Non-Rearmable External Alarms**

#### **Procedure:**

- 1 Press the **Menu Select** button directly below **CALL**, **PAGE** or **PHON** will turn off the external alarm(s) and place you directly in that feature.  
**OR**  
Press the **PTT** button or any control-head button to turn off the external alarm(s).
- 2 Press the **Menu Select** button directly below **H/L** momentarily to rearm the horn and lights feature.

*The **Volume Knob** and the **DIM** button have no effect on the state of the external alarm(s).*

### **Turning Off Rearmable External Alarms**

#### **Procedure:**

- 1 Press the **Menu Select** button directly below **CALL**, **PAGE** or **PHON** to turn off the external alarm(s) and place you directly in that feature.  
The external alarm(s) is turned off and automatically rearmable so that when you exit the entry, the external alarm(s) will automatically turn on.  
**OR**  
Press the **PTT** button or any control head button other than the **Menu Select** button directly below **H/L** to turn off the external alarm(s).  
The external alarm(s) is turned off and automatically rearmable so that when you exit the entry, the external alarm(s) will automatically turn on.  
**OR**  
Press the **Menu Select** button directly below **H/L** to turn off the external alarm(s) and exit the Horn and Lights feature.  
Press the **Menu Select** button directly below **H/L** momentarily to rearm the horn and lights feature.

*The **Volume knob** and the **DIM** button have no effect on the state of the external alarms.*

## Voice Announcement

This feature enables the radio to audibly indicate the current feature mode, Zone or Channel the user has just assigned. This audio indicator can be customized per customer requirements. This is typically useful when the user is in a difficult condition to read the content shown on the display.

Each voice announcement is within a limit of three seconds maximum. As much as 2000 unique voice announcements are allowed in a radio. The sum total duration for all voice announcements in a radio shall be no more than 1000 seconds.

**Note:** This feature must be preprogrammed by a qualified radio technician.

The features which Voice Announcement supports are:

- Zone
- Channel
- Scan
- Monitor
- Talkaround/Direct
- Tx Inhibit

**Note:** Voice announcements support certain number of zone-channel, but not all.

Seek advice from your dealer or qualified technician for the best selections for this feature.

The two options of priority for the Voice Announcement available are:

- **High** – enables the voice of the feature to announce even when the radio is receiving calls.
- **Low** – disables the voice of the feature from announcing when the radio is receiving calls.

### **Procedure:**

You hear a voice announcement when the features below are preprogrammed in the radio.

- The radio powers up. The radio announces the current zone and channel it is transmitting.
- Press the preprogrammed voice announcement button (which specifically programmed to playback the current zone and channel). The radio announces the current zone and channel it is transmitting.

**Note:** Pressing this preprogrammed playback button will always enable the voice feature to announce in High priority.

All the three programmable buttons at the side of the radio support this feature.

- Change to a new zone. The radio announces the current zone and channel it is transmitting.

- Change to a new channel remaining within the current zone. The radio announces the current channel.
- Press either the **Menu Select** button or preprogrammed button of the radio to launch or terminate Scan, Monitor, Talkaround/Direct or Transmit Inhibit. The radio announces the corresponding feature activation or deactivation.

---

## Helpful Tips

The following are suggestions to assist you in troubleshooting possible operating problems.



### Caution

The cables that connect to the rear of the radio could have live voltage on some of their pins. Do not remove or reconnect these cables. Only a qualified radio technician should perform this task. Service performed by unauthorized personnel may cause the radio to transmit an emergency alarm even if the unit is turned off.

If your radio is locked up or the display shows **FAIL 01/09**, turn the radio off and then back on. If this does not correct the condition, take the radio to a qualified radio technician for service.

If radio operation is intermittent, check with other persons using the system for similar problems before taking the radio in for service. Similar problems indicate a system malfunction rather than a radio failure.

If symptoms persist or, if your unit exhibits other problems, contact a qualified radio technician.

## Accessories

Your radio is compatible with the accessories listed in this chapter. Contact your dealer for details.

Antennas . . . . .	page 100
Audio . . . . .	page 101
Control Station . . . . .	page 101
Footswitches and PTTs . . . . .	page 102
Direct Entry Keypad and Siren . . . . .	page 102
Microphones . . . . .	page 103
Motorcycle . . . . .	page 103
Mounting Solution . . . . .	page 104
Power/CAN Cables . . . . .	page 104
Programming/Accessory Cables . . . . .	page 105

## Antennas

- Roof Top, 1/4 Wave 136 – 144 MHz (HAD4006\_)
- Roof Top, 1/4 Wave 144 – 152 MHz (HAD4007\_)
- Roof Top, 1/4 Wave, 152 – 162 MHz (HAD4008\_)
- Roof Top, 1/4 Wave, 162 – 174 MHz (HAD4009\_)
- Roof Mount Wideband VHF 136/162 (HAD4016\_)
- Roof Mount Wideband VHF 146/174 (HAD4017\_)
- VHF Wideband 136 – 174 MHz (HAD4021\_)
- 3 dB Low-Profile 762 – 870 MHz (HAF4013\_)
- 3 dB Elevated Feed 762 – 870 MHz (HAF4014\_)
- 3 dB Motorcycle 762 – 870 MHz (HAF4015\_)
- 1/4 Wave 762 – 870 MHz (HAF4016\_)
- 3 dB Co-Linear 762 – 870 MHz (HAF4017\_)
- 3 dB Low Profile Motorcycle 762 – 870 MHz (HAF4018\_)
- GPS Antenna Roof Mount (HAG4000\_)
- GPS Antenna Motorcycle (HAG4001\_)
- GPS Antenna Glass Mount (PMAN4001\_)
- 3dB, Roof Mount, 136 – 174 MHz (RAD4010AR\_)



## ■ Audio

---

- Standard Speaker 8 Ohm (HSN4031\_)
- Standard Speaker 3.2 Ohm (HSN4032\_)
- 7.5 Watt Speaker (Water Resistant) (HSN4038\_)
- 13 Watt Speaker (Water Resistant) (HSN4040\_)
- 13 Watt Speaker (Motorcycle) (HSN6003\_)

## ■ Control Station

---

- U.K. Cord (3002120F02)
- 110 V Line Cord (3060665A04)
- Europe Cord (3060665A05)
- Argentina Cord (3085801L01)
- Desk Tray with Speaker (HLN6042\_)
- Desk Tray Hardware (HLN7024\_)
- Power Supply 15 A Mid Power (HPN4007\_)
- Desktop Microphone (RMN5070\_)

## ■ Footswitches and PTTs

---

- PTT Footswitch Button (GLN7278\_)
- External Alarm Cable (HKN4258\_)
- Emergency Footswitch (HLN5113\_)
- Emergency Push Button (HLN5131\_)
- External Alarm Buzzer 110MA (HLN6953\_)
- External Alarm Relays (HLN6969\_)
- Accessory PTT (RLN5926\_)

## ■ Direct Entry Keypad and Siren

---

- Direct Entry Keypad Siren Public Address Deck 8 Button (H1336\_)
- Direct Entry Keypad Status Message Deck 8 Button (H1338\_)
- Direct Entry Keypad Status Message Deck 16 Button (H1339\_)
- Fuse Cable (HKN4265\_)
- Siren Cable (HKN4363\_)
- Direct Entry Keypad to O5 Control Head Cable (HKN6189\_)
- Mounting Bracket (HKN6938\_)
- Auxiliary Switch Panel (HLN1224\_)
- Siren (HLN1439\_)
- Siren Switchbox (HLN6819\_)
- Round Chrome Bull Horn (TDN6251\_)
- Rectangular Chrome Bull Horn (TDN6252\_)
- Underhood-Grey Bull Horn (TDN6253\_)
- Round-Grey Bull Horn (TDN6254\_)

## ■ Microphones

---

- HandSet/Hangup Armored Cable (HKN1018\_)
- Motorcycle Water Resistant Microphone with DB9 Connector (HMN1079\_)
- Water Resistant Microphone (HMN1089\_)
- Traditional Palm Microphone (HMN1090\_)
- Keypad Microphone (HMN4079\_)
- Keypad Handset (HMN4097\_)
- IMPRES™ Visor Microphone (RMN5054\_)
- Desktop Microphone (RMN5070\_)

## ■ Motorcycle

---

- Motorcycle Remote Cable (3075217A01)
- Motorcycle Power Cable (HKN6032\_)
- Motorcycle Enclosure, Black, U.S.A. (HLN7021\_)
- Motorcycle Water Resistant Microphone with DB9 Connector (HMN1079\_)
- Motorcycle Waterproof Speaker (HSN6003\_)

## ■ Mounting Solution

---

- Remote Control Head Trunnion (HKN6186\_)
- High Power Quick Release Trunnion with Lock (HLN7003\_)
- Mid Power Key Lock (HLN6372\_)
- Mid Power Trunnion (HLN7002\_)

## ■ Power/CAN Cables

---

- 10' Power Cable Dash Mount (HKN4191\_)
- 20' Power Cable Mid Power Remote Mount (HKN4192\_)
- Motorcycle Power Cable (HKN6032\_)
- 100W Power Cable (HKN6110\_)
- 131' CAN Cable Remote Mount (HKN6164\_)
- 115' CAN Cable Remote Mount (HKN6165\_)
- 75' CAN Cable Remote Mount (HKN6166\_)
- 50' CAN Cable Remote Mount (HKN6167\_)
- 30' CAN Cable Remote Mount (HKN6168\_)
- 17' CAN Cable Remote Mount (HKN6169\_)
- 10' CAN Cable Remote Mount (HKN6170\_)
- Accessory Connector for Speaker and Ignition (HLN6863\_)



## ■ Programming/Accessory Cables

---

- Remote Mount RS232 Cable (HKN6122\_)
- RS232 Cable Kit 6' Dash Mount (HKN6160\_)
- RS232 Cable Kit 20' Remote Mid Power (HKN6161\_)
- USB Cable, MAP Connector (6 ft) (HKN6163\_)
- USB Cable, MAP Connector (15 ft) (HKN6172\_)
- Keyloader Adaptor MMP/Hirose 1.5" Cable (HKN6182\_)
- RS232 MMP Cable (HKN6183\_)
- USB MMP Programming Cable (HKN6184\_)
- Remote Control Head Power, Speaker, Audio Headset Jacks (HKN6187\_)
- Remote Control Head Power and Speaker (HKN6188\_)
- Remote Control Head VIP Connector (HKN6196\_)
- Ignition Sense Cable, Dash Mount (HLN6863\_)
- Remote Control Head MAP Connector (HLN6961\_)
- Standard Microphone Extension Cable (PMKN4033\_)
- Keyload Cable KVL3000 Plus to Hirose (TKN8531\_)

## Appendix: Maritime Radio Use in the VHF Frequency Range

Take a moment to review the following:

Special Channel Assignments . . . . . page 106

Operating Frequency Requirements . . . . . page 107

### ■ Special Channel Assignments

#### Emergency Channel

If you are in imminent and grave danger at sea and require emergency assistance, use **VHF Channel 16** to send a distress call to nearby vessels and the United States Coast Guard. Transmit the following information, in this order:

- 1 “MAYDAY, MAYDAY, MAYDAY.”
- 2 “THIS IS \_\_\_\_\_, CALL SIGN \_\_\_\_\_.”  
*State the name of the vessel in distress 3 times, followed by the call sign or other identification of the vessel, stated 3 times.*
- 3 Repeat “MAYDAY” and the name of the vessel.

- 4 “WE ARE LOCATED AT \_\_\_\_\_.”  
*State the position of the vessel in distress, using any information that will help responders to locate you, e.g.:*
  - *latitude and longitude*
  - *bearing (state whether you are using true or magnetic north)*
  - *distance to a well-known landmark*
  - *vessel course, speed or destination*
- 5 State the nature of the distress.
- 6 Specify what kind of assistance you need.
- 7 State the number of persons on board and the number needing medical attention, if any.
- 8 Mention any other information that would be helpful to responders, such as type of vessel, vessel length and/or tonnage, hull color, etc.
- 9 “OVER.”
- 10 Wait for a response.
- 11 If you do not receive an immediate response, remain by the radio and repeat the transmission at intervals until you receive a response. Be prepared to follow any instructions given to you.

#### Non-Commercial Call Channel

For non-commercial transmissions, such as fishing reports, rendezvous arrangements, repair scheduling, or berthing information, use **VHF Channel 9**.

## ■ Operating Frequency Requirements

A radio designated for shipboard use must comply with Federal Communications Commission Rule Part 80 as follows:

- on ships subject to Part II of Title III of the Communications Act, the radio must be capable of operating on the 156.800 MHz frequency
- on ships subject to the Safety Convention, the radio must be capable of operating:
  - in the simplex mode on the ship station transmitting frequencies specified in the 156.025 – 157.425 MHz frequency band, and
  - in the semiduplex mode on the two frequency channels specified in the table below.

**Note:** Simplex channels 3, 21, 23, 61, 64, 81, 82, and 83 cannot be lawfully used by the general public in US waters.

Additional information about operating requirements in the Maritime Services can be obtained from the full text of FCC Rule Part 80 and from the US Coast Guard.

**Table A-1: VHF Marine Channel List**

Channel Number	Frequency (MHz)	
	Transmit	Receive
1	156.050	160.650

**Table A-1: VHF Marine Channel List (Continued)**

Channel Number	Frequency (MHz)	
	Transmit	Receive
2	156.100	160.700
*	156.150	160.750
4	156.200	160.800
5	156.250	160.850
6	156.300	–
7	156.350	160.950
8	156.400	–
9	156.450	156.450
10	156.500	156.500
11	156.550	156.550
12	156.600	156.600
13**	156.650	156.650
14	156.700	156.700
15**	156.750	156.750
16	156.800	156.800
17**	156.850	156.850
18	156.900	161.500
19	156.950	161.550
20	157.000	161.600
*	157.050	161.650
22	157.100	161.700
*	157.150	161.750

Table A-1: VHF Marine Channel List (Continued)

Channel Number	Frequency (MHz)	
	Transmit	Receive
24	157.200	161.800
25	157.250	161.850
26	157.300	161.900
27	157.350	161.950
28	157.400	162.000
60	156.025	160.625
*	156.075	160.675
62	156.125	160.725
63	156.175	160.775
*	156.225	160.825
65	156.275	160.875
66	156.325	160.925
67**	156.375	156.375
68	156.425	156.425
69	156.475	156.475
71	156.575	156.575
72	156.625	—
73	156.675	156.675
74	156.725	156.725
75	***	***
76	***	***
77**	156.875	—

Table A-1: VHF Marine Channel List (Continued)

Channel Number	Frequency (MHz)	
	Transmit	Receive
78	156.925	161.525
79	156.975	161.575
80	157.025	161.625
*	157.075	161.675
*	157.125	161.725
*	157.175	161.775
84	157.225	161.825
85	157.275	161.875
86	157.325	161.925
87	157.375	161.975
88	157.425	162.025

\* Simplex channels 3, 21, 23, 61, 64, 81, 82, and 83 cannot be **lawfully used** by the general public in US waters.

\*\* Low power (1 W) only

\*\*\* Guard band

**Note:** A — in the Receive column indicates that the channel is transmit only.


## Glossary

This glossary is a list of specialized terms used in this manual.

Term	Definition
<b>ACK</b>	Acknowledgment of communication.
<b>Active Channel</b>	A channel that has traffic on it.
<b>Analog Signal</b>	An RF signal that has a continuous nature rather than a pulsed or discrete nature.
<b>ARS</b>	Automatic Registration Service
<b>ASTRO 25 Trunking</b>	Motorola standard for wireless digital trunked communications.
<b>ASTRO Conventional</b>	Motorola standard for wireless digital conventional communications.
<b>Autoscan</b>	A feature that allows the radio to automatically scan the members of a scan list.
<b>AUX CH</b>	Auxiliary Control Head
<b>Call Alert</b>	Privately page an individual by sending an audible tone.

Term	Definition
<b>Carrier Squelch</b>	Feature that responds to the presence of an RF carrier by opening or unmuting (turning on) a receiver's audio circuit. A squelch circuit silences the radio when no signal is being received so that the user does not have to listen to "noise".
<b>Central Controller</b>	A software-controlled, computer-driven device that receives and generates data for the trunked radios assigned to it. It monitors and directs the operations of the trunked repeaters.
<b>Channel</b>	A group of characteristics such as transmit/receive frequency pairs, radio parameters, and encryption encoding.
<b>CHIB</b>	Control Head Interface Board
<b>Control Channel</b>	In a trunking system, one of the channels that is used to provide a continuous, two-way/data communications path between the central controller and all radios on the system.
<b>Conventional</b>	Typically refers to radio-to-radio communications, sometimes through a repeater (see Trunking).
<b>Conventional Scan List</b>	A scan list that includes only conventional channels.

Term	Definition
<b>CP</b>	Codeplug
<b>Cursor</b>	A visual tracking marker (a blinking line) that indicates a location on the display.
<b>Deadlock</b>	Displayed by the radio after three failed attempts to unlock the radio. The radio must be powered off and on prior to another attempt.
<b>Digital Private Line (DPL)</b>	A type of coded squelch using data bursts. Similar to PL except a digital code is used instead of a tone.
<b>Digital Signal</b>	An RF signal that has a pulsed, or discrete, nature, rather than a continuous nature.
<b>Dispatcher</b>	An individual who has radio system management duties.
<b>DSP</b>	Digital Signal Processing
<b>Dynamic Regrouping</b>	A feature that allows the dispatcher to temporarily reassign selected radios to a single special channel so they can communicate with each other.
<b>ESN</b>	Electrical Serial Number

Term	Definition
<b>Failsoft</b>	A feature that allows communications to take place even though the central controller has failed. Each trunked repeater in the system transmits a data word informing every radio that the system has gone into failsoft.
<b>FCC</b>	Federal Communications Commission.
<b>Hang Up</b>	Disconnect.
<b>Home screen</b>	The first display information after the radio completes its self test.
<b>KVL</b>	Key-variable loader: A device for loading encryption keys into the radio.
<b>LCD</b>	Liquid crystal display.
<b>LED</b>	Light-emitting diode.
<b>Menu Entry</b>	A software-activated feature shown at the bottom of the display – selection of these features is controlled by the  .
<b>MCHB</b>	Millennium Control Head Board

Term	Definition
<b>Monitor</b>	Check channel activity through menu entries. If the channel is clear, you hear static. If the channel is in use, you hear conversation. It also serves as a way to check the volume level of the radio, since the radio “opens the squelch” when the monitor button is pressed.
<b>Multi-System Talkgroup Scan List</b>	A scan list that can include both talkgroups (trunked) and channels (conventional).
<b>Network Access Code</b>	Network Access Code (NAC) operates on digital channels to reduce voice channel interference between adjacent systems and sites.
<b>Non-Tactical/ Revert</b>	The user talks on a preprogrammed emergency channel. The emergency alarm is sent out on this same channel.
<b>OTAR</b>	Over-the-air rekeying.
<b>Page</b>	A one-way alert, with audio and/or display messages.
<b>Personality</b>	A set of unique features specific to a radio.
<b>PIN</b>	Personal Identification Number
<b>Preprogrammed</b>	Refers to a software feature that has been activated by a qualified radio technician.

Term	Definition
<b>Private (Conversation) Call</b>	A feature that lets you have a private conversation with another radio user in the talkgroup.
<b>Private Line (PL)</b>	A sub-audible tone that is transmitted such that only receivers decoding the tone receives it.
<b>Programmable</b>	Refers to a radio control that can have a radio feature assigned to it.
<b>PTT</b>	Push-To-Talk – the <b>PTT button</b> engages the transmitter and puts the radio in transmit (send) operation when pressed.
<b>Radio Frequency (RF)</b>	The part of the general frequency spectrum between the audio and infrared light regions (about 10 kHz to 10,000,000 MHz).
<b>Repeater</b>	A conventional radio feature, where you talk through a receive/transmit facility that re-transmits received signals, in order to improve communications range and coverage.
<b>Selective Call</b>	A feature that allows you to call a select individual, intended to provide privacy and to eliminate the annoyance of having to listen to conversations of no interest to you.

Term	Definition
<b>Selective Switch</b>	Any digital P25 traffic having the correct Network Access Code and the correct talkgroup.
<b>Squelch</b>	Special electronic circuitry, added to the receiver of a radio, that reduces, or cuts off, unwanted signals before they are heard in the speaker.
<b>Standby</b>	An operating condition whereby the radio's speaker is muted but still continues to receive data.
<b>Status Calls</b>	Pre-defined text messages that allow the user to send a conditional message without talking.
<b>Tactical/ Non-Revert</b>	The user talks on the channel that was selected before the radio entered the emergency state.
<b>Talkaround</b>	Bypass a repeater and talk directly to another unit for easy local unit-to-unit communications.
<b>Talkgroup</b>	An organization or group of radio users who communicate with each other using the same communication path.
<b>TMS</b>	Text Messaging Service

Term	Definition
<b>Trunking</b>	The automatic sharing of communications paths between a large number of users (see Conventional).
<b>Trunking Priority Monitor Scan List</b>	A scan list that includes talkgroups that are all from the same trunking system.
<b>USK</b>	Unique Shadow Key.
<b>UTC</b>	Coordinated Universal Time. The international time standard (formerly Greenwich Mean Time, or GMT). Zero hours UTC is midnight in Greenwich, England, which is located at 0 degrees longitude. Everything east of Greenwich (up to 180 degrees) is later in time; everything west is earlier. There are 42 time authorities around the world that are constantly synchronizing with each other. Abbreviated as UTC (English backronym = Universal Time, Coordinated), it is also known as Zulu (Z) Time.
<b>Zone</b>	A grouping of channels.



# Commercial Warranty and Service

## Limited Warranty

### MOTOROLA COMMUNICATION PRODUCTS

#### I. WHAT THIS WARRANTY COVERS AND FOR HOW LONG:

MOTOROLA INC. ("MOTOROLA") warrants the MOTOROLA manufactured Communication Products listed below ("Product") against defects in material and workmanship under normal use and service for a period of time from the date of purchase as scheduled below:

APX 7500 O5 Control Head	One (1) Year
Product Accessories	One (1) Year

MOTOROLA, at its option, will at no charge either repair the Product (with new or reconditioned parts), replace it (with a new or reconditioned Product), or refund the purchase price of the Product during the warranty period provided it is returned in accordance with the terms of this warranty. Replaced parts or boards are warranted for the balance of the original applicable warranty period. All replaced parts of Product shall become the property of MOTOROLA.

This express limited warranty is extended by MOTOROLA to the original end user purchaser only and is not assignable or transferable to any other party. This is the complete warranty for the

Product manufactured by MOTOROLA. MOTOROLA assumes no obligations or liability for additions or modifications to this warranty unless made in writing and signed by an officer of MOTOROLA. Unless made in a separate agreement between MOTOROLA and the original end user purchaser, MOTOROLA does not warrant the installation, maintenance or service of the Product.

MOTOROLA cannot be responsible in any way for any ancillary equipment not furnished by MOTOROLA which is attached to or used in connection with the Product, or for operation of the Product with any ancillary equipment, and all such equipment is expressly excluded from this warranty. Because each system which may use the Product is unique, MOTOROLA disclaims liability for range, coverage, or operation of the system as a whole under this warranty.

#### II. GENERAL PROVISIONS:

This warranty sets forth the full extent of MOTOROLA'S responsibilities regarding the Product. Repair, replacement or refund of the purchase price, at MOTOROLA'S option, is the exclusive remedy. THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES. IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL MOTOROLA BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, FOR ANY LOSS OF USE, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, LOST PROFITS OR SAVINGS OR OTHER INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR

INABILITY TO USE SUCH PRODUCT, TO THE FULL EXTENT SUCH MAY BE DISCLAIMED BY LAW.

### III. STATE LAW RIGHTS:

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION OR EXCLUSIONS MAY NOT APPLY.

This warranty gives specific legal rights, and there may be other rights which may vary from state to state.

### IV. HOW TO GET WARRANTY SERVICE:

You must provide proof of purchase (bearing the date of purchase and Product item serial number) in order to receive warranty service and, also, deliver or send the Product item, transportation and insurance prepaid, to an authorized warranty service location. Warranty service will be provided by MOTOROLA through one of its authorized warranty service locations. If you first contact the company which sold you the Product (e.g., dealer or communication service provider), it can facilitate your obtaining warranty service. You can also call MOTOROLA at 1-800-927-2744 US/Canada.

### V. WHAT THIS WARRANTY DOES NOT COVER:

- A) Defects or damage resulting from use of the Product in other than its normal and customary manner.
- B) Defects or damage from misuse, accident, water, or neglect.

- C) Defects or damage from improper testing, operation, maintenance, installation, alteration, modification, or adjustment.
- D) Breakage or damage to antennas unless caused directly by defects in material workmanship.
- E) A Product subjected to unauthorized Product modifications, disassembles or repairs (including, without limitation, the addition to the Product of non-MOTOROLA supplied equipment) which adversely affect performance of the Product or interfere with MOTOROLA's normal warranty inspection and testing of the Product to verify any warranty claim.
- F) Product which has had the serial number removed or made illegible.
- G) Rechargeable batteries if:
  - any of the seals on the battery enclosure of cells are broken or show evidence of tampering.
  - the damage or defect is caused by charging or using the battery in equipment or service other than the Product for which it is specified.
- H) Freight costs to the repair depot.
- I) A Product which, due to illegal or unauthorized alteration of the software/firmware in the Product, does not function in accordance with MOTOROLA's published specifications or the FCC type acceptance labeling in effect for the Product at the time the Product was initially distributed from MOTOROLA.
- J) Scratches or other cosmetic damage to Product surfaces that does not affect the operation of the Product.
- K) Normal and customary wear and tear.

## VI. PATENT AND SOFTWARE PROVISIONS:

MOTOROLA will defend, at its own expense, any suit brought against the end user purchaser to the extent that it is based on a claim that the Product or parts infringe a United States patent, and MOTOROLA will pay those costs and damages finally awarded against the end user purchaser in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

- A) that MOTOROLA will be notified promptly in writing by such purchaser of any notice of such claim;
- B) that MOTOROLA will have sole control of the defense of such suit and all negotiations for its settlement or compromise; and
- C) should the Product or parts become, or in MOTOROLA's opinion be likely to become, the subject of a claim of infringement of a United States patent, that such purchaser will permit MOTOROLA, at its option and expense, either to procure for such purchaser the right to continue using the Product or parts or to replace or modify the same so that it becomes non-infringing or to grant such purchaser a credit for the Product or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the Product or parts as established by MOTOROLA.

MOTOROLA will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or devices not furnished by MOTOROLA, nor will MOTOROLA have any liability for the use of ancillary equipment or software not furnished by MOTOROLA which is attached to or used in connection with the Product. The foregoing states the entire liability of MOTOROLA with respect to infringement of patents by the Product or any parts thereof.

Laws in the United States and other countries preserve for MOTOROLA certain exclusive rights for copyrighted MOTOROLA software such as the exclusive rights to reproduce in copies and distribute copies of such MOTOROLA software. MOTOROLA software may be used in only the Product in which the software was originally embodied and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such MOTOROLA software or exercise of rights in such MOTOROLA software is permitted. No license is granted by implication, estoppel or otherwise under MOTOROLA patent rights or copyrights.

## VII. GOVERNING LAW:

This Warranty is governed by the laws of the State of Illinois, U.S.A.

## SERVICE

Proper repair and maintenance procedures will assure efficient operation and long life for this product. A Motorola maintenance agreement will provide expert service to keep this and all other communication equipment in perfect operating condition. A nationwide service organization is provided by Motorola to support maintenance services. Through its maintenance and installation program, Motorola makes available the finest service to those desiring reliable, continuous communications on a contract basis. For a contract service agreement, please contact your nearest Motorola service or sales representative, or an authorized Motorola dealer.

Express Service Plus (ESP) is an optional extended service coverage plan, which provides for the repair of this product for a period of three years from the date of shipment from the factory, or the date of delivery if purchased from an authorized Motorola two-way radio dealer. For more information about ESP, contact the Motorola Radio Support Center, 2204 Galvin Drive, Elgin, IL 60123, 1-800-227-6772.





**MOTOROLA**

Motorola, Inc.  
1301 E. Algonquin Rd.  
Schaumburg, IL 60196-1078, U.S.A.

MOTOROLA and the Stylized M Logo are registered  
in the U.S. Patent and Trademark Office.

All other product or service names are the property of  
their respective owners.

© 2009 by Motorola, Inc.

All rights reserved. Printed in the U.S.A.  
September 2009

RO-1-2005



**6875947M01-A**