

CMWC1ZZAAF/ABF

User Guide

Author: Kenichi Shibano

Version: 1.0

Release Date: July 13, 2012

This document explains how to control Murata CMWC1ZZAAF.

1. Module introduction

CMWC1ZZAAF, CMWC1ZZABF is a hostless wifi module which integrate wifi drvier and TCP/IP stack.

The operation temperature is -20~+75degree.

2. Operation Manual

EVK set up is shown in figure1.





Figure1

<Set up>

1. Connect EVK and PC through USB cable







2. Install USB-UART converter driver (FTDI D2xx driver). Customer can download from below website.

<http://www.ftdichip.com/Drivers/D2XX.htm>

3. Please open device manager. Customer can see USB Serial Port if driver install is succeeded.




4. Please open properties of USB serial port and change port setting as below.



5. Please open UART communication tool on PC such as hyper terminal. And use same port setting as 4.


After connection is done, enter “help”, then module responds console command list. Customer can refer to command list and change setting by themselves.



```
Serial-COM9 - SecureCRT
File Edit View Options Transfer Script Tools Help
Serial-COM9
help
Console Commands:
  help [<command> [<example_num>]]
    - Print help message or command example.
  dhcpc
    - Perform DHCP as a client to obtain an IP address.
  get_mac_addr
    - Get the device MAC address.
  get_rssi
    - Get the received signal strength of the AP (client mode only).
  join <ssid> <openlwpalwpa2> [key] [ip netmask gateway]
    - Join an AP, DHCP assumed if no IP address provided
  join_default
    - Join the AP "YOUR_AP_SSID" and obtain an IP address using DHCP
  join_specific <ssid> <bssid> <channel> <openlwpalwpa2> <key> [ip netmask gateway]
    - Join a specific AP, DHCP assumed if no IP address provided
  leave
    - Leave an AP.
  powersave <1|0>
    - Enable/disable powersave mode.
  scan
    - Scan all enabled channels and print a list of APs found.
  set_ip <ip> <netmask> <gateway>
    - Set a static IP.
  set_tx_power <0-32>
    - Set the tx power in dBm.
  get_tx_power
    - Gets the tx power in dBm.
  status
    - Print status of the Wi-Fi and network interfaces.
Ready                               Serial: COM9   30, 3   30 Rows, 92 Cols   VT100
```

<Sample application 1> Module control by console mode and webpage

1. If customer enters “start_prov”, EVK starts default access point(AP) mode setting.
SSID: muRata_Hostless_Wifixxxxxxxxxxxx, xxxxxxxxxxxxxx is EVK mac address
Security: none
DHCP: available
IP address: 192.168.1.1




If customer wants to change setting by themselves, pls enter “stop_prov”.

2. Customer can connect EVK from WiFi client(PC or smartphone, etc). Password is 12345678.




- Customer can access webpage inside EVK. And change EVK setting to connect with other AP.
URL: 192.168.1.1




Click “Scan and select network”.


- Join AP network. Join “WUART-Demo” in this document, password is “1234567890”
First, please enter AP password then click “join”. In actual case, customer can select any AP.




After you joined WiFi network, EVK is not in AP mode and changed to client, so EVK and WiFi client will be disconnected.




- You will see attached message from UART port after joined network after joined AP. EVK connects to AP now then EVK becomes client mode. EVK owns IP: 192.168.1.103 in this document. (Different IP address may be assigned in actual case, please confirm IP address.) Customer can check IP address at EVK through AP's setting webpage too.




- Connect to same AP with EVK(WUART-Demo) from other client(ex. PC),



7. Access 192.168.1.103 and you will see attached web page.



Click any button then you will see received message from UART.




<Sample application 2> TCP Server – Client demo


- 0. Please follow same procedure as <sample application 1>,
8. Connect to same AP with EVK(WUART-Demo) from other client(ex. PC),




- 1. Murata provides TCP server-client demo tool. (CAsySocket_s.exe)
Please open the .exe file and you will see below GUI.
- 2. Please enter PC side IP address, it's 192.168.1.101 in this document and please input server port number in random(1234 in this document). And click 接听




- 3. Please send tcp_connect to EVK.
tcp_connect [server ip] [server port],
server ip and server port should be same as the one which you enter into CAsySocket_s.




4. After connection success, CAsySocket_s receives the packet from EVK via WiFi AP.





5. Customer can receive packet from server to EVK via AP.
This case, enter "muRata China" then click 发送 button in CAsySocket_s.



Then customer can check EVK received packed by "tcp_read"



6. Customer can send packet from EVK to server.



<Appendix>

Console Commands:

help [<command> [<example_num>]]

- Print help message or command example.

dhcpc

- Perform DHCP as a client to obtain an IP address.

get_mac_addr

- Get the device MAC address.

get_rssi

- Get the received signal strength of the AP (client mode only).

join <ssid> <open|wpa|wpa2> [key] [ip netmask gateway]

- Join an AP. DHCP assumed if no IP address provided

join_default

- Join the AP 'YOUR_AP_SSID' and obtain an IP address using DHCP

join_specific <ssid> <bssid> <channel> <open|wpa|wpa2> <key> [ip netmask gateway]

- Join a specific AP. DHCP assumed if no IP address provided

leave

- Leave an AP.

powersave <1|0>

- Enable/disable powersave mode.

scan

- Scan all enabled channels and print a list of APs found.

set_ip <ip> <netmask> <gateway>

- Set a static IP.

set_tx_power <0-32>

- Set the tx power in dBm.

get_tx_power

- Gets the tx power in dBm.

status

- Print status of the Wi-Fi and network interfaces.

start_ap <ssid> <open|wpa|wpa2> <key> <channel>

- Start AP mode.

stop_ap

- Stop AP mode.

wifi_on

- Turn Wi-Fi device on.

wifi_off

- Turn Wi-Fi device off.

wifi_reset

- Reset the Wi-Fi device.

antenna <0|1|3>

- Antenna selection. 3 = Auto

set_country <country code>

- Set country.
- ping <destination>
- Pings the specified IP or Host.
- start_dhcpd
- Starts a DHCP daemon.
- stop_dhcpd
- Stops the DHCP daemon.
- get_random
- Get a random number.
- join_wps <pbcc|pin> [pin] [<ip> <netmask> <gateway>]
- Join an AP using WPS
- tcp_test_tx_server
- Waits for connection then sends TCP packets.
- tcp_test_rx_server
- Waits for connection then receives TCP packets.
- tcp_test_tx_client [server ip]
- Connects to a server then sends TCP packets.
- tcp_test_rx_client [server ip]
- Connects to a server then receives TCP packets.
- tcp_connect [server ip] [server port]
- Connects to a server then receives TCP packets.
- tcp_disconnect
- Connects to a server then receives TCP packets.
- tcp_write [payload]
- Write to the server through the TCP socket opened in tcp_connect.
- tcp_read [timeout]
- Read from the server through the TCP socket opened in tcp_connect.
- start_prov
- Starts the provisioning demo mode.
- stop_prov
- Stops the provisioning demo mode.

Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna; Increase the separation between the equipment and receiver; Connect the equipment into an outlet on a circuit different from that to which the receiver is connected; Consult the dealer or an experienced radio/TV technician for help.

In accordance with FCC Part 15C, this module is listed as a Limited Modular Transmitter device.

Therefore, the final host product must be submitted to [SyChip] for confirmation that the installation of the module into the host is in compliance with the regulations of FCC and IC Canada. Specifically, if an antenna other than the model documented in the Filing is used, a Class 2 Permissive Change must be filed with the FCC.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

FCC Label Instructions

The outside of final products that contains this module device must display a label referring to the enclosed module. This exterior label can use wording such as the following: "Contains Transmitter Module FCC ID: [VPYABF]" or "Contains FCC ID: [VPYABF]." Any similar wording that expresses the same meaning may be used.

To satisfy FCC RF Exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For final installation :

Only the antenna shown in the filing may be used

If the final device is made available to non-professional users, then the antenna must either be inside the host device enclosure, or changing the antenna must be made impossible by using a glue which will make it necessary to break the antenna connector when trying to remove it.

End of document