

A
B
MT
D
E
F
G
H
I
J
K
L
M

SECTION **MT**
MANUAL TRANSAXLE

CONTENTS

PRECAUTIONS	3	CASE AND HOUSING COMPONENTS	17	F
Caution	3	GEAR COMPONENTS	18	
PREPARATION	4	SHIFT CONTROL COMPONENTS	20	
Special Service Tools	4	FINAL DRIVE COMPONENTS	21	G
Commercial Service Tools	6	Component Parts (RS6F51A)	22	
NOISE, VIBRATION, AND HARSHNESS (NVH)		CASE AND HOUSING COMPONENTS	22	
TROUBLESHOOTING	7	GEAR COMPONENTS	23	H
NVH Troubleshooting Chart	7	SHIFT CONTROL COMPONENTS	25	
MANUAL TRANSAXLE	7	FINAL DRIVE COMPONENTS	26	
DESCRIPTION	8	Disassembly and Assembly (RS5F51A)	26	I
Cross-Sectional View	8	DISASSEMBLY	26	
DOUBLE-CONE SYNCHRONIZER	9	ASSEMBLY	30	
REVERSE GEAR NOISE PREVENTION FUNCTION (SYNCHRONIZING METHOD)	9	Disassembly and Assembly (RS6F51A)	35	J
M/T OIL	10	DISASSEMBLY	35	
Changing M/T Oil	10	ASSEMBLY	39	
DRAINING	10	Adjustment (RS5F51A)	45	K
FILLING	10	INPUT SHAFT END PLAY	45	
Checking M/T Oil	10	MAINSHAFT END PLAY	46	
OIL LEAKAGE AND OIL LEVEL	10	DIFFERENTIAL SIDE BEARING PRELOAD	47	
SIDE OIL SEAL	11	REVERSE IDLER GEAR END PLAY	48	L
Removal and Installation	11	Adjustment (RS6F51A)	49	
REMOVAL	11	INPUT SHAFT END PLAY	49	
INSTALLATION	11	MAINSHAFT END PLAY	50	M
POSITION SWITCH	12	DIFFERENTIAL SIDE BEARING PRELOAD	51	
Checking	12	REVERSE IDLER GEAR END PLAY	52	
BACK-UP LAMP SWITCH	12	INPUT SHAFT AND GEARS	54	
PARK/NEUTRAL POSITION SWITCH	12	Assembly and Disassembly (RS5F51A)	54	
CONTROL LINKAGE	13	DISASSEMBLY	54	
Removal and Installation of Control Device and Cable	13	INSPECTION AFTER DISASSEMBLY	55	
AIR BREATHER HOSE	14	ASSEMBLY	57	
Removal and Installation	14	Assembly and Disassembly (RS6F51A)	61	
TRANSAXLE ASSEMBLY	15	DISASSEMBLY	61	
Removal and Installation	15	INSPECTION AFTER DISASSEMBLY	62	
REMOVAL	15	ASSEMBLY	64	
INSTALLATION	16	MAINSHAFT AND GEARS	68	
Component Parts (RS5F51A)	17	Assembly and Disassembly (RS5F51A)	68	
		DISASSEMBLY	68	
		INSPECTION AFTER DISASSEMBLY	69	

ASSEMBLY	71	SERVICE DATA AND SPECIFICATIONS (SDS)	97
Assembly and Disassembly (RS6F51A)	76	General Specifications	97
DISASSEMBLY	76	TRANSAXLE	97
INSPECTION AFTER DISASSEMBLY	77	FINAL GEAR	98
ASSEMBLY	79	Gear End Play	98
REVERSE IDLER SHAFT AND GEARS	84	Clearance Between Baulk Ring and Gear	98
Assembly and Disassembly (RS5F51A)	84	3RD,4TH,5TH,6TH & REVERSE BAULK RING...	98
DISASSEMBLY	84	1ST AND 2ND DOUBLE BAULK RING	98
INSPECTION AFTER DISASSEMBLY	84	Available Snap Rings	99
ASSEMBLY	85	INPUT SHAFT SPACER	99
Assembly and Disassembly (RS6F51A)	85	6TH BUSHING	99
DISASSEMBLY	85	5TH MAIN GEAR	99
INSPECTION AFTER DISASSEMBLY	85	Available C-Rings	99
ASSEMBLY	86	MAINSHAFT C-RING	99
FINAL DRIVE	87	Available Thrust Washer	100
Assembly and Disassembly (RS5F51A)	87	INPUT SHAFT THRUST WASHER	100
PRE-INSPECTION	87	DIFFERENTIALSIDE GEAR THRUST WASHER	100
DISASSEMBLY	87	Available Adjusting Shims	100
INSPECTION AFTER DISASSEMBLY	88	MAINSHAFT ADJUSTING SHIM	100
ASSEMBLY	88	INPUT SHAFT REAR BEARING ADJUSTING SHIM	101
Assembly and Disassembly (RS6F51A)	90	MAINSHAFT REAR BEARING ADJUSTING SHIM	101
PRE-INSPECTION	90	REVERSE IDLER GEAR ADJUSTING SHIM ...	101
DISASSEMBLY	91	6TH MAIN GEAR ADJUSTING SHIM	101
INSPECTION AFTER DISASSEMBLY	92	Available Shims	102
ASSEMBLY	92	BEARING PRELOAD	102
SHIFT CONTROL	95	DIFFERENTIAL SIDE BEARING ADJUSTING SHIM(S)	102
Inspection (RS5F51A)	95		
SHIFT FORK	95		
Inspection (RS6F51A)	96		
SHIFT FORK	96		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Caution

ECS008BM

- Do not reuse transaxle oil, once it has been drained.
- Check oil level or replace oil with vehicle on level ground.
- During removal or installation, keep inside of transaxle clear of dust or dirt.
- Check for the correct installation status prior to removal or disassembly. If mating marks are required, be certain they do not interfere with the function of the parts they are applied to.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Be careful not to damage sliding surfaces and mating surfaces.

A

B

MT

D

E

F

G

H

I

J

K

L

M







PREPARATION

PREPARATION







PFP:00002

Special Service Tools





ECS008BN

Tool name Tool number	Description
<p>Puller KV381054S0</p>  <p>ZZA0601D</p>	<ul style="list-style-type: none"> ● Side bearing outer race removal ● Mainshaft front bearing removal
<p>Drift ST35321000 a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.</p>  <p>ZZA1000D</p>	<ul style="list-style-type: none"> ● Input shaft oil seal installation ● Reverse main gear installation ● 1st bushing installation ● 1st-2nd synchronizer hub installation ● 2nd bushing installation ● 3rd main gear installation ● Differential side bearing removal
<p>Drift ST30720000 a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.</p>  <p>ZZA0811D</p>	<ul style="list-style-type: none"> ● Differential oil seal installation ● Differential side bearing outer race installation ● Mainshaft rear bearing installation ● Differential side bearing installation
<p>Drift ST33200000 a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.</p>  <p>ZZA1002D</p>	<ul style="list-style-type: none"> ● Mainshaft front bearing installation ● 6th bushing installation (RS6F51A) ● 4th main gear installation ● 5th main gear installation ● 6th main gear installation (RS6F51A)
<p>Drift KV40105320 a: 88 mm (3.46 in) dia.</p>  <p>ZZA0898D</p>	<ul style="list-style-type: none"> ● Differential side bearing outer race installation
<p>Drift ST33061000 a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.</p>  <p>ZZA1000D</p>	<ul style="list-style-type: none"> ● Bore plug installation ● Differential side bearing removal

PREPARATION




Tool name Tool number	Description
<p>Drift ST33052000 a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.</p>  <p>ZZA1023D</p>	<ul style="list-style-type: none"> ● Welch plug installation ● Input shaft rear bearing removal ● Input shaft bearing spacer and 5th stopper removal (RS5F51A) ● 5th bushing, thrust washer, 4th input gear, 4th gear bushing, 3rd-4th synchronizer hub and 3rd input gear removal ● Input shaft front bearing installation ● 6th input gear and 6th bushing removal (RS6F51A) ● Mainshaft rear bearing removal ● 4th main gear and 5th main gear removal ● 6th main gear removal (RS6F51A)
<p>Drift KV40105020 a: 39.7 mm (1.563 in) dia. b: 35 mm (1.38 in) dia. c: 15 mm (0.59 in)</p>  <p>ZZA1133D</p>	<ul style="list-style-type: none"> ● 5th input gear and synchronizer hub removal ● 3rd main gear, 2nd main gear, 2nd bushing, 1st-2nd synchronizer hub, 1st main gear, reverse main gear and 1st bushing removal
<p>Press stand KV40105710 a: 46 mm (1.81 in) dia. b: 41 mm (1.61 in)</p>  <p>ZZA1058D</p>	<ul style="list-style-type: none"> ● 3rd-4th synchronizer hub installation ● 4th bushing installation ● 5th bushing installation ● 5th synchronizer hub installation (RS5F51A) ● 5th-6th synchronizer hub installation (RS6F51A) ● 2nd bushing installation ● 3rd main gear installation
<p>Press stand ST38220000 a: 63 mm (2.48 in) dia. b: 65 mm (2.56 in)</p>  <p>ZZA1058D</p>	<ul style="list-style-type: none"> ● Reverse main gear installation ● 1st bushing installation ● 1st-2nd synchronizer hub installation
<p>Drift ST30032000 a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia.</p>  <p>ZZA0978D</p>	<ul style="list-style-type: none"> ● 5th stopper and input shaft bearing spacer installation (RS5F51A) ● Input shaft front bearing installation
<p>Drift ST30901000 a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.</p>  <p>ZZA0978D</p>	<ul style="list-style-type: none"> ● Input shaft rear bearing installation ● 4th main gear installation ● 5th main gear installation ● 6th main gear installation (RS6F51A) ● Mainshaft rear bearing installation

PREPARATION

Tool name Tool number		Description
Puller ST30031000	 ZZA0537D	<ul style="list-style-type: none"> Measuring wear of 1st and 2nd baulk ring
Drift KV40101630 a: 68 mm (2.68 in) dia. b: 60 mm (2.36 in) dia.	 ZZA1003D	<ul style="list-style-type: none"> Reverse main gear installation
Drift KV38102510 a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia.	 ZZA0838D	<ul style="list-style-type: none"> 1st bushing installation 1st-2nd synchronizer hub installation Differential side bearing installation
Drift KV40104830 a: 70 mm (2.76 in) dia. b: 63.5 mm (2.50 in) dia.	 ZZA0936D	<ul style="list-style-type: none"> Differential side bearing installation

Commercial Service Tools

ECS008B0

Tool name		Description
Puller	 ZZA0537D	Each bearing gear and bushing removal
Puller	 NT077	Each bearing gear and bushing removal
Pin punch Tip diameter: 4.5 mm (0.177 in) dia.	 ZZA0815D	Each retaining pin removal and installation

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

ECS008BP

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

MANUAL TRANSAXLE

Reference page														
SUSPECTED PARTS (Possible cause)														
	OIL (Oil level is low.)													
	OIL (Wrong oil.)													
	OIL (Oil level is high.)													
	GASKET (Damaged)													
	OIL SEAL (Worn or damaged)													
	O-RING (Worn or damaged)													
	SHIFT CONTROL LINKAGE (Worn)													
	CHECK PLUG RETURN SPRING AND CHECK BALL (Worn or damaged)													
	SHIFT FORK (Worn)													
	GEAR (Worn or damaged)													
	BEARING (Worn or damaged)													
	BAULK RING (Worn or damaged)													
	INSERT SPRING (Damaged)													
Symptoms	Noise	1	2								3	3		
	Oil leakage		3	1	2	2	2							
	Hard to shift or will not shift		1	1				2					3	3
	Jumps out of gear							1	2	3	3			

DESCRIPTION


DESCRIPTION

PFP:00000

Cross-Sectional View

ECS008BQ

RS5F51A and RS6F51A




SCIA0749E

DESCRIPTION


DOUBLE-CONE SYNCHRONIZER

Double-cone synchronizer is adopted for 1st and 2nd gears to reduce operating force of the shift lever.



REVERSE GEAR NOISE PREVENTION FUNCTION (SYNCHRONIZING METHOD)

The gear can be matched smoothly in a structure by setting synchronizer hub, coupling sleeve, baulk ring and insert spring to reverse gear, and letting gear be synchronized.



M/T OIL


PFP:KLD20

Changing M/T Oil DRAINING

ECS008BR

1. Start the engine and let it run to warm up the transaxle.
2. Stop the engine. Remove drain plug and drain oil.
3. Set a gasket on the drain plug and install it to the transaxle.

Drain plug:

 **30 - 39 N·m (3.1 - 3.9 kg-m, 23 - 28 ft-lb)**

CAUTION:

Do not reuse gasket.

FILLING


1. Remove filler plug. Fill with new oil until oil level reaches the specified limit near filler plug mounting hole.

Oil grade : **API GL-4**

Capacity (reference) : **Approx. 2.3 ℓ (4 Imp pt)**

2. After refilling oil, check oil level. Assemble gasket to filler plug, then install it to transaxle body.

Filler plug:

 **30 - 39 N·m (3.1 - 3.9 kg-m, 23 - 28 ft-lb)**

CAUTION:

Do not reuse gasket.

Checking M/T Oil OIL LEAKAGE AND OIL LEVEL

ECS008BS


- Check that oil is not leaking from transaxle or around it.
- Check oil level from filler plug mounting hole as shown in the figure.

CAUTION:

Never start engine while checking oil level.


- Set a new gasket on the filler plug and install it on the transaxle.

Filler plug:

 **30 - 39 N·m (3.1 - 3.9 kg-m, 23 - 28 ft-lb)**

CAUTION:

Do not reuse gasket.



SCIA0361E

SIDE OIL SEAL

SIDE OIL SEAL

PFP:32113

Removal and Installation


ECS008BT

REMOVAL

- Clutch housing side oil seal used on 4WD vehicles is attached to the transfer. Be sure to replace it when transfer is removed.
1. Remove the drive shaft from the transaxle.
 2. Remove oil seal with flat tip screwdriver.

CAUTION:

Be careful not to damage the case surface when removing the oil seal.



INSTALLATION

1. Using a drift (special service tool), drive the oil seal straight until it protrudes from the case end equal to dimension A shown in the figure.

Dimension "A":

Within 0.5 mm (0.020 in) of flush with the case.


Drift to be used:

Transaxle case side: ST30720000

Clutch housing side: ST30720000

CAUTION:

- When installing oil seals, apply multi-purpose grease to oil seal lips.
 - Oil seals are not reusable. Never reuse them.
2. Install all parts in reverse order of removal and check oil level after installation.



POSITION SWITCH

POSITION SWITCH


PFP:32005

Checking BACK-UP LAMP SWITCH

ECS008BU

- Check continuity.

Gear position	Continuity
Reverse	Yes
Except reverse	No



PARK/NEUTRAL POSITION SWITCH

- Check continuity.

Gear position	Continuity
Neutral	Yes
Except neutral	No

CONTROL LINKAGE


CONTROL LINKAGE

PFP:34103

Removal and Installation of Control Device and Cable

ECS008BV

Refer to the figure for removal and installation procedure.



CAUTION:

- Keep in mind that the select side lock plate for securing the control cable is different from the one on the shift side.
- After assembly, make sure selector lever automatically returns to Neutral when it is moved to 1st, 2nd, or Reverse.

AIR BREATHER HOSE

AIR BREATHER HOSE


PFP:31098

Removal and Installation


ECS008BW

Refer to the figure for air breather hose removal and installation information.

QR engine models



YD engine models



CAUTION:

- Make sure there are no pinched or restricted areas on the air breather hose caused by bending or winding when installing it.
- Be sure to insert hose into the transaxle tube until overlap area reaches the spool.


TRANSAXLE ASSEMBLY

PFP:32010

Removal and Installation

ECS008BX

A
B
MT
D
E
F
G
H
I
J
K
L
M



REMOVAL

1. Remove air cleaner, air duct, and battery.
2. Remove the air breather hose.
3. Remove clutch operating cylinder.

CAUTION:

Do not depress clutch pedal during removal procedure.

4. Disconnect control cable from transaxle.
5. Drain gear oil from transaxle.
6. Disconnect PNP switch, back-up lamp switch, and ground harness connectors.
7. Remove exhaust front tube and the drive shaft.
8. Remove transfer.
 - Refer to [TF-11, "Removal and Installation from Vehicle"](#).
9. Remove starter motor.
10. Place a jack onto the transaxle.


CAUTION:

When setting jack, be careful not to bring it into contact with the switch.

11. Remove center member, engine insulator and engine mount bracket.
 - Refer to [EM-69, "ENGINE ASSEMBLY"](#) (QR engine models) or [EM-193, "ENGINE ASSEMBLY"](#) (YD engine models).
12. Remove suspension members.
 - Refer to [FSU-12, "FRONT SUSPENSION MEMBER"](#).
13. Support engine by placing a jack under oil pan.
14. Remove bolts securing transaxle to engine.

TRANSAXLE ASSEMBLY

15. Remove transaxle from vehicle.



INSTALLATION

Paying attention to the following items, install in the reverse order of removal.

- When installing the transaxle to the engine, tighten to the specified torque.

CAUTION:

When installing transaxle, be careful not to bring transaxle input shaft into contact with the clutch cover.

QR engine models:



Bolt No.	1	2	3*	4	5	6
Quantity	2	1	1	2	2	2
"ℓ" mm (in)	40 (1.57)	75 (2.95)	45 (1.77)	40 (1.57)	30 (1.18)	40 (1.57)
Tightening torque N·m (kg - m, ft - lb)	69.6 - 79.4 (7.1 - 8.1, 52 - 58)			39.2 - 46.1 (4.0 - 4.7, 29 - 34)		30.4 - 40.2 (3.1 - 4.1, 23 - 29)

*: Tightening the bolt for 4WD models.

YD engine models:

Bolt No.	1	2	3	4	5	6
Quantity	2	2	1	1	3	1
"ℓ" mm (in)	55 (2.17)	70 (2.76)	120 (4.72)	45 (1.77)	40 (1.57)	35 (1.38)
Tightening torque N·m (kg - m, ft - lb)	40 - 49 (4.0 - 5.0, 29 - 36)			31 - 36 (3.1 - 3.7, 23 - 26)		

- After installation, check oil level, and look for leaks and loose mechanisms.




TRANSAXLE ASSEMBLY

Component Parts (RS5F51A) CASE AND HOUSING COMPONENTS

ECS008BY

SEC. 321



: N•m (kg-m, ft-lb)

: Apply genuine anaerobic liquid gasket,
Three Bond TB1215, Loctite Part No. 51813 or equivalent.


SCIA1112E

- | | | |
|-------------------|---------------------------|----------------------------------|
| 1. Clutch housing | 2. Input shaft oil seal | 3. Oil channel |
| 4. Magnet | 5. Differential oil seal | 6. Ball pin |
| 7. Washer | 8. Transaxle case | 9. Welch plug |
| 10. Bore plug | 11. Differential oil seal | 12. Park/Neutral position switch |
| 13. Oil gutter | 14. Back-up lamp switch | 15. Air breather tube |
| 16. Baffle plate | 17. Filler plug | 18. Gasket |
| 19. Drain plug | 20. Gasket | |

TRANSAXLE ASSEMBLY

GEAR COMPONENTS

SEC. 322



★ : Select proper thickness.

NOTE :


- Apply gear oil to gears, shafts, synchronizers and bearings when assembling.
- Replace (8) and (10), (20) and (21) as a set.

SCIA0385E

- | | | |
|---------------------------------------|--------------------------------|---|
| 1. Input shaft front bearing | 2. Input shaft | 3. Needle bearing |
| 4. 3rd input gear | 5. 3rd baulk ring | 6. Spread spring |
| 7. 3rd & 4th shifting insert | 8. 3rd & 4th synchronizer hub | 9. 4th baulk ring |
| 10. 3rd & 4th coupling sleeve | 11. Bushing | 12. Needle bearing |
| 13. 4th input gear | 14. Thrust washer | 15. Bushing |
| 16. Needle bearing | 17. 5th input gear | 18. 5th baulk ring |
| 19. 5th shifting insert | 20. 5th synchronizer hub | 21. 5th coupling sleeve |
| 22. 5th stopper | 23. Input shaft bearing spacer | 24. Snap ring |
| 25. Input shaft rear bearing | 26. Oil channel | 27. Input shaft rear bearing adjusting shim |
| 28. Retaining pin | 29. Reverse idler shaft | 30. Thrust needle bearing |
| 31. Needle bearing | 32. Reverse idler gear (Front) | 33. Reverse baulk ring |
| 34. Reverse coupling sleeve | 35. Insert spring | 36. Reverse idler gear (Rear) |
| 37. Reverse idler gear adjusting shim | | |

TRANSAXLE ASSEMBLY

SEC. 322




SCIA0386E

- | | | |
|--------------------------------|---|--------------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft bearing retainer | 3. Mainshaft |
| 4. Reverse main gear | 5. 1st main gear | 6. Bushing |
| 7. Needle bearing | 8. 1st inner baulk ring | 9. 1st gear synchronizer cone |
| 10. 1st outer baulk ring | 11. Spread spring | 12. 1st & 2nd shifting insert |
| 13. 1st & 2nd synchronizer hub | 14. 2nd outer baulk ring | 15. 2nd gear synchronizer cone |
| 16. 2nd inner baulk ring | 17. 1st & 2nd coupling sleeve | 18. Bushing |
| 19. Needle bearing | 20. 2nd main gear | 21. 3rd main gear |
| 22. 3rd & 4th mainshaft spacer | 23. 4th main adjusting shim | 24. 4th main gear |
| 25. 5th main gear | 26. Snap ring | 27. Mainshaft rear bearing |
| 28. Mainshaft C ring | 29. C ring holder | 30. Snap ring |
| 31. Snap ring | 32. Mainshaft rear bearing adjusting shim | |

TRANSAXLE ASSEMBLY

SHIFT CONTROL COMPONENTS

SEC. 328




SCIA0387E

- | | | |
|---------------------------|--------------------------|---------------------------|
| 1. Reverse shift fork | 2. Shifter cap | 3. Reverse fork rod |
| 4. Reverse lever assembly | 5. 5th & reverse bracket | 6. 5th & reverse fork rod |
| 7. 5th shift fork | 8. Retaining pin | 9. 3rd & 4th bracket |
| 10. 3rd & 4th shift fork | 11. 3rd & 4th fork rod | 12. 1st & 2nd shift fork |
| 13. 1st & 2nd bracket | 14. 1st & 2nd fork rod | 15. Shift check sleeve |
| 16. Inter lock pin | 17. Check ball | 18. Shift check sleeve |
| 19. Check spring | 20. Check plug | 21. Control assembly |
| 22. O ring | 23. Shift check | 24. Stopper bolt |
| 25. Stopper ring | | |

TRANSAXLE ASSEMBLY

FINAL DRIVE COMPONENTS

SEC. 381



SCIA0388E


- | | | |
|---|------------------------------|---|
| 1. Differential side bearing outer race | 2. Differential side bearing | 3. Differential case |
| 4. Final gear | 5. Differential side bearing | 6. Differential side bearing outer race |
| 7. Differential side bearing adjusting shim | 8. Pinion mate shaft | 9. Side gear |
| 10. Side gear thrust washer | 11. Pinion mate gear | 12. Pinion mate gear washer |
| 13. Retaining pin | | |

TRANSAXLE ASSEMBLY

Component Parts (RS6F51A) CASE AND HOUSING COMPONENTS

ECS008BZ

SEC. 321



: N·m (kg-m, ft-lb)

: Apply genuine anaerobic liquid gasket,
Three Bond TB1215, Loctite Part No. 51813 or equivalent.


SCIA1112E

- | | | |
|-------------------|---------------------------|----------------------------------|
| 1. Clutch housing | 2. Input shaft oil seal | 3. Oil channel |
| 4. Magnet | 5. Differential oil seal | 6. Ball pin |
| 7. Washer | 8. Transaxle case | 9. Welch plug |
| 10. Bore plug | 11. Differential oil seal | 12. Park/Neutral position switch |
| 13. Oil gutter | 14. Back-up lamp switch | 15. Air breather tube |
| 16. Baffle plate | 17. Filler plug | 18. Gasket |
| 19. Drain plug | 20. Gasket | |

TRANSAXLE ASSEMBLY

GEAR COMPONENTS

SEC. 322



★ : Select proper thickness.

NOTE :


- Apply gear oil to gears, shafts, synchronizers and bearings when assembling.
- Replace (8) and (10), (20) and (21) as a set.

SCIA0956E

- | | | |
|--------------------------------|---|---------------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. Needle bearing |
| 4. 3rd input gear | 5. 3rd baulk ring | 6. Spread spring |
| 7. 3rd & 4th shifting insert | 8. 3rd & 4th synchronizer hub | 9. 4th baulk ring |
| 10. 3rd & 4th coupling sleeve | 11. Bushing | 12. Needle bearing |
| 13. 4th input gear | 14. Thrust washer | 15. Bushing |
| 16. Needle bearing | 17. 5th input gear | 18. 5th baulk ring |
| 19. 5th & 6th shifting insert | 20. 5th & 6th synchronizer hub | 21. 5th & 6th coupling sleeve |
| 22. 6th baulk ring | 23. 6th input gear | 24. Needle bearing |
| 25. Bushing | 26. Snap ring | 27. Input shaft rear bearing |
| 28. Oil channel | 29. Input shaft rear bearing adjusting shim | 30. Retaining pin |
| 31. Reverse idler shaft | 32. Thrust needle bearing | 33. Needle bearing |
| 34. Reverse idler gear (Front) | 35. Reverse baulk ring | 36. Reverse coupling sleeve |
| 37. Insert spring | 38. Reverse idler gear (Rear) | 39. Reverse idler gear adjusting shim |

TRANSAXLE ASSEMBLY

SEC. 322




SCIA0957E

- | | | |
|--------------------------------|---|--------------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft bearing retainer | 3. Mainshaft |
| 4. Reverse main gear | 5. 1st main gear | 6. Bushing |
| 7. Needle bearing | 8. 1st inner baulk ring | 9. 1st gear synchronizer cone |
| 10. 1st outer baulk ring | 11. Spread spring | 12. 1st & 2nd shifting insert |
| 13. 1st & 2nd synchronizer hub | 14. 2nd outer baulk ring | 15. 2nd gear synchronizer cone |
| 16. 2nd inner baulk ring | 17. 1st & 2nd coupling sleeve | 18. Bushing |
| 19. Needle bearing | 20. 2nd main gear | 21. 3rd main gear |
| 22. 3rd & 4th mainshaft spacer | 23. 4th main adjusting shim | 24. 4th main gear |
| 25. 5th main gear | 26. 6th main gear | 27. Mainshaft rear bearing |
| 28. Mainshaft C ring | 29. C ring holder | 30. Snap ring |
| 31. Snap ring | 32. Mainshaft rear bearing adjusting shim | 33. 5th & 6th mainshaft spacer |
| 34. 6th main adjusting shim | | |

TRANSAXLE ASSEMBLY

SHIFT CONTROL COMPONENTS

SEC. 328




- | | | |
|--------------------------------|------------------------------|--------------------------|
| 1. Reverse shift fork | 2. Shifter cap | 3. Reverse fork rod |
| 4. Reverse lever assembly | 5. 5th & 6th bracket | 6. 5th & 6th fork rod |
| 7. 5th & 6th shift fork | 8. Retaining pin | 9. 3rd & 4th bracket |
| 10. 3rd & 4th shift fork | 11. 3rd & 4th fork rod | 12. 1st & 2nd shift fork |
| 13. 1st & 2nd fork rod bracket | 14. 1st & 2nd fork rod | 15. Shift check sleeve |
| 16. Inter lock pin | 17. Check ball | 18. Shift check sleeve |
| 19. Check spring | 20. Check plug | 21. Control assembly |
| 22. O ring | 23. Shift check | 24. Stopper bolt |
| 25. Stopper ring | 26. Reverse bracket fork rod | 27. Reverse bracket |

SCIA0958E

TRANSAXLE ASSEMBLY

FINAL DRIVE COMPONENTS

SEC. 381



SCIA0388E


- | | | |
|---|------------------------------|---|
| 1. Differential side bearing outer race | 2. Differential side bearing | 3. Differential case |
| 4. Final gear | 5. Differential side bearing | 6. Differential side bearing outer race |
| 7. Differential side bearing adjusting shim | 8. Pinion mate shaft | 9. Side gear |
| 10. Side gear thrust washer | 11. Pinion mate gear | 12. Pinion mate gear washer |
| 13. Retaining pin | | |

Disassembly and Assembly (RS5F51A)

DISASSEMBLY

1. Remove drain plug and filler plug.
2. Remove park/neutral position switch and back-up lamp switch.
3. After removing shift check and stopper bolt, remove control assembly.


ECS008C0



SCIA0389E

TRANSAXLE ASSEMBLY

4. Remove check plugs (3 pieces), check springs (3 pieces), check balls (3 pieces) and shift check sleeve (1 piece).




5. Remove transaxle case fixing bolts.
6. Remove bore plug.


CAUTION:

Be careful not to damage transaxle case.


7. While spreading the snap ring of mainshaft rear bearing located at bore plug hole, remove transaxle case.
8. Remove oil gutter, baffle plate.
9. Remove snap ring, mainshaft rear bearing adjusting shim and input shaft rear bearing adjusting shim from transaxle case.




10. Remove differential side bearing outer race (transaxle case side) and then adjust shim.



11. Remove welch plug.



12. Remove differential oil seal (transaxle case side).
13. Remove magnet from clutch housing.




TRANSAXLE ASSEMBLY

14. With shift lever in 5th position, remove bracket bolts from reverse lever assembly. Lift reverse lever assembly to remove.


CAUTION:

Be careful not to lose shifter cap.


15. Pull out reverse fork rod then remove reverse shift fork.




16. Shift 3rd & 4th fork rod to 3rd position. Remove retaining pin of 5th shift fork using pin punch.




17. Remove stopper rings for 5th & reverse bracket.
18. Pull out 5th & reverse fork rod and remove 5th shift fork and 5th & reverse bracket.
19. Remove check balls (2 pieces) and inter lock pin.



20. Remove retaining pin of 3rd & 4th bracket using pin punch.
21. Remove stopper rings for 3rd & 4th shift fork.
22. Pull out 3rd & 4th fork rod and remove 3rd & 4th shift fork and bracket.
23. Remove shift check sleeve from clutch housing.



24. Remove retaining pin of 1st & 2nd shift fork using pin punch.
25. Pull out 1st & 2nd fork rod with bracket.
26. Remove 1st & 2nd shift fork.
27. Remove retaining pin of 1st & 2nd bracket using pin punch and separate 1st & 2nd fork rod and bracket.



TRANSAXLE ASSEMBLY


28. Remove gear components from clutch housing in the following procedure.

- a. While tapping input shaft with plastic hammer, remove input shaft assembly, mainshaft assembly and reverse idler gear assembly as a set.

CAUTION:


Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.

- b. Remove final drive assembly.




29. Remove bearing retainer and then mainshaft front bearing.


30. Remove oil channel on mainshaft side.



31. Remove differential oil seal (clutch housing side).




32. Remove differential side bearing outer race (clutch housing side).



33. Remove input shaft oil seal.

CAUTION:

Be careful not to damage clutch housing.




TRANSAXLE ASSEMBLY

ASSEMBLY

1. Using a drift, install input shaft oil seal from clutch housing end of side to the depth of 1.8 to 2.8 mm (0.071 to 0.110 in).

CAUTION:


Do not reuse oil seals.



2. Using a drift, install differential oil seal until the face is flush with clutch housing.

CAUTION:


Do not reuse oil seals.



3. Install oil channel on mainshaft side.

CAUTION:


Be careful with orientation of installation.



4. Using a drift, install mainshaft front bearing.

CAUTION:


Be careful with orientation of installation.




TRANSAXLE ASSEMBLY

5. Install bearing retainer.


CAUTION:
Install with punched surface facing up.



6. Install differential side bearing outer race.




7. Install final drive assembly into clutch housing.




8. Install input shaft assembly, mainshaft assembly, and reverse idler gear assembly into clutch housing.

CAUTION:
Be sure not to damage input shaft oil seal.



9. Install 1st-2nd fork rod bracket onto 1st-2nd fork rod, and then install retaining pin.

CAUTION:
Do not reuse retaining pins.




TRANSAXLE ASSEMBLY

10. Install 1st-2nd fork rod and 1st-2nd shift fork, and then install retaining pin.

CAUTION:

Do not reuse retaining pins.

11. Install shift check sleeve.



12. Install 3rd-4th bracket, 3rd-4th shift fork, and 3rd-4th fork rod with inter lock pin.

13. Install stopper ring onto 3rd-4th shift fork.

CAUTION:


Do not reuse stopper ring.

14. Install retaining pin onto 3rd-4th bracket.

CAUTION:

Do not reuse retaining pins.

15. Install 2 check balls.




16. Install 5th-reverse bracket, 5th shift fork, and 5th-reverse fork rod.

17. Install stopper ring onto 5th-reverse bracket.

CAUTION:

Do not reuse stopper ring.



18. Install retaining pin onto 5th shift fork.

CAUTION:

Do not reuse retaining pins.


19. Install reverse shift fork and reverse fork rod.

20. Install reverse lever assembly following procedures below.


- a. Install shifter cap onto reverse lever assembly cam, and then install them onto reverse shift fork.

CAUTION:

Do not drop shifter cap.



- b. While lifting reverse shift fork, align cam with 5th-reverse bracket.




TRANSAXLE ASSEMBLY

- c. Tighten mounting bolts to specified torque, and then install reverse lever assembly.
21. Install check ball, 5th-reverse shift check sleeve, check spring and 5th-reverse check ball plug.

CAUTION:

- Do not reuse check ball plug.
- Do not drop check ball.

22. Install the magnet onto clutch housing.




23. Using a drift, install differential oil seal until it is flush with end face of transaxle case.

CAUTION:

Do not reuse oil seals.

24. Install selected input shaft adjusting shim onto input shaft.
 - For selection of adjusting shims, refer to [MT-45. "INPUT SHAFT END PLAY"](#).
25. Install baffle plate and oil gutter.
26. Install transaxle case following procedures below.
 - a. Install selected mainshaft rear bearing adjusting shim into transaxle case.
 - For selection of adjusting shims, refer to [MT-46. "MAINSHAFT END PLAY"](#).
 - b. Temporarily install snap ring of mainshaft rear bearing into transaxle case.




CAUTION:

Do not reuse the snap ring.


- c. Apply recommended sealant to mating surfaces of transaxle case and clutch housing.

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.




- d. With snap ring of mainshaft rear bearing temporarily installed, place transaxle case over clutch housing.



TRANSAXLE ASSEMBLY

- e. Through bore plug mounting hole, with snap ring stretched, and lift up mainshaft assembly from the control assembly mounting hole.
- f. Securely install snap ring onto mainshaft rear bearing.



- g. Tighten mounting bolts.

Bolt A:

: 50.0 - 53.9 N·m (5.1 - 5.4 kg-m, 37 - 39 ft-lb)

Bolt B:

: 63.0 - 66.9 N·m (6.5 - 6.8 kg-m, 47 - 49 ft-lb)

CAUTION:

Always replace bolts B as they are self-sealing bolts.

- h. Install control assembly.

CAUTION:

Do not reuse the O-ring.

- i. Install shift check and stopper bolt.



CAUTION:

Does not reuse shift check and stopper bolt.

27. Using a drift, install bore plug.

CAUTION:

Do not reuse bore plug.




TRANSAXLE ASSEMBLY

28. Using a drift, install welch plug.

CAUTION:


Do not reuse welch plug.



29. Install 2 check balls, 2 check springs and 2 check ball plugs.

CAUTION:

Do not reuse check ball plug.




30. Apply recommended sealant to threads of neutral switch and reverse lamp switch. Then install them into transaxle case.

31. Install gaskets onto drain plug and filler plug, and then install them into transaxle case.

CAUTION:


- **Do not reuse gasket.**
- **After oil is filled, tighten filler plug to specified torque.**



Disassembly and Assembly (RS6F51A)


DISASSEMBLY

1. Remove drain plug and filler plug.
2. Remove park/neutral position switch and back-up lamp switch.
3. After removing shift check and stopper bolt, remove control assembly.



TRANSAXLE ASSEMBLY

4. Remove check plugs (4 pieces), check springs (4 pieces), check balls (4 pieces) and shift check sleeve (2 pieces).




5. Remove transaxle case fixing bolts.
6. Remove bore plug.


CAUTION:

Be careful not to damage transaxle case.


7. While spreading the snap ring of mainshaft rear bearing located at bore plug hole, remove transaxle case.
8. Remove oil gutter, baffle plate.
9. Remove snap ring, mainshaft rear bearing adjusting shim and input shaft rear bearing adjusting shim from transaxle case.




10. Remove differential side bearing outer race (transaxle case side) and then adjusting shim.



11. Remove welch plug.



12. Remove differential oil seal (transaxle case side).
13. Remove magnet from clutch housing.




TRANSAXLE ASSEMBLY

14. With shift lever in 5th position, remove bracket bolts from reverse lever assembly. Lift reverse lever assembly to remove.


CAUTION:

Be careful not to lose shifter cap.


15. Pull out reverse fork rod then remove reverse shift fork.




16. Remove retaining pin of reverse bracket.
17. Pull out reverse bracket and reverse bracket fork rod.
18. Remove check ball (2 pieces) and inter lock pin.




19. Shift 3rd & 4th fork rod to 3rd position. Remove retaining pin of 5th & 6th shift fork using pin punch.



20. Remove stopper rings for 5th & 6th bracket.
21. Pull out 5th & 6th fork rod and remove 5th & 6th shift fork and 5th & 6th bracket.
22. Remove check balls (2 pieces) and inter lock pin.



23. Remove retaining pin of 3rd & 4th bracket using pin punch.
24. Remove stopper rings for 3rd & 4th shift fork.
25. Pull out 3rd & 4th fork rod and remove 3rd & 4th shift fork and bracket.
26. Remove shift check sleeve from clutch housing.



A

B

MT

D

E

F

G

H

I

J


K

L

M

TRANSAXLE ASSEMBLY


27. Remove retaining pin of 1st & 2nd shift fork using pin punch.
28. Pull out 1st & 2nd fork rod with bracket.
29. Remove 1st & 2nd shift fork.
30. Remove retaining pin of 1st & 2nd bracket using pin punch and separate fork rod and bracket.




31. Remove gear components from clutch housing in the following procedure.
 - a. While tapping input shaft with plastic hammer, remove input shaft assembly, mainshaft assembly and reverse idler gear assembly as a set.

CAUTION:
Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.


 - b. Remove final drive assembly.




32. Remove main bearing retainer and then mainshaft front bearing.
33. Remove oil channel on mainshaft side.



34. Remove differential oil seal (clutch housing side).




35. Remove differential side bearing outer race (clutch housing side).



TRANSAXLE ASSEMBLY

36. Remove input shaft oil seal.

CAUTION:
Be careful not to damage clutch housing.



A

B


MT

D

ASSEMBLY

1. Using a drift, install input shaft oil seal from clutch housing end of side to the depth of 1.8 to 2.8 mm (0.071 to 0.110 in).

CAUTION:
Do not reuse oil seals.




E

F

G

2. Using a drift, install differential oil seal until the face is flush with clutch housing.

CAUTION:
Do not reuse oil seals.



H


I

J

K

3. Install oil channel on mainshaft side.

CAUTION:
Be careful with orientation of installation.



L


M

TRANSAXLE ASSEMBLY

4. Using a drift, install mainshaft front bearing.

CAUTION:


Be careful with orientation of installation.




5. Install bearing retainer.

CAUTION:


Install with punched surface facing up.



6. Install differential side bearing outer race.




7. Install final drive assembly into clutch housing.



8. Install input shaft assembly, mainshaft assembly, and reverse idler gear assembly into clutch housing.

CAUTION:

Be sure not to damage input shaft oil seal.




TRANSAXLE ASSEMBLY

9. Install 1st-2nd fork rod bracket onto 1st-2nd fork rod, and then install retaining pin.

CAUTION:

Do not reuse retaining pin.




10. Install 1st-2nd fork rod and 1st-2nd shift fork, and then install retaining pin.

CAUTION:

Do not reuse retaining pin.

11. Install shift check sleeve.



12. Install 3rd-4th bracket, 3rd-4th shift fork, and 3rd-4th fork rod with inter lock pin.

13. Install stopper ring onto 3rd-4th shift fork.

CAUTION:


Do not stopper ring.

14. Install retaining pin onto 3rd-4th bracket.

CAUTION:

Do not reuse retaining pin.

15. Install 2 check balls.




16. Install 5th-6th bracket, 5th-6th shift fork, and 5th-6th fork rod with inter lock pin.

17. Install stopper ring onto 5th-6th bracket.

CAUTION:

Do not stopper ring.



18. Install retaining pin onto 5th-6th shift fork.

CAUTION:

Do not reuse retaining pin.

19. Install 2 check balls.


20. Install check ball, 5th-6th shift check sleeve, 5th-6th check spring and 5th-6th check ball plug.

CAUTION:

● **Do not reuse check ball plug.**

● **Do not drop check ball.**

21. Install reverse bracket fork rod and reverse lever bracket.



TRANSAXLE ASSEMBLY

22. Install retaining pin onto reverse bracket.


CAUTION:

Do not reuse retaining pin.


23. Install reverse shift fork and reverse fork rod.
24. Install reverse lever assembly following procedures below.
a. Install shifter cap onto reverse lever assembly cam, and then install them onto reverse shift fork.

CAUTION:

Do not drop shifter cap.



- b. While lifting reverse shift fork, align cam with reverse bracket.




- c. Tighten mounting bolts to specified torque, and then install reverse lever assembly.
25. Install check ball, reverse shift check sleeve, reverse check spring and reverse check ball plug.

CAUTION:

- Do not reuse check ball plug.
- Do not drop check ball.

26. Install the magnet onto clutch housing.



27. Using a drift, install differential oil seal until it is flush with end face of transaxle case.

CAUTION:

Do not reuse oil seals.

28. Install selected input shaft adjusting shim onto input shaft.
● For selection of adjusting shims, refer to [MT-49, "INPUT SHAFT END PLAY"](#).

29. Install baffle plate and oil gutter.

30. Install transaxle case following procedures below.


- a. Install selected mainshaft rear bearing adjusting shim into transaxle case.

- For selection of adjusting shims, refer to [MT-50, "MAINSHAFT END PLAY"](#).

- b. Temporarily install snap ring of mainshaft rear bearing into transaxle case.

CAUTION:

Do not reuse the snap ring.




TRANSAXLE ASSEMBLY


- c. Apply recommended sealant to mating surfaces of transaxle case and clutch housing.

CAUTION:


Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



- d. With snap ring of mainshaft rear bearing temporarily installed, place transaxle case over clutch housing.



- e. Through bore plug mounting hole, with snap ring stretched, and lift up mainshaft assembly from the control assembly mounting hole.
- f. Securely install snap ring onto mainshaft rear bearing.



- g. Tighten mounting bolts.

Bolt A:

: 50.0 - 53.9 N·m (5.1 - 5.4 kg-m, 37 - 39 ft-lb)


Bolt B:

: 63.0 - 66.9 N·m (6.5 - 6.8 kg-m, 47 - 49 ft-lb)

CAUTION:

Always replace bolts B as they are self-sealing bolts.

- h. Install control assembly.



TRANSAXLE ASSEMBLY

CAUTION:

Do not reuse the O-ring.

- i. Install shift check and stopper bolt.


CAUTION:

Does not reuse shift check and stopper bolt.

31. Using a drift, install bore plug.

CAUTION:


Do not reuse bore plug.



32. Using a drift, install welch plug.

CAUTION:


Do not reuse welch plug.



33. Install 2 check balls, 2 check springs and 2 check ball plugs.

CAUTION:


Do not reuse check ball plug.



34. Apply recommended sealant to threads of neutral switch and reverse lamp switch. Then install them into transaxle case.
35. Install gaskets onto drain plug and filler plug, and then install them into transaxle case.

CAUTION:

- **Do not reuse gasket.**
- **After oil is filled, tighten filler plug to specified torque.**



TRANSAXLE ASSEMBLY

Adjustment (RS5F51A) INPUT SHAFT END PLAY

ECS008C2

- When adjusting input shaft end play, select adjusting shim for input shaft bearing. To select adjusting shim, measure clearance between transaxle case and input shaft rear bearing.
- Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.


End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "O" = (O₁ - O₂) + End play

O: Thickness of adjusting shim

O₁: Distance between transaxle case end face and mounting face of adjusting shim

O₂: Distance between clutch housing case end face and end face of input shaft rear bearing




Adjusting Shim

Shim thickness	Part number	Shim thickness	Part number	Shim thickness	Part number
0.40 mm (0.0157 in)	32225 8H500	0.88 mm (0.0346 in)	32225 8H512	1.36 mm (0.0535 in)	32225 8H524
0.44 mm (0.0173 in)	32225 8H501	0.92 mm (0.0362 in)	32225 8H513	1.40 mm (0.0551 in)	32225 8H560
0.48 mm (0.0189 in)	32225 8H502	0.96 mm (0.0378 in)	32225 8H514	1.44 mm (0.0567 in)	32225 8H561
0.52 mm (0.0205 in)	32225 8H503	1.00 mm (0.0394 in)	32225 8H515	1.48 mm (0.0583 in)	32225 8H562
0.56 mm (0.0220 in)	32225 8H504	1.04 mm (0.0409 in)	32225 8H516	1.52 mm (0.0598 in)	32225 8H563
0.60 mm (0.0236 in)	32225 8H505	1.08 mm (0.0425 in)	32225 8H517	1.56 mm (0.0614 in)	32225 8H564
0.64 mm (0.0252 in)	32225 8H506	1.12 mm (0.0441 in)	32225 8H518	1.60 mm (0.0630 in)	32225 8H565
0.68 mm (0.0268 in)	32225 8H507	1.16 mm (0.0457 in)	32225 8H519	1.64 mm (0.0646 in)	32225 8H566
0.72 mm (0.0283 in)	32225 8H508	1.20 mm (0.0472 in)	32225 8H520	1.68 mm (0.0661 in)	32225 8H567
0.76 mm (0.0299 in)	32225 8H509	1.24 mm (0.0488 in)	32225 8H521	1.72 mm (0.0677 in)	32225 8H568
0.80 mm (0.0315 in)	32225 8H510	1.28 mm (0.0504 in)	32225 8H522		
0.84 mm (0.0331 in)	32225 8H511	1.32 mm (0.0520 in)	32225 8H523		


CAUTION:

Only 1 adjusting shim can be selected.

- Using depth micrometer and straight edge, measure dimension "O₁" between transaxle case end face and mounting face of adjusting shim.



- Using depth micrometer and straight edge as shown in the figure, measure dimension "O₂" between clutch housing case end face and end face of input shaft rear bearing.
- Install selected input shaft rear bearing adjusting shim onto input shaft.



TRANSAXLE ASSEMBLY

MAINSHAFT END PLAY


- When adjusting mainshaft end play, select adjusting shim for mainshaft rear bearing. To select adjusting shim, measure clearance "M" between transaxle case and mainshaft rear bearing.
- Calculate dimension "P" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for mainshaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = "M" + End play

P: Thickness of adjusting shim

M: Distance between mainshaft rear bearing and transaxle case




Adjusting Shim

Shim thickness	Part number
0.44 mm (0.0173 in)	32238 8H510
0.48 mm (0.0189 in)	32238 8H511
0.52 mm (0.0205 in)	32238 8H512
0.56 mm (0.0220 in)	32238 8H513
0.60 mm (0.0236 in)	32238 8H514
0.64 mm (0.0252 in)	32238 8H515
0.68 mm (0.0268 in)	32238 8H516
0.72 mm (0.0283 in)	32238 8H517
0.76 mm (0.0299 in)	32238 8H518
0.80 mm (0.0315 in)	32238 8H519
0.84 mm (0.0331 in)	32238 8H520
0.88 mm (0.0346 in)	32238 8H521
0.92 mm (0.0362 in)	32238 8H522
0.96 mm (0.0378 in)	32238 8H523
1.00 mm (0.0394 in)	32238 8H524
1.04 mm (0.0409 in)	32238 8H560
1.08 mm (0.0425 in)	32238 8H561

CAUTION:

Only 1 adjusting shim can be selected.

- Install mainshaft assembly to clutch housing.
- Install snap ring to transaxle case.
- Install transaxle case to clutch housing, and temporarily assemble them with fixing bolts. Install temporarily snap ring to mainshaft rear bearing.
- Install dial gauge to snap ring access hole, and expand snap ring. Lift mainshaft assembly through control assembly installation hole, and push it against transaxle case. This state shall be defined as base. Moving distance of mainshaft assembly, with snap ring fit on main bearing, becomes "M".



TRANSAXLE ASSEMBLY

DIFFERENTIAL SIDE BEARING PRELOAD

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.
- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to satisfy specification of preload for differential side bearing.


Preload: 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "L" = (L₁ - L₂) + Preload

L: Thickness of adjusting shim

L₁ Distance between clutch housing case end face and mounting face of adjusting shim

L₂ Distance between differential side bearing and transaxle case





Adjusting Shim

Shim thickness	Part number
0.48 mm (0.0189 in)	31438 80X00
0.52 mm (0.0205 in)	31438 80X01
0.56 mm (0.0220 in)	31438 80X02
0.60 mm (0.0236 in)	31438 80X03
0.64 mm (0.0252 in)	31438 80X04
0.68 mm (0.0268 in)	31438 80X05
0.72 mm (0.0283 in)	31438 80X06
0.76 mm (0.0299 in)	31438 80X07
0.80 mm (0.0315 in)	31438 80X08
0.84 mm (0.0331 in)	31438 80X09
0.88 mm (0.0346 in)	31438 80X10
0.92 mm (0.0362 in)	31438 80X11

CAUTION:


Up to 2 adjusting shims can be selected.

- Using depth micrometer and straightedge, measure dimension "L₁" between clutch housing case end face and mounting face of adjusting shim.
- Install outer race onto differential side bearing on final gear side. Holding lightly the outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).
- Using depth micrometer and straightedge as shown in the figure, measure dimension "L₂" between differential side bearing outer race and transaxle case end face.



TRANSAXLE ASSEMBLY

4. Install selected adjusting shim and then differential side bearing outer race.



REVERSE IDLER GEAR END PLAY

- When adjusting reverse idler gear end play, select adjusting shim for reverse idler gear. To select adjusting shim, measure clearance between transaxle case and reverse idler gear.
- Calculate dimension "Q" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for reverse idler gear.


End play: 0.04 - 0.10 mm (0.0016 - 0.0039 in)

Dimension "Q" = (Q₁ - Q₂) + End play

Q: Thickness of adjusting shim

Q₁: Distance between transaxle case end face and mounting face of adjusting shim

Q₂: Distance between clutch housing case end face and end face of reverse idler gear




Adjusting Shim

Shim thickness	Part number	Shim thickness	Part number
1.76 mm (0.0693 in)	32237 8H800	2.24 mm (0.0882 in)	32237 8H812
1.80 mm (0.0709 in)	32237 8H801	2.28 mm (0.0898 in)	32237 8H813
1.84 mm (0.0724 in)	32237 8H802	2.32 mm (0.0913 in)	32237 8H814
1.88 mm (0.0740 in)	32237 8H803	2.36 mm (0.0929 in)	32237 8H815
1.92 mm (0.0756 in)	32237 8H804	2.40 mm (0.0945 in)	32237 8H816
1.96 mm (0.0772 in)	32237 8H805	2.44 mm (0.0961 in)	32237 8H817
2.00 mm (0.0787 in)	32237 8H806	2.48 mm (0.0976 in)	32237 8H818
2.04 mm (0.0803 in)	32237 8H807	2.52 mm (0.0992 in)	32237 8H819
2.08 mm (0.0819 in)	32237 8H808	2.56 mm (0.1008 in)	32237 8H820
2.12 mm (0.0835 in)	32237 8H809	2.60 mm (0.1024 in)	32237 8H821
2.16 mm (0.0850 in)	32237 8H810	2.64 mm (0.1039 in)	32237 8H822
2.20 mm (0.0866 in)	32237 8H811		

CAUTION:


Only 1 adjusting shim can be selected.

1. Using depth micrometer and straight edge, measure dimension "Q₁" between transaxle case end face and mounting face of adjusting shim.



TRANSAXLE ASSEMBLY

- Using depth micrometer and straight edge as shown in the figure, measure dimension "Q2" between clutch housing case end face and end face of reverse idler gear.
- Install selected reverse idler gear adjusting shim onto reverse idler gear assembly.



Adjustment (RS6F51A) INPUT SHAFT END PLAY

- When adjusting input shaft end play, select adjusting shim for input shaft bearing. To select adjusting shim, measure clearance between transaxle case and input shaft rear bearing.
- Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.


End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "O" = (O1 - O2) + End play

O: Thickness of adjusting shim

O1 Distance between transaxle case end face and mounting face of adjusting shim

O2 Distance between clutch housing case end face and end face of input shaft rear bearing




Adjusting Shim

Shim thickness	Part number	Shim thickness	Part number	Shim thickness	Part number
0.40 mm (0.0157 in)	32225 8H500	0.84 mm (0.0331 in)	32225 8H511	1.28 mm (0.0504 in)	32225 8H522
0.44 mm (0.0173 in)	32225 8H501	0.88 mm (0.0346 in)	32225 8H512	1.32 mm (0.0520 in)	32225 8H523
0.48 mm (0.0189 in)	32225 8H502	0.92 mm (0.0362 in)	32225 8H513	1.36 mm (0.0535 in)	32225 8H524
0.52 mm (0.0205 in)	32225 8H503	0.96 mm (0.0378 in)	32225 8H514	1.40 mm (0.0551 in)	32225 8H560
0.56 mm (0.0220 in)	32225 8H504	1.00 mm (0.0394 in)	32225 8H515	1.44 mm (0.0567 in)	32225 8H561
0.60 mm (0.0236 in)	32225 8H505	1.04 mm (0.0409 in)	32225 8H516	1.48 mm (0.0583 in)	32225 8H562
0.64 mm (0.0252 in)	32225 8H506	1.08 mm (0.0425 in)	32225 8H517	1.52 mm (0.0598 in)	32225 8H563
0.68 mm (0.0268 in)	32225 8H507	1.12 mm (0.0441 in)	32225 8H518	1.56 mm (0.0614 in)	32225 8H564
0.72 mm (0.0283 in)	32225 8H508	1.16 mm (0.0457 in)	32225 8H519	1.60 mm (0.0630 in)	32225 8H565
0.76 mm (0.0299 in)	32225 8H509	1.20 mm (0.0472 in)	32225 8H520	1.64 mm (0.0646 in)	32225 8H566
0.80 mm (0.0315 in)	32225 8H510	1.24 mm (0.0488 in)	32225 8H521		

CAUTION:


Only 1 adjusting shim can be selected.

- Using depth micrometer and straight edge, measure dimension "O1" between transaxle case end face and mounting face of adjusting shim.



TRANSAXLE ASSEMBLY

2. Using depth micrometer and straight edge as shown in the figure, measure dimension "O₂" between clutch housing case end face and end face of input shaft rear bearing.
3. Install selected input shaft rear bearing adjusting shim onto input shaft.



MAINSHAFT END PLAY


- When adjusting mainshaft end play, select adjusting shim for mainshaft rear bearing. To select adjusting shim, measure clearance "M" between transaxle case and mainshaft rear bearing.
- Calculate dimension "P" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for mainshaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = "M" + End play

P: Thickness of adjusting shim

M: Distance between mainshaft rear bearing and transaxle case



Adjusting Shim

Shim thickness	Part number
0.44 mm (0.0173 in)	32238 8H510
0.48 mm (0.0189 in)	32238 8H511
0.52 mm (0.0205 in)	32238 8H512
0.56 mm (0.0220 in)	32238 8H513
0.60 mm (0.0236 in)	32238 8H514
0.64 mm (0.0252 in)	32238 8H515
0.68 mm (0.0268 in)	32238 8H516
0.72 mm (0.0283 in)	32238 8H517
0.76 mm (0.0299 in)	32238 8H518
0.80 mm (0.0315 in)	32238 8H519
0.84 mm (0.0331 in)	32238 8H520
0.88 mm (0.0346 in)	32238 8H521
0.92 mm (0.0362 in)	32238 8H522
0.96 mm (0.0378 in)	32238 8H523
1.00 mm (0.0394 in)	32238 8H524
1.04 mm (0.0409 in)	32238 8H560
1.08 mm (0.0425 in)	32238 8H561


CAUTION:

Only 1 adjusting shim can be selected.

1. Install mainshaft assembly to clutch housing.
2. Install snap ring to transaxle case.
3. Install transaxle case to clutch housing, and temporarily assemble them with fixing bolts. Install temporarily snap ring to mainshaft rear bearing.

TRANSAXLE ASSEMBLY

4. Install dial gauge to snap ring access hole, and expand snap ring. Lift mainshaft assembly through control assembly installation hole, and push it against transaxle case. This state shall be defined as base. Moving distance of mainshaft assembly, with snap ring fit on main bearing, becomes "M".



DIFFERENTIAL SIDE BEARING PRELOAD

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.
- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to satisfy specification of preload for differential side bearing.


Preload: 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "L" = (L₁ - L₂) + Preload

L: Thickness of adjusting shim

L₁ Distance between clutch housing case end face and mounting face of adjusting shim

L₂ Distance between differential side bearing and transaxle case




Adjusting Shim

Shim thickness	Part number
0.48 mm (0.0189 in)	31438 80X00
0.52 mm (0.0205 in)	31438 80X01
0.56 mm (0.0220 in)	31438 80X02
0.60 mm (0.0236 in)	31438 80X03
0.64 mm (0.0252 in)	31438 80X04
0.68 mm (0.0268 in)	31438 80X05
0.72 mm (0.0283 in)	31438 80X06
0.76 mm (0.0299 in)	31438 80X07
0.80 mm (0.0315 in)	31438 80X08
0.84 mm (0.0331 in)	31438 80X09
0.88 mm (0.0346 in)	31438 80X10
0.92 mm (0.0362 in)	31438 80X11

CAUTION:


Up to 2 adjusting shims can be selected.

1. Using depth micrometer and straightedge, measure dimension "L₁" between clutch housing case end face and mounting face of adjusting shim.
2. Install outer race onto differential side bearing on final gear side. Holding lightly the outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).




TRANSAXLE ASSEMBLY

- Using depth micrometer and straightedge as shown in the figure, measure dimension "L2" between differential side bearing outer race and transaxle case end face.



- Install selected adjusting shim and then differential side bearing outer race.



REVERSE IDLER GEAR END PLAY

- When adjusting reverse idler gear end play, select adjusting shim for reverse idler gear. To select adjusting shim, measure clearance between transaxle case and reverse idler gear.
- Calculate dimension "Q" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for reverse idler gear.


End play: 0.04 - 0.10 mm (0.0016 - 0.0039 in)

Dimension "Q" = (Q1 - Q2) + End play

Q: Thickness of adjusting shim

Q1 : Distance between transaxle case end face and mounting face of adjusting shim

Q2 : Distance between clutch housing case end face and end face of reverse idler gear



Adjusting Shim


Shim thickness	Part number	Shim thickness	Part number
1.76 mm (0.0693 in)	32237 8H800	2.24 mm (0.0882 in)	32237 8H812
1.80 mm (0.0709 in)	32237 8H801	2.28 mm (0.0898 in)	32237 8H813
1.84 mm (0.0724 in)	32237 8H802	2.32 mm (0.0913 in)	32237 8H814
1.88 mm (0.0740 in)	32237 8H803	2.36 mm (0.0929 in)	32237 8H815
1.92 mm (0.0756 in)	32237 8H804	2.40 mm (0.0945 in)	32237 8H816
1.96 mm (0.0772 in)	32237 8H805	2.44 mm (0.0961 in)	32237 8H817
2.00 mm (0.0787 in)	32237 8H806	2.48 mm (0.0976 in)	32237 8H818
2.04 mm (0.0803 in)	32237 8H807	2.52 mm (0.0992 in)	32237 8H819
2.08 mm (0.0819 in)	32237 8H808	2.56 mm (0.1008 in)	32237 8H820
2.12 mm (0.0835 in)	32237 8H809	2.60 mm (0.1024 in)	32237 8H821
2.16 mm (0.0850 in)	32237 8H810	2.64 mm (0.1039 in)	32237 8H822
2.20 mm (0.0866 in)	32237 8H811		

CAUTION:


Only 1 adjusting shim can be selected.

TRANSAXLE ASSEMBLY

1. Using depth micrometer and straight edge, measure dimension "Q1 " between transaxle case end face and mounting face of adjusting shim.



2. Using depth micrometer and straight edge as shown in the figure, measure dimension "Q2 " between clutch housing case end face and end face of reverse idler gear.
3. Install selected reverse idler gear adjusting shim onto reverse idler gear assembly.



A

B

MT

D

E

F

G

H

I

J

K

L

M

INPUT SHAFT AND GEARS

INPUT SHAFT AND GEARS

PFP:32200

Assembly and Disassembly (RS5F51A) DISASSEMBLY

ECS008C4

1. Before disassembling, measure end play for 3rd, 4th, and 5th input gears.


End play standard value

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)


4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)


2. Remove oil channel.




3. Remove input shaft rear bearing.



4. Remove the snap ring.




5. Remove input shaft bearing spacer and 5th stopper simultaneously.




INPUT SHAFT AND GEARS


6. Remove 5th input gear and synchronizer hub assembly simultaneously.
7. Remove 5th needle bearing.



8. Remove 5th bushing, thrust washer, 4th input gear, 4th needle bearing, 4th gear bushing, 3rd-4th synchronizer hub assembly, 3rd-4th baulk ring and 3rd input gear simultaneously.
9. Remove 3rd needle bearing.



10. Remove input shaft front bearing.




INSPECTION AFTER DISASSEMBLY

Input Shaft and Gears

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, etc. of shaft
- Excessive wear, damage, peeling, etc. of gears




INPUT SHAFT AND GEARS


Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and excessive wear of contact surfaces of coupling sleeve, synchronizer hub, and shifting insert
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



Baulk ring clearance

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.


Clearance

Standard

3rd and 4th : 0.9 - 1.45 mm (0.0354 - 0.0571 in)

5th : 0.95 - 1.4 mm (0.0374 - 0.0551 in)


Limit value : 0.7 mm (0.0276 in)



Bearing

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing




INPUT SHAFT AND GEARS

ASSEMBLY


1. Install 3rd needle bearing.
2. Install 3rd input gear and 3rd baulk ring.
3. Install spread spring, shifting insert and 3rd-4th synchronizer hub onto 3rd-4th coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub.
- Do not reuse 3rd-4th synchronizer hub.



- Be careful with orientation of coupling sleeve.




- Be sure not to hook center projection of 2 spread springs on same shifting insert.



4. Install 3rd-4th synchronizer hub assembly.


CAUTION:

Align grooves of shifting insert and 3rd baulk ring.



INPUT SHAFT AND GEARS


5. Install 4th bushing.
6. Install 4th baulk ring.
7. Install 4th input gear and 4th needle bearing.



8. Select thrust washer so that dimension "C2" satisfies standard below. Then install it onto input shaft.

Standard for dimension C2

: 154.7 - 154.8 mm (6.091 - 6.094 in)




Thrust Washer

Thickness	Part number	Thickness	Part number
3.84mm (0.1512 in)	32347 8H500	4.02mm (0.1583 in)	32347 8H503
3.90mm (0.1535 in)	32347 8H501	4.08mm (0.1606 in)	32347 8H504
3.96mm (0.1559 in)	32347 8H502	4.14mm (0.1630 in)	32347 8H505

CAUTION:

Only one thrust washer can be selected.

9. Install 5th bushing.
10. Install 5th needle bearing and 5th input gear.
11. Install 5th baulk ring.




12. Install spread spring, shifting insert and 5th synchronizer hub onto 5th coupling sleeve.


INPUT SHAFT AND GEARS

CAUTION:


- Be careful with orientation of synchronizer hub and shifting insert.



- Be careful with orientation of coupling sleeve.




- Be sure not to hook center projection of 2 spread springs on same shifting insert.



13. Install 5th synchronizer hub assembly.


CAUTION:

- Align grooves of 5th shifting insert and 5th baulk ring.



INPUT SHAFT AND GEARS


14. Install 5th stopper and then input shaft bearing spacer.



15. Install snap ring onto input shaft, and check that end play (gap between snap ring and groove) of input shaft bearing spacer satisfies standard.

End play standard value : 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, select snap ring.




Snap Rings

Thickness	Part number	Thickness	Part number
1.71mm (0.0673 in)	32204 8H510	2.01mm (0.0791 in)	32204 8H516
1.76mm (0.0693 in)	32204 8H511	2.06mm (0.0811 in)	32204 8H517
1.81mm (0.0713 in)	32204 8H512	2.11mm (0.0831 in)	32204 8H518
1.86mm (0.0732 in)	32204 8H513	2.16mm (0.0850 in)	32204 8H519
1.91mm (0.0752 in)	32204 8H514	2.21mm (0.0870 in)	32204 8H520
1.96mm (0.0772 in)	32204 8H515	2.26mm (0.0890 in)	32204 8H521

16. Install input shaft rear bearing.


CAUTION:

Install input shaft rear bearing with its brown surface facing the input gear side.



17. Install input shaft front bearing.

18. Install oil channel onto input shaft.



INPUT SHAFT AND GEARS


19. Check end play of 3rd, 4th, and 5th input gears.

End play standard value

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



ECS008C5

Assembly and Disassembly (RS6F51A) DISASSEMBLY

1. Before disassembling, measure end play for 3rd, 4th, 5th and 6th input gears.

End play standard value

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)



5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

2. Remove oil channel.


3. Remove input shaft rear bearing.

4. Remove the snap ring.




5. Remove 6th input gear, 6th bushing and 6th needle bearing.

6. Remove 6th baulk ring, 5th-6th coupling sleeve and shifting insert.




INPUT SHAFT AND GEARS


7. Remove 5th input gear and 5th synchronizer hub assembly simultaneously.
8. Remove 5th needle bearing.



9. Remove 5th bushing, thrust washer, 4th input gear, 4th needle bearing, 4th gear bushing, 3rd-4th synchronizer hub assembly, 3rd-4th baulk ring and 3rd input gear simultaneously.
10. Remove 3rd needle bearing.



11. Remove input shaft front bearing.




INSPECTION AFTER DISASSEMBLY

Input Shaft and Gears

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, etc. of shaft
- Excessive wear, damage, peeling, etc. of gears




INPUT SHAFT AND GEARS


Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and excessive wear of contact surfaces of coupling sleeve, synchronizer hub, and shifting insert
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



Baulk ring clearance

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.


Clearance

Standard

3rd and 4th : 0.9 - 1.45 mm (0.0354 - 0.0571 in)

5th and 6th : 0.95 - 1.4 mm (0.0374 - 0.0551 in)


Limit value : 0.7 mm (0.0276 in)



Bearing

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing




INPUT SHAFT AND GEARS

ASSEMBLY


1. Install 3rd needle bearing.
2. Install 3rd input gear and 3rd baulk ring.
3. Install spread spring, shifting insert and 3rd-4th synchronizer hub onto 3rd-4th coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub.
- Do not reuse 3rd-4th synchronizer hub.



- Be careful with orientation of coupling sleeve.




- Be sure not to hook center projection of 2 spread springs on same shifting insert.



4. Install 3rd-4th synchronizer hub assembly.


CAUTION:

Align grooves of shifting insert and 3rd baulk ring.



INPUT SHAFT AND GEARS


5. Install 4th bushing.
6. Install 4th baulk ring.
7. Install 4th input gear and 4th needle bearing.



8. Select thrust washer so that dimension "C2" satisfies standard below. Then install it onto input shaft.

Standard for dimension C2

: 154.7 - 154.8 mm (6.091 - 6.094 in)




Thrust Washer

Thickness	Part number	Thickness	Part number
3.84mm (0.1512 in)	32347 8H500	4.02mm (0.1583 in)	32347 8H503
3.90mm (0.1535 in)	32347 8H501	4.08mm (0.1606 in)	32347 8H504
3.96mm (0.1559 in)	32347 8H502	4.14mm (0.1630 in)	32347 8H505

CAUTION:

Only one thrust washer can be selected.

9. Install 5th bushing.
10. Install 5th needle bearing and 5th input gear.
11. Install 5th baulk ring.




12. Install 5th-6th synchronizer hub, spread spring and shifting insert onto 5th-6th coupling sleeve.


INPUT SHAFT AND GEARS

CAUTION:

- Be careful with orientation of synchronizer hub.
- Do not reuse 5th-6th synchronizer hub.




- Be sure not to hook center projection of 2 spread springs on same shifting insert.




13. Install 5th-6th synchronizer hub assembly.

CAUTION:

Align grooves of 5th-6th shifting insert and 5th-6th baulk ring.



14. Install 6th needle bearing, 6th input gear onto 6th bushing, and then install them onto input shaft.




INPUT SHAFT AND GEARS

15. Install snap ring onto input shaft, and check that end play (gap between snap ring and groove) of 6th bushing satisfies standard.

End play standard value : 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, select snap ring.




Snap Rings

Thickness	Part number	Thickness	Part number
1.76 mm (0.0693 in)	32204 8H511	2.01 mm (0.0791 in)	32204 8H516
1.81 mm (0.0713 in)	32204 8H512	2.06 mm (0.0811 in)	32204 8H517
1.86 mm (0.0732 in)	32204 8H513	2.11 mm (0.0831 in)	32204 8H518
1.91 mm (0.0752 in)	32204 8H514	2.16 mm (0.0850 in)	32204 8H519
1.96 mm (0.0772 in)	32204 8H515	2.21 mm (0.0870 in)	32204 8H520

16. Install input shaft rear bearing.


CAUTION:

Install input shaft rear bearing with its brown surface facing the 6th input gear side.



17. Install input shaft front bearing.

18. Install oil channel onto input shaft.



19. Check end play of 3rd, 4th, 5th and 6th input gears.


End play standard value

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



MAINSHAFT AND GEARS

MAINSHAFT AND GEARS

PFP:32241


Assembly and Disassembly (RS5F51A) DISASSEMBLY

ECS008C6


1. Before disassembling, measure end play of 1st and 2nd main gears.

End play standard value


- 1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)
2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)




2. Remove the snap ring.
3. Remove C-ring holder, and then mainshaft C-ring.



4. Remove mainshaft rear bearing.




5. Remove the snap ring.




MAINSHAFT AND GEARS

6. Remove 4th main gear and 5th main gear simultaneously.
7. Remove adjusting shim.
8. Remove 3rd-4th mainshaft spacer.



9. Remove 3rd main gear, 2nd main gear, 2nd gear needle bearing, 2nd bushing, 1st-2nd synchronizer hub assembly, 1st main gear, reverse main gear, 1st gear needle bearing, and 1st bushing simultaneously.




INSPECTION AFTER DISASSEMBLY

Mainshaft and Gears

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.




MAINSHAFT AND GEARS


Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk ring clearance

- Double cone synchronizer (1st and 2nd)
Check clearance of outer baulk ring, synchronizer cone, and inner baulk ring of 1st and 2nd double cone synchronizers, following procedure below.

CAUTION:

Outer baulk ring, synchronizer cone, and inner baulk ring as a set control clearance A and B. If measurement exceeds service limit value, replace all of them as a set.




1. Using a dial gauge, measure clearance A at 2 or more points diagonally opposite, and calculate mean value.

Clearance A

Standard : 0.6 - 0.8 mm (0.024 - 0.031 in)

Limit value : 0.2 mm (0.008 in) or less




MAINSHAFT AND GEARS

- Using a feeler gauge, measure clearance B at 2 or more points diagonally opposite, and calculate mean value.

Clearance B

Standard : 0.6 - 1.1 mm (0.024 - 0.043 in)


Limit value : 0.2 mm (0.008 in) or less



Bearing


Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing




ASSEMBLY

- Install reverse main gear.




CAUTION:

Be careful with orientation of reverse main gear.



MAINSHAFT AND GEARS


2. Install 1st bushing.
3. Install needle bearing, and then 1st main gear.




4. Install spread spring, shifting insert and 1st-2nd synchronizer hub onto 1st-2nd coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub.
- Do not reuse 1st-2nd synchronizer hub.



- Be careful with orientation of coupling sleeve.



- Be sure not to hook center projection of 2 spread springs on same shifting insert.




MAINSHAFT AND GEARS


5. Install 1st gear synchronizer assembly onto mainshaft, and synchronizer hub assembly onto mainshaft.

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side must have been removed.
- Be careful with orientation of coupling sleeve.



6. Install 2nd bushing.
7. Install outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side.
8. Install 2nd needle bearing and 2nd gear.




9. Install 3rd main gear.

CAUTION:

Be careful with orientation of 3rd main gear.


10. Install 3rd-4th mainshaft spacer.



11. Select suitable adjusting shim so that dimension "C1" satisfies standard value below, and install it onto mainshaft.

Standard for dimension C1

: 173.85 - 173.95 mm (6.844 - 6.848 in)



MAINSHAFT AND GEARS

Adjusting Shim

Thickness	Part number	Thickness	Part number
0.52 mm (0.0205 in)	32238 8H500	0.84 mm (0.0331 in)	32238 8H504
0.60 mm (0.0236 in)	32238 8H501	0.92 mm (0.0362 in)	32238 8H505
0.68 mm (0.0268 in)	32238 8H502	1.00 mm (0.0394 in)	32238 8H506
0.76 mm (0.0299 in)	32238 8H503	1.08 mm (0.0425 in)	32238 8H507


CAUTION:

Only one adjusting shim can be selected.

- Install 4th main gear.

CAUTION:


Be careful with orientation of 4th main gear.



- Install 5th main gear.

CAUTION:


Be careful with orientation of 5th main gear.



- Install snap ring onto mainshaft, and check that end play of 5th main gear satisfies standard value.

End play standard value : 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, reselect snap ring.




Snap Rings

Thickness	Part number	Thickness	Part number
1.85 mm (0.0728 in)	32204 8H500	2.05 mm (0.0807 in)	32204 8H504
1.90 mm (0.0748 in)	32204 8H501	2.10 mm (0.0827 in)	32204 8H505
1.95 mm (0.0768 in)	32204 8H502	2.15 mm (0.0846 in)	32204 8H506
2.00 mm (0.0787 in)	32204 8H503	2.20 mm (0.0866 in)	32204 8H507

MAINSHAFT AND GEARS


15. Install mainshaft rear bearing.



16. Install C-ring onto mainshaft, and check that end play of mainshaft rear bearing satisfies standard value.

End play standard value : 0 - 0.06 mm (0 - 0.0024 in)

- If measurement is outside the standard range, reselect C-ring.



C-ring

Thickness	Part number	Thickness	Part number
2.535 mm (0.0866 in)	32348 8H800	2.835 mm (0.1116 in)	32348 8H810
2.565 mm (0.1010 in)	32348 8H801	2.865 mm (0.1128 in)	32348 8H811
2.595 mm (0.1022 in)	32348 8H802	2.895 mm (0.1140 in)	32348 8H812
2.625 mm (0.1033 in)	32348 8H803	2.925 mm (0.1152 in)	32348 8H813
2.655 mm (0.1045 in)	32348 8H804	2.955 mm (0.1163 in)	32348 8H814
2.685 mm (0.1057 in)	32348 8H805	2.985 mm (0.1175 in)	32348 8H815
2.715 mm (0.1069 in)	32348 8H806	3.015 mm (0.1187 in)	32348 8H816
2.745 mm (0.1081 in)	32348 8H807	3.045 mm (0.1199 in)	32348 8H817
2.775 mm (0.1093 in)	32348 8H808	3.075 mm (0.1211 in)	32348 8H818
2.805 mm (0.1104 in)	32348 8H809		


17. Fit C-ring holder, and install snap ring.

18. Check end play of 1st and 2nd main gears.

End play standard value

1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



MAINSHAFT AND GEARS

Assembly and Disassembly (RS6F51A)


EC5008C7

DISASSEMBLY


1. Before disassembling, measure end play of 1st and 2nd main gears.

End play standard value


- | | |
|----------|---------------------------------------|
| 1st gear | : 0.20 - 0.30 mm (0.0079 - 0.0118 in) |
| 2nd gear | : 0.06 - 0.16 mm (0.0024 - 0.0063 in) |




2. Remove the snap ring.
3. Remove C-ring holder, and then mainshaft C-ring.



4. Remove mainshaft rear bearing, adjust shim and 6th main gear.
5. Remove 5th-6th mainshaft spacer.




6. Remove 4th main gear and 5th main gear simultaneously.
7. Remove adjusting shim.
8. Remove 3rd & 4th mainshaft spacer.



MAINSHAFT AND GEARS

9. Remove 3rd main gear, 2nd main gear, 2nd gear needle bearing, 2nd bushing, 1st-2nd synchronizer hub assembly, 1st main gear, reverse main gear, 1st gear needle bearing, and 1st bushing simultaneously.



A

B

MT


D

INSPECTION AFTER DISASSEMBLY

Mainshaft and Gears

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.



E

F


G

H

Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly.




I

J

K

L

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



M


MAINSHAFT AND GEARS

Baulk ring clearance

- Double cone synchronizer (1st and 2nd)
Check clearance of outer baulk ring, synchronizer cone, and inner baulk ring of 1st and 2nd double cone synchronizers, following procedure below.

CAUTION:

Outer baulk ring, synchronizer cone, and inner baulk ring as a set control clearance A and B. If measurement exceeds service limit value, replace all of them as a set.




- Using a dial gauge, measure clearance A at 2 or more points diagonally opposite, and calculate mean value.

Clearance A

Standard : 0.6 - 0.8 mm (0.024 - 0.031 in)

Limit value : 0.2 mm (0.008 in) or less




- Using a feeler gauge, measure clearance B at 2 or more points diagonally opposite, and calculate mean value.

Clearance B

Standard : 0.6 - 1.1 mm (0.024 - 0.043 in)


Limit value : 0.2 mm (0.008 in) or less



Bearing

Check items below. If necessary, replace them with new ones.


- Damage and rough rotation of bearing



MAINSHAFT AND GEARS


ASSEMBLY

1. Install reverse main gear.




CAUTION:

Be careful with orientation of reverse main gear.




2. Install 1st bushing.
3. Install needle bearing, and then 1st main gear.



4. Install spread spring, shifting insert and 1st-2nd synchronizer hub onto 1st-2nd coupling sleeve.


CAUTION:

- Be careful with orientation of synchronizer hub.
- Do not reuse 1st-2nd synchronizer hub.




MAINSHAFT AND GEARS

- Be careful with orientation of coupling sleeve.




- Be sure not to hook center projection of 2 spread springs on same shifting insert.




5. Install 1st gear synchronizer assembly onto mainshaft, and synchronizer hub assembly onto mainshaft.

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side must have been removed.
- Be careful with orientation of coupling sleeve.



6. Install 2nd bushing.
7. Install outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side.
8. Install 2nd needle bearing and 2nd gear.




9. Install 3rd main gear.

CAUTION:

Be careful with orientation of 3rd main gear.

10. Install 3rd-4th mainshaft spacer.




MAINSHAFT AND GEARS

- Select suitable adjusting shim so that dimension "C1" satisfies standard value below, and install it onto mainshaft.

Standard for dimension C1

: 173.85 - 173.95 mm (6.844 - 6.848 in)



Adjusting Shim

Thickness	Part number	Thickness	Part number
0.52 mm (0.0205 in)	32238 8H500	0.84 mm (0.0331 in)	32238 8H504
0.60 mm (0.0236 in)	32238 8H501	0.92 mm (0.0362 in)	32238 8H505
0.68 mm (0.0268 in)	32238 8H502	1.00 mm (0.0394 in)	32238 8H506
0.76 mm (0.0299 in)	32238 8H503	1.08 mm (0.0425 in)	32238 8H507


CAUTION:

Only one adjusting shim can be selected.

- Install 4th main gear.

CAUTION:

Be careful with orientation of 4th main gear.




- Install 5th main gear.

CAUTION:


Be careful with orientation of 5th main gear.

- Install 5th-6th mainshaft spacer.



MAINSHAFT AND GEARS

15. Install 6th main gear.



16. Select 6th main adjusting shim and then install it onto mainshaft.

- Calculate thickness “S” of 6th main adjusting shim by procedure below so that end play dimension between 6th main gear and mainshaft rear bearing becomes the dimension shown below.


End play: 0 - 0.1 mm (0 - 0.004 in)

Dimension “S” = (S₁ - S₂) + End play

S: Thickness of adjusting shim

S₁ : Dimension from mainshaft standard face to mainshaft rear bearing press-fit end face

S₂ : Dimension from mainshaft standard face to 6th main gear end face



Adjusting Shim


Thickness	Part number	Thickness	Part number
0.88 mm (0.0346 in)	32237 8H560	1.20 mm (0.0472 in)	32237 8H564
0.96 mm (0.0378 in)	32237 8H561	1.28 mm (0.0504 in)	32237 8H565
1.04 mm (0.0409 in)	32237 8H562	1.36 mm (0.0535 in)	32237 8H566
1.12 mm (0.0441 in)	32237 8H563		

CAUTION:

Only one adjusting shim can be selected.

- Using height gauge, measure dimension “S₁” and “S₂”.
- Install selected 6th main adjusting shim to mainshaft.

17. Install mainshaft rear bearing.




MAINSHAFT AND GEARS

18. Install C-ring onto mainshaft, and check that end play of mainshaft rear bearing satisfies standard value.

End play standard value : 0 - 0.06 mm (0 - 0.0024 in)


- If measurement is outside the standard range, reselect C-ring.



C-ring

Thickness	Part number	Thickness	Part number
2.535 mm (0.0998 in)	32348 8H800	2.835 mm (0.1116 in)	32348 8H810
2.565 mm (0.1010 in)	32348 8H801	2.865 mm (0.1128 in)	32348 8H811
2.595 mm (0.1022 in)	32348 8H802	2.895 mm (0.1140 in)	32348 8H812
2.625 mm (0.1033 in)	32348 8H803	2.925 mm (0.1152 in)	32348 8H813
2.655 mm (0.1045 in)	32348 8H804	2.955 mm (0.1163 in)	32348 8H814
2.685 mm (0.1057 in)	32348 8H805	2.985 mm (0.1175 in)	32348 8H815
2.715 mm (0.1069 in)	32348 8H806	3.015 mm (0.1187 in)	32348 8H816
2.745 mm (0.1081 in)	32348 8H807	3.045 mm (0.1199 in)	32348 8H817
2.775 mm (0.1093 in)	32348 8H808	3.075 mm (0.1211 in)	32348 8H818
2.805 mm (0.1104 in)	32348 8H809		

19. Fit C-ring holder, and install snap ring.




20. Check end play of 1st and 2nd main gears.

End play standard value

1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



REVERSE IDLER SHAFT AND GEARS

REVERSE IDLER SHAFT AND GEARS

PFP:32281

Assembly and Disassembly (RS5F51A) DISASSEMBLY

ECS008C8


1. Remove reverse idler gear adjusting shim.
2. Remove reverse idler gear (rear), reverse coupling sleeve and insert spring simultaneously.
3. Remove reverse idler gear needle bearing.
4. Remove thrust needle bearing.
5. Remove reverse baulk ring.
6. Remove reverse idler gear (front).
7. Remove reverse idler gear needle bearing.
8. Remove thrust needle bearing.
9. Pull off locking pin from reverse idler shaft.

INSPECTION AFTER DISASSEMBLY

Reverse Idler Shaft and Gears

Check items below. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.




Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and insert spring.
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




REVERSE IDLER SHAFT AND GEARS

Baulk ring clearance

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard : 0.95 - 1.4 mm (0.0374 - 0.0551 in)
Limit value : 0.7 mm (0.0276 in)



Bearing

Check items below. If necessary, replace them with new ones.


- Damage and rough rotation of bearing.

ASSEMBLY

Paying attention to following work, assemble in reverse order of disassembly.

CAUTION:

- Be careful with orientation of insert spring.



Assembly and Disassembly (RS6F51A)

DISASSEMBLY


1. Remove reverse idler gear adjusting shim.
2. Remove reverse idler gear (rear), reverse coupling sleeve and insert spring simultaneously.
3. Remove reverse idler gear needle bearing.
4. Remove thrust needle bearing.
5. Remove reverse baulk ring.
6. Remove reverse idler gear (front).
7. Remove reverse idler gear needle bearing.
8. Remove thrust needle bearing.
9. Pull off locking pin from reverse idler shaft.

INSPECTION AFTER DISASSEMBLY

Reverse Idler Shaft and Gears

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.




REVERSE IDLER SHAFT AND GEARS


Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and insert spring.
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk ring clearance

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard : 0.95 - 1.4 mm (0.0374 - 0.0551 in)

Limit value : 0.7 mm (0.0276 in)



Bearing

Check items below. If necessary, replace them with new ones.


- Damage and rough rotation of bearing.

ASSEMBLY

Paying attention to following work, assemble in reverse order of disassembly.

CAUTION:

- Be careful with orientation of insert spring.



FINAL DRIVE

FINAL DRIVE


PFP:38411

Assembly and Disassembly (RS5F51A)

ECS008CA

PRE-INSPECTION

- Check the clearance between side gear and differential case as follows.
1. Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.




2. Upright the differential case so that the side gear to be measured faces upward.
3. Place final drive adapter and dial indicator onto side gear. Move side gear up and down, and measure the clearance.

Clearance between side gear and differential case
: 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:


There should be no resistance and gears should rotate freely.

4. If not within specification, adjust the clearance by changing thrust washer thickness.
5. Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way.




DISASSEMBLY

1. Remove mounting bolts. Then, separate the final gear from differential case.
2. Using a drift and puller, remove differential side bearing (clutch housing side).




3. Using a drift and puller, remove differential side bearing (transaxle case side).



FINAL DRIVE


4. Using a pin punch, pull out lock pin and pinion mate shaft.
5. Rotate pinion mate gears, and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from differential case.



INSPECTION AFTER DISASSEMBLY

Gear, Washer, Shaft and Case

- Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case. If necessary, replace with a new one.




Bearing

- Check for bearing damage and rough rotation. If necessary, replace with a new one.


CAUTION:

When replacing tapered roller bearing, replace outer and inner races as a set.



ASSEMBLY

1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.
2. Install side gear thrust washers and side gears into differential case.
3. While rotating pinion mate thrust washers and pinion mate gears, aligning them diagonally, install them into differential case.




FINAL DRIVE

4. Insert pinion mate shaft into differential case.


CAUTION:

Be sure not to damage pinion mate thrust washers.



5. Measure end play of side gears following procedure below. Then select side gear thrust washer.

- a. Upright the differential case so that its side gear to be measured face upward.
- b. Place final drive adapter and dial indicator onto side gears.




- c. Move side gears up and down to measure end play, and select thrust washer so that it satisfies standard.

End play standard value

: 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

- There should be no resistance and gears should rotate freely.
- Place differential case upside down. Be sure to measure end play for opposite side-gears likewise.



Thrust washer

Thickness	Part number
0.75 mm (0.0295 in)	38424 81X00
0.80 mm (0.0315 in)	38424 81X01
0.85 mm (0.0335 in)	38424 81X02
0.90 mm (0.0354 in)	38424 81X03
0.95 mm (0.0374 in)	38424 81X04


CAUTION:

Only one thrust washer can be selected.

6. Using a pin punch, drive a lock pin into the pinion mate shaft.


CAUTION:

Do not reuse the lock pin.




FINAL DRIVE


- Using a drift (special service tool), install differential side bearing (transaxle case side).



- Using a drift (special service tool), install differential side bearing (clutch housing side).




- Install final gear into differential case, and tighten final gear mounting bolts.



Assembly and Disassembly (RS6F51A) PRE-INSPECTION

ECS008CB

- Check the clearance between side gear and differential case as follows.
- Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.



- Upright the differential case so that the side gear to be measured faces upward.

FINAL DRIVE


- Place final drive adapter and dial indicator onto side gear. Move side gear up and down, and measure the clearance.

Clearance between side gear and differential case
: 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

There should be no resistance and gears should rotate freely.

- If not within specification, adjust the clearance by changing thrust washer thickness.
- Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way.



A

B


MT

D

E

DISASSEMBLY

- Remove mounting bolts. Then, separate the final gear from differential case.
- Using a drift and puller, remove differential side bearing (clutch housing side).




F

G

H

- Using a drift and puller, remove differential side bearing (transaxle case side).




I

J

K

L

- Using a pin punch, pull out lock pin and pinion mate shaft.
- Rotate pinion mate gears, and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from differential case.




M

FINAL DRIVE

INSPECTION AFTER DISASSEMBLY

Gear, Washer, Shaft and Case

- Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case. If necessary, replace with a new one.




Bearing

- Check for bearing damage and rough rotation. If necessary, replace with a new one.


CAUTION:

When replacing tapered roller bearing, replace outer and inner races as a set.



ASSEMBLY


1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.
2. Install side gear thrust washers and side gears into differential case.
3. While rotating pinion mate thrust washers and pinion mate gears, aligning them diagonally, install them into differential case.



4. Insert pinion mate shaft into differential case.


CAUTION:

Be sure not to damage pinion mate thrust washers.



FINAL DRIVE

5. Measure end play of side gears following procedure below. Then select side gear thrust washer.
 - a. Upright the differential case so that its side gear to be measured faces upward.
 - b. Place final drive adapter and dial indicator onto side gears.




- c. Move side gears up and down to measure end play, and select thrust washer so that it satisfies standard.

End play standard value

: 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

- There should be no resistance and gears should rotate freely.
- Place differential case upside down. Be sure to measure end play for opposite side-gears likewise.



Thrust washer

Thickness	Part number
0.75 mm (0.0295 in)	38424 81X00
0.80 mm (0.0315 in)	38424 81X01
0.85 mm (0.0335 in)	38424 81X02
0.90 mm (0.0354 in)	38424 81X03
0.95 mm (0.0374 in)	38424 81X04


CAUTION:

Only one thrust washer can be selected.


6. Using a pin punch, drive a lock pin into the pinion mate shaft.

CAUTION:

Do not reuse the lock pin.




7. Using a drift (special service tool), install differential side bearing (transaxle case side).




FINAL DRIVE

8. Using a drift (special service tool), install differential side bearing (clutch housing side).



9. Install final gear into differential case, and tighten final gear mounting bolts.



SHIFT CONTROL


SHIFT CONTROL

PFP:32982

Inspection (RS5F51A)

ECS008CC


- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.



SHIFT FORK

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below.

Item	One-side wear specification	Sliding width of new part
1st & 2nd	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
3rd & 4th	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
5th	0.2 mm (0.008 in)	6.10 - 6.23 mm (0.2402 - 0.2453 in)
Reverse	0.2 mm (0.008 in)	12.80 - 12.93 mm (0.5039 - 0.5091 in)




SHIFT CONTROL

Inspection (RS6F51A)

ECS008CD


- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.



SHIFT FORK

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below.

Item	One-side wear specification	Sliding width of new part
1st & 2nd	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
3rd & 4th	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
5th & 6th	0.2 mm (0.008 in)	6.10 - 6.23 mm (0.2402 - 0.2453 in)
Reverse	0.2 mm (0.008 in)	12.80 - 12.93 mm (0.5039 - 0.5091 in)





SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PPF:00030

General Specifications TRANSAXLE

ECS008CE

Engine			QR20DE	QR25DE	YD22DDTi	
Transaxle model			RS5F51A		RS6F51A	
Model code number			8H500	9H608	8H868	
Number of speed			5		6	
Synchromesh type			Warner			
Shift pattern			5 speed			 SCIA0821E
			6 speed			 SCIA0955E
Gear ratio	1st		3.500	3.416	3.500	
	2nd		1.944			
	3rd		1.258			
	4th		0.947			
	5th		0.772	0.733	0.772	
	6th		—		0.630	
	Reverse		3.374	3.252	3.374	
Number of teeth	Input gear	1st	14	12	14	
		2nd	18			
		3rd	31			
		4th	38			
		5th	44	45	44	
		6th	—		46	
		Reverse	14	12	14	
	Main gear	1st	49	41	49	
		2nd	35			
		3rd	39			
		4th	36			
		5th	34	33	34	
		6th	—		29	
		Reverse	38			
	Reverse idler gear	Front	37			
		Rear	46	38	46	
Oil capacity ℓ (Imp pt)			2.3 (4)			

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine	QR20DE	QR25DE	YD22DDTi
Transaxle model	RS5F51A		RS6F51A
Model code number	8H500	9H608	8H868
Remarks	Reverse synchronizer	Installed	
	Double baulk ring type synchronizer	1st & 2nd synchronizer	

FINAL GEAR

Engine	QR20DE	QR25DE	YD22DDTi
Transaxle model	RS5F51A		RS6F51A
Model code number	8H500	9H608	8H868
Final gear ratio	4.750	4.428	
Number of teeth	Final gear/Pinion	76/16	62/14
	Side gear/Pinion mate gear	14/10	

Gear End Play

ECS008CF

Unit: mm (in)

Gear	End play
1st main gear	0.20 - 0.30 (0.0079 - 0.0118)
2nd main gear	0.06 - 0.16 (0.0024 - 0.0063)
3rd input gear	0.18 - 0.31 (0.0071 - 0.0122)
4th input gear	0.20 - 0.30 (0.0079 - 0.0118)
5th input gear	0.06 - 0.16 (0.0024 - 0.0063)
6th input gear (For RS6F51A model)	0.06 - 0.16 (0.0024 - 0.0063)

Clearance Between Baulk Ring and Gear 3RD, 4TH, 5TH, 6TH & REVERSE BAULK RING

ECS008CG


— 6th for RS6F51A Models —

Unit: mm (in)

Standard	Wear limit
3rd	0.9 - 1.45 (0.0354 - 0.0571)
4th	0.9 - 1.45 (0.0354 - 0.0571)
5th	0.95 - 1.4 (0.0374 - 0.0551)
6th (For RS6F51A model)	0.95 - 1.4 (0.0374 - 0.0551)
Reverse	0.95 - 1.4 (0.0374 - 0.0551)

1ST AND 2ND DOUBLE BAULK RING

Unit: mm (in)



SCIA0950E

Dimension	Standard	Wear limit
A	0.6 - 0.8 (0.024 - 0.031)	0.2 (0.008)
B	0.6 - 1.1 (0.024 - 0.043)	0.2 (0.008)

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Snap Rings INPUT SHAFT SPACER

ECS008CH

—For RS5F51A Models—

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.71 (0.0673)	32204 8H510	2.01 (0.0791)	32204 8H516
1.76 (0.0693)	32204 8H511	2.06 (0.0811)	32204 8H517
1.81 (0.0713)	32204 8H512	2.11 (0.0831)	32204 8H518
1.86 (0.0732)	32204 8H513	2.16 (0.0850)	32204 8H519
1.91 (0.0752)	32204 8H514	2.21 (0.0870)	32204 8H520
1.96 (0.0772)	32204 8H515	2.26 (0.0890)	32204 8H521

*: Always check with the Parts Department for the latest parts information.

6TH BUSHING

—For RS6F51A Models—

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32204 8H511	2.01 (0.0791)	32204 8H516
1.81 (0.0713)	32204 8H512	2.06 (0.0811)	32204 8H517
1.86 (0.0732)	32204 8H513	2.11 (0.0831)	32204 8H518
1.91 (0.0752)	32204 8H514	2.16 (0.0850)	32204 8H519
1.96 (0.0772)	32204 8H515	2.21 (0.0870)	32204 8H520

*: Always check with the Parts Department for the latest parts information.

5TH MAIN GEAR

—For RS5F51A Models—

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.85 (0.0728)	32204 8H500	2.05 (0.0807)	32204 8H504
1.90 (0.0748)	32204 8H501	2.10 (0.0827)	32204 8H505
1.95 (0.0768)	32204 8H502	2.15 (0.0846)	32204 8H506
2.00 (0.0787)	32204 8H503	2.20 (0.0866)	32204 8H507

*: Always check with the Parts Department for the latest parts information.

Available C-Rings MAINSHAFT C-RING

ECS008CI


End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
2.535 (0.0998)	32348 8H800	2.835 (0.1116)	32348 8H810
2.565 (0.1010)	32348 8H801	2.865 (0.1128)	32348 8H811
2.595 (0.1022)	32348 8H802	2.895 (0.1140)	32348 8H812
2.625 (0.1033)	32348 8H803	2.925 (0.1152)	32348 8H813
2.655 (0.1045)	32348 8H804	2.955 (0.1163)	32348 8H814
2.685 (0.1057)	32348 8H805	2.985 (0.1175)	32348 8H815
2.715 (0.1069)	32348 8H806	3.015 (0.1187)	32348 8H816
2.745 (0.1081)	32348 8H807	3.045 (0.1199)	32348 8H817
2.775 (0.1093)	32348 8H808	3.075 (0.1211)	32348 8H818
2.805 (0.1104)	32348 8H809		

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Thrust Washer INPUT SHAFT THRUST WASHER

ECS008CJ



SCIA1008E

Standard length "C2"		154.7 - 154.8 mm (6.091 - 6.094 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
3.84 (0.1512)	32347 8H500	4.02 (0.1583)	32347 8H503
3.90 (0.1535)	32347 8H501	4.08 (0.1606)	32347 8H504
3.96 (0.1559)	32347 8H502	4.14 (0.1630)	32347 8H505

*: Always check with the Parts Department for the latest parts information.


DIFFERENTIAL SIDE GEAR THRUST WASHER

Allowable clearance between side gear and differential case with washer		0.1 - 0.2 mm (0.004 - 0.008 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.75 (0.0295)	38424 81X00	0.84 (0.0331)	32238 8H504
0.80 (0.0315)	38424 81X01	0.92 (0.0362)	32238 8H505
0.85 (0.0335)	38424 81X02	1.00 (0.0394)	32238 8H506
0.90 (0.0354)	38424 81X03	1.08 (0.0425)	32238 8H507
0.95 (0.0374)	38424 81X04		

*: Always check with the Parts Department for the latest parts information.

Available Adjusting Shims MAINSHAFT ADJUSTING SHIM

ECS008CK



SCIA1009E

Standard length "C1"		173.85 - 173.95 mm (6.844 - 6.848 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.52 (0.0205)	32238 8H500	0.84 (0.0331)	32238 8H504
0.60 (0.0236)	32238 8H501	0.92 (0.0362)	32238 8H505
0.68 (0.0268)	32238 8H502	1.00 (0.0394)	32238 8H506
0.76 (0.0299)	32238 8H503	1.08 (0.0425)	32238 8H507

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

INPUT SHAFT REAR BEARING ADJUSTING SHIM

End play			0 - 0.06 mm (0 - 0.0024 in)		
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.40 (0.0157)	32225 8H500	0.88 (0.0346)	32225 8H512	1.36 (0.0535)	32225 8H524
0.44 (0.0173)	32225 8H501	0.92 (0.0362)	32225 8H513	1.40 (0.0551)	32225 8H560
0.48 (0.0189)	32225 8H502	0.96 (0.0378)	32225 8H514	1.44 (0.0567)	32225 8H561
0.52 (0.0205)	32225 8H503	1.00 (0.0394)	32225 8H515	1.48 (0.0583)	32225 8H562
0.56 (0.0220)	32225 8H504	1.04 (0.0409)	32225 8H516	1.52 (0.0598)	32225 8H563
0.60 (0.0236)	32225 8H505	1.08 (0.0425)	32225 8H517	1.56 (0.0614)	32225 8H564
0.64 (0.0252)	32225 8H506	1.12 (0.0441)	32225 8H518	1.60 (0.0630)	32225 8H565
0.68 (0.0268)	32225 8H507	1.16 (0.0457)	32225 8H519	1.64 (0.0646)	32225 8H566
0.72 (0.0283)	32225 8H508	1.20 (0.0472)	32225 8H520	1.68 (0.0661)	32225 8H567**
0.76 (0.0299)	32225 8H509	1.24 (0.0488)	32225 8H521	1.72 (0.0677)	32225 8H568**
0.80 (0.0315)	32225 8H510	1.28 (0.0504)	32225 8H522		
0.84 (0.0331)	32225 8H511	1.32 (0.0520)	32225 8H523		

*: Always check with the Parts Department for the latest parts information.

** : RS5F51A model only.

MAINSHAFT REAR BEARING ADJUSTING SHIM

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.44 (0.0173)	32238 8H510	0.80 (0.0315)	32238 8H519
0.48 (0.0189)	32238 8H511	0.84 (0.0331)	32238 8H520
0.52 (0.0205)	32238 8H512	0.88 (0.0346)	32238 8H521
0.56 (0.0220)	32238 8H513	0.92 (0.0362)	32238 8H522
0.60 (0.0236)	32238 8H514	0.96 (0.0378)	32238 8H523
0.64 (0.0252)	32238 8H515	1.00 (0.0394)	32238 8H524
0.68 (0.0268)	32238 8H516	1.04 (0.0409)	32238 8H560
0.72 (0.0283)	32238 8H517	1.08 (0.0425)	32238 8H561
0.76 (0.0299)	32238 8H518		

*: Always check with the Parts Department for the latest parts information.

REVERSE IDLER GEAR ADJUSTING SHIM

End play		0.04 - 0.10 mm (0.0016 - 0.0039 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H812
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H813
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H814
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H815
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H816
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H817
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H818
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H819
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H820
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H821
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H822
2.20 (0.0866)	32237 8H811		

*: Always check with the Parts Department for the latest parts information.

6TH MAIN GEAR ADJUSTING SHIM

—For RS6F51A Models—

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.88 (0.0346)	32237 8H560	1.20 (0.0472)	32237 8H564
0.96 (0.0378)	32237 8H561	1.28 (0.0504)	32237 8H565
1.04 (0.0409)	32237 8H562	1.36 (0.0535)	32237 8H566
1.12 (0.0441)	32237 8H563		

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Shims

ECS008CL

— Differential Side Bearing Preload and Adjusting Shim

BEARING PRELOAD

Differential side bearing preload: L*	0.15 - 0.21 mm (0.0059 - 0.0083 in)
---------------------------------------	-------------------------------------

*: Install shims which are “deflection of differential case” + “L” in thickness.

DIFFERENTIAL SIDE BEARING ADJUSTING SHIM(S)

Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.48 (0.0189)	31438 80X00	0.72 (0.0283)	31438 80X06
0.52 (0.0205)	31438 80X01	0.76 (0.0299)	31438 80X07
0.56 (0.0220)	31438 80X02	0.80 (0.0315)	31438 80X08
0.60 (0.0236)	31438 80X03	0.84 (0.0331)	31438 80X09
0.64 (0.0252)	31438 80X04	0.88 (0.0346)	31438 80X10
0.68 (0.0268)	31438 80X05	0.92 (0.0362)	31438 80X11

*: Always check with the Parts Department for the latest parts information.