



SMART6[™] User Manual

OM-20000150

Rev 0B

September 2013



SMART6 User Manual

Revision Level: 0B
Publication Number: OM-20000150
Revision Date: September 2013
Firmware Version: 6.220 (OEM060220RN0000)

Warranty

NovAtel® Inc. warrants that its GNSS products are free from defects in materials and workmanship, subject to the conditions set forth on our web site: www.novatel.com/products/warranty/.

Antenna Module	One (1) Year
Cables and Accessories	Ninety (90) Days
Software Warranty	One (1) Year

Return Instructions

To return products, refer to the instructions found under the Return Policy tab on the Warranty page: www.novatel.com/products/warranty/.

Proprietary Notice

Information in this document is subject to change without notice and does not represent a commitment on the part of NovAtel Inc. The software described in this document is furnished under a licence agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software on any medium except as specifically allowed in the license or non-disclosure agreement.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of a duly authorized representative of NovAtel Inc.

The information contained within this manual is believed to be true and correct at the time of publication.

AdVance, NovAtel, GLIDE, NovAtel Connect and OEM6 are registered trademarks of NovAtel Inc.

SMART6 is a trademark of NovAtel Inc.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by NovAtel Inc. is under license. All other brand names are trademarks of their respective holders.

Manufactured and protected under U.S. Patent:

#5,390,207	#6,184,822 B1	#6,664,923 B1
#5,495,499	#6,211,821 B1	#6,922,167 B2
#5,734,674	#6,445,354 B1	#7,250,916
#5,809,064	#6,608,998 B1	#7,738,536 B2
#5,414,729	#6,452,560 B2	#7,738,606 B2
#5,736,961	#6,728,637 B2	#7,885,317 B2
#6,243,409 B1		

© Copyright 2013 NovAtel Inc. All rights reserved. Unpublished rights reserved under International copyright laws.



Table of Contents

Notice	7
Customer Service	9
1 Introduction	11
1.1 Features and Models	11
2 Installation and Setup	13
2.1 Additional Equipment Required	13
2.1.1 SMART6 Setup	13
2.1.2 Power Supply Requirements	15
2.1.3 Mounting Plate	15
2.1.4 Mounting the SMART6	17
2.1.5 Connecting Data Communications Equipment	17
2.2 Additional Features and Information	18
2.2.1 Status Indicators	18
2.2.2 MKI and PPS Strobes	18
2.2.3 Emulated Radar (ER)	19
2.2.4 Controller Area Network (CAN)	19
2.2.5 Tilt Compensation	19
3 Operation	22
3.1 Communications with the Receiver	22
3.1.1 Serial Port Default Settings	22
3.1.2 Communicating Using a Remote Terminal	22
3.1.3 Communicating Using a Computer	22
3.2 Getting Started	23
3.2.1 Starting the Receiver	23
3.2.2 Communicating with the Receiver Using NovAtel Connect	23
3.3 Transmitting and Receiving Corrections	24
3.3.1 Base Station Configuration	26
3.3.2 Rover Station Configuration	27
3.3.3 GPS + GLONASS Base and Rover Configuration	27
3.3.4 Configuration Notes	28
3.4 GLIDE	29
3.4.1 Dual-Frequency GLIDE	29
3.5 Emulated Radar (ER)	29
3.6 Tilt Compensation	30
3.7 Recommended Configuration	31
4 NovAtel Firmware and Software	32
4.1 Firmware Updates and Model Upgrades	32
4.1.1 Firmware Updates	32
4.1.2 Model Upgrades	33
4.2 Authorization Code	33
4.3 Updating or Upgrading Using the WinLoad Utility	34
4.3.1 Transferring Firmware Files	34
4.3.2 Using the WinLoad Utility	35
4.4 Updating using SoftLoad Commands	36
4.4.1 Working with S-Records	37
4.5 Upgrading Using the AUTH Command	38
4.5.1 Upgrade Procedure	38
5 Bluetooth Configuration	39
5.1 Bluetooth Wireless Technology on the SMART6 receiver	39
5.2 Pairing with a new SMART6	39
5.3 Determining the Bluetooth Serial Port	42
5.4 Communicate with the SMART6 Using Bluetooth Wireless Technology	45

A Technical Specifications	46
A.1 SMART6 Receiver Performance	46
A.2 SMART6 Specifications.....	47
A.2.1 SMART6 Communication/Power Cable (01018999).....	49
A.2.2 SMART6 Connector and Cable Requirements	50
B Commands	52
B.1 Syntax Conventions	52
B.2 BTCONTROL Enable/Disable Bluetooth wireless technology.....	53
B.3 COM Configure COM Port.....	54
B.4 FRESET Clear Selected Data from NVM and Reset.....	56
B.5 LOG Request Logs from the Receiver.....	58
B.6 \$PMDT Configure Tilt Compensation	61
B.7 RADARCFG Configure the ER Output	62
B.8 SETCANNAME Sets the CAN name fields.....	63
C Logs	64
C.1 Position Logs	64
C.1.1 NMEA Logs.....	64
C.1.2 NovAtel Position Logs.....	65
C.2 Other Logs	65
C.2.1 RADARSIGNAL ER Signal and Position Information.....	66
C.2.2 TILT Compensation.....	68
C.2.3 VERSION HW and SW Versions and Serial Numbers.....	68
D Replacement Parts	69
D.1 SMART6	69
D.2 User Manuals	69
Index	70

Figures

1	SMART6 Receiver	11
2	SMART6 Connector	13
3	Simplified SMART6 Setup	14
4	SMART6 Surface Mounting Plate	15
3	SMART6 Pole Mounting Plate	16
5	SMART6 Orientation	17
6	SMART6 Installation	20
7	SMART6 Orientation	20
8	Open Connection Window	23
9	Basic Differential Setup	25
10	SMART6 Tilt Compensation	30
11	WinLoad's Open Window	35
12	Open File in WinLoad	35
13	COM Port Setup	35
14	Searching for Card	36
15	Authorization Code Window	36
16	Upgrade Process Complete	36
3	Bluetooth Icon	39
4	Bluetooth Devices Window	40
5	Add a device window	40
6	Add a device - Select a pairing option	41
7	Add a device - Enter pairing code	41
8	Bluetooth Link Serial Port	42
9	Add a device - Successful	42
10	Bluetooth Icon	42
11	Bluetooth Devices Window	43
12	Bluetooth Devices Window - Device Menu	44
13	Bluetooth Devices Window - Properties	44
14	Properties - Services Tab	45
17	SMART6 Dimensions	48
18	SMART6 Communication/Power Cable	49

Tables

1	SMART6 Models	11
2	SMART6 Connector Pin-Out	13
3	SMART6 LED Status Indicators	18
4	Available CAN Signals on the SMART6	19
5	SMART6 Communication/Power Cable Pinouts	50
6	SMART6 Mating Connectors	51
7	Recommended Fuse and Fuse Holders	51
8	SMART6 Commands	52
9	FRESET Target	57
10	Detailed Serial Port Identifiers	60
11	Response Modes	62
12	SMART6 Logs in Alphabetical Order	65
13	Position or Velocity Type	67
14	Solution Status	67
15	Component Type	68
16	SMART6 Product	69
17	Reference User Manuals	69

Notice

The following notices apply to the SMART6.



Changes or modifications to this equipment not expressly approved by NovAtel Inc. could result in violation of FCC, Industry Canada and CE Marking rules and void the user's authority to operate this equipment.

FCC Notices

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SMART6 has been tested and found to comply with the emission limits for a Class B digital device, pursuant to part 15 of the FCC Rules. The Class B limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the SMART6
- Increase the separation between the equipment and the SMART6
- Connect the equipment to an outlet on a circuit different from that to which the SMART6 is connected
- Consult the dealer or an experienced radio/TV technician for help



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



In order to maintain compliance as a Class "B" digital device, shielded cables should be used for the RS-232 serial data ports (Belden 1036A or equivalent) and twisted pair cable should be used for the CAN port (shielded twisted pair will improve CAN performance in electrically harsh environments). I/O signals should be referred to signal ground (connector pin 5) and not power ground (connector pin 9). If I/O signals route to different areas of the vehicle, dedicated signal grounds for I/O should be spliced into a common connection to connector pin 5 at a point close to the SMART6.

Industry Canada

SMART6 Class B digital apparatuses comply with Canadian ICES-003.

SMART6 appareils numérique de la classe B sont conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CE

The enclosures carry the CE mark.

"Hereby, NovAtel Inc. declares that this SMART6 is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive 1999/5/EC, the EMC Directive 4/108/EC and the RoHS Recast Directive 2011/65/EU."

WEEE

If you purchased your OEM6 family product in Europe, please return it to your dealer or supplier at the end of its life. The objectives of the European Community's environment policy are, in particular, to preserve, protect and improve the quality of the environment, protect human health and utilise natural resources prudently and rationally. Sustainable development advocates the reduction of wasteful consumption of natural resources and the prevention of pollution. Waste electrical and electronic equipment (WEEE) is a regulated area. Where the generation of waste cannot be avoided, it should be reused or recovered for its material or energy. WEEE products may be recognized by their wheeled bin label .¹

1. Visit the NovAtel Web site at www.novatel.com/products/weee-and-rohs/ for more information on WEEE.

Customer Service

NovAtel Knowledge Base

If you have a technical issue, visit the NovAtel support website at www.novatel.com | Support | Helpdesk and Solutions | Knowledge and Forums. Through this page, you can search for general information about SMART® antennas and other technologies, information about NovAtel hardware, software, installation and operation issues.

Before Contacting Customer Support

Before you contact NovAtel Customer Support about a software problem perform the following steps:

1. Issue the following logging commands to collect data to a file on your computer for 15 minutes:

```
LOG VERSIONA ONCE
LOG RXSTATUSA ONCE
LOG RXCONFIGA ONCE
LOG RAWEPHEMA ONNEW
LOG BESTPOSA ONTIME 1
LOG RANGEA ONTIME 1
```

2. Send the file containing the logs to NovAtel Customer Service, using either the NovAtel ftp site at <ftp://ftp.novatel.com/incoming> or the support@novatel.com e-mail address.
3. You can also issue a `FRESET` command to the receiver to clear any unknown settings.



The `FRESET` command will erase all user settings and perform a factory reset. You should know your configuration and be able to reconfigure the receiver before you send the `FRESET` command.

If you are having a hardware problem, send a list of the troubleshooting steps taken and the results.




Contact Information

Use one of the following methods to contact NovAtel Customer Support:

Call the NovAtel Hotline at 1-800-NOVATEL (U.S. and Canada) or +1-403-295-4500 (international)	
Fax: +1-403-295-4901	Write: NovAtel Inc. Customer Support Department 1120 - 68 Avenue NE Calgary, AB Canada, T2E 8S5
E-mail: support@novatel.ca	
website: www.novatel.com	

Conventions

Conventions used in this manual are the following:

	Note that provides information to supplement or clarify the accompanying text.
	Caution that a certain action, operation or configuration may result in incorrect or improper use of the product.
	Warning that a certain action, operation or configuration may result in regulatory noncompliance, safety issues or equipment damage.

- The letter H in the *Offset* columns of the commands and logs tables represents the header length for that command or log. Refer to the [OEM6 Family Firmware Reference Manual](#) for ASCII and binary header details.
- The number following 0x is a hexadecimal number.
- Command descriptions' brackets, [], represent the optionality of parameters.
- In tables where values are missing they are assumed to be reserved for future use.
- Status words are output as hexadecimal numbers and must be converted to binary format (and in some cases then also to decimal). For an example of this type of conversion, refer to the RANGE log in the [OEM6 Family Firmware Reference Manual](#).

Conversions and their binary or decimal results are always read from right to left. For a complete list of hexadecimal, binary and decimal equivalents, refer to *Unit Conversion* available on our web site at www.novatel.com/support/knowledge-and-learning/.

The SMART6 is a high performance GNSS receiver and antenna, capable of receiving and tracking different combinations of GNSS L1/L2 code and carrier signals on a maximum of 120 channels. SBAS (Satellite Based Augmentation Systems) support, which includes WAAS (North America), EGNOS (Europe) and MSAS (Japan) is standard. Refer to [NovAtel's GNSS Book](#) for an overview of each of the above signal types. The SMART6 rear panel also features Light Emitting Diodes (LEDs) for status indication.

Once properly powered, the SMART6 begins operating as a fully functional GNSS system. *Figure 1, SMART6 Receiver* shows the SMART6 without connecting cables.

Figure 1: SMART6 Receiver



1.1 Features and Models

The main features of the SMART6 are:

- an enhanced high performance GNSS L1/L2 receiver
- a high performance GNSS L1/L2 antenna
- a CAN port
- three RS-232 COM ports or two RS-232 COM ports and Bluetooth
- three LED status indicators
- a water and dust tight enclosure
- Bluetooth wireless technology (optional)
- tilt compensation (optional)

The SMART6 is available in several different firmware models whose configurations may include other additional features. Some possible configurations can be seen in *Table 1, SMART6 Models*.

Table 1: SMART6 Models

NovAtel Part Number	Description
01019123	SMART6
01019125	SMART6 with Tilt
01019121	SMART6 with Bluetooth
01019127	SMART6 with Bluetooth and Tilt

Contact NovAtel Sales at www.novatel.com/where-to-buy/contact-us for information regarding available models, upgrading a model to increase feature/functionality or go to www.novatel.com/support/firmware-software-and-manuals/firmware-software-updates/ to obtain product updates. Refer to *Chapter 4, NovAtel Firmware and Software* on page 32 for details.



Refer to the [OEM6 Installation and Operation Manual](#) for detailed information on receiver communications and operation.

2.1 Additional Equipment Required

In order for the SMART6 to perform optimally, the following additional equipment is required:

- A cable harness for communicating and powering the SMART6 (NovAtel cable harness 01018999 is available with three DB-9 connectors, four bare cables and a SMART6 connector) or similar
- A fused power supply (user supplied) (refer to *Table 7, Recommended Fuse and Fuse Holders on Page 51* for details)
- A computer (user supplied)

2.1.1 SMART6 Setup

Complete the following steps to connect and power the SMART6.

1. Mount the SMART6 on a secure, stable structure with an unobstructed view of the sky from horizon to horizon (refer to *Section 2.1.4 Mounting the SMART6 on page 17* for details).
2. Connect the NovAtel interface cable, or custom wiring harness, to the *COM and Power* port on the back of the SMART6, see *Figure 2, SMART6 Connector*.

Figure 2: SMART6 Connector





Table 2: SMART6 Connector Pin-Out

Pin	Use	Pin	Use
1	COM1 TxD	8	COM3 TxD ^a
2	COM1 RxD	9	Power Negative/Return
3	COM2 TxD	10	ER_OUT (Emulated Radar Output)
4	COM2 RxD	11	MKI (Mark Input)
5	Signal Ground (COM/MKI/PPS/ER)	12	PPS (Pulse Per Second) Output
6	CAN+	13	COM3 RxD ^a
7	CAN-	14	Power Positive/Source


a. On Bluetooth models, COM3 is not available.

3. Connect the NovAtel cable or custom wiring harness to a DB-9 serial port on a computer or other data storage device.
4. Connect the NovAtel cable or custom wiring harness to the power supply and turn on the power supply to the SMART6 (the SMART6 cable is also a power cable). The power LED  on the receiver glows red when the SMART6 is properly powered.



Fuse/holder recommendations can be found in *Table 7, Recommended Fuse and Fuse Holders* on *Page 51*.

Figure 3: Simplified SMART6 Setup



Minimum conductor size for all wiring is 0.5 mm/20 AWG. NovAtel recommends tying to ground any floating input lines.

2.1.2 Power Supply Requirements

The SMART6 requires +8 to +36 VDC input power (refer to *SMART6 Specifications on page 47* for additional power supply specifications).

The SMART6 cable provides power in (BATT+) and power ground (BATT-) bare wires for connecting the SMART6 to a vehicular power system (or equivalent).




The SMART6 power source must be protected by a 5 A Fast Blow Fuse or damage to wiring may result (not covered by warranty). Refer to *SMART6 Connector and Cable Requirements on page 50*.

2.1.3 Mounting Plate


Two mounting plates are available to facilitate mounting the receiver: a surface mounting plate and a pole mounting plate.

Figure 4: SMART6 Surface Mounting Plate



To install the mounting plate, use the adhesive tape or the mounting holes at each corner of the plate.

Figure 3: SMART6 Pole Mounting Plate



To install the pole mounting plate:


1. Use four M4 screws to connect the mounting plate to the SMART6.
2. Screw the mounting plate onto a mount, such as a range pole, tribrach, or tripod, with a 1" x 14 thread.
A 5/8" to 1" bushing adaptor is available (part number 12023275).

2.1.4 Mounting the SMART6

Mount the SMART6 on a secure, stable structure capable of safe operation in the specific environment.

- If installing on a vehicle, mount the SMART6 on the vehicle roof, ideally close to the pivot point of the vehicle. The SMART6 must be mounted with the connector facing the rear of the vehicle (see *Figure 5, SMART6 Orientation*).

Figure 5: SMART6 Orientation



The SMART6 must be rigidly secured to the vehicle to avoid errors caused by vibration and motion.

- If installing in a stationary location, mount the SMART6 in a location that has a clear view of the sky so that each satellite above the horizon can be tracked without obstruction. For more information, refer to [NovAtel's GNSS Book](#).

2.1.5 Connecting Data Communications Equipment

To communicate with the receiver for sending commands and obtaining logs, a connection to data communications equipment is required. Refer to *Table 5, SMART6 Communication/Power Cable Pinouts* on *Page 50* on for more information.




2.2 Additional Features and Information

This section contains information on the additional features of the SMART6, which may affect the overall design of the receiver system.

2.2.1 Status Indicators

LED indicators on the SMART6 provide the status of the receiver. The table below shows the meaning of the LEDs.

Table 3: SMART6 LED Status Indicators

Red	Yellow	Green	Condition
			
Off	Off	Off	Power is not available. (Red indicator may also not be lit if a boot failure has occurred.)
On	Off	Off	Power is available but no satellites are being tracked yet.
On	Flashing	Off	Tracking at least one satellite but not a valid position.
On	On	Off	Position valid in basic autonomous mode.
On	On	Flashing	SBAS tracking, but not enough data for enhanced solution.
On	On	On	Position valid in an enhanced accuracy mode (WAAS/EGNOS/MSAS/DGPS).



Flashing means that the LED is turning on and off at a 1 Hz rate - 0.5 seconds on and 0.5 seconds off.

Troubleshooting:

- If the power is on but the yellow LED does not flash within one minute, then no satellites are being tracked. There may be excessive blockage or the SMART6 may be defective. Make sure the SMART6 has an unobstructed view of the sky. Try power cycling the SMART6.
- If the yellow LED is flashing but doesn't progress to solid yellow within one minute, then insufficient satellites are being tracked or the signal quality is poor and ephemeris data cannot be received. Normally, four satellites are sufficient for a valid position as long as they are widely distributed in the sky. If LED is stuck on blinking yellow, there may be excessive signal blockage or the SMART6 may be defective. Make sure the SMART6 has an unobstructed view of the sky. Try power cycling the SMART6.
- If the yellow LED is on, but the green doesn't turn on within five minutes than no SBAS or DGPS positions are available. If you are using SBAS, make sure SBAS is available in your area and that the SMART6 is configured to enable SBAS positions (SBASCONTROL ENABLE). For DGPS, make sure the SMART6 is configured with the correct serial port parameters and to accept the DGPS protocol your area is using and that your data modem is connected and working.
- The green LED blinks when SBAS is detected then it comes on solid when SBAS is enabled. The LED will stay dark if SBAS is not detected.

2.2.2 MKI and PPS Strobes

The Mark Input (MKI) and Pulse Per Second (PPS) strobe provide status and synchronization signals. PPS is a 3.3 V CMOS output; MKI is a 5 V logic tolerant input.

Pin-out information can be found on *Table 5, SMART6 Communication/Power Cable Pinouts* on page 50.

2.2.3 Emulated Radar (ER)

The SMART6 outputs an emulated RADAR signal via the bare wires labeled ER_GND and ER_OUT on the SMART6 cable. See *Table 5, SMART6 Communication/Power Cable Pinouts* on page 50 for the pin-out details of this cable.

The ER outputs a logic high of supply voltage minus 0.5 V minimum and logic low of 0.5 V maximum with a rise and fall time of less than 1 ms. Its output references signal GND and provides logic low output until its speed is greater than 1 km/Hr. ER can be configured to operate at one of three distinct frequencies (26.11, 28.12 or 36.11 Hz/km/Hr, with 26.11 Hz/km/Hr being the default value) and with an effective range from 1 km/Hr to 55 km/Hr for near-horizontal applications. See *Section B.7, RADARCFG Configure the ER Output* on page 62 for more information.

2.2.4 Controller Area Network (CAN)

The SMART6 supports the following NMEA2000 Parameter Group Messages (PGN):

- PGN 129029 GNSSPositionData (1 Hz)
- PGN 129025 GNSSPositionRapidUpdate (10 Hz)
- PGN 129026 COGandSOGRapidUpdate (10 Hz)



The CAN must be activated by entering the `SETCANNNAME` command (refer to *B.8 SETCANNNAME Sets the CAN name fields* on page 63). To have the CAN set up automatically at subsequent start ups, also send the `SAVECONFIG` command.

Table 4: Available CAN Signals on the SMART6

CAN	Pins
CAN+	Pin 6
CAN-	Pin 7

2.2.5 Tilt Compensation

The SMART6 Tilt Compensation feature corrects for errors in position caused by tilting of the vehicle.



Refer to *Tilt Compensation* on page 30 for a detailed description of the Tilt Compensation feature.

To fully install and set up tilt compensation:


1. Mount the SMART6 on the vehicle.
2. Measure, set and save the height of the SMART6 from the ground.
3. Level the tilt sensor and save the data.




Refer to *\$PMDT Configure Tilt Compensation* on page 61 for height, level and update commands.

2.2.5.1 Physical Installation

The SMART6 must be mounted as close to the center of the vehicle as possible, as illustrated in *Figure 6, SMART6 Installation*.

Figure 6: SMART6 Installation

The SMART6 must be mounted with the connector facing the rear of the vehicle, as shown in *Figure 7, SMART6 Orientation*:

Figure 7: SMART6 Orientation

The SMART6 must be rigidly secured to the vehicle to minimize errors due to vibration and motion.

2.2.5.2 Height Measurement and Configuration

The height measurement should be made while the vehicle has the correct tire pressure and is parked on a hard-packed and level surface. The measurement should be made from the ground to the bottom of the SMART6 connector. The measurement accuracy should be within 1 to 2 inches (2.5 to 5.0 cm).

Once the measurement has been made (in feet and inches, or metres), refer to *Section B.6, \$PMDT Configure Tilt Compensation* on page 61 for instructions on how to set the height in the SMART6. The height must be saved after the height command is sent. This must be done so the height data is saved between power cycles. Instructions on sending the save command are outlined in *Section B.6, \$PMDT Configure Tilt Compensation* on page 61.

Note that changes in tire pressure over time can potentially cause errors in tilt compensation. This is because the height of vehicle can vary with tire pressure.

The SMART6 is shipped from the factory with the height set to 0.0 metres.

2.2.5.3 Leveling the Tilt Sensor

The vehicle must be parked on flat ground when the level command is sent to the SMART6. Refer to *Section B.6, \$PMDT Configure Tilt Compensation* on page 61 for instructions on how to send the level command.

After the tilt sensor has been leveled, the data must be saved to non-volatile memory using the save command. Instructions on using the save command are outlined in *Section B.6, \$PMDT Configure Tilt Compensation* on page 61.

Before operating the SMART6 for the first time, ensure the installation instructions in *Chapter 2, Installation and Setup* were followed. It is assumed that a computer is used during initial operation and testing for greater ease and versatility.

3.1 Communications with the Receiver

Communication with the receiver typically consists of issuing commands through the communication ports from an external serial communications device. This could be either a terminal or computer connected directly to the receiver serial port using a DB-9 connector on the SMART6 communication/power cable. If using a radio, connect it to another DB-9 connector on the same communication/power cable by means of the radio serial cable supplied with the radio. It is recommended that you become thoroughly familiar with the commands and logs detailed in the [OEM6 Family Firmware Reference Manual](#) to ensure maximum utilization of the receiver's capabilities.

3.1.1 Serial Port Default Settings

The receiver communicates with the computer or terminal via an RS-232 serial port. For communication to occur, both the receiver and the operator interface have to be configured properly. The receiver's COM1, COM2 and COM3 default port settings are as follows:

- 9600 bps, no parity, 8 data bits, 1 stop bit, no handshaking, echo off

To change the default settings, use the `COM` command. See *Appendix B.3, COM Configure COM Port* starting on *Page 54* for details.

The data transfer rate chosen determines how fast information is transmitted. For example, outputting a log whose message byte count is 96. The default port settings allows 10 bits/byte (8 data bits + 1 stop bit + 1 framing bit). It therefore takes 960 bits per message. To get 10 messages per second, 9600 bps is required. Also remember that even if the bps is set to 9600, the actual data transfer rate is lower and depends on the number of satellites being tracked, data filters in use and idle time. It is suggested a margin is set when choosing a data rate (115200 is recommended for most applications).



Although the receiver can operate at data transfer rates as low as 300 bps, this is not desirable. For example, if several data logs are active (that is, a significant amount of information needs to be transmitted every second) but the bit rate is set too low, data will overflow the serial port buffers, causing a warning in the receiver status and loss of data.

3.1.2 Communicating Using a Remote Terminal

One method of communicating with the receiver is through a remote terminal. The receiver is pre-wired to allow proper RS-232 interface with the data terminal. To communicate with the terminal, the receiver only requires the RX, TX and GND lines to be used. Request to Send (RTS)/Clear to Send (CTS) hardware handshaking is not available. Ensure the terminal's communications set up matches the receiver's RS-232 protocol.

3.1.3 Communicating Using a Computer

A computer can be set up to emulate a remote terminal as well as provide the added flexibility of creating multiple command batch files and data logging storage files. Any standard communications software package, that emulates a terminal, can be used to establish bidirectional communications with the receiver. For example, HyperTerminal or NovAtel's Graphical User Interface (GUI) program NovAtel Connect™. All data is sent as raw 8-bit binary or ASCII characters.

3.2 Getting Started

3.2.1 Starting the Receiver

When first powered, the SMART6 undergoes a complete self-test. The results of this test can be viewed by connecting to the receiver and requesting the RXSTATUS log. Refer to the [OEM6 Family Firmware Reference](#) manual for details.


If a persistent error develops, contact your local NovAtel dealer first. If the problem remains unresolved, contact NovAtel directly through any of the methods listed in the *Customer Service* section on page 9.

3.2.2 Communicating with the Receiver Using NovAtel Connect

NovAtel Connect is a Windows based GUI used to access the receiver's many features. Convert is a utility that converts between file formats and strips unwanted records for data file compilation. Both are included in the NovAtel Connect PC Utilities bundle available from: www.novatel.com/support/firmware-software-and-manuals/firmware-software-updates/.

Launch the NovAtel Connect program and select *Device | Open Connect* from its main menu. The *Open Connection* window appears.

Figure 8: Open Connection Window



Refer to the NovAtel Connect help file or press F1 while the cursor is in a NovAtel Connect window. Ensure the *Console* and *ASCII Messages* windows are open by selecting them from the *View* menu.

When the receiver is first turned on, no data is transmitted from the COM ports except for the port prompt. The console window displays a port name:

- [COM1]** if connected to COM1 port
- [COM2]** if connected to COM2 port
- [COM3]** if connected to COM3 port or through Bluetooth

Any of the above prompts indicate the receiver is ready and waiting for command input.



1. You may also have to wait for output from receiver self-tests. For example, on start-up, the SMART6 is set to log the RXSTATUS log ONNEW on all ports. Refer to the [OEM6 Family Firmware Reference Manual](#) for more details.
2. If NovAtel Connect is unable to locate the SMART6, try using a different COM port to communicate to the receiver. Once communication has been established, issue the `FRESET STANDARD` command. You should now be able to use the original communication port again.

Commands are typed at the interfacing computing device's keypad and executed after issuing a carriage return command which is usually the same as pressing the <Enter> key.

An example of a response to an input command is the `FIX POSITION` command. It can be as:

```
[COM2] FIX POSITION 51.11635 -114.0383 1048.2 [Carriage Return]
<OK
```

where [COM2] is the port prompt, followed by the command entered and [Carriage Return] is a prompt to press the <Enter> key.

The example above illustrates the command input to the base receiver's COM2 port, which sets the position of the base station receiver for differential operation. Confirmation that the command was actually accepted is the appearance of <OK.

If a command is entered incorrectly, the receiver responds with:

```
<Invalid Message ID          (or a more detailed message)
```




Ensure the computer's Control Panel Power Settings are not set to Hibernate or Standby modes. Data is lost if one of these modes occurs during a logging session.

3.3 Transmitting and Receiving Corrections

RTK or DGPS corrections can be transmitted from a base station to a rover station to improve position accuracy. The base station is the GNSS receiver, which is acting as the stationary reference. It has a known position and transmits correction messages to the rover station. The rover station is the GNSS receiver which does not know its exact position and can be sent correction messages from a base station to calculate differential GNSS positions. The SMART6 can be used as a base receiver to transmit RTK or DGPS corrections or a rover to receive the same corrections. An example of a differential setup is given in *Figure 9, Basic Differential Setup* on page 25.

Figure 9: Basic Differential Setup



Reference	Description
1	SMART6 receiver
2	User supplied 5 A fast blow fuse
3	User supplied power supply, for example a battery
4	User supplied device to COM1
5	User supplied device to COM2
6	User supplied device to COM3
7	User supplied cable or NovAtel 01018999 Communication/Power cable



The configuration shown in *Figure 9, Basic Differential Setup* is valid for SMART6 receivers without optional Bluetooth. For a SMART6 receiver with Bluetooth, two of the serial devices connect through COM1 and COM2 and the other device must connect through Bluetooth.

System biases can introduce errors, refer to our *GNSS Book* found on our Web site at www.novatel.com/support/knowledge-and-learning/ for more information. In most cases, a data link between the base station and rover station (two NovAtel receivers) is required to receive corrections. SBAS corrections can be accomplished with one receiver and are exceptions to the base/rover concept. Generally, a link capable of data throughput at a rate of 9600 bits per second and less than 4.0 s latency is recommended.

Once the base and rover are set up, configure them as shown in the configuration examples that follow in *Section 3.3.1, Base Station Configuration* on page 26 and *Section 3.3.2, Rover Station Configuration* on page 27.

3.3.1 Base Station Configuration

At the base station, enter the following commands:

```
COM [port] bps [parity[ databits[stopbits[handshake[echo[break]]]]]]]
interfacemode port rx_type tx_type [responses]
fix position latitude longitude height
log port message [trigger [period]]
```

Examples of these commands include the following:

```
RTCA      com com2 9600 N 8 1 N off
            interfacemode com2 none rtca off
            fix position 51.11358042 -114.04358013 1059.4105
            log com2 rtcaobs ontime 1
            log com2 rtcaref ontime 10
            log com2 rtca1 ontime 5           (optional for RTK)
            log com2 rtcaephem ontime 10 1   (optional)

RTCM     com com2 9600 N 8 1 N off
            interfacemode com2 none rtcm off
            fix position 51.11358042 -114.04358013 1059.4105
            log com2 rtcm3 ontime 10        (required for RTK)
            log com2 rtcm22 ontime 10 1     (optional)
            log com2 rtcm1819 ontime 1
            log com2 rtcm1 ontime 5

RTCMV3   com com2 9600 N 8 1 N off
            interfacemode com2 none rtcmv3 off
            fix position 51.11358042 -114.04358013 1059.4105
            log com2 rtcm1006 ontime 10
            log com2 rtcm1003 ontime 1

CMR+    com com2 9600 N 8 1 N off
            interfacemode com2 none cmr off
            fix position 51.11358042 -114.04358013 1059.4105
            log com2 cmrobs ontime 1
            log com2 cmrplus ontime 1       (Important to use ontime 1 with cmrplus)

CMR     com com2 9600 N 8 1 N off
            interfacemode com2 none cmr off
            fix position 51.11358042 -114.04358013 1059.4105
            log com2 cmrobs ontime 1
            log com2 cmrref ontime 10
            log com2 cmrdesc ontime 10 1
```

3.3.2 Rover Station Configuration

At the rover station, enter:

```
COM [port] bps [parity[databits[stopbits[handshake[echo[break]]]]]]
interfacemode port rx_type tx_type [responses]
```

For example:

```
RTCA      interfacemode com2 rtca none off
RTCM      interfacemode com2 rtcn none off
RTCMV3    interfacemode com2 rtcmv3 none off
CMR+      interfacemode com2 cmr none off
CMR       interfacemode com2 cmr none off      (same as CMR+)
```

3.3.3 GPS + GLONASS Base and Rover Configuration

This section shows how to set up a base and rover OEM6 GPS + GLONASS enabled receivers for GPS + GLONASS RTK operation:

Base Station:

```
fix position lat lon hgt                (enter your own lat, lon, and hgt values)
com com2 9600 N 8 1 N off
interfacemode com2 none rtca off
log com2 rtcaref ontime 10
log com2 rtcaobs2 ontime 1
log com2 rtca1 ontime 5                  (optional, enable code-DGPS coverage)
saveconfig                               (optional, save configuration to non-volatile memory)
```

Rover Station:

```
com com2 9600 N 8 1 N off
interfacemode com2 rtca none off
log com1 bestposa ontime 1              (optional, view position information)
saveconfig                               (optional, save configuration to non-volatile memory)
```

3.3.4 Configuration Notes

For compatibility with other GNSS receivers and to minimize message size, it is recommended using the standard form of RTCA, RTCM, RTCMV3 or CMR corrections as shown in the base and rover examples above. This requires using the `INTERFACEMODE` command to dedicate one direction of a serial port to only that message type. When the `INTERFACEMODE` command is used to change the mode from the default, NOVATEL, you can no longer use NovAtel format messages.

To mix NovAtel format messages and RTCA, RTCM, RTCMV3 or CMR messages on the same port, leave the `INTERFACEMODE` set to NOVATEL and log out variants of the standard correction messages with a NovAtel header. ASCII or binary variants can be requested by simply appending an "A" or "B" to the standard message name. For example on the base station:

```
interfacemode com2 novatel novatel
fix position 51.11358042 -114.04358013 1059.4105
log com2 rtcmlb ontime 2
```

Using the receiver in this mode consumes more CPU bandwidth than using the native differential messages as shown in *Section 3.3.1, Base Station Configuration* on page 26.

At the rover station, leave the `INTERFACEMODE` default settings (`interfacemode com2 novatel novatel`). The rover receiver recognizes the default and uses the corrections it receives with a NovAtel header.

The `PSRDIFFSOURCE` and `RTKSOURCE` commands set the station ID values which identify the base stations from which to accept pseudorange or RTK corrections respectively. These are useful commands when the rover station is receiving corrections from multiple base stations. Refer to NovAtel's [GNSS Book](#) for more information on SBAS, available from www.novatel.com.

All `PSRDIFFSOURCE` entries fall back to SBAS (even NONE) for backwards compatibility (assuming SBAS was enabled).

At the base station it is also possible to log out the contents of the standard corrections in a form that is easier to read or process. These larger variants have the correction fields broken out into standard types within the log, rather than compressed into bit fields. This can be useful to modify the format of the corrections for a non-standard application or to look at the corrections for system debugging purposes. These variants have "DATA" as part of their names (for example, `RTCADATA1`, `RTCMDATA1`, `CMRDATAOBS` and more). Refer also to the [OEM6 Family Firmware Reference Manual](#) detailed descriptions of the various message formats.

Information on how to send multiple commands and log requests using DOS or Windows can be found on our web site at www.novatel.com/support/knowledgedb.htm.

3.4 GLIDE

SMART6 contains NovAtel's GLIDE which is a positioning algorithm for single-frequency GPS and GPS/GLONASS applications. GLIDE produces a smooth position output tuned for applications where time relative accuracy (pass-to-pass) is more important than absolute accuracy. Because of this, it is well suited for agricultural applications.

Multipath signals tend to induce time varying biases and increase the measurement noise on the L1/L2 pseudorange measurements. Carrier phase measurements are much less susceptible to the effects of multipath. The GLIDE algorithm fuses the information from the L1 code and the L1 phase measurements into a Position Time Velocity (PVT) solution.

GLIDE includes settings for a dynamic mode, a static mode and an "auto" mode, where the filtering parameters are automatically adjusted as vehicle velocity varies between stationary and dynamic states.

3.4.1 Dual-Frequency GLIDE

NovAtel's dual-frequency GLIDE technology adds to the superior pass-to-pass performance provided by single-frequency GLIDE. Dual-frequency GLIDE is ideal for agricultural and machine guidance applications where relative positioning is critical. Using GLIDE significantly reduces the variation in position errors to less than 1 cm from one epoch to the next. Dual-frequency GLIDE improves the absolute accuracy of the GLIDE position and creates a robust solution resistant to the effects of high ionospheric activity. GLIDE works in all code positioning modes, including single point, DGNSS and SBAS.

Refer to the NovAtel white papers at www.novatel.com/support/knowledge-and-learning/published-papers-and-documents/white-papers/ for more information on GLIDE. Also refer to application note "APN-038 Pseudorange/Delta-Phase (PDP) and GLIDE Filters" at www.novatel.com/support/knowledge-and-learning/published-papers-and-documents/application-notes/.

3.5 Emulated Radar (ER)

A typical radar sensor emits radio beams that bounce off the ground and computes ground speed based on the speed at which objects are passing in front of the sensor. The output of the sensor is a digital pulse, the frequency of which is proportional to the vehicle's ground speed. This is often used in agricultural applications such as planting and spraying. The SMART6 eliminates the need for separate ground-sensing radar equipment by converting the GPS-derived velocity to proportional frequency output. The following emulated radar signal parameters can be configured by the customer:

- Frequency Step: Specifies how the frequency output relates to the vehicle speed.
- Signal Update Rate: Specifies how often the frequency output is updated to match the vehicle speed.
- Response Mode: Specifies how quickly changes in velocity are reflected in the frequency output. Setting a slower response mode reduces spikes (noise) in the velocity but increases latency. Setting a higher response mode reduces latency, but may result in noisier frequency output. Refer to *RADARCFG Configure the ER Output* on page 62 for more detailed information.

After it is configured using the RADARCFG command, Emulated Radar (ER) pulses are output through the SMART6 cables (see *Table 5, SMART6 Communication/Power Cable Pinouts* on page 50) and the RADARSIGNAL log (see *RADARSIGNAL ER Signal and Position Information* on page 66).

3.6 Tilt Compensation

The SMART6 Tilt Compensation feature corrects for errors in position caused by tilting of the vehicle. The SMART6 senses the vehicle's roll angle and, with the user-entered "height above ground", compensates the position output to give the position under the vehicle rather than at the antenna.



Information about installation and setup can be found in:


- *Tilt Compensation* on page 19

Information about tilt-compensation commands can be found in:

- `$PMDT Configure Tilt Compensation` on page 61

As shown in *Figure 10, SMART6 Tilt Compensation*, if an agricultural implement is operating on sloped terrain, the position will be in error by an amount proportional to the tilt angle.

Figure 10: SMART6 Tilt Compensation



If tilt compensation is enabled, the SMART6 determines the tilt and corrects the position data before it is forwarded to the user equipment. In the above example, the tilt is 10 degrees, and the position correction that needs to be applied is 62 cm.

The BESTPOS, BESTXYZ and all NMEA GPGGA logs will provide tilt-compensated position logs.

3.7 Recommended Configuration

The following command is recommended to enable CAN:

```
setcanname 305 2 0 0 23 0 0 28 can2
```

The following command is recommended to enable SBAS (WAAS/GNOS/MSAS) corrections:

```
sbascontrol enable
```

The following commands are recommended to enable GLIDE:

```
pdpfilter enable  
pdpmode relative auto
```

NovAtel has registered manufactured ID code 305 with J1939. When complete, configuration can be saved with the `SAVECONFIG` command. For more information about these commands, refer to the [OEM6 Family Firmware Reference Manual](#), available at www.novatel.com/support/firmware-software-and-manuals/product-manuals-and-doc-updates/.

Download the most recent versions of the NovAtel firmware and receiver software from the NovAtel website at [www.novatel.com Support/Firmware/Software and Manuals](http://www.novatel.com/Support/Firmware/Software%20and%20Manuals).

OEM6 Firmware and Software



Refer to *Section 4.3.1, Transferring Firmware Files* on page 34 for descriptions of the Update and OEM versions.

NovAtel Connect PC Utilities Software Bundle

Bundled PC Utilities software includes:

- NovAtel Connect (a GUI interface)
- Connection Import (improves connection profiles)
- Convert (converts receiver data logs into different formats)
- USB Drivers and Window Signing



The NovAtel Connect PC Utilities bundle can be download from our web site: www.novatel.com/support/firmware-software-and-manuals/firmware-software-updates/novatel-connect/

Firmware and Software included

- SoftLoad firmware
- WinLoad software utility



WinLoad and SoftLoad instructions follow.

4.1 Firmware Updates and Model Upgrades

A local NovAtel dealer can provide all the information needed to upgrade or update a receiver. Refer to www.novatel.com/where-to-buy for contact information or contact sales@novatel.com or support@novatel.com directly.

4.1.1 Firmware Updates

Firmware updates are firmware releases that include fixes and enhancements to the receiver functionality. Firmware updates are released on the NovAtel web site as they become available. New firmware must be loaded into the receiver through one of the COM ports. Once loaded, the receiver reboots and begins operating with the new firmware.



Direct access to a serial COM port on the SMART6 receiver is required.

4.1.2 Model Upgrades

Model upgrades enable purchased receiver features.

Contact a local NovAtel dealer to assist in selecting the upgrade options that best suit your GNSS needs at www.novatel.com/where-to-buy. Contact NovAtel Customer Support www.novatel.com/support or [NovAtel Sales](#) to request a temporary upgrade authorization code for trial purposes.

The receiver stores the firmware in Non-Volatile Memory (NVM), which allows model upgrades to be performed without returning the receiver to the dealer. Model upgrades can be applied to the receiver with an authorization code and the `AUTH` command.

4.2 Authorization Code

An authorization code, commonly known as an auth-code, is required to upgrade and possibly update an OEM6 family receiver. Auth-codes are obtained by contacting [NovAtel Customer Support](#). Upon contact, NovAtel Customer Support requires:

- the receiver model number
- the receiver serial number
- the receiver firmware version

Enter the `LOG VERSION` command to determine the receiver model, serial number and firmware version.

Example:

```

ENTER  ───► MODEL NUMBER   SERIAL NUMBER   FIRMWARE VERSION
GPSCARD "D2LR0RTTRA" "BFN11230026" "OEM615-1.00" "OEM060200RN0000"
                                     |
                                     |
          PRODUCT FAMILY   FIRMWARE NUMBER   RELEASE INDICATOR
    
```

After determining the appropriate model and firmware version the authorization code (auth-code) is issued. The auth-code is required to unlock the features on the new model type.

To upgrade to a new model with the same firmware version, use the `AUTH` command with the issued auth-code (if required), as outlined in *Upgrading Using the AUTH Command*.

To upgrade to a new model with a higher firmware version, the new firmware `.shex` file needs to be loaded into the OEM6 receiver using the WinLoad utility program. WinLoad and the firmware `.shex` files can be found at [www.novatel.com/Support/Firmware/Software and Manuals/Product Updates](http://www.novatel.com/Support/Firmware/Software%20and%20Manuals/Product%20Updates). Refer to *Section 4.3, Updating or Upgrading Using the WinLoad Utility* on page 34 for use instructions.

Firmware version OEM060200RN0000 (also known as firmware version 6.200) and later contain the Firmware Signature feature. This firmware feature removes the authorization code dependency on the firmware version and eliminates the need to obtain an auth-code when downloading the latest version of signed firmware.

If updating from a version before 6.200 to a signed 6.200 version, an authorization code is required. The receiver must have boot version code 6.100 or later for signed firmware to work.

In version OEM060200RN0000, the receiver serial number and the software model are built into the signature in the firmware file. Once the 6.200 signed firmware is installed with a signature auth-code, future firmware updates no longer require a new unique auth-code.



An authorization code is still required if the software model changes for temporary trial upgrades or purchased permanent upgrades.

The new download package includes a signed firmware file type that uses an extension designated as “.shex” (example OEM060200RN0000.shex), as well as the latest Winload utility and What’s New file containing firmware update change details.



Prior to firmware version OEM060200RN0000, authorization codes depended on the software model, the firmware version and the serial number of the receiver. The authorization code changed if any of the three items changed. This is no longer the case.

4.3 Updating or Upgrading Using the WinLoad Utility

WinLoad is the simplest and most common way to update or upgrade an OEM6 receiver.

4.3.1 Transferring Firmware Files

To proceed with an update or possibly an upgrade, obtain the latest version of firmware from the NovAtel website at www.novatel.com/support/firmware-software-and-manuals/firmware-software-updates/oem6-family/.

Types of Firmware Files

- **OEM Version** - NovAtel Customer Service may generate and provide the required authorization code. Authorization codes are obtained by contacting support@novatel.com or at www.novatel.com/Support/.

The OEM version is named OEMXXXX.EXE, where XXXX is the firmware version.

For convenience, copy the update file to a GNSS sub-directory (for example, C:\GNSS\LOADER).

If the firmware update file is password protected, NovAtel Customer Support provides the required password. After copying the file to a computer, perform the following steps to extract the files:

Syntax: [filename] [password] (if required)

where filename is the name of the compressed file (but not including the .EXE extension) and password if the password is required for extraction.

Example: OEM060200RN0000.shex

In the above example, a window appears asking for a password.

The self-extracting archive produces the following files:

winload.exe	WinLoad utility program
howto.txt	Instructions on how to use the WinLoad utility
whatsnew.rtf	Information on the changes made in the firmware since the last revision
x..x.shex	Firmware version upgrade file, where x..x defines the product name and release (e.g., OEM060000RN0000.shex)

The files are extracted to unzip/program files/NovAtel Inc/x.xxx Full Update Disk, where x.xxx is the firmware version.



NovAtel has an online video tutorial that explains firmware uploading at: www.novatel.com/support/knowledge-and-learning/video-tutorials-and-tech-presentations/.


4.3.2 Using the WinLoad Utility

If opening WinLoad for the first time, ensure the file and communications settings are correct.

Open a File to Download


Select File | Open. Navigate to the file to open (*Figure 11*).

Figure 11: WinLoad's Open Window



When a file is selected, the filename appears in the main WinLoad display area and in the title bar (*Figure 12*).


Figure 12: Open File in WinLoad



Communications Settings

To set the communications port and baud rate, select Settings | COM Settings. Choose the computer port to use from the Com Port drop down list and the baud rate from the Download Baudrate drop down list. Set the baud rate as high as possible (the default of 115200 is preferred if a higher baud rate is not available).

Figure 13: COM Port Setup




Downloading Firmware


1. Select the file to download according to *Open a File to Download on Page 35*.
2. Ensure the file path and name are displayed in main display area (see *Figure 12, Open File in WinLoad on page 35*).
3. Click Write Flash to download the firmware.
4. When Searching for card appears in the main display, power cycle the receiver.

Figure 14: Searching for Card

5. If the Authorization Code window appears, enter the auth-code and click **OK**. See *Section 4.2, Authorization Code on page 33* for further information about the Authorization Code.

Figure 15: Authorization Code Window

6. The receiver finishes the download and then resets. The process is complete when **Done** appears in the main display area.

Figure 16: Upgrade Process Complete

7. Close WinLoad.

4.4 Updating using SoftLoad Commands

To use Softload to update an OEM6 family receiver.



Use SoftLoad if automated loading is required or the platform used to communicate with the receiver is not supported by WinLoad.



Refer to *Types of Firmware Files on page 34* for details on updating versus upgrading.

1. Open a connection to any port on the receiver.
2. Request the SOFTLOADSTATUS log using the following command:
`LOG SOFTLOADSTATUS ONCHANGED`
3. Initialize SoftLoad with a SOFTLOADRESET command. This command stops all tracking on the receiver to ensure sufficient memory is available for the loading process. A RXSTATUSEVENTA log reports a SoftLoad In Progress status.
4. Open the *.shex firmware file.



If using NovAtel Connect, close all windows before using the SOFTLOADSREC command to avoid failure. Only the Console and ASCII Message windows may remain open.

- Send each line of the *.shex file to the receiver in a `SOFTLOADSREC` command. The S-Records must be enclosed by quotation marks:

```
SOFTLOADSREC "<S-RECORD>"
```



To significantly decrease data transfer time, NovAtel recommends creating a batch file to automatically send each line of `SOFTLOADSREC`. Contact [NovAtel Customer Support](#) for assistance creating SoftLoad batch files.

- Send the `SOFTLOADCOMMIT` command.
- During the loading process, `SOFTLOADSTATUSA` logs report the load status. Wait for the `SOFTLOADSTATUSA` to indicate loading is complete.



Signature auth-codes are maintained internally by the receiver and do not need to be re-entered. Refer to *Section 4.2, Authorization Code on page 33* for details on obtaining any auth-code.

- Reset the receiver by entering `RESET` or `FRESET` command or power cycling.
- Once the receiver resets, the new version of firmware is active.



The SoftLoad process can be cancelled safely at any time during the process using the `RESET` command.

4.4.1 Working with S-Records

- Records beginning with S0, S5 and S7 should be passed to the receiver directly using the `SOFTLOADSREC` command. These records contain meta data about the firmware image.
- Records beginning with S3 form the actual firmware image and can be converted to `SOFTLOADDATA` binary commands. Aside from the header, each pair of characters forms the ASCII representation of binary byte. The format is as follows:

S3	LL	AAAAAAA	DDDDDDDD...DDDDDDDD	CC
			Little Endian Data. These bytes are copied into the "data" field of the <code>SOFTLOADDATA</code> command	Check Sum. One's compliment of all other bytes
			4 - Byte Address. Set this as the value of "offset" in the <code>SOFTLOADDATA</code> command	
			Length. This is the hexadecimal number of character pairs to follow in the record. This value minus 4 bytes for the address and 1 byte for the check sum is copied into the "data length" field of the <code>SOFTLOADDATA</code> command	
Header				

- Multiple S3 records can be packaged into a single `SOFTLOADDATA` command as long as the data from one S3 record follows immediately after the previous record, up to a maximum of 4096 bytes of data. That is, the address must equal the previous address plus the previous data length. The "offset" field remains the address of the first S3 record and the "data" and "data length" are updated to include the new data.
- The shex file data may contain many gaps and jumps. For example, in most NovAtel shex files data for address `0x000_00000` is stored near the very end of the file.

4.5 Upgrading Using the AUTH Command

The `AUTH` command authorizes the enabling (unlocking) of model features. The `AUTH` command is used to upgrade a new OEM6 family model, available with the same firmware version as the current model. This command only functions with a valid auth-code assigned by [NovAtel Customer Support](#).

The upgrade can be performed directly through the NovAtel Connect command line or from any other communications program.



Refer to *Types of Firmware Files on page 34* for details on updating versus upgrading.

4.5.1 Upgrade Procedure

1. Power up the OEM6 family receiver and establish communications (refer to the Quick Start Guide included with the product for instructions).
2. Issue the `LOG VERSION` command to verify the current model, firmware version and serial number (refer to *Section 4.2, Authorization Code on page 33* for instructions on obtaining).
3. Issue the `AUTH` command, followed by the auth-code and model type (refer to *Section 4.2, Authorization Code on page 33* for details on obtaining any auth-code). The syntax is as follows:

```
auth <your auth-code here>
```

where `auth` is a command that enables model upgrades and `auth-code` is the upgrade authorization code, expressed as follows:

```
XXXXXX,XXXXXX,XXXXXX,XXXXXX,XXXXXX,MODEL,EXPDATE
```

where:

1. Each X character is a case-insensitive ASCII character.
2. The MODEL string is a maximum of 15 characters long and represents the model enabled by the auth-code.
3. The EXPDATE string is the auth-code's expiry date, in YYMMDD format

Example:

```
auth 7WBMBK,887CB6,K5J3FH,5DF5P2,42PW8G,D1SB0GTT0,121211
```

When the `AUTH` command is executed, the OEM6 family receiver reboots. Issuing the `LOG VERSION` command confirms the new upgrade model type and firmware version number.

If communicating using NovAtel Connect, the communication path must be closed and reopened using the Device menu.

Bluetooth is a wireless radio communication standard designed for use over short ranges (within 10 m). This chapter describes how to use the Bluetooth interface on the SMART6.

5.1 *Bluetooth* Wireless Technology on the SMART6 receiver

Bluetooth wireless technology is configured on the SMART6's internal COM3 port. After your computer is configured for *Bluetooth* operation, use HyperTerminal or NovAtel Connect to communicate through COM3. To log data over the *Bluetooth* port, specify COM3 as the output port (e.g. `log com3 bestposa ontime 1`).

5.2 Pairing with a new SMART6



Ensure that your computer is equipped with a built-in, or external plug-in, *Bluetooth* adapter and is already configured with the appropriate *Bluetooth* driver.



The information in this section is specific to pairing an SMART6 with a Windows 7 based computer.

For information about pairing the SMART6 with other Bluetooth capable devices, refer to the devices user documentation.

To pair with an SMART6 in range:

1. Power on the SMART6.
2. Double-click the *Bluetooth* icon in the notification area, see *Figure 3* on page 39. The *Bluetooth Devices* window opens, see *Figure 4* on page 40.

Figure 3: Bluetooth Icon






Figure 4: Bluetooth Devices Window




3. On the Bluetooth Devices window, click the *Add a device* button. The *Add a device* window appears. The computer searches for any Bluetooth device in range and displays the devices found on the window, see *Figure 5* on page 40.

Figure 5: Add a device window




4. Select the SMART6 system and click the *Next* button. The *Select a pairing option* window appears, see *Figure 6* on page 41.

Figure 6: Add a device - Select a pairing option





5. Click the *Enter the device's pairing code* button. The *Enter the pairing code for the device* window appears, see *Figure 7* on page 41.

Figure 7: Add a device - Enter pairing code



6. Type the SMART6 pairing code, **0000**, and click the *Next* button. Windows installs the serial port driver and assigns a serial port number to the Bluetooth link. Make a note of the serial port number assigned. See *Figure 8, Bluetooth Link Serial Port* on page 42 and *Figure 9, Add a device - Successful* on page 42.

Figure 8: Bluetooth Link Serial Port**Figure 9: Add a device - Successful**

On some operating systems, the SMART6 must be re-paired every time it is restarted. To re-pair in Windows 7, click the Bluetooth icon in the notification area and enter the pairing code when prompted. For instructions on re-pairing in other operating systems, see the user documentation that came with the operating system.

5.3 Determining the Bluetooth Serial Port

To determine the serial port associated with the Bluetooth link to the SMART6:

1. Double-click the *Bluetooth* icon in the notification area, see *Figure 10* on page 42. The *Bluetooth Devices* window opens, see *Figure 11* on page 43.



Figure 10: Bluetooth Icon

Figure 11: Bluetooth Devices Window



2. In the *Bluetooth Devices* window, right-click the SMART6 device and select *Properties*, see *Figure 12* on page 44.
The Properties window for the SMART6 appears, see *Figure 13* on page 44.

Figure 12: Bluetooth Devices Window - Device Menu






Figure 13: Bluetooth Devices Window - Properties



3. Click the *Services* tab. The Services tab displays the serial port information about the Bluetooth link to the SMART6. See *Figure 14* on page 45.

Figure 14: Properties - Services Tab



5.4 Communicate with the SMART6 Using *Bluetooth* Wireless Technology

1. Open a terminal program (HyperTerminal, for example) and configure it to the serial port assigned to the Bluetooth link. If you do not know the serial port information, see *Section 5.3, Determining the Bluetooth Serial Port* on page 42.
2. Configure the port settings as follows:
9600 bps, no parity, 8 data bits, 1 stop bit, no handshaking, echo off
3. Through the terminal program, connect to the Bluetooth serial port and verify the connection.
4. Type the following VERSION log request into the command prompt to ensure that the connection works:

```
log version
```

A.1 SMART6 Receiver Performance

PERFORMANCE ^a			
Channel Configuration	120 Channels can be configured to track: L1 GPS L2 GPS (optional) L2C GPS (optional) L1 GLONASS (optional) L2 GLONASS (optional) Galileo E1 (optional) BeiDou B1 (optional) SBAS ^b		
Horizontal Position Accuracy (RMS) ^c	Single Point	1.5 m	
	Single Point L1/L2	1.2 m	
	SBAS ^c	0.6 m	
	DGPS	0.4 m	
	RT-2™	1 cm + 1 ppm	
Measurement Precision (RMS)		GPS	GLO
	L1 C/A code	4 cm	8 cm
	L1 carrier phase	0.5 mm	1 mm
	L2 P(Y) code ^d	8 cm	8 cm
	L2 carrier phase ^d	1 mm	1 mm
	L2C code ^e	8 cm	8 cm
	L2C carrier phase ^e	0.5 mm	0.5 mm
Maximum Data Rate ^f	Measurements	up to 50 Hz	
	Position	up to 50 Hz	
Time to First Fix	Cold Start ^g	<50 s	
	Hot Start ^h	<35 s	
Signal Reacquisition	L1	0.5 s (typical)	
	L2	1.0 s (typical)	
Time Accuracy	20 ns RMS		
Velocity Accuracy ⁱ	0.03 m/s RMS		

a. Typical values. Performance specifications subject to GPS system characteristics, US DOD operational degradation, ionospheric and tropospheric conditions, satellite geometry, baseline length, multipath effects and the presence of intentional or unintentional interference sources.

b. Satellite Based Augmentation Systems (SBAS) include WAAS (North America), EGNOS (Europe) and MSAS (Japan).

c. GPS only.

d. L2 P for GLONASS.

e. L2 C/A for GLONASS.

f. Model specific.

g. Typical value. No almanac or ephemerides and no approximate position or time.

h. Typical value. Almanac and recent ephemerides saved and approximate time entered. For more information, refer to the "SETAPPROXTIME" command in the [OEM6 Family Firmware Reference Manual](#) found on our web site at www.novatel.com/support/firmware-software-and-manuals/product-manuals-and-doc-updates/.

i. Export licensing restricts operation to a maximum velocity of 515 metres per second.

A.2 SMART6 Specifications

INPUT/OUTPUT CONNECTORS	
SMART6 Communication/Power	+8 to +36 V DC at 2.9 W ^a For the cable pinouts and drawings, see <i>Section A.2.1, SMART6 Communication/Power Cable (01018999)</i> on page 49
Serial Com Ports	RS-232 F Compliant (Rx and Tx signals only)
CAN	SAE J1939/ ISO 11783/ ISO 11898 Compatible
Emulated Radar Output	High = Supply Voltage -0.5V Minimum Low = 0.5V Maximum Load = 3K Ohm Minimum
PPS Output	3.3 V CMOS Logic Compatible
MKI Input	3.3 V CMOS Logic/5 V Tolerant
INPUT/ OUTPUT CONNECTOR PROTECTION	
Electrical Conducted/ Coupled disturbance tolerance	ISO 7637-2:2004 Functional Class A: Pulses 2a, 3a, 3b, 4 Functional Class C: Pulses 1, 2b
LED INDICATORS	
Power, Error and Position Valid	Refer to <i>Section 2.2.1, Status Indicators</i> on page 18 for details
PHYSICAL	
Size	80.9 x ϕ 155 mm ^b
Weight	<550 g
Mounting	2 x magnetic mount
	4 x M4 screw inserts
	Optional mounting plate
ENVIRONMENTAL ^c	
Operating Temperature	-40°C to +75°C
Storage Temperature	-55°C to +90°C
Humidity	Not to exceed 95% non-condensing
Immersion	MIL-STD-810G Method 512.5 Procedure 1
Shock	MIL-STD-810G Method 516.6
Solar Radiation	EN60950-22 8.2 MIL-STD-810G Method 505.5
Salt Fog	MIL-STD-810G, 509.5
Sand and Dust	MIL-STD-810G, 510.5
ENVIRONMENTAL ^c	
Vibration	Random: MIL-STD-810G, Method 514.6E-I Sinusoidal: IE 68-2-6 ASAE ER455, 5.15.2 Level 1
Compliance	FCC, IC, CE
Ingress Protection Rating	IP67

a. Power consumption values for GPS L1/L2.

b. ϕ denotes diameter, here and in the *Dimensions* graphic on page 48.

c. See also the *Notice* section of this manual starting on page 9.

A.2.1 SMART6 Communication/Power Cable (01018999)

The SMART6 cable (refer to *Figure 18, SMART6 Communication/Power Cable*), provides a means of supplying power from a battery while operating in the field. The exposed wires (red for positive and black for negative) can then be connected to a vehicular power circuit (or equivalent) protected by a 5 A fast blow fuse (user supplied). The cable has three DB-9 connectors to accommodate a computer serial (RS-232) communication port, a modem or radio transmitter to propagate differential corrections (refer to the user supplied modem or radio transmitter user guide for information on its connectors).



Bluetooth wireless technology uses the COM3 port. When Bluetooth wireless technology is enabled, COM3 is not available on the SMART6 connector or the cable.

In addition, there are a number of bare wires where the outer insulation is cut away but the wires beneath remain intact. See *Table 5, SMART6 Communication/Power Cable Pinouts* on page 50 for their pinouts. For more information on mating connectors and part numbers, see *Table 6, SMART6 Mating Connectors* on page 51.

This cable is RoHS compliant.

Figure 18: SMART6 Communication/Power Cable




Table 5: SMART6 Communication/Power Cable Pinouts

Signal Name	J1	J2	J3	J4	Label
COM1_TXD	1	2			
COM1_RXD	2	3			
COM2_TXD	3		2		
COM2_RXD	4		3		
COM3_TXD	8			2	
COM3_RXD	13			3	
COM1 GND	5	5			
COM2 GND			5		
COM3 GND				5	
MKI GND					MKI GND
Emulated Radar GND					ER GND
Pulse Per Second GND					PPS GND
CAN+		6			
CAN-	7				CANI-
PWR RET (GND)	9				BATT-
Emulated Radar Out	10				ER_OUT
EVENT MARK IN	11				MKI
PPS	12				PPS
PWR INPUT	14				BATT+

A.2.2 SMART6 Connector and Cable Requirements

Custom cables for installing the SMART6 can be created using the following guidelines:

- Wire size: must be 0.5 mm-1.25 mm (20-16 AWG)
- Batt+ connection must be protected by 5 A fast blow fuse
- Serial data signals (TxD, RxD, signal ground) must be run in shielded cable. Connect shields to ground at SMART6 end only
- CAN signal conductors must be twisted (40 twists/m, 12 twists/ft)
- Use only the recommended mating connectors listed below. Use only gold plated pins



Failure to observe the given cable construction guidelines and fusing requirements in this section may result in damage to the wiring or equipment and voiding the warranty.



NovAtel recommends tying to ground any floating input lines.

The connector used in the SMART6 is an “AMPSEAL” dust and water sealed type produced by Tyco. The following part numbers pertain to the mating connector required to make connections to the SMART6. These numbers are provided for information only and are not available from NovAtel as separate parts.

Table 6: SMART6 Mating Connectors

Product	Part Description	Company	Part Number
SMART6 mating connector (J1 - <i>Figure 18</i> on <i>page 49</i>)	14-pin sealed receptacle housing-black	Tyco/AMP	776273-1
Gold plated pins (20-16 AWG) for (J1) SMART6 connector Gold plated pins for SMART6 connector/strip	Pins, loose piece	Tyco/AMP	770854-3
	Pins, strip (reel)	Tyco/AMP	770520-3
Seal Plug for unused pins on mating connector. (All connector positions must be populated with a pin or seal plug to achieve the IP-67 rating for the cable connection.)	Seal plug	Tyco/AMP	770678-1

Table 7 details the part numbers for recommended fuses and fuse holders. These numbers are provided for information only and are not available from NovAtel as separate parts.

Table 7: Recommended Fuse and Fuse Holders

Fuse	Recommended Fuse/Fuse Holder		
12 V System Fuse (standard size blade)	ATO Silver Blade Fuse 5 A (32 V)	Littelfuse	0287005
	Or Equivalent		
12 V System Fuse (mini size blade)	Mini Blade Fuse 5 A (32 V)	Littelfuse	0297005
	Or Equivalent		
12 V System Fuse High Reliability, Harsh Environment (standard size blade)	FKS ATO Blade Fuse 5A (80 V)	Littelfuse	166.7000.450
	Or Equivalent		
Inline Fuse Holder, (for standard size blade)	Waterproof ATO Fuse Holder	Littelfuse	FHAC0001
	Or Equivalent		
Inline Fuse Holder, (for mini size blade)	Waterproof Mini Fuse Holder	Littelfuse	0FHM0001
	Or Equivalent		

The SMART6 firmware implements the OEM6 family command set, documented in the [OEM6 Family Firmware Reference Manual](#). Commonly used SMART6 commands are summarized in *Table 8, SMART6 Commands* and documented in this appendix.

Table 8: SMART6 Commands

ASCII Command	Message ID	Description
BTCONTROL	8205	Enable or disable Bluetooth wireless technology.
COM	4	Configure the receiver serial port.
FRESET	20	Factory reset (existing OEM6 commands extended to SMART6)
LOG	1	Request logs from the receiver
\$PMDT	8200	Configure the Tilt Compensation function (SMART6 command)
RADARCFG	8192	Configure the Emulated Radar signal output (SMART6 command)
SETCANNNAME	1091	Set the CAN name fields.

The arguments for each of these commands are described in the following sections.

For a complete listing and description of the other commands that the SMART6, an OEM6 based receiver, is capable of processing, refer to the [OEM6 Family Firmware Reference Manual](#).

B.1 SYNTAX CONVENTIONS

The following rules apply when entering commands, at the command prompt, from a keyboard.

1. Courier font is used to illustrate program output or user input.
2. References to other commands, logs or any of their fields are shown in *italics*.
3. The commands are not case sensitive. For example, you could type either `RESET` or `reset`.
4. Except where noted, either a space or a comma can separate commands and their required entries. For example, you could type either `fix position 51.11358042 -114.04358013 1059.4105` or `fix position 51.11358042, -114.04358013, 1059.4105`.
5. At the end of a command, a carriage return is required. For example, press <Enter> or <Return> on your keyboard.
6. Responses are provided to indicate whether or not an entered command was accepted. The format of the response depends on the format of the command. Refer to the [OEM6 Family Firmware Reference Manual](#) for more information.
7. Optional parameters are indicated by square brackets ([]). For commands that contain optional parameters, the value used if the optional parameter is not specified is given in the syntax table for the command.
8. Data format definitions, as specified in the “Format” field, are detailed in the [OEM6 Family Firmware Reference Manual](#). Note that all binary data is little-endian byte-ordered.

B.2 BTCONTROL Enable/Disable Bluetooth wireless technology

The BTCONTROL command enables or disables the Bluetooth module. To ensure no possibility of interference, when the module is disabled it is completely powered down.

Message ID: 8205

Abbreviated ASCII Syntax:

```
BTCONTROL switch
```

Factory Default:

The *Bluetooth* module is enabled by default.

Example 1 to disable Bluetooth wireless technology:

```
btcontrol disable
```

Example 2 to enable Bluetooth wireless technology:

```
btcontrol enable
```

Field	Data	Description	Binary Bytes	Binary Format	Binary Offset
1	BTCONTROL header	This field contains the command name or the message header depending on whether the command is abbreviated ASCII, ASCII or binary.	-	-	0
2	switch	Enable or disable <i>Bluetooth</i> wireless technology 0 = ENABLE 1 = DISABLE (default = ENABLE)	4	Enum	H



1. To enable the current state of the Bluetooth module to persist across receiver resets and power-ups, issue a *SAVECONFIG* command.
2. Changing the Bluetooth wireless technology from disabled to enabled takes several seconds to execute. This means that, even though the user will get an immediate "OK>" response followed by the COM prompt, the Bluetooth module may not be ready for communication.

B.3 COM Configure COM Port

This command is used to configure the receiver's serial ports.

The current COM port configuration can be reset to the default state at any time by sending two hardware break signals of 250 milliseconds each, spaced by fifteen hundred milliseconds (1.5 seconds), with a pause of at least 250 milliseconds following the second break. This will:

- Stop the logging of data on the current port (see `UNLOGALL` command in the [OEM6 Family Firmware Reference Manual](#)).
- Clear the transmit and receive buffers on the current port.
- Return the current port to its default settings.
- Set the interface mode to NovAtel for both input and output (see `INTERFACEMODE` command in the [OEM6 Family Firmware Reference Manual](#)).



Baud rates higher than 115,200 bps are not supported by standard computer hardware. Special computer hardware may be required for higher rates, including 230400 bps, 460800 bps and 921600 bps. Also, some computers have trouble with baud rates beyond 57600 bps.

Message ID: 4

Abbreviated ASCII Syntax

```
COM [port] bps [parity[ databits [stopbits [handshake [echo [break]]]]]]]
```

Factory Default:

```
COM COM1 9600 N 8 1 N OFF ON
COM COM2 9600 N 8 1 N OFF ON
COM COM3 9600 N 8 1 N OFF ON
```



On SMART6 receivers with Bluetooth wireless technology, the default settings for COM3 are:

```
com3 115200 n 8 1 cts off off
```

Changing the COM3 serial port settings could interfere with the ability to communicate using Bluetooth.

ASCII Example:

```
COM COM1 57600 N 8 1 N OFF ON
```



Use the COM command before using the `INTERFACEMODE` command on each port.



Watch for situations where the COM ports of two receivers are connected together and the baud rates do not match. Data transmitted through a port operating at a slower baud rate may be misinterpreted as break signals by the receiving port if it is operating at a higher baud rate.

This is because data transmitted at the lower baud rate is stretched relative to the higher baud rate. In this case, configure the receiving port to have break detection disabled using the COM command.

Field	Field Type	ASCII Value	Binary Value	Description	Binary Format	Binary Bytes	Binary Offset
1	COM header	-	-	This field contains the command name or the message header depending on whether the command is abbreviated ASCII, ASCII or binary.	-	H	0
2	port	1	COM1	Select COM port 1 to configure	Enum	4	H
		2	COM2	Select COM port 2 to configure			
		3	COM3	Select COM port 3 to configure			
		6	THISPORT	Select the current COM port (default)			
		8	ALL	Select all COM ports			
3	bps/ baud	300, 600, 900, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, or 230400		Communication baud rate (bps). Bauds of 460800 and 921600 are also available on COM1 of OEM6 based products	ULong	4	H+4
4	parity	N	0	No parity (default)	Enum	4	H+8
		E	1	Even parity			
		O	2	Odd parity			
5	databits	7 or 8		Number of data bits (default = 8)	ULong	4	H+12
6	stopbits	1 or 2		Number of stop bits (default = 1)	ULong	4	H+16
7	handshake	N	0	No handshaking (default)	Enum	4	H+20
		XON	1	XON/XOFF software handshaking			
8	echo	OFF	0	No echo (default)	Enum	4	H+24
		ON	1	Transmit any input characters as they are received			
9	break	OFF	0	Disable break detection	Enum	4	H+28
		ON	1	Enable break detection (default)			

B.4 FRESET Clear Selected Data from NVM and Reset

This command clears data that is stored in non-volatile memory. Such data includes the almanac, ephemeris and any user specific configurations. The commands, ephemeris and almanac related data can be cleared by using the `STANDARD` target. The model can only be cleared by using the `MODEL` target. The receiver is forced to hardware reset. In addition, values entered using the `CLOCKCALIBRATE` command can only be cleared by using the `CLKCALIBRATION` target.

Issuing the `FRESET` command affects Tilt as follows:

- Tilt sensor level is restored to the factory default
- Tilt enable/disable is not be affected



`FRESET STANDARD` (which is also the default) causes any commands, ephemeris, GNSS and almanac data previously saved to NVM to be erased.

Message ID: 20

Abbreviated ASCII Syntax:

```
FRESET [target]
```

Input Example:

```
FRESET COMMAND
```



If you are receiving no data or random data from your receiver, try the following before contacting NovAtel:

- Verify that the receiver is tracking satellites
- Check the integrity and connectivity of power and data cables
- Verify the baud rate settings of the receiver and terminal device (your computer or data logger)
- Switch COM ports
- Issue a `FRESET` command

Field	Field Type	ASCII Value	Binary Value	Description	Binary Format	Binary Bytes	Binary Offset
1	FRESET header	-	-	This field contains the command name or the message header depending on whether the command is abbreviated ASCII, ASCII or binary.	-	H	0
2	target	See Table 9, <i>FRESET Target</i> on Page 57		What data is to be reset by the receiver. (default=STANDARD)	Enum	4	H

Table 9: FRESET Target

Binary	ASCII	Description
0	STANDARD	Resets commands, ephemeris and almanac (default).
1	COMMAND	Resets the stored commands (saved configuration)
2	GPSALMANAC	Resets the stored GPS almanac
3	GPSEPHEM	Resets the stored GPS ephemeris
4	GLOEPHEM	Resets the stored GLONASS ephemeris
5	MODEL	Resets the currently selected model
10	USERDATA	Resets SMART6 only commands
11	CLKCALIBRATION	Resets the parameters entered using the <code>CLOCKCALIBRATE</code> command
20	SBASALMANAC	Resets the stored SBAS almanac
21	LAST_POSITION	Resets the position using the last stored position
31	GLOALMANAC	Resets the stored GLONASS almanac
52	PROFILEINFO	Resets the stored profile configurations

B.5 LOG Request Logs from the Receiver

Many different types of data can be logged using several different methods of triggering the log events. Every log element can be directed to any combination of the three COM ports. The ONTIME trigger option requires the addition of the *period* parameter. See the [OEM6 Family Firmware Reference Manual](#) for further information and a complete list of data log structures. The LOG command tables in this section show the ASCII command format.

The optional parameter [hold] prevents a log from being removed when the `unlogall` command, with its defaults, is issued. To remove a log that was invoked using the [hold] parameter requires the specific use of the `unlog` command. To remove all logs that have the [hold] parameter, use the `UNLOGALL` command with the *held* field set to 1.

The [port] parameter is optional. If [port] is not specified, [port] is defaulted to the port that the command was received on.



1. The OEM6 family of receivers can handle 64 logs at a time. If it is more than 64 logs at a time, the receiver responds with an Insufficient Resources error.
2. Maximum flexibility for logging data is provided to the user by these logs. The user is cautioned, however, to recognize that each log requested requires additional CPU time and memory buffer space. Too many logs may result in lost data and degraded CPU performance. Receiver overload can be monitored using the idle time field and buffer overload bits of the Receiver Status in any log header.
3. Polled log types do not allow fractional offsets or ONTIME rates faster than 1 Hz.
4. Use the ONNEW trigger with the MARKTIME or MARKPOS logs.
5. Only the MARKPOS or MARKTIME logs and 'polled' log types are generated, on the fly, at the exact time of the mark. Synchronous and asynchronous logs output the most recently available data.
6. If the ONTIME trigger is used with asynchronous logs, the time stamp in the log does not necessarily represent the time the data was generated but rather the time when the log is transmitted.

Message ID: 1

Abbreviated ASCII Syntax:

```
LOG [port] message [trigger [period [offset [hold]]]]
```

Abbreviated ASCII Example 1:

```
LOG COM1 BESTPOS ONTIME 7 0.5 HOLD
```

The above example shows BESTPOS logging to COM port 1 at 7 second intervals and offset by 0.5 seconds (output at 0.5, 7.5, 14.5 seconds and so on). The [hold] parameter is set so logging is not disrupted by the `unlogall` command.

To send a log only one time, the trigger option can be ignored.

Abbreviated ASCII Example 2:

```
LOG COM1 BESTPOS ONCE 0.000000 0.000000 NOHOLD
```

Refer to the *Command Formats* section of the [OEM6 Family Firmware Reference Manual](#) for additional examples.



1. In NovAtel Connect there are two ways to initiate data logging to the receiver's serial ports:
 - the LOG command in the *Console* window or
 - use the interface provided in the *Logging Control* window.
2. Only the ASCII/Abbreviated ASCII log table is included in this manual. Refer to the LOG command in the [OEM6 Family Firmware Reference Manual](#) for binary log details.

Factory Default:

```

LOG COM1 RXSTATUSEVENTA ONNEW 0 0 HOLD
LOG COM2 RXSTATUSEVENTA ONNEW 0 0 HOLD
LOG COM3 RXSTATUSEVENTA ONNEW 0 0 HOLD

```

Field	Field Name	ASCII Value	Description	Field Type
1	LOG (ASCII) header	-	This field contains the command name or the message header depending on whether the command is abbreviated ASCII or ASCII respectively	-
2	port	See Table 10, Detailed Serial Port Identifiers on page 60	Output port (default = THISPORT)	Enum
3	message	Any valid message name, with an optional A or B suffix	Message name of log to output	Char []
4	trigger	ONNEW	Output when the message is updated (not necessarily changed)	Enum
		ONCHANGED	Output when the message is changed	
		ONTIME	Output on a time interval	
		ONNEXT	Output only the next message	
		ONCE	Output only the current message (default)	
		ONMARK	Output when a pulse is detected on the mark 1 input, MK11	
5	period	Any positive double value larger than the receiver's minimum raw measurement period	Log period (for ONTIME trigger) in seconds (default = 0)	Double
6	offset	Any positive double value smaller than the period	Offset for period (ONTIME trigger) in seconds. To log data at 1 second after every minute, set the period to 60 and the offset to 1 (default = 0)	Double
7	hold	NOHOLD	Allow log to be removed by the UNLOGALL command (default)	Enum
		HOLD	Prevent log from being removed by the UNLOGALL command	

Table 10: Detailed Serial Port Identifiers

ASCII Port Name	Hex Port Value	Decimal Port Value ^a	Description
NO_PORTS	0	0	No ports specified
COM1_ALL	1	1	All virtual ports for COM port 1
COM2_ALL	2	2	All virtual ports for COM port 2
COM3_ALL	3	3	All virtual ports for COM port 3
THISPORT_ALL	6	6	All virtual ports for the current port
ALL_PORTS	8	8	All virtual ports for all ports
XCOM1_ALL	9	9	All virtual COM1 ports
XCOM2_ALL	10	10	All virtual COM2 ports
XCOM3_ALL	11	17	All virtual COM3 ports
COM1	20	32	COM port 1, virtual port 0
COM1_1	21	33	COM port 1, virtual port 1
...			
COM1_31	3f	63	COM port 1, virtual port 31
COM2	40	64	COM port 2, virtual port 0
...			
COM2_31	5f	95	COM port 2, virtual port 31
COM3	60	96	COM port 3, virtual port 0
...			
COM3_31	7f	127	COM port 3, virtual port 31
THISPORT	c0	192	Current COM port, virtual port 0
THISPORT_31	df	223	Current COM port, virtual port 31
XCOM1	1a0	416	Virtual COM1 port, virtual port 0
XCOM1_1	1a1	417	Virtual COM1 port, virtual port 1
...			
XCOM1_31	1bf	447	Virtual COM1 port, virtual port 31
XCOM2	2a0	672	Virtual COM2 port, virtual port 0
XCOM2_1	2a1	673	Virtual COM2 port, virtual port 1
...			
XCOM2_31	2bf	703	Virtual COM2 port, virtual port 31
...			
XCOM3	9a0	2464	Virtual COM3 port, virtual port 0
...			
XCOM3_31	9bf	2495	Virtual COM3 port, virtual port 31

a. Decimal port values 0 through 16 are only available to the UNLOGALL command and cannot be used in the UNLOG command or in the binary message header.



For detailed information on virtual ports, refer to the LOG command in the [OEM6 Family Firmware Reference Manual](#).

B.6 \$PMDT Configure Tilt Compensation

Use this NMEA command to configure the Tilt Compensation function.

Syntax

\$PMDT, [command], [parameters]*cksum

Host	Description	Command Format	Tilt Sensor Response
u ^{a b}	Set GPS Sensor Height	To set the GNSS sensor height in feet and inches: \$PMDT,u,,ff,ii*cksum crlf Example: To set the GNSS sensor height to 12 ft 6 in, the command is: \$PMDT,u,,12,6*40 Note: Feet and inches are entered as integers. You can enter feet and inches, but not feet, inches and metres.	Response to the "u" command: \$PMDT,<,GNSS sensor height (inches):nnnnn crlf where nnnnn is a five digit integer, sensor height in inches. In this example, the Tilt Sensor response is: \$PMDT,<,GNSS sensor height (inches): 00150
		To set the GNSS sensor height in metres: \$PMDT,u,,,mmm.mmm*cksum crlf Example: To set the GNSS sensor height to 3.5 metres, the command is: \$PMDT,u,,,3.5*7C	Response to the "u" command: \$PMDT,<,GNSS sensor height (inches):nnnnn crlf where nnnnn is a five digit integer, sensor height in inches. In this example, the Tilt Sensor response is: \$PMDT,<,GNSS sensor height (inches): 00137
I	Set Field Level	\$PMDT,I*cksum crlf Example: \$PMDT,I*4D	Response to the "I" command: \$PMDT,<,Level state set crlf Example: \$PMDT,<,Level state set
x	Update Flash Values	To update flash values (needs to follow any height or level command that is not done each time you power up): \$PMDT,x*cksum crlf Example: \$PMDT,x*59	Response to the "x" command: \$PMDT,<,Flash updated crlf Example: \$PMDT,<,Flash updated

a. If all fields in the u command are zero or null, the current height is transmitted without change (with the format shown above).

b. If an invalid entry is received (>500 inches), the response is:

\$PMDT,<Max legal height exceeded: nnnnn and will be ignored clrf

For example, if you enter 42 ft 6 in, you will get the following response:

\$PMDT,<,Max legal height exceeded: 00510 and will be ignored

\$PMDT,<,GPS sensor height (inches): 00150

Refer to *Tilt Compensation* on page 19 and *Tilt Compensation* on page 30 for setup instructions.

B.7 RADARCFG Configure the ER Output

Use this command to configure the Emulated Radar (ER) output. ER is available through the SMART6 interface cable, see *Table 5, SMART6 Communication/Power Cable Pinouts* on page 50 for pin-out details.

Message ID: 8192

Syntax

```
radarcfg switch freq_step update_rate resp_mode threshold
```

Field	Data	Description	Bytes	Format	Units	Offset
1	Header	This field contains the command name or the message header depending on whether the command is abbreviated ASCII, ASCII or binary.		-	-	0
2	switch	Enable or disable radar emulation 0 = ENABLE 1 = DISABLE (default = enable)	4	Enum	none	H
3	freq_step	Frequency step per kilometer per hour. Range: 26.11, 28.12 or 36.11 (default = 36.11)	8	Double	Hz/kph	H+4
4	update_rate	Specify how often to update radar output Range: 1, 2, 5, 10, 20 (default = 10) ^a	4	Integer	Hz	H+12
5	resp_mode	Specify the time response mode, over which to average velocity samples, see <i>Table 11, Response Modes</i> . (Default = 500) ^a	4	Integer	none	H+16
6	threshold	The threshold is only applicable when the response mode is set to 2. The response time is 1000 ms when the velocity is greater than this value, otherwise, it is 500 ms. Range: 2-50 kph (default = 5 kph)	8	Double	kph	H+20

- a. The number of samples used for smoothing depends on both the update_rate and resp_mode parameters. For instance, if the update_rate is 5 Hz and the resp_mode is 2000ms, the number of samples used will be 10.

Table 11: Response Modes

Mode	Description
2000	2000 ms
1000	1000 ms
500	500 ms (default)
2	Automatically switches between 1000 and 500 ms
1	Performs no smoothing

Example 1 to disable radar emulation: `radarcfg disable 26.11 1 1 2`

Example 2 to set the frequency step to 36.11 Hz/kph, update rate to 1 Hz and no smoothing: `radarcfg enable 36.11 1 1 2`

B.8 SETCANNAME Sets the CAN name fields

This command sets the CAN device name fields.

Message ID: 1091

Abbreviated ASCII Syntax:

```
setcanname ManufacturerCode IndustryGroup DeviceClass DeviceClassInstance Function FunctionInstance
ECUInstance PreferredAddress
```

Factory Default:

```
setcanname 305 2 0 0 23 0 0 28 can2
```

Field	Field Type	ASCII Value	Binary Value	Description	Binary Format	Binary Bytes	Binary Offset
1	SETCANNAME header	-	-	This field contains the command name or the message header depending on whether the command is abbreviated ASCII, ASCII or binary.	-	H	0
2	ManufacturerCode			CAN module's Manufacturer Code	ULong	4	H
3	IndustryGroup			Industry group number (default = 2)	ULong	4	H+4
4	DeviceClass			11783-5 Device class (default = 0)	ULong	4	H+8
5	DeviceClassInstance			11783-5 Device class instance (default = 0)	ULong	4	H+12
6	Function			11783-5 Function (default = 23)	ULong	4	H+16
7	FunctionInstance			11783-5 Function instance (default = 0)	ULong	4	H+20
8	ECUInstance			11783-5 ECU Instance (default = 0)	ULong	4	H+24
9	PreferredAddress			Device default address on start up (default=28)	ULong	4	H+28
10	CanPort			CAN port to use (default = can2) Note: This field must be set to can2.	ULong	4	H+32

C.1 Position Logs

C.1.1 NMEA Logs

The NMEA logs (receiver outputs) supported by the SMART6 are summarized in Chapter 3 of the [OEM6 Family Firmware Reference Manual](#) in section "NMEA Standard Logs". The available logs include:

- GPGGA, which outputs a log of position system fix data and undulation. There are variants of GPGGA, specifically:
 - GPGGARTK, which has greater precision than GPGGA but with the loss of the undulation field
 - GPGGALONG, which has both greater precision and the undulation field
- GPVTG, which outputs track made good and ground speed

Each of the available NMEA standard logs is described in more detail in its own section of Chapter 3 of the [OEM6 Family Firmware Reference Manual](#).

The steps for configuring the receiver output, through the command line are:

1. Configure the communication port using the COM command, described in *Section B.3, COM Configure COM Port* on page 54. To set COM port 2 as follows:

Bit Rate	9600
Parity	none
Data Bits	8
Stop Bits	1
Handshaking	None
Echo	Off
Break	On

enter the following string:

```
com com2 9600 n 8 1 n off on
```

2. Select and configure the NMEA string to output. The information is described in Chapter 3 Data Logs of the [OEM6 Family Firmware Reference Manual](#), in the section for the particular log. For example, to log gpgga (position system fix data and undulation) at 2 Hz, enter the following string:

```
log gpgga ontime 0.5
```

You can configure the log to output at various frequencies, as described in *LOG Request Logs from the Receiver* on page 58.

The above command line operations can also be carried out through NovAtel Connect. Information about configuring the communication port can be found in NovAtel Connect online help. The procedure for adding a NMEA log through NovAtel Connect is summarized as follows:

1. In the **Logging control** window, click *Logging to one or more of the receiver's serial ports*. The **Add Log** window displays.
2. Beside **Select list**, select *Complete List* or *NMEA List*.
3. Beside **Log to file**, select the NMEA log you want to add.
4. Select the port.
5. Configure the remaining fields then click *Add*.

C.1.2 NovAtel Position Logs

In addition to NMEA logs, NovAtel supports a range of non-NMEA position logs, described in the [OEM6 Family Firmware Reference Manual](#), including:

- BESTPOS: This log contains the best available position computed by the receiver, for example:
`log bestposa ontime 0.5`
- BESTXYZ: This log contains the receiver's best available position and velocity in ECEF coordinates, for example:

```
log bestxyza ontime 1
```

C.2 Other Logs

The SMART6 firmware generates the logs in *Table 12, SMART6 Logs in Alphabetical Order*, in addition to those of the OEM6 Family log set. Refer to the *OEM6 Family Firmware Reference Manual*, which also contains procedures and explanations related to data logging and is available from our web site at: www.novatel.com/support/firmware-software-and-manuals/product-manuals-and-doc-updates/

Table 12: SMART6 Logs in Alphabetical Order

Message ID	ASCII Log	Description
8193	RADARSIGNAL	Radar signal and position information (New SMART6 log)
37	VERSION	Hardware versions, software versions, and serial numbers (Existing OEM6 log extended to SMART6)

C.2.1 RADARSIGNAL ER Signal and Position Information

This log contains position and Emulated Radar (ER) signal information.

Message ID: 8193

Log Type: Asynch

Recommended Input:

```
log radarsignala onchanged
```

ASCII Example 1 (stationary SMART6):

```
#radarsignala,com1,0,61.5,finesteering,1501,248381.628,00000000,8a1c,3723  
;sol_computed,waas,0.0139,0.00,0.00*f0d580ca
```

ASCII Example 2 (moving SMART6):

```
#radarsignala,com1,0,42.5,finesteering,1428,206179.600,00000000,baa8,3349  
;sol_computed,waas,0.3315,2,0.3152,473.97,29.62*c1479c20
```

Field #	Field type	Data Description	Format	Binary Bytes	Binary Offset
1	RADARSIGNAL header	Log header		H	0
2	sol status	Solution status, see <i>Table 14, Solution Status</i> on page 67	Enum	4	H
3	vel type	Velocity type, see <i>Table 13, Position or Velocity Type</i> on page 67	Enum	4	H+4
4	speed	Speed over ground (m/s)	Double	8	H+8
4	varf freq	External VARF output frequency (Hz)	Double	8	H+16
5	radar freq	Radar signal frequency (Hz) as output by the Emulated Radar Out signal. See <i>Section B.7, RADARCFG Configure the ER Output</i> on page 62.	Double	8	H+24
6	xxxx	32-bit CRC (ASCII and Binary only)	Hex	4	H+32
7	[CR][LF]	Sentence terminator (ASCII only)	-	-	-

Table 13: Position or Velocity Type

Type (binary)	Type (ASCII)	Description
0	NONE	No solution
1	FIXEDPOS	Position has been fixed by the FIX POSITION command
2	FIXEDHEIGHT	Position has been fixed by the FIX HEIGHT/AUTO command
8	DOPPLER_VELOCITY	Velocity computed using instantaneous Doppler
16	SINGLE	Single point position
17	PSRDIFF	Pseudorange differential solution
18	WAAS	Solution calculated using corrections from an SBAS
19	PROPAGATED	Propagated by a Kalman filter without new observations
32	L1_FLOAT	Floating L1 ambiguity solution
33	IONOFREE_FLOAT	Floating ionospheric-free ambiguity solution
34	NARROW_FLOAT	Floating narrow-lane ambiguity solution
48	L1_INT	Integer L1 ambiguity solution
49	WIDE_INT	Integer wide-lane ambiguity solution
50	NARROW_INT	Integer narrow-lane ambiguity solution

Table 14: Solution Status

Solution Status (Binary)	Solution Status (ASCII)	Description
0	SOL_COMPUTED	Solution computed
1	INSUFFICIENT_OBS	Insufficient observations
2	NO_CONVERGENCE	No convergence
3	SINGULARITY	Singularity at parameters matrix
4	COV_TRACE	Covariance trace exceeds maximum (trace > 1000 m)
5	TEST_DIST	Test distance exceeded (maximum of 3 rejections if distance > 10 km)
6	COLD_START	Not yet converged from cold start
7	V_H_LIMIT	Height or velocity limits exceeded (in accordance with export licensing restrictions)
8	VARIANCE	Variance exceeds limits
9	RESIDUALS	Residuals are too large
10	DELTA_POS	Delta position is too large
11	NEGATIVE_VAR	Negative variance
12	Reserved	
13	INTEGRITY_WARNING	Large residuals make position unreliable
14-17	Reserved for SPAN-capable receivers	
18	PENDING	When a FIX POSITION command is entered, the receiver computes its own position and determines if the fixed position is valid ^a
19	INVALID_FIX	The fixed position, entered using the FIX POSITION command, is not valid
20	UNAUTHORIZED	Position type is unauthorized - HP or XP on a receiver not authorized for it

- a. PENDING implies there are not enough satellites being tracked to verify if the FIX POSITION entered into the receiver is valid. The receiver needs to be tracking two or more GPS satellites to perform this check. Under normal conditions you should only see PENDING for a few seconds on power up before the GPS receiver has locked onto its first few satellites. If your antenna is obstructed (or not plugged in) and you have entered a FIX POSITION command, then you may see PENDING indefinitely.

C.2.2 TILT Compensation

Tilt Compensation affects existing logs as follows:

- NovAtel logs that provide the Extended Solution Status field (BESTPOS and BESTXYZ, both documented in *OEM6 Family Firmware Reference Manual*) use the 0x80 bit to flag the fact that Tilt Compensation is being applied.
- For NMEA GPGGA, GPGGARTK, and GPGGALONG logs, the precision of various fields indicates whether the Tilt Compensation is being applied.

C.2.3 VERSION HW and SW Versions and Serial Numbers

The Component Type of the VERSION log, refer to the [OEM6 Family Firmware Reference Manual](#), is extended to include SMART6 information as in *Table 15, Component Type*.

Table 15: Component Type

Binary Value ^a	ASCII Value	Description
0	UNKNOWN	Unknown Component
1	GPSCARD	OEM6 GPSCard Component
3	ENCLOSURE	SMART6 Receiver
8	USERINFO	User application information component
981073925 (0x3A7A0005)	DB_USERAPPAUTO	Auto-starting user application firmware

a. Unused numbers are reserved for future use.

```
[COM1]<VERSION COM1 0 85.0 FINESTEERING 1727 510341.712 00000000 3681 10985
< 1
< GPSCARD "D2LR0GTTR" "BFN12390111" "OEM628-1.01" "OEM060210RN0000"
"OEM060200RB0000" "2012/Sep/13" "13:46:16"
[COM1]
```

The following are lists of the replacement parts available for the NovAtel SMART6 receiver. Should assistance be required or you need to order additional components, contact your local NovAtel dealer or *Customer Service* representative.

D.1 SMART6

Table 16: SMART6 Product

Part Description	NovAtel Part
SMART6	01019123
SMART6 with Tilt	01019125
SMART6 with Bluetooth	01019121
SMART6 with Bluetooth and Tilt	01019127
Cable: 14-pin socket to 3 DB-9 connectors, twisted CAN I/O pair, and other bare wire connectors (see A.2.1 <i>SMART6 Communication/Power Cable (01018999)</i> on page 49)	01018999
Mounting Plate	70023072
Pole Mount Kit	01019142

D.2 User Manuals

Table 17: Reference User Manuals

Part Description	NovAtel Part
OEM6 Family Installation and Operation User Manual	OM-20000128
OEM6 Family Firmware Reference Manual	OM-20000129



The accessories above are also available from www.novatel.com

Index

Symbols

\$PMDT command 61, 63

A

accuracy

 position 24, 46

 velocity 46

almanac

 reset 56

antenna

 internal 11

 specifications 47

AUTH command 38

authorization 38

AUX port 60

B

base station 28

baseline 24

baud rate 22

baud rate, *see* bps

BESTPOS log 65

BESTXYZ log 65

bidirectional communication 22

bit rate, *see* bps

Bluetooth

 configuration 39

bps 55

break 54–55

BTCONTROL 53

buffer 22

C

cable

 integrity 56

 serial 22

CAN. *See* Controller Area Network

Caution 22

CDU software 58

CMR 28

cold start 46

COM command 54

COM port 58

command 52

 communication 22

 error message 24

 example 24

 interface 28

 multiple 28

 port 22

 pre-configure 26

 prompt 23

 RTK 28

commands

 in CDU 33

communication

 bidirectional 22

 Bluetooth 39

 CDU 23

 computer 22

 notice 7

 operation 22

 port 17, 22

 remote terminal 22

COMVOUT command 54

configuration

 additional equipment 13

 base station 26

 Bluetooth 39

 CDU 23

 non-volatile memory 56

 port 22, 54

 rover station 27

 RTK 28

configuring 31

connector

 mounting bracket 15

Controller Area Network 19

copyright 2

Customer Service 56

customer service 33

D

data

 Bluetooth 39

 format 52

 link 25

 log 58

 port 17, 22

 start 23

 storage device 25

 terminal 22

 Warning 24

dealer 33

default

 interface mode 28

 offset 59

 period 59

 port 22, 58–59

 trigger 59

differential

 configuration note 28

 corrections 24, 49

- operation 24
- serial cable 49
- setup 25

directional communication 22
distance exceeded 67

E

echo 55
Emulated Radar (ER) 62, 66

- operation 31

enable Bluetooth 39

F

factory default

- setting 54

features 11, 23, 33, 38
firmware updates 33–34, 38
FRESET command 58

G

GL1DE 29
GPGGA log 64
GPVTG log 64

H

handshaking 22, 55
hardware

- enclosure 11
- replace 69
- required 13
- setup 25

header 10
height limit 67
hexadecimal 10
hold 58–59

I

identifier, serial port 60
idle time 22
input

- command 23–24
- differential 26–27
- mark 59
- power 15
- syntax 52

interface

- base or rover 26–27
- Bluetooth 39
- communication 22
- serial 22

introduction 11

L

LED

- front 11

- power 14, 18

light emitting diode (LED), *see* LED
log 28, 58, 65
LOG command 58
logs

- tilt compensation 68

M

memory

- non-volatile
 - erase 56

message trigger 59
model 11
model upgrades 33–34

N

NMEA logs 64
non-volatile memory (NVM)

- reset 56

note

- reset 56

Notices 7
NovAtel Inc. 2
NovAtel position logs 65

O

operation 22
optionality 10
output

- convention 10
- log 58–59
- status 23
- syntax 52

P

parity 22, 55
PC Utilities 15
period 58–59
port

- COM 22–23, 28
- configuration 54
- identifier 55, 60
- interface mode 26–27
- log 58–59
- output 59
- prompt 23–24
- serial 22
- settings 22

position

- accuracy 24
- base 24, 26
- best 66
- command 24, 28

position logs 65
power 14–15

pseudorange 28

R

RADARCFG command 61, 63

RADARSIGNAL log 66

receiver outputs 64

replacement parts 69

reset

- FRESET command 23

- hardware 56

RESET command 61, 63

revision, firmware 1

rover station 28

RTCA 28

RTCM 26, 28

RTCMV3 26, 28

S

satellite 22

self-test 23

serial

- cable 22

- number 33

- port 28, 60

syntax 52

T

technical specifications 46

terrain compensation. See tilt compensation

tilt compensation 18–19, 31

- \$PMDT command 61, 63

- logs 68

- operation 31

time 59

transmit 55

trigger, log 58

U

update firmware 33–34, 38

upgrade firmware 32

upgrade models 33–34

V

velocity limit 67

version 38

W

Warning

- CE 8

- FCC 7

warranty 2

WinLoad 34

WRITE command/log 68

