

# **Industrial Device Server DS-11-W User's Manual**

**Version 1.0**

**October, 2007.**

# Table of Content

<b>1</b>	<b>GETTING TO KNOW YOUR DEVICE SERVER .....</b>	<b>2</b>
1.1	About the DS-11-W Serial Device Server .....	2
1.2	Software Features .....	2
1.3	Hardware Features .....	3
<b>2</b>	<b>HARDWARE INSTALLATION .....</b>	<b>4</b>
2.1	Install DS-11-W on DIN-Rail .....	4
2.1.1	MOUNT DS-11-W ON DIN-RAIL .....	4
2.2	Wall Mounting Installation .....	5
2.2.1	MOUNT DS-11-W ON WALL .....	5
<b>3</b>	<b>HARDWARE OVERVIEW .....</b>	<b>8</b>
3.1	Front Panel .....	8
3.2	Front Panel LEDs .....	9
3.3	Top Panel .....	9
3.4	Bottom Panel .....	10
3.5	Rear Panel .....	11
<b>4</b>	<b>CABLES .....</b>	<b>13</b>
4.1	Ethernet Cables .....	13
<b>5</b>	<b>MANAGEMENT INTERFACE .....</b>	<b>15</b>
5.1	DS-Tool .....	15
5.1.1	INSTALL DS-TOOL .....	15
5.1.2	USING DS-TOOL .....	16
5.1.2.1	Explore DS device servers .....	16
5.1.2.2	Configure DS device servers .....	17
5.1.2.3	Configure serial port .....	25
5.2	Configuration by Web Browser .....	32
5.2.1	CONNECT TO THE WEB PAGE .....	32
5.2.1.1	System .....	33
5.2.1.2	Port serial setting .....	36
5.2.1.3	Management .....	41
5.2.1.4	Save/Reboot .....	45
5.3	Configuration by SSH Console .....	46
5.3.1	CONNECT TO DS .....	46
<b>6</b>	<b>TECHNICAL SPECIFICATIONS .....</b>	<b>47</b>

# 1

## Getting to Know Your Device Server

### 1.1 About the DS-11-W Serial Device Server



DS-11-W is an innovative 1 port RS232/422/485 to 802.11b/g WLAN and 1 port LAN device server. Users are able to configure DS-11-W by DS-Tool via LAN port or WLAN interface, but not simultaneously. Once LAN port is activated, WLAN interface will enter standby mode to minimize power consumption. Secondly, DS-11-W can simultaneously transfer data into 5 host PCs. This feature can assure all critical data that saved in different host PCs to avoid ethernet break or host PCs failure. Thirdly, DS-11-W provides dual redundant power inputs both on DC power jack and terminal block. DS-11-W also provides NAT pass through function so that users are able to manage DS-11-W inside or outside NAT router. It is easy for different IP domain users to use the Switch. Therefore, DS-11-W is the best communication solution for wireless application of serial devices.

### 1.2 Software Features

- High Speed Air Connectivity: WLAN interface support up to 54Mbps link speed
- Highly Security Capability: WEP/WPA/WPA2/802.1X/Radius/TKIP supported
- NAT-pass through: User can manage DS-11-W through NAT router
- Redundant Power Inputs: 12~48VDC on power jack and terminal block
- Redundant multiple host devices: 5 simultaneous in Virtual COM, TCP Server, TCP Client mode, UDP
- Secured Management by HTTPS and SSH
- Versatile Modes: Virtual Com, Serial Tunnel, TCP Server, TCP Client, UDP
- Event Warning by Syslog, Email, SNMP trap, and Beeper

- Various Windows O.S. supported: Windows NT/2000/ XP/ 2003/VISTA

## 1.3 Hardware Features

- Redundant Power Inputs: 12~48 VDC on terminal block and power jack
- Operating Temperature: -10 to 55°C
- Storage Temperature: -20 to 85 °C
- Operating Humidity: 5% to 95%, non-condensing
- Casing: IP-30
- 1 10/100Base-T(X) Ethernet port
- Reverse SMA connector for 2.4GHz antenna
- Dimensions(W x D x H) : 72mm(W)x125 mm(D)x31mm(H)

# 2


## Hardware Installation

### 2.1 Install DS-11-W on DIN-Rail

Each DS-11-W has a Din-Rail kit on rear panel. The Din-Rail kit helps DS-11-W to fix on the Din-Rail. It is easy to install the DS-11-W on the Din-Rail:

#### 2.1.1 Mount DS-11-W on DIN-Rail

Step 1: Slant the DS-11-W and mount the metal spring to Din-Rail.



Step 2: Push the DS-11-W toward the Din-Rail until you heard a “click” sound.




## 2.2 Wall Mounting Installation

Each DS-11-W has another installation method. A wall mount panel can be found in the package. The following steps show how to mount the DS-11-W on the wall:

### 2.2.1 Mount DS-11-W on wall


Step 1: Remove Din-Rail kit.



Step 2: Use 3 screws that can be found in the package to combine the wall mount panel. Just like the picture shows below:



The screws specification shows in the following two pictures. In order to prevent DS-11-W from any damage, the size of screws should not be larger than the size that used in DS-11-W.



Step 3: Mount the combined DS-11-W on the wall.






# 3

## Hardware Overview

### 3.1 Front Panel



1. Product description of DS.
2. LED for PWR1 and system status. When the PWR1 links, the green led will be light on.
3. LED for PWR2 and system status. When the PWR2 links, the green led will be light on.

4. LED of 10/100Base-T(X) Ethernet port.
5. LED of 802.11b/g WLAN port.
6. LED of serial port. Green for transmitting, red for receiving

## 3.2 Front Panel LEDs


The following table describes the labels that stick on the DS.

LED	Color	Status	Description
<b>PWR1</b>	Green/Red	On	DC power 1 activated.
		Red blinking	Indicates an IP conflict, or DHCP or BOOTP server did not respond properly
<b>PWR2</b>	Green/Red	On	DC power 2 activated.
		Red blinking	Indicates an IP conflict, or DHCP or BOOTP server did not respond properly
<b>ETH</b>	Green/Amber	Green On/Blinking	100Mbps LNK/ACT
		Amber On/Blinking	10Mbps LNK/ACT
<b>WLAN</b>	Green/Amber	Green On/Blinking	WLAN LNK/ACT Signal good
		Amber On/Blinking	WLAN LNK/ACT Signal poor
<b>Serial</b>	Green	Blinking	Serial port is transmitting data
	Red	Blinking	Serial port is receiving data

## 3.3 Top Panel


The Top panel components of DS are showed as below:

1. Terminal block include: PWR1 (12 ~ 48V DC)
2. Power Jack include: PWR2 (12 ~ 48V DC)
3. RJ45 Ethernet Connector: 2 10/100Base-T(X) Ethernet interface.
4. Reverse SMA connector for 2.4GHz antenna




### 3.4 Bottom Panel

The bottom panel components of DS are showed as below:



1. Reset bottom. 5 seconds for factory default.
2. Male DB9 connector: Serial interface of RS-232/422/485 (2 wire)(4 wire).

**Pin Assignment**



Pin#	RS232	RS422	RS485(4 wire)	RS485(2 wire)
1	DCD	RXD-	RXD-	
2	RXD	RXD+	RXD+	
3	TXD	TXD+	TXD+	DATA+
4	DTR	TXD-	TXD-	DATA-
5	GND	GND	GND	GND
6	DSR			
7	RTS			
8	CTS			
9	RI			
RS232 mode act as DTE				


3. DIP Switch: Termination for RS-422/485

DIP1	DIP2	Termination Configuration
ON	ON	Termination for Long Distance 4-wire RS485/RS422
ON	OFF	Reserved
OFF	ON	Termination for Long Distance 2-wire RS485
OFF	OFF	No Termination for RS232/422/485(short distance)

### 3.5 Rear Panel

The rear panel components of DS are showed as below:

1. Screw holes for wall mount kit and DIN-Rail kit.
2. Din-Rail kit
3. Wall Mount Kit



# 4

## Cables

### 4.1 Ethernet Cables

The DS-11-W has standard Ethernet ports. According to the link type, the DS-11-W use CAT 3, 4, 5, 5e UTP cables to connect to any other network device (PCs, servers, switches, routers, or hubs). Please refer to the following table for cable specifications.

Cable Types and Specifications

Cable	Type	Max. Length	Connector
10BASE-T	Cat. 3, 4, 5 100-ohm	UTP 100 m (328 ft)	RJ-45
100BASE-TX	Cat. 5 100-ohm UTP	UTP 100 m (328 ft)	RJ-45

#### 100BASE-TX/10BASE-T Pin Assignments

With 100BASE-TX/10BASE-T cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 are used for receiving data.

RJ-45 Pin Assignments

Pin Number	Assignment
1	TD+
2	TD-
3	RD+
4	Not used
5	Not used
6	RD-
7	Not used
8	Not used

The DS supports auto MDI/MDI-X operation. You can use a straight-through cable to connect PC to DS-11-W. The following table below shows the 10BASE-T/ 100BASE-TX MDI and MDI-X port pin outs.

MDI/MDI-X pins assignment

Pin Number	MDI port	MDI-X port
1	TD+(transmit)	RD+(receive)
2	TD-(transmit)	RD-(receive)
3	RD+(receive)	TD+(transmit)
4	Not used	Not used
5	Not used	Not used
6	RD-(receive)	TD-(transmit)
7	Not used	Not used
8	Not used	Not used

**Note:** "+" and "-" signs represent the polarity of the wires that make up each wire pair.

# 5


## Management Interface

### 5.1 DS-Tool


DS-Tool is a powerful Windows utility for DS series. It supports device discovery, device configuration, group setup, group firmware update, monitoring functions...etc. It is easy for you to install and configure devices over the network.

#### 5.1.1 Install DS-Tool

Step 1: Execute the Setup program, click “**start**” after selecting the folder for DS-Tool.




Step 2: When installation complete successfully, then click “**OK**”.



Step 3: Check for your selection.






## 5.1.2 Using DS-Tool

### 5.1.2.1 Explore DS device servers

DS-Tool will broadcast to the network and search all available DS devices in the network. The default IP address of the device is “192.168.10.2”, and selects the searching device you wish to use and press “Add” button. You can set static IP address or in DHCP client mode to get IP address automatically. Finally, click “OK” button to add the device.



### 5.1.2.2 Configure DS device servers

#### General settings

This page includes the setting of device name, SNTP server and Auto IP Report.

The screenshot shows a web-based configuration interface for a DS-11-W device. At the top, there are tabs for 'General', 'Security', 'Networking', 'Wireless', 'Notification', 'Management', 'Upgrade Firmware', and 'Save/Load'. The 'General' tab is active. The interface is divided into several sections:

- Model:** Industrial 1-port RS232/422/485 to 802.11 b/g WLAN Device Server
- Power:** A status indicator showing two bars, with the second bar filled green.
- Networking:** A status indicator showing one bar filled green and the text 'wlan'.
- LAN IP Address:** 192.168.0.41
- LAN MAC Address:** 00:00:56:04:02:07
- Version:** 1.05j
- WLAN IP Address:** Disabled
- WLAN MAC Address:** 00:00:00:00:00:00
- Locate On:** A button with a location pin icon.
- Device Name/Location:** DeviceServer-DEFAULT
- Using SNTP Time Server:** A checked checkbox.
- Auto IP Report:** A checked checkbox.
- SNTP Server IP:** pool.ntp.org
- Port:** 123
- Time Zone:** (GMT+08:00)Taipei
- IP Address:** 192.168.0.35
- Port:** 60001
- Get Current Host:** A button.
- Report Interval:** 10 Seconds

At the bottom of the interface, there are three buttons: 'Refresh', 'Apply Only', and 'Apply and Save'.

The following table describes the labels in this screen.

Label	Description
<b>Device Name/location</b>	You can set the device name or related information. By clicking “ <b>Locate On</b> ” button you can locate the serial server’s position.
<b>Set SNTP</b>	Input the SNTP server domain name or IP address, port and select the Time zone.
<b>Set Auto IP Report</b>	By Clicking the “ <b>Get current Host</b> ” button you will get your local IP, and then set the Report interval time. The device server will report its status periodically.  At “ <b>IP collection</b> ” option show the device report information. The report interval is 0 indicate disable this setting (default), but you can set the other IP or Port.


Security

The following table describes the labels in this screen.

Label	Description
<b>Accessible IP Setting</b>	<p>To prevent unauthorized access by setting host IP addresses and network masks.</p> <ol style="list-style-type: none"> <li>Only one host with a special IP address can access the device server , “<b>IP address /255.255.255.255</b>” (e.g., “<b>192.168.0.1/255.255.255.255</b>”).</li> <li>Hosts on a specific subnet can access the device server. “<b>IP address/255.255.255.0</b>” (e.g., “<b>192.168.0.2/255.255.255.0</b>”)</li> <li>Any host can access the device server. Disable this function by un-checking the “<b>Enable IP Filter</b>” checkbox</li> </ol>
<b>Password setting</b>	<p>You can set the password to prevent unauthorized access from your server. Factory default is no password.</p>

### Network Setting

Device DS can connect the Network by wire and wireless. You must assign a valid IP address for DS before attached in your network environment. Your network administrator should provide you the IP address and related settings. The IP address must be unique within the network (otherwise, DS will not have a valid connection to the network). You can choose from three possible “**IP configuration**” modes: Static, DHCP/BOOTP. The Factory Default IP address is “**192.168.10.2**”




The following table describes the labels in this screen.

Label	Description
<b>Using Static IP</b>	Manually assigning an IP address.
<b>Using DHCP/BOOTP</b>	IP Address automatically assigned by a DHCP server in your network.
<b>Subnet Mask</b>	All devices on the network must have the same subnet mask to communicate on the network.
<b>Gateway</b>	Enter the IP address of the router in you network.
<b>DNS Server</b>	Enter the IP address of the DNS server, The DNS server translates domain names into IP address.


**Wireless setting**


Wireless Network type includes two modes: Infra and Adhoc. The Infra type connects the network by wireless access point, but the Adhoc is formed by the association of wireless and mobile devices capable of communicating among themselves even when there is no networking infrastructure available.

**Infra Network**



**Adhoc Network**





The following table describes the labels in this screen.

Label	Description
<b>Network Type</b>	Type includes Infra and Adhoc.
<b>SSID</b>	Service Set Identifier Default is the default setting. The SSID is a unique name that identifies a network. All devices on a network must share the same SSID name in order to communicate on the network.
<b>Channel</b>	All devices on the network must be set to the same channel to communicate on the network. You can select the Auto.
<b>NO Encryption</b>	You can set no encryption mode, but this mode is insecurity and don't suggest use.
<b>WEP</b>	You can set four encryption 5characters (WEP64), 13 characters (WEP128), 10 digits (WEP64), 26digits (WEP128).
<b>TKIP</b>	TKIP (Temporal Key Integrity Protocol) is a key management protocol.
<b>AES</b>	AES (Advanced Encryption System) is a variable bit length symmetric digital encryption algorithm.

*\*Simply unplug the RJ-45 to change into wireless connection*

## Notification

Specify the events that should be notified to the administrator. The events can be notified by E-mail, SNMP trap, or system log.

General | Security | Networking | Wireless | **Notification** | Management | Upgrade Firmware | Save/Load

SNMP Trap  Email Notification  Syslog Notification

SNMP Settings | Email Settings | Syslog Settings

Notified Items:

- Hardware Reset (Cold Start)  DI\_1 Changed
- Software Reset (Warm Start)  DI\_2 Changed
- Login Failed  DI\_3 Changed
- IP Changed  DI\_4 Changed
- Password Changed  DO\_1 Changed
- Access IP Blocked  DO\_2 Changed
- Redundant Power Changed
- Redundant Ethernet Changed

System Log Settings

Server IP:  Port:

The following table describes the labels in this screen.

Label	Description
<b>SNMP Trap</b>	To notify events information by SNMP trap.
<b>Email Notification</b>	To notify events information by Email.
<b>Syslog Notification</b>	To notify events information by Syslog. You can use the current Host's Log server by click " <b>Using Current Host's Log Server</b> " button. You also can set other log server. (DS-tool log server port default 514)
<b>Notify items</b>	The events to be notified.
<b>Apply</b>	Apply current setting, but the setting will be lost after reboot.
<b>Apply and Save</b>	Apply and save current setting. Write configuration into flash memory.

## Management

General | Security | Networking | Wireless | Notification | Management | Upgrade Firmware | Save/Load

Web Management Enable

Telnet Management Enable

SNMP Management Enable

SNMP Management Settings

Community

Location

Contact

Trap Server1

Trap Server2

Trap Server3


Trap Server4

The following table describes the labels in this screen.

Label	Description
<b>Web Management Enable</b>	To enable management from Web. Click " <b>Goto Web Management</b> " button to access device web page, then set the device by web.
<b>Telnet Management Enable</b>	To enable management by Telnet(SSH). Click " <b>Goto Telnet Management</b> " button to execute Telnet command.
<b>SNMP Management Enable</b>	To enable management by SNMP.
<b>SNMP Management Settings</b>	To configure SNMP server related settings.




### Upgrade Firmware



The following table describes the labels in this screen.

Label	Description
<b>Browsing</b>	Browse the file and upgrade
<b>Upgrade</b>	Enable the firmware upgrade.

### Save/Load



The following table describes the labels in this screen.

Label	Description
<b>Save Configuration to Flash</b>	Save current configuration into flash memory.

<b>Load Default</b>	Load default configuration except the network settings. If you want to load all factory default, you need to press “Reset” button on the device (Hardware restore).
<b>Reboot Device</b>	Reboot the device server (warm start).
<b>Import Configuration</b>	Restore the previous exported configuration.
<b>Export Configuration</b>	Export current configuration to a file to backup the configuration.

### 5.1.2.3 Configure serial port

#### Serial Settings

The screenshot shows the 'Serial Settings' configuration page. At the top, there are tabs for 'Serial Settings', 'Service Mode', and 'Notification'. The main area is titled 'port1' and contains several configuration fields:

- Port Alias:** Port0
- Baudrate:** 38400
- Stop Bits:** 1
- Performance:** Throughput
- Parity:** No
- Flow Control:** No Flow
- Data Bits:** 8
- Interface:** RS232

Below these are the **Delimiter Settings**, which are split into 'Serial to Ethernet' and 'Ethernet to Serial'. Under 'Serial to Ethernet', there are four delimiter settings (Delimiter 1 to 4), each with a hex value field (currently 0) and an 'Enabled' checkbox. A 'Flush Serial to Ethernet Data Buffer After' field is set to 0 ms. A note explains that data is sent when the buffer is full (4K Bytes) or after a flush timeout.

At the bottom, there is a 'Force TX interval time' field set to 0 ms, with a note that data is sent when the TX buffer is full (4K Bytes) or after a timeout.

At the very bottom, there are three buttons: 'Refresh', 'Apply Only', and 'Apply and Save'.


The following table describes the labels in this screen.

Label	Description
<b>Port Alias</b>	Remark the port to hint the connected device.
<b>Interface</b>	RS232 / RS422 / RS485(2-wires) / RS485(4-wires)
<b>Baud rate</b>	110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/ 38400bps/57600bps/115200bps/230400bps

<b>Data Bits</b>	5, 6, 7, 8
<b>Stop Bits</b>	1, 2 (1.5)
<b>Parity</b>	No, Even, Odd, Mark, Space
<b>Flow Control</b>	No, XON/XOFF, RTS/CTS, DTR/DSR
<b>Performance</b>	Throughput: This mode optimized for highest transmission speed. Latency: This mode optimized for shortest response time.
<b>Serial to Ethernet</b>	<p><b>Delimiter:</b></p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "<b>Flush Serial to Ethernet data buffer</b>" times out. 0 means disable. Factory default is 0.</p> <p><b>Flush Data Buffer After:</b></p> <p>The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "<b>flush S2E data buffer</b>" timeout the data will also be sent. You can set the time from 0 to 65535 seconds.</p>
<b>Ethernet to Serial</b>	<p><b>Delimiter:</b></p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "<b>Flush Ethernet to Serial data buffer</b>" times out. 0 means disable. Factory default is 0.</p> <p><b>Flush Data Buffer After:</b></p> <p>The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "<b>flushE2S data buffer</b>" timeout the data will also be sent. You can set the time from 0 to 65535 seconds.</p>
<b>Force TX Interval Time</b>	Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. 0 means disable. Factory default value is 0.

### Service Mode – Virtual COM Mode

In Virtual COM Mode, the DS-Tool establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.



The following table describes the labels in this screen.

Label	Description
<b>Map Virtual COM</b>	Select a Virtual COM Name to map on.
<b>Max Connection</b>	The number of Max connection can support simultaneous connections are 5, default values is 1.
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0.

### Service Mode – TCP Server Mode

In TCP Server Mode, DS is configured with a unique Port combination on a TCP/IP network. In this case, DS waits passively to be contacted by the device. After a connection is established, it can then proceed with data transmission. TCP Server mode also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.

The following table describes the labels in this screen.

Label	Description
<b>Data Port</b>	Set the port number for data transmission.
<b>Auto Scan</b>	Scan the data port automatically.
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0.
<b>Max Connection</b>	The number of Max connection can support simultaneous connections are 5, default values is 1.

### Service Mode – TCP Client Mode

In TCP Client Mode, device can establish a TCP connection with server by the method you have settled (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or idle time settings.

The following table describes the labels in this screen.

Label	Description
<b>Destination Host</b>	Set the IP address of host.
<b>Port</b>	Set the port number of data port.
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0.
<b>Connect on Startup</b>	The TCP Client will build TCP connection once the connected serial device is started.

<p><b>Connect on Any Character</b></p>	<p>The TCP Client will build TCP connection once the connected serial device starts to send data.</p>
--	---

**Service Mode – UDP Client Mode**

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also receive data from one or multiple host

Serial Settings | Service Mode | Notification

port1  
Service Mode: UDP Mode

UDP Mode


UDP Settings  
Listening Port: 4004 [Auto Scan]

Multilink

	Destination Host Begin	to	Destination Host End	Sending Port	
1	192.168.0.1	to	192.168.0.100	10000	[Auto Scan]
2		to			[Auto Scan]
3		to			[Auto Scan]
4		to			[Auto Scan]

**Notification**

Specify the events that should be noticed. The events can be notified by E-mail, SNMP trap or system log.



The following table describes the labels in this screen.

Label	Description
<b>DCD changed</b>	When DCD (Data Carrier Detect) signal changes, it indicates that the modem connection status has changed. Notification will be sent.
<b>DSR changed</b>	When DSR (Data Set Ready) signal changes, it indicates that the data communication equipment is powered off. A Notification will be sent.
<b>RI changed</b>	When RI (Ring Indicator) signal changes, it indicates that the incoming of a call. A Notification will be sent.
<b>CTS changed</b>	When CTS (Clear To Send) signal changes, it indicates that the transmission between computer and DCE can proceed. A notification will be sent.
<b>Port connected</b>	In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, Virtual COM is ready to use. A notification will be sent.
<b>Port disconnected</b>	In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger. A notification will be sent.




## 5.2 Configuration by Web Browser


### 5.2.1 Connect to the Web page

Step 1: Input the IP address of DS with “<https://192.168.10.2>” in the Address input box of IE.

Step 2: Click “Yes” button on the dialog box.




Step 3: Input the name and password, then click “OK”.




*\*Only if password is set*

Step 4: The system information will be shown as below.



### 5.2.1.1 System SNTP




The following table describes the labels in this screen.

Label	Description
<b>Name</b>	You can set the name of DS
<b>SNTP</b>	Enable the SNTP server.
<b>Time zone</b>	After you set the SNTP enable, select the time zone you located.
<b>Time server</b>	Input SNTP server domain name or IP address and Port.
<b>Console</b>	Telnet Console (SSH) is included for security reasons. In some cases, you may need to disable this function to prevent unauthorized access from internet. The factory default is enable.

## IP Configuration

You must assign a valid IP address for DS before attached in your network environment. Your network administrator should provide you with the IP address and related settings. The IP address must be unique and within the network (otherwise, DS will not have a valid connection to the network). You can choose from three possible “**IP configuration**” modes: Static, DHCP/BOOTP. The Factory Default IP address is “**192.168.10.2**”




The following table describes the labels in this screen.

Label	Description
<b>Network Type</b>	Include Lan and Wireless.
<b>DHCP/BOOTP</b>	Obtain the IP address automatically from DHCP server.
<b>Static IP Address</b>	Assigning an IP address manually.
<b>Subnet Mask</b>	Set the subnet mask to communicate on the network.
<b>Gateway</b>	Enter the IP address of the router in you network.
<b>DNS Server</b>	Enter the IP address of the DNS server to translate domain names into IP address.
<b>Auto IP Report</b>	Set the report IP address and TCP port (60001 DS-tool default), then the device server will report it status periodically. At DS-Tool->IP collection option show the device server status. The report interval is 0 indicate disable this setting (default). Also you can set the other IP or Port.

## Wireless setting

Wireless Network type include two mode, Infra and Adhoc. The Infra type connect the network by wireless access point, but the Adhoc is formed by the association of wireless and mobile devices capable of communicating among themselves even if there is no networking infrastructure available.



The following table describes the labels in this screen.

Label	Description
<b>Network Type</b>	Type include Infra and Adhoc.
<b>SSID</b>	Service Set Identifier Default is the default setting. The SSID is a unique name that identifies a network. All devices on a network must share the same SSID name in order to communicate on the network.
<b>Channel</b>	All devices on the network must be set to the same channel to communicate on the network. You can select the Auto.
<b>NO Encryption</b>	You can set no encryption mode, but this mode is insecurity and we don't suggest to use it.
<b>WEP</b>	You can set four encryption 5 characters (WEP64),13 characters(WEP128), 10 digits(WEP64),26 digits(WEP128).
<b>TKIP</b>	TKIP (Temporal Key Integrity Protocol) is a key management protocol.
<b>AES</b>	AES (Advanced Encryption System) is a variable bit length symmetric digital encryption algorithm.

## Authentication

You can set the password to prevent unauthorized access from network. Input the “**Old password**” and “**New password**” to change the password. Factory default is no password.

The screenshot shows the 'User Authentication' configuration page. On the left is a 'MENU' tree with 'System' expanded. The main area contains three input fields: 'Old Password', 'New Password', and 'Confirm New Password', followed by an 'Apply' button.

### 5.2.1.2 Port serial setting

#### Serial configuration

The screenshot shows the 'Serial Configuration' page for 'Port1'. The form includes the following fields and options:

- Port Alias: Port0
- Interface: RS232
- Baud Rate: 38400
- Data Bits: 8
- Stop Bits: 1
- Parity: None
- Flow Control: None
- Force TX Interval Time: 0 ms
- Performance:  Throughput  Latency

An 'Apply' button is located at the bottom left of the form.

The following table describes the labels in this screen.

Label	Description
<b>Port Alias</b>	Remark the port to hint the connected device.
<b>Interface</b>	RS232 / RS422 / RS485(2-wires) / RS485(4-wires)
<b>Baud rate</b>	110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/

	38400bps/57600bps/115200bps/230400bps
<b>Data Bits</b>	5, 6, 7, 8
<b>Stop Bits</b>	1, 2 (1.5)
<b>Parity</b>	No, Even, Odd, Mark, Space
<b>Flow Control</b>	No, XON/XOFF, RTS/CTS, DTR/DSR
<b>Force TX Interval Time</b>	Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. 0 means disable. Factory default value is 0.
<b>Performance</b>	Throughput: This mode optimized for highest transmission speed. Latency: This mode optimized for shortest response time.
<b>Apply</b>	Activate settings on this page.

### Port Profile

**Port Profile**

Port1	
Local TCP Port	<input type="text" value="4000"/>
Command Port	<input type="text" value="4001"/>
Mode	Serial to Ethernet
Flush Data Buffer After	<input type="text" value="0"/> ms
Delimiter(Hex 0~ff)	1: <input type="text" value="00"/> 2: <input type="text" value="00"/> 3: <input type="text" value="00"/> 4: <input type="text" value="00"/>
Mode	Ethernet to Serial
Flush Data Buffer After	<input type="text" value="0"/> ms
Delimiter(Hex 0~ff)	1: <input type="text" value="00"/> 2: <input type="text" value="00"/> 3: <input type="text" value="00"/> 4: <input type="text" value="00"/>

The following table describes the labels in this screen.

Label	Description
<b>Serial to Ethernet</b>	<p><b>Flush Data Buffer After:</b></p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "<b>flush S2E data buffer</b>" timeout, the data will also be sent. You can set the time from 0 to 65535 seconds.</p> <p><b>Delimiter:</b></p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The</p>

	<p>data will be hold until the delimiters are received or the option “<b>Flush Serial to Ethernet data buffer</b>” times out. 0 means disable. Factory default is 0</p>
<b>Ethernet to serial</b>	<p><b>Flush Data Buffer After:</b></p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "<b>flush E2S data buffer</b>" timeout, the data will also be sent. You can set the time from 0 to 65535 seconds.</p> <p><b>Delimiter:</b></p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option “<b>Flush Ethernet to Serial data buffer</b>” times out. 0 means disable. Factory default is 0</p>

**Service Mode – Virtual COM Mode**

In Virtual COM Mode, the driver establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.

**Service Mode**

	Port1
Service Mode	Virtual COM Mode ▾
Idle Timeout	<input type="text" value="0"/> (0~65535)seconds
Alive Check	<input type="text" value="0"/> (0~65535)seconds
Max Connection	<input type="text" value="1"/> ▾ max. connection (1~5)

*\*Not allowed to mapping Virtual COM from web*

The following table describes the labels in this screen.

Label	Description
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function.

	Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0.
<b>Max Connection</b>	The number of Max connection can support simultaneous connections are 5, default values is 1.

**Service Mode – TCP Server Mode**

In TCP Server Mode, DS is configured with a unique Port combination on a TCP/IP network. In this case, DS waits passively to be contacted by the device. After the device establishes a connection with the serial device, it can then proceed with data transmission. TCP Server mode also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.

**Service Mode**

	Port1
Service Mode	TCP Server Mode <input type="button" value="v"/>
TCP Server Port	<input type="text" value="4000"/>
Idle Timeout	<input type="text" value="0"/> (0~65535)seconds
Alive Check	<input type="text" value="0"/> (0~65535)seconds
Max Connection	<input type="button" value="1"/> max. connection(1~5)

The following table describes the labels in this screen.

Label	Description
<b>TCP Server Port</b>	Set the port number for data transmission.
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP



	connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0.
<b>Max Connection</b>	Support up to 5 simultaneous connections are 5, default values is 1.

**Service Mode – TCP Client Mode**

In TCP Client Mode, device can establish a TCP connection with server by the method you have settled (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or idle time settings.

**Service Mode**

	Port1
Service Mode	TCP Client Mode <input type="button" value="v"/>
Destination Host	0.0.0.0 : 4000
Idle Timeout	0 (0~65535)seconds
Alive Check	0 (0~65535)seconds
Connect on	<input checked="" type="radio"/> Startup <input type="radio"/> Any Character
Destination Host      Port	
1.	0.0.0.0      65535
2.	0.0.0.0      65535
3.	0.0.0.0      65535
4.	0.0.0.0      65535
<input type="button" value="Apply"/>	

The following table describes the labels in this screen.

Label	Description
<b>Destination Host</b>	Set the IP address of host and the port number of data port.
<b>Idle Timeout</b>	When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting.
<b>Alive Check</b>	The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function.

	Factory default is 0.
<b>Connect on Startup</b>	The TCP Client will build TCP connection once the connected serial device is started.
<b>Connect on Any Character</b>	The TCP Client will build TCP connection once the connected serial device starts to send data.

### Service Mode – UDP Client Mode

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also receive data from one or multiple host

**Service Mode**

Port1		
Service Mode	UDP Mode <input type="button" value="v"/>	
Listen Port	4004	
Host start IP	Host end IP	Send Port
1. 192.168.0.1	192.168.0.100	20000
2. 0.0.0.0	0.0.0.0	65535
3. 0.0.0.0	0.0.0.0	65535
4. 0.0.0.0	0.0.0.0	65535

### 5.2.1.3 Management

#### Accessible IP Settings

Accessible IP Settings allow you to add or block the remote host IP addresses to prevent unauthorized access. If host's IP address is in the accessible IP table, then the host will be allowed to access the DS. You can choose one of the following cases by setting the parameter.

1. Only one host with a special IP address can access the device server, "**IP address /255.255.255.255**" (e.g., "**192.168.0.1/255.255.255.255**").
2. Hosts on a specific subnet can access the device server. "**IP**

address/255.255.255.0" (e.g., "192.168.0.2/255.255.255.0")

- Any host can access the device server. Disable this function by un-checking the "Enable IP Filter" checkbox

**Access IP Control List**

Enable IP Filtering (Not check this option will allow any IP to have accessibility)

No.	Activate the IP	IP Address	Netmask
1	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
6	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
7	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
8	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
9	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
10	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
11	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
12	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
13	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
14	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
15	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
16	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>

## SMTP/SNMP Configuration

Email Server configuration includes the mail server's IP address or domain. If the authentication is required, specify your name and password. There are 4 Email addresses that you can specify to receive the notification.

SNMP Server configuration includes the SNMP Trap Server IP address, Community, Location and Contact. There are 4 SNMP addresses you can specify to receive the notification.

SysLog server configuration includes the server IP and server Port. This option need to use with DS-Tool.

SMTP/SNMP Configuration	
E-mail Settings	
SMTP Server	<input type="text"/> Port <input type="text"/>
<input type="checkbox"/> My server requires authentication	
User Name	<input type="text"/>
Password	<input type="text"/>
E-mail Sender	<input type="text"/>
E-mail Address 1	<input type="text"/>
E-mail Address 2	<input type="text"/>
E-mail Address 3	<input type="text"/>
E-mail Address 4	<input type="text"/>
SNMP Trap Server	
SNMP Server 1	<input type="text"/>
SNMP Server 2	<input type="text"/>
SNMP Server 3	<input type="text"/>
SNMP Server 4	<input type="text"/>
Community	<input type="text"/>
Location	<input type="text"/>
Contact	<input type="text"/>
Syslog Server	
Syslog Server IP	<input type="text"/>
Syslog Server Port	<input type="text" value="0"/>

## System Event Configuration

Specify the events that should be notified to the administrator. The events can be notified by E-mail, SNMP trap, or system log.

**System Event Configuration**

Device Event Notification			
Hardware Reset (Cold Start)	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Software Reset (Warm Start)	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Login Failed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
IP Address Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Password changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Access IP Blocked	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Redundant Power Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Redundant Ethernet Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
SNMP Access Failed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Port Event Notification			
DCD Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
DSR Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
RI Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
CTS Changed	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Port Connected	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog
Port Disconnected	<input type="checkbox"/> SMTP Mail	<input type="checkbox"/> SNMP Trap	<input type="checkbox"/> Syslog

The following table describes the labels in this screen.

Label	Description
<b>Hardware Reset (Cold Start)</b>	This refers to starting the system from power off (contrast this with warm start). When performing a cold start, DS will automatically issue an Auto warning message by sending E-mail, log information or an SNMP trap after booting.
<b>Software Reset (Warm Start)</b>	This refers to restart the computer without turning the power off. When performing a warm start, DS will automatically send an E-mail, log information or SNMP trap after reboot.
<b>Login Failed</b>	When an unauthorized access from the Console or Web interface, a notification will be sent.
<b>IP Address Changed</b>	When IP address of device changed, a notification will be sent.
<b>Password Changed</b>	When password of device changed, a notification will be sent.
<b>Access IP Blocked</b>	When the host accesses the device with blocked IP addresses, a notification will be sent.
<b>Redundant</b>	When status of power changed, a notification will be sent.

<b>Power Change</b>	
<b>DCD changed</b>	When DCD (Data Carrier Detect) signal changes, it indicates that the modem connection status has been changed. A Notification will be sent.
<b>DSR changed</b>	When DSR (Data Set Ready) signal changes, it indicates that the data communication equipment is powered off. A Notification will be sent.
<b>RI changed</b>	When RI (Ring Indicator) signal changes, it indicates an incoming call. Notification will be sent.
<b>CTS changed</b>	When CTS (Clear To Send) signal changes, it indicates that the transmission between computer and DCE can proceed. A notification will be sent.
<b>Port connected</b>	In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, Virtual COM is ready to use. A notification will be sent.
<b>Port disconnected</b>	In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger. A notification will be sent.

#### 5.2.1.4 Save/Reboot

Factory Default  
Reset to default configuration.  
Click Reset button to reset all configurations to the default value.

Restore Configuration  
You can restore the previous saved configuration to Device Server.

File to restore:

Backup Configuration  
You can save current EEPROM value from the Device Server as a backup file of configuration.

Upgrade Firmware  
Specify the firmware image to upgrade.  
Note: Please DO NOT power off this device while upgrading firmware.

Firmware:

Reboot Device  
Please click [**Reboot**] button to restart device.


The following table describes the labels in this screen.

Label	Description
<b>Load Factory Default</b>	Load default configuration except settings of Network. If you want load all factory default, you should press " <b>Reset</b> " button on the device (Hardware restore).
<b>Import Configuration</b>	Restore the previous exported configuration.
<b>Export Configuration</b>	Export the current configuration to a file.
<b>Upgrade Firmware</b>	Upgrade to a new firmware with specified file.
<b>Reboot Device</b>	Reboot the device server (warm start).

## 5.3 Configuration by SSH Console

### 5.3.1 Connect to DS

You can use SSH Tool (e.g., PuTTY) to access SSH console of DS. The SSH console interface is shown below.



```

192.168.10.2
login as: admin
admin@192.168.10.2's password:

*****
***          Port Commander          ***
*****

Input System Password: ***
Password confirmed. Starting Main Menu.
-----
[Port Commander]
1. Overview
2. General Settings
3. Network Settings
4. Ports settings
5. Security(Accessible IP) Settings
6. Notification(Auto Warning) Settings
C. Change Password
L. Load Factory Default
S. Save configuration
R. Reboot
Q. Exit & Logout

Select one function (1-6,C,L,S,R,Q): █
  
```

# 6

## Technical Specifications

<b>Network Interface</b>	
Ethernet	1x 10/100Base-T(X) LAN
connector	RJ-45
Protection	Built-in1.5KV magnetic isolation
Protocols	ICMP, IP, TCP, UDP, DHCP, BOOTP, ARP/RARP, DNS, SNMP MIB II, HTTPS, SSH
<b>WLAN Feature</b>	
Operating Mode	Client mode
Radio Frequency Type	DSSS
Modulation	IEEE802.11b: CCK, DQPSK, DBPSK IEEE802.11g: OFDM with BPSK, QPSK, 16QAM, 64QAM
Frequency Band	America/FCC: 2.412~2.462 GHz (11 channels) Europe CE/ETSI: 2.412~2.472 GHz (13 channels)
Transmission Rate	IEEE802.11b: 1/ 2/ 5.5/ 11 Mbps IEEE802.11g: 6/ 9/ 12/ 18/ 24/ 36/ 48/ 54 Mbps
Transmit Power	IEEE802.11b/g: 16dBm
Encryption Security	WEP: (64-bit ,128-bit key supported) WPA: WPA2 :802.11i(WEP and AES encryption) PSK (256-bit key pre-shared key supported) 802.1X and Radius supported TKIP encryption
Wireless Security	SSID broadcast disable
<b>Serial Interface</b>	
Interface	1x RS232 / RS422 / 4(2)-Wire RS485. Which can be configured by DS-Tool
Connector	Male DB9



Baud Rate	110 bps to 230.4 Kbps
Data Bits	5, 6, 7, 8
Parity	odd, even, none, mark, space
Stop Bits	1. 1.5, 2
RS-232 signals	TxD, RxD, RTS, CTS, DTR, DSR, DCD, RI, GND
RS-422 signals	Tx+,Tx-, Rx+, Rx-,GND
RS-485 (4 wire) signals	Tx+,Tx-, Rx+, Rx-,GND
RS-485 (2 wire) signals	Data+, Data-,GND
Flow control	XON/XOFF, RTS/CTS, DTR/DSR
Protection	Built-in15KV ESD protection
LED Indicators	<p>PWR 1(2) / Ready:</p> <p>1) Red On: Power is on and booting up.  Red Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly.</p> <p>2) Green On: Power is on and functioning normally.  Green Blinking: Located by Administrator.</p> <p>ETH Link / ACT:</p> <p>Orange ON/Blinking: 10 Mbps Ethernet  Green ON/Blinking: 100 Mbps Ethernet</p> <p>WLAN Link /ACT: Green: Link, Orange: Poor signal</p> <p>Serial TX / RX LEDs:</p> <p>Red: Serial port is receiving data  Green: Serial port is transmitting data.</p>
<b>Power Requirements</b>	
Power Input Voltage	PWR1: 12~48VDC in 3-pin Terminal Block PWR2: 12~48VDC in Power Jack with Power Adapter
Reverse Polarity Protection	Present at terminal block
Power Consumption	4 Watts Max
<b>Software Utility</b>	
Utility	DS-Tool for Windows NT/2000/XP/2003/VISTA Device discovery Auto IP report Device setting (run-time change, no rebooting) Access control list Group setting Device monitoring Serial port monitoring Log info Group Firmware update

Serial Mode	Virtual Com / TCP Server / TCP Client / UDP / Serial Tunnel TCP Alive Check Timeout Inactivity Timeout Delimiter for Data Packing Force TX Timeout for Data Packing
Multiple Link	5 Hosts simultaneous connection: Virtual Com / TCP server / TCP Client / UDP
VCOM Driver	Windows NT/2000/XP/2003/VISTA
Configuration	Web HTTPS console, SSH console, DS-Tool for Windows NT/2000/XP/VISTA
<b>Environmental</b>	
Operating Temperature	-10 to 55°C (14 to 131°F)
Operating Humidity	5% to 95%(Non-condensing)
Storage Temperature	-20 to 85°C (-4 to 185 F)°
<b>Mechanical</b>	
Dimensions(W x D x H)	72 mm(W)x 125 mm(D)x 31 mm(H)
Casing	IP-30 protection
<b>Regulatory Approvals</b>	
Shock	IEC60068-2-27
Free Fall	IEC 60068-2-32
Vibration	IEC 60068-2-6
EMI	FCC Part 15, CISPR (EN55022) class A
EMS	EN61000-4-2 (ESD), EN61000-4-3 (RS), EN61000-4-4 (EFT), EN61000-4-5 (Surge), Level 3, EN61000-4-6 (CS), Level 3
MBTF	200,000 hours at least
Warranty	5 years

## **FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **CAUTION:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### **FCC RF Radiation Exposure Statement**

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.