

# MAGELLAN™

## All-In-One Wireless Security System V2.0

### Programming Guide

Model # MG-6130 / MG-6160



We hope this product performs to your complete satisfaction. Should you have any questions or comments, please visit [www.paradox.com](http://www.paradox.com) and send us your comments.

## Table of Contents

<b>Things You Should Know .....</b>	<b>2</b>	<b>Wireless Output Assignment .....</b>	<b>14</b>
About This Programming Guide.....	2	<b>Wireless Keypad Assignment .....</b>	<b>14</b>
Conventions .....	2	<b>Wireless Repeater Assignment.....</b>	<b>14</b>
Installer Code (Default: 0000 / 000000).....	2	<b>Wireless Programmable Output (PGM) Settings</b>	<b>14</b>
Maintenance Code (Default: 1111 / 111111).....	2	<b>Wireless Supervision Options .....</b>	<b>14</b>
Master Code (Default: 1234 / 123456).....	2	<b>Wireless Repeater Options.....</b>	<b>16</b>
<b>Entering Programming Mode .....</b>	<b>2</b>	<b>Appendix 1: PGM Event Table .....</b>	<b>18</b>
Single Digit Data Entry Method.....	2	<b>Appendix 2: Specifications .....</b>	<b>20</b>
Feature Select Programming Method.....	3	<b>Appendix 3: Connection Diagrams.....</b>	<b>21</b>
Decimal and Hexadecimal Values .....	3	Power Connections .....	21
<b>Installer Quick Keys .....</b>	<b>3</b>	Telephone Line Connections .....	22
<b>Zone Programming.....</b>	<b>4</b>	PGM Connections .....	23
<b>Remote Control Button Programming.....</b>	<b>5</b>	Hardwire Zone Connections.....	24
<b>System Timers .....</b>	<b>6</b>	Connecting the Radio Antenna (MG-6160 only) .....	24
<b>On-board Programmable Outputs (PGMs).....</b>	<b>6</b>	Connecting to a UIP-256.....	25
<b>System Options .....</b>	<b>7</b>	X10 Transmitter Connections (MG-6160 only).....	25
<b>Communicator Settings .....</b>	<b>10</b>	Connecting Magellan to WinLoad .....	26
<b>Report Codes .....</b>	<b>11</b>	Connecting a Paradox Memory Key (PMC-4).....	26
<b>System Settings.....</b>	<b>13</b>	Tabletop Mounting .....	27
<b>Wireless Transmitter Assignment.....</b>	<b>13</b>	Mounting Magellan on the Wall.....	27
		<b>Appendix 4: Ademco Contact ID Report Codes</b>	<b>28</b>
		<b>Appendix 5: Automatic Report Code List .....</b>	<b>30</b>

# Things You Should Know

## About This Programming Guide

This programming guide should be used in conjunction with the *Magellan Reference & Installation Manual* which can be downloaded from our website at [paradox.com](http://paradox.com). Use this guide to record the settings programmed for this console.

## Conventions



This symbol designates a warning or important information.




This symbol designates a suggestion or reminder.



This symbol designates a reference to another section, manual or guide.



This symbol designates a feature that can also be programmed in the Installer menu which can be accessed by pressing [MENU] and then entering your [INSTALLER CODE]. The icon will then be followed by the path or buttons that have to be pressed in order to access the feature once in the Installer menu. For example:

-[4] →[6] = Once in the Installer menu, press the [4] key and then press the [6] key to access the desired feature.

Refer to the Installer Menu Overview on the back cover for more information on accessing and using the Installer menu.

## Installer Code (Default: 0000 / 000000)

The Installer code is used to enter programming mode (see *Entering Programming Mode* on page 2), which allows you to program all the features, options and commands of the Magellan console **except** user codes. The Installer code can be 4 or 6 digits in length (see section [090] option [1] on page 7) where each digit can be any value from 0 to 9. See section [181] on page 13 to change the default code.

## Maintenance Code (Default: 1111 / 111111)

The Maintenance code is similar to the Installer code. It can be used to enter programming mode (see *Entering Programming Mode* on page 2), which allows you to program all the features, options and commands **except** for the Magellan console's communication settings (sections [108] to [112], sections [180] to [182]) as well as any user codes. The Maintenance code can be 4 or 6 digits in length (see section [090] option [1] on page 7) where each digit can be any value from 0 to 9. See section [182] on page 13 to change the default code (**Installer only**).

## Master Code (Default: 1234 / 123456)

With the System Master code a user can use any arming method and can program user codes. The System Master code can be 4 or 6 digits in length (see section [090] option [1] on page 7), where each digit can be any digit from 0 to 9. The System Master code cannot be changed by the Installer or Maintenance code, but it can be reset to default. See section [200] on page 13 to reset to default.

# Entering Programming Mode

Use the built-in keypad to access Magellan's installer programming mode. To access programming mode:

1. Press and hold the [0] key.
2. Enter your [INSTALLER CODE] or [MAINTENANCE CODE].
3. Enter the 3-digit [SECTION] you wish to program.
4. Enter the required [DATA].
5. Press the [\*] key to clear data or to go back one step. Press the [#] key to save changes.

There are two methods that can be used to enter data when in programming mode: Single Digit Data Entry and Feature Select Programming methods.

## Single Digit Data Entry Method

After entering programming mode, some sections will require that you enter decimal values from 000 to 255. Other sections will require that you enter hexadecimal values from 0 to F. The required data will be clearly indicated in this manual. When entering the final digit in a section, Magellan will automatically save and advance to the next section. Refer to Figure 1 on page 3 to see the keys and their equivalent decimal and/or hexadecimal value.

## Feature Select Programming Method

After entering certain sections, eight options will be displayed where each option from [1] to [8] represents a specific feature. Press the key corresponding to the desired option and the option number will appear in the LCD screen. This means the option is ON. Press the key again to remove the digit from the LCD screen (a \* appears), thereby, turning OFF the option. Press the [\*] key to set all eight options to OFF. When the options are set, press the [#] key to save and advance to the next section.

## Decimal and Hexadecimal Values

Figure 1: Decimal and Hexadecimal Values


### Hexadecimal only

values:

- [1] = A
- [2] = B
- [3] = C
- [4] = D
- [5] = E
- [6] = F

### Decimal and Hexadecimal Values:

Keys [0] to [9] = 0 to 9



## Installer Quick Keys

To access the Installer Quick keys, press and hold the [0] key from the Main keypad, enter the [INSTALLER CODE] and then press from the Center keypad:

Key [1] = *Test Report*: Send the "Test Report" report code programmed in section [171] (page 12) to the monitoring station.

Key [2] = *Cancel Communication*: Cancels all communication with the WinLoad software or with the monitoring station until the next reportable event.

Key [3] = *Answer WinLoad Software*: Will force the console to answer an incoming call from the monitoring station that is using the WinLoad software.

Key [4] = *Call WinLoad Software*: Will dial the PC telephone number programmed in section [115] (page 10) in order to initiate communication with a computer using the WinLoad software.

Key [5] = *Installer Test Mode*: The installer test mode will allow you to perform walk tests where the siren will squawk to indicate opened zones. Press the [5] key again to exit.

# Zone Programming

Zone Definitions (000 → [4] → [6])	
000 = Zone Disabled (default)	008 = Delayed Fire Zone
001 = Entry Delay 1	009 = 24Hr. Burglary Zone
002 = Entry Delay 2	010 = 24Hr. Hold-up Zone
003 = Follow Zone	011 = 24Hr. Buzzer Zone
004 = Follow / Stay Zone	012 = 24Hr. Gas Zone
005 = Instant Zone	013 = 24Hr. Heat Zone
006 = Instant / Stay Zone	014 = 24Hr. Water Zone
007 = Instant Fire Zone	015 = 24Hr. Freeze Zone


Zone Options		
[1] = Auto-zone Shutdown (default)	[6] = Intellizone†	
[2] = Bypassable Zone (default)	[7] = Delay alarm transmission	
[3] = Future Use	[8] = Force Zone (default)‡	
[4]   [5] Zone Alarm Type		
OFF   OFF Audible alarm (default)		
OFF   ON Pulsed alarm		
ON   OFF Silent alarm		
ON   ON Report only		

† Intellizone is not for use in UL installations.  
‡ Force Arming is not permitted in UL installations.


Section	Description	Zone Definition	Zone Options
[001]	Zone 1: _____	____/____/____	1 2 3 4 5 6 7 8
[002]	Zone 2: _____	____/____/____	1 2 3 4 5 6 7 8
[003]	Zone 3: _____	____/____/____	1 2 3 4 5 6 7 8
[004]	Zone 4: _____	____/____/____	1 2 3 4 5 6 7 8
[005]	Zone 5: _____	____/____/____	1 2 3 4 5 6 7 8
[006]	Zone 6: _____	____/____/____	1 2 3 4 5 6 7 8
[007]	Zone 7: _____	____/____/____	1 2 3 4 5 6 7 8
[008]	Zone 8: _____	____/____/____	1 2 3 4 5 6 7 8
[009]	Zone 9: _____	____/____/____	1 2 3 4 5 6 7 8
[010]	Zone 10: _____	____/____/____	1 2 3 4 5 6 7 8
[011]	Zone 11: _____	____/____/____	1 2 3 4 5 6 7 8
[012]	Zone 12: _____	____/____/____	1 2 3 4 5 6 7 8
[013]	Zone 13: _____	____/____/____	1 2 3 4 5 6 7 8
[014]	Zone 14: _____	____/____/____	1 2 3 4 5 6 7 8
[015]	Zone 15: _____	____/____/____	1 2 3 4 5 6 7 8
[016]	Zone 16: _____	____/____/____	1 2 3 4 5 6 7 8
[017]	Zone 17: _____	____/____/____	1 2 3 4 5 6 7 8
[018]	Zone 18: _____	____/____/____	1 2 3 4 5 6 7 8
[019]	Zone 19: _____	____/____/____	1 2 3 4 5 6 7 8
[020]	Zone 20: _____	____/____/____	1 2 3 4 5 6 7 8
[021]	Zone 21: _____	____/____/____	1 2 3 4 5 6 7 8
[022]	Zone 22: _____	____/____/____	1 2 3 4 5 6 7 8
[023]	Zone 23: _____	____/____/____	1 2 3 4 5 6 7 8
[024]	Zone 24: _____	____/____/____	1 2 3 4 5 6 7 8
[025]	Zone 25: _____	____/____/____	1 2 3 4 5 6 7 8
[026]	Zone 26: _____	____/____/____	1 2 3 4 5 6 7 8
[027]	Zone 27: _____	____/____/____	1 2 3 4 5 6 7 8
[028]	Zone 28: _____	____/____/____	1 2 3 4 5 6 7 8
[029]	Zone 29: _____	____/____/____	1 2 3 4 5 6 7 8
[030]	Zone 30: _____	____/____/____	1 2 3 4 5 6 7 8
[031]	Zone 31: _____	____/____/____	1 2 3 4 5 6 7 8
[032]	Zone 32: _____	____/____/____	1 2 3 4 5 6 7 8

# Remote Control Button Programming

Section	RC#	Data (Default: 4DE0)				Section	RC#	Data (Default: 4DE0)			
[040] Default	1-16	_____	_____	_____	_____			_____	_____	_____	_____
[041]	1	_____	_____	_____	_____	[049]	9	_____	_____	_____	_____
[042]	2	_____	_____	_____	_____	[050]	10	_____	_____	_____	_____
[043]	3	_____	_____	_____	_____	[051]	11	_____	_____	_____	_____
[044]	4	_____	_____	_____	_____	[052]	12	_____	_____	_____	_____
[045]	5	_____	_____	_____	_____	[053]	13	_____	_____	_____	_____
[046]	6	_____	_____	_____	_____	[054]	14	_____	_____	_____	_____
[047]	7	_____	_____	_____	_____	[055]	15	_____	_____	_____	_____
[048]	8	_____	_____	_____	_____	[056]	16	_____	_____	_____	_____



**MG-REM1**



**MG-REM2**

### Button Options Table

- 0 - Button disabled
- 1 - Regular arming
- 2 - Stay arming
- 3 - Instant arming
- 4 - Force arming
- 5 - N/A
- 6 - N/A
- 7 - N/A
- 8 - Panic 1†
- 9 - Panic 2†
- A\* - Panic 3†
- B\* - PGM Activation (Event Group #7, see Appendix 1: PGM Event Table)
- C\* - PGM Activation (Event Group #8, see Appendix 1: PGM Event Table)
- D\* - Turn FM radio ON/OFF (MG-6160 only)
- E\* - FM radio memory scan (MG-6160 only)
- F\* - Non-medical alarm

\* = Hex values A to F are keys [17/1] to [22/6] from Magellan's Center Keypad. Refer to Figure 1 on page 2.  
 † = The panic feature (section [091] options [1] to [3]) must be enabled.

The button of the MG-REM1 and MG-REM2 remote controls has been permanently programmed to disarm the system. However, when the system is disarmed and the Magellan console's radio is on (MG-6160 only), the button can be used for volume control. The button's functionality cannot be altered. The button of the MG-REM2 remote control has been permanently programmed to request feedback from the system. The button's functionality cannot be altered.

When section [040] is accessed, the console will display the contents of section [041] and copy the saved value of that section to all remote options: [041] to [56].

# System Timers

Section	Data (value from 000 to 255)	Description	Defaults
[060]	___/___/___ seconds	Entry delay 1 (■■■→[4] →[4]) †	045 secs.
[061]	___/___/___ seconds	Entry delay 2 (■■■→[4] →[4]) †	045 secs.
[062]	___/___/___ seconds	Exit delay (■■■→[4] →[4]) ‡	060 secs.
[063]	___/___/___ minutes	Bell cut-off time (■■■→[4] →[4]) *	004 mins.
[064]	___/___/___ x 15 minutes	No movement time	Disabled
[065]	___/___/___ seconds (minimum 10 seconds)	Intellizone delay	045 secs.
[066]	___/___/___ seconds	Recent closing delay	Disabled
[067]	___/___/___ times	Auto-zone shutdown	005 times
[068]	___/___/___ seconds	PGM1 timer	Disabled
[069]	___/___/___ seconds	PGM2 timer	Disabled
[070]	___/___/___ minutes	Power failure report delay	015 mins.
[071]	___/___/___ days	Auto-test report	Disabled
[072]	___/___/___ rings	Number of rings	008 rings
[073]	___/___/___ seconds	TLM fail timer	032 secs.
[074]	___/___/___ seconds	Answering machine override delay	030 secs.
[075]	___/___/___ seconds	Delay alarm transmission	Disabled
[076]	___/___/___ seconds (maximum 130 seconds)	Delay between dialing attempts ▽	020 secs.
[077]	___/___/___ seconds	Pager/voice delay	005 secs.
[078]	___/___/___ seconds	Remote panic disarm lock delay	020 secs.
[079]	___/___/___ repetitions (maximum 10 repetitions)	Voice reporting message repetitions	003 reps.
[080]	___/___/___ days	Closing delinquency delay	Disabled
[081]	___/___/___ (000 to 007**)	Entry delay audio selection (■■■→[4] →[4])	003
[082]	___/___/___ (000 to 007**)	Exit delay audio selection (■■■→[4] →[4])	002
[083]	Future use	Future use	Future use
[084]	___/___:___/___ Hours	Auto-test report time	Disabled
[085]	___/___:___/___ Hours	Auto-arm time (■■■→[8] →[3])	Disabled

\*\* 000 = No tone; 001 = Beeping; 002 = Countdown; 003 = Tonality 1; 004 = Tonality 2; 005 = Tonality 3; 006 = Tonality 4; 007 = Radio tuner (MG-6160 only)

† For UL installations, the Entry delay must not exceed 45 seconds.

‡ For UL installations, the Exit delay must not exceed 60 seconds.

\* For UL installations, the Bell cut-off time must be a minimum of 4 minutes; for cUL installations, the Bell cut-off time must be a minimum of 5 minutes.

▽ For UL installations, the number of dialing attempts shall not exceed 10.

## On-board Programmable Outputs (PGMs)

Section	Description	Event Group #	Sub-group #	Default
[086]	PGM1 Activation Event	(___/___)	(___/___)	No event programmed
[087]	PGM1 Deactivation Event	(___/___)	(___/___)	No event programmed
[088]	PGM2 Activation Event	(___/___)	(___/___)	No event programmed
[089]	PGM2 Deactivation Event	(___/___)	(___/___)	No event programmed

Refer to *Appendix 1: PGM Event Table* on page 18 for the PGM events that can be used to program Magellan's PGM outputs.

# System Options

## [090] General Options

### Option

- [1] Access code length
- [2] Audible trouble warning (except AC power failures)
- [3] Lock master code
- [4] Use user code 16 as duress code
- [5] Console tamper supervision
- [6] Need code to bypass zones
- [7] PGM1 normal state
- [8] PGM2 normal state

### OFF

- 6 digits
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- N.O.
- N.O.

### ON

- 4 digits**
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- N.C.
- N.C.

**Bold = Default setting**

## [091] General Options

### Option

- [1] Panic 1 (Emergency)
- [2] Panic 2 (Auxiliary)
- [3] Panic 3 (Fire)
- [4] Panic 1: Silent or audible alarm
- [5] Panic 2: Silent or audible alarm
- [6] Panic 3: Silent or audible alarm
- [7] PGM1 used as (MG-6160 only)
- [8] PGM2 used as (MG-6160 only)

### OFF

- Disabled
- Disabled
- Disabled
- Silent
- Silent
- Silent
- Direct output
- Direct output

### ON

- Enabled
- Enabled
- Enabled
- Audible
- Audible
- Audible
- X10 output 7
- X10 output 8

**Bold = Default setting**

## [092] Arming/Disarming Options

### Option

- [1] Auto-arm on time (  → [8] → [2] ) †
- [2] Auto-arm on no movement †
- [3] Auto-arm in what arming mode †
- [4] Switch to Stay arming if no entry delay is opened
- [5] Regular arming switches to Force arming †
- [6] Stay arming switches to Force arming †
- [7] One-touch Regular/Force arming †
- [8] One-touch Stay arming

### OFF

- Disabled
- Disabled
- Regular
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

### ON

- Enabled
- Enabled
- Stay
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**Bold = Default setting**

† Force arming and Auto-arming are not for use in UL installations.

## [093] Arming/Disarming Options

### Option

- [1] Future use
- [2] Future use
- [3] Bell squawk when arming/disarming with remote control \*
- [4] No exit delay when arming with remote control
- [5] Report system disarming
- [6] Exit delay termination
- [7] Follow zones become Entry Delay 2 zones when Delay zone is bypassed
- [8] FM tuner ON when system is armed (  → [8] → [1] ) (MG-6160 only)

### OFF

- Future use
- Future use
- Disabled
- Disabled
- Always
- Disabled
- Disabled
- Disabled

### ON

- Future use
- Future use
- Enabled
- Enabled
- After alarm only**
- Enabled
- Enabled
- Enabled

**Bold = Default setting**

\* Bell Squawk on Arm must be enabled for UL installations.



**[094] Zone Options****Bold = Default setting****Option**

- [1]** Stay delay zones
- [2]** Report zone restore
- [3] & [4]** Tamper recognition options †
- | <b>[3]</b> | <b>[4]</b> |  |
|------------|------------|--|
| <b>OFF</b> | <b>OFF</b> | - <b>Disabled</b>  |
| OFF        | ON         | - Trouble only   |
| ON         | OFF        | - Disarmed: Trouble only<br>- Armed: Follow <i>zone's alarm type</i> (page 4)  |
| ON         | ON         | - Disarmed: Audible alarm<br>- Armed: Follow <i>zone's alarm type</i> (page 4) |
- [5]** Generate tamper trouble if detected on bypassed zone
- [6] & [7]** Wireless transmitter supervision options ‡
- | <b>[6]</b> | <b>[7]</b> |  |
|------------|------------|--|
| OFF        | OFF        | - Disabled *   |
| <b>OFF</b> | <b>ON</b>  | - <b>Trouble only</b>  |
| ON         | OFF        | - Disarmed: Trouble only<br>- Armed: Follow <i>zone's alarm type</i> (page 4)  |
| ON         | ON         | - Disarmed: Audible alarm<br>- Armed: Follow <i>zone's alarm type</i> (page 4) |
- [8]** Generate supervision trouble if detected on bypassed zone

- OFF**
- Disabled**
- On Bell cut-off**
- See table
- See table

- ON**
- Enabled
- On zone closure
- See table
- See table

- No**
- See table
- See table

- Yes
- See table
- See table

- No**

- Yes

† For UL installations, Tamper recognition options must be enabled.

‡ For UL installations, Wireless supervision options must be enabled.

\* For UL installations, if the zone is programmed as a wireless fire zone, supervision must be enabled and the check-in supervision time must be set at 80 minutes (section [096] option [7] on page 8).

**[095] Zone Options****Bold = Default setting****Option**

- [1]** Zone 31 is hardwire zone 1 \*
- [2]** Zone 32 is hardwire zone 2 \*
- [3]** EOL (End-Of-Line) resistors †
- [4]** Stay arm siren delay
- [5]** Future use
- [6]** Live Display Mode for Wireless Keypad (MG32WK)
- [7] & [8]** Future use

- OFF**
- Disabled**
- Disabled**
- No EOL**
- Disabled

- ON**
- Enabled
- Enabled
- Use EOL resistors
- Enabled**

- Disabled

- Enabled**

\* For UL installations, if either or both of the hardwired zones are enabled, then section [095] option [3] option must be enabled.

† This feature only applies to Magellan's onboard zone inputs. Section [095] options [1] and [2] must be ON in order to use this feature.

**[096] General Options****Bold = Default setting****Option**

- [1] & [2]** Doorbell 1 tone options
- | <b>[1]</b> | <b>[2]</b> |                 |
|------------|------------|-----------------|
| <b>OFF</b> | <b>OFF</b> | - <b>Tone 1</b> |
| OFF        | ON         | - Tone 2        |
| ON         | OFF        | - Tone 3        |
| ON         | ON         | - Tone 4        |
- [3] & [4]** Doorbell 2 tone options
- | <b>[3]</b> | <b>[4]</b> |                 |
|------------|------------|-----------------|
| OFF        | OFF        | - Tone 1        |
| <b>OFF</b> | <b>ON</b>  | - <b>Tone 2</b> |
| ON         | OFF        | - Tone 3        |
| ON         | ON         | - Tone 4        |
- [5]** Daylight savings time
- [6]** AC power failure warning \*
- [7]** Check-in supervision time
- [8]** RF Jamming supervision \*

- OFF**
- See table
- See table

- ON**
- See table
- See table

- See table
- See table

- See table
- See table

- Disabled**
- Disabled**
- 24Hrs**
- Disabled

- Enabled
- Enabled
- 80 minutes
- Enabled**

\* This option must be enabled for UL installations.

**[097] General Options****Bold = Default setting****Option**

- [1]** Volume boost on entry/exit delay
- [2]** Volume boost in speakerphone mode
- [3] to [8]** Future use

- OFF**
- Disabled**
- Disabled
- Future use

- ON**
- Enabled
- Enabled**
- Future use



**[098] Dialer Options****Bold = Default setting****Option****[1] & [2]** Telephone line monitoring options \*

[1]	[2]	
<b>OFF</b>	<b>OFF</b>	- TLM disabled
OFF	ON	- Generate a trouble
ON	OFF	- Generate audible alarm if armed
ON	ON	- Silent alarms become audible

**OFF**

- See table
- See table

**ON**

- See table
- See table

**[3]** Switch to pulse on 5th attempt **Disabled** Enabled**[4]** Call back **Disabled** Enabled**[5]** Alternate dialing **Disabled** Enabled**[6]** Force dial Disabled **Enabled****[7]** DTMF dialing Disabled **Enabled****[8]** Pulse ratio 1:2 **1:1.5**

\* For UL installations, the telephone line monitoring must be enabled if off-premise transmission is used.

**[099] Dialer Options 2 \*****Bold = Default setting****Option****[1]** Use monitoring station telephone number 2 as**OFF**

- Regular
- Future use

**ON**

- Backup**
- Future use

**[2] to [8]** Future use

\* For UL installations, only one telephone number is allowed.

**[100] Event Call Direction Options for:****Bold = Default setting****Arming / Disarming Report Codes****Option****[1]** Call monitoring station telephone number 1**OFF**

- Disabled
- Disabled**
- Disabled**
- Future use

**ON**

- Enabled**
- Enabled
- Enabled
- Future use

**[2]** Call monitoring station telephone number 2**[3]** Call Pager telephone number**[4]** Future use**Alarm / Alarm Restore Report Codes****[5]** Call monitoring station telephone number 1 Disabled **Enabled****[6]** Call monitoring station telephone number 2 **Disabled** Enabled**[7]** Call Pager telephone number Disabled **Enabled****[8]** Future use Future use Future use**[101] Event Call Direction Options for:****Bold = Default setting****Tamper / Tamper Restore Report Codes****Option****[1]** Call monitoring station telephone number 1**OFF**

- Disabled
- Disabled**
- Disabled**
- Future use

**ON**

- Enabled**
- Enabled
- Enabled
- Future use

**[2]** Call monitoring station telephone number 2**[3]** Call Pager telephone number**[4]** Future use**Trouble / Trouble Restore Report Codes****[5]** Call monitoring station telephone number 1 Disabled **Enabled****[6]** Call monitoring station telephone number 2 **Disabled** Enabled**[7]** Call Pager telephone number **Disabled** Enabled**[8]** Future use Future use Future use**[102] Event Call Direction Options for:****Bold = Default setting****Special Report Codes \*****Option****[1]** Call monitoring station telephone number 1**OFF**

- Disabled
- Disabled**
- Disabled**
- Future use

**ON**

- Enabled**
- Enabled
- Enabled
- Future use

**[2]** Call monitoring station telephone number 2**[3]** Call Pager telephone number**[4] to [8]** Future use

\* For UL installations, only one telephone number is allowed.



# Report Codes

Default = FF

Arming Report Codes		Special Arming Report Codes		Disarming Report Codes		Special Disarming Report Codes	
Section	Data	Section	Data	Section	Data	Section	Data
[120]	___/___ User Code 1 ___/___ User Code 2 ___/___ User Code 3 ___/___ User Code 4	[124]	___/___ Auto-arming ___/___ Late to close ___/___ No movement ___/___ Partial arming	[126]	___/___ User Code 1 ___/___ User Code 2 ___/___ User Code 3 ___/___ User Code 4	[130]	___/___ End auto-arm ___/___ Disarm via PC ___/___ Future use ___/___ Future use
[121]	___/___ User Code 5 ___/___ User Code 6 ___/___ User Code 7 ___/___ User Code 8	[125]	___/___ Quick-arming ___/___ Arming via PC ___/___ Future use ___/___ Future use	[127]	___/___ User Code 5 ___/___ User Code 6 ___/___ User Code 7 ___/___ User Code 8		
[122]	___/___ User Code 9 ___/___ User Code 10 ___/___ User Code 11 ___/___ User Code 12			[128]	___/___ User Code 9 ___/___ User Code 10 ___/___ User Code 11 ___/___ User Code 12		
[123]	___/___ User Code 13 ___/___ User Code 14 ___/___ User Code 15 ___/___ User Code 16			[129]	___/___ User Code 13 ___/___ User Code 14 ___/___ User Code 15 ___/___ User Code 16		

Default = FF

Alarm Report Codes		Alarm Report Codes		Alarm Restore Report Codes		Alarm Restore Report Codes	
Section	Data	Section	Data	Section	Data	Section	Data
[131]	___/___ Zone 1 ___/___ Zone 2 ___/___ Zone 3 ___/___ Zone 4	[135]	___/___ Zone 17 ___/___ Zone 18 ___/___ Zone 19 ___/___ Zone 20	[139]	___/___ Zone 1 ___/___ Zone 2 ___/___ Zone 3 ___/___ Zone 4	[143]	___/___ Zone 17 ___/___ Zone 18 ___/___ Zone 19 ___/___ Zone 20
[132]	___/___ Zone 5 ___/___ Zone 6 ___/___ Zone 7 ___/___ Zone 8	[136]	___/___ Zone 21 ___/___ Zone 22 ___/___ Zone 23 ___/___ Zone 24	[140]	___/___ Zone 5 ___/___ Zone 6 ___/___ Zone 7 ___/___ Zone 8	[144]	___/___ Zone 21 ___/___ Zone 22 ___/___ Zone 23 ___/___ Zone 24
[133]	___/___ Zone 9 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12	[137]	___/___ Zone 25 ___/___ Zone 26 ___/___ Zone 27 ___/___ Zone 28	[141]	___/___ Zone 9 ___/___ Zone 10 ___/___ Zone 11 ___/___ Zone 12	[145]	___/___ Zone 25 ___/___ Zone 26 ___/___ Zone 27 ___/___ Zone 28
[134]	___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ Zone 16	[138]	___/___ Zone 29 ___/___ Zone 30 ___/___ Zone 31 ___/___ Zone 32	[142]	___/___ Zone 13 ___/___ Zone 14 ___/___ Zone 15 ___/___ Zone 16	[146]	___/___ Zone 29 ___/___ Zone 30 ___/___ Zone 31 ___/___ Zone 32

Special Alarm Report Codes		Tamper Report Codes		Tamper Report Codes		Tamper Restore Report Codes	
Section	Data	Section	Data	Section	Data	Section	Data
[147]	___/___ Emer. panic	[149]	___/___ Zone 1	[153]	___/___ Zone 17	[157]	___/___ Zone 1
	___/___ Aux. panic		___/___ Zone 2		___/___ Zone 18		___/___ Zone 2
	___/___ Fire panic		___/___ Zone 3		___/___ Zone 19		___/___ Zone 3
	___/___ Recent closing		___/___ Zone 4		___/___ Zone 20		___/___ Zone 4
[148]	___/___ Zone shutdown	[150]	___/___ Zone 5	[154]	___/___ Zone 21	[158]	___/___ Zone 5
	___/___ Duress		___/___ Zone 6		___/___ Zone 22		___/___ Zone 6
	___/___ Paramedical		___/___ Zone 7		___/___ Zone 23		___/___ Zone 7
	___/___ Future use		___/___ Zone 8		___/___ Zone 24		___/___ Zone 8
		[151]	___/___ Zone 9	[155]	___/___ Zone 25	[159]	___/___ Zone 9
			___/___ Zone 10		___/___ Zone 26		___/___ Zone 10
			___/___ Zone 11		___/___ Zone 27		___/___ Zone 11
			___/___ Zone 12		___/___ Zone 28		___/___ Zone 12
		[152]	___/___ Zone 13	[156]	___/___ Zone 29	[160]	___/___ Zone 13
			___/___ Zone 14		___/___ Zone 30		___/___ Zone 14
			___/___ Zone 15		___/___ Zone 31		___/___ Zone 15
			___/___ Zone 16		___/___ Zone 32		___/___ Zone 16

Tamper Restore Report Codes		System Trouble Report Codes		System Troubles Restore Report Codes		Special Report Codes	
Section	Data	Section	Data	Section	Data	Section	Data
[161]	___/___ Zone 17	[165]	___/___ Future use	[168]	___/___ Future use	[171]	___/___ Cold start
	___/___ Zone 18		___/___ AC failure		___/___ AC failure		___/___ Test report
	___/___ Zone 19		___/___ Battery failure		___/___ Battery failure		___/___ Future use
	___/___ Zone 20		___/___ Timer loss		___/___ Timer prog.		___/___ WinLoad logout
[162]	___/___ Zone 21	[166]	___/___ Unit tamper	[169]	___/___ Unit tamp. rest.	[172]	___/___ Installer logon
	___/___ Zone 22		___/___ Fail to comm.		___/___ Future use		___/___ Installer logout
	___/___ Zone 23		___/___ TX low battery		___/___ TX low battery		___/___ Delinquency
	___/___ Zone 24		___/___ TX superv. loss		___/___ TX superv. rest.		___/___ Future use
[163]	___/___ Zone 25	[167]	___/___ RF jamming supervision	[167]	___/___ RF jamming supervision		
	___/___ Zone 26		___/___ Future use		___/___ Future use		
	___/___ Zone 27		___/___ Future use		___/___ Future use		
	___/___ Zone 28		___/___ Future use		___/___ Future use		
[164]	___/___ Zone 29						
	___/___ Zone 30						
	___/___ Zone 31						
	___/___ Zone 32						

Wireless Module Trouble Report Codes		Wireless Module Trouble Restore Report Codes	
[173]	___/___ PGM Supervision Loss	[175]	___/___ PGM Supervision Restored
	___/___ PGM Tamper		___/___ PGM Tamper Restored
	___/___ Keypad Supervision Loss		___/___ Keypad Supervision Restored
	___/___ Keypad Battery Trouble		___/___ Keypad Battery Trouble Restored
[174]	___/___ Keypad AC Failure	[176]	___/___ Keypad AC Restored
	___/___ Repeater Supervision Lost		___/___ Repeater Supervision Restored
	___/___ Repeater Battery Trouble		___/___ Repeater Battery Trouble Restored
	___/___ Repeater AC Failure		___/___ Repeater AC Restored

## System Settings

Section	Data	Description	Default
[180]	___/___/___	Installer code lock (Enter <b>147</b> to lock code, <b>000</b> to unlock code)	000
[181]	___/___/___/___/___/___/___	Installer code (■■■→[4] →[8])	000000
[182]	___/___/___/___/___/___/___	Maintenance code (■■■→[4] →[8])	111111
[199]	Reset all programmable sections to factory default values		
[200]	Reset Master code to default (123456)		

## Wireless Transmitter Assignment

Wireless transmitter assignment may be done through the console's menu (■■■→[4] →[6]). Alternatively, assign the transmitter by entering its serial number in the corresponding section:

Section	Serial Number	Section	Serial Number
[201]	Zone 1: ___/___/___/___/___/___	[219]	Zone 19: ___/___/___/___/___/___
[202]	Zone 2: ___/___/___/___/___/___	[220]	Zone 20: ___/___/___/___/___/___
[203]	Zone 3: ___/___/___/___/___/___	[221]	Zone 21: ___/___/___/___/___/___
[204]	Zone 4: ___/___/___/___/___/___	[222]	Zone 22: ___/___/___/___/___/___
[205]	Zone 5: ___/___/___/___/___/___	[223]	Zone 23: ___/___/___/___/___/___
[206]	Zone 6: ___/___/___/___/___/___	[224]	Zone 24: ___/___/___/___/___/___
[207]	Zone 7: ___/___/___/___/___/___	[225]	Zone 25: ___/___/___/___/___/___
[208]	Zone 8: ___/___/___/___/___/___	[226]	Zone 26: ___/___/___/___/___/___
[209]	Zone 9: ___/___/___/___/___/___	[227]	Zone 27: ___/___/___/___/___/___
[210]	Zone 10: ___/___/___/___/___/___	[228]	Zone 28: ___/___/___/___/___/___
[211]	Zone 11: ___/___/___/___/___/___	[229]	Zone 29: ___/___/___/___/___/___
[212]	Zone 12: ___/___/___/___/___/___	[230]	Zone 30: ___/___/___/___/___/___
[213]	Zone 13: ___/___/___/___/___/___	[231]	Zone 31: ___/___/___/___/___/___
[214]	Zone 14: ___/___/___/___/___/___	[232]	Zone 32: ___/___/___/___/___/___
[215]	Zone 15: ___/___/___/___/___/___	[233]	Wireless Doorbell 1: ___/___/___/___/___/___
[216]	Zone 16: ___/___/___/___/___/___	[234]	Wireless Doorbell 2: ___/___/___/___/___/___
[217]	Zone 17: ___/___/___/___/___/___		
[218]	Zone 18: ___/___/___/___/___/___		

## Wireless Output Assignment

Wireless output assignment may be done through the console's menu (**[F4]** → **[7]**). Alternatively, assign the PGM by entering its serial number in the corresponding section:

Section	Serial Number	Section	Serial Number
[235]	PGM1: ____/____/____/____/____/____	[237]	PGM3: ____/____/____/____/____/____
[236]	PGM2: ____/____/____/____/____/____	[238]	PGM4: ____/____/____/____/____/____

## Wireless Keypad Assignment

Wireless keypad assignment may be done through the console's menu (**[F4]** → **[8]**). Alternatively, assign the keypad by entering its serial number in the corresponding section:

Section	Serial Number	Section	Serial Number
[243]	Keypad 1: ____/____/____/____/____/____	[245]	Keypad 3: ____/____/____/____/____/____
[244]	Keypad 2: ____/____/____/____/____/____	[246]	Keypad 4: ____/____/____/____/____/____

## Wireless Repeater Assignment

Wireless repeater assignment may be done through the console's menu (**[F4]** → **[9]**). Alternatively, assign the repeater by entering its serial number in the corresponding section:

Section	Serial Number	Section	Serial Number
[247]	Repeater 1: ____/____/____/____/____/____	[248]	Repeater 2: ____/____/____/____/____/____

## Wireless Programmable Output (PGM) Settings

Section	Description	Event Group #	Sub-group #	Default
[260]	Wireless PGM1 Activation Event	(____/____)	(____/____)	No event programmed
[261]	Wireless PGM1 Deactivation Event	(____/____)	(____/____)	No event programmed
[262]	Wireless PGM2 Activation Event	(____/____)	(____/____)	No event programmed
[263]	Wireless PGM2 Deactivation Event	(____/____)	(____/____)	No event programmed
[264]	Wireless PGM3 Activation Event	(____/____)	(____/____)	No event programmed
[265]	Wireless PGM3 Deactivation Event	(____/____)	(____/____)	No event programmed
[266]	Wireless PGM4 Activation Event	(____/____)	(____/____)	No event programmed
[267]	Wireless PGM4 Deactivation Event	(____/____)	(____/____)	No event programmed

Refer to *Appendix 1: PGM Event Table* on page 18 for the PGM events that can be used to program Magellan's PGM outputs.

Section	Data	Description	Default
[280]	____/____/____ (000 to 008) †	Wireless PGM1 timer	000
[281]	____/____/____ (000 to 008) †	Wireless PGM2 timer	000
[282]	____/____/____ (000 to 008) †	Wireless PGM3 timer	000
[283]	____/____/____ (000 to 008) †	Wireless PGM4 timer	000

† 000 = No delay; 001 = 1s delay; 002 = 5s delay; 003 = 15s delay; 004 = 30s delay; 005 = 1min delay; 006 = 5min delay; 007 = 15min delay; 008 = 30min delay.

## Wireless Supervision Options

[290] Wireless Transmitter Supervision Zone Options *	Option	OFF	ON
[1]	Zone 1 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[2]	Zone 2 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[3]	Zone 3 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[4]	Zone 4 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[5]	Zone 5 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[6]	Zone 6 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[7]	Zone 7 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled
[8]	Zone 8 supervision	<input type="checkbox"/> Disabled	<input type="checkbox"/> Enabled

**Bold = Default setting**

**[291] Wireless Transmitter Supervision Zone Options \*****Bold = Default setting****Option**

- [1] Zone 9 supervision
- [2] Zone 10 supervision
- [3] Zone 11 supervision
- [4] Zone 12 supervision
- [5] Zone 13 supervision
- [6] Zone 14 supervision
- [7] Zone 15 supervision
- [8] Zone 16 supervision

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**[292] Wireless Transmitter Supervision Zone Options \*****Bold = Default setting****Option**

- [1] Zone 17 supervision
- [2] Zone 18 supervision
- [3] Zone 19 supervision
- [4] Zone 20 supervision
- [5] Zone 21 supervision
- [6] Zone 22 supervision
- [7] Zone 23 supervision
- [8] Zone 24 supervision

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

**[293] Wireless Transmitter Supervision Zone Options \*****Bold = Default setting****Option**

- [1] Zone 25 supervision
- [2] Zone 26 supervision
- [3] Zone 27 supervision
- [4] Zone 28 supervision
- [5] Zone 29 supervision
- [6] Zone 30 supervision
- [7] Zone 31 supervision
- [8] Zone 32 supervision

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled
- Enabled

\* For UL installations, all programmed wireless zones must be supervised. For any wireless Fire zones in UL installations, the supervision option must be enabled (section [094] options [6] & [7]) and the check-in supervision time must be set at 80 minutes (section [096] option [7]).

**[294] Wireless PGM Supervision Options****Bold = Default setting****Option**

- [1] Wireless PGM1 supervision
- [2] Wireless PGM2 supervision
- [3] Wireless PGM3 supervision
- [4] Wireless PGM4 supervision
- [5] to [8] Future Use

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled

**[295] Wireless Keypad Supervision Options****Bold = Default setting****Option**

- [1] Wireless Keypad 1 supervision
- [2] Wireless Keypad 2 supervision
- [3] Wireless Keypad 3 supervision
- [4] Wireless Keypad 4 supervision
- [5] to [8] Future Use

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled

**[296] Wireless Repeater Supervision Options****Bold = Default setting****Option**

- [1] Wireless Repeater 1 supervision
- [2] Wireless Repeater 2 supervision
- [3] to [8] Future Use

**OFF**

- Disabled
- Disabled

**ON**

- Enabled
- Enabled



**[297] Wireless PGM Console Supervision Options (Follow Alarm/Follow Bell)**

**Bold = Default setting**

**Option**

- [1] PGM1 console supervision
- [2] PGM2 console supervision
- [3] PGM3 console supervision
- [4] PGM4 console supervision
- [5] to [8] Future Use

**OFF**

- Disabled
- Disabled
- Disabled
- Disabled

**ON**

- Enabled
- Enabled
- Enabled
- Enabled

## Wireless Repeater Options

Wireless Repeater Options		<b>Bold = Default setting</b>		MG-RPT1 #1 [300]		MG-RPT1 #2 [306]	
Option		OFF	ON	OFF	ON	OFF	ON
[1]	Repeat Wireless Zone 1 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless Zone 2 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless Zone 3 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless Zone 4 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5]	Repeat Wireless Zone 5 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[6]	Repeat Wireless Zone 6 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[7]	Repeat Wireless Zone 7 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[8]	Repeat Wireless Zone 8 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Wireless Repeater Options		<b>Bold = Default setting</b>		MG-RPT1 #1 [301]		MG-RPT1 #2 [307]	
Option		OFF	ON	OFF	ON	OFF	ON
[1]	Repeat Wireless Zone 9 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless Zone 10 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless Zone 11 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless Zone 12 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5]	Repeat Wireless Zone 13 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[6]	Repeat Wireless Zone 14 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[7]	Repeat Wireless Zone 15 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[8]	Repeat Wireless Zone 16 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Wireless Repeater Options		<b>Bold = Default setting</b>		MG-RPT1 #1 [302]		MG-RPT1 #2 [308]	
Option		OFF	ON	OFF	ON	OFF	ON
[1]	Repeat Wireless Zone 17 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless Zone 18 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless Zone 19 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless Zone 20 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5]	Repeat Wireless Zone 21 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[6]	Repeat Wireless Zone 22 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[7]	Repeat Wireless Zone 23 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[8]	Repeat Wireless Zone 24 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Wireless Repeater Options		MG-RPT1 #1 [303]		MG-RPT1 #2 [309]	
		Bold = Default setting			
Option		OFF	ON	OFF	ON
[1]	Repeat Wireless Zone 25 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless Zone 26 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless Zone 27 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless Zone 28 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5]	Repeat Wireless Zone 29 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[6]	Repeat Wireless Zone 30 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[7]	Repeat Wireless Zone 31 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[8]	Repeat Wireless Zone 32 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Wireless Repeater Options		MG-RPT1 #1 [304]		MG-RPT1 #2 [310]	
		Bold = Default setting			
Option		OFF	ON	OFF	ON
[1]	Repeat Wireless 2-Way PGM 1 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless 2-Way PGM 2 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless 2-Way PGM 3 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless 2-Way PGM 4 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5] to [8]	Future Use	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Wireless Repeater Options		MG-RPT1 #1 [305]		MG-RPT1 #2 [311]	
		Bold = Default setting			
Option		OFF	ON	OFF	ON
[1]	Repeat Wireless Keypad 1 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[2]	Repeat Wireless Keypad 2 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[3]	Repeat Wireless Keypad 3 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[4]	Repeat Wireless Keypad 4 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[5]	Repeat Doorbell 1 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[6]	Repeat Doorbell 2 Signals	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[7] & [8]	Future Use	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

# Appendix 1: PGM Event Table

Event Group #	Sub-group #
00 = Zone closed 01 = Zone opened	01 to 32 = Zone number 99 = Any zone number
02 = System status	00 = N/A 01 = N/A 02 = Silent alarm 03 = Buzzer alarm 04 = Steady alarm 05 = Pulsed alarm 06 = Strobe 07 = Siren stopped 08 = Squawk ON* 09 = Squawk OFF* 10 = Ground start 11 = System disarmed 12 = System armed 13 = Entry delay engaged 99 = Any system status event
03 = Bell status	00 = Bell OFF 01 = Bell ON 02 = Bell Squawk Arm 03 = Bell Squawk Disarm
04 = Future use	Future use
05 = Non-reportable event	00 = Telephone line trouble 01 = Future use 02 = Arm with no entry delay 03 = Arm in Stay mode 04 = Arm in Force mode 05 = Full arm when armed in Stay mode 06 = PC fail to communicate 07 = Future use 08 = Future use
<p>* Squawk ON/OFF is similar to Bell ON/OFF except it follows the arming/disarming even if section [093] option [3] is disabled (no bell squawk when arming/disarming with remote control). These 2 events are used to activate/deactivate a light, strobe, or any other PGM with squawk activation/deactivation capabilities.</p>	
05 = Non-reportable event (cont.)	09 = Doorbell 1 battery trouble 10 = Doorbell 1 battery trouble restore 11 = Doorbell 2 battery trouble 12 = Doorbell 2 battery trouble restore 13 = Utility Key 1 pressed (keys [1] and [9] from the center keypad) 14 = Utility Key 2 pressed (keys [2] and [10] from the center keypad) 15 = Utility Key 3 pressed (keys [3] and [11] from the center keypad) 16 = Utility Key 4 pressed (keys [4] and [12] from the center keypad) 17 = Utility Key 5 pressed (keys [5] and [13] from the center keypad) 18 = Utility Key 6 pressed (keys [6] and [14] from the center keypad) 19 = Utility Key 7 pressed (keys [7] and [15] from the center keypad) 20 = Utility Key 8 pressed (keys [8] and [16] from the center keypad) 21 = User remote access granted (MG-6160 only) 22 = User remote access denied (MG-6160 only) 23 = Tamper generated alarm 24 = Supervision loss generated alarm 99 = Any non-reportable event
06 = Remote access 07 = PGM activation (Remote control button option "B"; see page 5) 08 = PGM activation (Remote control button option "C"; see page 5)	01 to 16 = User number 99 = Any user number
09 = Cold Start zone	01 to 32 = Zone number 99 = Any zone number
10 = Future use	Future use
11 = Smoke Maintenance signal	01 to 32 = Zone number 99 = Any zone number







Event Group #	Sub-group #
12 = <i>Delay zone alarm transmission</i>	01 to 32 = Zone number 99 = Any zone number
13 = <i>Arming with user</i>	01 to 32 = User number 99 = Any user number
14 = <i>Special arming</i>	00 = Auto-arming 01 = Late to close 02 = No movement arming 03 = Partial arming 04 = Quick arming 05 = Arming through WinLoad 99 = Any special arming event
15 = <i>Disarming with user</i> 16 = <i>Disarm after alarm with user *</i> 17 = <i>Alarm cancelled with user **</i>	01 to 16 = User number 99 = Any user number
18 = <i>Special disarming</i>	00 = Auto-arm cancelled 01 = Disarm through WinLoad 02 = Disarm through WinLoad after alarm * 03 = Alarm cancelled through WinLoad ** 04 = Non-medical alarm cancelled 99 = Any special disarming event
19 = <i>Zone bypassed</i> 20 = <i>Zone in alarm</i> 21 = <i>Fire alarm</i> 22 = <i>Zone alarm restore</i> 23 = <i>Fire alarm restore</i>	01 to 32 = Zone number 99 = Any zone number
24 = <i>Special alarm</i>	00 = Panic non-medical emergency 01 = Panic medical (this medical panic alarm is not UL approved) 02 = Panic fire 03 = Recent closing 04 = Global shutdown 05 = Duress alarm (User 16) 99 = Any special alarm event
25 = <i>Zone shutdown</i> 26 = <i>Zone tampered</i> 27 = <i>Zone tamper restore</i>	01 to 32 = Zone number 99 = Any zone number
28 = <i>New trouble</i>	00 = N/A 01 = AC failure 02 = Battery failure 03 = Clock loss 04 = Console tamper 05 = Fail to communicate to monitoring station 06 = Fail to communicate to voice report 07 = Fail to communicate to pager 08 = RF jamming supervision 99 = Any new trouble event
29 = <i>Trouble restored</i>	00 = Telephone line restored 01 = AC failure 02 = Battery failure 03 = Clock lost 04 = Console tamper restore 05 = N/A 06 = N/A 07 = N/A 08 = RF jamming restore 99 = Any trouble restore event
30 = <i>Low battery on zone</i> 31 = <i>Low battery on zone restore</i> 32 = <i>Zone supervision trouble</i> 33 = <i>Zone supervision restored</i>	01 to 32 = Zone number 99 = Any zone number

\* An armed system is or was in alarm and was disarmed by a user.

\*\* A disarmed system is or was in alarm (e.g. 24Hr. zone) and was disarmed by a user.

Event Group #	Sub-group #
34 = <i>Special</i>	00 = System power up 01 = Reporting test 02 = WinLoad logon 03 = WinLoad logoff 04 = Installer in programming mode 05 = Installer exited programming mode 06 = Closing delinquency delay elapsed 99 = Any special event
35 = <i>Non-medical alarm</i>	01 to 16 = User number 99 = Any user number
36 = <i>Zone triggered a utility report</i> 37 = <i>Signal strength weak 1</i> 38 = <i>Signal strength weak 2</i> 39 = <i>Signal strength weak 3</i> 40 = <i>Signal strength weak 4</i>	01 to 32 = Zone number 99 = Any zone number
41 & 42 = <i>Reserved</i>	Reserved
43 = <i>PGM supervision lost</i> 44 = <i>PGM supervision restored</i> 45 = <i>PGM tampered</i> 46 = <i>PGM tamper restored</i>	01 to 04 = PGM number 99 = Any PGM number
47 = <i>Wireless keypad supervision lost</i> 48 = <i>Wireless keypad supervision restored</i> 49 = <i>Wireless keypad battery trouble</i> 50 = <i>Wireless keypad battery trouble restored</i> 51 = <i>Wireless keypad AC failure</i> 52 = <i>Wireless keypad AC failure restored</i>	01 to 04 = Keypad number 99 = Any keypad number
53 = <i>Wireless repeater supervision lost</i> 54 = <i>Wireless repeater supervision restored</i> 55 = <i>Wireless repeater battery trouble</i> 56 = <i>Wireless repeater battery trouble restored</i> 57 = <i>Wireless repeater AC failure</i> 58 = <i>Wireless repeater AC failure restored</i>	01 to 02 = Repeater number 99 = Any repeater number
80 = <i>Fire delay started</i> 81 = <i>Fire delay cancelled</i>	01 to 32 = Zone number 99 = Any zone number
82 = <i>PGM cold start</i>	01 to 04 = PGM number 99 = Any PGM number
83 = <i>Keypad cold start</i>	01 to 04 = Keypad number 99 = Any keypad number
84 = <i>Repeater cold start</i>	01 to 02 = Repeater number 99 = Any repeater number

## Appendix 2: Specifications

<b>Input Voltage</b>	12Vac to 16Vac* 20VA or 12Vdc to 18Vdc 1A
<b>Max. Current Consumption</b>	1A
<b>Backup Battery</b>	7.2Vdc NiMH rechargeable battery pack (order # 0780100178)
<b>2 PGMs</b>	PGM1: N.O. solid-state relay (not polarized); Internal resistance 16 $\Omega$ (max.); Max. handling current 100mA PGM2: One low powered open-collector; Max. handling current 50mA
<b>Standby Battery Life</b>	Minimum 24 hours
<b>Temperature Range</b>	0°C to 50°C (32°F to 122°F)
<b>Auxiliary Output</b>	When using an AC or DC power source, the auxiliary output provides 13.8V (200mA maximum)†
<b>Approvals</b>	    
	* It is recommended that you use a 12Vac 1A transformer to power the Magellan console. The console will generate less heat when connected to a 12Vac transformer than when connected to a 16.5Vac transformer. † To achieve this value, use a minimum of 15Vdc.

# Appendix 3: Connection Diagrams

## Power Connections

Figure 2: Connecting the AC Transformer




Figure 3: Connecting the DC Power Supply





Figure 4: Connecting the Battery




To order a battery pack, the battery pack's part number is:  
Paradox #0780100178.

Figure 5: Auxiliary Output


13.8Vdc, 200mA Auxiliary Output

Back view of the Magellan console.



## Telephone Line Connections

Figure 6: Telephone Line Direct Connect



Back view of the Magellan console.

To connect the telephone line directly to the console:

1. Connect a RJ31X to the R-1, T-1, RING and TIP terminals as shown at right.
2. Connect the telephone company wires and the home telephone to the RJ31X.







Figure 7: Line Plug Connection

Back view of the Magellan console.



**Do not connect the RJ-11 cable into this plug.**



To connect the telephone line directly to the console:

1. Insert one end of the 4-pin RJ-11 cable into the line plug of the Magellan console.
2. Insert the other end of the RJ-11 cable into a standard telephone wall plug.



# PGM Connections

Figure 8: PGM1 Connections

Back view of the Magellan console.






Figure 9: PGM2 Connections

Back view of the Magellan console.



# Hardwire Zone Connections


Figure 10: Hardwire Zone Connections



# Connecting the Radio Antenna (MG-6160 only)

Figure 11: Connecting the Radio Antenna


Back view of the Magellan console.



If the radio reception is not very good, connect the supplied radio antenna to the ANT terminal of the Magellan console. Move the antenna around until the spot with the best reception is found.

## Connecting to a UIP-256


Figure 12: Connecting to a UIP-256 Universal In-Field Programmer





## X10 Transmitter Connections (MG-6160 only)

Figure 13: Connecting the X10 Transmitter

1. Connect one end of the inverted 4-pin RJ-11 cable into the **X10** plug of the console.
2. Connect the other end of the inverted 4-pin RJ-11 cable into the X10 transmitter.
3. Plug the X10 transmitter into a standard wall outlet.


 For information on programming the X10 features of Magellan, refer to the X10 Operation User Guide which can be found and downloaded for free from our Web site at [paradox.com](http://paradox.com).

 X10 devices (transmitters, modules, etc.) are not supplied and cannot be purchased through Paradox Security Systems Ltd.




## Connecting Magellan to WinLoad

Figure 14: Connecting Magellan to WinLoad



## Connecting a Paradox Memory Key (PMC-4)

Figure 15: Connecting a Paradox Memory Key (PMC-4)



### Download Data to *Destination* Console

To download the data of a memory key into a console:

1. Remove power from the Magellan console (AC and battery) and connect the memory key to the 5-pin connector on the left side of the back of the console as shown above.
2. Re-apply both AC and battery power to the console.
3. Press the **[OK]** key and Magellan will begin downloading the data from the memory key.

### Copy Data to Memory Key from *Source* Console

To copy the contents of a console into the memory key.

1. Remove power from the Magellan console (AC and battery) and connect the memory key to the 5-pin connector on the left side of the back of the console as shown above. Re-apply both AC and battery power to the console.
2. Press the **[NEXT]** key and then the **[OK]** key. Magellan will begin copying its data into the memory key.




**The installer code of the Magellan console used to download data to the memory key must be the same installer code programmed in the Magellan console that is to download the contents from the same memory key. If the installer codes do not match, the contents of the memory key cannot be downloaded into the receiving console.**


**Example: The contents of the Magellan console A will be copied into memory key B. The installer code for console A is 111111. In order to download the contents of memory key B into the Magellan console C, the installer code programmed in console C must also be 111111.**

## Tabletop Mounting

Figure 16: Tabletop Mounting



- To mount the Magellan console on a tabletop the wall plate has to be inserted beforehand:
1. Slide the wall plate's tabs labeled **B** into the Magellan console's open slots labeled **D** (see Figure 17 on page 27).
  2. Insert two screws (included) through the wall plate's screw holes labeled **C** into holes labeled **E** in the Magellan console (see Figure 17 on page 27).
  3. Insert the two plastic feet (included) into the appropriate holes on the back plate of the Magellan console as shown at left.
  4. Attach the two rubber stops (included) to the lower edge of the wall plate as shown at left.


 The plastic feet are used to raise the Magellan console to a slight angle for easy viewing while the rubber stops prevent the console from sliding when Magellan is being used.



**Tabletop mounting may not be an approved installation method by local regulations. It is recommended that the local regulations be verified prior to installing the Magellan console using this method.**

## Mounting Magellan on the Wall

Figure 17: Mounting Magellan onto the Wall Plate




To mount the wall plate:

1. Place the wall plate on the desired spot of the wall.
2. Drill and insert the screws into the holes labeled **A** at left.

To mount the Magellan console:

1. Place the console back plate flush against the mounted wall plate.
2. Slide the Magellan's open slots labeled **D** (see Inset 1 below) onto the wall plate's tabs labeled **B**.
3. Gently apply downward pressure to insert the wall plate's tabs into Magellan's open slots.
4. Insert two screws through the wall plate's screw holes labeled **C** and into Magellan's back plate screw holes labeled **E** (see Inset 1 below). This will secure the console to the wall.

Inset 1: Magellan's Backplate



# Appendix 4: Ademco Contact ID Report Codes

CID#	Reporting Code	Programming Value
<b>Medical Alarms - 100</b>		
100	Medical alarm *	01
101	Pendant transmitter	02
102	Fail to report in	03
<b>Fire Alarms - 110</b>		
110	Fire alarm	04
111	Smoke	05
112	Combustion	06
113	Water flow	07
114	Heat	08
115	Pull station	09
116	Duct	0A
117	Flame	0B
118	Near alarm	0C
<b>Panic Alarms - 120</b>		
120	Panic Alarm	0D
121	Duress	0E
122	Silent	0F
123	Audible	10
124	Duress - Access grated	
125	Duress - Egress granted	12
<b>Burglar Alarms - 130</b>		
130	Burglary	13
131	Perimeter	14
132	Interior	15
133	24-hour	16
134	Entry/Exit	17
135	Day/Night	18
136	Outdoor	19
137	Tamper	1A
138	Near alarm	1B
139	Intrusion verified	1C
<b>General Alarms - 140</b>		
140	General alarm	1D
141	Polling loop open	1E
142	Polling loop short	1F
143	Expansion module failure	20
144	Sensor tamper	21
145	Expansion module tamper	22
146	Silent burglary	23
147	Sensor supervision failure	24
<b>24-hour Non-burglary - 150 and 160</b>		
150	24-hour non-burglary	25

CID#	Reporting Code	Programming Value
151	Gas detected	26
152	Refrigeration	27
153	Loss of heat	28
154	Water leakage	29
155	Foil break	2A
156	Day trouble	2B
157	Low bottled gas level	2C
158	High temperature	2D
159	Low temperature	2E
161	Loss of air flow	2F
162	Carbon monoxide detected	30
163	Tank level	31
<b>Fire Supervisory - 200 and 210</b>		
200	Fire supervisory	32
201	Low water pressure	33
202	Low CO <sub>2</sub>	34
203	Gate valve sensor	35
204	Low water level	36
205	Pump activated	37
206	Pump failure	38
<b>System Troubles - 300 and 310</b>		
300	System trouble	39
301	AC loss	3A
302	Low system battery	3B
303	RAM checksum bad	3C
304	ROM checksum	3D
305	System reset	3E
306	Panel program changed	3F
307	Self-test failure	40
308	System shutdown	41
309	Battery test failure	42
310	Ground fault	43
311	Battery missing/dead	44
312	Power supply over current limit	45
313	Engineer reset	46
<b>Sounder/Relay Troubles - 320</b>		
320	Sounder/relay	47
321	Bell 1	48
322	Bell 2	49
323	Alarm relay	4A
324	Trouble relay	4B
325	Reversing relay	4C
326	Notification appliance chk. #3	4D

CID#	Reporting Code	Programming Value
327	Notification appliance chk. #4	4E
<b>System Peripheral Troubles - 330 and 340</b>		
330	System peripheral	4F
331	Polling loop open	50
332	Polling loop short	51
333	Expansion module failure	52
334	Repeater failure	53
335	Local printer paper out	54
336	Local printer failure	55
337	Exp. module DC loss	56
338	Exp. module low battery	57
339	Exp. module reset	58
341	Exp. module tamper	59
342	Exp. module AC loss	5A
343	Exp. module self-test fail	5B
344	RF receiver jam detect	5C
<b>Communication Troubles - 350 and 360</b>		
350	Communication	5D
351	Telco 1 fault	5E
352	Telco 2 fault	5F
353	Long range radio	60
354	Fail to communicate	61
355	Loss of radio supervision	62
356	Loss of central polling	63
357	Long range radio VSWR prob.	64
<b>Protection Loop Troubles - 370</b>		
370	Protection loop	65
371	Protection loop open	66
372	Protection loop short	67
373	Fire trouble	68
374	Exit error alarm	69
375	Panic zone trouble	6A
376	Hold-up zone trouble	6B
377	Swinger trouble	6C
378	Cross-zone trouble	6D
<b>Sensor Troubles - 380 and 390</b>		
380	Sensor trouble	6E
381	Loss of supervision - RF	6F
382	Loss of supervision - RPM	70
383	Sensor tamper	71
384	RF transmitter low battery	72
385	Smoke detector Hi sensitivity	73
386	Smoke detector Low sensitivity	74



CID#	Reporting Code	Programming Value
387	Intrusion detector Hi sensitivity	75
388	Intrusion detector Low sensitivity	76
389	Sensor self-test failure	77
391	Sensor watch trouble	78
392	Drift compensation error	79
393	Maintenance alert	7A
<b>Open/Close - 400</b>		
400	Open/Close	7B
401	Open/Close by user	7C
402	Group open/close	7D
403	Automatic open/close	7E
404	Late to open/close	5E
405	Deferred open/close	5F
406	Cancel	7F
407	Remote arm/disarm	80
408	Quick arm	81
409	Keyswitch open/close	82
<b>Remote Access - 410</b>		
411	Call back request made	83
412	Success - download access	84
413	Unsuccessful access	85
414	System shutdown	86
415	Dialer shutdown	87
416	Successful upload	88
<b>Access Control - 420 and 430</b>		
421	Access denied	89
422	Access report by user	8A
423	Forced access	8B
424	Egress denied	8C
425	Egress granted	8D
426	Access door propped open	8E
427	Access point door status monitor trouble	8F
428	Access point request to exit	90
429	Access program mode entry	91
430	Access program mode exit	92
431	Access threat level change	93
432	Access relay/trigger fail	94
433	Access RTE shunt	95
434	Access DSM shunt	96
<b>Arming - 440 and 450</b>		
441	Armed Stay	97
442	Keyswitch armed Stay	98
450	Exception open/close	99

CID#	Reporting Code	Programming Value
451	Early open/close	9A
452	Late open/close	9B
453	Failed to open	9C
454	Failed to close	9D
455	Auto-arm failed	9E
456	Partial arm	9F
457	Exit error (user)	A0
458	User on premises	A1
459	Recent close	A2
<b>System - 460</b>		
461	Wrong code entry	A3
462	Legal code entry	A4
463	Re-arm after alarm	A5
464	Auto-arm time extended	A6
465	Panic alarm reset	A7
466	Service ON/OFF premises	A8
<b>Sounder Relay Disabled - 520</b>		
520	Sounder/Relay disabled	A9
521	Bell 1 disabled	AA
522	Bell 2 disabled	AB
523	Alarm relay disabled	AC
524	Trouble relay disabled	AD
525	Reversing relay disabled	AE
526	Notification appliance chk. #3 disabled	AF
527	Notification appliance chk. #4 disabled	B0
<b>Modules - 530</b>		
531	Module added	B1
532	Module removed	B2
<b>Communication Disables - 550 and 560</b>		
551	Dialer disabled	B3
552	Radio transmitter disabled	B4
<b>Bypasses - 570</b>		
570	Zone bypass	B5
571	Fire bypass	B6
572	24Hr. zone bypass	B7
573	Burglary bypass	B8
574	Group bypass	B9
575	Swinger bypass	BA
576	Access zone shunt	BB
577	Access point bypass	BC
<b>Test/Misc. - 600</b>		
601	Manual trigger test	BD
602	Periodic test report	BE

CID#	Reporting Code	Programming Value
603	Periodic RF transmission	BF
604	Fire test	C0
605	Status report to follow	C1
606	Listen-in to follow	C2
607	Walk test mode	C3
608	Periodic test - system trouble present	C4
609	Video transmitter active	C5
611	Point test OK	C6
612	Point not tested	C7
613	Intrusion zone walk tested	C8
614	Fire zone walk tested	C9
615	Panic zone walk tested	CA
616	Service request	CB
621	Event log reset	CC
622	Event log 50% full	CD
623	Event log 90% full	CE
624	Event log overflow	CF
625	Time/Date reset	D0
626	Time/Date inaccurate	D1
627	Program mode entry	D2
628	Program mode exit	D3
629	32-hour event log marker	D4
630	Schedule change	D5
631	Exception schedule change	D6
632	Access schedule change	D7
654	System inactivity	D8



# Appendix 5: Automatic Report Code List

System Event	Default Contact ID Report Code when using sections [790] to [795]	Default SIA Report Code when using sections [790] to [795]
Arming with Master Code (##)	3 4A1 - Close by user	CL - Closing Report
Arming with User Code (##)	3 4A1 - Close by user	CL - Closing Report
Arming with Keypad (##)	3 4A9 - Keypad Close	CS - Closing Keypad
Auto Arming	3 4A3 - Automatic Close	CA - Automatic Closing
Arm with PC software	3 4A7 - Remote arm/disarm	CL - Closing Report
Late To Close	3 4A4 - Late to Close	OT - Late to Close
No Movement	3 4A4 - Late to Close	NA - No Activity
Partial arming	1 574 - Group bypass	CG - Close Area
Quick arming	3 408 - Quick arm	CL - Closing Report
Closing Delinquency	1 654 - System Inactivity	CD - System Inactivity
Disarm with Master Code (##)	1 4A1 - Open by user	OP - Opening Report
Disarm with User Code (##)	1 4A1 - Open by user	OP - Opening Report
Disarm with Keypad (##)	1 4A9 - Keypad Open	OS - Opening Keypad
Disarm after alarm* with Master Code (##)	1 4A1 - Open by user	OP - Opening Report
Disarm after alarm* with User Code (##)	1 4A1 - Open by user	OP - Opening Report
Disarm after alarm* with Keypad (##)	1 4A1 - Keypad Open	OS - Opening Keypad
Cancel alarm** with Master Code (##)	1 4A6 - Open by user	OR - Disarm from Alarm
Cancel alarm** with User Code (##)	1 4A6 - Open by user	OR - Disarm from Alarm
Cancel alarm** with Keypad (##)	1 4A6 - Keypad Open	OS - Opening Keypad
Auto Arming Cancellation	1 4A5 - Deferred Open/Close	CE - Closing Extend
Disarm with PC software	1 4A7 - Remote arm/disarm	OP - Opening Report
Disarm after an alarm with PC software	1 4A7 - Remote arm/disarm	OR - Disarm From Alarm
Quick disarm	1 408 - Quick disarm	OP - Opening Report
Zone Bypassed (##)	1 57A - Zone bypass	UB - Untyped Zone Bypass
Zone alarm (##)	1 13A - Burglary Alarm	BA - Burglary Alarm
Fire alarm (##)	1 11A - Fire alarm	FA - Fire Alarm
Zone alarm restore (##)	3 13A - Burglary Alarm Restore	BH - Burglary Alarm Restore
Fire alarm restore (##)	3 11A - Fire alarm Restore	FH - Fire Alarm Restore
Panic 1 - Emergency	1 12A - Panic alarm	PA - Panic Alarm
Panic 2 - Medical	1 1AA - Medical alarm	MA - Medical Alarm
Panic 3 - Fire	1 115 - Pull Station	FA - Fire Alarm
Recent closing	3 4AA - Open/Close	CR - Recent Closing
Global zone shutdown	1 574 - Group bypass	CG - Close Area
Duress alarm	1 121 - Duress	HA - Hold-up Alarm
Zone shutdown (##)	1 57A - Zone bypass	UB - Untyped Zone Bypass
Zone tampered (##)	1 144 - Sensor tamper	TA - Tamper Alarm
Zone tamper restore (##)	3 144 - Sensor tamper restore	TR - Tamper Restoral
Keypad Lockout	1 421 - Access denied	JA - User Code Tamper

\* An armed system is or was in alarm and was disarmed by a user.

\*\* A disarmed system is or was in alarm (e.g. 24Hr. zone) and was disarmed by a user.

System Event	Default Contact ID Report Code when using sections [790] to [795]	Default SIA Report Code when using sections [790] to [795]
AC Failure	1 3A1 - AC loss	AT - AC Trouble
Battery Failure	1 3A9 - Battery test failure	YT - System Battery Trouble
Auxiliary supply trouble	1 3AA - System trouble	YP - Power Supply Trouble
Bell output current limit	1 321 - Bell 1	YA - Bell Fault
Bell absent	1 321 - Bell 1	YA - Bell Fault
Clock lost	1 626 - Time/Date inaccurate	JT - Time Changed
Fire loop trouble	1 373 - Fire trouble	FT - Fire Trouble
TLM trouble restore	3 351 - Telco 1 fault restore	LR - Phone Line restoral
AC Failure restore	3 3A1 - AC loss restore	AR - AC Restoral
Battery Failure restore	3 3A9 - Battery test restore	YR - System Battery Restoral
Auxiliary supply trouble restore	3 3AA - System trouble restore	YQ - Power Supply restored
Bell output current limit restore	3 321 - Bell 1 restore	YH - Bell Restored
Bell absent restore	3 321 - Bell 1 restore	YH - Bell Restored
Clock programmed	3 625 - Time/Date Reset	JT - Time Changed
Fire loop trouble restore	3 373 - Fire trouble restore	FJ - Fire Trouble Restore
Combus fault	1 333 - Expansion module failure	ET - Expansion Trouble
Module tamper	1 145 - Expansion module tamper	TA - Tamper Alarm
Module ROM_RAM_error	1 3A4 - Rom checksum bad	YF - Parameter Checksum Fail
Module TLM trouble	1 352 - Telco 2 fault	LT - Phone Line trouble
Module fail to communicate to monitoring station.	1 354 - Fail to communicate	YC - Communication Fails
Printer fault	1 336 - Local printer failure	VT - Printer Trouble
Module AC Failure	1 3A1 - AC loss	AT - AC Trouble
Module battery failure	1 3A9 - Battery test failure	YT - System Battery Trouble
Module Auxiliary supply trouble	1 3AA - System trouble	YP - Power Supply Trouble
Bus fault restore	3 333 - Expansion module failure restore	ER - Expansion Restoral
Module tamper restore	3 145 - Expansion module tamper restore	TR - Tamper Restoral
Module ROM_RAM_error restore	3 3A4 - Rom checksum bad restore	YG - Parameter Changed
Module TLM restore	3 352 - Telco 2 fault restore	LR - Phone Line Restoral
Printer fault restore	3 336 - Local printer failure restore	VR - Printer Restore
Module AC restore	3 3A1 - AC loss restore	AR - AC Restoral
Module battery restore	3 3A9 - Battery test failure restore	YR - System Battery Restoral
Module Auxiliary supply restore	3 3AA - System trouble restore	YQ - Power Supply Restored
Fail to communicate with monitoring station	1 354 - Fail to communicate	YC - Communication Fails
Module RF low battery	1 384 - RF transmitter low battery	XT - Transmitter Battery Trouble
Module RF battery restore	3 384 - RF transmitter battery restore	XR - Transmitter Battery Restoral
Module RF supervision trouble	1 381 - Loss of supervision - RF	US - Untype Zone Supervision
Module RF supervision restore	3 381 - Supervision restore - RF	UR - Untyped Zone Restoral
Cold Start	1 3A8 - System shutdown	RR - Power Up
Warm Start	1 3A5 - System reset	YW - Watchdog Reset
Test Report engaged	1 6A2 - Periodic test report	TX - Test Report
PC software communication finished	1 412 - Successful - download access	RS - Remote Program Success
Installer on site	1 627 - Program mode Entry	LB - Local Program
Installer programming finished	1 628 - Program mode Exit	LS - Local Program Success

## Warranty

Paradox Security Systems Ltd. ("Seller") warrants its products to be free from defects in materials and workmanship under normal use for a period of one year. Except as specifically stated herein, all express or implied warranties whatsoever, statutory or otherwise, including without limitation, any implied warranty of merchantability and fitness for a particular purpose, are expressly excluded. Because Seller does not install or connect the products and because the products may be used in conjunction with products not manufactured by Seller, Seller cannot guarantee the performance of the security system and shall not be responsible for circumstances resulting from the product's inability to operate. Seller obligation and liability under this warranty is expressly limited to repairing or replacing, at Seller's option, any product not meeting the specifications. Returns must include proof of purchase and be within the warranty period. In no event shall the Seller be liable to the buyer or any other person for any loss or damages whether direct or indirect or consequential or incidental, including without limitation, any damages for lost profits stolen goods, or claims by any other party, caused by defective goods or otherwise arising from the improper, incorrect or otherwise faulty installation or use of the merchandise sold.

Notwithstanding the preceding paragraph, the Seller's maximum liability will be strictly limited to the purchase price of the defective product. Your use of this product signifies your acceptance of this warranty.

BEWARE: Dealers, installers and/or others selling the product are not authorized to modify this warranty or make additional warranties that are binding on the Seller.

## Limitations of Alarm Systems

It must be understood that while your Paradox alarm system is highly advanced and secure, it does not offer any guaranteed protection against burglary, fire or other emergency (fire and emergency options are only available on certain Paradox models). This is due to a number of reasons, including but not limited to inadequate or improper installation/positioning, sensor limitations, battery performance, wireless signal interruption, inadequate maintenance or the potential for the system or telephone lines to be compromised or circumvented. As a result, Paradox does not represent that the alarm system will prevent personal injury or property damage, or in all cases provide adequate warning or protection.

Your security system should therefore be considered as one of many tools available to reduce risk and/or damage of burglary, fire or other emergencies, such other tools include but are not limited to insurance coverage, fire prevention and extinguish devices, and sprinkler systems.

We also strongly recommend that you regularly maintain your security systems and stay aware of new and improved Paradox products and developments.

## Warning for Connections to Non-Traditional Telephony (e.g. VoIP)

Paradox alarm equipment was designed to work effectively around traditional telephone systems. For those customers who are using a Paradox alarm panel connected to a non-traditional telephone system, such as "Voice Over Internet Protocol" (VoIP) that converts the voice signal from your telephone to a digital signal traveling over the internet, you should be aware that your alarm system may not function as effectively as with traditional telephone systems.

For example, if your VoIP equipment has no battery back-up, during a power failure your system's ability to transmit signals to the central station may be compromised. Or, if your VoIP connection becomes disabled, your telephone line monitoring feature may also be compromised. Other concerns would include, without limitation, Internet connection failures which may be more frequent than regular telephone line outages.

We therefore strongly recommend that you discuss these and other limitations involved with operating an alarm system on a VoIP or other non-traditional telephone system with your installation company. They should be able to offer or recommend measures to reduce the risks involved and give you a better understanding.

## TBR-21

In order to comply with TBR-21, standard force dialing must be enabled.

## UL AND ULC WARNINGS

### UL AND C-UL INSTALLATION NOTES

This equipment is UL listed in accordance with standard UL1023 (Household Burglar -- Alarm Systems Units), standard UL985 (Household Fire Warning Units) and standard UL1635 (Digital Alarm Communicator System Units). This equipment has the capability of being programmed with features not verified for use in UL installations. To stay within these standards, the installer should use the following guidelines when configuring the system:

- All components of the system should be UL listed for the intended application.
- If the system will be used for "Fire" detection, the installer should refer to NFPA Standards #72, Chapter 2. In addition, once installation is complete, the local fire authority must be notified of the installation.
- This equipment must be verified by a qualified technician once every three years.
- All keypads must use an anti-tamper switch.
- Maximum allowed entry delay is 45 seconds.
- Maximum allowed exit delay is 60 seconds.
- Minimum 4 minutes for bell cut-off time.
- The following features do not comply with UL requirements: Bypass Recall and Auto Trouble Shutdown.
- Do not connect the primary indicating device to a relay. The installer must use the bell output.
- To comply with UL985, the auxiliary power output should not exceed 200mA.
- Do not connect the zone ground terminal with UL Listed products.
- The metallic enclosure must be grounded to the cold water pipe.
- All outputs are Class 2 or power-limited, except for the battery terminal. The Class 2 and power-limited fire alarm circuits shall be installed using CL3, CL3R, CL3P, or substitute cable permitted by the National Electrical Code, ANSI/NFPA 70.


### RECOMMENDED:

- EOL resistor part #2011002000
- **For UL Installations:** Universal UB1640W 16.5VAC min **40VA**
- All outputs are rated from 11.3Vdc to 12.7Vdc
- 12Vdc 4Ah rechargeable acid/lead or gel cell backup battery (YUASA model #NP7-12 recommended) for residential use. Use a 7Ah battery to comply with fire requirements.
- Wheelock 46T-12 siren

## Legal


© 2004-2006 Paradox Security Systems Ltd. All rights reserved. Specifications may change without prior notice. One or more of the following US patents may apply: 6215399, 6111256, 5751803, 5721542, 5287111, 5119069, 5077549, 5920259, 5886632. Canadian and international patents may also apply. Magellan is a trademark or registered trademark of Paradox Security Systems Ltd. or its affiliates in Canada, the United States and/or other countries.







# Installer Menu Overview



† = Master Code only  
 [ ] = Installer Code only

