


Technical Support
 1 800 672 PAXT

support@paxton-access.co.uk

Technical help is available: **Monday - Friday from 5am - 5pm PST / 8am - 8pm EST**

Other documentation on all Paxton products can be found on our web site - <http://www.paxton-access.com/>

Fitting

Fix the back plate to the wall with the stainless steel screws provided in the fitting kit. The small slot in the plate edge should be positioned at the bottom.



Where the reader is to be fitted to a smooth surface, bulkhead, etc. a gasket is supplied to provide a weatherproof seal between the back plate and the mounting surface. (The reader has its own integral seal)

Locate the reader in the keyhole slots provided in the back plate. Make sure that the locking pin is close to the slot in the edge of the back plate. Rotate the reader clockwise until the locking pin engages in the slot.




To remove the reader, insert a small screwdriver into the cut out provided and use it to lift the locking pin. The reader can then be rotated anticlockwise to release it from the back plate.

Wiring



Cable extensions

Readers can be extended using Belden CR9540 10-core overall screened cable. The maximum cable length between reader and control unit is 100 yards.



White Labelled control units only provide 5v at the Red terminal. The red power wire for the reader should be connected directly to the 12v PCB supply terminal - as per diagram.

Frequently asked questions

Here is the list of topics about this product that receive the most technical support enquiries. We list them here to help you speed up the installation and trouble shooting process.

1 - Readers/Keypads not working

- . Software settings - Confirm that the settings of the reader or keypad are correct.
- . Connections - Check the wiring and integrity of reader/keypad terminal connections.
- . To confirm that an extended reader cable is not at fault, wire the reader direct into the reader port. If the reader works, this indicates a problem with the cable.
- . Supply voltage - confirm that the reader has sufficient voltage.
- . User token - Check that the user token used for testing the reader is operational.
- . Interference - Confirm whether the reader works when tested 'in hand' and not mounted on the wall. Ensure that readers are not mounted back to back or there is not interference from other RF devices.

2 - Readers / Keypads - Extending cable

- . Only Belden CR9538 /9540 can be used for cable extensions. CR9538 is 8 core for up to 25m, CR9540 10 core for 25-100m (maximum extension). When using CR9540, the two additional cores should be used to double up for power.

3 - Net2 - What to do if a user has no access

- . Check the reader LEDs when a card is shown:
 - . No LEDs - the reader has no power.
 - . No change in display - try the card on a known working readers. If there is still no response, replace the card.
 - . Green LED flashing when a card is presented, check the Relay 1 LED to check activity and the wiring to the lock.
 - . Red LED is flashing when a card is presented, check the validity of the user at the PC.
 - . - Check user's access level and ensure they have access by clicking on Current Validity.
 - . - Check the 'Valid Until' date and confirm this has not expired.
 - . Reinstate the ACU from the doors screen. Select the ACU's you wish to reinstate and then click OK.

4 - Switch2 - Adding an additional card pack

- . You need to be in possession of the original enrolment card. Present the original enrolment card to the reader and the Amber LED will flash, Green & Red LEDs will be off, then present the Enrolment card from the new card pack; the reader will beep and all LEDs will be lit. The additional cards will now be valid. Repeat this with each reader and with any additional card packs. Any valid enrolment card can be used to add further packs. This is the same for enrolling function card packs onto a system.

5 - Switch2 - How to reset the controller

- . Disconnect the power and remove the wires from the Green and Mauve terminals
- . Insert a wire link between the Green and Mauve terminals
- . Reconnect the power (the unit will bleep 4 times)
- . Disconnect the power and remove the link wire, reconnect the Green and Mauve wires
- . Reconnect the power (the unit will bleep 3 times per second). The unit is ready to be enrolled.

Suitability

Security sensitive doors 

Mounted on metal surface 

Wet environments 

Readers mounted together  300mm
**between
readers**

Specifications

Environment	Min	Max	
Operating temperatures - all items	-25 °C (-4 °F)	+55 °C (+131°F)	
Waterproof			IPX7
Cable length			5 yards
Electrical	Min	Max	
Voltage	8v DC	14v DC	
Current		130 mA	
Carrier frequency			125 kHz
Clock and data bit period			600 μs
Read Range	Token	Keyfob	Hands Free Token
	1 1/2"	1"	15"
Dimensions	Diameter	Depth	
	4"	5/8"	

The declaration of conformity may be consulted at - <http://paxton.info/596>

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.