

JADE COMPUTER PRODUCTS
CP/M 2.2 - DOUBLE D

THE FOLLOWING IS A LIST OF FILES PRESENT ON THE JADE DOUBLE D DISKETTE. A BRIEF DESCRIPTION IS ALSO INCLUDED.


ASM.COM	CP/M ASSEMBLER - PROVIDED BY DIGITAL RESEARCH.
X BIM.ASM	BOOTSTRAP INJECTION MODULE - PART 2 OF A SYSTEM BOOTSTRAP PROM. IN TDL MACRO ASSEMBLER SOURCE.
X BIM.HEX	BOOTSTRAP INJECTION MODULE - THIS FILES IN INTEL HEX FORMAT.
BIOS.ASM	BASIC I/O SYSTEM - PROVIDED BY DIGITAL RESEARCH. BIOS FOR MDS DEVELOPMENT SYSTEM.
V BIOSGEN.COM	BIOS GENERATOR UTILITY - USED TO READ AND WRITE AN IMAGE OF THE USERS CBIOS FROM AND TO SYSTEM TRACK 0. THE IMAGE OF CBIOS RESIDES AT 1000H TO 13FFH. USE DDT TO PUT THE CBIOS IMAGE AT THAT ADDRESS.
X BLT.ASM	BIOS LOADER TRANSIENT - SOURCE CODE FOR "COLD START LOADER" AS GENERATED BY MOVCPM.COM.
X BOOT.COM	BOOT - PRESENTED AS A COM FILE, IF EXECUTED BY A SINGLE DENSITY CP/M SYSTEM IN WHICH THE DOUBLE D ALSO IS PRESENT, THIS WILL BOOT THE DOUBLE D SYSTEM.
CBIOS.ASM	BASIC I/O SYSTEM - SKELETAL BIOS PROVIDED BY DIGITAL RESEARCH.
CPM20.COM	IMAGE OF COLD START LOADER, CCP AND BDOS IN THE SAME FORMAT AS GENERATED BY MOVCPM 20 * AND THEN SAVE 34 CPM20.COM.
X DCM.ASM	DISK CONTROLLER MODULE - SOURCE CODE (TDL Z80) FOR THE DOUBLE D ONBOARD Z80A.
X DCM.HEX	DISK CONTROLLER MODULE - INTEL HEX FORMAT OF DCM.
X DCMGEN.COM	DCM GENERATOR UTILITY - USED TO READ AND WRITE AN IMAGE OF THE USERS DCM FROM OR TO SYSTEM TRACK 0. THE IMAGE OF DCM RESIDES AT 1000H TO 13FFH. USE DDT TO PUT DCM IMAGE AT THIS ADDRESS AND TO MAKE PATCHES.
X DDBIOS.ASM	DOUBLE D BIOS - CP/M ASSEMBLER FORMAT SOURCE CODE FOR DOUBLE D BIOS. THIS ASSEMBLE IS LISTED IN THE SOFTWARE MANUAL.
X DDBIOS.HEX	DOUBLE D BIOS - INTEL HEX FORMAT DDBIOS FILE.
DDT.COM	DYNAMIC DEBUG TOOL - DIGITAL RESEARCH.
DEBLOCK.ASM	DEBLOCKING SOURCE CODE - DIGITAL RESEARCH.
DISKDEF.LIB	DISK DEFINITION LIBRARY - DIGITAL RESEARCH.
DUMP.ASM	FILE DUMP UTILITY - SOURCE BY DIGITAL RESEARCH.
DUMP.COM	FILE DUMP UTILITY - COM BY DIGITAL RESEARCH.
ED.COM	EDITOR UTILITY - DIGITAL RESEARCH.
X FORMAT.ASM	FORMAT UTILITY - DOUBLE D FORMAT PROGRAM SOURCE.
X FORMAT.COM	FORMAT UTILITY - DOUBLE D FORMAT PROGRAM. FORMATS ON ANY DRIVE A THROUGH D IN SINGLE AND DOUBLE DENSITY.
LOAD.COM	LOAD UTILITY - DIGITAL RESEARCH.
X MOVCPM.COM	CP/M RELOCATION UTILITY - GENERATES CP/M SYSTEM WITH BLT FOR JADE DOUBLE D.

OLDSYS.COM	SYSGEN UTILITY - DIGITAL RESEARCH SYSGEN.COM AS DOCUMENTED IN CP/M MANUALS.
PIP.COM	FILE TRANSFER UTILITY - DIGITAL RESEARCH.
X SBD.ASM	SYSTEM BOOT DRIVER - PART 1 OF SYSTEM PROM BOOT. ASSEMBLED SOURCE LISTING IS IN SOFTWARE MANUAL.
STAT.COM	SYSTEM STATUS UTILITY - DIGITAL RESEARCH.
SUBMIT.COM	CP/M BATCH SUBSYSTEM - DIGITAL RESEARCH.
* SYSGEN.COM	CSL/CCP/BDOS GENERATOR UTILITY - DOUBLE D SYSTEM TRACKS COMPATABLE. SIMILAR TO SYSGEN.COM DESCRIBED IN CP/M MANUALS BUT DOES NOT READ OR WRITE BIOS. USE BIOSGEN FOR YOUR CBIOS.
XSUB.COM	EXTENDED BATCH SUBSYSTEM - DIGITAL RESEARCH.

THE SYSTEM TRACKS HAVE A DIFFERENT LAYOUT THAN THE DISKETTES DISTRIBUTED BY DIGITAL RESEARCH. THIS SECTION PRESENTS A DISCRPTION OF THE SYSTEM TRACKS (0 AND 1) AS DISTRIBUTED FOR THE JADE DOUBLE D DISK CONTROLLER BOARD. THOSE MODULES RESIDING ON THE SYSTEM TRACKS WHICH OFTEN NEED TO BE MODIFIED FOR A SPECIFIC SYSTEM ARE ON TRACK 0, WHICH IS IN SINGLE DENSITY. CCP AND BDOS, WHICH ARE NOT MODIFIED BY THE USER ARE ON TRACK 1 IN DOUBLE DENSITY. ALL DATA TRACKS ARE IN SINGLE DENSITY SUCH THAT THE DOUBLE D DISTRIBUTION DISKETTE CAN BE READ AND MODIFIED ON MOST 8" SINGLE DENSITY CP/M SYSTEMS.

THE FOLLOWING TABLE SHOWS THE LAYOUT OF SYSTEM TRACK 0. THIS TRACK IS FORMATTED IN SINGLE DENSITY WITH 26 SEQUENTIALLY NUMBERED SECTORS.

SECTOR NUMBER	EXECUTION ADDRESS	FORMAT LD ADDR	MODULE NAME
01	N.A.	1000H	IDT
02	1380H (DD)	1080H	BLT
03		1100H	
04	4A00H+B	1180H	BIOS
05	4A80H+B	1200H	BIOS
06	4B00H+B	1280H	BIOS
07	4B80H+B	1300H	BIOS
08	4C00H+B	1380H	BIOS
09	4C80H+B	1400H	BIOS
10	4D00H+B	1480H	BIOS
11	4D80H+B	1500H	BIOS
12		1580H	RSV
13	1000H (DD)	1600H	DCM
14	1080H (DD)	1680H	DCM
15	1100H (DD)	1700H	DCM
16	1180H (DD)	1780H	DCM
17	1200H (DD)	1800H	DCM
18	1280H (DD)	1880H	DCM
19	1300H (DD)	1900H	DCM
20	1380H (DD)	1980H	DCM
21	1400H (DD)	1A00H	RSV
22	1480H (DD)	1A80H	RSV
23	1500H (DD)	1B00H	RSV
24	1580H (DD)	1B80H	RSV
25	1600H (DD)	1C00H	RSV
26	1680H (DD)	1C80H	RSV



THE FOLLOWING TABLE SHOWS THE LAYOUT OF SYSTEM TRACK 1. THIS TRACK IS FORMATTED IN DOUBLE DENSITY WITH 48 PHYSICALLY STAGGERED SECTORS.

SECTOR NUMBER	EXECUTION ADDRESS	FORMAT LD ADDR	MODULE NAME
01		1D00H	SPARE
02	3400H+B	1D80H	CCP
03	3480H+B	1E00H	CCP
04	3500H+B	1E80H	CCP
05	3580H+B	1F00H	CCP
06	3600H+B	1F80H	CCP
07	3680H+B	2000H	CCP
08	3700H+B	2080H	CCP
09	3780H+B	2100H	CCP
10	3800H+B	2180H	CCP
11	3880H+B	2200H	CCP
12	3900H+B	2280H	CCP
13	3980H+B	2300H	CCP
14	3A00H+B	2380H	CCP
15	3A80H+B	2400H	CCP
16	3B00H+B	2480H	CCP
17	3B80H+B	2500H	CCP
18	3C00H+B	2580H	BDOS
19	3C80H+B	2600H	BDOS
20	3D00H+B	2680H	BDOS
21	3D80H+B	2700H	BDOS
22	3E00H+B	2780H	BDOS
23	3E80H+B	2800H	BDOS
24	3F00H+B	2880H	BDOS
25	3F80H+B	2900H	BDOS
26	4000H+B	2980H	BDOS
27	4080H+B	2A00H	BDOS
28	4100H+B	2A80H	BDOS
29	4180H+B	2B00H	BDOS
30	4200H+B	2B80H	BDOS
31	4280H+B	2C00H	BDOS
32	4300H+B	2C80H	BDOS
33	4380H+B	2D00H	BDOS
34	4400H+B	2D80H	BDOS
35	4480H+B	2E00H	BDOS
36	4500H+B	2E80H	BDOS
37	4580H+B	2F00H	BDOS
38	4600H+B	2F80H	BDOS
39	4680H+B	3000H	BDOS
40	4700H+B	3080H	BDOS
41	4780H+B	3100H	BDOS
42	4800H+B	3180H	BDOS
43	4880H+B	3200H	BDOS
44	4900H+B	3280H	BDOS
45	4980H+B	3300H	BDOS
46		3380H	SPARE
47		3400H	SPARE
48		3480H	SPARE

SYSTEM TRACK GENERATOR UTILITIES:

THE THREE GENERATOR UTILITIES SYSGEN.COM, BIOSGEN.COM, AND DCMGEN.COM PROVIDE THE END USER THE ABILITY TO EXTRACT AND REWRITE VARIOUS SECTIONS OF THE SYSTEM TRACKS. THE FOLLOWING TABLE SHOWS WHICH SECTIONS OF MEMORY ARE USED BY EACH PROGRAM AND WHICH SYSTEM TRACK MODULES ARE READ OR REWRITTEN. SYSGEN.COM IS SIMILIAR TO THE SYSGEN.COM DESCRIBED IN THE CP/M 2.0 MANUAL SET. NOTICE THE DIFFERENCE IS THE BIOS MODULE. EACH OF THESE PROGRAMS PROVIDE A FILE LOAD FEATURE. AN EXAMPLE, IF YOU HAD A FILE CPM32.COM AND YOU WISHED TO WRITE THIS FILE TO THE SYSTEM TRACKS.

```
A>DDT CPM32.COM
(DDT DISPLAYS MESSAGE)
-GO
A>SYSGEN
(AND THEN WRITE YOUR FILE)
```

```
A>SYSGEN CPM32.COM
(YOU GET A FILE LOADED MESSAGE)
NOW WRITE YOUR FILE.
```

IN CHANGING THE CP/M SYSTEM SIZE, YOU MUST REWRITE BLT/CCP/BDOS USING SYSGEN.COM AND REWRITE BIOS USING BIOSGEN.COM. DCMGEN IS USED TO MODIFY DCM FOR SUCH PARAMETERS AND DISK DRIVE STEP TIMING. CONSULT YOUR DCM LISTING FOR THE TIMING PARAMETERS.

UTILITY	MODULE	TRACK	SECTORS	SYSTEM ADDRESS
SYSGEN.COM	BLT	0	2	0900-097FH
	CCP	1	2-17	0980-117FH
	BDOS	1	18-45	1180-1F7FH
BIOSGEN.COM	BIOS	0	4-11	1000-13FFH
DCMGEN.ASM	DCM	0	13-20	1000-13FFH

NOTES FOR RELEASE #1 DISKETTES. THE DDBIOS IS ASSEMBLED FOR A REV B DOUBLE D CONTROLLER BOARD. DDBIOS SOURCE SHOULD BE MODIFIED, REASSEMBLED, AND WRITTEN TO SYSTEM TRACK 0 FOR REV C BOARDS.

THE FOLLOWING JUMPERS SHOULD BE USED TO CONFIGURE A SHUGART 800
DISK DRIVE.

EACH DRIVE: A, B, C, Y, T2, DS, 800

DRIVE A: DS1

DRIVE B: DS2

DRIVE C: DS3

DIRVE D: DS4

LAST DRIVE: T1, T3, T4, T5, T6

THE L JUMPER IS SET DEPENDING ON THE -5V SUPPLY.
CONSULT YOU S800 MANUAL.

USE ONLY THESE JUMPERS, NO OTHERS.

NEW CP/M 2.2
BDOS FUNCTIONS

```
*****  
* FUNCTION 37:  RESET DRIVE      *  
*                               *  
*****  
* Entry Parameters:             *  
*   Register   C:  25H          *  
*   Register  DE:  Drive Vector *  
*                               *  
* Returned Value :              *  
*   Register   A:  00H          *  
*****
```

The RESET DRIVE function allows resetting of specified drive(s). The passed parameter is a 16 bit vector of drives to be reset, the least significant bit is drive A:.

In order to maintain compatibility with MP/M, CP/M returns a zero value.

```
*****  
* FUNCTION 40:  WRITE RANDOM WITH*  
*              ZERO FILL        *  
*****  
* Entry Parameters:             *  
*   Register   C:  28H          *  
*   Register  DE:  FCB Address *  
* Returned Value:               *  
*   Register   A:  Return Code *  
*****
```

The WRITE RANDOM WITH ZERO FILL operation is similar to FUNCTION 34: with the exception that a previously unallocated block is filled with zeros before the data is written.

DIGITAL RESEARCH CP/M R 22 FIELD SOFTWARE CHANGE

Copyright c 1980 Digital Research

ID# CPM22-0001 PROGRAM: BDOS ISSUE DATE: 02/19/80

Error Description: The following change affects only those CP/M systems which are using the optional blocking and deblocking algorithms listed in Appendix G of the CP/M Alteration Guide. If you are in doubt as to the applicability of this field change, please contact Digital Research or your CP/M distributor.

Patch Procedure: Ensure you have an archive copy of the distributed MOVCPM.COM file. Make changes to a version of MOVCPM.COM by carefully following the steps shown below: MOVCPM.COM is loaded into memory using DDT and the changes are made using the Assemble (A) and Set (S) commands. After making the changes, return to the console command processor using the Go (G) command, and SAVE the altered memory image on disk. The memory image on tracks 0 and 1 must also be updated. This can be accomplished by executing the new MOVCPM program, as described in the CP/M Alteration Guide, and integrating your customized I/O system.

```
ddt movecpm.com
DDT VERS 2.0
NEXT PC
2700 0100
-alc2
1CD2 nop
1CD3 nop
1CD4 lxi h,0
1CD7
```

```
-G0
```

```
save 38 movecpm.com
```

NOTE: This Field Software change is not installed in the CP/M version 2.2. It must be installed in all systems which use the deblocking algorithms listed in Appendix G of the CP/M Alteration Guide.

DD CONTROLLER

CONTROL PORT (OUT) 43H

DATA	BNK0RQ	EQU	00000001B	SHOW BANK 0 TO SYSTEM
	BNK1RQ	EQU	00000011B	SHOW BANK 1 TO SYSTEM
	CLEAR	EQU	10000000B	RESETS Z80 WHEN BNK RQ EXERCISED
	START	EQU	00000010B	REMOVE WINDOW FROM SYSTEM & EXECUTE INSTRUCTION

STATUS PORT (IN) 43H

WINDOW	EQU	00000001B	WINDOW NOT PRESENT BIT
BUSY	EQU	00000010B	CONTROLLER EXECUTING PGM BIT
WINDOW1	EQU	00000100B	WINDOW ADDR BIT (SWITCH)
WINDOW2	EQU	00001000B	" " "

DD DISK CONTROLLER COMMANDS

COMMAND BLOCK @ 1370H

1370	CBCMD	DB	COMMAND # 0-7
71	CBDRV	DB	DRIVE #
72	CBTRK	DB	TRACK #
73	CBSEC	DB	SECTOR #
74	CBFFG	DB	FORMAT FLAGS
75	CBSPR	DB	-
76	CBMOD	DB	MODE SELECTS
77	CBSTS	DB	CONTROLLER STATUS
78	CWLAD	DW	LOAD ADDR
7A	CWLNG	DW	LOAD LENGTH

LOCATION 1000H MUST BE 1041H FOR COMMAND.

0 LOG-ON DRIVE

1 READ SECTOR

2 WRITE SECTOR

3 FORMAT TRACK

4 READ ADDRESS

5 -

6 -

7 IDLE/BACKGROUND

DD DISK LOG
COMMAND 0 : LOG ON DRIVE

CMD BLOCK PASSED IN :

(CBDRV) = DRIVE # (0-3)

(CB

VALUES RETURNED :

(CBSTS) = BOARD STATUS

(CBTRK) = TRACK 0

(CBSEC) = SECTOR 1

DD DISK CONTROL

COMMAND 1 : READ SECTOR

PARAMS PASSED IN :

(CBDRV) = DRIVE # (0-3)

(CBTRK) = TRACK # TO SEEK

(CBSEC) = SECTOR # TO READ

PARAMS PASSED OUT :

SECTOR DATA @ 1380H

(CBSTS) = STATUS

DD. DISK CONT.

COMMAND 2 : WRITE SECTOR

PARAMS PASSED IN :

(CBDRV) = DRIVE # (0-3)

(CBTRK) = TRACK # OF SECTOR

(CBSEC) = SECTOR # TO WRITE

@ 1380H = START OF 128-BYTE SECTOR DATA TO WRITE

PARAMS PASSED BACK :

(CBSTS) = STATUS

COMMAND 3 : FORMAT TRACK

PARAMS PASSED IN :

(CBDRV) = DRIVE # (0-3)

(CBSEC) = FORMAT FLAG

(CBTRK) = TRACK TO FORMAT

@ 1708 = START OF FORMAT PGM.

PARAMS PASSED OUT :

(CBSTS) = STATUS

(CWLNG) = ?

DD DISK CONT.

COMMAND 4 : READ ADDRESS

PARAMS PASSED IN :

NOT IMPLEMENTED

PARAMS PASSED OUT :

NONE

DD DISK CONT.

COMMAND 7 : IDLE

PARAMS PASSED IN :

NONE

PARAMS PASSED OUT :

NONE

BIOS - JADE DOUBLE D CP/M 2.2

TITLE PAGE

```

; *****
;
; PROGRAM ID: BIOS - CPM 2.2
;
; *****
;
; PROPERTY OF: JADE COMPUTER PRODUCTS
; 4901 W. ROSECRANS BLVD.
; HAWTHORNE, CALIFORNIA
; 90250, U.S.A.
;
; *****
;
; VERSION: 2.2
;
; *****
; THIS BIOS CONTAINS DISK SUBROUTINES WHICH ARE
; COMPATABLE WITH THE DCM-2.2 MODULE AND THE JADE
; DOUBLE D DISK CONTROLLER. THIS COMBINATION WILL
; INTERFACE UP TO FOUR 8" DRIVES IN SINGLE AND DOUBLE
; DENSITY. THE CONSOLE, READER/PUNCH, AND PRINTER
; INTERFACES SHOULD BE ALTERED FOR SPECIFIC END USER
; SYSTEMS AS NEEDED.
; ***** SK *****

```

SKEW - 6/14

BIOS - JADE DOUBLE D CP/M 2.2

EQUATES

```

;*****
; DISK OPERATING SYSTEM ADDRESSES.
;*****

```

```

0014      NK.SYS  ==      20      ;SYSTEM SIZE IN K BYTES.
0400      K.BYTE ==      1024    ;1K BYTE SIZE.
5000      CPM.SZ ==      NK.SYS*K.BYTE ;TOP SYSTEM ADDRESS.
0000      CPM.BS  ==      CPM.SZ-(20*K.BYTE) ;CP/M BIAS VALUE.
3400      CCP     ==      CPM.BS+3400H ;ADDRESS OF CCP.
3C00      BDOS    ==      CPM.BS+3C00H ;ADDRESS OF BDOS.
4A00      BIOS    ==      CPM.BS+4A00H ;ADDRESS OF BIOS
C600      BIOS.R  ==      1000H-BIOS  ;DDT OFFSET 1000H LOAD.
0100      TPA     ==      0100H     ;ADDRESS OF TPA.
00FF      IOBYTE  ==      0FFH     ;INITIAL IOBYTE VALUE.
0000      DF.DRV  ==      0        ;INITIAL DEFAULT DRV.
0080      SEC.SZ  ==      0080H     ;BYTES PER SECTOR.
0100      FMT.SZ  ==      0100H     ;FORMAT BUFF SIZE.
0002      N.DRVS  ==      2        ;1-4 DRIVES.

```

```

;*****
; DOUBLE D HARDWARE PARAMETERS. PLEASE NOTE THIS
; SECTION CONTAINS CONDITIONAL STATEMENTS.
;*****

```

```

0043      D.PORT  ==      043H     ;DOUBLE D PORT ADDRESS.
0001      TRUE    ==      1        ;TRUE IS A ONE.
0000      FALSE   ==      0        ;FALSE IS A ZERO.
0001      REV.B   ==      TRUE     ;SET TRUE FOR REV B BOARDS.
0000      REV.C   ==      FALSE    ;SET TRUE FOR REV C BOARDS.
          .IFG    REV.B, I
0002      DS.HLT  ==      002H     ;STATUS PORT HALT INDICATORJ
          .IFG    REV.C, I
          DS.HLT  ==      001H     ;STATUS PORT HALT INDICATORJ

```

```

;*****
; DOUBLE D HARDWARE COMMANDS
;*****

```

```

0001      DC.SIN  ==      00000001B ;SWITCH DD BANK 0 INTO SYSTEM.
0001      DC.MB0  ==      00000001B ;SELECT DOUBLE D BANK 0.
0003      DC.MB1  ==      00000011B ;SELECT DOUBLE D BANK 1.
0000      DC.SOT  ==      00000000B ;SWITCH DD MEM OUT OF SYSTEM.
0002      DC.INT  ==      00000010B ;ISSUE DD Z80A INTERRUPT.

```

```

;*****

```

BIOS - JADE DOUBLE D CP/M 2.2

EQUATES

```

;*****
; DISK CONTROLLER MODULE LINKAGE (DCM - VER 2.2) *
;*****

```

```

;***** ( COMMAND BLOCK DEFINED )*****

```

```

0370 DD.CBT == 0370H ;COMMAND BYTE (BANK 0).
0371 DD.DRV == 0371H ;DRIVE NUMBER (BANK 0).
0372 DD.TRK == 0372H ;TRACK NUMBER (BANK 0).
0373 DD.SEC == 0373H ;SECTOR NUMBER (BANK 0).
0377 DD.STS == 0377H ;CMMD STATUS (BANK 0).
0380 DD.BUF == 0380H ;SECTOR BUFFER (BANK 0).
0300 DD.FBF == 0300H ;FORMAT BUFFER (BANK 1).
03A0 DD.DPB == 03A0H ;ID SEC DPB (BANK 0).
03B1 DD.DDF == 03B1H ;ID SEC FLAGS (BANK 0).

```

```

;***** ( DCM COMMANDS )*****

```

```

0000 DC.LOG == 000H ;LOG ON DISKETTE.
0001 DC.RDS == 001H ;READ SECTOR.
0002 DC.WRS == 002H ;WRITE SECTOR.
0003 DC.FMT == 003H ;FORMAT TRACK.

```

```

;*****
; CONSOLE DEFINITIONS *
;*****

```

```

0000 CNI.SP == 000H ;INPUT STATUS PORT
0002 CNI.SB == 002H ;INPUT STATUS BIT
0000 CNI.SI == 000H ;INPUT STATUS INVERT
0001 CNI.DP == 001H ;INPUT DATA PORT

0000 CNO.SP == 000H ;OUTPUT STATUS PORT
0004 CNO.SB == 004H ;OUTPUT STATUS BIT
0000 CNO.SI == 000H ;OUTPUT STATUS INVERT
0001 CNO.DP == 001H ;OUTPUT DATA PORT

```

```

;*****
; ASSEMBLER DIRECTIVES *
;*****

```

```

        .PABS
        .PHEX
        .XLINK
4A00    .LUC   BIOS

```

```

;*****

```

```

;*****
; BIOS JUMP VECTOR TABLE
;*****

```

```

4A00    C3 4A83    JMP    INIT           ;COLD START ENTRY
4A03    C3 4CBC    JMP    WARM          ;RELOAD CCP/BDOS
4A06    C3 4C80    JMP    CNS.CK        ;GET CONSOLE STATUS
4A09    C3 4C8A    JMP    CNS.IN        ;CONSOLE INPUT
4A0C    C3 4C95    JMP    CNS.OT        ;CONSOLE OUTPUT
4A0F    C3 4CA8    JMP    LIST          ;PRINTER OUTPUT
4A12    C3 4CA7    JMP    PUNCH         ;PUNCH OUTPUT
4A15    C3 4CA4    JMP    READER        ;READER INPUT
4A18    C3 4C3C    JMP    HOME          ;HOME SELECTED DRIVE
4A1B    C3 4C41    JMP    SELDISK       ;SELECT DISK DRIVE
4A1E    C3 4C60    JMP    SETTRK        ;SET TRACK NUMBER
4A21    C3 4C65    JMP    SETSEC        ;SET SECTOR NUMBER
4A24    C3 4C6A    JMP    SETDMA        ;SET TRANSFER ADDRESS
4A27    C3 4B03    JMP    DISKRD        ;PERFORM DISK READ
4A2A    C3 4B23    JMP    DISKWR        ;PERFORM DISK WRITE
4A2D    C3 4CAB    JMP    LISTST        ;RETURN LIST STAT
4A30    C3 4C70    JMP    SECTRN        ;TRANSLATE SECTOR
4A33    C3 4B50    JMP    FORMAT        ;FORMAT A TRACK

```

```

;*****
; RESERVE DRIVE PARAMETER BLOCKS
;*****

```

```

000F    DFB.SZ == 15           ;SIZE IS 15 BYTES.
4A36    D0.DPB: .BLKB DFB.SZ   ;RESERVES 15 BYTES.
4A45    D1.DPB: .BLKB DFB.SZ   ;FOR EACH DISK DRIVE.
4A54    D2.DPB: .BLKB DFB.SZ   ;DRIVE A THRU DRIVE D.
4A63    D3.DPB: .BLKB DFB.SZ

```

```

;*****
; BIOS VARIABLE STORAGE
;*****

```

```

4A72    00    BT.CMD: .BYTE 0           ;DCM COMMAND.
4A73    00    BT.DRV: .BYTE 0           ;DRIVE NUMBER.
4A74    00    BT.TRK: .BYTE 0           ;TRACK NUMBER.
4A75    00    BT.SEC: .BYTE 0           ;SECTOR NUMBER.
4A76    00    BT.SP0: .BYTE 0           ;SPARE BYTE 0.
4A77    00    BT.SP1: .BYTE 0           ;SPARE BYTE 1.
4A78    00    BT.MOD: .BYTE 0000000B   ;MODE CONTROLS.
4A79    00    BT.STS: .BYTE 0           ;COMMAND STATUS.
4A7A    0000   BT.LAD: .WORD 0           ;LOAD ADDRESS.
4A7C    0000   BT.LNG: .WORD 0           ;LOAD LENGTH.

4A7E    0000   BT.DMA: .WORD 0           ;SYSTEM TRANSFER ADDR.
4A80    0000   IT.PTR: .WORD 0           ;DRIVE TABLE POINTER.
4A82    00    LOG.RQ: .BYTE 0           ;LOG ON REQUEST REG.

```

```

;*****

```

```
*****
; INIT - COLD START ENTRY ** DIRECTORY BUFFER OVERLAY *
*****
```

```
4A83 DIR.BF == . ;BUFFER BEGINNING.
```

```
***** ( GET SYSTEM K SIZE IN ASCII )*****
```

```
4A83 31 0080 INIT: LXI SP,0080H ;SET UP STACK AREA.
4A86 21 5000 LXI H,CPM.SZ ;GET CPM SYS SIZE.
4A89 7C MOV A,H ;GET NMBR OF PAGES.
4ABA 0F RRC ; (/2).
4A8B 0F RRC ;CPM SIZE IN K.
4ASC 0600 MVI B,0 ;ZERO TENS COUNTER.
4A8E FE0A C.TENS: CPI 10 ;COMPARE AGAINST 10.
4A90 DA 4A99 JC C.ONES ;MUST BE LESS THAN 10.
4A93 D60A SUI 10 ;SUBTRACT 10.
4A95 04 INR B ;INC TENS COUNTER.
4A96 C3 4A8E JMP C.TENS ;COUNT TENS.
4A99 C630 C.ONES: ADI '0' ;ADD ASCII 0 TO REM.
4A9B 32 4AED STA SYS.OD ;STORE ONES DIGIT.
4A9E 78 MOV A,B ;GET TENS COUNTER.
4A9F C630 ADI '0' ;ADD ASCII 0 TO TENS.
4AA1 32 4AEC STA SYS.TD ;STORE TENS DIGIT.
```

```
***** ( SYSTEM INITIALIZATION )*****
```

```
4AA4 C3 4AC0 JMP C.LOGO ;JUMP OVER AREA.
4AA7 .BLKB 25 ;RESERVE INIT AREA.
```

```
***** ( SEND SYSTEM SIGN ON )*****
```

```
4AC0 21 4ACF C.LOGO: LXI H,MSG.S0 ;SIGN ON MSG ADDR.
4AC3 CD 4CAE CALL MSG.OT ;ISSUE MESSAGE.
4AC6 2A 4A04 LHLD BIOS+4 ;WARM START ADDRESS.
4AC9 22 4A01 SHLD BIOS+1 ;RESET COLD START.
4ACC C3 4CBC JMP WARM ;PERFORM WARM BOOT.

4ACF 0D0A0D0A MSG.S0: .ASCII [CR][LF][CR][LF]
4AD3 4A4144452043 .ASCII 'JADE COMPUTER PRODUCTS '[CR][LF]
4AEC 30 SYS.TD: .BYTE '0' ;TENS DIGIT.
4AED 30 SYS.OD: .BYTE '0' ;ONES DIGIT.
4AEE 4B2043502F4D .ASCIS 'K CP/M VERS 2.2 '[CR][LF][CR][LF]
```

```
***** ( FILL OUT DIRECTORY BUFFER )*****
```

```
4B03 .IFG (DIR.BF+SEC.SZ-.), [
.LOC DIR.BF+SEC.SZ ;FILL OUT SECTOR SIZE]
```

```
*****
```

```
*****  
; READ A DISK SECTOR ROUTINE *  
*****
```

```
4B03 3E01 DISKRD: MVI A,DC.SIN ;SWITCH DD INTO SYSTEM.  
4B05 D343 OUT D.PORT ;ISSUE DD COMMAND.  
4B07 3E01 MVI A,DC.RDS ;READ SECTOR COMMAND.  
4B09 CD 4B78 CALL DSK.EX ;PERFORM OPERATION.  
4B0C C2 4B49 JNZ DSK.ER ;ERROR EXIT.  
4B0F 2A 4A7E LHLD BT.DMA ;LOAD USER BUF ADDRESS  
4B12 EB XCHG ;MOVE HL TO DE.  
4B13 01 0380 LXI B,DD.BUF ;LOAD BUFFER OFFSET.  
4B16 2A 0040 LHLD D.ADDR ;LOAD DD WINDOW ADDR.  
4B19 09 DAD B ;HL NOW SECTOR BUFFER.  
4B1A 01 0080 LXI B,SEC.SZ ;LOAD SECTOR SIZE.  
4B1D CD 4BA7 CALL BLOCK ;BLOCK MOVE ROUTINE.  
4B20 C3 4B43 JMP DSK.OK ;NORMAL RETURN.
```

```
*****  
; WRITE A DISK SECTOR ROUTINE *  
*****
```

```
4B23 3E01 DISKWR: MVI A,DC.SIN ;SWITCH DD INTO SYSTEM.  
4B25 D343 OUT D.PORT ;ISSUE HARDWARE CMND.  
4B27 01 0080 LXI B,SEC.SZ ;LOAD SECTOR SIZE.  
4B2A 2A 0040 LHLD D.ADDR ;DD SYSTEM ADDRESS.  
4B2D 11 0380 LXI D,DD.BUF ;DD BUFFER OFFSET.  
4B30 19 DAD D ;HL NOW DD BUF ADDR.  
4B31 EB XCHG ;DE NOW DD BUF ADDR.  
4B32 2A 4A7E LHLD BT.DMA ;HL NOW USER BUF ADDR.  
4B35 CD 4BA7 CALL BLOCK ;BLOCK MOVE ROUTINE.  
4B38 3E02 MVI A,DC.WRS ;LOAD WRITE SEC CMND.  
4B3A CD 4B78 CALL DSK.EX ;CALL DISK EXECUTIVE.  
4B3D CA 4B43 JZ DSK.OK ;JUMP IF WRITE OK.  
4B40 C3 4B49 JMP DSK.ER ;ERROR EXIT.
```

```
*****  
; DISK READ/WRITE/FORMAT EXITS *  
*****
```

```
4B43 3E00 DSK.OK: MVI A,DC.SOT ;SWITCH DD OUT OF SYS.  
4B45 D343 OUT D.PORT ;ISSUE HARDWARE CMND.  
4B47 AF XRA A ;ZERO A REGISTER.  
4B48 C9 RET ;ERROR EXIT.
```

```
4B49 3E00 DSK.ER: MVI A,DC.SOT ;SWITCH DD OUT OF SYS.  
4B4B D343 OUT D.PORT ;ISSUE HARDWARE CMND.  
4B4D 3EFF MVI A,OFFH ;LOAD ERROR FLAGS.  
4B4F C9 RET ;ERROR EXIT.
```

```
*****
```

```

;*****
; FORMAT A DISK TRACK ROUTINE
;*****
  
```

```

4B50      3E01      FORMAT: MVI      A,DC.SIN      ;SWITCH DD INTO SYSTEM.
4B52      D343      X OUT      D.PORT      ;ISSUE HARDWARE CMND.
4B54      3E03      MVI      A,DC.MB1      ;SELECT DD BANK 1.
4B56      D343      OUT      D.PORT      ;ISSUE HARDWARE CMND.
4B58      01 0100   LXI      B,FMT.SZ      ;FORMAT PROG SIZE.
4B5B      2A 0040   LHLD     D.ADDR      ;DD SYSTEM ADDRESS.
4B5E      11 0300   LXI      D,DD.FBF     ;DD FORMAT BUF OFFSET.
4B61      19        DAD      D      ;HL NOW DD FBUF ADDR.
4B62      EB        XCHG     ;DE NOW DD FBUF ADDR.
4B63      2A 4A7E   LHLD     BT.DMA      ;FORMAT PROGRAM ADDR.
4B66      CD 4BA7   CALL     BLOCK      ;BLOCK MOVE ROUTINE.
4B69      3E01      MVI      A,DC.MBO      ;RESELECT DD BANK 0.
4B6B      D343      OUT      D.PORT      ;ISSUE TO DD HARDWARE.
4B6D      3E03      MVI      A,DC.FMT      ;LOAD FORMAT TRK CMND.
4B6F      CD 4B78   CALL     DSK.EX      ;CALL DISK EXECUTIVE.
4B72      CA 4B43   JZ      DSK.OK      ;JUMP IF WRITE OK.
4B75      C3 4B49   JMP     DSK.ER      ;ERROR EXIT.
  
```

```

;*****
; DOUBLE D EXECUTION SUBROUTINE
;*****
  
```

```

4B78      32 4A72   DSK.EX: STA      BT.CMD      ;STORE DCM COMMAND.
4B7B      01 0007   LXI      B,7      ;NMBR BYTE TO MOVE.
4B7E      11 0370   LXI      D,DD.CBT   ;COMMAND BYTE OFFSET.
4B81      2A 0040   LHLD     D.ADDR     ;DD SYS ADDRESS.
4B84      19        DAD      D      ;HL NOW PTS CMND BLK.
4B85      EB        XCHG     ;NOW ADDR IN DE.
4B86      21 4A72   LXI      H,BT.CMD   ;BIOS CMND BLOCK.
4B89      CD 4BA7   CALL     BLOCK      ;PERFORM BLOCK MOVE.
4B8C      3E02      MVI      A,DC.INT   ;LOAD DD INTERRUPT.
4B8E      D343      OUT      D.PORT      ;ISSUE DD INTERRUPT.
4B90      EB        XCHG     ;EXCHANGE SRC/DSTN.
4B91      01 0005   LXI      B,5      ;5 RETURN BYTES.
4B94      DB43      DSK.WT: IN      D.PORT      ;READ DD STATUS.
4B96      E602      ANI      DS.HLT     ;TEST HALT* FLAG.
4B98      C2 4B94   JNZ     DSK.WT     ;TEST UNTIL HALTED.
4B9B      3E01      MVI      A,DC.SIN   ;SWITCH DD INTO SYS.
4B9D      D343      OUT      D.PORT      ;ISSUE HARDWARE CMND.
4B9F      CD 4BA7   CALL     BLOCK      ;GET DD STATUS.
4BA2      3A 4A79   LDA      BT.STS     ;LOAD STATUS BYTE.
4BA5      A7        ANA      A      ;TEST FOR ERRORS.
4BA6      C9        RET      ;RETURN TO CALLER.
  
```

```

;*****
  
```

```
*****
; BLOCK - BLOCK MOVE (Z80 LDIR REGISTER USAGE) *
*****
```

```
4BA7 7E BLOCK: MOV A,M ;GET BYTE.
4BA8 12 STAX D ;STORE BYTE.
4BA9 23 INX H ;INC SOURCE PNTR
4BAA 13 INX D ;INC DESTINATION PNTR.
4BAB 0B DCX B ;DECREMENT COUNT.
4BAC 78 MOV A,B ;GET HIGH COUNT.
4BAD B1 ORA C ;OR IN LO COUNT.
4BAE C2 4BA7 JNZ BLOCK ;ANOTHER BYTE.
4BB1 C9 RET ;RETURN TO USER.
```

```
*****
; LOG-ON - SET DISK PARAMETER BLOCK *
*****
```

```
***** ( CHECK IF LOG-ON REQUESTED )*****
```

```
4BB2 3A 4A82 LOG.ON: LDA LOG.RQ ;CHECK LOG REQUEST.
4BB5 E601 ANI 001H ;LOG ON BIT TEST.
4BB7 C2 4B43 JNZ DSK.OK ;RETURN, NO LOG-ON.
```

```
***** ( READ IDENTITY SECTOR )*****
```

```
4BBA 22 4A80 SHLD DT.FTR ;STORE DRV TBL PNTR.
4BBD 3E01 MVI A,DC.SIN ;SWITCH DD INTO SYS.
4BBF D343 OUT D.PORT ;ISSUE HARDWARE CMND.
4BC1 3E00 MVI A,DC.LOG ;LOAD DCM LOG-ON CMND.
4BC3 CD 4B78 CALL DSK.EX ;PERFORM DISK OP.
4BC6 CA 4BCF JZ LOG.CK ;GO TO LOGON ERROR.
4BC9 21 0000 LXI H,0 ;ERROR, BAD LOG ON.
4BCC C3 4B49 JMP DSK.ER ;BIOS EXIT.
```

```
***** ( CHECK FOR JADE ID )*****
```

```
4BCF 11 0380 LOG.CK: LXI D,DD.BUF ;DD BUFFER OFFSET.
4BD2 2A 0040 LHL D.ADDR ;DD SYS ADDRESS.
4BD5 19 DAD D ;HL NOW PNTS BUFFER.
4BD6 11 4D4F LXI D,JADEID ;DE PNTS BIOS ID.
4BD9 0608 MVI B,ID.SZE ;SET LABEL SIZE.
4BDB 1A LOG.ID: LDAX D ;GET LABEL CHARACTER.
4BDC BE CMP M ;DOES ID SECTOR MATCH.
4BDD C2 4C0A JNZ LG3740 ;ASSUME DISKETTE 3740.
4BE0 05 DCR B ;DECREMENT COUNT.
4BE1 C2 4BDB JNZ LOG.ID ;CHECK IF ANOTHER CHR.
```

```
***** ( DISKETTE CONTAINS ID )*****
```

```
4BE4 CD 4C29 CALL TRNONE ;ASSUME DDENS.
4BE7 CD 4C31 CALL DPB.ADD ;GET DPB ADDR IN DE.
4BEA 01 03A0 LXI B,DD.DPB ;DPB ADDR OFFSET.
4BED 2A 0040 LHL D.ADDR ;DD SYSTEM ADDRESS.
4BF0 09 DAD B ;HL NOW AT ID DPB.
```

```

4BF1 01 000F      LXI      B,DPB.SZ      ;DPB SIZE IN BYTES.
4BF4 CD 4BA7      CALL     BLOCK         ;MOVE INTO DPB.
4BF7 11 03B1      LXI      D,DD.DDF     ;ID DTA DNS OFFSET.
4BFA 2A 0040      LHLD    D.ADDR       ;DD SYSTEM ADDR.
4bfd 19             DAD     D             ;HL POINTS FLAGS.
4BFE 7E             MOV     A,M          ;LOAD FLAGS.
4BFF E604           ANI     04H          ;TEST DATA DENSITY.
4C01 CC 4C1F      CZ      TR3740       ;IF 0 USE 3740 TRN.
4C04 2A 4A80      LHLD    DT.PTR       ;RELOAD POINTER.
4C07 C3 4B43      JMP     DSK.OK       ;EXIT BIOS JUMP.
  
```

***** (ASSUME 3740 DISKETTE)*****

```

4C0A CD 4C1F      LG3740: CALL     TR3740      ;SET SECTOR TRANSLATE.
4C0D CD 4C31      CALL     DPB.AD       ;SET REGISTER DE.
4C10 01 000F      LXI      B,DPB.SZ     ;DPB SIZE IN BYTES.
4C13 21 4D2C      LXI      H,SD.PBK     ;ADDRESS OF BLK IMAGE.
4C16 CD 4BA7      CALL     BLOCK         ;MOVE INTO DPB.
4C19 2A 4A80      LHLD    DT.PTR       ;RELOAD POINTER.
4C1C C3 4B43      JMP     DSK.OK       ;EXIT BIOS JUMP.
  
```

***** (SET 3740 SECTOR TRANSLATION)*****

```

4C1F 11 4D12      TR3740: LXI      D,SDTRAN  ;SECTOR TRAN TBL ADDR.
4C22 2A 4A80      LHLD    DT.PTR       ;ADDR DISK PARA HDR.
4C25 73             MOV     M,E          ;LOW ORDER ADDR.
4C26 23             INX     H            ;POINT NEXT BYTE.
4C27 72             MOV     M,D          ;HIGH ORDER ADDR.
4C28 C9             RET                 ;RETURN TO LOG USER.
  
```

***** (SET NO SECTOR TRANSLATION)*****

```

4C29 AF           TRNONE: XRA     A      ;ZERO A REGISTER.
4C2A 2A 4A80      LHLD    DT.PTR       ;ADDR OF PARA HDR.
4C2D 77             MOV     M,A          ;ZERO LOW ORDER ADDR.
4C2E 23             INX     H            ;NEXT BYTE.
4C2F 77             MOV     M,A          ;ZERO HIGH BYTE.
4C30 C9             RET                 ;RETURN TO LOG USER.
  
```

***** (GET DRIVE PARA BLK ADDR)*****

```

4C31 2A 4A80      DPB.AD: LHLD    DT.PTR       ;ADDR DISK PARA HDR.
4C34 11 000A      LXI      D,10        ;DPB TBL PNTR OFFSET.
4C37 19             DAD     D            ;NOW AT DPB PNTR.
4C38 5E             MOV     E,M          ;LOW ORDER ADDR.
4C39 23             INX     H            ;NEXT BYTE.
4C3A 56             MOV     D,M          ;HIGH ORDER ADDR.
4C3B C9             RET                 ;RETURN TO LOG USER.
  
```

***** (HOME DRIVE)*****

```

4C3C      OE00      HOME:  MVI      C,0          ;C REGISTER TO ZERO.
4C3E      C3 4C60      JMP      SETTRK      ;PERFORM SET TRACK.
  
```

***** (SELECT DRIVE - LOGON)*****

```

4C41      21 0000      SELDSK: LXI      H,0          ;ERROR RETURN CODE.
4C44      79          MOV      A,C          ;PUT DRIVE NMBR IN A.
4C45      32 4A73      STA      BT.DRV       ;STORE DRIVE NUMBER.
4C48      FE02      CPI      N.DRV      ;CHECK IF LEGAL DRIVE.
4C4A      D0          RNC          ;NO CARRY IF ILLEGAL.
4C4B      7B          MOV      A,E          ;CHECK IF LOG-ON REQ.
4C4C      32 4A82      STA      LOG.RQ       ;STORE LOGON REGISTER.
4C4F      3A 4A73      RETDSK: LDA      BT.DRV      ;GET DRIVE NUMBER.
4C52      6F          MOV      L,A          ;L = DISK NUMBER.
4C53      2600      MVI      H,0          ;ZERO H REGISTER.
4C55      29          DAD      H          ;*2.
4C56      29          DAD      H          ;*4.
4C57      29          DAD      H          ;*8.
4C58      29          DAD      H          ;*16 (SIZE OF HEADER).
4C59      11 4D57      LXI      D,DO.DPH     ;DRIVE 0 D.P.H.
4C5C      19          DAD      D          ;HL= DRIVE N DPH.
4C5D      C3 4BB2      JMP      LOG.ON       ;GO CHECK LOG-ON.
  
```

***** (SET TRACK)*****

```

4C60      79          SETTRK: MOV      A,C          ;MOVE TRACK NUMBER.
4C61      32 4A74      STA      BT.TRK       ;SAVE TRACK NUMBER.
4C64      C9          RET          ;RETURN TO CALLER.
  
```

***** (SET SECTOR)*****

```

4C65      79          SETSEC: MOV      A,C          ;MOVE SECTOR NUMBER.
4C66      32 4A75      STA      BT.SEC       ;SAVE SECTOR NUMBER.
4C69      C9          RET          ;RETURN TO CALLER.
  
```

***** (SET TRANSFER ADDRESS)*****

```

4C6A      60          SETDMA: MOV      H,B          ;HIGH ORDER MOVE.
4C6B      69          MOV      L,C          ;LOW ORDER MOVE.
4C6C      22 4A7E      SHLD     BT.DMA       ;SAVE TRANSFER ADDRESS.
4C6F      C9          RET          ;RETURN TO CALLER.
  
```

***** (SECTOR TRANSLATION) *****

4C70	7A	SECTRN:	MOV	A,D	; TESTING TBL ADDR.
4C71	B3		ORA	E	; ADDR IN REG DE.
4C72	CA 4C7B		JZ	NOTRAN	; IF ZERO, NO TRANS.
4C75	EB		XCHG		; (HL) NOW TRANS TBL.
4C76	09		DAD	B	; (HL) NOW TRANS SECTOR.
4C77	6E		MOV	L,M	; L IS TRANSLATED SEC.
4C78	2600		MVI	H,0	; HIGH ORDER BYTE ZERO.
4C7A	C9		RET		; RETURN TO CALLER.
4C7B	21 0001	NOTRAN:	LXI	H,1	; SET HL TO ONE.
4C7E	09		DAD	B	; ADD SEC NMBR TO HL.
4C7F	C9		RET		; RETURN TO CALLER.

 ; CONSOLE INPUT STATUS *

4C80	DB00	CNS.CK:	IN	CNI.SP	; INPUT STATUS
4C82	EE00		XRI	CNI.SI	; POLARITY ADJUST
4C84	E602		ANI	CNI.SB	; MASK STATUS BIT
4C86	C8		RZ		; RETURN NOT RDY
4C87	3EFF		MVI	A,OFFH	; SET READY FLAG
4C89	C9		RET		; RETURN RDY

 ; CONSOLE INPUT CHARACTER *

4C8A	CD 4C80	CNS.IN:	CALL	CNS.CK	; CALL STATUS CHECK.
4C8D	CA 4C8A		JZ	CNS.IN	; REPEAT TILL READY.
4C90	DB01		IN	CNI.DP	; INPUT CHARACTER.
4C92	E67F		ANI	07FH	; 7 BIT ASCII+SIGN.
4C94	C9		RET		; RETURN TO CALLER.

 ; CONSOLE OUTPUT *

4C95	DB00	CNS.OT:	IN	CNO.SP	; INPUT STATUS
4C97	EE00		XRI	CNO.SI	; ADJUST POLARITY
4C99	E604		ANI	CNO.SB	; MASK STATUS BIT
4C9B	CA 4C95		JZ	CNS.OT	; TRY AGAIN
4C9E	79		MOV	A,C	; GET CHARACTER
4C9F	E67F		ANI	07FH	; 7 BIT ASCII
4CA1	D301		OUT	CNO.DP	; SEND CHARACTER
4CA3	C9		RET		

; READER AND PUNCH DRIVERS - USER DEFINED *

4CA4 3E1A READER: MVI A,CNTL.Z ;RETURN END OD FILE.
4CA6 C9 RET ;NOT IMPLEMENTED.

4CA7 C9 PUNCH: RET ;NOT IMPLEMENTED.

; PRINTER DRIVER AREA *

4CA8 C3 4C95 LIST: JMP CNS.OT ;SEND TO CONSOLE

4CAB 3EFF LISTST: MVI A,OFFH ;READY
4CAD C9 RET

; SEND MESSAGE SUBROUTINE *

4CAE F5 MSG.OT: PUSH PSW ;SAVE CALLER FLAGS.
4CAF 4E ..REPT: MOV C,M ;LOAD CHARACTER.
4CB0 CD 4C95 CALL CNS.OT ;CONSOLE OUTPUT.
4CB3 7E MOV A,M ;SAME CAHRACTER.
4CB4 23 INX H ;INCREMENT POINTER.
4CB5 E680 ANI 080H ;TEST SIGN BIT.
4CB7 CA 4CAF JZ ..REPT ;ANOTHER CHARACTER.
4CBA F1 POP PSW ;RESTORE FLAGS.
4CBB C9 RET ;RETURN TO CALLER.

000A LF == 00AH ;ASCII LINE FEED.
000D CR == 00DH ;CARRAIGE RETURN.
001A CNTL.Z == 01AH ;CONTROL-Z (EOF).

```

;*****
; WARM REBOOT ENTRY - LOADS CCP/BDOS - INITIALIZES *
;*****

```

```

;***** ( SET UP FOR SYSTEM BOOT )*****

```

```

4CBC 31 0080 WARM: LXI SP,0080H ;SET UP STACK.
4CBF 3E00 MVI A,0 ;DRIVE 0 VALUE.
4CC1 32 4A73 STA BT.DRV ;SELECT DISK.
4CC4 01 3400 LXI B,CCP ;CP/M CCP ADDRESS.
4CC7 CD 4C6A CALL SETDMA ;SET DMA ADDR.
4CCA 0E02 MVI C,2 ;CCP 1ST SECTOR.
4CCC CD 4C65 CALL SETSEC ;SET SECTOR NMBR.
4CCF 0E01 MVI C,1 ;CCP/BDOS TRACK.
4CD1 CD 4C60 CALL SETTRK ;SET TRACK NUMBER.

```

```

;***** ( READ CCP/BDOS )*****

```

```

4CD4 CD 4B03 W.READ: CALL DISKRD ;READ ONE SECTOR.
4CD7 A7 ANA A ;SET FLAGS.
4CD8 C2 4CF4 JNZ W.EROR ;EXIT IF ERROR.
4CDB 3A 4A75 LDA BT.SEC ;GET SECTOR NMBR.
4CDE FE2D CPI 45 ;LAST SECTOR CHECK.
4CE0 CA 4CFB JZ W.ZRPG ;GOTO ZERO PAGE SET.
4CE3 3C INR A ;INCREMENT SECTOR.
4CE4 32 4A75 STA BT.SEC ;STORE NEXT SECTOR.
4CE7 11 0080 LXI D,SEC.SZ ;GET SECTOR SIZE.
4CEA 2A 4A7E LHLD BT.DMA ;GET TRANSFER ADDR.
4CED 19 DAD D ;CALCULATE NEW ADDR.
4CEE 22 4A7E SHLD BT.DMA ;SET NEW ADDRESS.
4CF1 C3 4CD4 JMP W.READ ;DO ANOTHER WARM READ.

```

```

;***** ( READ ERROR DETECTED )*****

```

```

4CF4 21 4D43 W.EROR: LXI H,MSG.LE ;GET ERROR MESSAGE.
4CF7 CD 4CAE CALL MSG.OT ;ISSUE MESSAGE.
4CFA 76 HLT ;OR GOTO MONITOR

```

```

;***** ( INITIALIZE SYSTEM PARAMETERS )*****

```

```

4CFB 01 0008 W.ZRPG: LXI B,8 ;BASE IMAGE SIZE.
4CFE 11 0000 LXI D,0 ;BASE ADDRESS SET.
4D01 21 4D3B LXI H,BS.IMG ;BASE IMAGE ADDR.
4D04 CD 4BA7 CALL BLOCK ;BLOCK MOVE ROUTINE.

```

```

;***** ( JUMP TO CCP )*****

```

```

4D07 21 0080 LXI H,0080H ;DEFAULT SECTOR BUFF.
4D0A 22 4A7E SHLD BT.DMA ;SET TRANSFER ADDRESS.
4D0D 0E00 MVI C,0 ;DISK NMBR: OLD DISK?
4D0F C3 3400 JMP CCP ;JUMP INTO CCP CP/M.

```

```

;*****

```

```
*****  
; (DISK REQUEST PARAMETERS)  
*****
```

0040 D.ADDR == 0040H ;DD SYSTEM MEM ADDRESS.

```
*****  
; 3740 FORMAT PARAMETERS ***** CP/M SINGLE DENSITY *  
*****
```

```
***** ( SINGLE DENSITY CP/M SECTORING )*****
```

4D12 01070D131905 SDTRAN: .BYTE 01H,07H,0DH,13H,19H,05H
4D18 0B111703090F .BYTE 0BH,11H,17H,03H,09H,0FH
4D1E 1502080E141A .BYTE 15H,02H,08H,0EH,14H,1AH
4D24 060C1218040A .BYTE 06H,0CH,12H,18H,04H,0AH
4D2A 1016 .BYTE 10H,16H

```
***** ( DEFAULT DISK PARAMETER BLOCK )*****
```

4D2C 001A SD.PBK: .WORD 26 ;SECTORS PER TRACK.
4D2E 03 .BYTE 3 ;BLOCK SHIFT FACTOR.
4D2F 07 .BYTE 7 ;BLOCK MASK.
4D30 00 .BYTE 0 ;NULL MASK.
4D31 00F2 .WORD 242 ;DISK SIZE - 1.
4D33 003F .WORD 63 ;DIRECTORY MAX.
4D35 C0 .BYTE 11000000B ;ALLOC 0.
4D36 00 .BYTE 0 ;ALLOC 1.
4D37 0010 .WORD 16 ;CHECK SIZE.
4D39 0002 .WORD 2 ;TRACK OFFSET.

```
*****  
; ZERO PAGE IMAGE *  
*****
```

4D3B C3 4A03 BS.IMG: JMP BIOS+03H ;WARM BOOT VECTOR.
4D3E FF00 .BYTE IOBYTE,DF.DRV ;I/O BYTE AND DFLT DRV.
4D40 C3 3C06 JMP BDOS+06H ;BDOS CALL VECTOR.

```
*****  
; MESSAGES *  
*****
```

4D43 0D0A4C4F4144 MSG.LE: .ASCIS [CR][LF]'LOAD ERROR'

```
*****  
; ID LABEL DEFINITIONS *  
*****
```

4D4F 4A6164652044 JADEID: .ASCII 'JADE DD' ;ID LABEL.
0008 ID.SZE == .-JADEID ;LABEL SIZE.

```
*****
```

; DRIVE PARAMETER HEADER AREA

4D57	0000	DO.DPH:	.WORD	0	;SECTOR TRAN TBL.
4D59	0000		.WORD	0	;SCRATCH AREA.
4D5B	0000		.WORD	0	;SCRATCH AREA.
4D5D	0000		.WORD	0	;SCRATCH AREA.
4D5F	4A83		.WORD	DIR.BF	;DIRECTORY BUFFER.
4D61	4A36		.WORD	DO.DPB	;DRIVE PARAM BLK.
4D63	4E1B		.WORD	DO.CHK	;DRIVE CHANGE BLK.
4D65	4D97		.WORD	DO.ALL	;DRIVE ALLOCATION.

4D67	0000	D1.DPH:	.WORD	0	
4D69	0000		.WORD	0	
4D6B	0000		.WORD	0	
4D6D	0000		.WORD	0	
4D6F	4A83		.WORD	DIR.BF	
4D71	4A45		.WORD	D1.DPB	
4D73	4E2B		.WORD	D1.CHK	
4D75	4DB8		.WORD	D1.ALL	

4D77	0000	D2.DPH:	.WORD	0	
4D79	0000		.WORD	0	
4D7B	0000		.WORD	0	
4D7D	0000		.WORD	0	
4D7F	4A83		.WORD	DIR.BF	
4D81	4A54		.WORD	D2.DPB	
4D83	4E3B		.WORD	D2.CHK	
4D85	4DD9		.WORD	D2.ALL	

4D87	0000	D3.DPH:	.WORD	0	
4D89	0000		.WORD	0	
4D8B	0000		.WORD	0	
4D8D	0000		.WORD	0	
4D8F	4A83		.WORD	DIR.BF	
4D91	4A63		.WORD	D3.DPB	
4D93	4E4B		.WORD	D3.CHK	
4D95	4DFA		.WORD	D3.ALL	

```
*****  
; DRIVE ALLOCATION AREAS DECLARED *  
*****
```

```
4D97      ADDR      =      .      ; AT CURRENT LOCATION.  
0021      ALL.SZ    ==     33      ; ALLOCATION BLOCK SIZE.  
  
4D97      D0.ALL   ==     ADDR     ; ALLOCATION FOR DRIVE 0.  
4DB3      ADDR     =     ADDR+ALL.SZ  
4DB3      D1.ALL   ==     ADDR     ; ALLOCATION FOR DRIVE 1.  
4DD9      ADDR     =     ADDR+ALL.SZ  
4DD9      D2.ALL   ==     ADDR     ; ALLOCATION FOR DRIVE 2.  
4DFA      ADDR     =     ADDR+ALL.SZ  
4DFA      D3.ALL   ==     ADDR     ; ALLOCATION FOR DRIVE 3.  
4E1B      ADDR     =     ADDR+ALL.SZ
```

```
*****  
; CHANGED DISK CHECK AREAS DECLARED *  
*****
```

```
0010      CHK.SZ   ==     16      ; CHECK AREA SIZE.  
4E1B      D0.CHK  ==     ADDR     ; CHECK AREA FOR DRIVE 0.  
4E2B      ADDR     =     ADDR+CHK.SZ  
4E2B      D1.CHK  ==     ADDR     ; CHECK AREA FOR DRIVE 1.  
4E3B      ADDR     =     ADDR+CHK.SZ  
4E3B      D2.CHK  ==     ADDR     ; CHECK AREA FOR DRIVE 2.  
4E4B      ADDR     =     ADDR+CHK.SZ  
4E4B      D3.CHK  ==     ADDR     ; CHECK AREA FOR DRIVE 3.  
4E5B      ADDR     =     ADDR+CHK.SZ
```

```
*****  
      .END
```

BIOS - JADE DOUBLE D CP/M 2.2

+++++ SYMBOL TABLE +++++

ADDR	4E5B	ALL.SZ	0021	BDOS	3C00	BIOS	4A00
BIOS.R	C600	BLOCK	4BA7	BS.IMG	4D3B	BT.CMD	4A72
BT.DMA	4A7E	BT.DRV	4A73	BT.LAD	4A7A	BT.LNG	4A7C
BT.MOD	4A78	BT.SEC	4A75	BT.SPO	4A76	BT.SP1	4A77
BT.STS	4A79	BT.TRK	4A74	CCP	3400	CHK.SZ	0010
CNI.DP	0001	CNI.SB	0002	CNI.SI	0000	CNI.SP	0000
CNO.DP	0001	CNO.SB	0004	CNO.SI	0000	CNO.SP	0000
CNS.CK	4C80	CNS.IN	4C8A	CNS.OT	4C95	CNTL.Z	001A
CPM.BS	0000	CPM.SZ	5000	CR	000D	C.LOGO	4AC0
C.ONES	4A99	C.TENS	4A8E	DO.ALL	4D97	DO.CHK	4E1B
DO.DPB	4A36	DO.DPH	4D57	D1.ALL	4DB8	D1.CHK	4E2B
D1.DPB	4A45	D1.DPH	4D67	D2.ALL	4DD9	D2.CHK	4E3B
D2.DPB	4A54	D2.DPH	4D77	D3.ALL	4DFA	D3.CHK	4E4B
D3.DPB	4A63	D3.DPH	4D87	DC.FMT	0003	DC.INT	0002
DC.LOG	0000	DC.MB0	0001	DC.MB1	0003	DC.RDS	0001
DC.SIN	0001	DC.SOT	0000	DC.WRS	0002	DD.BUF	0380
DD.CBT	0370	DD.DDF	03B1	DD.DPB	03A0	DD.DRV	0371
DD.FBF	0300	DD.SEC	0373	DD.STS	0377	DD.TRK	0372
DF.DRV	0000	DIR.BF	4A83	DISKRD	4B03	DISKWR	4B23
DPB.AD	4C31	DPB.SZ	000F	DSK.ER	4B49	DSK.EX	4B78
DSK.OK	4B43	DSK.WT	4B94	DS.HLT	0002	DT.PTR	4A80
D.ADDR	0040	D.PORT	0043	FALSE	0000	FMT.SZ	0100
FORMAT	4B50	HOME	4C3C	ID.SZE	0008	INIT	4A83
IOBYTE	00FF	JADEID	4D4F	K.BYTE	0400	LF	000A
LG3740	4C0A	LIST	4CA8	LISTST	4CAB	LOG.CK	4BCF
LOG.ID	4BDB	LOG.ON	4BB2	LOG.RQ	4A82	MSG.LE	4D43
MSG.OT	4CAE	MSG.SO	4ACF	NK.SYS	0014	NOTRAN	4C7B
N.DRVS	0002	PUNCH	4CA7	READER	4CA4	RETDSK	4C4F
REV.B	0001	REV.C	0000	SDTRAN	4D12	SD.PBK	4D2C
SECTRN	4C70	SEC.SZ	0080	SELDSK	4C41	SETDMA	4C6A
SETSEC	4C65	SETTRK	4C60	SYS.OD	4AED	SYS.TD	4AEC
TPA	0100	TR3740	4C1F	TRNONE	4C29	TRUE	0001
WARM	4CBC	W.EROR	4CF4	W.READ	4CD4	W.ZRPG	4CFB

```

*****
;
;          DISK CONTROLLER MODULE   (DCM)
;
*****
;
;          PROPERTY OF:      JADE COMPUTER PRODUCTS INC.
;                          4901 W. ROSECRANS BLVD.
;                          HAWTHORNE, CALIFORNIA
;                          90250,   U.S.A.
;
*****
;
;          VERSION:          2.20 - 8" DRIVES
;
*****
;
;          WRITTEN BY:      STAN KRUMME
;
*****
; THE DISK CONTROLLER MODULE (DCM) RESIDES INTERNAL
; TO THE JADE DOUBLE D DISK CONTROLLER BOARD. THIS
; PROGRAM PROVIDES A FACILITY TO READ/WRITE DISKETTE
; SECTORS AND FORMAT DISKETTE TRACKS (IN SINGLE AND
; DOUBLE DENSITY). THIS DCM SETS THE PARAMETERS FOR
; EACH DRIVE DURING THE "LOG-ON" OPERATION. THE
; FORMAT.COM PROGRAM WRITES AN IDENTIFICATION SECTOR
; WHICH PROVIDES THE NEEDED INFORMATION. IF THIS
; IDENTITY SECTOR IS NOT PRESENT ON THE DISKETTE,
; IT IS ASSUMED TO BE A STANDARD 8" 3740 FORMAT.
; THIS PROGRAM CONTAINS A 6 WORD TIMING BLOCK WHICH
; SHOULD BE PATCHED TO MATCH THE USERS DISK DRIVES.
; THIS HAS NORMALLY BEEN SET FOR SHUGART SAS00/801.
*****

```

; THE FOLLOWING IS A LIST OF THE INTERNAL I/O
; ADDRESS ASSIGNMENTS. THESE PORTS AND
; CONTROLS CAN ONLY BE USED BY THE ONBOARD Z80A.
; THESE PORTS AND CONTROLS ARE NOT IN THE S100
; BUS ADDRESS SPACE.

; (CONTROLLER PORT ASSIGNMENTS)

0000	BL.STS	==	000H	;BOARD STATUS PORT.
0000	BL.CTL	==	000H	;BOARD CONTROL PORT.
0004	WD.CMD	==	004H	;1791 COMMAND REGISTER.
0004	WD.STS	==	004H	;1791 STATUS REGISTER.
0005	WD.TRK	==	005H	;1791 TRACK REGISTER.
0006	WD.SEC	==	006H	;1791 SECTOR REGISTER.
0007	WD.DTA	==	007H	;1791 DATA REGISTER.

; (CONTROLLER FUNCTION ASSIGNMENTS)

0008	XP.STP	==	008H	;ISSUE STEP PULSE.
0010	XP.MTO	==	010H	;MOTOR TURN OFF.
0020	XP.IRR	==	020H	;S100 INT-REQ RESET.
0040	XP.MTX	==	040H	;MOTOR TIME EXTEND.
0080	XP.DSH	==	080H	;DATA SYNC HOLD.

; THE FOLLOWING LIST ASSIGNS EACH BIT POSITION
; AND FUNCTION OF THE BOARD CONTROL PORT (BL.CTL).

; (BIT ASSIGNMENTS)

0001	BC.DSA	==	00000001B	;DRIVE SELECT A (2*0).
0002	BC.DSB	==	00000010B	;DRIVE SELECT B (2*1).
0004	BC.DSE	==	00000100B	;DRIVE SELECT ENABLE.
0008	BC.EIA	==	00001000B	;EIA SIGNAL LEVEL OUT.
0010	BC.DDE	==	00010000B	;DOUBLE DENSITY ENABLE.
0020	BC.DAS	==	00100000B	;DIRECTION AND SIDE
0040	BC.PCA	==	01000000B	;PRECOMP SELECT A.
0080	BC.PCB	==	10000000B	;PRECOMP SELECT B.

; (FUNCTION ASSIGNMENTS)

0003	BC.DSN	==	BC.DSA!BC.DSB	;DRIVE NMBR MASK.
0000	BC.SDS	==	0	;SINGLE DENSITY.
0010	BC.DDS	==	BC.DDE	;DOUBLE DENSITY.
0040	BC.PCH	==	BC.PCA	;PRECOMP - HEAVY.
0080	BC.PCM	==	BC.PCB	;PRECOMP - MEDIUM.
00C0	BC.PCL	==	BC.PCA!BC.PCB	;PRECOMP - LIGHT.
0000	BC.PCZ	==	0	;PRECOMP - OFF.

; THE FOLLOWING LIST DEFINES EACH BIT AND
; FUNCTION OF THE BOARD STATUS PORT (BL.STS).

0001	BS.US0	==	00000001B	;USER SWITCH 0.
0002	BS.US1	==	00000010B	;USER SWITCH 1.
0004	BS.TST	==	00000100B	;TEST MODE SWITCH.
0008	BS.INT	==	00001000B	;HOST INT REQUEST.
0010	BS.EIA	==	00010000B	;EIA SIGNAL LEVEL IN.
0020	BS.MOF	==	00100000B	;MOTOR OFF INIDCATOR.
0040	BS.TSD	==	01000000B	;TWO SIDED DRIVE FLAG.
0080	BS.DCN	==	10000000B	;DISK CHANGE INDICATOR.

; THE FOLLOWING IS A LIST OF COMMAND CODES
; ISSUED TO THE 1791-01 DISK CONTROLLER.

0010	DC.HDL	==	00010000B	;SEEK/LOAD RW HEAD.
0018	DC.HDU	==	00010000B	;SEEK/UNLD RW HEAD.
0080	DC.RDS	==	10000000B	;READ SECTOR.
00A0	DC.WRS	==	10100000B	;WRITE SECTOR.
00F0	DC.WRT	==	11110000B	;WRITE TRACK FORMAT.
00C0	DC.RDA	==	11000000B	;READ TRACK ADDRESS.
00D0	DC.STS	==	11010000B	;SET TYPE 1 STATUS
00D8	DC.IFI	==	11011000B	;FORCED INTERRUPT.

; THE FOLLOWING LIST CONTAINS ALL THE
; MASKS USED TO TEST THE 1791-01 STATUS
; CODES (PORT WD.STS).

009D	DM.RER	==	10011101B	;READ ERROR TEST.
00FD	DM.WER	==	11111101B	;WRITE ERROR TEST.
00E4	DM.FER	==	11100100B	;FORMAT ERROR TEST.
0004	DM.TKO	==	00000100B	;TRACK 0 TEST.
0020	DM.HDL	==	00100000B	;HEAD LOAD TEST.
0080	DM.DNR	==	10000000B	;DRIVE NOT READY.
0004	DM.LDE	==	00000100B	;LOST DATA ERROR.

```
***** (BASE ADDRESS FOR DCM) *****  
1000      BASE      ==      1000H      ;BASE ADDRESS.  
  
***** (MEMORY BANKS) *****  
1000      BANK.0    ==      BASE+0000H  ;BANK 0 DEFINED.  
0400      BANK.L    ==      0400H      ;BANK LENGTH.  
1400      BANK.1    ==      BANK.0+BANK.L ;BANK 1 DEFINED.  
  
***** (RESTART VECTORS) *****  
1000      RST.0     ==      BANK.0+0000H ;RESTART 0.  
1008      RST.1     ==      BANK.0+0008H ;RESTART 1.  
1010      RST.2     ==      BANK.0+0010H ;RESTART 2.  
1018      RST.3     ==      BANK.0+0018H ;RESTART 3.  
1020      RST.4     ==      BANK.0+0020H ;RESTART 4.  
1028      RST.5     ==      BANK.0+0028H ;RESTART 5.  
1030      RST.6     ==      BANK.0+0030H ;RESTART 6.  
1038      RST.7     ==      BANK.0+0038H ;RESTART 7.  
  
; ***** (INTERRUPT VECTORS) *****  
1038      HR.INT    ==      RST.7      ;MASKABLE.  
1066      NM.INT    ==      BANK.0+0066H ;NON MASKABLE.  
  
***** (I/O COMMUNICATION ) *****  
1370      IO.BLK    ==      BANK.0+0370H ;I/O BLOCK BEGIN.  
1370      TP.STK    ==      IO.BLK+0000H ;TOP OF STACK.  
1370      CMD.BK    ==      IO.BLK+0000H ;COMMAND BLOCK.  
1380      BUF.BG    ==      IO.BLK+0010H ;SECTOR BUFFER.  
1700      FMT.BG    ==      BANK.1+0300H ;FORMAT BUFFER.  
1708      FMT.PS    ==      FMT.BG+0008H ;FORMAT PROGRAM.  
  
*****
```

```
*****  
; PAUSE IS USED AFTER THE 179X-01 IS ISSUED A COMMAND  
; AND BEFORE THE 179X-01 STATUS REGISTER IS READ. *  
; THIS ALLOWS THE 179X-01 TO 'DIGEST' THE COMMAND! *  
*****
```

```
.DEFINE PAUSE = [  
XTHL  
XTHL  
XTHL  
XTHL]
```

```
*****  
; WAIT IS A RESTART CALL TO THE TIMER SUBROUTINE *  
; ENTRY. THIS SUBROUTINE PROVIDES MOST OF THE *  
; TIMING USED BY THE DOUBLE D CONTROLLER. *  
*****
```

```
.DEFINE WAIT = [  
RST 1]
```

```
***** (ASSEMBLER DIRECTIVES) *****
```

```
.PABS  
.PHEX  
.XLINK
```

```
***** (TIMING CONSTANTS) *****
```

```
0019 TMR.FC == 0019H ;TIMING CONSTANT, FIRST PASS.  
001C TMR.NC == 001CH ;TIMING CONSTANT, NORMAL PASS.
```

```
***** (RETRY VALUES) *****
```

```
0005 RTY.SK == 5 ;REPOSITION R/W HEAD ON RETRY.  
0009 RTY.LS == 9 ;LAST REPEATED RETRY.
```

```
*****
```

```

;*****
; THE FOLLOWING AREA IS THE INITIAL START JUMP TABLE. *
; THE FIRST JUMP IS EXECUTED WHEN THE ONBOARD Z80A IS *
; RESET. THE SECOND JUMP IS THE DCM ENTRY FROM A *
; BOOTSTRAP LOADER. THIS ENTRY ASSUMES DCM HAS BEEN *
; LOADED INTO DOUBLE D BANK 1 BY THE LOADER ROUTINE. *
; THE LAST TWO BYTES HOLD THE JUMP ADDRESS USED BY *
; RESTART INTERRUPT ROUTINE AT BANK 0 + 0380H. *
;*****
    
```

```

1000          .LOC      RST.0          ;BEGINNING.
1000      C3 0000      JMP          -0- CLEAR      ;NOT IMPLEMENTED YET.
1003      C3 1780      JMP          INIT.B+BANK.L  ;INIT - BOOTSTRAPED.
1006      1041      HR.VEC: .WORD      X.CUTE      ;BUS INTERRUPT VECTOR.
    
```

```

;*****
; THE FOLLOWING SUBROUTINE IS THE ENTRY POINT FOR THE *
; DISK CONTROLLER TIMING MODULE. THIS MODULE PROVIDES *
; DELAYS WHICH ARE MULTIPLES OF 100 MICROSECONDS. THE *
; CONTENTS OF REGISTER PAIR DE DETERMINES THE TOTAL *
; PERIOD. (DELAY = (DE) * 100 MICROSECONDS). THIS *
; SUBROUTINE IS ENTERED BY THE MACRO "WAIT". *
;*****
    
```

```

1008          .LOC      RST.1          ;TIMING ENTRY POINT.
1008      0619      MVI          B,TMR.FC      ;FIRST TICK CONSTANT.
100A      10FE      DJNZ         .            ;AUTO DEC UNTIL ZERO.
100C      C3 1074      JMP          TICK.E      ;JUMP TO TICK ENTRY.
    
```

```

;*****
; THE FOLLOWING RESTART LOCATIONS ARE SPARES AT THIS *
; TIME. THEY MAY BE USED IN FUTURE UPGRADES. *
;*****
    
```

```

1018          .LOC      RST.3
1020          .LOC      RST.4
1028          .LOC      RST.5
1030          .LOC      RST.6
    
```

*CLEAR USE "DOWN" RTN
LD IX, DTAD
EI
HALT*

```

;*****
; THE FOLLOWING SECTION IS THE MASKABLE INTERRUPT *
; ROUTINE. THIS ROUTINE IS EXECUTED WHEN RESTARTING *
; THE Z80 FROM A HALT. THE FUNCTIONS ARE RESET THE *
; DOUBLE D INT REQ FLIP-FLOP, PUT THE INTERRUPTED *
; ADDR IN REG DE, AND JUMP ADDRESS AT "HR.VEC". *
;*****
    
```

```

1038          .LOC      HR.INT          ;HOST INTERRUPT ADDR.
1038      DB20      IN          XP.IRR      ;RESET INTERRUPT REQ FF
103A      D1        POP          D          ;PURGE INTERRUPTED ADDR
103B      2A 1006      LHLD         HR.VEC      ;LOAD RETURN ADDRESS
103E      E9        PCHL         ;JUMP RETURN ADDRESS
    
```

```

;*****
    
```

```

;*****
; THE FOLLOWING SECTION HALTS EXECUTION OF THE *
; ONBOARD Z80A PROCESSOR. DURING THIS TIME THE HOST *
; SYSTEM CAN SWITCH THE CONTROLLER MEMORY INTO THE *
; S100 BUS FOR STATUS CHECK, SETTING COMMAND BLOCK, *
; AND SECTOR DATA TRANSFERS. *
;*****
    
```

```

103F    FB    FETCH:  EI          ;ENABLE INTERRUPT START
1040    76    HLT          ;HALT ON-BOARD PROCESSOR
    
```

```

;*****
; THE FOLLOWING SECTION GAINS CONTROL AFTER THE DISK *
; CONTROLLER IS INTERRUPTED FROM THE HALT CONDITION. *
; THIS SECTION BRANCHES TO THE INDIVIDUAL COMMAND *
; ROUTINES. THE COMMAND TABLE CONTAINS THE ADDRESSES*
; FOR THIS DISTRIBUTION. *
;*****
    
```

```

1041    3A 1370 X.CUTE: LDA     CALL 1370      GET 1370's Command
1044    E607    ANI     CB.CMD      ;LOAD HOST COMMAND.
1046    87      ADD     ..MASK     ;MASK ANY OPTIONS.
1047    1600    MVI     A          ;GET 2*A VALUE.
1049    5F      MOV     D,0        ;ZERO D REGISTER.
104A    21 1053 LXI     H,..CMDT   ;LOAD TABLE ADDRESS.
104D    19      DAD     D          ;NOW POINTS TO ENTRY.
104E    5E      MOV     E,M       ;LOW ORDER ADDR LOAD.
104F    23      INX     H         ;POINT TO NEXT BYTE.
1050    56      MOV     D,M       ;HI ORDER ADDRESS.
1051    EB      XCHG             ;BRANCH ADDR IN HL.
1052    E9      PCHL            ;BRANCH TO COMMAND.
    
```

```

;*****
    
```

```

1053    ..CMDT ==          ;COMMAND TABLE.
1053    10AF    ..CM0A: .WORD $.LGON ;LOG-ON DRIVE.
1055    107C    ..CM1A: .WORD $.READ ;READ SECTOR.
1057    108B    ..CM2A: .WORD $.WRIT ;WRITE SECTOR.
1059    109A    ..CM3A: .WORD $.FORM ;FORMAT TRACK.
105B    10CC    ..CM4A: .WORD $.ADDR ;READ ADDRESS.
105D    10CF    ..CM5A: .WORD $.SPAR ;SPARE.
105F    10CF    ..CM6A: .WORD $.SPAR ;SPARE.
1061    10D2    ..CM7A: .WORD $.IDLE ;BACKGROUND.
0007    ..MASK ==          007H    ;COMMAND MASK.
    
```

```

;*****
    
```

```
*****  
; THE FOLLOWING SECTION IS THE NON-MASKABLE INTERRUPT*  
; ROUTINE. UPON 1791-01 COMMAND TERMINATION THE Z80 *  
; RECIEVES A NON-MASKABLE INTERRUPT. THE STATUS PORT*  
; IS INTERROGATED AND SAVED (SV.STS). REGISTER IY *  
; CONTAINS THE RETURN ADDRESS. *  
*****
```

```
1066          .LOC      NM.INT          ;NON-MASKABLE INT.  
  
1066  DB04      WD.INT: IN      WD.STS      ;GET 1791 STATUS.  
1068  A9        XRA      C              ;INVERT (1791).  
1069  32 130D   STA      SV.STS      ;SAVE STATUS.  
106C  FDE3      XTIY     ;EXCHANGE (SP)↔IY.  
106E  ED45      RETN                    ;RETURN AT OLD IY.
```

```
*****  
; THIS SECTION IS THE REMAINDER OF THE TIMING *  
; SECTION ENTERED BY A RESTART 1. SEE THAT SECTION *  
; FOR THE DESCRIPTION. *  
*****
```

```
1070  061C      TICK.R: MVI      B,TMR.NC ;NORMAL TICK CONSTANT.  
1072  10FE      DJNZ     .          ;AUTO DEC UNTIL ZERO.  
1074  1B        TICK.E: DCX     D          ;DECREMENT AMOUNT.  
1075  7A        MOV      A,D        ;GET HIGH ORDER.  
1076  B3        ORA      E          ;AND LOW ORDER.  
1077  00        NOP                    ;TIMING ADJUST.  
1078  00        NOP                    ;TIMING ADJUST.  
1079  20F5      JRNZ    TICK.R      ;REPEAT UNTIL ZERO.  
107B  C9        RET                    ;RETURN TO USER.
```

```
*****
```

```

;*****
; $.READ IS THE READ-SECTOR COMMAND CONTROLLER. *
;*****
    
```

```

107C    CD 10DD    $.READ: CALL    SELECT    ;SELECT DRIVE ROUTINE.
107F    C2 103F                JNZ    FETCH    ;DRIVE NOT READY EXIT.
1082    CD 1180                CALL   SEEK     ;SEEK TRACK, SET CTLS.
1085    CD 1265                CALL   RD.SEC   ;READ DISK SECTOR.
1088    C3 103F                JMP    FETCH    ;GET NEXT COMMAND.
    
```

```

;*****
; $.WRIT IS THE WRITE-SECTOR COMMAND CONTROLLER. *
;*****
    
```

```

108B    CD 10DD    $.WRIT: CALL    SELECT    ;SELECT DRIVE ROUTINE.
108E    C2 103F                JNZ    FETCH    ;DRIVE NOT READY EXIT.
1091    CD 1180                CALL   SEEK     ;SEEK TRACK, SET CTLS.
1094    CD 1294                CALL   WR.SEC   ;WRITE DISK SECTOR.
1097    C3 103F                JMP    FETCH    ;GET NEXT COMMAND.
    
```

```

;*****
; $.FORM IS THE FORMAT-TRACK COMMAND CONTROLLER. *
;*****
    
```

```

109A    CD 10DD    $.FORM: CALL    SELECT    ;SELECT DRIVE NUMBER.
109D    C2 103F                JNZ    FETCH    ;DRIVE NOT READY EXIT.
10A0    3A 1373                LDA    CB.SEC   ;LOAD FORMAT FLAGS.
10A3    DD7705                MOV    DV.FLG(X),A ;RESET DRIVE FLAGS.
10A6    CD 1180                CALL   SEEK     ;SEEK TRACK, SET CTLS.
10A9    CD 12C3                CALL   WR.TRK   ;WRITE DISK TRACK.
10AC    C3 103F                JMP    FETCH    ;GET NEXT COMMAND.
    
```

```

;*****
; $.LGON IS THE DRIVE LOG-ON COMMAND CONTROLLER *
;*****
    
```

```

10AF    CD 10DD    $.LGON: CALL    SELECT    ;SELECT DRIVE NUMBER.
10B2    C2 103F                JNZ    FETCH    ;DRIVE NOT READY EXIT.
10B5    AF                    XRA    A        ;ZERO REGISTER A.
10B6    32 1372                STA    CB.TRK   ;SET TRACK AT 0.
10B9    3C                    INR    A        ;NOW A REG IS 1.
10BA    32 1373                STA    CB.SEC   ;SET SECTOR TO ID.
10BD    CD 1180                CALL   SEEK     ;SEEK TRACK, SET CTLS.
10C0    C2 103F                JNZ    FETCH    ;POSSIBLE ERROR EXIT.
10C3    CD 1265                CALL   RD.SEC   ;READ ID SECTOR.
10C6    CD 114B                CALL   LOG.ON   ;LOG ON DISK DRIVE.
10C9    C3 103F                JMP    FETCH    ;GET NEXT COMMAND.
    
```

```

;*****
    
```

```
*****  
; $.ADDR IS THE READ-ADDRESS COMMAND CONTROLLER. *  
*****
```

```
10CC    C3 103F    $.ADDR: JMP     FETCH           ;NOT IMPLEMENTED.
```

```
*****  
; $.SPAR IS A SPARE COMMAND CONTROLLER. *  
*****
```

```
10CF    C3 103F    $.SPAR: JMP     FETCH           ;GET NEXT COMMAND.
```

```
*****  
; $.IDLE IS THE IDLE COMMAND CONTROLLER. *  
*****
```

```
10D2    DB00    $.IDLE: IN      BL,STS           ;INPUT BOARD STATUS.  
10D4    E608           ANI      BS,INT           ;CHECK HOST INTERRUPT.  
10D6    28FA           JRZ      $.IDLE           ;REPEAT IDLE CHECK.  
10D8    DB20           IN      XP,IRR           ;RESET INTERRUPT REQ.  
10DA    C3 103F    JMP     FETCH           ;GET NEXT COMMAND.
```

```
*****
```

```

;*****
; THE FOLLOWING SUBROUTINE IS RESPONSIBLE FOR
; SELECTING THE COMMAND REQUESTED DRIVE NMBR.
; BEFORE DRIVE SELECTION, THE DRIVE MOTOR STATE
; IS TESTED, AND IF NEEDED THEY ARE TURNED ON.
; INDEX REGISTER X IS SET TO POINT TO THE NEW
; SELECTED DRIVE IN THE DRIVE TABLE.
;*****

```

***** (MOTOR CHECK ROUTINE) *****

```

10DD    DB00    SELECT: IN      BL.STS    ;BOARD LEVEL STATUS.
10DF    E620    ANI      BS.MOF    ;CHECK MOTOR STATE.
10E1    2807    JRZ      ..CKDV    ;IF ON, CHECK DRIVE.
10E3    DB40    IN       XP.MTX    ;ISSUE MOTOR START.
10E5    ED5B 1314 LDED     TM.MTO    ;MOTOR STARTUP DELAY.
10E9    CF      WAIT      ;PROGRAMMABLE DELAY.

```

***** (SELECT DRIVE ROUTINE) *****

```

10EA    DB40    ..CKDV: IN      XP.MTX    ;EXTEND MOTOR TIMER.
10EC    3A 1371 LDA      CB.DRV    ;LOAD DRIVE NUMBER.
10EF    DDBE00 CMP      DV.NBR(X)    ;CURRENTLY SELECTED?
10F2    2831    JRZ      ..DVOK    ;GO IF DRIVE SELECTED.
10F4    CD 124B CALL     EX.HDU    ;UNLOAD R/W HEAD.
10F7    3A 130C LDA      SV.DRV    ;LOAD PORT IMAGE.
10FA    E6FB    ANI      #BC.DSE    ;DRIVE SELECT DSBLD.
10FC    D300    OUT      BL.CTL    ;ISSUE DESELECT.
10FE    3A 1371 LDA      CB.DRV    ;LOAD DESIRED DRIVE.
1101    E603    ANI      BC.DSN    ;MASK DRIVE NUMBER.
1103    D300    OUT      BL.CTL    ;OUTPUT DRIVE NMBR.
1105    F604    ORI      BC.DSE    ;SET DRV ENABLE BIT.
1107    D300    OUT      BL.CTL    ;ENABLE NEW DRIVE.
1109    32 130C STA      SV.DRV    ;SAVE DRIVE SELECT.

```

***** (SET TABLE POINTER) *****

```

110C    E603    ANI      BC.DSN    ;GET DRIVE NUMBER.
110E    DD21 1322 LXI      X,DV.TBL    ;DRIVE TABLE ADDR.
1112    11 0007 LXI      D,DV.DES    ;DRIVE ENTRY SIZE.
1115    3D      ..NEXT: DCR      A      ;DECREMENT DRV NO.
1116    FA 111D JM       ..SLED     ;IF S=1 EXIT.
1119    DD19    DADX     D      ;POINT NEXT DRIVE.
111B    18F8    JMPR     ..NEXT    ;TRY THIS DRIVE.

```

***** (EXIT) *****

```

111D    CD 1258 ..SLED: CALL     EX.STS    ;CHECK DRIVE STATUS.
1120    E680    ANI      DM.DNR    ;CHECK DRIVE NOT RDY.
1122    32 1377 STA      CB.STS    ;SET COMMAND STATUS.
1125    C9      ..DVOK: RET      ;RETURN TO CALLER.

```

```
*****  
; HOME.D IS THE SUBROUTINE THAT STEPS THE DISK DRIVE*  
; R/W HEAD OUTWARD UNTIL THE TRACK 0 FLAG BECOMES *  
; ACTIVE OR 255 STEPS HAVE BEEN ISSUED. *  
*****
```

```
***** (RESTORE R/W HEAD) *****
```

```
1126 2EFF HOME.D: MVI L,255 ;SET STEP COUNTER.  
1128 CD 1258 ..STEP: CALL EX.STS ;CHECK DISK STATUS.  
112B E604 ANI DM.TKO ;INSPECT TRACK 0 FLG.  
112D 200C JRNZ ..EXIT ;IF SET, GO ..EXIT.  
112F 2D DCR L ;DECREMENT STEP COUNT.  
1130 2815 JRZ ..EROR ;ERROR IF 255 STEPS.  
1132 DB08 IN XP.STP ;ISSUE STEP PULSE.  
1134 ED5B 1310 LDED TM.STP ;LOAD STEP DELAY.  
1138 CF WAIT ;PROGRAMMABLE DELAY.  
1139 18ED JMPR ..STEP ;TRY STEPPING AGAIN.
```

```
***** (DRIVE IS RESTORED) *****
```

```
113B ED5B 1312 ..EXIT: LDED TM.ALS ;TIME AFTER LAST STEP.  
113F CF WAIT ;PROGRAMMABLE DELAY.  
1140 3E00 MVI A,000H ;SET COMPLETE FLAG.  
1142 DD7701 MOV DV.TRK(X),A ;SET TRACK VALUE.  
1145 A7 ANA A ;SET RETURN FLAGS.  
1146 C9 RET ;RETURN TO CALLER.
```

```
***** (TRACK 0 NOT FOUND) *****
```

```
1147 3EFF ..EROR: MVI A,OFFH ;SET FAILURE FLAG.  
1149 A7 ANA A ;SET RETURN FLAGS.  
114A C9 RET ;RETURN TO CALLER.
```

```
*****
```

```

;*****
; LOG.ON IS THE SUBROUTINE THAT READS THE IDENTITY *
; SECTOR FROM THE DISKETTE AND MAKES THE NEEDED *
; ENTRYS INTO THE DRIVE TABLE. THE SECTOR DATA IS *
; ALSO LEFT IN THE SECTOR BUFFER FOR BIOS TO FINISH *
; THE LOG-ON OPERATION. *
;*****
    
```

***** (CHECK JADE IDENTITY) *****

```

114B 11 131A LOG.ON: LXI D,JADEID ;ID ADDRESS LOADED.
114E 21 1380 LXI H,ID.LBL ;SECTOR ID ADDRESS.
1151 0608 MVI B,ID.SZE ;ID LABEL SIZE.
1153 1A ..CKJI: LDAX D ;GET CHARACTER.
1154 BE CMP M ;CHECK AGAINST DISK.
1155 2017 JRNZ ..3740 ;IF DIFFERENT: 3740.
1157 10FA DJNZ ..CKJI ;REPEAT OPERATION.
    
```

***** (LOG-ON JADE FORMAT) *****

```

1159 3A 13A0 LDA ID.SPT ;SECTORS PER TRACK.
115C DD7703 MOV DV.SPT(X),A ;STORE IN DRIVE TBL.
115F 3A 13B0 LDA ID.STG ;STAGGER NUMBER.
1162 DD7703 MOV DV.SPT(X),A ;STORE IN DRIVE TBL.
1165 3A 13B1 LDA ID.FLG ;SIDE AND DENSITIES.
1168 DD7705 MOV DV.FLG(X),A ;STORE IN DRIVE TBL.
116B C3 103F JMP FETCH ;GET NEXT COMMAND.
    
```

~~JMP~~
~~RET~~

***** (ASSUME 3740 FORMAT) *****

```

116E 3E1A ..3740: MVI A,26 ;SECTORS PER TRACK.
1170 DD7703 MOV DV.SPT(X),A ;STORE IN DRIVE TBL.
1173 3E01 MVI A,1STG ;STAGGER NUMBER.
1175 DD7703 MOV DV.SPT(X),A ;STORE IN DRIVE TBL.
1178 3E00 MVI A,ID.FLD ;SIDE AND DENSITIES.
117A DD7705 MOV DV.FLG(X),A ;STORE IN DRIVE TBL.
117D C3 103F JMP FETCH ;GET NEXT COMMAND.
    
```

~~JMP~~
~~RET~~

```

;*****
; THE FOLLOWING SUBROUTINE PERFORMS THE TRACK SEEK *
; OPERATION. AFTER THE SEEK OPERATION, THE DENSITY *
; AND PRE-COMPENSATION CONTROLS ARE SET.          *
;*****
    
```

***** (HEAD LOADING) *****

```

1180 CD 1258      SEEK:  CALL    EX.STS      ;GET DRIVE STATUS.
1183 E620        ANI     DM.HDL        ;CHECK HEAD LOAD.
1185 2008        JRNZ    ..HLDD        ;BYPASS IF LOADED.
1187 CD 123E     CALL    EX.HDL        ;LOAD R/W HEAD.
118A ED5B 130E   LDED    TM.HLD        ;HEAD LOAD DELAY.
118E CF         WAIT    TM.HLD        ;PROGRAMMABLE DELAY.
    
```

***** (CHECK TRACK NUMBER) *****

```

118F 3A 1372     ..HLDD: LDA     CB.TRK      ;REQUESTED TRACK NO.
1192 DD9601     SUB     DV.TRK(X)    ;TRACK OFFSET REQ.
1195 2006        JRNZ    ..DSET      ;IF OFFSET, SET DIRC.
1197 DD7E06     MOV     A,DV.CTL(X)  ;GET PREVIOUS CTLS.
119A C3 122B     JNP     ..EXIT      ;GOTO SET CONTROLS.
    
```

***** (SET DIRECTION AND STEP COUNTER) *****

```

119D F5         ..DSET: PUSH    PSW        ;SAVE REG A AND FLGS.
119E ED5B 1318  LDED    TM.SAW      ;STEP AFTER WRITE.
11A2 CF         WAIT    TM.SAW      ;PROGRAMMABLE DELAY.
11A3 F1         POP     PSW        ;RESTORE A AND FLGS.
11A4 380A       JRC     ..SOUT      ;IF CARRY STEP OUT.
11A6 6F         ..SIN: MOV     L,A      ;MOVE OFFSET TO L.
11A7 3A 130C   LDA     SV.DRV      ;DRIVE SELECT BITS.
11AA F620       ORI     BC.DAS      ;SET DIRECTION IN.
11AC D300       OUT    BL.CTL      ;OUTPUT CONTROL.
11AE 180B       JMPR   ..STEP      ;GOTO STEP ROUTINE.
11B0 ED44       ..SOUT: NEG     ..STEP  ;COMPLEMENT OFFSET.
11B2 FA 1238   JM     ..HOME      ;BETTER HOME DRV.
11B5 6F         MOV     L,A      ;MOVE OFFSET TO L.
11B6 3A 130C   LDA     SV.DRV      ;DRIVE SELECT BITS.
11B9 D300       OUT    BL.CTL      ;SET DIRECTION OUT.
    
```

***** (ISSUE STEPS) *****

```

11BB DB08       ..STEP: IN     XP.STP   ;ISSUE STEP PULSE.
11BD ED5B 1310  LDED    TM.STP   ;STEP DELAY TIME.
11C1 CF         WAIT    TM.STP   ;PROGRAMMABLE DELAY.
11C2 2D         DCR     L          ;DECREMENT STEPS.
11C3 20F6       JRNZ    ..STEP     ;REPEAT OPERATION.
11C5 ED5B 1312  LDED    TM.ALS   ;MORE AFTER LAST STP.
11C9 CF         WAIT    TM.ALS   ;PROGRAMMABLE DELAY.
    
```

***** (TRACK SECTION DISTRIBUTE) *****

11CA	3A 1372	LDA	CB.TRK	;CURRENT TRACK NMBR.
11CD	FE01	CPI	1	;COMPARE AGAINST 1.
11CF	380C	JRC	..TRK0	;IF CARRY, TRACK 0.
11D1	2811	JRZ	..TRK1	;IF ZERO, TRACK 1.
11D3	FE1A	CPI	26	;CHECK OUTER THIRD.
11D5	381E	JRC	..OUTS	;GOTO OUTS SETTING.
11D7	FE34	CPI	52	;CHECK MIDDLE THIRD.
11D9	382B	JRC	..MIDS	;GOTO MIDS SETTING.
11DB	303A	JRNC	..INSD	;GOTO INSD SETTING.

***** (TRACK ZERO) *****

11DD	3A 130C	..TRK0:	LDA	SV.DRV	;GET DRIVE NUMBER.
11E0	F6C0		ORI	BC.SDS!BC.PCL	;SDEN AND PC-LOW.
11E2	1844		JMPR	..CTL5	;JUMP CONTROLS SET.

***** (TRACK ONE) *****

11E4	DDCB054E	..TRK1:	BIT	DF.T1D,DV.FLG(X)	;TRK 1 DENSITY FLG.
11E8	3A 130C		LDA	SV.DRV	;GET DRIVE NUMBER.
11EB	2004		JRNZ	..T1DD	;GO TO SET DDEN.
11ED	F6C0		ORI	BC.SDS!BC.PCL	;SDEN AND PC-LOW.
11EF	1837		JMPR	..CTL5	;JUMP CONTROLS SET.
11F1	F6D0	..T1DD:	ORI	BC.DDS!BC.PCL	;DDEN AND PC-LOW.
11F3	1833		JMPR	..CTL5	;JUMP CONTROLS SET.

***** (OUTSIDE TRACKS) *****

11F5	DDCB0556	..OUTS:	BIT	DF.DTD,DV.FLG(X)	;DATA DENSITY FLG.
11F9	3A 130C		LDA	SV.DRV	;GET DRIVE NUMBER.
11FC	2004		JRNZ	..OTDD	;GO TO SET DDEN.
11FE	F6C0		ORI	BC.SDS!BC.PCL	;SDEN AND PC-LOW.
1200	1826		JMPR	..CTL5	;JUMP CONTROLS SET.
1202	F6D0	..OTDD:	ORI	BC.DDS!BC.PCL	;DDEN AND PC-LOW.
1204	1822		JMPR	..CTL5	;JUMP CONTROLS SET.

***** (MIDDLE TRACKS) *****

1206	DDCB0556	..MIDS:	BIT	DF.DTD,DV.FLG(X)	;DATA DENSITY FLG.
120A	3A 130C		LDA	SV.DRV	;GET DRIVE NUMBER.
120D	2004		JRNZ	..MDDD	;GO TO SET DDEN.
120F	F6C0		ORI	BC.SDS!BC.PCL	;SDEN AND PC-LOW.
1211	1815		JMPR	..CTL5	;JUMP CONTROLS SET.
1213	F690	..MDDD:	ORI	BC.DDS!BC.PCM	;DDEN AND PC-MED.
1215	1811		JMPR	..CTL5	;JUMP CONTROLS SET.

***** (INSIDE TRACKS) *****

```
1217 DDCB0556 ..INSD: BIT DF.DTD,DV.FLG(X) ;DATA DENSITY FLG.
121B 3A 130C LDA SV.DRV ;GET DRIVE NUMBER.
121E 2004 JRNZ ..INDD ;GO TO SET DDEN.
1220 F6C0 ORI BC.SDS!BC.PCL ;SDEN AND PC-LOW.
1222 1804 JMPR ..CTL5 ;JUMP CONTROLS SET.
1224 F650 ..INDD: ORI BC.DDS!BC.PCH ;DDEN AND PC-HI.
1226 1800 JMPR ..CTL5 ;JUMP CONTROLS SET.
```

***** (SET CONTROLS)*****

```
1228 DD7706 ..CTL5: MOV DV.CTL(X),A ;SAVE CONTROLS.
122B D300 ..EXIT: OUT BL.CTL ;OUTPUT CONTROLS.
```

***** (SET TRACK VALUES AND EXIT)*****

```
122D 3A 1372 ..TKVL: LDA CB.TRK ;REQUESTED TRACK NO.
1230 DD7701 MOV DV.TRK(X),A ;SET DRIVE TABLE.
1233 A9 XRA C ;INVERT (1791-01).
1234 D305 OUT WD.TRK ;SET TRACK REGISTER.
1236 AF XRA A ;SET ZERO FLAG.
1237 C9 RET ;RETURN TO CALLER.
```

***** (CALIBRATE TRACK NUMBER)*****

```
1238 CD 1126 ..HOME: CALL HOME.D ;HOME SELECTED DRIVE.
123B C3 118F JMP ..HLDD ;NOW SEEK TRACK.
```

```

;*****
; THE FOLLOWING TWO SUBROUTINES PROVIDE THE R/W HEAD *
; LOAD AND UNLOAD FUNCTIONS. AS THE 179X-01 DOES NOT*
; OFFER THIS EXPLICIT COMMAND, THE SEEK COMMAND *
; (TYPE-1) IS USED WITH THE LOAD BIT SET TO EITHER *
; LOAD OR UNLOAD. THE DESTINATION TRACK IS SET EQUAL*
; TO THE CONTENTS OF THE TRACK REGISTER TO BYPASS THE*
; 179X-01 STEP FUNCTION. REFER TO THE FLOW-CHART FOR*
; 179X-01 TYPE 1 COMMANDS. *
;*****
    
```

***** (LOAD R/W HEAD) *****

```

123E   FDE1   EX.HDL: POP     Y           ;RETURN ADDR IN REG Y.
1240   DB05           IN     WD.TRK       ;READ PRESENT TRACK.
1242   D307           OUT    WD.DTA       ;SET DESTINATION TRK.
1244   3E10           MVI   A,DC.HDL     ;LOAD HEAD LOAD CMND.
1246   A9           XRA    C           ;INVERT (1791-01).
1247   D304           OUT    WD.CMD      ;ISSUE COMMAND.
1249   18FE           JMPR   .           ;WAIT FOR INTERRUPT.
    
```

***** (UNLOAD R/W HEAD) *****

```

124B   FDE1   EX.HDU: POP     Y           ;RETURN ADDR IN REG Y.
124D   DB05           IN     WD.TRK       ;READ PRESENT TRACK.
124F   D307           OUT    WD.DTA       ;SET DESTINATION TRK.
1251   3E18           MVI   A,DC.HDU     ;LOAD UNLD HEAD CMND.
1253   A9           XRA    C           ;INVERT (1791-01).
1254   D304           OUT    WD.CMD      ;ISSUE COMMAND.
1256   18FE           JMPR   .           ;WAIT FOR INTERRUPT.
    
```

```

;*****
; THE FOLLOWING SUBROUTINE IS USED TO UPDATE THE *
; 179X-01 STATUS PORT TO REFLECT CURRENT TYPE-1 *
; STATUS CODES. NOTE THIS IS A TYPE-4 COMMAND *
; WITH NO INTERRUPT CONDITIONS SET. *
;*****
    
```

```

1258   3ED0   EX.STS: MVI   A,DC.STS     ;LOAD SET-STATUS CMND.
125A   A9           XRA    C           ;INVERT (1791-01).
125B   D304           OUT    WD.CMD      ;ISSUE COMMAND.
125D   E3           PAUSE  .           ;PAUSE FOR 179X-01.
1261   DB04           IN     WD.STS      ;INPUT STATUS PORT.
1263   A9           XRA    C           ;INVERT (1791-01).
1264   C9           RET     .           ;RETURN TO USER.
    
```

```

;*****
; RD.SEC IS THE SUBROUTINE THAT INTERACTS WITH THE *
; 179X-01 DURING READ SECTOR OPERATIONS. THIS SECTION *
; INITIATES THE DISK TRANSFER, SERVICES THE CONTROLLER*
; CHIP DURING DATA TRANSFER, AND TERMINATES OPERATION *
; WHEN FINISHED. ERROR DETECTION IS IMPLEMENTED AND *
; RETRIES ARE EXRCUTED IF DATA ERRORS ARE DETECTED. *
;*****
    
```

```

;***** (INITIALIZE READ OPERATION) *****
    
```

```

1265 AF RD.SEC: XRA A ;ZERO A REGISTER.
1266 32 130B STA ERR.CT ;ZERO ERROR COUNT.
1269 3A 1373 LDA CB.SEC ;LOAD SECTOR NMBR.
126C A9 XRA C ;INVERT (1791-01).
126D D306 OUT WD.SEC ;SET SECTOR REGISTER.
126F FD21 1288 ..RTRY: LXI Y,..NMI ;LOAD NMI VECTOR.
1273 2A 1309 LHLD BUF.ST ;BUFFER START.
1276 3E80 MVI A,DC.RDS ;READ SECTOR COMMAND.
1278 A9 XRA C ;INVERT (1791-01).
1279 D304 OUT WD.CMD ;ISSUE READ COMMAND
127B E3 FAUSE ;ALLOW 1791 TO SETTLE
    
```

```

;***** (DATA TRANSFER LOOP) *****
    
```

```

127F DB80 ..REPT: IN XP.DSH ;HOLD FOR DATA
1281 DB07 IN WD.DTA ;INPUT DATA.
1283 A9 XRA C ;INVERT (1791-01).
1284 77 MOV M,A ;PUT INTO BUFFER
1285 23 INX H ;BUMP BUFF POINTER
1286 18F7 JMPR ..REPT ;GO FOR ANOTHER
    
```

```

;***** (CHECK STATUS) *****
    
```

```

1288 E69D ..NMI: ANI DM.RER ;TEST FOR ERRORS.
128A 32 1377 STA CB.STS ;SAVE READ STATUS.
128D C8 RZ ;RETURN COMPLETE.
128E CD 12DC CALL CHK.RT ;CHECK ABOUT RETRYS.
1291 28DC JRZ ..RTRY ;PERFORM RETRY.
1293 C9 RET ;ERROR RETURN.
    
```

```

;*****
    
```

```

;*****
; WR.SEC IS THE SUBROUTINE THAT INTERACTS WITH THE *
; 179X-01 DURING WRITE SETOR OPERATIONS. THIS SECTION*
; INITIATES THE DISK TRANSFER, SERVICES THE CONTROLLER*
; CHIP, AND TERMINATES THE OPERATION. ERROR DETECTION*
; IS IMPLEMENTED. *
;*****
    
```

***** (INITIALIZE WRITE OPERATION) *****

```

1294 AF WR.SEC: XRA A ;ZERO REGISTER.
1295 32 130B STA ERR.CT ;SET ERROR COUNTER.
1298 3A 1373 LDA CB.SEC ;LOAD SECTOR NMBR.
129B A9 XRA C ;INVERT (1791-01).
129C D306 OUT WD.SEC ;SET SECTOR REGISTER.
129E FD21 12B7 ..RTRY: LXI Y,..NMI ;SET NMI RETURN.
12A2 2A 1309 LHLD BUF.ST ;BUFFER START.
12A5 3EA0 MVI A,DC.WRS ;LOAD WRITE SECTOR CMD.
12A7 A9 XRA C ;INVERT (1791-01).
12A8 D304 OUT WD.CMD ;ISSUE COMMAND.
12AA E3 PAUSE ;ALLOW 1791 TO SETTLE
    
```

***** (DATA TRANSFER LOOP) *****

```

12AE DB90 ..REPT: IN XP.DSH ;HOLD FOR DATA REQ.
12B0 7E MOV A,M ;GET DATA BYTE.
12B1 A9 XRA C ;INVERT (1791-01).
12B2 D307 OUT WD.DTA ;OUTPUT DATA BYTE.
12B4 23 INX H ;INCREMENT BUFF POINTER
12B5 18F7 JMPR ..REPT ;REPEAT SEQUECE
    
```

***** (CHECK STATUS) *****

```

12B7 E6FD ..NMI: ANI DM.WER ;TEST FOR WRITE ERRORS.
12B9 32 1377 STA CB.STS ;STORE WRITE STATUS.
12BC C8 RZ ;RETURN COMPLETE.
12BD CD 12DC CALL CHK.RT ;CHECK ABOUT RETRYS.
12C0 28DC JRZ ..RTRY ;PERFORM RETRY.
12C2 C9 RET ;ERROR RETURN.
    
```

```
*****  
; WR.TRK IS THE SUBROUTINE WHICH INITIATES A FORMAT *  
; TRACK COMMAND (WRITE-TRACK 179X-01 TYPE 3). THE *  
; FORMATTING BYTE STREAM IS PROVIDED BY A PROGRAM *  
; WHICH MUST BE PRESENT IN THE FORMAT BUFFER. *  
*****
```

```
***** (INITIALIZE WRITE TRACK) *****
```

```
12C3 FD21 12D3 WR.TRK: LXI Y,..NMI ;LOAD NMI VECTOR.  
12C7 3EFO MVI A,DC.WRT ;WRITE TRACK CMND.  
12C9 A9 XRA C ;INVERT (1791-01).  
12CA D304 OUT WD.CMD ;ISSUE COMMAND.  
12CC E3 PAUSE ;ALLOW 179X TO SETTLE.  
12D0 C3 1708 JMP FMT.PS ;FORMAT PROG START.
```

```
***** (CHECK COMPLETION STATUS) *****
```

```
12D3 E6E4 ..NMI: ANI DM.FER ;TEST FOR ERRORS.  
12D5 32 1377 STA CB.STS ;STORE FORMAT STATUS.  
12D8 22 137A SHLD CW.LNG ;DISPLAY TRAIL BYTES.  
12DB C9 RET ;RETURN TO USER.
```

```
*****
```

```
*****  
; CHK.RT IS THE SUBROUTINE USED BY RD.SEC AND *  
; WR.SEC TO COUNT RETRY OPERATIONS AND PERFORM A *  
; RE-SEEK OPERATION WHEN NEEDED. *  
*****
```

```
***** (CHECK IF RECOVERABLE) *****
```

```
12DC E680 CHK.RT: ANI DM.DNR ;TEST NOT READY BIT.  
12DE 2028 JRNZ ..EXIT ;CAN NOT RECOVER.  
12E0 3A 1376 LDA CB.MOD ;GET COMMAND MODE.  
12E3 E680 ANI CM.NRT ;NO RETRYS CHECK.  
12E5 2021 JRNZ ..EXIT ;SHOULD NOT RECOVER.  
12E7 DB40 IN XP.MTX ;MOTOR TIME EXTEND.
```

```
***** (RECORD RETRY) *****
```

```
12E9 3A 130B LDA ERR.CT ;GET ERROR COUNT.  
12EC 3C INR A ;INCREMENT.  
12ED 32 130B STA ERR.CT ;STORE NEW COUNT.  
12F0 FE05 CPI RTY.SK ;SHOULD TRY SEEK?  
12F2 2008 JRNZ ..CKLS ;IF NOT, CHECK LAST.
```

```
***** (REPOSITION R/W HEAD) *****
```

```
12F4 CD 1126 CALL HOME.D ;HOME SELECTED DRIVE.  
12F7 200F JRNZ ..EXIT ;ERROR EXIT.  
12F9 CD 1180 CALL SEEK ;SEEK DESIRED TRACK.
```

```
***** (HOLD READ GATE FOR 3/4 REVOLUTION) *****
```

```
12FC FE09 ..CKLS: CPI RTY.LS ;WAS THIS THE LAST.  
12FE 2807 JRZ ..STNZ ;ERROR LAST RETRY. .  
1300 ED5B 1316 LDED TM.PLD ;PHASE LOCK DELAY.  
1304 CF WAIT ;PROGRAMMABLE DELAY.  
1305 AF XRA A ;CLEAR FOR RETRY.  
1306 C9 RET ;TRY AGAIN EXIT.
```

```
***** (ERROR EXIT) *****
```

```
1307 3C ..STNZ: INR A ;SET NOT ZERO.  
1308 C9 ..EXIT: RET ;ERROR EXIT.
```

```
*****
```

***** (BUFFER POINTERS) *****

1309 1380 BUF.ST: .WORD BUF.BG ;BUFFER START ADDRESS

130B 00 ERR.CT: .BYTE 0 ;RETRY ERROR COUNTER.

***** (HOLDING AREAS) *****

130C 00 SV.DRV: .BYTE 0 ;BL.CTL DRIVE BITS.

130D 00 SV.STS: .BYTE 000H ;1791 STATUS SAVE

***** (TIMING VALUES, 0.1 MS) *****

130E 015E TM.HLD: .WORD 350 ;HEAD ENGAGE TIME.

1310 0050 TM.STP: .WORD 80 ;STEPPER INTERVAL.

1312 0050 TM.ALS: .WORD 80 ;AFTER LAST STEP.

1314 0001 TM.MTD: .WORD 1 ;MOTOR START UP.

1316 04B0 TM.FLD: .WORD 1200 ;PHASE LOCK RECOVERY.

1318 000A TM.SAW: .WORD 10 ;STEP AFTER WRITING.

; * ENTRY * SA 800 FDD100 SA 850

; 8-C

; TM.HLD: .WORD 350 250 350

; TM.STP: .WORD 80 60 30

; TM.ALS: .WORD 80 80 120

; TM.MTD: .WORD 1 1 1

; TM.FLD: .WORD 1200 1200 1200

; TM.SAW: .WORD 10 10 10

***** (DISKETTE FORMAT LABEL) *****

131A 4A6164652044 JADEID: .ASCII "JADE^{IC} DD " ;DISKETTE ID LABEL.

0008 ID.SZE == (. - JADEID) ;ID LABEL SIZE.

1380 ID.LBL == BUF.BG+0000H ;ID SECTOR LABEL.

13A0 ID.BLK == ID.LBL+0020H ;ID BLOCK AREA.

13A0 ID.SPT == ID.BLK+0000H ;SECTORS/TRACK.

13B0 ID.STG == ID.BLK+0010H ;SECTOR STAGGER.

13B1 ID.FLG == ID.BLK+0011H ;DISKETTE FLAGS.

0000 ID.FLD == 00000000B ;3740 FLAGS.

DISK CONTROLLER MODULE (DCM)

DRIVE TABLE

```
***** (DRIVE TABLE ENTRIES) *****
```

```
0000 DV.NBR == 0 ;CURRENT DRIVE NUMBER.
0001 DV.TRK == 1 ;CURRENT TRACK NUMBER.
0002 DV.SEC == 2 ;CURRENT SECTOR NUMBER
0003 DV.SPT == 3 ;SECTORS PER TRACK.
0004 DV.STG == 4 ;SECTOR STAGGER NUMBER.
0005 DV.FLG == 5 ;SIDE AND DENSITY FLAGS
0006 DV.CTL == 6 ;LAST CONTROLS USED.
```

```
***** (DRIVE TABLE AREA) *****
```

```
1322 DV.TBL == . ;DRIVE TABLE ADDRESS.

1322 00FF00000002 DT.DE0: .BYTE 0,255,0,0,0,DF.DFL,0C4H ;DRIVE 0.
1329 01FF00000002 DT.DE1: .BYTE 1,255,0,0,0,DF.DFL,0C5H ;DRIVE 1.
1330 02FF00000002 .BYTE 2,255,0,0,0,DF.DFL,0C6H ;DRIVE 2.
1337 03FF00000002 .BYTE 3,255,0,0,0,DF.DFL,0C7H ;DRIVE 3.
133E 04FF00000000 DT.DE4: .BYTE 4,255,0,0,0,0,0 ;DUMMY.

0007 DV.DES == DT.DE1-DT.DE0 ;ENTRY SIZE.
```

```
***** (FLAG BIT DEFINITIONS) *****
```

```
0001 DF.T1D == 1 ;TRACK 1 DENSITY (1 = DOUBLE).
0002 DF.DTD == 2 ;DATA TRACKS DENSITY (1 = DD).
0003 DF.TSD == 3 ;TWO SIDED ( 1 = TWO SIDES).
0002 DF.DFL == 1<DF.T1D ;DEFAULT FLAGS.
```

```
*****
```

```
*****  
; THE FOLLOWING AREA IS DEFINED AS THE COMMAND BLOCK. *  
; THIS AREA IS RESERVED FOR SPECIFICATION BY THE HOST *  
; SYSTEM FOR ALL DISK OPERATIONS. CONTROLLER STATUS *  
; AT COMPLETION OF OPERATION IS PRESENT IN THIS AREA. *  
*****
```

```
1370          .LOC      CMD.BK  ;COMMAND BLOCK.  
  
1370      00      CB.CMD: .BYTE  0      ;CONTROL COMMAND.  
1371      00      CB.DRV: .BYTE  0      ;DRIVE NUMBER.  
1372      00      CB.TRK: .BYTE  0      ;TRACK NUMBER.  
1373      00      CB.SEC: .BYTE  0      ;SECTOR NUMBER.  
1374      00      CB.FFG: .BYTE  0      ;FORMAT FLAGS.  
1375      00      CB.SPR: .BYTE  0      ;UNASSIGNED.  
1376      00      CB.MOD: .BYTE  0      ;MODE SELECTS.  
1377      00      CB.STS: .BYTE  0      ;CONTROLLER STATUS.  
  
1378      0000     CW.LAD: .WORD  0      ;LOAD ADDRESS.  
137A      0000     CW.LNG: .WORD  0      ;LOAD LENGTH
```

```
***** (MODE BIT DEFINITIONS) *****
```

```
0080      CM.NRT  ==  1000000B  ;NO RETRYS ( = 1 ).
```

```
***** (STATUS BIT DEFINITIONS) *****
```

```
0080      CS.DNR  ==  1000000B  ;DRIVE NOT READY.  
0040      CS.WRP  ==  0100000B  ;WRITE PROTECTED.  
0020      CS.BT5  ==  0010000B  ;NOT ASSIGNED.  
0010      CS.RNF  ==  0001000B  ;RECORD NOT FOUND.  
0008      CS.CRC  ==  0000100B  ;CRC ERROR.  
0004      CS.LDE  ==  0000010B  ;LOST DATA ERROR.  
0002      CS.BT1  ==  0000001B  ;NOT ASSIGNED.  
0001      CS.BT0  ==  0000000B  ;NOT ASSIGNED.
```

```
*****
```

```
*****  
; THIS SECTION RESIDES IN THE DCM SECTOR BUFFER. THIS *  
; SECTION MOVES DCM FROM BANK 1 DOWN TO BANK 0. THE *  
; C REGISTER IS SET FOR 1791-01 OR 1793-01. THE LAST *  
; OPERATION IS TO READ THE BIOS LOADER SECTOR TO *  
; OVERLAY THIS INITIALIZATION SEQUENCE. BIOS LOADER *  
; THEN READ BIOS INTO BANK 1 AND HALTS. *  
*****
```

```
***** ( EXECUTES IN BANK 1 ) *****
```

```
1380          .LOC      BUF.BG          ;RESIDES IN BUFFER.  
1380      01 0400      INIT.B: LXI      B,BANK.L      ;SET BANK LENGTH.  
1383          LXI      D,BANK.0          ;SET DESTINATION.  
1384      21 1400      LXI      H,BANK.1          ;SET SOURCE ADDR.  
1389      ED50          LDIR            ;MOVE BLOCK.  
138B      C3 138E      JMP      ..DOWN          ;JUMP TO NEW IMAGE.
```

```
***** ( NOW IN BANK 0, SET INT MODE ) *****
```

```
138E      31 1370      ..DOWN: LXI      SP,TP.STK      ;SET STACK PNTR.  
1391      ED56          IMI            ;INTERRUPT MODE 1.
```

```
***** ( SET 1791-01/1793-01 ) *****
```

```
1393      0E00          MVI      C,0            ;LOAD C REG ZERO.  
1395      DB00          IN       BL,STS          ;BOARD STATUS.  
1397      E601          ANI      BS,USO          ;TEST USER SW #1.  
1399      2002          JRNZ     LD,BLT          ;SW OPEN - 1793.  
139B      0EFF          MVI      C,OFFH          ;SW CLOSED - 1791.
```

```
***** ( OVERLAY WITH BIOS LOADER TRANSIENT ) *****
```

```
139D      DD21 133E      LD.BLT: LXI      X,DT.DED      ;INIT DRIVE TBL.  
13A1          MVI      A,2            ;BIOS LOADER SECTOR.  
13A3      32 1373      STA      CB,SEC          ;SET SECTOR VALUE.  
13A6      DB40          IN       XP,MTX          ;MOTOR TIME EXTEND.  
13A8      21 1380      LXI      H,BUF.BG          ;SET RETURN ADDR.  
13AB      E5           PUSH     H            ;PUSH INTO STACK.  
13AC      C3 1265      JMP      RD.SEC          ;GET BIOS LOADER.
```

```
*****  
.END
```

DISK CONTROLLER MODULE (DCM)

+++++ SYMBOL TABLE +++++

BANK.0	1000	BANK.1	1400	BANK.L	0400	BASE	1000
BC.DAS	0020	BC.DDE	0010	BC.DDS	0010	BC.DSA	0001
BC.DSB	0002	BC.DSE	0004	BC.DSN	0003	BC.EIA	0008
BC.PCA	0040	BC.PCB	0080	BC.PCH	0040	BC.FCL	00C0
BC.PCM	0080	BC.PCZ	0000	BC.SDS	0000	BL.CTL	0000
BL.STS	0000	BS.DCN	0080	BS.EIA	0010	BS.INT	0008
BS.MOF	0020	BS.TSD	0040	BS.TST	0004	BS.US0	0001
BS.US1	0002	BUF.BG	1380	BUF.ST	1309	CB.CMD	1370
CB.DRV	1371	CB.FFG	1374	CB.MOD	1376	CB.SEC	1373
CB.SPR	1375	CB.STS	1377	CB.TRK	1372	CHK.RT	12DC
CMD.BK	1370	CM.NRT	0080	CS.BT0	0001	CS.BT1	0002
CS.BT5	0020	CS.CRC	0008	CS.DNR	0080	CS.LDE	0004
CS.RNF	0010	CS.WRP	0040	CW.LAD	1378	CW.LNG	137A
DC.HDL	0010	DC.HDU	0018	DC.IFI	00D8	DC.RDA	00C0
DC.RDS	0080	DC.STS	00D0	DC.WRS	00A0	DC.WRT	00F0
DF.DFL	0002	DF.DTD	0002	DF.T1D	0001	DF.TSD	0003
DM.DNR	0080	DM.FER	00E4	DM.HDL	0020	DM.LDE	0004
DM.RER	009D	DM.TKO	0004	DM.WER	00FD	DT.DEO	1322
DT.DE1	1329	DT.DED	133E	DV.CTL	0006	DV.DES	0007
DV.FLG	0005	DV.NBR	0000	DV.SEC	0002	DV.SPT	0003
DV.STG	0004	DV.TBL	1322	DV.TRK	0001	ERR.CT	130B
EX.HDL	123E	EX.HDU	124B	EX.STS	1258	FETCH	103F
FMT.BG	1700	FMT.PS	1708	HOME.D	1126	HR.INT	1038
HR.VEC	1006	ID.BLK	13A0	ID.FLD	0000	ID.FLG	13B1
ID.LBL	1380	ID.SPT	13A0	ID.STG	13B0	ID.SZE	0008
INIT.B	1380	IO.BLK	1370	JADEID	131A	LD.BLT	139D
LOG.ON	114B	NM.INT	1066	RD.SEC	1265	RST.0	1000
RST.1	1008	RST.2	1010	RST.3	1018	RST.4	1020
RST.5	1028	RST.6	1030	RST.7	1038	RTY.LS	0009
RTY.SK	0005	SEEK	1180	SELECT	10DD	SV.DRV	130C
SV.STS	130D	TICK.E	1074	TICK.R	1070	TMR.FC	0019
TMR.NC	001C	TM.ALS	1312	TM.HLD	130E	TM.MTD	1314
TM.PLD	1316	TM.SAW	1318	TM.STP	1310	TP.STK	1370
WD.CMD	0004	WD.DTA	0007	WD.INT	1066	WD.SEC	0006
WD.STS	0004	WD.TRK	0005	WR.SEC	1294	WR.TRK	12C3
XP.DSH	0080	XP.IRR	0020	XP.MTD	0010	XP.MTX	0040
XP.STP	0008	X.CUTE	1041	\$.ADDR	10CC	\$.FORM	109A
\$.IDLE	10D2	\$.LGON	10AF	\$.READ	107C	\$.SPAR	10CF
\$.WRIT	108B						

```

*****
;
; PROGRAM ID: SYSTEM BOOTSTRAP DRIVER
;
*****
;
; PROPERTY OF: JADE COMPUTER PRODUCTS
; 4901 W. ROSECRANS BLVD.
; HAWTHORNE, CALIFORNIA
; 90250, U.S.A.
;
*****
;
; VERSION: 2.2
;
*****
; THE SYSTEM BOOTSTRAP DRIVER IS ONE OF TWO MODULES
; THAT MAKE UP THE SYSTEM RESIDENT BOOTSTRAP. THIS
; MODULE IS TO BE EXECUTED BY THE SYSTEM PROCESSOR.
; DURING EXECUTION, THIS MODULE PERFORMS A BLOCK MOVE
; OF THE SECOND MODULE (BOOT INJECTION MODULE) INTO
; THE DOUBLE D CONTROLLER MEMORY. A SUCCESSFUL BOOT
; OPERATION BY THE DOUBLE D WILL LEAVE DCM IN BANK 0
; AND BIOS IN BANK 1. THE REMAINDER OF THIS MODULE
; THEN MOVES THE BIOS IMAGE TO THE PROPER SYSTEM
; ADDRESS AND JUMPS TO THE BIOS COLD START ENTRY.
; ***** SK *****
;
; *****
; DOUBLE D HARDWARE PARAMETERS. PLEASE NOTE THIS
; SECTION CONTAINS CONDITIONAL STATEMENTS.
; *****
;
0043 = D$PORT EQU 043H ;DOUBLE D PORT ADDRESS.
0001 = TRUE EQU 1 ;TRUE IS A ONE.
0000 = FALSE EQU 0 ;FALSE IS A ZERO.
0001 = REV$B EQU TRUE ;SET TRUE FOR REV B BOARDS.
0000 = REV$C EQU FALSE ;SET TRUE FOR REV C BOARDS.
0000 = MA10 EQU FALSE ;TRUE IF MA10 JUMPED (REV-B).
;
; IF REV$B
0002 = DS$HLT EQU 002H ;STATUS PORT HALT INDICATOR.
000C = DS$ASW EQU 00CH ;STATUS PORT ADDR SW MASK.
D$BASE SET 0E400H ;SYSTEM WINDOW BASE ADDRESS
ENDIF
;
; IF MA10
D$BASE EQU 0E000H ;SYSTEM WINDOW BASE ADDRESS
ENDIFF
;
; IF REV$C
DS$HLT EQU 001H ;STATUS PORT HALT INDICATOR.
DS$ASW EQU 00EH ;STATUS PORT ADDR SW MASK.
D$BASE EQU 0E000H ;SYSTEM WINDOW BASE ADDRESS
ENDIF
;
; *****
; BOOTSTRAP INJECTION MODULE PARAMETERS
; *****
;
1000 = IM$ADR EQU 1000H ;BOOT INJECTION MODULE ADDRESS.
00C0 = IM$SIZE EQU 00C0H ;BOOT INJECTION MODULE SIZE.
;

```

```

; BOOTSTRAP LINKAGE ADDRESS.
;*****
;
0080 = BSTACK EQU 0080H ;BOOTSTRAP TOP OF STACK.
0040 = D$ADDR EQU 0040H ;DOUBLE D ADDRESS POINTER.
0377 = BL$DCS EQU 0377H ;DCM DISK CONTROLLER STATUS.
0378 = BL$ADR EQU 0378H ;DCM LOAD AND JUMP ADDRESS.
037A = BL$BSZ EQU 037AH ;DCM BLOCK LOAD SIZE.
;
;*****
; DOUBLE D HARDWARE COMMANDS
;*****
;
0080 = DC$BGN EQU 080H ;RESET Z80A AND EXECUTE.
0001 = DC$MRQ EQU 001H ;REQUEST MEMORY WINDOW.
0000 = DC$MRT EQU 000H ;RELEASE MEMORY WINDOW$
0001 = DC$MBO EQU 001H ;SELECT MEMORY BANK 0.
0003 = DC$MB1 EQU 003H ;SELECT MEMORY BANK 1.
0002 = DC$EXC EQU 002H ;ISSUE DOUBLE D INTERRUPT.
;
;*****
; ASSEMBLER DIRECTIVES
;*****
;
0100 ORG 0100H ;MODULE ADDRESS (ALTERABLE).
;
;*****
; SET STACK AND CONTROLLER ADDRESS
;*****
;
0100 318000 BEGIN: LXI SP,BSTACK ;SET STACK POINTER.
0103 DB43 IN D$PORT ;INPUT STATUS PORT.
0105 E60C ANI DS$ASW ;MASK FOR ADDR SWS.
0107 07 RLC ;POSITION BITS.
0108 F6E4 ORI D$BASE SHR 8 ;OR IN BASE ADDR.
010A 67 MOV H,A ;HIGH BYTE VALUE.
010B 2E00 MVI L,0 ;LOW BYTE VALUE.
010D 224000 SHLD D$ADDR ;STORE THE ADDRESS
;
;*****
; INJECT BOOT MODULE INTO CONTROLLER
;*****
;
0110 3E01 INJECT: MVI A,DC$MBO ;REQUEST DD MEM BANK 0.
0112 D343 OUT D$PORT ;ISSUE COMMAND.
0114 01C000 LXI B,IM$SIZE ;INJECTION SIZE.
0117 EB XCHG ;D$ADDR HL TO DE.
0118 210010 LXI H,IM$ADR ;INJECTION MODULE.
011B CD5901 CALL BLOCK ;BLOCK MOVE.
;
;*****
; RESET AND START THE DISK PROCESSOR
;*****
;
011E 3E80 MVI A,DC$BGN ;BEGIN DD PROCESSOR.
0120 D343 OUT D$PORT ;ISSUE COMMAND.
0122 E3 XTHL ;ALLOW DOUBLE D TIME
0123 E3 XTHL ;TO START UP.
;
;*****
; WAIT FOR TASK COMPLETION
;*****
;
0124 DB43 WAIT: IN D$PORT ;INPUT DD STATUS.
0126 E602 ANI DS$HLT ;TEST HALT* STATUS.

```

; SWITCH CONTROLLER MEMORY INTO SYSTEM BUS *

012B 3E01 MVI A,DC\$MRQ ;REQUEST MEM (BANK 0).
012D D343 OUT D\$PORT ;ISSUE COMMAND.

;

; CHECK FOR BOOTSTRAP MALFUNCTION *

012F 2A4000 LHLD D\$ADDR ;CONTROLLER ADDRESS.
0132 117703 LXI D,BL\$DCS ;ERROR CODE OFFSET.
0135 19 DAD D ;SET HL POINTER.
0136 7E MOV A,M ;GET ERROR CODE.
0137 A7 ANA A ;TEST REGISTER.
0138 C26601 JNZ BAD\$LD ;BAD LOAD.

;

; PERFORM BLOCK TRANSFER FROM DISK MEMORY *

013B 2A4000 LHLD D\$ADDR ;CONTROLLER ADDRESS.
013E 117803 LXI D,BL\$ADR ;LOAD ADDRESS PNTR.
0141 19 DAD D ;SET HL POINTER.
0142 5E MOV E,M ;LOW ORDER ADDR.
0143 23 INX H ;INCREMENT HL.
0144 56 MOV D,M ;HIGH ORDER ADDR.
0145 23 INX H ;REQUIRES BL.BSZ NEXT.
0146 4E MOV C,M ;LOW ORDER LENGTH.
0147 23 INX H ;INCREMENT HL.
0148 46 MOV B,M ;HIGH ORDER LENGTH.
0149 D5 PUSH D ;USE AS JUMP ADDR.
014A 3E03 MVI A,DC\$MB1 ;SWITCH TO MEM BANK 1.
014C D343 OUT D\$PORT ;ISSUE COMMAND.
014E 2A4000 LHLD D\$ADDR ;DOUBLE D MEM ADDRESS.
0151 CD5901 CALL BLOCK ;MOVE BIOS MODULE.

;

; TRANSFER CONTROL TO OPERATING SYSTEM *

0154 3E01 MVI A,DC\$MBO ;SWITCH TO BANK.0
0156 D343 OUT D\$PORT ;ISSUE COMMAND.
0158 C9 RET ;GOTO BIOS COLD ENTRY.

;

; BLOCK MOVE SUBROUTINE (Z80 BLOCK MOVE REGISTERS) *

0159 7E BLOCK: MOV A,M ;GET BYTE.
015A 23 INX H ;INC POINTER
015B EB XCHG ;GET DESTINATION.
015C 77 MOV M,A ;PUT BYTE.
015D 23 INX H ;INC POINTER
015E EB XCHG ;GET SOURCE.
015F 0B DCX B ;ONE LESS TO DO.
0160 78 MOV A,B ;GET HI COUNT.
0161 B1 ORA C ;GET LO COUNT.
0162 C25901 JNZ BLOCK ;FINISH LOADING.
0165 C9 RET

;

; ERROR HAS BEEN DETECTED *

TDL Z80 CP/M DISK ASSEMBLER VERSION 2.21
SYSTEM BOOTSTRAP DRIVER - JADE DOUBLE D
TITLE PAGE

PAGE 1

```
*****  
;  
; PROGRAM ID: SYSTEM BOOTSTRAP DRIVER *  
;  
; *****  
; PROPERTY OF: JADE COMPUTER PRODUCTS *  
; 4901 W. ROSECRANS BLVD. *  
; HAWTHORNE, CALIFORNIA *  
; 90250, U.S.A. *  
;  
; *****  
; VERSION: 2.2 *  
;  
; *****  
; THE SYSTEM BOOTSTRAP DRIVER IS ONE OF TWO MODULES *  
; THAT MAKE UP THE SYSTEM RESIDENT BOOTSTRAP. THIS *  
; MODULE IS TO BE EXECUTED BY THE SYSTEM PROCESSOR. *  
; DURING EXECUTION, THIS MODULE PERFORMS A BLOCK MOVE *  
; OF THE SECOND MODULE (BOOT INJECTION MODULE) INTO *  
; THE DOUBLE D CONTROLLER MEMORY. A SUCCESSFUL BOOT *  
; OPERATION BY THE DOUBLE D WILL LEAVE DCM IN BANK 0 *  
; AND BIOS IN BANK 1. THE REMAINDER OF THIS MODULE *  
; THEN MOVES THE BIOS IMAGE TO THE PROPER SYSTEM *  
; ADDRESS AND JUMPS TO THE BIOS COLD START ENTRY. *  
; ***** SK ***
```

```
*****  
; DOUBLE D HARDWARE PARAMETERS. PLEASE NOTE THIS *  
; SECTION CONTAINS CONDITIONAL STATEMENTS. *  
*****
```

```
0043 D.PORT == 043H ;DOUBLE D PORT ADDRESS.  
0001 TRUE == 1 ;TRUE IS A ONE.  
0000 FALSE == 0 ;FALSE IS A ZERO.  
0001 REV.B == TRUE ;SET TRUE FOR REV B BOARDS.  
0000 REV.C == FALSE ;SET TRUE FOR REV C BOARDS.  
0000 MA10 == FALSE ;TRUE IF MA10 JUMPED (REV-B).
```

```
.IFG REV.B, [  
0002 DS.HLT == 002H ;STATUS PORT HALT INDICATOR.  
000C DS.ASW == 00CH ;STATUS PORT ADDR SW MASK.  
E400 D.BASE = 0E400H ;SYSTEM WINDOW BASE ADDRESS]
```

```
.IFG MA10, [  
D.BASE == 0E000H ;SYSTEM WINDOW BASE ADDRESS]
```

```
.IFG REV.C, [  
DS.HLT == 001H ;STATUS PORT HALT INDICATOR.  
DS.ASW == 00EH ;STATUS PORT ADDR SW MASK.  
D.BASE == 0E000H ;SYSTEM WINDOW BASE ADDRESS]
```

```
*****  
; BOOTSTRAP INJECTION MODULE PARAMETERS (ALTERABLE) *  
*****
```

```
0200 IM.ADR == 0200H ;BOOT INJECTION MODULE ADDRESS.  
00C0 IM.SZ == 00C0H ;BOOT INJECTION MODULE SIZE.
```

```
*****  
; BOOTSTRAP LINKAGE ADDRESS. *  
*****
```

```
0080 BSTACK == 0080H ;BOOTSTRAP TOP OF STACK.  
0040 D.ADDR == 0040H ;DOUBLE D ADDRESS POINTER.  
0377 BL.DCS == 0377H ;DCM DISK CONTROLLER STATUS.  
0378 BL.ADR == 0378H ;DCM LOAD AND JUMP ADDRESS.  
037A BL.BSZ == 037AH ;DCM BLOCK LOAD SIZE.
```

```
*****  
; DOUBLE D HARDWARE COMMANDS *  
*****
```

```
0080 DC.BGN == 080H ;RESET Z80A AND EXECUTE.  
0001 DC.MRQ == 001H ;REQUEST MEMORY WINDOW.  
0000 DC.MRT == 000H ;RELEASE MEMORY WINDOW.  
0001 DC.MB0 == 001H ;SELECT MEMORY BANK 0.  
0003 DC.MB1 == 003H ;SELECT MEMORY BANK 1.  
0002 DC.EXC == 002H ;ISSUE DOUBLE D INTERRUPT.
```

```
*****
```

```

;*****
; ASSEMBLER DIRECTIVES
;*****
    
```

```

                                .I8080          ;USE 8080 INSTRUCTION SUBSET.
                                .PABS           ;ASSEMBLE ABSOLUTE ADDRESS.
                                .PHEX          ;GENERATE INTEL HEX FORMAT.
0100                                .XLINK       ;SUPPRESS LINKAGE OUTPUT.
                                .LOC          0100H ;MODULE ADDRESS (ALTERABLE).
    
```

```

;*****
; SET STACK AND CONTROLLER ADDRESS
;*****
    
```

```

0100    31 0080    BEGIN: LXI    SP,BSTACK    ;SET STACK POINTER.
0103    DB43      IN      D,PORT           ;INPUT STATUS PORT.
0105    E60C      ANI     DS,ASW           ;MASK FOR ADDR SWS.
0107    07        RLC                    ;POSITION BITS.
0108    F6E4      ORI     D,BASE>8        ;OR IN BASE ADDR.
010A    67        MOV     H,A             ;HIGH BYTE VALUE.
010B    2E00      MVI     L,0             ;LOW BYTE VALUE.
010D    22 0040   SHLD   D,ADDR           ;STORE THE ADDRESS
    
```

```

;*****
; INJECT BOOT MODULE INTO CONTROLLER
;*****
    
```

```

0110    3E01      INJECT: MVI    A,DC.MBO    ;REQUEST DD MEM BANK 0.
0112    D343      OUT     D,PORT           ;ISSUE COMMAND.
0114    01 00C0   LXI     B,IM.SZ          ;INJECTION SIZE.
0117    EB        XCHG                    ;D.ADDR HL TO DE.

0118    21 0200   LXI     H,IM.ADR        ;INJECTION MODULE.
011B    CD 0159   CALL    BLOCK            ;BLOCK MOVE.
    
```

```

;*****
; RESET AND START THE DISK PROCESSOR
;*****
    
```

```

011E    3E80      MVI     A,DC.BGN        ;BEGIN DD PROCESSOR.
0120    D343      OUT     D,PORT           ;ISSUE COMMAND.
0122    E3        XTHL                    ;ALLOW DOUBLE D TIME
0123    E3        XTHL                    ;TO START UP.
    
```

```

;*****
; WAIT FOR TASK COMPLETION
;*****
    
```

```

0124    DB43      WAIT:  IN      D,PORT           ;INPUT DD STATUS.
0126    E602      ANI     DS,HLT           ;TEST HALT* STATUS.
0128    C2 0124   JNZ     WAIT            ;WAIT TILL HALTED.
    
```

```

;*****
; SWITCH CONTROLLER MEMORY INTO SYSTEM BUS *
;*****

```

```

012B 3E01 MVI A,DC.MRQ ;REQUEST MEM (BANK 0).
012D D343 OUT D.PORT ;ISSUE COMMAND.

```

```

;*****
; CHECK FOR BOOTSTRAP MALFUNCTION *
;*****

```

```

012F 2A 0040 LHLD D.ADDR ;CONTROLLER ADDRESS.
0132 11 0377 LXI D,BL.DCS ;ERROR CODE OFFSET.
0135 19 DAD D ;SET HL POINTER.
0136 7E MOV A,M ;GET ERROR CODE.
0137 A7 ANA A ;TEST REGISTER.
0138 C2 0166 JNZ BAD.LD ;BAD LOAD.

```

```

;*****
; PERFORM BLOCK TRANSFER FROM DISK MEMORY *
;*****

```

```

013B 2A 0040 LHLD D.ADDR ;CONTROLLER ADDRESS.
013E 11 0378 LXI D,BL.ADR ;LOAD ADDRESS PNTR.
0141 19 DAD D ;SET HL POINTER.
0142 5E MOV E,M ;LOW ORDER ADDR.
0143 23 INX H ;INCREMENT HL.
0144 56 MOV D,M ;HIGH ORDER ADDR.
0145 23 INX H ;REQUIRES BL.BSZ NEXT.
0146 4E MOV C,M ;LOW ORDER LENGTH.
0147 23 INX H ;INCREMENT HL.
0148 46 MOV B,M ;HIGH ORDER LENGTH.
0149 D5 PUSH D ;USE AS JUMP ADDR.
014A 3E03 MVI A,DC.MB1 ;SWITCH TO MEM BANK 1.
014C D343 OUT D.PORT ;ISSUE COMMAND.
014E 2A 0040 LHLD D.ADDR ;DOUBLE D MEM ADDRESS.
0151 CD 0159 CALL BLOCK ;MOVE BIOS MODULE.

```

```

;*****
; TRANSFER CONTROL TO OPERATING SYSTEM *
;*****

```

```

0154 3E01 MVI A,DC.MB0 ;SWITCH TO BANK.0
0156 D343 OUT D.PORT ;ISSUE COMMAND.
0158 C9 RET ;GOTO BIOS COLD ENTRY.

```

; BLOCK MOVE SUBROUTINE (Z80 BLOCK MOVE REGISTERS) *

0159	7E	BLOCK:	MOV	A,M	;GET BYTE.
015A	23		INX	H	;INC POINTER
015B	EB		XCHG		;GET DESTINATION.
015C	77		MOV	M,A	;PUT BYTE.
015D	23		INX	H	;INC POINTER
015E	EB		XCHG		;GET SOURCE.
015F	0B		DCX	B	;ONE LESS TO DO.
0160	78		MOV	A,B	;GET HI COUNT.
0161	B1		ORA	C	;GET LO COUNT.
0162	C2 0159		JNZ	BLOCK	;FINISH LOADING.
0165	C9		RET		

; ERROR HAS BEEN DETECTED *

0166	21 016D	BAD.LD:	LXI	H,ER.MSG	;ERROR MESSAGE
0169	CD 0196		CALL	MSG.OT	;DISPLAY IT.
016C	76		HLT		;HALT OR GOTO MONITOR.

016D 0D0A0A535953 ER.MSG: .ASCIZ [CR][LF][LF]"SYSTEM BOOT LOAD ERROR"

```

;*****
;  CONSOLE LINKAGE DEFINITIONS
;*****

```

```

0000      CNO.SP ==      000H      ;OUTPUT STATUS PORT.
0004      CNO.SB ==      004H      ;OUTPUT STATUS BIT.
0000      CNO.SI ==      000H      ;OUTPUT STATUS INVERT.
0001      CNO.DP ==      001H      ;OUTPUT DATA PORT.

000A      LF ==      00AH      ;ASCII LINE FEED
000D      CR ==      00DH      ;CARRIAGE RETURN

```

```

;*****
;  CONSOLE OUTPUT
;*****

```

```

0186      F5      CNS.OT: PUSH      PSW      ;SAVE CHARACTER
0187      DB00    ..WAIT: IN      CNO.SP    ;INPUT STATUS
0189      EE00    XRI      CNO.SI    ;ADJUST POLARITY
018B      E604    ANI      CNO.SB    ;MASK STATUS BIT
018D      CA 0187 JZ      ..WAIT    ;TRY AGAIN
0190      F1      POP      PSW      ;RESTORE CHARACTER
0191      E67F    ANI      07FH     ;7 BIT ASCII
0193      D301    OUT      CNO.DP    ;SEND CHARACTER
0195      C9      RET

```

```

;*****
;  DISPLAY MESSAGE SUBROUTINE
;*****

```

```

0196      F5      MSG.OT: PUSH      PSW      ;SAVE CALLER FLAGS.
0197      7E      ..REPT: MOV      A,M     ;LOAD CHARACTER.
0198      CD 0186 CALL      CNS.OT    ;CONSOLE OUTPUT.
019B      7E      MOV      A,M     ;SAME CHARACTER.
019C      23      INX      H       ;INCREMENT POINTER.
019D      E680    ANI      080H     ;TEST SIGN BIT.
019F      CA 0197 JZ      ..REPT    ;ANOTHER CHARACTER.
01A2      F1      POP      PSW      ;RESTORE FLAGS.
01A3      C9      RET      ;RETURN TO CALLER.

```

```

;*****

```

```

0100      .END      BEGIN

```

TDL Z80 CP/M DISK ASSEMBLER VERSION 2.21
SYSTEM BOOTSTRAP DRIVER - JADE DOUBLE D
+++++ SYMBOL TABLE +++++

PAGE 7

BAD.LD 0166	BEGIN 0100	BLOCK 0159	BL.ADR 0378
BL.BSZ 037A	BL.DCS 0377	BSTACK 0080	CNO.DP 0001
CNO.SB 0004	CNO.SI 0000	CNO.SP 0000	CNS.OT 0186
CR 000D	DC.BGN 0080	DC.EXC 0002	DC.MB0 0001
DC.MB1 0003	DC.MRQ 0001	DC.MRT 0000	DS.ASW 000C
DS.HLT 0002	D.ADDR 0040	D.BASE E400	D.PORT 0043
ER.MSG 016D	FALSE 0000	IM.ADR 0200	IM.SZE 00C0
INJECT 0110	LF 000A	MA10 0000	MSG.OT 0196
REV.B 0001	REV.C 0000	TRUE 0001	WAIT 0124

TDL Z80 CP/M DISK ASSEMBLER VERSION 2.21
INJECTION MODULE - JADE DOUBLE D DISK CONTROLLER
TITLE PAGE

PAGE 1

```
*****  
;  
; PROGRAM ID: BOOTSTRAP INJECTION MODULE *  
;  
*****  
;  
; PROPERTY OF: JADE COMPUTER PRODUCTS *  
; 4901 W. ROSECRANS BLVD. *  
; HAWTHORNE, CALIFORNIA *  
; 90250, U.S.A. *  
;  
*****  
;  
; VERSION: 2.2 *  
;  
*****  
; THE BOOTSTRAP INJECTION MODULE IS ONE OF TWO *  
; MODULES THAT TOGETHER MAKE UP THE SYSTEM RESIDENT *  
; BOOT. THIS MODULE IS DOWNLOADED INTO THE DOUBLE D *  
; MEMORY BY THE SYSTEM BOOTSTRAP DRIVER. THE MODULE *  
; THEN READS IN THE DISK CONTROLLER MODULE (DCM) FROM *  
; TRACK 0. THE ORIGIN OF THIS PROGRAM IS FIXED AS IT *  
; IS ASSEMBLED TO EXECUTE INSIDE THE DOUBLE D. THE *  
; BOOT INJECTION MODULE CAN THEREFORE RESIDE IN *  
; THE BOOTSTRAP PROM WITHOUT THE NEED TO REASSEMBLE. *  
; NOTE: STEP TIMING AND MOTOR TURN-ON DELAYS ARE *  
; DEFINED IN THIS MODULE. PATCHING MAY BE REQUIRED. *  
***** SK ***
```

```
*****  
; CONTROLLER PORT ASSIGNMENTS *  
*****
```

```
0000 BL.STS == 000H ;BOARD STATUS  
0000 BL.CTL == 000H ;BOARD CONTROLS  
0004 WD.CMD == 004H ;1791 COMMAND REGISTER  
0004 WD.STS == 004H ;1791 STATUS REGISTER  
0005 WD.TRK == 005H ;1791 TRACK REGISTER  
0006 WD.SEC == 006H ;1791 SECTOR REGISTER  
0007 WD.DTA == 007H ;1791 DATA REGISTER  
0008 XP.STP == 008H ;STEPPER PULSE  
0010 XP.MTO == 010H ;MOTOR TIME OUT  
0040 XP.MTX == 040H ;MOTOR TIME EXTEND  
0080 XP.DSH == 080H ;DATA SYNC HOLD
```

```
*****  
; 1791-01 COMMAND CODES *  
*****
```

```
0018 DC.HDL == 018H ;LOAD R/W HEAD.  
0090 DC.RMS == 090H ;READ MULTI-SECTOR.  
00D0 DC.STS == 0D0H ;SET TYPE 1 STATUS.
```

```
*****  
; BOARD STATUS AND CONTROL PORTS *  
*****
```

```
0001 BS.USO == 001H ;1791-01 INDICATOR (CLOSED).  
0000 BC.DRO == 000H ;DRIVE 0 SELECT.  
0004 BC.DSE == 004H ;DRIVE SELECT ENABLE
```

```
*****  
; DISK STATUS MASKS *  
*****
```

```
009C DM.RER == 10011100B ;READ ERROR TEST MASK  
0004 DM.TKO == 00000100B ;TRACK 0 TEST
```

```
*****  
; DISK DRIVE PARAMETERS *  
*****
```

```
0008 TM.STP == 8 ;STEPPER INTERVAL - MS.  
0001 TM.DBR == 1 ;DELAY BEFORE READ- MS.  
0050 NB.TRK == 80 ;MAXIMUM NMBR OF STEPS.
```

```
*****
```

```

;*****
; INTERNAL MEMORY ASSIGNMENTS
;*****

0000      BANK.0 ==      0000H      ;LOWER BANK ADDRESS.
0400      BANK.L ==      0400H      ;1K BANK LENGTH.
0400      BANK.1 ==      BANK.0+BANK.L ;UPPER BANK ADDRESS.
0066      INT.NM ==      BANK.0+0066H ;NON-MASKABLE INT ADDR.
0376      BL.ERC ==      BANK.0+0376H ;ERROR CODE LOCATION.
0377      BL.DCS ==      BANK.0+0377H ;DISK CONTROLLER STAT.

;*****
; BOOTSTRAP COMMUNICATION
;*****

0001      BE.HOM ==      001H        ;HOME ERROR.
0002      BE.RDA ==      002H        ;READ ERROR A.
0004      BE.RDB ==      004H        ;READ ERROR B.

;*****
; DISK CONTROLLER MODULE (DCM) LINKAGE
;*****

000D      DCM.SS ==      13          ;FIRST DCM SECTOR = 13.
0403      DCM.BG ==      BANK.1+3    ;DCM COLD START ENTRY.
0400      DCM.LN ==      0400H       ;DCM LENGTH

;*****
; ASSEMBLER DIRECTIVES
;*****

          .FABS          ;ABSOLUTE ADDRESSING.
          .PHEX         ;INTEL HEX FILE FORM.
          .XLINK         ;NO LINKAGE OUTPUT.
0000      .LOC          BANK.0      ;PROGRAM START POINT

;*****
; DELAY MACRO.  ALLOWS 1791 TO DIGEST INSTRUCTIONS
;*****

.DDEFINE DELAY = [
    XTHL
    XTHL
    XTHL
    XTHL]

;*****

```

 ; SET STACK, START DRIVE MOTOR, AND SET INVERT SW (C) *

```

0000 31 0400 BEGIN: LXI SP,BANK.1 ;SET UP STACK.
0003 DB40 IN XP.MTX ;TURN ON MOTOR.
0005 0E00 MVI C,0 ;ASSUME 1793.
0007 DB00 IN BL.STS ;INPUT STATUS.
0007 E601 ANI BS.USO ;TEST USER SW 0.
000F 2002 JRNZ SELECT ;GOTO SELECT DRV.
000D 0EFF MVI C,OFFH ;1791-01 INVERTS.
    
```

 ; CLEAR 1791-01 INTERRUPT AND SELECT DRIVE 0 *

```

000F CD 009C SELECT: CALL STATUS ;179X-01 FORCED CLEAR.
0012 3E04 MVI A,BC.DSE!BC.DRO ;DRIVE 0, ENABLED.
0014 D300 OUT BL.CTL ;OUTPUT CONTROLS.
    
```

 ; POSITION R/W HEAD AT TRACK ZERO *

```

0016 2E50 HOME: MVI L,NB.TRK ;SET MAX TRACKS.
0018 CD 009C STEP: CALL STATUS ;GET 179X STATUS.
001B E604 ANI DM.TKO ;TEST TRACK 0 BIT.
001D 200E JRNZ TRACK0 ;TRACK 0 EXIT.
001F 2D DCR L ;DEC ATTEMPTS.
0020 CA 0091 JZ ER.HOM ;CANT FIND TRK 0?
0023 DB08 IN XP.STP ;ISSUE STEP PULSE.
0025 11 0008 LXI D,TM.STP ;STEP INTERVAL TIME.
0028 CD 00A9 CALL TIMER ;PAUSE FOR PERIOD.
002B 18EB JMPR STEP ;TRY ANOTHER TIME.
    
```

 ; LOAD R/W HEAD ON SELECTED DRIVE *

```

002D 79 TRACK0: MOV A,C ;GET TRACK 0 VALUE.
002E D305 OUT WD.TRK ;SET TRACK REGISTER.
0030 D307 OUT WD.DTA ;SEEK SAME TRACK.
0032 FD21 003D LXI Y,RD.SET ;SET NMI RETURN ADDR.
0036 3E18 MVI A,DC.HDL ;HEAD LOAD COMMAND.
0038 A9 XRA C ;INVERT (1791-01).
0039 D304 OUT WD.CMD ;ISSUE COMMAND.
003B 18FE JMPR . ;WAIT FOR INTERRUPT.
    
```

```

;*****
; SET-UP FOR DCM READ OPERATION
;*****
    
```

```

003D 11 0001 RD.SET: LXI D, TM.DBR ;DELAY BEFORE READ.
0040 CD 00A9 CALL TIMER ;CALL MS. TIMER.
0043 11 0400 LXI D, BANK.L ;SET BANK LENGTH
0046 21 0400 LXI H, BANK.1 ;DCM LOAD ADDRESS
0049 FD21 0089 LXI Y, ER.RDA ;READ ERROR TRAP.
004D 3E0D MVI A, DCM.SS ;FIRST SEC OF DCM.
004F A9 XRA C ;INVERT (1791-01)
0050 D306 OUT WD.SEC ;SET 179X SEC REG.
0052 3E90 MVI A, DC.RMS ;READ MULTI-SECTOR.
0054 A9 XRA C ;INVERT (1791-01).
0055 D304 OUT WD.CMD ;ISSUE 179X COMMAND.
0057 E3 DELAY ;ALLOW 179X TO SETTLE.
005B 1813 JMPR R.BYTE ;GOTO READ ROUTINE.
    
```

```

;*****
; DISK INTERRUPT "NMI" ROUTINE
;*****
    
```

```

0066 .LOC INT.NM

0066 DB04 WD.INT: IN WD.STS ;GET 1791 STATUS.
0068 A9 XRA C ;INVERT (1791-01).
0069 32 0377 STA BL.DCS ;MAKE STATUS VISIBLE.
006C FDE3 XTIY ;EXCHANGE (SP)<>IY!
006E ED45 RETN ;BRANCH VECTOR ADDR.
    
```

```

;*****
; ACCEPT EACH BYTE AND STORE IN MEMORY
;*****
    
```

```

0070 DB80 R.BYTE: IN XP.DSH ;WAIT FOR DATA.
0072 DB07 IN WD.DTA ;INPUT INV DATA.
0074 A9 XRA C ;INVERT (1791-01).
0075 77 MOV M,A ;STORE DCM BYTE.
0076 23 INX H ;INCREMENT POINTER.
0077 1B DCX D ;DECREMENT LENGTH.
0078 7A MOV A,D ;GET HIGH REG.
0079 B3 ORA E ;THEN OR-IN LOW REG.
007A 20F4 JRNZ R.BYTE ;READ ANOTHER BYTE.
    
```

```

;*****
    
```

```

;*****
; TEST READ STATUS, TERMINATE OPERATION, GO DCM *
;*****
    
```

```

007C DB04 R.TEST: IN WD.STS ;INPUT READ STATUS.
007E A9 XRA C ;INVERT (1791-01).
007F E69C ANI DM.RER ;TEST FOR ERRORS.
0081 200A JRNZ ER.RDB ;READ ERROR TRAP.
0083 CD 009C CALL STATUS ;TERMINATE READ.
0086 C3 0403 JMP DCM.BG ;TRANSFER TO DCM.
    
```

```

;*****
; READ ERROR HAS BEEN DETECTED *
;*****
    
```

```

0089 3E02 ER.RDA: MVI A,BE.RDA ;LOAD READ ERROR CODE.
008B 1806 JMPR ER.HLT ;GO TO ERROR HALT.
008D 3E04 ER.RDB: MVI A,BE.RDB ;LOAD READ ERROR CODE.
008F 1802 JMPR ER.HLT ;GO TO ERROR HALT.
0091 3E01 ER.HOM: MVI A,BE.HOM ;HOME ERROR CODE.
0093 32 0376 ER.HLT: STA BL.ERC ;DISPLAY ERROR CODE.
0096 AF XRA A ;ZERO A REG.
0097 D300 OUT BL.STS ;DESELECT DRIVE.
0099 DB10 IN XP.MTO ;MOTOR OFF!
009B 76 HLT ;TERMINATE.
    
```

```

;*****
; GET UPDATED 1791-01 STATUS *
;*****
    
```

```

009C 3E00 STATUS: MVI A,DC.STS ;TYPE 4 - STATUS.
009E A9 XRA C ;INVERT (1791-01).
009F D304 OUT WD.CMD ;ISSUE COMMAND.
00A1 E3 DELAY ;ALLOW 1791 TIME.
00A5 DB04 IN WD.STS ;GET STATUS
00A7 A9 XRA C ;INVERT (1791-01).
00A8 C9 RET ;RETURN TO CALLER.
    
```

```

;*****
; TIMER - WAIT FOR (BC * 1.0) MILLISECONDS *
;*****
    
```

```

00A9 3EF7 TIMER: MVI A,247 ;LOAD INT MS VALUE.
00AB 3D MS.INT: DCR A ;DEC FOR 1 MS.
00AC 20FD JRNZ MS.INT ;REPEAT FOR 1 MS.
00AE 1B DCX D ;TEST FOR ANOTHER MS.
00AF 7A MOV A,D ;CHECK REG D.
00B0 B3 ORA E ;AND REGISTER E.
00B1 20F6 JRNZ TIMER ;DO ANOTHER 1 MS.
00B3 C9 RET ;TIME PERIOD EXPIRED!
    
```

```

;*****
    
```

.END

CHK.O 0000	BANK.1 0400	BANK.L 0400	BC.DRO 0000
DSE 0004	BEGIN 0000	BE.HOM 0001	BE.RDA 0002
BE.RDB 0004	BL.CTL 0000	BL.DCS 0377	BL.ERC 0376
BL.STS 0000	BS.USC 0001	DCM.BG 0403	DCM.LN 0400
DCM.SS 000D	DC.HDL 0018	DC.RMS 0090	DC.STS 00D0
DM.RER 009C	DM.TKO 0004	ER.HLT 0093	ER.HOM 0091
ER.RDA 0089	ER.RDB 008D	HOME 0016	INT.NM 0066
MS.INT 00AB	NB.TRK 0050	RD.SET 003D	R.BYTE 0070
R.TEST 007C	SELECT 000F	STATUS 009C	STEP 0018
TIMER 00A9	TM.DBR 0001	TM.STP 0008	TRACKO 002D
WD.CMD 0004	WD.DTA 0007	WD.INT 0066	WD.SEC 0006
WD.STS 0004	WD.TRK 0005	XP.DSH 0080	XP.MTD 0010
XP.MTX 0040	XP.STP 0008		

```

; *****
;
;          PROGRAM ID:      BIOS LOADER TRANSIENT      *
;
; *****
;
;          PROPERTY OF:    JADE COMPUTER PRODUCTS      *
;                          4901 W. ROSECRANS BLVD.    *
;                          HAWTHORNE, CALIFORNIA      *
;                          90250, U.S.A.             *
;
; *****
;
;          VERSION:        2.2                        *
;
; *****
; THE BIOS LOADER IS READ INTO THE DCM SECTOR BUFFER *
; AFTER THE DCM PROGRAM HAS INITIALIZE. THIS PROGRAM *
; THEN READS THE BIOS MODULE (1K) INTO BANK 1. THE  *
; COMMAND BLOCK IN DCM IS SET TO INDICATE THE BIOS  *
; MODULE SIZE AND ITS LOAD ADDRESS. THE BIOS LOADER *
; PROGRAM IS GENERATED BY MOVCPM.COM AS THE COLD   *
; START LOADER (900-97F HEX).                       *
; ***** SK *****

```

```
*****  
; CONTROLLER PORT ASSIGNMENTS *  
*****
```

```
0000      BL.STS  ==      000H      ;BOARD STATUS  
0000      BL.CTL  ==      000H      ;BOARD CONTROLS  
0004      WD.CMD  ==      004H      ;1791 COMMAND REGISTER  
0004      WD.STS  ==      004H      ;1791 STATUS REGISTER  
0006      WD.SEC  ==      006H      ;1791 SECTOR REGISTER  
0007      WD.DTA  ==      007H      ;1791 DATA REGISTER  
0010      XP.MTO  ==      010H      ;MOTOR TIME OUT  
0040      XP.MTX  ==      040H      ;MOTOR TIME EXTEND  
0080      XP.DSH  ==      080H      ;DATA SYNC HOLD
```

```
*****  
; 1791-01 COMMAND AND MASK. *  
*****
```

```
0080      DC.RDS  ==      10000000B ;READ SECTOR.  
009C      DM.RER  ==      10011100B ;READ ERROR MASK.
```

```
*****  
; SYSTEM ASSIGNMENTS *  
*****
```

```
0014      NMBR.K  ==      20          ;SYSTEM SIZE IN K.  
0400      LNG.1K  ==      1024        ;TOTAL BYTES IN 1K.  
5000      CPM.SZ  ==      NMBR.K*LNG.1K ;TOTAL SYSTEM BYTES.  
0600      BIOS.S  ==      LNG.1K*3/2  ;BIOS ALLOCATED SIZE.  
4A00      BIOS.A  ==      CPM.SZ-BIOS.S ;BIOS LOAD ADDRESS.
```

```
*****  
; INTERNAL MEMORY ASSIGNMENTS *  
*****
```

```
1000      BANK.0  ==      1000H        ;LOWER BANK ADDRESS.  
0400      BANK.L  ==      0400H        ;1K BANK LENGTH.  
1400      BANK.1  ==      BANK.0+BANK.L ;UPPER BANK ADDRESS.  
1370      IO.BLK  ==      BANK.0+0370H ;I/O BLOCK ADDRESS.  
1377      CB.STS  ==      IO.BLK+0007H ;COMMAND STATUS BYTE.  
1378      CW.LAD  ==      IO.BLK+0008H ;BIOS LOAD ADDR LOC.  
137A      CW.LNG  ==      IO.BLK+000AH ;BIOS LOAD LENGTH LOC.  
1380      SEC.BF  ==      BANK.0+0380H ;SECTOR BUFFER AREA.
```

```
*****  
; BIOS PROGRAM LINKAGE. *  
*****
```

```
0004      SEC.BG  ==      4            ;FIRST BIOS SECTOR.  
0008      SEC.NM  ==      8            ;NUMBER OF SECTORS.  
000B      SEC.EX  ==      SEC.BG+SEC.NM-1 ;LAST BIOS SECTOR.
```

```
*****
```

```

; *****
; ASSEMBLER DIRECTIVES
; *****

```

```

                                .PABS
                                .PHEX
                                .XLINK
1380                                .LOC      SEC.BF      ;PROGRAM START POINT

```

```

; *****
; PAUSE MACRO.  ALLOWS 1791 TO DIGEST INSTRUCTIONS!
; *****

```

```

.DEFINE PAUSE = [
    XTHL
    XTHL
    XTHL
    XTHL]

```

```

; *****
; INITIALIZE BIOS READ OPERATION
; *****

```

```

1380      21 0400      BEGIN:  LXI      H,LNG.1K      ;BIOS LOAD LENGTH.
1383      22 137A      SHLD     CW.LNG      ;LOAD LENGTH SET.
1386      21 4A00      LXI      H,BIOS.A      ;BIOS SYSTEM ADDR.
1389      22 1378      SHLD     CW.LAD      ;LOAD ADDRESS SET.
138C      21 1400      LXI      H,BANK.1     ;BIOS LOAD POINT.

```

```

; *****
; SET-UP FOR EACH READ SECTOR COMMAND
; *****

```

```

138F      FD21 13AB    RD.SEC: LXI      Y,RD.TST    ;SET NMI VECTOR.
1393      3A 13C7      LDA      SECTOR      ;FIRST BIOS SECTOR.
1396      A9           XRA      C           ;INVERT (1791-01).
1397      D306         OUT      WD.SEC      ;SET 1791 SEC REG.
1399      3E80         MVI     A,DC.RDS     ;READ SECTOR CMND.
139B      A9           XRA      C           ;INVERT (1791-01).
139C      D304         OUT      WD.CMD      ;ISSUE 1791 COMMAND.
139E      E3           PAUSE                ;ALLOW 1791 TO SETTLE.

```

```

; *****
; READ SECTOR OPERATION
; *****

```

```

13A2      DB80         RD.BYT: IN       XP.DSH      ;WAIT FOR DATA.
13A4      DB07         IN       WD.DTA      ;INPUT INV DATA.
13A6      A9           XRA      C           ;INVERT (1791-01).
13A7      77           MOV     M,A        ;STORE DCM BYTE.
13A8      23           INX     H          ;INCREMENT POINTER.
13A9      18F7         JMPR   RD.BYT      ;REPEAT OPERATION.

```

```

; *****

```

```
*****  
; CHECK READ SECTOR STATUS, REPEAT UNTIL BIOS LOADED *  
*****
```

```
13AB E69C RD.TST: ANI DM.RER ;TEST FOR ERRORS.  
13AD 200D JRNZ ERRORS ;ERROR DETECTED.  
13AF 3A 13C7 LDA SECTOR ;GET SECTOR NMBR.  
13B2 FE0B CPI SEC.EX ;CHECK IF LAST SEC.  
13B4 280F JRZ FINISH ;GO IF FINISHED.  
13B6 3C INR A ;INCREMENT.  
13B7 32 13C7 STA SECTOR ;STORE AWAY.  
13BA 1803 JMPR RD.SEC ;READ NEXT SECTOR.
```

```
*****  
; READ ERROR HAS BEEN DETECTED *  
*****
```

```
13BC 32 1377 ERRORS: STA CB.STS ;DISPLAY ERROR STATUS.  
13BF AF XRA A ;ZERO A REGISTER.  
13C0 D300 OUT BL.CTL ;DESELECT DRIVE.  
13C2 DB10 IN XP.MTO ;MOTOR OFF!  
13C4 76 HLT ;TERMINATE.
```

```
*****  
; BIOS SECTOR HAVE BEEN LOADED *  
*****
```

```
13C5 FB FINISH: EI ;ENABLE INTERRUPTS.  
13C6 76 HLT ;SHUTDOWN BOARD.
```

```
*****  
; SECTOR NUMBER STORAGE *  
*****
```

```
13C7 04 SECTOR: .BYTE SEC.BG ;SECTOR COUNTER.
```

```
*****  
.END
```

BANK.O 1000	BANK.1 1400	BANK.L 0400	BEGIN 1380
BIOS.A 4A00	BIOS.S 0600	BL.CTL 0000	BL.STS 0000
CB.STS 1377	CPM.SZ 5000	CW.LAD 1378	CW.LNG 137A
DC.RDS 0080	DM.RER 009C	ERRORS 13BC	FINISH 13C5
IO.BLK 1370	LNG.1K 0400	NMBR.K 0014	RD.BYT 13A2
RD.SEC 138F	RD.TST 13AB	SECTOR 13C7	SEC.BF 1380
SEC.BG 0004	SEC.EX 000B	SEC.NM 0008	WD.CMD 0004
WD.DTA 0007	WD.SEC 0006	WD.STS 0004	XP.DSH 0080
XP.MTO 0010	XP.MTX 0040		

TDL Z80 CP/M DISK ASSEMBLER VERSION 2.21
FORMAT - JADE DOUBLE D
TITLE PAGE

```

;*****
;
; PROGRAM ID:          FORMAT
;
;*****
;
; PROPERTY OF:        JADE COMPUTER PRODUCTS
;                    4901 W. ROSECRANS BLVD.
;                    HAWTHORNE, CALIFORNIA
;                    90250, U.S.A.
;
;*****
;
; VERSION:            2.2
;
;*****
;
; WRITTEN BY:         STAN KRUMME
;
;*****
; FORMAT IS A SYSTEM UTILITY WHICH PROVIDES A MEANS
; TO WRITE A SINGLE OR DOUBLE DENSITY FORMAT ON ANY
; OF DRIVES A THROUGH D. THIS UTILITY ALSO PROVIDES
; A COPY-SYSTEM-TRACKS FEATURE. THIS IS A USEFUL
; FUNCTION FOR FORMAT AS THE SYSTEM TRACKS CAN BE
; WRITTEN WITH THE OPERATING SYSTEM WHEN FORMATTED.
; THE USER CAN FORMAT ONLY THE SYSTEM TRACKS OF OLDER
; SINGLE DENSITY DISKETTES SUCH THAT THESE DISKETTES
; CAN CARRY THE OPERATING SYSTEM WITHOUT ERASING THE
; DATA TRACKS. FORMAT.COM IS 8080/8085/Z80 COMPATIBLE
;*****

```

```
*****  
; DRIVER MODULE DEFINITIONS  
*****
```

```
000A      LF      ==      00AH      ;ASCII LINE FEED.  
000D      CR      ==      00DH      ;CARRIAGE RETURN.  
0100      TPA     ==      0100H     ;TRANSIENT PROGRAM.  
0003      CNTL.C  ==      3         ;REQUEST REBOOT CPM.  
0000      TRK.0   ==      0         ;TRACK 0.  
0001      TRK.1   ==      1         ;TRACK 1.  
0002      TRK.2   ==      2         ;TRACK 2.  
004C      TRK.76  ==      76        ;TRACK 76.  
0080      SEC.SZ  ==      128       ;128 BYTES PER SECTOR.  
0001      ID.SEC  ==      1         ;ID SECTOR NUMBER.  
0000      REBOOT  ==      0         ;REBOOT ADDRESS.
```

```
*****  
; SYSTEM TRACKS COPY DEFINITIONS  
*****
```

```
1000      TK0.LP  ==      1000H     ;TRACK 0 TPA LOAD ADDR.  
0001      TK0.FS  ==      1         ;TRACK 0 FIRST SECTOR.  
001A      TK0.LS  ==      26        ;TRACK 0 LAST SECTOR.  
001A      TK0.NS  ==      TK0.LS-TK0.FS+1 ;TRACK 0 NMBER SECTORS.  
0F80      TK0.LC  ==      TK0.LP-SEC.SZ*TK0.FS ;TRACK 0 LOAD CONSTANT.  
0D00      TK0.SZ  ==      SEC.SZ*TK0.NS  ;TRACK 0 LOAD SIZE.  
1D00      TK1.LP  ==      TK0.LP+TK0.SZ  ;TRACK 1 TPA LOAD ADDR.  
0001      TK1.FS  ==      1         ;TRACK 1 FIRST SECTOR.  
0030      TK1.LS  ==      48        ;TRACK 1 LAST SECTOR.
```

```
*****  
; INJECTION MODULE DEFINITIONS  
*****
```

```
1700      FMT.EA  ==      1700H     ;FORMAT EXEC ADDRESS.  
0005      WD.TRK  ==      005H      ;DOUBLE D TRACK PORT.  
0007      WD.DTA  ==      007H      ;DOUBLE D DATA PORT.  
0080      XP.DSH  ==      80H       ;DATA SYNC HOLD PORT.  
0000      ZEROS   ==      00000000B   ;ALL ZERO BYTE.  
00FF      ONES    ==      11111111B   ;ALL ONES BYTE.
```

```
*****  
; BDOS CALL - VECTOR NUMBERS  
*****
```

```
0005      BDOS    ==      0005H     ;SYSTEM CALL ADDR.  
0001      CNS.RD  ==      1         ;READ CONSOLE.  
0002      CNS.WR  ==      2         ;WRITE CONSOLE.
```

```
*****  
; BIOS VECTOR DEFINITIONS  
*****
```

001B	BS.DSK ==	01BH	;SELECT DISK OFFSET.
001E	BS.TRK ==	01EH	;SET TRACK OFFSET.
0021	BS.SEC ==	021H	;SET SECTOR OFFSET.
0024	BS.DMA ==	024H	;SET ADDRESS OFFSET.
0027	BS.RDS ==	027H	;READ SECTOR OFFSET.
002A	BS.WRS ==	02AH	;WRITE SECTOR OFFSET.
0033	BS.FMT ==	033H	;FORMAT TRACK OFFSET.
0002	BS.PAG ==	0002H	;BIOS VECTOR POINTER.
0001	LOG.VC ==	1	;DRV SEL DONT LOGON.

```
*****  
; ASSEMBLER DIRECTIVES  
*****
```

	.I8080	
	.FABS	
	.PHEX	
	.XLINK	
0100	.LOC	TPA

```
*****  
; PROGRAM BEGINS *  
*****
```

0100 C3 0138 BEGIN: JMP INIT ;GO TO INITIALIZE.

```
*****  
; ASCII IDENTIFICATION INSERT *  
*****
```

0103 4A4144452043 .ASCII 'JADE COMPUTER PRODUCTS '
011A 444F55424C45 .ASCII 'DOUBLE D - FORMAT '
012C 56455253494F .ASCII 'VERSION 2.2 '

```
*****  
; SET STACK POINTER AND ISSUE LOG-ON *  
*****
```

0138 31 0100 INIT: LXI SP,TPA ;SET STACK POINTER.
013B 21 0521 LXI H,MSG.BG ;LOAD MESSAGE ADDR.
013E CD 0281 CALL MSG.OT ;ISSUE MESSAGE.

```
*****  
; FUNCTION SELECTION AND CONTROL DISTRIBUTOR *  
*****
```

0141 21 056C FUN.BG: LXI H,MSG.FL ;FUNCTION LIST ADDRESS.
0144 CD 0281 CALL MSG.OT ;ISSUE MESSAGE.
0147 CD 028F CALL CNS.IN ;GET CONSOLE CHARACTER.
014A FE31 CPI "1"
014C CA 017E JZ FUN.1 ;FMT DOUBLE DENSITY.
014F FE32 CPI "2"
0151 CA 01E3 JZ FUN.2 ;FMT SINGLE DENSITY.
0154 FE33 CPI "3"
0156 CA 01BB JZ FUN.3 ;FMT 3740.
0159 FE34 CPI "4"
015B CA 022B JZ FUN.4 ;FMT SYSTEM TRACKS.
015E FE35 CPI "5"
0160 CA 0259 JZ FUN.5 ;READ SYSTEM TRACKS.
0163 FE36 CPI "6"
0165 CA 026D JZ FUN.6 ;WRITE SYSTEM TRACKS.
0168 FE26 CPI "&"
016A CA 03FD JZ RST.6 ;DEBUG TDL TRAP.
016D FE27 CPI "<"
016F CA 03FE JZ RST.7 ;DDT TRAP.
0172 21 066C LXI H,MSG.SE ;SELECT ERROR MESSAGE.
0175 32 0670 STA LTR.SE ;STORE BAD SYMBOL.
0178 CD 0281 CALL MSG.OT ;ISSUE MESSAGE.
017B C3 0141 JMP FUN.BG ;TRY SELECTION AGAIN.

```
*****
```

```
*****
; FUNCTION 1 - FORMAT IN DOUBLE DENSITY *
*****
```

017E	3A 04D2	FUN.1:	LDA	DD.FLG	;LOAD DDENS FLAGS.
0181	32 0406		STA	F.FLAG	;STORE FORMAT FLAGS.
0184	21 068B		LXI	H,MSG.FD	;FORMAT DRIVE MESSAGE.
0187	CD 03AA		CALL	SEL.DR	;SELECT DRIVE LETTER.
018A	DA 0141		JC	FUN.BG	;CARRY: RESELECT.
018D	3E00		MVI	A,TRK.0	;TRACK 0.
018F	32 0404		STA	TRK.NO	;SET TRACK NUMBER.
0192	CD 02E4		CALL	FMT.SD	;FORMAT TRACK SDENS.
0195	DA 017E		JC	FUN.1	;JUMP ERROR DETECTED.
0198	3E01		MVI	A,TRK.1	;TRACK 1 VALUE.
019A	32 0404		STA	TRK.NO	;SET TRACK NUMBER.
019D	CD 02EA	..REPT:	CALL	FMT.DD	;FORMAT TRACK DDENS.
01A0	DA 017E		JC	FUN.1	;JUMP ERROR DETECTED.
01A3	3A 0404		LDA	TRK.NO	;LOAD TRACK NUMBER.
01A6	FE4C		CPI	TRK.76	;WAS IT THE LAST TRK.
01A8	CA 01B2		JZ	..ID	;AFTER LAST TRACK.
01AB	3C		INR	A	;INCREMENT TRACK NO.
01AC	32 0404		STA	TRK.NO	;STORE TRACK NUMBER.
01AF	C3 019D		JMP	..REPT	;FORMAT NEXT TRACK.
01B2	21 04A1	..ID:	LXI	H,IDS.DD	;ID SECTOR: DDENS.
01B5	CD 02C1		CALL	WRT.ID	;WRITE ID SECTOR.
01B8	C3 017E		JMP	FUN.1	;ANOTHER DISK?

```
*****
; FUNCTION 3 - FORMAT STANDARD 3740 *
*****
```

01BB	3E00	FUN.3:	MVI	A,0	;3740 SDENS FLAGS.
01BD	32 0406		STA	F.FLAG	;STORE FORMAT FLAGS.
01C0	21 068B		LXI	H,MSG.FD	;FORMAT DRIVE MESSAGE.
01C3	CD 03AA		CALL	SEL.DR	;SELECT DRIVE LETTER.
01C6	DA 0141		JC	FUN.BG	;CARRY: RESELECT.
01C9	3E00		MVI	A,TRK.0	;TRACK 0.
01CB	32 0404		STA	TRK.NO	;SET TRACK NUMBER.
01CE	CD 02E4	..REPT:	CALL	FMT.SD	;FORMAT TRACK SDENS.
01D1	DA 01BB		JC	FUN.3	;JUMP ERROR DETECTED.
01D4	3A 0404		LDA	TRK.NO	;LOAD TRACK NUMBER.
01D7	FE4C		CPI	TRK.76	;WAS IT THE LAST TRK.
01D9	CA 01BB		JZ	FUN.3	;AFTER LAST TRACK.
01DC	3C		INR	A	;INCREMENT TRACK NO.
01DD	32 0404		STA	TRK.NO	;STORE TRACK NUMBER.
01E0	C3 01CE		JMP	..REPT	;FORMAT NEXT TRACK.

```
*****
```

```
*****  
; FUNCTION 2 - FORMAT IN SINGLE DENSITY *  
*****
```

```
01E3 3A 0452 FUN.2: LDA SD.FLG ;LOAD SDENS FLAGS.  
01E6 32 0406 STA F.FLAG ;STORE FORMAT FLAGS.  
01E9 21 068B LXI H,MSG.FD ;FORMAT DRIVE MESSAGE.  
01EC CD 03AA CALL SEL.DR ;SELECT DRIVE LETTER.  
01EF DA 0141 JC FUN.BG ;CARRY: RESELECT.  
01F2 3E00 MVI A,TRK.0 ;TRACK 0.  
01F4 32 0404 STA TRK.NO ;SET TRACK NUMBER.  
01F7 CD 02E4 CALL FMT.SD ;FORMAT TRACK SDENS.  
01FA DA 01E3 JC FUN.2 ;JUMP ERROR DETECTED.  
01FD 3E01 MVI A,TRK.1 ;TRACK 1  
01FF 32 0404 STA TRK.NO ;SET TRACK NUMBER.  
0202 CD 02EA CALL FMT.DD ;FORMAT TRACK DDENS.  
0205 DA 01E3 JC FUN.2 ;JUMP ERROR DETECTED.  
0208 3E02 MVI A,TRK.2 ;TRACK 2.  
020A 32 0404 STA TRK.NO ;SET TRACK NUMBER.  
020D CD 02E4 ..REPT: CALL FMT.SD ;FORMAT TRACK SDENS.  
0210 DA 01E3 JC FUN.2 ;JUMP ERROR DETECTED.  
0213 3A 0404 LDA TRK.NO ;LOAD TRACK NUMBER.  
0216 FE4C CPI TRK.76 ;WAS IT THE LAST TRK.  
0218 CA 0222 JZ ..ID ;AFTER LAST TRACK.  
021B 3C INR A ;INCREMENT TRACK NO.  
021C 32 0404 STA TRK.NO ;STORE TRACK NUMBER.  
021F C3 020D JMP ..REPT ;FORMAT NEXT TRACK.  
0222 21 0421 ..ID: LXI H,IDS.SD ;ID SECTOR: SDENS.  
0225 CD 02C1 CALL WRT.ID ;WRITE ID SECTOR.  
0228 C3 01E3 JMP FUN.2 ;ANOTHER DISK?
```

```
*****  
; FUNCTION 4 - FORMAT JADE SYSTEM TRACKS ONLY *  
*****
```

```
022B 3A 0452 FUN.4: LDA SD.FLG ;LOAD SDENS FLAGS.  
022E 32 0406 STA F.FLAG ;STORE FORMAT FLAGS.  
0231 21 068B LXI H,MSG.FD ;FORMAT DRIVE MESSAGE.  
0234 CD 03AA CALL SEL.DR ;SELECT DRIVE LETTER.  
0237 DA 0141 JC FUN.BG ;CARRY: RESELECT.  
023A 3E00 MVI A,TRK.0 ;TRACK 0.  
023C 32 0404 STA TRK.NO ;SET TRACK NUMBER.  
023F CD 02E4 CALL FMT.SD ;FORMAT TRACK SDENS.  
0242 DA 022B JC FUN.4 ;JUMP ERROR DETECTED.  
0245 3E01 MVI A,TRK.1 ;TRACK 1  
0247 32 0404 STA TRK.NO ;SET TRACK NUMBER.  
024A CD 02EA CALL FMT.DD ;FORMAT TRACK DDENS.  
024D DA 022B JC FUN.4 ;JUMP ERROR DETECTED.  
0250 21 0421 LXI H,IDS.SD ;ID SECTOR: SDENS.  
0253 CD 02C1 CALL WRT.ID ;WRITE ID SECTOR.  
0256 C3 022B JMP FUN.4 ;ANOTHER DISK?
```

```
*****
```

; FUNCTION 5 - READ SYSTEM TRACKS *

0259	21 06B7	FUN.5:	LXI	H,MSG.RS	;READ SYSTEM MESSAGE.
025C	CD 03AA		CALL	SEL.DR	;SELECT DRIVE LETTER.
025F	DA 0141		JC	FUN.BG	;GOTO RESELECT.
0262	3E27		MVI	A,BS.RDS	;READ SECTOR VECTOR.
0264	32 0401		STA	RW.OPV	;TRANSFER IS READ.
0267	CD 0314		CALL	TRNSFR	;READ SYSTEM TRACKS.
026A	C3 0141		JMP	FUN.BG	;RESELECT FUNCTION.

; FUNCTION 6 - WRITE SYSTEM TRACKS *

026D	21 06D3	FUN.6:	LXI	H,MSG.WS	;WRITE SYSTEM MESSAGE.
0270	CD 03AA		CALL	SEL.DR	;SELECT REQUESTED DRV.
0273	DA 0141		JC	FUN.BG	;GOTO RESELECT.
0276	3E2A		MVI	A,BS.WRS	;WRITE SECTOR VECTOR.
0278	32 0401		STA	RW.OPV	;TRANSFER IS WRITE
027B	CD 0314		CALL	TRNSFR	;WRITE SYSTEM TRACKS.
027E	C3 026D		JMP	FUN.6	;WRITE ANOTHER DISK.

```

;*****
; MESSAGE DISPLAY ROUTINE
;*****
  
```

```

0281 F5 MSG.OT: PUSH PSW ;SAVE CALLER FLAGS.
0282 7E ..REPT: MOV A,M ;LOAD CHARACTER.
0283 CD 029C CALL CNS.OT ;CONSOLE OUTPUT.
0286 7E MOV A,M ;SAME CAHRACTER.
0287 23 INX H ;INCREMENT POINTER.
0288 E680 ANI 080H ;TEST SIGN BIT.
028A CA 0282 JZ ..REPT ;ANOTHER CHARACTER.
028D F1 POP PSW ;RESTORE FLAGS.
028E C9 RET ;RETURN TO CALLER.
  
```

```

;*****
; CONSOLE LINKAGE - BDOS CALLS
;*****
  
```

```

028F 0E01 CNS.IN: MVI C,CNS.RD ;BDOS CONSOLE READ.
0291 CD 0005 CALL BDOS ;SYSTEM CALL.
0294 E67F ANI 07FH ;7 BIT ASCII.
0296 FE03 CPI CNTL.C ;CHECK CONTROL-C.
0298 CA 0000 JZ REBOOT ;REBOOT SYSTEM.
029B C9 RET ;RETURN CALLER.
  
```

```

029C E5 CNS.OT: PUSH H ;SAVE TEXT INDEX.
029D 5F MOV E,A ;MOVE CHARACTER.
029E 0E02 MVI C,CNS.WR ;BDOS CONSOLE WRITE.
02A0 CD 0005 CALL BDOS ;SYSTEM CALL.
02A3 E1 POP H ;SAVE TEXT POINTER.
02A4 C9 RET ;RETURN CALLER.
  
```

```

;*****
; DISPLAY HEXIDECIMAL VALUE
;*****
  
```

```

02A5 7C HXW.OT: MOV A,H ;LOAD HIGH ORDER.
02A6 CD 02AA CALL HXB.OT ;DO HIGH BYTE.
02A9 7D MOV A,L ;LOAD LOW ORDER.
02AA F5 HXB.OT: PUSH PSW ;SAVE CHARACTER.
02AB 0F RRC ;SHIFT
02AC 0F RRC
02AD 0F RRC
02AE 0F RRC
02AF CD 02B3 CALL HXN.OT ;DO UPPER NIBBLE.
02B2 F1 POP PSW ;GET LOWER NIBBLE.
02B3 E60F HXN.OT: ANI 00FH ;MASK NIBBLE.
02B5 FE0A CPI 00AH ;LESS THAN 10?
02B7 DA 02BC JC ..NMBR ;DO NUMBER THING.
02BA C607 ..LTTR: ADI 'A'-'9'-1 ;ADD LETTER OFFSET.
02BC C630 ..NMBR: ADI '0' ;START AT ZERO.
02BE C3 029C JMP CNS.OT ;CONSOLE OUTPUT.
  
```

```

;*****
  
```

```
*****  
; WRITE ID SECTOR *  
*****
```

```
***** ( SET TRANSFER ADDRESS )*****
```

```
02C1 44 WRT.ID: MOV B,H ;MOV HL TO BC.  
02C2 4D MOV C,L ;MOV HL TO BC.  
02C3 2E24 MVI L,BS.DMA ;BIOS DMA VECTOR.  
02C5 CD 03F8 CALL BIOS ;SET TRANSFER ADDRESS.
```

```
***** ( SET TRACK TO ZERO )*****
```

```
02C8 0E00 MVI C,TRK.0 ;TRACK 0 SET.  
02CA 2E1E MVI L,BS.TRK ;BIOS TRACK VECTOR.  
02CC CD 03F8 CALL BIOS ;SET TRACK NMBR.
```

```
***** ( SET SECTOR TO ID.SEC )*****
```

```
02CF 0E01 MVI C,ID.SEC ;ID SECTOR VALUE.  
02D1 2E21 MVI L,BS.SEC ;BIOS SECTOR VECTOR.  
02D3 CD 03F8 CALL BIOS ;BIOS TRANSFER CALL.
```

```
***** ( PERFORM WRITE SECTOR )*****
```

```
02D6 2E2A MVI L,BS.WRS ;BIOS WRITE VECTOR.  
02D8 CD 03F8 CALL BIOS ;BIOS TRANSFER CALL.  
02DB B7 ORA A ;SET CONDITION CODES.  
02DC C8 RZ ;RETURN USER GOOD.  
02DD 21 06FF LXI H,MSG.NC ;TRANSFER INCOMPLETE.  
02E0 CD 0281 CALL MSG.OT ;ISSUE MESSAGE.  
02E3 C9 RET
```

```
*****
```

```

;*****
; FORMAT TRACK DRIVER *
;*****

```

```

;***** ( DENSITY ENTRIES )*****

```

```

02E4      21 0800      FMT.SD: LXI      H,FT3740      ;LOAD INJECTION ADDR.
02E7      C3 02ED      JMP          ST.DMA      ;GO SET DMA ADDR.
02EA      21 0900      FMT.DD: LXI      H,FTJ48D      ;LOAD INJECTION ADDR.

```

```

;***** ( SET INJECTION MODULE ADDRESS )*****

```

```

02ED      44          ST.DMA: MOV      B,H          ;MOV HL TO BC.
02EE      4D          MOV      C,L          ;MOV HL TO BC.
02EF      2E24        MVI      L,BS.DMA      ;BIOS DMA VECTOR.
02F1      CD 03F8      CALL     BIOS          ;SET TRANSFER ADDRESS.

```

```

;***** ( SET TRACK )*****

```

```

02F4      3A 0404      LDA      TRK.NO      ;LOAD TRACK NMBR.
02F7      4F          MOV      C,A          ;PUT INTO C REGISTER.
02F8      2E1E        MVI      L,BS.TRK    ;BIOS TRACK VECTOR.
02FA      CD 03F8      CALL     BIOS          ;SET TRACK NMBR.

```

```

;***** ( SET SECTOR TO FLAG )*****

```

```

02FD      3A 0406      LDA      F.FLAG      ;LOAD DCM FLAG.
0300      4F          MOV      C,A          ;DCM FLAGS.
0301      2E21        MVI      L,BS.SEC    ;BIOS SECTOR VECTOR.
0303      CD 03F8      CALL     BIOS          ;BIOS TRANSFER CALL.

```

```

;***** ( PERFORM FORMAT TRACK )*****

```

```

0306      2E33        MVI      L,BS.FMT    ;BIOS WRITE VECTOR.
0308      CD 03F8      CALL     BIOS          ;BIOS TRANSFER CALL.
030B      B7          ORA      A            ;SET CONDITION CODES.
030C      C8          RZ          ;RETURN USER GOOD.
030D      21 06FF      LXI      H,MSG.NC    ;TRANSFER INCOMPLETE.
0310      CD 0281      CALL     MSG.OT      ;ISSUE MESSAGE.
0313      C9          RET

```

```

;*****

```

 ; SYSTEM TRACKS TRANSFER FUNCTION - ENTRY POINT *

***** (TRANSFER TRACK 0) *****

```

0314      21 0407      TRNSFR: LXI      H,TKO.SL      ;ADDR OF SECTOR LIST.
0317      23              INX      H              ;SKIP ID SECTOR.
0318      22 03FF      SHLD     SYS.WP          ;INIT WORK POINTER.
031B      0E00          MVI      C,TRK.0        ;CBS TRACK NUMBER.
031D      2E1E          MVI      L,BS.TRK       ;BIOS TRACK VECTOR.
031F      CD 03F8      CALL     BIOS           ;BIOS TRANSFER CALL.
    
```

***** (SET SECTOR IN BIOS) *****

```

0322      2A 03FF      ..TKOS: LHLD     SYS.WP          ;LOAD SECTOR POINTER.
0325      4E              MOV      C,M          ;SECTOR NMBR TO REG C.
0326      2E21          MVI      L,BS.SEC      ;BIOS SETSEC VECTOR.
0328      CD 03F8      CALL     BIOS           ;BIOS TRANSFER CALL.
    
```

***** (SET ADDRESS IN BIOS) *****

```

032B      2A 03FF      LHLD     SYS.WP          ;LOAD SECTOR POINTER.
032E      A7              ANA      A              ;CLEAR CARRY BIT.
032F      7E              MOV      A,M          ;GET SECTOR NUMBER.
0330      1F              RAR      ;SECTOR NMBR / 2.
0331      57              MOV      D,A          ;HIGH LOAD OFFSET.
0332      3E00          MVI      A,0          ;ZERO A REGISTER.
0334      1F              RAR      ;CARRY TO BIT 7.
0335      5F              MOV      E,A          ;LOW LOAD OFFSET.
0336      21 0F80      LXI      H,TKO.LC      ;TRK 0 LOAD CONSTANT.
0339      19              DAD     D              ;HL = SEC LOAD ADDR.
033A      44              MOV      B,H          ;HL TO BC HIGH ORDER.
033B      4D              MOV      C,L          ;HL TO BC LOW ORDER.
033C      2E24          MVI      L,BS.DMA     ;BIOS ADDR VECTOR.
033E      CD 03F8      CALL     BIOS           ;BIOS TRANSFER CALL.
    
```

***** (SECTOR TRANSFER OPERATION) *****

```

0341      3A 0401      LDA      RW.OPV        ;LOAD OPERATION VECTOR.
0344      6F              MOV      L,A          ;TRANSFER TO REG L.
0345      CD 03F8      CALL     BIOS           ;BIOS TRANSFER CALL.
0348      B7              ORA      A              ;SET CONDITION CODES.
0349      C2 03A3      JNZ     ..BLOW        ;SOMETHING WRONG!
    
```

***** (INCREMENT NEXT SECTOR) *****

```

034C      2A 03FF      LHLD     SYS.WP          ;LOAD SECTOR POINTER.
034F      7E              MOV      A,M          ;LOAD SECTOR NUMBER.
0350      FE16          CPI      016H          ;CHECK LAST STAGGERED.
0352      CA 035C      JZ      ..TRK1        ;IF DONE, DO TRK 1.
0355      23              INX     H              ;INCREMENT POINTER.
0356      22 03FF      SHLD     SYS.WP          ;STORE IT AWAY.
0359      C3 0322      JMP     ..TKOS        ;NEXT TRK 0 SECTOR.
    
```

***** (TRANSFER TRACK 1) *****

```
035C 21 1D00  ..TRK1: LXI      H,TK1.LP      ;TRK 1 ADDR IN TPA.
035F 22 03FF          SHLD     SYS.WP      ;INIT WORK POINTER.
0362 3E01          MVI      A,TK1.FS      ;FIRST SECTOR NUMBER.
0364 32 0405          STA      SEC.NO      ;SET CURRENT SECTOR.
0367 0E01          MVI      C,TRK.1      ;SET TRACK AT 1.
0369 2E1E          MVI      L,BS.TRK     ;BIOS TRACK VECTOR.
036B CD 03F8          CALL     BIOS         ;BIOS TRANSFER CALL.
```

***** (SET SECTOR AND DMA IN BIOS) *****

```
036E 3A 0405  ..TK1S: LDA      SEC.NO      ;LOAD CURRENT SECTOR.
0371 4F          MOV      C,A         ;TRANSFER TO REG C.
0372 2E21          MVI      L,BS.SEC     ;BIOS SECTOR VECTOR.
0374 CD 03F8          CALL     BIOS         ;BIOS TRANSFER CALL.
0377 2A 03FF          LHLD    SYS.WP      ;LOAD WORK POINTER.
037A 44          MOV      B,H         ;MOVE HIGH ORDER.
037B 4D          MOV      C,L         ; AND LOW ORDER.
037C 2E24          MVI      L,BS.DMA    ;BIOS ADDR VECTOR.
037E CD 03F8          CALL     BIOS         ;BIOS TRANSFER CALL.
```

***** (SECTOR TRANSFER OPERATION) *****

```
0381 3A 0401          LDA      RW.OPV      ;LOAD OPERATION VECTOR.
0384 6F          MOV      L,A         ;TRANSFER TO REG L.
0385 CD 03F8          CALL     BIOS         ;BIOS TRANSFER CALL.
0388 B7          ORA      A           ;SET CONDITION CODES.
0389 C2 03A3          JNZ     ..BLOW      ;SOMETHING WRONG!
```

***** (INCREMENT NEXT SECTOR) *****

```
038C 3A 0405          LDA      SEC.NO      ;GET CURRENT SECTOR.
038F FE30          CPI      TK1.LS     ;WAS THIS THE LAST?
0391 C8          RZ          ;IF DONE, GO HOME.
0392 3C          INR      A         ;INCREMENT COUNT.
0393 32 0405          STA      SEC.NO      ;STORE IT AWAY.
0396 2A 03FF          LHLD    SYS.WP      ;LOAD WORK ADDRESS.
0399 11 0080          LXI      D,SEC.SZ   ;GET SECTOR SIZE.
039C 19          DAD      D         ;ADD TO ADDRESS.
039D 22 03FF          SHLD    SYS.WP      ;STORE NEW ADDRESS.
03A0 C3 036E          JMP     ..TK1S     ;ANOTHER TRK 1 SECTOR.
```

***** (ENCOUNTERED DIFFICULTY) *****

```
03A3 21 06FF  ..BLOW: LXI      H,MSG.NC      ;MESSAGE ADDRESS.
03A6 CD 0281          CALL    MSG.OT      ;SEND MESSAGE.
03A9 C9          RET          ;GO HOME.
```

```

;*****
; SELECT DRIVE THRU BIOS
;*****

```

```

;***** ( DISPLAY MESSAGE AND WAIT FOR DRIVE )*****

```

```

03AA 22 0402 SEL.DR: SHLD MSG.SV ;SAVE MESSAGE ADDRESS.
03AD 2A 0402 ..REPT: LHLD MSG.SV ;LOAD MESSAGE ADDRESS.
03B0 CD 0281 CALL MSG.OT ;ISSUE MESSAGE.
03B3 CD 028F CALL CNS.IN ;GET DRIVE LETTER.
03B6 FE0D CPI CR ;CHECK FOR RESELECT.
03B8 CA 03DE JZ ..EXIT ;IF CR GOTO EXIT AREA.

```

```

;***** ( SEE IF DRIVE LETTER GOOD )*****

```

```

03BB 32 072D STA DR.LTR ;DRIVE LETTER.
03BE 32 0670 STA LTR.SE ;ILLG DRV LTR.
03C1 D641 SUI 'A' ;GET NUMBER.
03C3 DA 03D5 JC ..ILLG ;ILLEGAL, REPEAT.
03C6 FE04 CPI 04H ;DRIVE A THRU D?
03C8 DA 03E0 JC ..NMBR ;GOOD NUMBER.
03CB D620 SUI 'A'-'A' ;CHECK LOWER CASE.
03CD DA 03D5 JC ..ILLG ;ILLEGAL, REPEAT.
03D0 D604 SUI 04H ;LOWER A THRU D?
03D2 DA 03E0 JC ..NMBR ;LEGAL DRIVE.

```

```

;***** ( EXIT TO RESELECT FUNCTION )*****

```

```

03D5 21 066C ..ILLG: LXI H,MSG.SE ;'SELECT ERROR'
03D8 CD 0281 CALL MSG.OT ;ISSUE MESSAGE.
03DB C3 03AD JMP ..REPT ;REPEAT SELECTION.

```

```

;***** ( EXIT TO RESELECT FUNCTION )*****

```

```

03DE 37 ..EXIT: STC ;SET CARRY.
03DF C9 RET ;RETURN.

```

```

;***** ( VALID DRIVE NUMBER )*****

```

```

03E0 4F ..NMBR: MOV C,A ;DRIVE NMBR TO C.
03E1 1E01 MVI E,LOG.VC ;LOG ON VECTOR.
03E3 2E1B MVI L,BS.DSK ;BIOS SELECT DISK.
03E5 CD 03F8 CALL BIOS ;BIOS TRANSFER CALL.
03E8 21 0716 LXI H,MSG.XX ;'TYPE CR WHEN READY'
03EB CD 0281 CALL MSG.OT ;SEND MESSAGE.
03EE CD 028F CALL CNS.IN ;GET CONSOLE CHAR.
03F1 FE0D CPI CR ;CHECK IF CR.
03F3 C2 03AD JNZ ..REPT ;IF NOT, TRY AGAIN.
03F6 A7 ANA A ;CLEAR CARRY.
03F7 C9 RET ;RETURN CALLER.

```

```

;*****

```

```

;*****
; BIOS TRANSFER ROUTINE
;*****

```

```

03F8 3A 0002 BIOS: LDA BS.PAG ;GET HIGH ADDRESS.
03FB 67 MOV H,A ;SET IT IN H REG.
03FC E9 PCHL ;JUMP TO BIOS.

```

```

;*****
; SOFTWARE TRAPS
;*****

```

```

03FD F7 RST.6: RST 6 ;EXIT FORMAT.
03FE FF RST.7: RST 7 ;EXIT FORMAT.

```

```

;*****
; WORKING VARIABLES
;*****

```

```

03FF 0000 SYS.WP: .WORD 0 ;ADDRESS POINTER.
0401 00 RW.OPV: .BYTE 0 ;READ OR WRITE VECTOR.
0402 0000 MSG.SV: .WORD 0 ;MESSAGE SAVE ADDRESS.

0404 00 TRK.NO: .BYTE 0 ;TRACK NUMBER HOLD.
0405 00 SEC.NO: .BYTE 0 ;SECTOR NUMBER HOLD.
0406 00 F.FLAG: .BYTE 0 ;FORMAT FLAG (DCM).

```

```

;*****
; 3740 SECTOR TRANSLATION
;*****

```

```

0407 01070D131905 TKO.SL: .BYTE 01H,07H,0DH,13H,19H,05H
0408 0B111703090F .BYTE 0BH,11H,17H,03H,09H,0FH
0409 1502080E141A .BYTE 15H,02H,08H,0EH,14H,1AH
040A 060C1218040A .BYTE 06H,0CH,12H,18H,04H,0AH
040B 1016 .BYTE 10H,16H

```

```

;*****

```

```
*****  
; JADE SINGLE DENSITY - IDENTITY SECTOR *  
*****
```

```
***** ( JADE IDENTIFICATION )*****
```

```
0421 4A6164652044 IDS.SD: .ASCII "JADE DD SINGLE DENSITY FORMAT "
```

```
***** ( DISK PARAMETER BLOCK - CP/M 2.2 )*****
```

```
0441 .LOC IDS.SD+20H ;LOCATE CP/M BLOCK.  
0441 001A .WORD 26 ;SECTORS PER TRACK.  
0443 03 .BYTE 3 ;BLOCK SHIFT FACTOR.  
0444 07 .BYTE 7 ;BLOCK MASK.  
0445 00 .BYTE 0 ;NULL MASK.  
0446 00F2 .WORD 242 ;DISK SIZE - 1.  
0448 003F .WORD 63 ;DIRECTORY MAXIMUM.  
044A C0 .BYTE 11000000B ;ALLOC 0.  
044B 00 .BYTE 0 ;ALLOC 1.  
044C 0010 .WORD 16 ;CHECK SIZE.  
044E 0002 .WORD 2 ;TRACK OFFSET.
```

```
***** ( DCM DISK PARAMETERS )*****
```

```
0451 .LOC IDS.SD+30H ;LOCATE DCM BLOCK.  
0451 06 .BYTE 6 ;SECTOR STAGGER (TRNS).  
0452 02 SD.FLG: .BYTE 00000010B ;DISKETTE FLAGS.  
  
04A1 .LOC IDS.SD+SEC.SZ ;EXTEND FULL SECTOR.
```

```
*****
```

```
*****  
; JADE DOUBLE DENSITY - IDENTITY SECTOR *  
*****
```

```
***** ( JADE IDENTIFICATION )*****
```

04A1 4A6164652044 IDS.DD: .ASCII "JADE DD DOUBLE DENSITY FORMAT "

```
***** ( DISK PARAMETER BLOCK - CP/M 2.2 )*****
```

04C1		.LOC	IDS.DD+20H	;LOCATE CP/M BLOCK.
04C1	0030	.WORD	48	;SECTORS PER TRACK.
04C3	04	.BYTE	4	;BLOCK SHIFT FACTOR.
04C4	0F	.BYTE	00001111B	;BLOCK MASK.
04C5	01	.BYTE	1	;NULL MASK.
04C6	00E0	.WORD	224	;DISK SIZE - 1.
04C8	003F	.WORD	63	;DIRECTORY MAXIMUM.
04CA	80	.BYTE	10000000B	;ALLOC 0.
04CB	00	.BYTE	0	;ALLOC 1.
04CC	0010	.WORD	16	;CHECK SIZE.
04CE	0002	.WORD	2	;TRACK OFFSET.

```
***** ( DCM DISK PARAMETERS )*****
```

04D1		.LOC	IDS.DD+30H	;LOCATE DCM BLOCK.
04D1	06	.BYTE	6	;SECTOR STAGGER (TRNS).
04D2	06	DD.FLG: .BYTE	00000110B	;DISKETTE FLAGS.

0521 .LOC IDS.DD+SEC.SZ ;EXTEND TO FULL SIZE

```
*****
```

```
*****
0521      MSG.BG:           ;CONSOLE SIGN ON                               *
*****

0521      ODOA             .ASCII [CR][LF]
0523      ODOA444F5542     .ASCII [CR][LF]'DOUBLE D - FORMAT UTILITY'
053E      ODOA56455253     .ASCII [CR][LF]'VERSION 2.2 '
054C      ODOA             .ASCII [CR][LF]
054E      ODOA55736520     .ASCIS [CR][LF]'USE CTL-C FOR SYSTEM REBOOT.'

*****
056C      MSG.FL:         ;DISPLAY FUNCTION SELECTIONS                       *
*****

056C      ODOA             .ASCII [CR][LF]
056E      ODOA2A2A2A2A     .ASCII [CR][LF]'*****  FUNCTIONS LIST  *****'
058F      ODOA             .ASCII [CR][LF]
0591      ODOA312E2046     .ASCII [CR][LF]'1. FORMAT  DOUBLE DENSITY 8" '
05B0      ODOA322E2046     .ASCII [CR][LF]'2. FORMAT  SINGLE DENSITY 8" '
05CF      ODOA332E2046     .ASCII [CR][LF]'3. FORMAT  STANDARD 3740  8" '
05EE      ODOA342E2046     .ASCII [CR][LF]'4. FORMAT  SYSTEM TRACKS ONLY'
060D      ODOA352E2052     .ASCII [CR][LF]'5. READ   SYSTEM TRACKS IMAGE '
062F      ODOA362E2057     .ASCII [CR][LF]'6. WRITE  SYSTEM TRACKS IMAGE '
0651      ODOA             .ASCII [CR][LF]
0653      ODOA454E5445     .ASCIS [CR][LF]'ENTER FUNCTION NUMBER: '

*****
066C      MSG.SE:         ;SELECTION ERROR                                   *
*****

066C      ODOAODOA         .ASCII [CR][LF][CR][LF]
0670      20               LTR.SE: .BYTE ' '
0671      206973204E4F     .ASCIS ' IS NOT A VALID SELECTION '

*****
```

```
068B      ;*****  
          MSG.FD:      ;FORMAT ON DISK DRIVE      *  
          ;*****  
068B      ODOAODOA    .ASCII [CR][LF][CR][LF]  
068F      577269746520 .ASCIS 'WRITE FORMAT ON DRIVE (CR TO RESELECT): '  
          ;*****  
06B7      MSG.RS:      ;READ SYSTEM ON DRIVE      *  
          ;*****  
06B7      ODOAODOA    .ASCII [CR][LF][CR][LF]  
06BB      524541442053 .ASCIS 'READ SYSTEM FROM DRIVE: '  
          ;*****  
06D3      MSG.WS:      ;WRITE SYSTEM ON DRIVE      *  
          ;*****  
06D3      ODOAODOA    .ASCII [CR][LF][CR][LF]  
06D7      575249544520 .ASCIS 'WRITE SYSTEM TO DRIVE (CR TO RESELECT): '  
          ;*****  
06FF      MSG.NC:      ;TRANSFER INCOMPLETE      *  
          ;*****  
06FF      ODOAODOA    .ASCII [CR][LF][CR][LF]  
0703      5452414E5346 .ASCIS 'TRANSFER INCOMPLETE'  
          ;*****  
0716      MSG.XX:      ;TYPE CR WHEN DRIVE READY      *  
          ;*****  
0716      ODOAODOA    .ASCII [CR][LF][CR][LF]  
071A      547970652043 .ASCII 'TYPE CR WHEN DRIVE '  
072D      20          DR.LTR: .BYTE  
072E      205245414459 .ASCIS 'READY.'  
          ;*****
```

```
*****  
; FORMAT - TITLE BLOCK AND PAGE ALIGNMENT *  
*****
```

```
        .DEFINE FORMAT [NAME] = [  
NAME    ==      (,!OFFH)+1      ;SET NEXT PAGE BOUNDARY.  
        .LOC      NAME          ;SET LOC TO NEXT PAGE.  
OFFSET  =        FMT.EA-NAME     ;DETERMINE ADDR OFFSET.  
        .Z80          ;NOW USE Z80 CODE.  
        .ASCII  'FORMAT!'  
        ;INCLUDE HEADER!
```

```
*****  
; DENSITY - DECLARE TYPE *  
*****
```

```
        .DEFINE DENSITY [TYPE] = [  
        .IFIDN [TYPE][SINGLE], [  
        .ASCII 'S'  
        .EXIT]  
        .IFIDN [TYPE][DOUBLE], [  
        .ASCII 'D'  
        .EXIT]  
        .ERROR 'INVALID DENSITY']
```

```
*****  
; SECTORS - SPECIFY SEQUENCE AND NUMBER OF SECTORS *  
*****
```

```
        .DEFINE SECTORS [LIST,NMBR] = [  
LXI     H,LIST+OFFSET ;SECTOR SEQUENCE ADDR.  
MVI     E,NMBR       ;NUMBER OF SECTORS.
```

```
*****  
; BLOCK - GENERATE A BLOCK OF CONSTANTS *  
*****
```

```
        .DEFINE BLOCK [COUNT, BYTE, %REPT] = [  
NMBR = COUNT          ;SET EQUAL FOR NOW.  
MVI   B,NMBR         ;LOAD NMBR OF BYTES.  
%REPT: IN   XP.DSH    ;WAIT FOR DATA REQ.  
MVI   A,BYTE        ;LOAD BYTE VALUE.  
XRA   C             ;INVERT (1791-01).  
OUT   WD.DTA       ;WRITE DATA PORT.  
DJNZ  %REPT        ;REPEAT FOR COUNT.
```

```
*****
```

```
*****  
; REPEAT - REPEAT FORMAT SECTION FOR EACH SECTOR *  
*****
```

```
.DEFINE REPEAT [LOCATION] = [  
DCR E ;DEC NMBR SECTORS LEFT.  
JNZ LOCATION+OFFSET]
```

```
*****  
; ENDING - RECORD NMBR OF TRAILING BYTES WRITTEN *  
*****
```

```
.DEFINE ENDING [BYTE,%REPT] = [  
LXI H,0 ;COUNT OF ZERO.  
%REPT: IN XP.DSH ;WAIT FOR REQ.  
MVI A,BYTE ;LOAD CONSTANT.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE TO PORT.  
INX H ;INCREMENT COUNT.  
JMP %REPT+OFFSET ;CONTINUE.]
```

```
*****
```

```
*****  
; WRITE - WRITE SPECIFIC FORMAT BYTES *  
*****
```

```
.DEFINE WRITE [TYPE,VALU] = [
```

```
***** ( ID ADDRESS MARK )*****
```

```
.IFIDN [TYPE][ID.MARK], [  
IN XP.DSH ;WAIT FOR DATA REQ.  
MVI A,OFEH ;ID ADDR MARK.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE DATA PORT.  
.EXIT] ;TERMINATE MACRO
```

```
***** ( INDEX MARK )*****
```

```
.IFIDN [TYPE][INDEX.MARK], [  
IN XP.DSH ;WAIT FOR DATA REQ.  
MVI A,OFCH ;INDEX MARK.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE DATA PORT.  
.EXIT] ;TERMINATE MACRO
```

```
***** ( DATA ADDRESS MARK )*****
```

```
.IFIDN [TYPE][DATA.MARK], [  
IN XP.DSH ;WAIT FOR DATA REQ.  
MVI A,OFBH ;DATA ADDR MARK.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE DATA PORT.  
.EXIT] ;TERMINATE MACRO
```

```
***** ( CRC )*****
```

```
.IFIDN [TYPE][CRC], [  
IN XP.DSH ;WAIT FOR DATA REQ.  
MVI A,OF7H ;GENERATE CRC.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE DATA PORT.  
.EXIT] ;TERMINATE MACRO
```

```
***** ( EXPLICIT BYTE VALUE )*****
```

```
.IFIDN [TYPE][BYTE], [  
IN XP.DSH ;WAIT FOR DATA REQ.  
MVI A,VALU ;EXPLICIT VALUE.  
XRA C ;INVERT (1791-01).  
OUT WD.DTA ;WRITE DATA PORT.  
.EXIT]
```

```
***** ( TRACK NUMBER )*****
```

```
.IFIDN [TYPE][TRACK.NO], [  
IN XP.DSH ;WAIT FOR REQUEST.
```

```
IN      WD.TRK      ;GET TRACK NUMBR.  
OUT     WD.DTA      ;WRITE DATA PORT.  
.EXIT]
```

***** (SECTOR NUMBER)*****

```
.IFIDN [TYPE][SECTOR.NO], [  
IN      XP.DSH      ;WAIT FOR REQUEST.  
MOV     A,M         ;SET SECTOR NUMBR.  
XRA    C           ;INVERT (1791-01).  
OUT     WD.DTA      ;WRITE DATA PORT.  
INX    H           ;INC SEC-NUMBR PNTR.  
.EXIT             ;TERMINATE MACRO]
```

***** (SIDE NUMBER)*****

```
.IFIDN [TYPE][SIDE.NO], [  
IN      XP.DSH      ;WAIT FOR REQUEST.  
MVI    A,0         ;SET SIDE NUMBER.  
XRA    C           ;INVERT (1791-01).  
OUT     WD.DTA      ;WRITE DATA PORT.  
.EXIT             ;TERMINATE MACRO]
```

***** (SECTOR SIZE CODE)*****

```
.IFIDN [TYPE][SECTOR.SIZE], [  
SEC.CD = OFFH      ;DECLARE BLANK.  
.IFIDN [VALU][128], [SEC.CD = 000H]  
.IFIDN [VALU][256], [SEC.CD = 001H]  
.IFIDN [VALU][512], [SEC.CD = 002H]  
.IFIDN [VALU][1024], [SEC.CD = 003H]  
.IFE    (SEC.CD-OFFH), [  
.ERROR  'INVALID SECTOR SIZE'  
IN      XP.DSH      ;WAIT FOR DATA REQ.  
MVI    A,SEC.CD     ;LOAD SIZE CODE.  
XRA    C           ;INVERT (1791-01).  
OUT     WD.DTA      ;WRITE DATA PORT.  
.EXIT             ;TERMINATE MACRO]
```

***** (ILLEGAL EXPANSION)*****

```
.ERROR  'ILLEGAL EXPANSION'
```

0800	464F524D4154	FORMAT	FT3740
0807	53	DENSITY	SINGLE
0808	21 17B5	SECTORS	SS3740,26 ✓
080D	0628	BG3740:1	BLOCK 40, ONES
0818	0606	2	BLOCK 6, ZEROS
0823	DB80		WRITE INDEX.MARK
082A	061A	3	BLOCK 26, ONES
0835	0606	RP3740:4	BLOCK 6, ZEROS
0840	DB80		WRITE ID.MARK
0847	DB80		WRITE TRACK.NO
084D	DB80		WRITE SIDE.NO
0854	DB80		WRITE SECTOR.NO
085B	DB80		WRITE SECTOR.SIZE,128
0862	DB80		WRITE CRC
0869	060B	5	BLOCK 11, ONES
0874	0606	6	BLOCK 6, ZEROS
087F	DB80		WRITE DATA.MARK
0886	0680	7	BLOCK 128,0E5H
0891	DB80		WRITE CRC
0898	061B	8	BLOCK 27, ONES
08A3	1D		REPEAT RP3740
08A7	21 0000	ENDING	ONES
08B5	010203040506	SS3740:	.BYTE 1, 2, 3, 4, 5, 6, 7, 8, 9,10
08BF	0B0C0D0E0F10		.BYTE 11,12,13,14,15,16,17,18,19,20
08C9	15161718191A		.BYTE 21,22,23,24,25,26

```

0900      464F524D4154      FORMAT FTJ48D
0907      44                DENSITY DOUBLE
0908      21 17AE          SECTORS SSJ48D,48

090D      0650      BGJ48D: 1 BLOCK      80,04EH
0918      060C      RPJ48D: 2 BLOCK      12,ZEROS
0923      0603      3 BLOCK      3,0F5H
092E      DB80      WRITE      ID.MARK
0935      DB80      WRITE      TRACK.NO
093B      DB80      WRITE      SIDE.NO
0942      DB80      WRITE      SECTOR.NO
0949      DB80      WRITE      SECTOR.SIZE,128
0950      DB80      WRITE      CRC
0957      0616      4 BLOCK      22,04EH
0962      060C      5 BLOCK      12,ZEROS
096D      0603      6 BLOCK      3,0F5H
0978      DB80      WRITE      DATA.MARK
097F      0680      7 BLOCK      128,0E5H
098A      DB80      WRITE      CRC
0991      0616      8 BLOCK      22,04EH
099C      1D          REPEAT    RPJ48D

09A0      21 0000      9 ENDING    ONES

09AE      0105090D1115 SSJ48D: .BYTE      1, 5, 9,13,17,21
09B4      191D2125292D      .BYTE      25,29,33,37,41,45
09BA      02060A0E1216      .BYTE      2, 6,10,14,18,22
09C0      1A1E22262A2E      .BYTE      26,30,34,38,42,46
09C6      03070B0F1317      .BYTE      3, 7,11,15,19,23
09CC      1B1F23272B2F      .BYTE      27,31,35,39,43,47
09D2      04080C101418      .BYTE      4, 8,12,16,20,24
09D8      1C2024282C30      .BYTE      28,32,36,40,44,48

      .END
  
```

← BLOCK
 BLOCK
 WRITE
 BLOCK
 12, ZEROS
 3,0F6H
 INDEX, MARK
 5D, 4EH

FORMAT - JADE DOUBLE D

+++++ SYMBOL TABLE +++++

BDOS	0005	BEGIN	0100	BG3740	080D	BGJ48D	090D
BIOS	03F8	BS.DMA	0024	BS.DSK	001B	BS.FMT	0033
BS.PAG	0002	BS.RDS	0027	BS.SEC	0021	BS.TRK	001E
BS.WRS	002A	CNS.IN	028F	CNS.OT	029C	CNS.RD	0001
CNS.WR	0002	CNTL.C	0003	CR	000D	DD.FLG	04D2
DR.LTR	072D	FMT.DD	02EA	FMT.EA	1700	FMT.SD	02E4
FT3740	0800	FTJ48D	0900	FUN.1	017E	FUN.2	01E3
FUN.3	01BB	FUN.4	022B	FUN.5	0259	FUN.6	026D
FUN.BG	0141	F.FLAG	0406	HXB.OT	02AA	HXN.OT	02B3
HXW.OT	02A5	IDS.DD	04A1	IDS.SD	0421	ID.SEC	0001
INIT	0138	LF	000A	LOG.VC	0001	LTR.SE	0670
MSG.BG	0521	MSG.FD	068B	MSG.FL	056C	MSG.NC	06FF
MSG.OT	0281	MSG.RS	06B7	MSG.SE	066C	MSG.SV	0402
MSG.WS	06D3	MSG.XX	0716	NMBR	0016	OFFSET	0E00
ONES	00FF	REBOOT	0000	RP3740	0835	RPJ48D	0918
RST.6	03FD	RST.7	03FE	RW.OPV	0401	SD.FLG	0452
SEC.CD	0000	SEC.NO	0405	SEC.SZ	0080	SEL.DR	03AA
SS3740	08B5	SSJ48D	09AE	ST.DMA	02ED	SYS.WP	03FF
TK0.FS	0001	TK0.LC	0F80	TK0.LP	1000	TK0.LS	001A
TK0.NS	001A	TK0.SL	0407	TK0.SZ	0D00	TK1.FS	0001
TK1.LP	1D00	TK1.LS	0030	TPA	0100	TRK.0	0000
TRK.1	0001	TRK.2	0002	TRK.76	004C	TRK.NO	0404
TRANSFR	0314	WD.DTA	0007	WD.TRK	0005	WRT.ID	02C1
XP.DSH	0080	ZEROS	0000				

^CB:
B>DDT
DDT VERS 1.4
-F100,1000,00
-IFORMAT.HEX
-R

The following is the hex code generated

by the FORMAT INJECTION MODULES.

NEXT FC
09DE 0000
-D800,8FF

```
0800 46 4F 52 4D 41 54 21 53 21 B5 17 1E 1A 06 28 DB FORMAT!S!.....(.  
0810 80 3E FF A9 D3 07 10 F7 06 06 DB 80 3E 00 A9 D3 .>.....>...  
0820 07 10 F7 DB 80 3E FC A9 D3 07 06 1A DB 80 3E FF .....>.....>.  
0830 A9 D3 07 10 F7 06 06 DB 80 3E 00 A9 D3 07 10 F7 .....>.....  
0840 DB 80 3E FE A9 D3 07 DB 80 DB 05 D3 07 DB 80 3E ..>.....>...  
0850 00 A9 D3 07 DB 80 7E A9 D3 07 23 DB 80 3E 00 A9 .....^...#...>..  
0860 D3 07 DB 80 3E F7 A9 D3 07 06 0B DB 80 3E FF A9 .....>.....>..  
0870 D3 07 10 F7 06 06 DB 80 3E 00 A9 D3 07 10 F7 DB .....>.....  
0880 80 3E FB A9 D3 07 06 80 DB 80 3E E5 A9 D3 07 10 .>.....>.....  
0890 F7 DB 80 3E F7 A9 D3 07 06 1B DB 80 3E FF A9 D3 ...>.....>...  
08A0 07 10 F7 1D C2 35 17 21 00 00 DB 80 3E FF A9 D3 .....5.!.....>...  
08B0 07 23 C3 AA 17 01 02 03 04 05 06 07 08 09 0A 0B .#.....  
08C0 0C 0D 0E 0F 10 11 12 13 14 15 16 17 18 19 1A 00 .....  
08D0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....  
08E0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....  
08F0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....  
-D900,9FF
```

```
0900 46 4F 52 4D 41 54 21 44 21 AE 17 1E 30 06 50 DB FORMAT!D!...O.P.  
0910 80 3E 4E A9 D3 07 10 F7 06 0C DB 80 3E 00 A9 D3 .>N.....>...  
0920 07 10 F7 06 03 DB 80 3E F5 A9 D3 07 10 F7 DB 80 .....>.....  
0930 3E FE A9 D3 07 DB 80 DB 05 D3 07 DB 80 3E 00 A9 >.....>...  
0940 D3 07 DB 80 7E A9 D3 07 23 DB 80 3E 00 A9 D3 07 .....^...#...>...  
0950 DB 80 3E F7 A9 D3 07 06 16 DB 80 3E 4E A9 D3 07 ..>.....>N...  
0960 10 F7 06 0C DB 80 3E 00 A9 D3 07 10 F7 06 03 DB .....>.....  
0970 80 3E F5 A9 D3 07 10 F7 DB 80 3E FB A9 D3 07 06 .>.....>.....  
0980 80 DB 80 3E E5 A9 D3 07 10 F7 DB 80 3E F7 A9 D3 ...>.....>...  
0990 07 06 16 DB 80 3E 4E A9 D3 07 10 F7 1D C2 18 17 .....>N.....  
09A0 21 00 00 DB 80 3E FF A9 D3 07 23 C3 A3 17 01 05 !.....>...#.....  
09B0 09 0D 11 15 19 1D 21 25 29 2D 02 06 0A 0E 12 16 .....!%)-.....  
09C0 1A 1E 22 26 2A 2E 03 07 0B 0F 13 17 1B 1F 23 27 .."&#.....#'  
09D0 2B 2F 04 08 0C 10 14 18 1C 20 24 28 2C 30 00 00 +/.....$(,0..  
09E0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....  
09F0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....  
-
```

```
0002 LIST NOCDND
0003 ;*****
0004 ;
0005 ; The Disk Controller Module contains the firmware for the Jade
0006 ; Double D Disk controller board.
0007 ;
0008 ;*****
0009 ;
0010 ; The disk controller module (DCM) resides internal to the Jade Double D
0011 ; Disk Controller board. This program provides a facility to read/write
0012 ; diskette sectors & format diskette tracks (in single & double density).
0013 ; This module sets the parameters for each drive during the "LOG-ON"
0014 ; operation. The FORMAT program (not in this module) writes an ident-
0015 ; ification sector (0,0) which provides the needed information. If this
0016 ; identity sector is not present on the diskette, it is assumed to be a
0017 ; standard 8" IBM 3740 format. This program contains a 5 word timing block
0018 ; which should be patched to match the user's disk drives. This has normally
0019 ; been set for Shugart SAB00/801 drives.
0020 ;
0021 ;*****
0022 ;
0023 ; REVISION STATUS:
0024 ;
0025 ; 1.0 - 1 AUG 82 GRH
0026 ; Initial release
0027 ;
0028 ; 1.1 - GRH
0029 ; Fix bug causing code to crash after predictable number of warm boots.
0030 ; A CALL was being made without a return in the login function.
0031 ;
0032 ; 1.2 - 1 AUG 82 GRH
0033 ; ADDED RECAL FEATURE TO RECOVER FROM THE INSTANCE WHERE THE
0034 ; HEAD IS OUTSIDE TRACK 0 BUT THE SENSOR IS STILL GIVING
0035 ; THE TRACK 0 SIGNAL. IF TRK 0 SENSE IS TRUE ON ENTRY, THE
0036 ; HEAD IS STEPPED IN SEVERAL TRACKS, THEN A TRK 0 SEEK IS
0037 ; PERFORMED.
0038 ;
0039 ; 1.3 - 31 AUG 83 GRH
0040 ; Add sector de-blocking algorithms for 255 byte sectors. Remove unused
0041 ; code & vars. Optimize code.
0042 ;
(3133) 0043 VERSN EQU '13'
0044 ;
0045 ;*****
(0000) 0046 FALSE EQU 0
(FFFF) 0047 TRUE EQU NOT FALSE
(0000) 0048 LSTINC EQU FALSE
```

DISK CONTROLLER MODULE (DCM)

FIRMWARE DEFINITIONS

```

      @237
(0080) @238 DMNRT: EQU 10000000B ;NO RETRYs (=1)
(0080) @239 SECSIZ EQU 128 ;SIZE OF LOGICAL SECTORS
      @240
```

DISK CONTROLLER MODULE (DCM)
 MAIN FIRMWARE

```

0242 ;*****
0243 ;
0244 ; REGISTER USAGE:
0245 ; A, B= SCRATCH
0246 ; C= 179X INVERSION CONSTANT
0247 ; DE= USED FOR FLAG, SECTOR BY R/W SECTOR SUBR
0248 ; HL= PTR TO DATA XFER BY R/W SECTOR SUBR
0249 ; IX= DISK PARAMETER BLOCK PTR
0250 ; IY= 179X NMI RETURN ADDRESS
0251 ; AF'= R/W FLAGS
0252 ; BC', DE', HL'= NOT USED
0253 ;
0254 ;*****
0255 ;
0256 ;-----
0257 ;
0258 ; THE FOLLOWING AREA IS THE INITIAL START JUMP TABLE.
0259 ; THE 1ST JUMP IS EXECUTED WHEN THE ONBOARD Z80 IS RESET.
0260 ; THE SECOND JUMP IS THE DCM ENTRY FROM A BOOTSTRAP LOADER.
0261 ; THIS ENTRY ASSUMES DCM HAS BEEN LOADED INTO DD BANK 1 BY THE
0262 ; LOADER ROUTINE.
0263 ;
0264 ;-----
0265 ;
0000 (0000) 0266 ORG 0
0267
0000 C31B00 R 0268 JP CLEAR ;RESET & RE-INITIALIZE Z-80 REGS
0269
0003 C38007 0270 JP INITB+BANKL ;INIT - BOOTSTRAPPED
0006 (0002) 0271 DS 2
0272
0273
0274 ;*****
0275 ;
0276 ; THIS SUBROUTINE IS THE ENTRY POINT FOR THE DISK CONTROLLER
0277 ; TIMING MODULE. THIS MODULE PROVIDES DELAYS WHICH ARE
0278 ; MULTIPLES OF 100 us. THE CONTENTS OF DE DETERMINES THE TOTAL
0279 ; PERIOD. (DELAY=(DE)*100 us).
0280 ;
0281 ;*****
0282 RSTB:
0008 0619 0283 LD B,TMRF C ;SET CONSTANT
000A 10FE 0284 DJNZ $
000C C31300 R 0285 JP TICKE ;GOTO TICK ENTRY
0286
000F 061C 0287 TICKR: LD B,TMRF C ;SET NORMAL CONSTANT
0011 10FE 0288 DJNZ $
0289
0013 1B 0290 TICKE: DEC DE ;COUNT -1
0014 7A 0291 LD A,D
0015 B3 0292 OR E ;IF COUNT NOT 0 THEN REPEAT
0016 00 0293 NOP
0017 00 0294 NOP
0018 20F5 0295 JR NZ,TICKR
    
```

DISK CONTROLLER MODULE (DCM)

MAIN FIRMWARE

```

001A C9      0296      RET                ;ELSE RETURN
              0297
              0298
              0299 ;-----
              0300 ;
              0301 ;     INITIALIZATION FROM RESET VECTOR
              0302 ;
              0303 ;-----
001B 312505  0304 CLEAR: LD     SP,STACK
001E CD1401  0305      CALL     INIT
0021 181D    0306      JR      SLEEP
              0307
              0308
              0309 ;-----
              0310 ;
              0311 ;     ENTRY VECTOR TO READ SECTOR
              0312 ;     USES RST 40 VECTOR
              0313 ;
              0314 ;-----
0023 (0005)  0315      DS      2BH - $
0028 C37002  0316 RST40: JP     RDSEC
              0317
              0318
              0319 ;*****
              0320 ;
              0321 ;     TEMPORARY INIT USED ONLY ONCE
              0322 ;
              0323 ;*****
002B (0005)  0327      DS      (3BH - 8) - $ ;POSITION CODE
              0328
0030 CD1401  0329 RST38A: CALL  INIT
0033 3E70    0330      LD     A,XCUTE ;MODIFY CALL VECTOR
0035 323E00  0331      LD     (HRVEC + 1),A
              0332
              0333 ;-----
              0334 ;
              0335 ;     MASKABLE INTERRUPT ROUTINE - EXECUTED WHEN RESTARTING THE
              0336 ;     Z80 FROM A HALT. THE FUNCTIONS ARE; RESET THE DD INT REQ
              0337 ;     FLOP, PUT THE INTERRUPTED ADDR IN DE & JUMP TO CMD HANDLER.
              0338 ;
              0339 ;-----
              0340 TSTACK:
0038 DB20    0341 RST38: IN     A,XPIRR ;RESET INT REQ
003A 312505  0342      LD     SP,STACK ;SET UP STACK
003D CD3000  0343 HRVEC: CALL  RST38A ;MODIFIED BY RST38A TO CALL XCUTE
              0344
              0345 ;-----
              0346 ;
              0347 ;     END OF SEQUENCE HALT - DURING THIS TIME, THE HOST SYSTEM
              0348 ;     CAN SWITCH THE CONTROLLER MEMORY INTO THE S100 BUS FOR
              0349 ;     STATUS CHECK, SETTING COMMAND BLOCK, & SECTOR DATA XFERS.
              0350 ;
              0351 ;-----
0040 FB      0352 SLEEP: EI                ;SET ALARM

```

DISK CONTROLLER MODULE (DCM)

MAIN FIRMWARE

```

0041 76      0353      HALT          ;GO TO SLEEP
              0354
              0355
              0356 ;-----
              0357 ;
              0358 ; READ ADDRESS COMMAND
              0359 ;
              0360 ;-----
              0361 ADDR:          ;NOT IMPLEMENTED
              0362
              0363
              0364 ;-----
              0365 ;
              0366 ; SPARE COMMAND
              0367 ;
              0368 ;-----
0042 217703 0369 SPAR: LD      HL,CSTS      ;SET COMMAND ERROR
0043 36FF    0370      LD      (HL),-1
0047 C9     0371      RET
              0372
              0373
              0374 ;-----
              0375 ;
              0376 ; IDLE COMMAND
              0377 ;
              0378 ;-----
0048 D800    0379 IDLE: IN      A,BLSTS      ;IF NO HOST INTERRUPT THEN WAIT
004A E608    0380      AND      BSINT
004C 28FA    0381      JR      Z,IDLE
004E D820    0382      IN      A,XPIRR      ;ELSE RESET INTERRUPT REQUEST & EXIT
0050 C9     0383      RET
              0384
              0385
              0386 ;*****
              0387 ;
              0388 ; THIS IS THE NON-MASKABLE INTERRUPT ROUTINE
              0389 ; UPON 1791 COMMAND TERMINATION, THE Z80 RECEIVES A NMI. THE
              0390 ; STATUS PORT IS INTERROGATED & SAVED (SVSTS). IY HAS RETURN
              0391 ; ADDR.
              0392 ;
              0393 ;*****
0051 (0015) 0397      DS      66H - #      ;ADJUST FOR NMI VECTOR LOCATION
              0398
0066 D804    0399 WDINT: IN      A,WDSTS      ;GET 1791 STATUS & RESET INT.
0068 99     0400      XOR      C
0069 327C03 0401      LD      (SVSTS),A
006C FDE3    0402      EX      (SP),IY          ;PUT RETURN ADDR ON STACK
006E ED45    0403      RETN
              0404
              0405
              0406 ;*****
              0407 ;
              0408 ; COMMAND SELECTOR SUBR GETS CONTROL AFTER THE DISK CONTROLLER IS
              0409 ; INTERRUPTED FROM THE HALT CONDITION. IT BRANCHES TO THE INDIVIDUAL

```

DISK CONTROLLER MODULE (DCM)

MAIN FIRMWARE

```

0410 ; COMMAND ROUTINES.
0411 ;
0412 ;*****
0070 CD6302 0413 XCUTE: CALL EXSTS ;SET 179X'S ATTENTION FOR CMDS
0414
0073 3A7003 0415 LD A,(CBCMD) ;GET HOST CMD
0416
0076 E607 0417 AND MASK ;LIMIT OPTIONS
0078 1600 0418 LD D,0
007A 5F 0419 LD E,A ;SET UP OFFSET
007B 218300 0420 LD HL,CMDT ;SET TABLE PTR
007E 19 0421 ADD HL,DE
0422
007F 6E 0423 LD L,(HL) ;GET ADDRESS
0080 2600 0424 LD H,0
0425
0082 E9 0426 JP (HL) ;GOTO COMMAND
0427
0428 ; COMMAND TABLE
0429
(0083) 0430 CMDT: EQU # ;COMMAND TABLE
0083 B1 0431 DB LSON ;LOG-ON DRIVE
0084 E5 0432 DB READ ;READ SECTOR
0085 EA 0433 DB WRIT ;WRITE SECTOR
0086 8B 0434 DB FORM ;FORMAT TRACK
0087 42 0435 DB ADDR ;READ ADDRESS
0088 42 0436 DB SPAR ;SPARES
0089 42 0437 DB SPAR
008A 4B 0438 DB IDLE ;BACKGROUND
(0007) 0439 MASK: EQU 7 ;COMMAND MASK (CHANGE IF # CMDS INCREASED)
0440
0441
0442 ;-----
0443 ;
0444 ; FORMAT TRACK COMMAND
0445 ;
0446 ;-----
008B CD2B01 0447 FORM: CALL SELECT
008E D0 0448 RET NZ
0449
008F 3A7303 0450 LD A,(CBSEC) ;GET FORMAT FLAGS
0092 D07703 0451 LD (IX+DVFLG),A ;RESET DRIVE FLAGS
0095 CD8C01 0452 CALL SEEK
0453
0098 FD21A800 0454 LD IY,NMIWT ;SET RETURN ADDR
0455
009C 3EF0 0456 LD A,DCWRT ;OUTPUT WRITE TRACK COMMAND TO 1791
009E A9 0457 XOR C
009F D304 0458 OUT WDCMD,A
00A1 E3 0459 EX (SP),HL ;WAIT FOR 1791
00A2 E3 0460 EX (SP),HL
00A3 E3 0461 EX (SP),HL
00A4 E3 0462 EX (SP),HL
00A5 C30807 0463 JP FMTPS
    
```

DISK CONTROLLER MODULE (DCM)
 MAIN FIRMWARE

```

0464
00A8 E6E4 0465 NMIWT: AND DMFER ;SET ANY ERRORS
00AA 327703 0466 LD (CBSTS),A
0467
00AD 227A03 0468 LD (CWLNG),HL ;DISPLAY TRAIL BYTES
00B0 C9 0469 RET
0470
0471
0472 ;-----
0473 ;
0474 ; DRIVE LOG-ON COMMAND READS THE IDENTITY SECTOR FROM THE
0475 ; DISKETTE AND MAKES THE NEEDED ENTRIES INTO THE DRIVE TABLE.
0476 ; THE SECTOR DATA IS ALSO LEFT IN THE SECTOR BUFFER FOR BIOS
0477 ; TO FINISH THE LOG-ON OPERATION.
0478 ;
0479 ;-----
00B1 CD2B01 0480 LGON: CALL SELECT
00B4 C0 0481 RET NZ
0482
00B5 AF 0483 XOR A ;SET TRACK=0
00B6 327203 0484 LD (CBTRK),A
0485
00B9 3C 0486 INC A ;SET SECTOR =1
00BA 327303 0487 LD (CBSEC),A
00BD CD8C01 0488 CALL SEEK
0489
00C0 218003 0490 LD HL,XBUF
00C3 1E01 0491 LD E,1
00C5 CD7002 0492 CALL R0SEC ;READ ID SECTOR
0493
00C8 114403 0494 LD DE,JADED ;SET STRING PTR
00CB 218003 0495 LD HL,IDLEL ;SET SECTOR BUFFER PTR TO COMPARE
00CE 0608 0496 LD B,IDSZE ;SET ID LENGTH
0497
00D0 1A 0498 CKJI: LD A,(DE) ;IF ID NOT=JADE THEN 3740
00D1 BE 0499 CP (HL)
00D2 200B 0500 JR NZ,I3740
0501
00D4 23 0502 INC HL ;ELSE INC PTRS
00D5 13 0503 INC DE
00D6 10F8 0504 DJNZ CKJI ;IF NOT DONE THEN REPEAT
0505
00D8 3A8103 0506 LD A,(IDFLB) ;SET SIDES & DENSITIES
00DB DD7703 0507 LD (IX+DVFLG),A
00DE C9 0508 RET
0509
0510 ; ASSUME 3740 FORMAT
0511
0512 I3740:
00DF 3E00 0513 LD A,IDFLD ;SIDE & DENSITIES FLAGS=0
00E1 DD7703 0514 LD (IX+DVFLG),A
00E4 C9 0515 RET
0516
0517
    
```

```

0518 ;-----
0519 ;
0520 ; READ SECTOR COMMAND
0521 ;
0522 ;-----
00E5 3EFF 0523 READ: LD A,-1 ;FLAG := READ
00E7 87 0524 OR A
00E8 1801 0525 JR DPCONT
0526
0527
0528 ;-----
0529 ;
0530 ; WRITE SECTOR COMMAND
0531 ;
0532 ;-----
00EA AF 0533 WRIT: XOR A ;FLAG := WRITE
00EB 08 0534 DPCONT: EX AF,AF' ;SAVE DP IN ALT REGS
0535
00EC 002B01 0536 CALL SELECT ;SELECT DRIVE
00EF 003C01 0537 CALL Z,SEEK ;SEEK TRACK
00F2 00 0538 RET NZ
0539
00F3 218003 0540 LD HL,XBUF ;DEFAULT TO UNBLOCKED
00F6 3A7303 0541 LD A,(CBSEC)
00F9 5F 0542 LD E,A
0543
00FA 007E03 0544 LD A,(IX + DVFLB) ;IF SECTOR SIZE == 128 THEN SKIP BLOCKING
00FD E6C0 0545 AND 11000000B
00FF 0A7402 0546 JP Z,RWSECA
0547
0102 00E902 0548 CALL DDBUFR ;SET UP PHYSICAL SECTOR BUFFER
0105 00 0549 RET NZ
0550
0106 08 0551 EX AF,AF' ;IF READ THEN ALREADY IN XBUF
0107 00 0552 RET NZ
0553
0108 57 0554 LD D,A
0109 08 0555 EX AF,AF'
010A 210004 0556 LD HL,SBUFR ;USE PHYSICAL SECTOR BUFFER
010D 3A0005 0557 LD A,(BSSECT)
0110 5F 0558 LD E,A
0111 037702 0559 JP RWSECT
0560
0561
    
```

DISK CONTROLLER MODULE (DCM)
SUBROUTINES

```

0553 ;*****
0554 ;
0555 ;   INITIALIZE REGS & VARS SUBR
0556 ;
0557 ;*****
0558
0114 0559 INIT:  IM      I
0116 0570      LD      C,0           ;IF NOT INVERTED DATA SELECT THEN CONTINUE
0118 0571      IN      A,BLSTS
011A 0572      AND     BSUS0
011C 0573      JR      NZ,STOP
011E 0574      DEC     C           ;ELSE SET UP INVERT MASK
011F 0575 STOP:  LD      IX,DTDED       ;SET DRIVE TABLE PTR
0123 0576      XOR     A           ;BLOCKED BUFFER := EMPTY
0124 0577      LD      (BSECT),A
0127 0578      LD      (BVDRV),A       ;BASE BLCTL BITS
012A 0579      RET
0580
0581
0582 ;*****
0583 ;
0584 ;   THIS SUBROUTINE IS RESPONSIBLE FOR SELECTING THE COMMAND
0585 ;   REQUESTED DRIVE #. BEFORE DRIVE SELECTION, THE DRIVE MOTOR
0586 ;   STATE IS TESTED AND IF NEEDED, THEY ARE TURNED ON.
0587 ;   EXIT - IX= NEW DRIVE TABLE
0588 ;   A= 0: OK, /0: ERR
0589 ;
0590 ;*****
012B 0591 SELECT: IN      A,BLSTS       ;GET BOARD LEVEL STATUS
012D 0592      AND     BSMDF       ;IF MOTOR ON THEN CHECK DRIVE
012F 0593      JR      Z,CKDV
0594
0131 0595      IN      A,XPMTX       ;ELSE ISSUE MOTOR START
0133 0596      LD      DE,TMMTO
0136 0597      RST     B
0598
0137 0599 CKDV:  IN      A,XPMTX       ;EXTEND MOTOR TIME
0600
0139 0601      LD      A,(BVDRV)     ;INSURE 179X INTRQ ENABLED FOR LATER
013C 0602      OR      BCDSE       ;CMDS
013E 0603      OUT     BLCTL,A
0604
0140 0605      LD      A,(CBDRV)     ;IF THIS DRIVE = OLD DRIVE THEN OK
0143 0606      SUB     (IX+DVNBR)
0146 0607      RET      Z
0608
0147 0609      LD      E,DCHDU       ;ELSE UNLOAD HEAD
0149 0610      CALL   EXHEAD
0611
014C 0612      LD      A,(BVDRV)     ;DESELECT CURRENT DRIVE,
014F 0613      AND     (NOT BCDSE)
0151 0614      OUT     BLCTL,A
0615
0153 0616      LD      A,(CBDRV)     ;SELECT DESIRED DRIVE,

```

DISK CONTROLLER MODULE (DCM)

SUBROUTINES

```

0156 E603      0617      AND      BCDSN
0158 D300      0618      OUT      BLCTL,A
015A F604      0619      OR       BCDSE
015C D300      0620      OUT      BLCTL,A
015E 320305    0621      LD       (SVDRV),A
                   0622
0161 E603      0623      AND      BCDSN      ;SELECT DRIVE TABLE FOR DRIVE
0163 DD214C03  0624      LD       IX,DVTBL
0167 110500    0625      LD       DE,DVDES   ;DRIVE TABLE ARRAY SIZE
                   0626
016A 3D        0627      NEXT:   DEC      A      ;IF DRIVE = 0 THEN EXIT WITH POINTER SET
016B FA7201    0628      JP      M,SLED
                   0629
016E DD19      0630      ADD     IX,DE      ;ELSE POINT TO NEXT ARRAY & REPEAT
0170 18F8      0631      JR      NEXT
                   0632
0172 CD6302    0633      SLED:   CALL     EXSTS     ;SET FLAGS PER DRIVE READY
0175 E680      0634      AND     DMDNR
0177 327703    0635      LD      (CBSTS),A
                   0636
017A C9        0637      RET
                   0638
                   0639
0640 ;*****
0641 ;
0642 ;   HOMED SUBROUTINE STEPS THE DISK DRIVE HEAD OUTWARD UNTIL
0643 ;   TRACK 0 FLAG IS TRUE OR 255 STEPS HAVE BEEN ISSUED
0644 ;   EXIT - A= 0: OK, -1: TRK 0 NOT FOUND
0645 ;
0646 ;*****
0647 HOMED:
017B CD6302    0648      CALL     EXSTS     ;IF NOT TRK 0 THEN NO RECAL
017E E604      0649      AND     DMTK0
0180 2817      0650      JR      Z,HOME1
                   0651
0182 2E0A      0652      LD      L,10      ;ELSE STEP IN BEYOND TRK 0
0184 3A0305    0653      LD      A,(SVDRV) ;SELECT 'IN'
0187 F620      0654      OR      BCDAS
0189 D300      0655      OUT     BLCTL,A
                   0656
018B DB08      0657      RECAL1: IN     A,XPSTP ;STEP
018D 115000    0658      LD      DE,TMSTPC
0190 CF        0659      RST     5
                   0660
0191 2D        0661      DEC     L
0192 20F7      0662      JR      NZ,RECAL1
                   0663
0194 3A0305    0664      LD      A,(SVDRV) ;RESTORE DIRECTION
0197 D300      0665      OUT     BLCTL,A
                   0666
0199 2EFF      0667      HOME1: LD      L,255D    ;SET MAX COUNT
                   0668
019B CD6302    0669      STEP:   CALL     EXSTS     ;IF ON TRACK 0 THEN EXIT
019E E604      0670      AND     DMTK0

```

DISK CONTROLLER MODULE (DCM)

SUBROUTINES

```

01A0 200B      0671      JR      NZ,EXIT
                0672
01A2 2D        0673      DEC     L           ;IF STEPS = 255 THEN ERRDR
01A3 2B13      0674      JR      Z,ERRDR
                0675
01A5 DB08      0676      IN      A,XPSTP    ;ISSUE STEP PULSE
                0677
01A7 115000    0678      LD      DE,TMSTPC  ;SET DELAY
01AA CF        0679      RST     8
01AB 16EE      0680      JR      STEP
                0681
                0682 ;      DRIVE IS RESTORED
                0683
01AD 115000    0684  EXIT:  LD      DE,TMALS  ;WAIT A BIT AFTER LAST STEP
01B0 CF        0685      RST     8
                0686
01B1 3E00      0687      LD      A,0        ;SET COMPLETE FLAG
01B3 DD7701    0688      LD      (IX+DVTRK),A ;SET TRACK VALUE
                0689
01B6 A7        0690      AND     A          ;SET RETURN FLAGS
01B7 C9        0691      RET
                0692
                0693 ;      TRACK 0 NOT FOUND
                0694
01B8 3EFF      0695  ERRDR: LD      A,0FFH   ;SET FAILURE FLAG
01BA A7        0696      AND     A
01BB C9        0697      RET
                0698
                0699
0700 ;*****
0701 ;
0702 ;      TRACK SEEK SUBROUTINE
0703 ;      EXIT - DENSITY & PRE-COMP CONTROLS SET
0704 ;              ZF= OK, NZ= ERROR
0705 ;
0706 ;*****
01BC CD6302    0707  SEEK:  CALL    EXSTS    ;IF HEAD ALREADY LOADED THE BYPASS
01BF E620      0708      AND     DMHDL
01C1 2009      0709      JR      NZ,HLDD
                0710
01C3 1E18      0711      LD      E,DCHDL    ;ELSE LOAD HEAD
01C5 CD5702    0712      CALL    EXHEAD
                0713
01C8 115E01    0714      LD      DE,TMALD
01CB CF        0715      RST     8
                0716
01CC 3A7203    0717  HLDD:  LD      A,(CBTRK)  ;IF CURRENT TRACK=REQUESTED TRACK THEN EXIT
01CF DD9601    0718      SUB     (IX+DVTRK)
01D2 2006      0719      JR      NZ,DSET
                0720
01D4 DD7E04    0721      LD      A,(IX+DVCTL) ;ELSE GET PREVIOUS CTLS & RETURN
01D7 C34402    R 0722      JP      EXITS
                0723
                0724 ;      SET DIRECTION & STEP COUNT
    
```

DISK CONTROLLER MODULE (DCM)
SUBROUTINES

```

0725
01DA F5      0726 DSET:  PUSH  AF
01DB 110A00  0727      LD    DE, TMSAW      ;DELAY FOR STEP AFTER WRITE
01DE CF      0728      RST   B
                        0729
01DF F1      0730      POP   AF
01E0 300A    0731      JR    C, SOUT      ;CARRY=STEP OUT
                        0732
01E2 6F      0733 SIN:   LD    L, A
01E3 3A0305  0734      LD    A, (SVDRV)
01E6 F620    0735      OR   BCDAS
01E8 D300    0736      OUT  BLCTL, A
01EA 180B    0737      JR   STEPS
                        0738
01EC ED44    0739 SOUT:  NEG   ;COMPLEMENT OFFSET
01EE FA5102  0740      JP   M, HOME
                        0741
01F1 6F      0742      LD    L, A
01F2 3A0305  0743      LD    A, (SVDRV)
01F5 D300    0744      OUT  BLCTL, A
                        0745
01F7 D008    0746 STEPS: IN   A, XPSTP      ;ISSUE STEP PULSE
01F9 115000  0747      LD    DE, TMSTPC
01FC CF      0748      RST   B
                        0749
01FD 2D      0750      DEC   L      ;IF STEPS-1 NOT 0 THEN STEP AGAIN
01FE 20F7    0751      JR   NZ, STEPS
                        0752
0200 115000  0753      LD    DE, TMALS      ;ELSE EXTEND LAST PULSE
0203 CF      0754      RST   B
                        0755
0204 1EC0    0756 ; TRACK SECTION DISTRIBUTE
                        0757
0206 3A7203  0758      LD    E, BCSDS + BCPL ;USE SD, PRECOMP LOW AS DEFAULTS
                        0759
0209 FE01    0760      LD    A, (CBTRK)      ;IF TRACK 0 THEN USE DEFAULTS
020B 3830    0761      CP   1
020D 280A    0762      JR   C, CTLS
                        0763
020F FE1A    0764      JR   Z, TRK1          ;ELSE IF TRACK 1 THEN GOTO TRK1
                        0765
0211 3810    0766      CP   26D             ;ELSE IF < TRACK 26 THEN GOTO OUTS
0213 FE34    0767      JR   C, OUTS
                        0768
0215 3814    0769      CP   52D             ;ELSE IF < TRACK 52 THEN GOTO MIDS
0217 181C    0770      JR   C, MIDS
                        0771
0219 DDCB034E 0772      JR   INSD
                        0773
021D 281E    0774 ; TRACK 1
                        0775
0219 DDCB034E 0776 TRK1: BIT  DFT1D, (IX + DVFLG) ;IF SD THEN USE DEFAULTS
021D 281E    0777      JR   Z, CTLS
                        0778
0219 DDCB034E 0778
021D 281E
    
```

DISK CONTROLLER MODULE (DCM)

SUBROUTINES

```

021F 1ED0      0779 T1DD: LD      E,BCDD5 + BCPL      ;USE DD, LOW COMP
0221 181A      0780      JR      CTLS
                0781
                0782 ;      OUTSIDE TRACKS
                0783
0223 DDCB0356  0784 OUTS: BIT    DFDT0,(IX + DVFL6)    ;IF SD THEN USE DEFAULTS
0227 2814      0785      JR      Z,CTLS
                0786
0229 18F4      0787      JR      T1DD      ;ELSE USE SAME AS TRACK 1
                0788
                0789 ;      MIDDLE TRACKS
                0790
022B DDCB0356  0791 MIDS: BIT    DFDT0,(IX + DVFL6)    ;IF SD THEN USE DEFAULTS
022F 280C      0792      JR      Z,CTLS
                0793
0231 1E90      0794      LD      E,BCDD5 + BCPCM      ;USE DD, MEDIUM PRECOMP
0233 1808      0795      JR      CTLS
                0796
                0797 ;      INSIDE TRACKS
                0798
0235 DDCB0356  0799 INSD: BIT    DFDT0,(IX + DVFL6)    ;IF SD THEN USE DEFAULTS
0239 2802      0800      JR      Z,CTLS
                0801
023B 1E50      0802      LD      E,BCDD5 + BCPCB      ;SET DD, HIGH PRECOMP
                0803
                0804 ;      SET CONTROLS
                0805
023D 3A0305    0806 CTLS: LD      A,(SVDRV)      ;ADD DENSITY, PRECOMP BITS TO CONTROL BITS
0240 B3        0807      OR      E
0241 D07704    0808      LD      (IX + DVCTL),A
                0809
0244 D300      0810 EXITS: OUT    BLCTL,A
                0811
0245 3A7203    0812      LD      A,(CBTRK)      ;SET REQUESTED TRACK
0249 D07701    0813      LD      (IX + DVTRK),A
024C A9        0814      XOR    C
024D D305      0815      OUT    WDTRK,A      ;SET TRACK REGISTER
024F AF        0816      XOR    A      ;SET Z FLAG
0250 C9        0817      RET
                0818
                0819 ;      CALIBRATE TRACK #
                0820
0251 C07901    0821 HOME: CALL   HOMED      ;HOME SELECTED DRIVE
0254 C30C01    0822      JP      HLDD      ;NOW SEEK TRACK
                0823
                0824
                0825 ;*****
                0826 ;
                0827 ;      HEAD LOAD/UNLOAD SUBROUTINES
                0828 ;      ENTRY - E= HEAD COMMAND
                0829 ;
                0830 ;*****
0257 F0E1      0831 EXHEAD: POP    IY      ;IY=RETURN ADDR
0259 DB05      0832      IN     A,WDTRK      ;PERFORM SEEK TO CURRENT TRACK WITH HEAD LOAD
    
```

DISK CONTROLLER MODULE (DCM)
SUBROUTINES

```

025B 0307      0833      OUT      WDDTA, A
                0834
025D 7B       0835      LD       A, E      ;OUTPUT PASSED COMMAND
025E A9       0836      XOR      C
025F D304     0837      OUT      WDCMD, A
                0838
0261 18FE     0839      JR       $        ;WAIT FOR INTERRUPT
                0840
                0841
                0842 ;*****
                0843 ;
                0844 ;   GET STATUS SUBROUTINE
                0845 ;   EXIT - A= 179: STATUS
                0846 ;
                0847 ;*****
0263 3ED0     0848 EXSTS: LD   A, DCSTS ;OUTPUT SET STATUS COMMAND TO 179:
0265 A9       0849      XOR      C
0266 D304     0850      OUT      WDCMD, A
0268 E3       0851      EX       (SP), HL ;PAUSE
0269 E3       0852      EX       (SP), HL
026A E3       0853      EX       (SP), HL
026B E3       0854      EX       (SP), HL
026C D304     0855      IN      A, WDSTS ;GET LATEST STATUS
026E A9       0856      XOR      C
026F 09       0857      RET
                0858
                0859
                0860 ;*****
                0861 ;
                0862 ;   READ SECTOR SUBR PRESETS RWDP TO READ
                0863 ;
                0864 ;*****
0270 16FF     0865 R0SEC: LD   D, -1
0272 1803     0866      JR      RWSECT
                0867
                0868
                0869 ;*****
                0870 ;
                0871 ;   READ/WRITE SECTOR SUBR
                0872 ;   ENTRY- A' = 0: WRITE, /0: READ
                0873 ;   HL= XFER PTR
                0874 ;   E= SECTOR
                0875 ;   EXIT - NZ= ERROR
                0876 ;   A, HL, B= ?
                0877 ;
                0878 ;*****
0274 06       0879 RWSECA: EX  AF, AF'
0275 57       0880      LD      D, A
0276 06       0881      EX      AF, AF'
                0882
                0883
                0884 ;*****
                0885 ;
                0886 ;   READ/WRITE SECTOR SUBROUTINE INITIATES DISK XFER, SEVICES THE

```

DISK CONTROLLER MODULE (DCM)

SUBROUTINES

```

0087 ; CONTROLLER CHIP DURING DATA XFER, & TERMINATES OPERATION
0088 ; WHEN FINISHED. ERROR DETECTION IS IMPLEMENTED & RETRIES ARE
0089 ; EXECUTED IF DATA ERRORS ARE DETECTED.
0090 ; ENTRY - D= 0: WRITE, /0: READ
0091 ; HL= XFER PTR
0092 ; E= PHYSICAL SECTOR # (1..26)
0093 ; EXIT - NZ= ERROR
0094 ; HL, A, B= ?
0095 ;
0096 ;*****
0097
0277 AF 0098 RWSRCT: XDR A ;0 ERROR COUNT
0278 320405 0099 LD (ERRCT),A
0300 CALL CHOSIDE ;CHOOSE SIDE
0278 73 0901 LD A,E ;SET 1791 SECTOR REGISTER
027C 49 0902 XDR C
027D 0306 0903 OUT W0SEC,A
0904
027F FD21A002 0905 RWRTRY: LD IV,RWNMI ;SET NMI VECTOR FOR RETURN
0906
0283 0688 0907 LD B,DCRDS ;DEFAULT TO READ
0908
0285 7A 0909 LD A,D ;SELECT OPERATION
0286 B7 0910 OR A
0287 2002 0911 JR NZ,DPOK
0912
0289 06A8 0913 LD B,DCWRB ;WRITE OP
0914
028B 78 0915 DPOK: LD A,B ;OUTPUT READ SECTOR COMMAND
028C 49 0916 XDR C
028D 0304 0917 OUT WDCMD,A
0918
028F E3 0919 EX (SP),HL
0290 E3 0920 EX (SP),HL ;WAIT FOR 1791
0291 E3 0921 EX (SP),HL
0292 E3 0922 EX (SP),HL
0923
0293 7A 0924 LD A,D ;IF WRITE OP THEN GO DD IT
0294 B7 0925 OR A
0295 2820 0926 JR Z,WROP
0927
0297 0880 0928 RDREPT: IN A,XPSH ;GENERATE "HOLD" UNTIL 179X READY
0929
0299 0B07 0930 IN A,WDDTA ;XFER DATA TO BUFFER
029B A9 0931 XDR C
029C 77 0932 LD (HL),A
029D 23 0933 INC HL ;PTR +1
029E 18F7 0934 JR RDREPT
0935
0936 ; CHECK STATUS
0937
02A0 069D 0938 RWNMI: LD B,DMRER ;IF NO ERRORS THEN RETURN
02A2 F5 0939 PUSH AF ;SAVE 179X STATUS
0940

```

LD OR A, (SIDE)
B

DISK CONTROLLER MODULE (DCM)

SUBROUTINES

```

02A3 7A      0941      LD      A,D      ;IF WRITE OP THEN
02A4 B7      0942      OR      A
02A5 2002   0943      JR      NZ,RWMSK
                0944
02A7 06FD   0945      LD      B,DMWER  ;USE WRITE ERR MASK
                0946
02A9 F1      0947      RWMSK: POP     AF      ;179X STATUS
02AA A0      0948      AND     B
02AB 327703 0949      LD      (CBSTS),A
02AE C8      0950      RET     Z
                0951
02AF D5      0952      PUSH   DE      ;SAVE FLAG, SECTOR
02B0 CDC002 0953      CALL   CHKRT   ;IF RETRYS NOT EXHAUSTED THEN RETRY
02B3 01      0954      POP     DE
02B4 28C9   0955      JR      Z,RWRTRY
                0956
02B6 C9      0957      RET
                0958
                0959      WRDP:
02B7 DB80   0960      REPTW: IN      A,XPDSH ;HOLD FOR DATA REQ
                0961
02B9 7E      0962      LD      A,(HL)  ;OUTPUT DATA TO 1791
02BA A9      0963      XOR     C
02BB D307   0964      OUT    WDDTA,A
02BD 23      0965      INC    HL
02BE 18F7   0966      JR      REPTW
                0967
                0968
0269 ;*****
0270 ;
0271 ; CHECK FOR RETRYS SUBROUTINE
0272 ; EXIT - A= 0: OK, /0: ERROR
0273 ;
0274 ;*****
02C0 E680   0975      CHKRT: AND     DMDNR  ;IF NOT READY THEN EXIT
02C2 C0      0976      RET     NZ
                0977
02C3 3A7503 0978      LD      A,(CBMOD) ;IF NO RETRYS CHECK THEN EXIT
02C6 E680   0979      AND     CMNRT
02C8 C0      0980      RET     NZ
                0981
02C9 DB40   0982      IN      A,XPMTX
                0983
02CB 3A0405 0984      LD      A,(ERRCT) ;ERROR COUNT +1
02CE 3C      0985      INC    A
02CF 320405 0986      LD      (ERRCT),A
02D2 FE05   0987      CP     RTYSK   ;IF NOT TRY SEEK THEN CHECK LAST
02D4 2007   0988      JR      NZ,CKLS
                0989
02D6 CD7B01 0990      CALL   HOMED   ;HOME SELECTED DRIVE
02D9 CC8C01 0991      CALL   Z,SEEK ;RE-SEEK DESIRED TRACK
02DC C0      0992      RET     NZ     ;IF ERROR THEN EXIT
                0993
02DD FE09   0994      CKLS:  CP     RTYLS ;IF LAST RETRY THEN RETURN WITH ERROR
    
```

DISK CONTROLLER MODULE (DCM)
SUBROUTINES

```

02DF 2006      0995      JR      Z,STNZ
                        0996
02E1 11B004   0997      LD      DE,TEMPD      ;ELSE WAIT & RETURN WITH NO ERRORS
02E4 0F       0998      RST      B
                        0999
02E5 AF       1000      XOR      A
02E6 09       1001      RET
                        1002 ;
02E7 3C       1003 STNZ:   INC      A      ;SET NO RETRY FLAG (NZ)
                        1004
02E8 09       1005      RET
                        1006
                        1007
                        1008 ;*****
                        1009 ;
                        1010 ;   DEBLOCKING BUFFER HANDLER
                        1011 ;   ENTRY- AF'= ZF: WRITE OP, NZ: READ OP
                        1012 ;   EXIT - NZ= ERROR
                        1013 ;           HL, DE= ?
                        1014 ;
                        1015 ;*****
02E9 CD0C03   1017      CALL    BUFDK      ;SET UP SECTOR BUFFER
02EC 00       1018      RET      NZ
                        1019
02ED 05       1020      PUSH    BC
02EE 01B000   1021      LD      BC,SECSIZ ;SET UP XFER
02F1 11B003   1022      LD      DE,XBUF
02F4 210004   1023      LD      HL,SBUFR   ;DEFAULT TO LD HALF
                        1024
02F7 3A7303   1025      LD      A,(CBSSEC) ;COMPUTE LOGICAL HALF
02FA 3D       1026      DEC     A      ;0: LG, 1: HI
02FB 0B47     1027      BIT     0,A
02FD 2003     1028      JR      Z,XOK
                        1029
02FF 21B004   1030      LD      HL,SBUFR + SECSIZ ;XFER HI HALF
                        1031
0302 00       1032 XOK:   EX      AF,AF'   ;IF READ THEN OK
0303 2001     1033      JR      NZ,NOTWRT
                        1034
0305 EB       1035      EX      DE,HL    ;ELSE REVERSE DIRECTION
                        1036
0306 00       1037 NOTWRT: EX     AF,AF' ;RESTORE FLAG
0307 EDB0     1038      LDIR
                        1039
0309 C1       1040      POP     BC
030A AF       1041      XOR     A      ;RETURN OK
030B 09       1042      RET
                        1043
                        1044
                        1045 ;*****
                        1046 ;
                        1047 ;   CHECK FOR BUFFER OK SUBR
                        1048 ;   EXIT - NZ= ERROR

```

DISK CONTROLLER MODULE (DCM)
SUBROUTINES

```

1049 ;           HL,DE,A= ?
1050 ;*****
1051 BUFOK:
030C 3A7303 1052     LD     A,(CBSEC)           ;COMPUTE PHYSICAL SECTOR
030F 3D      1053     DEC     A           ;1..N -> 0..N-1
0310 CB2F  1054     SRA     A           ;N' = N / 2
0312 3C      1055     INC     A           ;0..N'-1 -> 1..N'
1056
0313 5F      1057     LD     E,A           ;SAVE FOR LATER
0314 3A0005 1058     LD     A,(BSECT)
0317 B8      1059     CP     E
0318 200F  1060     JR     NZ,NOTSAME
1061
031A 3A0205 1062     LD     A,(BDISK)           ;IF BUFFER NOT SAME THEN READ BUFR
031D DBE00  1063     CP     (IX + DVNBR)
0320 2007  1064     JR     NZ,NOTSAME
1065
0322 3A0105 1066     LD     A,(BTRACK)
0325 DBE01  1067     CP     (IX + DVTRK)
0328 C8      1068     RET     Z           ;SAME, JUST RETURN
1069
1070 NOTSAME:
0329 210004 1071     LD     HL,SBUFR           ;SET PTR
032C DE      1072     PUSH  DE           ;SAVE PHYSICAL SECTOR #
032D CD7002 1073     CALL  RDSEC
0330 D1      1074     POP   DE
0331 2802  1075     JR     Z,BRDOK           ;IF ERROR THEN CLEAR BUFFER
1076
0333 1E00  1077     LD     E,0
1078
0335 210005 1079     BRDOK: LD     HL,BSECT           ;UPDATE BUFFER PTRS
0338 73      1080     LD     (HL),E
0339 23      1081     INC   HL
033A DD7E01 1082     LD     A,(IX + DVTRK)
033D 77      1083     LD     (HL),A
033E 23      1084     INC   HL
033F DD7E00 1085     LD     A,(IX + DVNBR)
0342 77      1086     LD     (HL),A
0343 C9      1087     RET
1088
1089

```

DISK CONTROLLER MODULE (DCM)

DATA AREAS

```

1091
1092 ;-----
1093 ;
1094 ; DISKETTE FORMAT LABEL
1095 ;
1096 ;-----
0344 4A616465 1097 JADEID: DB 'Jade DD ' ;DISKETTE ID LABEL
      20444420
      (0008) 1098 IDSIZE: EQU $-JADEID ;LABEL LENGTH
      1099
      (0330) 1100 IDLBL: EQU BUFR0+0 ;ID SECTOR LABEL OFFSET
      1101
      (03A0) 1102 IDBLK: EQU IDLBL+20H ;ID DISK DESCRIPTOR BLOCK OFFSET
      (03A0) 1103 IDSPR: EQU IDBLK+0 ;SECTORS PER TRACK OFFSET
      (03B0) 1104 IDSTG: EQU IDBLK+10H ;SECTOR STAGGER OFFSET
      (03B1) 1105 IDPL6: EQU IDBLK+11H ;DISKETTE FLAGS OFFSET
      1106
      (0000) 1107 IDFLD: EQU 00000000B ;3740 FLAGS
      1108
      1109 ;-----
      1110 ;
      1111 ; DRIVE TABLE OFFSETS
      1112 ;
      1113 ;-----
      (0000) 1114 DVNBR: EQU 0 ;CURRENT DRIVE #
      (0001) 1115 DVTRK: EQU 1 ;CURRENT TRACK #
      (0002) 1116 DVSEC: EQU 2 ;CURRENT SECTOR #
      1117 ;
      1118 ; DISK FORMAT FLAG BYTE
      1119 ;
      1120 ;BIT #: 76543210
      1121 ; ^^ ^^^^ TRACK 0 DENSITY (0: SD, 1: DD) (ALLWAYS 0)
      1122 ; || ||| TRACK 1 DENSITY
      1123 ; \| || TRACK 2..75 DENSITY
      1124 ; | | SIDES FLAG (0: 1 SIDE, 1: 2 SIDES)
      1125 ; | _____ BYTES PER SECTOR (00: 120, 01: 256, 10: 512, 11: 1024)
      1126 ;
      (0003) 1127 DVFLG: EQU 3 ;SIDE & DENSITY FLAGS
      1128
      1129 ; FLAG BIT DEFINITIONS
      1130
      (0001) 1131 DFT1D: EQU 1 ;TRK 1 DENSITY (1=DBL)
      (0002) 1132 DFD1D: EQU 2 ;DATA TRKS DENSITY (1=DBL)
      (0003) 1133 DFTSD: EQU 3 ;2 SIDED (1=2 SIDES)
      (0002) 1134 DFD1D: EQU DFT1D + DFT1D ;DEFAULT FLAGS
      1135
      (0004) 1136 DVCTL: EQU 4 ;LAST CONTROLS USED OFFSET
      1137
      1138 ; DRIVE TABLES
      1139
      (034C) 1140 DVTBL: EQU $
034C 00FF0002 1141 DTDE0: DB 0,255D,0,DFDFL,0C4H ;DRIVE 0
      CA
0351 01FF0002 1142 DTDE1: DB 1,255D,0,DFDFL,0C5H ;DRIVE 1

```

DISK CONTROLLER MODULE (DCM)

DATA AREAS

```

0355 03FF0002 1143 DB 2,255D,0,DFDFL,0C6H ;DRIVE 2
0356 03FF0002 1144 DB 3,255D,0,DFDFL,0C7H ;DRIVE 3
0357 04FF0000 1145 DTDED: DB 4,255D,0,0,0 ;DUMMY
0358 (0005) 1146 DVDES: EQU DTDE1-DTDE0 ;ENTRY SIZE
1147
1148
1149 ;-----
1150 ;
1151 ; COMMAND BLOCK
1152 ; THIS IS THE HOST COMMUNICATION AREA
1153 ;
1154 ;-----
0365 (0005) 1155 DB CMDBLK - $ ;POSITION BLOCK
1156 ;CMDBLK: COMMENTED OUT, DEFINED IN INCLUDE FILE
0370 00 1160 DB 0 ;CONTROL COMMAND
0371 00 1161 DB 0 ;DRIVE #
0372 00 1162 DB 0 ;TRACK #
0373 00 1163 DB 0 ;SECTOR #
0374 00 1164 DB 0 ;FORMAT FLAGS
0375 00 1165 DB 0 ;UNASSIGNED
0376 00 1166 DB 0 ;MODE SELECTS
0377 00 1167 DB 0 ;CONTROLLER STATUS
0378 0000 1168 DW 0 ;LOAD ADDR
0379 0000 1169 DW 0 ;LOAD LENGTH
037C 00 1170 SVSTS DB 0 ;1791 RAW STATUS
1171
037D (0003) 1175 DB BUF8-$
(0380) 1176 XBUF EQU $ ;DATA XFER BUFFER START
1177

```

DISK CONTROLLER MODULE (DCM)
INITIALIZATION ROUTINE

```

1179 ;-----
1180 ;
1181 ; THIS CODE IS ENTERED BY THE BOOT INJECTION MODULE (BIM) FROM ENTRY
1182 ; VECTOR AT DCM ADDRESS 0003H (ACTUALLY AT 0403H WHEN EXECUTED).
1183 ; IT RELOCATES THE ENTIRE DCM CURRENTLY IN BANK 1 TO BANK 0, THEN TRANSFERS
1184 ; CONTROL TO IT'S BANK 0 IMAGE WHICH THEN PROCEEDS TO INITIALIZE THE FIRMWARE
1185 ; AND LOAD THE BIOS LOADER INTO THIS BUFFER.
1186 ;
1187 ;-----
0382 010004 1188 INITS: LD BC,BANKL ;SET BYTE COUNT TO MOVE
0383 110000 1189 LD DE,BANK0
0384 010004 1190 LD HL,BANK1
0385 0050 1191 CDIR ;XFER DCM TO BANK 0 FROM LOAD
0386 030003 R 1192 JP DOWN ;TRANSFER TO FOLLOWING CODE NOW IN BANK 0 ALSO
1193 ;
038E 010005 1194 DOWN: LD SP,STACK
0391 001401 1195 CALL INIT
1196
0394 1002 1197 LD E,2 ;LOAD IN BIOS LOADER SECTOR
0396 0040 1198 IN A,XPYTX
0398 010003 1199 LD HL,BUF06 ;SET RETURN TO EXECUTE BLT
0399 05 1200 PUSH HL
039C 037002 1201 JP RDSEC
1202
1206

```

DISK CONTROLLER MODULE (DCM)

UNINITIALIZED VARIABLES

```

(0400) 1208 ORG BANK1
1209 ;
1210 ; PHYSICAL SECTOR LOCS FOR DEBLOCKING
1211 ;
0400 (0100) 1212 SBUFR DS 256 ;PHYSICAL SECTOR BUFFER
1213 ;
1214 ; NOTE: THE FOLLOWING 3 BYTES MUST APPEAR IN THIS ORDER, THEY ARE
1215 ; INDEXED BY A POINTER IN BUFOK SUBR.
1216 ;
0500 (0001) 1217 BSECT DS 1 ;CURRENT SECTOR #
0501 (0001) 1218 BTRACK DS 1 ;CURRENT SECTOR TRACK #
0502 (0001) 1219 BDISK DS 1 ;CURRENT SECTOR DISK #
1220
0503 (0001) 1221 SVDIV DS 1 ;BLCTL DRIVE BITS
0504 (0001) 1222 ERCT DS 1 ;RETRY COUNT
1223
0505 (0020) 1224 DS 32 ;STACK SIZE
(0525) 1225 STACK EQU #
1226
0525 (0000) 1230 END

```

```

Errors      0
Range Count 4

```

DISK CONTROLLER MODULE (DCM)

Symbol	Value	Defn	References
ADDR	0042	0361	0435
BANK0	0200	0204	0205 0208 0220 1189
BANK1	0400	0205	0221 0233 1190 1203 1208 1227
BANKL	0400	0203	0205 0270 1188
BCDAS	0020	0098	0654 0735
BCODE	0010	0097	0107
BCDDS	0010	0107	0779 0794 0802
BCDR0	0000	0101	
BCDSA	0001	0093	0105
BCDSB	0002	0094	0105
BCDSE	0004	0095	0602 0613 0619
BCDSN	0003	0105	0617 0623
BCEIA	0008	0096	
BCPCA	0040	0099	0108 0110
BCPCB	0040	0100	0109 0110
BCPCN	0040	0108	0802
BCPCL	00C0	0110	0758 0779
BCPCM	0080	0109	0794
BCPCZ	0000	0111	
BCSDS	0000	0106	0758
BDISK	0502	1219	1062
BEHDM	0021	0226	
BERDA	0002	0227	
BERDB	0004	0228	
BLCTL	0000	0078	0603 0614 0618 0620 0655 0665 0736 0744 0810
BLSTS	0000	0077	0379 0571 0591
BRDOK	0335	1079	1075
BSDCN	0080	0123	
BSECT	0500	1217	0557 0577 1058 1079
BSEIA	0010	0120	
BSINT	0008	0119	0380
BSMDF	0020	0121	0592
BSTED	0040	0122	
BSTST	0004	0118	
BSUS0	0001	0116	0572
BSUS1	0002	0117	
BTRACK	0501	1218	1066
BUFBG	0380	0220	1100 1172 1175 1199
BUFFOK	030C	1051	1017
CBCMD	0370	0209	0415
CBDRV	0371	0210	0605 0616
CBFFG	0374	0213	
CBMDD	0376	0215	0978
CBSEC	0373	0212	0450 0487 0541 1025 1052
CBSPR	0375	0214	
CBSTS	0377	0216	0369 0466 0635 0949
CBTRK	0372	0211	0484 0717 0760 0812
CHKRT	0200	0975	0953
CKDV	0137	0599	0593
CKJI	0000	0498	0504
CKLS	0200	0994	0988
CLEAR	0018	0304	0268
CMDBLK	0370	0208	0209 0210 0211 0212 0213 0214 0215 0216 0217 0218 1155 1158
CMDT	0083	0430	0420

DISK CONTROLLER MODULE (DCM)

Symbol	Value	Defn	References
CMNRT	0000	0238	0979
CSBSY	0001	0159	
CSCRC	0003	0156	
CSDNR	0000	0152	
CSDRR	0002	0167	
CSHLD	0020	0154	
CSINDX	0002	0158	
CSLDE	0004	0166	
CSRNF	0010	0165	
CSSE	0010	0155	
CSTK0	0004	0157	
CSTYPE	0020	0163	
CSWFLT	0020	0164	
CSWRP	0040	0153	
CTLS	023D	0806	0762 0777 0780 0785 0792 0795 0800
CWLAD	037B	0217	
CWLNG	037A	0218	0468
DCHDL	0010	0127	0711
DCHDU	0010	0128	0609
DCIFI	0000	0146	
DCMBG	0403	0233	
DCMLN	0400	0234	
DCMB5	0004	0232	
DCRDA	00C0	0144	
DCRDE	0088	0140	0907
DCRKS	0098	0141	
DCSTS	0000	0145	0848
DCWRS	0008	0142	0913
DCWRT	00F0	0147	0456
DFDFL	0002	1134	1141 1142 1143 1144
DFDTD	0002	1132	0784 0791 0799
DFT1D	0001	1131	0776 1134 1134
DFTSD	0003	1133	
DMDNR	0080	0176	0634 0975
DMFER	00E4	0173	0465
DMHDL	0020	0175	0708
DMLDE	0004	0177	
DMRER	009D	0171	0938
DMTK0	0004	0174	0649 0670
DMWER	00FD	0172	0945
DOBUFR	02E9	1016	0548
DOWN	038E	1194	1192
DSET	01DA	0726	0719
DTDE0	034C	1141	1146
DTDE1	0351	1142	1146
DTDED	0360	1145	0575
DVCTL	0004	1136	0721 0808
DVDES	0005	1146	0625
DVFLG	0003	1127	0451 0507 0514 0544 0776 0784 0791 0799
DVNBR	0000	1114	0606 1063 1085
DVSEC	0002	1116	
DVTRL	034C	1140	0624
DVTRK	0001	1115	0688 0718 0813 1067 1082
EROR	0180	0695	0674

DISK CONTROLLER MODULE (DCM)

Symbol	Value	Defn	References
ERRCT	0504	1222	0899 0984 0986
EXHEAD	0257	0831	0610 0712
EXIT	01AD	0684	0671
EXITS	0244	0810	0722
EXSTS	0263	0848	0413 0633 0648 0669 0707
FALSE	0000	0046	0047 0048
FMTEG	0700	0221	0222
FMTDS	0708	0222	0463
FORM	008B	0447	0434
HLD0	01CC	0717	0709 0822
HOME	0251	0821	0740
HOME1	0199	0666	0650
HOMED	017B	0647	0821 0990
HRVEC	003D	0343	0331
I3740	000F	0512	0500
IDBLK	03A0	1102	1103 1104 1105
IDFLD	0000	1107	0513
IDFLG	03B1	1105	0506
IDLBL	0380	1100	0495 1102
IDLE	004B	0379	0381 0438
IDSPT	03A0	1103	
IDSTG	03B0	1104	
IDSTZ	0009	1098	0496
INIT	0114	0569	0305 0329 1195
INITB	0380	1188	0270
INSD	0235	0799	0772
JADEID	0344	1097	0494 1098
LBDN	00B1	0480	0431
LSTINC	0000	0048	0071 0137
MASK	0007	0439	0417
MIDS	022B	0791	0770
NBTAK	0050	0184	
NEXT	016A	0627	0631
NMINT	0066	0206	
NMIWT	00A8	0465	0454
NDTSAME	0329	1070	1060 1064
NDTWR	0306	1037	1033
OPCONT	00EB	0534	0525
OPCK	028B	0915	0911
OLTS	0223	0784	0767
RDREPT	0297	0928	0934
RDSEC	0270	0865	0316 0492 1073 1201
READ	00E5	0523	0432
RECAL1	018B	0657	0662
REPTW	0287	0960	0966
RST38	003B	0341	
RST38A	0030	0329	0343
RST40	002B	0316	
RST8	0008	0282	
RTYLS	0009	0199	0994
RTYSK	0005	0198	0987
RWMSK	02A9	0947	0943
RWNMI	02A0	0938	0905
RWRTRY	027F	0905	0955

DISK CONTROLLER MODULE (DCM)

Symbol	Value	Defn	References
RWSECA	0274	0879	0546
RWSECT	0277	0898	0559 0866
SEUFR	0400	1212	0556 1023 1030 1071
SECSIZ	0080	0239	1021 1030
SEEK	018C	0707	0452 0488 0537 0991
SELECT	0120	0591	0447 0480 0536
SIN	01E2	0733	
SLED	0172	0633	0628
SLEEP	0040	0352	0306
SOUT	01EC	0739	0731
SPAR	0042	0369	0436 0437
STACK	0525	1225	0304 0342 1194
STEP	0198	0669	0680
STEPS	01F7	0746	0737 0751
STNZ	02E7	1003	0995
STOP	011F	0575	0573
SVDRV	0503	1221	0578 0601 0612 0621 0653 0664 0734 0743 0806
SVSTS	037C	1170	0401
T1DD	021F	0779	0787
TICKE	0013	0290	0285
TICKR	000F	0287	0295
TNALS	0050	0186	0684 0753
TMSBR	0001	0183	
TMHLD	015E	0185	0714
TMMTO	0001	0187	0596
TMPLD	0480	0188	0997
TMRFC	0019	0193	0283
TMRNC	001C	0194	0287
TMSAW	000A	0189	0727
TMSTP	0008	0181	
TMSTRC	0050	0182	0658 0678 0747
TRK1	0219	0776	0764
TRUE	FFFF	0047	
TSTACK	0038	0340	
VERSN	3133	0043	
WDCMD	0004	0079	0458 0837 0850 0917
WDDTA	0007	0083	0833 0930 0964
WDINT	0066	0399	
WDSEC	0006	0082	0903
WDSTS	0004	0080	0399 0855
WDTRK	0005	0081	0815 0832
WRIT	00EA	0533	0433
WRDP	0287	0959	0926
XBUF	0380	1176	0490 0540 1022
XCLTE	0070	0413	0330
XCK	0302	1032	1028
XDSH	0080	0088	0928 0960
XDIRR	0020	0086	0341 0382
XPMTD	0010	0085	
XPMYX	0040	0087	0595 0599 0982 1198
XPSTP	0008	0084	0657 0676 0746

VFR #2

3888	3600	SECTS.
486	450K	DRIVE CAP.
64	64	DIR ENTS.
64	64	CHK DIR
256	256	REC/EXT
16	16	REC/BLK
52	48	SPT
2	2	RSVT

OLD

00:17.05

NEW NON-BLOCKED


00:16.98

NEW BLOCKED

00:36.05

PIPING FILE TO NEW NAME


(X = FILE)





BLOCK IS BIT IN DISK DESCRIPTOR.
 HALF IS DETERMINED FROM BIT 0 OF SECTOR

BUFFER HAS FLAGS :

BSECTOR	DB	0	;	0 = UNUSED	1-255 = SECTOR #
BTRACK	DB	0	;	TRACK #	
BDISK	DB	-1	;	DRIVE #	







; WAIT FOR HOST COMMAND (INT)

RST 38H

0038
CLEAR INT REQUEST FF
WASTE INT RETURN

(XCODE) (HVEC)
0070
EXISTS GET 179K
ATTN.

0073
GET COMMAND
ADDR FROM TABLE

PUT 'FETCH' ON
STACK FOR RETURN

JP CMD.

LGON, READ, WRIT, FORM, ADDR, SPAR, SPAR,
IDLE


ADDR,
SPAR
00BF
SET EMD ERR
00C4
RET


IDLE
00C5
HOST
INTERAT ?
N
Y 00CB
CLEAR HOST
INT.
00CD
RET


READ
004B
SELECT
004E
ERR ?
Y RET
N 004F
SEEK
0052
RDSEC
0272

WRIT
0055
SELECT
0058
ERR ?
Y RET
N 0059
SEEK
005C
WRSEC
02A1

FORM
0099
SELECT
009C
ERR ?
Y RET
N 009D
SET DRIVE FLAGS
00A3
SEEK
00A6
WRTRK
02D0









;179x DONE INTERRUPT

LGON

LOGON COMMAND




TIMING DELAY
ENTRY - DE = # (100µs)




DRIVE SELECT SUBR.

EXIT - ZF: OK
NZ: ERROR, NOT READY




HOME CURRENT DRIVE TO TRACK 0 SUBR.


EXIT - ZF : OK
NZ : ERROR.




SEEK



EX HDL



EX HDU



EXSTS

