



**AIRBUS**

**A318/A319/A320/A321**

**AeroGal**  
AEROLINEAS GALAPAGOS S.A.

# **FLIGHT CREW OPERATING MANUAL**

The content of this document is the property of Airbus. It is supplied in confidence and commercial security on its contents must be maintained. It must not be used for any purpose other than that for which it is supplied, nor may information contained in it be disclosed to unauthorized persons. It must not be reproduced in whole or in part without permission in writing from the owners of the copyright.

© AIRBUS 2005. All rights reserved.

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## TRANSMITTAL LETTER

**Issue date: 17 OCT 17**

This is the FLIGHT CREW OPERATING MANUAL major event publication at issue date 17 OCT 17 for the A318/A319/A320/A321 and replacing last issue dated 05 SEP 17

Intentionally left blank

Please incorporate this major event revision as follow:

Localization Subsection Title	Remove	Insert
		Rev. Date
PLP-LESS <b>LIST OF EFFECTIVE SECTIONS/SUBSECTIONS</b>	ALL	17 OCT 17
OEB-PLP-LEOEB <b>LIST OF EFFECTIVE OPERATIONS ENGINEERING BULLETIN</b>	ALL	17 OCT 17
OEB-PLP-LEDU <b>LIST OF EFFECTIVE DOCUMENTARY UNITS</b>	ALL	17 OCT 17
OEB-50 <b>Modification of the AFTER START Normal Procedure</b>	ALL	

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Intentionally left blank

# **PRELIMINARY PAGES**

Intentionally left blank

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
R	PLP-LESS	LIST OF EFFECTIVE SECTIONS/SUBSECTIONS	17 OCT 17
	GEN-PLP-LETDU	LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS	17 OCT 17
	GEN	General Information	05 SEP 17
	DSC-PLP-LETDU	LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS	17 OCT 17
	DSC-20-10	Overview	22 MAR 17
	DSC-20-20	Description	22 MAR 17
	DSC-20-30	Ground Handling	19 JUN 17
	DSC-20-40	Ground Clearance Diagram	22 MAR 17
	DSC-20-50	Landing Geometry	19 JUN 17
	DSC-20-60	Visual Ground Geometry	19 JUN 17
	DSC-21-10-10	General	22 MAR 17
	DSC-21-10-20	Main Components	22 MAR 17
	DSC-21-10-30	Temperature and Flow Regulation	22 MAR 17
	DSC-21-10-40	System Operation under Failure Condition	22 MAR 17
	DSC-21-10-50	Controls and Indicators	22 MAR 17
	DSC-21-20-10	General	22 MAR 17
	DSC-21-20-20	Main Components	22 MAR 17
	DSC-21-20-30	System Operation	22 MAR 17
	DSC-21-20-40	Controls and Indicators	22 MAR 17
	DSC-21-30-10	General	22 MAR 17
	DSC-21-30-20	Avionics Ventilation	22 MAR 17
	DSC-21-30-40	Battery Ventilation	22 MAR 17
	DSC-21-30-50	Lavatory and Galley Ventilation	22 MAR 17
	DSC-21-30-60	Controls and Indicators	22 MAR 17
	DSC-21-40-10	General	22 MAR 17
	DSC-21-40-20	System Operation	22 MAR 17
	DSC-21-40-30	Controls and Indicators	22 MAR 17
	DSC-21-40-35	ECAM Cond Page	22 MAR 17
	DSC-22_10-10	Description	22 MAR 17
	DSC-22_10-20	System Interface Diagram	22 MAR 17
	DSC-22_10-30	FMGS Modes of Operation	22 MAR 17
	DSC-22_10-40-05	Management of the Displays	22 MAR 17
	DSC-22_10-40-10	MCDU	22 MAR 17
	DSC-22_10-40-20	FCU	05 SEP 17
	DSC-22_10-40-30	Thrust Levers	22 MAR 17
	DSC-22_10-40-40	Primary Flight Display	22 MAR 17
	DSC-22_10-40-50	Navigation Display	22 MAR 17
	DSC-22_10-50-10	General	22 MAR 17
	DSC-22_10-50-20	Characteristic Speeds	22 MAR 17
	DSC-22_10-50-30	Limit Speeds	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-22_10-50-40	<b>Protection Speeds</b>	22 MAR 17
	DSC-22_10-50-50	<b>Other Speeds</b>	22 MAR 17
	DSC-22_20-10	<b>General</b>	22 MAR 17
	DSC-22_20-20-05	<b>General</b>	22 MAR 17
	DSC-22_20-20-10	<b>Position Computation</b>	22 MAR 17
	DSC-22_20-20-20	<b>Evaluation of Position Accuracy</b>	22 MAR 17
	DSC-22_20-20-30	<b>Radio Navigation Tuning</b>	05 SEP 17
	DSC-22_20-20-40	<b>Alignment of Inertial Reference System</b>	22 MAR 17
	DSC-22_20-20-50	<b>Navigation Database</b>	22 MAR 17
	DSC-22_20-30-05	<b>General</b>	22 MAR 17
	DSC-22_20-30-10-05	<b>General</b>	12 APR 17
	DSC-22_20-30-10-15	<b>FMS2 HONEYWELL</b>	22 MAR 17
	DSC-22_20-30-20-05	<b>General</b>	22 MAR 17
	DSC-22_20-30-20-25	<b>FMS2 Honeywell</b>	22 MAR 17
	DSC-22_20-40-10	<b>Optimization</b>	22 MAR 17
	DSC-22_20-40-20	<b>Cost Index</b>	22 MAR 17
	DSC-22_20-40-30	<b>Predictions</b>	22 MAR 17
	DSC-22_20-50-10-25	<b>FMS2 Honeywell</b>	05 SEP 17
	DSC-22_20-50-20-35	<b>FMS2 Honeywell</b>	22 MAR 17
	DSC-22_20-50-30	<b>MCDU - Data Format List</b>	22 MAR 17
	DSC-22_20-60-10	<b>Effect of Baro Reference Setting</b>	22 MAR 17
	DSC-22_20-60-20	<b>Clear Key (Clearing Function)</b>	22 MAR 17
	DSC-22_20-60-30	<b>How to Execute a Diversion</b>	22 MAR 17
	DSC-22_20-60-40	<b>Engine Out</b>	05 SEP 17
	DSC-22_20-60-50	<b>Secondary Flight Plan</b>	22 MAR 17
	DSC-22_20-60-60	<b>Pilots/Stored Route Function</b>	22 MAR 17
	DSC-22_20-60-70	<b>Report Page</b>	22 MAR 17
	DSC-22_20-60-80	<b>Closest Airports</b>	22 MAR 17
	DSC-22_20-60-90	<b>Time Marker</b>	22 MAR 17
	DSC-22_20-60-100	<b>Step ALTS</b>	12 APR 17
	DSC-22_20-60-110	<b>Required Time of Arrival (RTA)</b>	22 MAR 17
	DSC-22_20-60-120	<b>Equitime Point</b>	22 MAR 17
	DSC-22_20-60-130	<b>MCDU Back Up Navigation</b>	22 MAR 17
	DSC-22_20-60-150	<b>Descent Profile Optimization (if installed)</b>	22 MAR 17
	DSC-22_20-70	<b>AOC Functions</b>	22 MAR 17
	DSC-22_20-80	<b>Print Functions</b>	22 MAR 17
	DSC-22_20-90-10	<b>FMGC Reset</b>	12 APR 17
	DSC-22_20-90-20	<b>"CHECK GW" or "CHECK WEIGHT" Message</b>	22 MAR 17
	DSC-22_20-100-20	<b>FMS2 HONEYWELL Temporary Abnormal Behaviors</b>	22 MAR 17

*Continued on the following page*





**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-22_20-100-40	All FMS Temporary Abnormal Behaviors	22 MAR 17
	DSC-22_30-10	General	22 MAR 17
	DSC-22_30-20	Flight Director	22 MAR 17
	DSC-22_30-30	Autopilot (AP)	22 MAR 17
	DSC-22_30-40	Speed/Mach Control	22 MAR 17
	DSC-22_30-50	AP/FD Modes General	22 MAR 17
	DSC-22_30-60	AP/FD Lateral Modes	22 MAR 17
	DSC-22_30-70-10	Principles	22 MAR 17
	DSC-22_30-70-20	Climb Mode	22 MAR 17
	DSC-22_30-70-30	Open Climb Mode	22 MAR 17
	DSC-22_30-70-50	Descent Mode	22 MAR 17
	DSC-22_30-70-60	Open Descent Mode	22 MAR 17
	DSC-22_30-70-65	Altitude Acquire Mode	12 APR 17
	DSC-22_30-70-70	Altitude Hold Mode	22 MAR 17
	DSC-22_30-70-80	Vertical Speed Mode - Flight Path Angle Mode (V/S - FPA)	05 SEP 17
	DSC-22_30-70-90	Expedite	22 MAR 17
	DSC-22_30-75	Mode Reversions	22 MAR 17
	DSC-22_30-80-10	General	22 MAR 17
	DSC-22_30-80-20	Takeoff	22 MAR 17
	DSC-22_30-80-30-05	General	22 MAR 17
	DSC-22_30-80-30-10	Precision Approach	19 JUN 17
	DSC-22_30-80-30-20	Non Precision Approach	05 SEP 17
	DSC-22_30-80-40	Go Around (GA)	22 MAR 17
	DSC-22_30-90	Autothrust	22 MAR 17
	DSC-22_30-100	Flight Mode Annunciator (FMA)	22 MAR 17
	DSC-22_30-110	Temporary Abnormal Behaviors	05 SEP 17
	DSC-22_40-10	General	22 MAR 17
	DSC-22_40-20	Yaw Functions	22 MAR 17
	DSC-22_40-30	Flight Envelope Function	22 MAR 17
	DSC-22_40-40	Windshear Detection Function	22 MAR 17
	DSC-22_40-50	Controls and Indicators	22 MAR 17
	DSC-22_45	Auto Flight - AOC Functions	22 MAR 17
	DSC-22_46	Auto Flight - Print Interface	22 MAR 17
	DSC-23-10-10	Introduction	22 MAR 17
	DSC-23-10-20	Radio Tuning	22 MAR 17
	DSC-23-10-30	Intercommunication Systems	22 MAR 17
	DSC-23-10-40	Cockpit Voice Recorder	22 MAR 17
	DSC-23-10-50	Controls	22 MAR 17
	DSC-23-20-10	Flight Crew Interphone System	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-23-20-20	Cabin Interphone System	05 SEP 17
	DSC-23-20-30	Service Interphone System	05 SEP 17
	DSC-23-20-40	Passenger Address	05 SEP 17
	DSC-23-30-10	Radio Communication	05 SEP 17
	DSC-23-40-10	Emergency Evacuation	19 JUN 17
	DSC-23-40-30	Emergency Locator Transmitter	22 MAR 17
	DSC-23-50	Memo Display	05 SEP 17
	DSC-24-10-10	General	22 MAR 17
	DSC-24-10-20	Generation of Electrical Power	22 MAR 17
	DSC-24-10-30-10	General	22 MAR 17
	DSC-24-10-30-20	Normal Configuration	22 MAR 17
	DSC-24-10-30-30	Abnormal Configurations	22 MAR 17
	DSC-24-10-30-40	Distribution Table	22 MAR 17
	DSC-24-20	Controls and Indicators	22 MAR 17
	DSC-25-10-10	General	22 MAR 17
	DSC-25-10-20	Cockpit Plan	22 MAR 17
	DSC-25-10-30	Seats	22 MAR 17
	DSC-25-10-40	Main Instrument Panels	22 MAR 17
	DSC-25-10-50	Pedestal	22 MAR 17
	DSC-25-10-60	Overhead Panel	22 MAR 17
	DSC-25-10-70	C/B Panels	22 MAR 17
	DSC-25-10-80	Foot Warmer (If Installed)	22 MAR 17
	DSC-25-20	Emergency Equipment	22 MAR 17
	DSC-26-10	General	22 MAR 17
	DSC-26-20-10	System Description	05 SEP 17
	DSC-26-20-20	Controls and Indicators	22 MAR 17
	DSC-26-30-10	System Description	22 MAR 17
	DSC-26-30-20	Controls and Indicators	22 MAR 17
	DSC-26-40-10	System Description	22 MAR 17
	DSC-26-50-10	System Description	22 MAR 17
	DSC-26-50-20	Controls and Indicators	22 MAR 17
	DSC-27-10-10	General	22 MAR 17
	DSC-27-10-20	Architecture	22 MAR 17
	DSC-27-20-10-10	General	22 MAR 17
	DSC-27-20-10-20	Pitch Control	22 MAR 17
	DSC-27-20-10-30	Lateral Control	22 MAR 17
	DSC-27-20-10-50	Sideslip Target	22 MAR 17
	DSC-27-20-10-70	Aircraft Trimming	22 MAR 17
	DSC-27-20-20	Reconfiguration Control Laws	22 MAR 17

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-27-20-30	<b>Controls and Indicators</b>	22 MAR 17
	DSC-27-30-10	<b>Description</b>	22 MAR 17
	DSC-27-30-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-28-10-10	<b>General</b>	22 MAR 17
	DSC-28-10-20	<b>Tanks</b>	22 MAR 17
	DSC-28-10-30	<b>Engine Feed</b>	22 MAR 17
	DSC-28-10-50	<b>APU Feed</b>	22 MAR 17
	DSC-28-10-60	<b>Fuel Recirculation System</b>	22 MAR 17
	DSC-28-10-70	<b>Refueling and Defueling</b>	22 MAR 17
	DSC-28-10-80	<b>Fuel Quantity Indication and Level Sensing</b>	22 MAR 17
	DSC-28-10-90	<b>Fuel Tank Inerting System</b>	22 MAR 17
	DSC-28-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-29-10-10	<b>General</b>	22 MAR 17
	DSC-29-10-20	<b>Generation</b>	22 MAR 17
	DSC-29-10-30	<b>Distribution</b>	22 MAR 17
	DSC-29-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-30-10-10	<b>Description</b>	22 MAR 17
	DSC-30-20-10	<b>Description</b>	22 MAR 17
	DSC-30-20-20	<b>Controls And Indicators</b>	22 MAR 17
	DSC-30-30-10	<b>Description</b>	22 MAR 17
	DSC-30-30-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-30-40-10	<b>Description</b>	22 MAR 17
	DSC-30-40-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-30-50-10	<b>Description</b>	22 MAR 17
	DSC-30-50-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-30-60-10	<b>Description</b>	19 JUN 17
	DSC-30-60-20	<b>Controls and Indicators</b>	22 MAR 17
	DSC-30-70-10	<b>Description</b>	22 MAR 17
	DSC-31-05-10	<b>Introduction</b>	22 MAR 17
	DSC-31-05-20	<b>Cockpit Arrangement</b>	22 MAR 17
	DSC-31-05-30	<b>Architecture</b>	05 SEP 17
	DSC-31-05-40	<b>Controls and Switching</b>	22 MAR 17
	DSC-31-05-50	<b>Reconfiguring the DMC</b>	22 MAR 17
	DSC-31-05-60	<b>Reconfiguring DUs</b>	22 MAR 17
	DSC-31-10	<b>ECAM Description</b>	12 APR 17
	DSC-31-15	<b>Indications on E/WD</b>	22 MAR 17
	DSC-31-20	<b>Indications on SD</b>	22 MAR 17
	DSC-31-25-10	<b>General</b>	22 MAR 17
	DSC-31-25-20	<b>Example</b>	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-31-27	OEB Reminder	22 MAR 17
	DSC-31-30	ECAM Controls	05 SEP 17
	DSC-31-40	Indications on PFD	19 JUN 17
	DSC-31-45	Indications on ND	22 MAR 17
	DSC-31-50	EFIS Controls	22 MAR 17
	DSC-31-55-10	General	22 MAR 17
	DSC-31-55-20	Controls and Indicators	22 MAR 17
	DSC-31-60-10	Flight Data Recording System	22 MAR 17
	DSC-31-60-20	Controls and Indicators	22 MAR 17
	DSC-31-60-30	Aircraft Integrated Data System	22 MAR 17
	DSC-32-10-10	Description	22 MAR 17
	DSC-32-10-20	Landing Gear System/Interface	22 MAR 17
	DSC-32-10-30	Interactions between Landing Gear and Aircraft Systems	22 MAR 17
	DSC-32-10-40	Controls and Indicators	22 MAR 17
	DSC-32-20-10	Description	22 MAR 17
	DSC-32-20-20	Controls and Indicators	05 SEP 17
	DSC-32-30-10	Description	22 MAR 17
	DSC-32-30-20	Controls and Indicators	22 MAR 17
	DSC-33-10-10	General	22 MAR 17
	DSC-33-10-20	Description	22 MAR 17
	DSC-33-10-30	Controls and Indicators	22 MAR 17
	DSC-33-20-10	General	22 MAR 17
	DSC-33-20-20	Controls and Indicators	22 MAR 17
	DSC-33-30-10	Description	05 SEP 17
	DSC-33-30-20	Controls and Indicators	22 MAR 17
	DSC-33-40-10	Controls and Indicators	22 MAR 17
	DSC-34-NAV-10-10	Description	22 MAR 17
	DSC-34-NAV-10-20	Controls and Indicators	22 MAR 17
	DSC-34-NAV-15-10	Description	22 MAR 17
	DSC-34-NAV-20	Standby Instruments	22 MAR 17
	DSC-34-NAV-30-10	Tuning	22 MAR 17
	DSC-34-NAV-30-20	Nav aids	22 MAR 17
	DSC-34-NAV-30-30	Controls and Indicators	22 MAR 17
	DSC-34-NAV-40-10	Description	22 MAR 17
	DSC-34-SURV-10-10	Description	22 MAR 17
	DSC-34-SURV-10-20	Controls and Indicators	22 MAR 17
	DSC-34-SURV-30-10	Description	22 MAR 17
	DSC-34-SURV-30-20	Predictive Windshear System	22 MAR 17
	DSC-34-SURV-30-30	Controls and Indicators	22 MAR 17

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-34-SURV-40-10	Description	22 MAR 17
	DSC-34-SURV-40-20	GPWS Basics Modes	05 SEP 17
	DSC-34-SURV-40-35	Predictive GPWS Functions	22 MAR 17
	DSC-34-SURV-40-40	Controls and Indicators	19 JUN 17
	DSC-34-SURV-60-10	Description	22 MAR 17
	DSC-34-SURV-60-20	Controls and Indicators	22 MAR 17
	DSC-35-10	General	22 MAR 17
	DSC-35-20-10	Description	22 MAR 17
	DSC-35-20-20	Controls and Indicators	22 MAR 17
	DSC-35-30-10	Description	22 MAR 17
	DSC-35-30-20	Controls and Indicators	22 MAR 17
	DSC-35-40-10	Description	22 MAR 17
	DSC-36-10-10	General	22 MAR 17
	DSC-36-10-20	Engine Bleed System	22 MAR 17
	DSC-36-10-30	APU Bleed Air Supply	22 MAR 17
	DSC-36-10-40	Crossbleed	22 MAR 17
	DSC-36-10-50	Leak Detection	22 MAR 17
	DSC-36-10-60	Operation Following Failures	22 MAR 17
	DSC-36-20	Controls and Indicators	22 MAR 17
	DSC-38-10	Description	22 MAR 17
	DSC-45-10	Description	22 MAR 17
	DSC-45-20	System Operation	22 MAR 17
	DSC-45-25	Data Loading	22 MAR 17
	DSC-45-30	Printer	22 MAR 17
	DSC-46-10-10	General System Description	22 MAR 17
	DSC-46-10-20-10	General	22 MAR 17
	DSC-46-10-40-30	MCDU Datalink Pages	22 MAR 17
	DSC-46-10-40-40	MCDU Scratchpad Messages	22 MAR 17
	DSC-46-10-40-60	ECAM	22 MAR 17
	DSC-46-10-50	How To	22 MAR 17
	DSC-46-20-20	Applications	05 SEP 17
	DSC-46-30	Electronic QRH (eQRH)	22 MAR 17
	DSC-46-40-10	General	22 MAR 17
	DSC-46-40-20	In Seat Power Supply System	22 MAR 17
	DSC-46-40-30	Controls and Indicators	19 JUN 17
	DSC-49-10-10	General	22 MAR 17
	DSC-49-10-20	Main Components	22 MAR 17
	DSC-49-20	Controls and Indicators	22 MAR 17
	DSC-52-10-10	General	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	DSC-52-10-20	Passenger Doors	22 MAR 17
	DSC-52-10-30	Emergency Exits	22 MAR 17
	DSC-52-10-40	Cargo Doors	22 MAR 17
	DSC-52-10-50	Avionics Compartment Access Door	22 MAR 17
	DSC-52-10-60	Cockpit Door	22 MAR 17
	DSC-52-10-80	Escape Slides/Rafts	22 MAR 17
	DSC-52-20	Controls and Indicators	22 MAR 17
	DSC-52-40-10	Description	22 MAR 17
	DSC-52-40-20	Cockpit Door Locking System (CDLS)	22 MAR 17
	DSC-52-40-30	Cockpit Door Surveillance System (CDSS)	22 MAR 17
	DSC-52-50	How to	22 MAR 17
	DSC-56-10	General	22 MAR 17
	DSC-56-20	Fixed Windows	22 MAR 17
	DSC-56-30	Sliding Windows	22 MAR 17
	DSC-56-40	Description	22 MAR 17
	DSC-70-05	Overview	22 MAR 17
	DSC-70-10	System Description	22 MAR 17
	DSC-70-20	FADEC	22 MAR 17
	DSC-70-30-10	General	22 MAR 17
	DSC-70-30-20	Thrust Levers	22 MAR 17
	DSC-70-30-30	Thrust Rating Limit	22 MAR 17
	DSC-70-30-40	Thrust Control	22 MAR 17
	DSC-70-40	Fuel System (CFM56)	22 MAR 17
	DSC-70-50	Oil System	22 MAR 17
	DSC-70-60	Airbleed System (CFM56)	22 MAR 17
	DSC-70-70	Thrust Reverser System	22 MAR 17
	DSC-70-80-10	General	22 MAR 17
	DSC-70-80-20	Architecture	22 MAR 17
	DSC-70-80-30	Ignition System	22 MAR 17
	DSC-70-80-40	Engine Starting System	22 MAR 17
	DSC-70-90-10	Overhead Panel	22 MAR 17
	DSC-70-90-20	Pedestal	22 MAR 17
	DSC-70-90-30	Maintenance Panel	22 MAR 17
	DSC-70-90-40	Engine Display	05 SEP 17
	DSC-70-90-50	Memo Display	22 MAR 17
	PRO-PLP-LETDU	LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS	05 SEP 17
	PRO-ABN-ABN-00	INTRODUCTION	05 SEP 17
	PRO-ABN-ABN-ADV	[ADV] ECAM ADVISORY	05 SEP 17
	PRO-ABN-ABN-MEM	[MEM] MEMORY ITEMS	19 JUN 17

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PRO-ABN-ABN-QRH	<b>[QRH] PROCEDURES</b>	22 MAR 17
	PRO-ABN-ABN-RESET	<b>[RESET] SYSTEM RESET</b>	05 SEP 17
	PRO-ABN-A-ICE	<b>A-ICE</b>	22 MAR 17
	PRO-ABN-AIR	<b>AIR</b>	22 MAR 17
	PRO-ABN-APU	<b>APU</b>	22 MAR 17
	PRO-ABN-APUF	<b>APU FIRE</b>	22 MAR 17
	PRO-ABN-AUTO_FLT	<b>AUTO FLT</b>	19 JUN 17
	PRO-ABN-AVNCs	<b>AVIONICS SMOKE</b>	22 MAR 17
	PRO-ABN-BLEED	<b>BLEED</b>	22 MAR 17
	PRO-ABN-BRAKES	<b>BRAKES</b>	22 MAR 17
	PRO-ABN-NWS	<b>BRAKES-NWS</b>	22 MAR 17
	PRO-ABN-CAB_PR	<b>CAB PR</b>	22 MAR 17
	PRO-ABN-C_B	<b>C/B</b>	22 MAR 17
	PRO-ABN-COM	<b>COM</b>	22 MAR 17
	PRO-ABN-COND	<b>COND</b>	22 MAR 17
	PRO-ABN-CONFIG	<b>CONFIG</b>	12 APR 17
	PRO-ABN-DATALINK	<b>DATALINK</b>	22 MAR 17
	PRO-ABN-DOOR	<b>DOOR</b>	22 MAR 17
	PRO-ABN-EIS	<b>EIS</b>	22 MAR 17
	PRO-ABN-ELEC	<b>ELEC</b>	05 SEP 17
	PRO-ABN-ENG	<b>ENG</b>	05 SEP 17
	PRO-ABN-F_CTL	<b>F/CTL</b>	19 JUN 17
	PRO-ABN-FUEL	<b>FUEL</b>	22 MAR 17
	PRO-ABN-FWS	<b>FWS</b>	22 MAR 17
	PRO-ABN-HYD	<b>HYD</b>	05 SEP 17
	PRO-ABN-LG	<b>L/G</b>	05 SEP 17
	PRO-ABN-MISC	<b>MISC</b>	19 JUN 17
	PRO-ABN-NAV	<b>NAV</b>	19 JUN 17
	PRO-ABN-OVERSPEED	<b>OVERSPEED</b>	19 JUN 17
	PRO-ABN-RECORDER	<b>RECORDER</b>	22 MAR 17
	PRO-ABN-SMOKE	<b>SMOKE</b>	05 SEP 17
	PRO-ABN-SURV	<b>SURV</b>	22 MAR 17
	PRO-ABN-VENT	<b>VENT</b>	22 MAR 17
	PRO-ABN-WHEEL	<b>WHEEL</b>	22 MAR 17
	PRO-ABN-W_A_ICE	<b>WING A.ICE</b>	22 MAR 17
	PRO-ABN-90	<b>Detailed Cabin / Cockpit Evacuation Procedure</b>	05 SEP 17
	PRO-NOR-SOP-01	<b>General Information</b>	19 JUN 17
	PRO-NOR-SOP-02	<b>Flight Preparation</b>	22 MAR 17
	PRO-NOR-SOP-03	<b>Safety Exterior Inspection</b>	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PRO-NOR-SOP-04	<b>Preliminary Cockpit Preparation</b>	05 SEP 17
	PRO-NOR-SOP-05	<b>Exterior Walkaround</b>	05 SEP 17
	PRO-NOR-SOP-06	<b>Cockpit Preparation</b>	12 APR 17
	PRO-NOR-SOP-07	<b>Before Pushback or Start</b>	19 JUN 17
	PRO-NOR-SOP-08	<b>Engine Start</b>	05 SEP 17
	PRO-NOR-SOP-09	<b>After Start</b>	22 MAR 17
	PRO-NOR-SOP-10	<b>Taxi</b>	05 SEP 17
	PRO-NOR-SOP-11	<b>Before Takeoff</b>	22 MAR 17
	PRO-NOR-SOP-12	<b>Takeoff</b>	19 JUN 17
	PRO-NOR-SOP-13	<b>After Takeoff</b>	22 MAR 17
	PRO-NOR-SOP-14	<b>Climb</b>	22 MAR 17
	PRO-NOR-SOP-15	<b>Cruise</b>	22 MAR 17
	PRO-NOR-SOP-16	<b>Descent Preparation</b>	19 JUN 17
	PRO-NOR-SOP-17	<b>Descent</b>	05 SEP 17
	PRO-NOR-SOP-18-A	<b>Approach General</b>	22 MAR 17
	PRO-NOR-SOP-18-B	<b>Aircraft Configuration Management</b>	22 MAR 17
	PRO-NOR-SOP-18-C	<b>Aircraft Guidance Management</b>	05 SEP 17
	PRO-NOR-SOP-19	<b>Landing</b>	05 SEP 17
	PRO-NOR-SOP-20	<b>Go-Around</b>	22 MAR 17
	PRO-NOR-SOP-21	<b>After Landing</b>	05 SEP 17
	PRO-NOR-SOP-22	<b>Parking</b>	05 SEP 17
	PRO-NOR-SOP-23	<b>Securing the Aircraft</b>	19 JUN 17
	PRO-NOR-SOP-90	<b>Standard Callouts</b>	22 MAR 17
	PRO-NOR-SUP-SUP	<b>Supplementary Procedures Menu</b>	22 MAR 17
	PRO-NOR-SUP-ADVWXR	<b>Adverse Weather</b>	22 MAR 17
	PRO-NOR-SUP-COM	<b>Communication</b>	22 MAR 17
	PRO-NOR-SUP-ENG	<b>Engines</b>	19 JUN 17
	PRO-NOR-SUP-FUEL	<b>Fuel</b>	05 SEP 17
	PRO-NOR-SUP-LG-LG_DN	<b>Flight with Landing Gear Down</b>	05 SEP 17
	PRO-NOR-SUP-LG-LG	<b>Operation with Nosewheel Steering Offset</b>	05 SEP 17
	PRO-NOR-SUP-MISC-D	<b>Pushback with Power Push Unit</b>	22 MAR 17
	PRO-NOR-SUP-MISC-A	<b>High Altitude Airport Operations</b>	22 MAR 17
	PRO-NOR-SUP-MISC-C	<b>Operations at QNH Above 1050 hPa</b>	22 MAR 17
	PRO-NOR-SUP-NAV	<b>Navigation</b>	22 MAR 17
	PRO-NOR-SRP-01-05	<b>Introduction</b>	22 MAR 17
	PRO-NOR-SRP-01-10	<b>Cockpit Preparation</b>	22 MAR 17
	PRO-NOR-SRP-01-15	<b>Before Pushback or Start</b>	22 MAR 17
	PRO-NOR-SRP-01-20	<b>Taxi</b>	22 MAR 17
	PRO-NOR-SRP-01-30	<b>Takeoff</b>	22 MAR 17

*Continued on the following page*



*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PRO-NOR-SRP-01-40	<b>Climb</b>	22 MAR 17
	PRO-NOR-SRP-01-50	<b>Cruise</b>	22 MAR 17
	PRO-NOR-SRP-01-60	<b>Descent</b>	22 MAR 17
	PRO-NOR-SRP-01-70	<b>Approach</b>	22 MAR 17
	PRO-NOR-SRP-01-80	<b>Go-Around</b>	22 MAR 17
	PRO-SPO-20	<b>Flight Without Cabin Pressurization</b>	22 MAR 17
	PRO-SPO-40-10	<b>General</b>	22 MAR 17
	PRO-SPO-40-20	<b>Operational Limitations</b>	22 MAR 17
	PRO-SPO-40-30	<b>Dispatch Consideration</b>	22 MAR 17
	PRO-SPO-40-40	<b>Diversion During Extended Range Operations</b>	22 MAR 17
	PRO-SPO-40-50	<b>Procedures</b>	05 SEP 17
	PRO-SPO-40-60	<b>Performance</b>	22 MAR 17
	PRO-SPO-45	<b>Engine Intermix Operations</b>	19 JUN 17
	PRO-SPO-50	<b>Reduced Vertical Separation Minimum - RVSM</b>	22 MAR 17
	PRO-SPO-51	<b>Required Navigation Performance (RNP)</b>	05 SEP 17
	PRO-SPO-60	<b>Operations on Narrow Runways</b>	22 MAR 17
	PRO-SPO-85	<b>ILS PRM Approach</b>	22 MAR 17
	LIM-PLP-LETDU	<b>LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS</b>	22 MAR 17
	LIM-INT	<b>Introduction</b>	05 SEP 17
	LIM-AG-F_CTL	<b>Flight Maneuvering Load Acceleration Limits</b>	22 MAR 17
	LIM-AG-OPS	<b>Operational Parameters</b>	05 SEP 17
	LIM-AG-SPD	<b>Speeds</b>	22 MAR 17
	LIM-AG-WGHT	<b>Weights</b>	22 MAR 17
	LIM-AIR	<b>Air Bleed/Cond/Press/Vent</b>	22 MAR 17
	LIM-AFS-10	<b>General</b>	05 SEP 17
	LIM-AFS-20	<b>Automatic Approach, Landing and Rollout</b>	22 MAR 17
	LIM-APU	<b>Auxiliary Power Unit</b>	05 SEP 17
	LIM-CAB	<b>Cabin Systems</b>	22 MAR 17
	LIM-COM	<b>Communication</b>	19 JUN 17
	LIM-ENG	<b>Engines</b>	22 MAR 17
	LIM-F_CTL	<b>Flight Controls</b>	22 MAR 17
	LIM-FUEL	<b>Fuel</b>	22 MAR 17
	LIM-ICE_RAIN	<b>Ice and Rain Protection</b>	22 MAR 17
	LIM-LG	<b>Landing Gear</b>	19 JUN 17
	LIM-NAV	<b>Navigation</b>	22 MAR 17
	LIM-OXY	<b>Oxygen</b>	22 MAR 17
	LIM-SURV	<b>Surveillance</b>	22 MAR 17
	OEB-PLP-LETDU	<b>LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS</b>	17 OCT 17
R	OEB-PLP-LEOEB	<b>LIST OF EFFECTIVE OPERATIONS ENGINEERING BULLETIN</b>	17 OCT 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PER-PLP-LETDU	<b>LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS</b>	17 OCT 17
	PER-LOD-GEN	<b>GENERAL</b>	22 MAR 17
	PER-LOD-CGO	<b>CARGO LOADING</b>	22 MAR 17
	PER-LOD-FUL	<b>FUEL</b>	22 MAR 17
	PER-LOD-WBA-LTS	<b>LOAD AND TRIM SHEET</b>	22 MAR 17
	PER-LOD-WBA-FIT-10	<b>FUEL INDEX TABLE</b>	22 MAR 17
	PER-OPD-GEN	<b>GENERAL</b>	22 MAR 17
	PER-OPD-CON-AEO	<b>ALL ENGINES OPERATIVE</b>	22 MAR 17
	PER-OPD-CON-OEI	<b>ONE ENGINE INOPERATIVE</b>	22 MAR 17
	PER-THR-GEN	<b>GENERAL</b>	22 MAR 17
	PER-THR-MTO	<b>MAXIMUM TAKEOFF</b>	22 MAR 17
	PER-THR-MGA	<b>MAXIMUM GO AROUND</b>	22 MAR 17
	PER-THR-FLX	<b>FLEXIBLE TAKEOFF</b>	22 MAR 17
	PER-THR-MCT	<b>MAXIMUM CONTINUOUS</b>	22 MAR 17
	PER-THR-MCL	<b>MAXIMUM CLIMB</b>	22 MAR 17
	PER-THR-MCR	<b>MAXIMUM CRUISE</b>	22 MAR 17
	PER-TOF-THR-FLX-10	<b>DEFINITION OF FLEXIBLE TAKEOFF</b>	22 MAR 17
	PER-TOF-THR-FLX-20	<b>USE OF FLEXIBLE TAKEOFF</b>	22 MAR 17
	PER-TOF-THR-FLX-30	<b>REQUIREMENTS</b>	22 MAR 17
	PER-TOF-THR-FLX-40	<b>RECOMMENDATION</b>	22 MAR 17
	PER-TOF-TOC-05	<b>INTRODUCTION</b>	22 MAR 17
	PER-TOF-TOC-10-10	<b>TAKEOFF PERFORMANCE</b>	22 MAR 17
	PER-TOF-TOC-10-20	<b>TAKEOFF CHART DESCRIPTION</b>	22 MAR 17
	PER-TOF-TOC-10-30	<b>ADDITIONAL INFORMATION</b>	22 MAR 17
	PER-TOF-TOC-12-10	<b>DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS</b>	22 MAR 17
	PER-TOF-TOC-12-30	<b>EXTRAPOLATION</b>	22 MAR 17
	PER-TOF-TOC-12-40	<b>MAXIMUM STRUCTURAL TAKEOFF WEIGHT</b>	22 MAR 17
	PER-TOF-TOC-12-50	<b>SUMMARY</b>	22 MAR 17
	PER-TOF-TOC-14-10	<b>DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS</b>	22 MAR 17
	PER-TOF-TOC-14-20	<b>FLEXIBLE TAKEOFF NOT POSSIBLE</b>	22 MAR 17
	PER-TOF-TOC-14-25	<b>FLEXIBLE TAKEOFF POSSIBLE BUT NOT USED</b>	22 MAR 17
	PER-TOF-TOC-14-30	<b>SUMMARY</b>	22 MAR 17
	PER-TOF-TOC-16-10	<b>TAKEOFF PERFORMANCE</b>	22 MAR 17
	PER-TOF-TOC-16-20	<b>TAKEOFF CHART DESCRIPTION</b>	22 MAR 17
	PER-TOF-TOC-16-30	<b>ADDITIONAL INFORMATION</b>	22 MAR 17
	PER-TOF-TOC-18-10	<b>DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS</b>	22 MAR 17
	PER-TOF-TOC-18-20	<b>EXTRAPOLATION</b>	22 MAR 17

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PER-TOF-TOC-18-30	MAXIMUM STRUCTURAL TAKEOFF WEIGHT	22 MAR 17
	PER-TOF-TOC-18-40	SUMMARY	22 MAR 17
	PER-TOF-TOC-20-10	DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS	22 MAR 17
	PER-TOF-TOC-20-20	FLEXIBLE TAKEOFF NOT POSSIBLE	22 MAR 17
	PER-TOF-TOC-20-30	SUMMARY	22 MAR 17
	PER-TOF-TOD-24	QNH/BLEEDS CORRECTION	22 MAR 17
	PER-TOF-TOD-25-10	SPEEDS LIMITED BY VMCG/VMCA	22 MAR 17
	PER-TOF-TOD-25-20	V2 LIMITED BY VMU/VMCA	22 MAR 17
	PER-TOF-CTA-10	GENERAL	22 MAR 17
	PER-TOF-CTA-20	DEFINITIONS	22 MAR 17
	PER-TOF-CTA-30	OPERATIONAL CONDITIONS	22 MAR 17
	PER-TOF-CTA-40-10	TAKEOFF PERFORMANCE	22 MAR 17
	PER-TOF-CTA-40-20	TAKEOFF FROM A WET RUNWAY	22 MAR 17
	PER-TOF-CTA-40-30	TAKEOFF FROM A CONTAMINATED RUNWAY	22 MAR 17
	PER-TOF-CTA-40-40	EXAMPLE	22 MAR 17
	PER-FPL-GEN-MFR	MINIMUM RECOMMENDED FUEL REQUIREMENTS	22 MAR 17
	PER-FPL-GEN-FPL	FLIGHT PLAN	22 MAR 17
	PER-FPL-FLP-QFP-10	INTRODUCTION	22 MAR 17
	PER-FPL-FLP-QFP-20	CORRECTION FOR DEVIATION FROM REFERENCE LANDING WEIGHT	22 MAR 17
	PER-FPL-FLP-QFP-30	EXAMPLE	05 SEP 17
	PER-FPL-FLP-QFP-40	FLIGHT PLANNING AT A GIVEN MACH NUMBER	22 MAR 17
	PER-FPL-FLP-QFP-50	FLIGHT PLANNING AT LONG RANGE SPEED	22 MAR 17
	PER-FPL-FLP-ALN-20	ALL ENGINES OPERATIVE	22 MAR 17
	PER-CLB-GEN	GENERAL	22 MAR 17
	PER-CLB-CLT	CLIMB TABLES	22 MAR 17
	PER-CRZ-ALT-10	OPTIMUM AND MAXIMUM ALTITUDES	22 MAR 17
	PER-CRZ-ALT-20	WIND ALTITUDE TRADE FOR CONSTANT SPECIFIC RANGE	22 MAR 17
	PER-CRZ-CRT-10	GENERAL	22 MAR 17
	PER-CRZ-CRT-20	CRUISE AT M.78	22 MAR 17
	PER-CRZ-CRT-30	CRUISE AT LONG RANGE	22 MAR 17
	PER-CRZ-ICQ-10	GENERAL	22 MAR 17
	PER-CRZ-ICQ-20	EXAMPLE	22 MAR 17
	PER-HLD-GEN	GENERAL	22 MAR 17
	PER-HLD-HLD	HOLDING TABLES	22 MAR 17
	PER-DES-GEN	GENERAL	22 MAR 17
	PER-DES-STD	STANDARD	22 MAR 17
	PER-DES-EMG	EMERGENCY	22 MAR 17

*Continued on the following page*

**PRELIMINARY PAGES**  
**LIST OF EFFECTIVE SECTIONS/SUBSECTIONS**

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>Localization</b>	<b>Subsection Title</b>	<b>Rev. Date</b>
	PER-GOA-GEN	<b>GENERAL</b>	22 MAR 17
	PER-GOA-ACG-NOR	<b>NORMAL</b>	22 MAR 17
	PER-GOA-ACG-CAT	<b>CAT II</b>	22 MAR 17
	PER-LDG-GEN	<b>GENERAL</b>	19 JUN 17
	PER-LDG-CTA-10	<b>GENERAL</b>	22 MAR 17
	PER-LDG-CTA-20	<b>DEFINITIONS</b>	05 SEP 17
	PER-LDG-DIS-MAT	<b>Runway Condition Assessment Matrix for Landing</b>	22 MAR 17
	PER-LDG-DIS-RLD	<b>REQUIRED LANDING DISTANCES / MANUAL LANDING</b>	22 MAR 17
	PER-LDG-DIS-RLA	<b>REQUIRED LANDING DISTANCES</b>	22 MAR 17
	PER-OEI-GEN	<b>GENERAL</b>	22 MAR 17
	PER-OEI-ALT-10	<b>CEILINGS</b>	22 MAR 17
	PER-OEI-CRT-10	<b>STANDARD AND OBSTACLE STRATEGIES</b>	22 MAR 17
	PER-OEI-CRT-20	<b>FIXED SPEED STRATEGIES</b>	22 MAR 17
	PER-OEI-ICQ-10	<b>STANDARD STRATEGIES</b>	22 MAR 17
	PER-OEI-ICQ-20	<b>FIXED SPEED STRATEGIES</b>	22 MAR 17
	PER-OEI-HLD	<b>HOLDING</b>	22 MAR 17
	PER-OEI-DES-10	<b>STANDARD STRATEGY</b>	22 MAR 17
	PER-OEI-DES-15	<b>OBSTACLE STRATEGY</b>	22 MAR 17
	PER-OEI-DES-20	<b>FIXED SPEED STRATEGIES</b>	22 MAR 17
	PER-OEI-DES-30	<b>DESCENT TO LANDING</b>	22 MAR 17

(1) Evolution code : N=New, R=Revised, E=Effectivity, M=Moved

This table gives, for each delivered aircraft, the cross reference between:

- The Manufacturing Serial Number (MSN).
- The Fleet Serial Number (FSN) of the aircraft as known by AIRBUS S.A.S.
- The registration number of the aircraft as known by AIRBUS S.A.S.
- The aircraft model.

<b>M<sup>(1)</sup></b>	<b>MSN</b>	<b>FSN</b>	<b>Registration Number</b>	<b>Model</b>
	4547		HC-CJV	320-214

(1) Evolution code : N=New, R=Revised



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PRELIMINARY PAGES**  
**AIRCRAFT ALLOCATION TABLE**

Intentionally left blank

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	J0006		20 AUG 10	FUEL SYSTEM - ADDITIONAL TREATMENT OF CENTRE TANK STRUCTURE AND INSTALLATION OF CENTRE TANK SYSTEM
	<b>Applicable to: ALL</b>			
	J0012		20 AUG 10	NAVIGATION LIGHTS SYSTEM - INSTALLATION OF A SECOND NAVIGATION LIGHT SYSTEM
	<b>Applicable to: ALL</b>			
	J0022		20 AUG 10	INSTALLATION OF A FUEL QUANTITY SELECTOR IN THE FLIGHT COMPARTMENT
	<b>Applicable to: ALL</b>			
	J0071		20 AUG 10	WING STRUCTURE-INTRODUCTION OF A WING TIP INCORPORATING A TIP FENCE FOR 72T MTOW A/C
	<b>Applicable to: ALL</b>			
	J0664		20 AUG 10	FUEL SYSTEM-TO IMPROVE LOW LEVEL WARNING
	<b>Applicable to: ALL</b>			
	J0689		20 AUG 10	WING-TO DELETE L/E VENTILATION SYSTEM (PICCOLO TUBE)
	<b>Applicable to: ALL</b>			
	J1255		20 AUG 10	FUEL - TANK LEVEL SENSING - CHANGE TO LOW PRESSURE WARNING
	<b>Applicable to: ALL</b>			
	J1334		20 AUG 10	LANDING GEAR-MLG-LGCIU-INTRODUCTION OF A NEW STANDARD FOR IMPROVED PROXIMITY SENSOR FAULT MONITORING FUNCTION
	<b>Applicable to: ALL</b>			
	J1617		20 AUG 10	FLIGHT CONTROLS - GENERAL - DELETE LAF FEATURE FROM A320 DEFINITION (PRODUCTION SOLUTION)
	<b>Applicable to: ALL</b>			
	J2190		20 AUG 10	FUEL - MAIN FUEL PUMPS SYSTEMS - CENTRE TANK PUMPS AUTO FEED FAULT.ADAPT PUMP CONTROL LATCH FOR FLIGHT DECK REFUEL CABABILITY
	<b>Applicable to: ALL</b>			
	J2257		20 AUG 10	FUEL - MANUAL MAGNETIC INDICATORS - ATTITUDE MONITOR DELETION
	<b>Applicable to: ALL</b>			
	J2360		20 AUG 10	FUEL - QUANTITY INDICATION - INTRODUCE FUEL LEAK DETECTION ASSOCIATED WITH FQIC - 13 - 9
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	J2361		20 AUG 10	FUEL - QUANTITY INDICATION - REMOVAL OF FUEL LEAK DETECTION FUNCTION ASSOCIATED WITH THE FQIC 13 - 9
<b>Applicable to: ALL</b>				
	J2527		20 AUG 10	FUEL - QUANTITY INDICATING - INTRODUCE NEW STANDARD OF FUEL QTY INDICATING COMPUTER 13-10
<b>Applicable to: ALL</b>				
	J2662		15 FEB 13	FUEL - QUANTITY INDICATING - INTRODUCE NEW STANDARD OF FQIC (P/N SIC5059 14-20)
<b>Applicable to: ALL</b>				
	J2816		07 APR 11	WING - FIXED PARTITION - INTRODUCED A STANDARD OF BOX WITHOUT DRY BAY
<b>Applicable to: ALL</b>				
	J2963		07 APR 11	REDUCTION IN QUANTITY OF MAGNETIC LEVEL INDICATORS
<b>Applicable to: ALL</b>				
	K0024		20 AUG 10	INSTALLATION OF ADDITIONAL CARGO DOOR (BULK DOOR)
<b>Applicable to: ALL</b>				
	K0026		20 AUG 10	LIGHTS - LOGOLIGHTS - INSTALLATION OF LOGOLIGHTS SYSTEM
<b>Applicable to: ALL</b>				
	K0035		20 AUG 10	FIRE PROTECTION - FWD LOWER HOLD - INSTALLATION OF SMOKE DETECTION SYSTEM
<b>Applicable to: ALL</b>				
	K0036		20 AUG 10	FIRE PROTECTION - AFT LOWER HOLD - INSTALLATION OF SMOKE DETECTION SYSTEM
<b>Applicable to: ALL</b>				
	K0037		20 AUG 10	FIRE PROTECTION - FWD AND AFT LOWER HOLD INSTALLATION OF A SINGLE SHOT FIRE EXTINGUISHING SYSTEM
<b>Applicable to: ALL</b>				
	K0052		20 AUG 10	INSTALLATION OF AN AIDS
<b>Applicable to: ALL</b>				
	K0064		20 AUG 10	LIGHTS - INSTALLATION OF STROBE LIGHTS SYNCHRONISED MODE
<b>Applicable to: ALL</b>				
	K0066		20 AUG 10	AIR CONDITIONING - VENTILATION SYSTEM FOR FWD CARGO COMPARTMENT
<b>Applicable to: ALL</b>				

*Continued on the following page*



*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	K0082		20 AUG 10	WATER WASTE-INSTALL VACUUM TOILET SYSTEM
	<b>Applicable to: ALL</b>			
	K0151		20 AUG 10	EQUIPMENT FURNISHINGS ESCAPE FACILITIES INSTALL SLIDE RAFTS (AIRCROISERS)
	<b>Applicable to: ALL</b>			
	K10003		07 APR 11	AIRBORNE AUXILIARY POWER - CONTROL AND MONITORING INTRODUCE SOFTWARE VERSION 06.00.000
	<b>Applicable to: ALL</b>			
	K10009		20 AUG 10	EQUIPMENT/FURNISHINGS - CURTAINS AND PARTITIONS INTRODUCE IMPROVED STRIKES FOR COCKPIT DOOR
	<b>Applicable to: ALL</b>			
	K1014		20 AUG 10	WATER/WASTE-RELOCATION OF POT.WATER TANK FROM SECTION 18 TO SECTION 15 AND REDESIGN OF POT.WATERSYSTEM
	<b>Applicable to: ALL</b>			
	K10359		20 AUG 10	LIGHTS - EMERGENCY LIGHTING - DEFINE FLOOR MOUNTED LUFTHANSA TECHNIK 900 SERIES EEPMS
	<b>Applicable to: ALL</b>			
	K10463		25 NOV 11	AIR CONDITIONING PACK TEMPERATURE CONTROL INTRODUCE IMPROVED AIR CONDITIONING CONTROLLER P/N 1803B0000-02
	<b>Applicable to: ALL</b>			
	K10494		20 AUG 10	AIRBORNE AUXILIARY POWER - CHANGE STANDARD APU HONEYWELL GTCP36-300 TO APIC APS3200
	<b>Applicable to: ALL</b>			
	K11047		20 AUG 10	COMMUNICATION - ANTI HIJACK CAMERA MONITORING - INSTALL COCKPIT DOOR SURVEILLANCE SYSTEM DISPLAYEDON SD
	<b>Applicable to: ALL</b>			
	K1119		20 AUG 10	EQUIPMENT FURNISHINGS-C.C-REARRANGE COMPARTMENT 4 INTO TWO ZONES
	<b>Applicable to: ALL</b>			
	K11694		07 APR 11	EQUIPMENT/FURNISHINGS-MISCELLANEOUS EMERGENCY EQUIPMENT-INSTALLATION OF ELT(406AFN) WITH RCP IN COCKPIT AND NAV PROVISIONS-HONEYWELL
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	K12405		07 APR 11	COMMUNICATIONS-CIDS-INTRODUCE HANDSET SERIES N40A FROM VENDOR HOLMBERG
	<b>Applicable to: ALL</b>			
	K12824		20 OCT 11	COMMUNICATIONS - CIDS - INSTALL CIDS AND SDF OBRM SOFTWARE P/N -33A AND CAM UPDATE
	<b>Applicable to: ALL</b>			
	K12825		20 OCT 11	COMMUNICATIONS - CIDS - INSTALL CIDS DIRECTOR P/N -333B
	<b>Applicable to: ALL</b>			
	K13078		07 APR 11	OXYGEN - PASSENGER OXYGEN - INTRODUCE OPTIONAL CHEMICAL OXYGEN HYBRID CONTAINER 22 MIN (DAE SYSTEMS)
	<b>Applicable to: ALL</b>			
	K1420		20 AUG 10	DOORS-FWD/AFT CARGO DOOR-INTRODUCTION OF LOCKING INDICATION
	<b>Applicable to: ALL</b>			
	K1806		20 AUG 10	AIR CONDITIONING SYSTEM POWER SUPPLY - MODIFY POWER TO FLOW CONTROL VALVE
	<b>Applicable to: ALL</b>			
	K2335		20 AUG 10	LAVATORY SMOKE DETECTION - IMPROVEMENT OF SMOKE DETECTION
	<b>Applicable to: ALL</b>			
	K2393		20 AUG 10	AIR COND.-CABIN PRESSURE CONTROL-IMPROVE CONTROLLER TO ENABLE USE OF EXTERNAL MODE
	<b>Applicable to: ALL</b>			
	K2450		20 OCT 11	AUXILIARY POWER UNIT - INTRODUCTION OF APIC APS-3000
	<b>Applicable to: ALL</b>			
	K2938		20 AUG 10	DOORS - C.C.DOOR HYDRAULIC SYSTEM - INTRODUCE MODIFIED ELECTRICAL (MANUAL) SELECTOR VALVE -
	<b>Applicable to: ALL</b>			
	K2962		20 AUG 10	HYDRAULIC POWER - MAIN BLUE HYDRAULIC POWER - IMPROVE MAINTENACE STATUS OF BLUE HYDRAULIC RESERVOIR -
	<b>Applicable to: ALL</b>			
	K3118		20 AUG 10	AUXILIARY POWER UNIT - CONTROL AND MONITORING - INTRODUCTION OF NEW ECB P/N 304817-1
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	K3279		20 AUG 10	AUXILIARY POWER UNIT - CONTROL AND MONITORING - MODIFIED WIRE HARNESSSES TO NEW ECB
	<b>Applicable to: ALL</b>			
	K3471		20 AUG 10	GENERAL - INCREASE DESIGN WEIGHT TO 61T MZFW
	<b>Applicable to: ALL</b>			
	K3599		20 AUG 10	AIR CONDITIONING - COCKPIT AND CABIN TEMPERATURE CONTROL - INTRODUCE IMPROVED ZONE TEMPERATURE CONTROLLER -03
	<b>Applicable to: ALL</b>			
	K3901		20 AUG 10	COMMUNICATIONS - CIDS - MODIFICATION OF DIRECTOR POWER SUPPLY PRINCIPLE
	<b>Applicable to: ALL</b>			
	K4574		20 AUG 10	AIR CONDITIONING-FLOW CONTROL AND INDICATING- INTRODUCE IMPROVED AIR CONDITIONING PACKAGE FOR FLOW CONTROL
	<b>Applicable to: ALL</b>			
	K4725		06 JUL 16	DOORS - CARGO COMPARTMENT DOOR FWD AND AFT - MODIFY CARGO DOORS
	<b>Applicable to: ALL</b>			
	K4726		20 AUG 10	WATER/WASTE-TOILET SYSTEM-INTRODUCE IMPROVED TOILET ASSY
	<b>Applicable to: ALL</b>			
	K4787		20 AUG 10	LIGHTS - INTRODUCTION OF A COMMON EPSU
	<b>Applicable to: ALL</b>			
	K4793		20 AUG 10	AIR CONDITIONING-AIR COOLING SYSTEM-INTRODUCE AN IMPROVED RAM OUTLET (RAO)
	<b>Applicable to: ALL</b>			
	K4913		20 AUG 10	HYDRAULIC POWER - AUXILIARY HYDRAULIC POWER - INSTALL A319 RAM AIR TURBINE ON A320
	<b>Applicable to: ALL</b>			
	K5157		20 AUG 10	OXYGEN-PASSENGER OXYGEN-INTRODUCE IMPROVED OPTIONAL CHEMICAL OXYGEN CONTAINER (22 MIN) TO REPLACE "HIGH FLOW" CONTAINER
	<b>Applicable to: ALL</b>			
	K5213		20 AUG 10	AIR CONDITIONING - PACK TEMPERATURE CONTROL - INTRODUCE IMPROVED PACK TEMPERATURE CONTROLLER
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	K5446		20 AUG 10	INDICATING/RECORDING SYSTEMS - INSTALLATION OF A COMBINED FDIU/DMU
<b>Applicable to: ALL</b>				
	K5549		20 AUG 10	OXYGEN - PASSENGER OXYGEN - INTRODUCE CHEMICAL OXYGEN CONTAINER (15MIN) WITH IMPROVED ACTUATOR (VENDOR PURITAN)
<b>Applicable to: ALL</b>				
	K5801		20 AUG 10	AIR CONDITIONING-PRESSURE CONTROL AND MONITORING- INTRODUCE MODIFIED PRESSURE CONTROLLER P/N 9022-15702-10
<b>Applicable to: ALL</b>				
	K6156		20 AUG 10	AIR CONDITIONING-PACK TEMPERATURE CONTROL- INTRODUCE MODIFIED PACK TEMPERATURE CONTROLLER
<b>Applicable to: ALL</b>				
	K6164		20 AUG 10	GENERAL-INCREASE A320 DESIGN WEIGHTS TO 77,0T MTOW; 66,0T MLW AND 62.5T MZFW
<b>Applicable to: ALL</b>				
	K6318		20 OCT 11	APU-CONTROL AND MONITORING-INTRODUCE APIC ECB SOFTWARE VERSION 5
<b>Applicable to: ALL</b>				
	K6443		20 AUG 10	AIR CONDITIONING_AIR COOLING INSTALL A NEW ECS
<b>Applicable to: ALL</b>				
	K6936		20 AUG 10	AUXILIARY POWER UNIT (APU)-GENERAL- INCREASE OPERATION ENVELOPE TO 39800 FT. FOR GTC36-300
<b>Applicable to: ALL</b>				
	K7072		20 AUG 10	LIGHTS-EMERGENCY LIGHTING- EPSU LOAD DISTRIBUTION IMPROVEMENT
<b>Applicable to: ALL</b>				
	K7755		20 AUG 10	EQUIPMENT/FURNISHINGS PAX COMPARTMENT INTRODUCE A MODIFIED INTRUSION AND PENETRATION RESISTANCE COCKPIT DOOR
<b>Applicable to: ALL</b>				
	K7790		20 AUG 10	DOORS PASSENGER COMPARTMENT FIXED PARTITIONS INTERIOR DOOR-ELECTRICAL COCKPIT DOOR RELEASE SYSTEM
<b>Applicable to: ALL</b>				
	K7847		25 NOV 11	EQUIPMENT/FURNISHINGS PASSENGER COMPARTMENT DEFINITION OF A PED POWER

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
				SUPPLY SYSTEM PROVIDING 110/60 HZ FROM VENDOR THALES
	<b>Applicable to: ALL</b>			
	K8400		20 AUG 10	COMMUNICATIONS CABIN INTERCOMMUNICATION MODIFY CABIN INTERCOMMUNICATION DATA SYSTEM ON A319
	<b>Applicable to: ALL</b>			
	K8734		25 NOV 11	AIR CONDITIONING - AIR COOLING ADAPT A318 ECS TO A320
	<b>Applicable to: ALL</b>			
	K8905		20 AUG 10	EQUIPMENT/FURNISHINGS -CURTAINS AND PAR INSTALL A DEADBOLT FOR THE REINFORCED COCKPIT DOOR
	<b>Applicable to: ALL</b>			
	K9458		25 NOV 11	AIR CONDITIONING - PACK TEMPERATURE CONTROL IMPROVED AIR CONDITIONING SYSTEM CONTROLLER P/N 1803B0000-01
	<b>Applicable to: ALL</b>			
	K9473		20 AUG 10	AIR CONDITIONING-PRESSURE CONTROL AND MONITORING-INTRODUCE RESIDUAL PRESSURE CONTROL UNIT (RPCU)
	<b>Applicable to: ALL</b>			
	K9877		20 AUG 10	EQUIPMENT / FURNISHINGS - CURTAINS AND PARTITIONS - MODIFY DEADBOLT FOR REFORCED COCKPIT DOOR
	<b>Applicable to: ALL</b>			
	P0033		07 APR 11	COMMUNICATIONS - HF1 SYSTEM PROVISION FOR HF1 SYSTEM
	<b>Applicable to: ALL</b>			
	P0034		07 APR 11	SINGLE HF SYSTEM
	<b>Applicable to: ALL</b>			
	P0040		20 AUG 10	4TH OCCUPANT SEAT
	<b>Applicable to: ALL</b>			
	P0091		20 AUG 10	ALTERNATIVE FLIGHT CREW OXYGEN BOTTLE (77.1CU/FT) IN COMPOSITE MATERIAL FOR FIXED SYSTEM
	<b>Applicable to: ALL</b>			
	P0143		20 AUG 10	COMMUNICATIONS - INSTALLATION OF A 3RD RMP
	<b>Applicable to: ALL</b>			
	P0147		20 AUG 10	DESIGN WEIGHT-MTOW 72T-STRUCTURAL REINFORCEMENT
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P0197	23-1365 15	07 APR 11	COMMUNICATIONS-SINGLE HF SYSTEM INSTALLATION
<b>Applicable to: ALL</b>				
	P0287		07 APR 11	NAVIGATION-REPLACE EXISTING VOR DDRMI WITH A COMBINED VOR ADF DDRMI COLLINS
<b>Applicable to: ALL</b>				
	P0415		20 AUG 10	COMMUNICATIONS-HOT MIKE RECORDING
<b>Applicable to: ALL</b>				
	P10022		07 APR 11	ENGINE FUEL AND CONTROL FADEC SYSTEM INTRODUCE NEW "5BO" ECU SOFTWARE STD ON CFM56-5B ENGINES - CNF CFM 109B -
<b>Applicable to: ALL</b>				
	P10098	24-1120 04	20 AUG 10	ELECTRICAL POWER AC ESSENTIAL GENERATION SWITCHING INSTALL AUTO SWITCHING SYSTEM FOR AC&DC ESS BUS.
<b>Applicable to: ALL</b>				
	P10267		20 AUG 10	NAVIGATION - RADIO MAGNETIC INFORMATION SWITCHING AND INDICATING : RE-INSTALL THALES DDRMI VOR/DME INDICATORS (ANTI-MOD 33503)
<b>Applicable to: ALL</b>				
	P10321	22-1289 01	07 APR 11	AUTO-FLIGHT - GENERAL - REMOVE AFM LIMITATION ON NON PRECISION APPROACHES WITH ONE ENGINE OUT
<b>Applicable to: ALL</b>				
	P10383	31-1334 04 31-1414 03	20 AUG 10	INDICATING/RECORDING SYSTEMS FLIGHT WARNING COMPUTER (FWC) INSTALL FWC STANDARD H2-F5
<b>Applicable to: ALL</b>				
	P10439	22-1248 01	20 AUG 10	AUTO-FLIGHT FMGC INSTALL FMGC HNWL STD P1C12 ON CFM A/C
<b>Applicable to: ALL</b>				
	P10443	27-1182 04	07 APR 11	FLIGHT CONTROL - ELAC SYSTEM - INTRODUCE ELAC "L93" SOFTWARE STANDARD
<b>Applicable to: ALL</b>				
	P10493		07 APR 11	FLIGHT CONTROL - ELAC - ACTIVATE HIGH ALTITUDE UPSETS VMO/MMO OVERSHOOT PROTECTION FUNCTION ON ELAC
<b>Applicable to: ALL</b>				
	P10527	31-1433 01	20 AUG 10	INDICATING/RECORDING SYSTEM - ELECTRONIC INSTRUMENT SYSTEM (EIS)- INSTALL DISPLAY MANAGEMENT COMP. SOFTW. EIS2 S8-1
<b>Applicable to: ALL</b>				

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P10660		01 DEC 15	NAVIGATION - ADIRU - INSTALL HONEYWELL ADIRU BLOCK III STANDARD L3.5
	<b>Applicable to: ALL</b>			
	P10686	22-1266 03	07 APR 11	AUTO-FLIGHT - FMGC INSTALL HONEYWELL PERFORMANCE DATABASE RELEASE 1A (PS4087592-901)
	<b>Applicable to: ALL</b>			
	P10694	22-1296 06	20 AUG 10	AUTO-FLIGHT - FMGC ACTIVATE "MOD NAV IN GO AROUND" ON FMGC
	<b>Applicable to: ALL</b>			
	P10762	22-1269 05	20 AUG 10	AUTO FLIGHT - FMGC INSTALL FMGC HWL H2C12 (RELEASE 1A) ON CFM A/C
	<b>Applicable to: ALL</b>			
	P11146		07 APR 11	LANDING GEAR - PARKING/ULTIMATE EMERGENCY BRAKING ACTIVATE PARKING BRAKE MONITORING FUNCTION ON SA A/C
	<b>Applicable to: ALL</b>			
	P11325	73-1095 02	18 MAR 15	ENGINE FUEL AND CONTROL - FADEC SYSTEM INTRODUCE ECU SOFTWARE STANDARD "5BR" ON CFM56-5B ENGINES
	<b>Applicable to: ALL</b>			
	P11473	22-1315 05	22 MAR 16	AUTO FLIGHT - FLIGHT MANAGEMENT SYSTEM (FMS) ACTIVE BARO RADIO SETTING FUNCTION
	<b>Applicable to: ALL</b>			
	P11620		07 APR 11	INDICATING/RECORDING SYSTEMS - FWC - ACQUISITION/INTERFACE - ACTIVATE MONITORING OF ATC / XPDR
	<b>Applicable to: ALL</b>			
	P11744		07 APR 11	FLIGHT CONTROLS - SEC SYSTEM - INTRODUCE NEW SPOILER ELEVATOR COMPUTER (SEC) SOFTWARE STD 120 WITH HARD B'
	<b>Applicable to: ALL</b>			
	P11807	31-1433 01	31 JUL 14	INDICATING/RECORDING SYSTEM ELECTRONIC INSTRUMENT SYSTEM (EIS) INSTALL NEW EIS2 SOFTWARE S9
	<b>Applicable to: ALL</b>			
	P11856	22-1315 05	07 APR 11	AUTO - FLIGHT FMGC: ACTIVATE NO AP DISCONNECTION BELOW MDA/MDH UNTIL MISSED APPROACH POINT
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P1237		20 AUG 10	INDICATING RECORDING SYSTEM-TOGGLE SWITCHES RELOCATED IN 25VU ON OVERHEAD PANEL
	<b>Applicable to: ALL</b>			
	P1302		20 AUG 10	LANDING GEAR-POST EIS STANDARD 4 OF BSCU EQUIPMENT
	<b>Applicable to: ALL</b>			
	P1312		07 APR 11	LIGHTS-COCKPIT-INTEGRALLY LIGHTED PLACARD 25VU,ANTI ICE PART MODIFIED
	<b>Applicable to: ALL</b>			
	P1390		20 AUG 10	ELECTRICAL GENERATION-BCL'S CHANGE
	<b>Applicable to: ALL</b>			
	P1450		20 AUG 10	NAVIGATION - ATC MODE "S" - ACTIVATION OF SELECTIVE INTERROGATION FUNCTION
	<b>Applicable to: ALL</b>			
	P1485		20 AUG 10	ELECTRICAL POWER-"BAT OFF"INDICATOR LIGHT POWER SOURCE MODIFIED
	<b>Applicable to: ALL</b>			
	P1631		20 AUG 10	NAVIGATION - MODIFY GPWC WARNINGS
	<b>Applicable to: ALL</b>			
	P1669		20 AUG 10	AIR CONDITIONING-AVIONICS VENTILATION ADD A NON RETURN VALVE AT AIR INLET
	<b>Applicable to: ALL</b>			
	P1752		20 AUG 10	HYDRAULICS-MODIFICATION OF ELECTRICAL ROUTING OF GREEN LEAKAGE MEASUREMENT ELECTROVALVE CONTROL
	<b>Applicable to: ALL</b>			
	P1850		20 AUG 10	FLIGHT CONTROLS-ELAC SYSTEM-EFCS ELAC -SOFTWARE L62
	<b>Applicable to: ALL</b>			
	P1873		20 AUG 10	AIR CONDITIONING-ESSENTIAL DC SUPPLY FOR FORWARD CARGO COMPARTMENT SHUT-OFF VALVES
	<b>Applicable to: ALL</b>			
	P1883		20 AUG 10	FLIGHT CONTROLS-FCDC L 40
	<b>Applicable to: ALL</b>			
	P1906		20 AUG 10	ENGINES FUEL AND CONTROL-EIU FOR CFMI POWERPLANT (SOFTWARE VERSION 11)
	<b>Applicable to: ALL</b>			
	P1970	23-1365 15	20 AUG 10	COMMUNICATIONS-INSTALL HF1 IN EMERGENCY CONFIG. (ETOPS)
	<b>Applicable to: ALL</b>			

*Continued on the following page*



*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P2040		20 AUG 10	OXYGENE-COCKPIT-MODIFY LP VALVE
	<b>Applicable to: ALL</b>			
	P2196		20 AUG 10	BATCH OF MINOR IMPROVEMENTS OF SERIES A/C DESIGN (AS ZONE) FROM A/C N 268
	<b>Applicable to: ALL</b>			
	P2205		20 AUG 10	FIRE PROTECTION - REPLACE ENGINE/APU FIRE PANEL
	<b>Applicable to: ALL</b>			
	P2218		20 AUG 10	NAVIGATION - TCAS II COMPLETE PROVISIONS
	<b>Applicable to: ALL</b>			
	P2223		20 AUG 10	NAVIGATION - INSTALLATION OF GPWC MARK V WITH INTERFACE WITH CFDS
	<b>Applicable to: ALL</b>			
	P2294		20 AUG 10	ENGINE FUEL AND CONTROL - CFM 56 POWERPLANT EIU VERSION 12
	<b>Applicable to: ALL</b>			
	P2316		20 AUG 10	AUTOFLIGHT - ACTIVATE WINDSHEAR FUNCTION
	<b>Applicable to: ALL</b>			
	P2493		20 AUG 10	COCKPIT - INSTALL A340 TYPE PILOT SEATS
	<b>Applicable to: ALL</b>			
	P2546		20 AUG 10	INDICATING/RECORDING SYSTEMS - INSTRUMENTS - DEFINE SDAC STANDARD FOR A321 COF A
	<b>Applicable to: ALL</b>			
	P2547		07 APR 11	INDICATING/RECORDING SYSTEMS - INSTRUMENTS - DEFINE DMC STANDARD FOR A321 COF A
	<b>Applicable to: ALL</b>			
	P2588		20 AUG 10	OXYGEN - COCKPIT - REPLACE BASIC AIR LIQUIDE PBE BY DRAEGER
	<b>Applicable to: ALL</b>			
	P2590		20 AUG 10	NAVIGATION - INSTALL A TCAS II COLLISION AVOIDANCE SYSTEM
	<b>Applicable to: ALL</b>			
	P2879		20 AUG 10	INDICATING RECORDING SYSTEM - SDAC - DEFINE A PIN PROGRAM FOR FWD C.C VENTILATION
	<b>Applicable to: ALL</b>			
	P2960		20 AUG 10	CERTIFICATION DOCUMENTS - GENERAL - CERTIFICATION FOR TAKING OFF WITH 15 KNOT TAILWING
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P2963		20 AUG 10	AIR CONDITIONING - IMPROVE CABIN PRESSURIZATION CONTROL ON 25VU -
	<b>Applicable to: ALL</b>			
	P3004		20 AUG 10	LIGHTS-COCKPIT LIGHTING-IMPROVE COCKPIT LIGHTING
	<b>Applicable to: ALL</b>			
	P3011		20 AUG 10	FMS - FMS CROSS LOAD
	<b>Applicable to: ALL</b>			
	P3044		20 AUG 10	NAVIGATION - ADAPT SHELVES FOR INSTALLATION OF 4MCUADIRS -
	<b>Applicable to: ALL</b>			
	P3102		20 AUG 10	AUTO FLIGHT - FCU-CPIP1 STANDARD
	<b>Applicable to: ALL</b>			
	P3105		20 AUG 10	ENGINE FUEL AND CONTROL - CFM 56 - EIU VERSION 13
	<b>Applicable to: ALL</b>			
	P3197		20 AUG 10	GENERAL - OPERATION FROM HIGH ALTITUDE AIRPORTS (CFM ENGINES) (PRESSURE ALTITUDE LIMIT 9200 FT)
	<b>Applicable to: ALL</b>			
	P3202		20 AUG 10	AUTOFLIGHT - FCU - CPIP 2 STANDARD M10
	<b>Applicable to: ALL</b>			
	P3204		20 AUG 10	AUTO FLIGHT - FMGC - A320/A321 STANDARD WITH SOFTWARE OPTIONS + 400 KILOWORDS DATA BASE OPTION + ACARS HARDWARE PROVISION (B1 CFM VERSION)
	<b>Applicable to: ALL</b>			
	P3365		20 AUG 10	ICE PROTECTION - ICING INDICATOR ILLUMINATION
	<b>Applicable to: ALL</b>			
	P3379		20 AUG 10	INDICATING/RECORDING SYSTEMS - GENERAL - DEFINE PIN PROGRAMMING FOR STD VERSIONS
	<b>Applicable to: ALL</b>			
	P3420		22 MAR 16	A320/321 ENERGY MANAGEMENT FUNCTIONS - ACTIVATION BY PIN PROGRAMMING FOR IAE AND CFM ENGINES
	<b>Applicable to: ALL</b>			
	P3510		20 AUG 10	NAVIGATION - ADIRS - IMPROVED STANDARD OF A320 ADIRU
	<b>Applicable to: ALL</b>			
	P3511		20 AUG 10	AUTO FLIGHT - FLIGHT AUGMENTATION - AFS COMPUTER A320/A321 FAC CFM/IAE
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P3524		20 AUG 10	ELECTRICAL GENERATION - APU GENERATOR NEW STANDARD
	<b>Applicable to: ALL</b>			
	P3588		20 AUG 10	LANDING GEAR - A320/A321 TWIN WHEELS BSCU STANDARD 7 (70B VERSION)
	<b>Applicable to: ALL</b>			
	P3594		20 AUG 10	INDICATING/RECORDING SYSTEMS - ELECTRICAL CLOCK - INSTALLATION OF A CLOCK SMITHS TYPE 2610
	<b>Applicable to: ALL</b>			
	P3660		20 AUG 10	FLIGHT CONTROLS - EFCS EQUIPMENT - MODIFY SEC STANDARD FOR A320 AND A321
	<b>Applicable to: ALL</b>			
	P3686		20 AUG 10	AUTO FLIGHT: FLIGHT AUGMENTATION COMPUTER INTRODUCE FAC POST CDN ON A320/321.
	<b>Applicable to: ALL</b>			
	P3694		20 OCT 11	AUTO FLIGHT-FMGC-A320/321-FG STANDARD FOR A321 CFM CAT III
	<b>Applicable to: ALL</b>			
	P3756		20 AUG 10	AUTO FLIGHT - GENERAL - EXTEND CAT III B AUTOMATICLANDING CAPABILITY (FOR CFM ENGINES)
	<b>Applicable to: ALL</b>			
	P3790		20 AUG 10	NAVIGATION-AIRS-IMPROVED STANDARD OF HONEYWELL 4 MCU ADIRU
	<b>Applicable to: ALL</b>			
	P3830		20 AUG 10	FLIGHT CONTROLS-PARTIAL LIFT DUMPING FUNCTION ACTIVATION
	<b>Applicable to: ALL</b>			
	P3878		20 AUG 10	FLIGHT CONTROL-ELAC SYSTEM-INSTALL ELAC 69J
	<b>Applicable to: ALL</b>			
	P3955		07 APR 11	NACELLES/PYLONS-IAE/CFM-ADAPT PYLON PRIMARY STRUCTURE FOR A321 GROWTH VERSION
	<b>Applicable to: ALL</b>			
	P3957		06 JUL 16	ATA 2900 HYDRAULIC POWER-GENERAL INSTALL AN HYDRAULIC SHUT-OFF VALVE ON THE CFM THRUST REVERSER SYSTEM
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P3964		20 AUG 10	NAVIGATION-WEATHER RADAR SYSTEM-NEW SEXTANT ATC/TCAS CONTROL PANEL -SFE WITH FULL TIME AND ABOVE BELOW FUNCTIONS
	<b>Applicable to: ALL</b>			
	P4023	35-1025 07	20 AUG 10	GENERAL - HIGH ALTITUDE CERTIFICATION UP TO 14.500 FT
	<b>Applicable to: ALL</b>			
	P4054		20 AUG 10	AUTOFLIGHT-FCU-INSTALL M11 STANDARD
	<b>Applicable to: ALL</b>			
	P4087		20 AUG 10	NAVIGATION-ADIRS-INSTALL HONEYWELL ADIRS PROVIDING THE GPS PRIMARY NAVIGATION CAPABILITY
	<b>Applicable to: ALL</b>			
	P4089		20 AUG 10	AUTO-FLIGHT - FMGC - REDUCE VAPP FOR A320 CFM/IAE
	<b>Applicable to: ALL</b>			
	P4121		20 AUG 10	EXHAUST - THRUST REVERSER CONTROL AND INDICATING -ACTIVATE ADDITIONAL THRUST REVERSER LOCK CONTROL
	<b>Applicable to: ALL</b>			
	P4151		20 AUG 10	INDICATING/RECORDING SYSTEMS - UP AND DOWN DATA LOADING SYSTEM - INSTALL A "PORTABLE DATA LOADER" CONNECTOR AND DISK STOWAGE.
	<b>Applicable to: ALL</b>			
	P4155		20 AUG 10	AUTOFLIGHT - FLIGHT MANAGEMENT AND GUIDANCE COMPUTER - ACTIVATION OF ACARS AND PRINTER INTERFACES IN F.M.S ( CFM ENGINES)
	<b>Applicable to: ALL</b>			
	P4170		20 AUG 10	FLIGHT CONTROLS - FCDC - PROVIDE A VISUAL INDICATION FOR SIMULTANEOUS SIDE STICK ACTION
	<b>Applicable to: ALL</b>			
	P4191		20 AUG 10	NAVIGATION AND COMMUNICATIONS REPLACE BFE EQUIPMENT BY SFE EQUIPMENT
	<b>Applicable to: ALL</b>			
	P4205		20 AUG 10	AUTOFLIGHT - FMGC - ACTIVATE PRINTER INTERFACE IN FMS (CFM AND IAE ENGINES)
	<b>Applicable to: ALL</b>			
	P4230		20 AUG 10	POWER PLANT-GENERAL INTRODUCTION OF CFM56-5B/P
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P4234		20 AUG 10	ICE AND RAIN PROTECTION-WINDSHIELD RAIN PROTECTION DESACTIVATION OF RAIN REPELLENT SYSTEM.
	<b>Applicable to: ALL</b>			
	P4281		20 AUG 10	ENGINE FUEL AND CONTROL-CONTROLLING INTRODUCE OF A NEW ECU SOFTWARE STANDARD 5BE-1 FOR CFM56-5B SAC ENGINES
	<b>Applicable to: ALL</b>			
	P4287	31-1264 04	20 AUG 10	INDICATING-RECORDING SYSTEM FWC DEFINE OEB REMINDER NEW FUNCTION IN FWC
	<b>Applicable to: ALL</b>			
	P4319		20 AUG 10	AUTO FLIGHT/FCU DEFINE FD ENGAGEMENT IN CROSSED BARS AT GO AROUND
	<b>Applicable to: ALL</b>			
	P4320		20 AUG 10	AUTO FLIGHT - ACTIVATE GLOBAL SPEED PROTECTION AND FD DISENGAGEMENT UPON SPEED CONDITIONS
	<b>Applicable to: ALL</b>			
	P4378	00-1054 19	20 AUG 10	CERTIFICATION - GENERAL - CERTIFICATION FOR HIGH ALTITUDE AIRPORT OPERATION
	<b>Applicable to: ALL</b>			
	P4395		20 AUG 10	INDICATING/RECORDING SYSTEMS.EIS.UNITS OF UNITS OF INDICATION "RUNWAY LENGHTS"IN FEET.
	<b>Applicable to: ALL</b>			
	P4419		25 NOV 11	NAVIGATION - ADIRS - INSTALL HONEYWELL ADIRU 4 MCU STANDARD WITH OPTIMIZED HARDWARE P/N "AD09"
	<b>Applicable to: ALL</b>			
	P4425		25 NOV 11	NAVIGATION-ADIRS-INSTALL HONEYWELL ADIRU 4 MCU STANDARD, CAPABLE OF A319 IAE AIRCRAFT
	<b>Applicable to: ALL</b>			
	P4495		20 AUG 10	INDICATING/RECORDING SYSTEMS- DISPLAY MANAGEMENT COMPUTER (DMC) DEFINE DMC V32 STANDARD
	<b>Applicable to: ALL</b>			
	P4497		20 AUG 10	DOORS-EMERGENCY ESCAPE SLIDE RELEASE AND OVERPRESSURE WARNING SYSTEMS-MODIFY CONTROL LOGIC OF THE OVERPRESSURE WARING SYSTEM
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P4502		20 AUG 10	INFORMATION SYSTEMS - ATIMS - INSTALL ATSU COMPUTER FOR PRE-FANS CONFIGURATION
<b>Applicable to: ALL</b>				
	P4528		20 AUG 10	ENGINE FUEL AND CONTROL -CONTROLLING-INTRODUCE AN ECU SOFTWARE STD 5BH FOR CFM56-5B SAC ENGINES.
<b>Applicable to: ALL</b>				
	P4539		20 AUG 10	AUTO FLIGHT-GENERAL/FLIGHT CONTROL UNIT-DEFINE AND INSTALL SEXTANT MODULAR FCU
<b>Applicable to: ALL</b>				
	P4576		20 AUG 10	LANDING GEAR-GENERAL WHEELS AND BRAKES EQUIPMENT COST REDUCTION ELECTRICAL ALTERNATE BRAKING
<b>Applicable to: ALL</b>				
	P4647		20 AUG 10	NAVIGATION - WEATHER RADAR SYSTEM - COLLINS DUAL PWS ACTIVATOR
<b>Applicable to: ALL</b>				
	P4706		22 MAR 16	NAVIGATION - ADF - INSTALLATION OF 1 ADF QUANTUM LINE P/N 066-50014-0202
<b>Applicable to: ALL</b>				
	P4709	00-1043 56	20 AUG 10	LANDING WITH A 15 KNOT TAILWIND
<b>Applicable to: ALL</b>				
	P4770		20 AUG 10	NAVIGATION - WEATHER RADAR SYSTEM. INSTALL FULL PROVISION FOR THE SECOND TRANSCEIVER.
<b>Applicable to: ALL</b>				
	P4773		20 AUG 10	NAVIGATION - INSTALL DUAL COLLINS ADF 700 - P/N 622-5222-020
<b>Applicable to: ALL</b>				
	P4786		07 APR 11	COCKPIT PROTECTIVE BREATHING EQUIPMENT (PBE)-SCOTT AVIATION
<b>Applicable to: ALL</b>				
	P4789		20 AUG 10	NAVIGATION-MMR-INSTALLATION OF SEXTANT MULTICI-MODE RECEIVERS PROVIDING ILS (FM IMMUNE) AND GPS PRIMARY FUNCTION
<b>Applicable to: ALL</b>				
	P4801		20 AUG 10	ELECTRICAL POWER - GENERATION SYSTEM - DEFINE AND INSTALL ON A320 FAMILY NEW ELECTRICAL GENERATION CONCEPT (WIRING/EQUIPMENT)
<b>Applicable to: ALL</b>				

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P4808		20 AUG 10	LANDING GEAR - GENERAL - WHEELS AND BRAKES - EQUIPMENT COST REDUCTION BSCU REDESIGN
	<b>Applicable to: ALL</b>			
	P4859		22 MAR 16	NAVIGATION - ADF - INSTALL AN ADF 900 RECEIVER P/N 822-0299-020
	<b>Applicable to: ALL</b>			
	P4867		22 MAR 17	NAVIGATION - EGPWS - INSTL. NEW SPECIFICATION INSTALLATION OF EGPWC (NEW SPECIFICATION)
	<b>Applicable to: ALL</b>			
	P4885		20 AUG 10	NAVIGATION - EGPWS - ACTIVATION OF ENHANCED FUNCTIONS OF THE EGPWS
	<b>Applicable to: ALL</b>			
	P4916		20 AUG 10	FLIGHT CONTROL - GENERAL - ELAC-SYSTEM - INSTALL ELAC COMPATIBLE A320/321/319 (EM2 PROGRAM)
	<b>Applicable to: ALL</b>			
	P4954		20 AUG 10	AUTO FLIGHT - FMGC - DEFINE AND INSTALL FMGC B546CAM0102 FOR A319 AUTOLAND CFM ENGINES (CAPABLE OF GPS/ACARS FUNCTION)
	<b>Applicable to: ALL</b>			
	P4977	31-1264 04	20 AUG 10	INDICATING/RECORDING SYSTEMS - FWC - PROVIDE NEW SYNTHETIC VOICE "DUAL INPUT"
	<b>Applicable to: ALL</b>			
	P4983		20 AUG 10	AUTO FLIGHT - FLIGHT AUGMENTATION - DEFINE FAC STANDARD B0513
	<b>Applicable to: ALL</b>			
	P5020		20 AUG 10	NAVIGATION - ATC - INSTALL GABLES ATC/TCAS CONTROL PANEL P/N G6990-40
	<b>Applicable to: ALL</b>			
	P5071		20 AUG 10	ICE AND RAIN PROTECTION-WINDSHIELD RAIN PROTECTIONREACTIVATE RAIN REPELLENT SYSTEM WITH FLUID COMPATIBLE WITH OZONE PROTECTION RULES
	<b>Applicable to: ALL</b>			
	P5138		20 AUG 10	FLIGHT CONTROLS-GENERAL-ELAC SYSTEM- INSTALL ELAC STANDARD L80
	<b>Applicable to: ALL</b>			
	P5168		20 AUG 10	NAVIGATION-MMR-INSTALLATION OF COLLINS MULTI-MODE RECEIVERS PROVIDING ILS (FM IMMUNE) AND GPS PRIMARY FUNCTION
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P5224		20 AUG 10	NAVIGATION - EGPWS - INTRODUCE OPTIONAL AURAL WARNINGS FOR EGPWS
	<b>Applicable to: ALL</b>			
	P5228	31-1118 20	07 APR 11	INDICATING/RECORDING SYSTEM-FWC-ACTIVATE THE HI ALT SET" RIGH MEMO FOR HIGH ALTITUDE AIRPORT OPERATION
	<b>Applicable to: ALL</b>			
	P5239		20 AUG 10	NAVIGATION-ATC MODE "S"-INSTALL ATC/TCAS CONTROL UNIT P/N C12240B02
	<b>Applicable to: ALL</b>			
	P5241		20 AUG 10	NAVIGATION-WEATHER RADAR SYSTEMS-INSTALL COLLINS SINGLE WITH PROVISION FOR THE SECOND SYSTEM
	<b>Applicable to: ALL</b>			
	P5253		20 AUG 10	NAVIGATION ADIRS REMOVE ADIRS CDU
	<b>Applicable to: ALL</b>			
	P5314		20 AUG 10	AUTO FLIGHT - GENERAL - MULTIPURPOSE CONTROL AND DISPLAY UNIT (MCDU) - INSTALL MCDU HONEYWELL 2ND GENERATION P/N : 4077880-980
	<b>Applicable to: ALL</b>			
	P5429		20 AUG 10	ENGINE FUEL AND CONTROL - GENERAL FADEC SYSTEM A320/CFM56-5B - INTRODUCE ECU SOFTWARE STANDARD 5BI
	<b>Applicable to: ALL</b>			
	P5451		20 AUG 10	ELECTRICAL POWER - GENERAL AC & DC MAIN DISTRIBUTION - INSTALL A/C AND DC SHEDDABLE BUSBARS
	<b>Applicable to: ALL</b>			
	P5459		20 AUG 10	POWER PLANT - GENERAL - ADD RELAY LOGIC FOR CONTROL PACK CLOSURE AT ENGINE START
	<b>Applicable to: ALL</b>			
	P5465		20 AUG 10	INDICATING/RECORDING SYSTEMS - CLOCKS - INSTALL AIR PRECISION CLOCK P/N APE5100 CAPABLE OF GPS TIME
	<b>Applicable to: ALL</b>			
	P5518	32-1336 01	20 AUG 10	LANDING GEAR - GENERAL - NORMAL BRAKING - INTRODUCE STD 8 BSCU TWIN VERSION
	<b>Applicable to: ALL</b>			
	P5567		20 AUG 10	INDICATING/RECORDING SYSTEM - DMC - DEFINE DMC V40 STANDARD
	<b>Applicable to: ALL</b>			

*Continued on the following page*



*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P5583		20 AUG 10	NAVIGATION - ADIRS - REDUCED VERTICAL SEPARATION MINIMUM (RVSM) USING ADR 1 AND ADR 2 ONLY (A319/A320/A321 APPLICABLE)
	<b>Applicable to: ALL</b>			
	P5638		20 AUG 10	NAVIGATION - STANDBY DATA : ALTITUDE AND HEADING -INSTALL ISIS (INTEGRATED STANDBY INSTRUMENT SYSTEM) - SERIAL SOLUTION -
	<b>Applicable to: ALL</b>			
	P5669		20 AUG 10	NAVIGATION - TCAS - INSTALL ALLIED SIGNAL TCAS COMPUTER P/N 066-50000-2220 (WITH CHANGE 7.0) (BFE)
	<b>Applicable to: ALL</b>			
	P5706	31-1257 01	20 AUG 10	INDICATING/RECORDING SYSTEMS- FLIGHT WARNING COMPUTER (FWC) INSTALL FWC STD H2/E3
	<b>Applicable to: ALL</b>			
	P5768		20 AUG 10	ELECTRICAL POWER - AC EMERGENCY GENERATION - ACTIVATE ON A320 SAME ELECTRICAL EMERG. CONFIGURATION THAN A321
	<b>Applicable to: ALL</b>			
	P5895		20 AUG 10	NAVIGATION-GPWS-INSTALL EGPWS P/N-206-206 & INHIBIT AUTOMATIC DEACTIVATION OF ENHANCED FUNCTIONS.
	<b>Applicable to: ALL</b>			
	P6030		05 SEP 17	ELECTRICAL POWER - AC GENERATION - INSTALL ELECTRICAL OUTLETS IN COCKPIT
	<b>Applicable to: ALL</b>			
	P6044		20 AUG 10	ICE AND RAIN PROTECTION - GENERAL - WINDSHIELD RAIN PROTECTION INSTALL IMPROVED GAGE ASSY P/N 4020W35-2
	<b>Applicable to: ALL</b>			
	P6125		25 NOV 11	NAVIGATION - ADIRU - INSTALL HNWL ADIRU 4 MCU AD11 (NEW HARD) WITH 4 TRIMS OF ANEMO CORRECTION LAWS POSSIBILITIES AND MAGVAR TABLES UPDATED
	<b>Applicable to: ALL</b>			
	P6142		20 AUG 10	NAVIGATION -STANDBY BY DATA-ATTITUDE AND HEADING-COMPLETE PROVISIONS FOR ISIS ELECTRICAL SUPPLY
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P6146		20 AUG 10	INDICATING/RECORDING SYSTEM - FWC - INTRODUCE "F/CTL FLAP LVR NOT ZERO" RED WARNING
<b>Applicable to: ALL</b>				
	P6201		20 AUG 10	GENERAL-FLIGHT ENVIRONMENTAL ENVELOPE- EXTENSION TO 12100 M
<b>Applicable to: ALL</b>				
	P6251		20 AUG 10	ICE AND RAIN PROTECTION - GENERAL - WINDSHIELD RAIN PROTECTION - INSTALL NEW GAGE ASSYWITHOUT INPUT VALVE FUNCTION P/N 4020W35-3
<b>Applicable to: ALL</b>				
	P6375		20 AUG 10	LANDING GEAR-PARKING/ULTIMATE EMERGENCY BRAKING -INSTALL A PRESSURE SWITCH (PARKING BRAKE SYSTEM IMPROVEMENT
<b>Applicable to: ALL</b>				
	P6544		20 AUG 10	INDICATING RECORDING SYSTEM - FWC ACTIVATE SPECIFIC FWC PROCEDURE
<b>Applicable to: ALL</b>				
	P6578		20 AUG 10	INDICATING/RECORDING SYSTEMS - ELECTRONIC INSTRUMENT SYSTEM INSTALL DMC, DU AND DISKETTES FOR EIS2
<b>Applicable to: ALL</b>				
	P6588		20 AUG 10	INFORMATION SYSTEM - ATIMS IMPROVE ATSU AIRCRAFT INTERFACE SOFTWARE TO UPDATE SERVICE PROVIDERS LIST AND MANAGEMEN
<b>Applicable to: ALL</b>				
	P6589		20 AUG 10	INDICATING/RECORDING SYSTEMS - CFDIU INTRODUCE CFDIU STANDARD 9B
<b>Applicable to: ALL</b>				
	P6630	00-1058 97	20 AUG 10	CERTIFICATION DOCUMENTS - GENERAL - CERTIFY AIRCRAFT FOR OPERATION ON RUNWAYS LESS THAN 45 M WIDTH
<b>Applicable to: ALL</b>				
	P6687		20 AUG 10	COMMUNICATION - RADIO MANAGMENT INTRODUCE NEW RMP STANDARD 2 P/N C12848AB02
<b>Applicable to: ALL</b>				
	P6688		07 APR 11	COMMUNICATIONS - RADIO MANAGEMENT INSTALL A THIRD RADIO MANAGEMENT PANEL
<b>Applicable to: ALL</b>				

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P6703	22-1079 08 22-1102 02 22-1226 04	20 AUG 10	AUTO FLIGHT - FLIGHT AUGMENTATION COMPUTER INSTALL NEW FAC SOFTWARE STANDARD P/N B397BAM0515
	<b>Applicable to: ALL</b>			
	P6766		26 JAN 16	NAVIGATION - ILS (MMR) - INSTALL HONEYWELL MMR PROVIDING ILS (FM IMMUNE) AND GPS PRIMARY FUNCTIONS (HYBRID ARCHITECTURE)
	<b>Applicable to: ALL</b>			
	P6777		07 APR 11	INFORMATION SYSTEM - ATIMS UPGRADE ATSU HARDWARE FOR NEW ARINC 429 I/O BOARD
	<b>Applicable to: ALL</b>			
	P6801	31-1257 01	20 AUG 10	INDICATING RECORDING SYSTEM - FWC INSTALL FWC STANDARD H2E4
	<b>Applicable to: ALL</b>			
	P6832		20 AUG 10	INFORMATION SYSTEMS - ATIMS - DEFINE AND INSTALL NEW SOFTWARE ATSU A/C INTERFACE UPGRADED
	<b>Applicable to: ALL</b>			
	P6901	27-1160 01	20 AUG 10	FLIGHT CONTROLS - ELAC SYSTEM - INTRODUCE ELAC SOFTWARE "L90" CAPABLE OF A318
	<b>Applicable to: ALL</b>			
	P6911		20 AUG 10	INDICATING/RECORDING SYSTEM : FROM FWC-F1 PIN-PROGRAMMING FOR IMPROVING THE MONITORING ABOUT THE NORMAL BRAKING SYSTEM
	<b>Applicable to: ALL</b>			
	P6954	22-1102 02 22-1226 04	20 AUG 10	AUTO FLIGHT - FLIGHT AUGMENTATION COMPUTER (FAC SYSTEM) - INTRODUCE FAC SOFTWARE "BAM0516" CAPABLE OF A318
	<b>Applicable to: ALL</b>			
	P6985		20 AUG 10	NAVIGATION - ADIRS - INSTALL HONEYWELL ADIRU 4MCU CAPABLE OF A318 A/C
	<b>Applicable to: ALL</b>			
	P6987		20 AUG 10	AUTO FLIGHT - FMGC INSTALL FMGC P/N B546CAM0103 (CFM GPS/ACARS)
	<b>Applicable to: ALL</b>			
	P7005	32-1336 01	20 AUG 10	LANDING GEAR - NORMAL BRAKING - INTRODUCE STD 9 BSCU (TWIN VERSION)
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P7092		20 AUG 10	INDICATING/RECORDING SYSTEM - EIS - ACTIVATE FUEL FLOW/DELTA ISA FUNCTION BY PIN PROGRAMMING ON DMC
	<b>Applicable to: ALL</b>			
	P7125	31-1257 01	20 AUG 10	INDICATING/RECORDING SYSTEMS - FWC - INSTALL FWC STANDARD H2 F1 ON A318 PW
	<b>Applicable to: ALL</b>			
	P7148		20 AUG 10	COMMUNICATIONS - HF SYSTEM - ACTIVATE DATA LINK FUNCTION FOR HFDR 1
	<b>Applicable to: ALL</b>			
	P7175		20 AUG 10	ELECTRICAL POWER - GENERAL - INSTALL A COMMERCIAL SHEDDING PUSH-BUTTON SWITCH IN COCKPIT
	<b>Applicable to: ALL</b>			
	P7185		19 JUN 17	NAVIGATION - EGPWS INSTALL ENHANCED GPWS P/N 965-1676-001
	<b>Applicable to: ALL</b>			
	P7186		20 AUG 10	NAVIGATION - EGPWS ACTIVATE PEAKS MODE OF EGPWS IN CONJUNCTION WITH THE TERRAIN DISPLAY
	<b>Applicable to: ALL</b>			
	P7187		20 AUG 10	NAVIGATION - EGPWS ACTIVATE GEOMETRIC ALTITUDE FUNCTION IN THE EGPWS
	<b>Applicable to: ALL</b>			
	P7188		20 AUG 10	NAVIGATION - EGPWS ACTIVATE OBSTACLE OPTION ON THE EGPWS
	<b>Applicable to: ALL</b>			
	P7218		22 MAR 16	AUTOFLIGHT - FLIGHT MANAGEMENT AND GUIDANCE COMPUTER (FMGC) DEVELOP FMS 2ND GENERATION HONEYWELL STEP1
	<b>Applicable to: ALL</b>			
	P7247		20 AUG 10	FLIGHT CONTROLS - ELAC SYSTEM - INSTALL ELAC STANDARD L81
	<b>Applicable to: ALL</b>			
	P7268		20 AUG 10	NAVIGATION - ADIRU RESTORE RVSM 3 CIRCUITS CAPABILITIES - SERIAL SOLUTION
	<b>Applicable to: ALL</b>			
	P7278		20 AUG 10	INDICATING RECORDING SYSTEM - EIS2 INSTALL EIS2 SOFTWARE CAPABLE OF A318 A/C
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P7300		05 SEP 17	ELECTRICAL POWER - AC GENERATION - INSTALL ELECTRICAL OUTLETS IN COCKPIT 4MM AND 4.8MM DIA. PLUGS
<b>Applicable to: ALL</b>				
	P7397		01 DEC 15	NAVIGATION - ADIRS INSTALL HONEYWELL ADIRU 4MCU CAPABLE OF A318
<b>Applicable to: ALL</b>				
	P7407		07 APR 11	COMMUNICATION - RADIO MANAGEMENT INSTALL RMP STANDARD 3 WITH MLS AND GLS FUNCTION CAPABILITY
<b>Applicable to: ALL</b>				
	P7425		06 JUL 16	NAVIGATION - ATC - INSTALL HONEYWELL ATC TRA67A INCORPORATING EUROPEAN MODE S REGULATIONS
<b>Applicable to: ALL</b>				
	P7455		20 AUG 10	ELECTRICAL POWER - GENERAL IN FLIGHT ENTERTAINMENT (IFE) POWER SUPPLY ON SHEDDABLE BUSBARS CONTROLLED BY "GALY & CAB" SW
<b>Applicable to: ALL</b>				
	P7519		20 AUG 10	AUTOFLIGHT - FMGC - INSTALL FMGC CFM C13042AA01 (EQUIPPED WITH FMS2 HONEYWELL)
<b>Applicable to: ALL</b>				
	P7635	27-1160 01	20 AUG 10	FLIGHT CONTROLS - ELAC SYSTEM INTRODUCE ELAC SOTWARE L82
<b>Applicable to: ALL</b>				
	P7721	32-1247 02	20 AUG 10	LANDING GEAR - WHEELS AND BRAKES REMOVE THE TEMPORARY REVISIONS 5.02.00/23 AND 5.03.00/23 ON FLIGHT MANAL
<b>Applicable to: ALL</b>				
	P7790		20 AUG 10	AUTO FLIGHT FLIGHT MANAGEMENT AND GUIDANCE SYSTEM ACTIVATE FMA ENHANCEMENT FUNCTION
<b>Applicable to: ALL</b>				
	P7919		20 AUG 10	ENGINE FUEL AND CONTROL - FADEC SYSTEM - INTRODUCE NEW FADEC SOFTWARE "5BK" ON SAC CFM56-5B ENGINES
<b>Applicable to: ALL</b>				
	P7929		20 AUG 10	NAVIGATION - WEATHER RADAR SYSTEM INSTALL COLLINS DUAL CONTROL PANEL TO ACTIVATE MULTISCAN FUNCTION
<b>Applicable to: ALL</b>				

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P8069	73-1080 01	20 AUG 10	ENGINE FUEL AND CONTROL - FADEC SYSTEM INTRODUCE NEW ECU SOFTWARE STANDARD "5BL" FOR CFM56-5B ENGINES CAPABLE OF A318 CFM A/C
<b>Applicable to: ALL</b>				
	P8076		20 AUG 10	LANDING GEAR NORMAL BRAKING INSTALL BSCU STD L4.5
<b>Applicable to: ALL</b>				
	P8175		20 AUG 10	INDICATING/RECORDING SYSTEMS - SDAC - ACTIVATE IAS DISCREPANCY MONITORING BY PIN PROGRAMMING
<b>Applicable to: ALL</b>				
	P8176		07 APR 11	INDICATING/RECORDING SYSTEMS - SDAC - ACTIVATE DUAL PITOT MONITORING BY PIN PROGRAMMING
<b>Applicable to: ALL</b>				
	P8194		20 AUG 10	NAVIGATION - ADIRS ACTIVATE ALIGNMENT IMPROVEMENT FUNCTION ON ADIRU
<b>Applicable to: ALL</b>				
	P8232	31-1266 02	20 AUG 10	INDICATING/RECORDING SYSTEMS - FWC - INTRODUCE IAS DISCREPANCY AND DUAL PITOT MONITORING ON FWC H2F1
<b>Applicable to: ALL</b>				
	P8241		07 APR 11	PLACARDS AND MARKINGS - CABIN - CONFIGURATE THE CABIN FOR NON SMOKING FLIGHT
<b>Applicable to: ALL</b>				
	P8243		20 AUG 10	CERTIFICATION DOCUMENTS / EXTEND OPERATING FLIGHT ENVELOPE TO MINUS 2000FT PRESSURE ALTITUDE
<b>Applicable to: ALL</b>				
	P8256	22-1102 02 22-1226 04	20 AUG 10	AUTO FLIGHT FLIGHT AUGMENTATION COMPUTER INSTALL FAC STANDARD BAM0617 FOR A318 EIS
<b>Applicable to: ALL</b>				
	P8274	31-1257 01	20 AUG 10	INDICATING RECORDING SYSTEM FWC INSTALL FWC STANDARD H2F2
<b>Applicable to: ALL</b>				
	P8303		20 AUG 10	NAVIGATION DDRMI REMOVE DDRMI VOR/ADF/DME INDICATORS
<b>Applicable to: ALL</b>				

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P8440	32-1291 01	20 AUG 10	LANDING GEAR - WHEELS AND BRAKES INTRODUCE GOODRICH DURACARB CARBON BRAKES WITH ANTI - OXYDAN "M1"
	<b>Applicable to: ALL</b>			
	P8564		20 AUG 10	INDICATING/RECORDING SYSTEM EIS ACTIVATE ENGINE AVAIL DISPLAY
	<b>Applicable to: ALL</b>			
	P8626		20 AUG 10	NAVIGATION - STANDBY DATA (ISIS) - INSTALL ISIS STANDARD VA01 WITH CORRECTION OF "OUT OF ORDER" MESSAGE & "NEW IMU STANDARD"
	<b>Applicable to: ALL</b>			
	P8671		20 AUG 10	INDICATING RECORDING SYSTEM EIS INSTALL DMC SOFTWARE EIS2 S4-2 TO CORRECT TEMPORARY LOSS OF ALL EIS2 IMAGES
	<b>Applicable to: ALL</b>			
	P8708	22-1168 01	20 AUG 10	AUTOFLIGHT - FMGC INSTALL FMS2 HONEYWELL P1C11 ON A/C FITTED WITH CFMI PPS
	<b>Applicable to: ALL</b>			
	P8710		20 AUG 10	NAVIGATION - WEATHER RADAR SYSTEM - INSTALL COLLINS TRANSCEIVER FULLY COMPLIANT WITH MULTISCAN FUNCTION
	<b>Applicable to: ALL</b>			
	P8751		20 AUG 10	NAVIGATION - EGPWS - INSTALL AN EGPWC CAPABLE OF PEAKS/OBSTACLE FUNCTIONS WITH EIS1 & OF USING GPS LATERAL POSITION
	<b>Applicable to: ALL</b>			
	P8799		20 AUG 10	NAVIGATION - EGPWS - INSTALL AN EGPWC CAPABLE OF PEAKS/OBSTACLE FUNCTIONS WITH EIS1 & OF USING GPS LATERAL POSITION
	<b>Applicable to: ALL</b>			
	P8850		20 AUG 10	PNEUMATIC - ENGINE BLEED AIR SUPPLY - INTRODUCE BMC STD 9 CAPABLE OF A318 PW
	<b>Applicable to: ALL</b>			
	P8863		20 AUG 10	INDICATING/RECORDING SYSTEM FWC ACQUISITION INTERFACE CONNECT FWC TO RPWS TO PREVENT DOOR OPENING WITH RESIDUAL CABIN PRESSURE
	<b>Applicable to: ALL</b>			
	P8866		20 AUG 10	LANDING GEAR NORMAL BRAKING INSTALL BSCU STD L4.8 (EM2)
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	MODIFICATION	Linked SB	Incorp. Date	Title
	P9038		20 AUG 10	AUTO FLIGHT MCDU INSTALL LCD MCDU HONEYWELL
<b>Applicable to: ALL</b>				
	P9107	31-1267 03 31-1300 02	20 AUG 10	INDICATING/RECORDING SYSTEM FLIGHT WARNING COMPUTER - FWC - INSTALL FWC STANDARD H2 F3
<b>Applicable to: ALL</b>				
	P9171		20 AUG 10	NAVIGATION - ADIRS INTRODUCE AIR DATA MONITORING FUNCTION
<b>Applicable to: ALL</b>				
	P9196		07 APR 11	NAVIGATION - STANDBY DATA (ISIS) INSTALL ISIS STD WB01 WITH CORRECTION OF "OUT OF ORDER" MESSAGE
<b>Applicable to: ALL</b>				
	P9207		20 AUG 10	NAVIGATION - ATC / MODE S - CERTIFY EHS FUNCTION
<b>Applicable to: ALL</b>				
	P9225		20 AUG 10	INDICATING / RECORDING SYSTEM : ELECTRONIC INSTRUMENT SYSTEM (EIS) - INSTALL DISPLAY MANAGEMENT COMPUTER SOFTWARE EIS2 S6-1
<b>Applicable to: ALL</b>				
	P9333		01 DEC 15	NAVIGATION - AIR DATA/INERTIAL REFERENCE SYSTEM - INSTALL HONEYWELL ADIRU P/N HG2030-AE23
<b>Applicable to: ALL</b>				
	P9508		20 AUG 10	INDICATING/RECORDING SYSTEMS - SDAC - ACQUISITION/INTERFACE CONFIGURATION CABIN FOR NO PED FLIGHTS
<b>Applicable to: ALL</b>				
	P9522		20 AUG 10	AUTO FLIGHT - MCDU ACTIVATE BACK UP NAV FUNCTION
<b>Applicable to: ALL</b>				
	P9552	73-1086 00	20 AUG 10	ENGINE FUEL AND CONTROL - FADEC SYSTEM INSTALL "5BM" STANDARD ECU SOFTWARE FOR CFM 56-5B ENGINES
<b>Applicable to: ALL</b>				
	P9594		07 APR 11	PNEUMATIC LEAK DETECTION ACTIVATE PYLON LEAK DETECTION MONITORING
<b>Applicable to: ALL</b>				
	P9655		07 APR 11	LANDING GEAR NORMAL BRAKING INSTALL BSCU SOFTWARE STD "L4.9" (EM2)
<b>Applicable to: ALL</b>				

*Continued on the following page*



*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	P9824		20 AUG 10	INDICATING / RECORDING SYSTEMS NSTALL DISPLAY MANAGEMENT COMPUTER SOFTWARE EIS2 S7 ELECTRONIC INSTRUMENT SYSTEM
	<b>Applicable to: ALL</b>			
	P9873		20 AUG 10	POWER PLANT - GENERAL INTRODUCE CFM56-5BX/3 ENGINE (SAC) "TECH INSERTION PROGRAM"
	<b>Applicable to: ALL</b>			
	P9894		07 APR 11	AUTO FLIGHT - FLIGHT AUGMENTATION COMPUTER - INTRODUCE TAIL STRIKE INDICATION ON PFD FOR A320 & A321 A/C
	<b>Applicable to: ALL</b>			
	P9895		20 AUG 10	AUTO FLIGHT - FLIGHT AUGMENTATION COMPUTER - INTRODUCE TAIL STRIKE "PITCH-PITCH" CALL-OUT FOR A320 & A321 AIRCRAFT
	<b>Applicable to: ALL</b>			
	P9902		07 APR 11	NAVIGATION - WEATHER RADAR SYSTEM - INSTALL COLLINS WXR MULTISCAN WRT -2100 P/N 822-1710-213
	<b>Applicable to: ALL</b>			
	P9920		07 APR 11	GENERAL - TECHNICAL DOCUMENTATION EXTENSION OF FLEX TEMPERATURE - UPDATE FM & FCOM DOCUMENTATION
	<b>Applicable to: ALL</b>			
	22-1359 05		22 MAR 16	AUTO-FLIGHT-FLIGHT MANAGEMENT AND GUIDANCE COMPUTER (FMGC)-INSTALL FMGC HONEYWELL H2C13 ON CFM A/C
	<b>Applicable to: ALL</b>			
	27-1234 01		19 JUN 17	FLIGHT CONTROL - ELEVATOR AILERON COMPUTER SYSTEM (ELAC)-INSTALL L97 STANDARD ON ELAC B WITH DATA LOADING CAPABILITY
	<b>Applicable to: ALL</b>			
	27-1243 01		22 MAR 16	FLIGHT CONTROLS - ELEVATOR AILERON COMPUTER SYSTEM (ELAC) - INSTALL ELAC B L97+ WITH DATA LOADING CAPABILITY
	<b>Applicable to: ALL</b>			
	31-1373 00		31 JUL 14	INDICATING/RECORDING SYSTEMS - FLIGHT WARNING COMPUTER (FWC) - INSTALL FWC STANDARD H2-F6
	<b>Applicable to: ALL</b>			

*Continued on the following page*

*Continued from the previous page*

<b>M<sup>(1)</sup></b>	<b>MODIFICATION</b>	<b>Linked SB</b>	<b>Incorp. Date</b>	<b>Title</b>
	31-1414 03		18 MAR 15	INDICATING RECORDING SYSTEMS - FWC - INTRODUCE FWC STANDARD H2-F7
	<b>Applicable to: ALL</b>			
	34-1506 34		22 MAR 17	NAVIGATION - TCAS - INSTALL A NEW HONEYWELL TCAS TPA-100B
	<b>Applicable to: ALL</b>			
	47-1026 10		19 JUN 17	INERT GAS SYSTEM - INSTALLATION OF FUEL TANK INERTING SYSTEM (FTIS)
	<b>Applicable to: ALL</b>			

(1) Evolution code : N=New, R=Revised, E=Effectivity

# **GENERAL INFORMATION**

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**GENERAL INFORMATION**

**PRELIMINARY PAGES**

TABLE OF CONTENTS

Aircraft Configuration Summary.....	A
If Installed Table.....	B
Main FCOM Changes.....	C
FCOM Purpose.....	D
List of Effective Sections/Subsections (LESS) - Paper ONLY.....	E
List of Effective Operations Engineering Bulletins (LEOEB).....	F
List of Effective Documentary Units (LEDU) - Paper Only.....	G
List of Effective Temporary Documentary Units (LETDU) - Paper Only.....	H
Aircraft Allocation Table (AAT) - Paper Only.....	I
List of Modifications (LOM) - Paper Only.....	J
FCOM Use and Organization.....	K
FCOM Format and Style Information - Paper only.....	L
FCOM Revisions.....	M
Abbreviations.....	N



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**GENERAL INFORMATION**

**PRELIMINARY PAGES**

TABLE OF CONTENTS

Intentionally left blank

**AIRCRAFT CONFIGURATION SUMMARY**

Applicable to: ALL

Ident.: GEN-ACS-00016449.0001001 / 26 JUN 15

For awareness and for the specified aircraft, the following table provides the flight crew with a list of optional aircraft systems and functions related to flight and aircraft operations.

Ident.: GEN-ACS-00018963.0001001 / 04 MAR 16

Item	System	Installed
------	--------	-----------

Ident.: GEN-ACS-00015613.0001001 / 23 JUN 15

ADS-B OUT	SURV	No
-----------	------	----

Ident.: GEN-ACS-00016448.0001001 / 23 JUN 15

AP Automatic Disconnection at Minima	AUTO FLT	No
--------------------------------------	----------	----

Ident.: GEN-ACS-00015927.0001001 / 26 JUN 15

AP /FD TCAS	AUTO FLT	No
-------------	----------	----

Ident.: GEN-ACS-00015892.0002001 / 19 FEB 16

Automatic FD Bar Engagement	AUTO FLT	Yes
-----------------------------	----------	-----

Ident.: GEN-ACS-00016009.0002001 / 23 JUN 15

Backup Navigation Function of the MCDU	AUTO FLT	Yes
--	----------	-----

Ident.: GEN-ACS-00016014.0002001 / 23 JUN 15

BUSS	NAV	Yes
------	-----	-----

Ident.: GEN-ACS-00016010.0001001 / 23 JUN 15

CPDLC	DATALINK	No
-------	----------	----

Ident.: GEN-ACS-00015917.0001001 / 23 JUN 15

Derated Takeoff	ENG	No
-----------------	-----	----

Ident.: GEN-ACS-00019728.0002001 / 06 JUN 16

Descent Profile Optimization (DPO)	AUTO FLT	No
------------------------------------	----------	----

Ident.: GEN-ACS-00015912.0001001 / 23 JUN 15

FLS Function in the FMS	AUTO FLT	No
-------------------------	----------	----

Ident.: GEN-ACS-00015913.0005001 / 23 JUN 15

FMS 2 Release 1A	AUTO FLT	Yes
------------------	----------	-----

Ident.: GEN-ACS-00015899.0001001 / 23 JUN 15

GLS	AUTO FLT	No
-----	----------	----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-ACS-00015924.0002001 / 23 JUN 15

GPS	NAV	Yes
-----	-----	-----

Ident.: GEN-ACS-00016553.0002001 / 23 JUN 15

GPS PRIMARY Function	NAV	Yes
----------------------	-----	-----

Ident.: GEN-ACS-00015926.0001001 / 23 JUN 15

Metric Altitude Indications on the PFD	EIS	No
--	-----	----

Ident.: GEN-ACS-00015900.0001001 / 23 JUN 15

MLS	AUTO FLT	No
-----	----------	----

Ident.: GEN-ACS-00015923.0002001 / 19 FEB 16

NAV Mode automatically Engaged (Armed) in Go-Around	AUTO FLT	Yes
---	----------	-----

Ident.: GEN-ACS-00016013.0002001 / 23 JUN 15

PWS	SURV	Yes
-----	------	-----

Ident.: GEN-ACS-00015920.0001001 / 23 JUN 15

QFE BARO Setting	NAV	No
------------------	-----	----

Ident.: GEN-ACS-00019573.0001001 / 10 MAY 16

RAAS	SURV	No
------	------	----

Ident.: GEN-ACS-00015897.0001001 / 23 JUN 15

RNP AR	AUTO FLT	No
--------	----------	----

Ident.: GEN-ACS-00016008.0001001 / 23 JUN 15

ROW / ROPS	SURV	No
------------	------	----


Ident.: GEN-ACS-00016015.0001001 / 22 MAR 17

Soft Go-Around	ENG	No
----------------	-----	----

**IF INSTALLED TABLE**

**Applicable to: ALL**

Ident.: GEN-IFIT-00016590.0001001 / 23 JUN 15


The "If Installed Table" provides a list of optional systems and functions of the aircraft. For most of the optional systems or functions associated with the "if installed"  symbol in the FCOM, the table indicates if the optional systems or functions are installed, or not installed.

*Note:* Highly customized options such as cabin installations are not covered in the following table.

Ident.: GEN-IFIT-00018965.0001001 / 22 MAR 16

Item	System	Installed
------	--------	-----------



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>GENERAL INFORMATION</b>
---	----------------------------

Ident.: GEN-IFIT-00015896.0002001 / 17 MAR 17

L13

4th Occupant Folding Seat 4th Occupant Fourth Occupant	EQUIPMENT	Yes
--	-----------	-----

Ident.: GEN-IFIT-00016012.0002001 / 21 MAR 16

L13

4th Oxygen Mask Four	OXY	Yes
-------------------------	-----	-----

Ident.: GEN-IFIT-00018779.0002001 / 21 MAR 16

AC ESS FEED Auto Switching	ELEC	Yes
----------------------------	------	-----

Ident.: GEN-IFIT-00016516.0001001 / 21 MAR 17

L13

ACT 1 ACT 2 ACTs ACT 1 ACT 2 ACT 1 OR 2 ACT PUMP ACT PUMP LO PR ACT XFR FAULT ACT1 ACT2 ACTs Additional center tank	FUEL	No
---	------	----

Ident.: GEN-IFIT-00020299.0002001 / 13 SEP 16

L13

1 ADF ADF 1 ADF1	NAV	No
------------------------	-----	----

Ident.: GEN-IFIT-00020300.0002001 / 13 SEP 16

L13

2 ADF s 2 ADF ADF 1 ADF 1 ADF 2 ADF 2 ADF s	NAV	Yes
---	-----	-----



# GENERAL INFORMATION

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00016641.0001001 / 23 JUN 15

ADS-B OUT	SURV	No
-----------	------	----

Ident.: GEN-IFIT-00015891.0001001 / 21 MAR 16

L13 AFT Cargo Heating AFT CRG HOT AIR temperature selector HOT AIR pb AFT CRG HEAT AFT CARGO HEAT AFT CARGO DUCT OVHT AFT Cargo heat controller Cargo Heat Cargo Temperature Regulation CRG HEAT Forward (aft) cargo heat controller HOT AIR	COND	No
---	------	----

Ident.: GEN-IFIT-00015901.0002001 / 21 MAR 16


L13 AFT Cargo Smoke Detector SMOKE AFT CARGO SMOKE SMOKE AFT CRG DET FAULT AFT CRG DET AFT CARGO SMOKE AFT CRG DET FAULT	FIRE	Yes
--	------	-----

Ident.: GEN-IFIT-00015931.0001001 / 21 MAR 16

L13 AFT Cargo Ventilation Cargo Ventilation AFT ISOL VALVE AFT CRG VENT AFT CRG VENT FAULT AFT Cargo isol valves FWD (AFT) CARGO DUCT OVHT FWD (AFT) CRG HEAT FWD (AFT) CRG HEAT FAULT FWD (AFT) CRG ISOL VALVE FWD (AFT) CRG VENT FAULT FWD (AFT) CRG VENT Forward (aft) cargo isolation valves isolation valves	VENT	No
---	------	----

Ident.: GEN-IFIT-00016522.0001001 / 23 JUN 15

Aileron Anti Droop	F/CTL	No
--------------------	-------	----

 <b>A318/A319/A320/A321</b> <b>FLIGHT CREW</b> <b>OPERATING MANUAL</b>	<b>GENERAL INFORMATION</b>
---	----------------------------

Ident.: GEN-IFIT-00015919.0002001 / 21 MAR 16

L13

Air Conditioning System Controller ( ACSC ) ACSC ACSC 1 ACSC 2 Air Conditioning System Controllers	COND	Yes
--	------	-----

Ident.: GEN-IFIT-00016523.0001001 / 23 JUN 15

AP / FD TCAS	AUTO FLT	No
--------------	----------	----

Ident.: GEN-IFIT-00016640.0001001 / 21 MAR 16

L13

ATSAW ADS-B IN	SURV	No
-------------------	------	----

Ident.: GEN-IFIT-00016524.0002001 / 23 JUN 15

Automatic FD Bar Engagement	AUTO FLT	Yes
-----------------------------	----------	-----

Ident.: GEN-IFIT-00018780.0002001 / 21 MAR 16

L13

Avail Indication During Engine Start AVAIL Indication	ENG	Yes
--	-----	-----

Ident.: GEN-IFIT-00016681.0002001 / 21 MAR 16

L13

Backup Navigation Function of the MCDU BACK UP NAV	AUTO FLT	Yes
---	----------	-----

Ident.: GEN-IFIT-00016525.0002001 / 21 MAR 16

L13

BARO /RADIO Instead of MDA / MDH / DH BARO BARO /RADIO	NAV	Yes
--	-----	-----

Ident.: GEN-IFIT-00016526.0001001 / 21 MAR 16

L13

Brake Fans Brake cooling fans BRK FAN Brake Fan Brake fans 1, 2, 3 and 4 Brake fans 5, 6, 7 and 8	BRAKE	No
--	-------	----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00015875.0002001 / 21 MAR 16

L13

Bulk Cargo Door Bulk Cargo Compartment Door Bulk Door	DOORS	Yes
---	-------	-----

Ident.: GEN-IFIT-00018781.0002001 / 21 MAR 16

L13

BUSS Backup Speed/Altitude Scale Backup Speed Scale	NAV	Yes
---	-----	-----

Ident.: GEN-IFIT-00021488.0002001 / 17 MAR 17

L13

Cargo ventilation system Cargo isolation valves Extraction fan	VENT	Yes
--	------	-----

Ident.: GEN-IFIT-00016535.0001001 / 22 MAR 17

L13

Center Fuel Tank Transfer Valves Center Tank Transfer Valves L CTR TK XFR valve CTR TK XFR valve R	FUEL	No
---	------	----

Ident.: GEN-IFIT-00021220.0001001 / 22 MAR 17

L13

Center Fuel Tank Pumps CTR TK PUMP 1 CTR TK PUMP 2	FUEL	Yes
--	------	-----

Ident.: GEN-IFIT-00015930.0002001 / 21 MAR 16

L13

Chemical Oxygen System 22 min Chemical Oxygen System 22 min	OXY	Yes
---	-----	-----

Ident.: GEN-IFIT-00016625.0002001 / 17 MAR 17

L13

CIDS-SDF CIDS 1 SMOKE DETECT Smoke Detection Function ( SDF )	SMOKE	Yes
---	-------	-----

Ident.: GEN-IFIT-00015929.0002001 / 17 MAR 17

L13

Cockpit Door Deadbolt Deadbolt	EQUIPMENT	Yes
-----------------------------------	-----------	-----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00018782.0002001 / 21 MAR 16

Cockpit Door Escape Panel	DOOR	Yes
---------------------------	------	-----

Ident.: GEN-IFIT-00016690.0001001 / 21 MAR 16

L13

Cockpit Fixed Second Oxygen Bottle Two	OXY	No
---	-----	----

Ident.: GEN-IFIT-00016612.0001001 / 23 JUN 15

Cockpit Foot Heater	COND	No
---------------------	------	----

Ident.: GEN-IFIT-00016639.0001001 / 17 MAR 17

L13

Cockpit Foot Warmer Foot Warmer System Foot Warmer ON/OFF Control Switch	EQUIPMENT	No
--	-----------	----

Ident.: GEN-IFIT-00021875.0002001 / 25 JUL 17

L13

Cockpit Power Outlet Power Outlet	EQUIPMENT	Yes
--------------------------------------	-----------	-----

Ident.: GEN-IFIT-00016614.0002001 / 21 MAR 16

L13

COMMERCIAL pb COMMERCIAL	ELEC	Yes
-----------------------------	------	-----

Ident.: GEN-IFIT-00016615.0001001 / 23 JUN 15

CVR Datalink Function	COM	No
-----------------------	-----	----

Ident.: GEN-IFIT-00016626.0001001 / 23 JUN 15

CVR ERASE pb	COM	No
--------------	-----	----

Ident.: GEN-IFIT-00016647.0001001 / 21 MAR 17

L13

DC BUS Entertainment TR Entertainment DC BUS Ent DC BUS Entertainment TR Ent TR Ent.	ELEC	No
---	------	----

Ident.: GEN-IFIT-00016527.0002001 / 21 MAR 16

L13

DDRM1 Digital Distance and Radio Magnetic Indicator	NAV	Yes
--	-----	-----

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

Ident.: GEN-IFIT-00016528.0001001 / 21 MAR 16

L13

Derated Takeoff DERATE	ENG	No
---------------------------	-----	----

Ident.: GEN-IFIT-00019730.0002001 / 06 JUN 16

L13

Descent Profile Optimization DPO	AUTO FLT	No
-------------------------------------	----------	----

Ident.: GEN-IFIT-00016580.0002001 / 21 MAR 16

L13

Display of Delta ISA Delta ISA	EIS	Yes
-----------------------------------	-----	-----

Ident.: GEN-IFIT-00016529.0001001 / 23 JUN 15

Dual Ice Detection System	ICE	No
---------------------------	-----	----

Ident.: GEN-IFIT-00016574.0002001 / 23 JUN 15

Dual Navigation Lights	LIGHTS	Yes
------------------------	--------	-----

Ident.: GEN-IFIT-00016628.0002001 / 17 MAR 17

L13

EGPWS	SURV	Yes
-------	------	-----

Ident.: GEN-IFIT-00016530.0002001 / 23 JUN 15

Electrical Alternate Braking	L/G	Yes
------------------------------	-----	-----

Ident.: GEN-IFIT-00016575.0002001 / 23 JUN 15

ELT sw	COM	Yes
--------	-----	-----

Ident.: GEN-IFIT-00020758.0002001 / 18 MAY 17

L13

EVAC Panel COMMAND PB (guarded) COMMAND PB Evacuation ( EVAC ) signalling EVAC HORN HORN SHUT OFF PB CAPT and PURS/CAPT SW	COM	Yes
--	-----	-----

Ident.: GEN-IFIT-00021713.0001001 / 03 AUG 17

Expedite	AUTO FLT	Yes
----------	----------	-----

Ident.: GEN-IFIT-00015918.0002001 / 23 JUN 15

Extended FLEX Takeoff	ENG	Yes
-----------------------	-----	-----

Ident.: GEN-IFIT-00016531.0002001 / 21 MAR 16

L13

External Ice Detector Light ICE IND	ICE	Yes
--	-----	-----

Ident.: GEN-IFIT-00021527.0001001 / 17 MAR 17

FANS A+ DCDU ATC MSG pb	FANS	No
-------------------------------	------	----

Ident.: GEN-IFIT-00021529.0001001 / 17 MAR 17

FANS B DCDU ATC MSG pb	FANS	No
------------------------------	------	----

Ident.: GEN-IFIT-00021530.0001001 / 17 MAR 17

FANS B+ DCDU ATC MSG pb	FANS	No
-------------------------------	------	----

Ident.: GEN-IFIT-00015909.0001001 / 21 MAR 16

L13

Fan Speed Controller (FSC) Two Operating Speeds	VENT	No
--	------	----

Ident.: GEN-IFIT-00016629.0003001 / 21 MAR 16

L13

Fire Extinguishing in the AFT Cargo SMOKE FWD (AFT) CRG BTL 1(2) FAULT Forward (aft) cargo fire extinguishing	FIRE	Yes
---	------	-----

Ident.: GEN-IFIT-00016630.0005001 / 21 MAR 16

L13

Fire Extinguishing in the FWD Cargo SMOKE FWD (AFT) CRG BTL 1(2) FAULT Forward (aft) cargo fire extinguishing	FIRE	Yes
---	------	-----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00015898.0001001 / 21 MAR 17

L13

FLS F-G/S F-G/S BASED ON ISA F-G/S-F-LOC F-G/S-LOC F-LOC F-LOC*/F-LOC FLS 1 FLS 2 FLS function NO FLS FOR THIS APPR	AUTO FLT	No
---	----------	----

Ident.: GEN-IFIT-00016579.0002001 / 23 JUN 15

FMS Crossload	AUTO FLT	Yes
---------------	----------	-----

Ident.: GEN-IFIT-00016589.0004001 / 23 JUN 15

HONEYWELL FMS 2 Release 1A H2	AUTO FLT	Yes
-------------------------------	----------	-----

Ident.: GEN-IFIT-00015617.0002001 / 23 JUN 15

FTIS	FUEL	Yes
------	------	-----

Ident.: GEN-IFIT-00016532.0001001 / 23 JUN 15

Fuel Leak Detection	FUEL	No
---------------------	------	----

Ident.: GEN-IFIT-00016533.0001001 / 23 JUN 15

Fuel Tank Overflow Alert	FUEL	No
--------------------------	------	----

Ident.: GEN-IFIT-00015893.0001001 / 21 MAR 16

L13

FWD Cargo Heating Temperature Selector FWD (AFT) CARGO DUCT OVHT FWD (AFT) CRG HEAT FWD (AFT) CRG HEAT FAULT FWD CRG HEAT Cargo Heat Cargo Temperature Regulation CRG HEAT Forward (aft) cargo heat controller HOT AIR Fwd cargo heat controller	COND	No
---	------	----



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00015925.0002001 / 21 MAR 16

L13

FWD Cargo Smoke Detector SMOKE FWD CARGO SMOKE FWD CARGO SMOKE SMOKE FWD CRG DET FAULT FWD CRG DET	FIRE	Yes
--	------	-----

Ident.: GEN-IFIT-00015932.0002001 / 21 MAR 16

L13

FWD Cargo Ventilation FWD Cargo Outlet Isolation Valve Cargo Ventilation FWD ISOL Valve FWD CRG VENT FWD CARGO ISOL VALVE Forward (aft) cargo isolation valves Fwd cargo isol valves	VENT	Yes
---	------	-----

Ident.: GEN-IFIT-00016617.0001001 / 21 MAR 16

L13

Galley Bus Automatic Shedding Galley Load Automatic Shedding	ELEC	No
---	------	----

Ident.: GEN-IFIT-00016618.0002001 / 21 MAR 16

L13

GAPCU Ground and Auxiliary Power Control Unit	ELEC	Yes
--	------	-----

Ident.: GEN-IFIT-00019705.0001001 / 13 MAY 16

L13

Gaseous Oxygen Generators in lavatories Gaseous Generators	OXY	No
---	-----	----

Ident.: GEN-IFIT-00016534.0001001 / 21 MAR 16

L13

GLS GLS Autoland GLS1 GLS2	AUTO FLT	No
-------------------------------------	----------	----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00016649.0002001 / 21 MAR 16

L13		
GPS FM / GPS POS DISAGREE GPS 1(2) FAULT GPS 1 GPS 2 GPS 1+2	NAV	Yes

Ident.: GEN-IFIT-00016650.0002001 / 21 MAR 16

L13		
GPS PRIMARY Function GPS PRIMARY	NAV	Yes

Ident.: GEN-IFIT-00020297.0001001 / 17 MAR 17

GSM Onboard	COM	No
-------------	-----	----

Ident.: GEN-IFIT-00015911.0002001 / 21 MAR 17

L13		
HF Datalink HF 1(2) DATA FAULT HF DATA LINK	COM	Yes

Ident.: GEN-IFIT-00020132.0002001 / 22 MAR 17

L13		
HF System HF HF 1 HF 2	COM	Yes

Ident.: GEN-IFIT-00016644.0002001 / 21 MAR 16

L13		
HI ALT pb Operation on High Altitude Airfields HI ALT LANDING pb-sw HI ALT LANDING pb-sw	OXY	Yes

Ident.: GEN-IFIT-00018783.0001001 / 21 MAR 16

HUD	SURV	No
-----	------	----

Ident.: GEN-IFIT-00016651.0002001 / 23 JUN 15

IRS Alignment Based on GPS Position	NAV	Yes
-------------------------------------	-----	-----

Ident.: GEN-IFIT-00015618.0002001 / 23 JUN 15

ISIS	NAV	Yes
------	-----	-----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00020693.0001001 / 17 MAR 17

L13

ITP ATSA ITP ITP TRAFFIC LIST page IN TRAIL PROCEDURE IN TRAIL PROCEDURE page	SURV	No
---	------	----

Ident.: GEN-IFIT-00016594.0002001 / 23 JUN 15

LAF	F/CTL	No
-----	-------	----

Ident.: GEN-IFIT-00016596.0001001 / 21 MAR 16

L13

LAT DEV SCALE pb L/DEV deviation scale	NAV	No
---	-----	----

Ident.: GEN-IFIT-00016600.0001001 / 23 JUN 15

LOC B/C	AUTO FLT	No
---------	----------	----

Ident.: GEN-IFIT-00016602.0002001 / 21 MAR 16

L13

Logo Light LOGO Logo Lights	LIGHTS	Yes
-----------------------------------	--------	-----

Ident.: GEN-IFIT-00020306.0001001 / 17 MAR 17

Man-made Obstacle Function	SURV	Yes
----------------------------	------	-----

Ident.: GEN-IFIT-00016604.0002001 / 23 JUN 15

Manual Flush Control	WATER	Yes
----------------------	-------	-----

Ident.: GEN-IFIT-00016605.0002001 / 21 MAR 16

Manual Shutoff Valves	WATER	Yes
-----------------------	-------	-----

Ident.: GEN-IFIT-00016688.0001001 / 23 JUN 15

Metric Altitude Indications on the PFD	EIS	No
--	-----	----

Ident.: GEN-IFIT-00016536.0001001 / 21 MAR 16

L13

MLS MLS1 MLS2	AUTO FLT	No
---------------------	----------	----

Ident.: GEN-IFIT-00016603.0002001 / 23 JUN 15

NAV Mode automatically Engaged (Armed) in Go-Around	AUTO FLT	Yes
---	----------	-----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00016645.0002001 / 23 JUN 15

OEB Reminder	EIS	Yes
--------------	-----	-----

Ident.: GEN-IFIT-00021528.0001001 / 17 MAR 17

Optional Applications: DCL OCL D-ATIS	FANS	No
--	------	----

Ident.: GEN-IFIT-00016597.0003001 / 21 MAR 16

L13 2 Pairs of Overwing Emergency Exit Overwing Escape Route FWD EMER EXIT	DOORS	Yes
---	-------	-----

Ident.: GEN-IFIT-00016538.0002001 / 21 MAR 16

L13 Parking Brake Monitoring PARK BRK FAULT	BRAKE	Yes
---	-------	-----

Ident.: GEN-IFIT-00021553.0002001 / 17 MAR 17

Predictive GPWS	SURV	Yes
-----------------	------	-----

Ident.: GEN-IFIT-00016608.0002001 / 22 MAR 16

L13 Printer Function in FMS PRINT FUNCTION PRINTER NOT AVAILABLE	AUTO FLT	Yes
---	----------	-----

Ident.: GEN-IFIT-00016609.0002001 / 21 MAR 16

Push to Level Off	AUTO FLT	Yes
-------------------	----------	-----

Ident.: GEN-IFIT-00016648.0002001 / 17 MAR 17

L13 PWS Windshear DET WINDSHEAR DETECTION PRED W/S DET FAULT W/S AHEAD WINDSHEAR AHEAD Windshear PRED W/S DET predictive windshear system PWS SCAN	SURV	Yes
--	------	-----

Ident.: GEN-IFIT-00016695.0001001 / 23 JUN 15

QAR	RECORDING	No
-----	-----------	----

Ident.: GEN-IFIT-00016643.0001001 / 21 MAR 16

L13

QFE BARO Setting QFE OPTION	NAV	No
--------------------------------	-----	----

Ident.: GEN-IFIT-00016610.0001001 / 23 JUN 15

RAAS	SURV	No
------	------	----

Ident.: GEN-IFIT-00016539.0003001 / 21 MAR 16

L13

Rain Repellent System Rain Repellent RAIN RPLNT pb RAIN RPLNT	RAIN	Yes
--	------	-----

Ident.: GEN-IFIT-00016737.0001001 / 23 JUN 15

RMP Load Function	COM	No
-------------------	-----	----

Ident.: GEN-IFIT-00016581.0001001 / 23 JUN 15

RNP pb	NAV	No
--------	-----	----

Ident.: GEN-IFIT-00016582.0001001 / 21 MAR 16

L13

ROW / ROPS ROW /ROP	SURV	No
------------------------	------	----

Ident.: GEN-IFIT-00016583.0002001 / 23 JUN 15

RPCU	CAB PR	Yes
------	--------	-----

Ident.: GEN-IFIT-00016642.0001001 / 22 MAR 17

L13

SATCOM SATCOM DATA FAULT SATCOM FAULT Satellite Communications (SATCOM) SATCOM System	COM	No
---	-----	----

Ident.: GEN-IFIT-00016646.0001001 / 17 MAR 17

L13

SDCU Smoke Detection Control Unit SDCU	SMOKE	No
---	-------	----

Ident.: GEN-IFIT-00016584.0001001 / 23 JUN 15

Second Fire Extinguishing Bottle	FIRE	No
----------------------------------	------	----

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Ident.: GEN-IFIT-00018784.0001001 / 22 MAR 17

L13

Soft Go-Around SOFT GA Go-Around soft	ENG	No
---	-----	----

Ident.: GEN-IFIT-00018785.0001001 / 21 MAR 16

L13

Steep Approach Capability STEEP APPR	NAV	No
---	-----	----

Ident.: GEN-IFIT-00016586.0001001 / 23 JUN 15

T2CAS	SURV	No
-------	------	----

Ident.: GEN-IFIT-00016587.0001001 / 23 JUN 15

T3CAS	SURV	No
-------	------	----

Ident.: GEN-IFIT-00016588.0002001 / 21 MAR 17

L13

Tail Strike Pitch Limit Indicator Tailstrike Pitch Limit Indicator	EIS	Yes
---	-----	-----

Ident.: GEN-IFIT-00018786.0002001 / 21 MAR 16

Temperature Control Panel	COND	Yes
---------------------------	------	-----

Ident.: GEN-IFIT-00016541.0001001 / 23 JUN 15

Thrust Bump	ENG	No
-------------	-----	----

Ident.: GEN-IFIT-00016011.0001001 / 21 MAR 16

L13

TPIS TYRE LO PR	WHEEL	No
--------------------	-------	----

Ident.: GEN-IFIT-00017055.0001001 / 17 MAR 17

HZD switch ON Weather Hazard Prediction Function WX+T+H WX+T+HZD	SURV	No
---	------	----

Ident.: GEN-IFIT-00020783.0001001 / 20 DEC 16

Weight and Balance System (WBS)	EIS	No
---------------------------------	-----	----

Ident.: GEN-IFIT-00016543.0001001 / 21 MAR 16

L13

Wiper Intermittent Position Intermittent Sweep Function Intermittent Sweeping	RAIN	No
---	------	----

**MAIN FCOM CHANGES**

Ident.: GEN-00012867.0001001 / 03 AUG 17

Applicable to: ALL

The purpose of the Main FCOM Changes is to provide operators with general information about the most significant changes that are introduced in the current revision of the manual.

The main FCOM changes are available on the Airbus World portal, under the path: Content Library / Flight Operations / Manuals / Main FCOM - FCTM - MMEL Changes.

In addition, every revised Documentary Unit (DU) has a revision highlight (HL) that:

- Indicates the change(s) made to the DU
- Can be found in the associated “Preliminary Pages – Summary of Highlights” subchapter.

In addition to the Main FCOM Changes, the Modification Operational Impact (MOI ) documents available on the Airbus World portal provide the operational impact linked to a MOD number.

**FCOM PURPOSE**

Ident.: GEN-00012627.0001001 / 17 MAR 17

Applicable to: ALL

**FCOM PURPOSE**

The Flight Crew Operating Manual (FCOM) is a support documentation for flight crew.

The purpose of the FCOM is to:

- Provide all necessary operating limitations, procedures, performance and system information the flight crew needs to safely and efficiently operate A320 family aircraft during normal, abnormal, and emergency situations
- Serve directly as Flight Crew Operating Manual, or as a basis for Operators to develop their own customized Airline Operations Manual, in accordance with applicable requirements
- Serve as a comprehensive reference guide during initial and refresher flight crew training.

*Note:* This manual is not designed:

- To teach basic piloting skills
- To provide basic piloting techniques applicable to jet aircraft, or information, that are considered as basic airmanship for trained flight crews who are familiar with that type of aircraft and its general handling characteristics.

The Flight Crew Operating Manual (FCOM ) complements the Airplane Flight Manual (AFM).

If the FCOM data differs from the AFM data, the AFM remains the reference.

As a supplement to the FCOM , the FCTM may provide additional information that the flight crew should read in conjunction with the FCOM. For more information, *Refer to FCTM/GI FCTM Purpose.*

For any questions or comments related to this manual, the Operator's Flight Operations Management can contact the Airbus Flight Operations Support & Training Standards department.

## FCOM CONTENTS

The FCOM has five sections:

- Aircraft Systems : This section is divided into ATA chapters for each aircraft system. This section includes a specific description of each system and its associated cockpit interfaces.
- Procedures : This section contains the following chapters:
  - Normal Procedures that include the SOP , the SRP, and the Supplementary Procedures
  - Abnormal and Emergency Procedures
  - Special Operations.
- Limitations : This section provides the aircraft and system limitations that the flight crew must know or refer to in operations.
- Operations Engineering Bulletins (OEB)
- Performance : This section includes the aircraft performance for each flight phase.

## DOCUMENTARY UNITS

The FCOM is made of Documentary Units (DU ). The DU is the smallest part of information with a technical content.

The DUs are listed on a separate "List of Effective Documentary Units" (LEDU). *Refer to the General section.*

- Note:
1. *DUs can be grouped into Group of DU (GDU)*
  2. *Temporary information may be provided via Temporary DU (TDU).*

## IDENTIFICATION STRIP

Below the title of the DU, the identification strip provides:

- The list of MSN the DU is applicable to
- For TDU , the reference to the DU impacted by the TDU.

## **LIST OF EFFECTIVE SECTIONS/SUBSECTIONS (LESS) - PAPER ONLY**

Ident.: GEN-00013786.0001001 / 23 JUN 15

Applicable to: **ALL**

The List of Effective Sections/Subsections (LESS ) summarizes all the sections and subsections contained in the FCOM . For each revision, a new LESS is issued when at least one DU of the section/subsection is changed.



The LESS consists of:

- The "M" field that may provide the following evolution code:
  - The "N" letter indicates a new section introduced by the revision
  - The "R" letter indicates a section in which the content has been revised
  - The "E" letter indicates an aircraft validity change within the section
  - The "M" letter indicates a section that have move within the FCOM
- The "Localization" field that allows localizing the section within the manual with the product structure
- The "Subsection title" field
- The "Rev. Date" field that indicated the date at which the section was changed.

### LIST OF EFFECTIVE OPERATIONS ENGINEERING BULLETINS (LEOEB)

Ident.: GEN-00013787.0001001 / 17 MAR 17

Applicable to: ALL

*Refer to OEB-GEN OEB Content and Management*

### LIST OF EFFECTIVE DOCUMENTARY UNITS (LEDU) - PAPER ONLY

Ident.: GEN-00013789.0001001 / 23 MAR 11

Applicable to: ALL

For each revision, a new List of Effective Documentary Units (LEDU ) is issued at the section level. The LEDU provides information about the DU localization, applicability, identification and issue date.

The LEDU consists of:

- The "M" field that may provide the following Evolution Code:
  - The "N" letter indicates a new DU introduced by the revision
  - The "R" letter indicates a revised DU: The content of the DU is updated by the revision. A vertical line in the margin of the DU locates the modified part
  - The "E" letter indicates an aircraft validity change for the DU: The list of MSNs for which the DU is effective has been changed compared to the previous LEDU, by addition or deletion of one or several MSN
- The "Localization" field that allows localizing the DU in the manual with the product structure of the manual
- The "T" field (Temporary Information) that contains a cross if the associated DU is a TDU
- The "DU title" that provides the title of the DU
- The "DU identification" that identifies the DU with its own unique identification number or the GDU with its own unique code.
- The "DU date" that indicates when the DU has been released

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

- The DU criteria which lists the technical or operational criteria for which the DU and solution is applicable to.
- The “Applicable to” which provides the list of aircraft this DU and solution is applicable to
- The “Impacted by TDU” which is the identification of the TDU superseding the DU

**LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS (LETDU) - PAPER ONLY**

Ident.: GEN-00013803.0001001 / 23 JUN 15

**Applicable to: ALL**

The List of Effective Temporary Documentary Units (LETDU) provides a summary of the Temporary DU impacting the section.

The LETDU consists of:

- The "M" field that may provide the following Evolution Code:
  - The "N" letter indicates a new TDU introduced by the revision
  - The "R" letter indicates a revised TDU: The content of the TDU is updated by the revision. A vertical line in the margin of the TDU locates the modified part
  - The "E" letter indicates an aircraft validity change for the TDU: The list of MSNs the TDU is applicable to has been changed compared to the previous LETDU, by addition or deletion of one or several MSN
- The “Localization” field that allows localizing the TDU in the manual with the product structure of the manual
- The “TDU Title” that provides the title of the TDU
- The “TDU identification” that identifies the TDU with its identification number with its own unique code
- The “TDU date” that indicates when the TDU has been released
- The TDU criteria which lists the technical or operational criteria, the it is applicable to
- The “Applicable to” which provides the list of aircraft this TDU is applicable to
- The “Impacted DU” which is the Identification of DU superseded by the TDU
- The “Reason for issue” of the TDU

*Note:* 1. TDU is displayed on a yellow background  
 2. within the QRH the TDU replaces the impacted DU

**AIRCRAFT ALLOCATION TABLE (AAT) - PAPER ONLY**

Ident.: GEN-00013804.0001001 / 23 JUN 15

**Applicable to: ALL**

The Aircraft Allocation Table (AAT ) provides a view of the fleet covered in the FCOM . For each aircraft, the AAT provides its MSN, its registration number and the model.

**LIST OF MODIFICATIONS (LOM) - PAPER ONLY**

Ident.: GEN-00013805.0001001 / 23 JUN 15

Applicable to: ALL

The List of Modifications (LOM) lists the criteria (Modification Proposal (MP) or Service Bulletins (SB)) which the installation on the aircraft affects the FCOM.

Note: Each MP has one or more associated MODs. The MP/MOD correlation is available in AirN@v / Engineering.

The LOM also indicates:

- The title of the criteria
- The date of incorporation of the criteria in the FCOM
- The list of aircraft that have the criteria
- The "M" field that may indicate the following evolution code
  - The "E" letter indicates an aircraft validity change of the criteria. The list of aircraft to which the criteria applies has changed compared to the previous FCOM revision, by addition or deletion of one or several aircraft.
  - The "N" letter indicates new criteria added by this FCOM revision
  - The "R" letter indicates a change in the criteria title or associated SB

**FCOM USE AND ORGANIZATION**

Ident.: GEN-00012688.0001001 / 21 MAR 16

Applicable to: ALL

**DEFINITIONS OF WARNINGS, CAUTIONS AND NOTES**

The following are the official definitions of warnings, cautions and notes taken directly from the JAR25/CS-25 and applicable to Airbus flight operation documentation:

- WARNING** An operating procedure, technique, etc. that may result in personal injury or loss of life if not followed.
- CAUTION** An operating procedure, technique, etc. that may result in damage to equipment if not followed.
- NOTE** An operating procedure, technique, etc. considered essential to emphasize. Information contained in notes may also be safety related.

**INFORMATION TYPE AND LAYERS**

The FCOM has technical information that may be used for:

- Flight crew operations in flight, or on ground
- Airlines operations on ground
- Training.

To take the above-noted objectives into account, the FCOM is organized in three layers as follows:

- Layer 1: "Need to know"  
 Layer 1 presents information that is necessary in the cockpit.
- Layer 2: "Nice to know"  
 Layer 2 presents information that is used as a reference, in order to fully understand the logic of the aircraft and pilot interfaces.
- Layer 3: Detailed information  
 Layer 3 provides more detailed explanations, that are not necessarily needed in flight.

*Note: For paper only, the following examples show the visual characteristics of each kind of layer*


<b>EXAMPLE</b>	- Text in layer 1 Layer 1 is the default layer. No symbology when not following layer 2 or layer 3 information.
----------------	--

<b>L2</b>	<b>EXAMPLE</b>	- Text in layer 2
-----------	----------------	-------------------

<b>L3</b>	<b>EXAMPLE</b>	- Text in layer 3
-----------	----------------	-------------------

<b>L1</b>	<b>EXAMPLE</b>	- Text in layer 1 (as this text follows a text in layer 2 or 3, symbology "L1")
-----------	----------------	---

**OPTIONAL EQUIPMENT**

The legend  (if installed) indicates that a paragraph or an illustration is applicable only if the related optional equipment is installed.

**FCOM FORMAT AND STYLE INFORMATION - PAPER ONLY**




Ident.: GEN-00013793.0001001 / 21 MAR 16

Applicable to: ALL


**TABLE OF CONTENTS**

Each TOC entry has an alphabetical index that identifies this TOC entry within its subsection. The manual user can easily find a TOC entry content within the manual thanks to this alphabetical

index and the subsection identification. Both are indicated in the TOC and both cross-refer to the paper page footer (see the TOC indexing part below).

<ul style="list-style-type: none"> <li>[-] DSC-35 Oxygen             <ul style="list-style-type: none"> <li>[-] Preliminary Pages                 <ul style="list-style-type: none"> <li>Table of Contents</li> <li>Summary of Highlights</li> </ul> </li> <li>[-] DSC-35-10 General                 <ul style="list-style-type: none"> <li>Description</li> </ul> </li> <li>[-] DSC-35-20 Fixed Oxygen System for Cockpit                 <ul style="list-style-type: none"> <li>[-] DSC-35-20-10 Description                     <ul style="list-style-type: none"> <li>General</li> <li>Operation</li> <li>Schematic</li> <li>Mask Setting</li> <li>Mask Stowage</li> </ul> </li> <li>[-] DSC-35-20-20 Controls and Indicators                     <ul style="list-style-type: none"> <li>Overhead Panel</li> <li>Stowage Box</li> <li>Crew Oxygen Mask</li> <li>Pressure Regulator</li> <li>DOOR/OXY ECAM Page</li> </ul> </li> <li>[-] DSC-35-20-30 Electrical Supply</li> <li>[-] DSC-35-30 Fixed Oxygen System for Cabin</li> <li>[-] DSC-35-40 Portable Oxygen System</li> </ul> </li> </ul> </li> </ul>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; text-align: center;">   <b>A318/A319/A320/A321</b>  <small>FLIGHT CREW OPERATING MANUAL</small> </td> <td style="text-align: center;"> <b>AIRCRAFT SYSTEMS</b>  <b>OXYGEN</b>  <small>PRELIMINARY PAGES - TABLE OF CONTENTS</small> </td> </tr> </table> <p><b>DSC-35-10 General</b> Description ..... A</p> <p><b>DSC-35-20 Fixed Oxygen System for Cockpit</b></p> <p>DSC-35-20-10 Description</p> <p>General ..... A</p> <p>Operational ..... B</p> <p>Schematic ..... C</p> <p>Mask Setting ..... D</p> <p>Mask Stowage ..... E</p> <p>DSC-35-20-20 Controls and Indicators</p> <p>Overhead Panel ..... A</p> <p>Stowage Box ..... B</p> <p>Crew Oxygen Mask ..... C</p> <p>Pressure Regulator ..... D</p> <p>DOOR/OXY ECAM Page ..... E</p> <p>DSC-35-20-30 Electrical Supply</p> <p>Bus Equipment List ..... A</p>	 <b>A318/A319/A320/A321</b> <small>FLIGHT CREW OPERATING MANUAL</small>	<b>AIRCRAFT SYSTEMS</b> <b>OXYGEN</b> <small>PRELIMINARY PAGES - TABLE OF CONTENTS</small>
 <b>A318/A319/A320/A321</b> <small>FLIGHT CREW OPERATING MANUAL</small>	<b>AIRCRAFT SYSTEMS</b> <b>OXYGEN</b> <small>PRELIMINARY PAGES - TABLE OF CONTENTS</small>		

### HEADER AND FOOTER



1. Airline logo
2. Aircraft types and manual
3. Level 2 chapter (PSL level 2 : GEN, DSC, PRO, LIM, OEB, PER)
4. Level 3 chapter
5. Level 4 chapter
6. Revision mark
7. Key product (document identification and aircraft designation)
8. Key product (manual code)
9. Page index
10. Last evolution date
11. Identification strip (list of impacted aircraft)
12. PSL path

## REVISION MARK


In the paper format, a vertical bar in the margin of the DU identifies the modified part. Each vertical bar has a numerical index that refers to the associated reason of the change in the Summary of Highlight.

This Summary of Highlight lists all the changes and associated reasons of the change (if necessary) that the revision has introduced.

## TOC INDEXING

In the paper page footer, the TOC indexing is of the following type:

- A : The paper page contains the whole "A" TOC entry content
- A to B : The paper page contains the whole "A" and "B" TOC entries contents
- A → : The "A" TOC entry content starts on this paper page and continues on the following paper page
- ← A : The "A" TOC entry content starts on a previous paper page and finishes on this paper page
- ← A → : The "A" TOC entry content starts on a previous paper page and continues on the following paper page
- A to C→ : The paper page contains the whole "A" and "B" TOC entries contents but the "C" TOC entry content starts on this paper page and continues on the following paper page

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>GENERAL INFORMATION</b>
---	----------------------------

- ← A to C : The paper page contains the whole "B" and "C" TOC entries contents but the "A" TOC entry content starts on a previous paper page and finishes on this paper page
- ← A to C → : The paper page contains the whole "B" TOC entry content but the "A" TOC entry content starts on a previous paper page and finishes on this paper page and the "C" TOC entry content starts on this paper page and continues on the following paper page

- Note:*
1. The indexes follow the alphabetical order: A, B, C, ..., Z, AA, AB, AC, ..., AZ, BA, BB, BC, ...
  2. For each subsection, the index starts again from A.
  3. When a TOC entry content continues on the following paper page, the text "Continued on the following page" is also indicated.

<b>FCOM REVISIONS</b>
-----------------------

Ident.: GEN-00012634.0001001 / 24 OCT 14  
 Applicable to: ALL

**FCOM REVISION**

FCOM revisions are issued to add, update, or revise information. The Operator determines the revision periodicity.  
 When necessary, a revision may be issued in between the defined periodicity (e.g. need for urgent update).  
 A vertical bar appears to the left of all revised parts of the manual.

**TEMPORARY INFORMATION**

Some FCOM sections may need a temporary update (e.g. to explain a system behavior that will be modified by a future standard). In such cases, the applicable FCOM section is updated with a Temporary Documentary Unit (TDU).  
 Information contained in the TDU is highlighted in the manual and the initial content of the FCOM remains available for consultation and comparison and is highlighted (identification strip) as being impacted by the TDU.  
 A List of Effective Documentary Units (LEDU ) is provided in the FCOM

**OPERATIONS ENGINEERING BULLETINS**

Operations Engineering Bulletins (OEB) are issued, when it is necessary, to rapidly transmit technical and procedural information.  
 The OEB chapter provides a list of all applicable OEBs.

**ABBREVIATIONS**

Ident.: GEN-00012598.0001001 / 05 SEP 17

Applicable to: **ALL**

**A**

Abbreviation	Term
A>B	A is greater than B
A≥B	A is greater than or equal to B
A<B	A is less than B
A≤B	A is less than or equal to B
A/BRK	Autobrake
A/C	Aircraft
A/P	Autopilot
AP	Autopilot
A/S	Airspeed
A/SKID	Anti-skid
A/THR	Auto Thrust
AA	Airworthiness Authorities
AAL	Above Aerodrome Level
AAT	Aircraft Allocation Table
AB	Abort
ABCU	Alternate Braking Control Unit
ABN	Abnormal
ABV	Above
AC	Alternating Current
ACARS	ARINC Communication Addressing and Reporting System
ACAS	Airborne Collision Avoidance System
ACCEL	Acceleration
ACC	Active Clearance Control
ACCU	Accumulator
ACP	Audio Control Panel
ACS	Aircraft Configuration Summary
ACSC	Air Conditioning System Controller
ACT	Additional Center Tank
ADC	Air Data Computer
ADF	Automatic Direction Finder
ADIRS	Air Data Inertial Reference System
ADIRU	Air Data Inertial Reference Unit
ADM	Air Data Module
ADR	Air Data Reference
ADS-B	Automatic Dependent Surveillance - Broadcast
ADS-C	Automatic Dependent Surveillance - Contract

*Continued on the following page*



*Continued from the previous page*

<b>Abbreviation</b>	<b>Term</b>
ADV	Advisory
AEVC	Avionic Equipment Ventilation Controller
AFM	Airplane Flight Manual
AFS	Auto Flight System
AGL	Above Ground Level
AIDS	Aircraft Integrated Data System
AIL	Aileron
AIME	Autonomous Integrity Monitoring Extrapolation
AIP	Attendant Indication Panel
AIU	Audio Interface Unit
ALT	Altitude
ALTN	Alternate
AMC	Acceptable Means of Compliance
AMI	Airline Modifiable Information
AMU	Audio Management Unit
ANT	Antenna
AOA	Angle of Attack
AOC	Airline Operational Control
APP	Approach
APPR	Approach
APPU	Assymetry Position Pick-off Unit
APU	Auxiliary Power Unit
AR	Authorization Required
ARINC	Aeronautical Radio Incorporated
ARN	Aircraft Registration Number
ARP	Aerospace Recommended Practice
ARPT	Airport
ASAP	As Soon As Possible
ASD	Accelerate Stop Distance
ASI	Air Speed Indicator
ASP	Audio Selector Panel
ATC	Air Traffic Control
ATM	Air Traffic Management
ATN	Aeronautical Telecommunications Network
ATE	Automatic Test Equipment
ATIS	Automatic Terminal Information System
ATS	Auto Thrust System
ATSAW	Airborne Traffic Situational Awareness
ATSU	Air Traffic Service Unit
ATT	Attitude

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
AUTO	Automatic
AVNCS	Avionics
AWY	Airway

**B**

Abbreviation	Term
B/C	Back Course
BARO	Barometric
BAT	Battery
BCL	Battery Charge Limiter
BCDS	Bite Centralized Data System
BCU	Backup Control Unit
BDDV	Brake Dual Distribution Valve
BITE	Built-In Test Equipment
BIU	BITE Interface Unit
BFE	Buyer Furnished Equipment
BFO	Beat Frequency Oscillator
BMC	Bleed Monitoring Computer
BNR	Binary
BRG	Bearing
BRK	Brake
BRT	Bright
BSCU	Braking Steering Control Unit
BTC	Bus Tie Contactor
BTL	Bottle
BTS	Bleed Temperature Sensor
BUS	Busbar
BUSS	Back Up Speed Scale

**C**

Abbreviation	Term
C/B	Circuit Breaker
CB	Circuit Breaker
C/L	Checklist
CL	Checklist
CAB	Cabin
CAPT	Captain, Capture
CAS	Calibrated Airspeed
CAT	Category
CBMS	Circuit Breaker Monitoring System

*Continued on the following page*

*Continued from the previous page*

<b>Abbreviation</b>	<b>Term</b>
CCD	Cursor Control Device
CDL	Configuration Deviation List
CDLS	Cockpit Door Locking System
CDSS	Cockpit Door Surveillance System
CDU	Control Display Unit
CF	Cost of Fuel
CFDIU	Centralized Fault Display Interface Unit
CFDS	Centralized Fault Display System
CFP	Computerized Flight Plan
CG	Center of Gravity
CHAN	Channel
CHG	Change
CHK	Check
CI	Cost Index
CIDS	Cabin Intercommunication Data System
CIDS-SDF	Cabin Intercommunication Data System - Smoke Detection Function
CKPT	Cockpit
CIS	Commonwealth of Independent States
CLB	Climb
CLR	Clear
CLSD	Closed
CM1(2)	Crewmember 1 (left seat) or 2 (right seat)
CM1	Crewmember 1 (left seat)
CM2	Crewmember 2 (right seat)
CMPTR	Computer
CMS	Constant Mach Segment
CMS	Centralized Maintenance System
CNSU	Cabin Network Server Unit
CO	Company
CO RTE	Company Route
COND	Conditioning
CONF	Configuration
CONT	Continuous
CPC	Cabin Pressure Controller
CPCU	Cabin Pressure Controller Unit
CPDLC	Controller-Pilot Data Link Communication
CRC	Continuous Repetitive Chime
CRG	Cargo
CRS	Course
CRT	Cathode Ray Tube

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
CRZ	Cruise
CSAS	Conditioned Service Air System
CSCU	Cargo Smoke Control Unit
CSD	Constant Speed Drive
CSM/G	Constant Speed Motor/Generator
CSTR	Constraint
CT	Cost of Time
CTL	Control
CTL PNL	Control Panel
CTR	Center
CVR	Cockpit Voice Recorder

**D**

Abbreviation	Term
DA	Drift Angle
DAC	Digital to Analog Converter
DAC	Double Annular Combustor
DAR	Digital AIDS Recorder
DC	Direct Current
DCDU	Datalink Control and Display Unit
DCL	Digital Cabin Logbook
DDRMI	Digital Distance and Radio Magnetic Indicator
DECEL	Deceleration
DES	Descent
DEST	Destination
DET	Detection, Detector
DEV	Deviation
DFA	Delayed Flap Approach
DFDR	Digital Flight Data Recorder
DH	Decision Height
DIR	Direction
DIR TO	Direct To
DISC	Disconnect
DISCH	Discharge
DIST	Distance
DITS	Digital Information Transfer System
DIV	Diverter
DMC	Display Management Computer
DME	Distance Measuring Equipment
DMU	Data Management Unit (Aids)

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
DN	Down
DPO	Descent Profile Optimization
DSDL	Dedicated Serial Data Link
DTG	Distance To Go
DTO	Derated Takeoff
DU	Display Unit
DU	Documentary Unit

**E**

Abbreviation	Term
EWD	Engine/Warning Display
ECAM	Electronic Centralized Aircraft Monitoring
ECAS	Emergency Cockpit Alerting System
ECB	Electronic Control Box (APU)
ECM	Engine Condition Monitoring
ECON	Economic
ECP	ECAM Control Panel
ECS	Environmental Control System
ECU	Engine Control Unit
EDP	Engine-Driven Pump
EEC	Electronic Engine Computer
EFB	Electronic Flight Bag
EFCS	Electronic Flight Control System
EFIS	Electronic Flight Instruments System
EFF	Electronic Flight Folder
EFOB	Estimated Fuel On Board
EGPWS	Enhanced Ground Proximity Warning System
EGT	Exhaust Gas Temperature
EIS	Electronic Instruments System
EIU	Engine Interface Unit
ELAC	Elevator Aileron Computer
ELEC	Electrics
ELT	Emergency Locator Transmitter
ELEV	Elevator
ELV	Elevation
EMER	Emergency
EMER GEN	Emergency Generator
ENG	Engine
EO	Engine-Out
EOSID	Engine-Out Standard Instrument Departure

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
EPE	Estimated Position Error (equal to EPU)
EPR	Engine Pressure Ratio
EPU	Emergency Power Unit
EPU	Estimated Position Uncertainty (equal to EPE)
EQPT	Equipment
EROPS	Extended Range Operation
ESS	Essential
EST	Estimated
ETA	Estimated Time of Arrival
ETE	Estimated Time Enroute
ETOPS	Extended Twin Operations
ETP	Equal Time Point
EVMU	Engine Vibration Monitoring Unit
EWD	Engine/Warning Display
EXP	Expedite
EXT PWR	External Power
EXTN	Extension

**F**

Abbreviation	Term
F	Fuel
FAA	Federal Aviation Administration
FAP	Forward Attendant Panel
F/C	Flight Crew
F/O	First Officer
FO	First Officer
FAC	Flight Augmentation Computer
FADEC	Full Authority Digital Engine Control System
FAF	Final Approach Fix
FANS	Future Air Navigation System
FAP	Forward Attendant Panel
FAR	Federal Aviation Regulations
FAV	Fan Air Valve
FCDC	Flight Control Data Concentrator
FCMS	Fuel Control and Monitoring System
FCOM	Flight Crew Operating Manual
FCTM	Flight Crew Techniques Manual
FCU	Flight Control Unit
FD	Flight Director
FDGJ	Fan Drive Gear System

*Continued on the following page*

*Continued from the previous page*

<b>Abbreviation</b>	<b>Term</b>
FDIMU	Flight Data Interface and Management Unit
FDIU	Flight Data Interface Unit
FDU	Fire Detection Unit
FEP	Final End Point
FF	Fuel Flow
FG	Flight Guidance
FGC	Flight Guidance Computer
F-G/S	FLS Glide Slope
FIDS	Fault Isolation and Detection System
FL	Flight Level
FLEX	Flexible
FLHV	Fuel Lower Heating Value
F-LOC	FLS Localizer
FLP	Flap
FLS	FMS Landing System
FLSCU	Fuel Level Sensing Control Unit
FLT	Flight
F/CTL	Flight Control
FLT CTL	Flight Control
FLXTO	Flexible Takeoff
FM	Flight Management
FMA	Flight Mode Annunciator
FMGC	Flight Management and Guidance Computer
FMGS	Flight Management and Guidance System
FMS	Flight Management System
FMV	Fuel Metering Valve
FNL	Final
FOB	Fuel On Board
FOHE	Fuel Oil Heat Exchanger
FOM	Figure Of Merit
FPA	Flight Path Angle
F-PLN	Flight Plan
FPD	Flight Path Director
FPPU	Feedback Position Pick-off Unit
FPV	Flight Path Vector
FQ	Fuel Quantity
FQI	Fuel Quantity Indication
FQIC	Fuel Quantity Indication Computer
FQU	Fuel Quantity Unit
FREQ	Frequency

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
FRT	Front
FRV	Fuel Return Valve
FTIS	Fuel Tank Inerting System
FU	Fuel Used
FWC	Flight Warning Computer
FWD	Forward
FWS	Flight Warning System

**G**

Abbreviation	Term
G/S	Glideslope
GA	Go-Around
GAPCU	Ground and Auxiliary Power Control Unit
GBAS	Ground Based Augmentation System
GCU	Generator Control Unit
GDU	Group of Documentary Unit
GEN	Generator
GES	Ground Earth Station
GLC	Generator Line Contactor
GLS	GBAS Landing System
GLS	GNSS Landing System
GMT	Greenwich Mean Time
GND	Ground
GND TEMP	Ground Temperature
GNSS	Global Navigation Satellite System
GPCU	Ground Power Control Unit
GPIRS	Global Positioning and Inertial Reference System
GPS	Global Positioning System
GPWS	Ground Proximity Warning System
GRND	Ground
GRP	Geographic Reference Point
GRVTY	Gravity
GS	Ground Speed
GSM	Global System for Mobile Communication
GW	Gross Weight

**H**

Abbreviation	Term
HC	Harness Connector
HCU	Hydraulic Control Unit

*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

*Continued from the previous page*

Abbreviation	Term
HDG	Heading
HDG/S	Heading Selected
HDL	Handle
HF	High Frequency
HI	High
HLD	Hold
HM	Holding Pattern with a Manual Termination
HMU	Hydrau-Mechanical Unit
HMS	Heat Management System
HP	High Pressure
HPA	Hectopascal
HPC	High Pressure Compressor
HPSOV	High Pressure Shut-off Valve
HPT	High Pressure Turbine
HPV	High Pressure Valve
HUD	Head Up Display
HUDC	Head Up Display Computer
HYD	Hydraulic

!

Abbreviation	Term
I/O	Inputs/Outputs
I/P	Input or Intercept Profile
IAF	Initial Approach Fix
IAS	Indicated Airspeed
IATA	International Air Transport Association
ICAO	International Air Transport Organization
IDENT	Identification
IDG	Integrated Drive Generator
IFE	In Flight Entertainment
IFPC	Integrated Fuel Pump and Control
IFR	Instrument Flight Rules
IGGS	Inert Gas Generation System
IGN	Ignition
INHIB	Inhibited
ILS	Instrument Landing System
IM	Inner Marker
IMC	Instrument Meteorological Conditions
IMM	Immediate
INB	Inbound

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
INBO	Inboard
INCREM	Increment
IND	Indicator
INIT	Initialization
INOP	Inoperative
INR	Inner
INST	Instrument
INTCPT	Intercept
INV	Inverter
IP	Intermediate Pressure
IPC	Intermediate Pressure Check valve
IPPU	Instrumentation Position Pick-off Unit
IR	Inertial Reference
IRS	Inertial Reference System
ISA	International Standard Atmosphere
ISDU	Initial System Display Unit
ISIS	Integrated Standby Instrument System
ISOL	Isolation
ISPSS	In Seat Power Supply System
ITP	In-Trail Procedure

**J**

Abbreviation	Term
JAA	Joint Aviation Authorities
JAR	Joint Aviation Requirements

**K**

Abbreviation	Term
--------------	------

**L**

Abbreviation	Term
L/G	Landing Gear
LAF	Load Alleviation Function
LAT	Lateral
LAT	Latitude
LAT REV	Lateral Revision
LAV	Lavatory
LCD	Liquid Crystal Display
LCN	Load Classification Number

*Continued on the following page*

*Continued from the previous page*

<b>Abbreviation</b>	<b>Term</b>
LDA	Landing Distance Available
	Localizer Directional Aid
L DEV	Lateral Deviation
LDG	Landing
LDS	Laptop Docking Station
LED	Light Emitting Diode
LEDU	List of Effective Documentary Units
LEOEB	List of Effective Operations Engineering Bulletins
LESS	List of Effective Section/Subsections
LF	Low Frequency
LGCIU	Landing Gear Control Interface Unit
LGPIU	Landing Gear Position Indicator Unit
LH	Left-Hand
LIM	Limitation
LIS	Localizer Inertial Smoothing
LK	Lock
LL	Latitude/Longitude
LLS	Left-Line Select key
LO	Low
LOC	Localizer
LONG	Longitude
LP	Low Pressure
LPC	Low Pressure Compressor
LPT	Low Pressure Turbine
LRRA	Low Range Radio Altimeter
LRU	Line Replaceable Unit
LS	Loudspeaker
LSK	Line Select Key
LT	Light
LTS	Load and Trim Sheet
LVL	Level
LVL/CH	Level Change
LVR	Lever
LW	Landing Weight

**M**

<b>Abbreviation</b>	<b>Term</b>
MABH	Minimum Approach Break-off Height
MAC	Mean Aerodynamic Chord
MAG	Magnetic

*Continued on the following page*

*Continued from the previous page*

<b>Abbreviation</b>	<b>Term</b>
MAG DEC	Magnetic Declination
MAG VAR	Magnetic Variation
MAINT	Maintenance
MAN	Manual
MAP	Missed Approach Point
MAX	Maximum
MAX CLB	Maximum Climb
MAX DES	Maximum Descent
MAX END	Maximum Endurance
MC	Master Caution
MCDU	Multipurpose Control and Display Unit
MCT	Maximum Continuous Thrust
MCU	Modular Concept Unit
MDA	Minimum Descent Altitude
MDDU	Multifunction Disk Drive Unit
MDH	Minimum Descent Height
MECH	Mechanic
MEA	Minimum En Route Altitude
MED	Medium
MEL	Minimum Equipment List
MFA	Memorized Fault Annunciator
MGB	Main Gearbox
MIN	Minimum
MKR	Marker
MLA	Maneuver Load Alleviation
MLG	Main Landing Gear
MLS	Microwave Landing System
MLW	Maximum Landing Weight
MM	Middle Marker
MMEL	Master Minimum Equipment List
MMO	Maximum Operating Mach
MMR	Multi Mode Receiver
MN	Mach number
MORA	Minimum Off Route Altitude
MP	Modification Proposal
MRIU	Maintenance and Recording Interface Unit
MSA	Minimum Safe Altitude
MSG	Message
MSL	Mean Sea Level
MSU	Mode Selector Unit

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
MTBF	Mean Time Between Failure
MTC	Modulated Turbine Cooling
MTOW	Maximum Takeoff Weight
MZFW	Maximum Zero Fuel Weight

**N**

Abbreviation	Term
N/A	Not Applicable
NA	Not Applicable
N1	Low Pressure Rotor Speed (in %)
N2	High Pressure Rotor Speed (in %)
NACA	National Advisory Committee for Aeronautics
NAI	Engine Nacelle Anti-Ice
NAV	Navigation
NAVAID	Navigation Aid
NCD	Non Computed Data
ND	Navigation Display
NDB	Non Directional Beacon
NLG	Nose Landing Gear
NORM	Normal
NPA	Non Precision Approach
NW	Nosewheel
NWS	Nosewheel Steering

**O**

Abbreviation	Term
O/P	Output
OANS	On-board Airport Navigation System
OAT	Outside Air Temperature
OBRM	On Board Replaceable Module
OEB	Operations Engineering Bulletin
OFF/R	Off Reset
OFST	Offset
OIS	Onboard Information System
OIT	Onboard Information Terminal
OLB	OPS Library Browser
OM	Outer Marker
OP	Open
OPP	Opposite
OPS	Operations

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
OPT	Optimum
OUTB	Outbound
OUTR	Outer
OVBD	Overboard
OVHD	Overhead
OVHT	Overheat
OVRD	Override
OVSPD	Overspeed
OXY	Oxygen

**P**

Abbreviation	Term
P/N	Part Number
PN	Part Number
PA	Passenger Address
P-ALT	Profile Altitude
PAX	Passenger
PAR	Precision Approach Radar
PBCS	Performance-Based Communication and Surveillance
PBE	Portable Breathing Equipment
PBN	Performance Based Navigation
P-CLB	Profile Climb
PCU	Power Control Unit
P-DES	Profile Descent
PDB	Performance Data Base
PDU	Pilot Display Unit
PED	Portable Electronic Device
PERF	Performance
PES	Passenger Entertainment System
PF	Pilot Flying
PFC	Porous Friction Course
PFD	Primary Flight Display
PHC	Probes Heat Computer
P-MACH	Profile Mach
PM	Pilot Monitoring
PNL	Panel
POB	Pressure Off Brake
POS	Position
PPOS	Present Position
PPU	Position Pick-off Unit

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
PR	Pressure
PRED	Prediction
PRESS	Pressure, Pressurization
PROC	Procedure
PROC T	Procedure Turn
PROF	Profile
PROG	Progress
PROTEC	Protection
P-SPEED	Profile Speed
PSL	Product Structure Level
PSU	Passenger Service Unit
PT	Point
PTR	Printer
PTT	Push To Talk
PTU	Power Transfer Unit (Hydraulic)
PVI	Paravisual Indicator
PWR	Power
PWS	Predictive Windshear System

**Q**

Abbreviation	Term
QAR	Quick Access Recorder
QFE	Field Elevation Atmosphere Pressure
QFU	Runway Heading
QNE	Sea Level Standard Atmosphere Pressure (1013 hPa)
QNH	Sea Level Atmosphere Pressure
QRH	Quick Reference Handbook
QT	Quart (US)
QTY	Quantity

**R**

Abbreviation	Term
R/I	Radio/Inertial
RA	Radio Altimeter, Resolution Advisory
RAAS	Runway Awareness and Advisory System
RACC	Rotor Active Clearance Control
RAD	Radio
RAIM	Receiver Autonomous Integrity Monitoring
RAT	Ram Air Turbine
RATC	Remote ATC Box

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
RCDR	Recorder
RCL	Recall
RCP	Required Communication Performance
RCVR	Receiver
REAC	Reactive
REC	Recommended
RED	Reduction
REG	Regulation
REL	Release
REV	Reverse
RH	Right-Hand
RLD	Required Landing Distance
RLSK	Right Line Select Key
RMI	Radio Magnetic Indicator
RMP	Radio Management Panel
RNAV	Area Navigation
RNG	Range
RNP	Required Navigation Performance
ROP	Runway Overrun Protection
ROPS	Runway Overrun Prevention System
ROW	Runway Overrun Warning
RPCU	Residual Pressure Control Unit
RPM	Revolution Per Minute
RPTG	Repeating
RQRD	Required
RSP	Required Surveillance Performance
RSV	Reserves
RSVR	Reservoir
RTA	Required Time of Arrival
RTE	Route
RTL	Rudder Travel Limit
RTO	Rejected Takeoff
RTOW	Regulatory Takeoff Weight
RUD	Rudder
RVSM	Reduced Vertical Separation Minimum
RWY	Runway



**S**

<b>Abbreviation</b>	<b>Term</b>
S	South
S/C	Step Climb
S/D	Step Descent
S/D	Shut Down
S/F	Slats/Flaps
S/N	Serial Number
SN	Serial Number
SAAAR	Special Aircrew and Aircraft Authorization Required
SAC	Single Annular Chamber
SAT	Static Air Temperature
SATCOM	Satellite Communication
SC	Single Chime
SCP	Software Control Panel
SD	System Display
SDAC	System Data Acquisition Concentrator
SDCU	Smoke Detection Control Unit
SDF	Smoke Detection Function, Simplified Directional Facility
SEC	Spoiler Elevator Computer
SEL	Selector
SFCC	Slat/Flap Control Computer
SFE	Seller-Furnished Equipment
SID	Standard Instrument Departure
SIM	Simulation
SLT	Slat
SOP	Standard Operating Procedure
SPD	Speed
SPD LIM	Speed Limit
SPLR	Spoiler
SRS	Speed Reference System
STAR	Standard Terminal Arrival Route
STAT	Static
STAT INV	Static Inverter
STBY	Standby
STD	Standard
STEER	Steering
STRG	Steering
STS	Status
SWTG	Switching
SYNC	Synchronize
SYS	System

**T**

Abbreviation	Term
T.O	Takeoff
T/O	Takeoff
TO	Takeoff
T/C	Top of Climb
T/D	Top of Descent
TA	Traffic Advisory
TAC	Taxiing Aid Camera
TACAN	Tactical Air Navigation
TACT	Tactical
TAS	True Air Speed
TAT	Total Air Temperature
TAU	Time to intercept
TAWS	Terrain Awareness and Warning System
TBC	To Be Confirmed
TBD	To Be Determined
T2CAS	Traffic and Terrain Collision Avoidance System
T3CAS	Traffic and Terrain Collision Avoidance System
TCA	Turbine Cooling Air
TCAS	Traffic Alert and Collision Avoidance System
TCC	Turbine Case Cooling
TCM	Thrust Control Malfunction
TDU	Temporary Documentary Unit
TEMP	Temperature
TFTS	Terrestrial Flight Telephon System
TGT	Target
THR	Thrust
THS	Trimable Horizontal Stabilizer
TK	Tank
TK	Track angle
TKE	Track Angle Error
TLA	Throttle Lever Angle
TLU	Travel Limitation Unit
TMR	Timer
TOC	Table of Contents
TOD	Takeoff Distance
TOGA	Takeoff - Go-Around
TOGW	Takeoff Gross Weight
TOR	Takeoff Run
TOW	Takeoff Weight

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
T-P	Turn Point
TPIS	Tire Pressure Indicating System
TR	Transformer Rectifier
T-R	Transmitter-Receiver
TRANS	Transition
TRK	Track
TROPO	Tropopause
TRU	Transformer Rectifier Unit
TRV	Travel
TSM	Trouble Shooting Manual
TTG	Time to Go
TVMC	Minimum Control Speed Temperature
TWY	Taxiway

**U**

Abbreviation	Term
UFD	Unit Fault Data
ULB	Underwater Locator Beacon
UNLK	Unlock
UP	Up, Upper
USB	Universal Serial Bus
UTC	Universal Coordinated Time

**V**

Abbreviation	Term
V/S	Vertical Speed
V1	Decision Speed
V2	Takeoff Safety Speed
VAPP	Approach Speed
VBV	Variable Bypass Valve
VC	Calibrated airspeed
VDEV	Vertical Deviation
VEL	Velocity
VERT	Vertical
VERT REV	Vertical Revisor
VFE	Maximum Speed for each Flap configuration
VFEN	VFE Next
VFTO	Final Takeoff Speed
VHF	Very High Frequency
VHV	Very High Voltage

*Continued on the following page*

*Continued from the previous page*

Abbreviation	Term
VIB	Vibration
VIP	Vertical Intersection Point
VLE	Maximum Landing Gear Extended Speed
VLS	Lowest Selectable Speed
VLV	Valve
VM	Maneuvering Speed
VMAX	Maximum Allowable Speed
VMC	Visual Meteorological Conditions
VMCA	Minimum Control Speed in the Air
VMCG	Minimum Control Speed on Ground
VMCL	Minimum Control Speed at Landing
VMIN	Minimum Operating Speed
VMO	Maximum Operating Speed
VMU	Minimum Unstick Speed
VOR	VHF Omnidirectional Range
VOR-D	VOR-DME
VR	Rotation Speed
VREF	Landing Reference Speed
VSC	Vacuum System Controller
VSI	Vertical Speed Indicator
VSV	Variable Stator Vane
VU	Visual Unit

**W**

Abbreviation	Term
W/S	Wind Shear
WAI	Wing Anti-Ice
WARN	Warning
WBm	Weight and Balance Manual
WBS	Weight and Balance System
WBS	Weight and Balance System
WD	Warning Display
WGD	Windshield Guidance Display
WHC	Window Heat Computer
WNDW	Window
WPT	Waypoint
WSHLD	Windshield
WT	Weight
WTB	Wing Tip Brake
WXR	Weather Radar

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**X**

Abbreviation	Term
XBLD	Crossbleed
XCVR	Transceiver
XFR	Transfer
XMTR	Transmitter
XPDR	Transponder
XTK	Crosstrack Error

**Y**

Abbreviation	Term
--------------	------

**Z**

Abbreviation	Term
ZFCG	Zero Fuel Center of Gravity
ZFW	Zero Fuel Weight
ZFWCG	Zero Fuel Weight Center of Gravity field
Zp	Pressure Altitude

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

Intentionally left blank

# **AIRCRAFT SYSTEMS**

Intentionally left blank



**DSC-20 Aircraft General**

**DSC-21 Air Conditioning / Pressurization / Ventilation**

**DSC-22\_10 Auto Flight - General**

**DSC-22\_20 Auto Flight - Flight Management**

**DSC-22\_30 Auto Flight - Flight Guidance**

**DSC-22\_40 Auto Flight - Flight Augmentation**

**DSC-22\_45 Auto Flight - AOC Functions**

**DSC-22\_46 Auto Flight - Print Interface**

**DSC-23 Communications**

**DSC-24 Electrical**

**DSC-25 Equipment**

**DSC-26 Fire Protection**

**DSC-27 Flight Controls**

**DSC-28 Fuel**

**DSC-29 Hydraulic**

**DSC-30 Ice and Rain Protection**

**DSC-31 Indicating/Recording Systems**

**DSC-32 Landing Gear**

**DSC-33 Lights**

**DSC-34-NAV Navigation**

*Continued on the following page*

*Continued from the previous page*

**DSC-34-SURV Surveillance**

**DSC-35 Oxygen**

**DSC-36 Pneumatic**

**DSC-38 Water / Waste**

**DSC-45 Maintenance System**

**DSC-46 Information Systems**

**DSC-49 APU**

**DSC-52 Doors**

**DSC-56 Cockpit Windows**

**DSC-70 Engines**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PRELIMINARY PAGES

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

M	Localization	DU Title	DU identification	DU date
---	--------------	----------	-------------------	---------

No Temporary Documentary Unit



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

Intentionally left blank

# **AIRCRAFT SYSTEMS**

AIRCRAFT GENERAL

Intentionally left blank

**DSC-20-10 Overview**

General.....	A
Engines.....	B
Cockpit.....	C
Cabin.....	D
Cargo.....	E

**DSC-20-20 Description**

General Arrangement.....	A
Principal Dimensions.....	B
Unpressurized Compartments.....	C
Antenna Locations.....	D
Ground Service Connections and Panels.....	E



**DSC-20-30 Ground Handling**

Taxiing.....	A
180 degrees Turn on Runway.....	B

**DSC-20-40 Ground Clearance Diagram**

Ground Clearance Diagram.....	A
-------------------------------	---

**DSC-20-50 Landing Geometry**

ILS/GLS  /MLS  Final Approach and Landing Geometry.....	A
Minimum Visual Ground Segments (Flare Phase).....	B

**DSC-20-60 Visual Ground Geometry**

Visual Ground Geometry.....	A
-----------------------------	---



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AIRCRAFT GENERAL

#### OVERVIEW

#### GENERAL

Ident.: DSC-20-10-00000284.0001001 / 22 MAR 16

**Applicable to: ALL**

The A320 is a subsonic, medium-range, civil transport aircraft.

#### ENGINES

Ident.: DSC-20-10-00000285.0001001 / 13 DEC 10

**Applicable to: ALL**

The aircraft has two high bypass turbofan engines mounted under the wings.

#### COCKPIT

Ident.: DSC-20-10-00000286.0002001 / 13 DEC 10

**Applicable to: ALL**

The cockpit is designed for a two-member crew. It also has a place for 2 observers.

#### CABIN

Ident.: DSC-20-10-00000287.0007001 / 05 FEB 15

**Applicable to: ALL**

The passenger seating layout may vary, depending on operating requirements.

#### CARGO

Ident.: DSC-20-10-00000289.0001001 / 13 DEC 10

**Applicable to: ALL**

Two cargo compartments are under the cabin floor.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**

OVERVIEW

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**

DESCRIPTION

**GENERAL ARRANGEMENT**

Ident.: DSC-20-20-00000290.0001001 / 21 MAR 16


**Applicable to: ALL**

This subchapter gives the principal aircraft dimensions, location of unpressurized areas, antennas, ground service connections, and ground maneuvering characteristics.

**PRINCIPAL DIMENSIONS**

Ident.: DSC-20-20-00000291.0001001 / 22 MAY 12


Applicable to: ALL



**UNPRESSURIZED COMPARTMENTS**

Ident.: DSC-20-20-00000292.0001001 / 21 MAR 16


Applicable to: ALL



**ANTENNA LOCATIONS**

Ident.: DSC-20-20-00000293.0001001 / 28 JUL 14


Applicable to: ALL



**GROUND SERVICE CONNECTIONS AND PANELS**

Ident.: DSC-20-20-00000295.0001001 / 09 OCT 12

Applicable to: ALL



- (1) Toilet servicing
- (2) Water filling and/or draining
- (3) Electrical ground power receptacle
- (4) LP ground air supply connector
- (5) HP ground air supply connector
- (6) Hydraulic
- (7) IDG oil filling
- (8) Engine oil filling
- (9) Refueling/defueling

- (10) Gravity filling panels
- (11) Refueling/defueling panel
- (12) APU oil filling



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**

DESCRIPTION


Intentionally left blank



**TAXIING**

Ident.: DSC-20-30-00000294.0002001 / 01 JUN 17

Applicable to: ALL



**180 DEGREES TURN ON RUNWAY**


Ident.: DSC-20-30-00021674.0001001 / 06 JUN 17

Applicable to: **ALL**

With the recommended 180 ° turn technique, on dry runway, the approximate turn width is 24 m (79 ft) without margin.

*Note:* The flight crew should consider additional margin when the runway is wet or contaminated.


For more information about the 180 ° Turn Technique, Refer to *FCTM/PR-NP-SOP-100 180 degrees Turn on Runway*.



**GROUND CLEARANCE DIAGRAM**

Ident.: DSC-20-40-00018435.0001001 / 19 JAN 16

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**


GROUND CLEARANCE DIAGRAM

Intentionally left blank

**ILS/GLS ◀ /MLS ◀ FINAL APPROACH AND LANDING GEOMETRY**

Ident.: DSC-20-50-00019878.0001001 / 22 FEB 17

Applicable to: ALL




CONDITIONS :	GLIDE PATH (°)	Ⓐ	Ⓑ	TOUCHDOWN POINT Ⓒ
- FLAPS FULL				
- ILS ANTENNA AT 50 ft AT THRESHOLD	2°5	348 m 1145 ft	112 m 366 ft	236 m 779 ft
- NO FLARE - PITCH ANGLE : 4°	3°	291 m 954 ft	93 m 306 ft	198 m 648 ft

**MINIMUM VISUAL GROUND SEGMENTS (FLARE PHASE)**

Ident.: DSC-20-50-00019879.0001001 / 22 FEB 17

Applicable to: ALL




	CAT III		CAT II
H	15 ft ( $\theta = 5.4^\circ$ )	50 ft ( $\theta = 4.7^\circ$ )	100 ft ( $\theta = 4.7^\circ$ )
VISUAL SEGMENT	60 m (197 ft)		120 m (394 ft)
A	36 ft	71 ft	121 ft
OBSCURED B	43 m (140 ft)	79 m (259 ft)	134 m (442 ft)
MINIMUM RVR	103 m (337 ft)	139 m (456 ft)	254 m (836 ft)

*Note:* This drawing illustrates that, for a CAT III landing (60 m minimum visual segment), the minimum Runway Visual Range (RVR) is 103 m at 15 ft.

**VISUAL GROUND GEOMETRY**

Ident.: DSC-20-60-00010294.0001001 / 22 MAY 12

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIRCRAFT GENERAL**

VISUAL GROUND GEOMETRY

Intentionally left blank



# **AIRCRAFT SYSTEMS**

AIR CONDITIONING / PRESSURIZATION /  
VENTILATION

Intentionally left blank

**DSC-21-10 Air Conditioning**

**DSC-21-10-10 General**

General.....	A
Architecture.....	B


**DSC-21-10-20 Main Components**

Air Conditioning Pack.....	A
Pack Schematic (Simplified).....	B
Pack Flow Control Valve.....	C
Emergency Ram Air.....	D
Mixer Unit.....	E
Hot-Air Pressure-Regulating Valve.....	F
Trim Air Valves.....	G

**DSC-21-10-30 Temperature and Flow Regulation**

General.....	A
Temperature Regulation.....	B
Air Conditioning System Controllers.....	C

**DSC-21-10-40 System Operation under Failure Condition**

General.....	A
Air Conditioning System Controllers  .....	B
Air Cycle Machine Failure.....	C
Hot Air Pressure Regulating Valve Failure.....	D
Trim Air Valve Failure.....	E

**DSC-21-10-50 Controls and Indicators**

Controls on Overhead Panel.....	A
ECAM BLEED Page.....	B
ECAM COND Page.....	C
ECAM CAB PRESS Page.....	D
ECAM Cruise Page.....	E
Memo Display.....	F

**DSC-21-20 Pressurization**


**DSC-21-20-10 General**

General.....	A
Automatic Operation.....	B
Manual Operation.....	C
SCHEMATICS.....	D

*Continued on the following page*

*Continued from the previous page*

**DSC-21-20-20 Main Components**

Cabin Pressure Controllers.....	A
Outflow Valve.....	B
Safety Valves.....	C
Residual Pressure Control Unit (RPCU  ).....	D

**DSC-21-20-30 System Operation**

Automatic Pressure Control Mode.....	A
Pressurization Flight Profile.....	B
Manual Pressure Control Mode.....	C
Ditching.....	D

**DSC-21-20-40 Controls and Indicators**

Overhead Panel.....	A
ECAM CAB PRESS Page.....	B
ECAM Cruise Page.....	C
ECAM DOOR/OXY Page.....	D
Memo Display.....	E

**DSC-21-30 Ventilation**

**DSC-21-30-10 General**

General.....	A
--------------	---

**DSC-21-30-20 Avionics Ventilation**

General.....	A
Main Components.....	B
Normal Operation, Open-Circuit Configuration.....	C
Normal Operation, Close-Circuit Configuration.....	D
Normal Operation, Intermediate Configuration.....	E
Abnormal Operation.....	F

**DSC-21-30-40 Battery Ventilation**

Battery Ventilation.....	A
--------------------------	---

**DSC-21-30-50 Lavatory and Galley Ventilation**

Lavatory and Galley.....	A
--------------------------	---

**DSC-21-30-60 Controls and Indicators**

Overhead Panel.....	A
ECAM CAB PRESS Page.....	B

*Continued on the following page*



*Continued from the previous page*

**DSC-21-40 Cargo**

DSC-21-40-10 General

General.....	A
Schematic.....	B

DSC-21-40-20 System Operation

FWD Cargo Ventilation  .....	A
AFT Cargo Ventilation  .....	B
AFT Cargo Heating  .....	C
FWD Cargo Heating  .....	D

DSC-21-40-30 Controls and Indicators

Overhead Panel.....	A
---------------------	---

DSC-21-40-35 ECAM Cond Page

ECAM COND Page.....	A
---------------------	---



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AIR CONDITIONING / PRESSURIZATION / VENTILATION

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL**

Ident.: DSC-21-10-10-00017767.0001001 / 21 MAR 16

Applicable to: ALL

The air conditioning system is fully automatic.


It provides continuous air renewal and maintains a constant, selected temperature in the following three zones : COCKPIT, FWD CABIN, AFT CABIN. These three zones are independently controlled.

Air is supplied by the pneumatic system, via:


- Two pack flow control valves,
- Two packs,
- The mixing unit, which mixes the air that comes from the cabin and the packs.

Air is then distributed to the cockpit and the cabin.

In an emergency, a ram air inlet can provide ambient air to the mixing unit.

The temperature in the flight deck and in the cabin can be selected from the cockpit's AIR COND panel. Temperature regulation of the temperature is ensured by a zone controller and two pack controllers, or two Air Conditioning System Controller (ACSC) .

Temperature regulation is optimized via the hot air pressure regulating valve, and the trim air valves that add hot air, tapped upstream of the packs, to the air coming from the mixing unit.


A temperature control panel  is also available on the Forward Attendant Panel (FAP). During cruise, the cabin crew can modify each cabin zone temperature that is selected from the cockpit, with a limited authority of  $\pm 2.5$  °C. ( $\pm 4.5$  °F).

Low-pressure air is supplied to the mixing unit by a ground connection.

**ARCHITECTURE**

Ident.: DSC-21-10-10-00000297.0003001 / 22 MAY 12

Applicable to: ALL






**AIR CONDITIONING PACK**

Ident.: DSC-21-10-20-00017768.0001001 / 21 MAR 16


Applicable to: ALL

The two packs operate automatically and independently of each other. Pack operation is controlled by signals coming from the pack controller or the Air Conditioning System Controller (ACSC) . Warm pre-conditioned bleed air enters the cooling path via the pack flow control valve, and is ducted to the primary heat exchanger.

Then, the cooled bleed air enters the compressor section of the air-cycle machine and is compressed to a higher pressure and temperature.

It is cooled again in the main heat exchanger and enters the turbine section, where it expands and, in expanding, generates power to drive the compressor and cooling air fan.


The removal of energy during this process reduces air temperature, resulting in very low air temperature at turbine discharge.

 A water separator system dries the air before it enters the turbine section.

**PACK SCHEMATIC (SIMPLIFIED)**

Ident.: DSC-21-10-20-00000299.0008001 / 22 MAY 12


Applicable to: ALL



### PACK FLOW CONTROL VALVE

Ident.: DSC-21-10-20-00017769.0001001 / 21 MAR 16

Applicable to: ALL

This valve is pneumatically-operated and electrically-controlled. It regulates the air flow in accordance with signals received from the pack controllers or the ACSC  .

In the absence of air pressure, a spring keeps the valve closed.

The valve closes automatically in case of pack overheat, engine start, or operation of the fire or ditching pushbutton. The valve is controlled from the AIR COND panel.

### EMERGENCY RAM AIR

Ident.: DSC-21-10-20-00000301.0001001 / 20 DEC 16

Applicable to: ALL

An emergency ram air inlet ventilates the cockpit and cabin to remove smoke, or if both packs fail. The emergency ram air inlet valve is controlled by the RAM AIR pushbutton on the AIR COND panel. This pushbutton opens the ram air valve, provided that ditching is not selected.

When the RAM AIR pushbutton is ON : The outflow valve opens about 50 %, provided that it is under automatic control and  $\Delta P$  is less than 1 PSI. The outflow valve does not automatically open if it is under manual control, even if  $\Delta P$  is less than 1 PSI. If  $\Delta P$  is greater than 1 PSI, the check valve located downstream the ram air door will not open, even if the ram air door has been selected open. No airflow will then be supplied.

### MIXER UNIT

Ident.: DSC-21-10-20-00000302.0001001 / 21 MAR 16

Applicable to: ALL

This unit mixes cold fresh air from the packs with the cabin air being recirculated through recirculation fans. The mixer unit is also connected to the emergency ram air inlet and the low pressure ground inlets.

### HOT-AIR PRESSURE-REGULATING VALVE

Ident.: DSC-21-10-20-00000303.0003001 / 15 FEB 11

Applicable to: ALL

In the absence of air, a spring keeps the valve closed. This pneumatically-operated and electrically-controlled valve regulates hot air pressure, which is tapped upstream of the packs. The air conditioning system controller 1 regulates this valve. This valve closes upon pressing the HOT AIR pushbutton on the AIR COND panel, or when both lanes of one air conditioning system controller fail.

The valve closes automatically, if:


- The duct overheats, or
- The cockpit trim air valve fails, or
- Both cabin trim air valves fail.



The hot-air pressure-regulating valve remains operative, even if either the forward or aft cabin trim air valve fails.

### TRIM AIR VALVES

Ident.: DSC-21-10-20-00017771.0001001 / 21 MAR 16

Applicable to: ALL

These valves are electrically-controlled by the zone controller or the ACSC . A trim air valve, associated with each zone, adjusts the temperature by adding hot air.

The cockpit trim air valve is controlled by the ACSC 1 , and the cabin trim air valves are controlled by the ACSC 2 .

## AIRCRAFT SYSTEMS


### AIR CONDITIONING / PRESSURIZATION / VENTILATION

#### AIR CONDITIONING - TEMPERATURE AND FLOW REGULATION

## GENERAL

Ident.: DSC-21-10-30-00017772.0001001 / 21 MAR 16


Applicable to: ALL



Temperature regulation is automatic and controlled by one zone controller and two pack controllers, or the ACSC .

## TEMPERATURE REGULATION



Ident.: DSC-21-10-30-00017773.0001001 / 21 MAR 16

Applicable to: ALL

Temperature regulation is achieved by the zone controller or the ACSC .


The zone controller regulates the temperature of the two cabin zones and the cockpit. The ACSC 2  regulates the temperature of the two cabin zones, and the ACSC 1  regulates the cockpit temperature.

### BASIC TEMPERATURE REGULATION


The flight crew uses the temperature selectors on the air conditioning panel to select the reference temperatures. The zone controller or the ACSC  computes a temperature demand from the selected temperature and the actual temperature. The reference temperatures are then fine tuned for each cabin zone through the temperature control panel  installed on the FAP.

The actual temperature is measured by sensors:

- In the cockpit, for the cockpit zone;
- In the lavatory extraction circuit and galley ventilation system, for the cabin.

A signal corresponding to the lowest demanded zone temperature goes to the pack controller or the ACSC , which then make both packs supply the required outlet temperature.

### OPTIMIZED TEMPERATURE REGULATION

The zone controller or the ACSC  optimizes temperature by acting on the trim air valves. The temperature selection range is from 18 °C (64 °F) to 30 °C (86 °F).

## AIR CONDITIONING SYSTEM CONTROLLERS

Ident.: DSC-21-10-30-00017775.0001001 / 20 DEC 16

Applicable to: ALL

Each air conditioning system controller regulates the temperature of its associated pack, by modulating the bypass valve and the ram air inlet flap.

The ram air inlet flap closes during takeoff and landing to avoid the ingestion of foreign matter.

*Note: During takeoff, the ram air inlet flap closes when takeoff power is set, and the main landing gear struts are compressed.*

*During landing, it closes as soon as the main landing gear struts are compressed, as long as speed is at or above 70 kt.*

*It opens 20 s after the speed drops below 70 kt.*

The air conditioning system controllers also regulate flow by modulating the associated pack flow control valve.

### **PACK FLOW CONTROL**

The flight crew can use the PACK FLOW selector to adjust the pack flow for the number of passengers and for external conditions.

Whatever the crew selects, the system delivers higher flow for any of the following circumstances:

- In single-pack operation,
- When the APU is supplying bleed air.


The system delivers normal flow if the flight crew selects LO flow and the temperature demand cannot be satisfied.

### **ENGINE PRESSURE DEMAND**

When the cooling demand in one zone cannot be satisfied, if the bleed pressure is too low, the air conditioning system controller sends a pressure demand signal to both Engine Interface Units (EIU) to increase the minimum idle and to raise the bleed pressure.

### **APU FLOW DEMAND**

When the APU bleed valve is open, the air conditioning system controller signals the APU 's Electronic Control Box (ECB ) to increase the APU flow output when any zone temperature demand cannot be satisfied.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AIR CONDITIONING / PRESSURIZATION / VENTILATION</b></p> <p>AIR CONDITIONING - SYSTEM OPERATION UNDER FAILURE CONDITION</p>
---	---

**GENERAL**

Ident.: DSC-21-10-40-00000309.0002001 / 21 MAR 16  
**Applicable to: ALL**

Each controller is comprised of two lanes. One lane controls the system, the other takes over full control, in case of an active lane failure.

**AIR CONDITIONING SYSTEM CONTROLLERS** ⚠

Ident.: DSC-21-10-40-00018747.0001001 / 21 MAR 16  
**Applicable to: ALL**

**ONE LANE FAILURE**

No effect, as the second lane takes over.

**BOTH LANES FAILURE**

The related pack is lost, and the hot air pressure-regulating valve and associated trim air valves close.

**AIR CYCLE MACHINE FAILURE**

Ident.: DSC-21-10-40-00000312.0003001 / 21 MAR 16  
**Applicable to: ALL**

If the Air Cycle Machine (ACM) fails (compressor/turbine seizure), the affected pack may be operated in heat exchanger cooling mode.

Warm pre-conditioned bleed air enters the cooling path via the pack valve and goes to the primary heat exchanger. Then, the main part of the cooled air goes directly downstream of ACM turbine through the bypass valve, and the rest goes through the failed ACM.

The ACM seizure reduces the pack flow.

As for normal pack operation :

- The air conditioning system controller regulates temperature by modulating the bypass valve and the ram air inlet flap.
- The air conditioning system controller regulates the hot air flow through the trim air valves to optimize cockpit/cabin temperature regulation. Hot air flow is lower than in normal pack operation, because pack flow is reduced.

**HOT AIR PRESSURE REGULATING VALVE FAILURE**

Ident.: DSC-21-10-40-00000313.0001001 / 21 MAR 16  
**Applicable to: ALL**

Failed open : No effect.

Failed closed : Optimized regulation is lost. Trim air valves are driven to the fully closed position. Pack 1 controls the cockpit temperature to the selected value and pack 2 controls the cabin temperature (FWD and AFT) to the mean value of the selected temperatures.

**TRIM AIR VALVE FAILURE**

Ident.: DSC-21-10-40-00000314.0001001 / 21 MAR 16

Applicable to: **ALL**


Optimized temperature regulation of the corresponding zone is lost.



**CONTROLS ON OVERHEAD PANEL**

Ident.: DSC-21-10-50-00000315.0002001 / 20 DEC 16

Applicable to: ALL



(1) Zone temperature selector

- 12 o'clock position: 24 °C (76 °F)
- COLD position: 18 °C (64 °F)
- HOT position: 30 °C (86 °F).

(2) HOT AIR pb

ON : The valve regulates hot air pressure.

OFF : The valve closes, and the trim air valves close.

The FAULT circuit is reset.

FAULT : The FAULT light comes on amber, along with an associated ECAM caution, when duct overheat is detected. The fault circuit detects an overheat when the duct temperature reaches 88 °C (190 °F) once.

The valve and trim air valves close automatically.

The FAULT light goes off when the temperature drops below 70 °C (158 °F), and the flight crew selects OFF.

(3) PACK pb-sw

**ON** : The pack flow control valve is automatically-controlled.

It opens, except in the following cases:

- Upstream pressure below minimum
- Compressor outlet overheat
- Engine start sequence:
  1. If the crossbleed valve is closed, the valve located on the starting engine side immediately closes, when the MODE selector is set to IGN (or CRK)
  2. It remains closed on the starting engine side (provided the crossbleed valve is closed) when:
    - The MASTER sw is set to ON (or MAN START pb is set to ON)
    - The start valve is open
    - N2 < 50 %.

*Note: If the crossbleed valve is open at engine start, both pack flow control valves close.*

3. On ground, reopening of the valves is delayed for 30 s to avoid a supplementary pack closure cycle during second engine start.

- FIRE pb, of the engine on the related side, is pressed
- Ditching is selected.

**OFF** : The pack flow control valve closes.

**FAULT** It : Comes on amber, and a caution appears on the ECAM, if the pack flow control valve position disagrees with the selected position, or in the case of compressor outlet overheat or pack outlet overheat.

(4) PACK FLOW selector

- Permits the selection of pack valve flow, according to the number of passengers and ambient conditions (smoke removal, hot or wet conditions)  
 LO (80 %) – NORM (100 %) – HI (120 %)
- Manual selection is irrelevant in single pack operation, or with APU bleed supply. In these cases, HI is automatically selected
- If LO is selected, the pack flow can be automatically selected up to 100 % when the cooling demand cannot be satisfied.


(5) RAM AIR pb (guarded)

ON : The ON light comes on white.

If the DITCHING pb, on the CABIN PRESS panel, is in normal position:

- The emergency ram air inlet opens
- If  $\Delta p \geq 1$  PSI: The outflow valve control remains normal. No emergency ram air flows in
- If  $\Delta p < 1$  PSI: The outflow valve opens to about 50 % when under automatic control. It does not automatically open when it is under manual control. Emergency ram airflow is directly supplied to the mixer unit.

OFF: The emergency ram air inlet closes.



(1) CAB FAN pb


ON : The two cabin fans are on.

OFF: The two cabin fans are off.

**ECAM BLEED PAGE**

Ident.: DSC-21-10-50-00000316.0003001 / 21 MAR 16

Applicable to: ALL




- (1) Pack outlet temperature  
 It appears in green. It becomes amber, if the temperature is higher than 90 °C.
- (2) PACK RAM AIR inlet  
 Crossline: The flap is normally closed.  
 – Green  
 In transit : The flap is partially open  
 – Amber  
 Inline – : The flap is fully open on ground.  
 Amber  
 Inline – : The flap is fully open in flight.  
 Green
- (3) Pack turbine bypass valve position  
 Indication is green.  
 C = Cold – Valve closed  
 H = Hot – Valve open.

- (4) Pack compressor outlet temperature  
It appears in green. It becomes amber, if the temperature is higher than 260 °C.
- (5) Pack flow  
It appears in green. It becomes amber, if the pack flow control valve is closed.  
*Note: The pack flow indication can be up to 30 % below the actual flow rate.*
- (6) Pack flow control valve  
  - Inline - Green : Open.
  - Inline - Amber : Open, and disagrees with the control position.
  - Crossline - Green : Fully closed.
  - Crossline - Amber : Fully closed, and disagrees with the control position.
- (7) User Indication  
It appears in green. It becomes amber, in flight, when RAM AIR flap is not fully open, and both pack flow control valves are closed .

**ECAM COND PAGE**

Ident.: DSC-21-10-50-00000317.0004001 / 09 OCT 12

Applicable to: ALL




- (1) Cabin FAN fault indication  
It appears in amber, if the recirculation fan is detected as faulty.
- (2) Zone temperature  
It is in green.
- (3) Zone duct temperature  
It appears in green, and becomes amber at 80 °C (176 °F).
- (4) Zone trim air valve position  
The arrow is green. It is replaced by amber crosses ("XX") if the valve fails.  
C = Cold valve fully closed.  
H = Hot valve fully open.
- (5) Hot air pressure regulating valve  
In line - Green : Valve is normally open.  
In line - Amber : Valve is abnormally open (disagrees with control position).  
Crossline - Green : Valve is normally fully closed.  
Crossline - Amber : Valve is closed and pushbutton OFF, or valve position disagrees with control position.
- (6) TEMP  
Unit of measure (°C or °F) is indicated in cyan.

**ECAM CAB PRESS PAGE**

Ident.: DSC-21-10-50-00000318.0001001 / 09 OCT 12

Applicable to: ALL




(1) PACK indication

Triangle normally green, PACK 1(2) indication normally white. Both become amber when pack flow control valve is closed with associated engine running.

**ECAM CRUISE PAGE**

Ident.: DSC-21-10-50-00000319.0002001 / 09 OCT 12

Applicable to: ALL



- (1) Zone indication  
This field also displays the temperature scale in use (°C or °F).
- (2) Zone temperature


**MEMO DISPLAY**

Ident.: DSC-21-10-50-00016760.0001001 / 21 MAR 16

Applicable to: ALL

**RAM AIR ON** : This memo appears in green, if the RAM AIR pb-sw is ON.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AIR CONDITIONING / PRESSURIZATION / VENTILATION</b></p> <p>PRESSURIZATION - GENERAL</p>
---	--


**GENERAL**

Ident.: DSC-21-20-10-00017903.0001001 / 21 MAR 16  
**Applicable to: ALL**

The cabin pressurization system has four general functions:

- Ground function : Fully opens the outflow valve on ground
- Prepressurization : During takeoff, increases cabin pressure to avoid a surge in cabin pressure during rotation
- Pressurization in flight : Adjusts cabin altitude, and rate of change to provide passengers with a comfortable flight
- Depressurization : After touchdown, gradually releases residual cabin overpressure before the ground function fully opens the outflow valve.

The system consists of:

- Two Cabin Pressure Controllers (CPC)
- One Residual Pressure Control Unit (RPCU (  )
- One outflow valve, with an actuator that incorporates three motors (two for automatic operation, one for manual operation)
- One control panel
- Two safety valves.

Any one of the three independent electric motors may power the outflow valve.

Normally, one of the two cabin pressure controllers operates the outflow valve by means of its associated automatic motor.

In case of ditching, an override switch on the control panel allows the flight crew to close the outflow valve and all valves below the flotation line.

The flight crew can set the system to operate automatically, semi-automatically, or manually.

In normal operation, cabin pressurization is fully automatic.

**AUTOMATIC OPERATION**

Ident.: DSC-21-20-10-00000323.0001001 / 21 MAR 16  
**Applicable to: ALL**

The flight crew monitors the operation of the system, but does nothing to control it. Air pressure in the cabin follows external schedules that the system receives as signals from the Flight Management and Guidance System (FMGS).

When FMGS data is not available for automatic pressurization, the crew only needs to select the landing field elevation.

The pressurization system then uses the manually-selected landing field elevation for internal schedules.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AIR CONDITIONING / PRESSURIZATION / VENTILATION**  
PRESSURIZATION - GENERAL

**MANUAL OPERATION**

Ident.: DSC-21-20-10-00000324.0001001 / 21 MAR 16

Applicable to: **ALL**

In manual mode, the flight crew controls the cabin altitude via the manual motor of the outflow valves, by operating controls on the pressurization control panel.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS


AIR CONDITIONING / PRESSURIZATION / VENTILATION

PRESSURIZATION - GENERAL

## SCHEMATICS

Ident.: DSC-21-20-10-00000325.0002001 / 21 MAR 16

Applicable to: ALL



## CABIN PRESSURE CONTROLLERS

Ident.: DSC-21-20-20-00000326.0001001 / 21 MAR 16

Applicable to: ALL

Two identical, independent, digital controllers automatically control the system, by maintaining the proper cabin pressure. They receive signals from the Air Data Inertial Reference System (ADIRS), the Flight Management and Guidance Computer (FMGC), the Engine Interface Unit (EIU), and the Landing Gear Control Interface Unit (LGCIU).

When the system is in automatic or semi-automatic mode, one controller is active, the other is on standby.

The controllers also generate signals for the Electronic Centralized Aircraft Monitoring (ECAM). For operation in manual mode, each controller has a backup section, which is powered by an independent power supply in the controller N°1 position. This section also has a pressure sensor that generates the cabin altitude and pressure signal for the ECAM, when MAN mode is selected. The controllers communicate with each other via a cross-channel link.

## OUTFLOW VALVE

Ident.: DSC-21-20-20-00000327.0001001 / 21 MAR 16

Applicable to: ALL

The outflow valve is on the right-hand side of fuselage, behind the aft cargo compartment and below the flotation line.

The outflow valve assembly consists of a flush, skin-mounted, rectangular frame, carrying inward and outward opening flaps linked to the actuator. The actuator contains the drives of the two automatic motors and the manual motor. Either of two automatic motors operates the valve in automatic mode, and the manual motor operates it in manual mode.

In automatic mode, the operating controller signals the position of the valve to the ECAM.

In manual mode, the backup section of the N° 1 controller signals the position of the valve to the ECAM.

**Note:** *When the RAM AIR pushbutton is ON, and  $\Delta p$  is below 1 PSI, the system drives the outflow valve about 50 % open if it is under automatic control. If the system is under manual control, the outflow valve does not automatically open, even if  $\Delta p$  is below 1 PSI.*

## SAFETY VALVES

Ident.: DSC-21-20-20-00000328.0001001 / 21 MAR 16

Applicable to: ALL

Two independent pneumatic safety valves prevent cabin pressure from going too high (8.6 PSI above ambient) or too low (1 PSI below ambient).

They are located on the rear pressure bulkhead, above the flotation line.

**RESIDUAL PRESSURE CONTROL UNIT (RPCU  )**

Ident.: DSC-21-20-20-00017788.0001001 / 21 MAR 16

Applicable to: ALL

The RPCU automatically depressurizes the aircraft in case of abnormal residual pressure on ground. It automatically opens the outflow valve, when:

- The outflow valve is not fully open, and
- Both CPCs are failed, or manual mode is selected, and
- The aircraft is on ground, and
- All engines are shutdown, or all ADIRS indicate an airspeed below 100 kt.

**AUTOMATIC PRESSURE CONTROL MODE**

Ident.: DSC-21-20-30-00000329.0001001 / 14 NOV 11

Applicable to: ALL

**GENERAL**

- Two identical, independent, automatic systems (each consisting of a controller and its associated motors) control cabin pressure.  
Either system controls the single outflow valve.  
Only one controller operates at a time.  
  
An automatic transfer occurs:
  - 70 s after each landing.
  - If the operating system fails.
- The controller automatically controls the cabin pressure. It limits the cabin pressure to 8 000 ft maximum and optimizes it during climb and descent phases.
- The controller normally uses the landing elevation and the QNH from the FMGC , and the pressure altitude from ADIRS.  
If FMGC data are not available, the controller uses the captain BARO Reference from the ADIRS and the LDG ELEV selection.
- Pressurization is assumed through the following modes:

**GROUND (GN)**

Before takeoff, and 55 s after landing, the outflow valve fully opens to ensure that there is no residual cabin pressure. At touchdown, any remaining cabin pressure is released at a cabin vertical speed of 500 ft/min.

**TAKEOFF (TO)**

To avoid a pressure surge at rotation, the controller pre-pressurizes the aircraft at a rate of 400 ft/min, until the  $\Delta P$  reaches 0.1 PSI. At liftoff, the controller initiates the climb phase.

**CLIMB (CL)**

During climb, the cabin altitude varies according to a fixed pre-programmed law that takes into account the aircraft's actual rate of climb.

**CRUISE (CR)**

During cruise, the controller maintains cabin altitude at the level-off value, or at the landing field elevation, whichever is higher.

**DESCENT (DE)**

During descent, the controller maintains a cabin rate of descent, such that the cabin pressure is equal to the landing field pressure +0.1 PSI, shortly before landing.  
 The maximum descent rate is 750 ft/min.


**ABORT (AB)**

If the aircraft does not climb after takeoff, the abort mode prevents the cabin altitude from climbing.  
 Cabin pressure is set back to the takeoff altitude +0.1 PSI.

**PRESSURIZATION FLIGHT PROFILE**

Ident.: DSC-21-20-30-00000331.0001001 / 08 SEP 15

Applicable to: ALL



**MANUAL PRESSURE CONTROL MODE**

Ident.: DSC-21-20-30-00000332.0001001 / 21 MAR 16

Applicable to: ALL

If both automatic systems fail, the flight crew may use the CABIN PRESS control panel to take over manual control of cabin pressurization.

- Release the MODE SEL pushbutton to select MAN, and
- Push the MAN V/S CTL switch UP or DN to increase or decrease cabin altitude.

The first of these actions cuts off power to the AUTO motors, and enables the MAN motor to control the outflow valve.




- Note:
1. Due to the slow operation of the outflow valves in manual mode, and the limited resolution of the outflow valves' position on the ECAM , the visual ECAM indication of a change in the outflow valves' position can take up to 5 s.
  2. As the pressurization system is manually-controlled, the outflow valve does not open automatically at touchdown.

## DITCHING

Ident.: DSC-21-20-30-00017789.0001001 / 21 MAR 16

Applicable to: ALL

To prepare for ditching, the flight crew must press the DITCHING pb on the CABIN PRESS control panel to close the outflow valve, the emergency ram air inlet, the avionics ventilation inlet and extract valves, the pack flow control valves, and the FWD cargo outlet isolation valve  .



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

PRESSURIZATION - SYSTEM OPERATION

Intentionally left blank

**OVERHEAD PANEL**

Ident.: DSC-21-20-40-00000334.0004001 / 07 MAY 13

Applicable to: ALL



(1) LDG ELEV knob

**AUTO** : The pressurization system uses the FMGS data to construct an optimized pressure schedule.  
 To exit the AUTO position, pull out and turn the selector.

**Other positions** : The pressurization schedule does not use the landing elevation from the FMGS, but instead uses the landing elevation selected with this knob (from -2 000 to +14 000 ft) as its reference.

*Note:* The LDG ELEV knob scale is only given as an indication; refer to the ECAM information for accurate adjustment.

(2) MODE SEL pb

**AUTO** : Automatic mode is operating. One of the two systems controls the outflow valve.

**MAN** : This legend appears in white, and FAULT does not come on. The flight crew then uses the MAN V/S CTL selector to control the outflow valve.

*Note:* Switching the MODE SEL pb to MAN, for at least 10 s, then returning it to AUTO will select the other system.

**FAULT** It : This legend appears in amber and the ECAM caution light comes on only when both automatic systems are faulty.

*Note:* The pilot may notice a variation in the CAB ALT indication on the ECAM PRESS page, when the system switches from the cabin pressure control AUTO mode to MAN mode, due to the reduced resolution of the backup pressure sensor.

(3) MAN V/S CTL selector

The switch is springloaded to neutral and controls the outflow valve position through operation of the MAN motor, when the MODE SEL pb is in the MAN position.

UP : The valve moves towards the open position.

DN : The valve moves towards the closed position.

*Note:* To target precise cabin vertical speed rate, only short inputs should be applied on the selector.

(4) DITCHING pb (guarded)

Normal : The system functions normally.

ON : The operating system sends a “close” signal to the outflow valve, emergency ram air inlet, avionics ventilation inlet and extract valves, pack flow control valves, and forward cargo isolation outlet valve.  
 The cargo extract fans stop automatically.


*Note:* The outflow valve will not close automatically, if it is under manual control.

<b>CAUTION</b>	On ground, If the ditching pushbutton is set to ON, with the low pressure ground cart connected and all doors closed, a differential pressure will build up.
----------------	--

**ECAM CAB PRESS PAGE**

Ident.: DSC-21-20-40-00000335.0002001 / 21 MAR 16

Applicable to: ALL



(1) LDG ELEV AUTO/MAN

- LDG ELEV AUTO: appears in green when the LDG ELEV selector is in AUTO.
- LDG ELEV MAN: appears in green when the LDG ELEV selector is not in AUTO.

Neither appears when the indications from SDAC are not valid.

(2) Landing elevation

The landing elevation selected either automatically by the FMGS or manually by the pilot appears in green (but not when the MODE SEL pushbutton switch is in MAN).

(3) V/S FT/MIN (cabin vertical speed)

The analog and digital presentations appear in green when V/S is in the normal range. The digital presentation pulses when V/S > 1 750 ft/min (resets at 1 650 ft/min).

(4) ΔP PSI (cabin differential pressure)

The analog and digital presentations appear in green when ΔP is in the normal range. They appear in amber when  $\Delta P \leq -0.4$  PSI or  $\geq 8.5$  PSI. The digital presentation pulses if  $\Delta p > 1.5$  PSI (resets at 1 PSI) during flight phase 7. (Refer to DSC-31-15 Flight Phases).

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

**PRESSURIZATION - CONTROLS AND INDICATORS**

(5) CAB ALT FT (cabin altitude)

The analog and digital presentations appear in green, in normal range.

They appear in red if the cabin altitude goes above 9 550 ft.

The digital presentation pulses if the cabin altitude is at or above 8 800 ft (resets at 8 600 ft).

(6) Active system indication (SYS 1 or SYS 2 or MAN)

SYS 1 or SYS 2 appears in green when active and in amber when faulty. When either system is inactive, its title does not appear.

MAN appears in green when the MODE SEL switch is in MAN.

(7) Safety valve position

SAFETY appears in white and the diagram in green when both safety valves are fully closed.

SAFETY and the diagram appear in amber when either valve is not closed.

*Note: The safety valve opens when the cabin differential pressure is between 8.2 and 8.9 PSI. The range is due to the reduced accuracy of  $\Delta P$  measurements (in MAN mode), combined with the decrease in cabin differential pressure that occurs immediately after the safety valves open.*

(8) Outflow valve position


The diagram is green when the valve is operating normally.

The diagram becomes amber when the valve opens more than 95 % during flight.

**ECAM CRUISE PAGE**

Ident.: DSC-21-20-40-00000336.0002001 / 09 OCT 12

Applicable to: ALL




(1) LDG ELEV AUTO/MAN

Identical to the CAB PRESS page

- (2) CAB V/S FT/MIN (cabin vertical speed)

Green, in normal range.

Pulses, when the V/S > 1 750 ft/min (resets at 1 650 ft/min).



- (3) CAB ALT FT (cabin altitude)

Green, in normal range.

Red, for excessive cabin altitude :  $\geq 9\ 550$  ft.

Pulses for cabin altitude at, or above, 8 800 ft (resets at 8 600 ft).

- (4)  $\Delta$ P indication


It is normally green. Pulses green when CAB  $\Delta$ P  $\geq 1.5$  PSI before landing.

It becomes amber, when out of normal range  $\Delta$ p  $\leq -0.4$  PSI or  $\geq 8.5$  PSI.

**ECAM DOOR/OXY PAGE**

Ident.: DSC-21-20-40-00000337.0003001 / 21 MAR 16

Applicable to: ALL



(1) V/S (cabin vertical speed)

This number only appears during flight phases 5, 6 and 7. (Refer to DSC-31-15 Flight Phases for flight phase definitions).

- It is normally green.
- It pulses, when the V/S is greater than 1 750 ft/min and stops pulsing, when less than 1 650 ft/min.
- It becomes amber, when the V/S is greater than 2 000 ft/min, or less than -2 000 ft/min.

**MEMO DISPLAY**

Ident.: DSC-21-20-40-00016761.0001001 / 21 MAR 16

Applicable to: ALL

**MAN LDG ELEV** : This memo appears in green, if the LDG ELEV knob is not in the AUTO position.



**GENERAL**

Ident.: DSC-21-30-10-00017790.0001001 / 21 MAR 16

**Applicable to: ALL**

The ventilation system includes ventilation for:

- The avionics, controlled by the Avionics Equipment Ventilation Controller (AEVC),
- The batteries,
- The lavatories and galleys.

Note: For more information about cargo ventilation  , Refer to DSC-21-40-10 General.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

**VENTILATION - GENERAL**

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AIR CONDITIONING / PRESSURIZATION / VENTILATION</b></p> <p style="text-align: center;">VENTILATION - AVIONICS VENTILATION</p>
---	--

**GENERAL**

Ident.: DSC-21-30-20-00000341.0001001 / 24 FEB 11

**Applicable to: ALL**

The avionics ventilation system is fully automatic.

It cools the electrical and electronic components in the avionics compartment and on the flight deck, including the instrument and circuit breaker panels. It uses two electric fans to force the circulation of cooling air.

Whatever the configuration of the avionics ventilation system is, a part of the avionics ventilation air is sucked from the cockpit through the different cockpit panels.


**MAIN COMPONENTS**

Ident.: DSC-21-30-20-00017791.0001001 / 21 MAR 16

**Applicable to: ALL**

**FANS**

Two electric fans continuously circulate air around the avionics equipment, when the aircraft is electrically supplied.

The Fan Speed Controller (FSC)  controls the avionics ventilation fan speed as a function of temperature::

1. High speed when the ventilation air temperature is above +40 °C (104 °F )
2. Low speed when the ventilation air temperature is below +35 °C ( 95 °F)

**SKIN AIR INLET AND OUTLET VALVES**

These valves admit air from outside the aircraft and evacuate hot air from the avionics equipment.

**SKIN EXCHANGE INLET AND OUTLET BYPASS VALVES**

These valves enable air to circulate between the avionics bay and the space under the cargo compartment floor.

**AIR CONDITIONING INLET VALVE**

This valve opens to enable the air conditioning circuit to supply fresh air to the avionics bay.

**SKIN EXCHANGE ISOLATION VALVE**

This valve connects or isolates the skin heat exchanger.

**AVIONICS EQUIPMENT VENTILATION CONTROLLER (AEVC)**

The AEVC controls the operation of all fans and valves in the avionics ventilation system.

**NORMAL OPERATION, OPEN-CIRCUIT CONFIGURATION**


Ident.: DSC-21-30-20-00000343.0001001 / 16 APR 14

Applicable to: ALL

**GROUND OPERATIONS**

The open-circuit configuration operates when skin temperature is above the on-ground threshold.

On-ground threshold = +12 °C (53 °F), temperature increasing, or  
 +9 °C (48 °F), temperature decreasing.



(\*)

**Note:** In some cases, the opening of the skin air valves can be delayed even if the skin temperature is above the on-ground thresholds: This is to avoid condensation phenomenon when the temperature inside the avionics compartment is too cold.

**NORMAL OPERATION, CLOSE-CIRCUIT CONFIGURATION**

Ident.: DSC-21-30-20-00000345.0001001 / 09 OCT 12

Applicable to: ALL

**FLIGHT OPERATIONS**


The close-circuit configuration operates when skin temperature is beneath the in-flight threshold.

In flight threshold = +35 °C (95 °F), temperature increasing, or  
+32 °C (90 °F), temperature decreasing.

**GROUND OPERATIONS**

The close-circuit configuration operates when skin temperature is beneath the on-ground threshold.

On ground threshold = +12 °C (53 °F), temperature increasing, or  
+9 °C (48 °F), temperature decreasing.



**NORMAL OPERATION, INTERMEDIATE CONFIGURATION**

Ident.: DSC-21-30-20-00000344.0001001 / 09 OCT 12


Applicable to: ALL

**FLIGHT OPERATIONS**

The intermediate configuration operates when skin temperature is above the in-flight threshold.

In flight threshold = +35 °C (95 °F), temperature increasing, or  
+32 °C (90 °F), temperature decreasing.

*Note: The measuring range of the skin temperature sensed is between -50 °C and 80 °C. Outside of this range, the AEVC sets the avionics ventilation configuration to the intermediate configuration (partially open) until the temperature is within the operation range again.*




**ABNORMAL OPERATION**

Applicable to: ALL

Ident.: DSC-21-30-20-A-00000346.0001001 / 20 JAN 15

**BLOWER FAULT OR EXTRACT FAULT ALERT**

When the BLOWER or the EXTRACT pushbutton switch is set at the OVRD (override) position, the system is in closed-circuit configuration and adds air from the air conditioning system to the ventilation air.



When the BLOWER pushbutton switch is set at OVRD, the blower fan is stopped and the extract fan continues to run.

When the EXTRACT pushbutton switch is set at OVRD, the extract fan is controlled directly from the pushbutton. Both fans continue to run.




Ident.: DSC-21-30-20-A-00000347.0001001 / 09 OCT 12

**SMOKE CONFIGURATION**

When the smoke detector detects smoke in the avionics ventilation air the BLOWER and the EXTRACT FAULT lights come on.

When both the BLOWER and the EXTRACT pushbuttons are set to the OVRD position, the air conditioning system supplies cooling air, which is then exhausted overboard. The blower fan stops.



Ident.: DSC-21-30-20-A-00000348.0001001 / 21 MAR 16

**CONTROLLER FAILURE**

The system goes to the same configuration as above, except that the skin exchange isolation valve stays open.

The inlet valve and the skin exchange inlet bypass valve remain in the position they were in before the failure occurred.

The extract fan keeps running.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AIR CONDITIONING / PRESSURIZATION / VENTILATION

#### VENTILATION - BATTERY VENTILATION

### BATTERY VENTILATION

Ident.: DSC-21-30-40-00000350.0001001 / 21 MAR 16

**Applicable to: ALL**

A venturi in the skin of the aircraft draws air from the space around the batteries and vents it overboard. The resulting airflow ventilates the batteries.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

VENTILATION - BATTERY VENTILATION

Intentionally left blank


**LAVATORY AND GALLEY**

Ident.: DSC-21-30-50-00000351.0001001 / 09 OCT 12

Applicable to: ALL

An extraction fan draws ambient cabin air through the lavatories and galleys and exhausts it near the outflow valve.

The extraction fan runs continually when electric power is available.



**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**


**VENTILATION - LAVATORY AND GALLEY VENTILATION**

Intentionally left blank

**OVERHEAD PANEL**

Ident.: DSC-21-30-60-00000352.0001001 / 24 FEB 11

Applicable to: ALL



(1) BLOWER pb-sw and EXTRACT pb-sw

**AUTO:** : When both pushbutton switches are on AUTO:

- On the ground before the application of TO power, the ventilation system is in open circuit configuration (closed configuration when the skin temperature is below the ground threshold).
- On the ground after the application of TO power, and in flight, the ventilation system is in closed circuit configuration.

**OVRD:** : When either pushbutton switch is on OVRD:

- The system goes to closed circuit configuration.
- Air from the air conditioning system is added to ventilation air. (The blower fan stops if the BLOWER pushbutton switch is in the OVRD position).

When both pushbutton switches are on OVRD:

- Air flows from the air conditioning system and then overboard.
- The extract fan continues to run.

**FAULT :** Lights up amber (and ECAM activates)

It: in the blower switch, if :

- blowing pressure is low (See \*)
- duct overheats (See \*)
- computer power supply fails
- smoke warning is activated

in the extract switch, if :

- extract pressure is low (See \*)
- computer power supply fails
- smoke warning is activated.


\* If the warning occurs on the ground when the engines are stopped, the external horn sounds.

(2) *Refer to DSC-21-10-50 Controls on Overhead Panel*

**ECAM CAB PRESS PAGE**

Ident.: DSC-21-30-60-00000353.0003001 / 03 APR 13

Applicable to: ALL



(1) BLOWER, VENT and EXTRACT Indications

VENT message normally appears in white. It becomes amber, if there is a BLOWER FAULT, EXTRACT FAULT, or AVNCS SYS FAULT.

BLOWER message appears in amber if there is a BLOWER FAULT.

EXTRACT message appears in amber if there is an EXTRACT FAULT.

(2) INLET and OUTLET Indications

Normally white. The corresponding indication becomes amber, when the inlet valve or the outlet valve is failed.



(3) INLET and OUTLET Valve Diagrams



This indicates that the valve is fully closed.  
It is normally green, but is amber if there is a disagreement.



This indicates that the valve is fully open.  
It is normally green, but is amber if there is a disagreement.

NOTE: Because of the accuracy of the temperature sensors, on the ground the closed or open indication may become amber when the temperature is close to the valve opening or closing threshold.



This indicates that the inlet valve is in transit (inlet valve only).  
It is amber.



This indicates that the outlet valve is partially open (the outlet valve is closed but a small internal flap is open).



If the valve position is not available or the received status for the valve is inconsistent, XX appears in amber.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

VENTILATION - CONTROLS AND INDICATORS

Intentionally left blank

**GENERAL**

Ident.: DSC-21-40-10-00017795.0001001 / 21 MAR 16

Applicable to: ALL

**CARGO VENTILATION** 

An extraction fan draws air from forward cargo compartment or aft cargo compartment, and exhausts it overboard. Air from the cabin replaces the exhausted air, thus ventilating the cargo compartments.


**CARGO TEMPERATURE REGULATION** 

The system can mix hot bleed air with the air coming from the cabin, therefore giving the flight crew control of the temperature in the forward or aft cargo compartment.

**SCHEMATIC**

Ident.: DSC-21-40-10-00000357.0001001 / 22 MAY 12

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

CARGO - GENERAL

Intentionally left blank

**FWD CARGO VENTILATION** 

Ident.: DSC-21-40-20-00017796.0001001 / 21 MAR 16

**Applicable to: ALL**

Air from the cabin goes via the inlet isolation valve to the forward cargo compartment, driven either by an extraction fan or by differential pressure in flight. A skin-mounted venturi discharges the air overboard via the outlet isolation valve. The cargo ventilation controller controls the operation of the inlet and outlet isolation valves and the extraction fan.

The ventilation system operates in two modes:

- On the ground or when  $\Delta P \leq 1$  PSI in flight, the controller opens the isolation valves, then starts the extraction fan
- In flight when  $\Delta P > 1$  PSI, the controller stops the fan, and differential pressure maintains the ventilation.

The controller closes the isolation valves and stops the extraction fan when:

- The flight crew sets the FWD ISOL VALVE pb-sw to OFF, or
- The forward cargo smoke detection unit detects smoke.

The outlet valve closes and the extraction fan stops when the flight crew sets the DITCHING pb-sw to ON.

**AFT CARGO VENTILATION** 

Ident.: DSC-21-40-20-00017797.0001001 / 21 MAR 16

**Applicable to: ALL**

Air from the cabin goes via the inlet isolation valve to the aft cargo compartment, driven by an extraction fan. Air is controlled by the outlet isolation valve and then goes outboard through the outflow valve.

The cargo ventilation controller controls the operation of the inlet and outlet isolation valves and the extraction fan.

When the isolation valves are fully open, the extraction fan operates continuously when the aircraft is on the ground and during flight.

The controller closes the isolation valves and stops the extraction fan when:

- The flight crew sets the AFT ISOL VALVE pb-sw to OFF, or
- The aft cargo smoke detection unit detects smoke.

**AFT CARGO HEATING** 

Ident.: DSC-21-40-20-00017798.0001001 / 21 MAR 16

Applicable to: ALL

The ventilation system for the aft cargo compartment uses hot engine bleed air (upstream of the packs), mixing it with the ambient cabin air that flows through the cargo compartment.

The cargo regulating valve regulates the pressure of this hot air supply, and the trim air valve, which is modulated electrically by the controller, controls the flow.

The cargo pressure regulating valve is pneumatically operated and electrically controlled from the HOT AIR pb on the CARGO HEAT panel.

The hot air is controlled by the cargo trim air valve which is modulated electrically by the controller.

The hot air is then mixed with air from the cabin and supplied to the cargo compartment through the ventilation inlet isolation valve.

According to the temperature selector demand, the controller regulates the amount of hot air added by the trim air valve, until the desired temperature is reached.

If the inlet temperature exceeds 70 °C, the controller closes the trim air valve.

If the inlet temperature exceeds 88 °C, the controller interprets this as a duct overheat and closes the pressure regulating valve. This valve then remains closed until the flight crew resets the system by pressing the HOT AIR pb — which it cannot do until the temperature drops below 70 °C.

**FWD CARGO HEATING** 

Ident.: DSC-21-40-20-00017799.0001001 / 21 MAR 16

Applicable to: ALL

The ventilation system for the forward cargo compartment uses hot engine bleed air, which is also used for cockpit and cabin temperature control, mixing it with the ambient cabin air that flows through the cargo compartment.

The cockpit and cabin hot air pressure regulating valve regulates the pressure of this hot air supply, and the cargo trim air valve, which is modulated electrically by the controller, controls the flow.

The hot air mixes with air from the cabin as it supplied to the cargo compartment through the ventilation inlet isolation valve.


The controller regulates the amount of hot air added by the trim air valve to get the desired temperature, per the temperature selector.

If the inlet temperature exceeds 70 °C, the controller closes the trim air valve. If the inlet temperature reaches 88 °C, the controller interprets this as a duct overhead and closes the pressure regulating valve. This valve then remains closed until the flight crew resets the system by pressing the HOT AIR pb - which it cannot do until the temperature drops below 70 °C.

**OVERHEAD PANEL**

Ident.: DSC-21-40-30-00017800.0001001 / 20 MAR 17

Applicable to: ALL



(1) **FWD ISOL VALVE pb-sw**

The switch controls the forward isolation valves and the extraction fan.

**Auto** : The inlet and outlet isolation valves open, extraction fan runs if there is no smoke detected in the fwd cargo bay.

**OFF** : The inlet and outlet isolation valves and the trim air valve close, the extraction fan stops.

**FAULT** It : The light, associated with the ECAM caution, comes on amber when either inlet or outlet valve is not in the selected position.

(2) **AFT ISOL VALVE pb-sw**

The switch controls the isolation valves and the extraction fan.

**Auto** : The inlet and outlet isolation valves open, extraction fan runs if there is no smoke detected in the aft cargo bay.

**OFF** : The inlet and outlet isolation valves and the trim air valve close, the extraction fan stops.

**AIRCRAFT SYSTEMS**

**AIR CONDITIONING / PRESSURIZATION / VENTILATION**

**CARGO - CONTROLS AND INDICATORS**


**FAULT It :** The light, associated with the ECAM caution, comes on amber when either inlet or outlet valve is not in the selected position.



**ECAM COND PAGE**

Ident.: DSC-21-40-35-00006005.0009001 / 22 MAY 12

Applicable to: ALL



- (1) Zone indication  
It is white.
- (2) Inlet isolation valve  
In line – Green : Valve is open.  
Crossline – Amber : Valve is closed.
- (3) Outlet isolation valve  
Crossline – Green : Valve is open.  
In line – Amber : Valve is closed.

Intentionally left blank

# **AIRCRAFT SYSTEMS**

AUTO FLIGHT - GENERAL

Intentionally left blank

**DSC-22\_10-10 Description**

FMGC Standard.....	A
Preamble.....	B
Description.....	C
General Philosophy.....	D
Flight Management Guidance Computer (FMGC).....	E
Multipurpose Control and Display Unit (MCDU).....	F
Flight Control Unit (FCU).....	G
Flight Augmentation Computer (FAC).....	H
Other Flight Crew Interfaces.....	I
Flight Crew Interface with FMGC.....	J

**DSC-22\_10-20 System Interface Diagram**

System Interface Diagram.....	A
-------------------------------	---

**DSC-22\_10-30 FMGS Modes of Operation**

General.....	A
Dual Mode.....	B
Independent Mode.....	C
Single Mode.....	D
Back Up Navigation Mode.....	E

**DSC-22\_10-40 Pilot Interface**

**DSC-22\_10-40-05 Management of the Displays**

General.....	A
--------------	---

**DSC-22\_10-40-10 MCDU**

MCDU.....	A
-----------	---

**DSC-22\_10-40-20 FCU**

FCU.....	A
FCU Philosophy.....	B
Speed/Mach Control Area.....	C
Lateral Control Area.....	D
AP-A/THR Control Area.....	E
Vertical Control Area.....	F


**DSC-22\_10-40-30 Thrust Levers**

Thrust Levers.....	A
--------------------	---

*Continued on the following page*

*Continued from the previous page*

DSC-22_10-40-40 Primary Flight Display	
PFD.....	A
Climb Phase.....	B
Approach Phase.....	C
DSC-22_10-40-50 Navigation Display	
ND.....	A
Arc Mode.....	B
Plan Mode.....	C
Rose Modes.....	D
Flight Plan Display Colors.....	E
<b>DSC-22_10-50 Speeds Definition</b>	
DSC-22_10-50-10 General	
General.....	A
DSC-22_10-50-20 Characteristic Speeds	
Characteristic Speeds.....	A
DSC-22_10-50-30 Limit Speeds	
Limit Speeds.....	A
DSC-22_10-50-40 Protection Speeds	
Protection Speeds.....	A
DSC-22_10-50-50 Other Speeds	
Other Speeds.....	A

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - GENERAL</b></p> <p style="text-align: center;">DESCRIPTION</p>
---	--

**FMGC STANDARD**

Ident.: DSC-22\_10-10-00014871.0012001 / 24 JUL 13

**Applicable to: ALL**

The aircraft is equipped with FMS 2 HONEYWELL Release 1A H2 and FG C13.

**PREAMBLE**

Ident.: DSC-22\_10-10-00010067.0001001 / 17 AUG 10

**Applicable to: ALL**

This section gives a general description of the Auto Flight System and its functions:

- Architecture
- Function description
- Basic principle of systems:
  - Reversion
  - Protection
  - Managed and selected guidance modes.
- Mode information
- Display characteristics
- Operational principles
- Flight crew interface (MCDU pages)
- Degraded modes of operations.

**DESCRIPTION**

Ident.: DSC-22\_10-10-00010068.0001001 / 17 AUG 10

**Applicable to: ALL**

The Flight Management Guidance System (FMGS) contains the following units:

- Two Flight Management Guidance Computers (FMGC)
- Two Multipurpose Control and Display Units (MCDU ) (third MCDU optional)
- One Flight Control Unit (FCU)
- Two Flight Augmentation Computers (FAC).

**GENERAL PHILOSOPHY**

Ident.: DSC-22\_10-10-00010069.0001001 / 17 AUG 10

**Applicable to: ALL**

The Flight Management and Guidance System (FMGS) provides predictions of flight time, mileage, speed, economy profiles and altitude.

It reduces cockpit workload, improves efficiency, and eliminates many routine operations generally performed by the flight crew.

The Flight Management Guidance System (FMGS) operates as follows:

- During cockpit preparation the flight crew uses the Multipurpose Control and Display Unit (MCDU ) to insert a preplanned route from origin to destination. This route includes SID , EN ROUTE, WAYPOINTS, STAR , APPROACH, MISSED APPR , and ALTN route as available from the navigation database.
- Subsequently the system defines a vertical profile and a speed profile, taking into account ATC requirements and performance criteria.

Either FMGC performs all operations, if one FMGC fails.

The FMGS computes the aircraft position continually, using stored aircraft performance data and navigation data. Therefore it can steer the aircraft along a preplanned route and vertical and speed profiles. This type of guidance is said to be “managed”.

If the flight crew wants to modify any flight parameter (SPD , V/S , HDG , etc.) temporarily, they may do so by using the various Flight Control Unit (FCU ) selectors. The FMGS then guides the aircraft to the target value of this parameter that they have selected. This type of guidance is said to be “selected”.

The two available types of guidance, then, are:

- Managed guidance guides the aircraft along the preplanned route and the vertical and speed/Mach profile. (The FMGS computes the target values of the various flight parameters).
- Selected guidance guides the aircraft to the target values of the various flight parameters the flight crew selects by using the FCU selectors.

Selected guidance always has priority over managed guidance.

## FLIGHT MANAGEMENT GUIDANCE COMPUTER (FMGC)

Ident.: DSC-22\_10-10-00010073.0002001 / 17 AUG 10


Applicable to: **ALL**

Each FMGC is divided into two main parts:

- The Flight Management (FM) part controls the following functions:
  - Navigation and management of navigation radios
  - Management of flight planning
  - Prediction and optimization of performance
  - Display management.
- The Flight Guidance (FG) part performs the following functions:
  - Autopilot (AP) command
  - Flight Director (FD) command
  - Autothrust (A/THR) command.

Each FMGC has its own set of databases. The individual databases can be independently loaded into their respective FMGC , or independently copied from one FMGC to the other.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - GENERAL</b></p> <p align="center">DESCRIPTION</p>
---	--

Each FMGC contains these main databases:

1. The Navigation database (2.8 Mbytes) contains standard navigation data: Nav aids, waypoints, airways, enroute information, holding patterns, airports, runways, procedures (SID s, STARs, etc.), company routes, alternates.  
The airline updates this part every 28 days, and is responsible for defining, acquiring, updating, loading, and using this data. The updating operation takes 20 min to complete or 5 min if cross loaded from the opposite FMGC.
2. The Airline Modifiable Information (AMI ), also described as the FM Airline Configuration file, contains:
  - Airline policy values: THR RED altitude, ACC altitude, EO ACC altitude, PERF factor, IDLE factor.
  - Fuel policy values: Fuel for taxi, % of route reserve, maximum and minimum values of route reserve, etc.
  - AOC functions customization.
3. The Aircraft Performance database includes the Engine model, Aerodynamical model, and Performance model. The airline cannot modify this database.
4. The Magnetic Variation database.
5. Each FMGC contains elements stored by the flight crew that enable them to create 20 waypoints, 10 runways, 20 nav aids, and 5 routes.

**MULTIPURPOSE CONTROL AND DISPLAY UNIT (MCDU)**

Ident.: DSC-22\_10-10-00010074.0002001 / 17 AUG 10

Applicable to: ALL

Two MCDU s are installed on the pedestal for flight crew loading and display of data. The use of the MCDU allows the flight crew to interface with the FMGC by selection of a flight plan for lateral and vertical trajectories and speed profiles. The flight crew may also modify selected navigation or performance data and specific functions of Flight Management (revised flight plan, engine-out, secondary flight plan, etc.). Additional data from peripherals (Centralized Fault Display System (CFDS ), ARINC Communication Addressing and Reporting System (ACARS ), Air Traffic Service Unit (ATSU )...) can also be displayed. Data that is entered into the MCDU that is illogical or beyond the aircraft capabilities will either be disregarded or will generate an advisory message. The MCDU s allow the activation of the back-up navigation in the case of a dual FM Failure.

**FLIGHT CONTROL UNIT (FCU)**

Ident.: DSC-22\_10-10-00010075.0001001 / 17 AUG 10

Applicable to: ALL

The FCU located on the glareshield, is the short-term interface between the flight crew and the FMGC . It is used to select any flight parameters or modify those selected in the MCDU. The

autopilots and autothrust functions may be engaged or disengaged. Different guidance modes can be selected to change various targets (speed, heading, track, altitude, flight path angle, vertical speed).

### FLIGHT AUGMENTATION COMPUTER (FAC)

Ident.: DSC-22\_10-10-00010076.0001001 / 17 AUG 10

Applicable to: **ALL**

The FAC controls rudder, rudder trim and yaw damper inputs. It computes data for the flight envelope and speed functions. The FAC also provides warning for low-energy and windshear detection if these functions are installed.

### OTHER FLIGHT CREW INTERFACES

Applicable to: **ALL**

Ident.: DSC-22\_10-10-A-00010077.0001001 / 23 JUN 15

### THRUST LEVERS

The thrust levers are the main interface between the Flight Management Guidance Computer (FMGC), the Full Authority Digital Engine Control System (FADEC), and the flight crew.

The thrust levers:

- Arm the autothrust at takeoff, when FLX or TOGA is selected
- Limit the maximum thrust by their position when autothrust is active
- Disconnect the autothrust system when the flight crew sets them to IDLE
- Command the thrust manually when autothrust is not active
- Engage the common modes (takeoff or go-around) when TOGA (or FLX for takeoff) is set
- Set the autothrust to the active mode when they are between IDLE and CL detent (MCT in engine out).

Ident.: DSC-22\_10-10-A-00010078.0001001 / 17 AUG 10

### ELECTRONIC FLIGHT INSTRUMENTS (EFIS)

Two Primary Flight Displays (PFD) and Navigation Displays (ND) provide the flight crew with full-time flight guidance, navigation and system advisory information for all flight phases. An EFIS control panel is located at each end of the glareshield and is used to control both Primary and Navigation Displays. This panel includes controls to select various modes within the PFD. A selector allows the barometric altimeter setting to be displayed on the PFD. Various distance ranges can be selected on the ND, and two switches allow either the left or right VOR /ADF bearing pointers to be displayed on the ND.

Ident.: DSC-22\_10-10-A-00010079.0001001 / 17 AUG 10

### **PRIMARY FLIGHT DISPLAYS**

The PFDs combine several conventional flight instrument indications on one color display panel, for centralized reference of flight data.

This centralized color display includes:

- Flight Director attitude guidance targets
- Armed and engaged modes
- Navigation and instrument approach information
- Altimeter setting
- Barometric altitude
- System messages.

Ident.: DSC-22\_10-10-A-00010080.0002001 / 17 AUG 10

### **NAVIGATION DISPLAYS**

Five different color navigation compass displays can be selected:


- ARC (map mode)
- ROSE NAV (map mode)
- ROSE VOR
- ROSE LS
- PLAN.

Information displayed on these modes uses the aircraft's position as a reference point for the flight plan navigation data (lateral and vertical information).

**FLIGHT CREW INTERFACE WITH FMGC**

Ident.: DSC-22\_10-10-00010082.0002001 / 14 MAY 12


Applicable to: **ALL**



**SYSTEM INTERFACE DIAGRAM**

Ident.: DSC-22\_10-20-00010084.0001001 / 01 OCT 12

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**  
SYSTEM INTERFACE DIAGRAM

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_10-30-00010085.0002001 / 17 AUG 10

Applicable to: ALL

The FMGS has four modes of operation:

- Dual mode (the normal mode)
- Independent mode. Each FMGC being controlled by its associated MCDU
- Single mode (using one FMGC only)
- Back-up navigation mode.

**DUAL MODE**


Ident.: DSC-22\_10-30-00010086.0001001 / 01 OCT 12

Applicable to: ALL

This is the normal mode. The two FMGCs are synchronized: each performs its own computations and exchanges data with the other through a crosstalk bus.

One FMGC is the master, the other the slave, so that some data in the slave FMGC comes from the master.

All data inserted into any MCDU is transferred to both FMGCs and to all peripherals.




**MASTER FMGC LOGIC**

- If one autopilot (AP ) is engaged, the related FMGC is master:
  - It uses the onside FD for guidance
  - It controls the A/THR
  - It controls the FMA 1 and 2.
- If two AP s are engaged, FMGC1 is master.
- If no AP is engaged, and
  - The FD1 pb is on, then FMGC1 is master
  - The FD1 pb is off, and FD2 pb on then FMGC2 is master.
- If no AP /FD is engaged, A/THR is controlled by FMGC1.

**INDEPENDENT MODE**

Ident.: DSC-22\_10-30-00010087.0001001 / 01 OCT 12

Applicable to: ALL





The system automatically selects this degraded mode under specific abnormal conditions (e.g. different database validity on both FMGCs).

Both FMGCs work independently and are linked only to peripherals on their own sides of the flight deck (“onside” peripherals).

When this occurs, the “INDEPENDENT OPERATION” message is displayed on both MCDU scratchpads.



Each MCDU transmits data it receives from its onside FMGC . It affects only the onside EFIS (Electronic Flight Instrument System) and RMP (Radio Management Panel).  
On the POS MONITOR page (and GPS MONITOR page ), FMGS position (and GPS position ) from the opposite FMGC is not displayed.  
On the RAD NAV page (and PROG page, if the FMGS GPS is not installed), nav aids tuned on the opposite MCDU are not displayed. Corresponding fields are blank.

### **PROCEDURES ON GROUND**

- **If each FMGC is loaded with a different database**, the FMGS will only operate in independent mode.

CHECK the database number and validity.

CROSSLOAD  the database to restore the dual operation.

*Crossload function is available on ground only (in preflight or done phase), when an independent operation is detected.*

### **PROCEDURES IN FLIGHT**

DO NOT SWITCH the navigation databases.

MAKE the same entries on both MCDU s to have both AP /FDs similar orders.

*Both FG s being valid, 2 AP s may be engaged for CAT II or CAT III operations.*

- **In the event of a go-around and when the second AP is disconnected:**


ENSURE that the FMGC in command has correct flight plan orders and an updated nav database.

*Airbus does not recommend pulling one FMGC circuit breaker to force the system to operate in SINGLE mode.*

**SINGLE MODE**

Ident.: DSC-22\_10-30-00010088.0004001 / 01 OCT 12

Applicable to: ALL



The system automatically selects this degraded mode when one FMGC fails. When this occurs, the failed FMGC displays "OPP FMGC IN PROCESS" in white on the MCDU scratchpad.

On the ND usually associated with the failed FM:

- If the ND s are not both in the same mode or range, the associated ND displays "MAP NOT AVAIL" and "SET OFFSIDE RNG/MODE".
- If the ND s are in the same mode and range, the associated ND displays the "OFFSIDE FM CONTROL" amber message.

Both POS MONITOR pages display the same position (operative FMGC position).

Both FD s are driven by the same FMGC . Any entry on either MCDU is sent to the operative FMGC.

**PROCEDURES**

● **If a transient failure triggers a single mode of operation:**

DO NOT USE the MCDU(s) until the PLEASE WAIT message is suppressed.


SET both NDs on the same range and mode to display the same information from the operative FMGC.

When convenient, RESET the failed FMGC. (*Refer to DSC-22\_20-90-10 Manual FMGC Reset - General*).

**BACK UP NAVIGATION MODE**

Ident.: DSC-22\_10-30-00010089.0001001 / 01 OCT 12

Applicable to: ALL



The flight crew selects on the MCDU MENU page this degraded mode when both FMGCs fail. They recover the navigation function through the MCDU and IRS /GPS  $\langle \text{X} \rangle$ . The MCDU continuously memorizes the active flight plan in its memory.

If both FMGCs fail, the back up navigation provides the following functions:

- Flight Planning
- Aircraft position using inside IRS , IRS 3, or GPIRS position (if GPS  $\langle \text{X} \rangle$  )
- F-PLN display on ND
- No AP /FD NAV mode
- Limited lateral revision
- F-PLN automatic sequencing.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**  
FMGS MODES OF OPERATION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**

PILOT INTERFACE - MANAGEMENT OF THE DISPLAYS

**GENERAL**

Ident.: DSC-22\_10-40-05-00010083.0001001 / 17 AUG 10

**Applicable to: ALL**

The flight management system displays navigation, performance and guidance information on the:

- Multipurpose Control and Display Unit (MCDU)
- Navigation Display (ND ) of the Electronic Flight Instrument System (EFIS)
- Primary Flight Display (PFD ) of the EFIS.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**

PILOT INTERFACE - MANAGEMENT OF THE DISPLAYS


Intentionally left blank

**MCDU**

Applicable to: ALL

Ident.: DSC-22\_10-40-10-A-00010090.0003001 / 14 MAY 12

**MCDU INTERFACE**



Ident.: DSC-22\_10-40-10-A-00010091.0002001 / 13 DEC 12

## **GENERAL**

The Multipurpose Control and Display Unit (MCDU ) has a Liquid Crystal Display (LCD) with 14 lines of 24 characters each, including:

- A title line that gives the name of the current page in large letters
- Six label lines, each of which names the data displayed just below it (on the data field line)
- Six data field lines that display computed data or data inserted by the flight crew
- The scratchpad line that displays:
  - Specific messages
  - Information the flight crew has entered by means of the number and letter keys and which can then be moved to one of the data fields.

Ident.: DSC-22\_10-40-10-A-00010092.0001001 / 17 AUG 10


## **LINE SELECT KEYS**

There is a column of Line Select Keys (LSKs) on each side of the screen.

The flight crew uses these keys to:

- Move a parameter they have entered in the scratchpad to the appropriate line on the main screen
- Call up a specific function page indicated by a prompt displayed on the adjacent line
- Call up lateral or vertical revision pages from the flight plan page.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - GENERAL</b></p> <p>PILOT INTERFACE - MCDU</p>
---	--

Ident.: DSC-22\_10-40-10-A-00010093.0002001 / 17 AUG 10

## **KEYBOARD**

The keyboard includes:

- Function and Page keys Call up functions and pages the flight crew uses for flight management functions and computations.
- ↑ ↓ (or SLEW) keys Move a page up or down to display portions that are off the screen.
- ← → keys Moves to the next page of a multi-page element. An arrow in the top right corner indicates that another page is available.
- AIRPORT key Calls up the flight plan page that contains the next airport along the current flight plan. Successive pushes on the key show the alternate airport, the origin airport (before takeoff), and the next airport again.
- Number and letter keys allow the flight crew to insert data in the scratchpad so that they can use a line select key to enter it in the main display.
- Three keys have special functions:
  - CLR (clear) key Erases material (messages or inserted data) from the scratchpad or from certain areas of displayed pages.
  - OVFY (overfly) key Allows the aircraft to overfly a selected waypoint.
  - SP (space) key Allows to insert a space in specific message.

Ident.: DSC-22\_10-40-10-A-00010094.0002001 / 17 AUG 10

## **ANNUNCIATORS (ON THE SIDE OF THE KEYBOARD)**

- FAIL (amber) Indicates that the Multipurpose Control and Display Unit (MCDU) has failed.
- MCDU MENU (white) Indicates that the flight crew should call up a peripheral linked to the MCDU (such as ACARS , ATSU or CFDS).
- FM (white) Comes on while the flight crew is using the MCDU to display peripherals. This light tells the flight crew that the FMGC has an important message to deliver. The flight crew accesses the message by pressing the MCDU MENU key and the line select key adjacent to the FMGC prompt.

Ident.: DSC-22\_10-40-10-A-00010757.0002001 / 17 AUG 10

## **ANNUNCIATORS (ON THE TOP OF THE KEYBOARD)**

- FM 1 and FM 2 (amber) The onside FM is failed
- IND (amber) The onside FM detects an independent mode of operation while both FM are healthy.
- RDY (green) MCDU has passed its power up test after it was turned off using its DIM key.

Ident.: DSC-22\_10-40-10-A-00010750.0001001 / 17 AUG 10

## **BRT AND DIM KEYS**

Control the light intensity of the entire MCDU . MCDU power up is performed with the BRT key and MCDU shut down is performed with the DIM key.

Ident.: DSC-22\_10-40-10-A-00010097.0001001 / 17 AUG 10

## **DATA ENTRY**

The flight crew enters data by typing it into the scratchpad on the MCDU . Next, pressing the line select key (LSK ) will load the data from the scratchpad into the desired field. An error message displays if the data is out of range or not formatted correctly. To correct data, the flight crew may clear the message with the clear (CLR) key and then retype the message into the scratchpad. Pressing the CLR key when the scratchpad is empty displays "CLR". To clear data from a field, select CLR from the scratchpad to the data field to be cleared.

Ident.: DSC-22\_10-40-10-A-00010098.0001001 / 17 AUG 10

## **MCDU ENTRY FORMAT**

The flight crew enters information into the MCDU at the bottom line of the scratchpad. When data has lead zeros, they may be omitted if desired. For example a three-digit wind direction of 060 may be typed as 60. The display will still show 060. To enter an altitude below 1 000 ft, the lead zero must be added as 0400 for 400 ft. This differentiates the altitude from a flight level. To enter a double data entry such a speed/altitude, the separating slash must be used. If entering only the first part of a double entry, omit the slash. To enter only the second part of a double entry, a leading slash must be used i.e. /0400.


Ident.: DSC-22\_10-40-10-A-00010099.0001001 / 17 AUG 10

## **MESSAGES**

The scratchpad displays various messages for flight crew information. Theses messages are prioritized by importance to the flight crew as either amber or white.

Amber messages are:

- Navigation messages
- Data entry messages
- EFIS repeat messages.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - GENERAL</b> PILOT INTERFACE - MCDU
---	---

Amber messages are categorized into two types:

- Type 1 message that is a direct result of a flight crew action. Type 1 messages are displayed immediately in the scratchpad ahead of other messages.
- Type 2 messages inform the flight crew of a given situation or request a specific action. Stored in "last in", "first out" message queue that holds maximum of 5 messages.  
Type 2 messages are displayed in the scratchpad only if there are no Type 1 messages or other data and will remain until all the messages have been viewed and cleared with the CLR key.

White messages are advisory only.

Ident.: DSC-22\_10-40-10-A-00010101.0001001 / 17 AUG 10

### **CHARACTERS**

Small and large fonts are displayed according to the following rules:

- The title line and the scratchpad are displayed in large font
- Datafields are usually displayed in large font
- Label lines are displayed in small font
- Flight crew entries and modifiable data are displayed in large font
- Defaulted/computed and non modifiable data are displayed in small font.

Ident.: DSC-22\_10-40-10-A-00010102.0001001 / 17 AUG 10

### **COLORS**

DATA	MCDU COLOR
TITLES, COMMENTS, <, >, ↑ ↓, ← →, DASHES, MINOR MESSAGES	WHITE
- MODIFIABLE DATA - SELECTABLE DATA - BRACKETS	BLUE
- NON MODIFIABLE DATA - ACTIVE DATA	GREEN
- MANDATORY DATA (BOXES) - FLIGHT CREW ACTION REQUIRED - IMPORTANT MESSAGES - MISSED CONSTRAINT	AMBER
- CONSTRAINTS - MAX ALTITUDE	MAGENTA
PRIMARY F-PLN	GREEN WAYPOINTS, WHITE LEGS
TEMPORARY F-PLN	YELLOW WAYPOINTS, WHITE LEGS

*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**  
PILOT INTERFACE - MCDU

*Continued from the previous page*

<b>DATA</b>	<b>MCDU COLOR</b>
SECONDARY F-PLN	WHITE WAYPOINTS AND LEGS
MISSED APPROACH (not active)	BLUE WAYPOINTS, WHITE LEGS
ALTERNATE F-PLN (not active)	BLUE WAYPOINTS, WHITE LEGS
OFFSET	GREEN WAYPOINTS, WHITE LEGS, OFST DISPLAYED IN THE TITLE OF THE F-PLN PAGE
TUNED NAVAID	BLUE
"TO" WAYPOINT AND DESTINATION	WHITE

Ident.: DSC-22\_10-40-10-A-00010103.0001001 / 14 MAY 12

### SCREEN PROMPTS



**Screen 1: INIT**

Annotations for Screen 1:

- : Data entry is mandatory to allow the FMGC to perform all its functions.
- ↑↓: When these arrows are beside a label line, it is possible to increase or decrease the value displayed below by pressing [↑] or [↓] keys on the keyboard.
- Label line
- Dataline or data field
- Upper right corner of screen indicates that next page is available by depressing next page key.
- : This data will be computed by the FMGC if it has enough information, or provided out of the database or inserted by the crew.

**Screen 2: FROM TMPY**

Annotations for Screen 2:

- ← →: A turn (left ← or right →) is specified on the leg which started at the waypoints adjacent to the arrow.
- Δ: Displayed beside a fixed waypoint on the F-PLN page to indicate that the A/C will overfly the fixed point
- ← →: Indicate that pressing the adjacent LS key will activate the prompt or select some data.
- \*: Indicates that a constraint has been inserted. Displayed only if predictions available.
- \*: Indicates that pressing the adjacent LS key will change parameters affecting the active situation.
- ↑↓: Scrolling is available by pressing ↑ or ↓ key on the keyboard. The page is not large enough to display the whole information.

**Screen 3: LAT REV FRZ**

Annotations for Screen 3:

- < or >: Means that another page may be accessed by pressing the adjacent key.
- [ ]: A data insertion is possible.
- +,-: When an altitude constraint has been entered at the waypoint, the constraint value is displayed on the VERT REV page.
- A plus (+) is displayed for at above altitude constraint and a minus (-) for at or below altitude constraint.


Ident.: DSC-22\_10-40-10-A-00010104.0002001 / 23 JUN 15

### MCDU FUNCTION KEYS

The function keys on the Multipurpose Control and Display Units allow the flight crew to call up MCDU pages quickly.

The following is a summary of the purpose of each key:

DIR	<p>Calls up the DIR TO page, and enables the flight crew to proceed directly from the present position to any waypoint, entered manually or selected in the active flight plan.</p>
PROG	<p>Calls up the progress page corresponding to the phase of the active flight plan that is in progress.</p> <p>This page displays navigation information and active data such as the optimum and maximum recommended cruise flight levels. It enables the flight crew to update the FMGS position and to obtain a bearing and distance to any location.</p>
PERF	<p>Calls up the performance pages, that display the optimum speed or Mach number for each phase. The flight crew can amend these pages. The first page to be displayed is the one corresponding to the current flight phase (except for preflight and done phases).</p> <p>The flight crew can then use the appropriate 6L or 6R LSK to call up pages corresponding to future flight phases.</p>
INIT	<p>Calls up the flight plan initialization A page, which also gives the flight crew access to the B page. The flight crew uses the INIT pages to initialize Flight Management for the flight.</p> <p>The flight crew uses the INIT A page primarily to insert his flight plan and to align the inertial reference system.</p> <p>The flight crew uses the INIT B page to insert aircraft weight, fuel on board, CG and various fuel requirements. The FMGS uses this data to compute predictions and fuel planning parameters.</p> <p>The flight crew has access to the INIT A page only in the preflight phase. INIT B page (not accessible after engine start) is called up by pressing the "NEXT PAGE" key.</p>
DATA	<p>Calls up the data index page. This gives the flight crew access to various reference pages that show aircraft position, aircraft status, runways, waypoints, nav aids, routes, and data stored by the flight crew.</p>
F-PLN	<p>Calls up the flight plan A and B pages, which contain a leg-by-leg description of the active primary flight plan.</p> <p>The flight crew can use the slewing keys to review the entire active flight plan. They can make all lateral and vertical revisions to the flight plan through these pages, using the left LSKs for lateral revision and the right keys for vertical revision.</p>
RAD NAV	<p>Calls up the radio navigation page. This page displays the Radio Nav aids tuned automatically or manually through the FMGC.</p>

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - GENERAL</b></p> <p>PILOT INTERFACE - MCDU</p>
---	--

FUEL PRED	Calls up the fuel prediction page. Once the engines are started, this page displays the fuel predicted to be remaining at the destination and the alternate, as well as fuel management data.
SEC F-PLN	Calls up the index page for the secondary flight plan. The flight crew can use this page to call up the secondary flight plan and all the functions related to it (copying, deleting, reviewing, activating, and the INIT and PERF pages).
ATC COMM	Calls up the ATC applications (not activated).
MCDU MENU	Calls up the MCDU MENU page, which displays the subsystems currently addressed via the MCDU. The key next to the name of a subsystem enables the flight crew to select that subsystem. When the MCDU MENU annunciator lights up, the flight crew should press the MCDU MENU key. The menu will have [REQ] displayed next to the name of the subsystem that requires attention.

Ident.: DSC-22\_10-40-10-A-00010107.0005001 / 01 OCT 12

### MCDU DISPLAY

The MCDUs display:

- Position and accuracy information
- Tuned nav aids
- Lateral and vertical flight plans (waypoints, pseudo waypoints, constraints)
- Predictions (SPD, TIME, ALT, WIND)
- Fuel predictions and fuel management information (estimated fuel on board, extra fuel)
- Performance data.

F-PLN A page

	FROM AF5612 →	
[1L]	TOP9A TIME SPD/ALT	[1R]
	LSGG23 0000 148/ 1365	
[2L]	TOP9A BRG228° 6NM	[2R]
	PAS 0003 210/*5500	
[3L]	HOLD L TRK228° 12	[3R]
	7000 0006 °/ 7000	
[4L]	[SPD] 0	[4R]
	[LIM] 0006 210/ 7000	
[5L]	TOP9A 5	[5R]
	D136E 0007 *230* FL90	
[6L]	DEST TIME DIST EFOB	[6R]
	LGAT33R 0220 990 8.4	
	↑↓	

RADIO NAV PAGE

<b>RADIO NAV</b>		
[1L]	VOR1/FREQ STU/113.10	[1R]
	FREQ/VOR2 112.5 / TGO	
[2L]	CRS [ ]	[2R]
	ILS/FREQ	
[3L]	ISW / 109.90	[3R]
	CRS SLOPE	
[4L]	227 -3.0	[4R]
	ADF1/FREQ TOE/415.00	
[5L]	FREQ/ADF2 [ ][ ]	[5R]
[6L]	← ADF1 BFO	[6R]




**FCU**

Ident.: DSC-22\_10-40-20-00010112.0003001 / 03 AUG 17

Applicable to: ALL

The Flight Control Unit (FCU ) is located on the glareshield and is constituted of three control panels: One for the automatic flight controls and two for the Electronic Flight Instrument System (EFIS ). The FCU has two channels, each of which can independently command the central control panel. If one channel fails, the other channel can control all the functions.




**FCU PHILOSOPHY**

Ident.: DSC-22\_10-40-20-00010113.0002001 / 14 MAY 12

Applicable to: ALL

The flight crew can use two types of guidance to control the aircraft in auto flight. One type is managed by the Flight Management Guidance System (FMGS). The other uses target quantities which are manually entered by the flight crew.

When the aircraft uses target quantities from the FMGS (managed guidance), the FCU windows display dashes and the white dots next to those windows light up. When the aircraft uses target quantities, entered by the flight crew (selected guidance), the windows display the selected numbers and the white dots do not light up.



**Note:** The altitude window always displays an altitude selected by the flight crew (never dashes).

The FCU has four knobs:

- SPD-MACH
- HDG -TRK
- ALT
- V/S -FPA.

The knobs can be rotated, pushed in, and pulled out:


- In order to arm or engage managed guidance for a given mode, the flight crew pushes in the associated knob. If, for example, they push in the HDG knob, they engage or arms the NAV mode.
- In order to engage a selected guidance mode, the flight crew turns the knob to set the desired value, then pulls the knob out to engage the mode with a target value equal to the selected value.

**Note:** In managed guidance (lateral, vertical guidance or managed speed), the corresponding window is dashed. Turning a knob without pulling it, displays a value that is the sum of the current target and the turn action value. The display remains 45 s on the HDG /TRK and V/S windows and 10 s on the SPD/MACH window before the dashes reappear. This rule does not apply to the ALT knob/window.

**SPEED/MACH CONTROL AREA**

Ident.: DSC-22\_10-40-20-00010114.0002001 / 14 MAY 12

Applicable to: ALL



**SPD/MACH knob**

Display range: between 100 and 399 kt for speed, between 0.10 and 0.99 for Mach number.  
One rotation of the knob corresponds to approximately 32 kt or M 0.32.


**SPD/MACH pb**

Pushing this pushbutton changes the SPD target to the corresponding MACH target and vice versa.

**LATERAL CONTROL AREA**

Ident.: DSC-22\_10-40-20-00010115.0007001 / 14 MAY 12

Applicable to: ALL



**HDG/TRK knob**

Display range: between 0 ° and 359 °.  
 One rotation of the knob corresponds to 32 ° (1 ° per click).


**LOC pb**

Pushing this pushbutton arms, engages, or disengages the LOC mode.

**HDG V/S – TRK FPA pb**

The flight crew uses this pushbutton to select HDG (associated with V/S) or TRK (associated with FPA). Pushing it:


- Displays the Flight Path Vector (FPV) on the Primary Flight Display (PFD) or deletes it.
- On the PFD, changes the FD crossbar display (with the aircraft attitude as its reference) to the aircraft Flight Path Director (with the flight path vector as its reference) and vice versa.
- Changes heading reference into track reference in the HDG /TRK window and vice versa.
- Changes vertical speed reference target into flight path angle reference target in the V/S -FPA window and vice versa.



**AP-A/THR CONTROL AREA**

Ident.: DSC-22\_10-40-20-00010116.0001001 / 14 MAY 12

Applicable to: ALL



**AP1 pb AND AP2 pb**


The flight crew uses these pushbuttons to engage or disengage the autopilots. The buttons illuminate green when the autopilot is engaged.

**A/THR pb**

The flight crew uses this pushbutton to arm, activate, or disconnect the autothrust (A/THR). This button illuminates green if the A/THR is armed or active.

**VERTICAL CONTROL AREA**

Ident.: DSC-22\_10-40-20-00010117.0006001 / 22 MAY 12  
Applicable to: ALL



The FCU altitude window always displays a target value selected by the flight crew. It never displays dashes.

### **Altitude knob (INNER AND OUTER)**


Display range: 100 to 49 000 ft

- The outer knob has two positions: 100 and 1000
- The inner knob sets the altitude in the FCU window in increments of 100 or 1 000 ft, depending upon the position of the outer knob.

### **EXPED pb**

This pushbutton is used to engage the expedite mode. *Refer to DSC-22\_30-70-90 General.*

### **METRIC ALT pb**

This pushbutton is used to display the FCU altitude target in meters on the ECAM , or the current altitude and FCU /FM altitude target in meters on the PFD  .

### **V/S or FPA knob**

Range (V/S) : -6 000 to +6 000 ft/min

2 clicks = 100 ft/min

If the flight crew turns the knob slowly, each click equals 100 ft/min.

Range (FPA) : -9.9 ° to +9.9 °

1 click = 0.1 °

The flight crew turns this knob to set the value of the vertical speed (V/S ) or flight path angle (FPA ) to be displayed in the V/S or FPA window (They choose which, V/S or FPA, is to be displayed by pushing the HDG V/S - TRK FPA pb).

One rotation of the knob corresponds to 32 clicks. One complete rotation sets:

FPA = 3.2 °

V/S = 1 600 ft/min

When the flight crew pushes in the V/S or FPA knob, the system commands an immediate level-off by engaging the V/S or FPA mode with a target of zero. The flight mode annunciator (FMA) then displays "V/S = 0" in green when V/S or FPA is nulled. If the flight crew now turns the knob to put in a new setting for V/S or FPA, the aircraft changes flight path accordingly.

### **APPR pb**

This pushbutton arms, disarms, engages, or disengages the approach modes:

- LOC and G/S modes, if an ILS approach is selected in the active F-PLN.
- APP NAV -FINAL modes, if a non precision approach is selected in the active F-PLN.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**  
PILOT INTERFACE - FCU


Intentionally left blank



**THRUST LEVERS**

Ident.: DSC-22\_10-40-30-00010119.0001001 / 14 MAY 12

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - GENERAL**

PILOT INTERFACE - THRUST LEVERS

Intentionally left blank

**PFD**

Ident.: DSC-22\_10-40-40-00010677.0001001 / 17 AUG 10

**Applicable to: ALL**


The Flight Management and Guidance System generates the following information to the EFIS Primary Flight Display:

- Armed and engaged modes on the Flight Mode Annunciator (FMA)
- FMGS guidance targets (SPD , ALT , HDG)
- Vertical deviation from descent profile
- Messages
- Navigation information.

**CLIMB PHASE**

Ident.: DSC-22\_10-40-40-00010121.0002001 / 14 MAY 12


**Applicable to: ALL**



**APPROACH PHASE**

Ident.: DSC-22\_10-40-40-00010122.0013001 / 14 MAY 12

Applicable to: ALL



**ND**

Ident.: DSC-22\_10-40-50-00010123.0001001 / 17 AUG 10

Applicable to: ALL


The FMGS generates the following information, displayed on the EFIS Navigation Displays:

- Flight plan (active secondary, temporary, dashed)
- Aircraft position and lateral deviation from the flight plan
- Pseudo-waypoints along the flight plan
- Raw data from tuned Nav aids and type of selected approach
- Various display options (waypoints, Nav aids, NDBs, airports, constraints)
- Wind information and various messages.

**ARC MODE**

Ident.: DSC-22\_10-40-50-00010124.0001001 / 14 MAY 12


Applicable to: ALL



**PLAN MODE**

Ident.: DSC-22\_10-40-50-00010125.0001001 / 01 OCT 12


Applicable to: ALL



**ROSE MODES**

Ident.: DSC-22\_10-40-50-00010126.0022001 / 09 MAR 15

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - GENERAL

#### PILOT INTERFACE - NAVIGATION DISPLAY

### FLIGHT PLAN DISPLAY COLORS

Ident.: DSC-22\_10-40-50-00010127.0002001 / 17 AUG 10

Applicable to: ALL

F-PLN	Color
Primary Flight Plan	- Managed mode: Steady green - Selected mode: Dashed green
Track line	Steady green
Alternate flight plan	Dashed blue
Missed approach	Steady blue
Offset flight plan	Steady green (Original flight plan: Dashed green)
Temporary flight plan	Dashed yellow
Engine-out SID (not inserted)	Steady yellow
Secondary flight plan	Steady dimmed white
Abeam/Radial	Dashed blue





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - GENERAL**  
SPEEDS DEFINITION - GENERAL

**GENERAL**

Ident.: DSC-22\_10-50-10-00020369.0001001 / 17 MAR 17

**Applicable to: ALL**

This chapter shows the speed symbols and definitions.  
The source of the computation is also given, when applicable.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - GENERAL**

**SPEEDS DEFINITION - GENERAL**

Intentionally left blank

## CHARACTERISTIC SPEEDS

Ident.: DSC-22\_10-50-20-00020370.0002001 / 17 MAR 17

Applicable to: ALL

The characteristic speeds displayed on the PFD are computed by the Flight Augmentation Computer (FAC), according to aerodynamic data.

VLS (of normal landing configuration: CONF 3 or FULL), F, S and Green Dot speeds are also displayed on the MCDU TAKEOFF and/or APPR pages.

The speeds displayed by the MCDU are computed by the FMS, based on the aircraft gross weight (which is computed according to the entered ZFW and the FOB), or the predicted gross weight (for approach or go-around).

VS : Stalling speed.  
Not displayed.

For a conventional aircraft, the reference stall speed, VSmin, is based on a load factor that is less than 1 g. This gives a stall speed that is lower than the stall speed at 1 g. All operating speeds are expressed as functions of this speed (for example, VREF = 1.3 VSmin).

Because aircraft of the A320 family have a low-speed protection feature (alpha limit) that the flight crew cannot override, Airworthiness Authorities have reconsidered the definition of stall speed for these aircraft.

All the operating speeds must be referenced to a speed that can be demonstrated by flight tests. This speed is designated VS1g.

Airworthiness Authorities have agreed that a factor of 0.94 represents the relationship between VS1g for aircraft of the A320 family and VSmin for conventional aircraft types. As a result, Authorities allow aircraft of the A320 family to use the following factors :

$$V2 = 1.2 \times 0.94 \text{ VS1g} = 1.13 \text{ VS1g}$$
$$VREF = 1.3 \times 0.94 \text{ VS1g} = 1.23 \text{ VS1g}$$

These speeds are identical to those that the conventional 94 % rule would have defined for these aircraft. The A318, A319, A320 and A321 have exactly the same maneuver margin that a conventional aircraft would have at its reference speeds.

The FCOM uses VS for VS1g.

VLS : Lowest Selectable Speed.

Represented by the top of an amber strip along the airspeed scale on the PFD.

Computed by the FAC, based on aerodynamic data, and corresponds to 1.13 VS during takeoff, or following a touch and go.

Becomes 1.23 VS, after retraction of one step of flaps.

Becomes 1.28 VS, when in clean configuration.

*Note: If in CONF 0 VLS were 1.23 VS (instead of 1.28 VS), the alpha protection strip would hit the VLS strip on the PFD.*

Above 20 000 ft, VLS is corrected for Mach effect to maintain a buffet margin of 0.2 g.

In addition, VLS increases when the speedbrakes are extended.

F : Minimum speed at which the flaps may be retracted at takeoff.

In approach, used as a target speed when the aircraft is in CONF 2 or CONF 3.

Represented by "F" on the PFD speed scale. Equal to about 1.18 VS to 1.22 VS of CONF 1 + F.

S : Minimum speed at which the slats may be retracted at takeoff.

In approach, used as a target speed when the aircraft is in CONF 1.

Represented by "S" on the PFD airspeed scale.

Equal to about 1.22 VS to 1.25 VS of clean configuration.

O : Green dot speed.

Engine-out operating speed in clean configuration.

(Best lift-to-drag ratio speed).

Also corresponds to the final takeoff speed.

Represented by a green dot on the PFD scale.

Below 20 000 ft equal to 2 × weight (tons) +85

Above 20 000 ft, add 1 kt per 1 000 ft

**LIMIT SPEEDS**

Ident.: DSC-22\_10-50-30-00020383.0001001 / 17 MAR 17

Applicable to: ALL

- VA : Maximum design maneuvering speed. This corresponds to the maximum structural speed permitted for full control deflection, if alternate or direct law is active.
- VMCG : Minimum speed, on the ground during takeoff, at which the aircraft can be controlled by only using the primary flight controls, after a sudden failure of the critical engine, the other engine remaining at takeoff thrust.
- VMCA : Minimum control speed in flight at which the aircraft can be controlled with a maximum bank of 5 °, if one engine fails, the other engine remaining at takeoff thrust (takeoff flap setting, gear retracted).
- VMCL : Minimum control speed in flight, at which the aircraft can be controlled with a maximum bank of 5 °, if one engine fails, the other engine remaining at takeoff thrust (approach flap setting).
- VFE : Maximum speed for each flap configuration.
- VLE : Maximum speed with landing gear extended.
- VLO : Maximum speed for landing gear operation.
- VMO : Maximum speed.
- VFE NEXT : Maximum speed for the next (further extended) flap lever position.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - GENERAL**

SPEEDS DEFINITION - LIMIT SPEEDS

Intentionally left blank

**PROTECTION SPEEDS**

Ident.: DSC-22\_10-50-40-00020382.0001001 / 17 MAR 17

Applicable to: ALL

$V\alpha$  PROT,  $V\alpha$  MAX and VSW are computed by the FAC , based on aerodynamic data. They are only used for display on the PFD , and not for flight control protection (the activation of the protections is computed by the ELAC).

$V\alpha$  PROT : Angle of attack protection speed.

Corresponds to the angle of attack at which the angle of attack protection becomes active.

Represented by the top of a black and amber strip along the PFD speed scale, in normal law.

$V\alpha$  MAX : Maximum angle of attack speed.

Corresponds to the maximum angle of attack that may be reached in pitch normal law.

Represented by the top of a red strip along the PFD speed scale, in normal law.

VSW : Stall warning speed.

Represented by a red and black strip along the speed scale when the flight control normal law is inoperative.

VMAX : Represented by the bottom of a red and black strip along the speed scale.

Determined by the FAC according to the aircraft configuration.

Is equal to VMO (or speed corresponding to MMO ), VLE or VFE.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - GENERAL**

SPEEDS DEFINITION - PROTECTION SPEEDS

Intentionally left blank



**OTHER SPEEDS**

Ident.: DSC-22\_10-50-50-00020384.0004001 / 17 MAR 17

Applicable to: ALL

- V1 : The highest speed, during takeoff, at which the flight crew has a choice between continuing the takeoff or stopping the aircraft.  
Represented by “1” on the airspeed scale (or the V1 value when it is off the airspeed scale).  
Inserted manually through the MCDU by the flight crew.  
Displayed on the MCDU TAKEOFF page.
- VR : The speed at which the pilot rotates in order to reach V2 at an altitude of 35 ft at the latest after an engine failure.  
Inserted manually through the MCDU by the flight crew.  
Displayed on the MCDU TAKEOFF page.
- V2 : Takeoff safety speed that the aircraft attains at the latest at an altitude of 35 ft with one engine failed, and maintains during the second segment of the takeoff.  
Represented by the SPEED SELECT symbol on the speed scale.  
Minimum value equal to 1.13 VS for the corresponding configuration.  
Inserted manually through the MCDU by the flight crew.  
Displayed on the MCDU TAKEOFF page.
- VREF : Reference speed used for normal final approach.  
Equal to  $1.23 \times VS$  of CONF FULL.  
Displayed on the MCDU APPR page, if landing is planned in CONF FULL (VLS CONF FULL).
- VAPP : Final approach speed.  
Displayed on MCDU APPR page.  
Calculated by the FMGCs.  
Represents :  $VAPP = VLS + \text{wind correction}$   
The wind correction is limited to a minimum of 5 kt and a maximum of 15 kt.  
  
The flight crew may modify VAPP through the MCDU.  
- During autoland or when A/THR is on or in case of ice accretion or gusty crosswind greater than 20 kt, VAPP must not be lower than  $VLS + 5$  kt.

**SPEED TARGET** : Represented by a magenta triangle.  
Calculated by the FMGCs  
Gives efficient speed guidance in approach during various windy conditions.  
Represents :  
 $\text{SPEED TARGET} = \text{GS mini} + \text{actual headwind (measured by ADIRS)}$   
 $\text{GS mini} = \text{VAPP} - \text{TOWER WIND (headwind component along runway axis)}$   
calculated by FMGC from tower wind entered on MCDU).

# **AIRCRAFT SYSTEMS**

AUTO FLIGHT - FLIGHT MANAGEMENT

Intentionally left blank

**DSC-22\_20-10 General**

General.....A

**DSC-22\_20-20 Navigation**

**DSC-22\_20-20-05 General**

Navigation.....A

**DSC-22\_20-20-10 Position Computation**

General.....A  
MIX IRS Position.....B  
GPS Position.....C  
Radio Position.....D  
FM Position.....E  
Position Monitor.....F  
Takeoff Update.....G  
Navigation Modes.....H

**DSC-22\_20-20-20 Evaluation of Position Accuracy**

General.....A  
Estimated Position Uncertainty.....B  
FM/GPS Position Disagreement.....C  
Predictive GPS Page.....D

**DSC-22\_20-20-30 Radio Navigation Tuning**

General.....A  
Architecture.....B  
VOR.....C  
DME.....D  
ADF.....E  
ILS.....F  
Selection of Nav aids on MCDU Pages.....G  
Manual Tuning.....H  
Nav aid Identification.....I

**DSC-22\_20-20-40 Alignment of Inertial Reference System**

Alignment of Inertial Reference System.....A

**DSC-22\_20-20-50 Navigation Database**

General.....A  
Operations with an Outdated Navigation Database.....B

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_20-30 Flight Planning**

**DSC-22\_20-30-05 General**

Flight Planning..... A

**DSC-22\_20-30-10 Lateral Functions**

**DSC-22\_20-30-10-05 General**

General..... A  
 Manual Legs..... B  
 Flight Plan Construction..... C  
 Flight Plan Capacity..... D  
 Lateral Revisions..... E

**DSC-22\_20-30-10-15 FMS2 HONEYWELL**

General..... A  
 Temporary F-PLN (TMPY)..... B  
 Inserting an Airway with "Via"..... C  
 Inserting a Waypoint..... D  
 Fix Info..... E  
 Inserting a New Destination..... F  
 Holding Pattern..... G  
 Offset..... H  
 Alternate Function..... I  
 Enable ALTN..... J  
 DIR Key (Direct-to-Function)..... K  
 OVFY (Overfly) Key..... L  
 "Update at"..... M

**DSC-22\_20-30-20 Vertical Functions**

**DSC-22\_20-30-20-05 General**

General..... A  
 Vertical Flight Planning..... B  
 Flight Phases..... C  
 Vertical Revision..... D  
 Vertical Constraints (Speed, Altitude, Time)..... E

**DSC-22\_20-30-20-25 FMS2 Honeywell**

General..... A  
 Required Time of Arrival (RTA)..... B  
 Wind - Temperature - QNH..... C  
 Constant Mach Segment..... D

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_20-40 Performance**

**DSC-22\_20-40-10 Optimization**

General.....	A
Optimization.....	B

**DSC-22\_20-40-20 Cost Index**

Cost Index (CI).....	A
----------------------	---

**DSC-22\_20-40-30 Predictions**

General.....	A
Predictions for the Primary Flight Plan.....	B
Computation of Predictions.....	C
Predictions Displayed on the Navigation Display.....	D
Predictions Displayed on the MCDU.....	E
Type of Predictions.....	F
Examples of MCDU Predictions.....	G
Constraint Symbols (Star).....	H
Vertical Deviation.....	I
Operation Rules Concerning Predictions.....	J
Other Computations.....	K
Return-to-Trajectory Assumptions.....	L
Energy Circle.....	M
Introduction to PERF and IDLE Factors.....	N
PERF Factor.....	O
IDLE Factor.....	P
Procedure to Modify the PERF and IDLE Factors.....	Q

**DSC-22\_20-50 Controls and Indicators**

**DSC-22\_20-50-10 MCDU - Page Description**

**DSC-22\_20-50-10-25 FMS2 Honeywell**

General.....	A
MCDU MENU Page.....	B
INIT A Page.....	C
Route Selection Page.....	D
IRS INIT Page.....	E
WIND Pages.....	F
INIT B Page.....	G
Fuel Prediction Page.....	H
Flight Plan Pages.....	I
Lateral Revision Pages.....	J

*Continued on the following page*

*Continued from the previous page*

Fix Info Page.....	K
Offset Page.....	L
Airways Page.....	M
Departure Pages.....	N
Hold Pages.....	O
Direct TO Page.....	P
ARRIVAL Pages.....	Q
Alternate Page.....	R
Route Selection Page for Alternate.....	S
VERTICAL REVISION Pages.....	T
Step ALTS Page.....	U
RTA Page.....	V
Data Index Pages.....	W
Waypoint/Stored Waypoint/New Waypoint Pages.....	X
NAVAID/Stored NAVAID/New NAVAID Pages.....	Y
Runways/Stored Runways/New Runway Pages.....	Z
Route/Stored Route/New Route Pages.....	AA
Aircraft Status Page.....	AB
P/N XLOAD Page.....	AC
P/N Status Pages.....	AD
Duplicate Names Page.....	AE
Position Monitor Page.....	AF
Position Monitor and Position Frozen Page.....	AG
Selected NAVAIDS Page.....	AH
IRS Monitor Page.....	AI
GPS Monitor Page.....	AJ
Closest Airports Pages.....	AK
Equi-Time Point Page.....	AL
Print Function Pages.....	AM
ACARS Function Page.....	AN
ACARS Function Page 1.....	AO
Uplink TO Data REQ Pages.....	AP
Uplink MAX TO Data Pages.....	AQ
Uplink FLX TO Data Pages.....	AR
ACARS Function Page 2.....	AS
PERF Page.....	AT
PERF Takeoff Page.....	AU
PERF Climb Page.....	AV
PERF Cruise Page.....	AW
PERF Descent Page.....	AX

*Continued on the following page*




*Continued from the previous page*

PERF APPR Page.....	AY
PERF Go Around Page.....	AZ
PROG Pages.....	BA
Predictive GPS Pages.....	BB
Report Page.....	BC
Radio NAV Page.....	BD
Secondary Pages.....	BE
Back Up NAV Pages.....	BF
DSC-22_20-50-20 MCDU - Messages	
DSC-22_20-50-20-35 FMS2 Honeywell	
MCDU Message List.....	A
DSC-22_20-50-30 MCDU - Data Format List	
MCDU Data Format List.....	A
<b>DSC-22_20-60 Other Functions</b>	
DSC-22_20-60-10 Effect of Baro Reference Setting	
GENERAL.....	A
MCDU Altitude Predictions.....	B
Target Altitude on PFD.....	C
Procedures.....	D
DSC-22_20-60-20 Clear Key (Clearing Function)	
Clearing the Scratchpad of Data or Messages.....	A
Clearing Data Fields.....	B
DSC-22_20-60-30 How to Execute a Diversion	
General.....	A
En Route Diversion with Several Airports Available.....	B
En Route Diversion over Oceanic or Desertic Area.....	C
Diversion Preparation on the Secondary Flight Plan.....	D
Miscellaneous.....	E
Execution of the Diversion.....	F
Diversion to the Alternate Airport.....	G
DSC-22_20-60-40 Engine Out	
General.....	A
Flight Management Part.....	B
Flight Guidance Part.....	C
Autothrust.....	D
Engine-Out Conditions.....	E

*Continued on the following page*

*Continued from the previous page*

Engine-Out SID.....	F
Engine-Out in CLB Phase (above acceleration altitude).....	G
Engine-Out in Cruise Phase.....	H
Engine-Out in Descent Phase.....	I
Engine-Out In Approach Phase.....	J
Engine-Out in Go-Around Phase.....	K
<b>DSC-22_20-60-50 Secondary Flight Plan</b>	
Secondary Flight Plan.....	A
<b>DSC-22_20-60-60 Pilots/Stored Route Function</b>	
Stored Route Function.....	A
<b>DSC-22_20-60-70 Report Page</b>	
General.....	A
Report Page Access.....	B
<b>DSC-22_20-60-80 Closest Airports</b>	
Closest Airports.....	A
<b>DSC-22_20-60-90 Time Marker</b>	
General.....	A
How to Insert a Time Marker.....	B
<b>DSC-22_20-60-100 Step ALTS</b>	
Step Climb/Step Descent.....	A
<b>DSC-22_20-60-110 Required Time of Arrival (RTA)</b>	
General.....	A
Estimated Takeoff Time (ETT).....	B
<b>DSC-22_20-60-120 Equitime Point</b>	
Equitime Point.....	A
Equitime Point Entry.....	B
<b>DSC-22_20-60-130 MCDU Back Up Navigation</b>	
General.....	A
Back Up NAV Selection.....	B
Back Up NAV Operation.....	C
<b>DSC-22_20-60-150 Descent Profile Optimization (if installed)</b>	
Descent Profile Optimization  .....	A

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_20-70 AOC Functions**

Flight Plan Initialization Through ACARS.....	A
Takeoff Data.....	B
Wind Data.....	C

**DSC-22\_20-80 Print Functions**

Print Function.....	A
Print Function Access.....	B
On Ground Before Engine Start.....	C
Example (FM Preflight Report).....	D
In Flight.....	E
Example (FM Inflight Report).....	F
Reaching the Gate After Landing.....	G
Example (FM Postflight Report).....	H

**DSC-22\_20-90 Abnormal Operations**

**DSC-22\_20-90-10 FMGC Reset**

Automatic FMGC Reset and Resynchronization.....	A
Manual FMGC Reset.....	B

**DSC-22\_20-90-20 "CHECK GW" or "CHECK WEIGHT" Message**

"CHECK WEIGHT" Message.....	A
-----------------------------	---

**DSC-22\_20-100 Temporary Abnormal Behaviors**

**DSC-22\_20-100-20 FMS2 HONEYWELL Temporary Abnormal Behaviors**

Misalignment Of FMS F-PLN Legs For ILS Approaches.....	A
Incorrect Management Of ETA Entry On Predictive GPS Page.....	B
Flight Number Erased Upon AOC Flight Plan Uplink.....	C
Erroneous Fuel Prediction In The Case Of Descent With Two Altitude Constraints.....	D
Unexpected Switch Of Speed Target When RTA Is Used.....	E
Undue AP Disconnection or Reversion to V/S during Climb and Descent.....	F
VOR/DME and VOR/TACAN Not Automatically Tuned.....	G
Optimum Target Speeds not Updated following the Automatic Deletion of a Step Climb.....	H
Erroneous Lateral Guidance in NAV Mode with LOC Mode Armed during Approach.....	I
Undue Reduction of the Speed Target in case of DIR TO/ABEAM while Flying a Constant Mach Segment.....	J
Loss of Fuel and Time Predictions During Takeoff Data Insertion.....	K
Erroneous Trajectory during Procedures with a Turn Direction on a Leg with an Altitude Termination.....	L
Erroneous Vertical Profile during LOC B/C Approaches with a MAP Located Before the Runway Threshold.....	M

*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

PRELIMINARY PAGES - TABLE OF CONTENTS

*Continued from the previous page*

DSC-22\_20-100-40 All FMS Temporary Abnormal Behaviors

Erroneous Predictions.....	A
Spurious Engine Out Indication.....	B

**GENERAL**

Ident.: DSC-22\_20-10-00010128.0001001 / 17 AUG 10

**Applicable to: ALL**

The flight management and guidance system (FMGS) performs navigation functions and lateral and vertical flight planning functions. It also computes performance parameters and guides the aircraft along a preplanned route.

The Flight Management (FM) part controls the following functions:

- Navigation
- Management of flight planning
- Prediction and optimization of performance
- Management of navigation radios
- Management of displays



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**  
NAVIGATION - GENERAL

**NAVIGATION**

Ident.: DSC-22\_20-20-05-00010129.0001001 / 17 AUG 10

**Applicable to: ALL**

Essential navigation functions are:

- Computation of position
- Evaluation of position accuracy
- Radio navigation tuning
- Alignment of Inertial Reference System.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

NAVIGATION - GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>NAVIGATION - POSITION COMPUTATION</p>
---	---

**GENERAL**

Ident.: DSC-22\_20-20-10-00010130.0002001 / 16 MAR 11

**Applicable to: ALL**

Each FMGC computes its own aircraft position (called the "FM position") from a MIX IRS position and a computed radio position, or a GPS position.

The FMGS selects the most accurate position, considering the estimated accuracy and integrity of each positioning equipment.


GPS /INERTIAL is the basic navigation mode, provided GPS data is valid and successfully tested. Otherwise, nav aids plus inertial or inertial only are used. (*Refer to DSC-22\_20-20-10 Navigation Modes*).

**MIX IRS POSITION**


Ident.: DSC-22\_20-20-10-00010131.0002001 / 01 OCT 12

**Applicable to: ALL**

Each FMGC receives a position from each of the three IRS s, and computes a mean-weighted average called the "MIX IRS" position:



- If one of the IRS s drifts abnormally, the MIX IRS position uses an algorithm that decreases the influence of the drifting IRS within the MIX IRS position.



- If one of the IRS s fails, each FMGC uses only one IRS (onside IRS or IRS 3). Each IRS position and inertial speed are continuously tested. If the test fails, the corresponding IRS is rejected.
- When the "CHECK IRS (1, 2 or 3)/FM POSITION" message appears on the MCDU.

## GPS POSITION

Ident.: DSC-22\_20-20-10-00010132.0002001 / 23 JUN 15

Applicable to: **ALL**


Each IRS computes a mixed IRS /GPS position called the GPIRS position. For this, each IRS can independently select their GPS source in order to maximize the availability of GPS data. Of the three GPIRS positions that each FMGC receives, the FMS selects one GPIRS position based on a figure of merit and priority.

The FMS uses the following hierarchy to perform the selection:


- Onside GPIRS position
- GPIRS 3
- Opposite GPIRS position.

If the GPIRS data does not comply with an integrity criterion that is based on a Horizontal Integrity Limit (HIL) and on the automatic detection of failed satellites, the FMS rejects the GPS mode and uses the radio position update.

The flight crew can deselect/select the GPS position on the SELECTED NAVAIDS page, if necessary.



Information about the GPS position is displayed on the GPS MONITOR page.



*Note:* In nominal case, ADIRU 1 selects GPS 1 and ADIRU 2 selects GPS 2. The GPS selection by ADIRU 3 depends on the position of the ATT HDG selector switch. If one of the GPS source is rejected by the ADIRU s, all ADIRU s will select the same GPS source. As a result, the data of the GPS that is not selected is dashed on the GPS MONITOR page. The “GPS PRIMARY LOST” message may not be displayed.

**RADIO POSITION**

Ident.: DSC-22\_20-20-10-00010669.0020001 / 01 OCT 12

Applicable to: ALL

Each FMGC uses outside navaids to compute its own radio position. These navaids are displayed on the SELECTED NAVAIDS page.

The available navaids are:

- DME /DME
- VOR /DME


- LOC
- DME /DME -LOC
- VOR /DME -LOC.

It uses LOC to update the lateral position, using LOC beam during ILS approach.


LOC is also used for quick update, when in GPS /IRS mode.

If one or more nav aids fail, each FMGC can use offside nav aids to compute the VOR /DME , or the DME /DME radio position.

The radio nav aid selection is displayed on the DATA “SELECTED NAV AIDS” page.



- (1) VOR /DME selection (auto or manual) for display (onside VOR).
- (2) DME s automatic selection for DME /DME onside radio position.
- (3) ILS selection (auto or manual) for LOC update computation.


 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT MANAGEMENT</b> NAVIGATION - POSITION COMPUTATION
---	--

**FM POSITION**

Ident.: DSC-22\_20-20-10-00010135.0017001 / 17 AUG 10  
**Applicable to: ALL**

- At flight initialization, each FMGC displays an FM position that is a MIX IRS /GPS position (GPIRS):
- At takeoff, when the FM position is updated to the runway threshold position as stored in the database, possibly corrected by the takeoff shift entered on PERF TO page.
  - In flight, the FM position approaches the radio position or the GPS position at a rate depending upon the aircraft altitude.

*Note:* The FM position update at takeoff is inhibited when GPS PRIMARY is active.



**BIAS**

Each FMGC computes a vector from its MIX IRS position to the radio position or GPIRS position. This vector is called the “bias”.

Each FMGC updates its bias continuously as long as a radio position or a GPIRS position is available.

If an FMGC loses its radio/GPIRS position, it memorizes the bias and uses it to compute the FM position, which equals the MIX IRS position plus the bias. Until the radio or the GPIRS position is restored, the bias does not change.

The flight crew can update the FM position manually. This also updates the bias.

**POSITION MONITOR**

Ident.: DSC-22\_20-20-10-00010136.0016001 / 07 MAY 13  
**Applicable to: ALL**

The flight crew may check the position computation using the GPS MONITOR or POSITION MONITOR page.

**GPS MONITOR**

GPS1 POSITION			
1L	43°40.4N/000°17.6E		1R
	TTRK UTC GS		
2L	342.3 10:37:42 310		2R
	MERIT GPS ALT MODE/SAT		
3L	100M 10000 NAV/6		3R
GPS2 POSITION			
4L	43°40.4N/000°17.6E		4R
	TTRK UTC GS		
5L	342.3 10:37:42 310		5R
	MERIT GPS ALT MODE/SAT		
6L	100M 10000 NAV/6		6R

**POSITION MONITOR**

1L	FMS 1 4340.4N/00017.6E		1R
	3IRS/GPS		
2L	FMS 2 4340.4N/00017.6E		2R
	3IRS/GPS		
3L	GPIRS 4340.4N/00017.6E		3R
4L	MIX IRS 4340.4N/00017.6E		4R
	IRS1 IRS2 IRS3		
5L	NAV 0.4 NAV 0.2 NAV 0.4		5R
	SEL		
6L	<FREEZE	NAVAIDS>	6R

**1L** FM POSITION (FMGC1)

**2L** FM POSITION (FMGC2)

**3L** GPIRS OR RADIO POSITION (ONSHORE FMGC) WHICHEVER IS USED FOR POSITION UPDATING

**4L** MIX IRS POSITION (ONSHORE FMGC)

**TAKEOFF UPDATE**

Ident.: DSC-22\_20-20-10-00010137.0017001 / 04 AUG 16

**Applicable to: ALL**

A takeoff update requires that the takeoff runway be part of the flight plan. This provides the most accurate position update.

If the takeoff run starts at an intersection, enter a takeoff shift on the PERF TO page to refine the takeoff update.

An accurate takeoff update ensures a precise aircraft position during departure.

PERF TO PAGE

Takeoff runway in the flight plan.

TAKE OFF		
V1	FLP RETR	RWY
130	F=138	15R
VR	SLT RETR	TO SHIFT
131	S=179	[M] 900
V2	CLEAN	FLAPS/THS
131	O=202	[ ]/[ ]
TRANS ALT		FLX TO TEMP
4800		45°
THR	RED/ACC	ENG OUT ACC
3000/4365		
NEXT PHASE>		

FROM	AF5612 →	
LFB015R	0000 148/1490	
H146	BRG145	3NM
TOU/08		
6034	TRK034	14
D0730		
HUM20		21
CRESP		
MUPA2D		24
DO432		
DEST	TIME	DIST
EDHI	0148	759
		↑↓

If the takeoff is not initiated from runway threshold, to shift should be inserted to update the position.

F-PLN A PAGE (WITHOUT PREDICTIONS)

**NAVIGATION MODES**

Ident.: DSC-22\_20-20-10-00010138.0001001 / 19 JUL 11

Applicable to: ALL

The FMGS updates the FM position via the use of radio nav aids or GPS, if available. It can use four different FM navigation modes to make this update.

The decreasing order of priority is:

- IRS -GPS
- IRS -DME /DME
- IRS -VOR /DME
- IRS only.

During ILS approaches, the system performs a temporary lateral update, via one of the following modes:

- IRS -GPS /LOC
- IRS -DME /DME -LOC



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT MANAGEMENT

### NAVIGATION - POSITION COMPUTATION

- IRS -VOR /DME -LOC
- IRS -LOC.



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT MANAGEMENT</b> NAVIGATION - EVALUATION OF POSITION ACCURACY
---	---

**GENERAL**

Ident.: DSC-22\_20-20-20-00010448.0023001 / 27 MAY 13

**Applicable to: ALL**

The FMGS continuously computes an Estimated Position Uncertainty (EPU). It is an estimate of how much the FM position diverged, and it is a function of the navigation mode that the system uses.

CURRENT NAV MODE	EPU (RATE or THRESHOLD)	REMARK
IRS /GPS	$\sqrt{(FOM^2 + 100^2)}$ (in meters).	FOM = Figure of Merit of GPS. If above 0.28 NM, the FMS rejects the GPS position.
IRS /DME /DME	Moves toward 0.28 NM.	EPU decreases from initial value to 0.28 NM.
IRS /VOR /DME	0.1 NM + 0.05 X DME DIST. Minimum : 0.28 NM.	Dependent on the distance between the aircraft and the VOR /DME.
IRS ONLY	+8 nm/h for the first 30 min. 0 nm/h for the following 60 min. +4 nm/h for the following 30 min. 0 nm/h for the following 60 min. +2 nm/h after.	EPU increases continuously.

*Note:* After an IRS alignment or at takeoff, the EPU is set to 0.2 NM.

**ESTIMATED POSITION UNCERTAINTY**

Ident.: DSC-22\_20-20-20-00010499.0076001 / 01 OCT 12

**Applicable to: ALL**

The FMS displays the EPU to the flight crew and compares it with the Required Navigation Performance (RNP):

- If the EPU does not exceed the RNP, accuracy is HIGH
- If the EPU exceeds the RNP, accuracy is LOW.

The RNP is displayed in the REQUIRED field of the PROG page. The displayed RNP is (in a decreasing order of priority):

- The value that the flight crew entered
- The navigation database procedure value
- The system's default value.

When a flight crew enters an RNP that is higher than the published value, one of the following messages is displayed : "PROCEDURE RNP IS XX.XX", or "AREA RNP IS XX.XX". When this occurs, the flight crew should verify the RNP value that was manually entered in the REQUIRED field of the PROG page, and clear or modify it if necessary.


The "AREA RNP IS XX.XX" message is also displayed at the change of flight area if the new RNP (default value) is smaller than the displayed RNP (manually entered).

#### DEFAULT AREA RNP VALUES

EN ROUTE	2.0 NM
TERMINAL	1.0 NM
APPROACH	GPS 0.3 NM OTHER CASES 0.5 NM

When one FMGC changes the NAV accuracy from LOW to HIGH (or HIGH to LOW), the MCDU and the ND display the "NAV ACCUR UPGRAD" (or DOWNGRAD) message.

These messages are inhibited when the navigation mode is IRS /GPS.



The diagram illustrates the MCDU PROG PAGE and EFIS ND displays. The MCDU PROG PAGE shows flight data for DES AF024, including CRZ, OPT, REC, and MAX altitudes, and VDEV. It also displays predictive accuracy information: REQUIRED ACCUR (1.36NM), ESTIMATED ACCUR (HIGH 0.51NM), and a NAV ACCUR UPGRAD message. The EFIS ND shows a navigation display with various waypoints (VOR1, CGC, LMG, BDX, .2R, AGN, CDN, AMB, AVD, ANG, OL) and a NAV ACCUR UPGRAD message at the bottom. Annotations indicate that the message appears on the ND and any MCDU page.

When in IRS /GPS mode, the GPS PRIMARY status combines two different criteria:

- The accuracy criterion previously described (HIGH/LOW accuracy)
- An integrity criterion: This is the capability to detect a failure and provide appropriate warning of it. This criterion indicates the confidence that the flight crew can have in the FMS position.

If the GPS PRIMARY status complies with both criteria, "GPS PRIMARY" is displayed on the MCDU (PROG page, [5R] field and scratchpad) and temporarily on the ND.

If the GPS PRIMARY status no longer complies with one of these criteria (Navigation downgraded or integrity lost), the GPS PRIMARY status is lost and the MCDU and the ND display the "GPS PRIMARY LOST" message. It is possible to clear the scratchpad message on the MCDU , but not on the ND.

**CAUTION**

"HIGH" or "LOW" on the PROG page indicates the FM position accuracy, based on estimated uncertainty. When GPS PRIMARY mode is lost, the flight crew must periodically check this position accuracy. In GPS PRIMARY mode, the position accuracy is always at HIGH.


MCDU PROG PAGE

```

DES AF024
CRZ      OPT      REC MAX
-----  FL350    FL390
                VDEV = + 390 FT
UPDATE AT
* [      ]
  BRG / DIST
----- / ----- TO [  ]
PREDICTIVE
<GPS     GPS PRIMARY
REQUIRED ACCUR ESTIMATED
1.0NM    HIGH    0.2NM
GPS PRIMARY ←
          
```

1L 2L 3L 4L 5L 6L 1R 2R 3R 4R 5R 6R

EFIS ND



This message appears on the ND and on any MCDU page. (amber msg)

When the GPS is manually deselected, the "GPS IS DESELECTED" message is displayed on the MCDU , 80 NM before the T/D or at approach phase transition.

### FM/GPS POSITION DISAGREEMENT

Ident.: DSC-22\_20-20-00010500.0011001 / 17 AUG 10

Applicable to: ALL

When the GPS PRIMARY function is active, and either of the FM positions deviate from the GPS positions 1 or 2 by more than:

- A longitude threshold that depends on the latitude:
  - 0.5' for latitudes below 55°
  - 0.9' for latitudes at or above 55°, and below 70°.
- A latitude threshold of 0.5', regardless of the latitude,

then, the lower ECAM displays the NAV FM /GPS POS DISAGREE amber caution. The master caution light comes on and the single chime sounds.  
 This amber caution is inhibited during the takeoff phase.  
 Above 70° of latitude, a longitude difference does not trigger the alarm.

<b>PREDICTIVE GPS PAGE</b>
----------------------------

Ident.: DSC-22\_20-20-00010501.0001001 / 16 MAR 11

Applicable to: ALL

The predictive GPS page is only operative with the Honeywell ADIRS equipment. All fields are blank with Litton ADIRS equipment.  
 The predictive GPS function predicts the availability of the GPS within ± 15 min of ETA at destination, or at any waypoint entered by the flight crew.



Predictions are displayed on the predictive GPS page at time intervals of 5 min (+15 and -15 min of ETA).

To access this page, press the 5L key of the PROG page. This page also enables the deselection of up to 4 satellites at a time.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

NAVIGATION - EVALUATION OF POSITION ACCURACY

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_20-20-30-00010478.0001001 / 17 AUG 10

**Applicable to: ALL**

Radio nav aids are tuned for two different purposes: Display and computation.

It is possible to perform tuning for display in three different ways:

- Automatic tuning via FMGC software
- Manual tuning via the MCDU RAD NAV page
- Manual tuning via the Radio Management Panel (RMP ) if both FMGC s or both MCDUs fail.


The FMGS automatically tunes the radio nav aids for computation of the radio position.










*Note: The manual selection of a VOR or VOR /DME may prevent the FMGS from automatically tuning a VOR /DME to compute position. In this case, the related MCDU displays "TUNE BBB FFF.FF" (BBB = ident, FFF.FF = frequency).*

**ARCHITECTURE**

Ident.: DSC-22\_20-20-30-00010479.0001001 / 31 AUG 17

Applicable to: ALL



- In dual mode and independent mode, each FMGC simultaneously tunes the nav aids on its own side (one VOR , one DME , one ILS , one GLS  , one MLS  and one ADF  ). In these modes, the flight crew can also manually tune the VOR (and associated DME ) , ILS, GLS  , MLS  and ADF  .
- In single mode, the valid FMGC tunes nav aids on both sides. The flight crew can also use the RAD NAV page to manually tune both VOR s, both ADFs  , and the ILS / GLS  / MLS  .

Manual tuning has priority over automatic tuning.

Note: If one receiver fails, both FMGCs use the operative radio receiver to compute the position of the aircraft.



**VOR**

Ident.: DSC-22\_20-20-30-00010480.0001001 / 17 AUG 10

**Applicable to: ALL**

Each FMGC may tune only one VOR (manually or automatically).

Automatic tuning complies with the following priorities for tuning the VOR:

1. The specified navaid for the approach
2. The navaid that the flight crew should use to compute the current radio position
3. For display purposes:
  - A navaid specified for the active flight leg
  - The "TO" waypoint (TO WPT), if it is a navaid
  - The "FROM" waypoint (FROM WPT), if it is a navaid
  - A waypoint farther along the flight path, if it is a navaid
  - The navaid closest to the current position of the aircraft.

The scratchpad displays "SPECIFIC VOR-D UNAVAIL", if the VOR or the VOR /DME that the flight crew requires for tuning is deselected.

**DME**

Ident.: DSC-22\_20-20-30-00010481.0002001 / 17 AUG 10

**Applicable to: ALL**

Each FMGC automatically uses its four DME frequencies as follows:

- One DME frequency for display. It is possible to tune it manually or automatically. This DME frequency is also used for VOR /DME position computation.
- Two DME frequencies in DME /DME mode for calculating the radio position of the aircraft. The FMGC automatically tunes these as a function of their best accuracy. The flight crew does not receive any indication that this process is happening.
- One DME frequency is connected to the ILS /DME.

**ADF**

Ident.: DSC-22\_20-20-30-00010482.0001001 / 17 AUG 10

**Applicable to: ALL**

The FMGC automatically tunes one ADF, when the flight plan specifies a Non Directional Beacon (NDB) approach and a fix in the approach is the "TO" waypoint.

The scratchpad displays "SPECIFIC NDB UNAVAIL", if the NDB that the flight crew requires for autotuning is deselected.

**ILS**

Ident.: DSC-22\_20-20-30-00010483.0001001 / 17 AUG 10

Applicable to: ALL

Each FMGC automatically tunes one ILS frequency:

- In the PREFLIGHT or TAKEOFF phase, when the takeoff runway has an associated ILS.
- In the CLIMB, CRUISE, DESCENT, APPROACH, or GO-AROUND phase, when the type of approach in the flight plan is ILS.

The scratchpad displays "RWY /ILS MISMATCH" when the flight crew manually tunes the ILS and the entered frequency does not agree with the ILS or the LOC IDENT /FREQ that the flight crew requests for automatic tuning. The FMGS logic does not enable the flight crew to modify the course of an ILS when its frequency is identical to the ILS selected in the F-PLN.

**SELECTION OF NAVAIDS ON MCDU PAGES**

Ident.: DSC-22\_20-20-30-00010485.0032001 / 31 AUG 17

Applicable to: ALL

The MCDU displays the navaids tuned by the FMGC on two pages:

- RADIO NAV Page
- SELECTED NAVAIDS Page.


**RADIO NAV PAGE**

This page shows which navaids have been tuned automatically or manually for display purposes.



**SELECTED NAVAIDS PAGE**

This page lists the navaids tuned by the onside FMGC. No navaids can be modified on this page. The flight crew may deselect navaids and or GPS for the whole flight.



## MANUAL TUNING

Ident.: DSC-22\_20-20-30-00010486.0002001 / 01 MAR 17

Applicable to: ALL

INSERT the identifier on the RADIO NAV page.

*Preferably use the identifier.*



*Note:* The RAD NAV page may differ according to option installed (ADF 1, ADF2, xLS).

- If the MCDU displays “NOT IN DATA BASE”:

INSERT the frequency.

DISREGARD the ident that appears in small font on the MCDU.

*When a frequency is entered in the VOR field, the FMGC automatically associates to the tuned frequency the closest navaid identifier with the same frequency, and displays it on the RAD NAV page. This identifier may not correspond to the tuned navaid.*




If the closest navaid, found in the database, is of a different type (e.g. VOR instead of VOR /DME), the flight crew will obtain a partial tuning (e.g. VOR indication instead of VOR /DME indication).  
ENTER the course.

If the flight crew intends to manually tune an ILS that is not in the Navigation Database or to manually tune an ILS by its frequency (ident not entered), and if they do not enter the course, the flight crew will not be able to arm approach modes.




## NAVAID IDENTIFICATION

Ident.: DSC-22\_20-20-30-00010487.0001001 / 31 AUG 17

Applicable to: ALL

CHECK the xLS (ILS or GLS  or MLS ) identifier decoded on the PFD, and the VOR or ADF  on the ND.

*When the navaid identifier is decoded in agreement with that published, no audio check is necessary. When the decoding is different from the published one, check the audio. Due to morse coding inaccuracy, wrong decoding may sometimes occur.*

*For GLS , the audio signal may be inaudible. However, the GLS  identifier displayed on ND and PFD is raw data. Consequently, for GLS , no audio check is necessary.*

**Note:** *When a DME or a TACAN only is selected using either its identifier or its frequency, the NDs do not display the decoded indication.*

**ALIGNMENT OF INERTIAL REFERENCE SYSTEM**

Ident.: DSC-22\_20-20-40-00010143.0013001 / 01 OCT 12

Applicable to: ALL

The FMGS uses the reference point coordinates of the departure airport to align the IRS. It calls these up from the database automatically after the flight crew has entered a company route or an origin-destination city pair and pressed the ALIGN IRS key on the MCDU. The flight crew can adjust these coordinates manually to the gate position. A normal alignment takes 10 min, a fast alignment 30 s. Fast alignment is used to refine a position when time is limited.



Note: If the "IRS IN ALIGN" memo flashes on the E/WD during the alignment process, it indicates one of the following:

- It has detected excessive motion. (It automatically restarts the alignment)
- It has detected a disagreement between the position the MCDU has sent to the IRS, and the last memorized IRS position. The flight crew must enter new coordinates in the MCDU, and realign the IRS
- It has detected a disagreement between the latitude the MCDU has sent to the IRS, and the latitude the IRS has computed during the alignment
- The IRS has not received a position from the MCDU.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

NAVIGATION - ALIGNMENT OF INERTIAL REFERENCE SYSTEM

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p style="text-align: center;">NAVIGATION - NAVIGATION DATABASE</p>
---	--

**GENERAL**

Ident.: DSC-22\_20-20-50-00010410.0001001 / 09 MAR 15

**Applicable to: ALL**

Overall navigation performance is mainly based on two elements:

- The accuracy of the aircraft position calculation
- The validity of the flight path definition, as extracted from the navigation database.

The level of validation depends on the type of operations. For example, JAA TGL 10 requires that, for Precision RNAV in terminal area, providers and operators implement a quality assurance program for the navigation database, which may include a navigation database validation process. The highest level of validation is required for RNAV approach, with lateral and vertical navigation.

The navigation databases are revised every 28 days (AIRAC cycle). Flights should be conducted with a navigation database that is within its cycle. This should be checked on the AIRCRAFT STATUS MCDU page.

**OPERATIONS WITH AN OUTDATED NAVIGATION DATABASE**

Ident.: DSC-22\_20-20-50-00010411.0001001 / 13 DEC 12

**Applicable to: ALL**

Airbus recommends flying with an updated navigation database. However, in exceptional circumstances, and for a limited period of time, an aircraft can continue to operate beyond the end date of the database cycle, provided it is approved by the national authorities.

The following precautions need to be considered:

- Prior to flight, identify recent changes on the intended route, with the navigation charts and manuals. Some “strategic” new waypoints, not in the navigation database, may be worth entering as DEFINED WAYPOINT on MCDU.

*Note: Flying with an outdated database, in an airspace that was recently restructured with numerous new waypoints, should be avoided.*

- Check SID , STAR, and approach procedures of departure, destination and required alternates for recent changes.

Do not attempt to modify or manually construct terminal instrument procedures or approaches.

- Fly terminal instrument procedures and approaches with managed guidance, that are in the navigation database and that have been checked for accuracy. Otherwise, fly the procedure, or the approach, in selected guidance with conventional radio navaid raw data.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

NAVIGATION - NAVIGATION DATABASE

Intentionally left blank



## FLIGHT PLANNING

Ident.: DSC-22\_20-30-05-00010492.0002001 / 17 AUG 10

Applicable to: ALL

The flight crew uses the MCDU to insert flight plans into the FMGS:

- A lateral flight plan that defines the intended horizontal flight path
- A vertical flight plan that defines the intended speed and altitude profile for the aircraft to follow while flying the lateral flight plan.

*Note:* The flight planning function is available for both the primary and secondary flight plans.

The FMGS can contain two different flight plans:

- The ACTIVE flight plan, which is the basis for:
  - Lateral and vertical guidance
  - MCDU and ND display
  - Radio navigation autotuning
  - Performance predictions
  - Fuel planning.
- The SECONDARY flight plan which the flight crew may use:
  - When an alternate takeoff runway is probable
  - To plan a diversion
  - To prepare the next flight
  - To compare predictions or evaluations.

Each flight plan is composed of the same elements:

- The primary flight plan, from origin to destination and missed approach
- The alternate flight plan, from destination to alternate destination.

The flight crew enters the flight plan in either of two ways:

- Automatically by selecting a company route. Such a selection will call all the elements of the route out of the database.
- Manually by selecting an ORIGIN/DEST pair, and then selecting all successive waypoints, procedures, and vertical constraints on the MCDU.

The flight crew may then modify the flight plan on the ground or in flight, by making lateral and vertical revisions.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

FLIGHT PLANNING - GENERAL

Intentionally left blank

**General**

**GENERAL**

Ident.: DSC-22\_20-30-10-05-00011075.0002001 / 23 JUN 15


Applicable to: ALL

To insert the lateral flight plan, the flight crew can use either a company route number or an ICAO four-letter city pair.

The lateral flight plan includes the following elements:

- Departure
  - Takeoff runway
  - SID
  - En route transition.
- En route
  - En route waypoints and airways.
- Arrival
  - En route transition
  - STARs/VIAs
  - Landing runway with selected approach
  - Missed approach.
- Alternate flight plan.

These elements are defined by waypoints and legs between the waypoints.



The FMGC automatically strings the legs in sequence.

The flight plan has a discontinuity if any two waypoints do not have a leg defined between them.

The computer assumes that the aircraft will fly a direct leg between the two waypoints that define the discontinuity.

- Note:*
1. When the aircraft overflies a flight plan discontinuity, the NAV mode automatically reverts to the HDG (TRK) mode.
  2. In HDG /TRK mode, a waypoint is sequenced when it passes behind the aircraft, and the aircraft is less than 7 NM from it, and also when the difference between the track of the aircraft and the track of the leg is less than 90 °.
- If the aircraft is flying a discontinuity towards a waypoint, this waypoint is sequenced when the aircraft is less than 5 NM from it.*
- The same conditions apply in NAV mode, except that no distance to the waypoint is taken into account.*


The FMGS automatically strings additional types of legs, when departure or arrival procedures (SID - STAR - TRANS) are defined.

Those strings correspond to specific patterns that are heading or track referenced and are defined in the database, such as:

- DME arc leg
- Holding pattern to a fix, or reverse turn
- Course-to-fix leg
- Radius-to-fix leg
- Heading leg
- MANUAL leg.

The flight crew cannot create these types of legs: They are part of the stored departure/arrival procedures they have selected.

The flight crew can only create direct legs between manually defined geographic points (navaids, airports, waypoints).



Note: The departure and arrival procedures are defined in the database to minimize the amount of memory required.

They are divided, as follows:

- DEPARTURE = SID + EN ROUTE TRANSITION
- ARRIVAL = APPR VIA + STAR + EN ROUTE TRANSITION

The SID is the central common part of the departure procedure, as the STAR is of the arrival procedure. Enroute transitions (TRANS) are the various possible trajectories defined between the last SID point and the first enroute waypoints, and between the last enroute waypoint and the first fix of the STAR. "APPR VIAs" are the possible trajectories, defined between the last STAR point and the first point of the approach.


### MANUAL LEGS

Ident.: DSC-22\_20-30-10-05-00010629.0001001 / 17 AUG 10

Applicable to: ALL

A MANUAL leg stays on a constant TRK or HDG and has no termination point. The flight crew cannot insert it into a flight plan manually: it is part of a given procedure such as a SID or a STAR. When the aircraft is flying a MANUAL leg, the NAV mode remains engaged and predictions assume that the aircraft will fly a direct leg from its present position to the next waypoint (DIR TO). When the aircraft is cleared to fly to the next waypoint of the flight plan, the flight crew performs a DIR TO.

- Note:
1. In NAV mode, a MANUAL leg is sequenced only by performing a DIR TO.
  2. The use of the descent mode (DES) on a MANUAL leg is not recommended.



**FLIGHT PLAN CONSTRUCTION**

Ident.: DSC-22\_20-30-10-05-00011076.0032001 / 01 OCT 12

Applicable to: ALL

There are three ways of defining the route:


1. A company route, that is in the database, and is known by the flight crew.

The flight crew enters the name of the CO RTE into the [1L] field of the INIT A page. This action enters all the elements of the flight plan. The database usually includes an alternate route associated with the destination.



2. A company route, that is in the database, but the flight crew does not know it is there.

The flight crew enters a city pair in the [1R] field. The ROUTE SELECTION page automatically appears and enables the flight crew to review all stored routes between the two cities before selecting one of them.



3. There is no company route between the two cities.

The flight crew enters the city pair in the [1R] field. The ROUTE SELECTION page appears and displays "NONE".

The flight crew has to manually construct the entire flight plan.

For procedure, Refer to PRO-NOR-SRP-01-10 Flight Plan Initialization - General.

### FLIGHT PLAN CAPACITY

Ident.: DSC-22\_20-30-10-05-00010631.0002001 / 17 AUG 10

Applicable to: ALL

In terms of flight plan capacity, the FMS takes into account 3 flight plans:

- The active flight plan
- The secondary flight plan
- The temporary flight plan.

Each flight plan can contain up to 200 legs. If a flight plan contains 200 legs, and if the flight crew attempts to perform a lateral revision that increases the number of legs of this flight plan, the FMS rejects the revision and the MCDU displays the "F-PLN FULL" message. For the active and





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT MANAGEMENT

### FLIGHT PLANNING - LATERAL FUNCTIONS

secondary flight plans, the primary parts must contain less than 135 legs, and the alternate parts must contain less than 65 legs.

**LATERAL REVISIONS**


Ident.: DSC\_22\_20-30-10-05-00010632.0002001 / 07 APR 17

Applicable to: **ALL**

The flight crew can revise the lateral flight plan following two types of revisions:

1. Lateral revisions that have an immediate effect on the active flight plan:

- The flight crew inserts a new waypoint directly on the F-PLN page, deletes, or changes a waypoint from it:



When the flight crew enters a new waypoint, which does not exist in the flight plan, the following waypoint moves down the flight plan, with a discontinuity shown after the new waypoint.

- The flight crew adds a direct leg (DIR TO) from his present position to a selected waypoint: The flight crew can change the "TO" waypoint of the active leg. The DIR TO function gives access to DIR TO, DIR TO ABEAM, or DIR TO/INTERCEPT. The active leg then goes from the present position (T/P) to the waypoint selected or inserted as the new "TO" waypoint.

**1 SELECT** →

DIR TO	FBS1	
* [ ]		
1L LMG 0708	.79 / FL350	1R
2L (T/D) 0718	.79 / FL350	2R
3L	7.9 NM	3R
4L AMB 0721	273 / FL301	4R
5L VILRO 0723	" / FL253	5R
6L (LIM) 0730	*250 / FL100	6R
	↑↓	

**2 SELECT** →

DIR TO	FBS1	
*AMB	184° *	1R
WITH	RADIAL IN	
*ABEAM PTS	[ ]°	2R
3L LMG 0709	.79 / FL350	3R
4L (T/D) 0719	.79 / FL350	4R
5L AMB 0722	273 / FL301	5R
6L VILRO 0724	" / FL253	6R
	↑↓	

FROM UTC	FBS1	
T-P	SPD / ALT	1R
2L (T/D) 0722	.80 / FL350	2R
3L AMB 0724	283 / FL301	3R
4L VILRO 0727	" / FL253	4R
5L (LIM) 0734	250 / FL100	5R
6L LFP007 0745	207 16.5	6R
	↑↓	

2. Lateral revisions that lead to a temporary flight plan (TMPY) before they take effect:


The flight crew creates a temporary flight plan, then inserts it as a revision to the active flight plan. The flight crew does this when selecting, deleting, or modifying several waypoints of an airway or procedure at once (SID, STAR, HOLD, TAKEOFF or LANDING RWY). This modification is made on specific "LAT REV" pages from the flight plan page.

Possible revisions are:

- Insert or modify the departure procedure
- Insert or modify the arrival procedure
- Insert a waypoint
- Change the destination
- Insert an airway
- Insert an offset
- Insert a holding pattern
- Select or enable an alternate flight plan
- Fix information.

The purpose of the temporary flight plan is to allow the flight crew to check a revision on the MCDU and on the ND before inserting the changes into the active flight plan. It is a copy of the active flight plan that has been changed according to the flight crew revision. While it is displayed, the aircraft will continue to follow the original active flight plan.

No predictions are computed or displayed on the pages of the temporary flight plan.



A temporary flight plan is displayed for a check and/or new modification. Inserting the temporary revision will modify the active flight plan.

The screenshot displays two flight plan screens on a dark background. The top screen shows a temporary flight plan (TMPY) for flight AI5612. The bottom screen shows the active flight plan. A white arrow points from the 'INSERT \*' button on the top screen to the active flight plan screen. The flight plan data is as follows:

FROM	UTC	SPD/ALT
LMG	1526	/FL290
UR10	BRG008	115NM
AMB	----	----/----
UR10	TRK023	41
CDN	----	----/----
UB19		55
MAN	----	----/----
UB19		20
PON	----	----/----

FROM	UTC	SPD/ALT
LMG	1526	/FL290
UR10	BRG008	115NM
AMB	1541	310/FL290
UR10	TRK023	" / " 41
CDN	1547	" / " 55
UB19		" / " 20
MAN	1553	" / " 20
UB19		" / " 20
PON	1558	" / " 20
DEST	UTC	DIST
EGLL27R	1638	405
		6.7



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

FLIGHT PLANNING - LATERAL FUNCTIONS

Intentionally left blank

## FMS2 HONEYWELL

### GENERAL

Ident.: DSC-22\_20-30-10-15-00005067.0001001 / 09 FEB 11

Applicable to: ALL

The lateral revision function allows the pilot to create or modify the following parts of the flight plan:

- Airway
- Waypoint
- New destination
- Holding pattern
- Offset
- Alternate
- Fix information

Each time the pilot activates one of the above-listed revisions, he accesses a temporary flight plan that enables the modification to be checked before inserting it in the active flight plan. The crew selects these functions by pressing the left keys on F-PLN A or B.

- Direct to and overfly functions are accessed via the MCDU keys. No temporary flight plan is created with these functions.
- "Update at" capability is a specific function that manually updates the FM position. It does not use a temporary flight plan, but the pilot must confirm its insertion before it is activated.

### TEMPORARY F-PLN (TMPY)

Ident.: DSC-22\_20-30-10-15-00000460.0001001 / 01 OCT 12

Applicable to: ALL

When a pilot makes a lateral revision to the F-PLN, the FMGS creates a temporary flight plan. This is a copy of the active F-PLN, but is corrected by the lateral revision in progress.

The aircraft continues to follow the active F-PLN, until the temporary revision is inserted.

The revision appears in yellow font on both MCDU s and NDs.

- Lateral and vertical revisions cannot be made to a temporary F-PLN.
- Only one temporary F-PLN may be accessed at a time.
- The "DIRECT TO" function, when used, erases a temporary F-PLN.
- When a DIR TO is in process, a temporary revision cannot be displayed on the other MCDU.
- A TMPY F-PLN changes the title of the flight plan pages. (TMPY appears in all titles).
- No predictions are computed for a temporary flight plan (dashes are displayed).



Temporary data is displayed in yellow (ND and MCDU). Once inserted, it becomes active and is displayed in green.

## INSERTING AN AIRWAY WITH "VIA"


Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-E-00012828.0001001 / 14 MAY 12

### GENERAL

In the active flight plan, the pilot can insert up to 5 successive airway segments, going from a revised waypoint or ending at a given waypoint of the flight plan.






SELECT the revised waypoint (here CDN).  
 PRESS [ 5R ] to select the airways function.

Ident.: DSC-22\_20-30-10-15-E-00012829.0001001 / 14 MAY 12

**THE PILOT WISHES TO INSERT SUCCESSIVE AIRWAY SEGMENTS FROM A WAYPOINT**

e.g. from CDN - Airways UB19 – Airways UB25 – Ending point AAA.



WRITE the first airway in the scratchpad (here UB19).

PRESS [ 1L ] to insert it into the VIA field.


WRITE the second airway in the scratchpad (here UB25).

PRESS [ 2L ] to insert it into the VIA field.

The system automatically determines the first downpath intersection point between the 2 airways.

- If the airways have a common waypoint, the system selects it as the ending point of the first VIA.
- If they have no common waypoint, but have a single intersection, the system creates this intersection as an FM -computed point and displays X followed by the airway IDENT (here XUB25).
- If they have no common waypoint or intersection, the system displays NO INTERSECTION FOUND in the scratchpad.

Once the pilot has entered the required airways (up to 5), he must enter the ending point of the last selected airways:




WRITE the ending waypoint in the scratchpad (here AAA).

PRESS [ 2R ] to insert the ending waypoint into the TO field.

*Note: If two waypoints with the same IDENT belong to the same airway, the DUPLICATE NAMES page will not be called up, and the system selects the first one in the database.*

Ident.: DSC-22\_20-30-10-15-E-00012830.0001001 / 01 OCT 12

**THE PILOT WISHES TO INSERT ONE AIRWAY SEGMENT TO AN ENDING WAYPOINT**




WRITE the airway IDENT in the scratchpad (here UB19).  
 PRESS [ 1L ] to insert it into the VIA field.  
 WRITE the ending waypoint in the scratchpad (here PON).  
 PRESS [ 1R ] to insert it into the TO field.

- Note:*
- If the revise waypoint, or the ending waypoint, does not belong to the entered airway, the system displays AWY /WPT MISMATCH in the scratchpad.
  - If two waypoints with the same IDENT belong to the same airway, the DUPLICATE NAMES page will not be called up and the system selects the first one in the database.

Ident.: DSC-22\_20-30-10-15-E-00012831.0001001 / 09 FEB 11

**FLIGHT PLAN INSERTION**

The flight crew either inserts the flight plan directly from the AIRWAYS page, or from the TMPY F-PLN page. In both cases:  
 PRESS [ 6R ] to insert the temporary flight plan. Clear flight plan discontinuity, as needed.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p style="text-align: center;">FLIGHT PLANNING - LATERAL FUNCTIONS</p>
---	---

**INSERTING A WAYPOINT**

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-F-00012832.0001001 / 09 FEB 11

**GENERAL**

Waypoints can be inserted in two ways:

- Directly into the flight plan. All modifications go directly into the active flight plan. No temporary flight plan is created.
- By means of a lateral revision at the “NEXT WAYPOINT”, a process that creates a temporary flight plan.

The second method enables the temporary flight plan to be checked before it is inserted.

Ident.: DSC-22\_20-30-10-15-F-00012833.0001001 / 09 FEB 11

**WAYPOINT IDENTIFICATION**

The pilot can identify a waypoint by:

- Its identifier (if it is in the navigation database).
- A Latitude/Longitude (LL).
- A Place/Bearing/Distance (PBD). The waypoint is defined by its bearing and distance from a place.
- A Place-Bearing/Place-Bearing (PBX). The waypoint is defined by the interception of 2 radials from 2 places.
- A Place/Distance (PD). The waypoint is defined by a distance from a place, along the F-PLN.


*Note: If a slash or a dash is not entered properly, the MCDU displays a “FORMAT ERROR” message.*

When the Flight Management Guidance System receives a waypoint that is not in the database, it identifies it as LLxx or PBD xx or PBX xx or PD xx (xx is a two-digit number between 01 and 20) and stores it in the stored waypoints file of the database.

*Note: When NAV mode is engaged, the crew cannot modify the “TO” waypoint (active leg) using the waypoint insertion function. If the crew wants to modify it, the DIR TO function will be used.*

Ident.: DSC-22\_20-30-10-15-F-00012834.0001001 / 14 MAY 12

### WAYPOINT INSERTED DIRECTLY IN THE FLIGHT PLAN



1L	FROM	UTC	AI5612	SPD/ALT	1R
2L	TOU	1013		/FL220	2R
3L	LMG2D	BRG	308	23NM	3R
4L	AGN	1020	.78/	FL290	4R
5L	UR10	TRK	004	116	5R
6L	LMG	1035	.78/	FL290	6R
	UR10		" / "	97	
	AMB	1051	" / "	40	
	CND	1056	" / "	" / "	
	DEST	UTC	DIST	EFOB	
	LFPG1D	1134	352	8.4	
	LMG/330/135			↑ ↓	

1L	FROM	UTC	AI5612	SPD/ALT	1R
2L	TOU	1013		/FL220	2R
3L	LMG2D	BRG	308	23NM	3R
4L	AGN	1022	.80/	FL290	4R
5L	DIRECT	TRK	346	237	5R
6L	PBD02	1050	.80/	FL290	6R
	---F-PLN DISCONTINUITY---				
	LMG	1101	"	"	
	DEST	UTC	DIST	EFOB	
	LFPG1D	1154	554	7.2	
				↑ ↓	



WRITE the waypoint identifier or LAT /LONG, Place/Bearing/Distance or Place-Bearing/Place-Bearing into the scratchpad. (Example: Place: LMG, Bearing: 330 °, Distance: 135 NM).

PRESS the appropriate key to enter the waypoint into the flight plan. The rule is that the new waypoint appears next to the pressed key, and the previous waypoint moves down the flight plan path.

This operation creates a discontinuity between the new waypoint and the previous one. The new flight plan will have to be cleared of the discontinuity and some waypoints erased.

Ident.: DSC-22\_20-30-10-15-F-00012835.0001001 / 01 OCT 12

**ALONG TRACK WAYPOINT INSERTION**

On the F-PLN or STEP ALTS page, the pilot can enter an along track waypoint, defined as a place/distance waypoint.

The diagram illustrates the process of inserting an along track waypoint into a flight plan. It shows two screenshots of the flight plan display with numbered callouts and arrows indicating the sequence of actions.

**Top Screenshot:** Shows the initial flight plan with waypoints: TOU (1013 UTC, SPD/ALT /FL220), LMG2D (BRG 308, 23 NM), AGN (1020 UTC, .78/ FL290), LMG (1035 UTC, .78/ FL290), and AMB (1051 UTC, "/"). The scratchpad shows "AMB/-040".

**Bottom Screenshot:** Shows the flight plan after inserting the along track waypoint. The waypoints are: TOU (1013 UTC, SPD/ALT /FL220), AGN (1022 UTC, .80/ FL290), LMG (1035 UTC, .78/ FL290), PD01 (1045 UTC, "/"), and AMB (1051 UTC, "/"). The scratchpad shows "LFPG1D 1154 554 7.2".

**Callouts:**

- 1 WRITE:** Points to the scratchpad in the top screenshot where the waypoint identifier "AMB/-040" is entered.
- 2 SELECT:** Points to the "4L" key in the top screenshot, which is used to insert the waypoint into the flight plan.



WRITE the waypoint identifier and distance from this place.

According to the sign of the distance, the crew may define an along track waypoint before or after the revised place. (Example: AMB/-040).

PRESS the appropriate key adjacent to the place identifier. The system automatically positions the waypoint in the flight plan.

This operation does not create any discontinuity.

The system does not accept an along track waypoint entered at the FROM waypoint.



Ident.: DSC-22\_20-30-10-15-F-00012836.0001001 / 01 OCT 12

**WAYPOINT INSERTED THROUGH THE USE OF "NEXT WAYPOINT"**


**1 SELECT** →

FROM	UTC	IT5612 SPD/ALT
AGN	1013	/FL220
LMG2D	BRG004	93NM
LMG	1025	.78/FL290
UR10	TRK006	97
AMB	1030	"/"
UR10		40
CDN	1043	"/"
DIRECT		60
EVX	1051	"/"
DEST	UTC	DIST EFOB
LFPG1D	1134	352 8.4

**2 WRITE** →

LAT REV FROM LMG
45°49.0N/001°01.8E
<b>FIX INFO&gt;</b>
LL XING/INCR/NO
[ ]/[ ]/[ ]
NEXT WPT [ ]
NEW DEST [ ]
AIRWAYS>
<RETURN ANG

**3 ENTER** →



- SELECT the lateral revision (LAT REV) function at an appropriate waypoint.
- WRITE the waypoint identifier, or LAT /LONG, or Place/Bearing/Distance, or Place-Bearing / Place-Bearing into the scratchpad.
- ENTER it in the brackets under NEXT WPT (next waypoint).
- INSERT the temporary flight plan by pressing the [ 6R ] key.
- CLEAR the F-PLN discontinuity, as appropriate.

Ident.: DSC-22\_20-30-10-15-F-00012837.0001001 / 14 MAY 12

**LATITUDE/LONGITUDE CROSSING WAYPOINT INSERTION**

This function allows the insertion of one or several points along the flight-plan beyond the revised waypoint, at fixed latitude or longitude intervals (INCR) from a specified latitude or longitude. These waypoints are not considered as part of the pilot-defined elements. The system deletes them when sequenced.

LAT REV AT A WPT

LAT REV FROM LMG  
45°49.0N/001°01.6E

<p>&lt;HOLD ENABLE ←ALTN</p>	<p>LL XING/INCR/NO [ ]*[ ]*/[ ] NEXT WPT [ ] NEW DEST [ ] AIRWAYS&gt;</p>
--------------------------------------	---

<RETURN  
N46/1/3

1 WRITE →

ENTER 2 ←

FROM	UTC	SPD/ALT	FBS1 →
T-P	1038	.70/ FL350	
LMG	1211	250/ 2000	
N46	1213	" / "	TRK004° 11 7NM
N47	1227	" / "	60
N48	1241	" / "	61
DEST	UTC	DIST	EFOB
LFP007	1300	206	12.7

INSERT 3 ←



WRITE the latitude (NXX, XXN, SXX or XXS), the required increment in degrees between the successive waypoints, and the number of required waypoints.

(Example: The pilot wants to obtain 3 points, every degree from latitude N46: He enters N46/1/3).

PRESS [ 2R ] to insert it into the LL XING/INCR/NO field.

PRESS [ 6R ] to insert the new waypoints in the flight plan without discontinuity.

*The system does not store these waypoints in the database.*

## FIX INFO

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-G-00012838.0008001 / 09 FEB 11

### GENERAL


When using the FIX INFO function, the flight crew defines waypoint intersections of the flight plan with radials, circle or abeam associated to a fix.


When the flight crew inserts the intersection points, the system automatically identifies these points, but does not store them in the navigation database.

Ident.: DSC-22\_20-30-10-15-G-00012839.0008001 / 01 OCT 12

### INSERTING A RADIAL INTERCEPT WAYPOINT

The flight crew accesses the radial intercept function from the lateral revision page at the origin or “from” waypoint.





WRITE the reference fix identifier into the scratchpad (here POI), and ENTER it [1L].

*It may be any database or pilot-defined fix.*

WRITE the radial into the scratchpad (here 120 °) and ENTER it [2L].


*The defined radial appears as a blue dashed line on the ND.*

*If the radial line intersects the active flight plan, the system computes the time, distance to go, and the altitude at the intersection point.*

*Up to two radials can be entered.*

SELECT the required radial to insert the associated waypoint into the flight plan (if needed):

*The system automatically assigns its IDENT as the three first characters of the reference fix IDENT , followed by the radial. (Example: ABC 140). The blue dashed line disappears from the ND.*



Ident.: DSC-22\_20-30-10-15-G-00012840.0001001 / 01 OCT 12

**INSERTING A CIRCLE INTERCEPT WAYPOINT**

② INSERT → [4L]

① WRITE → [6L]

FIX INFO 1/4 →

REV FIX	POI	RADIAL	UTC	DTG	ALT
[ ]	[ ]	[ ]°	---	---	---
RADIUS		[ ] NM	---		
← ABEAM					
		20			

[1R]

[2R]

[3R] FIX INFO PAGE  
FOLLOWING REF  
FIX ENTRY

[4R]

[5R]

[6R]

[1L]

[2L]

[3L]

[4L]

[5L]

[6L]

FIX INFO 1/4

REV FIX	POI	RADIAL	UTC	DTG	ALT
[ ]	[ ]	[ ]°	---	---	---
RADIUS		*20 NM	1020	11	FL350
← ABEAM					

[1R]

[2R]

[3R]

[4R] A CIRCLE INTCP  
POINT IS COMPUTED  
AND INSERTABLE

[5R]

[6R]

WRITE the reference fix identifier into the scratchpad (here POI), and ENTER it [1L].

WRITE the circle radius in the scratchpad (here 20 NM), and ENTER it [4L]:

*The defined circle appears as a blue dashed circle on the ND. If the circle intersects the active flight plan, the system computes the time, along path distance to go and altitude at the first intersection point from the current aircraft position.*


GLG A318/A319/A320/A321 For A/C: HC-CJV  
 FCOM

← E →

DSC-22\_20-30-10-15 P 17/56

22 MAR 17

SELECT the required radius to insert the associated waypoint into the flight plan (if needed).  
 The system automatically assigns its IDENT as a D, followed by the radius, and followed by the three first characters of the reference fix IDENT (example D020 POI). The blue dashed circle disappears from the ND.



Ident.: DSC-22\_20-30-10-15-G-00012841.0008001 / 01 OCT 12

**INSERTING AN ABEAM INTERCEPT WAYPOINT**

SELECT →

FIX INFO 1/4 →

[1L] REF FIX	POI	UTC	DTG	ALT	
[2L] RADIAL	[ ]°	---	---	---	
[3L] RADIUS	[ ]NM	---	---	---	
[4L] ←ABEAM					

[1R]

[2R]

[3R] FIX INFO PAGE

[4R] FOLLOWING REF

[5R] FIX ENTRY

[6R]

FIX INFO 1/4

[1L] REF FIX	POI	UTC	DTG	ALT	
[2L] RADIAL	[ ]°	---	---	---	
[3L] RADIUS	[ ]NM	---	---	---	
[4L] ABEAM					
[5L] *0.94°		1505	52	FL350	

[1R]

[2R]

[3R] ABEAM INTCP

[4R] POINT IS COMPUTED

[5R] AND INSERTABLE

[6R]

WRITE the reference fix identifier into the scratchpad (here POI), and ENTER it [1L]




SELECT the ABEAM prompt [ 5L ]:

*A blue dashed line from the reference fix and perpendicular to the flight plan appears on the ND. The system computes the radial, time, distance to go, altitude and predictions related to the waypoint abeam the reference fix.*

SELECT [ 5L ] to insert the abeam intercept waypoint into the flight plan (if needed):

*The system automatically assigns its identifier as AB, followed by the first five characters of the reference fix identifier (Example ABXYZ). The blue dashed line disappears from the ND.*




**INSERTING A NEW DESTINATION**

Ident.: DSC-22\_20-30-10-15-00000471.0001001 / 14 MAY 12

Applicable to: ALL

The pilot may define a new destination and insert it via the lateral revision page. The pilot may then call up the new destination from any waypoint along the flight plan, except the FROM waypoint, the destination, and the missed-approach waypoint. When the new destination has been inserted, a flight plan discontinuity appears between the revision waypoint and the new destination. All waypoints beyond the revision waypoint (including the previous destination and associated missed approach) are deleted.



The diagram illustrates the sequence of operations for lateral revision in the flight management system. It shows three sequential screens with corresponding control actions:

- Screen 1:** Displays flight plan data for a route from ROCCA to LGAT33R. A callout '1 SELECT' points to the left side of the screen.
- Screen 2:** Shows the 'LAT REV FROM GEN' menu with options like '<HOLD', '<ENABLE', '<ALTN', and '<RETURN EHAM'. A callout '2 WRITE' points to the left side. A callout '3 ENTER' points to the right side.
- Screen 3:** Shows the flight plan with a temporary destination 'EHAM' and a callout '4 INSERT' pointing to the right side.

SELECT the lateral revision function at an appropriate waypoint.

WRITE the new destination in the scratchpad.

Enter it in the brackets under "NEW DEST".

INSERT the temporary flight plan ([ 6R ] key), and complete the flight plan to the new destination.

**HOLDING PATTERN**

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-A-00007222.0001001 / 09 FEB 11


**GENERAL**

This section describes holding patterns, associated guidance and flight crew procedures. The Flight Management and Guidance Computer (FMGC) has three types of holding patterns that the pilot can use in a flight plan.

Ident.: DSC-22\_20-30-10-15-A-00007163.0001001 / 01 OCT 12

**HOLD TO FIX (HF)**

The holding pattern is always part of an arrival or departure procedure. The aircraft flies it once and then automatically exits the holding pattern at the fix. The predicted speed in the holding pattern is the lowest of the ICAO speed limit, max endurance speed, or any speed constraint. Guidance to the fix in the holding pattern is similar to that on any leg of a flight plan. The HF patterns are part of the navigation database and cannot be created by the crew.



Ident.: DSC-22\_20-30-10-15-A-00007182.0001001 / 01 OCT 12


**HOLD TO ALTITUDE (HA)**

The aircraft flies the hold until it reaches the specified altitude. Then, it automatically exits the hold at the fix. The predicted speed for the holding pattern is the lowest of the ICAO speed limits, the max endurance speed, or any speed constraint.

The size of the holding pattern is a function of the predicted speed.

Guidance in a hold to altitude (HA) is similar to that for any leg of a flight plan.

The HAs are in the navigation database, as part of the arrival or departure procedures, and cannot be created by the crew.



Ident.: DSC-22\_20-30-10-15-A-00007206.0013001 / 01 OCT 12

**HOLD WITH MANUAL TERMINATION (HM)**

This type of holding pattern may be part of an arrival procedure, or the pilot may enter it at the present position or at any flight plan waypoint.


The pilot will use this type of holding pattern to comply with a defined procedure or a clearance limit, or to meet an operational need (such as losing altitude, holding for weather improvement, or absorbing an ATC delay).

This type of holding pattern is exited according to the pilot's decision, not automatically.

There are 3 types of HM.


All are modifiable.

**DATABASE HOLD**



If the holding pattern is part of the database, it is named DATABASE HOLD and all its associated data (inbound course, turn direction, time/distance) are defined in the database. The flight crew can modify this data.

**COMPUTED HOLD AT...**



If the holding pattern is not in the database, the FMGC designs a holding pattern and proposes it to the pilot. The associated data consists of default values that the pilot can modify.

**HOLD AT...**



If the pilot inserts into the active flight plan a holding pattern that is manually-corrected from a hold defined by the FMGS, the screen displays a “HOLD AT...” page. The 2R field displays REVERT TO DATABASE or REVERT TO COMPUTED to restore the database data, if necessary.

**PREDICTIONS AND GUIDANCE ASSOCIATED WITH A HM HOLDING PATTERN (HOLD WITH MANUAL TERMINATION)**


Before deceleration

If an altitude constraint is defined at the hold entry fix, then the FMS duplicates this constraint on the hold exit.

However, different constraints may be inserted at entry and exit fixes.

Although the hold is inserted into the flight plan, the FMGS does not take it into account for predictions until the aircraft enters the hold.

However, if the hold is not deleted by the crew, the FMGS schedules a deceleration point and displays it on the ND.



The FMGS predicts the estimated time and amount of fuel remaining at which the aircraft must exit holding, so as to comply with the fuel policy specified on the fuel prediction page. When the aircraft enters the holding pattern, the FMGS revises all predictions and assumes the aircraft will fly one turn of the holding pattern. All predictions are revised for one more holding circuit at holding fix overfly.

Upon reaching the speed change pseudo waypoint

The FMGS either causes the aircraft to decelerate to the hold speed (if managed speed is active and NAV mode engaged), or displays “SET HOLD SPD” (set hold speed) on the MCDU and primary flight display, if the flight crew had selected a speed target.


The default hold speed is the lowest of the:

- Maximum endurance speed
- ICAO limit holding speed
- Speed constraint (if any).

When no specific speed limit applies, the default hold speed is approximately equal to:

- Green Dot speed on the A318, A319, A320 (CFM) and A321
- Green Dot + 20 kt for altitude lower than 20 000 ft, on the A320 (IAE).
- Green Dot + 5 kt for altitude bigger than 20 000 ft, on the A320 (IAE).

The flight plan predictions for time and fuel do not yet consider that the hold will be flown, however, the navigation display shows the hold entry and holding pattern trajectory.



Deceleration receives priority, so that when the aircraft is in descent with the descent mode engaged, it will deviate above the descent path to decelerate. (VDEV becomes positive on the progress page).

The flight plan page displays an immediate exit prompt.

If the flight crew presses the key next to “IMM EXIT” before arriving at the holding fix, the aircraft will not enter the holding pattern, but will resume its phase-related managed-speed profile.





After reaching the hold entry fix


The aircraft enters the hold. The MCDU HOLD page displays the associated holding data:

- The inbound course (INB CRS)
- The TURN direction (L or R)
- The TIME/DIST
- The LAST EXIT time and the associated fuel to reach the alternate airport with no extra fuel.

The FMS assumes that the aircraft will fly one turn of the holding pattern, and revises the predictions accordingly.


When the holding pattern is defined by a leg time (and not a leg distance), the system revises the size of the hold as a function of the target speed.

- If managed speed is active, the system uses the predicted holding speed to calculate the size of the holding pattern.
- If the selected speed is active, the system uses the target speed selected by the flight crew at the entry fix sequencing to calculate the size of the holding pattern.
- The VDEV displayed on the primary flight display and the PROG page when the aircraft is flying in the HM (hold pattern with manual termination) is the difference between the aircraft's current altitude and the altitude at which it should be when it reaches the hold exit fix in order to be correctly positioned on the descent path.



With IMM EXIT pressed (aircraft in the holding pattern)

The predictions and guidance assume that the aircraft is immediately returning to the hold fix. Sequencing the hold fix, the aircraft exits the holding pattern and resumes its navigation. The flight plan page displays “RESUME HOLD\*” instead of “IMM EXIT\*”.



### HOLD EXIT PROCEDURE

Position (1) If "IMM EXIT" pressed, the aircraft will exit at the next fix overfly.

Position (2) If "IMM EXIT" pressed, the aircraft will make an immediate turn to the fix where the hold will be exited.

- **If managed speed is active:**

The computer sets the target speed to the applicable speed of the current phase (for example, speed constraint, ECON speed, or speed limit).

The computer then bases its predictions on the assumption that the flight will continue on the descent path, if the aircraft is in descent.

● **If DES mode is engaged:**

The following applies:

- The holding pattern is never included in the descent path computation.
- The flight crew cannot enter altitude and speed constraints at the hold exit fix. (This is only allowed at the hold entry fix).
- The vertical guidance in the HM , during the descent phase, calls for a constant -1 000 ft/min. But the computer considers altitude constraints that will take effect farther down the flight path as it calculates vertical guidance and predictions. The system will not allow the aircraft to descend below the next altitude constraint, neither the FCU selected altitude. If the aircraft reaches the next altitude constraint, it will level off and the altitude constraint mode will engage.

With RESUME HOLD pressed


If the flight crew presses the key next to “RESUME HOLD”, the aircraft remains in the holding pattern, and “IMM EXIT” is displayed again.

After that, each time the aircraft flies over the holding fix, the system updates the predictions for one more holding circuit.


**HOLDING PATTERN ENTRIES**

The FMGS offers three types of entry into holding patterns:


1. Direct entry
2. Teardrop entry
3. Parallel entry




1. The direct entry



2. The teardrop entry




3. The parallel entry



*Note:* If the leg the aircraft is flying toward the holding fix is on a “limit” between a teardrop entry and a parallel entry, the FMGC may compute and display either of the two entries. The pilot should keep this in mind and should not assume that the FMGC is malfunctioning.

If the flight plan leg toward the hold entry fix is on a course that is the reciprocal of the inbound course of the holding pattern, the aircraft will fly a parallel entry.




Ident.: DSC-22\_20-30-10-15-A-00007220.0001001 / 09 FEB 11

**PROCEDURE TO INSERT A HOLD (HOLD WITH MANUAL TERMINATION)**

The HOLD prompt allows the flight crew to enter a hold with manual termination (HM), at the revised waypoint or at the present position.


The flight crew accesses the HOLD page from a lateral revision at the present position (PPOS) or at a waypoint.



SELECT lateral revision at present position (PPOS), or an applicable waypoint.  
 PRESS the HOLD prompt [3L].

*A TMPY F-PLN is created and if applicable, the database hold is proposed.  
 If no database hold is available, the computed hold is proposed.*

CHECK and (if necessary) MODIFY the HOLD data.  
 CHECK the temporary flight plan and INSERT it, if appropriate.



Ident.: DSC-22\_20-30-10-15-A-00007219.0001001 / 09 FEB 11

**PROCEDURE TO DELETE A HOLD (HOLD WITH MANUAL TERMINATION)**

CLEAR the HOLD directly in the flight plan, as can be done for a normal waypoint.

**OFFSET**

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-B-00007230.0009001 / 14 MAY 12

**GENERAL**

Offset allows the flight crew to define an offset of the active flight plan. The offset can be immediate or deferred to start on a downstream leg. The offset will end by default or at a pre-planned end waypoint. Additionally, the flight crew can specify the intercept angle used for the transitions to and from the offset path.

In most cases, the pilot will use it enroute because of an ATC clearance, or to avoid bad weather expected along the flight plan route.

This page is accessed from LAT REV page at the FROM waypoint or at any waypoint downpath the flight plan, except the destination airport.


After inserting the offset in the flight plan, the flight plan page shows OFST in its title, left or right arrows are displayed on every label line between the start and end waypoints of the offset, and the navigation display shows the offset flight plan with a solid green line and the original flight plan with a dashed green line.

The offset is cleared:

- Automatically (holding pattern, approach), or
- Manually with the clear (CLR) key, or by entering "o" in the offset value field [ 1L ] or by using the delete prompt in the OFFSET page.

*Note: If the pilot enters an OFFSET when the aircraft is too close to the TO waypoint, the FMGS may refuse to accept it, in which case the MCDU displays the "ENTRY OUT OF RANGE" message.*





Ident.: DSC-22\_20-30-10-15-B-00007207.0010001 / 01 OCT 12

### **INSERTING AN OFFSET**

SELECT LAT REV page at a waypoint.

SELECT OFFSET function by pressing [ 2L ].


WRITE the required offset value and direction (for example, L5 or 5L), and enter it into [ 1L ] field.

CHECK or INSERT the START WPT from the list in [ 3L ] - [ 5L ] fields or manually enter it.

CHECK or ENTER the INTCP ANGLE in [ 1R ] field.

CHECK OR INSERT the END WPT from the list in [ 3R ] - [ 5R ] fields or manually enter it.

PRESS INSERT in [ 6R ] field to activate the OFFSET.




Ident.: DSC-22\_20-30-10-15-B-00007218.0009001 / 14 MAY 12

### MANUAL CANCELLATION OF AN OFFSET

There are two standard methods for cancelling an offset:

1. SELECT DIR TO a waypoint (the next waypoint, for example).
2. SELECT a Lateral Revision (LAT REV ) at FROM WPT.

CLEAR the OFFSET field or enter "0" in the OFFSET value field [1L], and press INSERT\* in [6R] to activate the temporary flight plan (cancelling OFFSET), or PRESS the OFFSET DELETE prompt [6R] to activate the temporary flight plan (cancelling OFFSET).



## ALTERNATE FUNCTION

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-C-00007240.0001001 / 09 FEB 11

### GENERAL

- The ALTERNATE FUNCTION performs two actions:
- It reviews and defines alternate airports and inserts them into the flight plan.
  - It allows a diversion to be activated through the ENABLE ALTN command.

Ident.: DSC-22\_20-30-10-15-C-00007217.0009001 / 23 JUN 15

### REVIEW AND SELECTION OF ALTERNATE AIRPORT

Several alternate airfields may be stored in the database and assigned to a destination. When the pilot selects a company route (CO RTE) (or a city pair), the computer strings the preferred alternate into the active flight plan.

The pilot may review the alternate airports on the ALTN page and, if the one selected is not suitable because of weather or fuel considerations, another alternate may be strung into the active flight plan.

The pilot may define an additional alternate airport into the list, if necessary.

The ALTERNATE page shows the track and distance (airway or direct) between destination and alternate, as well as fuel management data (EXTRA fuel, assuming the associated airfield is the alternate airport). This data will help the pilot change the preferred alternate, if necessary.

Access the ALTERNATE page through the ALTN prompt on the LAT REV page at destination.

Alternate airfields are attached to the destination.

### **ENTERING NEW ALTERNATE INTO THE F-PLN**

If the preferred alternate is unsuitable, proceed as follows:

SELECT F-PLN key on MCDU.


SELECT LAT REV at destination.

SELECT ALTN [5L].

SELECT an AIRFIELD IDENTIFIER.

INSERT the temporary flight plan.

*Note: If weather and destination airfield conditions permit, you may select "NO ALTN".  
Fuel predictions will be computed without alternate fuel.*



**SELECTION OF ANOTHER ALTERNATE**

Fuel management information for flight to another alternate airfield may be obtained by selecting the OTHER ALTN field.

SELECT LAT REV at DESTINATION.

SELECT ALTN [5L].

ENTER the airfield identifier in the brackets.

- If the airfield is not in the database, the **NEW RUNWAY** page automatically appears.
- If the airfield is in the database and there is a company route (CO RTE) to it, the **ROUTE SELECTION** page automatically appears.


SELECT the route, as appropriate, or RETURN to the ALTN page.


ENTER the distance in the brackets (if required). XTRA fuel and track (TRK) will appear.

SELECT the other alternate (OTHER ALTN ) as a primary alternate if convenient. (EXTRA fuel and DIST revert to AIRWAY distance).

INSERT it, if you want to have it as a primary alternate.

- Note:
- The pilot can always overwrite the "OTHER ALTN ". The new "OTHER ALTN" then replaces the previous one, which is lost.
  - The pilot can select OTHER ALTN as a primary alternate (active flight plan), to replace any alternate on the initial list.
  - If the pilot selects the other alternate as a primary alternate, and overwrites the OTHER ALTN field by entering a new airport, the first one will remain a primary alternate and the system will memorize a second OTHER ALTN.





The pilot may enter a distance in the OTHER ALTN field. The system will compute the extra fuel and the track for this distance.

**PREDICTED DATA FOR ALTERNATE**

Data predictions are based on:

- Aircraft weight being equal to landing weight at primary destination.
- Flight at FL 100 if the alternate F-PLN length is less than 100 NM , at FL 220 if the alternate F-PLN length is comprised between 100 and 200 NM , or else at FL 310.
- Cost index 0.
- Constant wind (as entered in the alternate field of the DES WIND page).
- Constant delta ISA (equal to delta ISA at primary destination).
- The along flight path distance from the destination to the alternate airport. If the flight crew enters an ALTN fuel value, this value is the one taken into account.


**ENABLE ALTN**

Ident.: DSC-22\_20-30-10-15-00000467.0009001 / 01 OCT 12

Applicable to: ALL

This enables the pilot to initiate a diversion by entering the alternate flight plan just after the revision waypoint (with a discontinuity).

The pilot may have to adjust the resulting flight plan (use “direct to”, or add or suppress waypoints), depending on the circumstances.



**TO ACTIVATE THE PRIMARY ALTN:**

**SELECT** a LAT REV at the “TO” waypoint (or at another suitable waypoint).


**PRESS** the ENABLE ALTN key.

**INSERT** the temporary flight plan.

**ENTER** an appropriate waypoint in DIRECT TO and adjust the flight plan.

**ADJUST** the cost index on the PERF page and the defaulted cruise flight level (CRZ FL ) on the PROG page, as required.





When ENABLE ALT is pressed at ABE, a flight plan discontinuity is created from ABE down to destination and the alternate route is linked to the active flight plan.

### DIR KEY (DIRECT-TO-FUNCTION)

Applicable to: ALL

Ident.: DSC-22\_20-30-10-15-D-00007243.0001001 / 09 FEB 11

#### GENERAL

The pilot uses the “Direct To” function to define a direct leg from the present position to any waypoint on the active flight plan or to any waypoint.

The designated waypoint may be entered by its identifier (if it is stored in the database) or by a latitude/longitude, place/bearing/distance, or a place-bearing/place-bearing.

*Note:* If the autopilot or flight director is in the heading/track or localizer mode, the “DIR TO” function engages the NAV mode.

Three functions are available through the DIR TO key:

- The DIR TO defines a direct leg from the present position to a specified waypoint. NAV mode engages simultaneously to the DIR TO selection. When the pilot uses DIR TO, the present position (PPOS) becomes the “FROM” waypoint and the active flight plan shows it as the T-P (turn point).
- The DIR TO /ABEAM function, defines the abeam waypoints along the direct leg. These waypoints are the projection on the direct leg of the initial F-PLN waypoints located between the aircraft position and the specified waypoint. NAV mode engages simultaneously to the DIR TO/ABEAM selection.
- The DIR TO /INTCPT function allows the definition of a specified RADIAL INBOUND or OUTBOUND at an inserted waypoint. The current aircraft track is used to compute the INTCPT point with the specified radial. NAV mode is armed simultaneously to the DIR TO /INTCPT selection.

The ND displays the DIR TO leg as a temporary flight plan leg between current aircraft position and specified waypoint. In case of a DIR TO /INTCPT, the leg is not displayed when the angle between the current aircraft track and the intercept radial exceeds 160 °.

Ident.: DSC-22\_20-30-10-15-D-00007216.0001001 / 14 MAY 12


**PROCEDURE FOR DIR TO WAYPOINT**


**CASE 1. THE “TO” WAYPOINT IS IN THE FLIGHT PLAN**

Example : DIR TO FRZ

PRESS the DIR key on the MCDU.

PRESS the line select key next to “FRZ”.






**CASE 2. THE “TO” WAYPOINT DOES NOT BELONG TO THE FLIGHT PLAN**

Example : Direct to ABC (ABC being an ident, LL or PBD or PBX (Place/Bearing-Place/Bearing))

PRESS the DIR key.

WRITE the waypoint identifier (e.g. ABC) into the scratchpad.

PRESS [1 L] to enter “ABC” in the “DIR TO” field.




ENTER → [1L] [1R]  
 [2L] [2R]  
 [3L] [3R]  
 [4L] [4R]  
 [5L] [5R]  
 [6L] [6R]

WRITE → [1L] [1R]  
 [2L] [2R]  
 [3L] [3R]  
 [4L] [4R]  
 [5L] [5R]  
 [6L] [6R]

DIR TO AI5612  
 \* [ ]  
 TOP 9C BRG136 32NM  
 TOP 1022 .78/FL290  
 UB25 TRK122 60  
 GEN 1030 \* \*  
 UB25 \* \* 57  
 BEROK 1037 \* \* 29  
 UB25 \* \* 110  
 FRZ 1041 \* \*  
 ANC 1055 \* \*  
 ABC

BEFORE THE DIR TO

TOP GEN BEROK FRZ



[1L] [1R]  
 [2L] [2R]  
 [3L] [3R]  
 [4L] [4R]  
 [5L] [5R]  
 [6L] [6R]

FROM AI5612 →  
 UTC SPD/ALT  
 T.P 1019 /FL290  
 DIRECT BRG157 54NM  
 ABC 1026 .78/FL290  
 - F.PLN DISCONTINUITY -  
 TOP 1034 \* / \*  
 UB23 \* / \* 60  
 GEN 1042 \* / \*  
 DEST UTC DIST EFOB  
 LGAT33R 1221 898 8.4

AFTER THE DIR TO


T.P TOP GEN BEROK FRZ  
 ABC F.PLN DISCONTINUITY

Clear the discontinuity and the waypoints that are not included in the new flight plan.


Ident.: DSC-22\_20-30-10-15-D-00007215.0001001 / 09 FEB 11

**PARTICULAR CASES FOR USE OF DIR TO**


- If the pilot is flying a manual leg (part of a SID or STAR ), the flight plan page displays “F-PLN DISCONTINUITY”, preceded by “MANUAL” (see below).  
 These legs are specific heading or track legs flown with no defined end waypoint.



- When the pilot encounters a flight plan discontinuity, or if a major reset occurs, the flight plan page displays “PPOS - F-PLAN DISCONTINUITY”, and the pilot loses managed guidance in both the lateral and vertical plans.  
 The autopilot or flight director reverts to the basic HDG V/S (or TRK FPA) modes. Predictions remain available and are based on the assumption that the aircraft will fly a direct leg from its present position to the next waypoint.



- **In both of these cases, the only way to get back to a standard flight plan is to perform a “DIR TO ” to a designated waypoint.**
- Following a DIR TO , the message “MAP PARTLY DISPLAYED” may appear on the NDs, if the new flight plan includes a very long leg (*Refer to DSC-31-45 Flags and Messages Displayed on ND*). When this message comes up, enter an intermediate waypoint to shorten the leg.

Note: During cruise, the DIR TO function is not available as long as uplink wind data, received through ACARS , is not inserted or cancelled on the CRUISE WIND page.

Ident.: DSC-22\_20-30-10-15-D-00007208.0009001 / 22 OCT 13

### PROCEDURE FOR DIR TO/ABEAM

Example : DIR TO/ABEAM BEROK


PRESS the DIR on the MCDU.

WRITE the waypoint identifier into the scratchpad (Example : BEROK).

PRESS [1 L] to enter the waypoint in the DIR TO field.

SELECT the ABEAM PTS function.

*The display reverts to F-PLN A page.*



**1 WRITE** → [6L] BEROK

DIR TO		AI101	
[1L]	[1R]	[TOPGC BRG136° 33NM	
[2L]	[2R]	TOP 1022 .78/FL290	
[3L]	[3R]	UB25 TRK122° 60	
[4L]	[4R]	N18E008 1030 * *	
[5L]	[5R]	UB25 57	
[6L]	[6R]	BEROK 1041 * *	
		UB25 29	
		FRZ 1041 * *	
		UB25 110	
		ANC 1055 * *	
		BEROK	↑↓


**2 ENTER** → [1L]

DIR TO		AI101	
[1L]	[1R]	[TOPGC BRG136° 33NM	
[2L]	[2R]	*BEROK [ ]°	
[3L]	[3R]	WITH [ ]°	
[4L]	[4R]	*ABEAM PTS [ ]°	
[5L]	[5R]	TOP 1022 .78/FL290	
[6L]	[6R]	UB25 TRK122° 60	
		N18E008 1030 * *	
		UB25 57	
		BEROK 1037 * *	
		UB25 29	
		FRZ 1041 * *	
			↑↓

**3 SELECT** → [2L]

FROM		AI101	
[1L]	[1R]	T.P 1025 /6000	
[2L]	[2R]	ABTOP 1041 .78/FL290	
[3L]	[3R]	AB1808 1048 * *	
[4L]	[4R]	BEROK 1057 * *	
[5L]	[5R]	UB25 25	
[6L]	[6R]	FRZ 1113 * *	
		DEST UTC DIST EFOB	
		ARPT33R 1259 1200 8.4	↑↓

F-PLN A PAGE



- Note:
1. If, between two waypoints projected on the direct leg, there was a discontinuity in the original flight plan, this discontinuity disappears between the corresponding abeam points on the direct leg.
  2. . Abeam waypoints computed from latitude/longitude-type waypoints are renamed by the system as "AB XXXXX", where "xxxxx" is an abbreviation in 5 characters, of the latitude and longitude of the initial waypoints.

Ident.: DSC-22\_20-30-10-15-D-00007221.0001001 / 14 MAY 12

**PROCEDURE FOR DIR TO/INTERCEPT**

PRESS the DIR key.

WRITE the waypoint identifier into the scratchpad.

PRESS [1L] to enter the waypoint in the DIR TO field.

*In the [1R] and [2R] fields, the MCDU displays the functions radial inbound and radial outbound from the waypoint.*

*If the waypoint belongs to the flight plan, the system displays the flight plan track as the default inbound radial. The crew can modify it.*

WRITE the required in or out radial into the scratchpad.

PRESS [1R] or [2R] to enter the radial in the required field.

*The ND displays the entered radial as an amber dotted line : The pilot can still modify it.*


PRESS [1R] or [2R] to confirm the DIR TO/INTERCEPT selection.

The display reverts to the F-PLN A page, the system arms the NAV mode, and engages the HDG mode. The FROM waypoint is the aircraft position at the time of the DIR TO /INTERCEPT selection. The MCDU indicates it as INBND or OUTBND.

- Note:**
1. If the waypoint does not belong to the flight plan, the system strings the DIR TO/INTERCEPT leg to this waypoint, and inserts a discontinuity following the waypoint.
  2. A DIR TO/INTERCEPT cancels any active offset.
  3. If the current AP /FD lateral mode is HDG or TRK , NAV becomes armed. If the NAV mode was engaged, NAV becomes armed. FCU HDG or TRK must be used to guide the aircraft. The ND displays an intercept point, if the intercept angle is less than 120 °. The system constantly updates it to reflect the current aircraft track and position with respect to the intercept radial. The NAV mode engages when reaching the intercept point.

**EXAMPLE: RADIAL INBND**

DIR TO AMB - RADIAL 200 ° INBOUND



The diagram illustrates the MCDU sequence for setting a DIR TO waypoint and a RADIAL IN intercept. It shows two stages of the MCDU display with corresponding button presses and a graphical representation of the intercept geometry.

**Stage 1: DIR TO AMB**

- Initial display: DIR TO \* [ ] FBS1
- Buttons: [1L] ENTER, [2L] LMG 0640 0.79 / FL350, [3L] (T/D) 0651 0.79 / FL350, [4L] AMB 0653 273 / FL301, [5L] VILRO 0655 16 \* / FL253, [6L] (SPD) (LIM) 0702 \*250 / FL100, [1R] FBS1, [2R] 79 NM, [3R] 0.79 / FL350, [4R] 18 TRK004°, [5R] 273 / FL301, [6R] 16 \* / FL253
- Message: DIR TO AMB IS ENTERED

**Stage 2: RADIAL IN**

- Buttons: [1L] \*AMB, [2L] WITH \*ABEAM PTS, [3L] LMG 0650 0.79 / FL350, [4L] (T/D) 0700 0.79 / FL350, [5L] AMB 0702 273 / FL301, [6L] VILRO 200 0705 16 \* / FL253, [1R] 184°\*, [2R] RADIAL IN, [3R] 79 NM, [4R] 0.79 / FL350, [5R] 18 TRK004°, [6R] 273 / FL301
- Message: Radial in defaulted value (AMB belongs to the F-PLN) Radial in is modified

**Final Display:**

- Buttons: [1L] \*AMB, [2L] WITH \*ABEAM PTS, [3L] LMG 0650 0.79 / FL350, [4L] (T/D) 0700 0.79 / FL350, [5L] AMB 0702 273 / FL301, [6L] VILRO 200 0705 16 \* / FL253, [1R] ENTER, [2R] 184°\*, [3R] RADIAL IN, [4R] 79 NM, [5R] 0.79 / FL350, [6R] 18 TRK004°, [6R] 273 / FL301
- Message: Radial in is modified

**Diagram:** A vertical line represents the radial. A point at the top is labeled 'AMB'. A point below it is labeled 'LMG'. A dashed line from the aircraft (represented by a crosshair) to AMB is labeled 'RADIAL 200°'.



New radial is confirmed

	DIR TO	FBS1	
	*AMB	RADIAL IN	200°*
1L	WITH	RADIAL OUT	[ ]°
2L	*ABEAM PTS		
3L	LMG	0 650	0.79 / FL350
4L	(T/D)	0700	0.79 FL350
5L	AMB	TRK004°	18
6L	VILRO	0702	273 / FL301
			16
			* / FL253
			↓↑

1R CONFIRM 5

	FROM	UTC	FBS1 →
	IN-BND		SPD/ALT
1L		0650	0.79 / FL350
2L	(T/D)	0703	0.80 / FL350
3L	AMB	0706	283 / FL301
4L	VILRO (SPD)	0708	* / FL350
5L	(LIM)	0715	*250 / FL100
6L	LFP007	0727	207 16.5
			↓↑

F-PLN  
A PAGE

INTCP

AMB

LMG

RADIAL 200°

**EXAMPLE: RADIAL OUTBND**

DIR TO AMB - RADIAL 200 ° OUTBOUND

**2** ENTER →

DIR TO AMB  
is entered

**1** WRITE →


Radial in defaulted value  
(AMB belongs to the  
F-PLN)  
Radial out is entered

**3** WRITE →

DIR TO	FBS1	
*[ ]		
LMG	0704	0.79 / FL350
(T/D)	0715	0.79 / FL350
	TRK004°	18
AMB	0717	2.73 / FL301
		16
VILRO	0719	° / FL253
(SPD)		47
(LIM)	0727	°250 / FL100
AMB		↓↑

DIR TO	FBS1	
*AMB		RADIAL IN
		184°*
WITH		RADIAL OUT
*ABEAM PTS		[ ]°
LMG	0705	0.79 / FL350
(T/D)	0715	0.79 / FL350
	TRK004°	18
AMB	0717	2.73 / FL301
		16
VILRO	0720	° / FL253
200		↓↑



The screenshot shows two data pages from the FMS. The top page displays radial out information for waypoints \*AMB and \*ABEAM PTS. The bottom page shows flight plan discontinuity information, indicating that the current page is a page out of the BND (Bounded) segment.

**Top Page Data:**

DIR TO	FBS1	RADIAL IN	[ ]°
*AMB			
WITH			
*ABEAM PTS		RADIAL OUT	200°*
LMG	0705	0.79 / FL350	
(T/D)	0715	0.79 FL350	
			79NM
AMB	TRK004*	18	
	0707	273 / FL301	
			16
VILRO	0720	* / FL253	

**Bottom Page Data:**

FROM	UTC	SPD/ALT	FBS1 →
OUT-BND	0705	.79 / FL350	
MANUAL	0719	.80 / FL350	
			BRG004* 87NM
---F-PLN DISCONTINUITY---			
(T/D)	0721	.80 / FL350	
			34
VILRO	0725	283 / FL253	
DEST	UTC	DIST	EFOB
LFP007	0744	241	15.8

**Annotations:**

- Left side: 1L-6L buttons.
- Right side: 1R-6R buttons.
- Text: "RADIAL OUT IS CONFIRMED" (left), "CONFIRM 5" (right, pointing to 2R button).
- Diagram: Shows a flight path with waypoints INTCP, LMG, and AMB. A dashed line indicates a radial out of 200 degrees from AMB.
- Text: "F-PLN a page out-BND becomes the from WPT and followed by the manual termination" (left).

**OVFY (OVERFLY) KEY**

Ident.: DSC-22\_20-30-10-15-00000469.0001001 / 01 OCT 12


Applicable to: ALL

The overfly key programs the Flight Management Guidance Computer to fly over a specific waypoint or NAVAID. To use it:

PRESS the "OVFY" key.

A "Δ" appears in the scratchpad.

INSERT it by pressing the key adjacent to the waypoint to be overflown. [3L] in this example.



1L AGN 1013 FL220 1R

2L LMG 1025 78 / FL290 2R

3L AMB 1038 " / " 3R

4L CDN 1043 " / " 4R

5L EUX 1051 " / " 5R

6L LFPG10 1100 352 8.4 6R

ENTER →

1 PRESS THE OVFY KEY: →

FROM IT5612  
 UTC SPD/ALT

LMG1 BRG004 93NM


UR10 TRK006 97

DIRECT 60

DEST UTC DIST EFOB

Δ ↑↓

The pilot cannot cancel the overfly program. If you do not want to fly over the point you have entered, use DIR TO (direct to) the next waypoint or engage the heading mode, whichever is more suitable.



The overfly function allows you to fly over a specific waypoint, and return the aircraft to the great circle track.


**"UPDATE AT"**

Ident.: DSC-22\_20-30-10-15-00000470.0001001 / 01 OCT 12

Applicable to: ALL

To manually change the position computed by the FMGC (FM position and bias), the pilot uses "UPDATE AT" on the progress page.

Use this facility with extreme caution: It is apt to be inaccurate, because it relies on the pilot's estimation of when a designated position has been reached.



WRITE the ident for the NAVAID (or waypoint or airport), or the coordinates, or the PBD or PBX (Place/Bearing-Place/Bearing) at which the update is intended.

PRESS [3L] to enter the ident in the "UPDATE AT" field. The coordinates of the point, along with its identifier (or "ENTRY", if the identifier is not in the database), appear in that field.

PRESS [3R] to activate the update, when you estimate that you are at the position.

*Note:* The system reinitializes the Estimated Position Error computation when a position update is performed. This may lead to the appearance of a "NAV ACCUR DOWNGRAD" or "NAV ACCUR UPGRAD" message.

If the "UPDATE AT" does not properly take effect, it corrupts the FM position.

- In an area with good radio NAVAID coverage:
  - If the update error is small, subsequent radio position updating will correct the FM position.
  - If the update error is large, the system will reject any radio updating because its internal "reasonableness test" will reject the various NAVAID s. Thus, the FM position will only be the MIX IRS position corrected by the position bias, determined at the time of the update, and the error will be maintained.
- In an area without proper NAVAID coverage, radio position updating will not be available and the FM position, if incorrect, will remain incorrect until a new manual update is performed.
- Therefore, the pilot should only use "UPDATE AT" in case of a major position problem, such as:
  - On the ground, no flight plan appears on the navigation display and ARC/ROSE NAV mode is selected.
  - A "CHECK IRS /FM POSITION" message appears on the MCDU.
  - A "FM /IR POSITION DISAGREE" message appears on the ECAM.

When GPS PRIMARY is operative, the FM position will always converge towards the GPS position at a rate depending on the aircraft altitude. Therefore, when GPS PRIMARY is operative, an inaccurate "update at" will have a temporary effect on the FM position.

**General**

**GENERAL**


Ident.: DSC-22\_20-30-20-05-00010939.0001001 / 01 OCT 12

Applicable to: ALL

The vertical flight plan is divided into the following flight phases:

Preflight - Takeoff - Climb - Cruise - Descent - Approach - Go-Around - Done.

All but "Preflight" and "Done" phases are associated with speed and altitude profiles.



Each phase has an assigned profile of target speeds. For each phase the FMGS computes an optimum (ECON) speed as a function of the strategic parameters (CI, CRZ FL, ZFW, ZFWCG, block FUEL) and performance criteria.

ECON speed is the basis of the managed speed profile.

The ECON speed can be modified by:

- Presetting a speed or Mach number on the MCDU (PERF page) for the next phase
- Selecting on the FCU a speed or a Mach number for the active phase
- Inserting speed constraints or speed limits on the MCDU vertical revision (VERT REV) page.

The vertical flight plan includes vertical constraints (altitude, speed, time) that may be stored in the data base or entered manually by the flight crew through vertical revision pages.

The flight crew may also define step climbs or step descents for cruise purposes. If the flight crew plans to climb to a higher flight level or descend to a lower level, they can use a vertical revision at any waypoint to insert the new level.

When all the vertical data has been defined, the FMGC computes the vertical profile and the managed speed/Mach profile from takeoff to landing.

**VERTICAL FLIGHT PLANNING**

Ident.: DSC-22\_20-30-20-05-00011065.0002001 / 17 AUG 10

Applicable to: ALL

**DATA ENTRY**

The vertical flight plan provides the FMGS with all the data required to calculate performance and predictions. This data is either entered by the flight crew or calculated by the FMS.



There are three categories of data:

- Strategic data, that applies to the overall flight profile:
  - Cost Index (CI)
  - Cruise Flight Level (CRZ FL) and STEP ALTS if any
  - Zero-Fuel Weight (ZFW)
  - Zero-Fuel Weight Center of Gravity (ZFWCG)
  - Block Fuel.
- Weather data:
  - Winds (for climb, cruise, descent, approach)
  - Sea level atmospheric pressure (QNH) at destination
  - Surface temperature (TEMP) at destination
  - Temperature in cruise phase
  - The Tropopause altitude (TROPO).
- Tactical data for the flight phases:
  - Phase switching conditions:
    - Setting of the thrust levers to TOGA or FLEX positions
    - Reaching acceleration altitude (ACCEL ALT)
    - Entering cruise (T/C)
    - Initiation of descent (T/D)
    - Passing a deceleration pseudo waypoint (DECEL PSEUDO WPT)
    - Touchdown.
  - Speed profile:
    - V2
    - Economy climb speed or Mach (ECON CLB SPD/MACH)
    - Preselected speed or Mach (SPD/MACH PRESELECTION)
    - Economy cruise Mach (ECON CRZ MACH)
    - Constant Mach
    - Economy descent Mach or speed (ECON DES MACH/SPD)
    - Approach speed (VAPP).
  - Vertical limitations:
    - Speed limits (SPD LIMIT)
    - Speed and altitude constraints (SPD AND ALT CSTR)
    - Time constraints or Required Time of Arrival (RTA).

In addition to the data entered by the flight crew, the FMS uses some real flight data parameters (CRZ SAT, actual wind) to improve the accuracy of the computed predictions.

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**FLIGHT PLANNING - VERTICAL FUNCTIONS**

**FLIGHT PHASES**

Ident.: DSC-22\_20-30-20-05-00011024.0007001 / 22 MAR 16

Applicable to: **ALL**

The vertical flight plan is divided into flight phases. For each phase, the FMGS computes the optimum speed or Mach Profile. These flight phases are:

Preflight - Takeoff - Climb - Cruise - Descent - Approach - Go-Around - Done.

FLIGHT PHASES	OPTIMUM SPEED PROFILE	SWITCHING CONDITIONS TO NEXT PHASE
PREFLIGHT	/	SRS takeoff mode engaged and N1 > 85 %(EPR ≥ 1.25) or Ground Speed >90 kt
TAKEOFF	V2 (V2 + 10)	At acceleration altitude or by engagement of another vertical mode.
CLIMB	ECON CLB SPD / MACH	Reaching cruise FL
CRUISE	ECON CRZ MACH	No step descent, and distance to destination < 200 NM, or all engines operative and selected altitude below Max [FL 200, highest DES ALT CSTR]
DESCENT	ECON DES MACH / SPD	- Overflying (DECEL ) pseudo waypoint with NAV (or LOC */LOC ) mode engaged and altitude <9 500 ft AGL - Manual activation of the approach phase.
APPROACH	VAPP (GS Min)	1. To Go-Around: When thrust levers at TOGA detent, or 2. To Done: 30 s after landing, or 3. To Climb: When inserting a new CRZ FL.
GO-AROUND	VAPP or current SPD, whichever is greater. Green Dot at ACC ALT	1. To Approach: Manual activation of the approach phase, or 2. To Climb: Above acceleration altitude, modification of the destination airport by: - Selection of the ALTN, or - Insertion of a NEW DEST, or - Insertion of a SEC F-PLN with a destination airport different from the destination airport of the active F-PLN.
DONE	/	To Preflight: When INIT or PERF key depressed.

*Note:* During the preflight phase, the flight crew inserts the flight plan, which includes all data needed for the flight.

During the Done phase, the FMGC erases the data entered for the flight. If the descent or the approach phase is inadvertently activated (manual approach phase activation, for example), the flight crew may reselect a CRZ FL on the PROG page to reactivate the CRZ phase.

**VERTICAL REVISION**

Ident.: DSC-22\_20-30-20-05-00011025.0002001 / 17 AUG 10

**Applicable to: ALL**

- The flight crew uses vertical revisions to enter or modify:
- The speed limit in the climb and descent phases
  - An altitude or speed constraint at the revised waypoint
  - A step climb or a step descent
  - New wind data
  - A time constraint.

The vertical revision page is accessed by pressing a right hand select key of the flight plan page.



**VERTICAL CONSTRAINTS (SPEED, ALTITUDE, TIME)**



Ident.: DSC-22\_20-30-20-05-00012689.0005001 / 18 FEB 15

**Applicable to: ALL**

The flight crew enters speed, altitude and time constraint, either to comply with ATC requests and specified procedures, or at the discretion of the flight crew, in response to operational variables.

**SPEED LIMIT**

A speed limit is associated with altitude as a maximum speed below a specified altitude (only one in climb and one in descent).



**ALTITUDE CONSTRAINT**

Altitude constraints may be attached to specific waypoints in the climb, descent, or approach phases.

To meet the altitude constraint, the aircraft must fly over the waypoint at an altitude equal, above or below the altitude constraint as specified by the flight crew or the database.

*Note: The database may contain an altitude constraint window (two altitudes between which the aircraft must fly passing over a given waypoint), but the flight crew cannot enter such a constraint manually.*

An altitude constraint is considered as missed if the system predicts more than 250 ft of difference between the constraint value and the predicted aircraft altitude.

Altitude constraints are observed in CLB or DES or APP NAV-FINAL modes.

The FMS automatically deletes from the F-PLN:

- The altitude constraints ("AT", "AT OR ABOVE", or "AT OR BELOW") with values greater than the CRZ FL
- The altitude constraint windows with the upper constraint greater than the CRZ FL.

The MCDU and the ND no longer display the deleted altitude constraints. These altitude constraints are no longer used for the computation of the FMS climb and descent profile. In that case, the scratchpad of the MCDU displays the "CSTR DEL ABOVE CRZ FL" message. The FMS does not delete the altitude constraints at the CRZ FL. The FMS computes the T/D, in order to respect these altitude constraints. However these altitude constraints are not used for guidance. If the flight crew initiates the descent before reaching the T/D, the aircraft descends below the altitude constraints, and the altitude constraints are missed (amber on the MCDU and on the ND).

### **SPEED CONSTRAINT**

Speed constraints may be attached to specific waypoints in the climb, descent or approach phases. To meet the speed constraint, the aircraft must fly over the waypoint with a speed equal or less than the speed constraint.

A speed constraint is considered as missed if the system predicts an aircraft speed 10 kt greater than the speed constraint.

Speed constraints are observed when NAV mode is engaged and speed target is managed. Otherwise speed constraints are disregarded.

### **TIME CONSTRAINT**

Time constraint may be attached to any waypoint except the "from" waypoint.

*Note:* No constraint can be associated with go-around waypoints.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

FLIGHT PLANNING - VERTICAL FUNCTIONS

Intentionally left blank

**FMS2 Honeywell**

**GENERAL**

Ident.: DSC-22\_20-30-20-25-00009323.0008001 / 14 MAY 12

Applicable to: ALL

The vertical revision function allows the pilot to modify the following parts of the flight plan:

- Speed limit
- Speed and altitude constraints
- Time constraints
- Wind
- Step climb or step descent
- Constant Mach Segment

The pilot selects these functions by pressing the right key on flight plan A or B.

The screenshot displays two screens from the FMS2 Honeywell system. The top screen, titled 'FROM', shows a flight plan segment for 'ALPHE' with various parameters. The bottom screen, titled 'VERT REV AT ALPHE', shows options for vertical revision such as speed limits, constraints, and wind.

FROM	EFOB	WIND
ADALE	15.3	246°/076
J34	BRG 104°	28 NM
01CRL	15.1	" ° / "
J34	TRK 120°	17
HASTE	14.9	" ° / "
J34		3.2
ALPHE	14.6	240°/092
J34		5.2
CRL	14.1	" ° / "
DEST	UTC	DIST
KLGA22	0058	636
		9.3
		↑↓

VERT REV AT ALPHE	
EFOB=14.6 EXTRA=0.3	
CLB SPD LIM	RTA>
250/10000	
SPD CSTR	ALT CSTR
*[ ]	[ ]*
MACH/START WPT	
*[ ]/ALPHE	
<WIND	STEP ALTS>
<RETURN	

*Note: This vertical functions section only describes the following three functions: Wind and time constraints, and Constant Mach Segment.  
For other vertical revision functions: Refer to the Systems Related Procedures section.*

## REQUIRED TIME OF ARRIVAL (RTA)

Applicable to: ALL

Ident.: DSC-22\_20-30-20-25-A-00009324.0001001 / 24 JAN 11

### GENERAL

A Required Time of Arrival (RTA) is a time requirement to be met over a specified waypoint of the lateral flight plan, including destination but excluding the origin and FROM waypoints. When the predictions are available, the time constraint value is replaced by the predicted time at the related waypoint, highlighted by a star (\*):

- If the RTA is predicted as matched, the star (\*) is in magenta.
- If the RTA is predicted as missed, the star (\*) is in amber.

No specific symbol is provided on the ND.

A time constraint is cleared in the same way as any other constraints. If a time constraint is automatically deleted. The MCDU displays an "RTA DELETED" message.

Ident.: DSC-22\_20-30-20-25-A-00000489.0008001 / 14 MAY 12

### ENTERING A REQUIRED TIME OF ARRIVAL


SELECT the F-PLN key on the MCDU.

SELECT a VERT REV at the revised waypoint.

SELECT the RTA prompt (2R).

CHECK, ENTER or MODIFY the identifier of the waypoint at which the time constraint is to be defined in the [1L] field.





WRITE the required time of arrival.

*The format is +/- HHMMSS (entry of seconds is not mandatory).*

ENTER it in the 1R field.

CHECK the 2R and 3R fields to determine whether the entered constraint can be met.

**WIND - TEMPERATURE - QNH**

Applicable to: ALL

Ident.: DSC-22\_20-30-20-25-B-00000490.0001001 / 24 JAN 11

**GENERAL**

In order to receive the best predictions, the pilot must enter wind and temperature values for the different phases and for the various waypoints of the cruise phase.

The system uses the temperature value at a given altitude, associated with the tropopause entered on the INIT A page, to optimize the temperature profile.

Ident.: DSC-22\_20-30-20-25-B-00009327.0001001 / 24 JAN 11

**ENTERING THE TRIP WIND AND TEMPERATURE DURING F-PLN INITIALIZATION**

The trip wind is a mean wind component for the entire flight from origin to destination. The pilot can enter it on the INIT B page prior to engine start. It is usually defined by the airline's flight operations on the computerized flight plan.

The FMGS does not consider the trip wind for alternate predictions.

The trip wind is used as long as no winds are entered in the CLB , CRZ , and DES WIND pages. When the pilot enters a CLB , CRZ or DES WIND, the FMGS disregards the trip wind.

PRESS the INIT key.

INSERT the temperature at cruise FL.

On the INIT B page, INSERT the TRIP WIND.

*The trip wind is defined as a headwind component (HDXX, XXHD or -XX), or as a tailwind (TLXX, XXTL or +XX).*

*The FMGS uses the trip wind to compute preliminary performance, time and fuel predictions.*

CHECK the predictions on the F-PLN B page.

Ident.: DSC-22\_20-30-20-25-B-00009328.0008001 / 01 OCT 12

**ENTERING THE WIND AND TEMPERATURE DURING F-PLN INITIALIZATION**

When completing the INIT A page, and once the wind and cruise FL temperature forecasts are available, the pilot may enter them, if significantly different, by pressing the wind prompt.

The pilot will access the different wind pages by using the NEXT PHASE and PREV PHASE prompts. He will slew the CRZ WIND page to access the various cruise wind waypoints.


The pilot will enter wind data as follows:

- For climb phase: By inserting either the HISTORY WIND data (as recorded during the last descent), or by inserting winds (at up to 5 altitudes) on the CLIMB WIND page.
- For cruise phase: By inserting winds (at up to 4 FL ) at various CRZ waypoints on the CRZ WIND pages. The 4 levels are the same for all the cruise waypoints. The pilot may enter the temperature of each waypoint and at destination on this page.
- For descent phase: By inserting winds (at up to 5 FL /altitudes) on the DES WIND page.
- For the ALTN F-PLN , an average wind may be entered on the DES WIND page for alternate cruise flight level.

*Note: Wind can be automatically received (and inserted) through the ACARS system (Refer to DSC-22\_20-70 Wind Data - Request for Wind Data).*

Once a CLIMB, CRZ, or DESCENT WIND is entered, the system ignores the TRIP WIND.

Once temperature and winds are inserted, the FMGS computes the ISA profile, and the F-PLN B page displays the forecast wind profile (by linear interpolation and propagation).



## WIND ENTRY RULES

When a wind entry is performed from an empty field, direction/velocity/altitude (or flight level) must be entered simultaneously. One entry in each bracket.

Overwriting a wind cancels the previous one.

Entered wind data can be cleared: The field reverts to brackets.

Propagated wind cannot be cleared.

Entering a new altitude, over an existing altitude, replaces that existing altitude at all cruise waypoints. Any winds entered at the overwritten altitude are lost at all cruise waypoints.

## ENTERING THE HISTORY WIND (F-PLN INITIALIZATION)

The pilot may insert the history wind, but cannot modify this page.

If convenient, PRESS the (6R) prompt to insert. After insertion, the [6R] prompt is suppressed, but the page still displays the wind values for information.

**ENTERING THE CLIMB WIND (F-PLN INITIALIZATION)**

If history winds are not convenient:

SELECT CLIMB WIND page from INIT A page or VERT REV page.

WRITE new winds into the scratchpad and ENTER.



Winds entered on the CLIMB, CRZ, and DESCENT WIND pages are always true north referenced.

Tower wind, entered on PERF APPR page is magnetic-referenced.


The pilot can enter “GRND” in the altitude field for wind at destination.

CLIMB WIND cannot be modified when the climb phase is active.

At climb phase transition, wind data switches from blue to green, and any attempted modification will trigger the “NOT ALLOWED” message.

The system extrapolates the highest wind entry to all higher levels.

The system interpolates winds between 2 entered levels.



Ident.: DSC-22\_20-30-20-25-B-00009329.0001001 / 14 MAY 12

### ENTERING THE CRUISE WINDS AND TEMPERATURES

At flight plan initialization, the CRZ WIND page displays all cruise waypoints with empty brackets. In flight, only downpath waypoints are displayed.

SELECT VERT REV at WPT.

PRESS the WIND prompt.


SELECT NEXT PHASE.

SLEW until relevant waypoint is displayed.

WRITE and ENTER the new temperature into the scratchpad.

WRITE and ENTER the new wind data into the scratchpad.

*WIND and temperature may be entered through the ACARS pages. (Refer to DSC-22\_20-70 Wind Data - Procedure to Insert Wind Data).*



The crew will modify the entered winds and temperatures in flight, if a significant difference is expected (greater than 30 kt or 30 ° for the wind data and greater than 5 °C for the temperature). The system propagates the pilot's (or ACARS) wind and temperature entries downpath, until a waypoint for which a different temperature or wind has been entered (for the same flight level), or until the last cruise waypoint.

The forecast winds at a waypoint are determined as follows:


- If the predicted altitude at the waypoint matches an altitude defined in the CRZ WIND page, the forecast wind, is the corresponding entered or propagated wind, displayed at that waypoint on the CRZ WIND page.
- If the predicted altitude lies between two altitudes entered on the CRZ WIND page, the wind direction and velocity are linearly interpolated.
- If the predicted altitude is above or below the set of cruise altitudes, the forecast wind is a constant value extrapolated from the entered or propagated wind at the highest (or lowest) altitude displayed on the CRZ WIND page for that point.

Once in flight, the FMGS considers the actual measured wind up to 200 NM ahead of the aircraft to permanently update the wind profile. This updated wind profile is used to compute the predictions and the performance data, but is not displayed to the crew.

The CRZ WIND pages display the propagated values in small blue font, and the pilot (or ACARS) entries in large blue font.

*Note:* The CRZ WIND page displays ACARS or crew-entered or propagated data. It never displays computed data (F-PLN B page only).

*Example:*



Ident.: DSC-22\_20-30-20-25-B-00009330.0001001 / 24 JAN 11

**EFFECT OF WIND ENTRIES ON OPTIMUM FLIGHT LEVEL**

The OPT FL computation considers the wind entries made at different altitudes (normally at the different CRZ FL).

When flying the subsequent CRZ FL, the OPT FL proposed by the PROG page may be affected by the wind entries made at the previous CRZ FL; these winds are automatically propagated and may be significantly different from the actual winds.

We recommend the following procedure: If the propagated winds at the lower altitudes are significantly different from the actual winds, enter the wind at these altitudes, or if not available, the wind measured at the current CRZ FL.



Ident.: DSC-22\_20-30-20-25-B-00009331.0016001 / 14 MAY 12

**ENTERING THE DESCENT WINDS**


The pilot will enter as many as one wind at 5 different FL or altitudes. This wind data will be used for descent profile and prediction computation.

From the vertical revision page, or from the CRZ WIND page:

PRESS the WIND prompt.

SELECT the DESCENT WIND page.


ENTER up to 5 different “wind/altitude”.



A wind is written as true direction/velocity/flight level or altitude in feet.

If the crew enters “GRND” in the altitude field, the system uses the associated wind as wind at destination.

The descent profile is corrected, as well as the tower wind entered in the PERF APPR page.



When the winds have been entered, the F-PLN B page displays the forecasted wind profile at all descent waypoints, using values it has interpolated from manual entries. Descent winds are not modifiable when the descent, approach, or go-around phase is active. At descent phase transition, wind data switches from blue to green, and any attempted modification will trigger the “NOT ALLOWED” message.

Ident.: DSC-22\_20-30-20-25-B-00009332.0001001 / 24 JAN 11

### ENTERING THE ALTERNATE WIND

Alternate wind is entered on the DESCENT WIND page.

The alternate cruise (ALTN CRZ) level defaults to:

- FL 220 if the length of the ALTN F-PLN is less than 200 NM.
- FL 310 if the length of the ALTN F-PLN is greater than 200 NM.

If an alternate wind is not defined, the predictions are computed with a wind defaulted to zero. Alternate wind can be modified at any time.

The alternate wind profile is as follows:

- ALTN CLB wind : Mean wind between ALTN CRZ wind (as entered on the DESCENT WIND page), and the wind at primary DEST (as entered on the PERF APPR page).
- ALTN CRZ wind : If no ALTN WIND has been entered on the DESCENT WIND page, the WIND at primary DEST (as entered on the PERF APPR page) is considered.  
 In case no entry is made, zero wind is assumed.
- ALTN DES wind : Mean wind between ALTN CRZ WIND and wind at FL 100.  
 Wind at FL 100 = Interpolation between wind at ALTN CRZ FL and zero at ALTN DEST.

Ident.: DSC-22\_20-30-20-25-B-00009333.0016001 / 14 MAY 12

**ENTERING THE APPROACH WIND TEMPERATURE AND QNH**

The wind at destination is entered in the 3L field of the PERF APPR page. It is copied in true reference into the DESCENT WIND page at ground level (GRND ), and F-PLN B page at destination. A ground entry on the DESCENT WIND page is, in the same way, automatically copied to F-PLN B page and the PERF APPR page. This wind is modifiable in descent, approach, and go-around phases.



- SELECT the PERF key on the MCDU.
- PRESS NEXT PHASE (6R).
- WRITE QNH and temperature, and enter them.
- WRITE the surface wind in the scratchpad, and enter it.

*Note:* At each wind entry, the descent profile is recomputed. Therefore, it is recommended to enter all winds, temperature, and QNH at the same time in order to minimize recomputation time.

**CONSTANT MACH SEGMENT**

Applicable to: ALL

Ident.: DSC-22\_20-30-20-25-C-00009334.0001001 / 14 MAY 12

**GENERAL**

The pilot can enter the start and end points of a constant Mach segment, and its associated Mach number, from the VERT REV page.

Only one constant Mach segment may be defined in the active flight plan, and only one in the secondary flight plan. No constant Mach segment can be defined in the alternate flight plan.

Ident.: DSC-22\_20-30-20-25-C-00000491.0008001 / 01 OCT 12

**ENTERING A CONSTANT MACH SEGMENT**

SELECT the F-PLN key on the MCDU.

SELECT VERT REV at a waypoint.

*(Except the destination and alternate flight plan waypoint).*


WRITE the Mach/start waypoint pair.

*It is possible to enter only the Mach or the waypoint. But, for the first entry, a Mach entry is mandatory.*

*The waypoint must be located in front of the aircraft and must be part of the cruise.*

ENTER it in the 4L field

*The END WPT prompt appears in the 4R field.*



WRITE the end waypoint.

*The end waypoint must be part of the cruise.*

ENTER it in the 4R field.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

FLIGHT PLANNING - VERTICAL FUNCTIONS

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT MANAGEMENT</b>  PERFORMANCE - OPTIMIZATION
---	---

<b>GENERAL</b>
----------------

Ident.: DSC-22\_20-40-10-00011077.0001001 / 17 AUG 10

**Applicable to: ALL**

The performance function:

- Optimizes a flight plan
- Computes predictions.

<b>OPTIMIZATION</b>
---------------------

Ident.: DSC-22\_20-40-10-00011084.0029001 / 23 JUN 15

**Applicable to: ALL**

The FMGC minimizes cost by optimizing the following items:

- Takeoff, approach, and go-around speeds (F , S , Green Dot, VAPP)
- Target speed for CLB , CRZ and DES phases (ECON SPD/MACH)
- Flight Level (for flight crew's information)
- Descent profile from CRZ FL down to the destination airport.

These items depend on the data the flight crew inserts during lateral and vertical flight planning and revision procedures.

Most are displayed on the PERF pages associated with the appropriate flight phases.

### **WIND PROFILE**

To obtain the best predictions, the flight crew must enter the wind for the various flight phases and specifically for waypoints in cruise.

#### **■ ON GROUND:**

During flight planning initialization, enter the winds for the climb and cruise phases using the HISTORY WIND and WIND pages. Enter, manually or with ACARS , different wind values in the climb and cruise phases. The system will compute a wind for all waypoints of the F-PLN using linear interpolation between manual/ACARS entries.

The wind profile will be displayed on the F-PLN B page, and is called forecast wind profile. Flight crew or ACARS entries are displayed in large font, and system-computed winds in small font.

#### **■ IN FLIGHT:**

The system updates the predictions and the current ECON speed, using the measured wind at the present position. It combines actual wind and forecast winds to compute the wind ahead of the aircraft, but this is totally transparent to the flight crew.

During cruise, the flight crew will enter the descent winds and the approach wind. The system will update the final predictions, compute the optimum descent profile and compute the optimum speed in descent and approach.

The forecast wind profile will be used to compute fuel and time predictions, as well as ECON speed/Mach targets.

**OPTIMUM TAKEOFF, APPROACH AND GO-AROUND SPEEDS**

The FMGC computes takeoff speeds (F , S, Green Dot) during the preflight and takeoff phases, using the performance model in the database and the takeoff weight.

The flight crew has to insert V1 , VR , and V2 in the PERF TO page manually.

The FMGC uses the performance model and either the predicted landing weight or the current gross weight at transition to the approach phase to compute approach speeds (VLS , VAPP , F , S, Green Dot).

On the PERF APPR page, the selected LDG CONF determines the applicable VLS and VAPP , the latter being updated by the WIND correction that the flight crew enters on the same page. The FMGC uses the performance model and gross weight to compute go-around speeds (F , S, Green Dot).



**OPTIMUM TARGET SPEED FOR CLIMB, CRUISE AND DESCENT (ECON SPD/MACH)**

The FMGS computes the optimum target speed (ECON SPD/MACH) as a function of:

- Cost index (CI)
- Cruise flight level (CRZ FL)
- Gross weight (GW)
- Wind and temperature models
- Performance factor.

The computer processes the ECON SPDs for the climb and descent phases before the initiation of the flight phase, and freezes the values once the flight phase becomes active.

When there is no time or speed constraint/limit, ECON SPEED is the optimum speed for the selected cost index. It refers to fuel and time cost and not directly to fuel saving.

The FM calculates ECON CLB , ECON DES and the associated top of climb and top of descent as a function of cost index, cruise FL, and meteo data.



The computer continually updates ECON CRUISE MACH (SPD), taking into account current weather conditions and modifications to the flight plan.

*Note: If the cruise FL is below FL 250, ECON CRUISE SPEED is computed.  
 If the cruise FL is above FL 250, ECON CRUISE MACH is computed.*

**PERF CLB PAGE**

1L	CLB				1R
2L	ACT MODE	UTC	DEST	EFOB	2R
3L	ECON	0051		8.5	3R
4L	CI				4R
5L	120		PRED TO	FL370	5R
6L	ECON		UTC	DIST	6R
	250	2320		111	
	EXPEDITE 2312 7.2				
	ACTIVATE		NEXT		
	←APPR PHASE		PHASE→		


**PERF CRZ PAGE**

1L	CRZ				1R
2L	ACT MODE	UTC	DEST	EFOB	2R
3L	MANAGED	1220		8.4	3R
4L	CI				4R
5L	40		TO (T/D)		5R
6L	MANAGED	UTC		DIST	6R
	.80	1213		131	
	MACH	DES	CABIN RATE		
	*.81		-350 FT/MN		
	STEP ALTS>				
	ACTIVATE		NEXT		
	←APPR PHASE		PHASE→		

ECON CRZ MACH

**PRESET TARGET SPEED FOR CLB PHASE**

The flight crew can preselect the climb speed before the CLB phase begins, by inserting a speed in the PRESEL field:




The active mode field changes from MANAGED to SELECTED, and the FM will use the entered speed for climb predictions computation.

The flight crew can revert to managed mode by pressing the 3L key.

### PRESET TARGET SPEED/MACH FOR DES PHASE


The flight crew can change the speed and/or Mach displayed in the MANAGED field by inserting a speed and/or Mach in the MANAGED field.

Although the entered speed is chosen by the flight crew, the FMGS uses it to compute the descent flight path and top of descent. It is therefore part of the managed descent profile.



The flight crew can revert to the optimum speed/Mach by clearing the 3L field.

**OPTIMUM FLIGHT LEVEL**




The optimum flight level (OPT FL) indicates the most economic flight level for a given cost index, weight, weather data. It is continuously updated in flight. It requires a 5 min minimum cruise time, at a minimum cruise flight level of FL 100.

The OPT FL is a compromise between fuel and time saving. As a result, the flight crew may observe jumps in OPT FL due to GW, ISA, or wind changes. The computation of the OPT FL considers the wind entries made at the different altitudes (normally at the different CRZ FL). When flying the subsequent CRZ FL, the OPT FL proposed by the PROG page may be affected by the wind entries made at the previous CRZ FL; these winds are automatically propagated and may be significantly different from the actual winds.

*Note: For simplification purposes, the FCOM /QRH gives the OPT FL at a given Mach number. It does not consider the cost index, therefore the FMGS and the FCOM /QRH values are different.*

FM displays OPT FL on the PROG page. The PROG page displays dashes for this quantity when the system detects an engine-out condition.



**OPTIMUM DESCENT PATH**

The vertical flight path is computed to minimize fuel consumption, while satisfying the various altitude constraints of the F-PLN and the descent speed profile, in order to reach VAPP at 1 000 ft.

The computer calculates the descent profile before the descent phase is initiated, taking into account:

- All lateral and vertical flight plan data
- The descent and approach winds, as inserted into the DESCENT WIND page and PERF APPR page, and the required maximum cabin rate of descent.

During descent, the descent profile is updated only if the flight plan is modified, or if data for the APPR phase (WIND, VAPP , or LDG CONF) are changed.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**  
PERFORMANCE - OPTIMIZATION

Intentionally left blank

**COST INDEX (CI)**

Ident.: DSC-22\_20-40-20-00011041.0001001 / 17 AUG 10

**Applicable to: ALL**

The cost index is a fundamental input for the ECON SPEED or ECON MACH computation. ECON SPEED and ECON MACH reduce the total flight cost in terms of flight time and fuel consumption (and not only in terms of fuel saving).

CI is the ratio of flight time cost (CT) to fuel cost (CF).

$CI = CT / CF$  (kg/min or 100 lb/h).

CI = 0 corresponds to minimum fuel consumption (Max Range).

CI = 999 corresponds to minimum time.

CI = Long Range Cruise (Refer to PRO-NOR-SRP-01-50 Preparation for Descent and Approach - Cost Index for Long-Range Cruise).

Note: The airline's operations department usually defines the cost index, to optimize each company route. The flight crew does not ordinarily modify the cost index during a flight.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

PERFORMANCE - COST INDEX

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>PERFORMANCE - PREDICTIONS</p>
---	---

**GENERAL**

Ident.: DSC-22\_20-40-30-00011080.0002001 / 17 AUG 10  
**Applicable to: ALL**

The FMGC computes predictions for the primary and secondary flight plans and displays them on the Multipurpose Control and Display Units (MCDU s), and on the navigation display (ND ) of the Electronic Flight Instrument System (EFIS).

The computations use the current state of the aircraft (GW , CG, position, altitude, speed, engaged mode of the autopilot or flight director, time, wind, temperature) for the active flight plan.

The computations use data entered by the flight crew for the secondary flight plan when it is not a copy of the active flight plan. When the secondary flight plan is a copy of the active flight plan, it uses the same data.

**PREDICTIONS FOR THE PRIMARY FLIGHT PLAN**

Ident.: DSC-22\_20-40-30-00011085.0001001 / 17 AUG 10  
**Applicable to: ALL**

The predictions displayed on the MCDU assume that the FMGS will guide the aircraft along the replanned lateral and vertical flight plans.

The predictions displayed on the ND assume that the aircraft will continue to operate in the modes (selected or managed) that are currently active.

As long as the aircraft is flying the flight plan under managed guidance, the predictions on the MCDU will match those on the ND.

If the flight crew does not fly the flight plan, the MCDU predictions assume that:

- The flight crew will fly back towards the flight-planned route
- The flight crew will immediately resume flying the FMGC managed modes.

If the flight crew does not fly the managed speed profile, the MCDU predictions assume that they will maintain the selected speed until they reach:

- In the climb or descent phase, the next speed limit or speed constraint if any, or next phase
- In cruise, the top of descent.

Then, the predictions assume that the flight crew will revert to managed speed.

**COMPUTATION OF PREDICTIONS**

Ident.: DSC-22\_20-40-30-00011086.0001001 / 17 AUG 10  
**Applicable to: ALL**

The system calculates various predictions for the active flight plan and updates them continually during flight as functions of:

- Revisions to the lateral and vertical flight plans
- Cost index

- Current winds and temperature
- Present position versus lateral and vertical flight plans
- Current guidance modes
- Speed control (managed/selected).

The MCDU and the ND show these predictions, each of which is based on specific assumptions.







*Note:* During computation, prediction fields on the MCDU pages display dashes.

**PREDICTIONS DISPLAYED ON THE NAVIGATION DISPLAY**


Ident.: DSC-22\_20-40-30-00011090.0002001 / 17 AUG 10

Applicable to: ALL





These predictions consist of symbols positioned along the lateral flight plan (NAV mode engaged) or the track line (NAV mode not engaged). These symbols (named as pseudo waypoints) and their meanings are:

Pseudo waypoint	Definition
	Level symbol at the position (top of climb or level-off) where the aircraft will reach: <ul style="list-style-type: none"> <li>- The FCU selected altitude (blue) or</li> <li>- The constrained altitude, if it is more restrictive than the FCU altitude and if appropriate modes are engaged (magenta).</li> </ul>
	Top of descent or continue descent symbol: <ul style="list-style-type: none"> <li>- Top of descent (always white)</li> <li>- Continue descent symbol (white if DES is not armed, blue if it is).</li> </ul>
	Start of CLIMB symbol: <ul style="list-style-type: none"> <li>- White if CLB is not armed</li> <li>- Blue if CLB is armed.</li> </ul>
	Intercept point symbol: The point where the aircraft is predicted to intercept the descent path, if there is any vertical deviation when the aircraft is in DES mode (white if DES is not engaged, blue if it is).
	Speed change symbol: The point at which the aircraft will initiate an automatic ACCEL or DECEL from current speed to a new computed speed if it encounters a SPD LIM , SPD CSTR , or HOLDING SPD (magenta).
	Decelerate point symbol: <ul style="list-style-type: none"> <li>- Indicates the point at which the aircraft is predicted to decelerate for approach (and thus switch to the approach phase)</li> <li>- Magenta, if in managed speed and NAV or approach mode is engaged</li> <li>- White, if in selected speed or HDG /TRK mode</li> <li>- Automatic deceleration only occurs when displayed in magenta.</li> </ul>


*Continued on the following page*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>PERFORMANCE - PREDICTIONS</p>
---	---

*Continued from the previous page*

Pseudo waypoint	Definition
	ALT CSTR symbol set around the constrained waypoint: <ul style="list-style-type: none"> <li>- Magenta, when the ALT CSTR is predicted to be met</li> <li>- Amber, when the ALT CSTR is predicted to be missed</li> <li>- White, when the ALT CSTR is not taken into account by the FMGS , and the NAV mode is engaged.</li> </ul>
 (10 45)  (ETP)	Time marker and equitime point symbols appear in green to indicate where the aircraft reaches the time marker or equitime point.
	Energy circle symbol (green arc) centered on the aircraft position and oriented to the current track line. Represents the Required Distance to Land. Only displayed if the lateral guidance mode is heading or track, and the current FMS flight phase is in cruise, descent or approach, and the aircraft is within 180 NM of the destination.
Crosstrack error XX.XR or XX.XL (X is a number)	The crosstrack error displays the lateral deviation between the aircraft position and the track of the F-PLN active leg. The value is limited to 99.9 NM left or right.
INTCPT	Intercept waypoint is displayed on the ND at the point at which the present track intercepts the F-PLN.

The predicted time of arrival at the TO WPT is located in the upper right-hand corner of the ND . It assumes direct distance from the aircraft position to the TO WPT and assumes current ground speed will be constant.



As a general rule, the ND indicates what the aircraft will fly, with the current active FG modes.

For example:

- The continuous green line on the ND represents the track the aircraft is currently flying:
  - If HDG /TRK is engaged, the track line is green and the flight plan is dashed
  - If NAV mode is engaged, the green line is the flight plan.
- If the speed target is manually selected, the speed-change symbol is no longer displayed because it will not be taken into account.
- When the aircraft is not following the vertical flight plan (OP CLB , OP DES , V/S ) but the NAV mode is engaged, the system disregards any altitude constraints and puts white circles around the waypoints that have these constraints and positions level symbols accordingly.
- Pseudo waypoints are adjusted each time predictions are updated.

**PREDICTIONS DISPLAYED ON THE MCDU**


Ident.: DSC-22\_20-40-30-00011093.0001001 / 14 MAY 12

Applicable to: ALL

The predictions displayed on the MCDU assume that AP (or FD order) is controlling the aircraft and flying it along the preplanned lateral and vertical flight plan.

Therefore:

- If the aircraft is guided along the flight plan (managed guidance), the MCDU predictions correspond exactly to what the aircraft is doing
- If the aircraft is not guided along the flight plan (selected guidance), the MCDU predictions assume that it will return immediately to the flight plan, intercepting at a predetermined angle, and will then proceed under managed guidance
- If the aircraft does not fly the managed speed profile (ECON , SPD CSTR ...), the MCDU predictions assume that it will remain at the present selected speed/Mach until it reaches the next SPD CSTR or SPD LIM or enters the next flight phase.



**F-PLN A**

FROM	TIME	SPD/ALT	AF5612 →
LSGG23	0000	148/ *1365	
TOP9A	BRG228	6NM	
PAS	0003	210/ 5500	
HOLD L	TRK228	12	
7000	0006	*/ 7000	
(SPD)		0	
(LIM)	0006	210/ 7000	
TOP9A			
D136E	0007	230/ *FL90	
DEST	TIME	DIST	EFOB
LGAT33R	0220	992	8.4

**F-PLN B**

FROM	EFOB	WIND	AF5612 ←
LSGG23	15.0	060°/005	
TOP9C	BRG228	6NM	
PAS	14.7	*/ 020	
HOLD L	TRK230	12	
7000	14.6	*/ 022	
(SPD)		0	
(LIM)	*	*	
TOP9C		5	
D136E	14.5	066°/026	
DEST	TIME	DIST	EFOB
LGAT33R	0220	992	8.4

**Note:** For secondary flight plan predictions, Refer to DSC-22\_20-60-50 Secondary Flight Plan.

**TYPE OF PREDICTIONS**

Ident.: DSC-22\_20-40-30-00011113.0002001 / 18 MAR 11

**Applicable to: ALL**

	<b>MCDU PAGE</b>
Pseudo waypoints: T/C , T/D , S/C , S/D , I/P , SPD LIM , DECEL	F-PLN A and B
TIME/SPD /ALT at each WPT and pseudo-WPT	F-PLN A
ETA /DIST TO DEST along F-PLN /EFOB at destination	F-PLN A and B
EFOB /T-WIND at each WPT and pseudo-WPT	F-PLN B
Constraint symbol * at each constrained WPT (TIME/SPD /ALT)	F-PLN A and B
Altitude error in case of missed ALT constraint	VERT REV
EFOB /EXTRA FUEL at each WPT	VERT REV
TIME/EFOB at destination	FUEL PRED /PERF CLB /CRZ /DES
TIME/DIST to a selected altitude	PERF CLB or DES
Fuel prediction prior engine start	INIT B
REC MAX FL	PROG
TIME/EFOB at Alternate	FUEL PRED
XTRA FUEL for various Alternates	ALTN
VDEV vertical deviation from vertical flight path	PROG

**EXAMPLES OF MCDU PREDICTIONS**

Ident.: DSC-22\_20-40-30-00011120.0001001 / 14 MAY 12

**Applicable to: ALL**


The following MCDU pages display some of the prediction types.

- Pseudo-waypoints:  
Top of Climb (T/C ) , Top-of-Descent (T/D ) , Start of Climb (S/C ) or Start of Descent (S/D ) for Step Climb/Descent, Speed Limit (SPD LIM ) , deceleration to approach phase (DECEL)
- Time, speed, and altitude predictions:  
TIME/SPD /ALT for all waypoints and pseudo-waypoints.

		FBS001 →			
		UTC	SPD/ALT		
[1L]	TOU	1254	250 / 4240	[1R]	
	(SPD)		8 NM		
[2L]	(LIM)	1256	250 / FL100	[2R]	
	LMG3B	TRK337°	2		
[3L]	OSKAM	1257	315 / FL118	[3R]	
	LMG3B		33		
[4L]	(T/C)	1302	.79 / FL310	[4R]	
	LMG3B		86		
[5L]	LMG	1313	" / "	[5R]	
	DEST	UTC	DIST	EFOB	
[6L]	LFP007	1343	325	7.8	[6R]
	NAV ACCUR	UPGRAD	↓↑		

		FROM			
		UTC	SPD/ALT		
[1L]	OSKAM	1300	270 / FL107	[1R]	
	LMG3B	BRG359°	33 NM		
[2L]	(T/C)	1322	.79 / FL310	[2R]	
	LMG3B	TRK358°	85		
[3L]	LMG	1333	" / "	[3R]	
			0		
[4L]	(S/C)	1333	.79 / FL310	[4R]	
			5		
[5L]	(T/C)	1333	.79 / FL320	[5R]	
	DEST	UTC	DIST	EFOB	
[6L]	LFP007	1451	450	6.3	[6R]
			↓↑		



**CONSTRAINT SYMBOLS (STAR)**

Ident.: DSC-22\_20-40-30-00011150.0001001 / 14 MAY 12

Applicable to: ALL

When a time speed or an altitude constraint is part of the vertical flight plan, it appears on the F-PLN A page only at the time of insertion, or when predictions are not yet available.

Once available, the time speed and altitude predictions are displayed for all F-PLN waypoints: when a speed or an altitude constraint is at a waypoint, a star symbol appears adjacent to the speed or altitude prediction. If the star is magenta, the constraint is predicted to be matched. If the star is amber, the constraint is predicted to be missed.



F-PLN A PAGE  
DURING PREDICTION  
COMPUTATION

		NW504 →			
[1L]	EMPYR	UTC SPD/ALT	---	---	---
[2L]	NANCI	5 NM	---	---	---
[3L]	NYACK	---	---	6000	---
[4L]	HAARD	TRK 021° 38 NM	---	210 / 6000	---
[5L]	YOMAN	18 NM	---	---	---
[6L]	DEST	---	---	+	3000
	KLGA22	UTC DIST EFOB	---	208	---
		↑ ↓			

[1R] [2R] [3R] [4R] [5R] [6R]

F-PLN A PAGE  
ONCE PREDICTIONS  
AVAILABLE

		NW504 →			
[1L]	EMPYR	0528 250 / 7400	---	---	---
[2L]	NANCI	530 * / * 6000	---	---	---
[3L]	NYACK	TRK 021° 38	---	538 * 210 / * 6000	---
[4L]	(DECEL)	14	---	541 210 / 4000	---
[5L]	HAARD	4	---	542 200 / * 3300	---
[6L]	DEST	---	---	UTC DIST EFOB	---
	KLGA22	0549 208 8.9	---	---	---
		↑ ↓			

[1R] [2R] [3R] [4R] [5R] [6R]

**Note:** If an altitude constraint is predicted as missed, the system tells you what will be the error at the specific waypoint.

### VERTICAL DEVIATION

Ident.: DSC-22\_20-40-30-00011139.0001001 / 29 SEP 15

**Applicable to: ALL**

During descent, the system indicates to the flight crew the vertical deviation from the computed descent profile (PFD and MCDU) and predicts where the flight crew can rejoin it. VDEV on the PFD and PROG page, predictions on the MCDU F-PLN page, symbols on the ND, enable assessment to the vertical position versus the computed flight profile.

### OPERATION RULES CONCERNING PREDICTIONS

Ident.: DSC-22\_20-40-30-00011140.0001001 / 17 AUG 10

**Applicable to: ALL**

The flight crew must properly update the flight plan data during the flight, in order to obtain accurate and meaningful predictions.

The flight crew should rely on the ND for short-term predictions. It indicates what the aircraft will do under the currently engaged modes (selected or managed).

The flight crew should rely on the MCDU for long-term predictions, when managed guidance is active or about to be reengaged.

## **OTHER COMPUTATIONS**

Applicable to: ALL

Ident.: DSC-22\_20-40-30-A-00011141.0002001 / 17 AUG 10

### **ENGINE-OUT CASE**

The FMGS computes an engine-out target speed for each flight phase. It computes an engine-out maximum altitude at long-range cruise speed, and displays it on the PROG page.

The new speed target becomes Green Dot in climb, and EO CRZ SPD in cruise.

The system computes the flight plan predictions down to the primary destination. If the aircraft is above EO MAX ALT, the predictions are computed, assuming that a drift down descent will immediately be performed to reach EO MAX ALT.

Ident.: DSC-22\_20-40-30-A-00011142.0001001 / 17 AUG 10

### **RECOMMENDED MAXIMUM ALTITUDE (REC MAX)**

The recommended maximum altitude is the lowest of the maximum altitude that:

- The aircraft can reach with a 0.3 g buffet margin
- The aircraft can fly in level flight at MAX CRZ rating
- The aircraft can maintain a V/S of 300 ft/min at MAX CLB thrust
- The aircraft can fly at a speed higher than Green Dot and lower than VMO /MMO
- The aircraft is certified at.

The REC MAX altitude is displayed on the PROG page.


Anti-ice is not taken into account for this computation. Refer to QRH graphs if icing conditions are expected.

A maximum altitude using a 0.2 g buffet margin is also computed. It is not displayed, but the system uses it to limit CRZ ALT entry.

Ident.: DSC-22\_20-40-30-A-00011250.0001001 / 17 AUG 10

### **PREDICTIONS FOR ALTERNATES**

Predictions for alternates are displayed on the ALTERNATES page.



They are based on:

- A default cruise FL equal to 220, if the airway distance is less than 200 NM. Otherwise, it is FL 310
- Simplified wind/temperature models, based on flight crew entries:
  - ALT CRZ wind, as entered on the FUEL PRED page
  - CRZ temperature interpolated from the temperature model for the primary flight plan.
- Airway distance, or direct distance, as provided by the database (manual entry, if not in the database)
- Cost index = 0 (minimum fuel)
- Initial aircraft weight equal to landing weight at primary destination.

**Note:**


1. No step can be inserted in an alternate flight plan
2. No predictions are displayed for the selected alternate on flight plan pages. However, the flight crew can read ALTN trip fuel and time on the INIT B page before engine start, and estimated time and estimated fuel on board at alternate on the FUEL PRED page after engine start.

### RETURN-TO-TRAJECTORY ASSUMPTIONS

Ident.: DSC-22\_20-40-30-00011148.0001001 / 19 DEC 12

**Applicable to: ALL**

If the aircraft is not on the lateral flight plan, predictions assume an immediate return to the active lateral leg with a 45° convergence angle, or that it will fly directly to the "TO" waypoint, when the required convergence angle is greater than 45°.



### ENERGY CIRCLE

Ident.: DSC-22\_20-40-30-00011144.0001001 / 17 AUG 10

Applicable to: ALL

The energy circle is a green arc, centered on the aircraft's position and oriented towards the current track line. It is displayed on the ND s during descent, when HDG or TRK mode is selected. It represents the required distance to land from the aircraft's position down to airport elevation at VAPP speed, considering all speed constraints on the vertical profile.

### INTRODUCTION TO PERF AND IDLE FACTORS

Ident.: DSC-22\_20-40-30-00014856.0001001 / 31 JAN 13

Applicable to: ALL

The FMGS contains a performance database to compute the predictions and the performance data. This performance database has a model of several aircraft configurations (aircraft type/engine model) to tune the performance and the FMGS predictions. For some aircraft configurations, the model can differ from the real aircraft performance. In these cases, the FMGS has to correct the computation of the performance and the predictions. This is the aim of PERF and IDLE factors. With time, the real aircraft drag and engine performance can deviate from the nominal model. The airline Flight Operations should periodically revise the value of these factors to adapt FMGS predictions to actual aircraft performance.

Note: *The IDLE factor is not available on aircraft with FMS1 Honeywell Legacy.*

**PERF FACTOR**

Applicable to: ALL

Ident.: DSC-22\_20-40-30-B-00011145.0001001 / 30 JAN 13

**GENERAL**

The FMGS uses the PERF factor to correct the predicted fuel flow that is used for the computation of the fuel predictions.

The PERF factor modifies the predicted fuel flow, according to the following formula:

$$FF_{pred} = FF_{model} \times \left( 1 + \frac{PERF\ FACTOR}{100} \right)$$

FF pred is the FF used for prediction.

FF model is the FF from the aero-engine model.

This correction is applied throughout the entire flight, and modifies the performance predictions and the ECON speed or Mach.

For example: Entering a PERF factor of +1.5 means that Flight Operations have evaluated the aircraft fuel deviation as 1.5 %, compared to the basic performance model (0.0).

Ident.: DSC-22\_20-40-30-B-00011147.0002001 / 06 SEP 16

**PERF FACTOR VALUES**

The PERF factors to be used on FMS2, depending on engine type, are:

- For CFM 56-5B engines only:

Depending on the engine type: CFM 56–5B SAC (Single Annular Chamber) or DAC (Double Annular Chambers), or non/P (without the new LP and HP blade compressor), a positive performance factor has to be entered on the MCDU STATUS page to increase the FMGS' predicted fuel consumption and match the actual fuel burnt.

		NON/P		/P or /3	
		SAC	DAC	SAC	DAC
<b>A321-111</b>	<b>CFM56-5B1</b>	2	2	0	1
<b>A321-112</b>	<b>CFM56-5B2</b>	2	2	0	1
<b>A321-211</b>	<b>CFM56-5B3</b>	2	2	0	1
<b>A321-212</b>	<b>CFM56-5B1</b>	2	2	0	1
<b>A321-213</b>	<b>CFM56-5B2</b>	2	2	0	1
<b>A321-214</b>	<b>CFM56-5B4</b>	-	-	1	-
<b>A320-214</b>	<b>CFM56-5B4</b>	3	3	0	1
<b>A320-215</b>	<b>CFM56-5B5</b>	-	-	0	-
<b>A320-216</b>	<b>CFM56-5B6</b>	-	-	0	-
<b>A319-111</b>	<b>CFM56-5B5</b>	4.5	4.5	0	1
<b>A319-112</b>	<b>CFM56-5B6</b>	4.5	4.5	0	1
<b>A319-115</b>	<b>CFM56-5B7</b>	4.5	4.5	0	1
<b>A318-111</b>	<b>CFM56-5B8</b>	-	-	0	-
<b>A318-112</b>	<b>CFM56-5B9</b>	-	-	0	-

- For other engines:

- A318 "PW": 0.0 %
- A319/A320 "CFM" Family fitted with CFM 56-5A engines: 0.0 %
- A319/A320/A321 "IAE" Family: 0.0 %
- A320 "PW" Family: 0.0 %
- A320 "CFM LEAP" Family: 0.0 %

All these numbers assume that:

- The aircraft is brand-new
- Anti-ice is OFF
- The air conditioning is on NORMAL for "IAE" engines and on LOW for "CFM" engines
- The conservative Fuel Lower Heating Value (FLHV) is 18400 btu/lb.

When an aircraft ages, fuel consumption degradation will be measured to determine the so-called “monitored fuel factor”. This factor corresponds to the deviation of the aircraft’s actual fuel consumption from the nominal model. Generally, the FLHV that is used during fuel factor monitoring is higher than the FMS value.

In order not to penalize FMS predictions, it is necessary to correct the “monitored fuel factor”. For example, add -1 % to the “monitored fuel factor”, when an FLHV of 18590 btu/lb is used. Once this factor is established by the airline, it should be arithmetically added to the above-noted performance factor.

- Note:**
1. At delivery, *ENTER* the *PERF* factor (given in the table above) directly in the MCDU (no correction factor is needed).
  2. When replacing an FMS 1 Legacy by an FMS 2, on any given aircraft model, the performance model that is stored in the FMS 2 may be different from the one that was previously stored in the FMS1 Legacy.  
As a result, *DISREGARD* the *PERF* factor previously entered in the MCDU. *ADD* the “monitored fuel factor” (when available) to the *PERF* factor (given above), and *ENTER* the resulting factor in the MCDU.

## IDLE FACTOR

**Applicable to: ALL**

Ident.: DSC-22\_20-40-30-D-00014861.0001001 / 29 SEP 15

### GENERAL

The FMGS uses the IDLE factor to adjust the computation of the vertical profile during the descent phase (IDLE segment).

The FMGS computes the vertical profile and the predictions from the Top of Descent (T/D) to the first altitude constraint with the following assumptions:

- The aircraft has a given thrust
- The aircraft has a given speed (within the speed target range).

The IDLE Factor adjusts the value of the given thrust by an addition of a delta (DELTA) thrust to IDLE thrust. With this additional thrust, the IDLE Factor gives flexibility to maintain the aircraft on the computed vertical profile in case of external perturbations such as windy conditions (previously entered by the flight crew in WIND pages).


Depending on the IDLE factor value, the FMGS modifies the position of the T/D and computes a vertical profile in function of the given thrust (IDLE + DELTA).

Therefore, the IDLE factor has a direct impact on:


- The computation of vertical profile
- The capability of the aircraft to maintain the vertical profile.

### **IMPACT ON VERTICAL PROFILE**

- If the IDLE factor is positive, the vertical profile is less steep than with IDLE factor 0. The descent phase starts earlier.
- If the IDLE factor is negative, the descent path is steeper than with IDLE factor 0. The descent phase starts later.



The following graph provides an example (average values) of the IDLE factor's effect on descent length:



Example: An IDLE factor of -3 decreases the computed descent length by 5 NM.




Ident.: DSC-22\_20-40-30-D-00014863.0001001 / 30 JAN 13


**IMPACT ON GUIDANCE**

In DES mode, the FMGS maintains the aircraft on the vertical profile and keeps the IAS within the speed target range.

If the aircraft deviates above the profile, the IAS will increase to return to the vertical profile.



When the aircraft returns to the descent profile, the IAS will decrease to the target speed.



Ident.: DSC-22\_20-40-30-D-00014864.0001001 / 30 JAN 13

**IDLE FACTOR AT DELIVERY**

The IDLE factor to be used at delivery is 0 %.

**PROCEDURE TO MODIFY THE PERF AND IDLE FACTORS**

Ident.: DSC-22\_20-40-30-00014857.0001001 / 30 JAN 13

Applicable to: ALL

**PROCEDURE TO MODIFY THE PERF AND IDLE FACTORS (ON GROUND ONLY)**

- PRESS the MCDU DATA key and then the A/C STATUS prompt in order to access the A/C STATUS page
- For aircraft with FMS2 Honeywell or Thales:
  - ENTER the change code in the CHG CODE field.  
The default value for this code is "ARM" but it is possible to modify it on airline request. The applicable code is then coded in the Airline Modifiable Information (AMI).  
When a valid change code is entered, the IDLE and PERF factors are displayed in blue.
  - ENTER the new IDLE and PERF factors in the MCDU scratchpad separated by a "/".  
For example: "-2/+1"
  - PRESS the corresponding key to insert the new IDLE and PERF factors.  
The new IDLE and PERF factors are displayed in large blue font.

*Note: Only authorized personnel should take the responsibility to update the IDLE and PERF factor values.*

- For aircraft with FMS1 Honeywell Legacy:
  - ENTER the new PERF factor in the MCDU scratchpad.
  - PRESS the corresponding key to insert the new PERF factor.  
The new PERF factor is displayed in large blue font.

*Note: 1. Only authorized personnel should take the responsibility to update the PERF factor value.  
2. The IDLE Factor is not available on aircraft with FMS1 Honeywell Legacy.*


**FMS2 Honeywell**

**GENERAL**

Ident.: DSC-22\_20-50-10-25-00000556.0001001 / 01 OCT 12

Applicable to: ALL

The Flight Management and Guidance System (FMGS) displays information on various “pages”. When a page cannot display all of the assigned information, it cues the pilot to call up additional information. There are three types of pages, and each type has its particular way of cuing the pilot to call up additional information.



**FIRST TYPE**

When this page cannot simultaneously display all the information on the screen (more information than the six pairs of lines can hold), the pilot can scroll the page up or down.

In this case, the screen displays a  $\uparrow \downarrow$  symbol in the bottom righthand corner (F-PLN pages, secondary F-PLN page, departure/arrival pages,...).


**SECOND TYPE**

When the information is on successive pages, the pilot presses the “NEXT PAGE” key to sequentially call up these pages.

In this case, an arrow is displayed in the top righthand corner of the screen (INIT pages).

**THIRD TYPE**

When different types of information are on successive pages, the pilot calls up these pages by pressing the key adjacent to the prompts  $>$ ,  $<$  or  $*$ .




### MCDU MENU PAGE

Ident.: DSC-22\_20-50-10-25-00000557.0010001 / 14 MAY 12

Applicable to: **ALL**

This page lists the various systems which the pilot can access via the MCDU.



The flight crew selects a system by pressing the key adjacent to the name of that system.

The name of the selected system is displayed in green, all others in white.

If the MCDU cannot establish communication with the selected system, it displays "OUT".

When a system calls for the flight crew attention, the MCDU displays "REQ" next to the system's name, and the "MCDU MENU" annunciator lights up.

When the flight crew presses the key next to the name of the system requiring attention, the "MCDU MENU" annunciator light goes out.

**SELECT** Pressing the [1R] key selects the NAV B/UP function and DESELECT

**NAV B/UP** NAV B/UP appears in the [1R] field.

If the NAV B/UP is inoperative, the field is blank.

**RETURN** This field is displayed when a function is active

When the MCDU communicated with a system other than the FMGC , the flight crew should use the MCDU MENU page to revert to the FMGC system.


## INIT A PAGE

Ident.: DSC-22\_20-50-10-25-00000558.0009001 / 14 MAY 12

Applicable to: ALL

The flight crew uses the INIT A page to initialize the flight plan and align the inertial reference system.

- The flight crew accesses to this page by pressing the INIT key on the MCDU . The INIT A page can be accessed on ground or in flight.
- The flight crew may also call up this page by:
  - Pressing the “NEXT PAGE” key on the MCDU console, while on the INIT B page, or
  - Pressing the key next to “RETURN” or “INSERT” on the route selection page, or
  - Pressing the key next to “INSERT” on the wind page.
- When in the done phase, the pilot may press the INIT key to switch to the next preflight phase.



[ 1L ] CO RTE

If the flight crew enters a company route number, the screen displays all data associated with that route (8 or 10 characters, depending on the pin program).

Inserting the CO RTE into the RTE selection page also enters the CO RTE number in this field.

[ 2L ] ALTN/CO RTE  
 (blue)


This field is dashed, until a primary destination is entered in the 1R field.

If a preferred alternate is associated with the primary destination, it is displayed in this field with the company route identification. The crew may manually enter an alternate and company route.

If preferred alternate is not associated with the primary destination, NONE is displayed in this field.

When the alternate route and the primary destination do not match, the MCDU scratchpad displays “DEST /ALTN MISMATCH”.

If the primary destination is changed, this field is modified accordingly.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

- [ 3L ] FLIGHT NUMBER The flight number automatically appears in this field, if it is stored with the company route. The flight crew may modify it, or enter a new number here.
- [ 5L ] COST INDEX This is usually stored in the database along with the company route. The flight crew may modify it, or enter a new value here. It defaults to the last entered value, if a value is not stored in the database.
- [ 6L ] CRZ FL/TEMP (cruise flight level and temperature) The cruise flight level is usually stored in the database along with the company route. If not, it has to be entered manually. If no cruise flight level is entered, the system will not furnish predictions, while the aircraft is on the ground. The flight crew has to enter the temperature at cruise flight level in order to refine the predictions. Otherwise, these are computed for ISA conditions. (If no sign is entered, the system uses a plus).
- [ 1R ] FROM/TO This field allows the pilot to enter a city pair (ICAO codes for city of origin and destination). This entry automatically deletes any previously entered company route and calls up the route selection page. If one airfield of the pair is not in the database, the display changes to the NEW RWY page.
- [ 2R ] INIT REQUEST This prompt is displayed if the pilot did not enter an active flight plan or entered a flight number or a company route that is not in the aircraft database. Selecting this prompt sends the ground a request for active flight plan initialization (downlink message). When the star is not displayed, a downlink message cannot be sent. The uplink flight plan is automatically inserted in the active flight plan, prior to engine start, provided an active flight plan does not exist. After engine start, the uplink flight plan is sent to the secondary flight plan and manually inserted or rejected. (*Refer to DSC-22\_20-70 Flight Plan Initialization Through ACARS*).
- [ 3R ] IRS INIT The flight crew presses this key to access the IRS INIT page.
- [ 5R ] WIND The pilot presses this key in order to gain access to the climb wind page, unless a temporary flight plan exists. In this case, the scratchpad displays TEMPORARY F-PLN EXISTS.
- [ 6R ] TROPO The default tropopause altitude is 36 090 ft. The pilot can use this field to modify it (60 000 ft maximum).

**ROUTE SELECTION PAGE**

Ident.: DSC-22\_20-50-10-25-00000559.0001001 / 17 MAR 11

Applicable to: ALL

This page displays all the company routes, stored in the database, that are associated with the inserted city pair. They can be called up manually, or displayed automatically.

- Manually : The pilot presses the FROM/TO or ALTN key on the INIT A page when a city pair is displayed.
- Automatically : The system displays it, when the pilot enters a city pair, or defines an alternate on the INIT A page of the active or secondary flight plan.



**TITLE** Identifies for the city pair inserted on the INIT A page.  
 (The numbers in the upper righthand corner are the total number of company routes from this city pair stored in the database).

**[ 1 L ]** This field shows the name of the company route. NONE appears, if there is no company route for this city pair.

**Line 2 to Line 5** These fields display the various elements of the company route: Waypoints in large green font, and airways in small white font.

**[ 6 L ] RETURN** The pilot presses this key to return to the INIT A page.

**[ 6 R ] INSERT** The pilot presses this key to insert the displayed company route in the flight plan, and return to the INIT A page.

**Note:** *The pilot can slew the display to show the rest of the route, if one page does not show it all, or to display other company routes for this city pair.*



**IRS INIT PAGE**

Ident.: DSC-22\_20-50-10-25-00013511.0051001 / 14 MAY 12  
**Applicable to: ALL**

The flight crew uses the IRS INIT page to align the inertial reference system. The crew accesses this page, by pressing the IRS INIT key on the INIT A page.



**Line 1**  
**LAT-REFERENCE-LONG**  
 This line provides the latitude and longitude of the FM reference position. This reference is extracted from the navigation database. The flight crew can modify this reference. Only when the FM reference position matches the origin airport position, the airport identifier is displayed in green. Otherwise, there are dashes at the place of the airport identifier. Latitude and longitude of the FM reference position are displayed in blue. The flight crew can modify the latitude and longitude values using the scroll keys.

**Line 2 LAT-GPS POSITION-LONG**  
 This line displays the GPS position latitude and longitude.

**Line 3 to 5**  
 These lines display the IRS 1-2-3 alignment state, source and latitude/longitude.  
 The alignment status can be ALIGNING ON XXX, or ALIGNED ON XXX or IN ATT . XXX is the alignment source and can be GPS or CDU or REF. It is displayed in white font.

**[ 6L ] RETURN**  
 The latitude and longitude values are displayed in green.  
 This prompt enables the flight crew to return to the INIT A page.

[ 6R]

If a reference is available, field displays ALIGN ON REF → in blue which is replaced by CONFIRM ALIGN\* in amber when 6R prompt is pressed. Pressing again the 6R prompt enables the transmission of the FM reference position displayed in line 1.

**WIND PAGES**

Ident.: DSC-22\_20-50-10-25-00000560.0009001 / 17 MAR 11

Applicable to: ALL


Winds in climb, cruise, descent and approach are necessary to provide the pilot with reliable predictions and performance. Wind pages enable the pilot to enter and/or review the winds propagated by the FMGS or sent by ACARS for the various flight phases.

*Note: On WIND pages, wind direction is always true-referenced.*

**CLIMB WIND PAGE**

This page enables the pilot to enter and/or review predicted wind vectors (direction and velocity) at up to 5 different levels.

**THE CLIMB WIND PAGE IS ACCESSED FROM:**



TITLE

CLIMB WIND in large white font.

[ 1L ] to [ 5L ] TRU  
WIND/ALT

This field displays the winds, entered at various climb altitudes : In blue before climb phase activation, and in green after climb phase activation.

This field may also display history winds or uplink winds. Large blue brackets are displayed before any wind entry. Pilot-entered and uplinked winds are displayed in large font. History wind data is displayed in small font.

Upon sequencing the top of climb, the climb winds are deleted.

*Note:* Climb winds are not deleted, when the origin airport is changed.

[ 1R ] HISTORY WIND

Displayed in preflight phase only. This key calls up the history wind page. This page is not modifiable (small green font), but can be inserted into the CLIMB WIND page by using the 6R key and modified accordingly.

[ 2R ] WIND REQUEST

Pressing this key sends a request for ACARS winds. (*Refer to DSC-22\_20-70 Wind Data - Request for Wind Data*).

[ 5R ] NEXT PHASE

Pressing this key calls up the CRUISE WIND page, or the DESCENT WIND page, if no cruise waypoint exists.

### HISTORY WIND PAGE



[ 6L ] CLIMB WIND

This key reverts the display to the CLIMB WIND page.


[ 6R ] INSERT

This key inserts the history wind values into the CLIMB WIND page.

### CRZ WIND PAGE

This page displays the wind direction and velocity for each cruise waypoint.

The cruise wind page enables the definition of a temperature at a given altitude, and is accessed as follows:



- TITLE** CRZ WIND AT in large white font.
- [ 1L ] to [ 4L ] TRU WIND/ALT These fields display the entered wind at various altitudes in blue. The entered winds are propagated at the same altitude to the downpath cruise waypoints, if no other winds are entered. The propagated wind direction and velocity are displayed in small fonts. Both uplinked winds and pilot-entered winds are displayed in large blue font. Wind data is modifiable during cruise.
- [ 5L ] SAT/ALT This field allows the pilot to enter a temperature at a given flight level, or to display a propagated value. The crew must enter both temperature and altitude at the first entry. They can then independently modify the temperature, or the altitude.
- [ 2R ] WIND REQUEST Pressing this key sends a request for ACARS winds. (*Refer to DSC-22\_20-70 Wind Data - Request for Wind Data*)
- [ 4R ] PREV PHASE This prompt is displayed in Preflight, Takeoff, Climb and Done phases. Pressing this prompt calls up the CLIMB WIND page.
- [ 5R ] NEXT PHASE Pressing this prompt calls up the DES WIND page. Any new entry performed on the CRZ WIND page is immediately inserted into the corresponding flight plan. Predictions are dashed on the F-PLN pages during the recomputation time. CRZ WIND page automatically reverts to F-PLN page, if a temporary flight plan is created or the secondary flight plan is activated.

**DESCENT WIND PAGE**

This page enables the pilot to define and display the winds used for computing the descent profile.

The pilot calls it up by selecting NEXT PHASE on the CRUISE WIND page, or the WIND prompt on the VERT REV page.



[ 1L ] to [ 5L ]

This displays inserted winds or uplinked winds, in large blue fonts, prior to activating the descent phase (modifiable values), and in green after descent phase activation (not modifiable values).

An entry of “GRND” in the “ALT” field is seen as the wind at ground level. This wind is copied on the PERF APPR page (and corrected for the magnetic variation).

A clear action on one key reverts the line to blue brackets.

[ 6L ] ALTERNATE

This field is only displayed when an alternate is defined.

The pilot-entered value or uplinked value is displayed in large blue font. It is always modifiable by the pilot.

[ 2R ] WIND REQUEST\*

Pressing this key sends a request for ACARS winds. (*Refer to DSC-22\_20-70 Wind Data - Request for Wind Data*).

[ 4R ] PREV PHASE

Pressing this key calls up the CRUISE WIND page. The field is erased after the top of descent has sequenced.

*Note:* Descent winds and alternate wind are deleted, if the destination airport is changed.

## INIT B PAGE


Ident.: DSC-22\_20-50-10-25-00000561.0009001 / 14 MAY 12

Applicable to: ALL

The pilot uses this page to initialize the gross weight and center of gravity, before starting the engines.

The pilot can call it up from the INIT A page during preflight phase prior to engine start, by pressing the NEXT PAGE key on the MCDU console, as long as engines have not been started.

This page automatically reverts to the FUEL PRED page after the first engine is started. The FMGC will stop using the pilot-entered block fuel and will compute its predictions based on the FOB indicated by the FQI computer (or the FAC as a back up) from that moment on.



- [ 1L ] TAXI This is the taxi fuel, which defaults to a preset value, (usually 200 kg or 400 lb in the AMI file). The crew can change the value through this field.
- [ 2L ] TRIP/TIME (green) This field displays trip fuel and time when predictions become available. The pilot cannot modify this data.
- [ 3L ] RTE RSV/% (blue) This field displays the contingency fuel for the route and the corresponding percentage of trip fuel. It may be equal to 0.0, if such is the policy of the operator. The flight crew can either enter a fuel quantity, or a percentage.

- [ 4L ] ALTN/TIME (blue/green) Displays alternate trip fuel and time, assuming that the Cost Index = 0 and that the aircraft flies at the default cruise flight level. (*Refer to DSC-22\_20-30-10-15 Alternate Function - Review and Selection of Alternate Airport*). The flight crew can modify the alternate fuel as required. In this case, alternate time will be dashed.
- [ 5L ] FINAL/TIME (blue) Displays the final reserve fuel and time calculated at the alternate airport (or destination airport, if selected in the “airline fuel policy” section of the AMI ). Before any crew entry, the FINAL field is dashed and FINAL TIME field is defaulted to the value specified in the AMI file (typically 30 min). The flight crew may enter a final fuel or time, and the system will compute associated holding time/fuel available. The system assumes a holding pattern at 1 500 ft AGL , with the aircraft in CONF 1 at maximum endurance speed (racetrack pattern, altitude and selected airport can be modified through the “airline fuel policy” section of the AMI).
- [ 6L ] MIN DEST FOB (blue) Displays the expected minimum fuel at destination. It is equal by default to the ALTN + FINAL fuel. This field can be modified directly by the flight crew, and is also impacted by the modification of ALTN and/or FINAL fuel.  
Note: *If pilot entry of MIN DEST FOB is lower than ALTN + FINAL fuel, the message “CHECK MIN DEST FOB” is triggered on the MCDU.*
- [ 1R ] ZFW/ZFWCG (blue) Displays the Zero Fuel Weight (ZFW ) and Zero Fuel Weight CG (ZFWCG ). The flight crew must enter the ZFW /ZFWCG values (as appropriate) to obtain a speed profile and predictions.  
Note: *If the flight crew enters a ZFW value that exceeds the acceptable range (as defined in the OPC or in the performance database), the “ENTRY OUT OF RANGE” message appears and the value is rejected.*
- [ 2R ] BLOCK The block fuel in this field is a mandatory entry. When the flight crew enters a block fuel, the page title changes to INIT FUEL PREDICTION.

- [ 3R ] FUEL PLANNING (amber) Initiates an FMGC block fuel computation using current hypothesis and extra = 0. When the pilot selects this function, FUEL PLANNING becomes green, and the BLOCK field is dashed during FMGC computation. The title of the page changes to INIT FUEL PLANNING, and BLOCK CONFIRM\* replaces the FUEL PLANNING prompt, when the block fuel is computed by the FMGC. If the pilot modifies the parameters used to compute prediction before confirmation, the computation automatically restarts and FUEL PLANNING is displayed in green.
  
- [ 4R ] TOW/LW (green) Displays the computed Takeoff Weight (TOW ) and Landing Weight (LW) at the primary destination. This cannot be modified.
  
- [ 5R ] TRIP WIND (blue) This field allows the entry of a mean wind component for the trip from the origin to the destination. Upon entry of a CO RTE or FROM/TO pair, this field defaults to HD 000 in small font.  
An entry preceeded by -, H, HD is considered to be headwind, +, T, TL to be tailwind. The entered speed is displayed in large blue font.  
When the flight crew inserts a wind on the CLIMB, CRUISE or DESCENT WIND page, or on the PERF APP page, the system no longer considers the trip wind, and the corresponding field is dashed.
  
- [ 6R ] EXTRA/TIME (green) Displays the amount of extra fuel, and the resulting time available for holding over the primary destination.  
EXTRA FUEL = BLOCK – (TAXI + TRIP + RSV + MIN DEST FOB).  
The field displays its information in small font, and it cannot be modified by the flight crew.


**FUEL PREDICTION PAGE**

Ident.: DSC-22\_20-50-10-25-00000562.0009001 / 14 MAY 12

Applicable to: **ALL**

The pilot presses the FUEL PRED key on the MCDU console to display fuel prediction information at destination and alternate, as well as fuel management data after the engines are started.





[ 1L ] - [ 1R ]  
AT-UTC/TIME-EFOB  
(green)

Display time and fuel predictions to the primary destination. TIME is displayed before takeoff. UTC predictions are displayed after takeoff. If the flight crew has entered an Estimated Takeoff Time (ETT), the UTC is displayed. The EFOB at destination will turn to amber, if it becomes less than the MIN DEST FOB value.

[ 2L ] - [ 2R ]  
AT-UTC/TIME-EFOB  
(green)

These lines display time and fuel predictions to the alternate airport. (Refer to DSC-22\_20-30-10-15 Alternate Function - General).

[ 3L ] RTE RSV% (blue)

Before departure, this field displays the route reserve fuel and the corresponding percentage of trip fuel. It may be equal to 0.0, if such is the policy of the operator. The crew can either enter a fuel quantity or a percentage. After takeoff, it becomes green 0.0/0.0, and the corresponding fuel is added to the EXTRA fuel.

[ 4L ] ALTN/TIME  
(blue/green)

Displays alternate trip fuel and time, assuming that the Cost Index = 0 and that the aircraft flies at the default cruise flight level. (Refer to DSC-22\_20-30-10-15 Alternate Function - Review and Selection of Alternate Airport). The flight crew can modify the alternate fuel as required. In this case, alternate time will be dashed.

[ 5L ] FINAL/TIME (blue)	<p>Displays the final reserve fuel and time calculated at the alternate airport (or destination airport, if selected in the “airline fuel policy” section of the AMI). The flight crew may enter a final fuel or time, and the system will compute associated holding time/fuel available.</p> <p>The system assumes a holding pattern at 1 500 ft AGL , with the aircraft in CONF 1 at maximum endurance speed (racetrack pattern, altitude and selected airport can be modified through the “airline fuel policy” section of the AMI).</p>
[ 6L ] MIN DEST FOB (blue)	<p>Displays the expected Minimum Fuel at Destination. It is equal to the FINAL + ALTN fuel. The field can be modified directly by the flight crew, and is also impacted by the modification of the ALTN and/or the FINAL fuel.</p>
[ 3R ] ZFW/ZFWCG (blue)	<p>Displays the Zero Fuel Weight (ZFW ) and Zero Fuel Weight Center of Gravity (ZFWCG ) values, as entered before engine start on the INIT B page. The flight crew can re-enter or modify these values after engine start on the FUEL PRED page. If at engine start, no ZFW or ZFWCG values have been entered, amber boxes are displayed in the corresponding field. The flight crew must enter the ZFW /ZFWCG values to obtain a speed profile and predictions.</p>
[ 4R ] FOB (blue)	<p>Displays the Fuel On Board (FOB ) calculated by the FMGS and the following fuel sensors:</p> <ul style="list-style-type: none"> <li>- Fuel flow and fuel quantity sensors (/FF+FQ)</li> <li>- Fuel flow sensors only (/FF).</li> <li>- Fuel quantity sensors only (/FQ).</li> </ul> <p>The flight crew can modify the FOB value in flight, or modify the sensors used by entering “/FF ”, “/FQ” or “/FF+FQ”, as required.</p>
[ 5R ] GW/CG (green)	<p>The FMS continuously updates the GrossWeight (GW ) and Center of Gravity (CG ) during the flight. The field displays dashes, as long as the system is not calculating the Fuel On Board, or the ZFW has not been entered by the flight crew.</p> <p>The field cannot be modified.</p>
[ 6R ] EXTRA/TIME (green)	<p>Displays the amount of extra fuel, and the resulting time available for holding over the primary destination.</p> <p>EXTRA FUEL = FOB – (TAXI + TRIP + RSV + MIN DEST FOB).</p> <p>This field displays its information in small green font, and it cannot be modified by the flight crew.</p>

Note: All fields are dashed before engines are started.

**FLIGHT PLAN PAGES**

Ident.: DSC-22\_20-50-10-25-00000563.0009001 / 23 JUN 15

Applicable to: ALL

These pages display all waypoints of the active and alternate flight plans, along with associated predictions.


The pilot can make all revisions to the lateral and vertical flight plans from these pages:

He presses the left key to revise the lateral flight plan, and the right key to revise the vertical flight plan.

He presses the F-PLN key on the MCDU console to access the page A of the active flight plan.

**FLIGHT PLAN A PAGE**

Page A displays time, speed, and altitude predictions for each waypoint of the active flight plan.



TITLE

FLIGHT NUMBER (blank, if no flight number has been entered).  
 This line may display: TMPY in yellow if a temporary flight plan exists;  
 OFST in white, if a lateral offset is flown; or, OFST in yellow, if a lateral  
 offset revision is pending.

Line 1 to Line 5 WPT,  
 UTC, SPD, ALT

These lines display consecutive waypoints along with associated  
 predictions of time, speed or Mach and altitude for each.  
 TIME is displayed before takeoff, and UTC after takeoff. After the pilot  
 enters an estimated takeoff time (ETT), UTC is displayed.  
 The time and flight level display at the FROM waypoint (first line of  
 the flight plan) are values that the system memorized at waypoint  
 sequencing.

[ 1R ] SPD/ALT


The field dedicated to SPEED or MACH is blank at the FROM waypoint, except at the departure airport. (V1 associated with runway elevation, is displayed).

*Note:* When the HOLD marker is slewed, the HOLD SPD Label will overwrite the TIME/UTC title.

Line 6, DEST UTC/TIME  
 DIST, EFOB

DIST is the distance to destination along the displayed flight plan. EFOB is the estimated fuel on board at destination. The EFOB at destination will turn to amber, if it becomes less than the MIN DEST FOB value. The sixth line is permanent and is displayed in white font once predictions are available, except when a TMPY F-PLN is displayed or in some cases when an ALT CSTR is entered (“\*CLB or DES\*” prompt appears).

*Note:* The predicted altitude at a waypoint is related to the QNH below the transition altitude, and is given as a flight level above the transition altitude.



The generic flight plan page displays the FROM waypoint (last waypoint to be overflown) on the first line, and the TO waypoint (in white) on the second line. The FROM/TO flight plan leg is called the active leg.

The flight crew can use the scroll keys to review all flight plan legs down to the last point of the alternate flight plan. The AIRPORT key serves as a fast slew key. The pilot can press it to call up the next airport (DEST , ALTN, ORIGIN) to be displayed on the flight plan page.

In order to return to the beginning of the flight plan page, the pilot presses the F-PLN key on the MCDU console.

The display shows the name of the leg between two waypoints, and the distance between them on a line between the lines that identify them. During an approach, this in-between line also defines the angle of the final descent path. For example, “2-3 °” indicates that the leg is two nautical miles long, and the flight path angle is -3 °.

The display shows the bearing between FROM and TO waypoints as the bearing from the aircraft position to the TO waypoint. It shows track (TRK) between the waypoints shown in lines 2 and 3.

This is the outbound track of the next leg.

If the database contains a published missed approach procedure, or if someone has inserted one manually, the display shows it in blue after the destination runway identification. It turns green when the go-around phase becomes active.

After the last waypoint of the missed approach, the display shows the alternate flight plan in NAV mode.

When NAV mode is engaged, the flight crew can only clear or modify the TO waypoint by using the DIR key on the MCDU console.

## PREDICTIONS

The system calculates and displays predictions for all waypoints.

It uses the current wind to compute TO waypoint predictions, and uses predicted winds to compute all others.

## CONSTRAINTS

The database may define an altitude and speed constraint for each waypoint of the climb, descent, and approach phases, or the pilot may manually insert such constraints (except at origin, destination, FROM, and pseudo-waypoints).

The constraints are displayed in magenta, as long as predictions are not completed.

Once predictions are available, constraints are replaced by speed and altitude predictions, preceded by stars. If the star is in magenta, the system predicts that the aircraft will match the constraint (altitude within 250 ft, speed not more than 10 kt above the constraints). If the star is in amber, the system predicts that the aircraft will miss the constraint and the MCDU displays: "SPD ERROR AT WPT".

*Note:* SPD and ALT CSTR may either be entered on the VERT REV page or directly on the F-PLN A page, whereas TIME CSTR may only be entered from the RTA page.

## PSEUDO-WAYPOINTS

Pseudo-waypoints are geographical positions corresponding to an event in the vertical flight plan: T/C (top of climb), T/D (top of descent), SPD /LIM (speed limit), DECEL (deceleration for approach), etc. The display shows them as waypoints in parentheses.

## APPROACH DISPLAY


The flight crew cannot enter an altitude constraint at destination or Missed Approach Point (MAP).



**FLIGHT PLAN B PAGE**

This page displays fuel predictions and forecast winds at each waypoint.

The pilot calls it up by pressing the NEXT PAGE key when the FLIGHT PLAN A page is displayed.



TITLE

FLIGHT NUMBER (blank if no flight number has been entered).

Line 1 to Line 5  
WPT-EFOB-WIND

These lines display consecutive waypoints and associated fuel predictions, and the forecast wind profile.  
The direction of forecast winds is relative to true north.  
Forecast winds include winds entered by the pilot (large font) and the propagated winds at intermediate waypoints (small font).  
If the flight crew uses a trip wind, it will be displayed for each waypoint.  
If no other wind entry is made after takeoff, the FROM waypoint will display the actually recorded wind, and the waypoints downpath will still display the trip wind.

Line 6  
DEST-UTC/DIST-EFOB

Identical to F-PLN A page.

### LATERAL REVISION PAGES

Ident.: DSC-22\_20-50-10-25-00000564.0009001 / 01 OCT 12

Applicable to: **ALL**


These pages give the pilot a list of the lateral flight plan revisions, which can be used to change the flight plan beyond a selected waypoint.

The pilot calls up these pages from the flight plan pages (A or B) by pressing the left key adjacent to the selected waypoint.


Different lateral flight plan revisions are available for different waypoints.



	<div style="border: 1px solid white; padding: 5px;"> <p>LAT REV FROM LSGG              45°12.0N/007°27.2E</p> <p>&lt;DEPARTURE      FIX INFO&gt;</p> <p>LL XING/INCR/NO</p> <p>[ ]/[ ]/[ ]/[ ]</p> <p>NEXT WPT</p> <p>[ ]</p> <p>ENABLE</p> <p>←ALTN</p> <p>NEW DEST</p> <p>[ ]</p> <p>&lt;RETURN</p> </div>	
LAT REV AT THE ORIGIN		
1L		1R
2L		2R
3L		3R
4L		4R
5L		5R
6L		6R
	<div style="border: 1px solid white; padding: 5px;"> <p>LAT REV FROM LGAT              37°53.8N/023°43.7E</p> <p>ARRIVAL&gt;</p> <p>NEXT WPT</p> <p>[ ]</p> <p>ENABLE</p> <p>←ALTN</p> <p>&lt;ALTN</p> <p>&lt;RETURN</p> </div>	
LAT REV AT THE DESTINATION		
1L		1R
2L		2R
3L		3R
4L		4R
5L		5R
6L		6R




TITLE	The ident of the waypoint or airport selected for revision, along with its latitude and longitude. If the selected waypoint is the FROM waypoint, the title omits the aircraft latitude and longitude, and displays the "PPOS" (present position) instead.
[ 1L ] DEPARTURE	This prompt gives the pilot access to the departure pages, where he can select and insert runways, SID s, and TRANSs.
[ 2L ] OFFSET	This prompt gives the flight crew access to the OFFSET page.
[ 3L ] HOLD	This prompt gives access to the hold pages.
[ 4L ] ENABLE ALTN	This prompt allows the pilot to switch to the alternate flight plan at the selected revision waypoint, and use it as a new active flight plan. The system never displays this prompt at the FROM waypoint.
[ 5L ] ALTN	This prompt gives access to the alternate airport page. The system displays it only at the destination.
[ 6L ] RETURN	This prompt returns the display to the flight plan page.
[ 1R ] ARRIVAL	This prompt calls up the arrival pages, where RWY , APPR, STAR TRANS and VIA can be selected and inserted.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

- [ 1R ] FIX INFO      FIX INFO is only displayed on the lateral revision page at the origin or FROM waypoint. It gives access to the FIX INFO page.
- [ 2R ] LLLXING/INCR/NO      This prompt allows the pilot to create the latitude/longitude crossing point. The increment (INCR) ranges from 1 to 20 °, and the number of crossing points from 1 to 99. This prompt is not displayed for waypoints belonging to the descent procedure.
- [ 3R ] NEXT WPT      The pilot uses this prompt to enter the next waypoint. If this waypoint is a latitude/longitude, or is neither in the database nor in the pilot-defined elements, the display reverts to the NEW WAYPOINT PAGE.
- [ 4R ] NEW DEST      The pilot uses this prompt to enter a new destination.
- [ 5R ] AIRWAYS      The pilot uses this prompt to access the AIRWAYS page.
- [ 6R ] INSERT      This prompt is displayed when the pilot has created a temporary flight plan. It can be used to activate the temporary flight plan.

**TEMPORARY REVISION**

When the pilot selects a lateral revision, the system creates a “Temporary F-PLN ” and displays it in yellow on the MCDU , and as a dashed yellow line on the ND, enabling the pilot to review the data before inserting it. As long as the temporary flight plan is not inserted, the previous flight plan remains active and the system guides the aircraft along it.



**FIX INFO PAGE**

Ident.: DSC-22\_20-50-10-25-00000565.0009001 / 14 MAY 12


Applicable to: ALL

This page provides access to the RADIAL, CIRCLE, and ABEAM intercept functions.

The reference may be a given database fix or a pilot-defined element.

If the radial, circle or abeam intercepts the active flight plan, the intersection point can be converted to a waypoint and inserted into the flight plan.

The FIX INFO page may be accessed from the LAT REV page at the origin airport, or at FROM.



[ 1L ] REF FIX (blue) Allows entries of the REF FIX. This reference may be any database element (navaid, waypoint, NDB, airport, runway) or a pilot-defined element. Prior to entry, amber boxes are displayed.

[ 2L ] - [ 2R ] RADIAL Enables entry of a radial from the REF FIX.  
 (blue) and [ 3L ] - [ 3R ] (blue) If the radial line intersects the active flight plan, the FMGS will compute the time, the along path DTG (Distance To Go), and the altitude at the intersection point (small green font). A large blue star is then displayed to insert the intersection waypoint into the flight plan. This waypoint is not part of the pilot-stored elements. Format of the created waypoint is:

XXXNNN      XXX = First 3 letters of REF FIX ident.  
                   NNN = Value of the radial

[ 4L ] - [ 4R ] RADIUS  
 (blue)

This function enables the flight crew to enter a radius that defines a circle around the REF FIX.  
 When the circle intercepts the current flight path, the FMGS will compute the time, the along path distance and the altitude at the first intersection point, from the current aircraft position (small green front).  
 A large blue star is then displayed to insert the intersection waypoint into the flight plan. This waypoint is not part of the pilot stored element.

The waypoint is automatically labelled:

“DNNNXXX”    NNN = Value of the radius  
                   XXX = First 3 letters of the REF FIX ident.

[ 5L ] - [ 5R ] ABEAM

This function enables the pilot to create waypoints on a flight plan (primary or secondary) that are abeam a reference fix.  
 Once computed, the page displays the radial number in large green font. Time, distance and altitude predictions are displayed in small green font. Selecting the key adjacent to the star creates the waypoint and inserts it into the flight plan.  
 The waypoint is identified by AB + the REF FIX ident e.g. AB TLS.  
 Abeam waypoints are not stored in the pilot-stored waypoint database.

*Note: Four FIX INFO pages, providing the capability to define four different REF FIX elements, are available.*

**OFFSET PAGE**


Ident.: DSC-22\_20-50-10-25-00013512.0019001 / 14 MAY 12

**Applicable to: ALL**

This page allows the flight crew to insert a replanned offset into the flight plan by entering:

- A start waypoint
- An end waypoint
- An offset distance to the left or to the right
- The intercept angle value.

The flight crew calls up this page from the LATERAL REVISION page, by pressing [2L] key.



**TITLE** OFFSET in white large font. If a temporary flight plan exists, it is displayed in yellow large font.


**[ 1L ] OFFSET** This field displays the lateral offset distance, left or right, in the flight plan. The offset may be between 1 and 50 NM. Blue brackets are displayed until an offset is inserted. When the flight crew enters an offset, or modifies another element in the OFFSET page, the OFFSET field becomes yellow. One time the temporary flight plan is inserted, the field becomes blue. The flight crew can delete an inserted offset either by pressing the CLR key, by entering a zero for the amount of the offset, or by pressing OFFSET DELETE in 6L field.

**[ 2L ] START WPT** The START WPT ident for the offset is displayed in yellow if a temporary flight plan exists, in blue if already inserted, or in green when the field is not modifiable. The default START WPT shall be the waypoint where the lateral revision is performed, the first waypoint offsettable, or PPOS if the offset is currently flown.

This waypoint can also be selected from the list of waypoints in the fields 3L to 5L, or can be manually entered by the flight crew.

**[ 3L ] to [ 5L ]** Display the start waypoints available for selection. Two scrolling list are available. The active start waypoint is displayed in green in the list. Other waypoints are displayed in blue. The currently selected start waypoint does not have selection arrow associated.

**[ 6L ] RETURN ERASE** RETURN: The flight crew presses this key to return to the last displayed LAT REV page.  
 ERASE: It is displayed when a temporary flight plan has been created, and it enables the flight crew to erase the temporary flight plan.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

- [ 1R ] INTCP T ANGLE      This field displays the intercept angle. The angle may be between 10 ° and 50 °. The intercept angle in the AMI is the default value, and is shown in blue. When the flight crew enters an intercept angle, or modifies another element in the OFFSET page, the field becomes yellow. One time the temporary flight plan is inserted, the field becomes blue.
- [ 2R ] END WPT              The END WPT ident for the offset is displayed in yellow if a temporary flight plan exists, or in blue if already inserted. The default END WPT shall be the waypoint terminating the last consecutive offsettable leg from default or currently selected START WPT.  
This waypoint can also be selected from the list of waypoints in the fields 3R to 5R, or can be manually entered by the flight crew.
- [ 3R ] to [ 5R ]              Display the end waypoints available for selection. Two scrolling lists are available. The active end waypoint is displayed in green in the lists. Other waypoints are displayed in blue. The currently selected end waypoint does not have selection arrow associated.
- [ 6R ] INSERT OFFSET      INSERT: This field allows the flight crew to activate the temporary flight plan and reverts the display to the active flight plan. This field is displayed when the offset segment is completely defined on OFFSET page.  
DELETE                      OFFSET DELETE: This prompt enables the flight crew to create a temporary flight plan where the predefined offset is canceled. This field is displayed when an offset exists in the active flight plan.

*Note: If the waypoint lists in lines 3 to 5 do not fit in one page, the flight crew can scroll in an open loop, two lines by two lines. To keep the initial order of the list, two markers appear:*

- - START OF LIST -      :      This marker is displayed at the beginning of the list
- - END OF LIST -        :      This marker is displayed at the end of the list.


<b>AIRWAYS PAGE</b>
---------------------

Ident.: DSC-22\_20-50-10-25-00000566.0009001 / 14 MAY 12

**Applicable to: ALL**

This page allows the pilot to select up to five airways for stringing into the flight plan, after the revise waypoint.

The pilot calls up this page by pressing the lateral revision page [ 5R ] key.



TITLE	Revise point ident (large green font)
[ 1L ] to [ 5L ] VIA	This field displays the airways entered by the pilot.
[ 6L ] ERASE or RETURN	The flight crew presses this key to return to the lateral revision page. This field displays ERASE when a temporary flight plan is created. It enables the temporary flight plan to be erased.
[ 1R ] to [ 5R ] TO	Displays the end points of the corresponding airways entered on the [ 1L ] to [ 5L ] entries. The ending point is displayed in large blue font, if manually-entered, in blue small font if FMGC-computed.
[ 6R ] INSERT (amber)	Allows the entered VIA/TO segments to be inserted into the flight plan. The display reverts to the F-PLN page.

- Note:**
1. If the entered airway contains at least one fixed radius transition waypoint as defined in the navigation database, and the TO waypoint is defined and, the fixed radius transition waypoint is in the flight plan, then, "FIXED TURN RADIUS AWAY" is displayed between the VIA and TO fields.
  2. If the condition for display "FIXED TURN RADIUS AWAY" is satisfied for two consecutive airways lines, the second line displays (") instead of the whole message.



**DEPARTURE PAGES**

Ident.: DSC-22\_20-50-10-25-00000567.0001001 / 17 MAR 11


**Applicable to: ALL**

These pages allow the pilot to review departure procedures (RWY , SID , TRANS) and enter them into the active flight plan.

When the display shows the lateral revision page for the origin, the pilot calls them up by pressing the 1L key.


Three pages are available: RWY , and SID S and TRANS (if any).

The pilot sequentially calls up each page by selecting a data item (such as RWY ), or by pressing the NEXT PAGE key on the MCDU console.



Line 1 RWY, SID  
TRANS

This line displays the RWY, SID, and TRANS in green after they have been inserted into the active flight plan, or in yellow if selected but not yet inserted. If nothing has been selected or inserted, the line displays dashes.

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

- |                              |   |
|------------------------------|---|
| [ 2L ] to [ 5L ]<br>RWY/SIDs | <p>These fields display selectable and selected RWY s or SID s (including EOSID and NO SID option). The pilot can slew each list. Selectable RWY s and SIDs are displayed in blue with an arrow.</p> <p>Once a RWY or SID is selected, the arrow disappears.</p> <p>A RWY or SID, already inserted in the flight plan, is displayed in green.</p> <p>The display shows the length, heading, and, if available, the ILS ident and frequency for each runway.</p> |
| [ 6L ] ERASE or<br>RETURN    | <p>The pilot presses this key to erase a selected data item and revert to the previous selection.</p> <p>If the pilot erases the page, the display reverts to the active flight plan page.</p> <p>The display shows RETURN instead of ERASE, when the pilot has not created a temporary flight plan.</p>  |
| [ 2R ] to [ 5R ] TRANS       | <p>This field displays the selectable and selected enroute transitions in blue and green respectively. They are blank, if there are no transitions.</p>   |
| [ 6R ] INSERT or<br>BLANK    | <p>The pilot uses this key to insert a temporary procedure into the flight plan. The page reverts to the active flight plan page, when the insertion is completed.</p> <p>It is associated with RETURN (6L).</p>  |
| [ 6M ] EOSID                 | <p>Once a runway is inserted into the flight plan, this field displays any ENG OUT SID for that runway. If there is none, it displays NONE.</p>   |

<b>HOLD PAGES</b>
-------------------

Ident.: DSC-22\_20-50-10-25-00000568.0001001 / 01 OCT 12  
**Applicable to: ALL**

These pages allow the pilot to review and modify the holding pattern parameters at the selected revise waypoint.

The flight crew calls up these pages by pressing the HOLD key on the LAT REV page for the waypoint. The flight crew can insert database hold, holds computed by the FMS or holds that they manually define.



At first access, the HOLD page appears as follow:

**DATABASE HOLD**

If a hold is defined in the navigation database for the revised waypoint, and can be inserted, the parameters in [ 1L ], [ 2L ] and [ 3L ] appear in yellow.



**COMPUTED HOLD**

If a default hold is computed by the FMS and can be inserted, the parameters in [ 1L ], [ 2L ] and [ 3L ] appear in yellow.




A computed hold has the following default parameters:

- |                  |  |
|------------------|--|
| [ 1L ] INB CRS   | Inbound track of the F-PLN leg leading to the revised waypoint                               |
| [ 2L ] TURN      | Direction right (R) to turn in the hold  |
| [ 3L ] TIME/DIST | TIME on outbound leg is 1.5 min above 14 000 ft, 1 min below 14 000 ft.                      |
| [ 2R ]           | This field shows "REVERT TO COMPUTED" when the flight crew has modified the holding pattern. |

### **HOLD MODIFIED BY FLIGHT CREW**

If the flight plan contains a holding pattern that was defined by the pilot from an existing database or computed hold, the parameters in [ 1L ], [ 2L ] and [ 3L ] appear in blue.

If the pilot has modified holding pattern data from the database, the field next to [2R] displays "REVERT TO DATABASE" or "REVERT TO COMPUTED" to enable the pilot to revert to default parameters.



**EXAMPLE** | The pilot modifies the inbound course.




- [ 6R ] INSERT The pilot presses this key to insert the hold into the active flight plan.
- LAST EXIT UTC FUEL This field displays the time at which the aircraft must leave the holding pattern in order to meet fuel policy criteria (extra fuel = 0). The system also displays the estimated fuel on board at that time. Always displayed in thousand of kilograms or pounds.

**DIRECT TO PAGE**

Ident.: DSC-22\_20-50-10-25-00000569.0001001 / 23 JUN 15

Applicable to: ALL






Pressing the “DIR” key under the MCDU screen brings up the DIR TO page. On this page, the [ 1L ] key is the DIR TO key. The pilot presses it to modify the flight plan by creating a direct leg from the aircraft's present position to any selected waypoint. When in NAV mode, the pilot must use this key to modify the active leg or the TO waypoint. The pilot cannot call up this page when the aircraft's present position is not valid.

- [ 1L ] DIR TO                      Pressing this key selects the DIRECT TO or INTERCEPT waypoint. The pilot can identify the waypoint to be inserted by using its identifier, its latitude and longitude, place/bearing/distance, or place-bearing/place-bearing.
- Note: If the entered DIR TO is a latitude/longitude, the NEW WAYPOINT page is automatically called up.*
- If the pilot does not select the RADIAL IN (1R) or RADIAL OUT (2R) or ABEAM PTS (2L), the DIR TO function routes the aircraft from the present position to the waypoint inserted in the DIR TO field.
- Line 3 to Line 6                      These lines display the active flight plan with time/speed/distance predictions. The display may be slewed ↑ ↓ . Pressing any key activates the DIRECT TO function from the present position to the waypoint adjacent to that key.
- [ 2L ] ABEAM PTS                      The flight crew presses this key to activate the DIR TO /ABEAM function which projects the flight plan waypoints perpendicular on the DIR TO leg:


**EXAMPLE: DIR TO BEROK - ABEAM.**



[ 1R ] RADIAL IN and  
 [ 2R ] RADIAL OUT

The pilot fills in these fields to define a radial, associated to the waypoint defined in 1L. These keys respectively activate the DIR TO /INTERCEPT TO and DIR TO/INTERCEPT FROM functions. The pilot enters the radial in, or radial out, as : XXX, XXX being the radial.  
 The aircraft intercepts from its current position and tracks the selected waypoint and radial to (or from) this waypoint.

**EXAMPLE: RADIAL INBND - DIR TO BEROK - RADIAL 270 ° INBOUND**



If the DIR TO /INTCPT WPT entry is to a waypoint already in the flight plan, a default RADIAL IN is displayed in small font. However, no radial is displayed on the ND for this default radial. No default radial is provided for the RADIAL OUT field.

Selecting the INTCPT TO (RADIAL IN [ 1R ]) function:

- Activates the intercept radial INTO the WPT.
- Sets the course = radial IN + 180 °.
- Reverts the display to the F-PLN A page.

Selecting the INTCPT FROM (RADIAL OUT [ 2R ]) function:

- Activates the intercept radial FROM the WPT.
- Sets the course = radial OUT.
- Reverts the display to F-PLN A page.

For details, DSC\_22\_20\_30 Flight Planning.

*Note: It is not recommended to use the DIR TO function when the aircraft is on the ground. The use of the DIR TO function when the aircraft is on the ground may result in the loss of all departure data, that includes both of the following:*

- The takeoff speeds
- The derated level, or the flexible temperature.

**ARRIVAL PAGES**

Ident.: DSC-22\_20-50-10-25-00000570.0009001 / 14 MAY 12

Applicable to: ALL

These pages enable the pilot to review arrival procedures (approaches, VIAs, STAR s, TRANS) and enter them into the active flight plan.

The pilot calls them up from the LAT REV page for the destination by the pressing the 1R key. Three pages, APPR , STAR , and VIA, are available, along with a fourth, TRANS, if there are any transitions.

The pilot calls up each page sequentially, either by selecting a data item (such as APPR ), or by pressing the NEXT PAGE key on the MCDU console.

Line [ 1L ] - [ 1R ] [ 2R ] This line displays the APPR , VIA, STAR , and TRANS in green, if they have been inserted in the flight plan, and in yellow, as a temporary flight plan, if they have been selected but not yet inserted.  
It displays dashes or NONE, if nothing has been selected or inserted.


[ 2L ] APPR VIAS The pilot presses this key to call up transitions from the last point of the STAR to the first point of the approach.


[ 3L ] to [ 5L ] These fields list selectable and selected APPR s, STAR s, and VIAs. The flight crew can slew the pages, when necessary. Selectable APPR s, STARs, and VIAs are displayed in blue with an arrow.  
Once the pilot has selected an APPR , STAR , or VIA, the arrow disappears. After the APPR , STAR, or VIA is inserted into the flight plan, it is displayed in green.  
For each approach, the display shows runway length, heading, and the frequency and identifier of the ILS when ILS is available.  
In case there are multiple approaches for the same runway, the approach is identified with the runway plus the multiple indicator (i.e. ILS 33L-S).

[ 6L ] ERASE or RETURN The pilot presses this key to erase selected data and to revert to the previous selection. The page reverts to the LAT REV page.  
The field displays "RETURN", instead of ERASE, when the flight crew has not created a temporary flight plan.

[ 3R ] TRANS to [ 5R ] These fields display selectable and selected enroute transitions (if any). They are blue when selected, and become green when inserted into the active flight plan.

[ 6R ] INSERT The pilot presses this key to insert the temporary procedure into the active flight plan. The page reverts to the active flight plan page when this occurs.





### ALTERNATE PAGE

Ident.: DSC-22\_20-50-10-25-00000571.0001001 / 17 MAR 11

Applicable to: ALL

This page enables the pilot to review, in the NAV database, the alternate airports that are paired with the destination, and define additional alternates, if needed. (Alternate airports are linked to the

destination). The pilot calls up this page with the ALTN prompt, from the lateral revision page for the destination.



**TITLE**

The destination airport is displayed large green font.

**[ 1L ] ALTN**

This field displays the selected alternate: In green, if it is active; in yellow, if it is temporary. "NONE" is displayed, if NO ALTN option is selected, or if the destination has no alternate.

**Line 2 to line 5**

These lines display the identifications of alternates (up to 6), the extra fuel weight remaining after landing at the alternates, and the great-circle track and distances to them from the destination.

If the database contains a company route between the destination and the alternate, the distance shown is an airway distance, not a great-circle distance.

When the database defines a preferred alternate, it is displayed on Line 2 (if no scrolling has been performed).

- [ 4L ] OTHER ALTN      The pilot can enter an airport identifier in the brackets (Line 3). If that airport is not stored in the database , the NEW RUNWAY page appears for the pilot to use in defining it.  
                                  If it is stored in the database, the ROUTE SELECTION page appears, and the pilot can use it to select the best route.  
                                  The pilot may enter a distance in the DIST field of the OTHER ALTN prompt, in order to get preliminary fuel predictions. However, once he has selected the alternate airfield as a temporary alternate and then inserted it, the ALTN distance reverts either to the airway distance, if he has selected a company route, or otherwise to the direct distance to the alternate.  
                                  The pilot can use OTHER ALTN to overwrite and replace the previous OTHER ALTN.
  
- NO ALTN                      The pilot uses this key to select the NO ALTN option.
  
- [ 6L ] RETURN or              The pilot presses this key to make the display revert to the LAT REV page.  
 ERASE                        Pressing this key erases the temporary selection.
  
- [ 1R ] CO RTE                Pressing this key displays the active company route between the destination and the selected alternate.
  
- [ 6R ] INSERT                Pressing this key activates the temporary selection.

**ROUTE SELECTION PAGE FOR ALTERNATE**

Ident.: DSC-22\_20-50-10-25-00000572.0001001 / 17 MAR 11

Applicable to: ALL

This page enables the pilot to review the company route between the destination and the alternate, and to select a different route, if that seems appropriate.  
 This page comes up automatically, when the flight crew enters an ident in the OTHER ALTN field.  
 See the “Route Selection” page *Refer to DSC-22\_20-50-10-25 Route Selection Page* for a description of this page.





[ 6R ] SELECT

Pressing this key reverts the display to the alternate page. (The distance between the destination and the alternate is then the airway distance).

**VERTICAL REVISION PAGES**

Ident.: DSC-22\_20-50-10-25-00000573.0009001 / 14 MAY 12

Applicable to: ALL

These pages contain the menu of available vertical flight plan revisions that can be applied at a selected waypoint.

The pilot calls up these pages from the flight plan A or B pages by pressing the right hand key next to the selected revised waypoint.

The pilot may make several different vertical revisions (although some may not be available at all waypoints): Speed limit, speed constraint, altitude constraint, time constraint, wind page and STEP ALTS page.



<p>VERT REV AT DEST</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>1L</p> <p>2L</p> <p>3L</p> <p>4L</p> <p>5L</p> <p>6L</p> </div> <div style="width: 50%; text-align: center;"> <p>VERT REV AT KLGA                      EFOB=8.4 EXTRA=0.8</p> <p>CLB SPD LIM                      250/10000</p> <p>QNH                      [ ][ ][ ][ ]</p> <p>&lt;WIND STEP ALTS&gt;</p> <p>&lt;RETURN</p> </div> <div style="width: 45%; text-align: right;"> <p>1R</p> <p>2R</p> <p>3R</p> <p>4R</p> <p>5R</p> <p>6R</p> </div> </div>
<p>VERT REV AT WPT (Predictions not available)</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>1L</p> <p>2L</p> <p>3L</p> <p>4L</p> <p>5L</p> <p>6L</p> </div> <div style="width: 50%; text-align: center;"> <p>VERT REV AT CXR                      EFOB---- EXTRA----</p> <p>SPD CSTR ALT CSTR                      * [ ] -FL310</p> <p>MACH/START WPT                      * [ ] /CXR</p> <p>&lt;WIND STEP ALTS&gt;</p> <p>*CLB OR DES*</p> </div> <div style="width: 45%; text-align: right;"> <p>1R</p> <p>2R</p> <p>3R</p> <p>4R</p> <p>5R</p> <p>6R</p> </div> </div>
<p>VERT REV with constant MACH segment defined between N47E005 and N47W009 (both waypoints are in CRZ phase)</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>1L</p> <p>2L</p> <p>3L</p> <p>4L</p> <p>5L</p> <p>6L</p> </div> <div style="width: 50%; text-align: center;"> <p>VERT REV AT PEMAR                      EFOB=12.4 EXTRA=0.8</p> <p>SPD CSTR ALT CSTR                      * [ ] [ ] *</p> <p>MACH/START WPT END WPT                      .81/N47E005 N47W009</p> <p>&lt;WIND STEP ALTS&gt;</p> <p>&lt;RETURN</p> </div> <div style="width: 45%; text-align: right;"> <p>1R</p> <p>2R</p> <p>3R</p> <p>4R</p> <p>5R</p> <p>6R</p> </div> </div>

TITLE (white)

“VERT REV AT [location]”

The second line shows remaining fuel and extra fuel at the waypoint being revised.

[ 1L ] “TOO STEEP PATH BEYOND” (amber)

This message is displayed, if the waypoint is part of a leg with too steep a descent path.

[ 2L ] CLB/DES SPD LIM (magenta)	This field displays the speed limit applicable to the climb or descent phase. It displays it in large font when data has been inserted manually, and in small font when data comes from the database.
[ 3L ] SPD CSTR (magenta)	This field displays any speed constraint assigned to the revised waypoint. It is in large font when inserted manually, and in small font when it comes from the database. It is not displayed at the origin airport, at a FROM waypoint, a speed limit pseudo waypoint, or the destination airport.
[ 4L ] QNH	This field only functions when the revised waypoint is the primary destination. It allows the pilot to enter the atmospheric pressure at sea level. This field is identical to the QNH field of the PERF APPR page.
[ 4L ] MACH/START WPT (blue)	This prompt allows the pilot to enter or modify the start point of a constant Mach segment, and its associated Mach. It is not displayed at primary destination and alternate flight plan waypoints. ( <i>Refer to DSC-22_20-30-20-25 Constant Mach Segment - Entering a Constant Mach Segment</i> ).
[ 5L ] WIND (blue)	The pilot presses this key to access the wind pages. The first wind displayed page, corresponds to the selected waypoint (e.g. climb page), if the selected waypoint is a climb phase waypoint. A CLR action reverts it to brackets.
[ 6L ] RETURN or CLB	The pilot presses this key to return to the last displayed flight plan page. When displayed, pressing this key assigns the constraint to CLB phase and inserts it into the vertical flight plan. The page reverts to the flight plan page.
[ 2R ] RTA prompt	This prompt gives access to the RTA page. It is not displayed when the VERT REV page is accessed from the alternate F-PLN.
[ 3R ] ALT CSTR (magenta)	This field displays the altitude constraint assigned to this revised waypoint. It uses large font when the constraint is manually-entered, and small font when it is from the database. A CLR action reverts it to brackets.  The constraint may be: <ul style="list-style-type: none"> <li>- "At", entered as XXXXX (Example: FL 180).</li> <li>- "At or above", entered as + XXXXX or XXXXX + (Example: FL +310).</li> <li>- "At or below", entered as - XXXXX or XXXXX - (Example: -5 000).</li> <li>- A "window" constraint.</li> </ul> The altitude window consists of two altitudes between which the aircraft should fly. The crew cannot manually enter a "window" constraint.

- G/S INTCP (green) This field displays the glide intercept altitude for an ILS approach on the vertical revision page at destination.
- [ 4R ] ALT ERROR (green) When the aircraft misses a predicted altitude constraint, this field displays the difference between the altitude constraint and the predicted altitude. If, for example, “-500” appears in this field in green, the aircraft will reach the waypoint at an altitude 500 ft below the constraint altitude. This only applies to waypoints in the climb and descent phases.
- [4R] END WPT (blue) This prompt allows the pilot to enter or modify the endpoint of a constant Mach segment. It is displayed when a pair Mach/start exists in 4L field. This prompt is not displayed on the destination VERT REV page. (*Refer to DSC-22\_20-30-20-25 Constant Mach Segment - Entering a Constant Mach Segment*).
- [ 5R ] STEP ALTS (white) This legend appears for any waypoint, once a cruise altitude has been entered. It is not available in engine-out, descent, approach, and go-around phases. This gives the pilot access to the STEP ALTS page.
- [ 6R ] DES When this field displays “DES”, pressing this key assigns the constraints to the descent phase and inserts them into the vertical flight plan. The page reverts to the F-PLN page. (See note below).


Note: *Altitude and speed constraints may apply to the climb, descent, or approach phase, but never to the cruise phase. Fields 6L/6R display “CLB /DES” when the revised waypoint is a cruise phase waypoint and the FMGS needs to know if the new constraint is to be applied in climb or descent phase. The FMGS will modify the cruise phase accordingly. These 2 prompts also display “CLB /DES” when the predictions are not computed. (Top of climb and top of descent not yet defined).*

**STEP ALTS PAGE**

Ident.: DSC-22\_20-50-10-25-00000574.0009001 / 14 MAY 12

**Applicable to: ALL**

This page allows the pilot to insert up to four geographic step points and one optimal step point into the flight plan. This page also displays the fuel/time savings associated with the optional step. The flight crew calls it up either from the vertical revision page.



TITLE [1L] - [1R] [4L] - STEP ALTS in white followed by the current cruise altitude in green. [4R]

ALT/WPT {blue} : The waypoint identifier, as well as the altitude to step, can be entered in this field. Both are displayed in large font. The waypoint may either be an active (or secondary) flight plan waypoint, or an inserted optimal point (OPT). When an entry is made, a temporary F-PLN is created.

DIST / TIME (UTC)  
(small green font)

Displays the distance to go, and time from the present aircraft position along the flight plan to the step point.

Note: The following messages may be displayed in the DIST/TIME field:

- ABOVE MAX , if the step altitude exceeds the MAX altitude.
- "IGNORED", if the step start or end point is less than 50 NM from the top of descent or if the step climb is located prior to the top of climb or after the top of descent.
- "STEP AHEAD", when the aircraft is within 20 NM of the start step point.
- "NO OPTIMAL" if a non inserted optimal step falls in a discontinuity due to a flight plan change, or when no new optimal exists after an UPDATE or when no optimal step point exists for the entered altitude.

Note: If no optimal step point exists for the altitude displayed in [ 1L ], the "NO OPTIMAL" message is displayed in the FUEL/TIME field. This message is also displayed, if the optimal step falls into a discontinuity.

[ 5L ] OPT STEP:  
 ENTER ONLY ALT  
(white) TO OPT S/C  
(green small front)

This field displays the distance and time to an uninserted optimal step point, if one exists. It is displayed to guide the flight crew for the entry format of an optional step.

Note: On any flight plan change, an inserted optimal step remains in the flight plan at a fixed distance to destination.

[ 6L ] RETURN  
 [ 5R ] SAVINGS

The flight crew presses this key to return to the previous page.

This field displays the fuel and time savings prior to the insertion of the optimal step point.

Fuel savings are displayed in thousand of kilograms (or pounds) (maxi 99.9).

The value is preceded by:

- "-" in case of fuel saving,
- "+" in case of additional fuel cost.

Time savings are displayed in hours and minutes. The value is preceded by

- "-" in case of time saving,
- "+" in case of additional time cost.

[ 6R ] INSERT\* (amber) This field displays INSERT\*, when an optimal step point exists but is not yet inserted. When INSERT is selected:

- The optimal step point is inserted into the flight plan.
- OPT is displayed in line 1L.
- Optimal step distance and time are deleted in line 5L.
- The UPDATE\* blue prompt replaces the INSERT\* prompt.

UPDATE\* This prompt enables the computation of another optimal step point. The UPDATE\* prompt is then replaced by the INSERT\* prompt.

**RTA PAGE**


Ident.: DSC-22\_20-50-10-25-00000575.0009001 / 14 MAY 12

Applicable to: ALL

The Required Time of Arrival (RTA) page allows the entry and display of a waypoint identifier, with associated time constraints. The page also displays the entered or computed Estimated Takeoff Time (ETT), as well as the following data:


- Predicted ETA at the time-constrained waypoint;
- Performance adjusted SPD target;
- Time error;
- Distance to time constrained waypoint;
- Active speed mode;

The flight crew calls up this page with the RTA prompt from the vertical revision page.



TITLE RTA (large white font)



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

line 1	<p>This line displays:</p> <ul style="list-style-type: none"> <li>- AT WPT , DIST and RTA when a time constraint can be defined. The identifier of the revised waypoint or the first following waypoint at which the time constraint can be defined, is displayed by default in large blue font</li> <li>- AT WPT , DIST and RTA when a time constraint has already been defined. The associated constrained waypoint identifier is displayed by default in large blue font</li> <li>- AT WPT and white dashes when no time constraint can be defined</li> <li>- AT WPT and blue brackets if a time constraint can only be introduced before the waypoint at which the VERT REV has been initiated.</li> </ul> <p>Only when the waypoint identifier has been defined (by the flight crew or by default), blue brackets and a blue star are displayed in [ 1R ] field.</p> <p>The flight crew enters the time constraint as "HHMMSS", preceded by:</p> <ul style="list-style-type: none"> <li>- for at or before;</li> <li>+ for at or after;</li> <li>no sign for at.</li> </ul>
[2L] MANAGED	<p>This field displays the FMGS -computed ECON speed/Mach (<i>Refer to DSC-22_20-40-10 Optimization</i>)</p>
[3L] ACT MODE	<p>This field displays the active speed mode : MANAGED or SELECTED/NNN (NNN is the selected target speed).</p> <p>The pilot cannot modify it through this field.</p>
[6L] RETURN	<p>The pilot presses this key to revert the display to the VERT REV page.</p>
[2R] ETA	<p>When a required time at arrival has been defined, the 2R field displays the estimated time of arrival as "HHMMSS".</p>
[3R] RTA ERROR	<p>This field is blank when the RTA is predicted as made.</p> <p>If the RTA is predicted as missed, "RTA ERROR" is displayed in small white font, and the time error between ETA and RTA is displayed in small amber font.</p>
[6R] ETT	<p>The Estimated Takeoff Time (ETT) field is available in the preflight phase.</p> <p>If no ETT is available, the 6R field displays blue brackets and a blue star.</p> <p>Once available, the ETT is displayed in magenta.</p>
UTC	<p>Universal time is displayed in green for takeoff, climb, cruise, descent and approach phases.</p>

**DATA INDEX PAGES**

Ident.: DSC-22\_20-50-10-25-00000576.0001001 / 17 MAR 11

Applicable to: ALL


There are two INDEX pages:

The DATA INDEX 1/2 page gives access to various pages devoted to navigation.

The DATA INDEX 2/2 page lists the navigation data, entered in the FMGS.

The pilot enters those items labeled “stored” and can modify them. The pilot can call up the others, but cannot modify them.

The pilot calls up these pages by pressing the DATA key on the MCDU console:



**DATA INDEX 1/2 PAGE**

- |                  |   |
|------------------|---|
| [1L] POSITION    | When the flight crew presses these keys, the display shows all essential navigation data. |
| [2L] MONITOR     |   |
| [2L] IRS         |   |
| [2L] MONITOR     |   |
| [3L] GPS         | This key calls up the GPS MONITOR page.   |
| [3L] MONITOR     |   |
| [4L] <A/C STATUS | This key calls up the aircraft status page.   |
| [4L] CLOSEST     |   |
| [5L] <AIRPORTS   | This key calls up the closest airports page.  |
| [5L] EQUITIME    |   |
| [6L] <POINT      | This key calls up the equitime point page.  |
| [6R] ACARS/PRINT | This key calls up the PRINT function pages and the ACARS function pages.                  |
| [6R] FUNCTION    |   |

**DATA INDEX 2/2 PAGE**

[ 1L ] WAYPOINTS

[ 2L ] NAVAIDS

[ 3L ] RUNWAYS

[ 4L ] ROUTES

[ 1R ] STORED WAYPOINTS

[ 2R ] STORED NAVAIDS

[ 3R ] STORED RUNWAYS

[ 4R ] STORED ROUTES

These keys call up descriptions of waypoints, NAVAIDs, runways, and routes stored in the database, so that they can be reviewed.


These keys call up waypoints, NAVAIDs, runways, and routes that the pilot has stored, enabling the pilot to review and store them in, or delete them from, the database.

The airline can choose to automatically have all pilot-stored data erased in the done phase.

**WAYPOINT/STORED WAYPOINT/NEW WAYPOINT PAGES**

Ident.: DSC-22\_20-50-10-25-00000577.0001001 / 01 OCT 12

Applicable to: **ALL**



**WAYPOINT PAGE**

- The pilot can call up this page by pressing the 1L key on the DATA INDEX page. The display then shows waypoint information associated with the identifier the flight crew inserts it in the [ 1L ] field.
- With this page it is possible to call any waypoint not stored in the stored waypoint list, if they belong to the active, temporary, or secondary flight plan.

**STORED WAYPOINT PAGE**

The pilot calls up this page by pressing the 1R key on the DATA INDEX page. This page displays waypoints, defined and stored by the pilot. It lists each stored waypoint, along with a number that shows the relative order in which it was inserted in the database. This number is displayed in the upper righthand corner of the page. For example, "1/20" indicates that the waypoint was the first of 20 stored.

*Note: Latitude/Longitude crossing points and Abeam/Radial Intercept points are never included in the stored waypoint list.*

- |                        |   |
|------------------------|---|
| [ 1L ] IDENT           | To delete a waypoint, the pilot clears the 1L ident display.  |
| [ 2L ] LAT/LONG        | Latitude and longitude of the waypoint are displayed in this field.   |
| [ 3L ]                 | This field either displays PLACE/BRG /DIST or PLACE-BRG/<br>PLACE-BRG or PLACE/DIST, depending on how the waypoint was defined.   |
| [ 5R ] NEW<br>WAYPOINT | The pilot presses this key to call up the NEW WAYPOINT page.  |
| [ 6R ] DELETE ALL      | The pilot presses this key and the label changes to amber CONFIRM DELETE ALL. Pressing this key a second time deletes all the waypoints, stored by the flight crew, except those currently used in the active or secondary flight plan. ("F-PLN ELEMENT RETAINED" appears on the MCDU). |


**NEW WAYPOINT PAGE**

- The pilot calls up this page by pressing the 5R key on the STORED WAYPOINT page.
- The pilot can use this page to define and store up to 20 waypoints. Entering an additional waypoint deletes the first one.  
The pilot defines a waypoint by entering its ident in the data field next to 1L, then by entering its position in the amber boxes.  
The STORE prompt appears next to 6R when the boxes are filled in, and the pilot presses the key to store the waypoint in the database.  
If the pilot enters the waypoint's position as place/bearing/distance, or place-bearing/place-bearing, the FMGC computes its latitude and longitude.

**NAVAID/STORED NAVAID/NEW NAVAID PAGES**

Ident.: DSC-22\_20-50-10-25-00000578.0001001 / 01 OCT 12


Applicable to: ALL



**NAVAID PAGE**


The pilot calls up this page by pressing the 2L key on the DATA INDEX page 2.

This page displays NAVAID information associated with the identifier the pilot inserts in the [ 1L ] field.



- [ 2L ] CLASS This field identifies the NAVAID as VOR , DME , VOR DME , VORTAC, NDB , LOC , ILS , MLS , ILS /DME , MLS /DME , ILS /TAC or TACAN. It displays NON COLLOCATED, if the NAVAID is uncollocated.
- [ 4L ] FREQ or CHAN CHAN is displayed, if the class of NAVAID is an MLS or an MLS DME.
- [ 5L ] ELV This field gives the NAVAID elevation in feet above sea level. It is not displayed for VOR or NDB.
- [ 6L ] FIG OF MERIT This field shows how far out the FMGS can autotune a VOR , VOR /DME , VORTAC, or DME for display or for computing position.
  - 0 : up to 40 NM
  - 1 : up to 70 NM
  - 2 : up to 130 NM
  - 3 : up to 250 NM




 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION</p>
---	---

- [ 1R ] STATION DEC or RWY IDENT This is the magnetic declination in the NAVAID area (used only for VOR , VOR /DME, and VORTAC).  
The field displays RWY IDENT , if the NAVAID is a LOC , ILS , MLS , ILS /DME , MLS /DME or ILS/TAC.
- [ 2R ] CATEGORY This field shows the NAVAID 's category, if it is an ILS , ILS /DME , MLS , MLS /DME or ILS /TAC. A LOC DME has a category = 0.
- [ 3R ] COURSE This is the localizer course, if the NAVAID is an ILS or a LOC.
- [ 6R ] RETURN This prompt is displayed, if the page has been accessed from the SELECTED NAVAID page. The pilot presses this key to return to the SELECTED NAVAID page.

**STORED NAVAID PAGE**

The pilot calls up this page by pressing the 2R key on the DATA INDEX page. This page is used to display or delete defined and stored NAVAIDs.




A number in the upper righthand corner of the screen shows the relative order in which the NAVAIDs were stored. (For example, 3/7 means the third out of the seven stored).

Slew keys give the pilot access to the different stored NAVAIDs.

- [ 1L ] IDENT The pilot deletes a stored NAVAID by entering its ident in this field, then by pressing the CLR key at the bottom of the MCDU control panel.
- [ 6R ] DELETE ALL and CONFIRM The pilot presses this key to erase all the stored NAVAID s, except those currently used in the active or secondary flight plan. (The MCDU displays "F-PLN ELEMENT RETAINED.").

**NEW NAVAID PAGE**

The pilot calls up this page by pressing the 5R key on the STORED NAVAID page.



It can be used to define and store up to 20 NAVAID s. Entering an additional waypoint deletes the first one. The NAVAID elements must be entered in two steps:

1. Enter the data in the lines of amber boxes.
2. Enter frequency, elevation, figure of merit, and station declination or ILS category and course, if applicable.

**Note:** *The pilot cannot create an ILS /DME or an uncollocated NAVAID. If the runway associated with the ILS has been entered through the new runway page, the course, IDENT , and runway IDENT are already displayed on the new NAVAID page when it comes up (copied from the new runway page). For details, see the new runway page info below.*


- [ 1R ] STATION DEC The pilot must enter the magnetic declination, if the prompt is displayed. This prompt is displayed only for VOR , VORTAC or VOR /DME.
- [ 3R ] COURSE If the NAVAID is an ILS , LOC, enter the course.
- [ 6R ] STORE This prompt appears when all the amber boxes are filled in. The pilot presses the key to store the NAVAID.

A stored NAVAID is never used for position computation.

**RUNWAYS/STORED RUNWAYS/NEW RUNWAY PAGES**

Ident.: DSC-22\_20-50-10-25-00000579.0001001 / 17 MAR 11

Applicable to: ALL



**RUNWAY PAGE**

This page displays the following information:

- [ 1L ] IDENT            The runway IDENT, which comprises the airport identification and the runway direction, uses six or seven digits (Example: CYYZ 24L and LFRJ 08).
- [ 2L ] LAT/LONG        The latitude and longitude of the runway threshold.
- [ 4L ] LENGTH          The runway length in meters (M) or feet (ft), in five digits (9 999 ft).
- [ 5L ] ELV              The elevation of the threshold in feet above sea level.
- [ 6L ] CRS              The runway course (degrees magnetic).
- [ 1R ] LS IDENT        The LOC or ILS identifier.

**STORED RUNWAY PAGE**

The pilot uses this page to display or delete the defined and stored runways. The stored runways are listed and numbered in the order in which they were inserted. The number is displayed in the upper righthand corner of the page. (For example, 2/4 means the runway is the second of the four stored runways).

The pilot can delete any stored runway from the database by displaying its IDENT in the 1L field, then by pressing the CLR key on the MCDU control panel.

- [ 6R ] DELETE ALL      The pilot presses this key to erase all the stored runways, except those and CONFIRM            used in the active or secondary flight plan. (The MCDU displays "F-PLN DELETE ALL              ELEMENT RETAINED").
- [ 1L ] to [ 6L ]        These fields are similar to the RUNWAY page fields.

**NEW RUNWAY PAGE**

The pilot can use this page to define and store up to 10 runways.

- **When the pilot enters an ILS /LOC IDENT in the [ 1R ] field the new NAVAID page comes up. When the pilot has entered and stored the necessary data in the new NAVAID page, the new runway page reappears.**

The new runway page and the new NAVAID page (ILS /LOC) are not independent:

- **When the flight crew first defines the ILS /LOC (on the new NAVAID page) the new runway page, when called up, already displays the RWY course, RWY IDENT , and ILS IDENT (copied from the new NAVAID page).**
- **When the flight crew first defines the runway (on the new runway page) the new NAVAID page, when called up, already displays the ILS course, ILS IDENT , and runway IDENT.**

The pilot must enter the two runway directions on two different new runway pages (Example: LFRJ 08 and LFRJ 26) to allow the flight plan to select either one.

Note: When 10 runways are stored, entering a new stored runway deletes the first one of the list (1/10).


- [ 1L ] to [ 6L ] Enter information about the new runway.
- [ 1R ] LS IDENT Enter the ILS /LOC IDENT . The NEW NAVAID page comes up.
- [ 5R ] RETURN The pilot presses this key to return to the NEW NAVAID page.
- [ 6R ] STORE This prompt only appears when all the amber boxes have been filled in.

Note: The NEW RUNWAY may be used for departure or destination, but no SID or STAR can be associated or stored with this runway. Therefore, the pilot will use it as an "independent" airport.  
A new runway is identified by the 4-letter ICAO airport identifier, although all six or seven digits must be entered.

### ROUTE/STORED ROUTE/NEW ROUTE PAGES

Ident.: DSC-22\_20-50-10-25-00000580.0001001 / 01 OCT 12

Applicable to: ALL



### ROUTE PAGES

(Not-modifiable)

[ 1L ] CO RTE

Any company route IDENT, entered in this field, causes all the elements of the route to be displayed.

Line 2 to Line 6      These lines display the various route elements, including waypoints and airways.

[ 1R ] FROM/TO      This field is automatically filled in, when the pilot enters the IDENT for a company route. When the pilot manually enters a city pair, the MCDU displays “NOT IN DATA BASE” if the city pair is not in the navigation database. If the city pair is in the database, the CO RTE field displays the first route stored (small blue font). If more than one route is stored, the pilot can slew to see the different routes.

**STORED ROUTE PAGE**



This page displays up to 5 routes, stored by the pilot. The stored routes are listed and numbered in the order of insertion. The number is displayed in the upper right-hand corner of the page.

[ 1L ] CO RTE      This field identifies the stored route. Clearing this field deletes the stored route.

Line 2 to Line 5      The fields in these lines are identical to the corresponding fields in the route page.


[ 6L ] DELETE ALL      Pressing this key changes the label to amber CONFIRM DELETE ALL. Pressing this key a second time deletes all previously-stored routes.

[ 1R ] FROM/TO      This identifies the city pair of the stored route.

[ 6R ] NEW ROUTE      Pressing this key calls up the new route page.

**NEW ROUTE PAGE**

The pilot calls up this page by pressing the NEW ROUTE key on the stored route page. It can be used to store up to five new routes that have already been defined in the active or secondary flight plan.



- [ 1L ] CO RTE      This field enables the pilot to enter a new company route IDENT . If that IDENT has already been assigned, the entry is rejected.
- [ 2L ] STORE ACTIVE F-PLN (blue)      Pressing this key stores parameters of the active flight plan as new route. The display shows this prompt when the system contains a FROM/TO, but only during preflight.
- [ 3L ] STORE SECONDARY F-PLN (blue)      Pressing this key stores parameters of the secondary flight plan as new route. The display shows this prompt when the system contains a FROM/TO and the secondary flight plan has not yet been sequenced.



- Note:
- If it has not already been named, a stored route is automatically named when stored: SRTE 1 to SRTE 5.
  - When 5 routes are already stored, the pilot cannot insert a new stored route. The “STORED ROUTE FULL” message is displayed, and the pilot must manually delete a route in order to store a new one.
  - Several flight plan elements are not retained when the route is stored:
    - Pilot-entered holds
    - Offset
    - Pilot-entered constraints
    - Modifications to terminal procedures
    - Pseudo-waypoints
    - Step at optimum.
    - Pilot-entered constant Mach segment.
 The MCDU then displays “REVISIONS NOT STORED”.

<b>AIRCRAFT STATUS PAGE</b>
-----------------------------

Ident.: DSC-22\_20-50-10-25-00000581.0001001 / 28 APR 14

Applicable to: ALL

The system automatically displays this page at power up, but the pilot may also call it up by pressing the DATA key on the MCDU console.



**TITLE**                      **AIRCRAFT TYPE**

[ 1L ] ENGINE TYPE      The system uses this to calculate predictions.

Note:      When the same performance database is used for various aircraft configurations, the aircraft type displayed may differ from the actual aircraft.

- [ 2L ] ACTIVE DATABASE The validity period and part number are displayed in large font.
- [ 3L ] SECOND DATABASE The validity period is displayed in small font. The pilot can press the 3L key to switch to the second database as the active database.

**CAUTION** Cycling the database erases the primary and secondary flight plans, as well as the stored data. The flight crew must never do this in flight.

- [ 5L ] CHG CODE This field allows the entry of a code to change the IDLE and/or PERF factor, displayed in 6L. It is displayed in the PREFLIGHT and DONE phases. The label is displayed in small white font. The brackets, or the entered value, is displayed in large blue font.

- [ 6L ] IDLE/PERF It is only possible to modify these factors when the aircraft is on ground. If no value was entered, the FMS displays default values coded in the Airline Modifiable Information (AMI) file. Default values are displayed in small font, although manually entered values are displayed in large font.

When it is necessary to modify the IDLE or the PERF factor:

- ENTER the change code in the CHG CODE field [5L].  
 The default value for this code is "ARM" but it is possible to modify it on airline request (the applicable code is then coded in the Airline Modifiable Information (AMI) file).  
 When a valid change code is entered, the IDLE and PERF factors are displayed in blue.
- ENTER the new IDLE and/or PERF factor(s) in the scratchpad.
- PRESS the [6L] key to insert the new IDLE and/or PERF factor(s).  
 The new IDLE and/or PERF factor(s) is (are) displayed in large blue font.

- [4R] STORED This field displays pilot-stored data in a large green font. The field is blank, if no data is stored. (The airline can choose to have this data automatically erased at the done phase).
- [5R] DELETE ALL Pressing this key changes the label to amber CONFIRM DELETE ALL. Pressing this key a second time deletes all pilot-stored data, except data that is part of the active and secondary flight plans.
- [6R] STATUS/XLOAD This prompt gives access to the P/N STATUS and P/N XLOAD pages.

**P/N XLOAD PAGE**

Ident.: DSC-22\_20-50-10-25-00000582.0001001 / 17 MAR 11

**Applicable to: ALL**

This page allows the crossloading of all databases or configuration files part numbers which are different between both sides. Crossloading from this page avoids reviewing each individual P/N STATUS page.



TITLE	P/N XLOAD
[1L]	FMS 1 UPDATE: FMS 1 can be loaded on the right side MCDU. FMS 2 UPDATE: FMS 2 can be loaded on the left side MCDU
[4L]	START XLOAD: This blue prompt is displayed, only if the system detects a difference between both sides' part numbers. FMS 1/FMS 2 IDENTICAL: Displayed in green, when there is no difference between both sides' part numbers.
Line 5	FM 1 TO FM 2 or FM 2 TO FM 1: Indicates the crossloading direction. This line is not displayed when there is no difference between both side part numbers.
[5L]	A/C STATUS: This white prompt is displayed, when there is no crossloading in process. It gives access to the A/C STATUS page. MM: SS MIN REMAINING: Indicates the time remaining for crossload completion, when a crossload is in process.
[6L] PREV PAGE	The pilot presses this key to return to the A/C STATUS page.
[6R] NEXT PAGE	Pressing this key calls up the next P/N XLOAD page.

**P/N STATUS PAGES**

Ident.: DSC-22\_20-50-10-25-00000583.0001001 / 01 OCT 12

Applicable to: **ALL**

These pages allow reviewing and crossloading the following databases and configuration files between both FMS:

- Page 2 FMS SOFTWARE part numbers
- Page 3 NAV DATA BASE part numbers
- Page 4 FM AIRLINE CONFIG part numbers
- Page 5 FM OPTIONS CONFIG part numbers
- Page 6 PERF DATA BASE part numbers
- Page 7 FLIGHT TEST DATA BASE

CROSSLOAD NOT  
POSSIBLE

P/N STATUS 3 / 7

ELEMENT

NAV DATA BASE

FMS 1 P/N

PS1234567-123

FMS 2 P/N

PS1231565-123

←START XLOAD

FM1 TO FM2

<A/C STATUS

<PREV PAGE NEXT PAGE>

P/N STATUS 3 / 7

ELEMENT

NAV DATA BASE

FMS 1 P/N

PS1234567-123


FMS 2 P/N

PS1234564-123

NEED FM1/FM2 SOFTWARE  
IDENTICAL TO XLOAD

<A/C STATUS

<PREV PAGE NEXT PAGE>



**TITLE**

**P/N STATUS**

Line 1 ELEMENT

Indicates the name of the database or configuration file that can be crossloaded:

- FMS SOFTWARE on Page 2
- NAV DATA BASE on Page 3
- FM AIRLINE CONFIG on Page 4
- FM OPTIONS CONFIG on Page 5
- PERF DATA BASE on Page 6
- FLIGHT TEST DATABASE on Page 7.

Line 2 FMS1 P/N Line 3 FMS2 P/N

These fields display the part numbers of the database or configuration file (stated on line 1), that are installed on the FMS 1 and 2.

Identical part numbers are displayed in green, different ones in amber. During crossload, the updated part number is replaced by the amber “ACCEPTING XLOAD” message.


Line 4	<p>This line is empty when the active flight phase is not Preflight or Done.</p> <p>XLOAD FMx TO FMy or START XLOAD FMx TO FMy: This blue prompt is displayed when the database or configuration file (stated on line 1) can be crossloaded.</p> <p>XLOAD ARMED: Displayed in blue on the receiving FM when the crossload has been requested, but not yet confirmed.</p> <p>XLOAD IN PROCESS: Displayed in white when the crossload is ongoing.</p> <p>XLOAD NOT SUPPORTED: Crossloading is unavailable for this element.</p> <p>NO P/N TO XLOAD: The element is missing.</p> <p>NEED FG 1/FG 2 IDENTICAL TO XLOAD: The receiving side's FG software is incompatible with the FG software to be crossloaded.</p> <p>NEED FM 1/FM 2 SOFTWARE IDENTICAL TO XLOAD: The crossloaded element is incompatible with the receiving side's FM software.</p>
[5L] A/C STATUS	<p>This prompt is available, when no crossload is in process. This gives the pilot access to the aircraft status page.</p> <p>MM: SS MIN REMAINING: Displays the time remaining to complete the crossload, when a crossload is in process.</p>
[6L] PREV PAGE ABORT	<p>This key calls up the previous P/N STATUS page.</p> <p>This amber prompt is displayed when a crossload is in process. The pilot uses it to stop the crossload.</p>
[6R] NEXT PAGE CONFIRM*	<p>This key calls up the next P/N STATUS page.</p> <p>This amber prompt is displayed when a crossload has been armed. The pilot presses it to start the crossload.</p>

**DUPLICATE NAMES PAGE**

Ident.: DSC-22\_20-50-10-25-00000584.0001001 / 01 OCT 12

Applicable to: **ALL**

This page, which automatically appears, allows the pilot to select a specific waypoint, airport, or NAVAID when the database holds more than one under the same identifier.



The pilot presses the key adjacent to a waypoint, NAVAID, or airport to select it as the one to be entered. When the pilot has finished, the page automatically reverts to the previously displayed page.

**DISTANCE**

The direct distance to the aircraft is displayed in green above each name. If this distance is greater than 9 999 NM, 9 999 NM is displayed.

**LAT /LONG COLUMN**

This column lists the rounded off latitudes and longitudes of the different points, using the same identifier.

**FREQ/CHAN COLUMN**

This column lists the NAVAID s frequencies, if any. It displays CHAN for a MLS.

- Note:
- The *DUPLICATE NAMES* page is not displayed when 2 waypoints with the same *IDENT* belong to the same airway. The system selects the first waypoint found in the database.
  - The waypoints or *NAVAIDs* are ranked by their distance from the aircraft position.
  - When a waypoint is named using ICAO phonetic alpha characters, a minus sign and the ICAO code of the country where the waypoint is located, are displayed. e.g. Alpha in France becomes A-LF; Bravo in England becomes B-EG.

**POSITION MONITOR PAGE**


Ident.: DSC-22\_20-50-10-25-00000585.0001001 / 17 MAR 11

Applicable to: ALL

This page displays all the different positions that the FMGC has computed with the various available methods of navigation. It also shows which method obtained each position. (The positions should be almost identical).

The pilot calls up this page by pressing the 1L key on the data index page.





**POSITION MONITOR AND POSITION FROZEN PAGE**

Ident.: DSC-22\_20-50-10-25-00009133.0001001 / 29 MAR 12

Applicable to: ALL

Line 1 FMGC 1

This line shows the latitude and longitude, as calculated by the FMGC 1, and the navigation method used by the FMGC for that calculation (Example: “3 IRS /DME /DME”).



- Line 2 FMGC 2 This line shows the latitude and longitude, as calculated by the FMGC 2, and the navigation method used.
- Line 3 RADIO or GPS or GPIRS This line shows the latitude and longitude, calculated by the onside FMGC from selected radio NAVAID s (Example: DME /DME , VOR /DME , or LOC ) or from GPS or GPIRS.
- Line 4 MIX IRS This line shows the latitude and longitude of the weighted mean inertial reference system ( IRS ) calculated by the onside FMGC from the available IRSs.
- Line 5 IRS 1,2,3 This line shows the deviation in nautical miles of each IRS position from the onside FMGC position. It also displays the IRS mode, which can be INVAL, ALIGN, NAV or ATT.
- Note: INVAL is displayed when an ADIRS has failed, or the IRS position is not refreshed.*
- [ 6L ] FREEZE/UNFREEZE The pilot presses this key to freeze (or unfreeze) all the data displayed on the page. When the data is frozen, the title of the page specifies the time at which it was frozen.
- [ 6R ] SEL NAVAIDS The pilot presses this key to access the selected NAVAIDs page.

**SELECTED NAVAIDS PAGE**

Ident.: DSC-22\_20-50-10-25-00000586.0014001 / 03 APR 13

Applicable to: ALL

**MODIFIABLE ONLY FOR DESELECTION**

- Line 1 This field displays the NAVAID tuned for display purposes, and the tuning mode (AUTO, MAN , or RMP).
- Line 2 and 3 These fields display the NAVAID s, if any, tuned for the calculation of radio position by the FMGC.
- [ 4L ] This field displays the tuned ILS, GLS , MLS , if any.
- [ 5L ] DESELECT/SELECT RADIONAV The flight crew presses this key to manually select or deselect the NAVAIDs.
- If the flight crew selects (deselects) the NAVAID s for position calculation, "RADIONAV SELECTED" ("RADIONAV DESELECTED") is displayed in the label line in blue small font and "DESELECT" ("SELECT") is displayed in white large font. By default NAVAIDs are selected.
- The deselection of the RADIONAV inhibits use of radio position (either DME /DME or VOR /DME) for position calculation.


- |                                  |  |
|----------------------------------|--|
| [ 6L ]<br>DESELECT/SELECT<br>GPS | <p>The crew presses this key to manually select or deselect the GPS for position computation. Upon transition to the DONE phase, the prompt returns to DESELECT status.</p> <p>If the pilot deselects the GPS , “GPS IS DESELECTED” is displayed when the aircraft is less than 80 NM from the top of descent, or in approach phase.</p>   |
| [ 1R ] DESELECT to<br>[ 4R ]     | <p>The pilot deselects a NAVAID by entering its identifier in one of these six fields. Once deselected in this way, the NAVAID can no longer be tuned manually through the entry of its IDENT, nor can it be autotuned for display or determination of the position for the rest of the flight.</p> <p>The deselection is cleared:</p> <ul style="list-style-type: none"> <li>- Manually, by a CLR action into this field, or</li> <li>- Automatically upon transition to the done or preflight phase, or upon activation of the second database.</li> </ul> <p>The pilot may deselect as many as four stations.</p> |
| [ 6R ] RETURN                    | <p>The pilot presses this key to return to the POSITION MONITOR page.</p>  |

**IRS MONITOR PAGE**

Ident.: DSC-22\_20-50-10-25-00000587.0010001 / 01 OCT 12

**Applicable to: ALL**

This page displays the IRS data. The crew calls up this page by pressing the IRS monitor prompt of the DATA INDEX page.



TITLE DRIFT AT XXXX Displays "DRIFT AT" runway identifier, if at least one IRS average drift is displayed. (amber)

[1L] to [3L] IRS 1(2) (3) These prompts allow access to the associated IRS pages. Each label line displays the mode (NAV , ALIGN, ATT or INVAL), the average drift (upon transition to DONE phase), and the Time To NAV (if IRS in align) for each IRS. (white)

[1R] to [3R] Displays the status message of the associated IRS in small green font.

List of available messages:

IR FAULT  
CHECK C/B  
DELAYED MAINT  
CDU FAULT  
ENTER PPOS  
ENTER HEADING  
SELECT ATT  
REENTER PPOS  
EXCESS MOTION  
SYS BELOW -15 °  
SWITCH ADR


[5R] SET HDG (white) This field is displayed, if at least one IRS is in ATT mode.

This function allows initialization of a heading for IRS in ATT mode:

- If a heading has been entered in this field, or on the ADIRS panel, the value is displayed in blue.
- If not, amber boxes are displayed.

### **IRS 1 (2)(3) PAGE**

This page displays the IRS parameters and GPS /IRS hybrid parameters. The pilot calls up this page by pressing either the 1L key from the IRS MONITOR page, or the NEXT IRS prompt on another IRS page (closed loop).




- TITLE** Displays the selected IRS in large white font.  
 When data is frozen, IRS is replaced by “IRS FROZEN AT”, followed by the time at which the pilot has frozen the display.
- [1L] POSITION Displays the latitude/longitude given by the selected IRS.
- [2L] TTRK True track
- [3L] THDG True heading
- [4L] WIND True wind direction/velocity
- [5L] GPIRS GPS /IRS hybrid position of the IRS
- [6L] FREEZE/UNFREEZE Allows the crew to freeze or unfreeze all data displayed on all three IRS pages. When the data is frozen, the title of the page specifies the time at which it was frozen. It is automatically unfrozen when exiting the page.
- [2R] GS Ground speed
- [3R] MHDG Magnetic heading
- [4R] GPIRS ACCUR GPS /IRS Figure of Merit (meters or feet)

[6R] NEXT IRS      This prompt enables another IRS page (closed loop IRS 1 → 2 → 3 → 1) to be displayed.

<b>GPS MONITOR PAGE</b>
-------------------------

Ident.: DSC-22\_20-50-10-25-00000588.0001001 / 17 MAR 11  
Applicable to: ALL

This page displays the GPS data. The pilot calls up this page by pressing the GPS MONITOR prompt of the DATA INDEX page.



- Line 1 and 4 GPS 1,2    POSITION
- [ 2L ] and [ 5L ] TTRK    GPS 1, 2 true track
- [ 3L ] and [ 6L ] MERIT    GPS 1, 2 figure of merit (meters or feet)
- [ 2R ] and [ 5R ] GS      GPS 1, 2 ground speed
- [ 3R ] and [ 6R ]        GPS 1, 2 mode (INIT , ACQ, NAV, TEST, FAULT, AIDED or ALTAID) and  
MODE/SAT                Number of satellites tracked.
- INIT                        :    System initialization
- ACQ                        :    Satellite acquisition
- NAV                        :    Normal mode
- TEST                      :    System test
- FAULT                     :    Invalid system
- ALTAID/AIDED         :    Degraded modes. GPS uses aircraft inputs for  
computation purposes.
  
- [ 2 ] and [ 5 ] UTC      :    GPS 1, 2 UTC
- [ 3 ] and [ 6 ] GPS      :    GPS altitude is displayed for information purposes. It is not used by the  
ALT                        FMGS.

**CLOSEST AIRPORTS PAGES**


Ident.: DSC-22\_20-50-10-25-00000589.0001001 / 17 MAR 11

Applicable to: ALL

The system automatically selects the closest 4 airports from the current aircraft position, and displays them on these pages. A fifth one can be selected by the pilot.

Page 1 displays the bearing, distance, and time to go to each airport; page 2 displays the EFOB and allows the crew to enter an effective wind to be flown to each airport.

The flight crew accesses the CLOSEST AIRPORTS page 1 by pressing the 5L key from the DATA INDEX A page. They access the CLOSEST AIRPORTS page 2 by pressing the EFOB/WIND prompt (6R key) on page 1.



[1L] - [1R] to [4L] - [4R] The closest four airports are extracted from the database, and ranked by distance from the aircraft position.

**BRG** Displays the current bearing from the aircraft's position to the airport.

**DIST** Displays the current great-circle distance from the aircraft's position to the airport.

**TIME or UTC** Displays the predicted time to the airport, computed using the current wind or a wind vector entered on page 2, and the speed according to the current mode (managed or selected).

The time is only computed in cruise phase.



- [5L] The crew may enter a fifth airport here, using the 4-letter code. The entry may be modified at any time, even when "LIST FROZEN" is displayed. If the pilot enters an airport that is not in the database, then "NOT IN DATABASE" appears in the scratchpad.
- [1L] - [1R] EFOB to [5L] Displays the EFOB at each airport. EFOB is only computed in cruise phase.  
 - [5R] EFF WIND Used to enter an anticipated headwind or tailwind along the bearing to the airport. If the entry is preceded by +, T, or TL, a tailwind is assumed. If the entry is preceded by -, H, or HD, a headwind is assumed. Before pilot entry, a default value may be displayed, based on the current wind. The effective wind is used to compute the EFOB and time to the airport.
- [6L] This prompt enables the pilot to freeze and unfreeze the list of four airports.  
 FREEZE/UNFREEZE The list is automatically frozen when accessing page 2. It will remain frozen upon returning to page 1. The "LIST FROZEN" message is always displayed on page 2.
- RETURN Returns to page 1.
- [6R] EFOB/WIND Gives access to page 2. Pressing this prompt automatically freezes the list of the four closest airports.

*Note:*


- If the aircraft position becomes invalid, all fields are dashed, FREEZE/UNFREEZE and EFOB /WIND prompts are removed, LIST FROZEN is displayed, and the A/C POSITION INVALID message is displayed in the scratchpad. Page 2 cannot be accessed.
- Predictions (EFOB, TIME) displayed on the page assume:
  - ECON CRZ speed (managed) or current selected speed (selected)
  - CI (for managed speed only) and CRZ FL from primary F-PLN are kept
  - constant wind value
  - In case of engine out, the aircraft altitude is the minimum of (CRZ FL , EO MAX ALT)
  - Downpath steps are not considered
  - Descent fuel burn is a conservative value which only depends on the difference between current CRZ ALT and destination altitude.

**EQUI-TIME POINT PAGE**

Ident.: DSC-22\_20-50-10-25-00000590.0001001 / 18 DEC 12

Applicable to: ALL

The pilot uses this page to require an equitime point computation between two different points (airport, NAVAID , runway, NDB or waypoint). This pseudo-waypoint (ETP ) is displayed on the navigation display along the F-PLN. The EQUI-TIME POINT page is accessed by pressing the 6L key from the DATA INDEX page:



- [1L] A/C TO and (blue) [3L] Displays reference waypoint 1.
- Displays reference waypoint 2.

**Note:** Origin and destination airports are used by default for respective reference points 1 and 2, until a pilot entry is made.

- [1R] BRG/DIST/UTC and [3R] (green) Displays the bearing, distance, time, from the aircraft's current position to the reference waypoint 1.
- Displays the bearing, distance, time, from the current position of the aircraft to the reference waypoint 2.
- BRG : Displays the current great-circle bearing from the position of the aircraft to the reference waypoint.
- DIST : Displays the current great-circle distance from the position of the aircraft to the reference waypoint.
- UTC : Displays the predicted time of arrival at the reference waypoint (computed using the current wind or a wind vector, entered by the crew).
- The time is only computed in cruise phase. In other phases, it is dashed.

- [2L] and [4L] TRU WIND (blue) The pilot may enter the wind (direction/velocity) at the reference waypoint and the CRZ FL:  
This wind is used to compute the time from the aircraft's position to the reference waypoint, and to locate the equitime point.  
If no entry is made, the wind/velocity field will read zero.

[2R] and [4R] EPT TO XXX (green)	This field displays the bearing distance and the time from the equitime point position (ETP) to the reference waypoint.
[5R] ETP LOCATION	This field displays the ident of the next waypoint following the equitime point. It provides the distance along the flight plan from the equitime point to the indicated waypoint.
[6L] - [6R] A/C TO (ETP) DIST/UTC (green)	This field displays the distance and time from the aircraft's current position to the equitime point along the flight plan. If at least one reference waypoint exists, but no equitime point exists, the field is blank and NO ETP is displayed in 6L.

*Note: The assumptions for the equitime point computation include the cost index, speed managed (with SPD LIM), and winds.  
 In case of engine-out, the EO LRC speed is considered.*

**PRINT FUNCTION PAGES**

Ident.: DSC-22\_20-50-10-25-00000591.0001001 / 01 OCT 12


Applicable to: ALL

The PRINT FUNCTION pages enable the crew to print the data relative to the current flight.

This data comes from 2 different sources:

- ACARS uplink messages, and
- Active data from the current flight.

The pilot may access these pages from the "DATA INDEX" page1/2 by pressing the [6R] ACARS/PRINT FUNCTION key.



**PRINT FUNCTION PAGE 1/2**

This page displays the status of the automatic printing capabilities, for the uplink messages (left column), and the status of the manual printing capabilities of the current active data (right column).

**LEFT COLUMN**

- AUTO
- \* YES (blue)
  - Line 1: Uplink messages related to flight plan INIT data are automatically printed when received.
  - Line 2: Uplink messages related to takeoff data are automatically printed when received.
  - Line 3: Uplink messages related to wind data are automatically printed when received.
- \* NO (blue)
 

When "NO", preceded by a star, is displayed in front of a line, automatic printing is deselected. The pilot can reactivate it by pressing the left key of the line. Automatic printing is internally deactivated for the data of the line. The pilot cannot reactivate it manually.
- NO (without a star)
 

The ACARS function is not available for this line. Uplink messages can neither be received nor automatically printed.
- Blank

**RIGHT COLUMN**

**MANUAL** Displays the status of the manual printing capability of the active data (and not of the ACARS uplink data).

**PRINT \* (amber)** Pressing the right keys prints the following active data:  
 Line 1: Active flight plan INIT data  
 Line 2: Active takeoff data  
 Line 3: Active wind data

If the star is not displayed, printing is not possible.  
 When the key is pressed, the star is removed until the data is printed.

[6L] RETURN Pressing this key reverts the display to the DATA INDEX page.  
 [6R] ACARS FUNCTION Pressing this key reverts the display to the ACARS FUNCTION page.

**PRINT FUNCTION PAGE 2/2**

This page describes the printing capabilities of the reports displayed on lines 1 to 4.

**LEFT COLUMN**

**AUTO (white)** Line 1: The PREFLIGHT report is automatically printed at engine start.  
**\* YES (blue)** Line 2: The INFLIGHT report is automatically printed at takeoff.  
 Line 3: The POSTFLIGHT report is automatically printed at engine shutdown.

**\* NO (blue)** The report, displayed on the line, is not printed automatically. The pilot can reactivate the function by pressing the left key of the line.

**NO (without a star)** Automatic printing is internally deactivated for the report. The pilot cannot reactivate it.

**RIGHT COLUMN**

**MANUAL** Pressing a right key prints the report displayed on the line.  
**PRINT \*** If the star is not displayed, printing is not possible.  
 When the key is pressed, the star is removed until the report is printed.  
 For the PREFLIGHT, INFLIGHT and POSTFLIGHT reports, only one type of report is available for printing at any given time, depending on the current flight phase.  
 For the SEC F-PLN report, the print selection start is only displayed if a secondary flight plan exists.


**ACARS FUNCTION PAGE**


Ident.: DSC-22\_20-50-10-25-00000592.0001001 / 01 OCT 12

Applicable to: ALL

The ACARS FUNCTION pages display the functions enabling the crew to send manual requests or reports to the ground.

All functions, displayed on pages 1 and 2, may be inhibited through a pin program.  
 The ACARS /PRINT FUNCTION prompt is displayed on the DATA INDEX page 1/2. Pressing this key displays the PRINT FUNCTION page from which the ACARS FUNCTION page can be accessed.






**ACARS FUNCTION PAGE 1**

Ident.: DSC-22\_20-50-10-25-00000593.0001001 / 17 MAR 11

Applicable to: ALL



TITLE

ACARS FUNCTION 1/2 in white

- Line 1 F-PLN INIT REQ\* Pressing this key sends a request for flight plan to the ground (downlink message)  
The INIT REQUEST prompt of the INIT A page provides the same function.
- Line 2 TO DATA REQ\* Pressing this key sends a request for takeoff data.  
Displayed in the DONE and PREFLIGHT phases.  
The TO DATA REQUEST prompt of the UPLINK TO DATA REQ page provides the same function.
- Line 3 WIND DATA REQ\* Pressing this key sends a request for wind data.  
The WIND REQUEST prompt of the CLIMB, CRUISE, and DESCENT WIND pages provides the same function.

*Note: If "REQ" is not followed by a star, the request cannot be sent (downlink message).  
When a function (line 1 or 2 or 3) is deactivated internally, the corresponding line is blank.*

- [6L] RETURN The pilot presses this key to make the display revert to the DATA INDEX page.
- [6R] PRINT FUNCTION The pilot presses this key to access the PRINT FUNCTION page. (*Refer to DSC-22\_20-50-10-25 Print Function Pages*).


**UPLINK TO DATA REQ PAGES**

Ident.: DSC-22\_20-50-10-25-00000594.0009001 / 14 MAY 12

Applicable to: **ALL**

This page allows the flight crew to send a request for takeoff data for up to 2 runways. There is one page for each runway. The page is accessed from the PERF TAKEOFF page, or from the UPLINK XXX (MAX or DRT or FLX) TO DATA page, by pressing the UPLINK TO DATA prompt.





**TITLE**

White.

[ 1L ] TOW/TOCG  
 (green)

This field is dashed, until a runway is defined in the [ 1R ] field. The TOW /TOCG is defaulted to the values of the INIT B and FUEL PRED pages. If not available, dashes are displayed. It cannot be modified by the pilot.


[ 2L ] TEMP/QNH or  
 QFE (green/blue)

This field is dashed, until a runway is defined in the [ 1R ] field. It displays the temperature at origin and baro setting. TEMP = If the temperature is not defined, blue brackets are displayed, and the flight crew can modify this field according to the weather information. BARO = Defaulted to FCU selection and can be modified by the pilot.

[ 3L ] MAG WIND (blue)

This field is dashed, until a runway is defined in the [ 1R ] field. It displays the wind at the origin. If the wind is not defined, blue brackets are displayed. The pilot can modify this field.

- [ 4L ] CONTAM (blue) This field is dashed, until a runway is defined in the [ 1R ] field. The display is defaulted to DRY.  
 The scroll keys allow the crew to modify the runway contamination.  
 DRY, WET, 1/4 WATER, 1/2 WATER, 1/4 SLUSH, 1/2 SLUSH, COMP SNOW.
- [ 6L ] RECEIVED TO DATA This field calls up the UPLINK MAX (or FLX or DRT) TO DATA page that displays the data received by AOC.



- [ 1R ] SHIFT/RWY (blue) This field is dashed, until a runway is defined in the F-PLN . If a runway is defined in the F-PLN, it is automatically filled in as:  
 SHIFT = Value from the PERF TO page, or blue brackets [ ], if no value is defined.  
 RWY = F-PLN departure runway. The pilot can modify this field.
- [ 2R ] TO LIMIT (blue) It is dashed, until a runway is defined in the [ 1R ] field. It displays blue brackets [ ], when a runway is defined. The pilot may enter a length, considering runway obstacles.
- [ 3R ] FLAPS/THS (blue) This field is dashed, until a runway is defined in the [ 1R ] field; it is then defaulted to values from the PERF TO page. Blue brackets are displayed, if the PERF TO page does not have any defined values.
- [ 4R ] FLEX TO TEMP (blue) This field is dashed, until a runway is defined in the [ 1R ] field; it is then defaulted to values from the PERF TO page. Blue brackets are displayed, if the PERF TO page does not have any defined values. The pilot can modify this field and enter a FLEX TO temperature (FXX).
- [ 6R ] TO DATA REQUEST\* (amber) Pressing the key sends the takeoff data request message to the ground. The asterisk disappears when the request is sent. It reappears when the data is available.


Page 2/2 is a page used for requesting a second runway data.

*Note: If the UPLINK TO DATA REQ Page 2 is accessed (Page 1 being filled), the fields of this page are filled with default values after entry of a runway in [ 1R ]. QNH or QFE and wind are common with Page 1.*

**UPLINK MAX TO DATA PAGES**

Ident.: DSC-22\_20-50-10-25-00000595.0010001 / 01 OCT 12

Applicable to: ALL



This page is accessed from the UPLINK TO DATA REQ page by pressing the RECEIVED TO DATA key.

There is a set of 2 pages (MAX TO DATA and FLEX TO DATA) for each of the 4 uplinked runway data. Uplinked data is displayed in green. (It cannot be modified by the flight crew).

[1L] TOW/TOCG Uplinked reference Takeoff Gross Weight and Takeoff Center of Gravity.

[2L] TEMP/QNH (or QFE) Uplinked assumed temperature and BARO setting.

[3L] MAG WIND Uplinked takeoff runway wind.

[4L] CONTAM Uplinked takeoff runway contamination.


- [5L] THR RED/ACC Uplinked Thrust Reduction and Acceleration altitudes.
  - [6L] UPLINK TO DATA Pressing the key calls up the UPLINK TO DATA REQ page.
  - V1, VR, V2 Uplinked takeoff speeds.
  - [1R] SHIFT/RWY Uplinked TO runway IDENT, runway intersection and position shift.
  - [2R] TO LIMIT Uplinked runway length remaining.
  - [3R] FLAPS/THS Uplinked FLAPS/SLATS CONF and TRIM position.
  - [4R] FLEX TO Pressing this key calls up the UPLINK FLEX TO DATA pages.
  - [5R] ENG OUT ACC Uplinked engine-out acceleration altitude.
  - [ 6R ] INSERT UPLINK\* Uplinked takeoff data is available for insertion.
- Selecting this prompt inserts the following data on the PERF TO page:
- V1 , VR , V2
  - THR RED/ACC, ENG OUT ACC altitudes
  - FLAPS/THS
  - SHIFT
  - FLEX
- The display reverts to the PERF TO page, the asterisk disappears.
- This field is not displayed, if the runway does not match the active runway. If the runway matches the active runway but the uplinked TOW differs from the current TOW (the uplinked TOW is 3 t greater or 1 t lower than the TOW estimated by the FMS):
- The asterisk disappears and the insertion is not possible
  - The TOW value is displayed in amber in [1L] field.

Note: All previously-received data is replaced by the new uplinked data.

**UPLINK FLX TO DATA PAGES**

Ident.: DSC-22\_20-50-10-25-00000596.0001001 / 23 JUN 15

Applicable to: ALL



TITLE

UPLINK FLX TO DATA.

[2L]

FLX/QNH (or QFE)

When the UPLINK FLEX TO DATA page is selected, it displays uplink assumed Flex Temperature and BARO setting (QNH or QFE).

[4R] MAX TO


Pressing this key calls up the MAX TO DATA page.

For all other fields, *Refer to DSC-22\_20-50-10-25 Uplink MAX TO Data Pages*

**ACARS FUNCTION PAGE 2**

Ident.: DSC-22\_20-50-10-25-00000597.0001001 / 17 MAR 11

Applicable to: ALL



Line 1 F-PLN RPT      Pressing this key sends the flight plan report to the ground.  
 SEND

Line 2 POSITION RPT    Pressing this key sends a Position Report to the ground.  
 SEND

Note: - No report can be sent, if "SEND" is not followed by a star  
 - When a function (line 1 or 2) is deactivated through the navigation database policy file, the corresponding line is blank.

[6L] RETURN            The pilot presses this key to revert to the DATA INDEX page.

[6R] PRINT FUNCTION The pilot presses this key to access the PRINT FUNCTION page.


**PERF PAGE**

Ident.: DSC-22\_20-50-10-25-00000598.0001001 / 17 MAR 11

Applicable to: ALL

The flight plan is divided into the following phases:  
 PREFLIGHT, TAKEOFF, CLIMB, CRUISE, DESCENT, APPROACH, GO-AROUND, DONE.  
 Each phase, except for the preflight and done phases, has a performance (PERF) page. The PERF pages display performance data, speeds related to the various phases, and predictions.  
 Pressing the PERF key on the MCDU console calls up the performance page for the current active phase. Performance pages, relating to phases already flown, are not available.  
 In the preflight and done phases, pressing the PERF brings up the takeoff performance page.

Pressing the PERF key in the done phase makes the phase transition to the preflight phase.




The FMGS flight phases are not related to the FWC flight phases.

Line 6 Fields may display two different prompts, depending upon whether the phase is active or not.

- [6L] PREV PHASE To review the performance page for the previous phase. The prompt is unavailable on the takeoff performance page. It is also unavailable for phases already flown.
- [6L] ACTIVATE APPR PHASE To activate, then confirm, the APPR phase. Available only on the page corresponding to the active phase.
- [6R] NEXT PHASE To review the performance page for the next phase.

**Note: Engine-out condition**

- When the FMGS detects an engine-out condition, the system automatically calls up the performance page for the current flight phase (except when this occurs before the diversion point during takeoff or no EOSID exists in the flight plan) and displays "EO CLR \*\*" in the [1R] field and EO LRC (engine-out long range cruise) in the [2L] field. On the CLB, CRZ and DES (when the descent phase is not active) PERF pages, the pilot can enter a cost index value and overwrite to "EO LRC". Clearing the cost index reverts to EO LRC.  
 If the pilot presses the [1R] key, the system reverts to the normal processing (with no engine failed) and suppresses the EO information. (Refer to DSC-22\_20-30-10-15 General).
- If the engine-out condition is detected before the diversion point at takeoff, a temporary flight plan is created.




**PERF TAKEOFF PAGE**

Ident.: DSC-22\_20-50-10-25-00000599.0010001 / 08 JUL 15

Applicable to: ALL

During the preflight phase, the pilot presses the PERF key to call up the takeoff performance page.





**TITLE**

TAKE OFF RWY is in large green font when the takeoff phase is active, and in large white font when it is inactive. The active flight plan selected runway is displayed in large green font.

*Note: If the takeoff shift, or the flaps/THS, or the runway is changed after V1, VR or V2 insertion, but the origin airport remains the same, the MCDU "CHECK TAKE OFF DATA" message appears. All takeoff parameters are retained except in case of runway change. In case of runway change, the parameters are invalidated, but still displayed adjacent to each field. The "CONFIRM TO DATA" prompt in [6R] allows reverting to the previous values.*

[1L] V1 [2L] VR [3L] V2 The boxes remain amber, as long as the pilot does not make entries in them. The pilot can modify any entry, as long as the takeoff phase is not active.

- Note:
1. If the flight crew does not enter V2, the SRS mode will be unavailable at takeoff.
  2. The MCDU "V1 /VR /V2 DISAGREE" amber message appears if the inserted V1, VR, V2 speeds do not satisfy the condition:  $V1 \leq VR \leq V2$ .
  3. The MCDU "TO SPEED TOO LOW" amber message appears if the inserted V1, VR, V2 speeds do not satisfy the existing regulatory conditions regarding VMCG /VMCA and VS1G speeds.

[4L] TRANS ALT This field displays the navigation database default altitude (if defined) once the origin airport is entered. The pilot can modify it.  
 (transition altitude)

[5L] THR RED (thrust This is the altitude at which the pilot should reduce the thrust from TOGA /FLX to MAX CLIMB (CL detent) with all engines operative ("CLB" or "LVR CLB" flashing on the FMA).  
 reduction altitude)

- The thrust reduction altitude defaults to 1 500 ft above the runway elevation, or to the altitude set by the airline
- The pilot can modify this altitude: The minimum is 400 ft above the runway elevation.

ACC (Acceleration This is the altitude at which the climb phase is triggered.  
 altitude)

- The target speed jumps to the initial climb speed
- The default value is 1 500 ft above runway elevation
- The flight crew can modify the value. The minimum value is 400 ft above runway elevation, and it can be higher than, or equal to, or lower than THR RED.

- Note:
- A clearing action reverts both values to the defaulted ones
  - When the flight crew selects an altitude on the FCU that is below THR RED, it brings THR RED and ACC down to this altitude. (The 400 ft minimum still applies).

[6L] UPLINK TO DATA This key calls up the UPLINK TO DATA REQ page.  
 It is only displayed in the preflight and done phases.


[1R] EO CLR EO CLR is displayed when an engine-out is detected and when active flight phase is takeoff.

[2R] TO SHIFT	The takeoff shift is the distance in meters or feet between the beginning of the runway and the aircraft's takeoff position. When taking off from an intersection, the flight crew should insert this value to ensure a correct update of the FM position. The takeoff shift value must be positive, and cannot be greater than the runway length.
[3R] FLAPS/THS	This is a flight crew entry for the positions of the flaps and the trimmable horizontal stabilizer (THS) at takeoff. The flight crew can modify it until takeoff, by entering "UP X.X" or "X.X UP", or "DN X.X" or "X.X DN" for the THS.
[4R] FLX TO TEMP	The flight crew inserts the FLX TO temperature for FLX takeoff setting purposes. The flight crew can only enter it during preflight. The system sends it to the FADEC and displays the entered data on the upper ECAM display. The TEMP value is always entered in degrees Celsius.
[5R] ENG OUT ACC	This field displays the engine-out acceleration altitude, as defined in the database, or is manually entered by the flight crew. This is for display only, as a reminder. It cannot be cleared. The above ACC altitude rules of [5L] apply to this field.
[6R] NEXT PAGE or CONFIRM TO DATA*	This key calls up the climb performance page, or allows the flight crew to revert to the previously-entered T.O. parameters, in case of runway change with the same origin airport.

**PERF CLIMB PAGE**

Ident.: DSC-22\_20-50-10-25-00000600.0001001 / 14 MAY 12

Applicable to: ALL



- TITLE** CLB is displayed in large white fonts when the climb phase is inactive, and in large green fonts if it is active.
- [1L] ACT MODE** This field displays the preselected or active speed mode: **SELECTED** or **MANAGED**.  
 The pilot cannot modify it from this field.
- [2L] CI (Cost Index)** This field displays the cost index, as initialized on the INIT A or defaulted from the database, or inserted in this field by the pilot. EO LRC automatically replaces the cost index value in case of engine-out.
- [3L] MANAGED** This field displays the FMGS computed ECON speed/Mach (*Refer to DSC-22\_20-40-10 Optimization*).  
 Before **CLIMB** phase is active, if the preselected speed mode is **SELECTED**, a star is displayed next to the **MANAGED** speed. Pressing the 3L key in this case preselects **MANAGED** speed, and 4L reverts to brackets.

[4L] PRESEL or SELECTED	<p><u>If the climb phase is not active:</u> This field displays PRESEL as long as the climb phase is not active. The pilot can enter a preselected speed only.</p> <p><u>If the climb phase is active:</u> The title of this field becomes SELECTED. This field displays the selected (or preselected) SPD or MACH target. The pilot cannot modify it directly in this field, but can adjust it with the SPD /MACH selection knob on the FCU. If the pilot pushes in the FCU SPD /MACH selection knob to revert to managed speed, the system selects (or reselects) ECON SPD/MACH and [4L] is blank.</p>
[5L] Blank or EXPEDITE	<p>This field is blank as long as the aircraft is in preflight. This field displays this legend when the takeoff or climb phase is active. The flight crew cannot engage EXPEDITE from this field. It indicates the time and distance required to reach the altitude displayed in the 2R field, in case of climb at green dot.</p>
[6L] PREV PHASE	<p>This field displays this legend if climb phase is not active. The pilot presses this key to call up the takeoff page.</p>
[6L] ACTIVATE APPR PHASE	<p>The field displays this legend if the climb phase is active. Pressing this key once displays “CONFIRM APPR PHASE*”. Pressing it again activates the approach phase.</p>
[1R] EO CLR	<p>The system displays the EO CLR prompt in case of engine out in climb.</p>
[2R] PRED TO...	<p>This field displays the target altitude for the predictions shown in 3R, 4R, or 5L. It defaults to FCU altitude, but the pilot can modify it to any altitude below CRZ FL.</p>
[3R] [4R] [5R]	<p>These fields show time and distance predictions for the target altitude selected in [2R], computed for the current vertical mode and speed mode (MANAGED, SELECTED). These fields are displayed only while the takeoff, or climb phase is active.</p>
[6R] NEXT PHASE	<p>The flight crew presses this key to call up the PERF CRZ page.</p>

**PERF CRUISE PAGE**


Ident.: DSC-22\_20-50-10-25-00000601.0009001 / 30 MAR 15

Applicable to: ALL

CRZ PHASE NOT ACTIVE	1L	CRZ	1R
		ACT MODE UTC DEST EFOB	
		MANAGED 1220 8.4	
	2L	CI	2R
		540	
	3L	MANAGED	3R
	.80		
4L	PRESEL DES CABIN RATE	4R	
	* [ ] -350 FT/MN		
5L	STEP ALTS>	5R	
	PREV NEXT		
6L	<PHASE PHASE>	6R	

CRZ PHASE ACTIVE	1L	CRZ	1R
		ACT MODE UTC DEST EFOB	
		SELECTED 1114 8.4	
	2L	CI	2R
		540	
	3L	MANAGED	3R
	.80		
4L	DES CABIN RATE	4R	
	-350 FT/MN		
5L	STEP ALTS>	5R	
	ACTIVATE NEXT		
6L	←APPR PHASE PHASE>	6R	



- TITLE** CRZ in white large font, when cruise phase is not active, in green large font, when it is.
- [1L] ACT MODE** This field shows the preselected or active speed mode: **SELECTED** or **MANAGED**.  
 The pilot cannot modify it through this field.
- [2L] CI** This field shows the cost index as initialized on the INIT A page or defaulted from the database, or as inserted in this field by the crew.  
 EO LRC replaces automatically the cost index value in case of engine out.
- [3L] MANAGED** This field displays the FMGS computed ECON speed/Mach (*Refer to DSC-22\_20-40-10 Optimization*).  
 Before CRUISE phase is active, if the preselected speed mode is **SELECTED**, a star is displayed next to the **MANAGED** speed. Pressing the 3L key in this case preselects **MANAGED** speed, and 4L reverts to brackets.

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION

[4L] PRESEL	<p><u>If cruise phase is not active:</u>  The pilot can enter a preselected speed or Mach number.</p> <p><u>If cruise phase is active:</u>  This field is blank.</p> <p><u>Note:</u> <i>If the flight crew enters a value in the PRESEL field during the cruise altitude capture (ALT CRZ*), the FCU selected speed may revert to M 0.01.</i></p>
[6L] PREV PHASE or	The pilot can press this key to call up the climb page, if the cruise phase is not yet active.
[6L] ACTIVATE APPR PHASE	<p>This field displays this legend if the cruise phase is active. The flight crew presses the key once to change the legend to “CONFIRM APPR PHASE”. A second press activates the approach phase.</p> <p><u>Note:</u> <i>If the pilot activates the approach phase inadvertently, it can reselect the cruise flight level into the progress page to reactivate the cruise phase.</i></p>
[ 1R ] TIME/UTC DES EFOB	<p>Before takeoff this field displays the flight time to destination and the predicted remaining fuel on board. If the crew enters an estimated takeoff time, the field displays automatically the predicted arrival time (UTC ) at destination. After takeoff it displays the predicted arrival time at destination (UTC ) and the remaining fuel on board (DEST EFOB ) at destination, in green font. The DEST EFOB field will turn to amber, if the EFOB at destination becomes less than the MIN DEST FOB value displayed on the FUEL PRED page. EO CLR is displayed when an engine-out is detected.</p>
[2R] STEP TO FL XX, DRIFT DOWN TO FL XX, or TO T/D	The field, in combination with 3R, displays the predictions for the step point and the step altitude, the drift down altitude, or the Top of Descent.
[3R] TIME/UTC and DIST	This field displays the time and distance to go to the various points identified in 2R.
[4R] DES CABIN RATE	<p>This field displays MAX [computed DES cabin rate, maximum descent cabin rate]. The pilot may modify the value: the FM recomputes then the top of descent in order to match this value. If the FM cannot match the pilot entry, the FM computed value overwrites the pilot entry.</p> <p>A clear action reverts to the default value (-350 ft/min). DES CAB RATE being a negative value, 'minus" is not a necessary entry.</p>
[5R] STEP ALTS	This key calls up the STEP ALTS page (vertical revision <i>Refer to DSC-22_20-50-10-25 VERTICAL REVISION Pages</i> ).



[6R] NEXT PHASE      This key calls up the DES page.

**PERF DESCENT PAGE**

Ident.: DSC-22\_20-50-10-25-00000602.0011001 / 23 JUN 15

Applicable to: ALL

The image displays two screenshots of the PERF DESCENT PAGE on an MCDU. The top screenshot shows the 'DES' page with 'DES' in large white font. The data displayed is: ACT MODE MANAGED, CI 540, MANAGED .78/340, UTC 1215, DEST 8.4, EFOB. Navigation keys include PREVIOUS PHASE and NEXT PHASE. The bottom screenshot shows the 'DES' page with 'DES' in large green font. The data displayed is: ACT MODE SELECTED, CI 540, MANAGED .81/340, SELECTED .78/280, PRED TO FL200, UTC 1200, DIST 20, EXPEDITE 1155, ACTIVATE 15, NEXT PHASE. Navigation keys include APPR PHASE and NEXT PHASE.

**TITLE**      DES is in large white font if the descent phase is not active; it is in large green font, if it is.

[1L] ACT MODE      This field displays the preselected or active speed mode (MANAGED or SELECTED). The flight crew cannot modify it through this field.

[2L] CI      This field displays the cost index, as initialized on the INIT A page or defaulted from the database, or inserted in this field by the flight crew. The flight crew cannot modify it when the descent phase is active.

[3L] MANAGED

If the descent phase is not active:

Before the flight crew makes any entry. This field displays MANAGED in white, with the associated ECON descent Mach or speed in blue. The crew may overwrite the ECON descent Mach or speed by entering a Mach number or a speed in this field. The system uses the pilot entry to compute the descent profile. The descent may be flown in managed using this new pilot entry.

The entry is modifiable. It can be cleared to revert to ECON speed/Mach.

If the descent phase is active:

The flight crew cannot make an entry in this field.

The field displays the ECON speed/Mach or the speed/Mach value previously entered by the pilot.

[4L] blank or  
 SELECTED

If the descent phase is not active, or the descent phase is active but the active speed mode is MANAGED:

This field is blank.

If the descent phase is active and the active speed mode is SELECTED:

The field displays the speed or Mach target manually selected by the pilot. "SELECTED" is displayed in the [1L] field.

To modify the field value, the pilot will use the SPD /MACH selector knob of the FCU . [4L] field and FCU window will display the same value.

Pushing in the FCU speed selector knob activates the managed SPD/MACH target displayed in the [3L] field.

[5L] Blank or  
 EXPEDITE

If the descent phase is not active this field is blank.

Displays this legend if the descent phase is active.

It indicates the time and distance required to reach the altitude displayed in the 2R field at MMO /VMO speed. The pilot cannot select the EXPEDITE mode through this field.

[6L] PREV PHASE  
 or ACTIVATE APPR  
 PHASE

This key calls up the cruise phase page if the descent phase is not yet active.

Displayed if the descent phase is active. First press causes "CONFIRM APPR PHASE" to be displayed. Second press activates the approach phase.


- [ 1R ] TIME/UTC DEST Before takeoff, this field displays the flight time to destination and the predicted remaining fuel on board. If the crew enters an estimated takeoff time, the field displays automatically the predicted arrival time (UTC). After takeoff, it displays the predicted arrival time at destination (UTC ) and the remaining fuel on board (DEST EFOB ) at destination in green font. The DEST EFOB field will turn to amber, if the EFOB at destination becomes less than the MIN DEST FOB value displayed on the FUEL PRED page. EO CLR is displayed when an engine-out is detected.
- EFOB
- [2R] PRED TO... This field displays the target altitude for the predictions in [3R] [4R], or [5R]. The display defaults to the altitude selected on the FCU. The flight crew can modify it to any altitude lower than present altitude.
- [3R] [4R] [5R] These fields display time and distance predictions down to the target altitude selected in [2R], computed for the current vertical mode (DES or OP DES) and the indicated speed mode (MANAGED, SELECTED).
- [6R] NEXT PHASE The pilot presses this key to call up the PERF APPR page.

**PERF APPR PAGE**

Ident.: DSC-22\_20-50-10-25-00016132.0010001 / 24 FEB 15

Applicable to: **ALL**

PERF APPR Page



The diagram illustrates the PERF APPR MCDU page with two views of the display. Each view is flanked by six row select buttons (1L-6L on the left, 1R-6R on the right).

**Top View:**

- 1L: [ ] [ ] [ ] [ ]
- 2L: [ ] °
- 3L: [ ] °/[ ]
- 4L: 4000
- 5L: 134
- 6L: <PHASE

**Bottom View:**

- 1L: 1015
- 2L: 15 °
- 3L: 320°/10
- 4L: 4000
- 5L: 137
- 6L: <PHASE

**Right Side Labels (Common to both views):**

- 1R: F=144 ILS 33R
- 2R: S=188 [ ]
- 3R: 0=200 367
- 4R: LDG CONF CONF3-
- 5R: FULL
- 6R: NEXT PHASE>

**Callouts:**

- A box on the left explains: "F, S, GREEN DOT and VLS speeds computed by the FMGS assuming landing weight."
- A box below it states: "NOTE : VLS is the VLS of the selected LDG CONF (3 or FULL)"
- Arrows point from the VLS callouts to the 'VLS 129' value in both views.

PERF APPR Page (with BARO/RADIO option)






**F, S, GREEN DOT and VLS speeds computed by the FMGS assuming landing weight.**

**NOTE : VLS is the VLS of the selected LDG CONF (3 or FULL)**

Row	Left (L)	Center (APPR)	Right (R)
1	1L	QNH FLP RETR FINAL [ ] [ ] [ ] F=144 ILS 33R	1R
2	2L	TEMP SLT RETR BARO [ ]° S=188 [ ]	2R
3	3L	MAG WIND CLEAN RADIO [ ]°/[ ] 0=200 367	3R
4	4L	TRANS ALT LDG CONF 4000 CONF3·	4R
5	5L	VAPP VLS FULL 134 129	5R
6	6L	PREV NEXT PHASE <PHASE	6R

APPR is in large white font, if the approach phase is not active; it is in large green font, if it is.


[1L] QNH	<p>This field displays brackets, when the aircraft is more than 180 NM from the destination. Inside 180 NM, a mandatory amber box appears. The flight crew must enter the QNH in hPa or in inches of mercury.</p> <ul style="list-style-type: none"> <li>- For hPa, enter three or four digits</li> <li>- For inches of mercury: <ul style="list-style-type: none"> <li>• Enter two digits, or</li> <li>• Enter two digits followed by a decimal point and two additional digits.</li> </ul> </li> </ul> <p>The system interprets:</p> <ul style="list-style-type: none"> <li>- 1 003 as 1 003 hPa;</li> <li>- 29 as 29.00 in.</li> <li>- 29.92 as 29.92 in.</li> </ul> <p><i>Note:</i> An erroneous entry of an OAT in QNH field, for example 22 °C, or a higher value, is accepted by the system.</p> <p>The flight crew can modify this entry at any time.  The Cabin Pressure Controller (CPC) uses the QNH to compute the cabin repressurization segment. Therefore, an erroneous QNH entry may result in a cabin pressurization that is not appropriate.</p>
[2L] TEMP	<p>This field displays the temperature at destination. The field displays brackets until the pilot enters the temperature. The pilot can modify this figure.  The system uses this temperature to refine its computation of the descent profile (ISA model).</p>
[3L] MAG WIND	<p>The flight crew enters the magnetic wind in knots at the destination in this field. The system transmits any entry made in this field to the vertical revision and flight plan B pages (which display wind direction as true, not magnetic).</p>
[4L] TRANS ALT	<p>This field displays the transition altitude taken from the data base (small font) or entered by the flight crew (large font).  The flight crew can modify it at any time.</p>
[5L] VAPP	<p>The FMGC computes this approach speed, using the formula:  <math>VAPP = VLS + 1/3</math> of the headwind components (limited to <math>VLS + 5</math> as a minimum and <math>VLS + 15</math> as a maximum).  The flight crew can modify VAPP . A clear action reverts VAPP to the computed value.</p> <p><i>Note:</i> <math>VLS = 1.23 VS1G</math> of the selected landing configuration (full or 3).</p>
[6L] PREV PAGE	<p>This field displays this legend if the approach phase is not active.  Pressing this key calls up the descent performance page.</p>

[1R] FINAL	This field displays the approach specified in the flight plan. The flight crew cannot modify it through this field.
[2R] MDA/MDH or BARO 	<p>This field displays:</p> <ul style="list-style-type: none"> <li>- The Minimum Descent Altitude with associated brackets, or</li> <li>- The Minimum Descent Height with associated brackets, if: <ul style="list-style-type: none"> <li>- The QFE pin program is activated, or</li> <li>- The FCU setting is QFE, on aircraft equipped with the BARO  option.</li> </ul> </li> </ul> <p>The flight crew inserts the value, which it can modify at any time. If the flight crew makes an entry in [3R] or changes the approach, it clears this figure.</p>
[3R] DH or RADIO 	If the flight plan includes an ILS approach, this field displays "DH " or "RADIO"  and empty brackets. The flight crew inserts the decision height. The system will accept an entry of "NO", "NODH" or "NO DH". If the flight crew inserts an MDA or an MDH (or a BARO  value) in FIELD [2R], this erases the decision height, and this field reverts to brackets. The DH or RADIO range is 0 to 700 ft.
[4R] LDG CONF CONF 3	The flight crew can select configuration 3 by pressing the 4R key. This moves the * down to the [5R] field, which is displaying "FULL"?
[5R] FULL	The flight crew can use this key to select configuration FULL when necessary configuration FULL is the default landing configuration.
[6R] NEXT PHASE	Pressing this key calls up the go-around performance page.

**PERF GO AROUND PAGE**

Ident.: DSC-22\_20-50-10-25-00000604.0002001 / 01 OCT 12

Applicable to: ALL



TITLE

GO AROUND is in large white font, if the go-around phase is not active; it is in large green font, if it is.



[5L] THR RED ACC This field displays the thrust reduction altitude and the acceleration altitude.

**Thrust reduction altitude:**

- Altitude at which thrust must be reduced from takeoff/go-around thrust to maximum climb thrust
- “CLB ” or “LVR CLB” flashing on flight mode annunciator
- Defaults to 1 500 ft above destination runway elevation, or to the altitude set by the airline
- Can be modified by the crew (minimum 400 ft above destination runway elevation).

**Acceleration altitude:**

- Altitude at which target speed jumps to green-dot speed (see the note below)
- Defaults to 1 500 ft above destination runway elevation, or to the altitude set by the airline.
- Can be modified by the crew, but is always equal to (or higher than) the thrust reduction altitude.

[6L] PREV PHASE or This field displays this legend if the go-around phase is not active. Pressing the key calls up the PERF APPR page.

ACTIVATE APPR This field displays this legend if the go-around phase is active. Pressing it once makes “CONFIRM APPR” appear. A second press activates the approach phase.

[5R] ENG OUT ACC This display has the same characteristics as the display beside the 5R key on the takeoff page. It is for display only, and the pilot can modify it.

[6R] NEXT PHASE Pressing this key calls up the PERF APPR page.

[1R] Blank or EO CLR\* This field is normally blank. EO CLR\* is displayed when GO AROUND is the active phase and an engine-out condition is detected.

*Note: When the go-around phase is active, if the pilot enables ALTN or if the pilot inserts a new destination in the active flight plan and a new cruise flight level on the progress page, the go-around phase shifts automatically into the climb phase. (The target speed jumps from green dot speed to initial climb speed).*


**PROG PAGES**


Ident.: DSC-22\_20-50-10-25-00000605.0051001 / 22 MAR 17

Applicable to: ALL

The progress page is a multifunction page that enables the pilot to:

- Select a new cruise flight level
- Crosscheck the navigation accuracy of the Flight Management (FM) system and validate it
- Update the FM position
- Monitor the descent.





- TITLE** Different for each flight phase (see above). The vertical phase is in large green font. The flight number is in large white font. EO is large amber font, if the engine-out condition is detected.
- Line 1 CRZ (blue)** This line displays the cruise flight level, inserted on the INIT A page or directly in this field in blue. If the flight crew uses the FCU to select an altitude that is higher than the one displayed in this field, the system changes the number displayed to agree. In this line, the flight crew cannot insert a flight level that is lower than the FCU-selected altitude. This field shows dashes when the descent or approach phase is active.
- OPT** This field displays the optimum flight level (in green), that is computed based on the current gross weight, cost index, temperature and wind. This flight level requires a 5 min minimum cruise at a minimum cruise flight level of FL 100. It displays dashes if an engine-out is detected.

REC MAX

This field displays the recommended maximum altitude (in magenta), that is computed based on the current gross weight and temperature, and assuming that the anti-ice is off (if icing conditions are expected, Refer to QRH/PER-M Optimum & Maximum Altitudes (Paper Only) or the performance application of FlySmart with Airbus). It provides the aircraft with a 0.3 g buffet margin, a minimum rate of climb at MAX CL thrust, and level flight at MAX CRZ thrust. This field is limited to FL 398.  
 If one engine is out, this field displays the recommended maximum engine-out altitude, that is computed based on the long-range cruise speed and assuming that anti-ice is off.


[2L] REPORT

This key calls up the REPORT PAGE.

[2R] VDEV

This field is displayed during the descent and approach phases, when NAV mode is engaged, or in HDG mode, provided that the crosstrack error (XTK) is less than 5 NM. It displays the vertical deviation between the aircraft's current altitude and the FMS-computed vertical profile.




Line 3 POSITION  
 UPDATE AT 

The flight crew can update the FMS position via this field by entering either the IDENT of a waypoint, a NAVAID, an airport, a latitude and longitude (LL), a place/bearing/distance, or a place-bearing/place-bearing (PBX). When the flight crew has entered this data, this field changes its format to: "CONFIRM UPDATE AT", followed by the latitude/longitude and IDENT of the inserted position with an asterisk.

The flight crew presses the right-hand key adjacent to the asterisk to confirm the update, when the aircraft overflies the inserted position.

*Note: If no IDENT has been inserted, the field displays "ENTRY" instead of an IDENT.*




Line 4 BRG/DIST

On this line, the pilot can enter an airport, a waypoint, a NAVAID , or a runway. The pilot may enter each as an IDENT , a latitude/longitude (LL ), a place/bearing/distance (PBD), or a place-bearing/place-bearing (PBX). The field then shows the FMGC -computed bearing and distance from this site to the aircraft's present position. The last distance digit is in 1/10 of a NM. If it does not have an IDENT, the point is called "ENTRY".

Example:

BRG /DIST

340 °/95.4 to ENTRY



[5L] PREDICTIVE GPS This prompt gives access to the PREDICTIVE GPS page.

[5R] GPS PRIMARY This prompt is displayed, when the FMS navigation mode is GPS PRIMARY. When GPS PRIMARY is not available, or navigation mode is not GPS/IRS, this field is blank.

The scratchpad displays the relevant “GPS PRIMARY” message when this prompt appears; and “GPS PRIMARY LOST”, when the field turns to blank.

[6L] REQUIRED This field displays the default value for the required navigation accuracy level. The pilot can modify it. Provided no pilot entry has been made, the default value changes according to the actual flight area (En route, terminal, approach).

ACCUR HIGH/LOW This field shows the flight management system’s estimate of the navigational accuracy. “HIGH” indicates that the FMS estimates that the navigational accuracy matches the accuracy criteria of the area currently flown. “LOW” indicates that the criteria are not matched.

[6R] ESTIMATED This field displays the current estimated navigation accuracy value (EPE) as computed by the FMS.


**PREDICTIVE GPS PAGES**

Ident.: DSC-22\_20-50-10-25-00009139.0001001 / 31 AUG 17

Applicable to: ALL

- Note:
1. This page is only operative with Honeywell ADIRS.
  2. This page cannot be used as a substitute to determine pre-flight planning RAIM availability when required by operational regulations. Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed).

The pilot accesses this page by pressing the PREDICTIVE GPS prompt of the PROG page. This page displays information relative to theoretical predictive availability of GPS PRIMARY at destination, and at any waypoint selected by the crew.



[1L] DEST

Destination, airport as currently selected in active flight plan. It is not modifiable. This field displays dashes, when no destination airport exists.

[1R] ETA

This field is defaulted to the Estimated Arrival Time, as computed by the FMS (small blue font). The pilot may enter a value in this field (large blue font). Amber boxes are displayed, when no prediction exists, or the crew entry has been cleared.

Line 2 PRIMARY Y/N	<p>Predicted primary status at destination airport, at the following times: Estimated time of arrival <math>\pm 5, 10, 15</math> min. Availability of GPS PRIMARY at the corresponding time is indicated by Y, when PRIMARY is predicted to be available; and, by N, when GPS PRIMARY is predicted not to be available. These fields are blanked when the destination [1L] field, or the time [1R] field is not defined.</p>
[3L] WPT	<p>The pilot may enter a reference waypoint in this field. Blue brackets are displayed, when no entry has been made.</p>
[3R] ETA	<p>When a reference waypoint has been entered in the [3L] field, amber boxes are displayed. The crew is requested to enter a reference time in this field.</p>
Line 4 PRIMARY Y/N	<p>Information equivalent to [2L] / [2R] is displayed for any pilot-selected waypoint. The corresponding time of arrival is also displayed.</p>
Line 5 DESELECTED SATELLITES and Line 6 SATELLITES	<p>Enables the pilot to deselect up to four satellites by inserting the corresponding satellite number ; the number is then displayed in large blue font. When deactivated, the satellites are not considered for predictive GPS availability at destination, or at the selected waypoint. The deselection is cancelled when the entry is cleared (blue brackets are displayed), or the field is overwritten by a different satellite number.</p>

**REPORT PAGE**

Ident.: DSC-22\_20-50-10-25-00000606.0009001 / 14 MAY 12

Applicable to: ALL

The pilot calls this page by pressing the [2L] key on the PROG page:



The diagram illustrates the MCDU display for the REPORT AI101 page in three different phases. Each page is shown in a rounded rectangular box with row labels on the left (1L-6L) and right (1R-6R). A white arrow points from the first page to the second, and another from the second to the third.

**REPORT AI101 (PREFLIGHT PHASE)**

1L	<REPORT	1R
2L	UPDATE AT	2R
3L	*f	3R
4L	BRG/DIST	4R
5L	---*/--- TO	5R
6L	PREDICTIVE	6R
	<GPS	
	REQUIRED ACCUR	
	0.36NM HIGH	

**REPORT AI101 (IN FLIGHT)**

1L	OVHD	UTC	ALT	1R
2L	---	---	---	2R
3L	TO			3R
4L	AGN	1028	5000	4R
5L	NEXT			5R
6L	AUCH	1036	FL145	6R
	SAT	T.WIND	FOB	
	---	---	---	
	DEST	UTC	DIST	EFOB
	LFBZ	1110	396	2.0

**REPORT AI101 (IN FLIGHT)**

1L	OVHD	UTC	ALT	1R
2L	LMG	1013	FL380	2R
3L	TO			3R
4L	AGN	1028	FL380	4R
5L	NEXT			5R
6L	AUCH	1036	FL380	6R
	SAT	T.WIND	FOB	
	-42°	145°/063	18.0	
	T/D	UTC	DIST	
	AT FL380	1055	302	SEND*
	DEST	UTC	DIST	EFOB
	LFBZ	1110	396	2.0

This page displays information related to the FROM, TO, NEXT and DEST waypoints, as well as the current wind, temperature, distance and time to the next cruise profile change.

**TITLE (White)** Displays the flight number. This line displays EO in amber, in case an engine-out is detected.

**[1L] OVHD (green)** Displays the last sequenced waypoint. This field never displays the pseudo-waypoints and the F-PLN markers (T-P, PPOS, IN-BND, OUT-BND).

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION

- [1R] UTC/TIME ALT (green) This field displays the time and altitude recorded at the time of sequence.
- [2L]-[2R] TO (green) This field displays the active waypoint, predicted time of arrival and predicted altitude at this waypoint.  
*Note: Time and altitude values are identical to those values on the F-PLN pages.*
- [3L]-[3R] NEXT (green) Same information for the next waypoint.
- [4L] [4R] SAT/T.WIND/FOB (green) This field displays the static air temperature, the wind direction and velocity, and the FOB recorded at waypoint sequencing.
- [5L] T/D/UTC/DIST (green) This field displays the estimated time, and the distance to go to the next change of the cruise profile (T/D , S/C , S/D). These data are only displayed when the cruise phase is active.
- [5R] SEND\* (blue) The crew uses this prompt to downlink a position report. This field may be blank, depending on airline policy.
- Line 6 This field displays the estimated time of arrival, the distance along the F-PLN DEST/UTC/DIST/EFOB , and the estimated fuel on board (DEST EFOB) at destination. The DEST EFOB field will turn to amber, if the EFOB at destination becomes less than the MIN DEST FOB value displayed on the FUEL PRED page.. This display is identical to the information on the F-PLN pages.


*Note: No data can be inserted or modified on the REPORT page.*

**RADIO NAV PAGE**

Ident.: DSC-22\_20-50-10-25-00000607.0009001 / 06 APR 16

Applicable to: **ALL**

This page enables the pilot to select or verify the radio NAVAIDs, tuned for display purposes only. These NAVAID s include: VOR , VOR /DME , TAC , VORTAC, ILS , and ADF.



Line 1 VOR1/FREQ  
 FREQ/VOR2

This line displays the identifiers and frequencies of VORs 1 and 2, whether they are automatically or manually tuned.

To manually tune a VOR , the pilot inserts the IDENT or frequency. If the IDENT is not in the database, the new NAVAID page comes up. A “clear” action reverts the selection to the autotuned NAVAID.

Line 2 CRS

This line displays courses for the NAVAIDs in Line 1.

The pilot can manually enter the courses through these fields.

[3L] LS/FREQ

This field displays the IDENT of an ILS and its frequency (for ILS ). It is autotuned, if the ILS is associated to the departure runway, or if the flight plan contains an ILS approach. The flight crew may also enter an ILS manually. When the manually entered ILS differs from the ILS that the FMS would autotune, “RWY-LS MISMATCH” appears.

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

**CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION**

[4L] CRS SLOPE      CRS : This field displays the course associated with the LS displayed in Line 3. It comes up automatically if an LS is autotuned, or if an LS has been manually tuned via its IDENT. Otherwise, the course must be entered manually. The course may be backbeam (Bxxx) or frontbeam (Fxxx)..  
 SLOPE: This field displays the slope associated with the LS displayed in Line 3. It comes up automatically if an LS is autotuned for approach, or if an LS has been manually tuned via its IDENT.

- Note:
1. *The slope does not apply to LOC only, LDA, SDF or Backbeam approaches.*
  2. *If the flight crew intends to manually tune an ILS that is not in the navigation database or to manually tune an ILS by its frequency (ident not entered), and if they do not enter the course, the flight crew will not be able to arm approach modes.*

Line 5 ADF1/FREQ      This line displays the identifiers and frequencies of ADFs 1 and 2.  
 FREQ/ADF2      The pilot can use the IDENT or the frequency to manually tune the ADF.

Line 6 ADF1/BFO      When an ADF is selected, these fields display an ADF /BFO prompt. The  
 BFO/ADF2      flight crew presses the key once to erase the arrow and put the ADF in BFO mode. A clear action brings the arrow back and cancels BFO.

- Note:
- *The autotune function only works for NAVAIDs stored in the database.*
  - *When tuning manually, the operator should use the IDENT , rather than the frequency, unless the NAVAID is not in the database.*
  - *Manually-tuned frequencies are displayed in large font.*

**SECONDARY PAGES**

Ident.: DSC-22\_20-50-10-25-00000608.0009001 / 13 FEB 13


Applicable to: **ALL**

The SEC F-PLN key on the MCDU console allows the flight crew to call up the secondary index page and the secondary flight plan page. The secondary flight plan is generally for a diversion, for predictable runway changes for takeoff or landing, or for training.

There are two types of secondary index pages. The type selected depends on the presence of a secondary flight plan.

**SECONDARY INDEX PAGE**

**A SECONDARY FLIGHT PLAN IS ALREADY DEFINED**



- |                           |  |
|---------------------------|--|
| [1L] COPY ACTIVE (blue)   | The flight crew presses this key to copy the active flight plan into the secondary flight plan and delete the previous secondary plan. |
| [2L] SEC F-PLN (white)    | The flight crew presses this key to call up the secondary flight plan pages.   |
| [3L] DELETE SEC (blue)    | The flight crew presses this key to delete the current secondary flight plan.  |
| [4L] ACTIVATE SEC (amber) | The flight crew presses this key to activate the secondary flight plan as the active flight plan.                                      |

*Note:* "ACTIVATE SEC" routinely appears if the HDG/TRK mode is active. If the NAV mode is active, "ACTIVATE SEC" appears only if the active and secondary flight plans have a common active leg.

- |                     |  |
|---------------------|--|
| [ 1R ] INIT (white) | The flight crew presses this key to call up the SEC INIT A page.                                 |
| [2R] PERF (white)   | The flight crew presses this key to call up the performance pages for the secondary flight plan. |

**A SECONDARY FLIGHT PLAN IS NOT DEFINED**



- [1L] COPY ACTIVE (blue)      The pilot presses this key to copy the primary active flight plan into the secondary flight plan.
- [2L] SEC F-PLN (white)      The pilot presses this key to call up the secondary flight plan pages.
- [1R] INIT (white)      The pilot presses this key to call up the secondary INIT page. It is similar to the active INIT page, but blue brackets replace all the amber boxes.

**SECONDARY FLIGHT PLAN PAGES**

The secondary flight plan pages A and B are identical to those of the active flight plan, but are automatically sequenced, only when the secondary is copied from the primary and their active legs are identical.

The active and secondary flight plans pages differ from each other as follows:

**SECONDARY LATERAL REVISION PAGES:**

- ERASE and INSERT are not displayed.
- FIX INFO is not available.
- A lateral revision of the secondary flight plan does not create a temporary flight plan: All revisions are directly applied to the secondary flight plan.

**SECONDARY VERTICAL REVISION PAGES:**

A vertical revision on the secondary flight plan does not create a temporary flight plan.

**SECONDARY INIT A AND B PAGES:**

- They use blue brackets, instead of amber boxes.
- They have no align prompt.
- They do not provide for slewing or entering data in the 4L-4R fields (airport reference).

**SECONDARY STEP ALTITUDE PAGES:**

These pages operate as the primary STEP ALTS page, except that optimal step, savings are not available.

**SECONDARY WIND PAGES:**

They have no history wind page.


**SECONDARY PERFORMANCE PAGES:**

- All boxes are replaced by blue brackets.
- They have no engine-out mode, no engine-out long range cruise cost index.
- They have no expedite predictions.
- They have no ACTIVATE/CONFIRM APPROACH PHASE prompt.
- They have no PRED TO ALTN predictions on the PERF CLB and PERF DES pages.
- They have no engine-out drift down, no top of descent, no cabin descent rate information on the PERF CRZ page.

The secondary flight plan has no FUEL PRED page.

**SECONDARY INIT A PAGE IS ALSO USED TO REQUEST OR DISPLAY AN UPLINK INIT MESSAGE RECEIVED AFTER ENGINE START.**

This uplink INIT message can be cleared or inserted as SECONDARY INIT data.



[2R] INIT REQUEST\* Enable to request init data from the ground or,

[2R] INSERT UPLINK\* A downlink message has been received following a request.

The message can be cleared or entered in the SEC INIT page.





**BACK UP NAV PAGES**

Ident.: DSC-22\_20-50-10-25-00013508.0019001 / 29 JAN 13

Applicable to: ALL

The MCDU features a back up navigation function which provides simplified point-to-point GPIRS and IRS based navigation in case of a dual FM failure.

The backup Navigation mode allows limited lateral flight planning within the MCDU , that can be used to drive the Navigation Display and provides relative path position information and auto-sequencing of the Backup Navigation flight plan. The Backup Navigation flight plan reflects, as much as possible, the active primary FM flight plan upon its initial activation.

During FM normal operation, the F-PLN is continuously downloaded in the MCDU memory: the BACK UP NAV function links the MCDU of the failed FM to its onside IRS . All navigation data related to the MCDU F-PLN are displayed on the associated ND.


BACK UP NAV function is activated on the MCDU MENU page by pressing the NAV B/UP prompt. The MCDU back-up F-PLN may accept a maximum of 165 legs, including information such as waypoint position/identification, leg type, discontinuity, overfly and turn direction information (radial, pattern, heading leg... cannot be part of the MCDU F-PLN ). No secondary or temporary F-PLN exists.

BACK UP NAV pages display the data related to the BACK UP NAV function. There are six pages available while BACK UP NAV is active:

- B/UP F-PLN
- B/UP F-PLN for DIRECT TO
- B/UP PROG
- B/UP IRS for onside IRS (1+2)
- B/UP IRS 3
- B/UP GPS (if the GPS is installed)

**B/UP F-PLN PAGE**

The B/UP F-PLN page displays the MCDU F-PLN data. The pilot calls up this page by pressing the F-PLN key while B/UP NAV is active.



TITLE line 1 to line 5

B/UP F-PLN is displayed in a white large font


Display consecutive waypoints with their associated latitude/longitude. If a waypoint is to be overflowed, an overfly symbol (Δ) is displayed after the identifier.


If a turn is specified into the next leg, a large font arrow is displayed after the identifier.

Label lines contain the bearing, time to go and distance to the next waypoint displayed in small font.

white bearing

green time to go and distance

BRG Between FROM and TO waypoints: True or Mag depending on the TRUE pb-sw  position. T is displayed when the bearing is true referenced.

Between other waypoints: out bound true track of the great circle joining the 2 related waypoints, independant of TRUE pb-sw .


TTG HHMM limited to 9 959. Time between the 2 related waypoints.

DIST NM limited to 9 999.

line 6 DEST DEST airport identifier and associated latitude/longitude.  
 DIST to destination is computed as the direct distance from the aircraft to the active waypoint plus the along flight plan distances.  
 time to go to destination is computed as distance to destination divided by ground speed.  
 TTG and DEST are dashed if aircraft position is unavailable.

**B/UP F-PLN (DIR TO)PAGE**


The pilot calls up this page using the DIR key on MCDU while BACK UP NAV is active and aircraft position is valid.



TITLE [1L] DIR TO B/UP F-PLN is displayed in a white large font  
 Allows DIRECT TO selection to the desired waypoint.  
 This waypoint can be selected from the F-PLN or manually entered through the scratchpad (IDENT /LAT /LONG or LAT /LONG)

line 2 to line 6 Display consecutive waypoints of the F-PLN.  
 Same as the B/UP F-PLN page.  
 The TO WAYPOINT is displayed in [2L].  
 Vertical slewing function is available.


After a DIR TO selection, the B/UP F-PLN page is modified as following:



**B/UP PROG PAGE**

It displays flight parameters relative to the F-PLN or a selected waypoint.


The flight crew calls up this page by pressing the PROG key on MCDU when BACK UP NAV is active.



TITLE line 1 OVHD/ALT B/UP PROG is displayed in a white large font.



Displays the identifier of the last sequenced waypoint and the altitude at the time of the sequence.


line 2 BRG/DIST/TTG/TO Allows the flight crew to enter an existing MCDU F-PLN waypoint identifier or LAT /LONG or IDENT /LAT /LONG. MCDU then computes bearing, distance and time to go to that waypoint from the present position. The pilot may modify or clear this entry (2R field).


- BRG True or magnetic outbound track of the great circle joining aircraft present position to the entered waypoint: dependent on the TRUE pb-sw  position.
- DIST limited to 9 999.
- TTG HHMM limited to 9 959. time to go to the entered position computed assuming current ground speed.

These fields are displayed in a green small font.  
They are dashed if present position is unavailable.

[3L] Means of navigation used by the Back-Up Navigation. If GPS is fitted and is the navigation source, "GPS NAV " is displayed, otherwise "IRS ONLY NAV" is displayed.  
If the GPS is not installed, this field is blank.

[4L] IRS 1 (2 or 3) Current aircraft position provided by the selected IRS GPIRS  
BASED POS GPIRS 1 (2 IRS 1 (or 3 if IRS 1 failed) on MCDU 1  
or 3) (green) IRS 2 (or 3 if IRS 2 failed) on MCDU 2  
GPIRS 1 (or GPIRS 3) or MCDU 1   
GPIRS 2 (or GPIRS 3) or MCDU 2 

[4R] GS (green) Current ground speed from the selected IRS or GPS .


[5L] DTRK/TRK (green) Desired track of the MCDU F-PLN active leg and current aircraft track from the selected IRS /GPS (True or Mag).  
These tracks are true or magnetic depending on TRUE pb-sw  position.

[6L] IRS 1 (2) Gives access to onside B/UP IRS (1 or 2) page

[6R] GPS Gives access to B/UP GPS page.  
This prompt only appears when the GPS is installed.

**B/UP IRS 1 OR 2 OR 3 PAGE**

Display IRS 1, 2, 3 navigation data.  
The pilot calls up this page from B/UP PROG page, by pressing the corresponding prompt.



TITLE	B/UP IRS 1, 2, 3 displayed in a white large font.
[1L] POSITION	Current aircraft position from selected IRS
[2L] T TRK	True track
[2R] GS	Ground speed
[3L] T HDG	True heading
[3R] M HDG	Magnetic heading
[4L] WIND	Wind direction and velocity Wind direction is always true referenced.
[4R] GPIRS ACCUR	GPS accuracy in meters as in the IRS page.
[5R] GPIRS POSITION	If GPS is installed, the GPS IRS position is provided as in the IRS page.
[6L] RETURN	Gives access to B/UP PROG page

[6R] NEXT IRS Gives access to the next IRS page.  
 (Closed loop 1 → 2 → 3 → 1)


This page is not modifiable by the crew.

*Note:* The fields [4R] and [5L] are blanked when the GPS is not installed.

**B/UP GPS** 

Display GPS navigation data.

The flight crew calls up this page from B/UP PROG page, by pressing the corresponding prompt.



TITLE B/UP GPS 1, 2 displayed in a white large font.

[1L] GPS POSITION

Line 2: TTRK GPIRS position (latitude/longitude)

UTC: Time

GS: Ground Speed

Line 3: MERIT: GPS figure of merit

GPS ALT : GPS altitude

MODE/SAT: Navigation mode and number of tracked satellites. These values are displayed as in the FM GPS page.



[5R]

DESELECT/SELECT GPS : The flight crew may select and deselect the GPS for navigation Backup function. The default configuration is GPS selected.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - PAGE DESCRIPTION

Intentionally left blank



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - MESSAGES

**FMS2 Honeywell**

**MCDU MESSAGE LIST**

Ident.: DSC-22\_20-50-20-35-00000918.0020001 / 03 NOV 14

Applicable to: ALL

Messages displayed on the MCDU are of two types and displayed in two colors.

Type I : A direct result of a pilot action;

Type II : Information about a situation, or a call for pilot action;

Type II messages are stored in a first-in/first-out message queue (5 messages max)

They are suppressed, if correct data is entered or when they no longer apply

The flight crew can clear all messages by pressing the CLEAR key on the MCDU console.

Amber (A) : Important

White (W) : Less important

MESSAGE	TYPE/COLOR	CONDITIONS
A/C POSITION INVALID	II/A	The aircraft position has become invalid. If the message has been cleared and the flight crew attempts to call up the HOLD at PPOS or DIR TO page while the aircraft position is still invalid, then the message is displayed again.
ACT RTE UPLINK (ACARS msg)	II/W	A flight plan is stored in the active flight plan.
ALIGN IRS	II/A	Appears when the IRS are ready for alignment, but the INIT A page is not displayed on either side of the flight deck. The ALIGN IRS message requires that one of the flight crew call up the IRS INIT page, to align the IRS.
AREA RNP IS XX-XX	II/A	Displayed when the RNP value, manually-entered on the PROG page, is larger than the default RNP value associated to the current flight area and when there is no RNP value defined in the navigation database for the active leg or route.
AWY /WPT MISMATCH	I/W	The pilot entered VIA on the AIRWAYS page does not contain the revised point. If you enter a second airway IDENT, it must contain the first airway ending point.
BLOCK IGNORES RTA	II/W	A time constraint existing at initiation of flight planning, or an entry of a time constraint made after initiation of flight planning, are ignored by the fuel planning function.
CABIN RATE EXCEEDED	II/W	This message appears when the aircraft gets within 200 NM of the destination and the computed rate of descent makes it impossible for the cabin to be repressurized at the maximum rate.
CHECK ALTN WIND (ACARS msg)	II/W	The uplinked alternate cruise flight level differs from the defaulted alternate cruise flight level.

*Continued on the following page*

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
CHECK APPR SELECTION *EFIS PFD (FMA)	II/W	Displayed when a NON ILS approach is part of the F-PLN and an ILS is manually tuned on RAD NAV page. This message reminds the flight crew that available guidance modes for the approach are APP NAV/FINAL.  Displayed when in cruise at less than 100 NM from the top of descent or in descent or approach phase.
CHECK CO RTE (ACARS msg)	II/W	The uplinked company route identifier differs from the one specified in the request.
CHECK DATA BASE CYCLE	II/W	The current date does not match the effective date of the active database, and someone attempts to enter a FROM/TO or CO RTE.
CHECK IRS 1(2)(3)/FM POSITION	II/A	Each IRS position is compared to the FM position. The difference is greater than a threshold function of time.
CHECK IRS /AIRPORT POS	I/A	The distance between ADIRS alignment position and the NAV Database Airport Reference Point is at least 5 NM
CHECK DEST DATA (ACARS msg)	II/A	The aircraft is at 180 NM from destination and the destination QNH , TEMP or WIND displayed on the PERF APPR page received by ACARS uplink has to be checked.  If a modification of these parameters is performed creating a conflict with previous data, the message is triggered again.
CHECK FLT NBR (ACARS msg)	II/A	The uplinked flight number differs from the flight number specified in the request.
CHECK MIN DEST FOB	II/W	This message appears when the flight crew has manually entered the MIN DEST FOB value, and MIN DEST FOB < ALTN + FINAL, being FINAL an ALTN valid data.
CHECK NORTH REF * EFIS ND	II/A	The MAG/TRUE sw does not correspond to the airport MAG /TRUE bearing reference (as stored in the FMGS navigation database), either at the departure airport (during preflight), or at the destination airport (when entering the ARRIVAL area).
CHECK QFE	II/A	This appears at the transition from QNH to QFE reference, when the QFE altitude differs by more than 100 ft from the predicted altitude, with the QNH set on the MCDU by means of the airport elevation in the NAV database.
CHECK TAKEOFF DATA	II/A	Following a flight crew entry or modification of one of the take-off parameters, there may be an inconsistency between the take-off runway or the TO shift and V1 , VR , V2 , FLEX TO temperature or derated level.  The flight crew activated the secondary F-PLN in PREFLIGHT or DONE phase.
CHECK WEIGHT	II/A	The gross weights (GW ) computed by the flight management computer (FMC) and the flight augmentation computer (FAC) disagree by more than 7 t (7.7 US tons).

*Continued on the following page*

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
CLK IS TAKEOFF TIME	II/W	This appears when the flight crew has entered an Estimated Takeoff Time (ETT), and the actual time is equal to ETT.
CLOCK/GPS TIME DIFF XX	II/A	Aircraft clock time and GPS time differ by more than XX minutes.
CROSSLOAD ABORTED	II/W	Message displayed on the transmitting MCDU, indicating an error in the transmission process.
CROSSLOAD COMPLETE	II/W	The database crossload from one FMGC to the other was successfully completed.
CRZ FL ABOVE MAX FL	II/W	This appears when the flight crew enters a cruise altitude that is above the computed maximum altitude.
CSTR DEL ABOVE CRZ FL	II/W	This appears when a flight plan altitude constraint has been deleted because the flight crew has inserted a cruise flight level, or step-down altitude that is at or below the flight plan constraint.
CSTR DEL UP TO WPT 01	II/W	This appears when constraints get deleted because the aircraft transitions to a go-around flight phase, before the FMGS sequences the flight plan destination.
DECELERATE or T/D REACHED (Also displayed on PFD)	II/W	One of these messages appears when the aircraft has reached the T/D in managed speed and it has not yet begun the descent.
DELETING OFFSET	II/W	This appears when the system is deleting an offset automatically, which it does under certain specific conditions, such as: <ul style="list-style-type: none"> <li>- Change of active leg due to lateral revision.</li> <li>- Termination of next leg at destination runway and the current distance to go is less than or equal to the distance required to reach the path, or the next leg is not a CF, FM or TF leg.</li> </ul>
DEST /ALTN MISMATCH	I/W	The pilot attempts to enter an alternate CO RTE (which starts at an origin that is not the primary flight plan destination).
DEST EFOB BELOW MIN	II/A	The EFOB at destination calculated by the FMS is less than the MIN DEST FOB value specified on the FUEL PRED page, for more than 2 min. The message is triggered in flight, except during Takeoff and Climb phases.
DIR TO IN PROCESS	I/W	The flight crew calls up the vertical or lateral revision page on one MCDU while the direct to page is displayed on the other MCDU.
ENTER DEST DATA	II/A	The flight crew has not entered wind, QNH, or temperature for the destination, and the aircraft is 180 NM out.
ENTRY OUT OF RANGE	I/W	The flight crew attempts to enter data that is out of the range specified for the selected field.
FLT NBR UPLINK (ACARS msg)	II/W	A flight number has been added to the uplink flight plan without previous request.
F-PLN ELEMENT RETAINED	I/W	The flight crew attempts to delete stored NAVAIDs, waypoints or runways that are contained in any flight plan or that are being tuned.

*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

CONTROLS AND INDICATORS - MCDU - MESSAGES

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
F-PLN FULL	II/W	There is not enough memory in the flight plan allotment for the computer to accept more flight plan data.
FMS 1/FMS 2 A/C STS DIFF	II/W	This message always precedes a transition to independent mode, and appears at power-up if the system detects a difference in one of the following: - NAV database serial number - Performance database - FM operational program - Aircraft and airline program pins
FMS 1/FMS 2 GW DIFF	II/W	Onside and offside aircraft weight differ by 2 t or more.
FMS 1/FMS 2 PGM PIN DIFF	II/W	Onside and offside program pins are different.
FMS 1/FMS 2 POS DIFF	II/A	Onside and offside positions differ by 0.5 NM or more (5 NM when GPS is not installed).
FMS 1/FMS 2 SPD TGT DIFF	II/W	Onside and offside target speeds displayed on the PFD differ by 5 kt or more.
FORMAT ERROR	I/W	A data entry does not meet the specified entry format for a given field.
GPS PRIMARY LOST (also displayed on ND)	II/A	Displayed when GPS PRIMARY mode is lost.
GPS PRIMARY	II/W	Displayed when the FMS is transitioning to GPS PRIMARY
GPS IS DESELECTED	II/A	This message appears when GPS has been manually deselected and the aircraft is 80 NM before the top of descent or in approach phase.
INDEPENDENT OPERATION	II/A	The FMGCs operate independently of each other.
INITIALIZE WEIGHT/CG	II/A	The zero-fuel weight or block fuel (FOB) is undefined after engine start.
INVALID FLT NBR UPLINK (ACARS msg)	II/W	The uplink message contains a valid flight plan but no flight number.
INVALID PERF UPLINK (ACARS msg)	II/W	Performance uplink message has been rejected.
INVALID RTE UPLINK (ACARS msg)	II/W	An error was detected into the uplink message and it is rejected.
INVALID TAKEOFF UPLINK (ACARS msg)	II/W	The current uplink takeoff data message is rejected.
INVALID WIND UPLINK (ACARS msg)	II/W	The current uplink wind message is rejected.
LAT DISCONT AHEAD	II/A	The next leg is a discontinuity and the aircraft is 30 s from flying the leg.
LIST OF 10 IN USE	I/W	The flight crew has tried to enter more than ten stored runways into the database, and all of the first ten are included in a flight plan or a pilot-stored route.

*Continued on the following page*

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
LIST OF 20 IN USE	I/W	The flight crew has tried to create a PBD, LAT /LONG , or PBX, or store a pilot-defined waypoint or NAVAID when 20 are already in use (in a flight plan or pilot-stored routes).
MACH SEGMENT DELETED	II/W	A constant Mach segment of the active flight plan has been automatically deleted. This occurs when the secondary flight plan or the alternate is activated, or engine out is detected or when the flight phase changes from CRZ to another one.
MCDU OVERHEATED	II/A	This message is displayed for 15 s in case of MCDU overheating.
MORE DRAG (EFIS PFD)	II/W	DES mode is engaged, idle is selected and the aircraft must decelerate in order to recover the path, or to respect an altitude constraint, a speed limit or a speed constraint.
NAV ACCUR DOWNGRAD (also displayed on ND)	II/A	NAV accuracy has been downgraded from HIGH to LOW. (See FMGS principles for an explanation).
NAV ACCUR UPGRAD (*EFIS ND)	II/W	NAV accuracy has been upgraded from LOW to HIGH.
NEW ACC ALT-HHHH	II/W	The acceleration altitude has been changed.
NEW CRZ ALT-HHHHH	II/W	The cruise altitude has been changed.
NEW THR RED ALT-HHHH	II/W	The thrust reduction altitude has been changed.
NO ANSWER TO REQUEST (ACARS msg)	I/W	A crew request, was previously sent to the ground and no answer has been received for 4 min.
NO INTERSECTION FOUND	I/W	The system could not find any common waypoint nor intersection point through the airway.
NON UNIQUE ROUTE IDENT	I/W	The flight crew has tried to enter on the new route page a company route IDENT that is identical to an existing company route IDENT (pilot-defined or in the database).
NOT ALLOWED	I/W	Data entry is not allowed in the selected field, or a selection action is not allowed.
NOT ALLOWED IN NAV	I/W	An attempt to modify the TO waypoint is made while in NAV mode.
NO NAV INTERCEPT	II/A	It is triggered, when NAV mode is armed and, no INTERCEPT waypoint exists before the TO waypoint.
NOT IN DATA BASE	I/W	The pilot is trying to enter or call up a company route IDENT , a FROM/TO pair, a place defined by place-bearing-distance (PBD) or place-bearing/place-bearing (PBX) or an airport NAVAID , waypoint runway, or NAVAID frequency (including pilot-defined elements) that is not in the current database.
NOT XMITTED TO ACARS (ACARS msg)	II/W	A pilot request or a crew report was sent but the communication was not established or not acknowledged.
ONLY SPD ENTRY ALLOWED	I/W	The pilot is trying to enter a Mach number for a preselected speed value on the CLIMB page.

*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**CONTROLS AND INDICATORS - MCDU - MESSAGES**

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
OPP FMGC IN PROCESS	II/W	The offside FMGC is unhealthy, and the FM system mode is SINGLE. The message indicates that the MCDU on which the message is displayed is being driven by the FMGC on the other side.
PAGE UPDATE IN PROCESS	I/W	The pilot presses a key on the flight plan page while predictions are being updated.
PERF DATA UPLINK (ACARS msg)	II/W	Performance data are received from ground.
PLACE/D IN TRANSITION	I/W	If a place/distance waypoint is defined within a pre-planned "fixed turn radius" transition, the entry is rejected and the "PLACE/D IN TRANSITION" scratchpad message is displayed.
PLEASE WAIT	I/W	Resynchronization between both FMGCs is in progress.
PROCEDURE RNP IS XX.XX	II/A	Displayed when the RNP value, manually-entered on the PROG page, is larger than the RNP value defined in the navigation database for the active leg or route.
PRINTER NOT AVAILABLE (ACARS msg)	II/W	A printer communication error has been detected while printing a report. The printing is terminated.
RADIONAV IS DESELECTED	II/A	Radio nav aids have been manually deselected and the aircraft is 80 NM before the top of descent or in approach phase.
REF/GPS POS DIFF	I/A	This message is displayed when there is a discrepancy between the reference position entered by the pilot and the GPS position.
REF/LAST IRS POS DIFF	I/A	This message is displayed when there is a discrepancy between the reference position entered by the pilot and the last stored IRS position.
REVISIONS NOT STORED	II/W	This message, displayed when a pilot-defined route or company route (active or secondary flight plan) is stored, indicates that the following elements are not retained: <ul style="list-style-type: none"> <li>- Pilot-entered holds</li> <li>- Offsets</li> <li>- Modifications to terminal area procedures</li> <li>- Pilot-entered constraints</li> <li>- Pseudo waypoints</li> <li>- Step at optimum.</li> </ul>

*Continued on the following page*



*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
RTA DELETED	I/W	A time constraint is automatically deleted: <ul style="list-style-type: none"> <li>- In case of engine-out</li> <li>- When entering the holding pattern</li> <li>- In case of go-around</li> <li>- At phase transition from descent or approach to climb or cruise</li> <li>- When a time constraint is inserted in the same flight plan at a different waypoint</li> <li>- When the alternate flight plan is activated</li> <li>- When a DIR TO/ABEAM is performed, only if the time constrained waypoint is projected as an ABEAM waypoint</li> <li>- The time constrained waypoint is cleared or sequenced (regardless of active lateral mode)</li> <li>- Valid clock data is lost</li> <li>- The time constraint belongs to the active flight plan and the secondary flight plan is activated</li> <li>- The time constraint belongs to the secondary flight plan and COPY ACTIVE is performed.</li> </ul>
RTA EXISTS	I/W	Displayed if the pilot tries to clear an estimated takeoff time defined by the system.
RTE DATALINK IN PROG (ACARS msg)	I/W	A flight plan modification is performed after a F-PLN INIT request has been sent. This message is displayed until the uplink is entirely received.
RWY/LS MISMATCH	I/A	<ul style="list-style-type: none"> <li>- During climb, cruise, (ILS or MLS ) descent approach, or go-around, the LS frequency entered on the RAD NAV page does not match the LS associated with the destination runway.</li> <li>- During preflight or takeoff, the LS frequency entered on the RAD NAV page does not match the LS associated with the takeoff runway.</li> </ul>
SEC RTE UPLINK (ACARS msg)	I/W	A flight plan is stored in the secondary flight plan.
SELECT DESIRED SYSTEM	I/W	The MCDU displays its MENU page.
SELECT TRUE (also displayed on the ND)	I/A	The MAG/TRUE sw is set to MAG , while the IRS send true HDG /TRK.
SENSOR IS INVALID	I/W	<ul style="list-style-type: none"> <li>- The pilot has selected FF or FQ, or FF + FQ, or FQ + FF on the FUEL PRED page and the sole sensor or both of the selected sensors are invalid, or</li> <li>- The flight crew has entered fuel on board only, and the FF sensor is invalid.</li> </ul>

*Continued on the following page*

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
SET GREEN DOT SPEED (*SET GREEN DOT* displayed on PFD)	II/W (W)	This message appears when the following conditions are all met: - Engine-out condition - Aircraft in selected speed mode - FCU -selected speed equal to or greater than green-dot speed +10 kt, and ALT * or ALT not active, or FCU-selected speed equal to or less than green-dot speed -10 kt.
SET HOLD SPEED (also displayed on PFD)	II/W (W)	This instruction appears when the aircraft is in selected speed, the pilot has inserted a hold in the flight plan, the aircraft is 30 s or less from the point where it must start decelerating towards hold speed, and the selected speed differs from the hold speed by more than 5 kt.
SET MANAGED SPEED or CHECK SPEED MODE (Also displayed on PFD)	II/W (W)	The target speed is selected for the current phase, but there is no preselected speed for the next flight phase. When this is so, one of these messages is displayed at transitions from climb to cruise, and from climb or cruise to descent. The message is always displayed at the transition to descent from climb or cruise if selected speed is active. It is not displayed if managed speed is active.
SETTING SPD/RTA	II/W	Displayed when the system recomputes its managed speed target to satisfy the RTA constraints.
SPECIF NDB UNAVAIL	II/A	The NDB to be autotuned (specified for a NDB approach) is not available.
SPECIF VOR-D UNAVAIL (also displayed on ND)	II/A	- The VOR , VOR -DME , or VORTAC to be autotuned (specified for an RNAV or VOR approach) has previously been deselected by the flight crew, or - The bearing, the frequency, or the IDENT of the VOR (or VORDME or VORTAC) to be autotuned is invalid.
SPD ERROR AT WPT 01	II/W	In lateral managed flight, the system predicts that the aircraft will miss a speed constraint by more than 10 kt. When the prediction changes to bring the miss within 5 kt, the message is cleared.
SPD LIM EXCEEDED	II/A	The aircraft is more that 150 ft below the speed limit altitude and more than 10 kt over green dot or the speed limit (which ever is smaller).
STEP ABOVE MAX FL	II/W	The pilot has entered a step altitude that is above the predicted maximum altitude.
STEP AHEAD	II/W	Indicates that the aircraft is within 20 NM of the active step point.
STEP DELETED	II/W	A step has been automatically deleted.
STORED ROUTES FULL	I/W	The system already contains five pilot-defined routes. (Only five are allowed.)
TAKEOFF DATA UPLINK (ACARS msg)	II/W	A takeoff data message is received.

*Continued on the following page*

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
TEMPORARY F-PLN EXISTS	I/W	The flight crew has selected any key (except ERASE or INSERT) or attempted a flight planning operation on the secondary flight plan while the system is displaying a temporary flight plan.
TIME ERROR AT WPT 01	II/W	While the aircraft is in lateral managed flight the FMGC predicts that it will miss a time constraint ( <i>Refer to DSC-22_20-30-20-25 Required Time of Arrival (RTA) - Entering a Required Time of Arrival</i> ).
TIME MARKER LIST FULL	I/W	The system already contains four time markers. (Only four are allowed).
TIME TO EXIT	II/A	The aircraft must leave holding immediately to satisfy fuel reserve requirements. (Extra fuel is zero).
TO SPEED TOO LOW	II/A	This message appears if the inserted V1 , VR , V2 speeds do not satisfy the existing regulatory conditions regarding VMC and VS1G speeds.
TOO STEEP PATH AHEAD	II/A	The system displays this message in cruise phase if the aircraft is within 150 NM of its destination or in descent or approach phase and in NAV mode and the descent profile contains a segment that is too steep.
TUNE BBB FFF.FF	II/A	The system cannot autotune the VOR for approach or position because of a manual VOR selection.
TURN AREA EXCEEDANCE	II/A	This message is displayed 1.5 min before entry of the PI leg, when in NAV mode, if the PI lateral path exceed the protection envelope defined in the Navigation database.
UNKNOWN PROGRAM PIN	II/W	The system has been unable to initialize because of an incompatible or undefined aircraft pin program combination (A/C type, engine type, VMO/MMO parity) in the FMGC software.
UPLINK INSERT IN PROG (ACARS msg)	II/W	Displayed when an uplink message is currently inserted in the FMGS.
USING COST INDEX-NNN	I/W	This message is displayed when the system contains a flight plan, and the flight crew tries to enter a zero fuel weight or a gross weight into it before defining a Cost Index (CI). (In this case, the FMS defaults to the Cost Index from the last flight). It is also displayed when the flight crew inserts the ALTN F-PLN (in this case, the FMS defaults the cost index to 0).
V1 /VR /V2 DISAGREE	II/A	This message is displayed when the entered V1 , VR and V2 speeds do not satisfy the condition $V1 \leq VR \leq V2$ .
WAIT FOR SYSTEM RESPONSE	I/W	During the time between a subsystem selection and the display of the subsystem page, the MCDU MENU page remains displayed with this message.
WIND DATA UPLINK (ACARS msg)	II/W	Uplink wind message has been received.
WIND UPLINK EXISTS (ACARS msg)	I/W	A flight plan modification (active or secondary) is attempted when uplink winds are not inserted yet.

*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - MESSAGES

*Continued from the previous page*

MESSAGE	TYPE/COLOR	CONDITIONS
WIND UPLINK PENDING (ACARS msg)	I/A	A temporary flight plan exists or a DIR TO page is displayed and a wind uplink is received and stored.
XXXX IS DESELECTED	I/W	The flight crew attempts to enter a deselected NAVAID , via the SELECTED NAVAID page, that has already been deselected.

**MCDU DATA FORMAT LIST**

Ident.: DSC-22\_20-50-30-00000920.0051001 / 21 MAR 16

Applicable to: ALL

The following chart lists all the data the pilot may enter on the MCDU.

It also shows the acceptable format for the various data items, the acceptable range, the units of entry, and the MCDU pages on which the data can be entered.

The following codes are used to indicate various data formats:

- A : letters
- N : numbers
- X : letters and numbers






DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>ACCEL ALT</b>	See ALT		ft (MSL)	TAKEOFF (ACT/SEC <sup>(2)</sup> ) GO AROUND (ACT/SEC <sup>(2)</sup> )
<b>ALT</b>	NNNN or NNNNN (leading zeros must be included)	Max ALT = 39 000 Entry is rounded to the nearest 10 ft	ft (MSL)	PERF CLB PERF DES
<b>ALT CSTR</b>	See ALT	See ALT	ft (MSL)	VERT REV F-PLN A SEC F-PLN A
<b>AIRWAYS (VIA)</b>	XXXX	If not in data base "NOT IN DATA BASE" is displayed	N/A	LAT REV AIRWAYS <A>
<b>ARPT</b>	AAAA 1 character minimum. 4 maximum.	If AAAA is not in the database airport file, the New Runway page is displayed		INIT A (ACT/SEC <sup>(2)</sup> ) LAT REV ALTN F-PLN A-B (ACT/SEC <sup>(2)</sup> ) WAYPOINT DIR TO
<b>BARO</b>	Same as ALT	Ldg elevation to Idg elevation + 5000	ft (MSL)	PERF APPR (ACT/SEC <sup>(2)</sup> )
<b>BLOCK FUEL</b>	NN.N leading zeros may be omitted.	0-80/0-175.2	Thousands of Kg or thousands of Lb	INIT B (ACT/SEC <sup>(2)</sup> )
<b>CABIN RATE</b>	- NNN (- may be omitted)	100 - 999	ft/min	DES FORECAST or CRUISE PERF PAGE <A>
<b>CG</b>	NN.N	8.0 - 45.0	% MAC	INIT B. (ACT/SEC <sup>(2)</sup> ) FUEL PRED
<b>CHANNEL</b> <A>	NNN	500 - 699		NEW NAV AID RAD NAV

Continued on the following page

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - DATA FORMAT LIST

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>CLASS (NAVAID)</b>	AAAAAA (refer to RANGE for exact inputs allowed)	VOR DME VORDME VORTAC LOC , ILS NDB ILSDME MLS  TACAN 	N/A	NEW NAVAIID
<b>CO RTE</b>	XXXXXXX 7 or 10 characters (pin program)	If not in the NAVdatabase, a message will be displayed	N/A	INIT A ROUTE SELECTION NEW ROUTE ALTERNATE
<b>COST INDEX</b>	NNN may be entered as 1-3 digits; leading zeros may be omitted	0 to 999	Kg/Min or 100 lb/Hr	INIT A (ACT/SEC <sup>(2)</sup> ) PERF CLB (ACT/SEC <sup>(2)</sup> ) PERF CRZ (ACT/SEC <sup>(2)</sup> ) PERF DES (ALT/SEC <sup>(2)</sup> )
<b>CRS</b>	See INB CRS	See INB CRS	degrees	RADIO NAV NEW NAVAIID NEW RUNWAY
<b>CRZ FL</b>	Must be entered as FLIGHT LEVEL	Maximum FL (See FLIGHT LEVEL)	Hundred of ft	INIT A (ACT/SEC <sup>(2)</sup> ) PROG
<b>CRZ TEMP</b>	See TEMP		See TEMP	INIT A (ACT/SEC <sup>(2)</sup> ) FUEL PREDICTION
<b>CRZ WIND</b>	See WIND DIR/MAG	See WIND DIR/MAG	See WIND DIR/MAG	INIT A (ACT/SEC <sup>(2)</sup> ) FUEL PREDICTION
<b>DIST</b>	NN.N leading and trailing 0's may be omitted.	0 - 99.9 or 0 - 999 (or 9999  )	NM NM	HOLD ALTN
<b>DRT TO</b> 	"D"NN	Eight possible values		PERF TAKEOFF
<b>EFF WIND</b> 	± NNN "±" may be entered as "T" or "TL" "-" may be entered as "H" or "HD" Leading zeros may be omitted If no sign is input, "+" is taken	0 - 500	kts	CLOSEST AIRPORT EQUI-TIME INIT A SEC INT A

*Continued on the following page*

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>ELV</b>	± NNNN if no sign, + assumed Leading 0's may be omitted	Entry displayed to nearest 10 ft -400 to 20 470 ft (RWY) (or - 1000 to 20 470 ft <math>\triangleleft</math> ) -2 000 to 20 470 (NAVAID)	ft (MSL)	NEW RUNWAY  NEW NAVAID
<b>ETT/RTA</b> <math>\triangleleft</math>	HH:MM:SS	00:00:00 to 23:59:59	Hour HH Min MM Sec SS	RTA
<b>FF/FQ Sensors</b>	One or both may be entered, Both - /FF + FQ or - / FQ + FF Fuel flow - /FF Fuel Quantity - / FQ		N/A	FUEL PREDICTION
<b>FIG OF MERIT</b>	N	0 - 3	N/A	NEW NAVAID
<b>FINAL/TIME</b>	Only one may be entered at a time. NN.N or (NNN.N <math>\triangleleft</math> ) for FINAL NNNN for TIME	FINAL 0 - 10.0 (or 0 - 100 <math>\triangleleft</math> ) or 0 - 22.0 0 - 90 TIME	Thousand of kg or Thousand of lb minutes	FUEL PRED INIT B
<b>FLAPS</b>		0, 1, 2, or 3		TAKEOFF
<b>FLEX TO TEMP</b>	1. If Derated TO option not implemented: same as TEMP 2. If Derated TO option is implemented: F NN		NN in degrees centigrade	TAKEOFF
<b>FLIGHT LEVEL</b>	FLNNN or NNN Leading zeros on NNN may be omitted	Max FL = 390 (or Max FL = 410 <math>\triangleleft</math> )	Hundreds of ft (MSL)	F-PLN A-B, PROG VERT REV INIT A (ACT, SEC <sup>(2)</sup> ) PERF CLB PERF DES STEP PRED STEP ALTS <math>\triangleleft</math>

*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - DATA FORMAT LIST

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>FLIGHT NUMBER</b>	XXXXXXXX The 8 alphanumeric are not mandatory	N/A	N/A	INIT A F-PLN A-B
<b>FOB</b>	NN.N (leading zeros may be omitted)	See BLOCK	Thousands of kg or Thousands of Lb	FUEL PREDICTION
<b>FREQ</b>	NNN.NN ILS /VOR NNN.N NDB	108.00 - 117.95 190.0 - 1 750.0	MHz KHz	PROG. NEW NAVAID RADIO NAV
<b>FROM/TO</b>	AAAA /AAAA	AAAA must be in data base or message will be displayed	N/A	INIT A (ACT/SEC <sup>(2)</sup> )
<b>GW</b>	NN.N Leading and trailing zeros may be omitted	35 - 99.9 or 77.2 - 218	Thousands of kg or Thousands of Lb	FUEL PREDICTION
<b>IDLE FACTOR</b> ⚠	± N.N Leading and trailing zeros may be omitted	-9.9, +9.9	%	A/C STATUS
<b>INB CRS</b>	NNN Leading zeros may be omitted. An entry of 360 is displayed as 0.	000 - 359	Degrees	HOLD
<b>LAT</b>	DDMM.MB or BDDMM.M DD - degrees, MM.M - minutes, B - direction. Leading zeros may be omitted but the direction (B) is necessary. Latitude is displayed as DDMM.MB	B: N or S 0 ≤ DD ≤ 90 0 ≤ MM.M ≤ 59.9	Degree minutes tenths of minutes	INIT A (ACT/SEC <sup>(2)</sup> )
<b>LAT /LONG</b>	LAT /LONG See LAT and See LONG except both must be entered with "/" in between	See LAT and See LONG	See LAT and See LONG	F-PLN A-B (ACT/SEC <sup>(2)</sup> ) PROG NEW WAYPOINT NEW NAVAID DIR TO LAT REV NEW RUNWAY

*Continued on the following page*



*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>LENGTH</b>	NNNN Leading zeros may be omitted	1 000 - 8 000 m 3 282 - 9 999 ft	Meters or feet	NEW RUNWAY
<b>LONG</b>	DDMM.MB or BDDMM.M DDD - degrees MM.M - minutes B - direction. Leading zeros may be omitted but the direction (B) is necessary	B: E or W $0 \leq DDD \leq 180$ $0 \leq MM.M \leq 59$	Degree minutes tenths of minutes	INIT A
<b>MACH</b>	.NN The decimal point is necessary. Trailing zeros are not necessary	MAX = 0.82 MIN = 0.15	Mach Number	F-PLN A (ACT/SEC <sup>(2)</sup> ) PERF CLB PERF CRZ PERF DES
<b>MACH/SPD</b>	MACH and SPD must be entered with "/" between (See MACH and See SPD formats )	See MACH and See SPD	See MACH and See SPD	PERF DES (ACT/SEC <sup>(2)</sup> )
<b>NAVAID</b>	XXXX	Any alphanumeric	N/A	PROG NEW NAVAID NAVAID F-PLN A-B (ACT/SEC <sup>(2)</sup> ) LAT REV DIR TO RADIO NAV SELECTED NAVAIDS
<b>OFST</b>	NNB or BNN NN offset distance B direction	B: L or R $1 < NN < 50$	NM	LAT REV
<b>PERF FACTOR</b>	NN.N leading or trailing zeros may be omitted ( $\pm$ N.N)	-10.0 to +10.0 (or -9.9 - +9.9 $\triangleleft$ )	N/A	A/C STATUS








*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL







CONTROLS AND INDICATORS - MCDU - DATA FORMAT LIST

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>PLACE/BRG /DIST</b>	PLACE can be any data base ARPT , NAVAID or WAYPOINT - BRG must be a 3 digit entry without decimal digit. An entry of BRG = 360 is displayed as 0.	PLACE - If not in data base, a message "NOT IN DATA BASE" is displayed BRG - 000 - 360	N/A degrees	LAT REV (ACT/SEC <sup>(2)</sup> ) NEW WAYPOINT PROG DIR TO F-PLNA-B (ACT/SEC <sup>(2)</sup> ) STEP ALTS 
	DIST is NNN.N where leading zeros may be omitted ; all 3 parameters must be entered with "/" between	DIST - 0 - 999.9	NM	
<b>PLACE-BRG / PLACE-BRG</b>	See PLACE/BRG/ DIST A couple PLACE-BRG is entered with a dash in the middle. 2 couples have to be entered with "/" between	See PLACE/BRG/DIST	See PLACE/BRG/DIST	See PLACE/BRG/DIST
<b>PLACE/DIST</b> 	PLACE: See PLACE/ BRG/DIST DIST: See PLACE/ BRG/DIST	PLACE: See PLACE/ BRG/DIST DIST: 0 - 999.9	N/A NM	F-PLN A and B SEC F-PLN A and B LAT REV NEW WAYPOINT DIR TO STEP ALTS
<b>QNH</b>	NNNN (leading zero may be omitted).	950 - 1 050 (or 745 - 1050  )	Hecto-Pascals (hPa)	PERF APPR (ACT/SEC <sup>(2)</sup> )
	NN.NN (leading and trailing zeros may be omitted).	28.06 - 31.01 (or 22.00 - 31.00  )	In.Hg	
<b>RADIAL</b> 	NNN(T) 3 digits entry	000 - 360	Degrees	FIX INFO 1 to 4
<b>RADIAL IN</b> 	NNN(T) 3 digits entry	000 - 360	Degrees	DIR TO
<b>RADIAL OUT</b> 	NNN(T) 3 digits entry	000 - 360	Degrees	DIR TO FIX INFO 1 to 4

*Continued on the following page*

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>RADIO</b>	NNN	0-700 No is accepted if an ILS / GLS  ; APPR is selected	ft	PERF APPR (ACT/SEC <sup>(2)</sup> )
<b>RADIUS</b> 	DNNN 3 digits entry D is the identifiant of the circle radius	000 - 256	NM	FIX INFO 1 to 4
<b>REF FIX</b> 	See waypoint			FIX INFO 1 to 4
<b>RTE RSV</b>	may be entered as fuel or percentage of trip fuel	Fuel 0 - 10.0 0 - 21.7 % : 0 - 15.0	thousands of kg thousands of lb	INIT B (ACT/SEC <sup>(2)</sup> ) FUEL PRED
<b>RWY</b>	AAAAANND Where AAAA is See ARPT. NN is runway number (2 digits) must be entered D is L or R to be included only when there is more than one runway with the same number at ARPT.			RUNWAY NEW RUNWAY F-PLN A-B
<b>SAT /ALT</b> 	TEMP /ALT	See TEMP and See ALT	N/A	CRUISE WIND
<b>SET HDG</b> 	NNN/N (leading and trailing zeros may be omitted) will always be displayed as NNN/N	000.0 - 360.0	Degrees	IRS MONITOR
<b>SLOPE</b> 	NN.N	00.0 - 90.0	Degrees	NEW NAVAID
<b>SPD</b>	NNN (leading zero may be omitted)	MAX = 350 kt MIN = 90 kt	kt (CAS)	SEC F-PLN A PERF CLB PERF CRZ (ACT, SEC <sup>(2)</sup> ) PERF DES
<b>SPD CSTR</b>	See SPD	See SPD	kt (CAS)	F-PLN A (ACT/SEC <sup>(2)</sup> ) VERT REV (ACT/SEC <sup>(2)</sup> )



*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

CONTROLS AND INDICATORS - MCDU - DATA FORMAT LIST

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>SPD LIM</b>	SSS/NNNNN SSS is a speed NNNNN is an ALT or FLIGHT LEVEL (See ALT and See FLIGHT LEVEL)	SSS: See SPD	kt/ft (MSL)	VERT REV (ACT/SEC <sup>(2)</sup> )
<b>SPD/MACH</b>	See MACH/SPD	See MACH and See SPD	See MACH and See SPD	PERF DES (ACT/SEC <sup>(2)</sup> )
<b>STATION DEC</b>	NND Where NN is the declination and D is the direction. Leading zeros may be omitted. D is not required for an entry of zero declination.	NN: 01 - 99 D: E or W	Degrees	NEW NAVAID
<b>STEP ALT</b> 	SNNN or NNNS (where NNN is in Flight Level) or SNNNNN or NNNNNS (where NNNNN is in ALT) Leading zeros may be omitted	See FLIGHT LEVEL or See ALT	See FLIGHT LEVEL or See ALT	F-PLN A
<b>TAXI</b>	N.N Leading or trailing zeros may be omitted	0 - 9.9	Thousands of kg	INIT B (ACT/SEC <sup>(2)</sup> )
<b>TEMP</b>	± NN If no sign, + assumed	± 99	Degrees celsius	INIT A (ACT/SEC <sup>(2)</sup> ) FUEL PRED PERF APPR
<b>THR RED ALT</b>	See ALT	400 ft AGL mini	ft (MSL)	PERF TAKE OFF
<b>THS</b>	AAN.N or N.NAA where AA is UP or DN	max UP 7.0 max DN 5.0 increment 0.1	degrees	PERF TAKEOFF
<b>TRANS ALT</b>	See ALT			PERF GO AROUND
<b>TIME</b>	N.N	0 - 9.9	Minutes	HOLD
<b>TIME MARK.</b> 	HHMM	HH: 0 - 23 MM: 0 - 59	Hours Minutes	F-PLN A and B
<b>T.O SHIFT</b>	NNNN	1-Length of origin runway	m or ft	PERF TAKEOFF

*Continued on the following page*

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>TRIP WIND</b>	See EFF WIND		fts	INIT A SET INIT A
<b>TROPO</b>	See ALT	See ALT (or 60 000 $\triangleleft$ )	ft	INIT A FUEL PREDICTION SEC FUEL PREDICTION
<b>UTC CSTR</b>	HH MM Where HH are hours and MM are minutes. Leading zeros may be omitted 1 or 2 digit entry is interpreted as minutes	HH: 0 - 23 MM: 0 - 59	Hours and minutes	VERT REV
<b>V1</b>	See SPD		kt (CAS)	PERF TAKEOFF (ACT/SEC <sup>(2)</sup> )
<b>V2</b>	See SPD		kt (CAS)	PERF TAKEOFF (ACT/SEC <sup>(2)</sup> )
<b>VR</b>	See SPD		kt (CAS)	PERF TAKEOFF (ACT/SEC <sup>(2)</sup> )
<b>WIND</b>	See WIND DIR/ VELOCITY	See WIND DIR/ VELOCITY	See WIND DIR/ VELOCITY	F-PLN B (ACT/SEC <sup>(2)</sup> ) FUEL PREDICTION
<b>WAYPOINT</b>	XXXXX - may be from . 1-5 (1-7 $\triangleleft$ ) ) characters for waypoint. Acceptable as waypoint IDENT: ARPT NAVAID WAYPOINT LAT /LONG, PLACE BRG / PLACE BRG and PLACE/BRG / DIST PLACE/DIST $\triangleleft$ may be entered to define a waypoint			WAYPOINT NEW WAYPOINT F-PLN A and B (ACT/SEC <sup>(2)</sup> ) LAT REV PROG DIR TO FIX INFO $\triangleleft$ 1 AND 2 EQUI-TIME POINT $\triangleleft$ STEP ALTS $\triangleleft$ PREDICTIVE GPS $\triangleleft$

*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

CONTROLS AND INDICATORS - MCDU - DATA FORMAT LIST

*Continued from the previous page*

DATA NAME	FORMAT	RANGE (X is input)	UNITS	DISPLAY PAGE
<b>WIND DIR /WIND MAG</b>	NNN/NNN Both must be entered ; leading zeros may be omitted. An entry of WIND DIR = 360 is displayed as 0.	WIND DIRECTION 0 - 360	Degrees	INIT A PERF APPR (ACT/SEC <sup>(2)</sup> ) STEP PRED
		WIND MAG 0 - 200 (or 0 - 500 $\leq$ )	Kt	WIND F-PLN B VERT REV
<b>WIND DIRECTION/ MAG /ALT</b>	NNN/NNN/FL NNN or NNN/NNN/NN NNN	Direction and Velocity as above Minimum ALT 1 000	FL in hundred of ft, ALT in ft	DES FORECAST WIND PAGES $\leq$
<b>ZFW</b>	NN.N OR NNN.N Leading and trailing zeros may be omitted	MIN ZFW See – Max ZFW See	Thousands of kg or thousands of Lb	INIT B (ACT/SEC <sup>(2)</sup> )

<sup>(1)</sup> As defined in the Performance Data Base.

<sup>(2)</sup> ACT/SEC = Active or Secondary

**GENERAL**

Ident.: DSC-22\_20-60-10-00000921.0001001 / 10 DEC 09

**Applicable to: ALL**

The baro reference selector of the EIS (Electronic Instrument System) allows the pilot to use the standard barometric reference (STD), sea level atmospheric pressure (QNH), or atmospheric pressure at airfield elevation (QFE option) for the barometer setting.

The selected value is displayed in the baro reference display window of the EFIS control panel and on the Primary Flight Display (PFD) below the altitude scale.

The barometer setting is used as a reference for the altimeter of the PFD and for the PFD target altitude. In flight, it affects the predicted altitudes on the MCDU and the descent path computation.

**MCDU ALTITUDE PREDICTIONS**

**Applicable to: ALL**

Ident.: DSC-22\_20-60-10-A-00000922.0001001 / 10 DEC 09

**GENERAL**

The FMGS predicts at each waypoint of the flight plan an altitude that is a function of all data in the lateral and vertical flight plans.

Ident.: DSC-22\_20-60-10-A-00000927.0001001 / 10 DEC 09

**ON THE GROUND**

The altitude predicted at each waypoint is displayed as altitude in feet above mean sea level (AMSL) when it is below the transition altitude and as flight level when it is above the transition altitude. The altitude constraints are also displayed, and they follow the same rule (feet or flight level).

The predicted altitude is equal to the airport elevation plus the height you must attain in order to reach the waypoint in the applicable mode (climb or descent).



Ident.: DSC-22\_20-60-10-A-00000924.0001001 / 16 FEB 11

## **IN FLIGHT**

The predicted altitude is equal to the aircraft altitude (as a function of the barometer setting), plus or minus the height you must attain to reach the waypoint in the applicable mode (climb or descent).

- In climb:

Altitude predictions and constraints are displayed as altitude in feet above mean sea level (AMSL) at, or below, the transition altitude, and as the flight level above it.

For example : If the transition altitude is 5 000 ft and you insert an altitude constraint as 8 000 ft, the MCDU F-PLN A page displays it as FL 80

- In descent:

If “STD ” is selected on the EIS control panel, altitude predictions and constraints above the transition level are displayed as flight levels, and those below the transition level are displayed as altitude AMSL.

If sea level standard pressure (QNH ), or field elevation pressure (QFE option), is selected on the EIS control panel, altitude predictions and constraints are displayed as altitudes AMSL, regardless of the transition altitude.

For example: If the transition level is FL 50 and you insert an altitude constraint of 8 000 ft into the MCDU , the MCDU F-PLN S A page will display it as FL 80, if “STD ” is selected, and as 8 000 ft, if “QNH ” (or “QFE ” option) F-PLN A page is selected.

## **TARGET ALTITUDE ON PFD**

Ident.: DSC-22\_20-60-10-00000925.0001001 / 01 OCT 12

**Applicable to: ALL**

The PFD target altitude may either be:

- The altitude selected on the FCU, or
- A flight management altitude constraint, if the climb mode or descent mode is engaged and the system predicts a level-off at a constraint that comes before reaching the FCU altitude.

The PFD target altitude depends on the barometer setting:

- If “STD” is selected, the target is a flight level
- If “QNH ” or “QFE” is selected, the target is an altitude or height.

The aircraft will level off accordingly.




- Note:
- If the pilot changes the barometer setting during ALT \* or ALT CST\*, the aircraft may overshoot the target altitude, because the current value has been changed. However, the ALT \* and ALT CST\* modes allow the aircraft to regain the FCU altitude. As a general rule, avoid changing the barometer setting when in ALT \* or ALT CST\*
  - In aircraft equipped to use field elevation pressure (QFE option), switching from STD to QFE (or vice versa) in ALT CST\* green changes the target value and may revert the vertical mode into V/S mode.

**NOTE FOR AIRCRAFT WITH QFE (FIELD ELEVATION PRESSURE) PIN PROGRAM**

If you select “QFE ” on the EFIS control panel:

- The MCDU predictions follow the basic rules (altitudes are AMSL below the transition level, flight levels above it)
- The altitude constraints on the MCDU follow the basic rules
- The target altitude on the PFD is QFE related:
  - If the target altitude has been selected by the FCU, the aircraft will level off there.
  - If the target altitude is an altitude constraint, the PFD automatically shows that constraint as corrected by the airport elevation.



**PROCEDURES**

Ident.: DSC-22\_20-60-10-00000928.0001001 / 16 FEB 11

Applicable to: **ALL**

- The altitude constraints in departure and arrival procedures should be defined in the navigation database or by the pilot on the MCDU:
  - in terms of altitude AMSL below the transition altitude
  - in terms of flight level above the transition altitude

If a departure procedure defines an altitude constraint as an AMSL altitude above the transition altitude, you must convert it to STD, because the system and guidance will treat it as a flight level whenever you select the standard barometer setting.

- b. In climb you should switch from QNH (or QFE ) to STD on both EFIS control panels simultaneously when you reach the transition altitude.

All MCDU altitude predictions and altitude constraints and all PFD altitude targets will be displayed as flight levels.

- c. In descent, when ATC clears you to an altitude below the transition altitude, you can select QNH (or QFE ) on both EFIS control panels simultaneously.

All MCDU altitude predictions and constraints and PFD targets are now altitude AMSL.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

OTHER FUNCTIONS - EFFECT OF BARO REFERENCE SETTING

Intentionally left blank

### CLEARING THE SCRATCHPAD OF DATA OR MESSAGES

Ident.: DSC-22\_20-60-20-00000929.0001001 / 16 FEB 11

**Applicable to: ALL**

Press the “CLR” key with a single brief touch to erase the last alphanumeric character inserted in the scratchpad.

Press the key for more than three seconds to erase all the data inserted in the scratchpad. If the scratchpad is empty, it displays “CLR”.


### CLEARING DATA FIELDS

Ident.: DSC-22\_20-60-20-00000930.0001001 / 16 FEB 11

**Applicable to: ALL**

Clear a data field by pressing the “CLR” key, the scratchpad displays CLR, then select the prompt for the field you want to clear (3L for example).

- You cannot clear all data fields:
  - If the field contains data that has a default value or a value computed by the FMGC, the data reverts to this value.
  - Any attempt to clear the defaulted value has no effect.
- Clearing a constraint on the F-PLN page deletes both the speed constraint and the altitude constraint associated with the waypoint
- If you clear a data field that is a waypoint in the flight plan (primary or secondary), you delete this waypoint from the flight plan and create a discontinuity. The discontinuity can also be cleared in a similar way.



**GENERAL**

Ident.: DSC-22\_20-60-30-0000932.0002001 / 16 FEB 11  
**Applicable to: ALL**

Various features are provided to the crew in order to execute a diversion:

- The EQUITIME POINT
- The CLOSEST AIRPORTS pages
- The SECONDARY F-PLN
- The ENABLE ALTN function
- The NEW DEST revision

**EN ROUTE DIVERSION WITH SEVERAL AIRPORTS AVAILABLE**

Ident.: DSC-22\_20-60-30-00009508.0002001 / 16 FEB 11  
**Applicable to: ALL**

SELECT the CLOSEST AIRPORTS page.



SELECT the EFOB/WIND prompt.

INSERT the effective wind at selected airport.

CHECK the predictions and CHOOSE the adequate diversion airport.

PREPARE the diversion flight plan on the SEC F-PLN.

Note: Fuel/time predictions on the CLOSEST AIRPORTS page assume managed speed profile.

**EN ROUTE DIVERSION OVER OCEANIC OR DESERTIC AREA**

Ident.: DSC-22\_20-60-30-00009528.0001001 / 16 FEB 11

Applicable to: ALL

The diversion airports are usually determined before departure or using the CLOSEST AIRPORTS data.

SELECT the EQUI-TIME POINT page.



- ENTER the airport identns in 1L and 3L fields.
- ENTER the associated winds in 2L and 4L fields.
- CHECK the ETP position and time.
- ENTER a predicted time at ETP as time marker.
- PREPARE a diversion flight plan on the secondary flight plan.

**DIVERSION PREPARATION ON THE SECONDARY FLIGHT PLAN**

Ident.: DSC-22\_20-60-30-00009530.0002001 / 16 FEB 11


Applicable to: ALL

The following procedure shall be applied for all diversion cases, once the diversion airport has been selected, as well as the “most probable diversion point of the F-PLN”:

- PRESS the SEC F-PLN key
- PRESS the COPY ACTIVE prompt
- SELECT a lateral revision at diversion waypoint
- ENTER the ident of the diversion airport in the NEW DEST field.

*Then finalize the flight plan between the diversion point and the diversion airport. When the diversion airport is no longer applicable or ETP is sequenced, repeat the same procedure for the next diversion airport.*



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>OTHER FUNCTIONS - HOW TO EXECUTE A DIVERSION</p>
---	--

**MISCELLANEOUS**

Ident.: DSC-22\_20-60-30-00009531.0002001 / 16 FEB 11  
**Applicable to: ALL**

In some cases, the diversion airport may be simply chosen using the airports displayed on ND when AIRPORT is selected on the EIS control panel.

During oceanic or desertic area flights, the flight crew may use the PROG page, as follows:

ENTER the ident of the diversion airport in the 4R field of MCDU 1

ENTER the next diversion airport in the 4R field of MCDU 2

*Then, the FMS continuously calculated the BRG /DIST to the selected diversion airports.*

UPDATE the PROG pages when sequencing the ETP.

**EXECUTION OF THE DIVERSION**

Ident.: DSC-22\_20-60-30-00009532.0001001 / 16 FEB 11  
**Applicable to: ALL**

When the crew decides to divert:

PRESS the SEC F-PLN key.

SELECT the ACTIVATE SEC prompt.

SELECT DIR TO required point.



**DIVERSION TO THE ALTERNATE AIRPORT**

Ident.: DSC-22\_20-60-30-00009537.0001001 / 16 FEB 11

Applicable to: ALL


The primary F-PLN includes an alternate flight plan from destination to the preferred alternate airport. All fuel prediction and management (EXTRA fuel) take the alternate flight plan into consideration. If the crew decides to divert at the end of the cruise, or beyond the last ETP, or in the descent or go-around phases, this will most probably be to the alternate airport.

When the crew decides to divert:

SELECT a lateral revision at suitable waypoint  
SELECT ENABLE ALTN prompt  
CHECK the temporary flight plan and INSERT  
SELECT DIR TO required waypoint

Note:

- *In most cases, the LAT REV shall be selected at the TO WPT . This will facilitate the subsequent selection of the DIR TO waypoint.*
- *The ALTN flight plan shall be finalized, whenever the landing runway is known by the crew (before approach briefing).*  
*In most cases, this will ensure that the most probable flight plan is displayed on the MCDU once ENABLE ALTN is selected.*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p align="center">OTHER FUNCTIONS - ENGINE OUT</p>
---	---

**GENERAL**

Ident.: DSC-22\_20-60-40-00000937.0001001 / 16 FEB 11

**Applicable to: ALL**

When the FMGS detects an engine-out condition, the following occurs:

**FLIGHT MANAGEMENT PART**

Ident.: DSC-22\_20-60-40-00000938.0026001 / 16 MAR 11

**Applicable to: ALL**

- The managed target speeds is immediately set to a value that depends upon the flight phase
- All preselected speeds entered in the MCDU are deleted
- Step climb (or step descent), if entered, is deleted
- The time constraint is deleted
- The PROG page shows the engine-out maximum recommended (EO MAX REC) altitude
- The system automatically calls up the current performance page, which has the EO CLR (engine-out clear) prompt displayed in the 1R field (except during takeoff, before the diversion point is reached).

If the crew presses the EO CLR , the 2 engine predictions and performance will be restored. Reverting back to one engine-out performance is not possible, unless the system detects a new EO condition. Therefore, the pilot should not press the EO CLR key, if an actual engine-out is detected

**FLIGHT GUIDANCE PART**

Ident.: DSC-22\_20-60-40-00000939.0002001 / 04 JUL 17

Applicable to: **ALL**

- All selected modes remain available (the “HDG/TRK”, “V/S”, and “OPEN” modes, for example)
- In the speed reference system (SRS ) mode, the takeoff speed target is  $V_2$  , or the current speed if it is higher but no more than  $V_2 +15$ . The magenta triangle indicates  $V_2$  in all cases. The GO Around speed target is  $V_{APP}$  , or the current speed if higher, limited to  $VLS +15$  kt
- The system limits autopilot (AP ) and flight director (FD) bank angles during takeoff and approach phases as follows:
  - $15^\circ$  when the aircraft speed is below the maneuvering speeds (F, S, or Green Dot speed) -10 kt , and then
  - In selected lateral guidance:
    - Linear increase to  $25^\circ$  up to maneuvering speeds (F, S, or Green Dot speed) -3 kt
    - $25^\circ$  above maneuvering speeds (F, S, or Green Dot speed) -3 kt .
  - In managed lateral guidance:
    - Linear increase to  $30^\circ$  up to maneuvering speeds (F, S, or Green Dot speed) -3 kt
    - $30^\circ$  above maneuvering speeds (F, S, or Green Dot speed) -3 kt .

Note: *The engine-out bank angle limits apply, when the FG part of the FMGS has detected an engine-out. It cannot be cleared by the crew through the MCDU EO CLEAR prompt.*

**AUTOTHRUST**

Ident.: DSC-22\_20-60-40-00000940.0001001 / 16 FEB 11

Applicable to: **ALL**

The system extends the active range of the active engine from idle to maximum continuous thrust (MCT instead of CL thrust).

The Flight Mode Annunciator requests maximum continuous thrust on the live engine at a time that depends on when the engine-out occurs.

**ENGINE-OUT CONDITIONS**

Ident.: DSC-22\_20-60-40-00000941.0001001 / 16 FEB 11

Applicable to: **ALL**

The FMGS considers the aircraft to be in an engine-out condition, when one of the following conditions is present and the aircraft has commenced takeoff or is in flight:

- One engine master switch off, or
- $N_2$  below idle, or

- One thrust lever angle is below 5 ° with the other above 22 °, or
- The FADEC shows an engine fault.

## ENGINE-OUT SID

Applicable to: ALL


Ident.: DSC-22\_20-60-40-A-00000942.0001001 / 14 MAY 12

### GENERAL

An engine-out standard instrument departure (EOSID), when defined in the database, is always for a specific runway. It is indicated on the bottom line of the SID page for that runway, and you can select it manually.

The pilot can review the SID either by selecting the PLAN mode on the navigation display (solid yellow line), or by selecting it on the SID page. In the latter case, the navigation display shows the SID as a temporary flight plan.

The last point, if any, that is common to both the SID and engine-out SID is called the diversion point (DP).




Ident.: DSC-22\_20-60-40-A-00000943.0001001 / 14 MAY 12

### **WHEN AN ENGINE-OUT CONDITION OCCURS BEFORE THE DIVERSION POINT**

The MCDU automatically shows the engine-out SID as a temporary flight plan on the F-PLN page and on the ND. The EOSID can be inserted or erased.

**Note:** *The EOSID Diversion Point is the waypoint at which the EOSID diverges from the active SID.*

*If there is no common leg between the SID and the EOSID in the navigation database, the diversion point is by default the runway threshold. Therefore the SID and EOSID common leg(s) before the flight paths separation must be the same type and nature.*




Ident.: DSC-22\_20-60-40-A-00000944.0001001 / 14 MAY 12

**WHEN AN ENGINE-OUT CONDITION OCCURS AFTER THE DIVERSION POINT**

REMAIN on the SID path

*Note: The navigation display shows the engine-out SID as a yellow line for your information. Directing the aircraft to the EOSID should not be performed unless it allows obstacle clearance and the flight crew considers it is the best strategy for a particular case.*



Ident.: DSC-22\_20-60-40-A-00000945.0002001 / 14 MAY 12

**BELOW THRUST-REDUCTION (THR RED) ALTITUDE**

- The managed target speed changes to V2
- The PROG page displays the engine-out maximum recommended altitude



- The PERF TO page comes up on the display automatically with the “EO CLR” prompt in the 1R field
- The MCDU and the navigation display show the engine-out SID as a temporary flight plan, or the navigation display shows it for information only, depending upon the diversion point location.



**PROCEDURE**

● **When the aircraft reaches the engine-out acceleration altitude**

PUSH in the V/S knob to level off.

CLEAN up your configuration as the speed increases toward target speed.

*When the aircraft is clean and has reached Green Dot speed, “LVR MCT” flashes on the FMA,*

PULL out the altitude selector knob to resume the climb.

*The OP CLB. mode engages.*

MOVE the thrust lever for the live engine to “MCT” detent.

Ident.: DSC-22\_20-60-40-A-00000946.0006001 / 16 FEB 11

**ABOVE THRUST REDUCTION (THR RED) ALTITUDE**

- The managed target speed changes to V2
- “LVR MCT” flashes amber on the flight mode annunciator
- The PROG page displays the engine-out maximum recommended altitude
- The PERF TO page displays the “EO CLR” prompt in the 1R field
- The navigation display shows the EO SID.

## PROCEDURE

MOVE the thrust lever of the active engine to the MCT detent.

● **When the aircraft reaches the engine-out acceleration altitude:**

PUSH the V/S knob, in order to level off.

CLEAN UP configuration as the speed increases.

● **When the aircraft reaches Green Dot speed:**

PULL the ALT knob to resume the climb.

*Note: If necessary, move the thrust lever of the active engine to the TOGA detent. The Flight Mode Annunciator will display "LVR MCT", flashing in white, when the aircraft reaches Green Dot speed.*

## ENGINE-OUT IN CLB PHASE (ABOVE ACCELERATION ALTITUDE)

Applicable to: ALL

Ident.: DSC-22\_20-60-40-B-00000947.0003001 / 16 FEB 11

### ENGINE-OUT OCCURS WHILE AIRCRAFT IS ACTUALLY CLIMBING

- The managed target speed changes to Green Dot speed
- "LVR MCT" flashes white on the Flight Mode Annunciator
- The climb mode reverts to open climb (OP CLB) and the aircraft slowly decelerates down to Green Dot speed
- The MCDU shows the PERF CLB page with an "EO CLR\*" (clear engine-out) prompt
- The PROG page shows the engine-out maximum recommended altitude (EO MAX REC ALT).

## PROCEDURE

MOVE the thrust lever of the active engine to the MCT detent.

SET the altitude on the Flight Control Unit to an altitude below the engine-out maximum recovery altitude, as cleared by ATC.

INITIATE a diversion, when cleared to do so.

Ident.: DSC-22\_20-60-40-B-00000948.0001001 / 16 FEB 11

### ENGINE-OUT OCCURS WHILE THE AIRCRAFT IS FLYING IN ALT MODE AT AN ALTITUDE SET ON THE FLIGHT CONTROL UNIT

- The target speed is set to engine-out cruise speed (EO CRZ SPD), computed at the altitude set on the Flight Control Unit, but limited by the limit speed (SPD LIM), if there is one.

Other consequences and procedures are similar to previous engine out climb.

## ENGINE-OUT IN CRUISE PHASE

Ident.: DSC-22\_20-60-40-00000949.0001001 / 21 MAR 17

Applicable to: ALL

- The system sets the managed target speed to the higher of engine-out cruise Mach number or speed, or current speed.
- “LVR MCT” (or MCT) flashes on the Flight Mode Annunciator.
- The PERF CRZ page appears with the “EO CLR\*” (clear engine-out) prompt.
- The PROG page displays the engine-out maximum recommended altitude (EO MAX REC ALT).

### PROCEDURE

Perform engine out abnormal procedure.

Refer to *PER-OEI-GEN INTRODUCTION* “SINGLE ENGINE OPERATIONS”

- For standard strategy, Refer to *FCTM/PR-AEP-ENG Engine Failure During Cruise*
- For obstacle strategy, Refer to *FCTM/PR-AEP-ENG Engine Failure During Cruise*
- For fixed strategy, Refer to *FCTM/PR-AEP-ENG Engine Failure During Cruise*

Initiate a diversion if necessary.

**Note:** The engine-out descent strategy requires disconnection of the autothrust, and descent in OPEN DES mode.

Disconnecting the autothrust prevents an automatic setting of THR IDLE; therefore, the autopilot will fly the target speed in OP DES mode, with a thrust manually selected by the crew.

When reaching the FCU-selected altitude, or whenever normal descent is resumed to a lower altitude, reengage the autothrust.

## ENGINE-OUT IN DESCENT PHASE

Ident.: DSC-22\_20-60-40-00000951.0001001 / 16 FEB 11

Applicable to: ALL

- The managed target speed remains unchanged (ECON DES Mach number or speed, with any speed limitations).
- “LVR MCT” (or MCT) flashes on the Flight Mode Annunciator.
- The PERF DES page appears, showing the “EO CLR\*” prompt.
- The PROG page displays the engine-out maximum recommended altitude (EO MAX REC ALT).
- The descent mode (if engaged) reverts to V/S, if the aircraft is above the EO REC MAX. If not, the descent mode is maintained.

## PROCEDURE

MOVE the thrust lever for the live engine to the MCT detent.  
If necessary, SELECT a suitable flight mode for descent.  
DISCONNECT the autothrust and ADJUST thrust if necessary.

## **ENGINE-OUT IN APPROACH PHASE**

Ident.: DSC-22\_20-60-40-00000952.0001001 / 04 JUL 17

Applicable to: **ALL**

- The aircraft maintains approach speed (VAPP).
- "LVR MCT" (or MCT) flashes on the Flight Mode Annunciator.
- The PERF APPR page appears, showing the "EO CLR" prompt.
- The progress page displays the engine-out maximum recommended altitude (EO MAX REC ALT).

## PROCEDURE

MOVE the thrust lever for the live engine to the MCT detent.

### **CAUTION**

Below maneuvering speed (F, S, Green Dot) – 10 kt, the autopilot or flight director (AP/FD) cannot order a bank angle greater than 15 °.

Above maneuvering speed – 10 kt, this limit linearly increases until it reaches:

- In selected lateral guidance: 25 ° at maneuvering speed – 3 kt. The limit is then 25 ° for all speeds above maneuvering speed – 3 kt.
- In managed lateral guidance: 30 ° at maneuvering speed – 3 kt. The limit is then 30 ° for all speeds above maneuvering speed – 3 kt.

## **ENGINE-OUT IN GO-AROUND PHASE**

Ident.: DSC-22\_20-60-40-00000953.0002001 / 16 FEB 11

Applicable to: **ALL**

The results and procedures for takeoff phase apply, except that the displays do not show the engine-out SID.

**SECONDARY FLIGHT PLAN**

Ident.: DSC-22\_20-60-50-00000954.0011001 / 14 MAY 12

**Applicable to: ALL**


The secondary flight plan (SEC F-PLN) is an alternative flight plan which can be activated when required.

It may include all the vertical elements except history wind data.

The flight crew can:

- Create a secondary flight independently from the active flight plan (a secondary flight plan can be created while a temporary flight plan exists).
- Copy it from the active flight plan.
- Delete it completely.

- Activate it, when the “ACTIVATE SEC” prompt is displayed: The secondary flight plan becomes the active flight plan.



- The screen displays the “ACTIVATE SEC” prompt in flight if:
  - HDG (or TRK) mode is engaged, or
  - NAV mode is engaged, and the active leg of the primary and secondary flight plans is the same.
 The FMS sequences the secondary flight plan the same way as the active flight plan, when it is a copy of the active flight plan.

The navigation display shows the secondary flight plan in white. In PLAN mode, the crew can use the slew keys to review the secondary flight plan (as for the primary flight plan).

## **PREDICTIONS**

The FMGS computes predictions using the same performance methods and performance factor it uses for the active flight plan. However, it predicts pseudo waypoints only for the MCDU not for the Navigation Display (ND).

- **When the flight crew initializes the secondary flight plan with the SEC INIT function:**  
The FMGS computes the secondary flight plan predictions as if the aircraft were on ground before engine start. The FMGS computes these predictions one time and does not update them to indicate the progress of the flight (aircraft position, fuel consumption, etc.).
- **When the flight crew initializes the secondary flight plan with the COPY ACTIVE function:**  
The FMGS computes the secondary flight plan predictions as for the active flight plan. However:
  - The FMGS stops the update of the predictions if the first leg of the active flight plan is no longer the same as the active leg (i.e. if both flight plans diverge). The flight phase is the same as the flight phase at the time of the divergence.

*Note:* This does not apply to the preflight phase, when the FMGS computes the predictions if the departure airports are the same, even if the takeoff runways are different.
- **The flight crew may use the secondary flight plan in the following cases:**
  - At takeoff when an alternate takeoff runway is probable
  - On ground to initialize the FMGS again if the flight that the flight crew initially prepared is replaced by another flight (*Refer to PRO-NOR-SRP-01-05 Introduction*)
  - In flight to prepare a diversion
  - In flight when an alternate landing runway is probable
  - To prepare the next flight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

OTHER FUNCTIONS - SECONDARY FLIGHT PLAN

Intentionally left blank



**STORED ROUTE FUNCTION**


Ident.: DSC-22\_20-60-60-00000955.0002001 / 01 OCT 12

Applicable to: ALL

The stored route function allows the pilot to store or review as many as five different routes defined in an active or secondary flight plan.


This also allows the pilot to store a company route that is not yet in the database, but is expected to be flown several times (a charter route, for example).

Access the STORED ROUTES page from the DATA INDEX page.




A stored route can be reviewed by using the slew key.

In order to store a new route, first define the route through the active flight plan (on the ground only) or the secondary flight plan (on the ground or in flight) then proceed as described below.



**HOW TO STORE THE ACTIVE FLIGHT PLAN (DURING PREFLIGHT ONLY)**

- SELECT the DATA key on MCDU
- PRESS the “STORED ROUTES” key
- PRESS the “NEW ROUTE” key
- ENTER the name of the company route (optional).
- PRESS the “STORE ACTIVE F-PLN” key



### HOW TO STORE THE SECONDARY FLIGHT PLAN

SELECT the DATA key on MCDU  
PRESS the "STORED ROUTES" key  
PRESS the "NEW ROUTE" key  
ENTER the company route name (optional)  
PRESS the "STORE SECONDARY F-PLN" key

- Note:
- 1. In either case, you may only store a company route if the active or secondary flight plan is complete from origin to destination.*
  - 2. If you do not enter a name, the FMGS automatically names the stored route as "SRTE 1 (or 2 ...)" when it is stored.*
  - 3. The system does not retain several elements of the flight plans, when they are stored:*
    - Pilot-entered holds*
    - Offsets*
    - Pilot-entered constraints*
    - Modifications to a terminal procedure*
    - Pseudo waypoints**When this happens, it displays "REVISIONS NOT STORED".*
  - 4. If five routes are already stored the system will reject a new entry and display "STORED ROUTES FULL" on the MCDU . Delete one stored route by clearing the CO RTE name before inserting a new one.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

OTHER FUNCTIONS - PILOTS/STORED ROUTE FUNCTION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**  
OTHER FUNCTIONS - REPORT PAGE

### GENERAL

Ident.: DSC-22\_20-60-70-00006017.0001001 / 16 FEB 11

Applicable to: ALL

The REPORT page allows the crew to achieve the position reporting.

### REPORT PAGE ACCESS

Ident.: DSC-22\_20-60-70-00009524.0008001 / 29 SEP 15

Applicable to: ALL

The report page is accessed from the PROG PAGE.

1L

2L

3L

4L

5L

6L

```

<REPORT
  UPDATE AT
  *f  i
  BRG/DIST
  ---°/---,-
  PREDICTIVE
  <GPS
  REQUIRED
  2.0 NM
          
```

1R

2R

3R

4R

5R

6R

1L

2L

3L

4L

5L

6L

REPORT AI101

OVHD	UTC	ALT
---	---	---
TO		
AGN	1028	5000
NEXT		
AUCHE	1036	FL145
SAT	T.WIND	FOB
---	---	---
DEST	UTC	DIST EFOB
LFBZ	1110	396 8.2

1R

2R

3R

4R

5R

6R

REPORT PAGE IN  
PREFLIGHT PHASE

1L

2L

3L

4L

5L

6L

REPORT AI101

OVHD	UTC	ALT
LMG	1013	38000
TO		
AGN	1028	FL380
NEXT		
AUCHE	1036	FL380
SAT	T.WIND	FOB
-42°	145°/063	10.0
T/D	UTC	DIST
AT FL380	1055	302 SEND*
DEST	UTC	DIST EFOB
LFBZ	1110	396 8.2

1R

2R

3R

4R

5R

6R

REPORT PAGE  
IN FLIGHT

Note: In case a DIR TO with ABEAM WPT s is achieved, or in case a FIX INFO with ABEAM or RADIAL/CIRCLE intersection is inserted in the F-PLN , the TO WPT (provided on the REPORT page) will be the ABEAM WPT or the RADIAL/CIRCLE intersect waypoint, if any, as on the F-PLN page.

GLG A318/A319/A320/A321 For A/C: HC-CJV  
 FCOM

← B

DSC-22\_20-60-70 P 2/2  
 22 MAR 17

**CLOSEST AIRPORTS**


Ident.: DSC-22\_20-60-80-00006018.0001001 / 07 APR 11

Applicable to: ALL

The CLOSEST AIRPORTS page displays the four closest airports, from the position of the aircraft, found in the navigation database (*Refer to DSC-22\_20-50-10-25 Closest Airports Pages* for the page description), and the 5th airport, as selected by the crew.

For each airport, the FM computes:

- The BRG /DIST /ESTIMATED UTC from the position of the aircraft to the corresponding airport.
- The EFOB at the airport, assuming an EFFECTIVE WIND (defaulted or entered by the pilot).



Note: When the **CLOSEST AIRPORTS** page 2 is selected, the list of airports is automatically frozen, as indicated on the page.

The FUEL/TIME predictions to the closest airports use simplified assumptions:

- Managed speed profile in cruise, with the effective wind from the **CLOSEST AIRPORTS** page 2. In case of EO, Engine Out condition is considered.
- Continuous descent from CRZ FL down to the airport elevation.

Note: In case **SELECTED SPD** is used, the **CLOSEST AIRPORTS** page still provides good use to choose the applicable closest airport for diversion purposes. However, when **SELECTED SPD** is significantly different from **MANAGED SPD**, the predictions in terms of time and fuel must be disregarded since they are misleading.  
The predictions may then be checked on the **SEC F-PLN**.



**GENERAL**

Ident.: DSC-22\_20-60-90-00006019.0001001 / 16 FEB 11

**Applicable to: ALL**

The crew can enter a time marker in the F-PLN A or B page. Once entered, the FMGS displays a pseudo waypoint along the flight plan on the MCDU and on the Navigation Display. This pseudo waypoint shows the predicted location of the aircraft at the entered time.

**HOW TO INSERT A TIME MARKER**

Ident.: DSC-22\_20-60-90-00009522.0001001 / 01 OCT 12

**Applicable to: ALL**

WRITE the time marker in the scratchpad. The entry format is HHMM.  
 SELECT any left key of the F-PLN A or B page, to insert the time marker in the active flight plan.  
*The time marker is inserted in the flight plan according to time criteria, irrespective of the key chosen for entry.*

② ENTER →

① WRITE TIME MARKER

TIME MARKER →

PSEUDO-WAYPOINT

FROM	UTC	SPD/ALT	AI101 →
AGN	1149	/* FL120	
	BRG006°	24NM	
LACOU	1152	280/*FL205	
	TRK005	49	
(T/C)	1159	.78/FL330	
		43	
LMG	1205	*/"	
	UR10	96	
AMB	1217	*/"	
	DEST	UTC	DIST
EGLL27R	1300	352	EFOB 6.3
	1210		↑↓

FROM	UTC	SPD/ALT	AI101 →
AGN	1149	/*FL120	
	BRG006°	24NM	
LACOU	1152	280/*FL205	
	TRK005	49	
(T/C)	1159	.78/FL330	
		43	
(UTC)	1210	40	
(1210)	1210	*/"	
	DEST	UTC	DIST
EGLL27R	1300	352	EFOB 6.3
			↑↓

1R

2R

3R

4R

5R

6R

Prediction are recomputed. Time marker pseudo-waypoint is inserted along the active F-PLN (MCDU and ND)

*Up to four time markers may exist at a time. An attempt to enter a fifth time marker will cause the "TIME MARKER LIST FULL" message to appear on the scratchpad.*

GLG A318/A319/A320/A321 For A/C: HC-CJV	A to B →	DSC-22_20-60-90 P 1/2
FCOM		22 MAR 17

*The FMGS updates the time marker position with the predictions.*


*When the current clock time equals or exceeds the time marker entry, the FMGS sequences the time marker (even in preflight).*

**STEP CLIMB/STEP DESCENT**

Ident.: DSC-22\_20-60-100-00006020.0012001 / 12 APR 17

Applicable to: ALL

The STEP ALTS function enables to define the successive cruise Flight Levels. The optimum position to initiate a climb, from the initial (or current) cruise Flight Level to the next one, can also be determined.



**PRINCIPLE**

**GEOGRAPHIC STEPS**

Up to four geographic steps may be defined on the STEP ALTS page. These steps are initiated at the geographical position, along the F-PLN.

Rules

- The minimum step size is 1 000 ft.
- A Step Climb (S/C ) cannot follow a Step Descent (S/D).
- A STEP is automatically cleared, if:
  - The S/C (S/D) is sequenced without any level change done by the crew.
  - The crew achieves a LAT REV , which deletes the associated waypoint from the F-PLN
  - By EO condition.
- A STEP is manually cleared:
  - On the STEP ALTS page, by CLEARING the corresponding field.
  - On the F-PLN page, by CLEARING the (S/C ) or (S/D) pseudo-waypoints.
- A STEP entry is IGNORED, if the remaining CRZ distance is less than about 50 NM.
- Once the steps are inserted in the F-PLN, they are displayed:
  - On the MCDU , as (S/C ) , (S/D ) , (T/C ) , (T/D) pseudo waypoints.
  - On the ND, by associated white symbols.


**OPTIMUM STEP**

When geographic steps are inserted, or an altitude is entered, the FM proposes an OPTIMUM STEP start of climb position for the first step climb altitude ahead. Predicted FUEL and TIME savings are displayed when calculated to be greater than 100 kg or 1 min respectively. If no savings are found, no optimum step is proposed.

The OPT STEP is not automatically inserted. The crew must insert it, if appropriate. Once inserted, the OPT STEP point (OPT) becomes a fixed geographical point.

If some F-PLN parameters are subsequently changed (e.g. winds, new waypoints), an update of the optimum position relative to the previous one may be proposed. If savings exist, this new optimum may be inserted to replace the previous optimum step point.

Once an OPT STEP is inserted in the F-PLN, and the crew achieves a lateral F-PLN revision, the FM keeps the (OPT) along the new F-PLN, at the same distance from the aircraft's position, as previously determined.



Rules

- The OPT STEP is only computed by the FM, if data required for the prediction computation are inserted : F-PLN, CRZ FL, CI, GW, CG at least.
- The search of the OPT STEP begins 20 NM beyond (T/C) before Cruise, or ahead of the aircraft's position.
- The search of the OPT STEP ends 20 NM before the next STEP POINT, or 300 NM before the (T/D).
- Only one OPT STEP is computed at a time.

Guidance


When reaching the step point, the steps must be initiated by the crew by selecting the new CRZ FL, and pressing the FCU ALT selector knob. If sequenced without any crew action, the step is automatically deleted.

If the crew initiates the step:

- The CRZ FL is automatically reassigned to its new value.
- The guidance is THR CLB /CLB for a step climb.  
 THR IDLE/DES with V/S = -1 000 ft/min for a step descent.

**STEP ENTRY**

The STEP ALTS page is either accessed from : - The VERT REV page, or  
 the - PERF CRZ page.




**FOR GEOGRAPHIC STEP:**

- PRESS the F-PLN or PERF key.
- SELECT vertical revision at a cruise waypoint.
- SELECT the STEP ALTS prompt.

WRITE the ALT /WPT in the scratchpad, and ENTER it in [1L] to [4L].


- Note:
- The position may be a waypoint ident, PBD, PD.
  - The pilot may enter FL 350/LMG/-20. The FM will compute the geographic step 20 NM before LMG to FL 350.
  - To modify an inserted STEP:
    - To modify the CRZ FL only, enter it in the left key, as "FLXXX".
    - To modify the position only, enter it in the left key, as "/XXX".
    - To modify both, modify the position first, and then the CRZ FL (it is not possible to modify both in a single entry).

CHECK the PREDICTIONS.



**FOR OPTIMAL STEP**

Once all geographical steps are inserted, and the predictions are available, the STEP ALTS page displays the FUEL/TIME savings for the first step climb. If no significant savings are predicted, the NO OPTIMAL message is displayed.



To INSERT the proposed OPT STEP displayed in [5L]:  
SELECT the INSERT\* prompt in [6R].



The computed (OPT) step replaces the initially inserted step position, and is then considered at a fixed geographic position. Savings are no longer displayed, and the UPDATE\* prompt replaces the INSERT\* prompt. This prompt allows the crew to update the (OPT) step position, considering possible F-PLN or inserted wind changes.

If pressed, a new OPT point is proposed, with the associated SAVINGS and INSERT prompt, or NO OPTIMAL.

UPDATE prompt has been pressed, the new OPT STEP point gives additional savings:



**THERE ARE ONLY 2 CRZ FL S IN THE F-PLN:**

The pilot may obtain the OPT position of the STEP point, as follows:

INSERT the initial cruise FL on the INIT A page.

ENSURE that the ZFW , ZFWCG and BLOCK fuel are inserted on the INIT B page.

WRITE the new CRZ FL in the STEP ALTS page, in the [1L] field.


*Distance and time to optimum point and fuel/time saving are displayed.*

CHECK the fuel and time savings and prediction on the [5R] field.

*Savings are computed by comparing the entered step altitude, and the origin altitude of the step.*

INSERT, if suitable.





*Note: No OPT STEP is available in the SEC F-PLN.*

**MESSAGES**

Messages may be displayed in the DIST/TIME field:

- "ABOVE MAX", if the inserted step altitude exceeds the REC MAX ALT. The "STEP ABOVE MAX FL" scratchpad message is associated to the "ABOVE MAX" message.
- "IGNORED"

This message is displayed in the following cases:

- Step climb is located prior to the top of climb, or after the top of descent.
- Step end is at less than 50 NM from the top of descent. An optimum step point, < 200 NM from top of descent, cannot be inserted

- “STEP AHEAD”, when the distance to the step point is less than 20 NM . A “STEP AHEAD” scratchpad message is also displayed.  
The following message may be displayed in the scratchpad:
- “NOT ALLOWED”, if:
  - Four steps already exist in the F-PLN, and an additional entry is attempted.
  - Any attempt to enter a step at the FROM waypoint, or at a pseudo waypoint is done.
  - Two consecutive steps are entered at the same waypoint (e.g. step climb after step descent).

**GENERAL**

Ident.: DSC-22\_20-60-110-00006021.0001001 / 01 OCT 12

Applicable to: ALL

A time constraint (RTA) may be assigned at any waypoint of the F-PLN, downpath of the origin and the FROM waypoint. It can be an "AT", "AT OR BEFORE", or "AT OR AFTER" constraint.

The FMS computes a new managed speed profile from the aircraft position to the constrained waypoint, in order to match the 30 s difference ( $\Delta T$ ) between the time predicted at the constrained waypoint and the RTA. This modified managed speed profile can be checked using the speed prediction, displayed for each waypoint of the F-PLN page.

The RTA function uses a speed range between Green Dot speed and VMO - 10 (or MMO - 0.02). When the constrained waypoint is sequenced, the ECON SPD/MACH is resumed unless the constrained waypoint is located in a descent segment.

*Note: The FM does not compute a new managed speed profile when a RTA is entered in the descent profile while the aircraft is in cruise within 40 NM from the top of descent.*

The time constraint is inserted on the RTA page. A time constraint may be inserted at any waypoint of the primary or secondary flight plan.

If an engine-out condition is detected, the time constraint is automatically deleted and RTA DELETED message on scratchpad.


If the aircraft enters a holding pattern, the downpath time constraint is deleted.

Once inserted in the F-PLN, the RTA is displayed in magenta on the F-PLN page, as long as no predictions are available.

Once the predictions are available, the time constraint is replaced by the new predicted time at the associated waypoint, and highlighted by a star: (\*)

- The (\*) is magenta, if the time constraint is matched with the 30 s criteria.
- The (\*) is amber, if the time constraint is missed.

Time constraint matching criteria:



Note:  $\Delta T$  is the time difference between the time predicted at the constrained waypoint and the RTA.

### **TIME CSTR ENTRY**

PRESS the F-PLN key.

SELECT vertical revision at the revised waypoint.

SELECT the RTA key.

ENTER a waypoint at which a time constraint is to be defined.

WRITE the time constraint (+/-HHMMSS) into the scratchpad and ENTER

*The display automatically reverts to the F-PLN A page.*



- Note:
- The TIME CSTR can be directly cleared on the F-PLN A page, using the CLR key.
  - The time constraint is automatically deleted in the following cases:
    - Engine out, or
    - When entering a holding pattern, or
    - In case of Go-Around, or
    - A time constraint is entered at another waypoint, while another time constraint already exists.

*A scratchpad "RTA DELETED" message is displayed.*

### **ESTIMATED TAKEOFF TIME (ETT)**

Ident.: DSC-22\_20-60-110-00009523.0001001 / 23 JUN 15

Applicable to: **ALL**

The Estimated Takeoff Time (ETT) may be entered by the pilot during the preflight phase at the origin airport. This time is used as the initialization time for predictions.

The entry is accepted in the preflight phase, if the ETT is greater than the clock time.

**PROCEDURE**

PRESS the F-PLN key

SELECT a vertical revision at origin

SELECT the RTA page

WRITE the ETT into the scratchpad, and ENTER in the ETT field.

*The display automatically reverts to the F-PLN A page.*

- Note:
- If the current time exceeds the ETT entry, the CLK IS TAKE OFF TIME message is displayed ; the ETT is replaced by the clock time.
  - At takeoff, the takeoff time is automatically updated using the actual clock time.
  - An ETT entry is automatically deleted, if the origin airport is modified, or if the clock is inoperative.
  - If a time constraint is entered at a waypoint in the F-PLN , the takeoff time required to match the constraint is automatically computed by the FM. This result is displayed in magenta as ETT at the origin.

**USE OF TIME/ETT CONSTRAINT**

- During preflight :
- If an ETT has been entered, time predictions are based on the entered value (or clock time, if greater).
  - If both an ETT and a time constraint have been entered, time predictions are based on the entered ETT value (or clock time, if greater). The managed speed profile is computed to match the time constraint, as closely as possible, using a pseudo cost index value. (Not displayed).
  - If only a time constraint has been entered:
    - Optimum speeds are computed to determine the ETT, so as to satisfy the time constraint.
    - If necessary, flight time (based on optimum speeds) plus clock time (current) is greater than the time constraint ; optimum speeds are modified to match the time constraint as closely as possible.
- After Takeoff :
- The predictions are based on the current time.
  - Speeds are adjusted to satisfy the time constraint.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

OTHER FUNCTIONS - REQUIRED TIME OF ARRIVAL (RTA)

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p align="center">OTHER FUNCTIONS - EQUITIME POINT</p>
---	---

**EQUITIME POINT**

Ident.: DSC-22\_20-60-120-00006015.0001001 / 16 MAR 11  
**Applicable to: ALL**

The equitime point page displays the ETP , computed along the F-PLN route between two referenced positions (airports, waypoints or nav aids), defined by the pilot (*Refer to DSC-22\_20-50-10-25 Equi - Time Point Page* for the page description).


When first accessing the page, the FMS proposes origin and destination airfields, as defaulted positions.

The pilot may overwrite these two positions and insert the wind in their vicinity at the applicable CRZ FL.

The FMS then computes the resulting ETP , using the managed or selected speed, and blending the forecasted winds along the F-PLN route with the inserted winds.

The FMS provides:

- TIME and DIST from the aircraft position (or origin on ground) to the ETP
- The BRG /DIST from the ETP to the defined positions
- TIME overhead each position, assuming the aircraft flies from the present position to the defined position via the ETP
- (ETP ) pseudo waypoint is displayed on the ND along the F-PLN
- ETP location in relation to the subsequent waypoint.



**EQUITIME POINT ENTRY**

Ident.: DSC-22\_20-60-120-00009536.0001001 / 01 OCT 12  
**Applicable to: ALL**

PRESS the DATA key.

SELECT the EQUI-TIME POINT prompt.

*The EQUI-TIME POINT page is displayed. The origin and destination airports are used by default.*

ENTER the REF POINT 1 in the [1L] field.

ENTER the associated wind in the [2L] field.

*The wind to be inserted is the wind in the vicinity of the reference point at the CRZ FL.*

ENTER the REF POINT 2 in the [3L] field.

ENTER the associated wind in the [4L] field.

*The system displays the ETP location with regards to the next waypoint of the active flight plan following the ETP in the [5R] field, and the A/C TO (ETP) predictions in the [6R] field.*

EQUITIME PAGE  
AT ACCESS  
(DEFAULTED)

EQUI-TIME POINT			
A/C TO	BRG	DIST	UTC
LFBO	176°	249	1139
TRU WIND ETP TO LF80			
[2L]	110°/025	171°	265 1147
[3L]	EGLL	007°	293 1147
TRU WIND ETP TO EGLL			
[4L]	185°/045	006°	281 1147
ETP LOCATION			
N52W025/ -25.2			
A/C TO	DIST	UTC	
[6L] (ETP)	281	1112	

[1L]	[1R]
[2L]	[2R]
[3L]	[3R]
[4L]	[4R]
[5L]	[5R]
[6L]	[6R]

EQUITIME PAGE  
AT ACCESS  
(DEFAULTED)

EQUI-TIME POINT			
A/C TO	BRG	DIST	UTC
AA	029°	788	0945
TRU WIND ETP TO AA			
[2L]	075°/020	003°	563 1015
[3L]	AB	075°	1001 1012
TRU WIND ETP TO AB			
[4L]	270°/030	077°	627 1015
ETP LOCATION			
N52W025/ -25.2			
A/C TO	DIST	UTC	
[6L] (ETP)	371	0953	

[1L]	[1R]
[2L]	[2R]
[3L]	[3R]
[4L]	[4R]
[5L]	[5R]
[6L]	[6R]

- Note:
- The ETP pseudo-waypoint is not displayed on the MCDU F-PLN page. In order to easily locate it, or when closing the applicable ETP, the TIME MARKER may be used; this allows the crew to visualize it in advance on the F-PLN page or, to prepare the next applicable ETP on the Equi-time Point page
  - The ETP is computed using speed according to the current mode (managed or selected).



**GENERAL**

Ident.: DSC-22\_20-60-130-00012906.0011001 / 24 FEB 14


Applicable to: ALL

The MCDU NAV B/UP allows to link a MCDU to its associated IRS in order to allow the flight crew to monitor the navigation and to be provided with some basic flight planning functions in case of FM 1 + 2 failure.

**CAUTION**

The MCDU NAV B/UP is to be used only in case of FM 1 + 2 failure. It can be selected temporarily in case of FM1 or 2 only failure, in order to ensure that the function is available on the failed side.  
When in MCDU NAV B/UP on both sides, one FG at least must be available to engage AP and A/THR.

The MCDU NAV B/UP function provides:

- Aircraft position using outside IRS or IRS 3
- Aircraft position using GPIRS  position
- F-PLN as memorized in the MCDU
- F-PLN display on ND
- F-PLN automatic sequencing
- Limited lateral revisions
- Mag (True) bearing depending on the pilot selection, from aircraft position to the TO WPT and associated distance
- True track between waypoints
- Time estimates computed with current GS from outside IRS
- Total time and distance to destination

The following features are not provided:

- No DATA BASE available:
  - No autotuning, NAVAID S must be selected on RMP
  - No radio position
  - No EFIS CTL PANEL options
  - No LDG ELEV (must be manually selected on overhead panel).
- No performance data:
  - No CLB /DES /APP NAV/FINAL modes
  - No SPEED MANAGED
  - No automatic SPD/MACH change over.
- Most of predictions are lost:
  - No EFOB
  - No XTRA
  - No ETA at DEST.
- No multiple lateral F-PLN

- No AP/FD managed modes
- No crosstalk between MCDU s: F-PLN revisions have to be achieved on both MCDUs.

## **BACK UP NAV SELECTION**

Applicable to: **ALL**

Ident.: DSC-22\_20-60-130-A-00012907.0011001 / 16 FEB 11

### **FM F-PLN DOWNLOAD IN MCDU**

While BACK UP NAV is not active, the FM downloads permanently a condensed form of the F-PLN in the MCDU.

Downloaded information include:

- Waypoint position
- Waypoint identifier
- Leg type
- Discontinuity
- Overfly
- Turn direction.

Heading legs, course to fix legs, ..., computed INTCPT positions, pseudo waypoints, ..., cannot be downloaded.

They are replaced by discontinuities.

Maximum of 150 waypoints are downloaded.

Ident.: DSC-22\_20-60-130-A-00012908.0011001 / 14 MAY 12

**EXAMPLE OF DOWNLOADED F-PLN**

F-PLN before FM failure	[1L]	FROM	A1101 →		[1R]
		BIGAR	UTC	SPD/ALT	
	[2L]	BIG	117	/ 4888	[2R]
		C335°		9NM	
	[3L]	BIG09Δ	116	250 / *2700	[3R]
		TRK275°		1	
	(DECEL)	117	/ 2500		
[4L]	C275°		6	[4R]	
	AMB	118	160 / *2500		
[5L]	C275°		4 3.0°	[5R]	
	OM27R	120	*136 / *1310		
[6L]	DEST	TIME	DIST	EFOB	[6R]
	EGLL27R	121	518	36.9	
				↑↓	

Download B/UP F-PLN -CF legs are preceded by a discontinuity  -PSEUDO WPT are not downloaded	[1L]	B/UP FPLN			[1R]
		FROM	TTG	DIST	
	[2L]	BIG	5119.8N/00002.2E		[2R]
		--F-PLN DISCONTINUITY--			
	[3L]	BIG09Δ	5127.0N/00004.6W		[3R]
		--F-PLN DISCONTINUITY--			
[4L]	AMB	5128.6N/00014.1W		[4R]	
[5L]	DEST	TTG	DIST	[5R]	
[6L]	EGLL27R	---	518NM	[6R]	
				↑↓	

In that procedure, all the legs are coded as CF (Course to Fix) legs. This explains all the discontinuities resulting in the B/UP F-PLN.

These discontinuities may be cleared.

When the second FM fails

REENGAGE and SELECT the required AP and A/THR modes (if disconnected).

SELECT the NAV B/UP prompt on both MCDU.

SELECT NAV on both RMP

*Tune the required nav aids*

MCDU MENU  
SELECT  
NAV B/UP>


1L	<b>&lt;FM1</b>	1R
2L	<b>&lt;ACARS</b>	2R
3L	<b>&lt;ACMS</b>	3R
4L	<b>&lt;CMS</b>	4R
5L		5R
6L	<b>RETURN&gt;</b>	6R

B/UP FPLN

	<small>FROM</small>	<small>TTG</small>	<small>DIST</small>	
1L	<b>TOU</b>	<b>4340.8N/00118.7E</b>		1R
	<small>350°</small>	<small>0004</small>	<small>22NM</small>	
2L	<b>AGN</b>	<b>4353.3N/00052.4E</b>		2R
	<small>348°</small>	<small>0045</small>	<small>116NM</small>	
3L	<b>LMG</b>	<b>4549.ON/00101.6E</b>		3R
	<small>321° T</small>	<small>0045</small>	<small>97NM</small>	
4L	<b>AMBA</b>	<b>4725.1N/00102.5E</b>		4R
	<small>322° T</small>	<small>0053</small>	<small>40NM</small>	
5L	<b>N48E001</b>	<b>4803.5N/00123.3E</b>		5R
	<small>DEST</small>	<small>0126</small>	<small>443NM</small>	
6L	<b>LFPO</b>	<b>4843.4N/00222.9E</b>		6R
		<small>↑↓</small>		

B/UP F-PLN PAGE



- Only MCDU MENU
  - F-PLN key
  - PROG key
  - DIR key
- B/UP F-PLN page
  - B/UP PROG page
  - B/UP IRS 1, 2, 3 pages are available when BACK UP NAV is selected.
- B/U GPS (if GPS is installed).

### BACK UP NAV OPERATION

Applicable to: ALL

Ident.: DSC-22\_20-60-130-B-00012909.0011001 / 16 FEB 11

#### AP AND A/THR

One FG at least must be available to allow the engagement of AP /FD and A/THR . All FM managed modes are lost as well as managed speed.

As a consequence:

- LAT F-PLN is flown in HDG /TRK modes
- VERT F-PLN is flown in OPEN/V/S /FPA modes
- SPD TARGET is manually SELECTED on the FCU
- SPD /MACH crossover is manually SELECTED on the FCU.

It is recommended to use the TRK /FPA modes:

SELECT the required TRK on FCU at waypoint sequencing (as no AP /FD coupling exists in NAV B/UP). F-PLN sequencing is automatic.

MONITOR the track of the next leg prior reaching the TO waypoint (track between TO and next waypoints is true track).

ADJUST the track to follow the F-PLN with X-TRK = 0

USE OP DES or FPA to descend as suitable.

FPA allows easy altitudes predictions:

$$DNM = \Delta(\text{FL}) / \text{FPA}^\circ$$

Ident.: DSC-22\_20-60-130-B-00012910.0011001 / 16 FEB 11

## **NAVIGATION MONITORING**

The navigation accuracy check must be achieved periodically using the same principle as with FM navigation:

COMPARE computed data with raw data

SELECT ON RMP the applicable navaid

PRESS the [PROG] key



*B/UP PROG page is displayed*

WRITE in the scratchpad then ENTER the navaid LAT /LONG

SELECT associated navaid needle on the EFIS control panel.

COMPARE computed BRG /DIST with RAW DATA on ND

- If the crosscheck is POSITIVE the ND may be used in ROSE NAV /MAP modes with raw data
- If the crosscheck is NEGATIVE the ND must be used in ROSE VOR /ROSE ILS modes.

*Note: B/UP IRS  and B/UP GPS  pages may also be used to check the position.*

Ident.: DSC-22\_20-60-130-B-00012911.0011001 / 16 FEB 11

## **FLIGHT PLANNING**

The following revisions may be achieved:

- WPT insertion/deletion
- OVERFLY insertion/deletion

- DIR TO a waypoint
- CLR waypoints/discontinuities.

Waypoint identifiers are either published waypoint identifiers if present in the MCDU active F-PLN , or coded LAT /LONG identifiers resulting from flight crew entries.


All flight planning functions are directly applied on active F-PLN without LAT REV page.

Ident.: DSC-22\_20-60-130-B-00012912.0011001 / 23 JUN 15

**WAYPOINT INSERTION**

Waypoint insertion into the F-PLN is performed via the B/UP F-PLN page by selecting the line key adjacent to the desired point of insertion, whenever a pre-existing waypoint identifier or valid IDENT /LAT /LONG or LAT /LONG entry is displayed in the scratchpad.

Any waypoint entry which causes the number of legs in the route to exceed the maximum allowed results in the “F-PLN FULL” message.



- Note:
- If the inserted waypoint is entered only with LAT /LONG, its identifier would be : N48E001
  - If the flight crew writes a waypoint IDENT /LAT /LONG with an IDENT already used in the F-PLN, a message “NOT ALLOWED” is displayed.

Ident.: DSC-22\_20-60-130-B-00012913.0011001 / 16 FEB 11

### **WAYPOINT DELETION**

Waypoint and discontinuity may be deleted from the B/UP F-PLN page by using the CLR key.

Ident.: DSC-22\_20-60-130-B-00012914.0011001 / 16 FEB 11

### **OVERFLY INSERTION/DELETION**

Same as for the FM F-PLN.

Ident.: DSC-22\_20-60-130-B-00012915.0011001 / 23 JUN 15

### **DIRECT TO A WAYPOINT**


The DIR TO function operates as for the normal F-PLN, except that RADIAL INTERCEPT and ABEAM functions are not available.

PRESS the DIR key.

WRITE LAT /LONG (or IDENT /LAT /LONG) on the scratchpad then INSERT in [1L].

SELECT the correct track on the FCU in order for the aircraft to turn toward the new TO waypoint.





In this example, the entered DIR TO waypoint is a LAT /LONG waypoint.

Due to the fact that this new waypoint is not identical to any waypoint in the F-PLN, a direct leg to that waypoint is created and followed by a discontinuity.

When the DIR TO function is completed, the B/UP F-PLN page is displayed with the DIR TO waypoint as the TO waypoint and the T-P waypoint as the FROM waypoint.


If a DIR TO function is achieved for a waypoint that belongs to the B/UP F-PLN, no F-PLN discontinuity is created.

Note: - In case of a DIR TO waypoint associated with an OVERFLY condition, the OVERFLY is kept.

Ident.: DSC-22\_20-60-130-B-00012916.0011001 / 14 MAY 12

### **CLR WAYPOINT/DISCONTINUITY**

CLR as for normal operation.



**B/UP FPLN**

FROM	TTG	DIST
TOU	4340.8N/00118.7E	
350°	0004	2.2NM
AGN	4353.3N/00052.4E	
348° T	0027	1.16NM
LMG	4549.0N/00101.6E	
321° T	0045	0.97NM
AMBA	4725.1N/00102.5E	
322° T	0053	0.40NM
N48E001	4803.5N/00123.3E	
DEST	0126	0.443NM
LFPO	4843.4N/00222.9E	
CLR		↑↓

B/UP F-PLN PAGE

**B/UP FPLN**

FROM	TTG	DIST
TOU	4340.8N/00118.7E	
350°	0004	2.2NM
AGN	4353.3N/00052.4E	
--- F-PLN DISCONTINUITY ---		
AMBA	4725.1N/00102.5E	
322° T	0053	0.40NM
N48E001	4803.5N/00123.3E	
DEST	0126	0.443NM
LFPO	4843.4N/00222.9E	
		↑↓

B/UP F-PLN PAGE

Ident.: DSC-22\_20-60-130-B-00012917.0011001 / 23 DEC 14

### APPROACHES

- ND display selection rule  
As per normal operation, it depends upon the result of NAV ACCY CROSS CHECK.  
Furthermore it depends also whether the F-PLN is complete, including the approach.

F-PLN	NAV ACCY CHECK	ND	
		PF	PM
Complete with appropriate approach	Positive	ARC or ROSE NAV Ref navaid Raw data	
	Negative	ROSE VOR /ILS	ARC or ROSE NAV or ROSE VOR /ILS Ref Navaid Raw Data
Incomplete	Positive or Negative	ROSE VOR /ILS	

Ident.: DSC-22\_20-60-130-B-00012918.0011001 / 16 FEB 11

### END OF DESCENT

ADJUST manually the landing elevation on the overhead panel.

SET the MDA on the standby altimeter.

Ident.: DSC-22\_20-60-130-B-00012919.0011001 / 23 JUN 15

### NON ILS APPROACHES

SELECT on RMP the approach reference nav aids.

*The autopilot and flight director available modes are TRK -FPA and HDG/VS*

*The autothrust available speed target is selected speed.*

Ident.: DSC-22\_20-60-130-B-00012920.0011001 / 16 FEB 11

### ILS APPROACHES

Only CAT 1 approaches may be flown since the DH indication is not available.

CHECK the ILS frequency and course on the RMP.

PUSH the LS pb on the EIS control panel.

*The autopilot and flight director available modes are APP (LOC – G/S – LAND)*

*The autothrottle available speed target is selected speed*

CHECK VAPP in the QRH.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT MANAGEMENT

OTHER FUNCTIONS - MCDU BACK UP NAVIGATION

Intentionally left blank

**DESCENT PROFILE OPTIMIZATION** ◀


Ident.: DSC-22\_20-60-150-00019723.0001001 / 07 JUN 16

Applicable to: ALL


During the idle segment in descent, margins are added to the idle thrust to have more flexibility to maintain the aircraft on the computed descent profile in case of external perturbations such as important wind change.


The Descent Profile Optimization (DPO ◀) optimizes the computed vertical profile. It decreases the idle thrust margins in descent and the speed margins in approach to reduce fuel burn in descent phase.

With DPO ◀, the computed vertical profile is steeper. The T/D is reached later. Before the final approach, the deceleration level-off is shorter.



With DPO ◀, along the idle segment, without altitude constraint, the descent profile computed by the FMS is the same as the one flown in OPEN DES mode. Therefore, reverting in OPEN DES mode during the descent does not change the descent rate.



With DPO , the FMGS has less flexibility to maintain the aircraft on the computed vertical profile in case of difference between wind entry and effective wind. Therefore, the accurate winds have to be entered in the FMGS before descent.

During descent, the VDEV should be closely monitored. If the aircraft goes above the flight descent profile, the flight crew may have to extend speed brakes to go back on the computed descent profile. If ENG ANTI ICE or ENG ANTI ICE + WING ANTI ICE are used during descent (inducing an increased idle thrust), the flight crew may have to extend speed brakes to stay on the computed descent profile.

**FLIGHT PLAN INITIALIZATION THROUGH ACARS**

Ident.: DSC-22\_20-70-00000956.0007001 / 01 OCT 12

Applicable to: ALL

**REQUEST FOR ACTIVE FLIGHT PLAN INITIALIZATION BEFORE ENGINE START**

Before engine start, the crew may request a route for the active flight plan. When the route is received, "AOC ACT F-PLN UPLINK" message is displayed on the MCDU indicating that the flight plan has been received and automatically inserted.

After engine start, it is not possible to initialize directly the active flight plan since the received flight plan is automatically routed into the secondary, and the MDCU displays "AOC SEC F-PLN UPLINK".

**PROCEDURE**


PRESS the INIT REQUEST \* prompt.

*The star (\*) disappears, all data fields are dashed except:*

- CO RTE , FLT NBR if previously displayed and
- Ddefault values.

*The star is not displayed when the FMGS cannot communicate with the ACARS. No request can be sent.*

*When an active flight plan exists, INIT REQUEST prompt is removed from the active INIT page and no request can be sent for the active flight plan. If a flight plan is entered manually after the request, the uplink message is routed to the secondary.*



**REQUEST FOR SECONDARY FLIGHT PLAN**

A request for a secondary flight plan can be initiated anytime. Any flight plan received after engine start is automatically routed into the secondary flight plan.

When the flight plan is received, a message “AOC SEC F-PLN UPLINK” is displayed on the MCDU scratchpad.

Before engine start, and if the SEC F-PLN is empty, any uplinked flight plan is automatically inserted into the secondary flight plan, and no flight crew action is required.



After engine start, or if the SEC F-PLN is not empty, the flight crew must manually insert the uplinked flight plan via INSERT UPLINK prompt.

### **PROCEDURE TO INSERT OR REJECT A SECONDARY FLIGHT PLAN**

When the uplink message is received, the INIT REQUEST prompt of the INIT A page is replaced by INSERT UPLINK (2R field). Pressing the 2R key will insert the flight plan into the secondary. Clearing the prompt will reject it.

If a temporary flight plan or a DIR TO is in progress, the uplink insertion is not accepted until the temporary flight plan or the DIR TO is completed.

1L

2L

3L

4L

5L

6L

SEC INIT →

CO RTE	FROM/TO
□□□□□□□□	□□□□/□□□□
ALTN/CO RTE	INIT
-----/-----	REQUEST*
FLT NBR	
□□□□□□□□	
LAT	LONG
-----	-----
COST INDEX	
---	WIND>
CRZ FL/TEMP	TROPO
-----/-----°	36090
AOC SEC F-PLN UPLINK	

1R

2R ← PRESS ①

3R

4R

5R

6R

1L

2L

3L

4L

5L

6L

SEC INIT →

CO RTE	FROM/TO
□□□□□□□□	□□□□/□□□□
ALTN/CO RTE	INSERT
-----/-----	UPLINK*
FLT NBR	
□□□□□□□□	
LAT	LONG
-----	-----
COST INDEX	
---	WIND>
CRZ FL/TEMP	TROPO
-----/-----°	36090
UPLINK INSERT IN PROG	

1R

2R ← PRESS ②

3R

4R

5R

6R

1L

2L

3L

4L

5L

6L

SEC INIT →

CO RTE	FROM/TO
20441	LSGG/LGAT
ALTN/CO RTE	INIT
LGTS	REQUEST*
FLT NBR	
A1101	
LAT	LONG
4512.ON	00727.2E
COST INDEX	
540	WIND>
CRZ FL/TEMP	TROPO
FL290/-42°	36090

1R

2R

3R

4R

5R

6R

## TAKEOFF DATA

Applicable to: ALL

Ident.: DSC-22\_20-70-A-00000957.0001001 / 15 FEB 11


### GENERAL

The takeoff data may be requested in preflight or done phase for the active flight plan only. It is always associated with the active flight plan message.

Ident.: DSC-22\_20-70-A-00000959.0001001 / 23 JUN 15

**PROCEDURE TO INSERT UPLINK TAKEOFF DATA**

PRESS the 6L key "RECEIVED TO DATA" when the message TAKEOFF DATA UPLINK is displayed.




This displays the uplink data on 2 different pages: **UPLINK MAX TO DATA**  
**UPLINK FLX TO DATA**

SELECT the data corresponding to the thrust to be used (MAX or FLEX) by pressing [4R].  
 SELECT the active runway data by slewing the pages (1/4... 4/4).

PRESS the [6R] key “INSERT UPLINK”.

*UPLINK MAX TO DATA and UPLINK FLX TO DATA pages are not modifiable.*

- **If the takeoff data displayed on this page are not relevant to the active runway entered in the flight plan** , the INSERT UPLINK prompt is not displayed.
- **When the takeoff data have been inserted** , the PERF TO page is amended of the new data.



## WIND DATA

Applicable to: ALL

Ident.: DSC-22\_20-70-B-00000961.0001001 / 01 OCT 12


### REQUEST FOR WIND DATA

To send a wind request, press the “WIND REQUEST” selection key of any wind pages. This request is automatically sent to the ground for one or more flight phases and for the selected flight plan (primary or secondary). The content of the wind request message is not dependent on the selected wind page (CLIMB, CRUISE or DESCENT) but on the flight phase in progress.

- For active flight plan or secondary flight plan that is a “COPY ACTIVE”, a wind request sent by the crew:
  - during preflight or takeoff phase, initiates a demand for climb, cruise, descent and alternate winds.
  - during climb and cruise phase, initiates a demand for cruise, descent and alternate winds.
  - during descent/approach and go around, no wind request is possible.
- For secondary flight plan that is not a “COPY ACTIVE” there is no restriction linked to flight phase.

Before engine start, and if data has not been entered in any WIND page for the flight plan, the uplinked wind data is automatically inserted into the flight plan, and no flight crew action is required.

If the uplinked wind message is received after engine start, or if data has been entered in any WIND page of the flight plan, the flight crew must manually insert the uplinked wind data via the INSERT UPLINK prompt.



When the amber star following the “WIND REQUEST” is not displayed, the FM is not able to communicate with the ACARS and the pilot cannot send any request.


Ident.: DSC-22\_20-70-B-00000962.0020001 / 14 MAY 12

### PROCEDURE TO INSERT WIND DATA

When the uplink message is received, the 2R field is modified, the amber “WIND REQUEST” is replaced by the blue “INSERT UPLINK\*”. This prompt, when pressed, enables the flight crew to insert the uplink wind data, phase by phase.

To access, review, insert or delete the uplink wind data of other phases, the crew uses “NEXT PHASE” or “PREV PHASE” key.

If the crew is not satisfied with the uplink winds, the flight crew will delete the winds, phase by phase clearing the "INSERT UPLINK" prompt. This will delete all the uplinked winds of the selected flight phase.



### CLIMB WIND PAGE

When a request is pending, the history WIND page cannot be accessed.

When the climb phase is active, the crew cannot request neither modify the climb winds of the active flight plan or secondary flight plan if it is a copy active.

**CRUISE WIND PAGE**

**CRUISE WIND**

TRU WIND/WPT CRZ FL  
 ---°/---/TOP FL330  
 WIND  
 ---°/---/KEBT REQUEST  
 ---°/---/BTIE  
 STEP FL370 PREV PHASE>  
 ---°/---/COVT NEXT PHASE>  
 ---°/---/KUABE  
 ---°/---/CAT ↑↓

CRUISE WIND PAGE REQUEST IS PENDING

1L 2L 3L 4L 5L 6L 1R 2R 3R 4R 5R 6R

---

**CRUISE WIND**

TRU WIND/WPT CRZ FL  
 260°/109/TOP FL330  
 INSERT  
 258°/080/KEBT UPLINK\*  
 265°/096/BTIE  
 STEP FL370 PREV PHASE>  
 240°/060/COVT NEXT PHASE>  
 245°/085/KUABE  
 250°/105/CAT WIND DATA UPLINK ↑↓

UPLINKED DATA PRIOR TO INSERTION

1L 2L 3L 4L 5L 6L 1R 2R 3R 4R 5R 6R

A wind request sent during cruise phase will apply for downpath waypoints of the cruise, descent, approach and alternate phases.

- If the uplink message contains more data and waypoints than the flight plan, the winds at extra waypoints are not considered and automatically discarded. This is transparent to the pilot
- Clearing the INSERT UPLINK\* prompt deletes all uplink wind data of the cruise phase. Cruise page reverts to the previous data.

*Note:* During cruise, whenever uplink wind data is received and not inserted or cancelled on the CRUISE WIND page, access to the DIR TO function is not possible. The “WIND UPLINK EXISTS” message is displayed on the MCDU scratchpad. Insert or cancel the uplinked wind message first and then access the DIR TO function.

**DESCENT WIND PAGE**

The procedures to insert, review or delete descent winds during preflight, climb or cruise phase are described in the above wind general procedure.

DESCENT WIND PAGE  
REQUEST IS PENDING

**DESCENT WIND**

TRU WIND/ALT

1L	---	
2L	---	WIND REQUEST
3L	---	PREV PHASE>
4L	---	
5L	---	ALTERNATE
6L	---	---

1R

2R

3R

4R

5R

6R

UPLINKED DATA  
PRIOR TO INSERTION

**DESCENT WIND**

TRU WIND/ALT

1L	060°/060/FL310	
2L	060°/050/FL200	INSERT UPLINK★
3L	060°/020/FL100	PREV PHASE>
4L	050°/010/FL050	
5L	ALTERNATE 065°/050/FL250	ALTN CRZ FL220
6L	---	---

WIND DATA UPLINK

1R

2R

3R

4R


5R

6R

If the alternate wind is not available, dashes are displayed in the field.

In descent, approach or go around phases, the pilot cannot request or modify the descent winds of the active flight plan or secondary flight plan if it is a "COPY ACTIVE".



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p>PRINT FUNCTIONS</p>
---	---

**PRINT FUNCTION**

Ident.: DSC-22\_20-80-00000964.0009001 / 18 MAR 11

**Applicable to: ALL**

The PRINT function allows various reports to be printed either automatically (when linked to ACARS <img alt="ACARS icon" data-bbox="221 228 241 244"/> or ATSU <img alt="ATSU icon" data-bbox="331 228 351 244"/> ) or manually.

The manual PRINT function allows printing of FM-generated flight reports and additional data:

F-PLN	INITialization data
T.O.	Data
WIND	Data
PREFLIGHT	REPORT
IN FLIGHT	REPORT
POSTFLIGHT	REPORT

A detailed description of the PRINT FUNCTION pages is provided in *Refer to DSC-22\_20-50-10-25 Print Function Pages.*

The print function is available if ACARS <img alt="ACARS icon" data-bbox="478 436 498 452"/> or ATSU <img alt="ATSU icon" data-bbox="588 436 608 452"/> are available or not.

The various flight reports contain most of the prediction information required by the flight crew to monitor the progress of the flight. The resulting documents can therefore be used as realistic master documents, based on the latest data provided by the flight crew to the computer, in terms of ATC clearances and weather information.

**PRINT FUNCTION ACCESS**

Ident.: DSC-22\_20-80-00000965.0004001 / 01 OCT 12

**Applicable to: ALL**

The PRINT FUNCTION page is accessed:

- From the DATA INDEX A PAGE, or
- From the AOC FUNCTION page (if ACARS <img alt="ACARS icon" data-bbox="528 654 548 670"/> ).

PRINT FUNCTION  
PAGE 1

PRINT FUNCTION 1/2 →

AUTO MANUAL

\*YES F-PLN INIT PRINT \*

TO DATA PRINT \*

\*NO WIND DATA PRINT \*

<RETURN ACARS  
FUNCTION>

1R

2R

3R

4R

5R

6R

PRINT FUNCTION  
PAGE 2

PRINT FUNCTION 2/2 →

AUTO MANUAL

\*YES PREFLIGHT PRINT \*

\*NO INFLIGHT PRINT \*

\*YES POSTFLIGHT PRINT \*

<RETURN ACARS  
FUNCTION>

1R

2R

3R

4R

5R

6R

*Note:* For an automatic printing, "time" is the time of the reception of the message. For a manual printing, "time" is the time of the print request.

**ON GROUND BEFORE ENGINE START**

Ident.: DSC-22\_20-80-00000966.0001001 / 23 JUN 15

Applicable to: ALL

When the overall F-PLN data (lateral, vertical including winds, steps, constraints) and the ZFW and ZFWCG values have been inserted:

SELECT the FUEL PLANNING prompt [3R],

- **If the computed BLOCK fuel does not correspond to the actual block fuel required for the flight:**

ENTER the actual block required for the flight in the [2R] field,

PRINT the PREFLIGHT report.

*The flight crew may then use the PREFLIGHT report to monitor the progress of the flight.*

*Note: Before printing the PREFLIGHT report, the flight crew must check that the F-PLN is complete (all F-PLN discontinuities must be cleared) and that all the F-PLN elements (including winds, steps, constraints, alternate airport) have been inserted, in order to obtain an accurate PREFLIGHT report.*



**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

PRINT FUNCTIONS

**EXAMPLE (FM PREFLIGHT REPORT)**

Ident.: DSC-22\_20-80-00000967.0001001 / 18 MAR 11

Applicable to: ALL

FM PREFLIGHT REPORT

DATE : 24 OCT 06  
TIME : 07 : 24

A/C TYPE	: A320-200	DATABASE	: AB49402001
ENG TYPE	: CFM56-5B4	CYCLE	: 29 SEP-26 OCT
FLT NUMBER	: AIB 105	FROM/TO	: EINN/LFBO
CO RTE	: .....	ALTN	: LFBP
ALTN CO RTE	: .....		
PERF FACTOR	: +1.5	COST INDEX	: 100
IDLE FACTOR	: +0.0		
CRUISE FL/STEP START WPT			
CRZ FL 1	: FL410		
FLIGHT PLAN DATA			
	DIST	TIME	CRZ FL
DEST-LFBO	: 714	01:32	FL410
ALTN-LFBP	: 80	01:52	FL220
DEP RWY	: 24		ARV PRC
DEP PRC	: .....		APR PRC
			ARV RWY

WPT	TIME	SPD/ALT	FOB	T. WIND	TAS	SAT	CRS	DIST
PREDICTED VALUES								
EINN24	00:00	133/-95	13.6	TL/040	-	+11	183	0
1520	00:00	159/1574	13.2	TL/040	163	+12	240	2
SHA	00:02	190/FL70	13.0	TL/040	211	+01	059	3
CRK	00:10	295/FL300	11.4	TL/040	459	-44	173	55
TIVLI	00:16	82/FL400	11.2	TL/040	467	-57	140	50
LND	00:27	84/FL410	11.0	TL/040	482	-57	140	99
NAKID	00:33	84/FL410	10.9	TL/040	482	-57	130	46
LIZAD	00:34	84/FL410	9.2	TL/040	482	-57	129	14
BALOT	00:38	84/FL410	8.7	TL/040	482	-57	130	37
BERAT	00:41	84/FL410	8.2	TL/040	482	-57	129	23
DIN	00:46	84/FL410	7.6	TL/040	482	-57	128	47
NTS	00:56	84/FL410	7.3	TL/040	482	-57	173	88
MINEL	01:02	84/FL410	7.1	TL/040	482	-57	153	46
VENAR	01:05	84/FL410	6.6	TL/040	482	-57	152	25
CGC	01:08	84/FL410	6.1	TL/040	482	-57	153	34
VELIN	01:14	320/FL280	5.9	TL/040	482	-41	158	45
AGN	01:25	250/FL60	5.2	TL/040	274	+02	157	72
LFBO	01:32	128/550	5.2	TL/040	129	+14	001	27

FUEL PREDICTIONS

TAXI :	0.2	ZFWCG	: 25.0 %
TRIP (DEST) :	8.4	ZFW	: 51.2
RSV :	1.3	TOW	: 66.5
ALTN :	0.6	LW	: 55.9
FINAL :	1.8	CG	: ---
EXTRA :	0.8		
BLOCK :	15.5		
MISC PERF DATA			
TROPOPAUSE :	36090		
CLB TRANS :	5000		
CRZ TEMP :	-60		

**IN FLIGHT**

Ident.: DSC-22\_20-80-00000968.0007001 / 18 MAR 11

**Applicable to: ALL**

Once the aircraft has reached the CRZ FL once, all the latest ATC clearances have been inserted in the FM, when all the WINDS/STEPS have been properly updated:

ACCESS the PRINT FUNCTION page

PRINT the INFLIGHT REPORT

*The inflight report provides the list of all the overflow F-PLN waypoints (HISTORY VALUES) with their associated data (Time, ALT, Fuel, ...), and the predictions to all the downpath waypoints (PREDICTED VALUES).*

*This new document replaces the PREFLIGHT report, since it carries all the latest expected F-PLN changes. It is the new applicable master document used to monitor the progress of the flight. The inflight report will be printed after each important F-PLN modification.*

Note: *If the selected Fuel Unit option is pounds, the HISTORY FOB values may be incorrectly printed in tons on the INFLIGHT REPORT. The CURRENT and PREDICTED FOB values, however, are correctly printed in pounds.*



**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

PRINT FUNCTIONS

**EXAMPLE (FM INFLIGHT REPORT)**

Ident.: DSC-22\_20-80-00000969.0001001 / 18 MAR 11

Applicable to: ALL

FM INFLIGHT REPORT

DATE : 24 OCT 06

TIME : 09 : 24

A/C TYPE	: A320-200	DATABASE	: AB49402001
ENG TYPE	: CFM56-5B4	CYCLE	: 29 SEP-26 OCT
FLT NUMBER	: AIB 105	FROM/TO	: LFBO/EINN
CO RTE	: .....	ALTN	: EIDW
ALTN CO RTE	: .....		
PERF FACTOR	: +1.5	COST INDEX	: 90
IDLE FACTOR	: +0.0		
CRUISE FL/STEP START WPT			
CRZ FL 1	: FL390		

FLIGHT PLAN DATA

	DIST	TIME	CRZ FL				
DEST-EINN	: 730	10:24	FL390				
ALTN-EIDW	: 106	10:50	FL220				
DEP RWY	: 14R		ARV PRC	: .....			
DEP PRC	: LMG3A		APR PRC	: .....			
			ARV RWY	: .....			

WPT	TIME	SPD/ALT	FOB	T. WIND	TAS	SAT	CRS	DIST
HISTORY VALUES								
LFBO14R	08:29	126/536	13.6	HD/070	-	+12	142	0
1000	08:30	141/982	13.2	056/003	141	+10	143	2

CURRENT POSITION : N43-37.9/E001-22.0

	08:32	252FL63	13.6	HD/070	297	-11	350	10
--	-------	---------	------	--------	-----	-----	-----	----

PREDICTED VALUES

OSKAM	08:34	320/FL130	10.4	HD/070	387	-11	350	14
LMG	08:52	.84/FL390	10.2	HD/070	482	-57	359	119
VERAC	08:59	.84/FL390	10.0	HD/070	482	-57	310	48
MAIXE	09:01	.84/FL390	9.9	HD/070	482	-57	310	18
NTS	09:11	.84/FL390	8.2	HD/070	482	-57	310	70
DIN	09:24	.84/FL390	7.7	HD/070	482	-57	352	88
BERAT	09:31	.84/FL390	7.2	HD/070	482	-57	309	47
BALOT	09:34	.84/FL390	6.6	HD/070	482	-57	309	23
LIZAD	09:40	.84/FL390	6.3	HD/070	482	-57	310	37
NAKID	09:42	.84/FL390	6.1	HD/070	482	-57	309	14
LND	09:48	.84/FL390	5.6	HD/070	482	-57	309	46
TIVLI	10:03	.84/FL390	5.1	HD/070	482	-57	322	99
CRK	10:10	320/FL170	4.9	HD/070	407	-19	319	50
SHA	10:23	128/900	4.2	HD/070	130	+13	353	55
EINN	10:24	128/100	4.2	HD/070	128	+15	001	2

FUEL INFORMATION AT 08:32

WEIGHT	CG	FOB	RSV/RSW%	FINAL	EXTRA
65.0	37.3%	13.6	0.4/5.0%	3.1	2.8

Note: In case of a major failure such as an engine out, a new print will be done when time permits.

**REACHING THE GATE AFTER LANDING**

Ident.: DSC-22\_20-80-00000970.0007001 / 18 MAR 11

**Applicable to: ALL**

The POSTFLIGHT REPORT gives a complete list of all the overflown waypoints during the flight (HISTORY VALUES).

Furthermore it provides:

- FUEL/TIME summary
- IRS Drift and G/S

When at the gate, after engine shutdown:

- ACCESS the PRINT FUNCTION page
- PRINT the POSTFLIGHT REPORT

*Note: If the selected Fuel Unit option is pounds, the HISTORY FOB values may be incorrectly printed in tons on the POSTFLIGHT REPORT.*



**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT MANAGEMENT**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

PRINT FUNCTIONS

**EXAMPLE (FM POSTFLIGHT REPORT)**

Ident.: DSC-22\_20-80-00000971.0001001 / 18 MAR 11

Applicable to: ALL

FM POSTFLIGHT REPORT

DATE : 24 OCT 06

TIME : 12 : 05

A/C TYPE	: A320-200	DATABASE	: AB49402001
ENG TYPE	: CFM56-5B4	CYCLE	: 29 SEP-26 OCT
FLT NUMBER	: AIB 105	FROM/TO	: EINN/LFBO
CO RTE	: .....	ALTN	: LFBP
ALTN CO RTE	: .....		
PERF FACTOR	: +1.5	COST INDEX	: 90
IDLE FACTOR	: +0.0		
FLIGHT PLAN DATA			

DEST-LFBO	DIST	TIME	CRZ FL				
ALTN/	:—	11:52	FL—				
DEP RWY	:—	:—	FL—				
DEP PRC	: 06		ARV PRC	: AGN2T			
	: .....		APR PRC	: VOR32L			
			ARV RWY	: 32L			

WPT	TIME	SPD/ALT	FOB	T. WIND	TAS	SAT	CRS	DIST
HISTORY VALUES								
EINN06	10:17	134/44	17.0	043/005	-	+11	053	0
1550	10:18	163/1536	16.9	235/019	165	+08	050	2
SHA	10:18	161/1691	16.9	236/019	163	+08	049	0
ABCRK	10:27	305/FL280	15.1	295/049	459	-41	149	53
TIVLI	10:33	.80/FL330	14.8	298/057	448	-64	143	46
LND	10:44	.84/FL330	14.1	320/034	477	-61	129	111
ABLIZAD	10:51	.84/FL330	13.6	326/034	474	-61	141	47
ABBERAT	10:58	.84/FL330	12.4	313/029	480	-59	141	21
ABOIN	11:03	.84/FL330	12.2	326/030	479	-60	142	44
ABNTS	11:13	.84/FL330	12.0	330/034	481	-60	142	126
ABVENAR	11:21	.84/FL330	10.2	335/028	479	-60	143	24
CGC	11:25	.84/FL330	9.7	339/031	476	-61	150	33
VELIN	11:31	.84/FL330	9.2	352/028	476	-60	154	45
AGN	11:40	312/FL220	8.6	050/024	429	-26	149	72
SOTAK	11:40	321/FL190	8.3	052/025	425	-20	141	5
D191K	11:44	253/FL90	8.1	347/015	288	+00	137	24
D165R	11:46	253/4360	7.6	309/014	265	+04	103	11
CD32L	11:49	175/2967	6.9	293/009	180	+05	322	5
FD32L	11:50	253/FL1609	6.2	308/007	132	+08	323	4
LFB032L	11:52	132/674	6.2	326/006	131	+11	321	3

FUEL AND TIME SUMMARY

START UP	SHUT DOWN
FUEL : 17.0	FUEL : 4.2
WEIGHT : 75.8	WEIGHT : 65.0
TIME : 10.09	TIME : 12:01
TO TIME : ---	LDG TIME : 11:52

IRS DATA AT : LFB032L

AVERAGE DRIFT	IRS 1	IRS 2	IRS 3
RESIDUAL GND SPD	- 00.3 NM/H	00.4 NM/H	00.3 NM/H
	- 01.0 KTS	03.0 KTS	1.0 KTS



## **AUTOMATIC FMGC RESET AND RESYNCHRONIZATION**

Applicable to: ALL

Ident.: DSC-22\_20-90-10-A-00012661.0001001 / 07 MAR 13

### **FM RESET**

When the FM software cannot work properly or receives instructions to perform impossible operations, it automatically resets itself. A resynchronization with the other FM always follows. When the reset is a minor one, the system will recover by itself. One single reset lasts 2 to 3 s maximum followed by 25 s of resynchronization.

When the reset is a major one:

- Resets recur at short intervals (several in 2 or 3 min)
- The memories are cleared, leading to the loss of F-PLN , GW , CI , CRZ FL , MCDU -entered speeds and NAVAIDs and to database switching.

***Note:** If three dual FM resets occur in 2 min, pilot-entered data is lost. If a dual reset is identified, it is recommended that the flight crew does not perform again the last MCDU actions for 1 min (in order to avoid a potential second dual reset, leading to the loss of pilot-entered data).*

Ident.: DSC-22\_20-90-10-A-00012662.0001001 / 10 JAN 11

### **FM RESYNCHRONIZATION**

An FM resynchronization automatically occurs after an FM reset but it may occur independently each time self comparisons between FM 1 and FM2 reveal discrepancies.

One single resynchronization lasts approximately 25 s.

If 5 several resynchronizations occur within 5 min, independent mode commences.

Ident.: DSC-22\_20-90-10-A-00012663.0001001 / 29 SEP 15

### **FMGC STATUS DURING A RESET/RESYNCHRONIZATION**

While a RESET/RESYNCH occurs:

- The ND shows "MAP NOT AVAIL"
- The MCDU reverts to the A/C STATUS page, with "PLEASE WAIT" displayed in the scratchpad
- Autotuning of Nav aids (VOR , DME , ADF) are lost on the failed side
- AP and managed modes may be transiently lost (reversion to HDG /V/S or TRK/FPA)
- If the pilot presses a key while the scratchpad is showing "PLEASE WAIT", there is no change at MCDU level. This is normal, and the crew should not respond by pulling the MCDU circuit breaker.



Ident.: DSC-22\_20-90-10-A-00012664.0002001 / 10 JAN 11

### SINGLE RESET OR DUAL RESET WITH AUTORECOVERY

If the RESET/RESYNCH succeeds, all functions are recovered.

*Note:* When an FMGC is recovered, its FD if previously engaged, is also recovered and its status is displayed on the FMA.

### **PROCEDURE**

RESELECT the convenient MCDU page.  
 REENGAGE managed modes and the AP.

*WAIT 1 min after the "PLEASE-WAIT" message has disappeared, before engaging the AP /FD of the failed FMGC.*

If both "MAP NOT AVAIL" and "SET OFFSIDE RNG/MODE" remain displayed on one ND , or if "OFFSIDE FM CONTROL" remains displayed, temporarily SELECT a different mode or range on the corresponding EIS control panel.

Ident.: DSC-22\_20-90-10-A-00012665.0002001 / 16 NOV 11


### SINGLE LATCH

If five successive resets occur, the failing FMGC will latch, and single mode operation will start.

While failed, the following occurs:

- On the ND usually associated with the failed FMGC:  
 If the ND s are not both in the same mode or range, the associated ND displays "MAP NOT AVAIL" and "SET OFFSIDE RNG/MODE". If the ND s are in the same mode and range, the associated ND displays the "OFFSIDE FM CONTROL" amber message
- The MCDU reverts to the MENU PAGE and shows an "FMGC TIME OUT" prompt

- If the AP and FD were previously engaged on the failed side, the AP and FD disengage and the right-hand column of the FMA shows that the operating FD is offside. The ECAM displays the “AP OFF” warning, and the master warning light and audio remind the pilot of the AP disengagement.
- All functions are restored on the operative side.



## PROCEDURE

Select the same range and mode on both ND s to give the failed ND side something to display. Select any function key on the affected FMGC MCDU. (The page will display “OPP FMGC IN PROGRESS”).

*Both MCDU s are now driven by the other FMGC , and only one AP /FD is available. The system works in SINGLE Mode.*

Perform a manual reset of the failed FMGC, when convenient.

Ident.: DSC-22\_20-90-10-A-00012666.0012001 / 10 JAN 11

## DUAL RESET WITH LOSS OF DATA AND AUTORECOVERY

Three successive dual resets without result erases all pilot-entered data (F-PLN , GW , CRZ FL , Cl...).

When FMGS recovery is obtained:

- Database cycle may have switched
- The FM position bias is lost. The FM position returns to the MIX IRS position
- Autotuning the VOR /DME is restored, based on the aircraft’s IRS position
- FMGS tuning of the ILS and ADF is not possible
- Lateral and vertical managed mode cannot reengage

- The “CAB PR LDG ELEV FAULT” ECAM message is displayed
- A map display may be lost on one ND.

## PROCEDURE

When the system has recovered:

SELECT the initial database.

SELECT DIR TO the required downpath waypoint.

SELECT LAT REV at the downpath waypoint, and redefine the DESTINATION.

SELECT the FUEL PRED page, and enter GW.

SELECT the PROG page, and enter CRZ FL.

SELECT the PERF page, and enter CI.

CHECK or reengage (as appropriate) the relevant speed/Mach target and vertical mode.

*Redefine the flight plan for the remainder of the flight, as the opportunity presents itself.*

If both “MAP NOT AVAIL” and “SET OFFSIDE RNG/MODE” remain displayed on one ND , or if “OFFSIDE FM CONTROL” remains displayed, temporarily SELECT a different mode or range on the corresponding EFIS control panel.

PERFORM a NAV accuracy check, when possible.

*A manual FM position update should be considered, if MIX IRS and actual positions differ by more than 20 NM.*

Ident.: DSC-22\_20-90-10-A-00012668.0013001 / 17 MAR 17

## DUAL LATCH

- Both FMGC s are inoperative. FM and FG capability are lost
- Both ND s display “MAP NOT AVAILABLE”. NAVAID tuning is not performed
- AP /FD , A/THR are lost
- FMGC (TIME OUT) subsystem page is displayed on both MCDUs
- The following messages are displayed on the ECAM:
  - “CAB PR LDG ELEV FAULT”
  - “AUTO FLT AP OFF”, if AP was engaged
  - “AUTO FLT A/THR OFF”, if A/THR was engaged.

## PROCEDURE

FLY raw data.

TUNE necessary NAVAID s using the RMPs.

PERFORM a manual reset of both FMGCs.

- **If successful, refer to dual reset with loss of data and auto recovery:**

*Note: A recovery will result in the loss of all pilot-entered data.*

■ **If unsuccessful:**

FLY raw data.

Select the NAV B/UP prompt on both MCDU DATA pages.

*(Refer to DSC-22\_20-60-130 General HOW TO USE, concerning navigation backup operation).*

SET the landing elevation of the destination on the overhead panel.

**Note for all FMGC automatic resets**

- A single or double FM auto-reset does not affect an ILS approach below 700 ft AGL . ILS frequency is locked and AP /FDs remain engaged
- Above 700 ft , the loss of ILS tuning due to a dual reset will cause a loss of LOC and G/S , and the disengagement of AP s and FDs
- During a non ILS approach, if the master FMGC fails, AP /FD and managed modes are lost and FDs engage in basic modes.

**MANUAL FMGC RESET**

Applicable to: **ALL**

Ident.: DSC-22\_20-90-10-B-00012669.0001001 / 10 JAN 11

On rare occasions, the FMGC may require manual resetting.  
If this occurs in flight, reset one FMGC at a time.

Ident.: DSC-22\_20-90-10-B-00020857.0001001 / 17 MAR 17

*Refer to System Reset Table - AUTO FLT*  
for the manual reset procedure of the FMGC.

Ident.: DSC-22\_20-90-10-B-00012671.0001001 / 17 MAR 17

**MANUAL RESET OF BOTH FMGC**

When the aircraft is on ground with the engines stopped, the flight crew may attempt a double and simultaneous CB reset when a single CB reset has failed.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

ABNORMAL OPERATIONS - FMGC RESET

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>AUTO FLIGHT - FLIGHT MANAGEMENT</b></p> <p align="center">ABNORMAL OPERATIONS - "CHECK GW" OR "CHECK WEIGHT" MESSAGE</p>
---	---

**"CHECK WEIGHT" MESSAGE**

Ident.: DSC-22\_20-90-20-00012677.0001001 / 17 MAR 17  
**Applicable to: ALL**

**DESCRIPTION**

The "CHECK WEIGHT" message appears on the MCDU when the Gross Weight (GW ) computed by the FMGC and the GW computed by the FAC disagree by more than 7 t (16 055 lb).

**PROCEDURE**

When this message appears:

FMS FOB ..... CHECK  
*CALL UP the MCDU FUEL PRED page and compare the FOB to the FOB from the Computerized F-PLN. Correct it if necessary.*

FMS ZFW value..... CHECK  
*CALL UP the MCDU FUEL PRED page and compare the ZFW to the ZFW on the loadsheet.*

● **If the FMS ZFW on the MCDU is not correct:**  
 FMS ZFW ..... CORRECT/RE-INSERT  
*The entry of a correct ZFW will clear the MCDU message.*

● **If the FMS ZFW on the MCDU is correct:**  
 VLS , F , S , GREEN DOT (PFD)..... DISREGARD  
*If the FMS GW is correct, the characteristic speeds computed by the FAC (displayed on PFD) may not be correct.*

QRH OPERATING SPEEDS..... USE  
*Refer to QRH/OPS Operating Speeds*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

ABNORMAL OPERATIONS - "CHECK  
GW" OR "CHECK WEIGHT" MESSAGE

Intentionally left blank



**MISALIGNMENT OF FMS F-PLN LEGS FOR ILS APPROACHES**

Ident.: DSC-22\_20-100-20-00013650.0001001 / 23 JUN 15

Applicable to: ALL

For the F-PLN legs belonging to an ILS approach, the FMS incorrectly uses its own Magnetic Variation table instead of the Magnetic Variation of the ILS associated to the approach (coded in the Navigation Data Base). This misbehaviour occurs when the Navaid used for the ILS approach is a DME.

In some cases, it may happen that magnetic variation of the airport differs by a few degrees from the ILS navaid. Thus, the FMS F-PLN does not match with the actual beam of the ILS beam.

When the ILS approach is coded with successive legs, these legs may also appear as not matching with intermediate approach waypoint.

For all approaches affected by this behaviour, the FMS will display an incorrect trajectory on ND for the LS approach. The guidance would also be wrong if the approach legs are flown in NAV instead of LOC mode.

**INCORRECT MANAGEMENT OF ETA ENTRY ON PREDICTIVE GPS PAGE**

Ident.: DSC-22\_20-100-20-00013652.0001001 / 22 MAY 12

Applicable to: ALL

During pre-flight, when a destination airport exists but the FMS does not compute predictions, amber boxes are displayed in the MCDU field ETA of the predicitive GPS page. When the flight crew manually enters an ETA, the value should be displayed in large cyan font.

With the current H2 standard, the FMS does not take into account the manual entry of an ETA (field 1R) for the destination (DEST, field 1L).


The FMS validates the manual entry only when an ETA is already computed by the FMS , when predictions are available (necessary conditions to have some predictions are : entry of a GW , CRZ FL , Cl and F-PLN).

This anomaly does not impact the ETA of the WPT field (3L and 3R). An ETA can be entered in the field 3L even if no predictions are computed.

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

TEMPORARY ABNORMAL BEHAVIORS - FMS2  
 HONEYWELL TEMPORARY ABNORMAL BEHAVIORS



**FLIGHT NUMBER ERASED UPON AOC FLIGHT PLAN UPLINK**

Ident.: DSC-22\_20-100-20-00013653.0001001 / 16 MAR 11

Applicable to: **ALL**

When a Flight Plan (F-PLN ) uplink is performed, if the uplinked F-PLN is inserted as the active F-PLN but does not contain a Flight Number, the previously entered Flight Number is erased. In such a case, the flight crew needs to re-enter the correct Flight Number on the INIT A page.

**ERRONEOUS FUEL PREDICTION IN THE CASE OF DESCENT WITH TWO ALTITUDE CONSTRAINTS**

Ident.: DSC-22\_20-100-20-00013655.0001001 / 16 MAR 11

Applicable to: **ALL**

**DESCRIPTION:**

If the flight plan has two altitude constraints for the descent, the flight crew may notice erroneous FMS fuel predictions.

**EXPLANATION**

If the flight plan has two altitude constraints for the descent, the FMS may define a geometric segment between both altitude constraints. If there is a deceleration required within the geometric segment, the FMS may consider that the geometric segment is too steep to fly without speedbrakes. In this case, the FMS tags the entire geometric segment as a speedbrake segment : The FMS assumes that during the entire segment half of the speedbrakes are extended, even for the parts where no deceleration is planned. As a consequence, the FMS will predict an increased thrust for the entire geometric segment. This may lead to erroneous fuel predictions. (a long geometric segment (e.g. above 100 NM) may lead to an error of 1.5 t for the fuel prediction at destination).

*Note:* When flying the geometric segment, the predictions become better as the aircraft approaches the end of the geometric segment, and turn back to normal when the aircraft has sequenced the second altitude constraint.

**PROCEDURE:**

If the flight crew suspects this behavior in preflight, or during the flight, they can delete and enter again one altitude constraint in descent and compare the fuel predictions of the flight plan with and without the geometric segment. This allows the flight crew to evaluate the impact of the geometric segment on the fuel predictions.

It is not recommended to permanently delete altitude constraints that are stored in the navigation database.

**UNEXPECTED SWITCH OF SPEED TARGET WHEN RTA IS USED**

Ident.: DSC-22\_20-100-20-00013659.0001001 / 16 NOV 11

Applicable to: ALL

An anomaly could be experienced when the RTA (Requested Time of Arrival) function is used. The MCDU and the PFD could suddenly display an erroneous speed target at the transition altitude when a RTA is entered and if the flight crew performs an action (Vapp entry or altitude constraint modification) that causes a F-PLN profile recomputation.

This scenario could also occur if the flight crew has inserted a RTA and then deleted this RTA (the FMS may erroneously retain the RTA target).

Some cases could happen while the aircraft is in descent (DES mode) in managed speed. This speed target change is significant at high altitude if the RTA speed target is lower than the speed target used before the beginning of the descent.

**PROCEDURE**

If an erroneous speed target is displayed at high altitude, the flight crew can manually select a speed to continue the descent.

**UNDUE AP DISCONNECTION OR REVERSION TO V/S DURING CLIMB AND DESCENT**

Ident.: DSC-22\_20-100-20-00014436.0017001 / 23 JUN 15


Applicable to: ALL

An AP disconnection or a reversion to the V/S mode may occur when the aircraft reaches an altitude constraint in the CLB or DES mode. The following are two situations in which this behavior may occur.


**Situation 1:** The aircraft is above the vertical profile.


When the aircraft is not on the vertical profile, the FMS makes assumptions in order to compute the FMS predictions. For example, if the aircraft flies in selected speed, the FMS considers an immediate return to managed speed.

These assumptions can result in FMS predictions that are not consistent with the real trajectory of the aircraft. Therefore, the FMS may not anticipate the need to level off, when the FCU selected altitude is above the altitude constraint in climb or below the altitude constraint in descent.



However, the FMS requests the ALT CST\* mode, when the aircraft reaches the altitude constraint, in order to level off and comply with the altitude constraint.

Due to problem of communication between the FMS and the FG , the FMGC may unduly revert to the V/S mode. The FWC triggers a triple-click aural warning  , and the aircraft goes beyond the altitude constraint.




**Situation 2:** The aircraft levels off at an altitude constraint in descent.


When the aircraft reaches an altitude constraint with the DES mode engaged and the FCU selected altitude below the altitude constraint, the FG engages the ALT CST \* mode. The FG also arms the DES mode, in order to resume the descent beyond the waypoint with the altitude constraint.

In very rare cases, the FMS does not see that the FG arms the DES mode:

- If the FINAL APP mode is armed, the FMGC may unduly:
  - Disconnect the AP, or
  - Disconnect the AP and revert to the V/S mode, or
  - Revert to the V/S mode.
- If the FINAL APP mode is not armed, the FMGC may unduly revert to the V/S mode.

In both of the above-mentioned cases, the FWC triggers a triple-click aural warning , and the aircraft goes beyond the altitude constraint.

If the AP disconnects, the FWC triggers a cavalry-charge aural warning.



**OPERATIONAL RECOMMENDATIONS**

Understand your FMA at all times.

- **If the AP disconnects, or if the FMGC reverts to the V/S mode:**

Adjust the vertical speed or level off in order to comply with the altitude constraint.

**VOR/DME AND VOR/TACAN NOT AUTOMATICALLY TUNED**

Ident.: DSC-22\_20-100-20-00014440.0001001 / 04 MAY 12

Applicable to: ALL

In case there is no NAVAID in the flight plan, nor any recommended NAVAID coded in the inserted procedure, the FMS may not automatically tune the expected Terminal or Low Altitude VOR /DME or VOR /TACAN.

The FMS may not automatically tune the expected NAVAID , if the aircraft is above 12 000 ft for a Terminal VOR /DME or VOR /TACAN , and above 18 000 ft for a Low Altitude NAVAID.

As a consequence, the ND and the MCDU RAD NAV page may not display the NAVAID information.

**OPERATIONAL RECOMMENDATIONS**

If the flight crew encounters the misbehavior during the flight, the flight crew can manually tune the expected VOR /DME or VOR /TACAN to recover the display on the ND.

As a manual tuning overrides any automatic tuning, the flight crew must clear the manual tuning, when the NAVAID is no longer required, in order to revert to the automatic NAVAID tuning.

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT MANAGEMENT

TEMPORARY ABNORMAL BEHAVIORS - FMS2  
HONEYWELL TEMPORARY ABNORMAL BEHAVIORS

### OPTIMUM TARGET SPEEDS NOT UPDATED FOLLOWING THE AUTOMATIC DELETION OF A STEP CLIMB

Ident.: DSC-22\_20-100-20-00014756.0001001 / 18 DEC 12

Applicable to: ALL

During the FMS climb phase, if the flight crew selects an altitude on the FCU that is above the Cruise Flight Level (CRZ FL) displayed on the PROG page, the altitude selected on the FCU becomes the new CRZ FL.

If this new CRZ FL is at or above the altitude of a Step Climb of the flight plan, the FMS automatically deletes the Step Climb. The FMS displays the "STEP DELETED" message.

As the optimum target speeds (ECON CLIMB speed/Mach and ECON CRUISE speed/Mach) depend on the CRZ FL, the FMS should immediately update the ECON CLIMB speed/Mach and the ECON CRUISE speed/Mach.

Due to a FMS misbehavior, the FMS may not correctly manage the automatic deletion of the Step Climb when the CRZ FL is automatically set to the altitude selected on the FCU. The FMS may not update the ECON CLIMB speed/Mach and the ECON CRUISE speed/Mach accordingly.

If the ECON CRUISE speed/Mach was not correctly updated, the FMS updates the ECON CRUISE speed/Mach when the aircraft reaches the new CRZ FL. However the FMS updates the ECON CRUISE speed/Mach with a rate of 0.01 Mach/min, in order to avoid a sudden increase of the speed target. Therefore the aircraft may take several minutes to reach the new ECON CRUISE speed/Mach.

### OPERATIONAL RECOMMENDATIONS

If the flight crew suspects this misbehavior during the flight:

REENTER the Cruise Flight Level (CRZ FL) on the PROG page, or the Cost Index (CI) on the PERF page, in order to activate an immediate update of the optimum target speeds (ECON CLIMB speed/Mach and ECON CRUISE speed/Mach).

### ERRONEOUS LATERAL GUIDANCE IN NAV MODE WITH LOC MODE ARMED DURING APPROACH

Ident.: DSC-22\_20-100-20-00015035.0001001 / 03 DEC 13

Applicable to: ALL

During approach, the FMS may guide the aircraft along a specific track instead of along the F-PLN with NAV mode green on the FMA, because of the LOC Convergence function (*Refer to DSC-22\_30-80-30-10 Precision Approach Modes - APPR Mode*).

The logics of the LOC Convergence function is as follows:

- If NAV mode is engaged, and LOC mode is armed,  
and  
The aircraft is within 20 NM of the destination runway,  
and  
The difference between the aircraft track and the QFU is less than 20 °.  
The aircraft is guided with a converging track of 20 ° from the LOC axis.  
The NAV mode remains engaged. However the aircraft no longer follows the F-PLN, but converges towards the LOC axis.
- If the difference between the aircraft track and the QFU becomes more than 20 ° when the LOC Convergence function is active:  
The FMS deactivates the LOC Convergence function, and the aircraft follows back the F-PLN. It may lead to slight oscillations, since the FMS may successively activate and deactivate the LOC Convergence function.

#### OPERATIONAL RECOMMENDATIONS

- If the flight crew considers that the LOC Convergence function may affect the guidance along the F-PLN trajectory in NAV mode:  
On the intercept trajectory for the LOC axis, the flight crew should push the APPR pb (or the LOC pb-sw) when appropriate.
- If the flight crew detects that the aircraft does not follow the intended trajectory:  
The flight crew should revert to HDG/TRK mode, and intercept the LOC axis with the HDG/TRK mode engaged and the LOC mode armed.

#### **UNDUE REDUCTION OF THE SPEED TARGET IN CASE OF DIR TO/ABEAM WHILE FLYING A CONSTANT MACH SEGMENT**

Ident.: DSC-22\_20-100-20-00015532.0003001 / 18 MAR 14

Applicable to: ALL

The FMS may erroneously command a Mach target of 0, when the following conditions are met:

- The aircraft is flying a Constant Mach Segment (CMS), and
- The TO waypoint is the end of the CMS, and
- The aircraft is close to the TO waypoint, i.e. about 1 NM, and
- The flight crew performs a DIR TO/ABEAM to a waypoint that is not part of the CMS.

In that case, the FMS does not create the abeam of the TO waypoint (end of the CMS), since it is too close from the aircraft.

In addition, the FMS erroneously keeps the CMS until the abeam of the next waypoint, and defines 0 as Mach target on the CMS . The FMS correctly computes the speed target once the abeam of the next waypoint is sequenced.

**OPERATIONAL RECOMMENDATIONS**

The flight crew should manually clear the CMS on the MCDU VERT REV page.

**LOSS OF FUEL AND TIME PREDICTIONS DURING TAKEOFF DATA INSERTION**


Ident.: DSC-22\_20-100-20-00015602.0001001 / 05 AUG 14

Applicable to: ALL

The flight crew may lose fuel and time prediction when the altitude of the first constraint is less than 50 ft below either the THR RED ALT or the ACC ALT , the update of fuel and time computation predictions may last a long time. The flight crew may think that the predictions are lost (the DEST EFOB and TRIP FUEL are also dashed on the FUEL PRED page).

The flight crew may encounter the situation described above, if one of the following occurs:

- The first altitude constraint of the SID is less than 50 ft below either the THR RED ALT or the ACC ALT.
- The flight crew inserts a THR RED ALT or an ACC ALT less than 50 ft above the first altitude constraint of the F-PLN.
- The flight crew modifies the F-PLN to insert an AT or an AT OR BELOW altitude constraint less than 50 ft below the THR RED ALT or the ACC ALT.



**OPERATIONAL RECOMMENDATION:**

The flight crew can recover the fuel and time predictions if the flight crew sets the THR RED ALT or ACC ALT value on the PERF TAKEOFF page to the same value as the first altitude constraint of the F-PLN.



**ERRONEOUS TRAJECTORY DURING PROCEDURES WITH A  
TURN DIRECTION ON A LEG WITH AN ALTITUDE TERMINATION**

Ident.: DSC-22\_20-100-20-00015748.0001001 / 09 SEP 14

Applicable to: ALL

In some very specific operational conditions that depend on the coding in the Navigation Database of the procedure, and on various performance conditions (aircraft weight, flaps, thrust setting, temperature, wind...), the FMS may compute an erroneous trajectory on some Standard Instrument Departures (SID), and on some Missed Approach procedures.

The SIDs and the Missed Approach procedures that may be affected are coded in the Navigation Database with a leg that has a turn direction and an altitude termination. The leg can be one of the following:

- A Course-to-an-Altitude (CA) leg that defines a course to follow to an altitude
- A Fix-to-an-Altitude (FA) leg that defines a track to follow from a waypoint to an altitude
- A Heading-to-an-Altitude (VA) leg that defines a heading to follow to an altitude
- A Holding-to-an-Altitude (HA) leg that defines a holding pattern to an altitude


The turn direction (left or right) that is coded on a leg indicates that the aircraft has to execute a turn in the specified direction to intercept the leg.

In some very specific operational conditions (aircraft weight, wind...), the FMS may predict that the aircraft will reach the altitude that terminates the leg, before the initiation of the leg. In that case, the FMS ignores the leg, and the associated turn direction.

The FMS computes a new trajectory to directly join the next leg. The trajectory may not be consistent with the published trajectory.

Example:

- Leg 1: a Course-to-Fix (CF) leg that defines a track (360 °) to a waypoint (WPT1)
- Leg 2: a Course-to-an-Altitude (CA) leg that defines a track (130 °) to intercept an altitude (3 000 ft). The leg is coded in the Navigation Database with a turn direction (left). The end of the leg depends on the aircraft performance. The turn direction is indicated by an arrow on the line of leg 1 on the MCDU
- Leg 3: a CF leg that defines a track (120 °) to a waypoint (WPT2)



Depending on the aircraft performance, the FMS may predict that the aircraft will reach 3 000 ft before WPT1. In that case, the FMS ignores the leg 2 (CA leg) because the aircraft is already above the altitude that ends leg 2, before the beginning of leg 2. The FMS also ignores the turn direction that is coded on the leg.

As a result, the FMS computes again the trajectory from the end of leg 1, directly to leg 3. As shown on the above illustration, this trajectory includes a right turn, instead of a left turn, because it induces the shortest course change to intercept leg 3 (CF leg).

If the NAV mode is engaged, the aircraft follows this erroneous trajectory.

**OPERATIONAL RECOMMENDATIONS**

The flight crew should pay particular attention to the check of the flight plan during the Cockpit Preparation, and during the Descent Preparation.

**CAUTION** Even if the flight plan is correct during the Cockpit Preparation or during the Descent Preparation, the FMS may compute and display an erroneous trajectory when the FMS updates its predictions after takeoff or after go-around initiation.

If the flight crew detects that the lateral flight plan does not agree with the published trajectory, the flight crew should revert to the HDG /TRK mode, and monitor NAVAID raw data as appropriate. The flight crew should reengage the NAV mode when the lateral flight plan is consistent with the published trajectory.

**ERRONEOUS VERTICAL PROFILE DURING LOC B/C APPROACHES WITH A MAP LOCATED BEFORE THE RUNWAY THRESHOLD**

Ident.: DSC-22\_20-100-20-00019782.0001001 / 25 JUL 16


Applicable to: ALL

**DESCRIPTION**

When the flight crew selects a LOC Back Course (LOC B/C ) approach in the arrival page of the MCDU , if the Missed Approach Point (MAP ) is located before the runway threshold, the FMS

builds the final approach vertical flight path assuming that there is an altitude constraint at the MAP, equal to the runway (RWY) threshold elevation plus 50 ft, disregarding the actual coded MAP altitude.

As a result, the FMS computes an erroneous vertical flight path for the final approach, an erroneous crossing altitude at the MAP, and displays an erroneous vertical deviation indication (V/DEV symbol on the PFD and V/DEV value on MCDU PROG page), when flying the approach.



Therefore, the flight crew must fly the LOC B/C approaches in selected vertical guidance mode (FPA or V/S mode), and they must disregard the V/DEV displayed on the PFD and MCDU PROG page.

**PROCEDURE**

For LOC B/C approaches, check the position of the MAP on the approach chart:

■ **If the MAP is located at the runway threshold:**

V/DEV symbol can be used to assist the flight crew in flying the vertical flight path in selected mode. Crosscheck the final descent with the published chart using altitude versus distance, as per Standard Operating Procedures (SOPs).

■ **If the MAP is located before the runway threshold:**

DISREGARD the V/DEV symbol, and crosscheck the final descent using the altitude versus the distance to the MAP.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

TEMPORARY ABNORMAL BEHAVIORS - FMS2  
HONEYWELL TEMPORARY ABNORMAL BEHAVIORS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT MANAGEMENT

TEMPORARY ABNORMAL BEHAVIORS - ALL  
FMS TEMPORARY ABNORMAL BEHAVIORS

## ERRONEOUS PREDICTIONS

Ident.: DSC-22\_20-100-40-00012672.0001001 / 17 MAR 17

Applicable to: ALL

The FMGS may display temporary erroneous predictions that can affect such data as ECON speed/Mach, optimum flight level, fuel or time predictions.

### PROCEDURE

If erroneous predictions are observed:

#### **ON GROUND, OR IN FLIGHT**

Check the cruise temperature (sign and value), the gross weight, and the cruise flight level.  
REENTER the same cost index to restart a computation (In descent or approach, a cost index change does not restart a computation), or  
MAKE a COPY ACTIVE, then activate the secondary, or  
MAKE a DIR TO the "TO" waypoint.

## SPURIOUS ENGINE OUT INDICATION

Ident.: DSC-22\_20-100-40-00012673.0001001 / 17 MAR 17

Applicable to: ALL

### PROCEDURE

If a spurious engine-out is detected:

PRESS the EO CLR prompt of the MCDU PERF page  
RE-ENGAGE previous vertical mode  
RE-ENTER preselected speeds (if any). No other consequences are to be expected.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT MANAGEMENT**

TEMPORARY ABNORMAL BEHAVIORS - ALL  
FMS TEMPORARY ABNORMAL BEHAVIORS

Intentionally left blank

# **AIRCRAFT SYSTEMS**

AUTO FLIGHT - FLIGHT GUIDANCE

Intentionally left blank



**DSC-22\_30-10 General**

General.....	A
Mode Reversions.....	B
Guidance Modes.....	C
Mode Selection.....	D
Lateral Modes.....	E
Vertical Modes.....	F
Interaction between AP/FD and A/THR Modes.....	G

**DSC-22\_30-20 Flight Director**

General.....	A
Flight Director (FD) Engagement.....	B
Flight Director (FD) Disengagement.....	C
Automatic FD Removal.....	D
FD Warnings.....	E

**DSC-22\_30-30 Autopilot (AP)**

General.....	A
AP Engagement.....	B
AP Disengagement.....	C
AP Warnings.....	D
Autoland Warning.....	E

**DSC-22\_30-40 Speed/Mach Control**

General.....	A
Managed Speed/Mach Target.....	B
Selected Speed/Mach Target.....	C
Auto SPD.....	D
Speed/Mach Switching.....	E
Managed Speed Target Memorization.....	F
Speed/Mach FCU Window Synchronization.....	G

**DSC-22\_30-50 AP/FD Modes General**

AP/FD Modes General.....	A
--------------------------	---

**DSC-22\_30-60 AP/FD Lateral Modes**

Heading or Track: HDG - TRK.....	A
HDG/TRK Preset.....	B
Navigation (NAV).....	C
Localizer Mode through the LOC Pushbutton.....	D

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_30-70 AP/FD Vertical Modes**

**DSC-22\_30-70-10 Principles**

General.....	A
Principles.....	B

**DSC-22\_30-70-20 Climb Mode**

General.....	A
Arming Conditions.....	B
Disarming Conditions.....	C
Engagement Conditions.....	D
Disengagement Conditions.....	E
Guidance.....	F

**DSC-22\_30-70-30 Open Climb Mode**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

**DSC-22\_30-70-50 Descent Mode**

General.....	A
Arming Conditions.....	B
Disarming Conditions.....	C
Engagement Conditions.....	D
Disengagement Conditions.....	E
Repressurization Segment.....	F
Descent Speed Profile.....	G
Guidance in DES Mode.....	H
DES Mode Profile.....	I

**DSC-22\_30-70-60 Open Descent Mode**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

**DSC-22\_30-70-65 Altitude Acquire Mode**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_30-70-70 Altitude Hold Mode**

General.....	A
Arming Conditions.....	B
Engagement Conditions.....	C
Disengagement Conditions.....	D
Guidance.....	E
Soft Altitude Mode (Cruise).....	F

**DSC-22\_30-70-80 Vertical Speed Mode - Flight Path Angle Mode (V/S - FPA)**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

**DSC-22\_30-70-90 Expedite**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

**DSC-22\_30-75 Mode Reversions**

General.....	A
Interaction between Lateral Modes, Vertical Modes, and Managed Speed Profile.....	B
Mode Reversion due to FCU Altitude Change.....	C
Reversion with Global Speed Protection.....	D
Mode Reversions (Summary).....	E

**DSC-22\_30-80 AP/FD Common Modes**

**DSC-22\_30-80-10 General**

General.....	A
--------------	---

**DSC-22\_30-80-20 Takeoff**

General.....	A
SRS (Speed Reference System).....	B
Runway (RWY).....	C

**DSC-22\_30-80-30 Approach**

**DSC-22\_30-80-30-05 General**

General.....	A
--------------	---

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_30-80-30-10 Precision Approach**

Precision Approach Modes.....	A
Speed Control.....	B
Typical ILS Approach.....	C
Autoland Warning Light.....	D
Landing Capabilities.....	E

**DSC-22\_30-80-30-20 Non Precision Approach**

General.....	A
Selection.....	B
Arming Conditions.....	C
Disarming Conditions.....	D
Engagement Conditions.....	E
Disengagement Conditions.....	F
Guidance.....	G

**DSC-22\_30-80-40 Go Around (GA)**

General.....	A
Engagement Conditions.....	B
Disengagement Conditions.....	C
Guidance.....	D

**DSC-22\_30-90 Autothrust**

General.....	A
Thrust Levers.....	B
A/THR Arming Conditions.....	C
A/THR Activation.....	D
A/THR Disconnection.....	E
Thrust Lock Function.....	F
A/THR Disconnection Caution.....	G
A/THR Modes.....	H
SPEED Mode in Approach Phase.....	I

*Continued on the following page*

*Continued from the previous page*

**DSC-22\_30-100 Flight Mode Annunciator (FMA)**

Flight Mode Annunciator (FMA).....	A
Autothrust Annunciations (FMA Column 1).....	B
AP/FD Vertical Modes (FMA Column 2).....	C
AP/FD Lateral Modes (FMA Column 3).....	D
AP/FD Common Modes (FMA Columns 2 and 3) .....	E
Approach Capabilities (FMA Column 4).....	F
AP/FD - A/THR Engagement Status (FMA Column 5).....	G
Special Messages (FMA Columns 2 and 3).....	H

**DSC-22\_30-110 Temporary Abnormal Behaviors**

CAT 3 Dual Inoperative.....	A
-----------------------------	---



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-10-00011031.0001001 / 17 AUG 10

**Applicable to: ALL**

The Flight Guidance (FG ) part of the FMGS controls:

- The Flight Director (FD)
- The Autopilot (AP)
- The Autothrust (A/THR).

**MODE REVERSIONS**

Ident.: DSC-22\_30-10-00011032.0001001 / 17 AUG 10

**Applicable to: ALL**

There are several types of mode reversions. Each one observes a specific logic that is described in the "Mode Reversions" section. (*Refer to DSC-22\_30-75 General*).


**GUIDANCE MODES**

Ident.: DSC-22\_30-10-00011033.0002001 / 23 JUN 15

**Applicable to: ALL**

Two types of autopilot and flight director modes are available to guide the aircraft:

- Managed modes: When the aircraft is using managed targets, the Flight Management and Guidance System (FMGS ) guides it along lateral and vertical flight paths and speed profiles computed by the Flight Management function (FM ) from data in the MCDU . FM manages the guidance targets.
- Selected modes: When the flight crew is using selected targets, the FMGS guides the aircraft along lateral and vertical flight paths and speed profiles to meet targets that the flight crew has selected manually on the FCU. The flight crew selects the guidance targets.

GUIDANCE	MANAGED modes	SELECTED modes
<b>LATERAL</b>	NAV, APP NAV LOC *, LOC RWY RWY TRK GA TRK ROLL OUT	HDG -TRK
<b>VERTICAL</b>	SRS (TO and GA) CLB , DES ALT CST, ALT CST* ALT CRZ G/S *, G/S FINAL, FINAL APP FLARE	OP CLB , OP DES V/S , FPA ALT *, ALT EXPEDITE 
<b>SPEED</b>	FMGC REFERENCE (ECON , Auto SPD , SPD LIM) EXPEDITE	FCU REFERENCE

**MODE SELECTION**

Ident.: DSC-22\_30-10-00011034.0001001 / 23 JUN 15

Applicable to: ALL

**MANAGED MODES**

- At takeoff, the managed modes engage automatically when the flight crew sets the thrust levers at the TO or FLX detent.
- During flight, the flight crew can arm or engage the managed modes (if the aircraft meets engagement conditions) by pushing in the appropriate knobs on the Flight Control Unit (FCU).
- The flight crew pushes the DIR TO key on the MCDU to insert a DIR TO leg. It engages or maintains the NAV mode.
- The flight crew pushes the APPR pb on the FCU to arm or engage the localizer and glide slope or “APP NAV-FINAL”, depending upon the approach type insert in the flight plan.
- The LOC pb arms or engages only the localizer mode.

**SELECTED MODES**

The flight crew can engage the selected modes by pulling out the appropriate FCU selection knobs.



**LATERAL MODES**

Ident.: DSC-22\_30-10-00011035.0003001 / 23 JUN 15

Applicable to: ALL

MODE	TYPE	GUIDANCE	REMARK
<b>RWY</b>	MANAGED	Mode used at takeoff to guide the aircraft along the runway centerline, using LOC.	Triggered by the thrust levers at FLX or TOGA position.
<b>RWY TRK</b>	MANAGED	Mode used to guide the aircraft along the track the aircraft was following at mode engagement.	
<b>NAV</b>	MANAGED	Mode used to guide the aircraft along the lateral F-PLN. Available above 30 ft after takeoff.	Automatically armed at takeoff, unless HDG /TRK is preset. In that case, RWY TRK engages after takeoff.
<b>HDG -TRK</b>	SELECTED	Mode used to guide the aircraft on a heading or a track selected by the flight crew. The target value is displayed in the FCU window.	<i>Note:</i> HDG /TRK is called "basic mode" because it is a backup mode for certain situations: - F-PLN discontinuity entry - AP engagement with no FD - Loss of F-PLN - MCDU NAV BACK UP.

Continued on the following page


*Continued from the previous page*

MODE	TYPE	GUIDANCE	REMARK
<b>LOC*</b> <b>LOC</b> <b>APP NAV</b>	MANAGED	Mode used to guide the aircraft on the lateral approach path (LOC or F-PLN approach path).	Selected by pressing APPR pb on the FCU ; the mode that engages depends upon the selected approach in the F-PLN.  <i>Note: For LOC only approach, do not select the FCU's APPR pb, but rather the LOC pb.</i>
<b>LAND</b>	MANAGED	Common mode engaged below 400 ft RA during an automatic ILS approach.	Engaged only if LOC mode and G/S mode are already engaged.
<b>GA TRK</b>	MANAGED	Mode used to guide the aircraft along the track the aircraft was following at mode engagement.	Triggered by the thrust levers at TOGA with Slats/Flaps in at least CONF 1.
<b>ROLL OUT</b>	MANAGED	Mode used to guide the aircraft on the runway, following an automatic landing.	FD rollout symbol is displayed on the PFD at touchdown.

**VERTICAL MODES**

Ident.: DSC-22\_30-10-00011036.0002001 / 23 JUN 15

Applicable to: ALL

MODE	TYPE	GUIDANCE	REMARK
<b>SRS</b>	MANAGED	Mode used at takeoff or go-around to maintain SRS speed (V2 , V2+10, VAPP...).	Triggered by the thrust levers at FLX or TOGA position. Disengages automatically at ACC ALT or when another VERT mode is engaged.
<b>CLB</b>	MANAGED	Mode used to climb towards FCU selected altitude along VERT F-PLN taking into account ALT CSTR . Available only if NAV mode engaged. The A/THR is in thrust mode (CLB).	The speed target may be either selected or managed. If managed, SPD CSTR , SPD LIM and HOLD SPD are taken into account. ALT mode is always armed ; displayed in magenta if the next level off is predicted at an ALT CSTR , and in blue if the next level off is predicted at the FCU selected altitude.
<b>DES</b>	MANAGED	Mode used to descend towards FCU selected altitude along the computed descent path taking into account ALT CSTR . Available only if NAV mode engaged. The A/THR may be in THRUST or SPD mode.	
<b>OP CLB</b> <b>OP DES</b>	SELECTED	Mode used to climb/descent directly to the FCU selected altitude. These modes disregard all ALT CSTR . The A/THR is in THRUST mode (CLB/DLE).	The speed target may be either selected or managed. ALT mode is systematically armed and blue. Altitude target is blue on PFD.
<b>EXPEDITE</b> 	SELECTED	Mode used to increase the vertical speed by selecting green dot in climb or 0.80/340 kt in descent.	Used to expedite a climb or descent towards a specific level.
<b>ALT CST*</b> <b>ALT CST</b>	MANAGED	Mode automatically engaged when reaching an ALT CSTR before the FCU selected altitude.	CLB /DES mode are systematically armed (blue).
<b>ALT*</b> <b>ALT</b> <b>ALT CRZ</b>	SELECTED	Mode used to maintain a level flight at the FCU selected altitude.	Soft ALT mode engages when FCU selected altitude = CRZ FL. Soft ALT is part of the managed guidance.

*Continued on the following page*

*Continued from the previous page*

MODE	TYPE	GUIDANCE	REMARK
V/S -FPA	SELECTED	Mode used to guide the aircraft along a vertical speed or a selected flight path angle.	Altitude target is blue on PFD . V/S -FPA is a basic mode. (Refer to DSC-22_30-10 Lateral Modes).
G/S* G/S FINAL	MANAGED	Mode used to guide the aircraft along the final approach path (G/S or non ILS)	Selected by depressing the APPR pb on the FCU . The mode engaged depends upon the selected approach in the F-PLN . Linked to APPR common mode (APPR pb).
FLARE	MANAGED	Common mode which provides the alignment to the runway center line on the yaw axis and the flare on the pitch axis.	Engages below 50 ft RA as a function of the current vertical speed.

**INTERACTION BETWEEN AP/FD AND A/THR MODES**

Ident.: DSC-22\_30-10-00011037.0002001 / 23 JUN 15  
Applicable to: ALL

The AP and FD pitch modes can control a target SPD /MACH or a vertical trajectory, and the A/THR mode can control a fixed thrust or a target SPD /MACH. However, the AP /FD and the A/THR cannot both control a target SPD/MACH simultaneously.

Therefore the AP /FD pitch modes and A/THR mode are coordinated as follows:

- If an AP /FD pitch mode controls a vertical trajectory, the A/THR mode controls the target SPD/MACH.
- If an AP /FD pitch mode controls a target SPD or MACH, the A/THR mode controls the thrust.
- If no AP /FD pitch mode is engaged, the A/THR mode reverts to controlling the SPD/MACH mode.

In other words, the selection of an AP /FD pitch mode determines which mode the A/THR controls.

AP /FD pitch modes	A/THR modes
V/S - FPA DES (geometric path) ALT *, ALT ALT CRZ *, ALT CRZ ALT CST*, ALT CST G/S *, G/S FINAL, FINAL APP	SPEED/MACH MODE
AP /FD OFF	


*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**  
GENERAL

*Continued from the previous page*

<b>AP /FD pitch modes</b>	<b>A/THR modes</b>
CLB /DES (idle path) OP CLB /OP DES EXP CLB/EXP DES  SRS	THR (CLB, IDLE) MODE
FLARE	RETARD (IDLE)



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

GENERAL

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-20-00012468.0001001 / 14 MAY 12

Applicable to: ALL

The Flight Director (FD ) displays guidance commands from the Flight Management and Guidance Computer (FMGC ) on the Primary Flight Display (PFD).


The flight crew may manually fly the aircraft, following FMGC guidance commands, or crosscheck the FMGC orders when the autopilot is engaged.

In normal operations, FD 1 displays FMGC 1 orders on the PFD 1 and FD 2 displays FMGC 2 orders on the PFD2.

The FD s use their respective inside FMGCs.

On the PFD:

1. The FD pitch and roll crossbars show pitch and roll demands.
2. Below 30 ft during landing and takeoff, when a localizer is available, the vertical bar is replaced by a yaw bar that gives lateral orders.
3. The Flight Path Director (FPD ) symbol relates to the Flight Path Vector (FPV).



The HDG V/S – TRK FPA pb on the FCU enables the flight crew to select either type of reference and display.

The FD pb on the Electronic Flight Instrument System (EFIS ) control panel allows the FD bars to be displayed or removed.

**FD BARS (HDG V/S SELECTED ON THE FCU)**

- The pitch bar is displayed if a vertical mode is engaged. It gives pitch orders for the vertical guidance
- The roll bar is displayed if a lateral mode is engaged. It gives roll orders for lateral guidance.

**FLIGHT PATH DIRECTOR (TRK FPA SELECTED ON THE FCU)**

The display is an alternate way of transmitting flight director commands.

- The Flight Path Vector (FPV) symbol illustrates the track and flight path angle actually being flown
- The Flight Path Director (FPD) symbol shows the flight crew how to intercept the required vertical and lateral flight trajectory. When the flight crew superimposes the FPV and the FPD symbols, the aircraft is flying the required trajectory.

**YAW BAR**

The yaw bar is displayed in RWY mode on takeoff and in FLARE and ROLL OUT modes at landing.

**FLIGHT DIRECTOR (FD) ENGAGEMENT**

Ident.: DSC-22\_30-20-00012469.0008001 / 01 OCT 12

Applicable to: ALL


The FD s are engaged automatically when the FMGC powers up.

**GROUND ENGAGEMENT**

- The "1FD 2" symbol appears on both PFDs
- No FD bars appear on the PFD s. (The PFD displays FD orders when a mode is active on the corresponding axis)
- The FCU windows display dashes.

**MANUAL FLIGHT ENGAGEMENT**

The two FD s engage in the HDG V/S or TRK FPA modes (basic modes).





**AUTOMATIC FLIGHT ENGAGEMENT**

FD bars are automatically restored in SRS /GA TRK modes at go-around engagement. If FPV /FPD was previously selected, it reverts to FD bars.

**FLIGHT DIRECTOR (FD) DISENGAGEMENT**

Ident.: DSC-22\_30-20-00012470.0006001 / 19 DEC 12


Applicable to: ALL

The flight crew may disengage one or two FD s manually, or FDs may disengage automatically if there is a failure.

**MANUAL DISENGAGEMENT**


**One FD OFF:**

- The FD bars no longer appear on the associated PFD.
- The corresponding FD is disengaged.




**Both FDs OFF:**

- The FD bars disappear from both PFDs.
- If no AP was engaged, lateral and vertical modes disengage. The A/THR, if active, automatically reverts to (or remains in) SPEED/MACH mode.
- If one AP was engaged when FD s are switched OFF, this AP remains engaged in the active modes but the FDs are no longer displayed.





**AUTOMATIC DISENGAGEMENT**

If one FD fails or one FMGC is not valid, both PFD s display the remaining FD.



**AUTOMATIC DISENGAGEMENT DUE TO SPEED PROTECTION**

When AP s are not engaged and the flight crew does not follow the FD bars to maintain the commanded trajectory in climb with CLB or OP CLB (or EXP CLB ) engaged or in descent with DES or OP DES (or EXP DES ) engaged, the FDs will disengage at the activation of the automatic speed mode protection.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**  
 FLIGHT DIRECTOR

*Refer to DSC-22\_30-75 Reversion with Global Speed Protection - Automatic Speed Mode Protection in Climb.*

**AUTOMATIC FD REMOVAL**

Ident.: DSC-22\_30-20-00012472.0001001 / 28 JAN 14

**Applicable to: ALL**

- The FD pitch bar is removed when no vertical mode is engaged or when ROLL OUT mode is engaged.
- The FD roll bar is removed when no lateral mode is engaged or when the RWY or ROLL OUT mode is engaged.
- Both FDs are removed when the aircraft pitch exceeds 25 ° up or 13 ° down, or bank angle exceeds 45 °.

**FD WARNINGS**

Ident.: DSC-22\_30-20-00012473.0001001 / 16 MAR 11

**Applicable to: ALL**

<b>FD bar WARNINGS</b>	<b>CONDITIONS</b>
Pitch FD bar (or FPV) flashes 10 s and then remains steady	<ul style="list-style-type: none"> <li>- If the ALT * mode is lost further to FCU altitude reference change of more than 250 ft.</li> <li>- When in APPR mode (G/S *, G/S , LAND, FINAL), FD reverts to V/S mode (flight crew action or loss of vertical approach mode).</li> <li>- One AP or one FD is engaged while both AP /FD were previously OFF.</li> </ul>
Pitch FD bar (or FPV) flashes permanently	Transmission of the GLIDE data is interrupted when in G/S , G/S * or LAND modes above 100 ft RA.
Roll FD bar (or FPV) flashes 10 s and then remains steady	<ul style="list-style-type: none"> <li>- When in APPR mode (LOC *, LOC , LAND, APP NAV ), FD reverts to HDG mode (flight crew action or loss of lateral approach mode).</li> <li>- One AP or one FD is engaged while both AP /FD were previously OFF.</li> </ul>
Roll FD bar (or FPV) flashes permanently	Transmission of the LOC data is interrupted when in LOC , LOC * or LAND modes above 15 ft RA.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

FLIGHT DIRECTOR

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>AUTO FLIGHT - FLIGHT GUIDANCE</b></p> <p>AUTOPILOT (AP)</p>
---	--

<b>GENERAL</b>
----------------

Ident.: DSC-22\_30-30-00011816.0001001 / 17 AUG 10

**Applicable to: ALL**

The AP:

- Stabilizes the aircraft around its center of gravity
- Acquires and tracks a flight path
- Flies the aircraft to an automatic landing or go-around.

The AP commands the:

- Position of the flight control surfaces for pitch, roll and yaw
- Nose wheel position.

<b>AP ENGAGEMENT</b>
----------------------

Ident.: DSC-22\_30-30-00011817.0014001 / 16 MAR 11

**Applicable to: ALL**

The flight crew can engage AP 1 or AP 2 by pressing the corresponding pushbutton on the FCU if the aircraft has been airborne for at least 5 s.

When one AP is engaged, the corresponding FCU pushbutton comes on and AP 1 (or 2) is displayed on the FMAs.

In BACK-UP NAV , AP can be engaged in selected modes if the FG part is available.

- One AP can be engaged on ground if the engines are not running. It disengages when one engine is started.
- Two AP s may be engaged at a time (AP 1 active, AP2 in standby), when the localizer/glide-slope or roll out or go-around mode is armed or engaged.  
Only one AP can be engaged at a time in all other cases.
- If one AP pb is set to ON with both FD s OFF, the AP engages in HDG V/S or TRK FPA mode, depending upon which mode the flight crew has selected on the FCU.
- If one AP pb is set to ON with at least one FD already ON, the AP engages in the current active FD modes.
- At takeoff, the AP cannot be engaged below 100 ft.

AP engagement increases the break out force on the sidestick controllers and on the rudder pedals.

AP engagement is indicated by the lighting of the corresponding FCU pushbutton and by the appearance of AP 1 (or 2) on the PFD 's FMA.

## AP DISENGAGEMENT

Ident.: DSC-22\_30-30-00011818.0009001 / 04 NOV 13

Applicable to: ALL

AP1 or 2 disengages when:

- The flight crew presses the takeover pb on the sidestick, or
- The flight crew presses the corresponding AP pb on the FCU, or
- The flight crew pushes on the sidestick harder than a defined threshold, or moves on the rudder pedals beyond a defined threshold, or
- The flight crew moves the pitch trim wheel beyond a defined threshold, or
- The other AP is engaged, except when localizer/glideslope modes are armed or engaged, or when the rollout or go-around mode is engaged, or
- Both thrust levers are set above the MCT detent and the aircraft is on ground, or
- One of the engagement conditions is lost.

In addition, in normal law with all protections available, the AP will disengage when:

- High speed protection activates, or
- Angle-of-attack protection activates:
  - From the liftoff to 100 ft RA during the landing, when  $\alpha$  prot +1 ° is reached, or
  - Below 100 ft RA during the landing, when  $\alpha$  MAX is reached, or
- Pitch attitude exceeds 25 ° up, or 13 ° down, or bank angle exceeds 45 °, or
- A rudder pedal deflection is more than 10 ° out of trim.

The standard manner for the flight crew to disengage the AP is to press the takeover pb on the sidestick.

When the AP is OFF, the associated pushbutton on the FCU goes off, and AP 1 (or AP 2) disappears from the FMA.


## AP WARNINGS

Ident.: DSC-22\_30-30-00011819.0001001 / 17 AUG 10

Applicable to: ALL

When the AP is disengaged, the system warns the flight crew:

- If the flight crew disengages it with the takeover pb on the sidestick, the warnings are temporary
- If the disengagement results from a failure, from the flight crew pushing the pushbutton on the FCU, or from a force on the sidestick, the visual and audio warnings are continual.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT GUIDANCE</b>  AUTOPILOT (AP)
---	---

		AP DISENGAGEMENT	
		TAKEOVER pb on SIDESTICK	BY OTHER MEANS
<b>CONSEQUENCE</b>	<b>MASTER WARNING light</b>	Flashing red during 3 s maximum	Flashing red
	<b>ECAM</b>	AP OFF red message 9 s maximum	<u>AUTO FLT</u> AP OFF red warning
	<b>AUDIO</b>	Cavalry charge 0.5 s minimum 1.5 s maximum	Continuous cavalry charge 1.5 s minimum
	<b>CLR pb on ECAM CONTROL PANEL</b>	Extinguished	Illuminated
<b>ACTION</b>	<b>MASTER WARNING light</b>	<ul style="list-style-type: none"> <li>- Extinguishes Master Warning light</li> <li>- Erases ECAM warning</li> <li>- Stops audio if pressed within 1.5 s</li> </ul>	<ul style="list-style-type: none"> <li>- Extinguishes Master Warning light</li> <li>- Stops audio after 1.5 s</li> </ul>
	<b>CLR pb on ECAM CONTROL PANEL</b>	No effect	<ul style="list-style-type: none"> <li>- Extinguishes CLR pb</li> <li>- Erases ECAM message</li> <li>- Calls status</li> </ul>
	<b>TAKEOVER pb</b>	<ul style="list-style-type: none"> <li>- Extinguishes Master Warning light</li> <li>- Erases ECAM warning</li> <li>- Stops audio if pressed within 1.5 s</li> </ul>	<ul style="list-style-type: none"> <li>- Extinguishes Master Warning light</li> <li>- Stops audio after 1.5 s</li> </ul>
<b>ECAM STATUS MESSAGE</b>		NO	YES

<b>AUTOLAND WARNING</b>
-------------------------

Ident.: DSC-22\_30-30-00011820.0001001 / 09 APR 15

Applicable to: ALL

Below 200 ft RA, an Autoland red light flashes in case of failures that require the interruption of an automatic landing.

Refer to DSC-22\_30-80-30-10 *Autoland Warning Light* for the detailed conditions triggering the Autoland warning.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

AUTOPILOT (AP)

Intentionally left blank



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT GUIDANCE</b> SPEED/MACH CONTROL
---	---

**GENERAL**

Ident.: DSC-22\_30-40-00011893.0001001 / 17 AUG 10

**Applicable to: ALL**

In flight, either the AP /FD pitch control, or autothrust may acquire and hold a target speed or Mach number, depending on the engaged modes.

Speed control is:

- Managed when the target comes from the FMGS
- Selected when the target comes from the SPD /MACH FCU window.

**MANAGED SPEED/MACH TARGET**


Ident.: DSC-22\_30-40-00011894.0001001 / 01 DEC 14

**Applicable to: ALL**

When the speed target is managed, the SPD /MACH window of the FCU shows dashes, and the corresponding dot is lighted. The PFD speed scale shows the speed target in magenta.

**ENGAGEMENT CONDITIONS**

The SPD target is managed, whenever AP or FD is engaged, and one of the following occurs:

- The flight crew pushes in the SPD/MACH knob
- EXPEDITE mode  is engaged
- V2 is inserted in the MCDU
- The speed reference system (SRS) is engaged (takeoff or go-around mode).

*Note: At takeoff, SRS will not engage if V2 is not available.*

**DISENGAGEMENT CONDITIONS**

Managed speed disengages any time the flight crew selects a speed target on the FCU, or if the speed was preselected.

**SPEED PROFILE**

The form of the managed SPD profile depends on the lateral NAV mode.

- **If NAV mode is engaged, the SPD profile takes into account all the constraints linked to the flight plan.**

The SPD profile is:

- V2 - SPD LIM - SPD CSTR (if applicable) - ECON CLB SPD /MACH - ECON CRZ MACH
- ECON or preset DES MACH/SPD -SPD LIM - SPD CSTR (if applicable) - HOLD SPD (if applicable) - VAPP.

- **If NAV mode is not engaged, the SPD/MACH constraints are not considered.**

The SPD profile is:

V2 - SPD LIM - ECON CLB SPD /MACH - ECON CRZ MACH - ECON or preset DES  
MACH/SPD - SPD LIM - VAPP.

- Note:
1. When both AP /FD s are OFF, A/THR reverts to selected SPEED mode, except when the approach phase is activated on MCDU where both managed and selected SPD are available.
  2. When expedite mode is engaged, the system disregards SPD LIM and SPD CSTR no matter what lateral mode is engaged.
  3. The managed speed/Mach target may be set below maneuvering speed but as long as the speed target is managed, the FMGS limits the aircraft to the maneuvering speed of the current slats/flaps configuration (VAPP , F , S, Green Dot).
  4. If the managed speed/Mach target is set above VMAX (VFE , VMO , MMO ), the FMGS automatically limits the speed to VMAX.
  5. If a SPD/MACH constraint has already been taken into account, it remains applied (until a more restrictive constraint applies).

### **MINI GROUND SPEED**

In approach phase, the managed speed target is the Mini Ground Speed target computed by the Flight Guidance (FG ) part of the FMGS. *Refer to DSC-22\_30-90 General* for details.

### **SELECTED SPEED/MACH TARGET**

Ident.: DSC-22\_30-40-00011895.0002001 / 17 AUG 10

Applicable to: ALL

To use a selected speed/Mach target, the flight crew uses the knob on the FCU to set the target speed, which is then displayed in the FCU window. It is also displayed in blue on the PFD speed scale.

Note: *The selected speed/Mach target may be set beyond VLS or VMAX , but when autothrust is active, the guidance limits the speed to VLS or VMAX.*

Selected speed has priority over managed speed. The only automatic change-over from selected to managed speed target may occur at go-around mode engagement.

In flight, if the situation calls for managed speed, both the PFD and the MCDU display a message proposing a manual change to managed speed (for example, SET MANAGED SPEED, SET HOLD SPEED, or SET GREEN DOT SPEED).

### **ENGAGEMENT CONDITIONS**

The aircraft has a selected speed target under any one of the following conditions:

- The flight crew pulls out the SPD/MACH knob (5 s after lift-off)
- Both AP /FD s are OFF (except in APPR phase)
- The FM speed target is lost (except in SRS , G/S, LAND, and GO AROUND modes)

- The MCDU has a preselected speed for the next phase, and the aircraft transitions into that phase
- The FMGC is powered up in flight.

**DISENGAGEMENT CONDITIONS**

The selected speed target disengages:

- When the managed SPD engages
- When the aircraft is on ground at engine start.

*Note:* With engines running, the flight crew can select a speed on the FCU only after takeoff.

**AUTO SPD**

Ident.: DSC-22\_30-40-00011896.0001001 / 17 AUG 10

Applicable to: ALL

The flight crew may insert the AUTO SPD (speed or Mach) on the PERF DES page to replace the ECON DES SPD.

In this case, the managed speed profile takes into account the selected value. The top of descent and the descent path are computed on AUTO SPD assumption.

**SPEED/MACH SWITCHING**

Ident.: DSC-22\_30-40-00011897.0001001 / 16 MAR 11

Applicable to: ALL

In managed speed, at the crossover altitude, the FMGC automatically changes the managed speed target to the corresponding MACH target. The FCU displays the Mach number corresponding to the speed at the switching altitude.

ALTITUDE	SPEED/MACH CROSS OVER TABLE.						
30500	280						
29500		290					
28500	295		300				
27500		305		310			
26500	300		315		325		
25500		310		325		330	
24500			320		335		350
MACH	0.76	0.77	0.78	0.79	0.80	0.81	0.82

*Note:* When the speed is selected, the flight crew has to perform the switching manually by pressing the SPD/MACH pb on the FCU . The FCU then displays the aircraft Mach number.

When the target speed is managed, the FMGC commands the switchover automatically as a function of the ECON MACH value.

### MANAGED SPEED TARGET MEMORIZATION

Ident.: DSC-22\_30-40-00011898.0001001 / 13 JAN 14

Applicable to: **ALL**

A dual FM failure has different consequences when it occurs in different phases of the flight.

The system handles target speed and SPD mode as follows:

- During approach with LOC and G/S engaged and radio height < 700 ft, the target speed is set to VAPP as previously memorized, and managed SPD target is maintained.
- At go-around, the target speed becomes the memorized go-around speed, which is the higher of VAPP or the speed when go-around was initiated. Managed SPD target is maintained.
- In all other cases, managed target speed reverts to selected, the value being the speed at the moment of the failure.

### SPEED/MACH FCU WINDOW SYNCHRONIZATION

Ident.: DSC-22\_30-40-00011899.0001001 / 17 AUG 10

Applicable to: **ALL**

When the target SPD is managed, the SPD /MACH display of the FCU shows dashes.

However, the window displays the target SPD or MACH in the following situations:

- The flight crew turns the SPD/MACH knob.  
If the flight crew does not pull the knob within 10 s after turning it, the selection reverts to dashes.
- The flight crew manually engages a selected SPD target.
- If the flight crew has manually preselected a speed or Mach number for the next phase on the MCDU PERF page, that preselected SPD /MACH engages when the aircraft enters that phase and the FCU window then displays as the target the preselected speed or Mach.
- If the FMGS is powered up in flight, the synchronized speed/Mach value is the current aircraft speed or Mach number.
- If no V2 is entered at takeoff, the V/S mode engages 5 s after lift-off (no speed reference system).  
The FCU speed target is the speed at V/S mode engagement. (A/THR becomes active when the thrust levers are set in the active range).

**AP/FD MODES GENERAL**

Ident.: DSC-22\_30-50-00011767.0007001 / 23 JUN 15



Applicable to: ALL

The FMGS has guidance parameters for both AP /FD lateral and vertical modes.

**The AP /FD lateral modes are:**

RWY, RWY TRK	Runway, Runway track mode
NAV	Nav mode
HDG, TRK	Heading, track mode. Also called basic modes
APP NAV	Approach Nav mode
LOC*, LOC	Loc capture, Loc track mode
LAND	Land mode. Managed submode that includes LOC and G/S modes below 400 ft RA
FINAL APP	Final approach mode. Managed submode that includes APP NAV and FINAL modes during non precision approach
ROLL OUT	Roll out mode (Autoland)
GA TRK	Go-around track mode

**The AP /FD vertical modes are:**

SRS	SRS mode used for takeoff and go-around
CLB	Climb mode
DES	Descent mode
OP CLB	Open Climb mode
OP DES	Open Descent mode
EXP CLB 	Expedite mode in climb
EXP DES 	Expedite mode in descent
V/S or FPA	Vertical Speed mode or Flight Path Angle mode. Also called basic modes
ALT*	Altitude capture
ALT	Altitude Hold mode
ALT CST*	Altitude constraint capture
ALT CST	Altitude constraint hold mode
ALT CRZ	Altitude hold of the cruise flight level
G/S*	Glide slope capture
G/S	Glide slope mode
FINAL	Final mode (Non precision approach)
FLARE	Flare mode (Autoland)




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD MODES GENERAL

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AUTO FLIGHT - FLIGHT GUIDANCE</b></p> <p style="text-align: center;">AP/FD LATERAL MODES</p>
---	---

**HEADING OR TRACK: HDG - TRK**

Ident.: DSC-22\_30-60-00012328.0013001 / 29 MAR 12

Applicable to: ALL

These modes guide the aircraft laterally along a heading or track selected by the flight crew. The HDG /TRK window of the FCU displays the target heading or track. The flight crew uses the HDG V/S -TRK FPA pb to select heading or track.

**ENGAGEMENT CONDITIONS**

HDG or TRK is engaged when one of the following conditions is met:

- The flight crew pulls out the HDG/TRK knob (not sooner than 5 s after lift-off)
- NAV , APP NAV or FINAL APP modes are disengaged, either by the loss of the lateral flight plan or when the flight crew enters a flight plan discontinuity
- LOC or LOC\* mode is lost
- The flight crew engages the AP /FD with no other mode already engaged (basic mode of AP /FD engagement)
- The flight crew presses the LOC pb, when APP NAV or FINAL APP modes are already engaged

HDG engages if the flight crew initiates a go-around below 100 ft and HDG or TRK was already engaged. When the aircraft is at 100 ft or above, HDG or TRK are no longer engaged.

**DISENGAGEMENT CONDITIONS**

The engagement of any other lateral mode disengages HDG or TRK.

**SYNCHRONIZING THE HDG /TRK WINDOW OF THE FCU**

The lateral window of the FCU displays a heading or a track value when:

- The HDG /TRK mode is engaged. The displayed value is the current HDG /TRK or the manually selected value of the target
- The flight crew turns the HDG/TRK knob. The value in the window first synchronizes with the current HDG /TRK , then displays the manual selection. It remains displayed for 10 s or 45 s depending upon FCU standard, then vanishes if the flight crew does not pull the knob (except in HDG preset)
- A HDG /TRK is preset (*Refer to DSC-22\_30-60 HDG/TRK Preset*)
- AP /FD is lost. The value becomes that of the aircraft current heading or track.

*Note: If HDG is switched to TRK (or vice versa), the value displayed in the window switches from heading to track (or vice versa).*

### **HDG/TRK PRESET**

Ident.: DSC-22\_30-60-00012329.0009001 / 29 MAR 12

Applicable to: ALL

The system has a HDG /TRK preset function for takeoff and go-around.  
If the flight crew chooses not to fly the flight plan after takeoff or go-around, they may preset a HDG or a TRK on the FCU by turning the HDG/TRK knob. The value they set remains displayed in the FCU HDG /TRK window until they pull the knob.

#### **OPERATION AT TAKEOFF**

HDG /TRK preset is available before takeoff and up to 30 ft RA . Turning the HDG/TRK knob before 30 ft sets the desired HDG /TRK. As a consequence:

- NAV is disarmed
- At 30 ft, RWY TRK is annunciated until the HDG/TRK knob is pulled.

#### **OPERATION AT GO-AROUND**

Whenever the LOC \*, LOC , LAND or GA modes are engaged, the HDG preset is available. If the flight crew rotates the HDG/TRK knob to set the value, it will remain displayed in the window. Pull out the HDG/TRK knob to activate the mode and turn the aircraft to the preset value.

When overflying the MAP , HDG /TRK will synchronize with the current value. The HDG /TRK preset function is no longer available.

#### **CANCELLATION**

The flight crew can cancel a preset HDG /TRK by:

- Engaging the NAV mode using the DIR TO
- Pushing in the HDG/TRK knob (arming NAV mode)
- Disengaging AP /FD.

### **NAVIGATION (NAV)**

Ident.: DSC-22\_30-60-00012330.0005001 / 23 JUN 15

Applicable to: ALL

NAV mode is a managed mode that steers the aircraft laterally along the flight plan defined in the FMGS . It is designed to have a zero cross-track error. The flight crew can arm or engage the NAV mode if the MCDU contains a lateral flight plan.

#### **ARMING CONDITIONS**

Satisfying one of the following conditions arms NAV:

- The aircraft is on ground with no HDG /TRK preset and no other lateral mode except runway mode
- The flight crew pushes in the HDG/TRK knob, unless the LOC mode is engaged



- The flight crew presses the APPR pb, if a non-ILS approach is selected
- A go-around is initiated, unless HDG /TRK is already preset.

### **DISARMING CONDITIONS**

NAV mode disarms if one of the following occurs:


- The flight crew pulls out the HDG/TRK knob
- The flight crew selects a preset HDG /TRK (TO or GA)
- The flight crew arms the LOC mode by pressing the LOC pb
- LAND mode has engaged
- The flight crew presses the APPR pb, if an XLS approach is selected.

### **ENGAGEMENT CONDITIONS**

NAV mode engages:

- Automatically at 30 ft RA after takeoff (if armed on the ground)
- When the flight crew orders "DIR TO " (except below 700 ft RA in LOC mode)
- When the flight crew pushes in the HDG/TRK knob when the aircraft is close to (within ~1 NM of) the active flight plan leg
- Automatically in flight when NAV is armed and the aircraft reaches the capture zone for the active flight plan leg
- Automatically during a go-around, when the aircraft is above 100 ft RA , and within the capture zone for the active flight plan leg, unless a HDG /TRK was preset.

Note: *During a go-around, when the approach was previously flown in NAV , APP NAV or FINAL APP modes, the NAV mode remains engaged, unless a HDG /TRK was preset.*



**CAUTION**

When NAV is armed, it will automatically engage if:

- The aircraft track line intercepts the flight plan before the TO waypoint, and
- The intercept waypoint (INTCP) is displayed on the ND, and
- The aircraft reaches the active flight plan leg.

*Note:* The TO waypoint is displayed in white on ND s and MCDUs.

**DISENGAGEMENT CONDITIONS**

The NAV mode disengages when:

- Any other lateral mode is engaged
- The flight plan is lost or the aircraft enters a flight plan discontinuity.

**INTERACTIONS WITH VERTICAL MODES**

When NAV mode is engaged, the vertical managed modes CLB or DES or FINAL take into account altitude and speed constraints linked to waypoints on the lateral flight plan. If NAV mode is disengaged, the vertical managed modes are not available and all downpath altitude and speed constraints are ignored.

## LOCALIZER MODE THROUGH THE LOC PUSHBUTTON

Ident.: DSC-22\_30-60-00012331.0001001 / 17 AUG 10

Applicable to: ALL

This mode captures and tracks a localizer beam independently of the glide path beam. Flight crew use it to fly localizer-only approaches or to initiate an ILS approach when intercepting the glide slope from above.

### **ARMING CONDITIONS**

The flight crew arms the LOC mode by pressing the LOC pb, provided that:

- An ILS is tuned (frequency and runway course)
- The aircraft is above 400 ft RA
- TO or GA mode is not engaged.

### **DISARMING CONDITIONS**

LOC mode is disarmed by:

- Pressing the LOC pb when LOC is armed
- Arming the NAV mode
- Engaging the GA mode.

*Note:* Engaging NAV mode by selecting DIR TO does not disarm the LOC mode.

### **ENGAGEMENT CONDITIONS**

The LOC mode engages automatically when capture conditions are met.

### **DISENGAGEMENT CONDITIONS**

The LOC mode disengages:

- When another lateral mode is engaged
- When the flight crew presses the LOC pb again (engaging the HDG /TRK mode on the current HDG /TRK).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD LATERAL MODES

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-70-10-00010507.0001001 / 17 AUG 10

Applicable to: ALL


Vertical modes guide the aircraft in the vertical plan.

**PRINCIPLES**

Ident.: DSC-22\_30-70-10-00010508.0001001 / 17 AUG 10

Applicable to: ALL

To leave an FCU selected altitude for another target altitude, the flight crew must turn the Altitude (ALT) knob in order to display the new target altitude and either:

- Pull out the ALT knob to engage the OPEN CLB /DES mode, or
- Push in the ALT knob to engage the CLB /DES mode, or
- Select a target vertical speed (V/S ) and pull out the V/S or FPA knob to engage V/S mode, or
- Select EXPEDITE  .

This arms ALT mode.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD VERTICAL MODES - PRINCIPLES

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-70-20-00010509.0001001 / 01 OCT 12

Applicable to: ALL

CLB mode guides the aircraft in a managed climb, at either a managed or a selected target speed, to an FCU selected altitude, taking into account altitude constraints at waypoints.

The system also considers speed constraints if the target speed is managed. The vertical flight path may include several segments:



The flight crew can arm the CLB mode during the takeoff, go-around, climb, and cruise phases and engage it during the climb and cruise phases.

**ARMING CONDITIONS**

Ident.: DSC-22\_30-70-20-00010510.0001001 / 17 AUG 10

Applicable to: ALL

The CLB mode is armed:

- On ground or when SRS mode is engaged (TO or GA) if the following conditions are met:
  - No other vertical mode is engaged
  - The ACCEL ALT (defined on the PERF TO or GA MCDU pages) is below the FCU selected altitude and the lowest altitude constraint.
- In flight, when the climb or go-around phase is active, and the following conditions are met:
  - The lateral NAV mode is engaged
  - The FCU selected altitude is above the aircraft's present altitude and the aircraft captures or flies an altitude constraint.

**DISARMING CONDITIONS**

Ident.: DSC-22\_30-70-20-00010511.0002001 / 23 JUN 15

Applicable to: ALL

The CLB mode is disarmed, if one of the following conditions is met:

- Another vertical mode is engaged
- The FCU selected altitude is lower than the present aircraft level
- The FCU selected altitude is set at the altitude constraint while ALT CST\* or ALT CST mode is engaged
- The aircraft transitions to DES or APPR phase
- Arming requirements are no longer met
- Vertical flight path validity is lost, or NAV mode is lost while ALT CST\* or ALT CST mode is engaged.

**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-20-00010512.0001001 / 17 AUG 10

Applicable to: ALL

The CLB mode can be engaged, if the following conditions are all met:

- The aircraft has been in flight for more than 5 s
- The selected FCU level is above the present aircraft level
- The descent, approach, or go-around phase is not active
- NAV mode is engaged
- Glideslope (G/S) mode is not engaged.

CLB mode automatically engages when the aircraft reaches ACC ALT , or sequences a waypoint with an altitude constraint while the CLB mode is armed.

CLB mode manually engages when the flight crew pushes in the ALT knob, with the CLB mode not armed and the current altitude is not an effective altitude constraint of the flight plan.

Note: When CLB mode is engaged:

- The V/S (FPA ) window of the FCU shows dashes
- The managed LVL/CH dot on the FCU lights up
- The Flight Mode Annunciator displays "CLB" in Column 2.



**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-20-00010513.0002001 / 17 AUG 10

Applicable to: ALL

The CLB mode disengages, if one of the following conditions is met:


- NAV mode is lost or disengaged (OP CLB engages). In this case, the reversion to OP CLB is accompanied by a triple click aural warning
- Another vertical mode engages
- The flight crew selects an altitude on the FCU that is lower than the present aircraft altitude. V/S (FPA) engages on the current V/S (FPA).

**GUIDANCE**

Ident.: DSC-22\_30-70-20-00010514.0002001 / 01 OCT 12

Applicable to: ALL


Climb mode gives the aircraft managed vertical guidance to the FCU selected altitude. It meets altitude constraints at waypoints either with managed speed incorporating speed constraints or with selected speed as target speed. The AP /FD pitch controls the speed or Mach number target and the A/THR is in thrust mode (CLB) corresponding to maximum climb thrust. The flight path may include several segments.



- When CLB mode is engaged, the system arms ALT and displays the applicable target altitude on the ALT scale.
  - If the next predicted level-off is an ALT CSTR , ALT is magenta on the FMA and the ALT CSTR is displayed in magenta on the altitude scale
  - If the next predicted level-off is the FCU altitude, ALT is blue on the FMA and the FCU selected altitude is displayed in blue on the altitude scale.

*Note: The system takes into account all constraints defined by the database or manually entered by the flight crew. Nevertheless this mode has the following particularity: When the aircraft is in CLB mode and the system predicts that it will miss an altitude constraint, it will not modify the target speed in an attempt to meet it. In this case, the flight crew may select an appropriate speed in order to meet the ALT CSTR.*

- The guidance does not modify the target speed in order to satisfy an altitude constraint. Therefore the constraint may not be met and may be predicted as missed
- When the aircraft levels off at the ALT CSTR , CLB mode arms automatically, then engages when the aircraft passes the constrained waypoint (if the FCU altitude is above the constraint altitude).

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AUTO FLIGHT - FLIGHT GUIDANCE</b></p> <p style="text-align: center;">AP/FD VERTICAL MODES - OPEN CLIMB MODE</p>
---	--

**GENERAL**

Ident.: DSC-22\_30-70-30-00010515.0001001 / 17 AUG 10  
**Applicable to: ALL**

The OPEN CLB mode is a selected mode. It uses the AP /FD pitch mode to maintain a SPD/MACH (selected or managed) while the autothrust (if active) maintains maximum climb thrust.


**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-30-00010516.0002001 / 16 MAR 11  
**Applicable to: ALL**

The OPEN CLB mode can only be engaged, if all of the following conditions are met:


- The aircraft is in flight for more than 5 s
- The LAND mode is not engaged
- The FCU selected altitude is higher than the aircraft's present altitude.

The OPEN CLB mode is engaged, if one of the following conditions occurs:

- The flight crew pulls out the ALT knob
- The flight crew pulls out the SPD/MACH knob, when TOGA mode or EXPED CLB  is engaged
- Acceleration altitude is reached, with CLB armed, and NAV mode not engaged
- Guidance reverts to ensure speed protection
- NAV mode is lost (or disengaged), when previously in CLB mode. Reversion to OPEN CLB is accompanied by a triple click aural warning (*Refer to DSC-22\_30-75 General*).

Note: When OPEN CLB is engaged:

- The FMA displays "OP CLB"
- The managed LVL/CH dot on the FCU goes out.



### DISENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-70-30-00010517.0001001 / 17 AUG 10

Applicable to: **ALL**

The OPEN CLB mode is disengaged by one of the following conditions:

- Engagement of any other vertical mode
- Reversion to V/S mode (*Refer to DSC-22\_30-75 General*)
- Selection of a lower altitude than the current aircraft altitude. V/S (FPA ) engages on the current V/S (FPA).

### GUIDANCE


Ident.: DSC-22\_30-70-30-00010518.0001001 / 01 OCT 12

Applicable to: **ALL**

When OPEN CLB is engaged, the target speed/Mach is maintained by adjusting the pitch with the elevator, whereas thrust is maintained either by the A/THR, or manually by the flight crew. Speed target may either be selected or managed.

The OPEN CLB mode disregards all altitude constraints up to the FCU selected altitude.

**OPEN CLB MODES, MANAGED SPEED**



**Note:** If the change is less than 1 200 ft in OPEN CLB mode, the aircraft responds with a rate of climb of 1 000 ft/min.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT GUIDANCE

AP/FD VERTICAL MODES - OPEN CLIMB MODE

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-70-50-00010521.0001001 / 17 AUG 10


Applicable to: ALL

The DES mode guides the aircraft along the descent path computed by the FMGS . The system computes this flight path backwards from the deceleration point up to the top of descent (T/D ), with respect to the speed and altitude constraints at the deceleration point, the guidance begins the deceleration to VAPP, to be reached at 1 000 ft above touchdown on the final descent path. Internally, the computer divides the descent path into various segments, depending on the relative positions of the constraints. It starts at top of descent (T/D) by setting up an “idle” segment that takes the aircraft down to the first constraint, and follows this with “geometric” segments between constraints.

The descent profile takes into account wind data and data from the lateral and vertical flight plans, and it is based upon the managed descent speed profile. It does not take holding patterns into consideration.

The descent profile has several segments:

- A repressurization segment. When necessary, this produces a repressurization rate for the cabin during descent. It is a function of the destination airport altitude and the selected cabin rate (defaulted to -350 ft/min but this can be modified)
- Idle path segment. The AP /FD controls the speed and the autothrust stays at idle thrust. The guidance computes this profile from the top of descent or the end of the repressurization segment to the first vertical constraint that cannot be flown at idle thrust
- Geometric path segments. The AP /FD controls the vertical path, and autothrust controls the speed. These segments take the aircraft from the first constraint to the deceleration point.



The descent mode is a managed mode that may be engaged during cruise. It can be armed or engaged in descent and approach phases (except if the FCU selected altitude is higher than the present aircraft altitude).

### ARMING CONDITIONS

Ident.: DSC-22\_30-70-50-00010522.0001001 / 17 AUG 10

Applicable to: ALL

The DES mode is armed when an ALT CSTR is captured and all the following conditions are met:

- FCU selected altitude is lower than present altitude
- NAV , LOC \* or LOC mode is engaged
- Takeoff or go-around phase is not active
- Flight profile is available.

### DISARMING CONDITIONS

Ident.: DSC-22\_30-70-50-00010523.0002001 / 23 JUN 15

Applicable to: ALL

The DES mode is disarmed if one of the following conditions is met:

- Engagement of another vertical mode
- FCU selected altitude is set above the aircraft current altitude
- Loss of NAV , LOC \* , or LOC mode
- Switching to the go-around phase



- Loss of vertical flight path validity
- Setting the FCU selected altitude at an altitude constraint while ALT CST\* was engaged. (ALT \* engages and DES mode disarms).

## ENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-70-50-00010524.0002001 / 23 JUN 15

Applicable to: ALL

The DES mode can be engaged, when the following conditions are met:

- The FCU selected altitude is lower than present altitude
- NAV , LOC \* , or LOC mode is engaged
- Takeoff, climb, or go-around phase is not active
- Vertical flight path is valid
- TO , G/S , LAND, FINAL or GA mode is not engaged, and:
  - The aircraft sequences a waypoint with an ALT CSTR , and DES mode is armed. The DES mode engages automatically, or
  - The flight crew presses the ALT knob, while ALT CST\* or ALT CST is not engaged, or
  - The flight crew presses the ALT knob, while ALT \* or ALT is engaged, but the current altitude is not an effective altitude constraint of the F-PLN.

Note: When DES mode is engaged:

- The V/S - FPA window of the FCU shows dashes
- The managed LVL/CH dot on the FCU lights up.

## DISENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-70-50-00010525.0002001 / 17 AUG 10

Applicable to: ALL

The DES mode is disengaged, if one of the following conditions is met:

- The NAV mode is lost or disengaged and the V/S or FPA mode engages. A triple click aural warning will sound
- Another vertical mode engages
- The flight crew selects an altitude on the FCU that is higher than the aircraft present altitude and the V/S (FPA ) engages on current V/S (FPA ). Same triple click logic, as for the OP DES case
- NAV mode is lost due to a discontinuity in the descent profile. AP /FD reverts to basic mode, and a triple click aural warning sounds. The vertical mode is boxed in white for 10 s.

Refer to DSC-22\_30-75 General.

**REPRESSURIZATION SEGMENT**

Ident.: DSC-22\_30-70-50-00010559.0002001 / 14 MAY 12

Applicable to: ALL

The top of descent (T/D) may be updated if the flight crew modifies the cabin rate of descent (default rate is -350 ft/min).

If the flight crew enters a lower cabin rate, the system computes a repressurization segment that takes into account the additional time needed for repressurization.



**DESCENT SPEED PROFILE**

Ident.: DSC-22\_30-70-50-00012563.0002001 / 14 MAY 12

Applicable to: ALL

The descent speed profile is usually the ECON SPD profile, amended by any speed constraints and speed limit contained in the flight plan.

Before the descent phase is active, if flight crew does not intend to fly the ECON speed/Mach profile, a different speed or Mach can be entered to amend the speed profile.

It is obtained by entering a Mach number and/or a speed in the MANAGED field of the PERF DES MCDU page (3L key).



If the flight crew reverts to the **SELECTED** speed/MACH mode during descent, the profile is not modified and the aircraft flies the same profile at the FCU selected speed/MACH value.

Basic managed SPD /MACH profile in DES mode is:

- ECON MACH, or **SELECTED** Mach
- ECON SPD, or **SELECTED** Speed
- SPD CSTR (if any)
- SPD LIMIT
- Green Dot/S /F /VAPP
- VAPP TARGET.

## GUIDANCE IN DES MODE

**Applicable to: ALL**

Ident.: DSC-22\_30-70-50-A-00010575.0001001 / 17 AUG 10

### **DESCENT INITIATION**

The aircraft will not start its descent automatically when reaching the top of descent (T/D). In order to initiate the descent, the flight crew sets the clearance altitude by turning the ALT knob then pushes the ALT knob.

The aircraft will descend immediately:

- If the top of descent is not reached, the aircraft descends at a constant V/S converging on the descent path
- If the aircraft is at or beyond the T/D, it descends at idle thrust.


Ident.: DSC-22\_30-70-50-A-00010563.0005001 / 01 OCT 12

**DURING THE DESCENT**

The flight crew will see a vertical deviation symbol (VDEV ) along the ALT scale on the PFD and a VDEV value on the PROG page, so that the aircraft's vertical position can be monitored versus the calculated descent profile.

The aircraft may deviate from the DES profile while DES mode is engaged if:

- Unexpected wind conditions are encountered
- Anti-icing is turned on
- The lateral flight plan is changed.



When the speed is managed, a target speed range displayed on the PFD defines acceptable speed variations around the nominal descent speed target.

Ident.: DSC-22\_30-70-50-A-00010565.0001001 / 19 DEC 12

**FMA DISPLAY**

When DES mode is engaged, the system arms ALT and displays the applicable target altitude on the PFD altitude scale.

- If the next predicted level-off is an altitude constraint, ALT is magenta on the FMA second line and the PFD displays the altitude constraint magenta above the altitude scale.

When the aircraft flies at the altitude constraint (ALT CSTR ), the system arms DES blue.

When the aircraft meets the constraint, DES engages again automatically.

- If the next predicted level-off is the FCU altitude, ALT is blue on the FMA and the PFD displays the FCU selected altitude in blue.




**DES MODE PROFILE**

Applicable to: ALL

Ident.: DSC-22\_30-70-50-B-00010567.0005001 / 01 OCT 12


**GENERAL**



Ident.: DSC-22\_30-70-50-B-00010568.0005001 / 17 AUG 10


**INTERCEPT POINT**

Associated with the VDEV displayed on PFDD, the ND shows an intercept point (I/P) on the flight plan. It indicates the position where the system predicts that the aircraft will intercept the descent profile.



## **AIRCRAFT ABOVE THE DESCENT PROFILE**

If the aircraft is above the descent profile, the speed will increase toward the upper limit of the managed speed range. If the speed reaches the upper limit, the aircraft will maintain the speed but will deviate from the profile (autothrust at idle).

The navigation display presents a pseudo waypoint  (intercept point) along the flight plan that assumes the aircraft will return to the profile using:


- Idle thrust
- 1/2 speedbrake extension
- ECON speed plus a margin (until intercepting the profile).

If necessary, the message “AIRBRAKES” (old FMGC standard) or “MORE DRAG” comes up on the PFD and the MCDU, and remains there as long as more drag (speedbrakes) is still required. The flight crew should respond to this message by deploying half speedbrakes.

Whenever the intercept point is predicted to be close to a constrained waypoint, the PFD and MCDU display an “AIRBRAKES” or “MORE DRAG” message depending upon the FMGS standard.

*Note:* With DES mode engaged, the speedbrakes extension will not necessarily increase the descent rate. It increases only if the aircraft is above path.





Ident.: DSC-22\_30-70-50-B-00010570.0002001 / 17 AUG 10

**AIRCRAFT BELOW THE DESCENT PROFILE**

If the aircraft is below the descent profile, its speed will be maintained at target speed until it reaches the descent profile. The lower margin becomes effective when the aircraft is on the descent profile but has to loose speed in order to stay on it.

The intercept point on the navigation display is based on the following assumptions:

- **If the aircraft is flying at an altitude that is higher than both the descent speed limit altitude and the destination elevation +5 000 ft:**  
 The FMGS maintains the V/S at -1 000 ft/min and the target speed, until the aircraft reaches the altitude constraint, or intercepts the descent profile.
- **If the aircraft is flying at an altitude that is lower than either the descent speed limit altitude, or the destination elevation +5 000 ft:**  
 The FMGS maintains the V/S at -500 ft/min and the target speed, until the aircraft reaches the altitude constraint or intercepts the descent profile.

Ident.: DSC-22\_30-70-50-B-00010572.0001001 / 17 AUG 10

### **LEVELING OFF AT A CONSTRAINT**

If the aircraft levels off at an ALT CSTR , the DES mode arms and remains armed until the aircraft passes the constraint, then reengages (if the FCU altitude is set below the altitude of the constraint).

If the FCU selected altitude is that of a constraint, the flight crew may continue the descent below that altitude by turning the ALT knob and pushing it in. This arms the DES mode, which reengages when the aircraft passes the constraint waypoint.


Ident.: DSC-22\_30-70-50-B-00010573.0002001 / 17 AUG 10

### **GUIDANCE IN A HOLD**

Just before the aircraft enters a holding pattern, the speed target becomes the holding speed. In the holding pattern, the DES mode commands V/S = -1 000 ft/min while A/THR maintains the holding speed. The aircraft will level off at the next altitude constraint if it is reached during the hold.

The current vertical deviation VDEV is based on the altitude at which the aircraft is supposed to cross the exit fix in order to be properly positioned on the descent profile.


Until the flight crew exits the hold, the FMGS in DES mode will maintain V/S = -1 000 ft/min considering downpath vertical constraint. This means that the aircraft will not descent below the next altitude constraint, neither the FCU selected altitude. If the aircraft reaches the next altitude constraint it will level off and ALT CST mode will engage.



Ident.: DSC-22\_30-70-50-B-00010574.0001001 / 01 OCT 12

**TOO STEEP PATH**

A descent segment is called “too steep path” when FM predicts that the descent segment between two constraint waypoints is impossible to fly at the planned descent speed with half speedbrakes extended.



When this occurs, the MCDU displays no predictions between the upper and the lower points of the too steep path. Relevant message “TOO STEEP PATH” is displayed on MCDU.



When the aircraft reaches the beginning of the too steep path segment, the FM recomputes the VDEV using an idle segment from the end of the too steep path segment.

**GENERAL**

Ident.: DSC-22\_30-70-60-00010576.0001001 / 17 AUG 10

**Applicable to: ALL**

The OPEN DES mode is a selected mode. It maintains a SPD /MACH (selected or managed) with the AP /FD pitch mode while autothrust (if active) maintains IDLE thrust.  
It is not to be used for final approach.

**ENGAGEMENT CONDITIONS**


Ident.: DSC-22\_30-70-60-00010577.0002001 / 17 AUG 10

**Applicable to: ALL**

The OPEN DES mode can be engaged only if the following conditions are met:

- The aircraft has been in flight for more than 5 s
- LAND mode is not engaged
- The FCU selected altitude is lower than present altitude.

The OPEN DES mode is engaged by one of the following:

- Pulling out the ALT knob
- Selecting a manual speed when EXP mode  is engaged.

Note: When OP DES is engaged:

- The FMA displays "OP DES"
- The managed LVL/CH dot on the FCU goes out
- The system arms the ALT mode.

**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-60-00010578.0003001 / 17 AUG 10

**Applicable to: ALL**

The OPEN DES mode is disengaged by one of the following conditions:

- Manual engagement of another vertical mode
- Selection of an altitude higher than present altitude. V/S (FPA ) engages on current V/S (FPA ).  
The vertical mode is boxed white. If within 5 s after the reversion to V/S , the flight crew does not confirm the altitude target change by another expected action, a triple click aural warning sounds, and the V/S (FPA) is boxed white and flashes for 10 s.

**GUIDANCE**

Ident.: DSC-22\_30-70-60-00010579.0002001 / 16 MAR 11

Applicable to: **ALL**

When OPEN DES is engaged, pitch control maintains the target speed/Mach number, and autothrust maintains idle thrust (or the flight crew maintains it manually). The speed target may be either selected or managed.

The OPEN DES mode disregards all altitude constraints.



**GENERAL**

Ident.: DSC-22\_30-70-65-00010580.0002001 / 07 APR 17

Applicable to: ALL

ALT \* mode guides the aircraft to acquire the FCU selected altitude.


ALT CST\* guides the aircraft to acquire an altitude constraint provided by Flight Management. Once the aircraft has reached the altitude, the altitude mode (ALT or ALT CST) engages.

**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-65-00010581.0002001 / 23 JUN 15

Applicable to: ALL

The mode engages when the aircraft reaches the altitude capture zone, defined by the aircraft vertical speed (among other parameters).



Note: ALT \* and ALT CST\* cannot be engaged below 400 ft, if either the takeoff or the go-around mode is engaged.

**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-65-00010582.0008001 / 19 DEC 12

Applicable to: **ALL**

The mode is disengaged by one of the following conditions:

- Engagement of V/S mode on current vertical speed by turning the FCU ALT knob by more than 250 ft.

If within 5 s after reversion to V/S (FPA) the flight crew does not confirm the altitude target change by:

- Pulling the ALT knob, or
- Setting a new V/S (FPA) target, or
- Pushing the V/S or FPA knob on the FCU,

then, a triple click aural warning sounds, and the V/S (FPA) is boxed white for additional 10 s.

- Engagement of another vertical mode provided the FCU altitude has been changed by more than 250 ft.



**GUIDANCE**

Ident.: DSC-22\_30-70-65-00010583.0006001 / 07 APR 17

Applicable to: **ALL**

The ALT \* and ALT CST\* mode have internal V/S guidance that is a direct function of the difference between present altitude and the altitude target.

The system switches automatically to ALT (altitude hold) when the altitude deviation becomes less than 20 ft.

ALT \* and ALT CST\* modes have internal protections that decreases the vertical speed when VLS or VMAX is reached (VLS or VMAX becomes the priority target).



- Note:
- *If the baro setting is changed during ALT \* mode, this may lead to an FCU target overshoot due to the change of the current value of the altitude. However ALT \* mode will allow the FCU altitude to be regained.*
  - *For aircraft equipped with QFE option, a switching from STD to QFE (or vice versa) in ALT CST\* mode, will change the target value and a reversion to V/S may occur if the target value is modified of 250 ft or more.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD VERTICAL MODES - ALTITUDE ACQUIRE MODE

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-70-70-00010584.0001001 / 17 AUG 10

**Applicable to: ALL**

The ALT mode maintains a target altitude. This target altitude is either the FCU selected altitude or an altitude constraint delivered by Flight Management.

**ARMING CONDITIONS**

Ident.: DSC-22\_30-70-70-00010585.0001001 / 17 AUG 10

**Applicable to: ALL**

The ALT mode arms automatically whenever the aircraft climbs or descends toward the target altitude.

Note: *The ALT mode arms only if the difference between the current altitude and the FCU selected altitude is at least 250 ft.*

When ALT is armed, the FMA displays the ALT message on its second line:

- Blue when the target altitude is the FCU selected altitude
- Magenta if the target altitude is an altitude constraint.

**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-70-00010586.0002001 / 17 AUG 10

**Applicable to: ALL**

The ALT mode is engaged automatically when the difference between present altitude and the target altitude becomes less than 20 ft with ALT\* engaged.

Note: *The ALT mode is displayed on the FMA when the V/S knob is pushed in or is pulled out with V/S -FPA target set to zero but V/S mode is still active. In other words, if V/S knob is dialled up or down, the aircraft will climb or descend without any pulling action.*

**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-70-00010587.0001001 / 17 AUG 10

**Applicable to: ALL**

The ALT mode disengages when any other vertical mode engages.

**GUIDANCE**


Ident.: DSC-22\_30-70-70-00010588.0002001 / 23 JUN 15

Applicable to: **ALL**

- The altitude that ALT mode holds is the altitude it memorized when engaged. It is not affected by a change of reference in the ALT window or by a change in the barometric correction.
- When ALT is engaged, the FMA displays ALT in green (FCU altitude hold) or ALT CST in green if it is an altitude constraint.



- If the AP is engaged while FD is already engaged in ALT mode at the FCU selected altitude, the autopilot:
  - Acquires and holds the FCU altitude if present altitude is within 250 ft of it, or
  - Commands a level-off if present altitude is more than 250 ft from the FCU altitude.



**SOFT ALTITUDE MODE (CRUISE)**

Ident.: DSC-22\_30-70-70-00010589.0002001 / 19 DEC 12

Applicable to: **ALL**

The soft altitude mode engages when the aircraft reaches the FCU altitude set as the cruise flight level (entered in the F-PLN or on PROG page).  
 The soft altitude mode corrects minor deviations from the Mach target by allowing a  $\pm 50$  ft variation from the CRZ FL. This feature improves fuel efficiency and passenger comfort and minimizes the changes in thrust.

MACH

ALT CRZ

HDG

AP1  
1FD2  
A/THR

FMA in SOFT ALT HOLD MODE



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD VERTICAL MODES - ALTITUDE HOLD MODE

Intentionally left blank


**GENERAL**

Ident.: DSC-22\_30-70-80-00010611.0004001 / 19 DEC 12

Applicable to: ALL

The V/S - FPA mode is a selected mode. It acquires and holds the vertical speed or the flight path angle displayed in the V/S - FPA window of the FCU.

The HDG V/S -TRK FPA pb on the FCU allows the flight crew to select either type of reference to be used for guidance and for display on the PFD.



**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-80-00010612.0003001 / 17 AUG 10

Applicable to: ALL

- The flight crew can engage the mode manually as follows:
- Pull out the V/S or FPA knob (at least 5 s after lift-off) or push it in for an immediate level off (V/S=0)
  - Engage the AP and/or FD if AP and FD are not engaged (basic mode of AP /FD engagement)
  - Select a different altitude (more than 250 ft from present altitude) when in ALT\* mode
  - Select a higher altitude than present altitude when in DES , OP DES modes or EXP DES mode
  - Select a lower altitude than present altitude when in CLB , OP CLB modes or EXP CLB mode.

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT GUIDANCE

AP/FD VERTICAL MODES - VERTICAL SPEED  
MODE - FLIGHT PATH ANGLE MODE (V/S - FPA)

The mode engages automatically:


- 5 s after lift-off, if no other vertical mode is engaged
- Upon loss of G/S \* or G/S mode
- Upon loss of FINAL mode
- Upon loss of LOC \* or LOC mode
- Upon loss of NAV mode when DES mode is engaged
- Upon loss of vertical flight path in DES mode.

### DISENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-70-80-00010592.0002001 / 17 AUG 10

Applicable to: ALL

The flight crew can disengage the V/S mode manually by:

- Pulling or pushing the Altitude knob, or
- Pushing the EXPED pb , or
- Initiating a go-around.

It disengages automatically:

- When the aircraft reaches the FCU altitude, or
- Upon G/S\* engagement.

### GUIDANCE

Ident.: DSC-22\_30-70-80-00010593.0009001 / 04 JUL 17

Applicable to: ALL

The FMGC pitch mode guides the aircraft to the target V/S or FPA . The corresponding A/THR mode is SPEED or MACH. The FMA displays V/S (FPA).

The V/S (FPA ) guidance has priority over the speed guidance. If the selected target V/S or FPA is too high (relative to the current thrust condition and speed), the FMGC will steer the aircraft to the target V/S or FPA, but the aircraft will also accelerate or decelerate.

When the speed reaches its authorized limit, V/S or FPA automatically decreases to maintain the minimum (or maximum) speed limit.

Note: If the flight crew sets V/S = 0 or pushes the V/S or FPA knob to level off, it automatically sets V/S or FPA target to zero and the aircraft levels off and maintains its altitude.

Note: If AP is engaged while a V/S is selected with only FD ON, the V/S will synchronise on the current aircraft V/S.



**GENERAL**

Ident.: DSC-22\_30-70-90-00010223.0001001 / 17 AUG 10

**Applicable to: ALL**

Expedite mode is an OPEN mode used in climb or descent to reach the desired altitude with the maximum vertical gradient.

**ENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-90-00010594.0001001 / 17 AUG 10

**Applicable to: ALL**

The flight crew can engage EXPEDITE if:

- The aircraft has been in flight for more than 5 s
- Managed speed is available.

The flight crew engages EXPEDITE manually by pushing the EXPED pb on the FCU:

- If the FCU selected altitude is higher than present altitude, EXP CLB mode engages
- If the FCU selected altitude is lower than present altitude, EXP DES mode engages.

**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-70-90-00010595.0003001 / 17 AUG 10

**Applicable to: ALL**

The flight crew can disengage EXPEDITE manually by:

- Pulling out the V/S or FPA knob to engage the V/S or FPA mode
- Pulling out the ALT knob to engage OP CLB or OP DES
- Pulling out the SPD/MACH knob to activate the selected speed target and engage OP CLB or OP DES. A white box appears around the longitudinal mode and flashes for 10 s. A triple click sounds
- Pushing in the ALT knob to engage the CLB or DES mode, provided that the engagement conditions are met
- Selecting a higher altitude than present altitude when in EXP DES. If this action is not followed by another expected flight crew action within 5 s, a triple click sounds. A steady white box appears around the longitudinal mode, then flashes for 10 s after the triple click

- Selecting a lower altitude than present altitude when in EXP CLB. If this action is not followed by another expected flight crew action within 5 s, a triple click sounds. A steady white box appears around the longitudinal mode, then flashes for 10 s after the triple click
- Activating a reversion to V/S to protect the aircraft from exceeding VLS or VMAX. A white box appears around the longitudinal mode and flashes for 10 s. A triple click sounds.

*Note: In FD mode only, if the flight crew does not follow the FD orders, a reversion to V/S occurs when reaching VMAX + 4 in EXP CLB or VLS - 2 in EXP DES (VLS - 17 with speedbrakes). Refer to DSC-22\_30-75 General.*

EXPEDITE disengages automatically with ALT\* engagement.

**GUIDANCE**


Ident.: DSC-22\_30-70-90-00010610.0002001 / 19 DEC 12

Applicable to: **ALL**

When the aircraft is in EXP CLB , the target speed is Green Dot, which is maintained with pitch control. Autothrust, if active, sets the thrust at CLB THRUST automatically.

When the aircraft is in EXP DES, the target speed is 340 kt or M 0.8 which is maintained with pitch control. Autothrust, if active, sets the thrust at IDLE automatically.

When EXPEDITE is engaged, the system disregards SPD CSTR , ALT CSTR , and SPD LIM.



**GENERAL**

Ident.: DSC-22\_30-75-00010633.0001001 / 17 MAR 17

Applicable to: ALL

Mode reversion are automatic mode changes that unexpectedly occur, but are designed to ensure coherent AP , FD and A/THR operations, in conjunction with flight crew input (or when entering a F-PLN discontinuity).

Due to the unexpected nature of their occurrence, the FMA should be closely monitored for mode reversions.

**INTERACTION BETWEEN LATERAL MODES,  
VERTICAL MODES, AND MANAGED SPEED PROFILE**

Ident.: DSC-22\_30-75-00012054.0006001 / 17 MAR 17

Applicable to: ALL

● **When NAV mode is engaged:**

The FMGS guides the aircraft along the flight plan and considers the constraints attached to the F-PLN waypoints. As a result:

- Managed CLB and DES modes are available
- The managed speed profile includes: V2 - SPD CSTR (if applicable) - SPD LIM - ECON CLB SPD /MACH - ECON CRZ MACH - ECON DES (MANAGED SPD ) - SPD /MACH - SPD CSTR - SPD LIM - HOLD SPD - VAPP /GS MIN.

It is valid for all vertical modes, except EXPEDITE .

● **When NAV mode is not engaged:**

The FMGS considers that the flight plan is not followed, and ignores all speed and altitude constraints linked to the F-PLN waypoints. As a result:

- The managed vertical CLB and DES modes are not available
- The managed SPD profile disregards the speed constraints and includes: V2 - SPD LIM - ECON CLB - ECON CRZ - ECON DES (MANAGED SPD ) - SPD LIM - VAPP /GS MIN target.

As a consequence, when NAV mode disengages (manual or automatic):

- CLB mode, when engaged, reverts to OPEN CLB. The lateral mode is boxed white for 10 s. The vertical mode is boxed white.

If within 5 s, the disengagement of the NAV mode is not confirmed by one of the following flight crew actions:

- FCU altitude change
- Level-off
- Selection of the V/S mode

then, a triple click aural warning sounds. In addition, a white box flashes around the vertical mode for additional 10 s.

- DES mode, when engaged, reverts to V/S mode on current value.

If within 5 s, the disengagement of the NAV mode is not confirmed by one of the following flight crew actions:

- FCU altitude change
- Level-off
- Selection of the V/S mode

then, a triple click aural warning sounds. In addition, a white box flashes around the vertical mode for additional 10 s.

This reversion to V/S (FPA ) mode on the current V/S target does not modify the pitch behavior of the aircraft. It is the flight crew's responsibility to adapt pitch, if necessary.

- Speed and altitude constraints are disregarded (but speed limit is retained).

### MODE REVERSION DUE TO FCU ALTITUDE CHANGE


Ident.: DSC-22\_30-75-00012053.0006001 / 01 OCT 12

Applicable to: **ALL**

When an OPEN mode is engaged, the aircraft climbs or descends towards the altitude set on the FCU . If the flight crew sets the FCU altitude to a target not compatible with the active open mode, a mode reversion occurs and V/S (or FPA ) engages on current V/S (or FPA).


This reversion applies to CLB , OP CLB , DES , OP DES, EXP DES  , EXP CLB  .

Example: Reversion from OP CLB to V/S:



FCU ALTITUDE CHANGE FROM FL150 TO FL70

With ALT \* engaged, the target altitude is changed by any value greater than 250 ft, V/S (or FPA ) engages on currents V/S (or FPA). Refer to DSC-22\_30-75 Mode Reversions (Summary).



If within 5 s after the reversion to V/S (FPA), the flight crew does not confirm the altitude target change by:

- Pulling the ALT knob, or
- Setting a new V/S (or FPA) target, or
- Pushing the V/S or FPA knob on the FCU,

then, a triple click sounds, and the V/S (FPA) is boxed white for additional 10 s.


**REVERSION WITH GLOBAL SPEED PROTECTION**

Applicable to: ALL

Ident.: DSC-22\_30-75-A-00012055.0010001 / 19 DEC 12


**AUTOMATIC SPEED MODE PROTECTION IN CLIMB**

FD s are engaged in an OPEN mode in climb with AP not engaged.

If FD s are engaged in CLIMB or OPEN CLIMB mode or EXP CLB  and the flight crew does not follow the FD bars to maintain the commanded climb (pitch too low and autothrust in maximum climb thrust), the aircraft accelerates.

Both FD s disengage when VMAX +4 is reached (VMAX being VMO , VLE or VFE ). If the A/THR is active, it reverts to SPEED mode and reduces the thrust to recover the speed target.


A triple click aural warning sounds.



Ident.: DSC-22\_30-75-A-00012056.0010001 / 01 OCT 12

**AUTOMATIC SPEED PROTECTION IN V/S (OR FPA) MODE IN CLIMB**

When climbing with V/S mode engaged: If the selected V/S value is excessive (with regards to thrust and speed), the FMGS maintains the V/S target, but the airspeed decreases. When reaching VLS (or VLS -5, if the speed target is VLS ), the AP temporarily abandons the V/S target, and automatically decreases the vertical speed to maintain VLS . The same applies if FPA mode is used with an excessive FPA target.



V/S mode remains engaged.

On the FMA , the V/S target is boxed with a flashing amber rectangle, and the V/S value pulses. Besides, an aural triple click is generated.




*Note:* When flying with FD bars only (AP OFF), the FMGS adjusts the pitch bar so that VLS is maintained. However, no triple click is generated and the V/S target display on the FMA remains unchanged.

Ident.: DSC-22\_30-75-A-00012057.0010001 / 01 OCT 12

### **AUTOMATIC SPEED MODE PROTECTION IN DESCENT**


FD s are engaged in an OPEN mode in descent with the AP not engaged.

If the FD s are engaged in DES , or OP DES mode, or EXP DES  and, if the flight crew does not follow the FD bars to maintain the commanded pitch, the aircraft decelerates (insufficient descent rate and idle thrust).

If the airspeed reaches VLS -2, both FD s disengage. (If speedbrakes are extended, the FD s disengage between VLS -2 and VLS-19, depending on the position of the speedbrakes).

The A/THR , if active, reverts to SPEED mode upon FDs disengagement, and increases thrust to recover the speed target.

A triple-click aural warning sounds.




Ident.: DSC-22\_30-75-A-00012058.0010001 / 01 OCT 12

**AUTOMATIC SPEED PROTECTION IN V/S (OR FPA) MODE IN DESCENT**

When descending with V/S mode engaged: If the selected V/S value is excessive (with regards to thrust and speed), the FMGS maintains the V/S target, but the airspeed increases. When reaching VMAX (VMO or VLE in clean, or VFE +4 kt), the AP temporarily abandons the V/S target, and automatically decreases the vertical speed to maintain VMAX.

The same applies if FPA mode is used with an excessive FPA target.



V/S mode remains engaged.

On the FMA , the V/S target is boxed with a flashing amber rectangle, and the V/S values pulses. Besides, an aural triple click is generated.

*Note:* When flying with FD bars only (AP OFF), the FMGS adjusts the pitch bar so that VMAX is maintained. However, no triple click is generated and the V/S target display on the FMA remains unchanged.



### MODE REVERSIONS (SUMMARY)

Ident.: DSC-22\_30-75-00012052.0008001 / 23 JUN 15

Applicable to: ALL

There are only 2 types of vertical mode reversions on aircraft equipped with global speed protection.



**REVERSION DUE TO A CHANGE OF THE FCU SELECTED ALTITUDE**

Vertical Mode Engaged	FCU Altitude Selection Change	Vertical Mode Switches to
CLB - OP CLB EXP CLB 	Below aircraft altitude	V/S on current V/S
DES - OP DES EXP DES 	Above aircraft altitude	
ALT* ACTIVE	Any change	

**REVERSION DUE TO THE LOSS OF NAV MODE (MANUAL OR AUTOMATIC)**

CONDITIONS	EVENT	CONSEQUENCE
CLB engaged	Loss of NAV mode	OP CLB engages
DES engaged		V/S engages

**SPEED PROTECTION WHEN FD ORDERS ARE NOT FOLLOWED BY THE FLIGHT CREW (AP NOT ENGAGED)**


CONDITIONS	EVENT	CONSEQUENCE
<ul style="list-style-type: none"> <li>- FD engaged only (no AP), and</li> <li>- OP DES or EXP DES  or DES engaged</li> <li>- A/THR active (IDLE thrust)</li> </ul>	IAS = VLS-2 (if speedbrakes are extended between VLS -2 and VLS-19)	FD bars disappear. If A/THR active, automatic engagement of SPEED mode on the A/THR. Thrust increases to recover the speed target.
<ul style="list-style-type: none"> <li>- FD engaged only (no AP), and</li> <li>- OP CLB or EXP CLB  or CLB engaged</li> <li>- A/THR active (CLIMB thrust)</li> </ul>	IAS = VMAX+4 VMAX = VFE or VLE or VMO /MMO	FD bars disappear. If A/THR active, automatic engagement of SPEED mode on the A/THR. Thrust decreases to recover the speed target.

**SPEED PROTECTION DUE TO EXCESSIVE V/S**

CONDITIONS	EVENT	CONSEQUENCE
Excessive V/S or FPA selected in climb	IAS = VLS (or VLS -5, if target = VLS)	The selected V/S (or FPA ) target is temporarily abandoned to maintain VLS in climb or VMAX in descent.
<ul style="list-style-type: none"> <li>- Excessive V/S or FPA selected in descent, and</li> <li>- Clean configuration</li> </ul>	IAS = VMAX	
<ul style="list-style-type: none"> <li>- Excessive V/S or FPA &lt; 0 selected in descent, and</li> <li>- Configuration other than clean</li> </ul>	IAS = VMAX	

### ENHANCED MODE REVERSION ALERTNESS

The following sequences, or mode reversions, are highlighted by a triple click:

- V/S selection in ALT\*
- SPD selection in SRS
- CLB (or EXP CLB ) to OP CLB, upon lateral flight crew action while climbing toward a constraint
- ALT \* to V/S , upon ALT target change
- FD disengagement in OPEN modes
- Alerting FMA display when V/S -(FPA) target is not held
- CLB to OP CLB reversion, upon profile loss
- Automatic FD re-engagement in basic mode
- DES to V/S upon flight plan loss
- FINAL DES to V/S , upon NAV loss
- Reversion to AP /FD basic modes due to the selection of a new approach, while approach mode is already armed or engaged
- NAV to HDG , upon NAV loss.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

MODE REVERSIONS

Intentionally left blank

**GENERAL**

Ident.: DSC-22\_30-80-10-00011875.0003001 / 16 MAR 11

**Applicable to: ALL**

These modes are called “common” because they are related to both the lateral and the vertical axes.

The AP /FD common modes are:

- On takeoff: Runway/Runway track associated to SRS vertical modes
- In approach: ILS approach (LAND) or non-ILS approach (APP NAV FINAL)
- In go around: NAV or Go around track associated to SRS vertical modes.

These modes are engaged simultaneously on both axes.

COMMON MODES		VERTICAL	LATERAL
TAKEOFF		SRS	RWY RWY TRK
APPROACH MODES	ILS APPROACH	G/S* G/S	LOC* LOC
	NON-ILS APPROACH	FINAL	APP NAV
GO AROUND (GA)		SRS	GA TRK NAV



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD COMMON MODES - GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>AUTO FLIGHT - FLIGHT GUIDANCE</b></p> <p style="text-align: center;">AP/FD COMMON MODES - TAKEOFF</p>
---	--

**GENERAL**

Ident.: DSC-22\_30-80-20-00012253.0001001 / 17 AUG 10  
**Applicable to: ALL**

Takeoff mode combines the SRS (Speed Reference System) vertical mode with the RWY lateral mode. Both are simultaneously engaged, but may be disengaged separately.

Takeoff mode is available:

- During the takeoff run and initial climb for FD bars guidance
- 5 s after lift-off for AP use.

**SRS (SPEED REFERENCE SYSTEM)**

**Applicable to: ALL**

Ident.: DSC-22\_30-80-20-A-00012260.0001001 / 17 AUG 10

**GENERAL**

The SRS mode controls pitch to steer the aircraft along a path in the vertical plan at a speed defined by the SRS guidance law.

Ident.: DSC-22\_30-80-20-A-00012256.0001001 / 23 JUN 15

**ENGAGEMENT CONDITIONS**

The SRS mode engages automatically when the thrust levers are set to the TOGA or FLX/MCT detent, providing:

- V2 has been inserted in the MCDU PERF TAKEOFF page
- The slats are extended
- The aircraft has been on ground for at least 30 s.

Ident.: DSC-22\_30-80-20-A-00012258.0002001 / 23 JUN 15

**DISENGAGEMENT CONDITIONS**

The SRS mode disengages:

- Automatically, at the acceleration altitude (ACC ALT ), or if ALT \* or ALT CST\* mode engages (above 400 ft RA)
- If the flight crew engages another vertical mode
- If the flight crew selects a speed while in SRS mode: SRS reverts to OP CLB mode, and a triple-click aural warning is heard.

*Note:* In Engine Out conditions, the SRS mode does not automatically disengage at EO ACC ALT. Refer to DSC-22\_20-60-40 General.

Ident.: DSC-22\_30-80-20-A-00012259.0011001 / 16 MAR 11


**GUIDANCE**

In SRS mode, the aircraft maintains a speed target equal to V2 +10 kt in normal engine configuration. When the FMGS detects an engine failure, the speed target becomes the highest of V2 or current speed, limited by V2+ 15 kt.

The SRS guidance law also includes:

- Attitude protection to reduce aircraft nose-up effect during takeoff (18 ° or 22.5 ° maximum in case of windshear)
- Flight path angle protection that ensures a minimum vertical speed of 120 ft/min
- A speed protection limiting the target speed to V2+15 kt.

*Note: If during takeoff the flight crew inadvertently sets an altitude on the FCU below the current altitude, the aircraft will remain in SRS mode until the flight crew takes some other action.*



**RUNWAY (RWY)**

Applicable to: **ALL**

Ident.: DSC-22\_30-80-20-B-00012255.0001001 / 17 AUG 10

**GENERAL**

The RUNWAY mode has two submodes:

- RWY mode, which gives lateral guidance orders during takeoff roll and initial climb out (up to 30 ft RA ) if a LOC signal is available
- RWY TRK mode, which gives lateral guidance on the track the aircraft was flying at mode engagement (at 30 ft RA).

Ident.: DSC-22\_30-80-20-B-00012323.0001001 / 17 AUG 10

### **ENGAGEMENT CONDITIONS**

The RWY engagement conditions are:

- The conditions required for SRS mode engagement:
  - V2 is inserted in the MCDU PERF TAKEOFF page
  - Slats are extended
  - The aircraft has been on ground for at least 30 s.
- The aircraft is receiving a LOC signal and LOC deviation is less than 1/2 dot
- The aircraft heading is within 20 ° of the ILS related course
- The ILS course is identical to the runway heading of the origin airport as selected for the active flight plan, if any.

The RWY TRK mode engages automatically at 30 ft (RA ) if NAV mode does not engage (NAV not armed prior to takeoff).

Ident.: DSC-22\_30-80-20-B-00012324.0001001 / 17 AUG 10

### **DISENGAGEMENT CONDITIONS**

RWY mode disengages if:

- The LOC signal is lost below 30 ft RA or the aircraft heading and the runway heading differ by more than 20 °.
- Another lateral mode is engaged.

*Note: If the takeoff runway has no ILS , RWY mode is not available and the PFD does not display the yaw bar nor "RWY " on FMA.*

Ident.: DSC-22\_30-80-20-B-00012325.0002001 / 16 MAR 11

### **GUIDANCE**

The RWY mode uses the LOC signal to guide the aircraft on the runway centerline while the aircraft is on the ground. The PFD displays the FD yaw bar and the FMA displays "RWY".

The RWY TRK mode guides the aircraft on the track the aircraft was flying at mode engagement. The FD displays the conventional guidance bar and the FMA displays "RWY TRK".



Typical FMA with RWY mode engaged.



**General**

**GENERAL**

Ident.: DSC-22\_30-80-30-05-00012378.0008001 / 01 OCT 12

Applicable to: ALL

The aircraft can fly different types of approaches:

- Precision approaches: ILS, MLS 
- Non-precision approaches: VOR /DME , VOR , NDB (if ADF ), RNAV
- Non-precision approaches using a Localizer only: LOC.

The flight crew uses an ARRIVAL lateral revision to insert these approaches into the flight plan:

- For precision approaches, the flight crew uses the APPR pb on the FCU to arm or engage the LOC and G/S guidance modes
- For non-precision approaches, the flight crew uses the APPR pb on the FCU to arm or engage the APP NAV and FINAL guidance modes, except for LOC approaches, where the flight crew only uses the LOC pb to arm or engage the LOC mode.

THE TYPE OF SELECTED APPROACH IS DISPLAYED ON THE TOP SIDE OF THE ND





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT GUIDANCE

AP/FD COMMON MODES - APPROACH

Intentionally left blank

**Precision Approach**

**PRECISION APPROACH MODES**

Applicable to: ALL

Ident.: DSC-22\_30-80-30-10-A-00012379.0003001 / 01 OCT 12

**GENERAL**

The ILS approach mode includes the following modes:

VERTICAL MODE	LATERAL MODE
G/S* (capture)	LOC* (capture)
G/S (track)	LOC (track)
COMMON MODES: LAND - FLARE - ROLL OUT	

The sequencing of these modes is automatic once the flight crew has pushed the APPR pb and the conditions for engagement are met.


**SELECTION**

The ILS approach is selected when the APPR pb of the FCU is pressed and:

- An ILS approach or a runway only or no approach is inserted in the Flight Management flight plan (ARRIVAL page), and an ILS frequency is set in on the MCDU, or
- Both radio management panels are set to NAV and each one has the ILS frequency and course set in.



**CHECK APPROACH SELECTION MESSAGE**






If the flight crew inserts a non-ILS approach into the flight plan, and then uses the RAD NAV page to tune an ILS manually, the MCDU displays “CHECK APPR SELECTION”. This message is a reminder that the available APPR guidance modes are APP NAV and FINAL.



## **APPR MODE**

### **ARMING CONDITIONS OF LOC AND G/S MODES**

The flight crew arms the ILS /GLS  /MLS  /APPR mode (LOC and G/S in blue on the FMA ) by pushing the APPR pb on the FCU, provided that:

- An ILS /GLS  /MLS  approach is selected
- The aircraft is above 400 ft RA
- The ILS /GLS  and RA are available
- Go-around or takeoff or final mode is not engaged
- ILS /GLS  /MLS  frequency/channel and course are identically set on both receivers.

LOC and G/S blue are displayed on the FMA. Both modes will automatically engage when conditions are met.

Second autopilot may be engaged.

Current landing capability is displayed on the FMA.

### **DISARMING CONDITIONS OF LOC AND G/S MODES**

ILS /GLS  /MLS  APPR mode disarms if the aircraft is above 400 ft, and:

- When the flight crew presses the APPR pb, or when the flight crew selects another approach, both the LOC and the G/S modes disarm.


The HDG/TRK mode engages if the LOC mode was engaged, and the V/S (FPA ) mode engages if the G/S mode was engaged

- When the flight crew presses the LOC pb, only the G/S mode disarms.

The V/S (FPA ) mode engages, if the G/S mode was engaged

- When the flight crew pulls the HDG/TRK knob
- When the flight crew engages the go-around mode.





**ENGAGEMENT CONDITIONS OF LOC AND G/S MODES**

When ILS /GLS /MLS capture conditions are fulfilled:

- LOC\* mode engages, and
- G/S \* mode engages. No radio altimeter validity is required with this FMGC standard for G/S engagement. The FMA displays “LOC\*”, or “G/S\*”, or both, in green.

Nevertheless, the G/S\* mode cannot engage, if:

- LOC\* mode is not engaged, or
- The aircraft is above the glide path and its trajectory does not cross the ILS G/S beam.

When the aircraft is established on the LOC axis, the LOC mode engages.



When the aircraft is established on the G/S axis, the G/S mode engages.

The FMA displays “LOC ” and “G/S ” in green. The AP /FD guides the aircraft along the G/S down to 30 ft, and along the LOC during the flare and rollout.

*Note:* G/S \* or G/S modes may be engaged above the operating range of the radio altimeters (8 000 ft for TRT, and 5 000 ft for Collins and Honeywell radio altimeters). The landing capability displayed on the FMA will reflect the lack of RA validity (CAT 1) until the radio altimeters become active.

*But, if the radio altimeters fail, or if the FMGS receives no radio altimeter data, LOC , G/S , and AP /FD s will disengage and FDs will re-engage on basic modes.*

## DISENGAGEMENT CONDITIONS OF LOC AND G/S MODES

If the aircraft is above 400 ft, the ILS /GLS  /MLS  APPR mode disengages when the flight crew:

- Presses the APPR pb, HDG V/S or TRK FPA engages
- Presses the LOC pb, the LOC mode remains engaged. The system reverts to V/S (FPA), if G/S was engaged
- Pulls out the HDG/TRK knob, HDG V/S or TRK FPA engages
- Engages the go-around mode
- Selects another approach. HDG V/S or TRK FPA modes engage.
- When the LOC or G/S signal has been lost for 7 s or more above 200 ft RA. AP /FD s disengage and FD s reengage in basic modes (HDG V/S or TRK FPA).

## DISENGAGEMENT CONDITIONS OF G/S ONLY

- The flight crew pulls out the V/S or FPA knob. LOC mode remains engaged, but G/S mode disengages and V/S or FPA engages.
- The flight crew pushes or pulls the ALT knob. LOC mode remains engaged, and the mode selected by the flight crew engages, as a function of the FCU selected altitude.

## LOC CONVERGENCE FUNCTION

The aim of the LOC Convergence function is to help the aircraft intercept and capture the LOC axis.

The aircraft is guided with a converging track of 20 ° from the LOC axis, when all the following conditions are met:

- NAV mode is engaged, and LOC mode is armed
- The aircraft is within 20 NM of the destination runway
- The difference between the aircraft track and the QFU is less than 20 °.

## ENHANCED LOC CAPTURE FUNCTION

The Enhanced LOC Capture function enhances the performance of the LOC capture and helps the aircraft to capture the LOC beam without overshoot.

### Pre-Capture of the LOC Beam

The pre-capture of the LOC beam aims to begin the LOC beam capture sooner.

LOC \* mode may engage when LOC mode is armed and when the aircraft reaches the LOC pre-capture zone. The LOC pre-capture zone is a geographical zone around LOC beam where it is possible to guide the aircraft toward the LOC beam, with the help of FMS position data. To ensure the capture of the LOC beam, the aircraft is guided with a 15 ° convergence angle with respect to runway QFU.


The LOC\* mode engagement in the pre-capture zone is possible, when :

- The LOC deviation is more than 2.3 dots
- The FMS is in GPS PRIMARY
- The difference between the track and the QFU is between 25 ° and 115 °
- The guidance roll order is such that LOC \* will capture the LOC beam without overshoot.



When the LOC deviation becomes lower than 2.3 dots, LOC \* mode no longer uses the FMS position data for guidance, but the actual LOC beam deviation to complete the capture of the axis.

Capture of the LOC Beam

Current conditions of LOC beam capture in the capture zone remain the same. This means that if approach conditions of the aircraft (interception angle, speed) do not need activation of the capture assistance, the LOC beam capture will occur as usual based on LOC deviation, aircraft track and guidance roll order conditions.



Note: On the PFD and on the ND, the flight crew will observe movement of the LOC deviation toward the center of the scale, only when the LOC deviation is less than 2 dots. This occurs when the aircraft is in the capture zone.

When the ILS /GLS  /MLS  frequency/channel or the ILS /GLS /MLS ident entered on the RAD NAV page differs from the ILS /GLS /MLS of the destination runway entered in the Flight Plan :

- The aircraft loses the LOC capture assistance function
- The “RWY/LS MISMATCH” message is displayed on the scratchpad
- The flight crew should select HDG mode to perform the LOC capture.

Note: *There is no glideslope capture assistance. The flight crew shall ensure that the aircraft flight path intercepts the G/S beam.*

ident.: DSC-22\_30-80-30-10-A-00012381.0002001 / 17 AUG 10

## **LAND MODE**

### **ENGAGEMENT CONDITIONS**

LAND mode automatically engages when the LOC and G/S modes are engaged, and the aircraft is below 400 ft RA . The FMA displays “LAND”, indicating that LOC and G/S are locked. No action on the FCU will disengage LAND mode. FLARE and ROLL OUT modes will successively engage.

### **DISENGAGEMENT CONDITIONS**

LAND mode disengages:

- Upon engagement of the go-around mode
- If the flight crew presses the APPR pb, when the aircraft has been on ground for at least 10 s with the autopilot disconnected
- When both AP /FDs are disengaged.

Note: *When LAND is not displayed on the FMA , at/or slightly below 400 ft, the landing capability degrades to CAT 1 and the triple click is generated. No autoland is authorized with CAT 1 displayed on the FMA.*

ident.: DSC-22\_30-80-30-10-A-00012382.0001001 / 17 AUG 10

## **FLARE MODE**

Once the aircraft reaches approximately 40 ft RA (the precise value is a function of V/S):

- The FLARE mode engages
- The FMA displays “FLARE” in green.

At 30 ft RA , the AP /FD aligns the yaw axis with the runway centerline and the aircraft flares on the pitch axis. If the autothrust is active, thrust is automatically reduced to IDLE (*Refer to DSC-22\_30-90 A/THR Modes - RETARD Mode*).

When both AP /FDs are disengaged, FLARE mode disengages.

After main landing gear touchdown, the autopilot (if engaged) sends a nose down order.

### **ALIGN SUB-MODE**

ALIGN is a sub-mode of LAND mode that lines up the aircraft's axis with the ILS course. It is not displayed to the flight crew.

Ident.: DSC-22\_30-80-30-10-A-00012383.0001001 / 17 AUG 10

### **ROLL OUT MODE**

At touchdown, the ROLL OUT mode engages and guides the aircraft along the runway centerline. The FMA displays "ROLL OUT" in green, and the PFD displays the yaw bar and no FD bars.

### **SPEED CONTROL**

Ident.: DSC-22\_30-80-30-10-00012384.0001001 / 17 AUG 10

**Applicable to: ALL**


The autothrust, when active, controls speed. The approach speed target (VAPP ) is either managed by the FMGS or selected by the flight crew:

- When managed, the speed target is computed by the FMGS and may be modified by the flight crew through the MCDU . At 700 ft RA , the current speed target value is memorized by the autothrust, to ensure stabilized speed guidance, even if Flight Management fails. Below 700 ft, any new VAPP or WIND entry in the MCDU has no effect on the speed target.
- When selected, the autothrust always targets the speed selected on the FCU.

**TYPICAL ILS APPROACH**

Ident.: DSC-22\_30-80-30-10-00012385.0001001 / 16 MAR 11

Applicable to: **ALL**



### AUTOLAND WARNING LIGHT

Ident.: DSC-22\_30-80-30-10-00012386.0002001 / 09 APR 15

Applicable to: ALL

The AUTOLAND warning flashes when:

- At least one RA indicates a height below 200 ft, and
- At least one AP is engaged with LAND or FLARE mode on the FMA, and
- At least one of the following conditions occurs:
  - The LOC deviation exceeds 1/4 dot and the aircraft is above 15 ft RA (the LOC scale flashes on the PFD), or
  - The GLIDE deviation exceeds 1 dot and the aircraft is above 100 ft RA (the GLIDE scale flashes on the PFD), or
  - Loss of LOC signal above 15 ft RA (The FD vertical bar flashes on the PFD), or
  - Loss of GLIDE signal above 100 ft RA (The FD horizontal bar flashes on the PFD), or
  - The difference between both RA indications is greater than 15 ft RA, or
  - The last autopilot disengages, or
  - The FMGS detects a long flare.

### LANDING CAPABILITIES

Ident.: DSC-22\_30-80-30-10-00012387.0001001 / 17 AUG 10

Applicable to: ALL

Each FMGC computes its own automatic landing capability.

The FMA displays “CAT 1”, “CAT 2”, “CAT 3 SINGLE” or “CAT 3 DUAL” messages as soon as the APPR pb is pushed in to arm ILS approach modes.

*Refer to PRO-NOR-SRP-01-70 Initial Approach.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD COMMON MODES - APPROACH

Intentionally left blank






## Non Precision Approach


### GENERAL

Ident.: DSC-22\_30-80-30-20-00012388.0120001 / 04 NOV 13

Applicable to: ALL

This mode guides the aircraft laterally and vertically down to the minimum along the final descent profile computed by the FMGS.

This mode is used to fly a non-ILS /non-GLS  /non-MLS  approach (VOR , VOR /DME , NDB (if ADF  ), RNAV...) as inserted into the flight plan.



The non-ILS /non-GLS  $\nabla$  /non-MLS  $\nabla$  approach includes the following managed modes:

- APP NAV mode for lateral guidance
- FINAL mode for vertical guidance.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS


### AUTO FLIGHT - FLIGHT GUIDANCE

AP/FD COMMON MODES - APPROACH

## SELECTION

Ident.: DSC-22\_30-80-30-20-00012389.0001001 / 17 AUG 10

Applicable to: ALL

A non-ILS approach (VOR , VOR /DME , NDB (if ADF  ), RNAV) is selected if the active flight plan calls for it (and it has been inserted in that flight plan).

## ARMING CONDITIONS

Ident.: DSC-22\_30-80-30-20-00012390.0001001 / 17 AUG 10

Applicable to: ALL

The flight crew arms the APP NAV and FINAL modes by pressing the APPR pb on the FCU, if all of the following conditions are met:

- The aircraft is above 400 ft AGL
- The flight plan is valid (lateral and vertical profile)
- The active flight plan has selected a non-ILS approach
- GA mode is not engaged.

The FMA displays “FINAL” and “APP NAV” in blue.

If NAV mode was already engaged, APP NAV engages immediately.

## DISARMING CONDITIONS

Ident.: DSC-22\_30-80-30-20-00012391.0006001 / 30 MAY 12

Applicable to: ALL

FINAL and APP NAV modes are disarmed when:

- The flight crew presses the APPR pb, or
- The flight crew presses the LOC pb, or
- The flight crew selects a precision approach instead of the approach currently armed, or
- The flight crew engages the GO AROUND mode.

Note: - after pressing the LOC pb, the LOC mode is armed  
- after the selection of a precision approach, the flight crew must press the APPR pb to arm the new approach

## ENGAGEMENT CONDITIONS


Ident.: DSC-22\_30-80-30-20-00012392.0003001 / 08 AUG 17

Applicable to: ALL

APP NAV and NAV modes engage under the same conditions:

If NAV mode was engaged, APP NAV engages immediately. If HDG /TRK is engaged, APP NAV engages when the intercept conditions are met (aircraft track line must intercept the flight plan active leg).

APP NAV will not engage if the "TO" waypoint is not displayed in white on the ND and MCDU.



FINAL APP is a lateral and vertical managed guidance approach mode that aims guiding aircraft from FDP down to MAP along a defined FPA. It is thus recommended to arm this mode when the TO waypoint is the FDP.

FINAL APP mode engages when:


- NAV or APP NAV is engaged,
- FINAL is armed (by pressing APPR on the FCU),
- Predictions are available in FMS,

- APPROACH phase is active,

Note: APPROACH phase may have to be manually activated on MCDU PERF page if the approach starts at high altitude above aerodrome level (i.e. RNAV (RNP) approaches).

- The aircraft is within the capture area of the FMS profile:
  - Laterally:  $\pm 1.5$  NM from the Final Descent Point.
  - Vertically: +150 ft above the Final Descent Point.
- The aircraft intercepts a descending leg of the vertical flight path.

Note: if APPR pb is pressed earlier, FINAL APP mode may engage. As a consequence, resulting speed and altitude management in FINAL APP may be inappropriate before FDP.



A blue arrow is displayed on ND s to indicate where the FINAL APP engagement conditions are met and where the final descent will begin automatically.

If the same arrow is displayed in white, at least one engagement condition is not fulfilled, FINAL APP will not engage and the aircraft will not descend automatically.

**Definition of the Final Descent Point (also called Vertical Intersection Point "VIP" for RNAV (RNP) approaches)**

The Final Descent Point is the waypoint from which starts the FMS segment with coded FPA . For RNAV (RNP ) approaches, this point may be indicated on the chart as "VIP".

This point is defined in the Navigation Database by:

- A constant vertical flight path beyond this point,
- A coded altitude constraint that may be "at" or "at or above" (e.g. +3 000 ft). This constraint is displayed on ND (in magenta), next to the corresponding waypoint, when the CSTR key is selected on the EFIS Control Panel. It is also shown on the F-PLN page at this WPT.



Note: *The Final Approach Fix (FAF) is the position from where the obstacle clearance is defined relative to an Obstacle Clearance Surface (OCS). Obstacle clearance is only ensured if the aircraft is flying on the defined vertical flight path. Before the FAF, minimum altitudes are published with fixed Minimum Obstacle Clearance (MOC). The Final Descent Point is the point in the procedure at or before the FAF from which a constant vertical flight path is defined.*

**DISENGAGEMENT CONDITIONS**

Ident.: DSC-22\_30-80-30-20-00012393.0052001 / 21 MAR 16

Applicable to: ALL

The FINAL and APP NAV modes disengage:

- If the flight crew pushes the APPR pb (HDG-V/S or TRK-FPA modes engage), or
- If the flight crew pushes the LOC pb (LOC mode arms if an ILS/MLS  /GLS  is selected and HDG-V/S or TRK-FPA modes engage), or
- If the flight crew pulls out the HDG/TRK knob (the FMGS reverts to HDG-V/S or TRK-FPA basic modes), or
- If the flight crew selects a precision approach (the FMGS reverts to HDG-V/S or TRK-FPA basic modes), or
- Automatically at Missed Approach Point (the FMGS vertical mode reverts to V/S / FPA and the FMGS lateral mode reverts to HDG / TRK or NAV), or
- When the GO AROUND mode engages.

Note:

- *If the flight crew engages V/S or FPA mode, only FINAL mode disengages. NAV mode remains engaged.*
- *In the case the flight crew selects a new approach, the flight crew must press the APPR pb to engage the new approach.*

**GUIDANCE**

Ident.: DSC-22\_30-80-30-20-00012394.0027001 / 29 MAR 12

Applicable to: ALL

The FINAL mode guides the aircraft on the vertical profile down to the minimum.

The FINAL mode displays on the PFD the aircraft vertical deviation from the descent path (VDEV symbol) on a  $\pm 200$  ft scale.

The FINAL mode:

- Anticipates leaving the altitude selected by the FCU when the aircraft reaches the Continue Descent symbol (blue arrow on the ND)
- Provides precise vertical guidance on the descent and final path with an internal vertical speed limitation to avoid excessive V/S.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

AP/FD COMMON MODES - APPROACH

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT GUIDANCE

AP/FD COMMON MODES - GO AROUND (GA)

## GENERAL

Ident.: DSC-22\_30-80-40-00012050.0005001 / 16 MAR 11

Applicable to: ALL

When the flight crew performs a go-around, the Speed Reference System (SRS) vertical guidance mode automatically engages.

In addition:

- The NAV mode is automatically engaged or armed, except if HDG /TRK was preset, or
- The GA TRK lateral mode is automatically engaged until the HDG/TRK knob is pulled if the HDG /TRK mode is preset.

*Note:* Below 100 ft, the HDG mode remains engaged with NAV mode armed if HDG /TRK was already engaged during approach.

## ENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-80-40-00012210.0004001 / 17 AUG 10

Applicable to: ALL

Setting at least one thrust lever to the TOGA detent engages both SRS /NAV modes, if:

- The flaps lever is at least in position 1, and
- The aircraft is in flight, or
- The aircraft has been on ground for less than 30 s (AP disengages and can be re-engaged 5 s after lift-off).

FD bars are automatically restored in SRS /NAV modes. If FPV /FPD was previously selected, it reverts to FD bars.

The FMA displays “SRS ” and “NAV” in green.

## DISENGAGEMENT CONDITIONS

Ident.: DSC-22\_30-80-40-00012220.0028001 / 17 AUG 10

Applicable to: ALL

The SRS mode disengages:

- Automatically, at the Go-around acceleration altitude (GA ACC ALT ), or if ALT \* mode engages (above 400 ft RA)
- If the flight crew engages another vertical mode
- If the flight crew selects a speed while in SRS mode: SRS reverts to OP CLB mode and a triple-click aural warning is heard.

*Note:* In Engine Out conditions, the SRS mode does not automatically disengage at EO ACC ALT. Refer to DSC-22\_20-60-40 General.

GA TRK disengages when the flight crew engages another lateral mode, above 100 ft RA.

*Note:* In dual AP configuration, disengagement of the Go-around mode on either axis causes AP2 to disconnect.


**GUIDANCE**

Ident.: DSC-22\_30-80-40-00012213.0009001 / 16 MAR 11

Applicable to: **ALL**

The SRS law maintains the current speed at Go-around engagement, or VAPP, whichever is higher. Nevertheless, the SRS speed target is limited to VLS +25 kt, in a two-engine configuration, and VLS +15 kt, in an engine-out configuration. When the SRS mode disengages, the target speed becomes the smaller of green dot speed or speed constraints.

GA TRK mode guides the aircraft along the current track at Go-around initiation.



**GENERAL**

Ident.: DSC-22\_30-90-00011930.0001001 / 17 MAR 17

Applicable to: ALL

The autothrust (A/THR ) is a function of the FMGS , it includes two independent A/THR commands, one per FMGC . Each one is able to control the thrust of both engines simultaneously through two Engine Interface Units and two Electronic Engine Controls (IAE engines) or two Engine Control Units (CFM engines). Only one FMGC controls the active A/THR , it is called the master FMGC.

Thrust is controlled:

- Automatically when the A/THR is active
- Manually by the flight crew.

The autothrust is active when the A/THR pb of the FCU is lighted green and A/THR is displayed white in the FMA 5th column.

The position of the thrust levers determines whether A/THR is armed, active, or disconnected.

The autothrust system, when active:


- Maintains a specific thrust in THRUST mode
- Controls the aircraft speed or Mach in SPEED/MACH mode
- Uses ALPHA FLOOR mode to set maximum thrust when the aircraft angle of attack exceeds a specific threshold.

The autothrust system can operate independently or with the AP /FD:

- When performing alone, A/THR always controls the speed
- If the autothrust system is working with the AP /FD , the A/THR mode and AP /FD pitch modes are linked together. *Refer to DSC-22\_30-10 Interaction between AP/FD and A/THR Modes.*

When autothrust is active, the FMGS commands the thrust according to the vertical mode logic, but uses a thrust not greater than the thrust commanded by the position of the thrust lever. For example, when the thrust levers are set at the CL (climb) detent, FG can command thrust between idle and max climb.

The autothrust system, when armed, automatically activates if the thrust levers are moved into the active range sector. Outside of this range, thrust levers control thrust directly.



**THRUST LEVERS**

Ident.: DSC-22\_30-90-00011957.0001001 / 23 JUN 15

Applicable to: ALL

The flight crew uses the thrust levers to do the following:


- Manually select engine thrust
- Arm and activate autothrust (A/THR)
- Engage reverse thrust
- Engage the takeoff and go-around modes.

When autothrust is disconnected, the thrust levers control thrust directly: each lever position corresponds to a given thrust.

Five detents divide each of the thrust lever sectors into four segments. The detents are:

- TO GA : Max takeoff thrust
- FLX MCT : Max continuous thrust (or FLX at takeoff)
- CL : Maximum climb thrust
- IDLE : Idle thrust for both forward and reverse thrust
- MAX REV : Maximum reverse thrust

When the thrust levers are at the IDLE position, the flight crew can pull them up to clear the IDLE stop and select reverse thrust. (There is no reverse detent as such).



### A/THR ARMING CONDITIONS

Ident.: DSC-22\_30-90-00011958.0001001 / 23 JUN 15

Applicable to: ALL

Arming conditions of the A/THR are numerous. The following is a list of the most important ones:

- One FMGC operative
- One FAC operative
- Two ADIRS operative
- Two FADECs operative
- One channel of the FCU operative
- One LGCIU operative
- A/THR is not manually disabled (instinctive disconnect pb has not been pressed for more than 15 s).

The flight crew arms A/THR:

- On ground
  - By pushing the A/THR pb on the FCU when the engines are not running, or
  - By setting the thrust levers at the FLX or TOGA detent when the engines are running.
- In flight
  - By pushing the A/THR pb on the FCU while the thrust levers are out of the active range, or
  - While A/THR is active (“A/THR ” white on the FMA ), by setting all thrust levers beyond the CL detent or at least one lever above the MCT detent, or
  - By engaging the go around mode.

When the A/THR is armed:

- The FCU's A/THR pb light comes on
- “A/THR ” is displayed in blue on the FMA.



**Note:** At takeoff, if the thrust levers are set back to idle, the A/THR disengages and cannot be rearmed until the aircraft becomes airborne.

## A/THR ACTIVATION

Applicable to: ALL

Ident.: DSC-22\_30-90-A-00011959.0001001 / 14 MAY 12

### GENERAL

The A/THR is active when it controls thrust or speed. The position of the thrust lever determines the maximum thrust that the A/THR system can command (except in  $\alpha$ -floor condition).

The A/THR being armed, is activated:

- When the flight crew sets both thrust levers between the CL and IDLE detents (two engines operative), or
- When the flight crew sets one thrust lever between the MCT and IDLE detents (one engine inoperative).

The A/THR being disconnected, is activated when the flight crew pushes the A/THR pb on the FCU while the thrust levers are within the active range, including IDLE position.

*Note: When the flight crew sets both thrust levers to IDLE position, the A/THR disconnects but, if the flight crew pushes the A/THR pb of the FCU, they will simultaneously arm and activate the autothrust. Due to the thrust levers position, IDLE thrust will be maintained.*

When ALPHA FLOOR is activated, regardless of the initial status of A/THR and the position of the thrust levers, the A/THR activates.

When A/THR is active:

- The A/THR pb on the FCU lights up
- The FMA displays A/THR mode in green in the first column and "A/THR" in white in the fifth column.



ident.: DSC-22\_30-90-A-00011960.0002001 / 16 MAR 11

## **EFFECTS OF THRUST LEVER MOVEMENT DURING A/THR ACTIVATION**

While A/THR is active:

- When both thrust levers are set above the CL detent (both engines operative) or one thrust lever is set above MCT (one engine operative), the A/THR reverts from active to armed. "A/THR" turns to blue on the FMA and the thrust levers control thrust directly.

The FMA displays "MAN THR" in white in its first column.

The thrust levers provide the flight crew with an immediate increase of thrust when both thrust levers are pushed above the CL detent (two engines) or the active thrust lever above the MCT detent (one engine operative).

- When both thrust levers are set below the CL detent (both engines operative) or one thrust lever is set below MCT (one engine operative), a repeating warning (amber caution, single chime, "A/THR LIMITED" ECAM message) is activated every 5 s until the flight crew moves the lever back into the detent. "LVR CLB" (both engines operative) or "LVR MCT" (one engine operative) flashes white in the first column of the FMA.

This device reminds the flight crew that the normal operating position of the thrust levers, when A/THR active, is the CL detent (two engines) or the MCT detent (one engine operative).

- When one thrust lever is in the CL detent and the other one out of detent, the "LVR ASYM" amber message comes up until both levers are set in the CL detent (only with both engines operative).

## **A/THR DISCONNECTION**

Applicable to: ALL

ident.: DSC-22\_30-90-B-00011961.0001001 / 17 AUG 10

### **GENERAL**

When the A/THR is disconnected, it is neither armed nor active.

The A/THR can be disconnected in two ways:

- Standard disconnection:
  - The flight crew pushes the instinctive disconnect pb on the thrust levers, or
  - The flight crew sets both thrust levers to IDLE detent.
- Non-standard disconnection:
  - The flight crew pushes the A/THR pb on the FCU while A/THR is active/armed, or
  - The system loses one of the arming conditions.



**CAUTION**

If the flight crew pushes and holds one instinctive disconnect pb for more than 15 s, the A/THR system is disconnected for the remainder of the flight. All A/THR functions including ALPHA FLOOR are lost, and they can be recovered only at the next FMGC power-up (on ground).

**THRUST LOCK FUNCTION**

Ident.: DSC-22\_30-90-00011963.0002001 / 17 AUG 10

Applicable to: **ALL**

The Thrust Lock function is activated when the thrust levers are in the CL detent (or the MCT detent with one engine out), and:

- The flight crew pushes the A/THR pb on the FCU, or
- The A/THR disconnects due to a failure.

The thrust is locked at its level prior to disconnection. Moving the thrust levers out of CL or MCT suppresses the thrust lock and gives the flight crew manual control with the thrust levers.

When the Thrust Lock function is active:

- "THR LK" flashes amber on the FMA
- ECAM "ENG THRUST LOCKED" flashes every 5 s
- ECAM displays "THR LEVERS.....MOVE"
- A single chime sounds and the Master Caution light flashes every 5 s.

All warnings cease when the flight crew moves the thrust levers out of the detent.

**A/THR DISCONNECTION CAUTION**


Ident.: DSC-22\_30-90-00011964.0002001 / 17 AUG 10

Applicable to: ALL

		A/THR DISCONNECTION	
		BY INSTINCTIVE DISCONNECT pb OR SETTING TWO LEVERS TO IDLE (if above 50 ft RA)	BY OTHER MEANS
CONSEQUENCE	MASTER CAUTION light	Illuminated 3 s maximum	Illuminated
	ECAM MESSAGE	A/THR OFF amber message 9 s maximum	Flashing <b>ENG THRUST LOCKED</b> amber caution, <b>AUTO FLT A/THR OFF</b> amber caution, blue "THR LEVERS....MOVE"
	AUDIO	Single chime	Single chime
	CLR pb on ECAM CONTROL PANEL	Extinguished	Illuminated
ACTION	MASTER CAUTION light	- Extinguishes MASTER CAUTION light - Erases ECAM message	Extinguishes MASTER CAUTION light
	CLR pb on ECAM CONTROL PANEL	No effect	- Extinguishes MASTER CAUTION light and CLR pb - Erases ECAM message - Calls status
	INSTINCTIVE DISCONNECT pb	- Extinguishes MASTER CAUTION light - Erases ECAM message	Extinguishes MASTER CAUTION light
ECAM STATUS MESSAGE		NO	YES

The standard disconnection triggers temporary ECAM message and caution light. Single chime sounds.

The non standard disconnection triggers caution light and ECAM message removed only by a flight crew action. Single chime sounds.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT GUIDANCE</b>  AUTOTHRUST
---	---

## A/THR MODES

Applicable to: ALL



Ident.: DSC-22\_30-90-C-00011965.0002001 / 23 JUN 15

### GENERAL

Except in takeoff and go-around situations, normal operation of the A/THR system requires the thrust levers to be:

- In the CL detent for the two-engine configuration. If they are not set in the CL detent, “LVR CLB ” flashes white on the FMA.
- In MCT detent when in the one-engine-out configuration. If the appropriate lever is not set in the MCT detent, “LVR MCT ” flashes white on the FMA.

The A/THR modes are selected automatically in conjunction with the AP /FD modes (except for ALPHA FLOOR):

A/THR in THRUST mode	AP /FD pitch mode maintains the speed: OP CLB - OP DES - CLB - EXP CLB  - EXP DES  - SRS - FLARE and DES (IDLE path)
A/THR in SPEED/MACH mode	If neither AP nor FD is engaged If AP /FD controls a vertical path: V/S - FPA - ALT * - ALT CST* - ALT - ALT CRZ - G/S * - G/S - FINAL and DES (geometric path)
A/THR in RETARD mode	AP /FD engaged in LAND mode during an automatic landing

Ident.: DSC-22\_30-90-C-00011966.0002001 / 23 JUN 15

### THRUST MODE

In THRUST mode, autothrust commands a specific thrust level in conjunction with the AP /FD pitch mode. This thrust level is limited by thrust lever position.

FMA Display	Meaning
THR MCT	Single engine thrust in climb. The live engine is at maximum continuous thrust (thrust lever in MCT detent)
THR CLB	Climb thrust in two engine configuration (at least one thrust lever in the CL detent, the other one below CL)
THR LVR	Undetermined thrust (neither CLB nor MCT thrust)
THR IDLE	Minimum thrust (both engines at IDLE thrust)

*Note:* When the A/THR is armed for takeoff or go-around, the FMA displays “MAN TOGA ” (or “MAN FLX”) in white to remind the flight crew that the thrust levers have been positioned properly.

Ident.: DSC-22\_30-90-C-00011967.0001001 / 27 JAN 12

## **RETARD MODE**

The RETARD mode is only available during automatic landing (AP engaged in LAND mode). At approximately 40 ft RA, the RETARD mode engages and remains engaged after touchdown. The A/THR commands IDLE thrust during the flare, and the FMA and engine warning display "IDLE". If the autopilot is disengaged during the flare before touchdown, the SPEED mode replaces the RETARD mode, and the flight crew has to manually reduce thrust.

*Note: In an automatic landing, the system generates a "RETARD" callout at 10 ft RA, which prompts the flight crew to move the thrust levers to IDLE in order to confirm thrust reduction. In manual landing conditions, the system generates this callout at 20 ft RA, as a reminder.*

Ident.: DSC-22\_30-90-C-00011968.0002001 / 17 AUG 10

## **ALPHA FLOOR**

ALPHA FLOOR is a protection that commands TOGA thrust, regardless of the thrust levers' positions. This protection is available from lift-off to 100 ft RA on approach.

ALPHA FLOOR calls up the following indications:

- "A FLOOR" in green, surrounded by a flashing amber box on the FMA, and in amber on the engine warning display, (as long as  $\alpha$ -floor conditions are met)
- "TOGA LK" in green, surrounded by a flashing amber box on the FMA, when the aircraft leaves the  $\alpha$ -floor conditions. TOGA thrust is frozen.

To cancel ALPHA FLOOR or TOGA LK thrust, the flight crew must disconnect the autothrust.

Ident.: DSC-22\_30-90-C-00011969.0001001 / 17 AUG 10

## **SPEED/MACH MODE**


In SPEED/MACH mode, the A/THR adjusts the thrust in order to acquire and hold a speed or Mach target.

The speed or Mach target may be:

- Selected on the FCU by the flight crew
- Managed by the FMGC.

When in SPEED/MACH mode, the A/THR does not allow speed excursions beyond the following limits, regardless of the target speed or Mach number:

- For a selected speed target, the limits are VLS and VMAX (VMO -MMO, VFE -VLE, whichever applies)
- For a managed speed target, the limits are maneuvering speed (Green Dot, S, F, whichever applies) and maximum speed (340/0.80-VFE -VLE, whichever applies).

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>AUTO FLIGHT - FLIGHT GUIDANCE</b></p> <p align="center">AUTOTHURST</p>
---	---

The changeover from SPEED to MACH mode is either automatic, performed by the FMGC, or manual, with the flight crew pushing the SPD/MACH pb.  
The FMA displays "SPEED" or "MACH".

**APPROACH AUTOTHURST:**

Below 3 200 ft RA , with at least CONF 1, the A/THR logic is modified to be more responsive to speed variation. This is referred to as approach autothrust.

**SPEED MODE IN APPROACH PHASE**

**Applicable to:** ALL

Ident.: DSC-22\_30-90-D-00011970.0001001 / 17 AUG 10

**GENERAL**

When the aircraft flies an approach in managed speed, the speed target displayed on the PFD in magenta is variable during the approach.  
This managed speed target is computed in the FMGS using the "ground speed mini function".

Ident.: DSC-22\_30-90-D-00011971.0002001 / 17 MAR 17

**GROUND SPEED MINI FUNCTION PRINCIPLE**

The purpose of the "ground speed mini function" is to take advantage of the aircraft inertia when the wind conditions vary during the approach. It does so by providing the flight crew with an adequate indicated speed target. When the aircraft flies this indicated speed target, the energy of the aircraft is maintained above a minimum level ensuring standard aerodynamic margins versus stall.

If the A/THR is active in SPEED mode, it will automatically follow the IAS target, ensuring an efficient thrust management during the approach.

The minimum energy level is the energy level the aircraft will have at touch down if it lands at VAPP speed with the tower reported wind as inserted in the PERF APPR page.

The minimum energy level is represented by the Ground Speed the aircraft will have at touch down. This Ground Speed is called "GROUND SPD MINI".

During the approach, the FMGS continuously computes the speed target using the wind experienced by the aircraft in order to keep the ground speed at or above the "Ground Speed Mini".

The ground speed mini enables an efficient management of the thrust in gusts or longitudinal shears. Thrust varies in the right sense, but in a smaller range ( $\pm 15\%$  N1) in gusty situations, which explains why it is recommended in such situations.

It provides additional but rational safety margins in shears.

It allows pilots "to understand what is going on" in perturbed approaches by monitoring the target speed magenta bugs: when target goes up = head wind gust.

The speed target is displayed on the PFD speed scale in magenta when approach phase and managed speed are active. It is independent of the AP /FD and/or A/THR engagements. Wind is a key factor in the "ground speed mini function".

Ident.: DSC-22\_30-90-D-00011972.0001001 / 17 AUG 10

### **TWR WIND**

It is the MAG WIND entered in the PERF APPR page. It is the average wind as provided by the ATIS or the tower. Gusts must not be inserted, they are included in the ground speed mini computation.

Ident.: DSC-22\_30-90-D-00011973.0001001 / 17 AUG 10

### **TWR HEADWIND COMPONENT**

The TWR HEADWIND COMPONENT is the component of the MAG WIND projected on the runway axis (landing runway entered in the flight plan). It is used to compute VAPP and GS mini.

Ident.: DSC-22\_30-90-D-00011974.0001001 / 17 AUG 10

### **CURRENT HEADWIND COMPONENT**

The actual wind measured by ADIRS is projected on the aircraft axis to define the CURRENT HEADWIND COMPONENT (instantaneous headwind).

The CURRENT HEADWIND COMPONENT is used to compute the variable speed target during final (IAS target).

Ident.: DSC-22\_30-90-D-00011975.0002001 / 17 AUG 10

### **VAPP COMPUTATION**

VAPP, automatically displayed on the MCDU PERF APPR page, is computed as follows:

- $VAPP = VLS + 1/3$  of the TWR HEADWIND COMPONENT, or
- $VAPP = VLS + 5$  kt, whichever is the highest.

"1/3 of the TWR HEADWIND COMPONENT" has two limits:

- 0 kt as the minimum value (no wind or tailwind)
- +15 kt as the maximum value.

The flight crew can manually modify the VAPP and TWR wind values on the PERF APPR page.

Ident.: DSC-22\_30-90-D-00011976.0002001 / 01 OCT 12

### **SPEED TARGET COMPUTATION**

The FMGS continuously computes a speed target (IAS target) that is the MCDU VAPP value plus an additional variable gust.



The gust is the instantaneous difference between the CURRENT HEADWIND COMPONENT and the TWR HEADWIND COMPONENT. It is always positive (or equal to zero for no wind or tailwind).

The IAS target is displayed on the PFD as a magenta triangle moving with the gust variation.

The IAS targets have 2 limits:

- VAPP, as the minimum value
- VFE -5 kt in CONF FULL, or VFE of the next configuration in CONF 1, 2 or 3 as the maximum value.

Ident.: DSC-22\_30-90-D-00011977.0001001 / 17 MAR 17

### **GROUND SPEED MINI (GS MINI) COMPUTATION**

Ground speed mini concept has been defined to prevent the aircraft energy from dropping below a minimum level during final approach. The GS mini value is not displayed to the flight crew.


This minimum energy level is the energy the aircraft will have at landing with the expected tower wind; it is materialized by the ground speed of the aircraft at that time which is called GS mini:

$$\text{GS mini} = \text{VAPP} - \text{Tower head wind component}$$


In order to achieve that goal, the aircraft ground speed should never drop below GS mini in the approach, while the winds are changing. Thus the aircraft IAS must vary while flying down, in order to cope with the gusts or wind changes. In order to make this possible for the pilot or for the A/THR, the FMGS continuously computes an IAS target speed, which ensures that the aircraft ground speed is at least equal to GS mini; the FMGS uses the instantaneous wind component experienced by the aircraft:

$$\text{IAS Target Speed} = \text{GS mini} + \text{Current headwind component}$$

This target speed is limited by VAPP in case of tailwind or if instantaneous wind is lower than the tower wind.









**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT GUIDANCE**

AUTOTHURST

Intentionally left blank

**FLIGHT MODE ANNUNCIATOR (FMA)**


Applicable to: ALL

Ident.: DSC-22\_30-100-A-00012356.0012001 / 19 DEC 12

**GENERAL**

The Flight Mode Annunciator (FMA) which is just above the PFDs, shows the status of the A/THR, the AP/FD vertical and lateral modes, the approach capabilities, and the AP/FD-A/THR engagement status.

A white box is displayed for 10 s around each new annunciation. The white box display time may be increased to 15 s in some mode reversion cases associated with an aural triple click.



Ident.: DSC-22\_30-100-A-00012357.0002001 / 17 AUG 10

**THE THREE LEFT COLUMNS**

The first line shows the engaged modes in green.

The second line shows the armed modes in blue or magenta.

Magenta indicates that the modes are armed or engaged because of a constraint.

The third line displays special messages:

- Messages related to flight controls have first priority:
  - “MAN PITCH TRIM ONLY” in red, flashing for 9 s, then steady
  - “USE MAN PITCH TRIM” in amber, pulsing for 9 s, then steady.
- Messages related to the FMGS have second priority.

Ident.: DSC-22\_30-100-A-00012358.0014001 / 16 MAR 11

**THE FOURTH COLUMN**

Displays approach capabilities in white.

Displays minimum in blue.

*Note:* The BARO or RADIO value on the FMA is not rounded off. The exact value appears on the FMA, and is the same value as the one inserted in the MCDU PERF APPR page.

Ident.: DSC-22\_30-100-A-00012359.0001001 / 17 AUG 10

**THE FIFTH COLUMN**

Displays the engagement status of AP, FD, and A/THR in white.

Displays a box around FD for 10 s in case of automatic FMGC switching.

Displays A/THR in blue when autothrust is armed but not active.

*Note:* The FMGS synchronizes A/THR mode, AP/FD modes and approach capability to provide identical information on both PFDs.


**AUTOTHROUST ANNUNCIATIONS (FMA COLUMN 1)**

Applicable to: ALL

Ident.: DSC-22\_30-100-B-00012360.0002001 / 23 JUN 15

**FIRST LINE**

DISPLAY	COLOR	MEANING
MAN TOGA	White White box	A/THR is armed, at least one thrust lever is in TOGA detent.
MAN FLX XX	White White box Blue numbers	A/THR is armed, at least one thrust lever is in MCT/FLX detent with FLXTO temp set at XX°. The other thrust lever is at or below the MCT/FLX detent.
MAN MCT	White White box	A/THR is armed, at least one thrust lever is in the MCT/FLX detent, the other is at, or below this detent.
MAN THR	White Amber box	A/THR is armed, and the most advanced thrust lever is above CL detent (two engines operative), or one above MCT/FLX (engine-out) and not in a detent.
THR MCT	Green	A/THR is active in thrust mode and the most advanced thrust lever is in the MCT/FLX detent (engine-out).
THR CLB	Green	A/THR is active in thrust mode and the most advanced thrust lever is in the CL detent.
THR IDLE	Green	A/THR is active in thrust mode and commands idle thrust.
THR LVR	Green	A/THR is active in thrust mode with both thrust levers below CL detent, or the live thrust lever (one engine) below MCT.
SPEED or MACH	Green	A/THR is active in SPEED or MACH mode.
A. FLOOR	Green Amber box	A/THR is active and commands TOGA thrust while $\alpha$ FLOOR conditions are met.
TOGA LK	Green Amber box	A/THR is active and TOGA thrust is locked ( $\alpha$ FLOOR conditions are no longer met).

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT GUIDANCE</b> FLIGHT MODE ANNUNCIATOR (FMA)
---	--

Ident.: DSC-22\_30-100-B-00012361.0002001 / 17 AUG 10

### **SECOND LINE**

Not used with this standard.

Ident.: DSC-22\_30-100-B-00012362.0002001 / 16 NOV 15

### **THIRD LINE**

DISPLAY	COLOR	MEANING
LVR CLB (flashing)	White	Request to set the thrust levers in CL detent in the case not in position while the aircraft is above the altitude of thrust reduction with both engines running.
LVR MCT (flashing)	White	Request to set the live thrust lever in MCT/FLX detent in the case not in position after an engine failure (with speed above green dot).
LVR ASYM	Amber	(Two engines only). One thrust lever in CL or MCT/FLX detent and the other one is not in this detent.
THR LK (flashing)	Amber	After A/THR disconnection (action of the flight crew on FCU or failure) resulting in thrust being frozen. Both thrust levers being in CL detent or one in MCT/FLX (engine out) detent.

*Note:* The amber caution light flashes and a single chime sounds every 5 s, as long as the flight crew takes no appropriate action in the following cases:

- THR LK
- LVR CLB (if the thrust levers are below the CLB detent)
- LVR MCT (if the thrust levers are below the FLX/MCT detent).

## AP/FD VERTICAL MODES (FMA COLUMN 2)

**Applicable to: ALL**

Ident.: DSC-22\_30-100-C-00012363.0006001 / 23 JUN 15

### **FIRST LINE**

DISPLAY	COLOR	MEANING
SRS	Green	Takeoff or go-around mode is engaged.
CLB	Green	Climb mode is engaged. The FMGS target altitude is higher than the actual altitude. ALT CSTR are taken into account.
OP CLB	Green	Open Climb mode is engaged. The FCU selected altitude is higher than the actual altitude. ALT CSTR are disregarded.
EXP CLB	Green	Expedite Climb is engaged. The selected altitude is higher than the actual altitude. Green dot speed is maintained, ALT CSTR are disregarded.
ALT* or ALT CST*	Green	ALT CAPTURE is engaged: - ALT * green in case of FCU selected altitude capture - ALT CST* green in case of ALT CSTR capture (vertical profile).

*Continued on the following page*

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - FLIGHT GUIDANCE

#### FLIGHT MODE ANNUNCIATOR (FMA)


*Continued from the previous page*

DISPLAY	COLOR	MEANING
ALT or ALT CST	Green	ALTITUDE HOLD mode is engaged: - ALT is green when the FCU selected altitude is held - ALT CST is green when an ALT CSTR is held (vertical profile).
ALT CRZ	Green	ALT mode is engaged and CRZ FL is held.
DES	Green	Descent mode is engaged. The FMGS target altitude is lower than the actual altitude. ALT CSTR are taken into account.
OP DES	Green	Open Descent mode is engaged. The FCU selected altitude is lower than the actual altitude. ALT CSTR are disregarded.
EXP DES	Green	Expedite Descent is engaged, the selected altitude is lower than the actual altitude. M 0.80 or 340 kt is maintained. ALT CSTR are disregarded.
G/S*	Green	Glide Slope capture mode is engaged.
G/S	Green	Glide Slope mode is engaged.
V/S±XXXX	Green + blue numbers	Vertical speed mode is engaged to acquire and hold the V/S selected on the FCU . ALT CSTR are disregarded. If the aircraft reaches VLS or VMAX and cannot maintain the target, the indication is boxed amber and flashes, and the target pulses.
FPA±XX	Green + blue numbers	Flight Path Angle mode is engaged to acquire and hold the FPA selected on the FCU . ALT CSTR are disregarded. If the aircraft reaches VLS or VMAX and cannot maintain the target, the indication is boxed amber and flashes, and the target pulses.

Ident.: DSC-22\_30-100-C-00012364.0002001 / 23 JUN 15

## SECOND LINE

DISPLAY	COLOR	MEANING
CLB	Blue	Climb mode is armed.
ALT	Blue or Magenta	Altitude mode is armed: - Blue when the target altitude is the FCU selected altitude - Magenta when the target altitude is an ALT CSTR.
DES	Blue	Descent mode is armed before the descent phase.
G/S	Blue	Glide Slope mode is armed.
FINAL	Blue	Final descent mode is armed.
ALT G/S	Blue/Blue	ALT and G/S modes are armed.
ALT G/S	Magenta/ Blue	ALT CST and G/S modes are armed.
ALT FINAL	Blue/Blue	ALT and FINAL modes are armed.
ALT FINAL	Magenta/ Blue	ALT CST and FINAL modes are armed.
DES G/S	Blue/Blue	DES and G/S modes are armed.
DES FINAL	Blue/Blue	DES and FINAL modes are armed.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - FLIGHT GUIDANCE</b> FLIGHT MODE ANNUNCIATOR (FMA)
---	--

Ident.: DSC-22\_30-100-C-00012365.0001001 / 17 AUG 10

### THIRD LINE

DISPLAY	COLOR	MEANING
SPEED SEL:XXX	Blue	Indicates a preset speed associated with the cruise or climb phase.
MACH SEL:XX	Blue	Indicates a preset Mach associated with the cruise or climb phase.

*Note:* These two messages use both the first and second columns (third line).

### AP/FD LATERAL MODES (FMA COLUMN 3)

Applicable to: ALL

Ident.: DSC-22\_30-100-D-00012366.0002001 / 16 MAR 11

### FIRST LINE

DISPLAY	COLOR	MEANING
RWY	Green	RWY mode is engaged.
RWY TRK	Green	RWY mode is engaged once airborne at or above 30 ft RA.
HDG	Green	HEADING mode is engaged.
TRK	Green	TRACK mode is engaged.
NAV	Green	NAV mode is engaged to guide the aircraft along the FM lateral F-PLN.
LOC*	Green	LOC capture mode is engaged.
LOC	Green	LOC track mode is engaged.
APP NAV	Green	NAV mode is engaged during a non-ILS approach.
GA TRK	Green	GO-AROUND TRACK mode is engaged.

Ident.: DSC-22\_30-100-D-00012367.0001001 / 17 AUG 10

### SECOND LINE

DISPLAY	COLOR	MEANING
NAV	Blue	NAV mode is armed.
LOC	Blue	LOC mode is armed.
APP NAV	Blue	NAV mode is armed for a non-ILS approach.

### AP/FD COMMON MODES (FMA COLUMNS 2 AND 3)

Ident.: DSC-22\_30-100-00012368.0002001 / 17 AUG 10

Applicable to: ALL

DISPLAY	COLOR	MEANING
LAND	Green	Land mode is engaged below 400 ft RA.
FLARE	Green	Flare mode is engaged.

*Continued on the following page*

*Continued from the previous page*

DISPLAY	COLOR	MEANING
ROLL OUT	Green	Roll out mode is engaged.
FINAL APP	Green	APP NAV and Final modes are engaged during a non-ILS approach.

**APPROACH CAPABILITIES (FMA COLUMN 4)**

**Applicable to: ALL**

Ident.: DSC-22\_30-100-E-00012369.0002001 / 17 AUG 10

**FIRST LINE**

DISPLAY	COLOR	MEANING
CAT 1	White	CAT 1 capability available.
CAT 2	White	CAT 2 capability available.
CAT 3	White	CAT 3 capability available.

Ident.: DSC-22\_30-100-E-00012370.0002001 / 17 AUG 10

**SECOND LINE**

DISPLAY	COLOR	MEANING
SINGLE	White	CAT 3 capability available, with FAIL PASSIVE condition.
DUAL	White	CAT 3 capability available, with FAIL OPERATIONAL condition.

Ident.: DSC-22\_30-100-E-00012371.0009001 / 16 MAR 11

**THIRD LINE**

DISPLAY	COLOR	MEANING
BARO XXXX	White Blue	Minimum Descent Altitude or Minimum Descent Height as inserted by the flight crew on the MCDU PERF APPR page.
RADIO XXX/NO DH	White Blue	Decision Height as inserted by the flight crew on the MCDU PERF APPR page. NO DH : when NO inserted on the MCDU PERF APPR page.

**AP/FD - A/THR ENGAGEMENT STATUS (FMA COLUMN 5)**

**Applicable to: ALL**

Ident.: DSC-22\_30-100-F-00012372.0001001 / 17 AUG 10

**FIRST LINE**

DISPLAY	COLOR	MEANING
AP1 + 2	White	Autopilot 1 and 2 are engaged.
AP1	White	Autopilot 1 is engaged.
AP2	White	Autopilot 2 is engaged.



Ident.: DSC-22\_30-100-F-00012373.0002001 / 17 AUG 10

**SECOND LINE**

DISPLAY	COLOR	MEANING
X FD Y	White	X and Y give the FD engagement status on PFD 1 and PFD2.  X and Y can be 1, 2, or -: - -: No FD is engaged on the corresponding PFD - 1: FD 1 is engaged on the corresponding PFD - 2: FD 2 is engaged on the corresponding PFD.  The normal status (FD 1 and 2 engaged) is 1 FD 2.

Ident.: DSC-22\_30-100-F-00012374.0001001 / 17 AUG 10

**THIRD LINE**

DISPLAY	COLOR	MEANING
A/THR	White	A/THR is active.
A/THR	Blue	A/THR is armed.



**SPECIAL MESSAGES (FMA COLUMNS 2 AND 3)**

Ident.: DSC-22\_30-100-00012539.0033001 / 05 NOV 15

**Applicable to: ALL**

The third line displays three types of messages:

- It gives first priority to Flight Control messages
- It gives second priority to vertical Flight Management messages
- It gives last priority to EFIS reconfiguration messages.

DISPLAY	COLOR	MEANING
MAN PITCH TRIM ONLY	Red	Displayed in case of loss of L+R elevators.
USE MAN PITCH TRIM	Amber	F/CTL are in direct law.
DISCONNECT AP FOR LDG	Amber	This message is displayed when, during a Non Precision Approach, the AP /FD remains engaged at: - Minimum minus 50 ft, or - 400 ft AGL (if no minimum entered)  This message is a reminder to the flight crew that AP must be disconnected before landing.
CHECK APPR SELECTION	White	The aircraft is in cruise at less than 100 NM from the Top of Descent or in descent or in approach and: - A non-ILS /non-GLS  approach has been selected - An ILS frequency/GLS  channel is tuned on the MCDU RAD NAV page.

*Continued on the following page*

*Continued from the previous page*

DISPLAY	COLOR	MEANING
SET MANAGED SPEED or CHECK SPEED MODE (Also displayed on PFD)	White	The SPEED target is selected but a preselected SPEED does not exist for the next flight phase.
SET GREEN DOT SPEED	White	The aircraft is in Engine Out mode and the SPEED target is selected. This message is displayed if the FCU selected speed is: ≤ Green Dot -10 kt, or ≥ Green Dot +10 kt, except in ALT * and ALT mode.
SET HOLD SPEED	White	The aircraft is in selected SPEED control, a Holding pattern is inserted in the F-PLN and the aircraft is 30 s before the deceleration point to the precomputed HOLD SPEED.
DECELERATE or T/D REACHED (Also displayed on PFD)	White	This message is displayed if the thrust is not reduced when passing the top of descent and the aircraft is above the descent profile.
MORE DRAG	White	DES mode is engaged, idle is selected, and either: - The aircraft is above the vertical profile and the predicted intercept point of the theoretical profile is at less than 2 NM from the next ALT CSTR, or - In auto speed control and the aircraft enters a speedbrake decelerating segment.

**CAT 3 DUAL INOPERATIVE**

Ident.: DSC-22\_30-110-00012674.0001001 / 28 JUN 17

**Applicable to: ALL**

"CAT 3 DUAL" INOP SYS is triggered in particular if one ADR or IR is rejected by FAC or FMGC.  
If "CAT 3 DUAL" is displayed in INOP SYS without any other failure being detected:

CHANGE the AP in command. It may allow the CAT 3 DUAL function to be recovered.

If unsuccessful:

SET FAC 1 pb to OFF, and back to ON

WAIT for FAC 1 fault ECAM warning to disappear, and

APPLY the same sequence for FAC 2.

- Note:
1. Do not reset the FACs with the C/Bs.
  2. If the CAT 3 DUAL INOP SYS is associated to another ECAM message (in particular ADR FAULT or IR FAULT...), it means that the root cause is not an ADR or IR rejection by FAC or FMGC. And consequently the AP switch or FAC reset will not clear the CAT 3 DUAL inop.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT GUIDANCE**

TEMPORARY ABNORMAL BEHAVIORS

Intentionally left blank

# **AIRCRAFT SYSTEMS**

AUTO FLIGHT - FLIGHT AUGMENTATION

Intentionally left blank

**DSC-22\_40-10 General**

GENERAL..... A

**DSC-22\_40-20 Yaw Functions**

YAW DAMPING..... A  
RUDDER TRIM..... B  
RUDDER TRAVEL LIMITATION..... C

**DSC-22\_40-30 Flight Envelope Function**

GENERAL..... A  
PFD Speed Scale Management..... B  
Alpha-Floor Protection..... C  
Low - Energy Aural Alert..... D

**DSC-22\_40-40 Windshear Detection Function**

Windshear Detection Function..... A  
WINDSHEAR DETECTION PRINCIPLES..... B  
GUIDANCE..... C

**DSC-22\_40-50 Controls and Indicators**

FAC ENGAGEMENT..... A  
RUDDER TRIM OPERATION..... B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - FLIGHT AUGMENTATION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank





**GENERAL**

Ident.: DSC-22\_40-10-00000840.0001001 / 24 FEB 15

Applicable to: ALL

The aircraft has two flight augmentation computers (FACs) that perform four main functions:

- Yaw function
  - Yaw damping and turn coordination
  - Rudder trim
  - Rudder travel limitation
- Flight envelope function
  - PFD speed scale management
    - Minimum/maximum speed computation
    - Maneuvering speed computation
  - Alpha-floor protection
- Low-Energy Aural Alert function 
- Windshear detection function 

In performing these functions the FAC uses independent channels :

Yaw damper  
Rudder trim  
Rudder travel limit  
Flight envelope

Each FAC interfaces with the elevator aileron computers (ELAC s) when the AP s are disengaged, or with the FMGS when at least one AP is engaged.

Both FACs engage automatically at power-up.

The pilot can disengage or reset each FAC (in case of failure) by means of a pushbutton on the flight control overhead panel.

When a FAC is disengaged (FAC pushbutton set off) but still valid, the flight envelope function of the FAC remains active.

If both FAC s are valid, FAC 1 controls the yaw damper, turn coordination, rudder trim, and rudder travel limit, and FAC2 is in standby.

FAC 1 keeps the aircraft within the flight envelope through FD 1 ; FAC 2 performs this function through FD2.

If a failure is detected on any channel of FAC 1, FAC2 takes over the corresponding channel.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT AUGMENTATION**

GENERAL

Intentionally left blank

### YAW DAMPING

Ident.: DSC-22\_40-20-00000851.0001001 / 18 MAR 11

Applicable to: ALL

Yaw damping stabilizes the aircraft in yaw and coordinates its turns.

In automatic flight (AP engaged) during takeoff and go around, it assists rudder application after an engine failure (short-term yaw compensation).

Note: When the AP is engaged, the FMGS sends orders to the FAC to give :

- Yaw damping during approach
- Yaw control for runway alignment in ROLL OUT mode

### RUDDER TRIM

Ident.: DSC-22\_40-20-00000855.0001001 / 09 DEC 09

Applicable to: ALL

The rudder trim function :

- Executes trim orders, entered by the pilot by using the manual trim knob.
- When AP is engaged
  - executes trim orders from the FMGS.
  - Assists the system in recovering from engine failure (long-term yaw compensation) in all flight guidance modes.
  - If the pilot pushes the rudder more than 10 ° out of trim, it disengages the AP.


Note: When the AP is engaged, the rudder trim knob is inoperative : the master FMGC sends rudder trim orders to the FAC.

### RUDDER TRAVEL LIMITATION

Ident.: DSC-22\_40-20-00000857.0001001 / 01 OCT 12

Applicable to: ALL

This function limits rudder deflection is based on speed in order to avoid high structural loads. It is governed by the following law :



If both FACs lose the rudder travel limitation function, the value of the rudder deflection limit is locked at the time of the second failure.

When the slats are extended, the FACs automatically set the rudder deflection limit at the low-speed setting (maximum authorized deflection).

**GENERAL**

Ident.: DSC-22\_40-30-00000859.0001001 / 09 DEC 09

**Applicable to: ALL**

As long as one Flight Augmentation Computer (FAC ) is valid, it governs the flight envelope function, the rudder position display, and the rudder trim indication regardless of what the flight crew does with the FAC pushbutton.

**PFD SPEED SCALE MANAGEMENT**

Ident.: DSC-22\_40-30-00000860.0001001 / 21 MAR 17

**Applicable to: ALL**

The FAC controls the speed scale on the PFD (*Refer to DSC-31-40 Attitude Data*).  
When both FAC s are operative, FAC 1 supplies data to PFD 1 and FAC 2 supplies it to PFD2.

The FAC computes:

- The minimum and maximum speeds:
  - VSW (stall warning)
  - VLS
  - VFE and VFE for the next configuration
  - VLE
  - VMO /MMO
- The maneuvering speeds:
  - Green Dot Speed
  - S speed
  - F speed

The FAC also computes the speed trend and displays it as an arrow on the PFD speed scale.  
The PFD displays these various speeds as appropriate, and they also go to the FMGC to be used as limits for various guidance modes.

Note: The principle of the speed computation is as follows:

- First, the FAC computes VS1G (stall speed). From VS1G it computes the Gross Weight (GW) which is also sent to the Elevator Aileron computers:
  - When the aircraft is below 14 500 ft and 250 kt, it computes this from current angle of attack, speed/Mach, altitude, thrust, and CG.
  - When the aircraft is above 14 500 ft or 250 kt, it computes this out of the GW, which it has memorized and updated with a fuel consumption model set in the FAC.
- Finally the FAC computes the various minimum and maneuvering speeds,  $V\alpha_{prot}$  and  $V_{sw}$ .
- The accuracies of the various minimum and maximum speeds are functions of the accuracy with which the FAC computes aircraft gross weight. Normal accuracy for VLS in CONFIG FULL is about  $\pm 3$  kt.

## ALPHA-FLOOR PROTECTION

Ident.: DSC-22\_40-30-00006198.0001001 / 17 MAR 17

Applicable to: ALL

Alpha-floor protection automatically sets the thrust at TOGA thrust, when the aircraft reaches a very high angle of attack.

The Flight Augmentation Computer (FAC) generates the signal that triggers the alpha-floor mode. This, in turn, sets TOGA thrust on the engines, regardless of the thrust lever positions (*Refer to DSC-22\_30-90 A/THR Modes - General*).

The FAC sends this signal when:

- The angle of attack is above a predetermined threshold, that is a function of the configuration.
- In CONF 3 and CONF FULL, this threshold decreases as a function of the aircraft deceleration rate (down to  $-3^\circ$ ).

Alpha-floor is available from lift-off until the aircraft reaches 100 ft RA in approach.

Note: The  $\alpha$  floor is activated through the A/THR system, when:

- $\alpha$  is greater than  $\alpha_{floor}$  ( $9.5^\circ$  in configuration 0;  $15^\circ$  in configuration 1, 2;  $14^\circ$  in configuration 3;  $13^\circ$  in configuration FULL), or
  - Sidestick deflection is greater than  $14^\circ$  nose up, with either the pitch attitude or the angle-of-attack protection active.
- The  $\alpha$  floor function is available from lift-off to 100 ft RA before landing.

- Note:
- *Alpha-floor is lost, when one of the following combinations of failures occurs:  
SFCC 1 and FAC2, or  
SFCC 2 and FAC1, or  
Both FCU channels, or  
1 EIU, or  
Both FMGCs.*
  - *Alpha-floor is lost under alternate or direct flight control law.*
  - *Alpha-floor is lost in engine-out, when slats/flaps are extended.*

### LOW - ENERGY AURAL ALERT

Ident.: DSC-22\_40-30-00006197.0001001 / 24 FEB 15

Applicable to: ALL

An aural low-energy “SPEED SPEED SPEED” alert, repeated every 5 s, warns the pilot that the aircraft’s energy level is going below a threshold under which he has to increase thrust, in order to regain a positive flight path angle through pitch control.

It is available in Configuration 2, 3, and FULL. The FAC computes the energy level with the following inputs:

- Aircraft configuration
- Horizontal deceleration rate
- Flight path angle.

The aural alert is inhibited when:

- TOGA is selected, or
- Below 100 ft RA, or
- Above 2 000 ft RA, or
- Alpha-floor, or the ground proximity warning system alert is triggered, or
- In alternate or direct law, or
- If both radio altimeters fail.

During deceleration, the low-energy aural alert is triggered before alpha floor (unless alpha floor is triggered by stick deflection). The amount of time between the two alerts depends on the deceleration rate.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT AUGMENTATION**

FLIGHT ENVELOPE FUNCTION

Intentionally left blank



## WINDSHEAR DETECTION FUNCTION

Ident.: DSC-22\_40-40-00006194.0001001 / 07 JUL 11

Applicable to: ALL

The windshear detection function is provided by the Flight Augmentation Computer (FAC) in takeoff and approach phase in the following conditions:

- At takeoff, 3 s after liftoff, up to 1 300 ft RA
- At landing, from 1 300 ft RA to 50 ft RA
- With at least CONF 1 selected.

The warning consists of:

- A visual "WINDSHEAR" red message displayed on both PFDs for a minimum of 15 s.
- An aural synthetic voice announcing "WINDSHEAR" three times.

## WINDSHEAR DETECTION PRINCIPLES

Ident.: DSC-22\_40-40-00006195.0001001 / 23 JUN 15

Applicable to: ALL

The FACs generate the windshear warning whenever the predicted energy level for the aircraft falls below a predetermined threshold.

In computing this energy level prediction, the FAC s use data from different sources. From ADIRS comes data such as vertical speed, air and ground speeds and slope ; from other sources come such derived parameters as total slope, longitudinal wind gradient, and vertical wind.

The FACs express this energy level as an angle of attack and compare it with an angle-of-attack threshold above which windshear conditions are most likely and pilot action is required.

## GUIDANCE

Ident.: DSC-22\_40-40-00006196.0001001 / 09 DEC 09

Applicable to: ALL

In windshear conditions, flight guidance acts on specially adapted FD pitch orders received from the speed reference system (SRS). The pilot must set go around thrust immediately (which also triggers the FD SRS mode), and follow the pitch order to execute the optimum escape maneuver.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT AUGMENTATION**

WINDSHEAR DETECTION FUNCTION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT AUGMENTATION**

CONTROLS AND INDICATORS

**FAC ENGAGEMENT**

Ident.: DSC-22\_40-50-00000861.0001001 / 09 DEC 09

**Applicable to: ALL**

*Refer to DSC-27-10-20 Yaw Control - General*

**RUDDER TRIM OPERATION**

Ident.: DSC-22\_40-50-00000862.0001001 / 09 DEC 09

**Applicable to: ALL**

*Refer to DSC-27-10-20 Yaw Control - General*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - FLIGHT AUGMENTATION**

CONTROLS AND INDICATORS

Intentionally left blank

# **AIRCRAFT SYSTEMS**

## AUTO FLIGHT - AOC FUNCTIONS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**AUTO FLIGHT - AOC FUNCTIONS**

PRELIMINARY PAGES - TABLE OF CONTENTS

General.....	A
Flight Plan Initialization Function.....	B
Takeoff Data Function.....	C
Wind Data Function.....	D
Flight Reports.....	E



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


## AIRCRAFT SYSTEMS

### AUTO FLIGHT - AOC FUNCTIONS

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>AUTO FLIGHT - AOC FUNCTIONS</b>
---	---

**GENERAL**

Ident.: DSC-22\_45-00000864.0001001 / 18 MAR 11  
**Applicable to: ALL**

The FMS AOC function gives an interface between a ground station and one onboard FMGC , allowing data transmission between these two computers via the ACARS Management Unit or the ATSU.

- Two different sets of message can be exchanged:
- UPLINK messages from the ground station. They consist in reception of data requested or directly sent to the crew.
  - DOWNLINK messages from the FMGC (master). They consist in reports or requests sent to the ground station.

The FMGS /ACARS or FMGS /ATSU interface enables the following AOC capabilities.

- F-PLN initialization (flight plan and performance data)
- Takeoff data
- Wind data
- Flight reports
- Broadcast data

Crews can send message using ACARS FUNCTION pages or relevant MCDU pages. Only one FMGC talks to the ground station. This FMGC is called FMGC “master”.

**GENERAL SCRATCHPAD MESSAGES**

- NOT XMITTED TO ACARS: A crew request or report was sent to the ground but the communication was not established or not acknowledged.
- NO ANSWER TO REQUEST : A crew request was previously sent to the ground and no answer (uplink message) was received within 4 min.

**FLIGHT PLAN INITIALIZATION FUNCTION**


Ident.: DSC-22\_45-00000865.0001001 / 18 MAR 11  
**Applicable to: ALL**

This function enables lateral and vertical flight plan data as well as initialization data to be exchanged between the aircraft and a ground station. The aircraft may send flight plan requests for active and secondary flight plan. (downlink messages). The ground station may send flight plan and initialization data (uplink messages) either under aircraft request or automatically without any request. Each uplink message concerns either the active or secondary flight plan but never both flight plans at the same time. The data sent to the aircraft are checked for flight plan consistency. A MCDU message comes up when an uplink message is received. “ACT (or SEC ) RTE UPLINK”.

If an error prevents the decoding process of the message, “INVALID RTE UPLINK” is displayed on MCDUs.

An uplink message can be routed to the active flight plan if no engine is started and no active flight plan exists. Otherwise, it is routed to the secondary. The crew will insert it into the secondary flight plan or will reject it using the CLR key.

*Note:* The flight plan may also be initialized using the ACARS FUNCTION page selected from DATA INDEX page.



**PERFORMANCE DATA**

On ground and before engine start, the ground station may also send performance data to the aircraft.

Performance data are always associated with the uplink flight plan. It is either automatically inserted with the active flight plan data, or stored in the secondary with the corresponding flight plan.

This message contains part or all of the following data:

ZFW, ZFWCG, taxi fuel, block fuel, cruise flight level, tropopause altitude, cruise temperature, transition altitude, cost index, performance factor.

*Note:* After engine start an uplink performance data message is rejected automatically without any scratchpad message.

**SCRATCHPAD MESSAGES RELATED TO FLIGHT PLAN AND PERFORMANCE**

- INVALID RTE UPLINK     An error is detected, the uplink message is rejected.
- ACT or SEC RTE UPLINK     A F-PLN is stored in the active or secondary flight plan.

FLT NUMBER UPLINK	FLT NBR has been initialized within a F-PLN message without previous request.
CHECK FLT NUMBER	The uplinked FLT NBR differs from the one specified in the request.
CHECK CO RTE	The uplinked CO RTE ident differs from the one specified in the request.
INVALID FLT NBR UPLINK	The uplink contains a valid F-PLN but the FLT NBR is invalid.
PERF DATA UPLINK	Performance data is received
INVALID PERF UPLINK	Performance uplink message has been rejected
RTE DATALINK IN PROG	A flight plan modification is performed after a F-PLN INIT request has been sent; this message is displayed until the uplink is received.
UPLINK INSERT IN PROG	This message is displayed during insertion of a Flight Plan.

**TAKEOFF DATA FUNCTION**

Ident.: DSC-22\_45-00000866.0001001 / 18 MAR 11

**Applicable to: ALL**


The takeoff data function is available for the active flight plan only. It is used to request to the ground station, information data for up to 2 runways and to receive this data for up to 4 runways. The crew sends a request indicating the departure airport, runway idents, CG , GW and weather conditions (such as BARO setting wind, temperature...). In response he receives the takeoff speeds for up to 4 runways but only one set of data may be inserted in the active flight plan for the selected active runway.

Takeoff speeds are computed for max and flex takeoff.

The takeoff data function has required the modification of the standard PERF TAKEOFF page and the addition of 2 news pages:

- UPLINK TO DAT REQ page that enables the crew to specify a request to the ground.
- UPLINK XXX TO DATA page (XXX for MAX or FLEX)

These 2 pages are accessed from the PERF TAKEOFF page in PREFLIGHT and DONE phase only.



**SCRATCHPAD MESSAGES RELATED TO TAKEOFF DATA**

- TAKEOFF DATA UPLINK : Takeoff data uplink message is received
- INVALID TAKEOFF : The UPLINK message is rejected
- UPLINK

**WIND DATA FUNCTION**

Ident.: DSC-22\_45-00000867.0001001 / 18 MAR 11

Applicable to: **ALL**

This function enables the crew to request and to receive forecasted winds associated to the active or secondary flight plan.

The uplink message (ground station to aircraft) may be received upon crew request or automatically without crew request.

The request is initiated from WIND pages or from ACARS FUNCTION page (*Refer to DSC-22\_20-70 Wind Data - Request for Wind Data*).

The uplink wind data when received are directly displayed on the wind pages but not inserted in the flight plan, one set for each flight phase: CLIMB, CRUISE, DESCENT. The alternate wind at alternate cruise flight level is displayed on DESCENT page.

- Winds are associated to altitude for climb and descent phases
- Winds are associated to waypoint for cruise phase and step level. One wind per waypoint.
  - On ground and without entered winds, an uplink message is directly inserted in the flight plan.
  - In flight, winds are temporary stored until the crew inserts it phase per phase. Phase of flight is indicated in the WIND title page.
  - Clearing the INSERT UPLINK\* prompt using the CLR key deletes the uplink wind data for the selected phase.

When uplink winds are deleted, the wind page reverts to the previous status.

The flight plan B page is modified of the uplink wind only after it is inserted by the crew. AOC uplink winds are then considered as crew manual entries (large font).

#### **SCRATCHPAD MESSAGES RELATED TO WIND DATA**

INVALID WIND UPLINK	An error is detected, the uplink is rejected.
WIND DATA UPLINK	Uplinked winds are received.
WIND UPLINK PENDING	A temporary flight plan exists or a DIR TO page is displayed when a wind uplink is received. The message is stored.
WIND UPLINK EXISTS	A F-PLN modification (active or secondary) is attempted when uplink winds are not inserted. This message disappears automatically when the wind uplink is inserted or deleted.
CHECK DEST DATA	The aircraft is at 180 NM from destination, and the destination QNH , TEMP or WIND displayed on the PERF APPR page was received by AOC uplink or, if following insertion of a descent wind uplink, a conflict concerning the above parameters exists.
CHECK ALTN WIND	The uplinked alternate cruise flight level differs from the default alternate cruise flight level.

### **FLIGHT REPORTS**

Ident.: DSC-22\_45-00000868.0001001 / 01 OCT 12

Applicable to: ALL

Flight reports provide real time information to the ground concerning the aircraft current situation and position.

Several types of flight reports are available:

- The Position report : provides current aircraft position
- the Progress report : provides data relative to the destination

- The Flight-Plan report : provides the active route
- the Performance Data report : provides performance data currently used by FMS.


These reports may be manually initiated via a dedicated prompt or automatically sent in response to a ground request or upon specific conditions.

**POSITION REPORT**

This report is sent:

- manually via a MCDU prompt or
- following a ground request or
- automatically upon sequencing a designated reporting fix (designated by the ground in a uplink message).

The manual POSITION REPORT downlink prompt is displayed on the PROG page. (SEND POS prompt).



**PROGRESS PAGE (STANDARD)**

```

ECON CRZ AF5612
CRZ      OPT    REC MAX
FL290    FL350  FL390

+SEND POS
BRG / DIST      TO [    ]
---*/-----
CONFIRM UPDATE AT
4353.3N/00052.4E  AGN*
VOR1/FREQHIGHFREQ/VOR2
ATH/114.40  117.20 /DDM
    
```

**PROGRESS PAGE WITH GPS STANDARD**

```

ECON DES AF5612
CRZ      OPT    REC MAX
FL290    FL350  FL390

+SEND POS  VDEV=+750FT
CONFIRM UPDATE AT
4401.8N/01100.2E  FRZ*
BRG / DIST      TO [    ]
---*/-----
PREDICTIVE
<GPS          GPS PRIMARY
REQUIRED ACCUR ESTIMATED
1.0 NM        HIGH          0.16NM
    
```

*Note: Position report are initiated from active flight plan only.*

## **POSITION REPORT CONTENT**

- Aircraft position
- Overfly reporting waypoint
- Time of report (UTC)
- Aircraft altitude
- Next reporting waypoint
- ETA at next reporting waypoint
- Reporting waypoint following next report
- SAT
- Current wind
- Remaining fuel

## **PROGRESS REPORT**

A progress report contains data relative to the aircraft arrival time and EFOB at destination for the active F-PLN.

This downlink message is automatically sent following:

- a ground request or
- a change of destination or
- a change of runway or
- a specific event. The possible events that can be selected in the navigation database policy file are :
  - X minutes to Top of Descent
  - Z minutes to Destination
  - ETA changes more than W minutes from the previous report.X, Z and W are minutes of time set in the navigation database policy file.

The progress report cannot be manually sent by the crew via a dedicated MCDU prompt.

## **PROGRESS REPORT CONTENT**

- Flight Number
- Arrival Airport Ident
- Destination Runway Ident
- Predicted remaining fuel
- ETA at destination
- Reason for report (specific event, ground request...).

## **FLIGHT PLAN REPORT**

The F-PLN report broadcasts flight plan data to the ground. Only data from the active flight plan can be sent.

This downlink message is sent to the ground:

- automatically following a ground request
- manually by the crew using a prompt displayed on the ACARS FUNCTION page ( DSC-22\_20 Auto Flight - Flight Management/50 Controls and Indicators/10 MCDU - Page Description/25 FMS2 Honeywell/ACARS Function Page). This prompt may be invalidated through the navigation database policy file.

The Flight Plan report can be downlinked either while on ground or in flight during any flight phase.

### **FLIGHT PLAN REPORT CONTENT**

The report contains the active and alternate flight plan.

### **PERFORMANCE DATA REPORT**

The Performance Data report is a downlink message that allows the transmission of performance data (CG , FUEL, CG ...) relative to the active F-PLN.

This message is automatically sent following a ground request. Manual sending is not possible.

### **PERFORMANCE DATA REPORT CONTENT**

Sends to the ground:

- Current GW
- Cruise Altitude
- Current CG
- Fuel on Board
- Block Fuel
- Reserve Fuel
- Cost Index
- Top of Climb Temperature
- Climb Transition Altitude
- Tropopause Altitude
- Taxi Fuel
- ZFW
- ZFWCG



# **AIRCRAFT SYSTEMS**

AUTO FLIGHT - PRINT INTERFACE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### AUTO FLIGHT - PRINT INTERFACE

#### PRELIMINARY PAGES - TABLE OF CONTENTS

Print Function.....	A
AOC/Printer Programming Options <img alt="printer icon" data-bbox="448 168 471 185"/> .....	B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**AUTO FLIGHT - PRINT INTERFACE**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**PRINT FUNCTION**

Ident.: DSC-22\_46-00000869.0003001 / 01 APR 11

**Applicable to: ALL**

The print function enables several types of data and report to be printed :

- Flight plan initialization data
- Takeoff data
- Wind data
- Preflight report
- In flight report
- Post flight report

The 3 first reports may differ when automatically or manually printed for the following reason :  
 The automatic process prints the uplink message although the manual process prints the current active data as displayed on the relevant MCDU pages.

The last 3 reports being processed from the same sources are identical in automatic or manual printing.

*Note: ACARS is not necessary linked to printing process. The printing function may be activated within the FMGS and selected independently from the ACARS.*

- One or several print functions may be deactivated *Refer to DSC-22\_20-50-10-25 Print Function Pages.*
- If an ACARS function is not active, (not selected in the nav database policy file) the printing process is invalidated for this specific ACARS function.

**AOC/PRINTER PROGRAMMING OPTIONS** 

Ident.: DSC-22\_46-00000870.0002001 / 11 FEB 11

**Applicable to: ALL**

Option programming for the AOC /PRINTER functions is obtained through the Navigation Data Base policy file or the Airline Modifiable Information (AMI) file.

The list summarizes the possible options:

Data Link (ACARS or AOC) Inhibit	Disables AOC function
F-PLN Data Request Inhibit	Disables uplink and downlink requests of F-PLN initialization data
Performance Data Request Inhibit	Disables uplink and downlink requests of Performance Initialization data
Takeoff Data Request Inhibit	Disables uplink and downlink request of Takeoff Initialization data
Wind Data Request Inhibit	Disables uplink and downlink request of predicted wind data

Flight Number Enable	Flight Number is included within the F-PLN Request or Progress Report downlinks
Position Report Inhibit	Disables a manual Position Report downlink
Progress Report Triggers	Defines the triggers for the automatic downlink of the Progress Report
F-PLN Report Inhibit	Disables the manual downlink of the F-PLN Report
Auto Print of ACARS or AOC uplinks	Selects/Deselects the automatic printing of the F-PLN , INIT , TO and wind data uplinks. If Autoprint is selected, the crew can deselect it manually. If auto printing is deselected, the crew cannot manually reselect it.
Auto Print of Flight Reports	Selects/Deselects the automatic printing of the Preflight, Inflight, Postflight reports. If selected, the crew can deselect it manually. If autoprint is deselected, the crew cannot manually preselected it.

# **AIRCRAFT SYSTEMS**

## **COMMUNICATIONS**

Intentionally left blank



**DSC-23-10 General**

DSC-23-10-10 Introduction

Introduction.....A

DSC-23-10-20 Radio Tuning

Description.....A  
Radio Management Panel.....B

DSC-23-10-30 Intercommunication Systems

Audio Management System.....A  
Cabin Intercommunication Data System.....B

DSC-23-10-40 Cockpit Voice Recorder

Description.....A  
Controls and Indicators.....B

DSC-23-10-50 Controls

Audio Control Panel.....A  
Side Stick Radio Selector.....B  
Loudspeaker Volume Knob.....C  
Audio Switching.....D

**DSC-23-20 Internal Communication**

DSC-23-20-10 Flight Crew Interphone System

Flight Crew Interphone System.....A

DSC-23-20-20 Cabin Interphone System

Introduction.....A  
Cabin Call System.....B

DSC-23-20-30 Service Interphone System

Introduction.....A  
Ground Mechanic Call System.....B

DSC-23-20-40 Passenger Address

Description.....A  
Controls and Indicators.....B

*Continued on the following page*

*Continued from the previous page*

**DSC-23-30 External Communication**

DSC-23-30-10 Radio Communication

Description.....	A
VHF.....	B
HF.....	C
SELCAL (Selective calling).....	D

**DSC-23-40 Emergency Communication**



DSC-23-40-10 Emergency Evacuation

Controls and Indicators.....	A
Purser Station.....	B

DSC-23-40-30 Emergency Locator Transmitter

Controls and Indicators.....	A
------------------------------	---

**DSC-23-50 Memo Display**

ACARS  .....	A
ATSU  .....	B
AUDIO 3 XFRD.....	C
SATCOM  .....	D


**INTRODUCTION**

Ident.: DSC-23-10-10-00018503.0001001 / 17 MAR 17

Applicable to: ALL

The communications system comprises the following subsystems :

- VHF/HF transceivers
- Radio tuning systems (Radio Management Panels).
- Audio integrating system (Audio Management Unit, Audio Control Panels).





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**COMMUNICATIONS**

GENERAL - INTRODUCTION

Intentionally left blank

**DESCRIPTION**

Ident.: DSC-23-10-20-00018494.0001001 / 17 MAR 17

Applicable to: ALL


Identical Radio Management Panels (RMPs):

- Give the flight crew control of all VHF radio communication systems (HF systems ☞).
- Provide backup to the FMGCs for controlling radio navigation systems (*Refer to DSC-34-NAV-30-10 General*).

The two RMPs are on the center pedestal (and the third ☞ is on the overhead panel).

Each RMP can control any VHF (HF ☞) transceiver. RMP 1 and RMP 2 are connected directly to all VHF (HF ☞) transceivers, (whereas RMP3 ☞ is connected to them via RMP 1 and RMP 2). RMP s are connected together so that each RMP is updated to the selections made on the other RMPs.

Only RMP1 functions in EMER ELEC CONFIG.




If one RMP fails, the remaining one controls all the VHF (HF ☞) transceivers.

**RADIO MANAGEMENT PANEL**

Ident.: DSC-23-10-20-00018495.0002001 / 17 MAR 17

Applicable to: ALL



(1) Frequency displays

The ACTIVE display window shows the active frequency of the selected radio, which is identified by a green light on the selection key.

The STBY /CRS (standby/course) display window shows a standby frequency that the pilot can activate by pressing the transfer key or change by rotating the tuning knobs. (For a description of the CRS function *Refer to DSC-34-NAV-30-30 Radio Management Panel (RMP)*).

(2) Transfer key



Pressing this key moves the active frequency to the standby window and the standby frequency to the active window.

This tunes the selected receiver to the new active frequency.

(3) Radio com selection keys

When the pilot presses one of these keys:

- The ACTIVE window displays the frequency set on that radio.
- The STBY /CRS window displays the selected standby frequency or course.
- The selected key displays a green monitor light.

- (4) Frequency selector knobs  
The pilot uses these concentric knobs to select the STBY frequency or CRS.  
The outer knob controls whole numbers; the inner knob controls decimal fractions.
- (5) AM pb-sw  
If the aircraft has HF radios and the flight crew has selected an HF transceiver, this switch selects the AM mode. (The default mode is the SSB, or single side-band, mode).  
This key displays a green monitor light when the AM mode is active.
- (6) SEL indicator  
The SEL indicator on both RMP s comes on amber when a transceiver normally associated with one RMP is tuned by another:
- VHF 1 tuned by RMP 2 or RMP 3,
  - VHF 2 tuned by RMP 1 or RMP 3.
  - VHF 3, HF 1, HF 2 (  ) tuned by RMP 1 or RMP 2.
- (7) NAV pb sw (with transparent switchguard)  
The pilot presses this key to be able to select navigation receivers and courses through the RMP. It does not affect the selection of communication radios and their frequencies. (*Refer to DSC-34-NAV-30-30 Radio Management Panel (RMP), for additional information*).
- (8) Radio navigation selection keys  
The pilot presses one of these keys to select a navigation radio to control through this RMP.  
This turns on the green monitor light in the key.  
*Refer to DSC-34-NAV-30-30 Radio Management Panel (RMP), for additional information.*
- (9) ON/OFF sw  
This switch controls the power supply to the RMP.  
**Note:** *RMP 3 is able to control VHF and HF transceivers through RMP 1 and RMP 2 even when they are OFF.*
- (10) LOAD FUNCTION   
When the ATC sends (CONTACT or MONITOR) CPDLC messages to the flight crew, a white light above the LOAD key comes on to indicate that the sent frequency is available to be loaded.  
Press on this LOAD key before closing the CONTACT/MONITOR messages to load this VHF frequency to the STBY /CRS window.

Note: *When a frequency from the ATC services (sent label via datalink) has been received, the ATSU validates the frequency and simultaneously sends the information to all the RMP in order to activate the LOAD function.  
When the LOAD function is activated, the flight crew can repeatedly load the frequency on each RMP as often as necessary; except if DATA is present on standby window.*



**AUDIO MANAGEMENT SYSTEM**



Ident.: DSC-23-10-30-00018496.0002001 / 17 MAR 17

Applicable to: ALL


The audio management system allows the flight crew to use :

- All the radio communication and radio navigation facilities installed on the aircraft in transmission and reception mode.
- The interphone systems.
- The call systems.
- The passenger address system.


The audio management system includes :

- An audio management unit (AMU).
- Three audio control panels (ACPs) (fourth and fifth optional).
- Sockets at each station:
  - Headset jack and boomset connector (hand microphone connector  ) for pilot, copilot, and third occupant.
  - Headset jack for fourth occupant.
- One interphone jack at the ground power receptacle.
- Boomsets for the pilot, copilot, and third occupant, and three hand microphones (fourth  ).
- Three cockpit oxygen mask microphones.
- One radio press-to-talk switch on each sidestick.
- One SELCAL code selection panel (avionics compartment).
- Two cockpit loudspeakers with separate volume controls.
- If installed, a jack panel in the electronic compartment that groups the headset jack, service interphone jack, hand mike connector, and boomset.
- An audio switching facility.

If audio channel 1 or 2 fails due to a failure either in an ACP or the corresponding AMU, the crew can use the AUDIO SWITCHING selector to select the third audio channel.



**LOCATION OF COMPONENTS (PILOT'S STATION)**



**CABIN INTERCOMMUNICATION DATA SYSTEM**

Ident.: DSC-23-10-30-00018497.0002001 / 17 MAR 17

Applicable to: ALL


The Cabin Intercommunication Data System (CIDS) transmits, controls, and processes signals for the following cabin systems :


- Cabin and service interphone
- Passenger address
- Passenger lighted signs
- Reading lights (LED technology)
- General cabin illumination

- Emergency evacuation signalling
- Lavatory smoke detectors and indicators
- Passenger entertainment music and video
- Escape slide bottle pressure monitoring
- Vacuum system control function
- Cargo and lavatory smoke detection function

The CIDS has the following main components :

- Two CIDS directors connected in parallel ; one active, and the other on standby.
  - Flight Attendant Panel (FAP) to monitor and control the cabin systems.
  - Attendant Indication Panels (AIP), After Attendant Panels (AAP) and Area Call Panels (ACP)
  - Decoder/Encoder Units (DEUs) linked to the two directors.
- Type A units (for passengers) installed along the cabin.  
 The loudspeakers, lighted signs, call buttons, call lights and general illumination ballast units are divided into small groups, each connected to a type A DEU.
  - Type B units (for attendants) installed near the exit doors. The Area Call panels, smoke detectors, attendant handsets, slide and door pressure sensors, and attendant indicator panels, are connected to type B DEUs.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>COMMUNICATIONS</b></p> <p align="center">GENERAL - COCKPIT VOICE RECORDER</p>
---	--

<b>DESCRIPTION</b>
--------------------

Ident.: DSC-23-10-40-00018569.0002001 / 17 MAR 17

**Applicable to: ALL**

The cockpit voice recorder (CVR) records :

- direct conversations between crew members in the cockpit
- all aural warnings sounded in the cockpit
- audio communications received and transmitted
- intercommunications conversations between crew members
- announcements transmitted over the passenger address system, if PA reception is selected on at least one audio control panel.

Only the last 2 h of recording are retained.

The CVR system consists of :

- a remote microphone behind the overhead panel
- a "hot mike" function, which records the crew members voice directly from their microphone, even if the push to talk switch is not activated.
- a crashproof four-track recorder, equipped with an underwater locating beacon, in the aft section of the aircraft
- a control panel on the overhead panel.

It is energized automatically :

- on the ground during the first 5 min after the aircraft electrical network is energized
- on the ground with one engine running
- in flight


On the ground, it is stopped automatically 5 min after the last engine shutdown provided the CVR jack is not used.

On the ground, the crew can energize the CVR manually by pressing the GND CTL pushbutton.


**CONTROLS AND INDICATORS**


Ident.: DSC-23-10-40-00018570.0001001 / 17 MAR 17

Applicable to: ALL



(1) GND CTL switch (spring-loaded)

ON : The CVR , DFDR , and QAR  are on.  
 The ON light comes on blue.

AUTO: The CVR , DFDR , and QAR  are on, according to the logic. (*Refer to DSC-23-10-40 Description*).

(2) CVR ERASE pb 

Pressed for 2 s : This completely erases the tape, if :

- The aircraft is on the ground, and
- The parking brake is on.

(3) CVR TEST pushbutton


Pressed and held : This activates the test, if the CVR is on (the GND CTL pushbutton pressed, or during the first 5 min after energization of the aircraft electrical network), and the parking brake is on.

*Refer to PRO-NOR-SOP-06 Overhead Panel - RCDR for additional information.*


**AUDIO CONTROL PANEL**

Ident.: DSC-23-10-50-00018498.0002001 / 17 MAR 17

Applicable to: ALL



(1) Transmission keys

- Pressed : The associated channel is selected for transmission. The three green lines come on. The pilot deselects the channel by pressing the pushbutton again, or selecting another channel.
- CALL : The legend flashes amber (and buzzer sounds) when the SELCAL system detects a call.
- MECH : The legend flashes amber (and buzzer sounds) for a call from the nose gear bay. The MECH light goes off after 60 s, if it is not reset.
- ATT : The legend flashes amber (and buzzer sounds) for a call from a cabin crew member. The ATT light goes off after 60 s, if it is not reset.
- SAT CALL It : The legend flashes amber when the SATCOM system detects a call.  The three green lines flash during the establishment of air to ground calls, or when SATCOM calls are on hold. After call establishment, the three green lines remain steady.

(2) Reception knobs

- Pressing and releasing the knob (knob out) selects the associated audio reception channel and the integral white light comes on
- Rotating the knob adjusts the volume
- The INTEG LT knob or ANN LT knob controls the brightness
- Pressing the knob (knob stays in) disconnects the associated audio reception channel.

*Note: To receive DME audio navigation signals that are associated with an ILS or MLS or GLS station: the flight crew must select the ILS pb (or LS pb) on the FCU . On some aircraft, the VOR reception channel must also be active on the ACP.*

(3) SELCAL/CALL RESET key

Pressing this key extinguishes CALL, MECH , and ATT lights.

(4) ON VOICE key

This key allows the flight crew to inhibit the audio navigation signals (VOR , ADF)  
Pressing this key filters out IDENT signals and turns on the green ON light.

(5) INT/RAD switch

This switch operates as a press-to-talk switch for boom mike or oxygen mask mike.

INT : Boom and mask mikes transmit on interphone regardless of which transmission key is selected. For reception on interphone, the crew member must have INT selected (INT reception knob out).

Neutral : Reception is normal. Boom and mask mikes do not transmit.

RAD (press and hold) : Boom and mask mikes transmit on the radio selected on the audio control panel.

(6) Passenger address (PA) function


*(Refer to DSC-23-20-40 Description).*



**SIDE STICK RADIO SELECTOR**

Ident.: DSC-23-10-50-00018499.0001001 / 17 MAR 17

Applicable to: ALL



This selector has the same function as the INT/RAD switch on the ACP.

**NEUTRAL** (spring-loaded) : Boom and mask mikes are dead.  
Reception is normal.


**RADIO** (squeezed) : Boom and mask mikes transmit through the equipment selected by the transmission key on the ACP.

*Note:* If **RADIO** is selected on the side stick when the INT/RAD switch is on INT, the radio function has priority over the interphone function.

**LOUDSPEAKER VOLUME KNOB**

Ident.: DSC-23-10-50-00018500.0001001 / 17 MAR 17

Applicable to: ALL



This knob adjusts the volume of the loudspeaker for radio communication.


- OFF : Loudspeaker does not respond to signals from the aircraft's radio equipment.
- Clockwise rotation : Loudspeaker broadcasts signals from the aircraft's radio equipment at increasing volume.

*Note: This knob does not control the loudness of aural alert and voice messages. In the case of acoustic feedback (i.e. Larsen effect) from the cockpit loudspeaker, the flight crew should reduce the volume of the cockpit loudspeaker. However, the flight crew should ensure that the volume of the cockpit loudspeaker is sufficient to hear radio communication.*

**AUDIO SWITCHING**

Ident.: DSC-23-10-50-00018501.0001001 / 17 MAR 17

Applicable to: **ALL**



The crew can switch to the third ACP if ACP 1 or ACP2 fails.  
 When the crew does this, it takes away the third occupant's access to the acoustic equipment.  
 AUDIO 3 XFRD appears in green on the ECAM MEMO display.

- NORM : Each crew member uses his dedicated communication equipment.
- CAPT 3: The pilot uses his acoustic equipment and the third occupant's ACP.
- F/O 3 : The copilot uses his acoustic equipment and the third occupant's ACP.


**FLIGHT CREW INTERPHONE SYSTEM**

Ident.: DSC-23-20-10-00019716.0001001 / 17 MAR 17

Applicable to: ALL

This system allows the flight crew members to communicate among themselves and, through a jack on the external power panel, with the ground mechanic.

**EXTERNAL POWER PANEL (FORWARD OF THE NOSE L/G BAY)**





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**COMMUNICATIONS**

INTERNAL COMMUNICATION - FLIGHT CREW INTERPHONE SYSTEM

Intentionally left blank


**INTRODUCTION**

Ident.: DSC-23-20-20-00018481.0001001 / 20 JUL 17

Applicable to: ALL

The system allows the flight crew to communicate with the flight attendants, and the flight attendants to communicate among themselves.

*Note:* Cabin interphone monitoring may be deactivated in flight depending on CIDS customization.



(1) CAB transmission key

Pressed: Three green lines come on.  
 Boom, mask, and hand mikes may be used for cabin interphone.

(2) CAB reception knob

Pressed and released (knob out): The integral white light comes on.  
 The station receives audio signals from the cabin.  
 Rotating the knob adjusts the volume.

Pressed (knob in): The white light goes out.  
 The cabin interphone is disconnected.


**CABIN CALL SYSTEM**

Applicable to: ALL


Ident.: DSC-23-20-20-10-00018482.0001001 / 02 NOV 16

**CALLS FROM THE COCKPIT**

The pushbuttons described here below are installed on the CALLS panel located on the overhead panel.



**PURS  /FWD/MID  /EXIT  /AFT PUSHBUTTON**



When pressed, the following aural and visual alerts will trigger in the cabin:

- Two lights come on in pink on the related area of the CALLS panel, as applicable.
- On the Attendant Indication Panel (AIP), the “CAPTAIN CALL” message appears and a light comes on in green.
- A high-low chime sounds in the related section of the cabin, as applicable.

**ALL pb** 



When pressed, all the stations simultaneously respond, as indicated above.

**EMER pb-sw (GUARDED)**



When pressed, the following aural and visual alerts will trigger in the cabin:

- Two pink lights flash on all area call panels.
- The “EMERGENCY CALL” message appears on all AIPs.
- A high-low chime sounds three times, on all of the loudspeakers.

Depending on aircraft configuration, on the cockpit CALLS panel, the white ON light and the amber CALL light come on.

The following aural and visual alerts will trigger in the cockpit, when an emergency call is made from the cabin to the cockpit:

- On the EMER pb-sw: The amber CALL light flashes.
- The ATT lights will flash on all Audio Control Panels (ACPs).
- Three buzzers will sound consecutively (for approx. three seconds each).

The cabin call system will reset, when the cabin crewmember hangs up the handset.

**TT light** 



When the TT pb on the FWD or AFT Attendant Panel is pressed, the TT light on the cockpit CALLS panel comes ON and a buzzer sounds three times in the cockpit.


**ATTND ADV pb** 



When pressed, in the case of an imminent takeoff or landing, the ON light comes on in blue, in addition to a green light on the area call panel in the cabin.



Ident.: DSC-23-20-20-10-00018483.0003001 / 17 MAR 17



(1) CAPT key

When pressed, the following aural and visual alerts will trigger in the cockpit:

- The ATT lights will flash on all Audio Control Panels (ACPs).
- A buzzer (inhibited during takeoff and landing) will sound.

In the cabin, the “CAPTAIN” message will appear on the Attendant Indication Panel (AIP) for which the CAPT key was pressed.

(2) EMER CALL key 

When pressed, the following aural and visual alerts will trigger in the cockpit:

- On the EMER pb-sw: The ON light flashes in white, and the CALL light flashes in amber.
- The ATT lights will flash on all ACPs.
- Three buzzers (inhibited during takeoff and landing) will sound consecutively.

In the cabin, the “EMERGENCY CALL” message will appear on all AIPs or on the AIP of the originating station based on its customization.

## INTRODUCTION

Ident.: DSC-23-20-30-00018485.0001001 / 20 JUL 17

Applicable to: ALL

The system allows for communication between :

- The flight crew and the service interphone jacks.
- The flight attendant stations and the service interphone jacks.
- The different service interphone jacks.

The Service Interphone system has :


- Seven interphone jacks.
- An OVRD switch located on the overhead panel.

The audio lines from the interphone jacks are connected to both CIDS directors.

### LOCATION OF INTERPHONE JACKS



**CONTROLS AND INDICATORS AT OVERHEAD PANEL**



(1) SVCE INT OVRD pushbutton switch


- Auto : Ground personnel can communicate with the flight crew by means of the service interphone jacks 10 s after the aircraft has landed. The landing gear must be compressed.
- ON : Communication is possible when the landing gear is not compressed. The ON light is white.

**GROUND MECHANIC CALL SYSTEM**

Applicable to: ALL

Ident.: DSC-23-20-30-10-00018486.0001001 / 17 MAR 17

**CONTROLS AND INDICATORS ON OVERHEAD PANEL**




**MECH pb**

- Pressed (and held) : COCKPIT CALL lights up blue on the external power panel in the nose L/G bay.  
An external horn sounds.
- Released : COCKPIT CALL remains lighted.  
The ground mechanic can extinguish it by pressing the RESET button on the external power panel. The external horn stops sounding.

Ident.: DSC-23-20-30-10-00018487.0001001 / 17 MAR 17

**CONTROLS AND INDICATORS ON THE EXTERNAL POWER PANEL**



(1) COCKPIT CALL pushbutton

Pressed : This calls the cockpit.

The MECH lights flash amber on the ACPs and a buzzer sounds.

Released : The MECH lights go out after 60 s if they are not reset on the ACPs.

The buzzer stops.

(2) COCKPIT CALL light

The blue light appears when cockpit calls the ground mechanic. An external horn also sounds.

(3) RESET pushbutton

Pressed The COCKPIT CALL light goes out.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**COMMUNICATIONS**

INTERNAL COMMUNICATION - SERVICE INTERPHONE SYSTEM

Intentionally left blank



**DESCRIPTION**

Ident.: DSC-23-20-40-00018685.0001001 / 17 MAR 17


Applicable to: ALL

The passenger address allows all crew members to make announcements to passengers in the cabin through loudspeakers. It can be operated from the cockpit (with ACP or handset) or from the cabin (attendant stations).

**CONTROLS AND INDICATORS**

Ident.: DSC-23-20-40-00018686.0001001 / 20 JUL 17

Applicable to: ALL



(1) PA reception knob

Pressed and released : The message goes to the loudspeakers, and the integral white light comes on.

The flight crew can turn the knob to adjust the volume.



Pressed (knob in) : The PA reception to the loudspeakers is disconnected. The white light goes out.


(2) PA transmission key


Pressed and held : The flight crew may use a boom, mask, or hand mike to make an announcement.

Three green lines come on.

*Note:* The flight crew may use a cockpit handset to make PA announcements without action on the ACPs.

- (3) OBS AUDIO ENT sw :
  - ON : Announcement from the cockpit can be heard through channel 9 of Passenger Entertainment System (PES).
  - OFF : Normal functioning of PES is restored.
- (4) PAIN USE light :

The light comes on when the PA is activated from the cockpit or from the cabin (cabin attendant or prerecorded announcement).
- (5) IFEIN USE light :


The light comes on when the IFE system is in use.
- (6) VIDEO IN USE light :

The light comes on when the video system is in use.

The flight crew can also use the cockpit handset, located at the bottom of the pedestal, for PA announcements.




Note: Due to numerous customizations of the handset and keypad, their functions are not described in detail.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>COMMUNICATIONS</b></p> <p style="text-align: center;">EXTERNAL COMMUNICATION - RADIO COMMUNICATION</p>
---	--

<b>DESCRIPTION</b>
--------------------


Ident.: DSC-23-30-10-00018475.0001001 / 17 MAR 17  
**Applicable to: ALL**

Either of the two Radio Management Panels (RMPs) (third RMP  ) can be used to tune each transceiver.

To transmit, the flight crew uses the Audio Control Panel (ACP ) to select a VHF or HF system. The ACP works through the Audio Management Unit (AMU ). Each system is connected to the RMP s, for frequency selection, and to the AMU for connection to the audio integrating and SELCAL (selective calling) systems.

<b>VHF</b>
------------

Ident.: DSC-23-30-10-00018472.0001001 / 27 APR 17  
**Applicable to: ALL**

Two identical VHF communication systems (third VHF system  ) are installed. Each system has a transceiver in the avionics compartment, and an antenna on the fuselage. Only VHF1 functions in EMER ELEC CONFIG. Its range is from 118.0 to 136.975 MHz.


<b>HF</b>
-----------

Ident.: DSC-23-30-10-00018473.0003001 / 04 JUL 17  
**Applicable to: ALL**

Two identical HF communication systems are optional. Each has a transceiver in the avionics compartment, and a common tuner and antenna in the vertical stabilizer. Its range is from 2.8 to 24 MHz.

The HF DATA transmission is inhibited on ground. A GND HF DATALINK pb, located on the overhead panel, may override the inhibition. HF must not be used during refueling.

The HF VOICE MODE is not inhibited on ground. The use of HF on ground must be limited to operational needs. It is important to check that nobody stays in the direct vicinity of the antennas if the HF is use on ground.



**SELCAL (SELECTIVE CALLING)**

Ident.: DSC-23-30-10-00018476.0001001 / 17 MAR 17


Applicable to: **ALL**


Upon receiving a call code corresponding to that of the aircraft, the SELCAL system aurally and visually advises the flight crew that a ground station is calling the aircraft.  
The aural warning is inhibited during takeoff and landing.

**CONTROLS AND INDICATORS**


Ident.: DSC-23-40-10-00018468.0001001 / 18 MAY 17


Applicable to: ALL




- (1) COMMAND pb (guarded) 

ON : In the cockpit : - EVAC light flashes red.  
- Depending on aircraft configuration, horn sounds.  
In the cabin : - EVAC lights flash at FWD and AFT attendant panels.  
- Evacuation tone sounds.

OFF : The alert is stopped.  
The EVAC light flashes red when the alert is activated.
- (2) HORN SHUT OFF pb 

Pressing this button silences the cockpit horn.
- (3) CAPT and PURS/CAPT sw 

CAPT and PURS : The alert may either be activated from the cockpit or the cabin.  
CAPT : The alert may only be activated from the cockpit.  
If one of the cabin CMD pb is pressed, only the cockpit horn sounds for 3 s.
- (4) CMD pb 

Pressing this button activates the alert, if the cockpit switch is at the CAPT & PURS position.  
Pressing it again stops the alert.
- (5) RESET pb

Pressing this button silences the EVAC tone.


(6) EVAC light

This light flashes when the alert is activated.

**PURSER STATION**

Ident.: DSC-23-40-10-00018469.0001001 / 17 MAR 17


Applicable to: **ALL**



**CONTROLS AND INDICATORS**

Ident.: DSC-23-40-30-00018516.0002001 / 17 MAR 17

Applicable to: ALL



(1) ELT selector


- ON : The Emergency Locator Transmitter (ELT) transmits an emergency signal.
- ARMED : In case of impact, the ELT transmits an emergency signal (on 121.5, 243 and 406 MHz).
- TEST/RESET : Starts the ELT autotest.

*Note:* If the ELT is unduly triggered in ARMED mode (by an external impact, hard landing, etc.), select the TEST/RESET position to reset the ELT and stop signal transmission.

(2) ON light and ELT light

These lights come on amber either when the emergency signal is transmitted, or during ELT autotest.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>COMMUNICATIONS</b></p> <p>MEMO DISPLAY</p>
---	---


**ACARS** 

Ident.: DSC-23-50-00018505.0001001 / 31 AUG 17  
**Applicable to: ALL**

- ACARS CALL** : This memo appears in green when ACARS has received a message from the ground requesting a voice communication on VHF. This message is pulsing green during 60 s then steady.
- VHF 3 VOICE** : This memo appears in green when VHF 3 is operating in voice mode and ACARS communication is interrupted.
- ACARS MSG** : This memo appears in green when ACARS has received a message from the ground. This message is pulsing green during 60 s then steady.
- ACARS STBY** : This memo appears in green when ACARS communications between the aircraft and the ground are lost, or when a failure occurs at ATSU initialization to indicate to the crew to enter some initialization parameters.

**ATSU** 

Ident.: DSC-23-50-00018506.0001001 / 31 AUG 17  
**Applicable to: ALL**

- VHF 3 VOICE** : This memo appears in green, if VHF 3 is operating in voice mode and ACARS communication is interrupted.
- HF VOICE** : This memo appears in green, if both HF s  are operating in voice mode. This message flashes for 10 s and then steady.

**AUDIO 3 XFRD**

Ident.: DSC-23-50-00018507.0001001 / 17 MAR 17  
**Applicable to: ALL**

- AUDIO 3 XFRD** : This memo appears in green, if the AUDIO SWITCHING selector is not on NORM.

**SATCOM** 

Ident.: DSC-23-50-00018508.0001001 / 31 AUG 17  
**Applicable to: ALL**

- SATCOM ALERT** : This memo appears in green when a message with priority level below 4 is received from the ground.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**COMMUNICATIONS**

MEMO DISPLAY

Intentionally left blank

# **AIRCRAFT SYSTEMS**

ELECTRICAL

Intentionally left blank

**DSC-24-10 Description**

DSC-24-10-10 General

General.....A

DSC-24-10-20 Generation of Electrical Power

AC Generators.....A  
DC Generation.....B  
Circuit Breakers (C/Bs).....C

DSC-24-10-30 Operations

DSC-24-10-30-10 General

General.....A

DSC-24-10-30-20 Normal Configuration

In Flight.....A  
On Ground.....B

DSC-24-10-30-30 Abnormal Configurations

Failure of One Engine Generator.....A  
Failure of AC BUS 1.....B  
Failure of One TR.....C  
Failure of TR 1 and TR 2.....D  
Emergency Generation after Loss of All Main Generators.....E  
EMER GEN Running.....F  
EMER GEN Running (Cont'd).....G  
Flight with Batteries Only.....H  
On Ground, Batteries Only (Speed < 50 kt).....I  
Smoke Configuration.....J

DSC-24-10-30-40 Distribution Table

Distribution Table.....A

**DSC-24-20 Controls and Indicators**

Overhead Panel.....A  
Overhead Panel (Cont'd).....B  
External Power Panel.....C  
Forward Cabin.....D  
ECAM ELEC Page.....E  
Memo Display.....F



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ELECTRICAL

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL**


Ident.: DSC-24-10-10-00017750.0001001 / 21 MAR 16

**Applicable to: ALL**


The electrical power system consists of a three-phase 115/200 V 400 Hz constant-frequency AC system and a 28 V DC system. Electrical transients are acceptable for equipment. Commercial supply has secondary priority.

In normal configuration, the electrical power system provides AC power. The electrical power system is constituted of 2 engine generators and 1 APU generator. Each generator can provide AC power to all electrical bus bars. A part of this AC power is converted into DC power for certain applications.

In the event that normal AC power is not available, an emergency generator can provide AC power. In the event that all AC power is not available, the electrical power system can invert DC power from the batteries into AC power.





 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>ELECTRICAL</b></p> <p style="text-align: center;">DESCRIPTION - GENERATION OF ELECTRICAL POWER</p>
---	--

**AC GENERATORS**

Ident.: DSC-24-10-20-00017751.0001001 / 21 MAR 16  
Applicable to: ALL

**ENGINE – DRIVEN GENERATORS**

Two AC generators (GEN 1, GEN 2), one driven by each main engine through an integrated drive, supply aircraft electrical power. Each generator can supply up to 90 KVA of three phase 115/200 V 400 Hz power.

Two Generators Control Units (GCU ) control the output of their respective generator. The main functions of each GCU are :

- Control the frequency and voltage of the generator output.
- Protect the network by controlling the associated generator line contactor.

**APU GENERATOR AND EXTERNAL POWER**

A third generator (APU GEN ), driven directly by the APU and producing the same output as each main engine generator, can replace either or both main engine generators at any time. A ground power connector near the nosewheel allows ground power to be supplied to all busbars.

A Ground Power Control Unit (GPCU) :

- Protects the network by controlling the external power contactor, or

A Ground and Auxiliary Power Control Unit (GAPCU)  :

- Regulates, via the APU Electronic Control Box, the frequency and voltage of the APU generator.
- Protects the network by controlling the external power contactor and the APU generator line contactor.

**EMERGENCY GENERATOR**

The blue hydraulic circuit drives an emergency generator that automatically supplies emergency AC power to the aircraft electrical system, if all main generators fail. This generator supplies 5 KVA of three-phase 115 and 200 V 400 Hz power.

A Generator Control Unit (GCU) :

- Keeps the emergency generator at a constant speed,
- Controls the generator's output voltage,
- Protects the network by the controlling the emergency generator line contactor, and
- Controls the emergency generator start-up.

**STATIC INVERTER**

A static inverter transforms DC power from Battery 1 into one KVA of single-phase 115 V 400 Hz AC power, which is then supplied to part of the AC essential bus. When the aircraft speed is above

## AIRCRAFT SYSTEMS

### ELECTRICAL

#### DESCRIPTION - GENERATION OF ELECTRICAL POWER

50 kt, the inverter is automatically activated, if only the batteries are supplying electrical power to the aircraft, regardless of the BAT 1 and BAT 2 pushbutton positions.

When the aircraft speed is below 50 kt, the inverter is activated, if only the batteries are supplying electrical power to the aircraft, and both BAT 1 and BAT 2 pushbuttons are on.

## DC GENERATION

Ident.: DSC-24-10-20-00017752.0001001 / 21 MAR 16


Applicable to: ALL

### TRANSFORMER RECTIFIERS (TRS)

Two main transformer rectifiers, TR 1 and TR 2, supply the aircraft's electrical system, with up to 200 A of DC current.

A third (identical) Transformer Rectifier, the ESS TR, can power the essential DC circuit from the emergency generator, if the engine and APU generators all fail, or if TR 1 or TR 2 fails.

Each TR controls its contactor by internal logic.

A fourth Transformer Rectifier (TR Entertainment ) powers the DC Entertainment bus bar dedicated to the In-Flight Entertainment system (IFE) in order to take into account IFE needs.

### BATTERIES

Two main batteries, each with a normal capacity of 23 Ah, are permanently connected to the two hot buses.

Each battery has an associated Battery Charge Limiter (BCL).

The BCL monitors battery charging and controls its battery contactor.

## CIRCUIT BREAKERS (C/BS)

Ident.: DSC-24-10-20-00000874.0002001 / 15 FEB 11

Applicable to: ALL

The aircraft has two types of C/Bs:

- Monitored (green): When out for more than 1 min, the C/B TRIPPED warning is triggered on the ECAM.
- Non-monitored (black).

The Wing Tip Brake (WTB) C/Bs have red caps on them to prevent them from being reset.

The C/B TRIPPED warning on the ECAM indicates the location of the affected C/B. The following panels are monitored: OVHD PNL, L(R) ELEC BAY, REAR PNL J-M or N-R or S-V or W-Z.

- Note: *The flight crew can clear the ECAM C/B TRIPPED caution by pressing:*
- *The EMER CANC pb: When pressed, this pushbutton clears and inhibits the ECAM C/B TRIPPED caution for the remainder of the flight, or*
  - *The CLR pb: When pressed, this pushbutton only clears the ECAM C/B TRIPPED caution. If the C/B remains pulled, any additional tripped circuit breakers on the same panel will not be detected, and the ECAM will not trigger the caution. However, if the C/B is pushed, any additional tripped circuit breakers will be detected, and the ECAM will trigger the caution again.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ELECTRICAL**

DESCRIPTION - GENERATION OF ELECTRICAL POWER

Intentionally left blank


**General**

**GENERAL**

Ident.: DSC-24-10-30-10-00017759.0001001 / 21 MAR 16

Applicable to: ALL

GEN 1 and 2 when operating have priority over the APU generator and over external power.  
External power has priority over the APU generator when the EXT PWR pb switch is ON.  
The APU generator or external power can supply the entire network.  
One engine generator can supply the entire network, except the DC BUS Entertainment.  
The generators cannot be connected in parallel.

Note: *Two generators are needed to supply the DC BUS Entertainment  , except on ground, where the APU generator (if not overloaded) or the external power is sufficient.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ELECTRICAL**

DESCRIPTION - OPERATIONS

Intentionally left blank

**Normal Configuration**

**IN FLIGHT**

Ident.: DSC-24-10-30-20-00000876.0002001 / 09 OCT 12

Applicable to: ALL


Each engine-driven generator supplies its associated AC BUS (1 and 2) via its generator line contactor (GLC 1 and GLC 2).

AC BUS 1 normally supplies the AC ESS BUS via a contactor.

TR 1 normally supplies DC BUS 1, DC BAT BUS, and DC ESS BUS.

TR 2 normally supplies DC BUS 2.

The two batteries are connected to the DC BAT BUS, if they need charging. When they are fully charged, the battery charge limiter disconnects them.




**ON GROUND**

Ident.: DSC-24-10-30-20-00000877.0002001 / 22 MAY 12

Applicable to: ALL


Either the APU generator, or external power, may supply the complete system.



On ground, when only ground services are required, external power can supply the AC and DC GND /FLT BUSES directly without supplying the entire aircraft network.

Personnel select this configuration with the MAINT BUS switch in the forward entrance area.







**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ELECTRICAL**

DESCRIPTION - OPERATIONS

Intentionally left blank

**Abnormal Configurations**

**FAILURE OF ONE ENGINE GENERATOR**

Ident.: DSC-24-10-30-00017760.0002001 / 21 MAR 16


Applicable to: ALL

The system automatically replaces the failed generator, with the :

- APU GEN, if available, or
- Other engine generator.

Part of the galley load and the DC BUS Ent  are automatically shed.


Note: The Galley Load Automatic Shedding  allows all the galley load to be automatically shed.




**FAILURE OF AC BUS 1**

Ident.: DSC-24-10-30-00017761.0002001 / 21 MAR 16

Applicable to: ALL

- AC BUS 2 can supply AC ESS BUS, and ESS TR can supply DC ESS BUS, both via the AC ESS FEED pb. This is done automatically with the AC ESS FEED Auto Switching .
- DC BUS 2 supplies DC BUS 1 and DC BAT BUS automatically after 5 s.



**FAILURE OF ONE TR**

Ident.: DSC-24-10-30-30-00000880.0002001 / 21 MAR 16


Applicable to: ALL

The contactor of each TR opens automatically, in case of :

- Overheat
- Minimum current

The other TR automatically replaces the faulty one.

The ESS TR supplies the DC ESS BUS.



**FAILURE OF TR 1 AND TR 2**

Ident.: DSC-24-10-30-30-00000881.0002001 / 09 OCT 12

Applicable to: ALL


If TR 1 and TR 2 are lost, DC BUS 1, DC BUS 2, and DC BAT BUS are lost. The DC ESS BUS is supplied by the ESS TR.



**EMER GEN RUNNING**

Ident.: DSC-24-10-30-30-00000883.0002001 / 17 MAR 11


Applicable to: ALL



**EMER GEN RUNNING (CONT'D)**

Ident.: DSC-24-10-30-30-00000884.0002001 / 21 MAR 16

Applicable to: ALL






**FLIGHT WITH BATTERIES ONLY**

Ident.: DSC-24-10-30-00017762.0001001 / 21 MAR 16


Applicable to: ALL



**ON GROUND, BATTERIES ONLY (SPEED < 50 KT)**

Ident.: DSC-24-10-30-30-00017763.0001001 / 21 MAR 16

Applicable to: ALL





**SMOKE CONFIGURATION**

Ident.: DSC-24-10-30-30-00017764.0002001 / 21 MAR 16

Applicable to: ALL

In this configuration the main busbars are shed. The electrical distribution is the same as it is in the emergency electrical configuration (loss of main generators), except the fact that in smoke configuration the fuel pumps are connected upstream of the GEN 1 line connector. The procedure sheds approximately 75 % of electrical equipment. All equipment that remains powered is supplied via the circuit breakers on the overhead panel (except for equipment supplied by hot buses).





*Note:* ECAM ELEC page is identical to that for emergency generator running.

**Distribution Table**

**DISTRIBUTION TABLE**

Ident.: DSC-24-10-30-40-00017765.0002001 / 21 MAR 16

Applicable to: ALL

	AC BUS 1	AC BUS 2	AC ESS BUS	AC SHED ESS	AC STAT INV	TR 1	TR 2	ESS TR	TR Ent. ⚠ (1)	DC BUS 1	DC BUS 2	DC BUS Ent. (1)	DC BAT BUS	DC ESS BUS	DC SHED ESS	HOT BUS 1	HOT BUS 2
<b>NORM CONF</b>	GEN 1	GEN 2	GEN 1	GEN 1	-	GEN 1	GEN 2	-	GEN 2	TR 1 GEN 1	TR 2 GEN 2	REN GEN 2	TR 1 GEN 1	TR 1 GEN 1	TR 1 GEN 1	BAT 1	BAT 2
<b>ONE GEN INOP AVAIL-X- (1, 2 or APU)</b>	GEN X	GEN X	GEN X	GEN X	-	GEN X	GEN X	-	GEN X	TR 1 GEN X	TR 2 GEN X	REN GEN X	TR 1 GEN X	TR 1 GEN X	TR 1 GEN X	BAT 1	BAT 2
<b>EMER CONF • BEFORE EMER GEN AVAILABILITY (about 8 s)</b>	-	-	ST INV BAT 1	-	ST INV BAT 1	-	-	-	-	-	-	-	-	BAT 2	-	BAT 1	BAT 2
<b>• EMER GEN RUNNING</b>	-	-	EMER GEN	EMER GEN	-	-	-	EMER GEN	-	-	-	-	-	ESS TR EMER GEN	ESS TR EMER GEN	BAT 1	BAT 2
<b>TR 1 FAULT</b>	GEN 1	GEN 2	GEN 1	GEN 1	-	-	GEN 2	GEN 1	-	TR 2 GEN 2	TR 2 GEN 2	-	TR 2 GEN 2	ESS TR GEN 1	ESS TR GEN 1	BAT 1	BAT 2
<b>TR 2 FAULT</b>	GEN 1	GEN 2	GEN 1	GEN 1	-	GEN 1	-	GEN 1	-	TR 1 GEN 1	TR 1 GEN 1	-	TR 1 GEN 1	ESS TR GEN 1	ESS TR GEN 1	BAT 1	BAT 2
<b>TR 1 + 2 FAULT</b>	GEN 1	GEN 2	GEN 1	GEN 1	-	-	-	GEN 1	-	-	-	-	-	ESS TR -GEN 1	ESS TR -GEN 1	BAT 1	BAT 2

(1) Two generators are needed to supply the DC BUS Entertainment ⚠, except on ground, where the APU generator (if not overloaded) or the external power is sufficient.

**AIRCRAFT SYSTEMS**

**ELECTRICAL**

DESCRIPTION - OPERATIONS


**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

ON GROUND BAT. ONLY	AC BUS 1	AC BUS 2	AC ESS BUS	AC SHED ESS	AC STAT INV	TR 1	TR 2	ESS TR	TR Ent.	DC BUS 1	DC BUS 2	DC BUS Ent.	DC BAT BUS	DC ESS BUS	DC SHED ESS	HOT BUS 1	HOT BUS 2
<b>Speed &gt;100 kt</b>	-	-	EMER GEN	EMER GEN	-	-	-	EMER GEN	-	-	-	-	-	ESS TR EMER GEN	ESS TR EMER GEN	BAT 1	BAT 2
<b>Rat stall or 50 kt ≤ speed ≤ 100 kt</b>	-	-	ST INV BAT 1	-	ST INV BAT 1	-	-	-	-	-	-	-	BAT 1-2	BAT 2	-	BAT 1	BAT 2
<b>Speed &lt; 50 kt</b>	-	-	-	-	ST INV BAT 1	-	-	-	-	-	-	-	BAT 1-2	BAT 2	-	BAT 1	BAT 2

**OVERHEAD PANEL**

Ident.: DSC-24-20-00017766.0004001 / 21 MAR 16

Applicable to: ALL



- (1) BAT 1(2) ind.  
Shows battery voltage in white.
- (2) BAT 1(2) pb-sw  
Controls the operation of the corresponding battery charge limiter.

**AIRCRAFT SYSTEMS**

**ELECTRICAL**


**CONTROLS AND INDICATORS**

- Auto** : The battery charge limiter controls automatically the connection and the disconnection of the corresponding battery to the DC BAT BUS (3 PP) by closing and opening of the battery line contactor.
- The batteries are connected to the DC BAT BUS in the following cases:
    - APU starting (MASTER SW pb-sw at ON and N < 95 %).

*Note:* The connection is limited to 3 min when the emergency generator is running.

  - Battery voltage below 26.5 V (battery charge). The charging cycle ends when battery charge current goes below 4 A.
    - On ground, immediately
    - In flight, after a time delay of 30 min.
  - Loss of AC BUS 1 and 2 when below 100 kt (EMER GEN not supplying).
- If AC BUS 1 and 2 are not energized and the EMER GEN is not supplying:
- Battery 1 supplies the AC STAT INV BUS, and, if speed is greater than 50 kt, the AC ESS BUS.
  - Battery 2 supplies the DC ESS BUS.
- Note:* In normal configuration the batteries are disconnected most of the time.
- Note:* A battery automatic cut-off logic prevents the batteries from discharging completely when the aircraft is on the ground (parking).
- Automatic battery contactors open when:*
- The aircraft is on the ground
  - The BAT pb switches are at AUTO
  - The main power supply (EXT PWR + GEN) is cut off
  - Battery voltage is low.
- The flight crew can reset the contactors by switching the BAT pb-sw to OFF then to AUTO.*
- OFF** : The battery charge limiter is not operating: the battery line contactor is open. OFF comes on white if the DC BAT BUS is supplied. Hot buses remain supplied.
- FAULT light** : Comes on amber, accompanied by an ECAM caution, when the charging current for the corresponding battery is outside limits. In this case the battery contactor opens.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>ELECTRICAL</b></p> <p>CONTROLS AND INDICATORS</p>
---	--

(3) IDG 1(2) (Integrated Drive Generator) pb-sw (guarded)

<b>CAUTION</b>	<ol style="list-style-type: none"> <li>1. Maintaining the IDG pb-sw during more than 3 s may damage the IDG disconnection mechanism.</li> <li>2. Disconnect the IDG only when the engine is running or windmilling. If not, the IDG will be damaged when starting the engine.</li> </ol>
----------------	--

The IDG switches are normally springloaded out.

Pressing this switch disconnects the IDG from its driveshaft: only maintenance personnel can reconnect it.

**FAULT** : Lights up amber, and ECAM caution comes on, if:

- light**
- IDG oil outlet overheats (above 185 °C), or
  - IDG oil pressure is low (inhibited at low engine speed: N2 below 14 %).
- It extinguishes when the IDG is disconnected.

(4) GEN 1 (2) pb-sw

**ON** : The generator field is energized and the line contactor closes if electrical parameters are normal.

**OFF** : The generator field is de-energized and the line contactors opens. The fault circuit is reset.

**FAULT light** : Lights up amber, and an ECAM caution comes on, if:

- The associated generator control unit (GCU) trips it.

*Note: If a differential fault trips the protection, reset action has no effect after two attempts.*

- Opening of the line contactor (except if the GEN pb-sw is selected OFF).

(5) APU GEN pb-sw

**ON** : The APU generator field is energized and the line contactor closes if parameters are normal and the EXT PWR line contactor is open. The bus tie contactor 1(2) closes automatically if GEN 1(2) is not operating.

**OFF** : The generator field is de-energized and the line contactor opens. The fault circuit is reset.

**FAULT** : Same as GEN 1 or 2 **FAULT**


**light** The APU GEN **FAULT** light is inhibited when APU speed is too low or if the APU GEN line contactor opens after EXT PWR or ENG GEN takes over.

(6) BUS TIE pb

- AUTO** : The bus tie contactors (BTC s) automatically open or close to maintain power supply to both AC BUS 1 and 2.
- One contactor is closed, when:
    - One engine generator supplies the associated AC BUS, and
    - The APU generator, or external power supplies the other side.
  - Both contactors are closed during single-engine operation, or operation on the APU generator, or external power supply.
- OFF** : Both bus tie contactors open.

(7) AC ESS FEED pb



- NORMAL** : The AC ESS BUS is supplied by AC BUS 1.
- ALTN** : The AC ESS BUS is supplied by AC BUS 2. The light comes on when manually selected.



*Note: With the AC ESS FEED Auto Switching  , AC BUS 2 will automatically supply AC ESS BUS when AC BUS 1 is lost.*

- FAULT light** : The amber light, and ECAM caution come on, when the AC ESS BUS is not electrically-supplied.


*Note: In case of a total loss of the main generators, the AC ESS BUS is automatically supplied by the emergency generator, or by the static inverter, if the emergency generator is not available.*



(8) GALLEY pb or GALY & CAB pb

- AUTO** : Main galley, secondary galley, in-seat power supply  and IFE  system (prerecorded announcement, telephone system, video/airshow, music...), are supplied.

The main galley, the in-seat power supply  and the IFE  systems are automatically shed:

- In flight: When only one generator is operating.
- On ground: When only one engine generator is operating. (All galleys are available when the APU GEN or EXT PWR is supplying power.)

*Note: With the Galley Load Automatic Shedding  the secondary galley is also automatically shed.*

- OFF : The main galley, secondary galley, in-seat power supply  and IFE  system (prerecorded announcement, telephone system, video/airshow, music ....) are not supplied.  
The electrical supply of the heating floor panels is shed.
- FAULT light : The amber light, and ECAM caution come on, when the load on any generator is more than 100 % of rated output.

(9) EXT PWR pb

AVAIL light comes on green, if:


- External power is plugged in, and
- External power parameters are normal.

When pressed:

- If the AVAIL light was on:
  - The external power line contactor closes
  - The AVAIL light goes off
  - The ON light comes on blue.
- If the ON light was on:
  - The external power line contactor opens
  - The ON light goes off
  - The AVAIL light comes on.

- Note: 1. External power has priority over the APU generator. The engine generators have priority over external power.  
2. The ON light stays on, even when the engine generators supply the aircraft.


(10) COMMERCIAL pb 

- ON : All aircraft commercial electrical loads are supplied:
- Cabin and cargo lights
  - Water and toilet system
  - Drain mast ice protection
  - Galley
  - Passenger's entertainment
  - Semi-automatic cargo loading 
- OFF : Switches off all aircraft commercial electrical loads.

**OVERHEAD PANEL (CONT'D)**

Ident.: DSC-24-20-00017778.0002001 / 21 MAR 17

Applicable to: ALL



(1) MAN ON pb (guarded)

**AUTO** : When the following conditions are met:

- AC BUS 1 is not electrically supplied, and
- AC BUS 2 is not electrically supplied, and
- Aircraft speed is greater than 100 kt.
- The RAT extends, and
- The blue hydraulic system drives the emergency generator.

As soon as the emergency generator electrical parameters are within tolerance the emergency generator is connected to the aircraft network.

**Pressed** : This selects manual RAT extension.

Emergency generator coupling occurs 3 s after the RAT supplies the emergency generator.

(2) FAULT light

This light comes on red if the emergency generator is not supplying power when AC BUS 1 and AC BUS 2 are not powered.

(3) EMER GEN TEST pb (guarded)

Pressed and held:

- If AC NORMAL BUSES are supplied:

- The EMER GEN is driven hydraulically if the blue electric pump is running.  
The AC ESS BUS and the DC ESS BUS are connected to the emergency generator.  
(The DC ESS SHED and AC ESS SHED buses are not powered.)
- ECAM displays the ELEC page automatically (only on the ground).

- If only the batteries supply the aircraft:

- The static inverter powers the AC ESS BUS.

(4) GEN 1 LINE pb-sw

OFF : GEN 1 line contactor opens.


The AC BUS 1 channel is supplied from GEN 2 through bus tie contactors. This is used for smoked drill.

SMOKE : *Refer to DSC-26-30-20 GEN 1 LINE pb-sw.*  
light

**EXTERNAL POWER PANEL**

Ident.: DSC-24-20-00000891.0001001 / 21 MAR 16

Applicable to: ALL




- (1) EXT PWR NOT IN USE  
 This white light comes on to inform ground personnel that the ground power unit is not supplying the aircraft network and can be removed.
- (2) EXT PWR AVAIL  
 This amber light comes on to indicate that external power is available and the voltage is correct.

**FORWARD CABIN**

Ident.: DSC-24-20-00000892.0001001 / 22 MAY 12

Applicable to: ALL

**MAINT BUS SW:**



This switch allows personnel to energize electrical circuits for ground servicing without energizing the entire aircraft electrical system.

**ON :** The switch latches magnetically if external power is connected and normal (AVAIL light on).

The AC and DC GND /FLT buses have power and the following loads can be energized:

- passenger compartment lighting
- galley lighting
- entrance area lights
- lavatory lighting and service
- vacuum cleaner sockets
- flight compartment service outlets
- hydraulic pump (yellow system)
- flight compartment flood lighting
- fuel quantity indications
- refueling
- cargo hold lighting
- main and nose landing gear compartment lighting
- belly fairing panel service outlets
- ground call
- equipment compartment lights and service outlets
- navigation lights.


The switch trips when the external source is removed.

**OFF :** The AC and DC GND /FLT buses are connected to AC BUS 2 and DC BUS 2.

**ECAM ELEC PAGE**

Ident.: DSC-24-20-00017780.0002001 / 21 MAR 16

Applicable to: **ALL**






(1) Battery indications

- BAT pb-sw at OFF:  
Legend is in white.



- BAT pb-sw at Auto:



(A)

Legend is normally white, but becomes amber:

- when voltage and current indications change to amber, or
- in case of a BAT FAULT alert.

(B) Battery voltage is normally green, but becomes amber if  $V > 31 \text{ V}$  or  $V < 25 \text{ V}$ .

(C) Battery current is normally green, but becomes amber if discharge current  $> 5 \text{ A}$ .

(2) Battery charge/discharge indication

 BATTERY CONTACTOR CLOSED. BATTERY CHARGING CURRENT > 1A (GREEN)  
 BATTERY CONTACTOR CLOSED. BATTERY DISCHARGE CURRENT > 1A (AMBER)  
 BATTERY CONTACTOR CLOSED. CURRENT < 1A (GREEN)  
 BATTERY CONTACTOR OPEN.

(3) DC BAT indication


It is normally in green. It becomes amber, if DC BAT voltage  $\leq 25$  V.

(4) Bus bar indication

The bus bar indication is normally green. It becomes amber when the corresponding bus bar is not powered.

SHED appears in amber, when AC or DC SHED ESS BUS is shed.

(5) TR 1 (2) indication



(A) Normally white, this legend becomes amber when legends B and C do.

(B) The TR voltage is normally in green. It becomes amber, if  $V > 31$  V, or  $V < 25$  V.


(C) The TR current is normally in green. It becomes amber, when the TR current  $\leq 5$  A.

(6) ESS TR indication



This legend follows the logic of the above-noted TR 1 (2) legend.  
The voltage and current are not displayed, when the essential TR contactor is open.

(7) EMER GEN indication



(A) This legend is normally in white. It becomes amber when either the voltage or frequency legend becomes amber.

(B) This legend is normally in green. It becomes amber, if:

- $V > 120 \text{ V}$  or
- $V < 110 \text{ V}$ .


(C) This legend is normally in green. It becomes amber, if:

- $F > 410 \text{ Hz}$  or
- $F < 390 \text{ Hz}$ .


Voltage and frequency indications are not displayed, when the EMER GEN line contactor is open.

(8) GEN 1(2) indications

- GEN pb-sw is OFF:  
 GEN is amber.  
 OFF indication is white  
 1 or 2 indication is white if the associated engine is running, amber if it is not.




- GEN pb-sw is ON.




- (A) GEN 1 or GEN 2, normally white, becomes amber if any of the following legends become amber.
- (B) The load legend, normally green, becomes amber if load > 100 %.
- (C) The voltage legend, normally green, becomes amber if V > 120 V or V < 110 V.
- (D) The frequency legend, normally green, becomes amber if F > 410 Hz or F < 390 Hz.

(9) APU GEN indications


- When the APU MASTER sw is OFF this legend is white regardless of the position of the APU GEN pb-sw.



- When the APU MASTER sw is ON, and the APU GEN pb-sw is OFF:  
The APU GEN legend is amber.  
The OFF legend is white.




- When the APU MASTER sw is ON and the APU GEN pb-sw is ON:  
The indications are the same as for GEN 1 (2).




(10) EXT PWR indications


- External power is not available.



- When external power is available:




- (A) This legend is normally white, but becomes amber, if either of the following legends turns amber.
- (B) This legend is normally green, but becomes amber, if  $V > 120 V$  or if  $V < 110 V$ .
- (C) This legend is normally green, but becomes amber, if  $F > 410 Hz$  or if  $F < 390 Hz$ .



- This legend appears during the static inverter test, and when pressing the ELEC pb on the ECAM control panel while ESS BUSES are supplied by the batteries. It is normally green, but becomes amber, if:
  - V < 110 V or V > 120 V.
  - F < 390 Hz or F > 410 Hz.

(11) IDG indications



(A) IDG1 (2) legend

The IDG legend is normally white, but becomes amber, if:

- Oil outlet temperature > 185 °C.
- Oil pressure gets too low.
- IDG becomes disconnected.

The 1 or 2 is white if the corresponding engine is running, amber if it is not and the FADEC is powered.

(B) DISC/LO PR indication

The DISC legend appears in amber, when the IDG is disconnected.

LO PR appears in amber, when IDG low pressure is detected and the associated engine is running.

(C) Oil outlet temperature

This legend is normally in green, but appears amber, if T > 185 °C.


It flashes, if 147 °C < T < 185 °C (advisory).

(12) GALLEY SHED indication

This legend appears in white when:

- The GALLEY pb-sw is OFF, or
- The main galleys are shed, meaning:
  - In flight, only one generator is operating.
  - On ground, the aircraft is being supplied by one engine generator only.

The legend is not displayed, when the aircraft is in its normal configuration.

(13) RISE indication 

This number, displayed in green, is the difference between the temperature at the IDG inlet and that at the IDG outlet.

**MEMO DISPLAY**

Ident.: DSC-24-20-00016808.0001001 / 21 MAR 16

Applicable to: **ALL**

**EMER GEN** : This memo appears in green, when the emergency generator is running.



# **AIRCRAFT SYSTEMS**

EQUIPMENT

Intentionally left blank

**DSC-25-10 Flight Deck**



**DSC-25-10-10 General**

General.....A  
 Principles For Pushbuttons With Integrated Indications.....B  
 General Arrangement.....C

**DSC-25-10-20 Cockpit Plan**

General.....A  
 Right Rear Corner.....B  
 Left Rear Corner.....C

**DSC-25-10-30 Seats**

Pilot Seats.....A  
 Pilot Seat Mechanical Adjustment.....B  
 Pilot Seat Electrical Adjustment  .....C  
 Head Rest Adjustment  .....D  
 Armrest Adjustment.....E  
 Observer Seat.....F  
 Observer Seat Adjustment.....G  
 Armrest.....H

**DSC-25-10-40 Main Instrument Panels**

Main Instrument Panel - Captain Side.....A  
 Main Instrument Panel - First Officer Side.....B

**DSC-25-10-50 Pedestal**

Pedestal.....A

**DSC-25-10-60 Overhead Panel**

Overhead Panel.....A

**DSC-25-10-70 C/B Panels**

C/B Panels.....A

**DSC-25-10-80 Foot Warmer (If Installed)**

General.....A  
 Controls.....B

**DSC-25-20 Emergency Equipment**

Flashlights  .....A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### EQUIPMENT

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL**

Ident.: DSC-25-10-10-00020853.0001001 / 17 MAR 17

**Applicable to: ALL**

The aircraft and system controls, required for piloting the aircraft, are arranged in such a way that the crew faces forward and all crewmembers can monitor instruments and systems.

The designers concentrated system controls on the overhead panel by making extensive use of pushbuttons, directly installed in the system synoptic.

*Note: This chapter describes the panels and equipment of the basic aircraft configuration, and may not correspond to the customized configuration of a specific aircraft. For more information on the installed equipment or panels, refer to the relevant chapter's system description.*

**PRINCIPLES FOR PUSHBUTTONS WITH INTEGRATED INDICATIONS**

Ident.: DSC-25-10-10-00000983.0001001 / 21 MAR 16

**Applicable to: ALL**

Whenever possible, pushbuttons used for corrective actions, have integrated status and failure indications.

The pushbutton positions, and their illuminated indications, follow the "lights out" principle.

- While corresponding to particular aircraft configurations, indications also have the following color codes :

- Warnings  
 RED : A failure requiring immediate action.
- Cautions  
 AMBER : A failure, of which the flight crew should be aware, but does not call for immediate action.
- Indications  
 GREEN : For normal system operation.  
 BLUE : For normal operation of a system used temporarily  
 WHITE : - For an abnormal pushbutton position.  
 - For a test result or maintenance information.

When the aircraft is in a normal configuration, only green lights can be permanently lit, whereas blue lights can be intermittently.

- Pushbutton positions :

<b>POSITION</b>	<b>BASIC FUNCTION</b>
Pressed In	ON, AUTO, OVRD, OPEN
Released Out	OFF, MAN , ALTN, SHUT

- Note:*
1. Certain pushbutton lights have two dots, indicating that the corresponding part of the pushbutton is not used.
  2. Certain pushbuttons do not remain pressed in. These are referred to as "Momentary Action" pushbuttons.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**


**EQUIPMENT**

FLIGHT DECK - GENERAL

**GENERAL ARRANGEMENT**

Ident.: DSC-25-10-10-00018419.0001001 / 17 MAR 17

Applicable to: ALL





**GENERAL**


Ident.: DSC-25-10-20-00017002.0001001 / 17 MAR 17

Applicable to: ALL

The cockpit can accommodate two crewmembers, plus a third and fourth occupant  .

The two pilot seats are mounted on columns.


The third and fourth occupant seats are folding seats.



**RIGHT REAR CORNER**

Ident.: DSC-25-10-20-00000986.0001001 / 06 DEC 16


Applicable to: ALL



**LEFT REAR CORNER**

Ident.: DSC-25-10-20-00018428.0001001 / 17 MAR 17

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**EQUIPMENT**

FLIGHT DECK - COCKPIT PLAN

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**


**EQUIPMENT**


FLIGHT DECK - SEATS

**PILOT SEATS**

Ident.: DSC-25-10-30-00018429.0002001 / 17 MAR 17

Applicable to: ALL



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b> <b>EQUIPMENT</b> FLIGHT DECK - SEATS</p>
---	---

**PILOT SEAT MECHANICAL ADJUSTMENT**

Ident.: DSC-25-10-30-00000989.0001001 / 22 MAR 17  
**Applicable to: ALL**

To adjust a seat mechanically, the occupant must lift the appropriate control handle. This unlocks the seat so that it may be moved. Releasing the control handle returns it to springloaded locked position. On electrically-powered seats, the mechanical adjustment is a backup: The seat should be adjusted electrically.


**PILOT SEAT ELECTRICAL ADJUSTMENT** 

Ident.: DSC-25-10-30-00018405.0001001 / 17 MAR 17  
**Applicable to: ALL**

To adjust a seat electrically, the occupant must press the appropriate control switch in the desired direction, and release it when the seat reaches the desired position. The switch then returns to the springloaded neutral position.

To adjust the vertical position of the lumbar cushion, the occupant must:

- Pull the control out to the unlocked position
- Turn the control to adjust the position of the cushion
- Push the control into the locked position.

**HEAD REST ADJUSTMENT** 

Ident.: DSC-25-10-30-00018406.0001001 / 17 MAR 17  
**Applicable to: ALL**

To adjust the headrest in inclination, the occupant presses the inclination control button, and releases it to lock the position.  
 To control the height of the headrest, the occupant must push it horizontally, adjust the height, and release it to lock the position.

**ARMREST ADJUSTMENT**


Ident.: DSC-25-10-30-00000993.0001001 / 21 MAR 17  
**Applicable to: ALL**

To adjust the inboard armrest, the occupant must turn the knurled knob, located on the bottom surface of the armrest.

**OBSERVER SEAT**

Ident.: DSC-25-10-30-00018430.0001001 / 17 MAR 17

Applicable to: ALL







**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS  
EQUIPMENT**

FLIGHT DECK - SEATS

**OBSERVER SEAT ADJUSTMENT**

Ident.: DSC-25-10-30-00000995.0001001 / 21 MAR 17

**Applicable to: ALL**


This seat has three positions :

- Normal : Centered on aircraft axis.
- Intermediate : Clear of the cockpit entrance.
- Stowed : Seat vertical and headrest folded back. The seat is usable in this position, and does not impede access to the documents and equipment on the right side of the cockpit.

**ARMREST**

Ident.: DSC-25-10-30-00018431.0001001 / 17 MAR 17

Applicable to: **ALL**



The position of the armrest is adjustable as follows:

- A. Height adjustment
- B. Pitch adjustment

The armrest also has a memory display (C) that shows pitch and height.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**EQUIPMENT**


FLIGHT DECK - SEATS

Intentionally left blank

**MAIN INSTRUMENT PANEL - CAPTAIN SIDE**

Ident.: DSC-25-10-40-00020851.0001001 / 21 MAR 17


Applicable to: ALL



**MAIN INSTRUMENT PANEL - FIRST OFFICER SIDE**

Ident.: DSC-25-10-40-00020852.0001001 / 21 MAR 17


Applicable to: ALL



**PEDESTAL**

Ident.: DSC-25-10-50-00020854.0001001 / 17 MAR 17

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**EQUIPMENT**

FLIGHT DECK - PEDESTAL


Intentionally left blank




**OVERHEAD PANEL**

Ident.: DSC-25-10-60-00020855.0001001 / 17 MAR 17

Applicable to: ALL






**C/B PANELS**


Ident.: DSC-25-10-70-00018436.0001001 / 17 MAR 17

Applicable to: ALL

**OVERHEAD PANEL**




**RIGHT REAR PANEL**



**GENERAL**

Ident.: DSC-25-10-80-00017009.0001001 / 17 MAR 17


Applicable to: ALL

The foot warmer system  has a heating panel attached to each pedal. The temperature of the panels is about 20 °C (68 °F).

**CONTROLS**

Ident.: DSC-25-10-80-00017008.0001001 / 17 MAR 17

Applicable to: ALL

The Foot Warmer ON/OFF control switch  is located on the main instrument panel, on the captain's and first officer's side.



**FOOT WARMER sw**

Operation of the associated heating panel on captain's pedals or first officer's pedals.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**EQUIPMENT**

FLIGHT DECK - FOOT WARMER (IF INSTALLED)


Intentionally left blank

**FLASHLIGHTS** 

Ident.: DSC-25-20-00018439.0001001 / 17 MAR 17

Applicable to: ALL

Emergency flashlights are installed in a bracket at each lateral console.  
Each flashlight comes on automatically when it is removed from its bracket.  
A push-to-test button and its associated red/green LED indicate the battery status.



(1) Push-to-Test Button

Pressing this button indicates the battery status.

(2) Charge Indicator (LED)

When the Push-to-Test button is pressed:

- If the LED comes on in green (flashes green one time), the flashlight battery is charged
- If the LED comes on in red (flashes red one time), the battery is low, and should be changed
- If the LED does not come on, the flashlight system has a failure and must be repaired.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**EQUIPMENT**

EMERGENCY EQUIPMENT

Intentionally left blank



# **AIRCRAFT SYSTEMS**

## **FIRE PROTECTION**

Intentionally left blank

**DSC-26-10 General**

Description..... A

**DSC-26-20 Engines and APU**

DSC-26-20-10 System Description

Fire Detection..... A  
Extinguishing..... B  
Fire Detection and Detection Fault Logic..... C

DSC-26-20-20 Controls and Indicators

FIRE Panel..... A  
ENG MASTER Panel..... B  
EXTERNAL POWER Panel..... C  
MAINTENANCE Panel..... D

**DSC-26-30 Avionics Bay**

DSC-26-30-10 System Description

Smoke Detection..... A

DSC-26-30-20 Controls and Indicators

EMER ELEC PWR Panel..... A  
VENTILATION Panel..... B

**DSC-26-40 Lavatory**

DSC-26-40-10 System Description

Smoke Detection..... A  
Wastebin Fire Extinguishing..... B

**DSC-26-50 Cargo Compartments**

DSC-26-50-10 System Description

Smoke Detection..... A  
Fire Extinguishing..... B

DSC-26-50-20 Controls and Indicators

CARGO SMOKE Panel..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FIRE PROTECTION

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FIRE PROTECTION

GENERAL

#### DESCRIPTION

Ident.: DSC-26-10-00021387.0006001 / 17 MAR 17

**Applicable to: ALL**

The fire and smoke protection system includes:

- Fire and overheat detection for the engines and APU
- Smoke detection for the cargo compartments, the lavatories, and the avionics bay
- Fire extinguishing for the cargo compartments, the engines, the APU, and the lavatories.

In addition, the aircraft includes portable fire extinguishers in the cockpit and in the cabin areas.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FIRE PROTECTION**

GENERAL

Intentionally left blank

**FIRE DETECTION**

Ident.: DSC-26-20-10-00021393.0001001 / 17 MAR 17


Applicable to: ALL

The engines and the APU each have a fire and overheat detection system consisting of:

- Two identical detection loops (A and B) mounted in parallel
- A Fire Detection Unit (FDU).

The fire detection loops consist of:

- Three or four (as installed) engine fire sensing elements, in the pylon nacelle, in the engine core, and in the engine fan section
- One fire sensing element in the APU compartment.



When a sensing element is subjected to heat, it sends a signal to the FDU. As soon as loops A and B detect temperature above a preset level, the fire warning system is triggered.

A fault in one loop (break or loss of electrical supply) does not affect the warning system and the unaffected loop still protects the aircraft.

**EXTINGUISHING**

Ident.: DSC-26-20-10-00021395.0001001 / 04 JUL 17

Applicable to: **ALL**

**ENGINES**

Each engine has two fire extinguisher bottles, with electrically-operated squibs to discharge their agents. Each squib has a dual electric supply. The flight crew controls the discharge of the fire extinguisher bottles from the FIRE panel in the cockpit.

**APU**

The APU has one fire extinguisher bottle, with two electrically-operated squibs to discharge its agent. The flight crew controls the discharge of the fire extinguisher bottle from the FIRE panel in the cockpit. When an APU fire is detected on the ground, the APU automatically shuts down, and the extinguisher bottle discharges automatically.

**FIRE DETECTION AND DETECTION FAULT LOGIC**

Ident.: DSC-26-20-10-00021394.0001001 / 17 MAR 17

Applicable to: **ALL**

Fire detection units process all the warnings and cautions originating in the sensing elements.


- A fire warning appears, if:
  - Both loops A and B send a fire signal, or
  - One loop sends a fire signal and the other one is failed, or
  - Breaks occur in both loops within 5 s of each other (flame effect), or
  - A test is performed on the FIRE panel
- A loop-fault caution appears, if:
  - One loop is failed, or
  - Both loops are failed, or
  - The FDU fails.



**FIRE PANEL**

Applicable to: ALL

Ident.: DSC-26-20-20-10-00021396.0002001 / 17 MAR 17



Ident.: DSC-26-20-20-10-00021415.0001001 / 17 MAR 17

**ENG 1(2) FIRE PB**

The pushbutton normal position is in, and guarded. When the flight crew pushes it, the pushbutton is released and sends an electrical signal that performs the following for the corresponding engine:

- Silences the aural fire warning
- Arms the fire extinguisher squibs
- Closes the low-pressure fuel valve
- Closes the hydraulic fire shut off valve
- Closes the engine bleed valve
- Closes the pack flow control valve
- Cuts off the FADEC power supply
- Deactivates the IDG.

The red lights come on, regardless of the pushbutton position, whenever the fire warning for the corresponding engine is activated.

Ident.: DSC-26-20-20-10-00021420.0001001 / 17 MAR 17

### **AGENT 1(2) PB-SW**

Both AGENT pushbutton-switches of an affected engine become active when the flight crew releases the ENG 1(2) FIRE pb.

A brief push on the pushbutton-switch discharges the corresponding fire agent.

- “SQUIB” comes on white when the flight crew releases the ENG 1(2) FIRE pb to help the flight crew identify the AGENT pb-sw to be activated.
- “DISCH” comes on amber when the corresponding fire extinguisher bottle has lost pressure.

Ident.: DSC-26-20-20-10-00021421.0001001 / 17 MAR 17

### **ENG 1(2) FIRE TEST PB**

This pushbutton tests the operation of the fire detection and extinguishing system for ENG 1(2).

When pressed:

- A continuous repetitive chime (CRC) sounds
- The MASTER WARNING lights flash
- ENG FIRE warning appears on ECAM.
- On the FIRE panel:
  - The ENG 1(2) FIRE pb lights up red
  - The SQUIB lights come on white if discharge supplies are available
  - The DISCH lights come on amber.
- On the ENG MASTER panel (pedestal):
  - The FIRE lights come on red.

Ident.: DSC-26-20-20-10-00021423.0001001 / 17 MAR 17

### **APU FIRE PB**

The pushbutton normal position is in, and guarded. When the flight crew pushes it, the pushbutton is released and sends an electrical signal that performs the following for the APU:

- Shuts down the APU
- Silences the aural warning
- Arms the squib on the APU fire extinguisher
- Closes the low-pressure fuel valve
- Shuts off the APU fuel pump
- Closes the APU bleed valve and X bleed valve and deactivates the APU generator.

The red lights come on, regardless of the pushbutton position, whenever an APU fire warning is activated.

Ident.: DSC-26-20-20-10-00021424.0001001 / 17 MAR 17

### **AGENT PB-SW**

The APU AGENT pb-sw becomes active when the flight crew releases the APU FIRE pb. A brief push on the pushbutton-switch discharges the corresponding fire agent.

- “SQUIB” comes on white when the pilot releases the APU FIRE pb.
- “DISCH” comes on amber when the fire extinguisher bottle has lost pressure.

*Note: A red disk, which is outside at the rear of the fuselage, signals that the agent is not discharged overboard due to bottle overpressure.*

Ident.: DSC-26-20-20-10-00021425.0001001 / 17 MAR 17

### **APU FIRE TEST PB**

This pushbutton tests the operation of the APU fire detection and extinguishing system.

When pressed:


- A continuous repetitive chime (CRC) sounds
- The MASTER WARNING lights flash
- APU FIRE warning appears on ECAM.
- On the FIRE panel:
  - The APU FIRE pb lights up red
  - The SQUIB light comes on white if discharge supplies are available
  - The DISCH light comes on amber.

*Note: The automatic shutdown of the APU on the ground does not occur when the flight crew performs this test.*

**ENG MASTER PANEL**

Applicable to: ALL

Ident.: DSC-26-20-20-00021427.0001001 / 17 MAR 17



Ident.: DSC-26-20-20-00021428.0001001 / 17 MAR 17


**ENG 1(2) FIRE LIGHT**

This light identifies the engine to be shutdown in the case of fire.  
The light comes on red when an engine fire warning is triggered.

**EXTERNAL POWER PANEL**

Applicable to: ALL

Ident.: DSC-26-20-20-30-00021429.0001001 / 17 MAR 17



Ident.: DSC-26-20-20-30-00021430.0001001 / 17 MAR 17

**APU FIRE LIGHT**

The red APU FIRE light comes on and an external warning horn sounds when the system detects an APU fire.

The APU fire extinguisher discharges automatically 3 s after the appearance of the fire warning.

The light goes out when the fire has been extinguished.

Ident.: DSC-26-20-20-30-00021431.0001001 / 17 MAR 17


**APU SHUT OFF PB**

This pushbutton is used for manual APU emergency shutdown, if an emergency situation is detected on ground by the ground crew. When this pushbutton is pressed, the APU low pressure fuel shutoff valve closes, and the ECB receives a signal that starts the shutdown sequence. The shutdown sequence is the same as the APU automatic shutdown sequence, except that there is no cool down cycle. Pressing this pushbutton also silences the external warning horn.

**MAINTENANCE PANEL**

Applicable to: **ALL**

Ident.: DSC-26-20-20-40-00021432.0001001 / 17 MAR 17



Ident.: DSC-26-20-20-40-00021435.0001001 / 17 MAR 17

**TEST PB-SW**

When pressed, tests the following APU circuits:

- Fire warning
- Auto extinguishing
- Shutdown.

During the test sequence, the APU MASTER sw must be ON.

If all circuits are operating correctly, the OK light comes on.

*Note: If the APU was running, it shuts down.*

Ident.: DSC-26-20-20-40-00021436.0001001 / 17 MAR 17

**RESET PB**

When pressed, resets the test circuit.

**SMOKE DETECTION**


Ident.: DSC-26-30-10-00021401.0001001 / 17 MAR 17

**Applicable to: ALL**

The air extraction duct of the avionics ventilation system has one smoke detector.

When smoke is detected for more than 5 s:

- The Single Chime (SC) sounds
- The MASTER CAUTION lights flash
- The ECAM **AVIONICS SMOKE** alert triggers
- On the EMER ELEC PWR panel, the SMOKE light of the GEN 1 LINE pb-sw comes on
- On the VENTILATION panel, the FAULT lights of the BLOWER pb-sw and the EXTRACT pb-sw come on.






**EMER ELEC PWR PANEL**

Applicable to: ALL

Ident.: DSC-26-30-20-A-00021439.0001001 / 17 MAR 17



Ident.: DSC-26-30-20-A-00021440.0001001 / 17 MAR 17


**GEN 1 LINE PB-SW**

**SMOKE light on** : The amber light comes on when smoke is detected in the avionics ventilation duct.

**VENTILATION PANEL**

Applicable to: ALL

Ident.: DSC-26-30-20-B-00021402.0001001 / 17 MAR 17



Ident.: DSC-26-30-20-B-00021437.0001001 / 17 MAR 17

**BLOWER PB-SW**

FAULT light on : The amber light comes on when smoke is detected in the avionics ventilation duct.

Ident.: DSC-26-30-20-B-00021438.0001001 / 17 MAR 17

**EXTRACT PB-SW**

FAULT light on : The amber light comes on when smoke is detected in the avionics ventilation duct.

**SMOKE DETECTION**


Ident.: DSC-26-40-10-00021441.0001001 / 17 MAR 17

Applicable to: ALL

The lavatory smoke detection system consists of:

- One smoke detector, in the air extraction duct of the lavatory
- A double channel Smoke Detection Control Unit (SDCU) or a Cabin Intercommunication Data Systems (CIDS) with a Smoke Detection Function (SDF) that triggers the applicable alerts (cockpit and cabin).

In the case of smoke in a lavatory, the detector sends a signal to the SDCU or CIDS, which transmits it to the Flight Warning Computer (FWC) for warning in the cockpit and in the cabin.



**WASTEBIN FIRE EXTINGUISHING**

Ident.: DSC-26-40-10-00001034.0001001 / 21 MAR 16

Applicable to: ALL

Each lavatory wastebin has an automatic fire extinguishing system.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FIRE PROTECTION

LAVATORY - SYSTEM DESCRIPTION

Intentionally left blank

**SMOKE DETECTION**

Ident.: DSC-26-50-10-00021442.0003001 / 17 MAR 17

Applicable to: ALL


The forward and aft cargo compartments smoke detection system consists of:

- Two smoke detectors that are in the forward cargo compartment ceiling panel cavities. Each detector is linked to one of the two detection loops (dual loop principle).
- Four smoke detectors that are in the aft cargo compartment ceiling panel cavities. Each detector is linked to one of the two detection loops (dual loop principle).
- A Smoke Detection Control Unit (SDCU) with two identical channels, or a Cabin Intercommunication Data Systems (CIDS) with a Smoke Detection Function (SDF), that receives signals from the smoke detectors, and transmits it to the ECAM.

Smoke in one cavity activates the cargo smoke warning if:

- Both smoke detectors detect smoke, or
- One smoke detector detects smoke and the other is inoperative.

Cargo isolation valves close automatically, and the extraction fan stops when the cargo smoke warning is activated.



**FIRE EXTINGUISHING**

Ident.: DSC-26-50-10-00021443.0005001 / 17 MAR 17

Applicable to: ALL


A fire extinguishing system protects the forward and aft cargo compartments.

One fire bottle with two discharge heads, one for each compartment, supplies three nozzles:

- One nozzle in the forward cargo compartment
- Two nozzles in the aft cargo compartment.

When the flight crew presses the FWD(AFT) DISCH pb, the action ignites the corresponding squib on the fire bottle, which then discharges the extinguisher agent into that cargo compartment.

When the bottle is empty, the DISCH light comes on amber.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FIRE PROTECTION

#### CARGO COMPARTMENTS - SYSTEM DESCRIPTION


Intentionally left blank



**CARGO SMOKE PANEL**

Applicable to: ALL

Ident.: DSC-26-50-20-10-00021446.0005001 / 17 MAR 17



Ident.: DSC-26-50-20-10-00021450.0001001 / 17 MAR 17

**SMOKE LIGHT**

This red light, and the associated ECAM warning, come on when the system detects smoke in the indicated cargo compartment. This light comes on, if:

- Both channels detect smoke, or
- One channel detects smoke and the other channel is faulty.

Ident.: DSC-26-50-20-10-00021451.0002001 / 17 MAR 17

**TEST PB**

Tests the operation of the cargo smoke detection system.

When pressed for at least 3 s, and until released:

- Tests the smoke detectors in sequence
- Turns on the red SMOKE lights twice, and displays the ECAM warning
- Closes the isolation valves of the cargo ventilation system
- The DISCH lights come on in amber.

Ident.: DSC-26-50-20-10-00021452.0001001 / 17 MAR 17

**DISCH LIGHT**

Within 60 s after pressing the discharge pushbutton, the amber DISCH light comes on when the associated bottle is fully discharged.

Ident.: DSC-26-50-20-10-00021454.0001001 / 17 MAR 17

**DISCH PB**

The DISCH pb ignites the squib, thereby discharging the extinguishing agent in the affected cargo compartment.

# **AIRCRAFT SYSTEMS**

## **FLIGHT CONTROLS**

Intentionally left blank

**DSC-27-10 General**

DSC-27-10-10 General

General.....	A
Basic Principle.....	B
Control Surfaces.....	C
Cockpit Controls.....	D
Computers.....	E

DSC-27-10-20 Architecture

General Architecture.....	A
Pitch Control.....	B
Roll Control.....	C
Speed Brakes and Ground Spoilers.....	D
Yaw Control.....	E

**DSC-27-20 Flight Control System**

DSC-27-20-10 Normal Law

DSC-27-20-10-10 General

General.....	A
--------------	---

DSC-27-20-10-20 Pitch Control

Ground Mode.....	A
Flight Mode.....	B
Flare Mode.....	C
Protections.....	D

DSC-27-20-10-30 Lateral Control

Normal Law.....	A
Bank Angle Protection.....	B

DSC-27-20-10-50 Sideslip Target

Sideslip Target.....	A
----------------------	---

DSC-27-20-10-70 Aircraft Trimming

AIRCRAFT TRIMMING.....	A
------------------------	---

*Continued on the following page*

*Continued from the previous page*

**DSC-27-20-20 Reconfiguration Control Laws**

General.....	A
Flight Controls Law Reconfiguration.....	B
Alternate Law.....	C
Alternate Law Without Reduced Protection.....	D
Direct Law.....	E
Abnormal Attitude Laws.....	F
Mechanical Back-Up.....	G

**DSC-27-20-30 Controls and Indicators**

Pedestal.....	A
Lateral Consoles.....	B
Glareshield.....	C
Overhead Panel.....	D
Side Stick Indications On PFD.....	E
ECAM F/CTL Page.....	F
ECAM Wheel Page.....	G
Memo Display.....	H

**DSC-27-30 Flaps and Slats**

**DSC-27-30-10 Description**

General.....	A
Main Components.....	B
Architecture.....	C
Configurations.....	D
Alpha/Speed Lock Function (Slats).....	E

**DSC-27-30-20 Controls and Indicators**

Pedestal.....	A
ECAM Upper Display.....	B

**GENERAL**

Ident.: DSC-27-10-10-00001043.0001001 / 21 MAR 16

**Applicable to: ALL**

The fly-by-wire system was designed and certified to render the new generation of aircraft even more safe, cost effective, and pleasant to fly.

**BASIC PRINCIPLE**

Ident.: DSC-27-10-10-00001044.0001001 / 21 MAR 16

**Applicable to: ALL**

Flight control surfaces are all :

- Electrically-controlled, and
- Hydraulically-activated.


The stabilizer and rudder can also be mechanically-controlled.

Pilots use sidesticks to fly the aircraft in pitch and roll (and in yaw, indirectly, through turn coordination).

Computers interpret pilot input and move the flight control surfaces, as necessary, to follow their orders.

However, when in normal law, regardless of the pilot's input, the computers will prevent excessive maneuvers and exceedance of the safe envelope in pitch and roll axis.


However, as on conventional aircraft, the rudder has no such protection.



**CONTROL SURFACES**

Ident.: DSC-27-10-10-00001045.0001001 / 21 MAR 16

Applicable to: ALL



The flight controls are electrically or mechanically controlled as follows :

**PITCH AXIS**

- Elevator = Electrical
- Stabilizer = Electrical for normal or alternate control. Mechanical for manual trim control

**ROLL AXIS**

- Ailerons = Electrical
- Spoilers = Electrical

**YAW AXIS**

- Rudder = Mechanical, however control for yaw damping, turn coordination and trim is electrical.

**SPEED BRAKES**

- Speed brakes = Electrical

*Note: All surfaces are hydraulically actuated.*



## COCKPIT CONTROLS

Ident.: DSC-27-10-10-00001046.0001001 / 21 MAR 16

Applicable to: ALL

- Each pilot has a sidestick controller with which to exercise manual control of pitch and roll. These are on their respective lateral consoles.  
The two sidestick controllers are not coupled mechanically, and they send separate sets of signals to the flight control computers.
- Two pairs of pedals, which are rigidly interconnected, give the pilot mechanical control of the rudder.
- The pilots control speed brakes with a lever on the center pedestal.
- The pilots use mechanically interconnected handwheels on each side of the center pedestal to control the trimmable horizontal stabilizer.
- The pilots use a single switch on the center pedestal to set the rudder trim.
- There is no manual switch for trimming the ailerons.

## COMPUTERS

Ident.: DSC-27-10-10-00001047.0001001 / 21 MAR 16

Applicable to: ALL

Seven flight control computers process pilot and autopilot inputs according to normal, alternate, or direct flight control laws.

The computers are :

### **2 ELAC s**

(Elevator Aileron Computer)

For : Normal elevator and stabilizer control.  
Aileron control.

### **3 SEC s**

(Spoilers Elevator Computer)

For : Spoilers control.  
Standby elevator and stabilizer control.


### **2 FAC s**

(Flight Augmentation Computer)

For : Electrical rudder control.

**IN ADDITION 2 FCDC**

Flight Control Data Concentrators (FCDC ) acquire data from the ELAC s and SEC s and send it to the electronic instrument system (EIS ) and the centralized fault display system (CFDS).





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FLIGHT CONTROLS**


GENERAL - GENERAL

Intentionally left blank

**GENERAL ARCHITECTURE**

Ident.: DSC-27-10-20-00001048.0002001 / 13 JAN 14

Applicable to: ALL




**PITCH CONTROL**

Applicable to: ALL

Ident.: DSC-27-10-20-A-00001049.0001001 / 21 MAR 16

**GENERAL**



Two elevators and the Trimmable Horizontal Stabilizer (THS ) control the aircraft in pitch. The maximum elevator deflection is 30 ° nose up, and 17 ° nose down. The maximum THS deflection is 13.5 ° nose up, and 4 ° nose down.

Ident.: DSC-27-10-20-A-00001050.0001001 / 21 MAR 16

**ELECTRICAL CONTROL**

- In normal operations, ELAC2 controls the elevators and the horizontal stabilizer, and the green and yellow hydraulic jacks drive the left and right elevator surfaces respectively. The THS is driven by N° 1 of three electric motors.
- If a failure occurs in ELAC 2, or in the associated hydraulic systems, or with the hydraulic jacks, the system shifts pitch control to ELAC 1. ELAC 1 then controls the elevators via the blue hydraulic jacks and controls the THS via the N° 2 electric motor.
- If neither ELAC 1 nor ELAC 2 is available, the system shifts pitch control either to SEC 1 or to SEC 2, (depending on the status of the associated circuits), and to THS motor N° 2 or N° 3.

In case of failure, the actuators are reconfigured, *Refer to DSC-27-10-20 Pitch Control - Schematic.*

Ident.: DSC-27-10-20-A-00001051.0001001 / 21 MAR 16

## **MECHANICAL CONTROL**

Mechanical control of the THS is available from the pitch trim wheel at any time, if either the green or yellow hydraulic system is functioning.

Mechanical control from the pitch trim wheel has priority over electrical control.

Ident.: DSC-27-10-20-A-00001053.0002001 / 21 MAR 16

## **ACTUATION**

### **ELEVATORS**

- Two electrically-controlled hydraulic servojacks drive each elevator.

Each servojack has three control modes :


- Active : The jack position is electrically-controlled.
  - Damping : The jack follows surface movement.
  - Centering : The jack is hydraulically retained in the neutral position.
- In normal operation :
    - One jack is in active mode.
    - The other jack is in damping mode.
    - Some maneuvers cause the second jack to become active.
  - If the active servojack fails, the damped one becomes active, and the failed jack is automatically switched to damping mode.
  - If neither jack is being controlled electrically, both are automatically switched to the centering mode.
  - If neither jack is being controlled hydraulically, both are automatically switched to damping mode.
  - If one elevator fails, the deflection of the remaining elevator is limited in order to avoid putting excessive asymmetric loads on the horizontal tailplane or rear fuselage.

### **STABILIZER**

- A screwjack driven by two hydraulic motors drives the stabilizer.
- The two hydraulic motors are controlled by :
  - One of three electric motors, or
  - The mechanical trim wheel.

Ident.: DSC-27-10-20-A-00001054.0001001 / 09 OCT 12

**SCHEMATIC**






**ROLL CONTROL**

Applicable to: ALL

Ident.: DSC-27-10-20-B-00001055.0003001 / 09 OCT 12

**GENERAL**



One aileron and four spoilers on each wing control the aircraft about the roll axis.

The maximum deflection of the ailerons is 25 °.

The ailerons extend 5 ° down when the flaps are extended (aileron droop).

The maximum deflection of the spoilers is 35 °.

Ident.: DSC-27-10-20-B-00001056.0001001 / 21 MAR 16

**ELECTRIC CONTROL**

- The ELAC 1 normally controls the ailerons.  
If ELAC 1 fails, the system automatically transfers aileron control to ELAC2.  
If both ELACs fail, the ailerons revert to the damping mode.
- SEC 3 controls the N° 2 spoilers, SEC 1 the N° 3 and 4 spoilers, and SEC2 the N° 5 spoilers.  
If a SEC fails, the spoilers it controls are automatically retracted.

Ident.: DSC-27-10-20-B-00001057.0001001 / 21 MAR 16

## **ACTUATION**

### **AILERONS**

Each aileron has two electrically controlled hydraulic servojacks.  
One of these servojacks per aileron operates at a time.

Each servojack has two control modes :

- Active : Jack position is controlled electrically
- Damping : Jack follows surface movement.

The system automatically selects damping mode, if both ELACs fail or in the event of blue and green hydraulic low pressure.

### **SPOILERS**

A servojack positions each spoiler. Each servojack receives hydraulic power from either the green, yellow, or blue hydraulic system, controlled by the SEC1, 2 or 3 (*Refer to DSC-27-10-20 General Architecture diagram*).

The system automatically retracts the spoilers to their zero position, if it detects a fault or loses electrical control.

If the system loses hydraulic pressure, the spoiler retains the deflection it had at the time of the loss, or a lesser deflection if aerodynamic forces push it down.

When a spoiler surface on one wing fails, the symmetric one on the other wing is inhibited.

## **SPEED BRAKES AND GROUND SPOILERS**

Applicable to: ALL

Ident.: DSC-27-10-20-C-00001058.0011001 / 26 MAY 14

## **SPEED BRAKE CONTROL**

The pilot controls the speedbrakes with the speed brake lever.  
The speedbrakes are actually spoilers 2, 3 and 4.

Speedbrake extension is inhibited, if:

- SEC 1 and SEC 3 both have faults, or
- An elevator (L or R) has a fault, or
- Angle-of-attack protection is active, or
- Flaps are in configuration FULL, or
- Thrust levers above MCT position, or
- Alpha Floor activation.

If an inhibition occurs when the speedbrakes are extended, they retract automatically and stay retracted until the inhibition condition disappears and the pilots reset the lever. (The speedbrakes can be extended again 10 s or more after the lever is reset).

When a speedbrake surface on one wing fails, the symmetric one on the other wing is inhibited.

*Note:*

1. For maintenance purposes, the speedbrake lever will extend the N° 1 surfaces when the aircraft is stopped on ground, whatever the slat/flap configuration.
2. When the aircraft is flying faster than 315 kt or M 0.75 with the autopilot engaged, the speedbrake retraction rate is reduced (Retraction from FULL to in takes about 25 s).

**L3** The maximum speedbrake deflection in manual flight is:

40 ° for spoilers 3 and 4

20 ° for spoiler 2.

The maximum speedbrake deflection with the autopilot engaged is:

25 ° for spoilers 3 and 4


12.5 ° for spoiler 2.

The maximum speedbrake deflection achievable with the autopilot engaged is obtained by setting the speedbrake lever to the half way position. On setting the position of the speedbrake lever from half to full, no increase in speedbrake deflection will be achieved.

For these surfaces (which perform both roll and speedbrake functions) the roll function has priority. When the sum of a roll order and a simultaneous speedbrake order on one surface is greater than the maximum deflection available in flight, the same surface on the other wing is retracted until the difference between the two surfaces is equal to the roll order.

Ident.: DSC-27-10-20-C-00017787.0002001 / 28 APR 16

## **GROUND SPOILER CONTROL**

The ground spoiler function involves all spoilers (full extension) and ailerons (Aileron Anti Droop ).

When a ground spoiler surface on one wing fails, the symmetric ground spoiler surface on the other wing is inhibited.

### **ARMING**

The pilot arms the ground spoilers by pulling the speedbrake control lever up into the armed position.


## **FULL EXTENSION – REJECTED TAKEOFF PHASE**

- If the ground spoilers are armed and the speed exceeds 72 kt, the ground spoilers will automatically extend as soon as both thrust levers are reset to idle.
- If the ground spoilers are not armed and the speed exceeds 72 kt, the ground spoilers will automatically extend as soon as reverse is selected on one engine (the other thrust lever remains at idle).

## **FULL EXTENSION - LANDING PHASE**

The ground spoilers will automatically extend when the following conditions are met:

- Speed brake lever not in the retracted position or ground spoilers armed and:
  - Both main landing gears on ground,
  - Both thrust levers at or below Idle position, or Reverse selected on at least one engine (and the other thrust lever below MCT position).
- Speed brake lever in the retracted position but ground spoilers not armed and:
  - Both main landing gears on ground,
  - Reverse selected on at least one engine (and the other thrust lever below MCT position).

The ailerons are fully-extended (Aileron Anti Droop ), provided one aileron servocontrol is available on each side, when:

- The ground spoilers are fully extended
- Flaps are not in clean CONF
- Pitch attitude is lower than 2.5 °
- Flying manually
- In normal law only.

## **PARTIAL EXTENSION**

In order to accelerate the full spoiler extension, the Phased Lift Dumping (PLD) function allows the ground spoilers to deploy with a reduced deflection when the following conditions are met:

- Speed brake lever not in the retracted position or ground spoilers armed and:
  - One main landing gear on ground,
  - Both thrust levers at or below Idle position.
- Speed brake lever in the retracted position but ground spoilers not armed and:
  - One main landing gear on ground,
  - Reverse selected on at least one engine (and the other thrust lever below MCT position).

In order to reduce the bounce severity at landing in the case of an inappropriate thrust lever handling during flare, ground spoilers are also partially deployed when the following conditions are met:

- Ground spoilers armed,
- Both main landing gears on ground,
- Both thrust levers at or below the Climb position.


## **RETRACTION**

The ground spoilers retract:

- After landing,
- After a rejected takeoff, when the ground spoilers are disarmed.
- During a touch and go, when at least one thrust lever is advanced above 20 °.

Ident.: DSC-27-10-20-C-00001060.0002001 / 22 MAY 12

**ROLL CONTROL - SCHEMATIC**




**YAW CONTROL**

Applicable to: ALL

Ident.: DSC-27-10-20-D-00001061.0001001 / 09 OCT 12

**GENERAL**



One rudder surface controls yaw.

Ident.: DSC-27-10-20-D-00001062.0001001 / 21 MAR 16

**ELECTRICAL RUDDER CONTROL**

The yaw damping and turn coordination functions are automatic.

The ELAC s compute yaw orders for coordinating turns and damping yaw oscillations, and transmit them to the FACs.

Ident.: DSC-27-10-20-D-00001063.0001001 / 21 MAR 16

**MECHANICAL RUDDER CONTROL**

The pilots can use conventional rudder pedals to control the rudder.

Ident.: DSC-27-10-20-D-00001064.0001001 / 21 MAR 16

**RUDDER ACTUATION**


Three independent hydraulic servojacks, operating in parallel, actuate the rudder. In automatic operation (yaw damping, turn coordination) a green servo actuator drives all three servojacks. A yellow servo actuator remains synchronized and takes over if there is a failure.

There is no feedback to the rudder pedals from the yaw damping and turn coordination functions.

Ident.: DSC-27-10-20-D-00001065.0003001 / 21 MAR 16

**RUDDER TRAVEL LIMIT**

The maximum rudder travel deflection gradually reduces as the speed increases, to avoid structural loads:



In the case of a failure that causes loss of the Rudder Travel limit system, the rudder deflection limit stops at the last value reached. At slats extension, full rudder travel authority is recovered. In all cases, the available rudder deflection provides sufficient yaw control within the entire flight envelope. This includes the case of maximum asymmetric thrust.

Ident.: DSC-27-10-20-D-00015506.0001001 / 21 MAR 16

**RELATIONSHIP BETWEEN SIDESLIP/RUDDER DEFLECTION/RUDDER PEDAL TRAVEL**

Regardless of the aircraft speed, therefore the maximum rudder deflection, full rudder pedal travel remains available. However, except at low speed, maximum rudder deflection is achieved before reaching maximum rudder pedal travel.

Ident.: DSC-27-10-20-D-00001066.0002001 / 21 MAR 16

**RUDDER TRIM**

The two electric motors that position the artificial feel unit also trim the rudder. In normal operation, motor N° 1 (controlled by FAC 1), powers the trim, and FAC2 with motor N° 2 remains synchronized as a backup.


In manual flight, the pilot can apply rudder trim via the rotary RUD TRIM switch on the pedestal. The pilot can use a button on the RUD TRIM panel to reset the rudder trim to zero.

*Note: With the autopilot engaged, the FMGC computes the rudder trim orders. The rudder trim rotary switch and the rudder trim reset pushbutton are not active.*



Ident.: DSC-27-10-20-D-00001067.0001001 / 21 MAR 16

**SCHEMATIC**





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FLIGHT CONTROLS**

GENERAL - ARCHITECTURE

Intentionally left blank

**General**


**GENERAL**

Ident.: DSC-27-20-10-10-00001068.0001001 / 17 MAR 17

Applicable to: ALL

Flight control normal law covers:

- three-axis control
- flight envelope protection
- alleviation of maneuver loads



One of the PF's primary tasks is to maintain the aircraft within the limits of the normal flight envelope. However, some circumstances, due to extreme situations or aircraft mishandling, may provoke the violation of these limits.

Despite system protections, the PF must not exceed deliberately the normal flight envelope. In addition, these protections are not designed to be structural limit protections (e.g. opposite rudder pedal inputs). Rather, they are designed to assist the PF in emergency and stressful situations, where only instinctive and rapid reactions will be effective.

Protections are intended to:

- Provide full authority to the PF to consistently achieve the best possible aircraft performance in extreme conditions
- Reduce the risks of overcontrolling, or overstressing the aircraft
- Provide PF with an instinctive and immediate procedure to ensure that the PF achieves the best possible result.

### Pitch Control

#### GROUND MODE

Ident.: DSC-27-20-10-20-00001069.0001001 / 20 SEP 13

Applicable to: ALL

Ground mode is a direct relationship between sidestick deflection and elevator deflection, without auto trim.

It automatically sets the trimmable horizontal stabilizer (THS) at 0 ° (inside the green band).

A setting that the pilot enters manually to adjust for CG has priority for takeoff.

When the aircraft reaches 75 kt during the takeoff roll, the system reduces the maximum up elevator deflection from 30 ° to 20 °.

#### FLIGHT MODE

Ident.: DSC-27-20-10-20-00001070.0003001 / 17 MAR 17

Applicable to: ALL

The normal-law flight mode is a load-factor-demand mode with automatic trim and protection throughout the flight envelope.


Following normal law, the sidestick controllers set the elevator and THS to maintain load factor proportional to stick deflection and independent of speed.

With the sidestick at neutral, wings level, the system maintains 1 g in pitch (corrected for pitch attitude), and there is no need for the pilot to trim by changing speed or configuration. Therefore pilots only need to perform minor corrections on the sidestick, if the aircraft deviates from its intended flight path. If the pilot senses an overcontrol, the sidestick should be released.

Pitch trim is automatic both in manual mode and when the autopilot is engaged. In normal turns (up to 33 ° of bank) the pilot does not have to make any pitch corrections once the turn is established.

The flight mode is active from takeoff to landing, and follows the logic shown schematically (*Refer to DSC-27-20-10-10 General*).

Airbus Pitch Characteristic



Automatic pitch trim freezes in the following situations:

- The pilot enters a manual trim order.
- The radio height is below 50 ft (100 ft with autopilot engaged).
- The load factor goes below 0.5 g.

When angle-of-attack protection is active, the THS setting is limited between the setting at the aircraft's entry into this protection and 3.5 ° nose down. (Neither the pilot nor the system can apply additional nose-up trim).

Similarly, when the load factor is higher than 1.25 g or when the aircraft exceeds 33 ° of bank, the THS setting is limited to values between the actual setting and 3.5 ° nose down.

When High Speed or High Mach Protection is active, the THS Setting is limited between the setting at the aircraft's entry into this protection and 11 ° nose-up.

**CONTROL WITH AUTOPILOT ENGAGED**

- The ELAC s and SECs limit what the autopilot can order.
- The pilot has to overcome a restraining force in order to move the sidestick when the autopilot is engaged. If he overcomes this force, he disconnects the autopilot.

- The pilot can also disconnect the autopilot by pushing on the rudder pedals (10 ° out of trim), or by moving the pitch trim wheel beyond a certain threshold.
- All protections of normal laws remain effective except pitch attitude protection.

**FLARE MODE**

Ident.: DSC-27-20-10-20-00001071.0001001 / 21 MAR 16

Applicable to: ALL

When the aircraft passes 50 ft RA, the THS is frozen and the normal flight mode changes to flare mode as the aircraft descends to land. Flare mode is essentially a direct stick-to-elevator relationship (with some damping provided by the load factor and the pitch rate feedbacks).

The system memorizes the aircraft's attitude at 50 ft, and it becomes the initial reference for pitch attitude control.

As the aircraft descends through 30 ft, the system begins to reduce the pitch attitude to -2 °nose down over a period of 8 s. Consequently, to flare the aircraft, a gentle nose-up action by the pilot is required.

**PROTECTIONS**


Applicable to: ALL

Ident.: DSC-27-20-10-20-A-00001072.0001001 / 21 MAR 16

**GENERAL**

The normal law protects the aircraft throughout the flight envelope, as follows :

- load factor limitation
- pitch attitude protection
- high-angle-of-attack (AOA) protection
- high-speed protection.



**LOAD FACTOR PROTECTION**


High load factors can be encountered during evasive maneuvers due to potential collisions, or CFIT ...

Pulling "g" is efficient, if the resulting maneuver is really flown with this "g" number. If the aircraft is not able to fly this trajectory, or to perform this maneuver, pulling "g" will be detrimental.

The load factor is automatically limited to:

- +2.5 g to -1 g for clean configuration.
- +2 g to 0 for other configurations.

Airbus LOAD FACTOR PROTECTION AND SAFETY



On most commercial aircraft, the potential for an efficient 2.5 g maneuver is very remote. Furthermore, as G Load information is not continuously provided in the cockpit, airline pilots are not used to controlling this parameter. This is further evidenced by inflight experience, which reveals that: In emergency situations, initial PF reaction on a yoke or sidestick is hesitant, then aggressive.

With load factor protection, the PF may immediately and instinctively pull the sidestick full aft: The aircraft will initially fly a 2.5 g maneuver without losing time. Then, if the PF still needs to maintain the sidestick full aft stick, because the danger still exists, then the high AOA protection will take over. Load factor protection enhances this high AOA protection.

Load factor protection enables immediate PF reaction, without any risk of overstressing the aircraft.

Flight experience has also revealed that an immediate 2.5 g reaction provides larger obstacle clearance, than a hesitant and delayed high G Load maneuver (two-second delay).



Ident.: DSC-27-20-10-20-A-00001074.0001001 / 17 MAR 17

## **PITCH ATTITUDE PROTECTION**

Excessive pitch attitudes, caused by upsets or inappropriate maneuvers, lead to hazardous situations:

- Too high a nose-up ► Very rapid energy loss
- Too low a nose-down ► Very rapid energy gain

Furthermore, there is no emergency situation that requires flying at excessive attitudes. For these reasons, pitch attitude protection limits pitch attitude:

- 30 ° nose up in conf 0 to 3 (progressively reduced to 25 ° at low speed).
- 25 ° nose up in conf FULL (progressively reduced to 20 ° at low speed).
- 15 ° nose down (indicated by green symbols “=” on the PFD’s pitch scale).

The flight director bars disappear from the PFD when the pitch attitude exceeds 25 ° up or 13 ° down. They return to the display when the pitch angle returns to the region between 22 ° up and 10 ° down.

Pitch attitude protection enhances high speed protection, high load factor protection, and high AOA protection.

Ident.: DSC-27-20-10-20-A-00001075.0002001 / 17 MAR 17


## **HIGH ANGLE-OF-ATTACK PROTECTION**

In the normal law, the aircraft is protected against stall, in dynamic maneuvers or gusts. When the current angle-of-attack becomes greater than  $\alpha_{PROT}$ , the high angle-of-attack (AOA) protection activates.

Without pilot input, the F/CTL computers will maintain the AOA equal to  $\alpha_{PROT}$ . The AOA can be further increased by the pilot input, up to a maximum value equal to  $\alpha_{MAX}$ . When the High AOA protection is activated, the normal law demand is modified and the side stick input is an angle-of-attack demand, instead of a load factor demand.

The PF must not deliberately fly the aircraft in the High AOA, except for brief periods, when maximum maneuvering speed is required.

Airbus AOA Protection



$V_{\alpha}$  PROT ,  $V_{\alpha}$  floor,  $V_{\alpha}$  MAX are mainly computed based on the AOA, and therefore they vary with configuration, weight and load factor.

Refer to DSC-22\_10-50-20 *Characteristic Speeds* for more information.

The angle-of-attack will not exceed  $\alpha_{MAX}$  , even if the pilot gently pulls the sidestick all the way back. The pilot can hold full back stick, if it is needed, and the aircraft stabilizes at an angle-of-attack close to but less than the 1 g stall. When flying at  $\alpha_{MAX}$  , the PF can make gentle turns, if necessary. If the pilot releases the sidestick, the angle-of-attack returns to  $\alpha_{PROT}$  and stays there. As the aircraft enters protection at the amber and black strip ( $\alpha_{PROT}$ ), the system inhibits further nose-up trim beyond the point already reached. The nose-down trim remains available, if the pilot pushes the stick forward.

Note: At takeoff, the  $\alpha_{PROT}$  is equal to the  $\alpha_{MAX}$  for 5 s.

This High AOA protection has priority over all other protections.

The aircraft can also enter  $\alpha_{PROT}$  at a high flight level, where it protects the aircraft from the buffet boundary. As at a low speed or low flight level, if the sidestick is merely released to neutral, the aircraft maintains the alpha for  $\alpha_{PROT}$  . This value of alpha is not the same as the value used at the low speed. Alpha for  $\alpha_{PROT}$  is reduced as a function of Mach, so that a typical cruise value is about 3.5 ° for the A318 and A321 aircraft, or 4.5 ° for the A319 and A320 aircraft. Therefore, the aircraft may climb with the sidestick free, when leaving a turn after entering  $\alpha_{PROT}$ .

If the pilot flies into  $\alpha$ PROT, he should leave it as soon as other considerations allow, by easing forward on the sidestick to reduce alpha below the value of  $\alpha$ PROT, while simultaneously adding power (if the  $\alpha$ floor has not yet been activated, or cancelled).

To deactivate the angle of attack protection, the pilot must push the sidestick:

- Greater than  $8^\circ$  forward, or,
- Greater than  $0.5^\circ$  for at least 0.5 s when  $\alpha < \alpha$ MAX.

In addition, below 200 ft, the angle of attack protection is also deactivated, when:


- Sidestick deflection is less than half nose-up, and
- Actual  $\alpha$  is less than  $\alpha$ PROT –  $2^\circ$ .

Between the  $\alpha$ PROT and  $\alpha$ MAX,  $\alpha$ floor protection may automatically set the go-around thrust. The  $\alpha$ floor will usually be triggered just after entering  $\alpha$ PROT, and the go-around thrust will automatically be applied. Therefore, if the sidestick is held aft, either inadvertently or deliberately, the aircraft will start to climb at a relatively constant low airspeed. To recover a normal flight condition, the  $\alpha$ PROT should be exited by easing forward on the sidestick, as described above, and the  $\alpha$ floor should be cancelled by using the disconnect pushbutton on either thrust lever as soon as a safe speed is regained. *Refer to DSC-22\_40-30 Alpha-Floor Protection* for more information.

#### **GPWS / WINDSHEAR CASE:**

In the case of application of GPWS or windshear procedures, aircraft protections provide maximum lift / maximum thrust / minimum drag. Therefore, CFIT escape manoeuvres will be much more efficient.

Protected A/C Versus Non-protected A/C Go-around Trajectory



The above-illustrated are typical trajectories flown by protected or not protected aircraft, when the PF applies the escape procedure after an aural “ GPWS PULL UP” alert. The graph demonstrates the efficiency of the protection, to ensure a duck-under that is 50 % lower, a bucket-distance that is 50 % shorter, a safety margin that more than doubles (due to a quicker reaction time), and a significant altitude gain ( $\pm 250$  ft). These characteristics are common to all protected aircraft, because the escape procedure is easy to achieve, and enables the PF to fly the aircraft at a constant AOA , close to the max AOA . It is much more difficult to fly the stick shaker AOA on an aircraft that is not protected.

Ident.: DSC-27-20-10-20-A-00001076.0002001 / 17 MAR 17

**HIGH SPEED PROTECTION**


The aircraft automatically recovers, following a high speed upset. Depending on the flight conditions (high acceleration, low pitch attitude), High Speed Protection is activated at/or above VMO /MMO.

When it is activated, the THS setting is limited between the setting at the aircraft’s entry into this protection and 11 ° nose-up. Positive spiral static stability is introduced to 0 ° bank angle (instead of 33 ° in normal law), so that with the sidestick released, the aircraft always returns to a bank angle of 0 °. The bank angle limit is reduced from 67 ° to 40 °.

As the speed increases above VMO /MMO, the sidestick nose-down authority is progressively reduced, and a permanent nose-up order is applied to aid recovery to normal flight conditions.

Therefore, in a dive situation:

- If there is no sidestick input on the sidestick, the aircraft will slightly overshoot VMO /MMO and fly back towards the envelope.
- If the sidestick is maintained full forward, the aircraft will significantly overshoot VMO /MMO . At approximately VMO +16 / MMO +0.04, the pitch nose-down authority smoothly reduces to zero (which does not mean that the aircraft stabilizes at that speed).




The PF, therefore, has full authority to perform a high speed/steep dive escape maneuver, when required, via a reflex action on the sidestick.

High Speed Protection is deactivated, when the aircraft speed decreases below VMO /MMO, where the usual normal control laws are recovered.

The autopilot disconnects at VMO + 15 kt and MMO + 0.04.

High speed protection symbol: }  
 Two green bars at VMO + 6



- Note:
1. The ECAM displays an "O/SPEED" warning at VMO + 4 kt and MMO + 0.006.
  2. At high altitude, this may result in activation of the angle of attack protection.  
 Depending on the ELAC standard, the crew may have to push on the stick to get out of this protection law.

Ident.: DSC-27-20-10-20-A-00001077.0001001 / 21 MAR 16

**LOW ENERGY AURAL ALERT ( IF INSTALLED)**

The low energy aural alert is computed by the FAC (*Refer to DSC-22\_40-10 General*).

## Lateral Control

### NORMAL LAW

Ident.: DSC-27-20-10-30-00001078.0001001 / 17 MAR 17

Applicable to: ALL


When the aircraft is on the ground (in “on ground” mode), the sidestick commands the aileron and roll spoiler surface deflection. The amount of control surface deflection that results from a given amount of sidestick deflection depends upon aircraft speed. The pedals control rudder deflection through a direct mechanical linkage. The aircraft smoothly transitions to “in flight” mode shortly after liftoff. When the aircraft is in the “in flight” mode, normal law combines control of the ailerons, spoilers (except N° 1 spoilers), and rudder (for turn coordination) in the sidestick. The pilot does not need to use the rudder for turn coordination. While the system thereby gives the pilot control of the roll and heading, it also limits the roll rate and bank angle, coordinates the turns, and damps the dutch roll. The roll rate requested by the pilot during flight is proportional to the sidestick deflection, with a maximum rate of 15 °/s when the sidestick is at the stop. When the aircraft is in “flare” mode, the lateral control is the same as in “in flight” mode. After touchdown, the aircraft smoothly transitions from “in flight” mode to “ground” mode.

### BANK ANGLE PROTECTION

Ident.: DSC-27-20-10-30-00001079.0001001 / 17 MAR 17

Applicable to: ALL

Inside the normal flight envelope, the system maintains positive spiral static stability for bank angles above 33 °. If the pilot releases the sidestick at a bank angle greater than 33 °, the bank angle automatically reduces to 33 °. Up to 33 °, the system holds the roll attitude constant when the sidestick is at neutral. If the pilot holds full lateral sidestick deflection, the bank angle goes to 67 ° and no further. If Angle-of-Attack protection is active, and the pilot maintains full lateral deflection on the sidestick, the bank angle will not go beyond 45 °. If High Speed Protection is active, and the pilot maintains full lateral deflection on the sidestick, the bank angle will not go beyond 40 °. If high speed protection is operative, the system maintains positive spiral static stability from a bank angle of 0 °, so that with the sidestick released, the aircraft always returns to a bank angle of 0 °. When bank angle protection is active, auto trim is inoperative. If the bank angle exceeds 45 °, the autopilot disconnects and the FD bars disappear. The FD bars return when the bank angle decreases to less than 40 °.



During a normal turn (bank angle less than 33 °), in level flight:

- The PF moves the sidestick laterally (the more the sidestick is moved laterally, the greater the resulting roll rate - e.g. 15 °/s at max deflection)
- It is not necessary to make a pitch correction
- It is not necessary to use the rudder.

In the case of steep turns (bank angle greater than 33 °), the PF must apply:

- Lateral pressure on the sidestick to maintain bank
- Aft pressure on the sidestick to maintain level flight.



**Sideslip Target**


**SIDESLIP TARGET**

Ident.: DSC-27-20-10-50-00001081.0001001 / 17 MAR 17

Applicable to: ALL

If one engine fails, the FAC modifies the sideslip indication slightly to show the pilot how much rudder to use to get the best climb performance (ailerons to neutral and spoilers retracted).

In the case of an engine failure at takeoff, or at go-around, the sideslip index on the PFD changes from yellow to blue (to provide the conditions for the blue display of the sideslip target, *Refer to DSC-31-40 Attitude Data*).



In flight, the lateral normal law commands some rudder surface deflection to minimize the sideslip. The pilot's response is normal and instinctive: zero the slip indication by applying the right amount of rudder to get the best climb performance.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FLIGHT CONTROLS

FLIGHT CONTROL SYSTEM - NORMAL LAW

Intentionally left blank

## Aircraft Trimming

### AIRCRAFT TRIMMING

Ident.: DSC-27-20-10-70-00002179.0001001 / 09 DEC 09

Applicable to: ALL

When the aircraft is :

- In normal cruise range (around M .77),
- In straight flight,
- With the autopilot engaged,
- With symmetrical engine thrust, and
- With fuel in the wing tanks distributed symmetrically,

the rudder trim should stay between  $1^\circ$  right and  $2.3^\circ$  left.

Note: *This indication corresponds to a true rudder deflection within  $\pm 1.5^\circ$ , taking into account the permanent offset of rudder trim indication, when the aircraft is in cruise conditions. (average  $0.5^\circ$  right,  $0.8^\circ$  left).*

*An indicated, rudder trim above  $1^\circ$  right or  $2.3^\circ$  left is acceptable, if maintenance personnel establishes that the corresponding real rudder position is within  $1.5^\circ$  left, and  $1.5^\circ$  right.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FLIGHT CONTROLS

FLIGHT CONTROL SYSTEM - NORMAL LAW

Intentionally left blank

**GENERAL**

Ident.: DSC-27-20-20-00001082.0001001 / 17 MAR 17

Applicable to: ALL

Depending on the failures occurring to the flight control system, or on its peripherals, there are 3 levels of reconfiguration :

- Alternate law  
They are two levels of alternate law : with and without reduced protections.
- Direct law
- Mechanical

The ECAM and PFD indicate any control law degradation.

**ON THE ECAM**

● **In ALTN Law:**

FLT CTL ALTN LAW (PROT LOST)

MAX SPEED                      320 kt (320 kt/M 0.77 on A318)

● **In Direct Law:**

FLT CTL DIRECT LAW (PROT LOST)

MAX SPEED                      320 kt/M 0.77

MAN PITCH TRIM USE

**ON THE PFD**


The PFD enhances the PF's awareness of the status of flight controls.

Specific symbols (= in green), and specific formatting of low speed information on the speed scale in normal law, indicate which protections are available.

When protections are lost, amber crosses (X) appear, instead of the green protection symbols (=).

When automatic pitch trim is no longer available, the PFD indicates this with an amber "USE MAN PITCH TRIM" message below the FMA.

Fly-by-Wire Status Awareness via the PFD




Therefore, by simply looking at this main instrument (PFD), the flight crew is immediately aware of the status of flight controls, and the operational consequences.

**FLIGHT CONTROLS LAW RECONFIGURATION**

Ident.: DSC-27-20-20-00001083.0001001 / 22 MAY 12


Applicable to: ALL



**ALTERNATE LAW**

Ident.: DSC-27-20-20-00001084.0001001 / 21 AUG 15

Applicable to: **ALL**



- (1) OR SLATS OR FLAPS  $\geq 2$  IF L/G INFORMATION NO LONGER AVAILABLE (LGCIU 1+2 FAULT OR SEC 1+2+3 FAULT)
- (2) OR SLATS OR FLAPS  $< 2$  IF L/G INFORMATION NO LONGER AVAILABLE (LGCIU 1+2 FAULT OR SEC 1+2+3 FAULT)
- (3) Refer to DSC-27-20-20 Flight Controls Law Reconfiguration.

**PITCH CONTROL**

**GROUND MODE**

Under alternate law the ground mode becomes active on the ground 5 s after touchdown. It is identical to the ground mode of the normal law.

**FLIGHT MODE**

In flight, the alternate law pitch mode follows a load-factor demand law much as the normal law pitch mode does, but it has less built-in protection (reduced protections).



## **FLARE MODE**

In pitch alternate law the flight mode changes to the flare mode when the pilot selects landing gear down. The flare mode is a direct stick-to-elevator relationship. (*Refer to DSC-27-20-20 Direct Law*).

## **LATERAL CONTROL**

When the aircraft flying in pitch alternate law, lateral control follows the roll direct law associated with yaw alternate or mechanical.

### **ROLL DIRECT LAW**

*Refer to DSC-27-20-20 Direct Law.*

### **YAW ALTERNATE LAW**

Only the yaw damping function is available. Damper authority is limited to  $\pm 5^\circ$  of rudder deflection.

## **REDUCED PROTECTIONS**

### **LOAD FACTOR LIMITATION**

The load factor limitation is similar to that under normal law.

### **PITCH ATTITUDE PROTECTION**

There is no pitch attitude protection. Amber Xs replace the green double bars “=” on the PFD.

### **LOW SPEED STABILITY**

An artificial low speed stability replaces the normal angle-of-attack protection. It is available for all slat/flap configurations, and the low speed stability is active from about 5 kt up to about 10 kt above stall warning speed, depending on the aircraft's gross weight and slats/flaps configuration.


A gentle progressive nose down signal is introduced, which tends to keep the speed from falling below these values. The pilot can override this demand.

The system also injects bank-angle compensation, so that operation effectively maintains a constant angle of attack.

In addition, audio stall warnings (crickets + “STALL” synthetic voice message) is activated at an appropriate margin from the stall condition.

The PFD speed scale is modified to show a black/red barber pole below the stall warning.

The  $\alpha$  floor protection is inoperative.



**HIGH SPEED STABILITY**

Above VMO or MMO, a nose up demand is introduced to avoid an excessive increase in speed. The pilot can override this demand.

In addition, the aural overspeed warning (VMO + 4 or MMO + 0.006) remains available.

**BANK ANGLE PROTECTION**

Not provided.

Note: The AP will disconnect, if speed exceeds VMO /MMO, or if the bank angle exceeds 45 °.

**ALTERNATE LAW WITHOUT REDUCED PROTECTION**

Ident.: DSC-27-20-20-00001085.0001001 / 21 MAR 16

Applicable to: ALL

This is identical to alternate law except that it does not include the low-speed stability or the high-speed stability. It includes only the load factor limitation.

**DIRECT LAW**

Ident.: DSC-27-20-20-00001086.0001001 / 21 MAR 16

Applicable to: ALL

**PITCH CONTROL**

The pitch direct law is a direct stick-to-elevator relationship (elevator deflection is proportional to stick deflection).

In all configurations the maximum elevator deflection varies as a function of CG.

It is a compromise between adequate controllability with the CG forward, and not-too-sensitive control with the CG aft.

There is no automatic trim : the pilot must trim manually.

The PFD displays in amber the message "USE MAN PITCH TRIM".

No protections are operative.

The  $\alpha$  floor function is inoperative.

Overspeed and stall warnings are available as for alternate law.

### **LATERAL CONTROL**

When flying in "direct law", the roll direct law associated with mechanical yaw control governs lateral control.

#### **ROLL DIRECT LAW**

The roll direct law is a direct stick-to-surface-position relationship. System gains are set automatically to correspond to slat/flap configuration.

With the aircraft in the clean configuration, the maximum roll rate is about 30 °/s.

With slats extended, it is about 25 °/s.

To limit roll rate, the roll direct law uses only ailerons and spoilers N° 4 and 5.

If spoiler N° 4 has failed, spoiler N° 3 replaces it.

If the ailerons have failed, all roll spoilers become active.

#### **YAW MECHANICAL CONTROL**

The pilot controls yaw with the rudder pedals.

The yaw damping and turn coordination functions are lost.

### **ABNORMAL ATTITUDE LAWS**

Ident.: DSC-27-20-20-00001087.0002001 / 18 JAN 17

Applicable to: ALL

If for any reason the aircraft goes far outside the normal flight envelope and reaches an extreme attitude, the flight control law will be modified.

The abnormal attitude law will engage and will provide the PF with maximum efficiency to recover normal attitude.

☒ The abnormal attitude law engages when one of the following values is reached:

- Bank angle above 125 °
- Pitch attitude above 50 ° nose up or below 30 ° nose down
- Speed below 60 to 90 kt (depending on the aircraft pitch attitude), or above 440 kt
- Mach above 0.91
- Angle of attack above 30 ° to 40 °, or below -10 °

ⓘ When the abnormal attitude law engages:

- The pitch alternate law is active with no protection, except load-factor protection and without autotrim.
- The roll direct law is active
- The yaw mechanical law is active.

When the aircraft returns within the normal flight envelope, the abnormal attitude law disengages and the following conditions remains for the remainder of the flight:

- The pitch alternate law is active with no protection and with autotrim.
- The roll direct law is active
- The yaw alternate law is active.

**MECHANICAL BACK-UP**


Ident.: DSC-27-20-20-00001088.0001001 / 17 MAR 17

Applicable to: **ALL**

The purpose of the mechanical backup is to achieve all safety objectives in MMEL dispatch condition: to manage a temporary and total electrical loss, the temporary loss of five fly-by-wire computers, the loss of both elevators, or the total loss of ailerons and spoilers.

**PITCH**

The pilot manually applies trim to the THS to control the aircraft in pitch.  
 The PFDs display “MAN PITCH TRIM ONLY” in red.



**LATERAL**

The pilot uses the rudder pedals as the mechanical backup to laterally control the aircraft .



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FLIGHT CONTROLS


FLIGHT CONTROL SYSTEM - RECONFIGURATION CONTROL LAWS

Intentionally left blank

**PEDESTAL**

Ident.: DSC-27-20-30-00001090.0002001 / 08 JUL 15

Applicable to: ALL



(1) RUD TRIM rotary selector

Controls the rudder trim actuator, which moves the neutral point of the artificial feel by the equivalent of one degree of rudder travel per second.

*Note:* The rudder trim rotary selector has no effect, when the autopilot is engaged.

(2) RESET pb

By pushing the RESET pb, the zero trim position is ordered at 1.5 °/s.

After the reset, an indication of up to 0.3° (L or R) may be observed in the rudder trim position indication.

*Note:* The RESET pb is not active, when the autopilot is engaged.

(3) Position Indicator

Displays the rudder trim direction (L or R) and value.

(4) SPEEDBRAKE lever

The lever controls:

- The position of the speedbrake surfaces.

To set speedbrake surfaces to a required position, the lever has to be pushed down and set to the required position. A “hardpoint” is provided at “½” SPEEDBRAKE position.

- The manual preselection of the ground spoilers.

To arm the ground spoilers, the lever must be pulled up when in the RET position.

When the lever is armed (or reverse thrust is selected), all spoiler’s surfaces will automatically extend at landing, or in case of a rejected takeoff.

(5) PITCH TRIM Wheel

Both pitch trim wheels provide mechanical control of the THS and have priority over electrical control. A pilot action on the pitch trim wheel disconnects the autopilot.

*Note:* Crew action on the pitch trim wheel does not disconnect the ELACs (micro-switches, actuated by the override mechanism, ensure that the computers remain synchronized with the manually-selected position).



The THS is manually-controlled on ground for the THS setting, before takeoff and in flight, when in direct law.

- Before takeoff, the pilot sets the THS to the angular value, determined as a function of the aircraft CG , using the CG scale on the wheel. The relationship between the aircraft CG and the THS setting shown on the trim wheel is only applicable for takeoff. The limits of the THS normal setting range for takeoff are indicated by a green band on the pitch trim wheel.
- In flight, when in direct law, the pilot uses the THS conventionally to fly in trim. In flight, the aircraft pitch trim setting depends on aircraft CG , weight, altitude and speed. Consequently, the relation between the aircraft CG , and the THS setting displayed on the pitch trim wheel, does not apply in flight.

Following nosewheel touchdown, as the pitch attitude becomes less than 2.5 ° for more than 5 s, pitch trim is automatically reset to zero.

Note: *This function is inoperative, when the green or yellow hydraulic system is not pressurized.*

## LATERAL CONSOLES

Ident.: DSC-27-20-30-00001091.0004001 / 17 MAR 17

Applicable to: ALL


### SIDESTICKS

Each pilot has on his lateral console a sidestick he can use to control pitch and roll manually. Each sidestick is springloaded to neutral.

When the autopilot is engaged, a solenoid-operated detent locks both sidesticks in the neutral position. If the pilot applies a force above a given threshold (5 daN in pitch, 3.5 daN in roll) the stick becomes free and the autopilot disengages.

The hand grip has two switches:

- Autopilot disconnect and sidestick takeover pushbutton.
- Push-to-talk button.



### **Sidestick priority logic**

- When only one pilot operates the sidestick, it sends his control signals to the computers.
- When the pilots move both side stick simultaneously in the same or opposite direction and neither takes priority, the system adds the signals of both pilots algebraically. The total is limited to the signal that would result from the maximum deflection of a single sidestick.

*Note: In the event of simultaneous input on both sidesticks (2 ° deflection off the neutral position in any direction) the two green SIDE STICK PRIORITY lights on the glareshield come on and "DUAL INPUT" voice message is activated.*

A pilot can deactivate the other stick and take full control by pressing and keeping pressed his priority takeover pushbutton.

For latching the priority condition, it is recommended to press the takeover push button for more than 40 s.

This allows the pilot to release his takeover push button without losing priority.

However, a pilot can at any time reactivate a deactivated stick by momentarily pressing the takeover push button on either stick.

If both pilots press their takeover pushbuttons, the pilot that presses last gets priority.

In case of a "SIDE STICK FAULT" ECAM warning, due to an electrical failure, the affected sidestick order (sent to the computer) is forced to zero. This automatically deactivates the affected sidestick. This explains why there is no procedure associated with this warning.

*Note: If an autopilot is engaged, any action on a takeover pushbutton disengages it.*

### **In a priority situation**


- A red light comes on in front of the pilot whose stick is deactivated.
- A green light comes on in front of the pilot who has taken control, if the other stick is not in the neutral position (to indicate a potential and unwanted control demand).

*Note: If the aircraft is on the ground and commencing its takeoff run and one stick is deactivated, this triggers the takeoff "CONFIG" warning.*

**GLARESHIELD**

Ident.: DSC-27-20-30-00001092.0002001 / 21 MAR 16

Applicable to: ALL



(1) SIDE STICK PRIORITY It

- Red arrow light :
- comes on in front of the pilot losing authority.
  - goes out if he has recovered his authority
    - if the other pilot releases his TAKEOVER pushbutton prior the priority condition is latched.
    - or
    - If he has used his takeover push button to cancel a latched priority situation.
- Sidestick priority audio : A “PRIORITY LEFT” or “PRIORITY RIGHT” audio voice message is given each time priority is taken.



Green CAPT and F/O lights :

- Both lights flash when the pilots move both sidesticks simultaneously and neither takes priority.
- When a pilot has taken priority by pressing the takeover pushbutton and the other pilot's sidestick is not at neutral, the light in front of the pilot with priority lights up. It goes out when the other pilot returns his stick to the neutral position.



**OVERHEAD PANEL**

Ident.: DSC-27-20-30-00017869.0001001 / 19 SEP 16

Applicable to: ALL



- (1) ELAC 1(2) pushbutton  
 Controls the Elevator and Aileron Computer (ELAC) 1(2).


- ON : ELAC 1(2) performs the following functions :
- Normal pitch and roll, normal LAF 
  - Alternate pitch, alternate LAF 
  - Direct pitch and roll
  - Abnormal attitude
  - Aileron droop
  - Acquisition of autopilot orders.
- OFF : The corresponding computer is not active. Switching it OFF, then ON, resets the computer.
- FAULT : Comes on amber, along with an ECAM caution:
- When a failure is detected
  - During ELAC power-up test (eight seconds).

*Note: The ELAC power-up test occurs when electrical power is turned on, or after the occurrence of an electrical transient lasting longer than 25 ms.*

The FAULT light goes off, when the pilot selects OFF, or at the end of the ELAC power-up test, if its results are satisfactory.

(2) SEC 1(2)(3) pushbutton

Controls the Spoiler and Elevator Computer (SEC) 1(2)(3).

- ON : SEC 1(2)(3) performs the following functions:
- Normal roll (by controlling the spoilers)
  - Speed brakes and ground spoilers
  - Alternate pitch (SEC 1 and SEC 2 only)
  - Direct pitch (SEC 1 and SEC 2 only)
  - Direct roll
  - Alternate LAF 
  - Abnormal attitude.
- OFF : The corresponding computer is not active. Switching it OFF, then ON, resets the computer.
- FAULT : Comes on amber, along with an ECAM caution, when a failure is detected.  
The FAULT light goes off, when the pilot selects OFF.

(3) FAC 1(2) pushbutton

Controls the Flight Augmentation Computer (FAC) 1(2).


- ON** : Both FACs perform the following functions:
- Normal roll (coordinating turns and damping dutch roll)
  - Rudder trim
  - Rudder travel limit
  - Alternate yaw
- OFF** : The corresponding computer is not active. Switching it OFF, and then ON, resets the computer.
- FAULT** : Comes on amber, along with an ECAM caution, when a failure is detected. The FAULT light goes off, when the pilot selects OFF.

**SIDE STICK INDICATIONS ON PFD**

Ident.: DSC-27-20-30-00001094.0001001 / 21 MAR 16

Applicable to: ALL


On the ground, after the first engine start, sidestick position indications appear white on both PFDs. The indications disappear when the aircraft goes from the ground into flight.



**ECAM F/CTL PAGE**

Ident.: DSC-27-20-30-00001095.0004001 / 15 OCT 12

Applicable to: ALL



(1) Spoilers/Speedbrakes' Indication

- Δ : Spoiler deflected by more than 2.5 ° (green)
- : Spoiler retracted (green)
- Δ : Spoiler fault deflected (amber)
- 1 : Spoiler fault retracted (amber)
- x : Spoiler position not valid (amber)

(2) Hydraulic System Pressure Indication


It is normally green. It becomes amber, if the hydraulic system's pressure decreases.

(3) ELAC /SEC Indication

- ELAC and SEC labels are always displayed in white
- The computer number is normally in green, and boxed in grey.  
The number and box become amber, if the computer fails, or is switched OFF.

(4) Aileron position indication

It is indicated with a white scale and green index. It changes to amber, when neither (green nor blue) servojack is available.



(5) Aileron and elevator actuator indication

"G" and "B" are normally displayed in green.

They become amber, in the case of a green or blue hydraulic system low pressure. The partial box also becomes amber, if the associated computer or actuator fails.

(6) Elevator position indication

It is indicated with a white scale and green index. The index becomes amber, when both associated actuators are not available.


(7) Pitch trim position indication

The pitch trim numbers are in green. They become amber, if green and yellow hydraulic system pressure decreases.

The "PITCH TRIM" legend is in white. It becomes amber, if the pitch trim jams.



(8) Yaw control indications



(A) Rudder position indication

It is normally in green. The rudder symbol becomes amber, if the blue, green, and yellow hydraulic pressures are low.

(B) Rudder travel limiter

It is normally in green. It becomes amber when travel limiter 1 and 2 are faulty. Two TLU messages are displayed in amber when the TLU indexes are suppressed.


(C) Rudder trim position

It is normally in blue. It becomes amber, if the rudder trim reset fails.

**ECAM WHEEL PAGE**

Ident.: DSC-27-20-30-00001096.0002001 / 15 FEB 11

Applicable to: ALL



(1) Spoilers/Speedbrakes' Indication

These indications are identical to those displayed on the FLT CTL page.

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-27-20-30-A-00016860.0001001 / 21 MAR 16

**GND SPLRS ARMED** : This memo appears in green when the ground spoilers are armed.

Ident.: DSC-27-20-30-A-00016859.0001001 / 21 MAR 16

**SPEED BRK** : This memo appears in green when the speedbrakes are extended.

**SPEED BRK** : This memo appears in amber when the speedbrakes should be retracted.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FLIGHT CONTROLS

FLIGHT CONTROL SYSTEM - CONTROLS AND INDICATORS

Intentionally left blank

**GENERAL**

Ident.: DSC-27-30-10-00001097.0001001 / 21 MAR 16

Applicable to: ALL

Each wing has the following lift augmentation devices :

- Two flap surfaces.
- Five slat surfaces.

These surfaces are electrically controlled and hydraulically operated.

The pilot extends slats and flaps by moving the FLAPS lever on the center pedestal.

It has five positions.

**MAIN COMPONENTS**

Ident.: DSC-27-30-10-00001098.0001001 / 21 MAR 16

Applicable to: ALL

The slat and flap systems are similar, comprising :

- Two slat flap control computers (SFCCs), each containing one slat channel and one flap channel.
- A power control unit (PCU) consisting of two independent hydraulic motors coupled by a differential gearbox.

The motors use green and blue hydraulic power for the slats and yellow and green power for the flaps.

Pressure-off brakes (POBs) lock the transmission when the slat or flap surfaces have reached the selected position or if hydraulic power fails.


- Five slat surfaces and two flap surfaces per wing.
- An assymetry position pick-off unit (APPU) that measures the assymetry between the left and right wings.
- A flap disconnect detection system, which detects attachment failure and inhibits flap operation in order to prevent further damage. A sensor detects the failure by measuring excessive differential movement between the inner and the outer flaps.
- Wingtip brakes (WTBs), activated in case of assymetry, mechanism overspeed, symmetrical runaway, or uncommanded movement of the surfaces. They cannot be released in flight. They use blue and green hydraulic power for the slats and for the right wing flaps, and blue and yellow hydraulic power for the left wing flaps.
- Feedback position pick-off units (FPPU s) that feed back position information to the SFCCs.
- An instrumentation position pick-off unit (IPPU ) that sends position data to the ECAM.

Note: *If the flap wingtip brakes are on, the pilot can still operate the slats, and if the slat wingtip brakes are on, he can still operate the flaps.  
If one SFCC is inoperative, slats and flaps both operate at half speed.  
If one hydraulic system is inoperative, the corresponding surfaces (slats or flaps) operate at half speed.*

**ARCHITECTURE**

Ident.: DSC-27-30-10-00001099.0001001 / 21 MAR 16

Applicable to: ALL



**CONFIGURATIONS**


Ident.: DSC-27-30-10-00001100.0001001 / 09 OCT 12

Applicable to: **ALL**

The FLAPS lever has five positions: 0, 1, 2, 3 and FULL.

Two configurations correspond to position 1: Configuration 1 and Configuration 1 + F.

The pilot selects these as follows:



- (1) When in Configuration 1 + F, the flaps retract to 0 ° automatically at 210 kt (before the airspeed reaches VFE).
- (2) When in configuration 1, the flaps extend to 10 ° automatically at 100 kt.

**ALPHA/SPEED LOCK FUNCTION (SLATS)**

Ident.: DSC-27-30-10-00001101.0001001 / 13 SEP 16

Applicable to: **ALL**

This function inhibits slat retraction at high angles-of-attack and low speeds.

The SFCC s use corrected angle-of-attack (alpha) or airspeed information from the ADIRUs to inhibit slat retraction.

When the FLAPS lever is set to 0, the slats alpha/speed lock function activates and inhibits slats retraction, if:

- The AOA is above 8.5 °, or
- The speed is less than 148 kt.



Note: *If the FLAPS lever is already set to 0, when either of the above conditions occurs, the function will not activate therefore the slats will continue to retract or will remain at 0.*

Once the slats alpha/speed lock function is active, the slats retract to 0 when:

- The AOA is less than  $7.6^{\circ}$  and
- The speed is above 154 kt.

Note: *When the aircraft is on ground and its speed is less than 60 kt, then the function will not activate.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FLIGHT CONTROLS**


FLAPS AND SLATS - DESCRIPTION

Intentionally left blank

**PEDESTAL**

Ident.: DSC-27-30-20-00001102.0001001 / 18 MAR 11

Applicable to: ALL



The five lever positions correspond to the following surface positions :

Position	SLATS	FLAPS	Indications on ECAM		
0	0	0		TAKEOFF	CRUISE
1	18	0	1		LDG
		10	1 + F	APPR	
2	22	15	2		
3	22	20	3		
<b>FULL</b>	27	35	FULL		

Before selecting any position, the pilot must pull the lever out of the detent. Balks at positions 1 and 3 prevent the pilot from calling for excessive flap/slat travel with a single action.

*Note:* The pilot cannot select an intermediate lever position.

**TAKEOFF IN CONFIGURATION 1**

1 + F (18 °/10 °) is selected. If the pilot does not select configuration 0 after takeoff, the flaps retract automatically at 210 kt.

**TAKEOFF OR GO-AROUND IN CONFIGURATION 2 OR 3**

If the pilot selects configuration 1, he gets 1 + F (18 °/10 °) if airspeed is under 210 kt.  
 If the pilot does not select configuration 0 after takeoff, the flaps retract automatically at 210 kt.

**CONFIGURATION 0 TO CONFIGURATION 1 IN FLIGHT**


Configuration 1 (18 °/0 °) is selected.

*Note:* After flap retraction, configuration 1 + F is no longer available until the airspeed is 100 kt or less, unless configuration 2, 3, or FULL has been selected previously.

**ECAM UPPER DISPLAY**

Ident.: DSC-27-30-20-00001103.0002001 / 14 NOV 11

Applicable to: ALL



(1) Position indexes

These white points indicate that the slats and flaps are in a selectable position. They do not appear, when the aircraft is in clean configuration.

(2) F and S

“F” and “S” normally appear in white. They become amber, if:

- Both relevant hydraulic systems fail, unless the aircraft is on ground with both engines stopped.
- The wingtip brakes are on.
- There is a slats or flaps fault.

“S (F) LOCKED” legend, appears in amber, in association with an ECAM caution, when the wingtip brakes are applied, or when the system detects a non-alignment between two flaps.

The “A-LOCK” legend pulses in green, when the slat alpha/speedlock function is active.

(3) Flaps/Slats’ actual position

These green boxes indicate the actual flaps/slats position.

They become amber, if:

- Both relevant hydraulic systems fail, unless the aircraft is on ground with both engines stopped.
- The wingtip brakes are on.
- There is a slats or flaps fault.

(4) Selected position

It is in blue, when the surfaces are in transit.

It disappears, when the selected position is reached.

(5) Flap lever position

The “0”, “1 + F”, “1”, “2”, “3”, or “FULL” legend appears.

- It is green, when the slats and flaps are in the selected position. “0” is not displayed, when the aircraft attains clean configuration.
- It becomes cyan, when the slats and flaps are in transit.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FLIGHT CONTROLS

FLAPS AND SLATS - CONTROLS AND INDICATORS

Intentionally left blank

# AIRCRAFT SYSTEMS

FUEL

Intentionally left blank



**DSC-28-10 Description**

DSC-28-10-10 General

GENERAL..... A

DSC-28-10-20 Tanks

Tanks..... A

DSC-28-10-30 Engine Feed

GENERAL..... A

Main Components..... B

Engine Feed..... C

Fuel Feed Sequence..... D

DSC-28-10-50 APU Feed

APU FEED..... A

DSC-28-10-60 Fuel Recirculation System

Fuel Recirculation System..... A

DSC-28-10-70 Refueling and Defueling

Refueling - Defueling..... A

DSC-28-10-80 Fuel Quantity Indication and Level Sensing

FUEL QUANTITY INDICATION (FQI) SYSTEM..... A

FUEL LEVEL SENSING CONTROL UNIT (FLSCU)..... B

Fuel System Architecture..... C

DSC-28-10-90 Fuel Tank Inerting System

Fuel Tank Inerting System..... A

**DSC-28-20 Controls and Indicators**

Overhead Panel..... A

Refueling Control Panel..... B

Maintenance Panel..... C

ECAM Fuel Page..... D

ECAM Upper Display..... E

Memo Display..... F



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FUEL

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FUEL

#### DESCRIPTION - GENERAL

### GENERAL

Ident.: DSC-28-10-10-00001107.0001001 / 13 NOV 13

**Applicable to: ALL**

The fuel system :

- Stores fuel in the tanks.
- Supplies fuel, in the correct quantities, to the fuel tanks during refueling.
- Supplies fuel to the engines and the Auxiliary Power Unit (APU).
- Circulates fuel to cool the Integrated Drive Generator (IDG).
- Keeps fuel in the outer tanks for wing bending and flutter relief.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FUEL**

DESCRIPTION - GENERAL

Intentionally left blank

**TANKS**

Applicable to: ALL

Ident.: DSC-28-10-20-A-00020195.0001001 / 17 MAR 17


The fuel is stored in the wings, in the center tank, and in the Additional Center Tank (ACT ).

The wings have inner and outer tanks.

There is a vent surge tank outboard of the outer tank in each wing.

When the aircraft has been refueled to maximum capacity, the fuel can expand by 2 % (20 °C temperature rise) without spilling.

There is an overpressure protector in each vent, outer and inner tank and between the center tank and the left inner tank.



Ident.: DSC-28-10-20-A-00020196.0003001 / 17 MAR 17

USABLE FUEL								
		OUTER TANKS	INNER TANKS	CENTER TANK	ACT	TOTAL WITH		
						NO ACT	1 ACT	2 ACTs
VOLUME	(liters)	880 x 2	7 099 x 2	8 250	2 992	24 209	27 201	30 193
	(US gallons)	232 x 2	1 875 x 2	2 179	790	6 395	7 185	7 975
WEIGHT <sup>(1)</sup>	(KG)	691 x 2	5 573 x 2	6 476	2 349	19 004	21 353	23 702
	(LB)	1 523 x 2	12 286 x 2	14 278	5 175	41 893	47 068	52 243

<sup>(1)</sup> Fuel density : 0.785 kg/l or 6.551 lb/US Gal.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FUEL**

DESCRIPTION - TANKS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>FUEL</b></p> <p style="text-align: center;">DESCRIPTION - ENGINE FEED</p>
---	--

**GENERAL**

Ident.: DSC-28-10-30-00001109.0002001 / 10 DEC 09  
**Applicable to: ALL**

The main fuel pump system supplies fuel from the center tank or the inner wing tanks to the engines. The system has six main fuel pumps.

**MAIN COMPONENTS**

**Applicable to: ALL**

Ident.: DSC-28-10-30-A-00001110.0002001 / 01 FEB 13

**TANK PUMPS**

In normal operation each engine is supplied by one pump in the center tank or two pumps in its own side inner tank.  
All wing tank pumps remain on throughout the flight. They are fitted with pressure relief sequence valves which ensure that, when all pumps are running, the center tank pumps will deliver fuel preferentially.

Ident.: DSC-28-10-30-A-00001111.0001001 / 31 JAN 13

**INTERTANK TRANSFER VALVES**

Two electrical transfer valves are mounted in each wing to permit fuel transfer from outer to inner tank.

Ident.: DSC-28-10-30-A-00001112.0001001 / 10 DEC 09

**CROSS FEED VALVE**

A cross feed valve controlled by a double motor allows both engines to be fed from one side or one engine to be fed from both sides.

Ident.: DSC-28-10-30-A-00001113.0001001 / 20 MAR 17

**ENGINE LP VALVES**

The engine fuel flow can be stopped by its low pressure (LP ) fuel valve. The LP fuel valve is closed by either :

- The engine master switch, or
- The ENG FIRE PUSH pushbutton.

Ident.: DSC-28-10-30-A-00001114.0002001 / 29 MAR 12

**SUCTION VALVES**


Closed by pumps pressure in normal operation, they allow engines to be fed by gravity if the inner tank pumps fail.

*Note: Center tank pumps are not fitted with suction valves. Therefore, gravity feeding is not possible from the center tank.*

**ENGINE FEED**

Ident.: DSC-28-10-30-00001115.0002001 / 18 MAR 14

Applicable to: **ALL**





**FUEL FEED SEQUENCE**


Ident.: DSC-28-10-30-00021263.0001001 / 21 MAR 17

Applicable to: **ALL**

The tanks empty in the following sequence :

1. The ACT2  : Fuel transfers into the center tank.
2. The ACT1  : Fuel transfers into the center tank.
3. The center tank.
4. The inner tanks: Each inner tank empties down to 750 kg (1 650 lb).
5. The outer tanks: Fuel transfers into the inner tanks.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>FUEL</b></p> <p style="text-align: center;">DESCRIPTION - ENGINE FEED</p>
---	--

## **CENTER TANK FUEL TRANSFER**

The center tank feeds fuel to the engines, when the center tank pumps are not stopped by the control logic described below. The inner tanks feed the engines when the center tank pumps are stopped.

### **CENTER TANK TRANSFER VALVE CONTROL LOGIC**

Each center tank pump stops, until approximately 500 kg (1 100 lb) of the fuel in its associated inner tank fuel has been used (when the fuel level reaches the underfull sensors).

With the MODE SEL in the MAN position, the center tank pumps will run. In manual mode, the CTR TK PUMP pb-sw must be selected OFF, when the center tank is empty.

### **FUEL TRANSFER FROM OUTER TO INNER TANKS**

The transfer valves automatically open, when the inner tank fuel reaches the low level (about 750 kg/1 650 lb), thus enabling the fuel to drain from the outer to inner tanks.

When open, the valves are latched open. They will automatically close at the next refueling operation.

- Note:*
1. Two level sensors are installed in each inner tank. Each sensor controls two transfer valves, one in each wing, ensuring simultaneous transfer to both wings.
  2. The 750 kg/1 650 lb value is based on a level aircraft attitude, with no acceleration. During steep descent or accelerations/decelerations, the transfer valves may open with more than 750 kg/1 650 lb of fuel in each inner tank, and the low level warning may be triggered.

### **IF THE AIRCRAFT HAS ONE ACT : ACT TO CENTER TANK TRANSFER**

ACT transfer automatically starts after takeoff at slats' retraction, if the center tank high-level sensor has been dry for 10 min, and the ACT is not empty.

Fuel transfers from the ACT to the center tank via pressurization of the tank, by closing the ACT vent valve and opening the air shutoff valve.

When the ACT is empty, the ACT transfer valve, the air shutoff valve and inlet valve close, and the ACT vent valve opens.

- Note:* ACT transfer stops, if the center tank high level becomes wet, by closing the ACTs transfer valve. The transfer valve reopens when the center tank high-level sensor becomes dry for 10 min.

Selecting the ACT pb-sw to FWD opens the ACT transfer valve, the ACT inlet valve, and starts the ACT transfer pump. It must be returned to AUTO, when the ACT is empty.

Center tank overflow is prevented, by returning the ACT pb-sw to AUTO, when the center tank is full.

**IF THE AIRCRAFT HAS TWO ACTS ◀ : ACT 1 + 2 TO CENTER TANK TRANSFER**

ACT transfer automatically starts after takeoff at slats' retraction, if the center tank high-level sensor has been dry for 10 min, and the ACT is not empty.

Fuel transfers from the ACT to the center tank via pressurization of the tank, by closing the ACT vent valve and opening the air shutoff valve.

ACT2 transfers first, via the ACT transfer valve and the ACT2 inlet valve.

When ACT2 is empty, the ACT2 inlet valve shuts, and the ACT1 inlet valve opens.

When ACT1 is empty, the ACT transfer valve and ACT1 inlet valve close.

When the aircraft is on ground after landing, the air shutoff valve closes and both ACT vent valves open, depressurizing the ACTs.

*Note: ACT transfer stop, if the center tank high level becomes wet, by closing the ACT transfer valve. The transfer valve reopens when the center tank high-level sensor becomes dry for 10 min.*

Selecting the ACT pb-sw to FWD opens the ACT transfer valve and starts the ACT transfer pump.

ACT2 empties first, then ACT1. It must be returned to AUTO, when the ACT is empty.

Center tank overflow is prevented, by returning the ACT pb-sw to AUTO, when the center tank is full.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FUEL

DESCRIPTION - APU FEED

### APU FEED

Ident.: DSC-28-10-50-00001120.0001001 / 10 DEC 09

**Applicable to: ALL**

A special fuel pump supplies fuel for APU startup when fuel feed pressure is low (due to loss of tank pumps or loss of normal AC electrical supply). This pump normally runs off the AC ESS SHED, but runs off the AC STAT INV BUS if the AC ESS SHED fails.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FUEL**

DESCRIPTION - APU FEED


Intentionally left blank

**FUEL RECIRCULATION SYSTEM**

Applicable to: ALL

Ident.: DSC-28-10-60-B-00020316.0001001 / 17 MAR 17

Illustration - For information only



Ident.: DSC-28-10-60-B-00020317.0004001 / 17 MAR 17

*Refer to DSC-70-40 IDG Cooling System.*

Some of the fuel supplied to each engine goes from the high-pressure fuel line in that engine, through the integrated drive generator (IDG) heat exchanger (where it absorbs heat), to the fuel return valve and back to the outer fuel tank.

This operation ensures the IDG cooling when the oil temperature is high or when at low engine power.

The FADEC controls the fuel return valve.

If the outer tank is already full, the fuel overflows to the inner tank through a spill pipe. On ground, the fuel recirculation is not inhibited if there is an overflow in the surge tanks (*Refer to DSC-70-40 IDG Cooling System*).

■ **If the FUEL MODE SEL pb-sw is in AUTO mode:**

If center tank is feeding, the wing tank will tend to overflow and the system automatically selects the CTR TK PUMP off when the inner tank is full. The wing tank pumps will feed until the engine

have used approximately 500 kg (1 100 lb) of fuel when the fuel level reaches the underfull sensors. The logic circuits then restart the center tank pumps.



■ **If the FUEL MODE SEL pb-sw is in MAN mode:**


If center tank is feeding, the wing tanks will tend to overfill but the system does not automatically select the CTR TK PUMPs OFF when the inner tank is full. Therefore, an overflow of the wing tanks can occur on ground if the CTR TK PUMPs are not switched OFF.

**REFUELING - DEFUELING**

Ident.: DSC-28-10-70-00021235.0002001 / 21 MAR 17

Applicable to: ALL

- During automatic refueling, fuel goes into the ACTs , the center tank and the outer cell of the wing tanks simultaneously. When the outer cell of the wing tank is full, fuel overflows into the inner cell. During manual refueling, fill the wing tanks first, then the center tank, then the ACTs .
- Electrical transients (caused by switching among the APU, the external and the engine electrical supply) during automatic refueling may stop the process. If the automatic refueling process is stopped, it is necessary to re-enter the Preselected Fuel Quantity.
- One (two) refueling point(s) is (are) installed under the wings, enabling the aircraft to be refueled from either the right or left (if installed) side.
- A refuel panel is located on the fuselage side beneath the right wing, or under the right or left wing adjacent to the refuel coupling.
- Another refuel panel is located on the cockpit overhead maintenance panel.
- A "READY FOR FUELING" green light is installed adjacent to the refuel coupling.



A gallery connects the refuel coupling to each tank's refuel valve.

Refueling is normally automatic, the required fuel load being set on the preselector.

Manual control is also available.

Automatic refueling starts with the outer tanks. If the selected fuel load exceeds the wing tank capacity, the center tank is simultaneously refueled.

When an outer tank is full, the fuel overflows into the inner tank through a spill pipe.

Refuel valves close automatically, when the tanks contain the preselected load, or when sensors detect a high fuel level.




The aircraft can be refueled, when only battery power is available.


The wing tanks can be refueled by gravity, through refueling points on top of the wings.

A transfer valve, between the engine feed system and the refueling gallery, allows :

- The tank pumps to transfer fuel from one tank to another
- Defueling through the refuel coupling.

Approximate refueling time at nominal pressure is:

- 17 min for wing tanks
- 20 min for all tanks (without ACT )
- 25 min for all tanks (with one ACT )
- 27 min for all tanks (with two ACTs )





**FUEL QUANTITY INDICATION (FQI) SYSTEM**

Ident.: DSC-28-10-80-00001123.0001001 / 10 DEC 09

**Applicable to: ALL**

The FQI is a computerized system that :

- transmits the actual total fuel mass, as well as the quantity and temperature of fuel in the tanks, to the ECAM.
- controls automatic refueling.

Two channels perform fuel computations : channel 2 activates automatically if channel 1 fails.

The FQI system has :

- an FQI computer.
- a set of capacitance probes in each tank to measure fuel level and temperature.
- one densitometer (cadensicon) sensor in each wing inner tank permitting the calculation of the fuel quantity.
- one Capacitance Index Compensator (CIC) in each inner tank giving the dielectric constant of the fuel in case of cadensicon failure.
- a quantity indicator for each tank installed on the refuel/defuel panel.
- a preselector on the refuel/defuel panel that shows the preselected and actual total fuel quantity.

**FUEL LEVEL SENSING CONTROL UNIT (FLSCU)**

Ident.: DSC-28-10-80-00001124.0001001 / 16 MAR 15

**Applicable to: ALL**

The fuel level system generates fuel-level and fuel-temperature signals in order to operate the appropriate switching functions for refueling and defueling and control the IDG cooling recirculation system and the center-tank-to-wing-tank fuel transfer system.

The FLSCU comprises :


- fuel level sensors in the tanks to sense high, low, and overflow levels.
- a fuel temperature sensor to control the IDG cooling recirculation.


When fuel quantity in one wing tank goes below 750 kg (1 650 lb), the low-level sensor triggers the LO LVL warning on ECAM. The LO LVL warning is totally independent from the displayed fuel quantity indication of the tank.

**FUEL SYSTEM ARCHITECTURE**

Ident.: DSC-28-10-80-00001125.0001001 / 22 MAY 12

Applicable to: ALL



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>FUEL</b></p> <p>DESCRIPTION - FUEL TANK INERTING SYSTEM</p>
---	--

**FUEL TANK INERTING SYSTEM**

Ident.: DSC-28-10-90-00013692.0001001 / 18 MAR 11

Applicable to: ALL

The A318, A319, A320 and A321 aircraft are equipped with a Fuel Tank Inerting System. The aim of this system is to reduce the flammability in the fuel tanks that have a high flammability exposure.


The fuel center tank is the only one that has a high flammability exposure. Therefore, the Fuel Tank Inerting System only needs to be installed for the center tank. All other tanks do not need Fuel Tank Inerting System installation.

To reduce the flammability in the center tank, the Fuel Tank Inerting System produces an oxygen-depleted air that goes in the center tank to replace the ambient air.

The system is installed in the belly fairing of the aircraft, and is composed by:

- A conditioned Service Air System (CSAS)
- An Inert Gas Generation System (IGGS).

The CSAS extracts and conditions some engine bleed air to adequate pressure and temperature. Then, the air goes through the IGGS where an Air Separation Module taps the nitrogen molecules. Therefore, an oxygen-depleted air is produced (with less than 12 % of oxygen) and replaces the ambient air of the center tank.



The Fuel Tank Inerting System does not require any flight crew action. It works independently as soon as the engines start and until they stop.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**FUEL**


DESCRIPTION - FUEL TANK INERTING SYSTEM

Intentionally left blank

**OVERHEAD PANEL**

Applicable to: ALL

Ident.: DSC-28-20-G-00020183.0001001 / 17 MAR 17



Ident.: DSC-28-20-G-00020239.0001001 / 17 MAR 17

**L(R) TK PUMPS 1(2) pb-sw**

- On : Pump is on (but only fuel feeds) when the delivery pressure of the center tank pumps drops below the threshold.
- OFF : Pump is off, and the OFF button comes on white.
- FAULT light : Amber light and ECAM caution come on, when the delivery pressure drops. It does not come on when OFF is selected.

Ident.: DSC-28-20-G-00020240.0001001 / 17 MAR 17

**MODE SEL pb-sw**

- AUTO : Control of center tank pumps is automatic:
  - They run at engine start for 2 min,
  - Before or after the engine start sequence, the pumps run if the slats are retracted,
  - They stop automatically 5 min after center tank low level is reached.

- MAN** : Flight crew manually controls the center tank pumps with the center tank pumps' pushbutton.
- FAULT light** : Amber light comes on, and ECAM caution comes on when center tank has more than 250 kg (550 lb) of fuel and the left or right wing tank has less than 5 000 kg (11 000 lb).

Ident.: DSC-28-20-G-00020256.0001001 / 17 MAR 17

**CTR TK PUMP 1(2) pb-sw**

- On** : Pump runs, if MAN mode is selected on the MODE SEL pb-sw. Pump is automatically controlled when AUTO mode is selected.
- OFF** : Pump is off and OFF button comes on white.
- FAULT light** : Amber light and associated ECAM caution come on, when the pump is in operation and the delivery pressure drops.

Ident.: DSC-28-20-G-00020257.0001001 / 17 MAR 17

**X FEED pb-sw**

- ON** : The valve opens, and the ON pushbutton comes on in white.
- OFF** : The valve closes, and the pushbutton does not come on.
- OPEN light** : This green light comes on, when the valve is fully open.

Ident.: DSC-28-20-G-00020258.0001001 / 17 MAR 17

**ACT pb-sw** 


- AUTO** : Control of the ACT transfer is automatic.
- The automatic forward transfer occurs, if:
    - The aircraft is in flight, and
    - The slats are retracted, and
    - At least one ACT low-level sensor is wet, and
    - The center tank high-level sensor has been dry for at least 10 min.
  - The automatic forward transfer stops, as soon as one of the above conditions is not met.
- FWD** : The manual transfer to the center tank is initiated by opening:
- The ACT transfer valve,
  - The ACT 1 or ACT 2 (if available) inlet valve.
- The ACT transfer pump is then commanded on.
- FAULT light** : Amber light and associated ECAM caution come on, when:
- The center tank has less than 3 000 kg (6 614 lb) of fuel, and 1 ACT has more than 250 kg (550 lb) of fuel, and
  - The ACT pb-sw is on AUTO.

*Note:* When no ACT is installed, the pushbutton is inoperative.

**REFUELING CONTROL PANEL**

Applicable to: ALL

Ident.: DSC-28-20-C-00020185.0001001 / 17 MAR 17



Ident.: DSC-28-20-C-00020265.0001001 / 21 MAR 17

**FUEL QUANTITY INDICATOR**

The number shows the quantity of fuel in each tank.  
Units may either be in kg x 1 000 or lb x 1 000 depending on the aircraft configuration.

Ident.: DSC-28-20-C-00020266.0001001 / 21 MAR 17

**HI LVL light**

This blue light comes on, when the system detects a high fuel level.  
The corresponding refuel valve closes automatically.

Ident.: DSC-28-20-C-00020267.0001001 / 21 MAR 17

**REFUEL VALVES selector (GUARDED IN NORM)**

**NORM** : Automatic refueling logic controls the refuel valves.

**OPEN** : Valves open when the MODE SELECT sw is set to the REFUEL or DEFUEL XFR position. Each refuel valve closes, when the system detects a high level in the associated tank.

**SHUT** : Valves close.

Ident.: DSC-28-20-C-00020268.0001001 / 17 MAR 17

### **MODE SELECT sw (GUARDED AT OFF)**

**OFF** : Refuel system is de-energized. Refuel valves are closed.

**REFUEL** : Refuel valves operate in automatic or in manual mode depending on the position of REFUEL VALVES sw.

**DEFUEL XFR** : Refuel/Defuel transfer valve opens.  
Refuel valve opens if the associated REFUEL VALVE sw is at OPEN.

Ident.: DSC-28-20-C-00020270.0001001 / 21 MAR 17

### **OPEN light**

This amber light comes on when the defuel transfer valve is open.

Ident.: DSC-28-20-C-00020271.0001001 / 17 MAR 17

### **TEST sw**

**HI LVL** : The HI LVL lights come on if high level sensors and associated circuits are serviceable.

*Note: If tanks are full (HI LVL lights on) during this test, the HI LVL lights go out if high level sensors and associated circuits are serviceable.*

**LTS** : Lights on panel and all 8's on FQI and preselector come on.

Ident.: DSC-28-20-C-00020272.0001001 / 21 MAR 17

### **PRESELECTED DISPLAY**

This display shows the preselected total fuel quantity in kg (lb) × 1 000 (multiply by 1 000 to get actual amount).

Ident.: DSC-28-20-C-00020273.0001001 / 17 MAR 17

### **Preselector sw**

Pressing the left or right side of the switch decreases or increases the preselected quantity.

Ident.: DSC-28-20-C-00020274.0001001 / 21 MAR 17

### **ACTUAL DISPLAY**

This display shows the total fuel on board.



Ident.: DSC-28-20-C-00020275.0001001 / 21 MAR 17

**END light**

This green light comes on steady when automatic refueling is completed.  
It flashes green if refueling is aborted.

Ident.: DSC-28-20-C-00020276.0002001 / 21 MAR 17

**CKPT light**

Indicates that cockpit refuel panel has priority.  
Illuminates when electrical PWR pb-sw on cockpit refuel is pressed.

Ident.: DSC-28-20-C-00020277.0001001 / 21 MAR 17

**BATT POWER TOGGLE SWITCH** 

**ON** : When the flight crew momentarily switches this to ON position and releases it, HOT BUS 1 supplies the FQI.

After completion of the FQI tests (about 40 s), the fuel quantity indications appear and refuel operation can be selected.

The electrical supply is automatically cut off:


- After 10 min, if no refuel operation is selected, or
- At the end of refueling.

**NORM** : The FQI is not supplied by batteries.

**MAINTENANCE PANEL**

Applicable to: ALL

Ident.: DSC-28-20-D-00020187.0007001 / 17 MAR 17



Ident.: DSC-28-20-D-00020286.0001001 / 21 MAR 17

### **PRESELECTED DISPLAY**

This display shows the preselected total fuel quantity in KG (or in LB depending on aircraft configuration) × 1 000 (multiply by 1 000 to get actual amount).

Ident.: DSC-28-20-D-00020287.0001001 / 21 MAR 17

### **ACTUAL DISPLAY**

This display shows the total fuel on board.


Ident.: DSC-28-20-D-00020288.0001001 / 17 MAR 17

### **Preselector sw**

Pressing the left or the right side of the switch decreases or increases the preselected quantity.

Ident.: DSC-28-20-D-00020289.0001001 / 21 MAR 17

### **END light**

This green light comes on steady when automatic refueling is achieved (associated with the green refuel light on wing extinguishing  ).  
It flashes green if refueling is aborted.


Ident.: DSC-28-20-D-00020290.0001001 / 17 MAR 17

### **PWR pb-sw**

- ON** : - Refuel system is energized  
- Cockpit refuel control/preselector panels takes priority (cockpit lights illuminate on cockpit and external refuel control panels)  
- Automatic high level test  
- REFUEL caption is displayed on ECAM.
- OFF** : - Refuel system is deenergized  
- ECAM "REFUEL" caption is cleared  
- Priority is cleared.
- FAULT** : This amber light comes on when auto high level test not satisfied.

Ident.: DSC-28-20-D-00020291.0001001 / 17 MAR 17

### **CTL pb-sw**

- ON** : - Start of refuel, (associated with refuel green light illumination on wing  )  
- Auto shut off occurs when the selected load is reached or in case of HI level detection  
- VALVE light comes amber if REFUEL VALVE CTL switch are not at NORM position (on refueling control panel).

Off : Refuel stops. The selected load can be reset.

Ident.: DSC-28-20-D-00020294.0001001 / 21 MAR 17


**CKPT light**

Comes on when PWR pb-sw switch is ON associated with the CKPT light on the external refuel control panel.

**ECAM FUEL PAGE**

Applicable to: ALL

Ident.: DSC-28-20-F-00020188.0004001 / 17 MAR 17



Ident.: DSC-28-20-F-00020213.0001001 / 17 MAR 17

**WING PUMP INDICATIONS**

- Inline - Green : Pump pressure is normal (pump contactor on).
- “LO” - Amber : Pump pressure is low (pump contactor on).
- Crossline - Amber : Pump contactor is off.

Ident.: DSC-28-20-F-00020214.0002001 / 17 MAR 17

**CTR TANKS PUMPS INDICATIONS**

- Inline - Green : Pump pressure is normal (pump contactor on).
- “LO” - Amber : Pump pressure is low (pump contactor on).
- Crossline - Green : Pump contactor is off, and auto shut-off is required.
- Crossline - Amber : Pump contactor is off, and auto shut-off is not required.

Ident.: DSC-28-20-F-00020216.0001001 / 17 MAR 17

**LP VALVE (ENG) INDICATIONS**

- Inline - Green : The valve is open.
- Inline - Amber : The valve is open, with the ENG MASTER switch OFF.
- Crossline - Amber : The ENG valve is fully closed.
- Transit - Amber : The valve is in transit.

Ident.: DSC-28-20-F-00020217.0001001 / 17 MAR 17


**X FEED INDICATIONS**

- Inline - Green : The valve is open.
- Inline - Amber : The valve is open, with X Feed pb off.
- Crossline - Green : The valve is closed.
- Crossline - Amber : The valve is closed with X feed pb ON.
- Transit - Amber : The valve is in transit.

Ident.: DSC-28-20-F-00020218.0002001 / 17 MAR 17

**TRANSFER VALVE INDICATIONS**

Outer to Inner Transfer



- ▷ : The triangle is green, during a transfer to inner.
- ▶ : The triangle is in solid amber, when the valves are open, while commanded closed.
- ▷ : The triangle is in amber, when a valve is in transit.
- XX : The valve position information is not available
- No display : valves are closed

Ident.: DSC-28-20-F-00020219.0001001 / 17 MAR 17

**APU INDICATIONS**

APU ← : APU is in white and the triangle is in green: the APU valve is open.

APU ← : APU and solid triangle are in amber : the APU valve is open, with the APU Fire Pushbutton out, or the APU MASTER switch OFF.

APU : APU is in amber : APU valve is closed and APU Fire pushbutton is out / or APU MASTER switch ON.

APU ◁ : APU and triangle are in white : the APU valve is closed.

Ident.: DSC-28-20-F-00020220.0001001 / 17 MAR 17

**FUEL TEMPERATURE INDICATION**

This appears when its associated temperature sensor is wet. It is normally in green.


An advisory only appears in phases 2 and 6, when the fuel temperature is:

- Above 45 °C for the inner cell, or 55 °C for the outer cell.
- Below -40 °C.

It becomes amber, and the ECAM displays a caution, if the temperature goes above the high limit or below the low limit.

Ident.: DSC-28-20-F-00020221.0002001 / 17 MAR 17

**FUEL QUANTITY INDICATION**



- It is normally in green.
- The units may either be in KG or LB, depending on the DMC pin program.
- Two dashes appear across the last two digits when the FQI is inaccurate (*Refer to DSC-28-20 Total Fuel Indication*).

Ident.: DSC-28-20-F-00020340.0001001 / 17 MAR 17

### **FUEL QUANTITY - BOXED INDICATIONS**

- The outer indication is boxed amber, if both transfer valves fail to open when the inner is at low level.
- The center tank indication is boxed amber, if both center tank pumps are failed, or are switched OFF.


Ident.: DSC-28-20-F-00020345.0001001 / 17 MAR 17

### **FUEL QUANTITY - ADVISORY**

An advisory appears in flight phases 2 and 6, when the difference between the fuel quantities in the two wings is greater than 1 500 kg (3 300 lb). The wing inner and outer tank indications pulse with the highest fuel level.


Ident.: DSC-28-20-F-00020346.0003001 / 17 MAR 17

### **FUEL ON BOARD (FOB) INDICATION**

It is normally in green. It indicates the total of all tanks (Including the ACTs  ).  
Two dashes appear across the last two digits when the FQI is inaccurate (*Refer to DSC-28-20 Total Fuel Indication*).

Units may either be in KG or LB, depending on the DMC pin program.

The indication is half-boxed in amber, if:

- Center tank pumps fail, or are switched OFF.
- Both transfer valves fail to open, when the inner tank is at low level.
- Any ACT  is not usable.

Ident.: DSC-28-20-F-00020347.0001001 / 17 MAR 17

### **FUEL USED INDICATION**

- The engine identification number is in amber, when the engine is below idle. It is in white color, when it is at, or above, idle.
- The fuel used indication is green from flight phase 2, until electrical power is cut off at the end of the flight. It is automatically reset, when the engine is started on ground.
- Units may either be in KG or LB, depending on the DMC pin program.

Ident.: DSC-28-20-F-00020348.0002001 / 17 MAR 17

### **ACT TO CENTER TANK FUEL TRANSFER INDICATION**

- It is normally in green.
- The ACT quantity is displayed in a grey box.
- This box becomes amber in case of a transfer fault.
- ACT 1 is indicated on the left and ACT 2 is indicated on the right.
- Units may either be in KG or LB, depending on the DMC pin program.
- A triangle indicates that the fuel transfer to the center tank has started:
  - △ : Green, when the automatic transfer begins.
  - ▲ : Fully green, when the manual transfer begins.

Ident.: DSC-28-20-F-00020351.0001001 / 17 MAR 17

### **FUEL FLOW INDICATION**

The Total Fuel Flow is displayed in KG/MIN or LB/MIN.


Units may either be in KG or LB, depending on the DMC pin program.

- It is normally in green.
- It is replaced by an amber XX if there is no valid data.

**ECAM UPPER DISPLAY**

Applicable to: **ALL**

Ident.: DSC-28-20-E-00020189.0002001 / 17 MAR 17



Ident.: DSC-28-20-E-00020193.0001001 / 17 MAR 17

**TOTAL FUEL INDICATION**

An amber half box appears around FOB, when the displayed quantity is not all usable (intercell transfer valve failure or loss of center tank pumps).

Units may either be in KG or LB, depending on the DMC pin program.

If the FOB indication is displayed with two dashes across the two least significant digits, the FQI is in degraded mode. In this case, the ECAM FUEL page can be called on ECAM lower display to determine which tank is affected.

The loss of accuracy resulting from the loss of FQI normal mode is as follows :

- Wing outer tank affected : +20 kg (+44 lb), -200 kg (-440 lb).
- Wing inner tank affected : ±110 kg (240 lb).
- Center tank affected : ±130 kg (290 lb).
- All tanks affected : +390 kg (+860 lb), -750 kg (-1660 lb).



Ident.: DSC-28-20-E-00020194.0001001 / 17 MAR 17

### MEMO DISPLAY

Memos are normally in green color, but they may be in amber color in abnormal situations.

### MEMO DISPLAY

Applicable to: ALL

Ident.: DSC-28-20-A-00016777.0001001 / 21 MAR 16

**CTR TK FEEDG** : This memo appears in green, if at least one center tank pump is energized.

Ident.: DSC-28-20-A-00016778.0001001 / 21 MAR 16



**FUEL X FEED** : This memo appears in green, if the fuel X FEED pb-sw is ON, and the X FEED valve is not fully closed. It appears in amber in flight phases 3,4, or 5.

Ident.: DSC-28-20-A-00016776.0001001 / 21 MAR 16

**OUTR TK FUEL XFRD** : This memo appears in green, if at least one transfer valve is open in one wing tank.

Ident.: DSC-28-20-A-00016779.0001001 / 21 MAR 16

**REFUELG** : This memo appears in green, when :

- The door of the refuel control panel  on the fuselage or on the wing is open, or
- The PWR pb-sw of the refuel control panel  in the cockpit is ON.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### FUEL

#### CONTROLS AND INDICATORS

Intentionally left blank

# **AIRCRAFT SYSTEMS**

HYDRAULIC

Intentionally left blank

**DSC-29-10 Description**

DSC-29-10-10 General

General.....	A
--------------	---

DSC-29-10-20 Generation

Green System Pump.....	A
Blue System Pumps.....	B
Yellow System Pumps.....	C
Power Transfer Unit (PTU).....	D
Ram Air Turbine (RAT).....	E
System Accumulators.....	F
Priority Valves.....	G
Fire Shutoff Valves.....	H
Leak Measurement Valves.....	I
Filters.....	J
Generation.....	K
Reservoir Pressurization.....	L
Indications.....	M

DSC-29-10-30 Distribution

Distribution.....	A
-------------------	---

**DSC-29-20 Controls and Indicators**

Overhead Panel.....	A
Maintenance Panel.....	B
ECAM HYD Page.....	C
Memo Display.....	D



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### HYDRAULIC

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**HYDRAULIC**

DESCRIPTION - GENERAL

**GENERAL**

Ident.: DSC-29-10-10-00001133.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has three continuously operating hydraulic systems : blue, green, and yellow. Each system has its own hydraulic reservoir. Normal system operating pressure is 3 000 PSI (2 500 PSI when powered by the RAT). Hydraulic fluid cannot be transferred from one system to another.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**HYDRAULIC**

DESCRIPTION - GENERAL

Intentionally left blank



### **GREEN SYSTEM PUMP**

Ident.: DSC-29-10-20-00001134.0001001 / 21 MAR 16

**Applicable to: ALL**

A pump driven by engine 1 pressurizes the green system.

### **BLUE SYSTEM PUMPS**

Ident.: DSC-29-10-20-00001135.0001001 / 21 MAR 16

**Applicable to: ALL**

An electric pump pressurizes the blue system. A pump driven by a ram air turbine (RAT) pressurizes this system in an emergency.

### **YELLOW SYSTEM PUMPS**

Ident.: DSC-29-10-20-00001136.0001001 / 21 MAR 16

**Applicable to: ALL**

A pump driven by engine 2 pressurizes the yellow system.

An electric pump can also pressurize the yellow system, which allows yellow hydraulics to be used on the ground when the engines are stopped.

Crew members can also use a hand pump to pressurize the yellow system in order to operate the cargo doors when no electrical power is available.

### **POWER TRANSFER UNIT (PTU)**


Ident.: DSC-29-10-20-00001137.0001001 / 21 MAR 16

**Applicable to: ALL**

A bidirectional power transfer unit enables the yellow system to pressurize the green system and vice versa.

The power transfer unit comes into action automatically when the differential pressure between the green and the yellow systems is greater than 500 PSI.

The PTU therefore allows the green system to be pressurized on the ground when the engines are stopped.



(\*) The PTU functioning is kept inhibited 40 seconds after the end of cargo door operation.

### RAM AIR TURBINE (RAT)

Ident.: DSC-29-10-20-00001138.0001001 / 21 MAR 16

Applicable to: ALL

A drop-out RAT coupled to a hydraulic pump allows the blue system to function if electrical power is lost or both engines fail. The RAT deploys automatically if AC BUS 1 and AC BUS 2 are both lost. It can be deployed manually from the overhead panel. It can be stowed only when the aircraft is on the ground.

### SYSTEM ACCUMULATORS

Ident.: DSC-29-10-20-00001139.0001001 / 21 MAR 16

Applicable to: ALL

An accumulator in each system helps to maintain a constant pressure by covering transient demands during normal operation.

### PRIORITY VALVES

Ident.: DSC-29-10-20-00001141.0001001 / 21 MAR 16

Applicable to: ALL

Priority valves cut off hydraulic power to heavy load users if hydraulic pressure in a system gets low.

### FIRE SHUTOFF VALVES

Ident.: DSC-29-10-20-00001142.0001001 / 21 MAR 16

Applicable to: ALL

Each of the green and yellow systems has a fire shutoff valve in its line upstream of its engine-driven pump. The flight crew can close it by pushing the ENG 1(2) FIRE pushbutton.

### LEAK MEASUREMENT VALVES

Ident.: DSC-29-10-20-00001143.0001001 / 21 MAR 16


Applicable to: ALL

Each system has a leak measurement valve upstream of the primary flight controls. These valves, which measure the leakage in each circuit, are closed by operation of the LEAK MEASUREMENT VALVES pushbutton switch on the maintenance panel.

### FILTERS

Ident.: DSC-29-10-20-00001144.0001001 / 21 MAR 16

Applicable to: ALL


 Filters clean the hydraulic fluid as follows :

- HP filters on each system and on the reservoir filling system and the normal braking system
- return line filters on each line
- case drain filters on engine pumps and the blue electric pump (which permit maintenance crew to monitor pump wear by inspecting the filters for the presence of metallic particles).

**GENERATION**

Ident.: DSC-29-10-20-00001145.0001001 / 08 FEB 13

Applicable to: ALL




**RESERVOIR PRESSURIZATION**

Ident.: DSC-29-10-20-00001146.0001001 / 08 FEB 13

Applicable to: ALL


Normally, HP bleed air from engine 1 pressurizes the hydraulic reservoirs automatically.  
 If the bleed air pressure is too low, the system takes bleed air pressure from the crossbleed duct.  
 The systems maintain a high enough pressure to prevent their pumps from cavitating.



**INDICATIONS**

Ident.: DSC-29-10-20-00001147.0002001 / 09 OCT 12


Applicable to: ALL



**DISTRIBUTION**

Ident.: DSC-29-10-30-00001148.0003001 / 08 FEB 13

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**HYDRAULIC**

DESCRIPTION - DISTRIBUTION


Intentionally left blank



**OVERHEAD PANEL**

Ident.: DSC-29-20-00001149.0001001 / 21 MAR 16

Applicable to: ALL



(1) ENG 1 (2) PUMP pb

On : The pump pressurizes the system when the engine is running.

OFF : The pump is depressurized. The generation of hydraulic power stops.

FAULT It : This amber light comes on, and the ECAM caution appears, if :

- The reservoir level is low
- The reservoir overheats
- The reservoir air pressure is low
- The pump pressure is low (inhibited on the ground, when the engine is stopped).

This light goes out, when the crew selects OFF, except during an overheat. (The light stays on as long as the overheat lasts).

(2) BLUE ELEC PUMP pb (guarded)

AUTO : If AC power is available, the electric pump operates :

- In flight
- On the ground, if one engine is running or if the crew has pressed the BLUE PUMP OVRD pushbutton on the maintenance panel.

OFF : The pump is de-energized.

**FAULT It :** This amber light comes on, and a caution appears on the ECAM, if :

- The reservoir level is low
- The reservoir overheats
- The air pressure in the reservoir is low
- The pump is delivering low pressure (inhibited on the ground, when the engines are stopped)
- The pump overheats.

The light goes out, when the crew selects OFF, except during an overheat. (The light stays on as long as the overheat lasts).

(3) YELLOW ELEC PUMP pb sw (springloaded)

**ON :** The electric pump is ON.  
 If the electrical power supply is removed, the pump will remain off when electrical power is applied again.

**Off :** The pump is off.  
 It comes on automatically when a crewman sets the lever of the cargo door manual selector valve to OPEN or CLOSE.  
 This inhibits the operation of other yellow system functions (except alternate braking and engine 2 reverse).

**FAULT It :** This amber light, accompanied by an ECAM caution, comes on if :

- the reservoir level is low
- air pressure in the reservoir is low
- the reservoir overheats
- pump pressure is low
- the pump overheats.

The light goes out when the crew selects OFF, except during an overheat. (The light stays on as long as the overheat lasts).

(4) PTU pb sw

**AUTO :** The bidirectional power transfer unit is armed and both the yellow and the green electrohydraulic valves are open.  
 The power transfer unit runs automatically when the differential pressure between the green and yellow systems is more than 500 PSI.

***Note:** The PTU is inhibited during the first engine start and automatically tested during the second engine start.*

**OFF :** Both the green and the yellow PTU electrohydraulic valves close. Power transfer stops.

**FAULT** It : This amber light comes on, and a caution appears on the ECAM, if :

- the green or the yellow reservoir overheats
- the green or the yellow reservoir has low air pressure
- the green or the yellow reservoir has a low fluid level.

The light goes out when the crew selects OFF, except during an overheat. (The light stays on as long as the overheat lasts).

(5) **RAT MAN ON pb**


The flight crew may extend the RAT at any time by pressing the RAT MAN ON pushbutton.

*Note:* The RAT extends automatically if AC BUS 1 and AC BUS 2 are lost. (Refer to DSC-24-20 Overhead Panel (Cont'd)).

**MAINTENANCE PANEL**

Ident.: DSC-29-20-00001150.0001001 / 21 MAR 16

Applicable to: ALL



(1) **BLUE PUMP OVRD pb sw (guarded)**

**ON** : The blue electric pump is on if the ELEC PUMP pushbutton switch on the HYD panel is at AUTO.

**Off** : The blue electric pump is off.


(2) LEAK MEASUREMENT VALVES pb sw (guarded)

- OFF:** The corresponding electrohydraulic valve closes and shuts off hydraulic supply to the primary flight controls.
- On :** The corresponding electrohydraulic valve opens to go back to normal hydraulic supply.

**ECAM HYD PAGE**


Ident.: DSC-29-20-00001151.0002001 / 23 JUN 15

Applicable to: **ALL**



(1) Reservoir quantity


It is in green, unless the fluid level goes below the warning level, in which case it becomes amber.



- (2) Reservoir LO AIR PRESS  
 This appears in amber, and a caution appears on ECAM, if the air pressure for the indicated reservoir drops below normal.
- (3) Reservoir OVHT  
 This appears in amber, and a caution appears on ECAM, if the temperature of returning hydraulic fluid temperature at the inlet to its reservoir is above normal.
- (4) FIRE VALVE  
 Cross line - Amber : The valve is fully closed.  
 In line - Green : The valve is not fully closed.
- (5) OVHT  
 This appears in amber if the electric pump for that system (blue or yellow) overheats.
- (6) RAT  
 RAT ▷ White : The RAT is stowed.  
 RAT ▣ Green : The RAT is not stowed.  
 RAT ► Amber : Pressure for stowing the RAT has been applied, or the RAT pump is not available.
- (7) ELEC  
 This legend, normally white, becomes amber if the associated power supply fails.
- (8) YELLOW ELEC PUMP control  
 ◁ White : The electric pump is off.  
 ▣ Green : The electric pump is ON.

◀ Amber : The electric pump is ON and the yellow system has low pressure.

(9) PTU control



(1)

Green : The power transfer unit (PTU) pushbutton switch is in AUTO and the PTU is not transferring pressure.

Amber : The PTU pb-sw is OFF.

(2)

Green : The PTU is supplying the green hydraulic system.

(3)

Green : The PTU is supplying the yellow hydraulic system.

(10) ENG PUMP control and low pressure indication

In line (Green) : The pushbutton switch for the designated PUMP is on and hydraulic pressure is normal.

Cross line (Amber) : The pushbutton switch for the designated PUMP is OFF.

“LO” (Amber) : The pushbutton switch for the designated PUMP is on and hydraulic pressure is low.

(11) System label

	<b>pressure &gt; 1 450 PSI</b>	<b>pressure &lt; 1 450 PSI</b>
<b>YELLOW</b>	white	amber
△	green	amber

(12) System pressure

This legend, normally green, becomes amber when system pressure is below 1 450 PSI.

(13) PUMP

This legend, normally white, becomes amber when N2 is below idle.

**MEMO DISPLAY**

**Applicable to: ALL**

Ident.: DSC-29-20-A-00016787.0001001 / 21 MAR 16

**HYD PTU** : This memo appears in green, when the power transfer unit is running.

Ident.: DSC-29-20-A-00016786.0001001 / 21 MAR 16

**RAT OUT** : This memo appears in green, if the Ram Air Turbine is not fully stowed. The color changes to amber during flight phases 1 and 2.

Intentionally left blank



# **AIRCRAFT SYSTEMS**

## ICE AND RAIN PROTECTION

Intentionally left blank

**DSC-30-10 General**

DSC-30-10-10 Description

General.....	A
Anti-Ice.....	B
Rain Removal.....	C

**DSC-30-20 Wing Anti-Ice**

DSC-30-20-10 Description

Description.....	A
------------------	---

DSC-30-20-20 Controls And Indicators

Overhead Panel.....	A
ECAM BLEED Page.....	B
Memo Display.....	C

**DSC-30-30 Engine Anti-Ice**

DSC-30-30-10 Description

Description.....	A
------------------	---

DSC-30-30-20 Controls and Indicators

Overhead Panel.....	A
Memo Display.....	B

**DSC-30-40 Window Heat**

DSC-30-40-10 Description

Description.....	A
------------------	---

DSC-30-40-20 Controls and Indicators

Overhead Panel.....	A
---------------------	---

**DSC-30-50 Probes Heat**

DSC-30-50-10 Description

Description.....	A
------------------	---

DSC-30-50-20 Controls and Indicators

Overhead Panel.....	A
---------------------	---


*Continued on the following page*

*Continued from the previous page*

**DSC-30-60 Rain Removal**


DSC-30-60-10 Description

Wipers..... A

Rain Repellent  ..... B

DSC-30-60-20 Controls and Indicators

Overhead Panel..... A

Rain Repellent  System Indicators..... B

**DSC-30-70 Ice Detection System**

DSC-30-70-10 Description

Visual Ice Indicator..... A

**GENERAL**

Ident.: DSC-30-10-10-00001154.0001001 / 16 MAR 11

Applicable to: ALL

The ice and rain protection system allows unrestricted operation of the aircraft in icing conditions and heavy rain.

**ANTI-ICE**

Ident.: DSC-30-10-10-00001155.0001001 / 29 MAR 12

Applicable to: ALL


Either hot air or electrical heating protects critical areas of the aircraft as follows:

**HOT AIR**

- Three outboard leading-edge slats of each wing
- Engine air intakes.

**ELECTRICAL HEATING**


- Flight compartment windows
- Sensors, pitot probes and static ports
- Waste-water drain mast.



**RAIN REMOVAL**

Ident.: DSC-30-10-10-00017416.0001001 / 21 MAR 16

Applicable to: **ALL**


Wipers and fluid rain repellent  , remove rain from the front windshield panels.

**DESCRIPTION**

Ident.: DSC-30-20-10-00017417.0001001 / 21 MAR 16

Applicable to: ALL

In flight, hot air from the pneumatic system heats the three outboard slats (3-4-5) of each wing. Air is supplied through one valve in each wing. The WING pushbutton on the ANTI ICE panel controls the valves. When the aircraft is on ground, the flight crew can initiate a 30 s test sequence by turning the system ON. If the system detects a leak during normal operation, the affected side's wing anti-ice valve automatically closes (*Refer to DSC-36-10-50 Leak Detection*). When wing anti-ice is selected, the N1 or EPR limit is automatically reduced, and the idle N1 or EPR is automatically increased. If the electrical power supply fails, the valves close.






**OVERHEAD PANEL**

Ident.: DSC-30-20-20-00017418.0001001 / 21 MAR 16

Applicable to: ALL



(1) WING ANTI ICE pb sw

This switch controls the wing anti ice system on the left and right sides simultaneously.

Off : ON light goes off.  
Wing anti-icing control valves close.

FAULT : Light comes on amber, and caution appears on ECAM, if:  
- The position of the anti-icing control valve is not the required position, or  
- Low pressure is detected.

*Note:* The amber FAULT light comes on briefly as the valves transit.

ON : Light comes on blue.  
WING A. ICE appears on the ECAM MEMO page.  
Wing anti ice control valves open if a pneumatic supply is available.  
On the ground the wing anti-icing control valves open for 30 s only (test sequence).

**ECAM BLEED PAGE**

Ident.: DSC-30-20-20-00001159.0001001 / 21 MAR 16

Applicable to: ALL

Refer to DSC-36-20 ECAM Bleed Page

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-30-20-20-A-00016939.0001001 / 21 MAR 16

**WING A.ICE** : This memo appears in green, if the WING ANTI ICE pb-sw is ON.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**ICE AND RAIN PROTECTION**

WING ANTI-ICE - CONTROLS AND INDICATORS

Intentionally left blank

**DESCRIPTION**

Ident.: DSC-30-30-10-00017422.0001001 / 21 MAR 16


**Applicable to: ALL**

An independent air bleed from the high pressure compressor protects each engine nacelle from ice. Air is supplied through a two-position (open and closed) valve that the flight crew controls with two pushbuttons, one for each engine.

The valve automatically closes, if air is unavailable (engine not running).

When an engine anti-ice valve is open, the N1 or EPR limit is automatically reduced and, if necessary, the idle N1 or EPR is automatically increased for both engines in order to provide the required pressure.


If electrical power fails, the valves open.



**OVERHEAD PANEL**

Ident.: DSC-30-30-20-00017425.0003001 / 21 MAR 16

Applicable to: ALL



(1) ENG 1 (2) ANTI ICE pb-sw

Off : ON light goes off.  
Engine anti-ice valve closes.

FAULT : Light comes on amber, and caution message appears on ECAM, if the position of the anti-ice valve disagrees with the ENG 1 (2) pushbutton selection.

*Note:* The amber FAULT light comes on briefly as valve transits.

ON : Light comes on blue.  
ECAM MEMO displays “ENG A. ICE”.  
Engine anti-icing valve opens if bleed air is available from the engine.

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-30-30-20-A-00016945.0001001 / 21 MAR 16

**ENG A.ICE** : This memo appears in green, if one or both ENG ANTI ICE pb-sw are ON.

Intentionally left blank

**DESCRIPTION**

Ident.: DSC-30-40-10-00017458.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft uses electrical heating for anti-icing each windshield and defogging the cockpit side windows.

Two independent Window Heat Computers (WHCs), one on each side, automatically regulate the system, protect it against overheating, and indicate faults.

Window heating comes on:

- automatically when at least one engine is running, or when the aircraft is in flight.
- manually, before engine start, when the flight crew switches ON the PROBE/WINDOW HEAT pushbutton switch.

Windshield heating operates at low power on the ground and at normal power in flight. The changeover is automatic.

Only one heating level exists for the windows.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ICE AND RAIN PROTECTION

WINDOW HEAT - DESCRIPTION

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**ICE AND RAIN PROTECTION**

WINDOW HEAT - CONTROLS AND INDICATORS

**OVERHEAD PANEL**

Ident.: DSC-30-40-20-00001165.0001001 / 21 MAR 16

**Applicable to: ALL**

*Refer to DSC-30-50-20 Overhead Panel*

Intentionally left blank

**DESCRIPTION**

Ident.: DSC-30-50-10-00017459.0001001 / 21 MAR 16

**Applicable to: ALL**

Electrical heating protects:

- Pitot probes
- Static ports
- Angle-Of-Attack (AOAs) probes
- Total Air Temperature (TAT) probes.

Three independent Probe Heat Computers (PHCs) automatically control and monitor:

- Captain probes
- F/O probes
- STBY probes.

They protect against overheating and indicate faults.

The probes are heated:

- Automatically when at least one engine is running, or when the aircraft is in flight.
- Manually, when the flight crew switches ON the PROBE/WINDOW HEAT pb.

On the ground, the TAT probes are not heated and pitot heating operates at a low level (the changeover to normal power in flight is automatic).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ICE AND RAIN PROTECTION


#### PROBES HEAT - DESCRIPTION

Intentionally left blank

**OVERHEAD PANEL**

Ident.: DSC-30-50-20-00017460.0001001 / 21 MAR 16

Applicable to: ALL



(1) PROBE/WINDOW HEAT pb

AUTO : Probes/Windows are heated automatically :

- In flight, or
- On the ground (except TAT probes) provided one engine is running.

ON : Light comes on blue. Probes and windows are heated permanently.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**ICE AND RAIN PROTECTION**


PROBES HEAT - CONTROLS AND INDICATORS

Intentionally left blank

**WIPERS**

Ident.: DSC-30-60-10-00017461.0001001 / 21 MAR 16

**Applicable to: ALL**

Each front windshield has an electrical wiper with two speeds, and with an intermittent sweep function . A rotary selector controls each wiper.

**RAIN REPELLENT **

Ident.: DSC-30-60-10-00017462.0001001 / 01 JUN 17

**Applicable to: ALL**


In moderate to heavy rain, the flight crew can spray a rain repellent liquid on the windshield to improve visibility.

After about 30 s, the windows are covered with spray.

Separate pushbuttons control rain repellent application on each side of the windshield.

**AIRCRAFT SYSTEMS**  
**ICE AND RAIN PROTECTION**

RAIN REMOVAL - DESCRIPTION








**OVERHEAD PANEL**

Ident.: DSC-30-60-20-00017466.0001001 / 21 MAR 16

Applicable to: ALL




- (1) WIPER rotary selector  
Each rotary selector controls its wiper at low speed, high speed, or intermittent sweeping . When turned off, the wiper stops out of view.
- (2) RAIN RPLNT pb-sw   
Each of these buttons controls the application of rain repellent fluid to the corresponding side of the front windshield. When the flight crew pushes the button, the timer applies a measured quantity of rain repellent to the windshield. To repeat the cycle, the flight crew must push the button again. This function is inhibited when the aircraft is on the ground and the engines are stopped.

**RAIN REPELLENT ◀ SYSTEM INDICATORS**

Ident.: DSC-30-60-20-00017587.0001001 / 21 MAR 16

Applicable to: ALL



- (1) Rain Repellent pressure indicator  
 This gauge shows the nitrogen pressure and therefore the remaining fluid in the rain repellent bottle. When the needle is in the yellow sector the bottle should be replaced.
- (2) Rain Repellent low level indicator (depending on aircraft configuration)  
 When the REFILL float is in view the bottle should be replaced.

**VISUAL ICE INDICATOR**

Ident.: DSC-30-70-10-00017471.0001001 / 21 MAR 16

**Applicable to: ALL**

An external visual ice indicator is installed between the two windshields.

There can be also an external ice detector light 

Intentionally left blank

# **AIRCRAFT SYSTEMS**

## **INDICATING/RECORDING SYSTEMS**

Intentionally left blank

**DSC-31-05 EIS General**

**DSC-31-05-10 Introduction**

Introduction.....A

**DSC-31-05-20 Cockpit Arrangement**

Cockpit Arrangement.....A

**DSC-31-05-30 Architecture**

Display Unit (DU).....A  
 Display Management Computer (DMC).....B  
 System Data Acquisition Concentrator (SDAC).....C  
 Flight Warning Computer (FWC).....D  
 Attention - Getters.....E  
 Loudspeaker.....F  
 EIS Block Diagram.....G

**DSC-31-05-40 Controls and Switching**

ECAM Control Panel (ECP).....A  
 EIS DMC Switching Selector.....B  
 ECAM/ND Switching.....C  
 EFIS Switching.....D

**DSC-31-05-50 Reconfiguring the DMC**

Reconfiguring the Display Management Computer (DMC).....A

**DSC-31-05-60 Reconfiguring DUs**

Failure of Upper ECAM DU (or CTL/Brightness Knob Turned to Off).....A  
 Failure of Lower ECAM DU (or CTL/Brightness Knob Turned to Off).....B  
 Failure of both ECAM DUs.....C  
 PFDU/NDU Reconfiguration.....D  
 DU Reconfiguration.....E  
 General.....F  
 Failure of a DU.....G  
 Feedback Messages.....H  
 Side1/Side2 Discrepancy Messages.....I  
 DU Reset.....J

*Continued on the following page*

*Continued from the previous page*

**DSC-31-10 ECAM Description**

ECAM DU Arrangement.....	A
Color Code.....	B
Warning/Caution Classification.....	C
Priority Rules.....	D
Types of Failures.....	E
Audio Indicators.....	F

**DSC-31-15 Indications on E/WD**

General.....	A
Independent Failure.....	B
Primary and Secondary Failure.....	C
Flight Phases.....	D
Memos.....	E
Configuration Warnings.....	F

**DSC-31-20 Indications on SD**

General.....	A
System Pages.....	B
Status Page.....	C
Permanent Data.....	D
Amber Crosses "XX" on the SD.....	E
Amber dashes on the SD.....	F

**DSC-31-25 ECAM Sequence**

**DSC-31-25-10 General**

General.....	A
--------------	---

**DSC-31-25-20 Example**

1 - The Ecam Detects No Failure.....	A
2 - The ECAM Detects a Failure.....	B
3 - The Flight Crew Follows the Instruction Displayed on the E/WD.....	C
4 - One of the Pilots Pushes the CLR Pushbutton on the ECP.....	D
5 - One of the Pilots Pushes the CLR Pushbutton a Second Time.....	E
6 - One of the Pilots Pushes the CLR Pushbutton a Third Time.....	F

**DSC-31-27 OEB Reminder**

General.....	A
Description.....	B
OEB Database.....	C

*Continued on the following page*




*Continued from the previous page*


**DSC-31-30 ECAM Controls**

ECAM Control Panel.....	A
Switching Panel.....	B
Attention Getters.....	C
Memo Display.....	D

**DSC-31-40 Indications on PFD**

General.....	A
Specific Ground Indications.....	B
Attitude Data.....	C
Airspeed.....	D
Altitude.....	E
Altitude (CONT'D).....	F
Vertical Speed.....	G
Heading.....	H
Flight Path Vector.....	I
Guidance.....	J
Trajectory Deviation.....	K
Flight Mode Annunciator.....	L
Tailstrike Pitch Limit Indicator  .....	M
Altitude Alert.....	N
Flags and Messages Displayed on PFD.....	O
Backup Speed/Altitude Scale.....	P

**DSC-31-45 Indications on ND**

General.....	A
ROSE Modes.....	B
ROSE LS Mode.....	C
Rose VOR Mode.....	D
ROSE NAV Mode/ARC Mode.....	E
Plan Mode.....	F
Weather Radar indications.....	G
PWS  indications.....	H
EGPWS.....	I
Flags and Messages Displayed on ND.....	J

*Continued on the following page*

*Continued from the previous page*

**DSC-31-50 EFIS Controls**

EFIS Control Panel.....	A
Other EFIS Controls.....	B
Chronometer.....	C

**DSC-31-55 Clock**

DSC-31-55-10 General

General.....	A
--------------	---

DSC-31-55-20 Controls and Indicators

General.....	A
Operation in Internal Mode.....	B

**DSC-31-60 FLT Recorders**

DSC-31-60-10 Flight Data Recording System

Description.....	A
------------------	---

DSC-31-60-20 Controls and Indicators

Overhead Panel.....	A
Pedestal.....	B

DSC-31-60-30 Aircraft Integrated Data System

Description.....	A
Controls On Pedestal.....	B

**INTRODUCTION**

Ident.: DSC-31-05-10-00001182.0001001 / 21 MAR 16

**Applicable to: ALL**

The Electronic Instrument System (EIS ) presents data on six identical Display Units (DUs):

- The Electronic Flight Instrument System (EFIS ) displays mostly flight parameters and navigation data on the Primary Flight Displays (PFD s) and Navigation Displays (NDs).
- The Electronic Centralized Aircraft Monitor (ECAM ) presents data on the Engine/Warning Display (E/WD ) and System Display (SD ) :
  - Primary engine indications, fuel quantity, flap and slat position
  - Warning and caution alerts, or memos
  - Synoptic diagrams of aircraft systems, and status messages
  - Permanent flight data



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**


EIS GENERAL - INTRODUCTION

Intentionally left blank


**COCKPIT ARRANGEMENT**

Ident.: DSC-31-05-20-00001183.0001001 / 09 OCT 12

Applicable to: ALL



Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>INDICATING/RECORDING SYSTEMS</b></p> <p>EIS GENERAL - ARCHITECTURE</p>
---	---

**DISPLAY UNIT (DU)**

Ident.: DSC-31-05-30-00001184.0002001 / 21 MAR 16  
**Applicable to: ALL**

The instrument panels have six identical units.  
 These DUs are full-color Liquid Crystal Displays (LCD).

**DISPLAY MANAGEMENT COMPUTER (DMC)**

Ident.: DSC-31-05-30-00001185.0002001 / 20 DEC 10  
**Applicable to: ALL**

Three identical Display Management Computers (DMC s) obtain data from the different sensors and computers, and send it to the display units. The display units then generate and display the applicable images. Each DMC has a single DMC channel, and can simultaneously supply one PFD , one ND and both ECAM display units (E/WD and SD).

**SYSTEM DATA ACQUISITION CONCENTRATOR (SDAC)**

Ident.: DSC-31-05-30-00001186.0001001 / 21 MAR 16  
**Applicable to: ALL**

The two identical SDAC s acquire data, then generate signals. Some of these signals go to the three DMC s, which use them to generate displays of system pages and engines parameters. Others go to the flight warning computers, which use them to generate ECAM messages and aural alerts.

**FLIGHT WARNING COMPUTER (FWC)**

Ident.: DSC-31-05-30-00001187.0001001 / 13 JAN 14  
**Applicable to: ALL**

The two identical FWCs generate alert messages, memos, aural alerts, and synthetic voice messages. For this purpose they acquire data:

- Directly from aircraft sensors, or systems, to generate red warnings
- Through the SDACs to generate amber cautions.

The ECAM display units display the alert messages generated by the FWCs.

The FWCs also generate:

- Radio height callouts
- Decision height callouts
- Landing distance and landing speed increments.

### ATTENTION - GETTERS

Ident.: DSC-31-05-30-00001188.0001001 / 21 MAR 16

Applicable to: **ALL**

The FWCs also drive the attention-getters. Each pilot has a set of these on the panel under the glareshield. They are :

- A master warning light, that flashes "MASTER WARN" in red, for red warnings.
- A master caution light, that illuminates "MASTER CAUT" in amber, for amber cautions.

### LOUDSPEAKER

Ident.: DSC-31-05-30-00001189.0001001 / 21 MAR 16

Applicable to: **ALL**


The communications loudspeakers announce aural alerts and voice messages, and do so even when they are turned off.



**EIS BLOCK DIAGRAM**

Ident.: DSC-31-05-30-00001190.0002001 / 06 JUL 17

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

EIS GENERAL - ARCHITECTURE

Intentionally left blank

### ECAM CONTROL PANEL (ECP)

Ident.: DSC-31-05-40-00001191.0001001 / 21 MAR 16

**Applicable to: ALL**

The ECAM Control Panel, located on the pedestal, includes :

- Such E/WD controls, as CLR , STS, and the brightness control knob.
- Such SD controls, as ENG, BLEED, PRESS..., system page selector, and the brightness control knob.

### EIS DMC SWITCHING SELECTOR

Ident.: DSC-31-05-40-00001192.0001001 / 22 MAR 16

**Applicable to: ALL**

A switch near the center of the SWITCHING panel which is located just above the ECAM control panel, enables the flight crew to replace the Captain or First Officer's Display Management Computer (DMC 1, or DMC 2) by DMC 3.

### ECAM/ND SWITCHING

Ident.: DSC-31-05-40-00001193.0001001 / 21 MAR 16

**Applicable to: ALL**

A switch on the right-hand side of the SWITCHING panel enables the flight crew to transfer the ECAM System Display to either the Captain or First Officer's Navigation Display.

### EFIS SWITCHING

Ident.: DSC-31-05-40-00001194.0001001 / 21 MAR 16

**Applicable to: ALL**

A PFD/ND XFR pushbutton on each side console enables the pilot to swap displays to the respective outside DUs.

Intentionally left blank

**RECONFIGURING THE DISPLAY MANAGEMENT COMPUTER (DMC)**

Ident.: DSC-31-05-50-00001195.0002001 / 21 MAR 16

**Applicable to: ALL**

In normal operation, each DMC drives the following Display Units :

- DMC 1 drives the CAPT PFD, CAPT ND and the ECAM DUs.
- DMC 2 drives the F/O PFD and F/O ND.
- DMC 3 is on standby, ready to drive any DU.

If DMC 1 or 2 fails (the "INVALID DATA" message is displayed on the DU s), the crew manually selects the DMC 3 source ("CAPT 3" or "F/O 3").

If DMC 1 fails (or DMC 3, if "CAPT 3" was selected), DMC 2 automatically drives the ECAM.

Intentionally left blank

**FAILURE OF UPPER ECAM DU (OR CTL/BRIGHTNESS KNOB TURNED TO OFF)**

Ident.: DSC-31-05-60-00001196.0001001 / 21 MAR 16

Applicable to: ALL

If the upper ECAM display fails, or is switched off :

- The engine/warning page automatically replaces the system/status page on the lower ECAM DU.

The flight crew can display the system/status page by :

- Using the "ECAM/ND XFR" switch, on the SWITCHING panel, to move it to a Navigation Display Unit (NDU), or
- Pushing and holding (for a maximum of 3 min) the related system page pushbutton, on the ECAM control panel, to temporarily display it on the lower ECAM DU (instead of the engine/warning page).

**FAILURE OF LOWER ECAM DU (OR CTL/BRIGHTNESS KNOB TURNED TO OFF)**

Ident.: DSC-31-05-60-00001197.0001001 / 21 MAR 16

Applicable to: ALL

If the lower ECAM display fails, or is switched off, the flight crew can display the system/status page by :

- Using the "ECAM/ND XFR" switch, on the SWITCHING panel, to display it on the NDU, or
- Pushing and holding (for a maximum of 3 min) the related system page pushbutton, on the ECAM control panel, to temporarily display it on the upper ECAM DU (instead of the engine/warning page).

**FAILURE OF BOTH ECAM DUs**

Ident.: DSC-31-05-60-00001198.0001001 / 21 MAR 16

Applicable to: ALL

If both ECAM displays fail, the flight crew may :

- Use the "ECAM/ND XFR", on the SWITCHING panel, to display the engine/warning page on a navigation display and, if needed,
- Push and hold (for a maximum of 3 min) the related system page pushbutton, on the ECAM control panel, to temporarily display the system/status page on an ND.

**PFDU/NDU RECONFIGURATION**

Ident.: DSC-31-05-60-00001199.0001001 / 21 MAR 16

Applicable to: ALL

If a PFDU fails, the system automatically transfers the PFD image to the NDU.

The pilot can also make this transfer manually by :

- turning the PFD ON-OFF/brightness control OFF, or
- pressing the PFD/ND/XFR pushbutton, which cross-changes the images between the PFDU and the NDU.


If an NDU fails, the pilot can use the PFD/ND/XFR pushbutton to transfer the ND image to the PFDU.



**DU RECONFIGURATION**

Ident.: DSC-31-05-60-00001200.0001001 / 21 MAR 16

Applicable to: ALL



## AIRCRAFT SYSTEMS

### INDICATING/RECORDING SYSTEMS

EIS GENERAL - RECONFIGURING DUS

#### GENERAL

Ident.: DSC-31-05-60-00012844.0001001 / 20 DEC 10

Applicable to: **ALL**

These messages are displayed on either the EFIS or the ECAM Display Unit (DU ) depending on the current EFIS or ECAM configuration.

#### FAILURE OF A DU

Ident.: DSC-31-05-60-00012846.0001001 / 20 DEC 10

Applicable to: **ALL**

If a DU fails, the flight crew may find one of the following displays:

- A blank screen with an "F" letter in amber, or
- A distorted display, or
- A blank screen with the "INVALID DISPLAY UNIT" message in amber.

#### FEEDBACK MESSAGES

Ident.: DSC-31-05-60-00012847.0001001 / 20 DEC 10

Applicable to: **ALL**

The DU displays the following messages in amber when the Display Management Computer (DMC ) detects a discrepancy between the parameters obtained by the DMC and the operational parameters displayed on the DU:

- "CHECK CAPT PFD " ("CHECK F/O PFD ") if the discrepancy concerns the PFD parameters
- "CHECK CAPT ND " ("CHECK F/O ND ") if the discrepancy concerns the ND parameters
- "CHECK EWD " if the discrepancy concerns the E/WD parameters
- "CHECK SD " if the discrepancy concerns the SD parameters.

In addition, if the aircraft is on ground, the "DU NOT MONITORED" message is displayed in amber when there is only one DMC , instead of two DMC s, that provides the affected DU with feedback information.

This message means that there is either a DMC test in progress or that there is an EIS failure.

In the case of an EIS failure, a maintenance action is necessary.

**SIDE1/SIDE2 DISCREPANCY MESSAGES**

Ident.: DSC-31-05-60-00012848.0001001 / 20 DEC 10

**Applicable to: ALL**

The DU displays the following messages along with a caution on the ECAM E/WD when there is a discrepancy between the parameters displayed on the Captain's EFIS and the First Officer's EFIS:

- Both PFD s display the message "CHECK ATT" if there is a discrepancy of at least 5 ° between the attitude values, pitch and/or roll
- Both PFD s display the message "CHECK ALT " if there is a discrepancy between the altitude values greater than 250 ft when the flight crew selects a QNH different from STD , or 500 ft when the flight crew selects a QNH STD
- Both PFD s and ND s display the message "CHECK HDG" if there is a discrepancy of at least 5 ° between the heading values.

*Note: The message "CHECK HDG " flashes for a few seconds on the ND s, and then it remains steady. If the flight crew selects the PLAN mode on the ND s the message "CHECK HDG" does not appear.*

**DU RESET**

Ident.: DSC-31-05-60-00012849.0001001 / 20 DEC 10

**Applicable to: ALL**

In the case of a DU reset, the message "SELF TEST IN PROGRESS" can be displayed in green and/or the message "WAITING FOR DATA" may be displayed in green during the EIS initialization.

Intentionally left blank


**ECAM DU ARRANGEMENT**

Ident.: DSC-31-10-00017519.0001001 / 21 MAR 16

Applicable to: ALL

The ECAM has two display units:

- One for the engine/warning display (E/WD).
- One for the system/status display (SD).



**COLOR CODE**

Ident.: DSC-31-10-00001202.0001001 / 21 MAR 16

Applicable to: **ALL**

The ECAM display uses a color code that indicates the importance of the failure or the indication.

- RED : The configuration or failure requires immediate action.
- AMBER : The flight crew should be aware of the configuration or failure, but need not take immediate action.
- GREEN : The item is operating normally.
- WHITE : These titles and remarks guide the flight crew, as they execute various procedures.
- BLUE : These are actions to be carried out, or limitations.
- MAGENTA : These are particular messages that apply to particular pieces of equipment or situations (inhibition messages, for example).

**WARNING/CAUTION CLASSIFICATION**

Ident.: DSC-31-10-00001203.0001001 / 21 MAR 16

Applicable to: ALL

	LEVEL	SIGNIFICATION	AURAL	VISUAL
<b>FAILURE MODE</b>	Level 3	Red warning : The configuration, or failure requires immediate action : - Aircraft in dangerous configuration, or limit flight conditions (eg: stall, o/speed) - System failure altering flight safety (eg : Eng fire, excess cab alt)	Continuous Repetitive Chime (CRC) or specific sound or synthetic voice	- MASTER WARN light red flashing or specific red light - Warning message (red) on E/WD - Automatic call of the relevant system page on the S/D <sup>(1)</sup> .
	Level 2	Amber caution :  The flight crew should be aware of the configuration or failure, but does not need to take any immediate action. However, time and situation permitting, these cautions should be considered without delay to prevent any further degradation of the affected system : - System failure without any direct consequence on the flight safety (eg: HYD G SYS LO PR)	Single Chime (SC)	- MASTER CAUT light amber steady - Caution message (amber) on E/WD - Automatic call of the relevant system page on the S/D <sup>(1)</sup> .
	Level 1	Amber caution : Requires crew monitoring : - Failures leading to a loss of redundancy or system degradation (eg : FCDC fault)	NONE	- Caution message (amber) on E/WD generally without procedure.
<b>INFORMATION</b>	ADVISORY	System parameters monitoring	NONE	- Automatic call of the relevant system page on the S/D. The affected parameter pulses green.
	MEMO	Information : Recalls normal or automatic selection of functions which are temporarily used	NONE	- Green, Amber, or Magenta message on E/WD

<sup>(1)</sup> except in some cases

**PRIORITY RULES**

Ident.: DSC-31-10-00001204.0001001 / 17 MAR 17

Applicable to: **ALL**

There are three priority levels for warnings and cautions :

- A level 3 warning has priority over a level 2 caution which has priority over a level 1 caution.

The FWC observes these priorities.

**INFORMATION PROVIDED WHEN NEEDED**

One of the main advantages of the ECAM is that it displays applicable information to the flight crew, on an "as needed" basis. The following outlines the ECAM's operating modes:

- **Normal Mode:**  
Automatically displays systems and memos, in accordance with the flight phase.
- **Failure Mode:**  
Automatically displays the appropriate emergency/abnormal procedures, in addition to their associated system synoptic.
- **Advisory Mode:**  
Automatically displays the appropriate system synoptic, associated with a drifting parameter.
- **Manual Mode:**  
Enables the flight crew to manually select any system synoptic via the ECAM Control Panel (ECP).

Most warnings and cautions are inhibited during critical phases of flight (T/O INHIBIT – LDG INHIBIT), because most system failures will not affect the aircraft's ability to continue a takeoff or landing.

**TYPES OF FAILURES**

Ident.: DSC-31-10-00001205.0001001 / 21 MAR 16


Applicable to: **ALL**

Independent : a failure that affects an isolated system or item of equipment without degrading the performance of others in the aircraft.

Primary : a failure of a system or an item of equipment that costs the aircraft the use of other systems or items of equipment.

Secondary : the loss of a system or an item of equipment resulting from a primary failure.



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>INDICATING/RECORDING SYSTEMS</b>  ECAM DESCRIPTION
---	--

**AUDIO INDICATORS**

Applicable to: ALL

AUDIO INDICATORS	MEANING	DURATION	AUDIO INDICATOR CANCELLATION <sup>(a)</sup>
------------------	---------	----------	---

Ident.: DSC-31-10-A-00015446.0001001 / 22 JUL 16

CONTINUOUS REPETITIVE CHIME	RED WARNINGS	PERMANENT	Press MASTER WARN It
-----------------------------	--------------	-----------	----------------------

Ident.: DSC-31-10-A-00015447.0001001 / 22 JUL 16

SINGLE CHIME	AMBER CAUTION	0.5 s	
--------------	---------------	-------	--

Ident.: DSC-31-10-A-00015448.0001001 / 04 FEB 14

CAVALRY CHARGE	A/P DISCONNECTION BY TAKE OVER pb	1.5 s	Second push on TAKE OVER pb
	A/P DISCONNECTION DUE TO FAILURE	PERMANENT	Press MASTER WARN It or TAKE OVER pb

Ident.: DSC-31-10-A-00015449.0006001 / 22 JUL 16

TRIPLE CLICK	Landing capability downgrade or some cases of mode reversion	0.5 s (3 pulses)	
--------------	--	------------------	--

Ident.: DSC-31-10-A-00015450.0001001 / 04 FEB 14

CRICKET + "STALL" message (synthetic voice)	STALL	PERMANENT	NIL
--	-------	-----------	-----

Ident.: DSC-31-10-A-00015451.0001001 / 23 JUN 15

BUZZER	CABIN CALL	3 s	NIL
	EMER CABIN CALL	3 s REPEATED 3 TIMES	NIL
	MECH CALL	As long as outside pb pressed	Press MASTER CAUT pb

Ident.: DSC-31-10-A-00015452.0001001 / 23 JUN 15

CONTINUOUS BUZZER	SELCAL CALL	PERMANENT	Press RESET key on ACP or press MASTER CAUT pb
-------------------	-------------	-----------	--

*Continued on the following page*

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

ECAM DESCRIPTION

*Continued from the previous page*

AUDIO INDICATORS	MEANING	DURATION	AUDIO INDICATOR CANCELLATION <sup>(a)</sup>
------------------	---------	----------	---

Ident.: DSC-31-10-A-00015453.0002001 / 06 APR 17

"WINDSHEAR" (synthetic voice)	WINDSHEAR	REPEATED 3 TIMES	NIL
"GO AROUND WINDSHEAR AHEAD" (synthetic voice)	Windshear ahead detected during the landing phase	PERMANENT	NIL
"WINDSHEAR AHEAD" (twice) (synthetic voice)	Windshear ahead detected during the takeoff phase	PERMANENT	NIL
"MONITOR RADAR DISPLAY" (synthetic voice)	Windshear ahead detected caution message	PERMANENT	NIL

Ident.: DSC-31-10-A-00015454.0001001 / 04 FEB 14

C CHORD	ALTITUDE ALERT (Refer to DSC-31-40 <i>Altitude Alert</i> )	1.5 s or PERMANENT	new ALTITUDE selection or press MASTER WARN pb
---------	--	--------------------------	--

Ident.: DSC-31-10-A-00015455.0001001 / 21 MAR 16

AUTO CALL OUT (synthetic voice)	HEIGHT ANNOUNCEMENT BELOW 2 500 ft (Refer to DSC-34-NAV-40-10 <i>Automatic Callout</i> )	PERMANENT	NIL
---------------------------------	--	-----------	-----

Ident.: DSC-31-10-A-00015456.0001001 / 21 MAR 17

GROUND PROXIMITY WARNING (synthetic voice)	(Refer to DSC-34-SURV-40-10 <i>Overview</i> )	PERMANENT	NIL
--	--	-----------	-----


Ident.: DSC-31-10-A-00015457.0001001 / 04 FEB 14

"PRIORITY LEFT" "PRIORITY RIGHT" (synthetic voice)	A/P TAKE OVER pb	1 s	NIL
--	------------------	-----	-----

Ident.: DSC-31-10-A-00015458.0001001 / 04 FEB 14

"RETARD" (synthetic voice)	Thrust levers not in IDLE or REVERSE position for landing	ONE TIME at 20 ft (10 ft in autoland with A/THR ON), Then PERMANENT	All Thrust levers are set to IDLE or REVERSE
----------------------------	---	---	--

*Continued on the following page*

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>INDICATING/RECORDING SYSTEMS</b>  ECAM DESCRIPTION
---	--

*Continued from the previous page*

AUDIO INDICATORS	MEANING	DURATION	AUDIO INDICATOR CANCELLATION <sup>(a)</sup>
------------------	---------	----------	--

Ident.: DSC-31-10-A-00015459.0001001 / 04 FEB 14

"RETARD-RETARD" (synthetic voice)	At least one Thrust Lever above IDLE after touchdown	Above 40 kt, PERMANENT	All Thrust levers are set to IDLE or REVERSE
--------------------------------------	--	------------------------	--

Ident.: DSC-31-10-A-00015460.0001001 / 04 FEB 14

TCAS (synthetic voice)	<i>(Refer to DSC-34-SURV-60-20 Aural Messages)</i>	PERMANENT	NIL
---------------------------	--	-----------	-----

Ident.: DSC-31-10-A-00015461.0001001 / 04 FEB 14

"SPEED, SPEED, SPEED" (Synthetic voice)	Current thrust is not sufficient to recover a positive flight through pitch control	Every 5 s until thrust is increased	THRUST LEVER(s)
--	---	-------------------------------------	-----------------

Ident.: DSC-31-10-A-00015463.0001001 / 04 FEB 14

"DUAL INPUT" (synthetic voice)	Both sidesticks are moved simultaneously	Every 5 s	One sidestick deactivated
-----------------------------------	--	-----------	---------------------------

Ident.: DSC-31-10-A-00015465.0001001 / 04 FEB 14

"PITCH, PITCH" (synthetic voice)	The aircraft pitch attitude is becoming excessive during flare and landing.	one time	NIL
-------------------------------------	---	----------	-----

<sup>(a)</sup> *The pilot can cancel any audio indicator, by pressing:*

- *The EMER CANC pb on the ECAM control panel, or*
- *The MASTER WARN pushbutton, except for OVERSPEED or L/G NOT DOWN warnings.*

Intentionally left blank


**GENERAL**

Ident.: DSC-31-15-00001207.0003001 / 21 MAR 17

Applicable to: ALL

The Engine Warning Display (E/WD ) appears on the ECAM 's upper Display Unit (DU).

- The upper part of this DU displays:
  - Engine parameters (*Refer to DSC-70-90-40 Engine Warning Display*)
  - Feedback messages (*Refer to DSC-31-05-60 Feedback Messages*)
  - Fuel On Board (FOB) (*Refer to DSC-28-20 ECAM Upper Display*)
  - Slats/Flaps' position (*Refer to DSC-27-20-30 ECAM F/CTL Page*)
- The lower part of this DU displays messages generated by the FWC:
  - Warning and caution messages, when a failure occurs
  - Memos when there is no failure.



The lower part of the DU , dedicated to ECAM messages, is divided into two sections that have several lines each.

- Bottom left : - Primary or independent warnings and cautions, or  
 - Memo information.
- Bottom right : - Title of the system affected by a primary or independent warning or caution, in the case of overflow on the bottom left part, or  
 - Secondary failure, or  
 - Memo, or  
 - Special lines (such as “AP OFF”, “LAND ASAP”).

As soon as the FWC detects a failure, and if there is no flight phase inhibition active, the E/WD displays the title of the failure and actions that the flight crew must perform.


The action line automatically clears, when the flight crew has performed the necessary action.

*Note:* Some action lines do not disappear from the E/WD even after the flight crew performs the necessary action.

**INDEPENDENT FAILURE**

Ident.: DSC-31-15-00001208.0001001 / 03 FEB 11

Applicable to: ALL




If there are too many ECAM messages for the amount of space available in the lower part of the E/WD, a green arrow appears at the bottom of the display, pointing down to show that the information has overflowed off the screen. The pilot can scroll down to view additional messages by pushing the CLR pushbutton on the ECAM control panel (on the pedestal, just below the lower ECAM DU).

**PRIMARY AND SECONDARY FAILURE**

Ident.: DSC-31-15-00001209.0001001 / 03 FEB 11

Applicable to: ALL



The ECAM DU displays a primary failure as a boxed title. It identifies a secondary failure by putting a star in front of the title of the affected system.

Note: The DU displays the overflow symbol, if primary or secondary failures overflow. In case of ELEC EMER CONFIG, the secondary failures are inhibited.


**FLIGHT PHASES**

Ident.: DSC-31-15-00001210.0001001 / 21 MAR 16

Applicable to: ALL

**GENERAL**

The FWC divides its functions according to these ten flight phases :




To improve its operational efficacy, the computer inhibits some warnings and cautions for certain flight phases. It does so to avoid alerting the pilots unnecessarily at times when they have high

workloads, such as during takeoff or landing. In these two phases, the DU displays magenta memos : “T.O. INHIBIT” (flight phases 3, 4, and 5), and “LDG INHIBIT” (flight phases 7 and 8).

*Note:* These flight phases are different from and independent of the ones that the FMGC uses.

**FLIGHT PHASE INHIBITION**

Two cases are possible (for instance) :



Effect on E/WD :

- (a) The failure occurs during phase 1. The E/WD displays the warning immediately and continues to display it as long as the failure is present, even in phase 2.
- (b) The failure occurs during phase 2. The E/WD displays the warning only when the aircraft has entered phase 3, where it is not inhibited. Then the warning remains displayed as long as the failure is present.

**MEMOS**

Applicable to: ALL

Ident.: DSC-31-15-A-00001211.0001001 / 21 MAR 16

**DISPLAY**

Memos appear in the lower part of the E/WD. They are normally in green, but may be amber in abnormal situations.

Memos list functions or systems that are temporarily used in normal operations.


Ident.: DSC-31-15-A-00001212.0002001 / 22 APR 16

**TO AND LDG MEMOS**


During the takeoff and landing phases, the right side of the memo area displays specific TO INHIBIT or LDG INHIBIT (magenta) memos.

Takeoff and landing memos are displayed, as follows, during the related flight phases:





- (\*) This line disappears when the test is completed. It is replaced by “TO CONFIG NORMAL”, if aircraft configuration is correct.  
 The test is requested again, if the configuration becomes abnormal.



- (\*) “CONF 3” is displayed in alternate or direct law, or if the GPWS LDG FLAP 3 pushbutton is ON.

Note: After a go-around, if the aircraft does not climb above 2 200 ft RA, the landing memo appears only below 800 ft RA during the subsequent approach.

**CONFIGURATION WARNINGS**

Ident.: DSC-31-15-00001214.0015001 / 16 MAR 11

Applicable to: ALL

The following warnings and cautions appear in the lower part of the E/WD if the aircraft is not in takeoff configuration when the flight crew presses the TO CONFIG pushbutton on the ECAM control panel or applies takeoff power.

WARNINGS/CAUTIONS	TO CONFIG TEST	TO POWER
CONFIG RUD TRIM NOT IN TO RANGE (R)	TRIGGERED	TRIGGERED
CONFIG PITCH TRIM NOT IN TO RANGE (R)		
CONFIG FLAPS NOT IN TO CONFIG (R)		
CONFIG SPD BRK NOT RETRACTED (R)		
CONFIG SLATS NOT IN TO CONFIG (R)		
CONFIG L SIDESTICK FAULT (R)		
CONFIG R SIDESTICK FAULT (R)		
DOOR (A)		
FWS OEB /FWC DISCREPANCY (A)		
BRAKES HOT (A)		
FUEL R(L) TK PUMP 1+2 LO PR (A)	TRIGGERED if the two GENs are inop.	NOT TRIGGERED
HYD G(Y) ENG 1(2) PUMP LO PR (A)		
HYD G(Y)(B) SYS LO PR (A)		
ELEC IDG 1(2) DISCONNECTED (A)		
ELEC GEN 1(2) FAULT (A)	NOT TRIGGERED	TRIGGERED
ELEC GEN 1(2) OFF (A)		
CONFIG PARK BRK ON (R)		
ENG THR LEVERS NOT SET (A)	NOT TRIGGERED	TRIGGERED

(R) Red warning

(A) Amber caution

**GENERAL**

Ident.: DSC-31-20-00001215.0001001 / 21 MAR 16

**Applicable to: ALL**

The system/status display (SD) uses the lower ECAM DU to display :

- pages showing synoptic diagrams of the aircraft systems, or
- the status page.

**SYSTEM PAGES**

Ident.: DSC-31-20-00001216.0002001 / 21 MAR 16

**Applicable to: ALL**


The lower ECAM DU can display 12 system pages (For description see relevant FCOM chapter):

- ENGINE (secondary engine parameters)
- BLEED (air bleed)
- CAB PRESS (cabin pressurization)
- ELEC (electric power)
- HYD (hydraulic)
- FUEL (fuel)
- APU (auxiliary power unit)
- COND (air conditioning)
- DOOR/OXY (doors/oxygen)
- WHEEL (landing gear, braking, ground spoilers, etc.)
- F/CTL (flight controls)
- CRUISE (cruise)

The pilot may manually call up a system page for display on the lower ECAM DU, or the system may automatically display a page.

- Manual:
  - The pilot can, at any time, use the pushbutton on the ECAM's control panel to call up and display any system page, except the CRUISE page.
  - The corresponding pushbutton on the ECAM control panel lights up.
  - A failure-related or advisory display automatically replaces a page the pilot has manually called up.
- Automatic, related to a failure:
  - The relevant system page automatically appears, as soon as any fault or malfunction triggers a caution or warning message.


- Automatic, advisory:
  - The relevant system page automatically appears, when a parameter drifts out of its normal range.
  - The value (shown in green) pulses, as long as it is outside its limits.
  - The advisory mode is inhibited in some flight phases.



**Note:** If an advisory is triggered, when the ECAM is in the single-display configuration, an advisory message appears on the upper part of the E/WD, and the associated key on the ECAM control panel flashes to identify the appropriate system page.



- Automatic, flight phase mode
  - If no other mode is engaged, the SD displays the system page related to the present flight phase, as shown in the following diagram.




- Phase 2 : The F/CTL page replaces the WHEEL page for 20 s when either pilot moves his sidestick (more than 3 ° in pitch or roll) or when the rudder pedal deflection is more than 22 °.
- The APU page appears when the APU MASTER switch is ON. It disappears when APU RPM has been above 95 % for 10 s, or when the APU MASTER switch is switched OFF.
- The ENGINE page appears at the beginning of start sequence or when a pilot selects “CRANK”. It disappears 10 s after the end of the start sequence, when the ENG MODE sel is set to NORM.

For a description of the ENGINE and AIR indications that appear when the SD is displaying the CRUISE page, see the relevant FCOM chapter.

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

INDICATIONS ON SD




**STATUS PAGE**

Ident.: DSC-31-20-00001217.0001001 / 12 APR 16

Applicable to: ALL

**PURPOSE**

The STATUS page provides an operational summary of the state of the aircraft. As illustrated in the following image, this operational summary includes all of the following:



- (1) Limitations (speed, flight level): Blue
- (2) Approach procedures: White (Red) (Amber)
- (3) Procedures (corrections to apply for landing): Blue
- (4) Information: Green
- (5) Cancelled caution: White
- (6) Inoperative system: Amber
- (7) Maintenance status: White
- (8) The arrow appears if the data on the STATUS page overflows the left or right area of the page.

The flight crew can press the CLR pb, in order to scroll the display to view the overflow.

*Note:* The titles of the different parts of the display appear in white and underlined.

### **STATUS PAGE DISPLAY**

The STATUS page appears when the flight crew presses the STS pb on the ECAM Control Panel (ECP).

The STATUS page automatically appears in abnormal operations if one of the following applies:

- The STATUS page is not empty, and the flight crew clears the last alert on the E/WD, or
- The STATUS page is not empty, and the flight crew selects the CONF1 for approach.

**BLANK LINES**

Each block that is described above (limitation block (1), approach procedure block (2), etc.) is separated by a blank line.

Therefore, a condition that is included in a limitation block (1) and the associated action line that is included in the procedure block (3) are separated by a blank line.

Example : Illustration with the ECAM alert **ENG 1(2) SHUTDOWN**.



In this example, the action line “LDG DIST PROC ... APPLY” applies only in the case of severe ice accretion.

**STS REMINDER**

The STS reminder appears on the E/WD if both the following conditions apply:

- The STATUS page is not empty: The STATUS page displays message other than “CANCELLED CAUTION” or MAINTENANCE status.
- There is a MAINTENANCE status at engines shutdown.




The MAINTENANCE status can appear only when the aircraft is on the ground, before engine start or after engine shutdown.

**PERMANENT DATA**

Ident.: DSC-31-20-00017520.0011001 / 25 JUL 16

Applicable to: ALL



(1) Temperature

The screen displays the Total Air Temperature (TAT ) and Static Air Temperature (SAT) in green.

The difference between the SAT and the International Standard Atmosphere temperature (ISA ) temperature (Delta ISA  $\Delta$ ) is displayed in green, in standard altitude mode and when the SAT is valid.

(2) G LOAL - ALT SEL

The screen displays one of the following items:

- Load factor (G LOAD) in amber, when the value is above 1.4 g or below 0.7 g for more than 2 s. The G LOAD amber indication remains displayed 5 s after the excessive load occurrence. The display of the load factor is inhibited during flight phases 1, 2, 3, 9 and 10.
- Altitude in green selected via the Flight Control Unit (FCU), if the flight crew selects metric units, and provided the load factor is not displayed.
- “CHECK CAPT (F/O) PFD”, “CHECK CAPT (F/O) ND” or “CHECK SD” all in amber (*Refer to DSC-31-05-20 Cockpit Arrangement*).

*Note:* The display of the feedback messages takes priority over the load factor indication.

(3) UTC

The screen displays the Universal Time Coordinated (UTC), synchronized with the cockpit clock, in green.

(4) GW

The screen displays the Gross Weight (GW) in green, as soon as the flight crew starts the first engine. The last two digits are dashed, if accuracy is degraded. On ground, blue dashes are displayed instead of the indication, if no computed data is available.

**AMBER CROSSES "XX" ON THE SD**

Ident.: DSC-31-20-00013602.0001001 / 18 MAR 11

Applicable to: **ALL**

If a parameter value on any SD page is not available for display, amber crosses "XX" appear instead of the value.

**AMBER DASHES ON THE SD**

Ident.: DSC-31-20-00015526.0001001 / 01 APR 14

Applicable to: **ALL**

If the accuracy of a parameter value on any SD page is degraded, amber dashes are displayed over the last digits.

**GENERAL**

Ident.: DSC-31-25-10-00001219.0001001 / 22 MAR 16

**Applicable to: ALL**

If ECAM detects a failure :

- The E/WD displays warning or caution messages.
- The master warning or master caution lights light up (except in the case of a level 1 caution).
- The system sounds an aural signal (except in the case of a level 1 caution).
- The system display (SD) shows the system page for the affected system.
- The CLR pushbutton on the ECAM control panel lights up.

In addition, a local warning light controlled directly by the affected system can light up.

After completing remedial procedures, the flight crew must push the CLR pushbutton repeatedly until the displays return to their normal configurations :


- MEMO messages on the E/WD
- The system page related to the present flight phase on the SD.
- The CLR light on the ECAM control panel turned off.

Intentionally left blank

**1 - THE ECAM DETECTS NO FAILURE**

Ident.: DSC-31-25-20-00001220.0004001 / 09 OCT 12

Applicable to: ALL



**2 - THE ECAM DETECTS A FAILURE**


Ident.: DSC-31-25-20-00001221.0004001 / 09 OCT 12

Applicable to: ALL

For example, a hydraulic reservoir is overheat.

**COCKPIT INDICATIONS**

- A single chime sounds
- Both MASTER CAUTION lights come on, and stay on
- A FAULT light, on the overhead HYD panel, comes on
- The memo space on the E/WD displays the "HYD B RSVR OVHT" message, and the "BLUE ELEC PUMP . . . . OFF" instruction
- The lower ECAM display (SD ) automatically calls up the hydraulic system's diagram, and displays "OVHT" in amber next to the blue system
- The ECAM 's CLR pushbutton lights up.



ECAM UPPER DISPLAY (E/W/D)

- BOTTOM LEFT
  - INDEPENDENT FAILURE
  - TITLE OF THE FAILURE
  - ACTIONS TO BE PERFORMED
- BOTTOM RIGHT
  - MEMO INFORMATION

ECAM LOWER DISPLAY (SD)

- SUMMARY OF THE AFFECTED SYSTEM AUTOMATICALLY DISPLAYED. OVHT IS DISPLAYED IN AMBER

**3 - THE FLIGHT CREW FOLLOWS THE INSTRUCTION DISPLAYED ON THE EWD**

Ident.: DSC-31-25-20-00001222.0002001 / 09 OCT 12

Applicable to: ALL

The flight crew switches off the BLUE ELEC PUMP pushbutton, depressurizing the blue hydraulic circuit.


**COCKPIT INDICATIONS**

- A single chime sounds.
- Both MASTER CAUTION lights stay on.
- A FAULT/OFF light, on the overhead panel, comes on.
- The second part of the message on the E/WD changes to “B SYS LO PR”.
- The SD 's system diagram shows an amber zero for the pressure in the blue system, along with the amber “OVHT”.
- The right side of the memo area indicates a secondary failure in the flight control system.
- The ECAM control panel's CLR pushbutton remains on.




**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

ECAM SEQUENCE - EXAMPLE



ECAM UPPER DISPLAY (E/W)

- BOTTOM LEFT  
 - INDEPENDENT FAILURE AND PRIMARY FAILURE
- BOTTOM RIGHT  
 - SECONDARY FAILURE



ECAM LOWER DISPLAY (SD)

- THE SYNOPTIC OF THE SYSTEM PAGE IS CHANGED ACCORDING TO THE NEW SYSTEM CONFIGURATION OVHT AND THE PRESSURE ARE DISPLAYED IN AMBER

**4 - ONE OF THE PILOTS PUSHES THE CLR PUSHBUTTON ON THE ECP**

Ident.: DSC-31-25-20-00001223.0003001 / 09 OCT 12


Applicable to: ALL

**COCKPIT INDICATIONS**

- The CLR pushbutton stays on.
- The FAULT/OFF light stays on.
- Hydraulic system messages disappear from the E/WD, and the right side of the memo area indicates a secondary failure in the flight control system.
- The SD automatically calls up the flight control system page, with surface actuator indications (associated with the blue hydraulic system) shown in amber.


**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

ECAM SEQUENCE - EXAMPLE



ECAM UPPER DISPLAY (E/WD)

- BOTTOM LEFT  
 • MEMO INFORMATION
- BOTTOM RIGHT  
 • SECONDARY FAILURE



ECAM LOWER DISPLAY (SD)

- F/CTL SYSTEM PAGE  
 AUTOMATICALLY DISPLAYS FAULTY SPOILERS (n°3) AND SURFACE ACTUATOR B PRESSURE INDICATIONS IN AMBER

**5 - ONE OF THE PILOTS PUSHES THE CLR PUSHBUTTON A SECOND TIME**

Ident.: DSC-31-25-20-00001224.0003001 / 09 OCT 12

Applicable to: ALL

**COCKPIT INDICATIONS**

- The ECP 's CLR and STS pushbuttons light up.
- The FAULT/OFF lights stay on.
- The E/WD's memo area returns to normal.
- The STATUS page automatically appears on the SD, displaying the procedures for completing the flight with a faulty blue system.

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

ECAM SEQUENCE - EXAMPLE

The upper display shows engine parameters: N1 at 19.8%, EGT at 375°C, N2 at 62.8%, and Fuel Flow (F.F) at 290 KG/H. It also displays fuel flow (FLX) at 88.2% and temperature at 35°C. Cabin status includes 'SEAT BELTS' and 'CTR TK FEEDG WING A.ICE'. Weight information shows 'FOB: 12650 KG'.

ECAM UPPER DISPLAY (E/WD)

- FULL MEMO DISPLAYED

**STATUS**

<p><u>APPR PROC HYD LO PR</u>                      .IF BLUE OVHT OUT:                      -BLUE ELEC PUMP..AUTO</p> <p>LDG DIST.....x 1.1</p> <p>SLATS SLOW                      CAT 3 SINGLE ONLY</p>	<p><u>INOP SYS</u>                      CAT 3 DUAL                      BLUE HYD                      SPLR 3                      B ELEC PUMP</p>
---	---

TAT - 5°C	23H56	G.W 60300 KG
SAT - 30°C		

ECAM LOWER DISPLAY (SD)

- THE STATUS PAGE IS AUTOMATICALLY DISPLAYED TO:

- PROVIDE THE PROCEDURE TO BE APPLIED FOR APPROACH.
- PROVIDE LANDING DISTANCE FACTORS AND INFORMATION.
- LIST THE INOPERATIVE SYSTEMS.

**6 - ONE OF THE PILOTS PUSHES THE CLR PUSHBUTTON A THIRD TIME**

Ident.: DSC-31-25-20-00001225.0003001 / 09 OCT 12

Applicable to: ALL

**COCKPIT INDICATIONS**

- The CLR pushbutton light goes off.
- The FAULT/OFF lights stay on.
- A status reminder appears at the bottom of the E/WD.
- The SD automatically displays the system page corresponding to the flight phase.

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

ECAM SEQUENCE - EXAMPLE

The upper display shows engine parameters: N1 at 19.8%, EGT at 375°C, N2 at 62.8%, and Fuel Flow (F.F) at 290 KG/H. Fuel gauges (FLX) show 88.2% and 35°C. Cabin status indicators include SEAT BELTS, CTR TK FEEDG WING A.ICE, and STS (Status Reminder).

ECAM UPPER DISPLAY (E/WD)

- FULL MEMO DISPLAYED

STATUS REMINDER


The lower display shows CRUISE data: F. USED 820 KG, OIL Q1 VIB 11.5, N1 0.9, N2 1.2. AIR data includes ΔP 1.2 PSI, CAB V/S 1150 FT/MN, CAB ALT 1150 FT, TAT +13°C, SAT +9°C, 23H56, and G.W 60300 KG.

ECAM LOWER DISPLAY (SD)

- RETURN TO THE FLIGHT PHASE RELATED SYSTEM PAGE : CRUISE PAGE

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>INDICATING/RECORDING SYSTEMS</b></p> <p style="text-align: center;">OEB REMINDER</p>
---	--

**GENERAL**

Ident.: DSC-31-27-00001226.0001001 / 21 MAR 16  
**Applicable to: ALL**

The OEB reminder function provides operational help to the crew by enabling them to clearly identify (on the ECAM) all procedures and status messages affected by an OEB. When a situation leading to a warning/caution occurs, a message informs the crew in real time that an OEB exists for the displayed warning and/or status and, consequently, that the procedure and/or status presented on the ECAM is not applicable. Then the crew must refer to the QRH where the correct information is provided.

**DESCRIPTION**

Ident.: DSC-31-27-00001227.0003001 / 22 MAY 12  
**Applicable to: ALL**


The OEB reminder flag may apply to the:

- ECAM procedure only,
- ECAM procedure and corresponding status messages,
- Status message only.

**PROCEDURE ONLY AFFECTED**

- The ECAM warning title remains unaltered,
- All corresponding actions are suppressed and replaced by the “REFER TO QRH /OEB PROC” message,
- The related status messages on the ECAM system display remains unaltered.


**COCKPIT INDICATION**



**PROCEDURE AND STATUS AFFECTED**

- The ECAM warning title remains unaltered,
- All corresponding actions are suppressed and replaced by the “REFER TO QRH /OEB PROC” message,
- The related status messages on the ECAM system display remains unchanged, except for the additional “REFER TO QRH /OEB PROC” title.


**COCKPIT INDICATION**



**STATUS MESSAGE ONLY AFFECTED**

- The ECAM warning title remains unaltered,
- The corresponding procedure remains unchanged, except for the additional "FOR STS REFER TO OEB" line.
- The related status messages on the ECAM system display remains unchanged, except for the additional "REFER TO QRH /OEB PROC" title.

**COCKPIT INDICATION**



**OEB DATABASE**

Ident.: DSC-31-27-00001228.0001001 / 21 MAR 16

**Applicable to: ALL**

The OEB database lists the warnings and cautions affected by an OEB.

The OEB database can be :


- Loaded manually on the aircraft via the MCDU , and stored in both FWCs.
- Crossloaded from one FWC to the other FWC.
- Updated by entering a code via the MCDU.
- Checked via the MCDU.

*Note: The code provided on the OEB is designed to ensure that the OEB database is not updated before the OEB is available.*

**ECAM CONTROL PANEL**

Ident.: DSC-31-30-00001229.0002001 / 26 JUL 17

Applicable to: ALL



(1) OFF / BRT knobs

Used to turn the ECAM DUs on and off, and to control their brightness (automatic adjustment of brightness for ambient light conditions is superimposed on this manual control).

*Note:* When the pilot turns the UPPER DISPLAY knob to OFF, the engine/warning (E/W) display appears on the lower display unit (automatic transfer).

(2) System page pushbuttons

- Call up the corresponding system pages on the SD
- Light up, when pushed for manual selection, or when an advisory is detected
- Call up the aircraft system page corresponding to the present flight phase or the current warning when pushed a second time.

When only one ECAM display is on, the pilot can display a system page for up to 3 min by pushing and holding the system page pushbutton.

- If an advisory condition arises, the relevant system page is not automatically displayed, but the pushbutton light pulses
- If an ECAM warning is triggered, the relevant system page is not automatically displayed, and the system page pushbutton does not light up.

(3) RCL pb

- When pressed, the E/WD displays all alerts previously cleared via the CLR pb that are still active.
- When pressed for more than 3 s, the E/WD displays:
  - All alerts previously cleared via the CLR pb that are still active
  - All alerts previously cancelled via the EMER CANC pb.

Note: 1. If there is no alert to recall, the “NORMAL” message appears for 3 s on the E/WD.  
2. This action on the RCL pb also suppresses the flight phase inhibition function until the next flight phase. As a consequence, all new alerts that should normally be inhibited will be displayed.

(4) STS pb

The pilot pushes this pushbutton to display the STATUS page on the lower SD . The pushbutton remains lit, as long as the SD displays the STS page. If the system has no status messages, the status page displays “NORMAL” for 3 s.

The pilot can clear the STATUS page by pushing the CLR pb, or by pushing the STS pb a second time.

When only one ECAM display is on :

- It displays the STATUS page only when the pilot pushes the STATUS pushbutton and holds it. He can display the next STATUS page, if any, by releasing the pushbutton and pushing it again (before 2 s have elapsed). The new page then appears after a short delay.
- The pilot can keep the STS pb pressed to display the STATUS page for a maximum of 3 min, after which the ECAM automatically displays the engine/warning page.

(5) CLR pb


This pushbutton remains lit as long as the E/WD is displaying a warning or caution message, or a status message on the SD.

If it is lit, pressing it changes the ECAM display.

(6) ALL pb

When this pushbutton is pressed and held down, the SD successively displays all the system pages at 3 s intervals.

If the ECAM control panel fails, the pilot can use this pushbutton to page through the system pages until he comes to the one he wants to look at. He then releases the pushbutton to select that page.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>INDICATING/RECORDING SYSTEMS</b></p> <p style="text-align: center;">ECAM CONTROLS</p>
---	---

(7) EMER CANC pb

This pushbutton affects the following :

- Warnings :

- Cancels (stops) an aural warning for as long as the failure condition continues
- Extinguishes the MASTER WARNINGS lights
- Does not affect the ECAM message display.

- Cautions :

- Cancels any present caution (single chime, MASTER CAUTION lights, ECAM message) for the rest of the flight.

The flight crew can press the RCL pb for more than 3 s in order to restore all the alerts previously canceled via the EMER CANC pb.

All the alerts previously canceled via the EMER CANC pb automatically reappear on the E/WD in flight phase 1 or 2, immediately after the alignment of IRs 1 and 2.

*Note:* This pushbutton should only be used to suppress spurious MASTER CAUTIONS.

(8) T.O CONFIG pb

This pushbutton simulates the application of takeoff power. This is a test that triggers a warning, if the aircraft is not in takeoff configuration. (*Refer to DSC-31-15 Configuration Warnings*).

If the configuration is correct, the E/WD displays the "TO CONFIG NORMAL" message in the TO MEMO section.


*Note:* If the ECAM control panel fails, the CLR, RCL, STS, EMER CANC, and ALL pushbuttons remain operative, because their contacts are directly wired to the flight warning and display management computers.

**SWITCHING PANEL**

Ident.: DSC-31-30-00001230.0002001 / 17 MAR 11

Applicable to: ALL

**ON PEDESTAL**



(1) EIS DMC rotary selector

**NORM** : DMC 1 supplies the CAPT's PFD, the CAPT's ND, and the ECAM's DUs.  
 DMC 2 supplies the F/O's PFD and the F/O's ND.

**CAPT 3** : DMC 3 replaces DMC 1.

**F/O 3** : DMC 3 replaces DMC 2.

*Note:* If a DMC fails, each of its associated DUs displays an "INVALID DATA" message.

(2) ECAM/ND XFR rotary selector

Transfers the system/status display to either the Captain's or the First Officer's ND.  
 The "ECAM ON ND" message is displayed on the lower ECAM display.


*Note:* If both ECAM DU s (E/WD and SD ) fail, the flight crew may use this switch to transfer the E/WD display to either navigation display. In this case, the "ECAM ON ND" message is not displayed.



**ATTENTION GETTERS**

Ident.: DSC-31-30-00001231.0001001 / 09 OCT 12

Applicable to: ALL



(1) MASTER WARN lights

- Flash red for level 3 warning
- Accompanied by an aural warning (continuous repetitive chime, specific sounds or synthetic voice).

(2) MASTER CAUT lights

- Light up steady amber for a level 2 caution
- Accompanied by a single chime.

These lights go out when :

- One pilot presses the light (except for some red warnings, such as the overspeed and stall warnings)
- The warning/caution situation is over
- The pilot presses the CLR pb on the ECAM control panel (except for some red warnings, such as the overspeed and stall warnings).
- The pilot presses the EMER CANC pb on the ECAM control panel.

The aural warnings cease when :

- One pilot presses the MASTER WARN light (except for some red warnings, such as the overspeed and stall warnings)
- The warning situation is over
- The pilot presses the EMER CANC pb on the ECAM control panel.

**MEMO DISPLAY**

Ident.: DSC-31-30-00018053.0001001 / 21 MAR 16

Applicable to: ALL

**SWITCHING** : This memo appears in green, when:

**PNL**




1. PFD/ND XFR pb is pressed and ECAM/ND XFR rotary selector is selected at CAPT or F/O side simultaneously, or
2. ATT HDG rotary selector is selected at CAPT or F/O side, or
3. AIR DATA rotary selector is selected at CAPT or F/O side, or
4. EIS DMC rotary selector is selected at CAPT or F/O side.


**GENERAL**

Ident.: DSC-31-40-00017531.0003001 / 21 MAR 16

**Applicable to: ALL**

The Primary Flight Display (PFD) provides the following information to the flight crew:

- Attitude and guidance
- Airspeed
- Altitude (BARO and radio) and vertical speed
- Heading and track
- FMGS modes (Flight Mode Annunciator)
- Vertical and lateral deviations
- Radio navigation information (ILS , MLS  , FLS  , GLS  , DME).




The FWC monitors main parameters such as attitude, heading, and altitude. For more information, Refer to DSC-31-40 Flags and Messages Displayed on PFD.

**SPECIFIC GROUND INDICATIONS**

Ident.: DSC-31-40-00001233.0001001 / 13 JAN 14

Applicable to: **ALL**



(1) Sidestick order indication

This symbol is in white, and appears as soon as one engine is started.

It indicates the total of the Captain's and First Officer's sidestick orders (shown here as left wing down, pitch up).

(2) Max Sidestick Deflection

This symbol is in white, and appears as soon as one engine is started.


(3) Ground Roll Guidance Command Bar

This symbol is in green, and appears when the aircraft is on ground, or below 30 ft radio height, provided that a localizer signal is available. It indicates the Flight Director yaw orders, to maintain the aircraft on the runway centerline.

**ATTITUDE DATA**

Ident.: DSC-31-40-00001234.0003001 / 09 OCT 12

Applicable to: ALL



- (1) Fixed Aircraft Symbol  
This symbol is in black, and outlined in yellow. The yellow outline is dimmed if the crew selects TRK -FPA , unless the FMA is in the TOGA or FLX mode.
- (2) Roll Scale  
This scale is in white, and has markers at 0, 10, 20, 30, and 45 ° of bank.
- (3) Roll Index (yellow)  
This pointer indicates the bank angle. When the bank angle exceeds 45 °, all the PFD symbols, except those for attitude, speed, heading, altitude, and vertical speed, disappear. The display returns to normal when the bank angle decreases below 40 ° .
- (4) Pitch Scale (white)  
This scale has markers every 10 ° between 80 ° nose up and 80 ° nose down (every 2.5 ° between 10 ° nose down and 30 ° nose up). When pitch angle exceeds 25 ° nose up or 13 ° nose down, all the PFD displays except attitude, speed, speed trend, heading, altitude, and vertical speed disappear. Beyond 30 ° , large red arrowheads indicate that the attitude has

become excessive and show the direction to move the nose in order to reduce it. The display returns to normal when pitch angle becomes less than 22 ° nose up or 10 ° nose down.

(5) Flight Control Protection Symbols

The display shows these symbols (=) in green:

- On the roll scale to mark the bank angle protection availability.
- On the pitch scale at 15 ° nose down or 30 ° nose up to mark the pitch limits.

An amber x replaces these symbols if the corresponding protection is lost.

*(Refer to DSC-27-20-10-20 Protections - General)*

(6) Sideslip Index (yellow)

This trapezoidal index moves beneath the roll index. On ground, it represents the lateral acceleration of the aircraft. In flight, it shows sideslip (as computed by the FAC). One centimeter of displacement indicates 0.2 g. The sideslip index is against its stop at 0.3 g.



In case of engine failure at takeoff or go around, the sideslip index changes from yellow to blue.

Note: The sideslip target is blue, if:

- CONF 1, 2, or 3 is selected, and
- Any ENG N1 > 80 % or one Thrust Lever > MCT ( $\geq$  FLX if FLX or DERATED TO), and
- The difference between the ENG N1's exceeds 35 %.


*In this case, the sideslip index is called  $\beta$  target.*

When this index is centered with the roll index, the sideslip equals the sideslip target for optimum aircraft performance.

**AIRSPED**

Ident.: DSC-31-40-00001235.0004001 / 21 MAR 17

Applicable to: ALL



- (1) Actual Airspeed Reference Line and Scale  
 A white scale, on a grey background, moves in front of a fixed yellow reference line (next to a yellow triangle) to indicate airspeed. The minimum airspeed indication is 30 kt.
- (2) Speed Trend (yellow)  
 This pointer starts at the speed symbol. The tip indicates the speed the aircraft will reach in 10 s, if its acceleration remains constant. The pointer only appears, when it is greater than 2 kt, and disappears when it is less than 1 kt.  
 It also disappears, if the FACs fail.
- (3) Target Airspeed (magenta or blue)  
 This symbol gives the target airspeed, or the airspeed corresponding to the target Mach number.  
 The target airspeed is the airspeed computed by FMGC in managed speed mode (magenta), or the airspeed manually entered on the FCU in selected speed mode (blue). The target speed is indicated by a magenta or blue triangle.  
 When the target speed is off the speed scale, its value is displayed as numbers, either above or below the speed scale.

(4) Mach Number (green)

It is displayed, when it is greater than 0.5.

(5) Speed Protection (green)

This symbol indicates the speed ( $V_{MO} +6$  kt or  $MMO +0.01$ ) at which overspeed protection becomes active (*Refer to DSC-27-20-10-20 Protections - General*).


(6) ECON Speed Range (magenta)

In descent mode with the ECON /AUTO SPD mode active, these two thick lines replace the selected speed symbol. It shows the upper and lower limits, calculated by the FMGC.

- The upper speed is target speed +20 kt, limited to  $V_{MAX}$  or  $V_{MO} -3$  kt or  $MMO -0.006$ , whichever is lowest.

If a speed limit or a speed constraint applies, the upper margin is limited to ECON SPD +5 kt.

- The lower speed margin is the target speed -20 kt, limited to green dot, F, S, or VLS, whichever is higher.



(1) Minimum Selectable Speed (VLS)

The top of the amber strip along the speed scale indicates this speed. It represents the lowest selectable speed providing an appropriate margin to the stall speed. (*Refer to DSC-27-20-10-20 Protections - High Speed Protection*)

VLS information is inhibited from touchdown until 10 s after liftoff.



(2) Alpha Protection Speed

The top of a black and amber strip along the speed scale indicates this speed. It represents the speed corresponding to the angle of attack at which alpha protection becomes active (*Refer to DSC-27-20-10-20 Protections - General*). It is displayed when in pitch normal law.

(3) Alpha MAX Speed

The top of a red strip along the speed scale indicates this speed. It represents the speed corresponding to the maximum angle of attack that the aircraft can attain in pitch normal law (*Refer to DSC-27-20-10-20 Protections - General*). It is displayed when in pitch normal law.

(4) VMAX

The lower end of a red and black strip along the speed scale defines this speed.

It is the lowest of the following:

- VMO or the speed corresponding to MMO
- VLE
- VFE


(*Refer to DSC-27-20-10-20 Protections - High Speed Protection*)

(5) Stall Warning Speed (VSW)

The top of a red and black strip along the speed scale defines this speed. It is the speed corresponding to the stall warning. (*Refer to DSC-27-20-10-20 Protections - General*).

VSW information is inhibited from touchdown until 5 s after liftoff.

It is displayed when operating in pitch alternate or pitch direct law.



(1) Decision Speed ( $V_1$ )

This is a blue symbol (numeral one) that the crew manually inserts via the MCDU. When it is off the scale, the upper part of the scale shows it in numbers.

It disappears after liftoff (*Refer to DSC-22\_10-50-50 Other Speeds*).

(2) Minimum Flap Retraction Speed

This is a green symbol (letter F).

It appears when the flap selector is in position 3 or 2. (*Refer to DSC-27-20-10-20 Protections - High Speed Protection*).

(3) Minimum Slat Retraction Speed

This is a green symbol (letter S).

It appears when the flap selector is in position 1. (*Refer to DSC-27-20-10-20 Protections - High Speed Protection*).

(4) VFE NEXT

The VFE next symbol is an amber equal sign showing the VFE corresponding to the next flap lever position.

It appears when the aircraft altitude is below 15 000 ft or 20 000 ft, depending upon the FAC standard (*Refer to DSC-22\_10-50-30 Limit Speeds*).

(5) Green Dot (Engine-out operating speed in clean configuration)

This green dot appears, when the aircraft is flying in the clean configuration.

It shows the speed corresponding to the best lift-to-drag ratio.

(6) Rotation speed: (VR)


VR is entered on the PERF takeoff page of the MCDU, and is indicated by a cyan circle. This cyan circle is visible during takeoff.

*Note:* V2 is represented by the target speed index during takeoff.  
V2 is manually inserted by the crew via the MCDU.

**ALTITUDE**

Ident.: DSC-31-40-00001237.0049001 / 29 OCT 13

Applicable to: ALL



(1) Altitude Indication

This appears both as a white moving scale, and as a green digital readout on a grey background. Small white marks are positioned on the scale against the round values (e.g. 280, 290...). "NEG" appears in the window in white for negative values. The altitude window changes from yellow to amber, if the aircraft deviates from the FCU-selected altitude or flight level.

On any approach for which an minimum is entered in the FMGC, the altitude numbers change from green to amber, when the aircraft goes below the minimum.

(2) Linear Deviation (green filled circle)

This symbol appears next to the altitude corresponding to the theoretical vertical profile computed by the FMGC . It is displayed from the top of descent down to the MAP altitude. The flight crew can read the linear deviation directly from the altitude scale. The range is  $\pm 500$  ft. When the linear deviation value exceeds  $\pm 500$  ft, the symbol stays at the range limit but changes to a half filled circle and the PROG page displays the exact value.

(3) Target Altitude or Selected Flight Level Symbol (blue)

This symbol shows the FCU selected altitude (if QNH BARO reference is selected) or the selected flight level (if STD BARO reference is selected.)

When the FMGC operates in the vertical managed mode, this symbol is magenta if it represents a flight plan altitude constraint that the FMGC will follow. If the target altitude or flight level is on the scale, the symbol is displayed and the numerical value appears inside the symbol.

If it is off the scale, the symbol is not displayed, and the numerical value appears above or underneath the scale.

(4) Barometric Reference

The display shows “STD” or it shows “QNH” and the numerical setting in hectoPascals or inches of mercury.

It pulses when the selection made by the flight crew is not correct (STD not selected above transition altitude in climb or STD still selected in approach below transition level).


**APPROACH MINIMUM INDICATION**

Approach minimum is displayed on the altitude scale by an amber indication.

**ALTITUDE (CONT'D)**

Ident.: DSC-31-40-00006121.0002001 / 13 JAN 14

Applicable to: ALL



(1) Radio Height

A value appears, when the aircraft is lower than 2 500 ft.

- If a DH has been entered, the radio height appears:

- In green, when  $DH + 100 \text{ ft} < RA < 2\,500 \text{ ft}$
- In amber, when  $RA < DH + 100 \text{ ft}$

If "NO" is entered as the DH on the MCDU APPROACH page, 0 ft becomes a default value.

When the aircraft reaches the decision height selected on the MCDU, DH letters flash amber for 9 s, then remain amber above the radio height indication.

- If no DH has been entered, or if both FMGCs fail, the radio height appears:

- In green, when  $400 \text{ ft} < RA < 2\,500 \text{ ft}$
- In amber, when  $RA \leq 400 \text{ ft}$

The radio height indication changes every 10 ft down to 50 ft, then every 5 ft down to 10 ft, then every foot.

(2) Landing Elevation (brown)

The top of the brown surface on the altitude scale represents the landing elevation at the flight-planned destination.

It is displayed:

- during flight phases 7 and 8 and
- if the STD reference mode is not selected.

(3) Ground reference

A red ribbon on the right of the altitude scale represents the field elevation. This ribbon, which is driven by the radio altimeter signal, is displayed below 570 ft.

It moves up, as does the lower line of the attitude sphere, with the altitude scale as the aircraft descends. When the aircraft has touched down, the top of this ribbon is at the middle of the attitude window.


**VERTICAL SPEED**

Ident.: DSC-31-40-00001239.0002001 / 21 MAR 17

Applicable to: ALL

The displayed vertical speed information is normally based on both inertial and barometric data. If inertial data is not available, it is automatically replaced by barometric information.

In this case, the window around the numerical value becomes amber.



- (1) Analog pointer  
This pointer, which is normally in green, points to a white vertical speed scale, displayed on a grey background and graduated at intervals of 500 ft/min.  
If the V/S is greater than 6 000 ft/min, the pointer stays at the end of the scale.

- (2) Digital indication  
This number, normally in green, is the vertical speed in hundreds of feet per minute.  
It disappears, if the vertical speed is less than 200 ft/min.

The analog pointer and the digital indication become amber, if:


- V/S is greater than 6 000 ft/min, (climb or descent)
- V/S is greater than 2 000 ft/min, during descent when 1 000 ft < RA < 2 500 ft, or
- V/S is greater than 1 200 ft/min, during descent and RA < 1 000 ft.

*Note:* For TCAS, Refer to DSC-34-SURV-60-20 TCAS Messages.

## HEADING

Ident.: DSC-31-40-00001240.0002001 / 07 MAY 13

Applicable to: ALL



- (1) Heading Reference Line and Scale  
A white scale on a grey background moves in front of a fixed yellow reference line to indicate the actual magnetic heading.  
"TRUE" appears, when the display indicates the true heading, rather than the magnetic heading (latitude above 73 ° North or below 60 ° South).

(2) Selected Heading or Track Index (blue)

This pointer is in blue, and indicates the heading or track displayed on the FCU HDG-TRK window.

The index is replaced by digits on the right or left side of the scale, when the selected value is off the scale.

If the FD pushbutton is OFF, a second heading/track symbol appears on the horizon line, and markers are displayed every 10 °.

(3) Actual Track Symbol

This symbol is a small green diamond.

**FLIGHT PATH VECTOR**

Ident.: DSC-31-40-00001241.0001001 / 17 MAR 17

Applicable to: ALL

The Flight Path Vector (FPV ) is the flight reference with the TRK and FPA as basic guidance parameters. When the TRK /FPA is selected on the FCU , the FPV appears on the PFD.

**INFORMATION PRESENTATION**


The FPV appears on the PFD as a symbol, known as the "bird". The bird indicates the track and flight patch angle in relation to the ground.

The track is indicated on the PFD by a green diamond on the compass, in addition to the lateral movement of the bird in relation to the fixed aircraft symbol. On the ND, the track is indicated by a green diamond on the compass scale. The difference in angle between track and heading indicates the drift.

The flight path angle is indicated on the PFD by the vertical movement of the bird in relation to the pitch scale.

With the flight directors (FD ) ON, the Flight Path Director (FPD ) replaces the HDG -VS Flight Director (FD ). With both FD pb set to OFF, the blue track index appears on the PFD horizon.





(1) Flight Path Vector (FPV)


This symbol appears, when the pilot selects TRK /FPA on the FCU.

The flight path vector represents the lateral and vertical trajectory of the aircraft with respect to the ground.

- On the lateral scale, it indicates the aircraft's track.
- On the vertical scale, it indicates the aircraft's flight path angle.

Example : The aircraft flies a track of 009 ° (heading 360 °, wind from west) and descends with a flight path angle of minus 7.5 °.

**USE OF FPV**

The bird is the flying reference that should be used when flying a stabilized segment of trajectory, e.g.: non-precision approach when the FLS function  is not used or visual circuit.

In dynamic manoeuvres, the bird is directly affected by the aircraft inertia and has a delayed reaction. As a result, the bird should not be used as a flight reference in dynamic manoeuvres. Refer to *FCTM/AS-BIRD Introduction* for more information.

## GUIDANCE

Ident.: DSC-31-40-00001242.0001001 / 13 JAN 14

Applicable to: **ALL**

Two completely different flight director modes are available, each with its own characteristic symbols. The symbol displayed corresponds to the basic operating reference the pilot has selected – either HDG V/S or TRK FPA.

In normal operation, PFD 1 displays FD1 orders.

If FD 1 fails, PFD 1 automatically displays FD 2 orders on PFD 1, the FD 2 indication in the right column of the FMA flashes for a few seconds.

This is also applicable to FD 2 orders, that are displayed on PFD2.

### **IF THE CREW HAS SELECTED HDG V/S TO BE THE BASIC REFERENCE:**


The PFD displays FD bars in green. They automatically move out of view at touchdown in ROLL OUT mode.

They flash for 10 s, and then remain steady, if the following occur:

- A reversion to the HDG V/S basic mode (manual or automatic), or
- The selected flight level is changed, when ALT CAPTURE mode is engaged, or
- The loss of LOC or G/S in LAND mode or loss of LAND mode, or
- At the first AP or FD engagement.

The PFD displays a yaw bar in green below 30 ft radio height, if a localizer signal is available:

- During takeoff (in RWY mode)
- Upon landing (in FLARE and ROLL OUT mode).




- (1) FD Crossed Bars (green)
- (2) Yaw Bar (green)

**THE CREW HAS SELECTED TRK FPA AS THE BASIC REFERENCE:**

An inertial flight path vector defines the aircraft's horizontal and vertical track, taking wind effect into account.

An associated flight path director symbol guides the flight crew onto the vertical and horizontal flight path targets.




- (1) Flight Path Vector (green)
- (2) Flight Path Director (green)

**TRAJECTORY DEVIATION**

Applicable to: ALL



Ident.: DSC-31-40-A-00017532.0001001 / 21 MAR 16

**ILS/GLS**  **/MLS**  **APPROACH**



(1) Localizer Deviation Scale and Index

(2) Glide slope Deviation Scale and Index

Deviation scales appear as soon as the flight crew presses an LS/ILS pb on the EFIS control panel. Deviation indexes appear when the glide slope and localizer signals of the ILS/GLS  (or the elevation and azimuth signals of the MLS  ) are valid, if deviation scales are displayed.

When a deviation index is out of the displayed range, only half a symbol appears at the end of the scale.


The LOC scale flashes and continues to flash if the deviation exceeds 1/4 dot for two seconds while the aircraft is between 15 ft and 1 000 ft, and CAT 2 or CAT 3 capability displayed on the FMA , and either LOC , LAND, or FLARE is engaged. The glideslope scale flashes and continues to flash if the deviation exceeds one dot for two seconds (above 100 ft RA).

“LOC” and the glideslope scale half index symbols flash, and continue to flash, when the deviation exceeds two dots for two seconds.

One dot represents a deviation of  $\pm 0.8^\circ$  on the localizer scale, and  $\pm 0.4^\circ$  on the glideslope scale.

Ident.: DSC-31-40-A-00017533.0004001 / 21 MAR 16

**ILS/GLS  /MLS  APPROACH (CONT'D)**



(1) ILS/GLS  /MLS  information (magenta)

The following information appears on the PFD , when the crew has selected an ILS frequency/GLS channel/MLS channel and course, and pressed the LS pb:


- ILS /GLS /MLS identification, as decoded by the ILS /GLS /MLS receiver;
- ILS frequency/GLS channel/MLS channel;
- For ILS /MLS : DME distance, if the ILS /MLS has a DME . For GLS : distance to runway threshold computed by the MMR.

(2) ILS/GLS  /MLS  course Pointer (magenta)

This pointer appears on the PFD , when the crew has selected an ILS frequency/GLS channel/MLS channel and course, and pressed the LS pb.


It is a dagger-shaped symbol on the heading scale.

The ILS /GLS /MLS course pointer is replaced by digits on the right or left hand of the heading scale (in a white box) when the ILS /GLS /MLS course value is outside the displayed portion of the heading scale.

- (3) Marker Indications  
 OM appears in blue, when the aircraft flies over the outer marker.  
 MM appears in amber, when it flies over the middle marker.  
 IM appears in white, when it flies over an airways marker beacon or the ILS/GLS  inner marker.
- (4) LS Message  
 This flashes amber, when the APPR mode is armed, but the LS pb has not been selected.
- (5) Selected approach  
 The ILS /GLS /MLS indication is displayed in magenta according to the approach selected by the crew.

Ident.: DSC-31-40-A-00001245.0022001 / 09 OCT 12

**NON PRECISION APPROACH**




- (1) Vertical Deviation Scale and Index  
 These symbols appear when in the approach phase and, when either FINAL is armed/engaged or a non-LS approach has been entered. They are displayed in the approach or go-around phase, until the MDA has been reached, or the MAP or the runway has been sequenced. They give the vertical deviation from the trajectory defined by the FMGC. Each index scale graduation represents 100 ft. The range is  $\pm 200$  ft.

*Note: If the LS pb is pressed, glide deviation has priority over vertical deviation information. As long as VDEV display conditions are met, and the LS pb is selected, an amber VDEV message flashes above the glide scale.*

**FLIGHT MODE ANNUNCIATOR**

Ident.: DSC-31-40-00001246.0002001 / 09 OCT 12

Applicable to: **ALL**




For a detailed discussion of legends and messages that may appear during FMGS operations, see FLIGHT GUIDANCE chapter (Refer to DSC-22\_30-100 Flight Mode Annunciator (FMA) - General).



**TAILSTRIKE PITCH LIMIT INDICATOR** 

Ident.: DSC-31-40-00017534.0003001 / 21 MAR 16

Applicable to: ALL



(1) Tailstrike Pitch Limit

The pitch limit indicates the maximum pitch attitude to avoid the tailstrike risk at landing. The indication is a fixed value corresponding to the main landing gear compressed. The indication appears at 400 ft radio height. The indication disappears, when there is no longer a risk of tailstrike.


**ALTITUDE ALERT**

Ident.: DSC-31-40-00001247.0002001 / 22 MAY 12

Applicable to: ALL

The FWC generates an altitude warning (C chord sound and PFD's altitude window pulses in yellow or flashes in amber), when the aircraft approaches a preselected altitude or flight level, or when it deviates from its selected altitude or flight level.

This warning results from a comparison between the altitude (ADIRS ) and the preselected altitude displayed on FCU.




- Selecting a new altitude, or pushing the ECAM's EMER CANC pushbutton, or pressing either MASTER WARN pushbutton, cancels the continuous C chord.
- Selecting a new altitude stops the flashing of the altitude window.
- The altitude alert is inhibited:
  - When the slats are out, with the landing gear is selected down, or
  - In approach after the aircraft captures the glideslope, or
  - When the landing gear is locked down.

**FLAGS AND MESSAGES DISPLAYED ON PFD**

Ident.: DSC-31-40-00001248.0012001 / 21 MAR 17

Applicable to: ALL



- (1) ATT flag (red)  
If the PFD loses all attitude data, its entire sphere is cleared to display the ATT flag.
- (2) CHECK ATT , CHECK CAPT (F/O ) PFD , CHECK EWD , DU NOT MONITORED (amber)  
For CHECK ATT, Refer to DSC-31-05-60 Side1/Side2 Discrepancy Messages  
For more information, Refer to DSC-31-05-10 Introduction
- (3) SI flag (red)  
If the sideslip information is lost or any reverse is deployed in flight, the index disappears and a red SI flag appears.

- (4) FPV flag (red)  
In the TRK FPA mode, when the drift angle or flight path angle is not valid, an FPV flag appears.
- (5) FD flag (red)  
If both FMGC s fail, or if both FD s are disengaged and the FD pushbutton is on and the attitude is valid, a red FD flag appears.
- (6) SPD flag (red)  
If the speed information fails, a SPD flag replaces the speed scale.
- (7) SPD SEL flag (red)  
If the selected speed information fails, a SPD SEL flag appears.
- (8) SPD LIM flag (red)  
This flag appears when both FAC s are inoperative, or in case of SFCC dual flap/slat channel failure.  
In this case, the following PFD information is lost : VLS , S, F, Green Dot, Vtrend, Vmax, VFE next, VSW.
- (9) V1 INOP flag (red)  
When the V1 signal is not valid, a V1 INOP flag replaces the digital value.
- (10) ALT flag (red)  
If the altitude information fails, the ALT flag replaces the altitude scale.
- (11) CHECK ALT flag (amber)  
For more information, *Refer to DSC-31-05-60 Side1/Side2 Discrepancy Messages*
- (12) ALT SEL flag (red)  
If the selected altitude information fails, an ALT SEL flag appears.
- (13) V/S flag (red)  
If the vertical speed information fails, the V/S flag replaces the vertical speed scale.
- (14) LOC and G/S flags (red)  
If the localizer or glideslope receiver fails, a LOC or G/S flag appears on the deviation scale.
- (15) VDEV flag (red)  
If the vertical deviation information fails, and the LS pb is not pressed, a VDEV flag replaces the VDEV scale.
- (16) RA flag (red)  
If both radio altimeters fail, this flag appears in place of the radio height indication.

- (17) DH flag (amber)  
A DH flag appears, when the aircraft reaches the selected DH.
- (18) HDG flag (red)  
If the heading information fails, the HDG flag replaces the heading scale.
- (19) CHECK HDG flag (amber)  
For more information, *Refer to DSC-31-05-60 Side1/Side2 Discrepancy Messages*
- (20) MACH flag (red)  
This flag appears, if the Mach data fails.
- (21) VDEV (amber)  
At the top of the glide scale, this message flashes in approach phase and, when either the FINAL mode is armed/engaged, or a non-LS approach has been selected, and the LS pushbutton is selected.
- (22) DME 1 flag (red)  
When the DME distance is not valid, a DME 1 (on PFD 1) or DME 2 (on PFD 2) flag replaces the DME distance indication.
- (23) ILS1 flag (red)  
If an ILS frequency fails, or if either the LOC or G/S signals fail, an ILS 1 (on PFD 1) or ILS 2 (on PFD 2) flag replaces the ILS frequency indication.
- (24) WINDSHEAR warning (red)  
This message is displayed, when windshear is detected (reactive windshear warning) by the FAC.  
*Refer to DSC-22\_40-40 Windshear Detection Function*
- (25) W/S AHEAD  
This message is displayed, when the predictive windshear system has detected windshear ahead of the aircraft.  
The message is in amber or red, depending on the alert level.  
*Refer to DSC-34-SURV-30-20 Windshear Alerts Inhibition*  
**Note:** 1. All flags, except, V1 INOP which is steady, flash for 9 s, then remain steady.  
2. For information on the TCAS flag, *Refer to DSC-34-SURV-60-20 PFD Indications.*
- (26) CHECK SD , CHECK CAPT (F/O ) ND (amber)  
For more information, *Refer to DSC-31-05-10 Introduction.*

**BACKUP SPEED/ALTITUDE SCALE**

Applicable to: ALL

Ident.: DSC-31-40-B-00019127.0001001 / 16 MAY 17

**GENERAL**

The BackUp Speed Scale (BUSS) enables to fly the aircraft when airspeed indications are unreliable.

When the BUSS is activated:

- The BUSS replaces the normal speed,
- The GPS altitude replaces the barometric altitude scales.


The BUSS is displayed on both PFD s when the flight crew turn off all ADRs.

The activation of this BUSS is not reversible.

The BUSS information is based on the angle of attack (AOA), and depends on the slat/flap configuration.

Ident.: DSC-31-40-B-00019128.0001001 / 21 MAR 16

**BACKUP SPEED SCALE**




(1) **Red FAST area**

This area indicates the excessive speed range while decreasing the margin to the maximum structural speed.

- (2) Amber FAST area  
This area indicates the excessive speed range while keeping an appropriate margin to the maximum structural speed.
- (3) Green area  
The green area indicates the safe speed range.
- (4) Target speed (green triangle)  
This symbol indicates the optimum target speed.  
During the approach, it indicates the target speed for the approach.
- (5) Actual speed reference (yellow line)  
This line indicates the current speed of the aircraft.
- (6) Amber SLOW area  
This area indicates the too low speed range while keeping an appropriate margin to the stall speed.
- (7) Red SLOW area  
This area indicates the too low speed range while reducing the margin to the stall speed.

**BACKUP ALTITUDE SCALE**



- (1) Current GPS altitude  
Two amber dashes cover the last two digits.

- (2) GPS ALT flag  
This flag indicates that the barometric altitude is replaced by the GPS altitude.
- (3) GPS flag (displayed depending of the aircraft configuration)  
This flag indicates that the barometric altitude is replaced by the GPS altitude.

Note: *The vertical speed indication is no longer displayed.*



**GENERAL**

Ident.: DSC-31-45-00001249.0003001 / 21 MAR 16

Applicable to: ALL

There are five different displays (five modes to display navigation information) :


- ROSE LS
- ROSE VOR
- ROSE NAV
- ARC
- PLAN

The Navigation Display (ND) can provide a weather radar image in all modes, except PLAN.

**ROSE MODES**

Ident.: DSC-31-45-00001250.0002001 / 19 MAY 14

Applicable to: ALL



- (1) Aircraft symbol (yellow)  
 Fixed and centered in the display, this symbol points to the yellow lubber line.

(2) Aircraft heading

The fixed yellow lubber line points to the aircraft magnetic heading on the moving white compass rose. Small white triangles are fixed at 45 ° intervals on the circumference of the compass rose.

“TRUE” appears at the top of the compass rose, when it is displaying true heading instead of magnetic heading (latitude above 73 ° North or 60 ° South).

(3) Selected heading or track (blue)

This pointer shows the heading or track indicated on the FCU 's HDG TRK counter.

(4) Actual aircraft track (green)

This symbol is a small green diamond.

(5) Ground speed and true air speed (green)

ADIRS furnishes these speeds.

(6) Wind direction and speed

ADIRS provides the wind direction and speed. The digital direction and the analog direction (indicated by the green arrow) both reflect the true north reference. The green arrow only appears, if the wind speed is above two knots.

If the display does not receive either wind speed or direction, dashes replace the numbers on the display.

(7) NAVAIDs

When the ADF -OFF-VOR selector switch on either the pilot's or copilot's EFIS control panel is set to ADF or VOR , the inside ND displays the following characteristics of the corresponding NAVAID in white for VOR or in green for ADF (left side for receiver 1 and right side for receiver 2):

- Type of NAVAID (ADF or VOR)
- Shape and color of the associated bearing pointer (if the bearing pointer is in view).
- NAVAID identification (or frequency by default)
- DME distance if a DME is collocated with the selected VOR . ADF and DME distance are never displayed at the same time.
- Mode of tuning
  - M for a NAVAID tuned manually by the pilot through the MCDU (underlined and dimmed),
  - R for a NAVAID tuned from an RMP (Radio Management Panel) (underlined and dimmed),
  - Nothing for a NAVAID tuned automatically by the FMGC.


If reception fails, the ND stops displaying the associated data (except for the identification or frequency).

- (8) Bearing pointer (green for ADF , white for VOR)  
 This pointer appears when bearing data is available.  
 If the aircraft is not receiving the beacon or if a receiver fails, the associated bearing pointer disappears.
- (9) Chronometer Indication (white)  
 These numbers appear when the onside chronometer is started.  
 They display the elapsed time.  
 The indication is in minutes and seconds from 0 to 59 min 59 s, and in hours and minutes from 1 h to 99 h 59 min (Seconds are not displayed beyond 59 min 59 s).
- (10) Range marks  
 The range scale value selected on the EFIS control panel (10 to 320 NM) governs the scale of the ND.

**ROSE LS MODE**

Ident.: DSC-31-45-00009584.0065001 / 24 NOV 15

Applicable to: ALL



- (1) ILS Course Pointer (Magenta)  
 This symbol points at the selected ILS course.

The ILS is either selected by the FMGC (autotuned or manually) or manually selected by the flight crew via the RMP backup mode. If no course has been entered, the default value is 360 °.

(2) Localizer Deviation Bar (Magenta)

This bar moves laterally with respect to the course pointer. Its scale has two white dots on each side of the zero deviation. Each dot corresponds to a deviation of approximately  $\pm 0.8^\circ$ . If the lateral deviation exceeds 1/4 dot ( $0.2^\circ$ ) above 15 ft RA, both the bar and the scale flash.

(3) Glide Deviation (Magenta)

This diamond moves on a vertical scale that has two white dots on each side of the yellow reference line. Each dot corresponds to a deviation of approximately  $\pm 0.4^\circ$ . If the deviation exceeds one dot above 100 ft RA, both the scale and the diamond flash.

(4) Selected ILS Information

This area displays the ILS frequency (magenta), selected course (magenta), and identification (magenta).

(5) ILS Message (Green)

This message indicates the full runway name of the selected approach. This message appears:


- The flight crew selects an ILS approach on the MCDU, and
- The FMS flight phase is DES , APP or GA , or the FMS phase is CRZ and the along track distance to destination is less than 250 NM.

*Note: ILS 1 information appears on PFD 1 and ND 2.  
ILS 2 information appears on PFD 2 and ND 1.*

**ROSE VOR MODE**

Ident.: DSC-31-45-00001252.0029001 / 05 NOV 15

Applicable to: ALL




- (1) VOR Course Pointer (Cyan)  
This symbol points to the selected VOR course.  
The VOR course is either automatically selected by the FMGC or manually selected by the flight crew via the MCDU pages or the RMP backup mode.
- (2) Lateral Deviation Bar (Cyan)  
This bar indicates the VOR deviation on a lateral scale.  
Each dot corresponds to 5 ° of lateral deviation. When the lateral deviation exceeds 10 °, the bar remains displayed on the outer dot.  
The arrow on the bar provides the TO/FROM indication.
- (3) VOR Information (White and cyan)  
This area displays the frequency and identification (if decoded by the receiver) of the selected VOR in white, the selected course in cyan, and the tuning mode in white.
- (4) VOR or GPS Message (Green)  
VOR 14L appears when the flight crew selects a VOR approach on the MCDU.  
GPS 14L appears when the flight crew selects a GPS approach.

**ROSE NAV MODE/ARC MODE**

Ident.: DSC-31-45-00001253.0017001 / 08 FEB 13

Applicable to: ALL

ROSE NAV and ARC modes give the pilot the same information, but ARC mode limits it to the forward 90° sector.



(1) Range Marks and Values

The values displayed on the ND are:

- |                  |   |
|------------------|---|
| In ROSE NAV mode | 1/4 of the selected range for the inner circle.         |
|                  | 1/2 of the selected range for the heading scale circle. |
| In ARC mode      | 1/4 of the selected range for the first inner arc.      |
|                  | 1/2 of the selected range for the second inner arc.     |
|                  | 3/4 of the selected range for the third inner arc.      |

(2) Flight Plan

The crew can use the MCDU to select various types of flight plan:

- The active flight plan (the flight plan the aircraft is actually following when the NAV mode is engaged) is represented by a continuous green line. The ND shows only the part of the flight plan that is ahead of the aircraft, as well as the waypoints that are still to be overflown and the waypoint from which the aircraft is coming.

The ND does not show a SID or a STAR, except for the last waypoint of the SID and the first waypoint of the STAR, when the selected range is 160 or 320 NM.

If the primary flight plan is not active, it is represented by a dotted green line.

- A continuous blue line portrays the missed approach procedure, and a dashed blue line portrays the flight plan to the alternate.

The missed approach and the alternate flight plan are displayed when:

- In ARC or ROSE NAV mode, a missed approach waypoint or an alternate flight plan waypoint is displayed on the outside MCDU.
- In PLAN mode a missed approach or alternate waypoint is displayed in the 2L field of the outside MCDU.

- The secondary flight plan is represented by a continuous white line. The ND continues to display the active flight plan

- Temporary flight plan

The revised portion of the flight plan is represented by a dotted yellow line

- Flight plan capture

When the aircraft is off the primary flight plan and is flying toward it in HDG mode with the NAV mode armed, the ND shows the new active flight plan as a continuous green line if the FMGC has computed the intercept path.

The part of the flight plan before the interception point shows as a dotted green line.



(3) Waypoint




The ND can display various kinds of waypoints:

Flight plan waypoints

The ND displays these as green diamonds (white, for TO waypoints). When the flight crew selects the WPT option on his EFIS control panel, all waypoints other than flight plan waypoints are displayed in magenta.

Pseudo waypoint







Point of the flight path where the aircraft is predicted to reach a selected altitude or speed.


Pseudo waypoint	Definition
 	<p>Level symbol (top of climb or level-off position), when the aircraft reaches:</p> <ul style="list-style-type: none"> <li>- The FCU-selected altitude (blue arrow), or</li> <li>- The constrained altitude, if it is more restrictive than the FCU altitude and if appropriate modes are engaged (magenta)</li> </ul> <p>- It does not appear when the aircraft is within 100 ft above, or below, the selected altitude.</p>
	<p>Top of descent symbol, or continue descent symbol:</p> <ul style="list-style-type: none"> <li>- White, if DES is not armed</li> <li>- Blue, if DES is armed.</li> </ul>

*Continued on the following page*



*Continued from the previous page*

Pseudo waypoint	Definition
	<p>Start of CLIMB symbol:</p> <ul style="list-style-type: none"> <li>- White, if CLB is not armed</li> <li>- Blue, if CLB is armed.</li> </ul>
	<p>Intercept point symbol:</p> <ul style="list-style-type: none"> <li>- White, if only the NAV mode is engaged</li> <li>- Blue, if DES mode is engaged</li> <li>- Indicates the point at which the aircraft is predicted to intercept the descent path, if there is any vertical deviation while the aircraft is in DES mode.</li> </ul>
	<p>Speed change symbol (magenta):</p> <p>Indicates the point at which the aircraft will start an automatic acceleration or deceleration from the current speed to a new computed speed for SPD LIM , SPD CSTR , or HOLDING SPD.</p>
	<p>Decelerate point symbol:</p> <ul style="list-style-type: none"> <li>- Indicates the point at which the aircraft is predicted to decelerate for approach (and thus switch to the approach phase)</li> <li>- Magenta, if in managed speed and NAV or approach mode is engaged</li> <li>- White, if in selected speed or HDG /TRK mode</li> <li>- Automatic decelerations only occur when displayed in magenta.</li> </ul>
	<p>ALT CSTR symbol set around the constrained waypoint:</p> <ul style="list-style-type: none"> <li>- Magenta, when the ALT CSTR is predicted to be met</li> <li>- Amber, when the ALT CSTR is predicted to be missed</li> <li>- White, when the ALT CSTR is not taken into account by the FMGS , and NAV mode is engaged.</li> </ul>
	<p>Energy circle symbol (green arc) centered on the aircraft position and oriented to the current track line. Represents the Required Distance to Land.</p> <p>Only displayed if the lateral guidance mode is heading or track, and the current FMS flight phase is in cruise, descent or approach, and the aircraft is within 180 NM of the destination.</p>




(4) TO waypoint

This is the next waypoint to be overflown.

This area of the screen also shows:

- Waypoint identification (white)
- Track to go (green)
- Distance to go (green)
- Estimated time of arrival (green), assuming the aircraft will fly directly from its present position to the TO waypoint at the current ground speed.



(5) NAVAIDs

The display uses specific symbols for NAVAIDs:



DME or TACAN



VOR



VOR /DME



NDB

The symbol appears:

- In green if the NAVAID is a current waypoint of the flight plan
- In white if it is the TO waypoint
- In blue when the NAVAID is tuned for display either automatically by the FMGC or manually through the MCDU
- In magenta when the NAVAID is not part of the flight plan and is called for display as an option (corresponding option pushbutton pressed on the FCU EFIS control panel).

(6) Airport

**Airport included in the flight plan:**

- If the runway is not specified, the airport is represented by a star and the identification is displayed in white.  
Example: \* LSGG
- If the runway is specified, it is represented by an oriented runway symbol in white.



LSGG  
33R

The runway is drawn to scale (paved length) if the selected range is 10, 20 or 40 NM.

Optional airport information

The airports that are not displayed as part of the flight plan may be called for display (ARPT pb on the EFIS control panel).

They are represented by a star and the identification in magenta.

(7) ILS Course (Magenta)

When the pilot pushes the LS pb-sw on the EFIS control panel, and if an ILS station has been selected, the display shows an ILS course symbol.

(8) ILS Marker Beacons

The screen shows these as waypoints (diamonds).

When the aircraft overflies a marker beacon, the corresponding symbol flashes:


- Blue for the outer marker.
- Amber for the middle marker.
- White for the inner marker.

(9) Cross Track Error

This is the aircraft's lateral deviation from the active leg of the flight plan (related to the great circle route). It is indicated in nautical miles (NM), with the letter R (right) or L (left), according to the position of the aircraft with respect to the flight plan.

(10) Track Line

This line appears in green only in the ROSE NAV or ARC mode when HDG or TRK has been selected on the FCU.




(11) Procedure turns and holding patterns

These only appear when they are part of the flight plan. For the 160 and 320 NM range scales, each one is represented by a white arrow that originates at the associated fix and indicates the direction of the turn.

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**

INDICATIONS ON ND



For shorter range scales, and if the procedure turn or the holding pattern is in the next or the active leg, the display shows the full circuit or pattern.



**PLAN MODE**

Ident.: DSC-31-45-00001254.0002001 / 24 FEB 11

Applicable to: **ALL**


This mode statically displays the flight plan legs on a map oriented to true north. The map is centered on a map reference point, that the pilot selects by scrolling to it on his MCDU.

The map reference point is the waypoint displayed on the second line of the MCDU 's F-PLN page. It can either be the active waypoint (next waypoint to be overflown), or any other waypoint of the flight plan.

The pilot can scroll through the overall flight plan, and display it in PLAN mode.

The pilot chooses the scale of the map with the range selector (the diameter of the outer circle corresponds to the selected range).

Data on NAVAIDS and on their characteristics and associated bearing pointers are not available in this mode.



- (1) Aircraft Position and True Track  
The orientation of the yellow aircraft symbol always indicates the true track of the aircraft. Its position represents the aircraft position given by the FMGS.
- (2) Map Reference Point  
If the CSTR option is not selected, the track and distance from the map reference point to the next F-PLN waypoint is displayed in magenta.
- (3) Cross Track Error  
*Refer to DSC-31-45 ROSE NAV Mode/ARC Mode.*

**WEATHER RADAR INDICATIONS**

Ident.: DSC-31-45-00015503.0001001 / 21 MAR 17

Applicable to: ALL

*Refer to DSC-34-SURV-30-30 Weather Radar indication on ND.*

**PWS  INDICATIONS**

Ident.: DSC-31-45-00015504.0001001 / 21 MAR 17


Applicable to: ALL

*Refer to DSC-34-SURV-30-30 PWS (if installed) indication on PFD and ND*

**EGPWS**

Ident.: DSC-31-45-00009586.0013001 / 08 AUG 13

Applicable to: ALL






(1) EGPWS terrain picture

The ND displays the EGPWS terrain picture, when the TERR ON ND switch is selected ON, and the ND is not in PLAN mode. The terrain picture replaces the weather radar image. Terrain data is displayed independently of the aircraft relative altitude.

The terrain appears in different colors and densities, in accordance with its relative height:



- Note:
- Areas without available terrain data in the EGPWS database appear in magenta
  - The reference altitude is computed based on the current aircraft altitude or, if descending more than 1 000 ft/min, the altitude expected in 30 s
  - In case of flight above the maximum elevation number, the relief between the minimum and maximum displayed elevations is displayed by using three different green levels.

(2) Center Part Messages

- The “TERR CHANGE MODE” indication is displayed in red (or amber), in the case of a Terrain Awareness Display (TAD) warning (or caution) alert, if the current selected display mode is PLAN
- The “TERR REDUCE RANGE” indication is displayed in red (or amber), in the case of a Terrain Awareness Display (TAD) warning (or caution) alert, if the selected range is 160 NM or 320 NM.

(3) TERR indication

To differentiate between the terrain and the weather display, the weather radar TILT is replaced by a blue TERR, and the terrain display sweeps from the center outward to both ND sides.

(4) Warning and caution messages

TERRAIN or OBST (amber) : For a caution.

TERRAIN or OBST (red) : For a warning.

When triggered, these messages flash for 9 s, then remain steady until the caution or warning alert condition disappears.

TERR RNG (red) : For a RANGE error warning.

TERR TST (amber) : Appears during the EGPWS test, when the terrain pattern is displayed, and there is no failure.

(5) Terrain or obstacle caution alert

Generated when a conflict exists between the terrain caution envelope, ahead of the aircraft, and database-stored terrain/obstacles. The conflict area is shown in solid yellow.

(6) Terrain or obstacle warning alert

Generated when a conflict exists between the terrain warning envelope, ahead of the aircraft, and terrain/obstacles data stored in the database. The conflict area is shown in solid red.

- Note: *When an alert is generated (either caution or warning) and TERR ON ND is not selected, the terrain is automatically displayed and the TERR ON ND's pushbutton ON light comes on.*

(7) Lowest and highest elevations


Minimum and maximum elevations encountered ahead of the aircraft, within the selected ND range. The color code of the elevation figures is the same as for the EGPWS terrain picture.

Note: *The elevations shown on the ND correspond to the terrain included in the selected ND range, ahead of the aircraft. In ARC mode, the elevations are linked with the terrain displayed on the ND. In ROSE mode, the elevations may not represent the lowest and highest terrain currently displayed on the ND.*

**FLAGS AND MESSAGES DISPLAYED ON ND**

Ident.: DSC-31-45-00001256.0425001 / 21 MAR 17

Applicable to: ALL



(1) HDG Flag (red)

If the heading data fails, the rose, arc and associated symbols disappear. A HDG flag flashes for 9 s, then remains steady in the upper part of the ND.

(2) CHECK HDG Flag (amber)

For more information: *Refer to DSC-31-05-60 Side1/Side2 Discrepancy Messages*

(3) Center Part Messages

- The screen displays a MODE CHANGE message in green if there is a discrepancy between the selected mode on the EFIS control panel and the mode sent from the outside FMGC , or while the DMC is preparing a new page for display
- The screen displays a RANGE CHANGE message in green if there is a discrepancy between the range selected on the EFIS control panel and the range sent from the outside FMGC. A MODE CHANGE message has priority over a RANGE CHANGE message
- The screen displays a MAP NOT AVAIL message in red for several reasons:
  - The MODE CHANGE or RANGE CHANGE message has been displayed more than 6 s, or
  - The FMGC has failed, or
  - The FMGC has delivered an invalid aircraft position.
- The screen displays a W/S SET RNG 10 NM message if a predictive windshear alert is triggered and the range is above 10 NM.  
The message is displayed in the color corresponding to the windshear alert: red for a warning, amber for a caution
- The screen displays a W/S CHANGE MODE message if a predictive windshear alert is triggered and the ND is not in ARC or ROSE mode. The message appears in red for a warning, or amber for a caution.

(4) LOC Flag (red)

If LOC data fails, this flag flashes for 9 s, then remains steady.

(5) G/S Flag (red)

If G/S data fails, this flag flashes for 9 s, then remains steady.

(6) VOR Flag (red)

In ROSE VOR mode, when the VOR bearing is not valid, this flag flashes for 9 s, then remains steady.

(7) VOR 1(2) or ADF 1(2) or DME 1(2) Flag (red)

If a navigation receiver fails, the appropriate one of these flags flashes for 9 s, then remains steady.

(8) VOR Course Flag

If the VOR course fails, a red CRSXXX flag appears.

If there is non-computed data (NCD ), a blue CRS - - - flag appears.

(9) Other messages

- MAP PARTLY  
DISPLAYED (amber) : In case of incomplete data transmission between the FMGC (priority criteria) and the DMC , or if the DMC cannot draw the complete MAP.  
This message is also displayed when a very long leg exists in the flight plan. A leg is considered as “very long” when the starting point (or endpoint) is located at more than 45 ° from the aircraft location (45 ° of longitude or latitude).  
This DMC limitation results from a compromise between accurate drawing precision and maximum leg length that can be displayed.
- NAV ACCUR UPGRAD, : Signals a change in navigation accuracy.  
or (white) NAV ACCUR  
DOWNGRAD (amber)
- SPECIFIC VOR/D : If the NAVAID, that is tuned for the selected approach or  
UNAVAIL (amber) departure, is not available.
- BACK-UP NAV (amber) : If the MCDU back-up navigation mode is activated (*Refer to  
DSC-22\_10-40-10 MCDU - MCDU Interface*)
- SET OFFSIDE : Displayed on ND 1(2), in case of an FMGC 1(2) failure when the  
RNG/MODE (amber) two ND ranges or modes selected on the EFIS control panels are different.
- OFFSIDE FM CONTROL : If the offside FM supplies the onside ND.  
(amber)
- GPS PRIMARY (white, : This message appears when GPS PRIMARY mode is available,  
boxed white) or has been recovered. The pilot can clear this message by  
pressing the CLR key on the MCDU.
- GPS PRIMARY LOST : This message appears when GPS PRIMARY is not available,  
(amber, boxed white) and not clearable by pilot action.
- ↓ (green) : Overflow arrow, displayed when more than one of the following  
messages are present at the same time:  
- NAV ACCUR DOWNGRAD  
- NAV ACCUR UPGRAD  
- SPECIF VOR-D UNAVAIL  
- MAP PARTLY DISPLAYED  
- SET OFFSIDE RNG/MODE  
- GPS PRIMARY  
- GPS PRIMARY LOST

*Note: For information about the TCAS messages: Refer to DSC-34-SURV-60-20 TCAS Messages.*

(10) OFST R(L) XX message (yellow)

The screen displays this message, when a temporary or an offset flight plan is entered. The offset value is given in NM.

*Note: For information about the TCAS messages: Refer to DSC-34-SURV-60-20 TCAS Messages.*

(11) PRED W/S flag (amber)

The WINDSHEAR sw on the weather radar panel is set to AUTO, and a Predictive Windshear System fault is detected. This message appears on ground, or when flaps and slats are extended.

It is associated with a single chime. The radar image remains available, provided that the fault does not affect the radar mode.

(12) GPS message (green)

This message shows the full runway name of the selected approach. It is displayed, when the flight crew selects a GPS approach.


(13) CHECK EWD , CHECK CAPT (F/O ) PFD , CHECK SD , CHECK CAPT (F/O ) ND (amber)

For more information: *Refer to DSC-31-05-60 Feedback Messages*

**EFIS CONTROL PANEL**

Ident.: DSC-31-50-00001257.0003001 / 09 OCT 12

Applicable to: ALL



(1) Barometer Reference Display Window

Range : 745 hPa to 1 100 hPa.

(2) Barometer Reference Selector

- a. Outer ring : For selection of the units for the barometer reference-either hectoPascals or inches of mercury.

*Note:* The unit selected does not appear on the PFD.

- b. Inner knob : For selection of the reference value displayed in the barometer reference display window and on the PFD below the altitude scale.

At FCU initialization, the window displays 1 013 or 29.92, depending on the unit selected.

- Pulling the knob selects the standard BARO reference setting. The PFD then displays "STD." (Rotating the knob has no effect.)
- Pushing the knob from the STD position makes the last selected QNH BARO setting available.

(3) FD pb

Pushing this button removes the FD bars from the associated PFD (or removes the flight path director symbol if the TRK FPA reference is selected).

The pushbutton light goes out.

Pushing it again restores the FD bars (or the FPD symbol) and the green pushbutton light comes on.

(4) LS pb

Pushing this button displays the localizer and glide slope scales on the PFD.

Deviation symbols appear if there is a valid ILS signal.

The green pushbutton light comes on.

(5) Mode Select Switch

This switch selects a navigation display for the outside ND.

(6) Range Select Switch

This switch selects a range scale for the outside ND.

*Note: If the mode or the range data fails, the default selection is the ROSE NAV mode and 80 NM range.*

(7) ADF -VOR Select Switches

These switches select ADF or VOR bearing pointers and DME distance on the outside ND, as well as the corresponding NAVAID data characteristics in any mode except PLAN mode.

(8) Optional Data Display Pushbutton

Pushing this button displays optional data in addition to the data permanently displayed in PLAN, ARC, or ROSE NAV modes. The green pushbutton light comes on.


Only one option can be activated at a time.



**OTHER EFIS CONTROLS**

Ident.: DSC-31-50-00001258.0002001 / 15 FEB 11

Applicable to: ALL



(1) OFF/BRT knobs

- These knobs turn the PFD and ND display units on and off, and control their brightness.
- The display brightness adjusts automatically for changing light conditions, and is also adjusted manually.

PFD Brightness Control Knob

Rotating this knob all the way counterclockwise switches off the PFD . In this case, the PFD image is automatically displayed on the NDU, but the pilot may recover the ND by means of the PFD -ND XFR pushbutton .

ND Brightness Control Knob

The outer knob controls the brightness of both the weather radar image and EGPWS terrain display.

The inner knob controls the general brightness of the ND symbols.

Rotating this knob all the way counterclockwise switches off the NDU.

(2) PFD /ND Pushbutton


Pushing this button interchanges the PFD and the ND.

If the PFDU fails, the PFD automatically transfers to the NDU.

**CHRONOMETER**

Ident.: DSC-31-50-00001259.0001001 / 15 FEB 11

Applicable to: ALL



(1) CHRONO Pushbutton

Pushing this button displays chronometer time on the outside ND.

Pushing it again freezes the displayed value.

Pushing it a third time resets the chronometer, and the chronometer time disappears from the display.

**GENERAL**

Ident.: DSC-31-55-10-00001260.0002001 / 21 MAR 16

**Applicable to: ALL**

A fully independent clock is on the right side of the control panel.

It sends time to the centralized fault data interface unit, the flight data interface unit, and the flight management and guidance computer.

The clock has two electrical supplies, one of which is a direct connection to the aircraft battery hot bus.

The clock performs four functions :

- It displays "UTC" (GMT) time in hours, minutes and seconds on the center counter.
- It displays elapsed time (ET) (from engine startup) in hours and minutes on the lower counter.
- It drives the chronometer (CHR), which measures a time interval (from the pushing of the CHRONO button) in minutes and seconds.
- It can replace the UTC with the date.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INDICATING/RECORDING SYSTEMS**


CLOCK - GENERAL

Intentionally left blank

**GENERAL**

Ident.: DSC-31-55-20-00001261.0003001 / 16 MAR 11

Applicable to: ALL



- (1) UTC (GMT) counter  
 This counter displays the present time in 24 h format from 0 to 23 h 59 min 59 s.
- (2) Elapsed Time (ET)  
 This counter registers the elapsed time up to 99 h and 59 min.
- (3) Chrono (CHR) counter  
 This Counter registers elapsed time from 0 to 99 min 59 s. It is controlled by the CHR pushbutton.
- (4) CHR pushbutton  
 First push : starts the CHR counter  
 Second push : stops the CHR counter, keeps the display at its last indication.
- (5) Reset (RST) pushbutton  
 When pressed, the CHR counter restarts from 0 if the chrono is running.

(6) ET selector

- “RUN” : the ET counter starts
- “STP” : the ET counter stops counting
- spring loaded “RST” : the ET counter is blanked. The selector returns to its STP position when the selector is released.

*Note: A cumulative elapsed time can be realized by alternatively setting this switch in “RUN” and “STP” position.*

(7) DATE/SET pushbutton

First push : sets the clock to date mode. The UTC time display is replaced by the date (day month year).

Second push : sets the clock to time mode. The date display disappears.

*Note: in order to select the date mode, the UTC selector must be set on “GPS” or “INT” position.*

(8) UTC selector

“GPS” : Time (or date, if selected) is displayed, and this data is synchronized on GPS information.

- Note:*
- If the signal between the GPS and the clock is not detected, dashes are displayed. Only the “INT” and “SET” positions are then available.
  - If the signal is detected, but GPS data is invalid, the clock automatically runs on its internal time.
  - The clock will automatically resynchronize on the GPS information, as soon as the GPS data becomes available.

“INT” : Internal time (or date, if selected) is displayed.

- Note:*
- The clock’s internal time is initialized with the latest valid GPS information.
  - If there is no valid GPS information at power up, the internal time will be 00:00:00, until the clock is initialized.

“SET” : Allows the internal time and date to be initialized.

**OPERATION IN INTERNAL MODE**

Ident.: DSC-31-55-20-00007126.0001001 / 21 MAR 17

Applicable to: ALL

**DATE INITIALIZATION**

Set the UTC selector on “SET”. The minute digits flash, and the seconds' digits are blank.

To increase data, turn the DATE/SET button clockwise.

To decrease data, turn the DATE/SET button counterclockwise.

- First, push on DATE/SET : To set the hour.
- Second, push on DATE/SET : To set the year.
- Third, push on DATE/SET : To set the month.
- Fourth, push on DATE/SET : To set the day.

Switch the UTC selector to the "INT" position, and the clock starts with the seconds' digits at 00.

*Note:* This process must be completed in less than one minute. Otherwise, it will be necessary to reset the CFDS in order to synchronize the lower ECAM time display with the cockpit clock display. Resetting the CFDS is a maintenance operation.

### **PRECAUTION IN CASE OF ATC DATALINK COMMUNICATION**

If the clock is set to internal (INT) mode and the flight crew manually sets the time and date, the clock does not comply with the time precision required for ATC datalink communication (+/-1 s UTC). This may lead to the rejection of messages, or to the acceptance of obsolete messages:

- The CPDLC function will send CPDLC messages with an erroneous date/time
- The CPDLC function will accept obsolete uplink messages and may reject uplink messages with a correct date/time
- The uplink messages for oceanic and departure clearance will be displayed in the Datalink Control and Display Unit (DCDU) with an erroneous time
- The ADS-C function will continue to operate, but in a degraded mode.

To comply with the time precision requirement for ATC datalink communication, the flight crew must either:

- Use the clock in GPS mode, or
- Use the clock in INT mode and synchronize the clock with the GPS at least one time per day. This synchronization ensures that the UTC time drift is below +/- 1 s UTC.

### **GPS SYNCHRONIZATION IN INTERNAL MODE**

When the clock is set to INT mode, the UTC time is only based on the internal clock and is not synchronized with the GPS. To reset the drift that results from the UTC internal time, the flight crew must perform the following actions:

- Set the UTC selector of the clock to the GPS mode and keep this setting during at least 10 seconds
- Then reset the UTC selector of the clock to INT mode.

These actions result in a resynchronization of the internal clock with the GPS.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**AIRCRAFT SYSTEMS**

**INDICATING/RECORDING SYSTEMS**

CLOCK - CONTROLS AND INDICATORS

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>INDICATING/RECORDING SYSTEMS</b></p> <p>FLT RECORDERS - FLIGHT DATA RECORDING SYSTEM</p>
---	---

**DESCRIPTION**

Ident.: DSC-31-60-10-00001262.0002001 / 09 OCT 12

**Applicable to: ALL**

The Flight Data Recording System, which records the mandatory parameters, consists of the following components:

- A Flight Data Interface and Management Unit (FDIMU)
- A Digital Flight Data Recorder (DFDR)
- A three-axis Linear Accelerometer (LA)


The FDIMU collects and processes parameters from the SDAC s, DMC s, FWC s, FCDC s, BSCU , the DFDR event pushbutton, the GND CTL pushbutton and the Clock.

It stores the mandatory flight parameters in the DFDR.

The DFDR can store the last 25 h data, at least. It stores this data on a fireproof and shockproof device. An underwater locator beacon is attached to the DFDR.

The linear accelerometer measures the acceleration of the aircraft along each of the three axes.

The QAR is an operational recorder that stores the same data as the DFDR . However the QAR is more accessible for the maintenance crew.



The recording system is automatically active:

- On the ground, during the first five minutes after the aircraft electric network is energized.
- On the ground, after the first engine start.
- In flight (whether the engines are running or not).


On the ground, the recording system stops automatically five minutes after the second engine shuts down.

On the ground, the crew can start the recording system manually by pressing the GND CTL pushbutton.

**OVERHEAD PANEL**

Ident.: DSC-31-60-20-00001263.0001001 / 09 OCT 12

Applicable to: ALL



(1) GND CTL pushbutton (springloaded)

**ON** : The Cockpit Voice Recorder (CVR) and the Flight Data Recorders are active. The ON light is on.


**AUTO**: The Cockpit Voice Recorder (CVR) and the Flight Data Recorders are active, according to the logic.

The system automatically switches from ON to AUTO at the first engine start, and also in case of an electrical transient.

**PEDESTAL**

Ident.: DSC-31-60-20-00001264.0001001 / 22 MAY 12

Applicable to: ALL



(1) DFDR EVENT pushbutton

Pressing this button (briefly) sets an event mark on the Flight Data records.

**DESCRIPTION**

Ident.: DSC-31-60-30-00005369.0002001 / 09 OCT 12

Applicable to: ALL

The AIDS is used to monitor various aircraft system parameters in order to make maintenance easier and to allow formulating operational recommendations.

The AIDS can generate system reports. The Airbus Standard Reports are preprogrammed reports available at aircraft delivery. The operator can create its own reports.

The AIDS uses the Flight Data Interface and Management Unit (FDIMU) to acquire the relevant aircraft system parameters. The FDIMU is connected to the rest of the AIDS as shown below.


The system may be programmed using the MCDU s. The crew can select any report to be displayed on the MCDUs.

The Printer prints the flight phase programmed reports or any report selected on the MCDU.

This printing may be automatic or in response to the AIDS PRINT pushbutton.

The AIDS may send automatic reports via ACARS <img alt="ACARS icon" data-bbox="575 398 595 413"/> .


An optional Digital Recorder may be installed to extend the recording capacity.



**CONTROLS ON PEDESTAL**

Ident.: DSC-31-60-30-00005370.0001001 / 20 DEC 10

Applicable to: ALL



(1) AIDS PRINT pushbutton

Pushing this pushbutton causes the immediate printing of a specific report, depending on the flight phase. The crew may then use the MCDU to select another report for immediate printing.

# **AIRCRAFT SYSTEMS**

LANDING GEAR

Intentionally left blank



**DSC-32-10 Gears and Doors**

**DSC-32-10-10 Description**

General.....A  
 Main Landing Gear (MLG).....B  
 Nose Landing Gear (NLG).....C  
 Landing Gear Extension and Retraction Equipment.....D  
 Landing Gears and Doors Operation.....E

**DSC-32-10-20 Landing Gear System/Interface**

Landing Gear Control Interface Unit (LGCIU).....A  
 Proximity Detector Output Signals.....B  
 Proximity Detector Output Signals (Cont'd).....C

**DSC-32-10-30 Interactions between Landing Gear and Aircraft Systems**

GENERAL.....A  
 Proximity Detectors on Shock Absorbers.....B  
 Proximity Detectors on Uplocks.....C  
 Proximity Detectors on Doors.....D  
 Proximity Detectors on Downlocks.....E  
 Proximity Detectors on Cargo Doors.....F  
 Proximity Detectors on Flaps Attachments.....G

**DSC-32-10-40 Controls and Indicators**

Landing Gear Indicator Panel.....A  
 Landing Gear Selector Lever.....B  
 Landing Gear Gravity Extension.....C  
 WHEEL SD Page.....D  
 Memo Display.....E

**DSC-32-20 Nose Wheel Steering**

**DSC-32-20-10 Description**

Description.....A  
 Architecture.....B

**DSC-32-20-20 Controls and Indicators**

Side Consoles.....A  
 WHEEL SD Page.....B  
 Memo Display.....C

*Continued on the following page*


*Continued from the previous page*

**DSC-32-30 Brakes and Antiskid**

**DSC-32-30-10 Description**

General.....	A
Anti-Skid System.....	B
Auto Brake.....	C
Braking Modes.....	D
Braking Schematic.....	E

**DSC-32-30-20 Controls and Indicators**

Center Instrument Panel.....	A
Auto BRK Panel.....	B
Brake Fan  .....	C
Pedestal.....	D
WHEEL SD Page.....	E
Memo Display.....	F

**GENERAL**

Ident.: DSC-32-10-10-00018598.0001001 / 21 MAR 16

**Applicable to: ALL**

The landing gear consists of :

- Two main landing gears that retract inboard
- One nose landing gear that retracts forward.

Doors enclose the landing gear bays. Gear and doors are electrically controlled and hydraulically operated.

The doors, which are fitted to the landing gear struts, are operated mechanically by the gear and close at the end of gear retraction.

All gear doors open while the gear is retracting or extending.

Two Landing Gear Control and Interface Units (LGCIU s) control the extension and retraction of the gear and the operation of the doors. They also supply information about the landing gear to ECAM for display, and send signals indicating whether the aircraft is in flight or on the ground to other aircraft systems.

A hand crank on the center pedestal allows the flight crew to extend the landing gear if the aircraft loses hydraulic systems or electrical power.

**MAIN LANDING GEAR (MLG)**

Ident.: DSC-32-10-10-00018599.0001001 / 21 MAR 16

**Applicable to: ALL**

Each main gear has twin wheels and an oleopneumatic shock absorber.

Each main wheel has an antiskid brake.

**NOSE LANDING GEAR (NLG)**

Ident.: DSC-32-10-10-00018600.0001001 / 21 MAR 16

**Applicable to: ALL**


The two-wheeled nose gear has an oleopneumatic shock strut and a nose wheel steering system.

**LANDING GEAR EXTENSION AND RETRACTION EQUIPMENT**


Ident.: DSC-32-10-10-00018601.0001001 / 21 MAR 16

Applicable to: ALL

**MAIN LANDING GEAR**



**NOSE LANDING GEAR**



**LANDING GEARS AND DOORS OPERATION**

Applicable to: ALL


Ident.: DSC-32-10-10-A-00018602.0001001 / 21 MAR 16

**NORMAL OPERATION**

The flight crew normally operates the landing gear by means of the lever on the center instrument panel.

The LGCIU s control the sequencing of gear and doors electrically. One LGCIU controls one complete gear cycle, then switches over automatically to the other LGCIU at the completion of the retraction cycle. It also switches over in case of failure.

The green hydraulic system actuates all gear and doors. When the aircraft is flying faster than 260 kt, a safety valve automatically cuts off hydraulic supply to the landing gear system. Below 260 kt, the hydraulic supply remains cut off as long as the landing gear lever is up.



Ident.: DSC-32-10-10-A-00018603.0001001 / 21 MAR 16

### LANDING GEAR GRAVITY EXTENSION

If the normal system fails to extend the landing gear hydraulically, the flight crew can use a crank to extend it mechanically.

When a crew member turns the crank, it :

- Isolates the landing gear hydraulics from the green hydraulic system
- Unlocks the landing gear doors and the main and nose main gear
- Allows gravity to drop the gear into the extended position.

Locking springs help the crew to crank the main gear into the locked condition, and aerodynamic forces assist in the locking of the nose gear.

The gear doors remain open.

The flight crew can reset the emergency extension system in flight after using it for training (if green hydraulic pressure is available).

Intentionally left blank



## **LANDING GEAR CONTROL INTERFACE UNIT (LGCIU)**

Applicable to: ALL

Ident.: DSC-32-10-20-A-00018604.0001001 / 21 MAR 16

### **GENERAL**

The LGCIUs receive position information from the landing gear, cargo door, and landing flap systems.

Ident.: DSC-32-10-20-A-00018605.0001001 / 21 MAR 16

### **LANDING GEAR INFORMATION**

The LGCIUs receive landing gear position information from proximity detectors when:

- The landing gears are locked down or up, or
- The shock absorbers are compressed or extended, or
- The landing gear doors are open, or closed, or
- The bogie are aligned or not.


The LGCIUs send the landing gear position data to other aircraft systems.

In case of a LGCIU failure, the landing gear is controlled by the remaining healthy LGCIU.

Ident.: DSC-32-10-20-A-00018606.0001001 / 21 MAR 16

### **CARGO DOORS INFORMATION**

Sensors send to the LGCIUs the position of the following components :

- Manuel selector valves
- Locking shaft
- Locking handle
- Safety shaft
- Door sills  .

The LGCIUs detect electrical failures only in certain proximity switches in the cargo door system :

- Locking shaft
- Locking handle
- Safety shaft.

When an LGCIU makes such a detection, it indicates the NON LOCKED condition for that component.

Ident.: DSC-32-10-20-A-00018607.0001001 / 21 MAR 16

### **LANDING FLAPS INFORMATION**


The LGCIU s process the signals from four flap disconnect proximity switches, then send them to the Slat/Flap Control Computers (SFCCs).

The LGCIU s do not monitor failures in the SFCC system.

**PROXIMITY DETECTOR OUTPUT SIGNALS**

Ident.: DSC-32-10-20-00001278.0001001 / 22 MAY 12


Applicable to: ALL



**PROXIMITY DETECTOR OUTPUT SIGNALS (CONT'D)**

Ident.: DSC-32-10-20-00001279.0001001 / 21 MAR 16

Applicable to: ALL






**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### LANDING GEAR

GEARS AND DOORS - LANDING GEAR SYSTEM/INTERFACE

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>LANDING GEAR</b> GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS
---	---

**GENERAL**

Ident.: DSC-32-10-30-00001285.0001001 / 10 DEC 09  
**Applicable to: ALL**


The following tables present the operational effects of the proximity detectors on aircraft systems.  
 How to read the tables :

SYSTEM	LGCIU 1	LGCIU 2	A/C IN FLT	A/C ON GROUND
SERVICE INTERPHONE	6	6	.....	.....
SFCC 1(2)	5	(5)	.....	.....

The above lines mean that the service interphone receives the output n° 6 from both LGCIU s, while SFCC 1 receive the output 5 from LGCIU 1 and SFCC 2 the output 5 from LGCIU 2.  
 The two additional columns give the system functioning when the aircraft is in flight and on the ground.

**PROXIMITY DETECTORS ON SHOCK ABSORBERS**

Ident.: DSC-32-10-30-00018608.0003001 / 06 SEP 16  
**Applicable to: ALL**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>GENERAL</b>	STROBE lts		5	On when AUTO selected	Off when AUTO selected
	LOGO lts		5	Off when flaps retracted	On
	AIRSTAIRS 	3	1	Control inhibited <sup>(1)</sup>	Control not inhibited <sup>(2)</sup>
	CARGO DOOR <sup>(5)</sup>		5	Normal control not available	Normal control available
	WATER FILLING		5	Preselect water servicing inhibited	Preselect water servicing available


*Continued on the following page*

## AIRCRAFT SYSTEMS

### LANDING GEAR

#### GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>AIR COND</b>	AVNCS COOLING	5	5	<ul style="list-style-type: none"> <li>• Skin temp. &lt; 35 °C : The system is in closed conf. <sup>(1)</sup></li> <li>• Skin temp. &gt; 35 °C : The system is in intermediate conf. <sup>(1)</sup></li> </ul>	<ul style="list-style-type: none"> <li>• Skin temp. &lt; 5 °C : The system is in closed conf. <sup>(2)</sup></li> <li>• Skin temp. &gt; 5 °C : The system is in open conf. <sup>(2)</sup></li> </ul>
	GRND COOLING 	1 3	1 3	Inhibited <sup>(1)</sup>	Not inhibited <sup>(2)</sup>
	FWD CARGO VENT		5	Extract fan stopped when $\Delta P > 1$ PSI	Extract fan on
	CAB PRESS	5	5	Climb mode active <sup>(4)</sup>	<ul style="list-style-type: none"> <li>- Prepressurization active before TO <sup>(3)</sup></li> <li>- Depressurization active after LDG <sup>(3)</sup></li> </ul>
	PACK 1(2) TEMP CONTROL		3 (1)	Pack air inlet flaps opened	Pack air inlet flap fully closed at TO and LDG
<b>APU</b>	APU AUTO SHUTDOWN	5		<p>In case of oil low press, automatic shutdown is delayed by 15.5 s</p> <ul style="list-style-type: none"> <li>- In case of oil low press, the automatic shutdown is delayed by : <ul style="list-style-type: none"> <li>• 15.5 s if the oil temp &lt; -4 °C</li> <li>• 0.05 s if oil temp &gt; -4 °C</li> </ul> </li> </ul>	

*Continued on the following page*

## AIRCRAFT SYSTEMS

### LANDING GEAR

#### GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>COMMUNICATIONS</b>	SERVICE INTERPHONE	6	6	Inhibited <sup>(6)</sup>	Available <sup>(7)</sup>
	PUBLIC ADDRESS	1 3	1 3	P.A. increased level <sup>(6)</sup>	P.A. low level <sup>(7)</sup>
	ADIRU and AVIONICS ground warning	1 3	1 3	External horn and light inhibited <sup>(6)</sup>	External horn and light not inhibited <sup>(7)</sup>
	FLT INTERPHONE	9		Communication with ground mechanic inhibited	Communication with ground mechanic available
	COCKPIT CALL LIGHT	9		Inhibited	Not inhibited
	ACARS (ACARS MU or ATSU)	7		Available	Available
	CVR	1 3 7	1 3	Runs <sup>(6)</sup>	Runs: <sup>(7)</sup> - during the first 5 min following energization - with one engine running  Stops: <sup>(7)</sup> 5 min after second engine shutdown
CVR		5	<ul style="list-style-type: none"> <li>• ERASE function inhibited</li> <li>• No low frequency signal in the loudspeakers if test performed</li> </ul>	<ul style="list-style-type: none"> <li>• ERASE function not inhibited</li> <li>• Low frequency signal in the loudspeakers if test performed</li> </ul>	
<b>ELEC</b>	DC generation	5		APU start on batteries only, is delayed by 45 s	No APU start delay when on batteries only
	GALLEY supply		5	Main galley not supplied when APU GEN only is supplying	Main galley supplied when APU GEN only is supplying
<b>EIS</b>	EIS	5		Display test inhibited when ANN LT TEST is selected	Display test not inhibited
<b>FIRE</b>	APU	5		No APU fire automatic extinguishing	Automatic extinguishing not inhibited

*Continued on the following page*


## AIRCRAFT SYSTEMS

### LANDING GEAR

#### GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>FLT CTL</b>	SFCC 1(2)	5	(5)	<ul style="list-style-type: none"> <li>• For SFCC 1(2): Slats alpha/speed lock function active</li> <li>• For SFCC (2): No flaps movement inhibition if the cargo door is opened</li> </ul>	<ul style="list-style-type: none"> <li>• For SFCC 1(2): Slats alpha/speed lock function active if speed &gt; 60 kt</li> <li>• For SFCC (2): Flaps movement inhibition if cargo door is opened</li> </ul>
<b>FLT INST</b>	<ul style="list-style-type: none"> <li>• DFDR</li> <li>• QAR </li> </ul>	1 3 7	1 3	Runs <sup>(6)</sup>	<p>Runs: <sup>(7)</sup></p> <ul style="list-style-type: none"> <li>• During the first 5 min following energization</li> <li>• With one engine running</li> </ul> <p>Stops: <sup>(7)</sup> 5 min after second engine shut down</p>
<b>FUEL</b>	FQI	5		FQI uses flight attitude correction due to wing bending	FQI uses ground attitude correction
<b>HYD</b>	BLUE and GREEN pumps	1 3		Blue or green pump "FAULT" light not inhibited when related pump is stopped <sup>(6)</sup>	Blue or green pump "FAULT" light inhibited when related pump is stopped <sup>(7)</sup>
	BLUE pump	7		Runs when electrical power is available	Runs when at least one engine is running
	BLUE and YELLOW pumps		1 3	Blue or yellow pump "FAULT" light not inhibited when related pump is stopped <sup>(6)</sup>	Blue or yellow pump "FAULT" light inhibited when related pump is stopped <sup>(6)</sup>
	PTU		7	PTU runs if green/yellow diff. press > 500 PSI	<p>PTU runs if green/yellow diff. press &gt; 500 PSI and</p> <ul style="list-style-type: none"> <li>• both MASTER LEVERS are at OFF or</li> <li>• Both MASTER LEVERS are at ON or</li> <li>• Nose wheel steering is not in towing position with parking brake released.</li> </ul> <p>PTU is inhibited during the use of the cargo door hand pump and for 40 s after its use.</p>

*Continued on the following page*




## AIRCRAFT SYSTEMS

### LANDING GEAR

#### GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>ICE RAIN PROT</b>	CAPT , (F/O), ((STBY)) probes and CAPT , (F/O) windows heating	4, (2) ((8))	4, (2) ((8))	<ul style="list-style-type: none"> <li>CAPT , (F/O), ((STBY)) pitots and CAPT , (F/O) windows : high heating level applied</li> <li>All other probes and windows are heated<sup>(6)</sup></li> </ul>	<ul style="list-style-type: none"> <li>With engines stopped: no heating<sup>(6)</sup></li> <li>With at least one engine running:</li> <li>CAPT , (F/O), ((STBY)) pitots and CAPT , (F/O) windows are heated at low level<sup>(6)</sup></li> </ul>
	WING ANTI ICE	3	1	Wing anti ice valves open when the WING ANTI ICE pb is at ON <sup>(6)</sup>	Wing anti ice valves open for 30 s when the WING ANTI ICE pb is at ON <sup>(6)</sup>
	RAIN REPELLENT	1 3	1 3	Not inhibited <sup>(6)</sup>	Inhibited if engines are stopped <sup>(7)</sup>
	DRAIN MAST <sup>(10)</sup>		9	High heating level is applied	Low heating level is applied
<b>LANDING GEAR</b>	L/G SAFETY VALVE	6		Safety valve closes if aircraft speed > 260 kt	Safety valve opened
	L/G control	10	10	Retraction not inhibited <sup>(9)</sup>	Retraction inhibited <sup>(9)</sup>
	TIRE PRESS 		5	"TYRE LO PRESS" warning threshold set to its flight level	"TYRE LO PRESS" warning threshold set to its ground level
<b>NAVIGATION</b>	STAND BY ALTI	5		VIBRATION function active	VIBRATION function inhibited
	ATC 1(2)	3	(1)	ATC 1(2) available in AUTO mode	ATC 1(2) inhibited in AUTO mode
	ADIRU 1 <sup>(10)</sup>	7		No external horn when ADIRU supplied from batteries only	External horn not inhibited

*Continued on the following page*

**AIRCRAFT SYSTEMS**


**LANDING GEAR**

**GEARS AND DOORS - INTERACTIONS BETWEEN  
LANDING GEAR AND AIRCRAFT SYSTEMS**

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	A/C IN FLT	A/C ON GRND
<b>POWER PLANT</b>	FADEC 1(2)	1	(1)	<u>On ENG 1(2):</u> <sup>(6)</sup> <ul style="list-style-type: none"> <li>• Reverse inhibited</li> <li>• No automatic start abort</li> <li>• FADEC always supplied</li> <li>• FLEX not available</li> <li>• If installed, BUMP not selectable</li> </ul>	<u>On ENG 1(2):</u> <sup>(8)</sup> <ul style="list-style-type: none"> <li>• Reverse available</li> <li>• Automatic start abort available</li> <li>• 5 min after eng-shut down FADEC 1(2) no more supplied</li> <li>• FLEX available</li> <li>• If installed, BUMP selectable</li> </ul>
		3	(3)		
		8	(8)		

- (1) *When either LGCIU indicates flight.*
- (2) *When both LGCIU indicate ground.*
- (3) *When either LGCIU indicates ground.*
- (4) *When both LGCIU indicate flight.*
- (5) *Valid from MSN 44.*
- (6) *When either output indicates flight.*
- (7) *When all outputs indicate ground.*
- (8) *When both outputs indicate ground.*
- (9) *One valid output is sufficient.*
- (10) *Valid from MSN 22.*

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>LANDING GEAR</b> GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS
---	---

**PROXIMITY DETECTORS ON UPLOCKS**

Ident.: DSC-32-10-30-00018610.0002001 / 21 MAR 16  
**Applicable to: ALL**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	L/G UNLOCKED	L/G NOT UNLOCKED
<b>LANDING GEAR</b>	L/G control	19	19	If UP selected <sup>:(1)</sup> L/G doors will close	If UP selected <sup>:(1)</sup> L/G doors will not close
	ECAM WHEEL page	16	16	If UP selected <sup>:(2)</sup> L/G uplocked indications	If UP selected <sup>:(2)</sup> L/G in transit indications
		17 18	17 18		
	L/G indicator panel	16 17 18		If UP selected <sup>:(2)</sup> no indication	If UP selected <sup>:(2)</sup> "UNLK" red indications

- (1) One valid output is sufficient.  
 (2) When all outputs indicate the same position.

**PROXIMITY DETECTORS ON DOORS**

Ident.: DSC-32-10-30-00018611.0001001 / 21 MAR 16  
**Applicable to: ALL**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	DOORS FULLY OPENED	DOORS CLOSED
<b>LANDING GEAR</b>	L/G control	24	24	L/G extension or retraction possible <sup>(1)</sup>	L/G extension or retraction inhibited <sup>(1)</sup>
	ECAM WHEEL page	20	20	Doors fully opened indication	Doors closed indication
		21	21		
		22 23	22 23		

- (1) One valid output is sufficient.

**PROXIMITY DETECTORS ON DOWNLOCKS**

Ident.: DSC-32-10-30-00018613.0001001 / 21 MAR 16  
**Applicable to: ALL**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	L/G DOWNLOCKED	L/G NOT DOWNLOCKED
<b>GEN</b>	TAXI/T.O lights		15	Lights not inhibited	Lights inhibited
<b>COMM</b>	SIGNS	12	12	"NO SMOKING" <sup>(1)</sup> and "EXIT" signs on when AUTO selected <sup>(2)</sup>	"NO SMOKING" <sup>(1)</sup> and "EXIT" signs inhibited when AUTO selected <sup>(3)</sup>



*Continued on the following page*

**AIRCRAFT SYSTEMS**


**LANDING GEAR**

**GEARS AND DOORS - INTERACTIONS BETWEEN  
LANDING GEAR AND AIRCRAFT SYSTEMS**

*Continued from the previous page*

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	L/G DOWNLOCKED	L/G NOT DOWNLOCKED
<b>FLT INST</b>	WBS 	15	15	Active <sup>(4)</sup>	Inhibited <sup>(5)</sup>
<b>FMGS</b>	FAC 1(2)	12	12	VLE indication displayed on PFD 1(2)	No VLE indication
<b>LANDING GEAR</b>	L/G control	14	14	If DOWN selected : <sup>(6)</sup> L/G doors will close	If DOWN selected : <sup>(6)</sup> L/G doors will not close
	ECAM WHEEL page	11 13 15	11 13 15	If DOWN selected : <sup>(7)</sup> L/G down indications	If DOWN selected : <sup>(7)</sup> L/G in transit indications
	L/G INDIC panel	11 13 15		If DOWN selected : <sup>(7)</sup> L/G down indications	If DOWN selected : <sup>(7)</sup> L/G in transit indications
	BRAKING STEERING	15	15	BSCU test operative <sup>(2)</sup>	BSCU test inhibited <sup>(3)</sup>
	BRAKE COOLING FANS 		13	Cooling available when ON selected	Cooling inhibited when ON selected
<b>NAV</b>	GPWS	13		"TOO LOW-FLAPS" or "TOO LOW TERRAIN" warning operative	"TOO LOW-GEAR" or "TOO LOW TERRAIN" warning operative

- (1) For cabin not configured for non smoking flight*
- (2) When either output indicates DOWNLOCK.*
- (3) When both outputs indicate NOT DOWNLOCK.*
- (4) When both outputs indicate DOWNLOCK.*
- (5) When either output indicates NOT DOWNLOCK.*
- (6) One valid output is sufficient.*
- (7) When all outputs indicate the same position.*


 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>LANDING GEAR</b> GEARS AND DOORS - INTERACTIONS BETWEEN LANDING GEAR AND AIRCRAFT SYSTEMS
---	---

**PROXIMITY DETECTORS ON CARGO DOORS**

Ident.: DSC-32-10-30-00018614.0001001 / 21 MAR 16

Applicable to: ALL

**LOCKING HANDLE OR SHAFT, DOOR SILLS**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	LOCKED	UNLOCKED
<b>CRG DOORS</b>	ECAM DOOR PAGE	<b>30 (31)</b>		Forward (aft) door symbol appears green	Forward (aft) door symbol appears amber, associated with "CARGO" amber
	CARGO DOOR OPERATION		<b>34 (35)</b>	Forward (aft) door normal opening inhibition	Forward (aft) door normal opening possible
			<b>36 (37)</b>		Forward (aft) door normal operation possible

**MANUAL SELECTOR VALVE**

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	CLOSE	OPEN
<b>CRG DOORS</b>	CARGO DOOR OPERATION		<b>32 (33)</b>	Forward (aft) door normal opening inhibition	Forward (aft) door normal opening possible

**PROXIMITY DETECTORS ON FLAPS ATTACHMENTS**

Ident.: DSC-32-10-30-00001291.0001001 / 22 MAR 16

Applicable to: ALL

	SYSTEM	LGCIU 1 OUTPUT	LGCIU 2 OUTPUT	FLAP ATTACHMENT	FLAP ATTACHMENT FAILURE
<b>FLT CTL</b>	SFCC	<b>28 (29)</b>	<b>28 (29)</b>	L(R) FLAPS normal operation <sup>(1)</sup>	"FLAPS LOCKED" warning <sup>(2)</sup>

<sup>(1)</sup> When at least one SFCC detects normal operation

<sup>(2)</sup> When both SFCCs detect attachment failure

**AIRCRAFT SYSTEMS**

**LANDING GEAR**


GEARS AND DOORS - INTERACTIONS BETWEEN  
LANDING GEAR AND AIRCRAFT SYSTEMS

Intentionally left blank

**LANDING GEAR INDICATOR PANEL**

Ident.: DSC-32-10-40-00018615.0001001 / 21 MAR 16

Applicable to: ALL



This panel is connected to LGCIU1, which receives signals from proximity detectors.

▽ light: comes on green if the gear is locked down.

UNLK: comes on red if the gear is not locked in the selected position.  
 light

***Note:** This panel is connected to the LGCIU1 only, therefore, the lights on the LDG GEAR indicator panel come on as long as the LGCIU1 is electrically supplied. If one UNLK indication remains on, the landing gear position can be confirmed using the WHEEL SD page (information from LGCIU 1 & 2). Only one green triangle on each landing gear is sufficient to confirm that the landing gear is downlocked.*

**LANDING GEAR SELECTOR LEVER**

Ident.: DSC-32-10-40-00018616.0001001 / 20 MAY 16


Applicable to: ALL

A two-position selector lever sends electrical signals to the two LGCIUs. These control the green hydraulic supply to the landing gear system by means of selector valves.

The flight crew must always move the L/G lever in one continuous movement (i.e. with no stop between both positions).

When the flight crew selects UP or DOWN (and if the airspeed is below 260 kt):

- All landing gear doors open
- Each landing gear moves to the selected position
- All landing gear doors close.



(1) L/G LEVER

- UP** : This position selects landing gear retraction.  
 While the landing gear doors are opening, the normal brake system brakes the wheels of the main landing gear automatically.  
 A brake band in the nose landing gear well brakes the nose landing gear wheels as the doors close (for aircraft equipped with nose landing gear rubbing strips).
- DOWN** : This position selects landing gear extension.  
 An interlock mechanism prevents anyone from accidentally retracting the gear while the aircraft is on the ground. It does so by locking the lever in DOWN position when the shock absorber on either main gear is compressed (aircraft on ground) or the nose wheel steering is not centered.  
 The landing gear hydraulic system remains pressurized as long as the landing gear is extended (if green hydraulic pressure is available).

(2) RED ARROW


This red arrow lights up if the landing gear is not locked down when the aircraft is in the landing configuration, and a red warning appears on ECAM.



**LANDING GEAR GRAVITY EXTENSION**

Ident.: DSC-32-10-40-00018617.0001001 / 21 MAR 16

Applicable to: ALL




To put the landing gear down by gravity, the flight crew must pull the gear crank out, then turn it clockwise for 3 turns.

When the flight crew operates the crank handle, the cutout valve shuts off hydraulic pressure to the landing gear system and depressurizes it.

**WHEEL SD PAGE**

Ident.: DSC-32-10-40-00018618.0007001 / 21 MAR 16

Applicable to: ALL




(1) Landing gear position indication

The landing gear positions are indicated by 2 triangles for each gear. The indications are as follow:

- Green triangle indicates that one LGCIU detects a landing gear downlocked
- Red triangle indicates that one LGCIU detects a landing gear in transit
- No triangle indicates that one LGCIU detects a landing gear uplocked
- Amber crosses will replace the right triangle to indicate that LGCIU 1 or LGCIU 2 has failed.

*Note: Only one green triangle on each landing gear strut is sufficient to confirm that the landing gear is downlocked.*

- (2) Landing gear door position indication



- (3) UP LOCK

This legend appears amber along with a caution on the ECAM if the landing gear uplock is engaged when the landing gear is down locked.

- (4) L/G CTL

This legend appears amber along with an ECAM caution if the landing gear lever and the landing gear position do not agree. This legend only appears when the landing gear is moving to the selected position.

**MEMO DISPLAY**

Ident.: DSC-32-10-40-00018778.0001001 / 22 MAR 16

Applicable to: ALL

**FLT L/G DOWN** : This memo appears in green if the aircraft is operated in ferry flight conditions with landing gear down.

**AIRCRAFT SYSTEMS**

**LANDING GEAR**

GEARS AND DOORS - CONTROLS AND INDICATORS

Intentionally left blank

**DESCRIPTION**

Ident.: DSC-32-20-10-00018619.0007001 / 21 MAR 16


Applicable to: ALL

A hydraulic actuating cylinder steers the nose wheel. The yellow hydraulic system supplies pressure to the cylinder, and electric signals from the Brake and Steering Control Unit (BSCU) control it.

The BSCU receives orders from:

- Captain's, and the First Officer's steering hand wheels (orders added algebraically), or
- Rudder pedals, or
- Autopilot.

The BSCU transforms these orders into nose wheel steering angle. That angle has the following limits, which depend on ground speed and the origin of the orders.



The steering system receives actuating hydraulic pressure when:

- A/SKID & N/W STRG switch is ON
- Towing control lever is in normal position
- At least one engine is running
- Aircraft is on ground.

The handwheel can turn the nosewheel up to  $75^\circ$  in either direction. A lever, on the towing electrical box (on nose landing gear), enables ground crew to deactivate the steering system for towing. Then the wheel can be turned  $95^\circ$  in either direction.

To prevent rudder pedal orders, or autopilot orders, from going to the BSCU, the pilots can use the pushbutton on either steering handwheel.

00000An internal cam mechanism returns the nose wheel to the centered position after takeoff.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS


### LANDING GEAR

NOSE WHEEL STEERING - DESCRIPTION

## ARCHITECTURE

Ident.: DSC-32-20-10-00001298.0002001 / 21 MAR 16

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### LANDING GEAR

NOSE WHEEL STEERING - DESCRIPTION


Intentionally left blank



**SIDE CONSOLES**

Ident.: DSC-32-20-20-00018620.0001001 / 21 MAR 16

Applicable to: ALL



(1) Steering handwheels

The steering handwheels, which are interconnected, can steer the nose wheel up to 75 ° in either direction.

*Note:* The steering system centers the nose wheel automatically after liftoff.


(2) Rudder PEDALS DISC pb

Pressing this button on either handwheel removes control of nose wheel steering from the rudder pedals until the button is released.

**WHEEL SD PAGE**

Ident.: DSC-32-20-20-00018622.0004001 / 21 MAR 16

Applicable to: ALL



(1) N/W STEERING indication

It appears in amber, when nosewheel steering is lost, due to failure of the nosewheel steering system, or of both BSCU channels, or in case of a yellow hydraulic system low pressure, or if the A/SKID & N/W STRG switch is OFF.

(2) N/W STEERING hydraulic supply indication:

Only when the N/W STEERING indication is displayed, Y is displayed:

- In green when the yellow hydraulic system is not failed, or
- In amber when the yellow hydraulic system low pressure.


**MEMO DISPLAY**

Ident.: DSC-32-20-20-00016853.0001001 / 10 AUG 15

Applicable to: ALL

**NW STRG DISC** : This memo appears in green, when the nose wheel steering selector is in the towing position.

**NW STRG DISC** : This memo appears in amber, if one engine is running.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>LANDING GEAR</b></p> <p style="text-align: center;">BRAKES AND ANTISKID - DESCRIPTION</p>
---	---

<b>GENERAL</b>
----------------

Ident.: DSC-32-30-10-00018623.0002001 / 21 MAR 16

**Applicable to: ALL**

The main wheels are equipped with carbon multidisc brakes, which can be actuated by either of two independent brake systems.

The normal system uses green hydraulic pressure, whereas the alternate system uses the yellow hydraulic system backed up by the hydraulic accumulator.

An anti-skid and autobrake system is also provided.

Braking commands come from either the brake pedals (pilot action), or the autobrake system (deceleration rate selected by the crew).

In normal operation, a dual channel Brake and Steering Control Unit (BSCU) controls normal braking and antiskid.

Depending on the failure, braking may revert to:

- Alternate braking with antiskid. This braking mode is controlled by the Alternate Braking Control Unit (ABCU ), and the antiskid is controlled by the BSCU
- Alternate braking without antiskid. This braking mode is fully-controlled by the ABCU
- Alternate braking without antiskid on accumulator. This braking mode is fully-controlled by the ABCU.


All the normal and alternate braking components are fully-monitored. Any detected failure is signaled to the crew via ECAM warnings.

The BSCU performs the following secondary functions:

- Checks the residual pressure in the brakes
- Monitors the brake temperature
- Provides discrete wheel speed information to other aircraft systems.

A changeover between the two BSCU channels takes place at each DOWN landing gear lever selection, or in case one channel fails.

The main gear wheels are fitted with fusible plugs which protect against tire burst, in the event of overheating.

Main gear wheels are also equipped with brake cooling fans  , which permit a high speed cooling of brakes.

<b>ANTI-SKID SYSTEM</b>
-------------------------

Ident.: DSC-32-30-10-00018624.0001001 / 21 MAR 16

**Applicable to: ALL**

The antiskid system provides maximum braking efficiency by maintaining the wheels at the limit of an impending skid.

At skid onset, brake release orders are sent to the normal and alternate servovalves, as well as to the ECAM system which displays the released brakes.

Without using autobrake, full braking performance is achieved only with brake pedals at full deflection.

The antiskid system is deactivated below 20 kt (ground speed).

An ON/OFF switch activates, or deactivates, the antiskid and nosewheel steering systems.

### **PRINCIPLE**

The speed of each main gear wheel (given by a tachometer) is compared to the aircraft speed (reference speed). When the speed of a wheel decreases below approximately 0.87 times (depending on conditions) reference speed, brake release orders are given to maintain the wheel slip at that value (best braking efficiency).

In normal operation, the reference speed is determined by the BSCU from the horizontal acceleration of ADIRU 1, or ADIRU 2, or ADIRU 3.

In case all ADIRUs fail, reference speed equals the maximum of either main landing gear wheel speeds.

## **AUTO BRAKE**

Applicable to: ALL

Ident.: DSC-32-30-10-A-00018625.0001001 / 21 MAR 16

### **GENERAL**

The purposes of the autobrake system are the following:

- Reduce the braking distance in case of an aborted takeoff
- Establish and maintain a selected deceleration rate during landing, thereby improving passenger comfort and reducing crew workload.

Ident.: DSC-32-30-10-A-00018626.0002001 / 21 MAR 16

### **SYSTEM ARMING**

The crew may arm the system by pressing the LO, MED, or MAX pushbutton provided all the following arming conditions are met :

- Green pressure available
- Anti-skid electrically-powered
- No failure in the braking system
- At least one ADIRU is available.

*Note:* 1. Auto brake may be armed with the parking brake on.  
2. MAX autobrake mode cannot be armed in flight.

Ident.: DSC-32-30-10-A-00018627.0002001 / 21 MAR 16

### **SYSTEM ACTIVATION**

Automatic braking is activated when:

- The command for ground spoilers extension is detected (*Refer to DSC-27-10-20 Speed Brakes and Ground Spoilers - Speed Brake Control*), for LO and MED mode, or
- The command for ground spoilers extension is detected, and the aircraft speed is above 40 kt, for MAX mode.

Therefore, if the aircraft makes an acceleration stop and begins to decelerate when its speed is under 72 kt, the automatic braking will not activate because the ground spoilers will not extend. For autobrake to activate, at least two SEC's must be operative.

Ident.: DSC-32-30-10-A-00018628.0001001 / 21 MAR 16

### **SYSTEM DEACTIVATION**

The system deactivates when:

- The system disarmed (*Refer to DSC-32-30-10 Auto Brake - System Disarming*), or
- The ground spoilers retract. In this case it remains armed.

Ident.: DSC-32-30-10-A-00018629.0002001 / 21 MAR 16

The system disarms when:

- Flight crew presses the pushbutton switch, or
- One or more arming conditions is lost, or
- After take-off/touch and go, or
- Flight crew applies enough deflection to at least one brake pedal when autobrake is active in MAX, MED or LO mode.

## **BRAKING MODES**

**Applicable to: ALL**

Ident.: DSC-32-30-10-B-00018630.0001001 / 21 MAR 16

### **GENERAL**

There are four modes of operation:

- Normal braking
- Alternate braking with antiskid
- Alternate braking without antiskid
- Parking brake.

Ident.: DSC-32-30-10-B-00018631.0001001 / 21 MAR 16

### **NORMAL BRAKING**

Normal braking is operative when:

- Green hydraulic pressure is available
- A/SKID & N/W STRG switch is ON.

During normal braking, antiskid is operative and autobrake is available.

Braking is electrically-controlled through the BSCU from:

- Pilot's pedals, or
- Automatically activates when:
  - On ground by the autobrake system, or
  - In flight when the landing gear lever is up.

The antiskid system is controlled by the BSCU via the normal servo valves.

There is no brake pressure indication in the cockpit.

Ident.: DSC-32-30-10-B-00018632.0002001 / 17 MAR 17

### **ALTERNATE BRAKING WITH ANTI-SKID**

Autobrake is inoperative.

Braking uses this mode when green hydraulic pressure is insufficient, and :

- Yellow hydraulic pressure is available
- A/SKID & N/W STRG switch is ON
- Parking brake is not ON.

Braking inputs are made by the brake pedals and sent to the ABCU . Then, taking into account the brake pedal input, the ABCU:

- Energizes the alternate brake selector valve to pressurize the yellow hydraulic circuit
- Electrically controls the Alternate Servo Valve to obtain the correct pressure for the related brakes.

Antiskid is controlled by the BSCU.

A triple indicator on the center instrument panel indicates the pressure delivered to the left and right brakes, as well as the accumulator pressure.

*Note: Initial pedal force or displacement produces more braking action in alternate mode than in normal mode.*

Ident.: DSC-32-30-10-B-00018633.0002001 / 17 MAR 17

### **ALTERNATE BRAKING WITHOUT ANTI-SKID**

Autobrake and antiskid are inoperative.

The antiskid system is either deactivated:

- Electrically (A/SKID & N/W STRG sw OFF, or power supply failure, or BSCU failure), or
- Hydraulically (Y + G system low pressure, the brakes are supplied by the brake accumulator only).

Depending on the brake pedals' demand, the ABCU controls the alternate brake selector and the alternate servovalves.

Brake pressure and accumulator pressure are indicated on a triple indicator, located on the center instrument panel. To avoid wheel locking and limit the risk of tire burst, brake pressure is automatically limited to 1 000 PSI.

The accumulator can supply at least 7 full brake applications.

*Note:* Initial pedal force or displacement produces more braking action in alternate mode than in normal mode.

Ident.: DSC-32-30-10-B-00018634.0002001 / 21 MAR 16

## **PARKING BRAKE**

Brakes are supplied by the yellow hydraulic system, or by accumulator pressure via the parking brake control valve, which opens allowing full pressure application on the main gear wheel brakes. The accumulator maintains the parking pressure for at least 12 h.

If the parking brake is activated and no yellow hydraulic or accumulator brake pressure is available, then the normal braking system can be applied via the brake pedals.


Yellow accumulators can be pressurized by pressing the yellow electrical pump switch.

A triple indicator on the center instrument panel indicates the pressure delivered to the left and right brakes, as well as the accumulator pressure.

**BRAKING SCHEMATIC**

Ident.: DSC-32-30-10-00001316.0003001 / 09 OCT 12

Applicable to: ALL






**CENTER INSTRUMENT PANEL**

Ident.: DSC-32-30-20-00018635.0002001 / 21 MAR 16

Applicable to: ALL



(1) A/SKID & N/W STRG sw


**ON :** If green hydraulic pressure is available, then antiskid is available.

If green hydraulic pressure is lost, then:

- Yellow hydraulic pressure automatically takes over to supply the brakes
- Antiskid and nosewheel steering remain available
- Triple indicator shows yellow system brake pressure.

**OFF :** The yellow hydraulic system supplies pressure to the brakes.

- Antiskid is deactivated. The pilot must refer to the triple indicator to limit brake pressure and avoid locking a wheel
- Nosewheel steering is lost
- Differential braking remains available through the pedals
- Triple indicator displays yellow system brake pressure.



(2) BRAKES and ACCU PRESS indicator

Brake pressure is only indicated when the yellow hydraulic system controls the brake pressure, This is when the:

- Alternate braking system is activated, or
- Parking brake is applied.

ACCU : Indicates the pressure in the yellow brake accumulator.


PRESS

BRAKES : Indicates the yellow pressure delivered to the left and right brakes, as measured upstream of the alternate servovalves.

**AUTO BRK PANEL**

Ident.: DSC-32-30-20-00018636.0002001 / 21 MAR 16

Applicable to: ALL



(3) AUTO/BRK panel

The springloaded MAX , MED , and LO pushbutton switches arm the appropriate deceleration rate. The usage for each mode are as follow:

- MAX mode is normally selected for takeoff.  
 In the case of an aborted takeoff, maximum pressure goes to the brakes, as soon as the system generates the ground spoiler deployment order
- MED or LO mode is normally selected for landing:
  - MED mode sends progressive pressure to the brakes 2 s after the ground spoilers deploy in order to decelerate the aircraft at 3 m/s<sup>2</sup> (9.8 ft/s<sup>2</sup>)
  - LO mode sends progressive pressure to the brakes 4 s after the ground spoilers deploy, in order to decelerate the aircraft at 1.7 m/s<sup>2</sup> (5.6 ft/s<sup>2</sup>).

The lighting on the pushbutton switches are as follow:

ON light : comes on blue to indicate positive arming

DECEL light : comes on green when the actual deceleration is 80 % of the selected rate

*Note: On slippery runways, the predetermined deceleration may not be reached, due to antiskid operation. In this case, the DECEL light will not come on. This does not mean that autobrake is not working.*


Off : The corresponding autobrake mode is not armed

**BRAKE FAN** 

Ident.: DSC-32-30-20-00018637.0001001 / 21 MAR 16

Applicable to: ALL

**BRK FAN**



(4) **BRK FAN pb-sw** 

ON light : The brake fans run if the lefthand main landing gear is down and locked

Off : The brake fans stop

HOT : This amber light comes on when the brakes get too hot (A caution appears on light ECAM, also)

**PEDESTAL**

Ident.: DSC-32-30-20-00018638.0001001 / 21 MAR 16

Applicable to: ALL




- (1) PARKING BRK handle  
Flight crew pulls this handle, then turns it clockwise, to apply the parking brake.  
The ECAM memo page displays "PARK BRK".

**CAUTION** If the pointer is not at ON, the parking brake is not on.

**WHEEL SD PAGE**

Ident.: DSC-32-30-20-00018639.0008001 / 21 MAR 16

Applicable to: ALL



(1) Release indicators

■ It appears in amber in case of brake released fault.

(2) ANTI SKID indication



(A) ANTISKID label

It appears in amber, a long with an ECAM caution, in case of a total BSCU failure, or when the A/SKID & N/W STRG sw is OFF, or if the BSCU detects an ANTI-SKID failure, or in case of normal braking and yellow hydraulic system low pressure.  
 It appears in green in case of autobrake, normal braking, or alternate braking failure, and antiskid is still available.

(B) BSCU channel indication

When ANTISKID label is displayed, the number of the failed system(s) is (are) displayed in amber, if any.

(3) AUTO BRK

This legend appears:

- In green when auto brake is armed, or
- Flashing green for 10 s after autobrake disengagement, or
- In amber, along with an ECAM caution, to indicate a system failure.

MED , LO, or MAX appears underneath in green to show which rate has been selected.

(4) Wheel number

This white number identifies individual wheels of the main landing gear.

(5) Brake temperature

- Temperature normally appears in green.
- Green arc appears on the hottest wheel when one brake temperature exceeds 100 °C.
- Green arc becomes amber, and an ECAM caution appears, when the corresponding brake temperature exceeds 300 °C.

(6) NORM BRK indication



(A) NORM BRK label

This indication appears in green when autobrake or alternate braking is failed, and normal braking is still available.

The legend appears in amber when normal braking is failed due to total BSCU failure, or to the loss of the green hydraulic pressure, or to the loss of antiskid.

(B) NORM BRK hydraulic supply indication

G is displayed when the NORM BRK label is displayed. It is green when green hydraulic pressure is available and amber, in case of green hydraulic low pressure.

(7)




(A) ALTN BRK label

This indication appears in green, if the braking system is in alternate mode and not failed, or in case autobrake or normal braking is failed and alternate braking is still available.

This indication appears in amber when alternate braking is failed.

(B) ALTN BRK hydraulic supply indication

Y is displayed when the ALTN BRK label is displayed. It is green when yellow hydraulic pressure is available and amber, in case of yellow hydraulic low pressure.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>LANDING GEAR</b></p> <p style="text-align: center;">BRAKES AND ANTISKID - CONTROLS AND INDICATORS</p>
---	---

(C) ACCU indications



- (\*) Appears in green, when the ALTN BRK label is displayed, and the yellow hydraulic pressure is available.  
Appears in amber, with no arrow, when the yellow hydraulic system and the accumulator are in low pressure.
- (\*\*) Appears in green when the alternate braking is pressurized by the yellow accumulator.

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-32-30-20-A-00016854.0001001 / 22 MAR 16

**AUTO BRK LO/MED/MAX** : This memo appears in green, depending on the selection of the AUTO BRK pb.

Ident.: DSC-32-30-20-A-00016855.0001001 / 22 MAR 16

**AUTO BRK OFF** : This memo appears in green if the auto brake is failed.

Ident.: DSC-32-30-20-A-00016856.0001001 / 22 MAR 16

**BRK FAN** : This memo appears in green if the BRK FAN pb  is ON.

Ident.: DSC-32-30-20-A-00016857.0001001 / 22 MAR 16

**PARK BRK** : This memo appears in green, if the parking brake is ON, during flight phases 1, 2, 9 and 10.

Intentionally left blank



# AIRCRAFT SYSTEMS

LIGHTS

Intentionally left blank

**DSC-33-10 Cockpit Lighting**

DSC-33-10-10 General

General.....A

DSC-33-10-20 Description

Description.....A

Schematic.....B

DSC-33-10-30 Controls and Indicators

Overhead Panel.....A

Maintenance Panel.....B

Lateral Window.....C

Pedestal.....D

Glareshield.....E

Main Inst Panel.....F

**DSC-33-20 Exterior Lighting**

DSC-33-20-10 General

General.....A

DSC-33-20-20 Controls and Indicators

Schematic.....A

Overhead Panel.....B

Memo Display.....C

**DSC-33-30 Emergency Lighting**

DSC-33-30-10 Description

General.....A

Proximity Emergency Escape Path Marking System/Exit Signs.....B

DSC-33-30-20 Controls and Indicators

Controls and Indicators.....A

**DSC-33-40 Signs**

DSC-33-40-10 Controls and Indicators

Overhead Panel.....A

Memo Display.....B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### LIGHTS

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL**

Ident.: DSC-33-10-10-00017615.0001001 / 21 MAR 16

**Applicable to: ALL**

The instrument panel has both integral instrument lighting and flood lighting.

The brightness of all panel lighting is adjustable.

Spot lights and flood lights provide lighting for all work surfaces and the side consoles.

Two dimmable dome lights provide lighting for the overall cockpit. When the batteries are supplying electrical power, only the right-hand dome light is on line.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**LIGHTS**

COCKPIT LIGHTING - GENERAL

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>LIGHTS</b> COCKPIT LIGHTING - DESCRIPTION</p>
---	--

<b>DESCRIPTION</b>
--------------------

Ident.: DSC-33-10-20-00017616.0001001 / 21 MAR 16  
**Applicable to: ALL**

**INTEGRATED LIGHTING FOR INSTRUMENTS AND PANELS**

All instruments and panels in the cockpit (other than display units) have integral lighting. The flight crew can adjust the brightness of all integral lighting.

**ANNUNCIATOR LIGHTS**

The ANN LT sw on the overhead panel controls the brightness of all the annunciator lights in the cockpit.  
The ANN LT sw sets the brightness of all annunciator lights at the same level.  
The flight crew can test the annunciator lights with the following procedure: Set the ANN LT sw to the TEST position, and check to see that all the annunciator lights come on.

**DOME LIGHTS**

Two dome lights provide the cockpit with shadow-free lighting.

**MAP HOLDER LIGHTING** 

Each flight crewmember has a map holder that can be lighted.

**CONSOLE AND BRIEFCASE LIGHTING**

Each flight crewmember has lighting for briefcase stowage, the side console, and the floor.

**CENTER INSTRUMENT PANEL**

Lights under the glareshield provide lighting for the center instrument panel.

**STANDBY COMPASS**

The standby compass has integral lighting.

**READING LIGHTS**

Each flight crewmember has a reading light.


**PEDESTAL LIGHTING**

A flood light in the middle of the overhead panel provides lighting for the center pedestal.

**SCHEMATIC**

Ident.: DSC-33-10-20-00001336.0002001 / 05 FEB 14

Applicable to: ALL






**OVERHEAD PANEL**

Ident.: DSC-33-10-30-00017617.0001001 / 21 MAR 16

Applicable to: ALL



- (1) OVHD INTEG LT knob  
This knob turns the overhead panel's integral lighting on and off, and adjusts its brightness.
- (2) ICE IND & STBY COMPASS sw  
This switch turns the standby compass light and the external ice detector light on and off.
- (3) DOME sw  
The DOME sw controls both dome lights.  
The DOME sw can have one of the two following configurations:



- BRT : Both dome lights are on and bright.
- DIM : Both dome lights are on and dim.
- OFF : Both dome lights are off.

- (4) ANN LT sw  
The ANN LT sw controls all the flight deck annunciator lights.  
The ANN LT sw can have one of the two following configurations:



**TEST :** All flight deck annunciator lights turn On.  
 The figure '8' is displayed on all Liquid Crystal Display (LCD) of the FCU.

**DIM :** Reduces the brightness of all flight deck annunciator lights.

**BRT :** All flight deck annunciator lights operate normally.

***Note:** When the ANN LT sw is set to TEST, do not reconfigure the DU (ECAM /ND transfer) or the DMC (DMC switching).*

(5) READING LT knob

The reading light on each side of the overhead panel has its own control knob that turns it on and off and adjusts its brightness.

**MAINTENANCE PANEL**

Ident.: DSC-33-10-30-00001338.0001001 / 22 MAY 12

**Applicable to: ALL**



(1) AVIONICS COMPT LT pushbutton switch


**AUTO :** avionic compartment lighting is automatically controlled by door opening.

**ON :** avionic compartment lighting is on.

**LATERAL WINDOW**

Ident.: DSC-33-10-30-00001339.0002001 / 05 FEB 14

Applicable to: ALL




- (1) Map light sw (Captain and F/O)
- (2) Brightness adjustment knob
- (3) Light

**PEDESTAL**

Ident.: DSC-33-10-30-00017619.0001001 / 21 MAR 16

Applicable to: ALL



- (1) FLOOD LT MAIN PNL knob  
 Turns on or off, and adjusts the brightness of the main instrument panel.
- (2) INTEG LT MAIN PNL & PED knob  
 Turns on or off, and adjusts the brightness of the integral lights of:
  - The main instrument panel
  - The center pedestal.


(3) FLOOD LT PED knob



Turns on or off, and adjusts the brightness of the pedestal lights.

**GLARESHIELD**

Ident.: DSC-33-10-30-00001341.0002001 / 21 JAN 14

Applicable to: **ALL**




- (1) This knob adjusts the brightness of the integral lighting on the glareshield.
- (2) This knob adjusts the brightness of the FCU displays.
- (3) This lighting  illuminates the sliding table and map holder.
- (4) This knob  adjusts the brightness of the sliding table and map holder lighting.

**MAIN INST PANEL**

Ident.: DSC-33-10-30-00017620.0001001 / 21 MAR 16

Applicable to: ALL



(1) CONSOLE/FLOOR sw

Each switch controls the lights of the side console and of the briefcase on each side of the cockpit. In addition, each switch controls the lighting of the floor around each flight crew member's seat. The lights can either be bright, dim, or off.


Intentionally left blank

**GENERAL**

Ident.: DSC-33-20-10-00017621.0001001 / 21 MAR 16

**Applicable to: ALL**

Exterior lighting includes the following lights:

- The navigation lights
- The landing lights
- The runway turn off lights
- The TO and TAXI lights
- The logo lights 
- The anticollision lights
- The wing and engine scan lights.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### LIGHTS

EXTERIOR LIGHTING - GENERAL

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS


### LIGHTS

EXTERIOR LIGHTING - CONTROLS AND INDICATORS

## SCHEMATIC

Ident.: DSC-33-20-20-00017622.0001001 / 21 MAR 16


Applicable to: ALL










**OVERHEAD PANEL**

Ident.: DSC-33-20-20-00017623.0004001 / 21 MAR 16



Applicable to: ALL



- (1) BEACON sw  
This switch turns on and off the two flashing red lights, one on top and one on the bottom of the fuselage.
- (2) WING sw  
This switch turns on and off two beam lights on each side of the fuselage. These lights provide lighting on the wing leading edge and on the engine air intake to detect ice accretion.
- (3) NAV & LOGO  sw  
There are single navigation light, or dual navigation lights  on each wing and in the APU tail cone.  
A blue light  below each navigation light allows to monitor the navigation light wear (LED technology). When the NAV & LOGO  sw is ON, this light  flashes in blue if the navigation light replacement should be planned.  
There are logo lights  in the upper surface of each horizontal stabilizer. These light provide lighting for the company logo on the vertical stabilizer provided the main landing gears are compressed, or depending on the aircraft configuration, when flaps are extended (at least 15 ° on some aircraft) or slats are extended.




The NAV & LOGO  sw can have one of the following configuration:



- ON : Turns on the NAV and the LOGO lights .
- OFF : The NAV and the LOGO lights  are off.

or



- 2 : Turns on NAV 2 and the LOGO lights .
- 1 : Turns on NAV 1 and the LOGO lights .
- OFF : The NAV and the LOGO lights  are off.

(4) **NOSE sw**

This switch turns the taxi and takeoff lights on and off.

- TO : Turns on both taxi and takeoff lights.
- TAXI : Turns on only taxi light.
- OFF : Taxi and takeoff lights off.

*Note: These two lights, attached to the nose gear strut, go off automatically when landing gear is retracted.*

(5) **L and R LAND sel**

These selectors control the landing lights.

- ON : Extends the (left or right) landing lights which come on automatically when fully extended.
- OFF : Shuts off the landing lights which remain extended.
- RETRACT : Shuts off and retracts the landing lights.



(6) **RWY TURN OFF sw**

This switch turns the runway turn-off lights on and off.

*Note: These lights go off automatically when landing gear is retracted.*

(7) **STROBE sw**

This switch turns on and off the three synchronized strobe lights, one on each wing and one below the tail cone.

A blue light  below each strobe light allows to monitor the strobe light wear (LED technology). When STROBE sw is OFF or BEACON sw is ON, this light  flashes in blue if the strobe light replacement should be planned.

ON : The strobe lights flash white.

AUTO : The strobe lights come on automatically when the main landing gear is not compressed.

OFF : The strobe lights are off.

**MEMO DISPLAY**

**Applicable to: ALL**

Ident.: DSC-33-20-20-M-00016785.0001001 / 21 MAR 16

**LDG LT** : The message is displayed in green, if one landing light is extended.

Ident.: DSC-33-20-20-M-00016784.0001001 / 21 MAR 16

**STROBE LT OFF** : The message is displayed in green, if the STROBE sw is OFF in flight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### LIGHTS

EXTERIOR LIGHTING - CONTROLS AND INDICATORS


Intentionally left blank

**GENERAL**




Ident.: DSC-33-30-10-00017632.0024001 / 21 MAR 16

Applicable to: ALL


The emergency lighting system consists of the following:

- Proximity emergency escape path marking systems (escape path and exit markers)
- Overhead emergency lights
- EXIT signs
- Lavatory auxiliary lights
- Overwing escape route  lighting
- Escape slide lighting.

When in operation:

- The proximity emergency escape path marking system is powered by internal batteries for at least 12 min.
- The DC SHED ESS BUS supplies the cabin emergency lighting.
- If DC SHED ESS BUS fails, batteries inside the light provides power to cabin emergency lighting.
- In nominal case, the DC SHED ESS BUS charges these internal batteries if:
  - The EMER LT sw is not at ON
  - The EMER pb on the Purser's panel is not pressed
  - The DC BUS 1 is supplied
  - Depending on the CIDS/CAM programming, when:
    - The NO SMOKING sw , or
    - The NO PORTABLE ELEC DEVICE sw , or
    - The EXIT sw  is set to OFF or AUTO when the landing gear is retracted.


Lavatory auxiliary lights are always on. They are supplied by 28 V DC ESS BUS.

The escape slides have an integral lighting system. The escape slide lights and overwing escape route  lights come on automatically when the slide is armed and the door or emergency exit is open. They are supplied by internal batteries.

**PROXIMITY EMERGENCY ESCAPE PATH MARKING SYSTEM/EXIT SIGNS**

Ident.: DSC-33-30-10-00017646.0013001 / 21 MAR 16

Applicable to: ALL






**CONTROLS AND INDICATORS**

Ident.: DSC-33-30-20-00017708.0027001 / 21 MAR 16

Applicable to: ALL



(1) EMER EXIT LT sw

The EMER EXIT LT sw can have one of the following configuration:



ON : Overhead emergency lights, EXIT signs and proximity marking system come on.

OFF : Above lights are off.

- ARM :
- Exit markers come on when the normal aircraft electrical power or DC SHED ESS BUS is lost.
  - The overhead emergency lights come on if:
    - Normal aircraft electrical power system fails or
    - DC SHED ESS BUS fails or
    - AC BUS 1 fails.
  - Exit signs come on if:
    - Normal aircraft electrical power system fails or
    - DC SHED ESS BUS fails or

*Note: The LIGHT EMER pb on the Purser's panel can turn on the emergency lighting regardless of the position of the EMER EXIT LT sw.*

(2) EMER EXIT LT-OFF It

OFF : The amber EMER EXIT LT-OFF It comes on when the EMER EXIT LT sw is set to OFF.


(3) LIGHT EMER pb

When pressed, this button performs the same function as the EMER EXIT LT sw when it is set to ON.

**OVERHEAD PANEL**




Ident.: DSC-33-40-10-00017709.0001001 / 21 MAR 16

Applicable to: ALL






The switches described below are installed on the SIGNS panel on the overhead panel.

The cabin signs consist of the following:

- A SEAT BELTS sw, and
- A NO SMOKING sw , or
- An EXIT sw , or
- A NO PORTABLE ELEC DEVICE sw .

The SEAT BELTS sw activates the FASTEN SEAT BELT and RETURN TO YOUR SEAT signs.


The NO SMOKING sw  or EXIT sw  activate the EXIT and NO SMOKING signs.

The NO PORTABLE ELEC DEVICE sw  activates the EXIT and NO MOBILE signs.

A low tone chime sounds (depending on CIDS/CAM programming) each time a sign goes on or off.


Each switch has 3 positions:



ON : Signs are on in the cabin

AUTO : Signs are on in the cabin when either landing gear is extended or flaps/slats are extended  
 (position 1, 2, 3, or FULL)

OFF : Signs are off in the cabin

Example of switches layout:



- Note:**
1. If the cabin altitude goes above 11 300 ft ( $\pm$  350 ft), the cabin lights (depending on CIDS/CAM programming) and all the cabin signs, except the NO PORTABLE ELEC DEVICE signs  come on regardless of switches position.
  2. For NON SMOKER , the NO SMOKING signs are always on.

### MEMO DISPLAY

Ident.: DSC-33-40-10-00016783.0001001 / 21 MAR 16

Applicable to: **ALL**

When the corresponding signs are on, the ECAM displays in green the **SEAT BELTS** message, the **NO SMOKING** message or the **NO PED**, depending on aircraft customization.

# **AIRCRAFT SYSTEMS**

NAVIGATION

Intentionally left blank

**DSC-34-NAV-10 ADIRS**

DSC-34-NAV-10-10 Description

General.....	A
Probes Location.....	B
Probes Schematic.....	C
ADIRS Schematic.....	D

DSC-34-NAV-10-20 Controls and Indicators

Overhead Panel.....	A
Pedestal.....	B
Memo Display.....	C
Maximum Differences Between Speed/Mach Indications.....	D

**DSC-34-NAV-15 GPS**

DSC-34-NAV-15-10 Description

Description.....	A
------------------	---

**DSC-34-NAV-20 Standby Instruments**



Compass.....	A
Description of the ISIS.....	B
Attitude.....	C
Airspeed.....	D
Altimeter.....	E
Landing System Function.....	F
Bugs Function.....	G
Flags.....	H

**DSC-34-NAV-30 Radio Nav**

DSC-34-NAV-30-10 Tuning

General.....	A
Architecture.....	B


DSC-34-NAV-30-20 Nav aids

VOR.....	A
ILS/GLS  /MLS  .....	B
ADF  .....	C
DME.....	D
Marker Beacon.....	E

*Continued on the following page*

*Continued from the previous page*

**DSC-34-NAV-30-30 Controls and Indicators**


Digital Distance and Radio Magnetic Indicator  (DDRMI)..... A  
Radio Management Panel (RMP)..... B

**DSC-34-NAV-40 Radio Altimeter**

**DSC-34-NAV-40-10 Description**

General..... A  
Automatic Callout..... B



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>NAVIGATION</b> ADIRS - DESCRIPTION</p>
---	--

**GENERAL**

Ident.: DSC-34-NAV-10-10-00018524.0001001 / 21 MAR 16

**Applicable to: ALL**

The Air Data and Inertial Reference System (ADIRS ) supplies temperature, anemometric, barometric and inertial parameters to the EFIS system (PFD and ND ) and to other user systems (FMGC , FADEC , ELAC , SEC , FAC , FWC , SFCC , ATC , GPWS , CFDIU , CPC).

The system includes:

- Three identical ADIRUs (Air Data and Inertial Reference Units).

Each ADIRU is divided in two parts, either of which can work separately in case of failure in the other:

- The ADR part (Air Data Reference) which supplies barometric altitude, airspeed, Mach, angle of attack, temperature and overspeed warnings.
- The IR part (Inertial Reference) which supplies attitude, flight path vector, track, heading, accelerations, angular rates, ground speed and aircraft position.

- One ADIRS control panel on the overhead panel for selection of modes (NAV , ATT, OFF) and indications of failures.

- Four types of sensors:

- Pitot probes (3)
- Static pressure probes (STAT) (6)
- Angle of attack sensors (AOA) (3)
- Total air temperature probes (TAT) (2)


These sensors are electrically heated to prevent from icing up.

- Eight ADM s (Air Data Modules) which convert pneumatic data from PITOT and STAT probes into numerical data for the ADIRUs.
- A switching facility for selecting ADR 3 or IR 3 for instrument displays in case of ADIRU1 or 2 failure.

**PROBES LOCATION**

Ident.: DSC-34-NAV-10-10-00018525.0001001 / 21 MAR 16


Applicable to: ALL



**PROBES SCHEMATIC**

Ident.: DSC-34-NAV-10-10-00018526.0001001 / 21 MAR 16

Applicable to: ALL




**Note:** ADIRU (1) is supplied by CAPT probes,  
ADIRU (2) is supplied by F/O probes,  
ADIRU (3) is supplied by STBY probes and CAPT TAT.

**ADIRS SCHEMATIC**

Ident.: DSC-34-NAV-10-10-00018527.0001001 / 21 MAR 16


Applicable to: **ALL**



**OVERHEAD PANEL**

Ident.: DSC-34-NAV-10-20-00018528.0002001 / 21 MAR 16

Applicable to: ALL



(1) ADR 1(2)(3) pb sw

OFF light : Air data output disconnected.

FAULT light : This amber light comes on with an ECAM caution if a fault is detected in the air data reference part.

(2) IR 1(2)(3) pb sw

OFF light : Inertial data output disconnected.

FAULT light : This amber light comes on with an ECAM caution when a fault affects the respective IR.

Steady : the respective IR is lost.

Flashing : the attitude and heading information may be recovered in ATT mode.

(3) IR 1(2)(3) mode rotary sel

OFF : The ADIRU is not energized.

ADR and IR data are not available.

- NAV : Normal mode of operation.  
 Supplies full inertial data to aircraft systems.
- ATT : IR mode supplying only attitude and heading information if the system loses its ability to navigate.  
 The heading must be entered through the MCDU and has to be reset frequently (about every 10 min).

**(4) ON BAT light**

The ON BAT light comes on in amber when the aircraft battery supplies at least one IRS . The ON BAT light also comes on for a few seconds at the beginning of a complete IRS alignment. The light does not come on in the case of a fast alignment.


*Note: When the aircraft is on ground and if at least one ADIRU is supplied by aircraft batteries:*

- An external horn sounds
- The ADIRU and AVNCS light comes on amber on the EXTERNAL POWER panel.

**PEDESTAL**


Ident.: DSC-34-NAV-10-20-00018529.0001001 / 21 MAR 16

Applicable to: ALL



**(1) ATT HDG and AIR DATA sel**

- NORM : ADIRU 1 supplies data to PFD 1, ND 1, DDRMI and VOR /DME.  
 ADIRU 2 supplies data to PFD 2, and ND2.
- CAPT 3 : ADR 3 or IR 3 replaces ADR 1 or IR1.
- F/O 3 : ADR 3 or IR 3 replaces ADR 2 or IR2.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>NAVIGATION</b> ADIRS - CONTROLS AND INDICATORS
---	---

**MEMO DISPLAY**

**Applicable to: ALL**  
 Ident.: DSC-34-NAV-10-20-A-00017043.0002001 / 21 MAR 16

**IR IN ATT ALIGN** : This memo appears in green during the IR alignment in Attitude mode.

Ident.: DSC-34-NAV-10-20-A-00017041.0002001 / 21 MAR 16

The memo "IRS IN ALIGN X MN" appears during IRS alignment in flight phase 1 or 2. X MN indicates the number of remaining minutes (1 < X < 10), until NAV mode is reached.

Before any engine is started:

**IRS IN ALIGN X MN** : This memo appears in green when at least one active IRS is being aligned.


**IRS IN ALIGN X MN** : This memo pulses in green, if the alignment of one IRS is faulty.


When one engine is started:

**IRS IN ALIGN X MN** : This memo appears in amber during IRS alignment. If the alignment of one IRS is faulty, this memo is replaced by the "IR NOT ALIGNED" ECAM caution.

**MAXIMUM DIFFERENCES BETWEEN SPEED/MACH INDICATIONS**

Ident.: DSC-34-NAV-10-20-00021130.0002001 / 17 MAR 17  
**Applicable to: ALL**

FL	SPEED	SPEED/MACH COMPARISON BETWEEN					
		ADR 1 and ADR 2 (on PFD)		ADR 3 and ADR 1, or ADR 3 and ADR2		Standby Airspeed Indicator and any ADR 1, or 2, or 3	
		kt	Mach	kt	Mach	kt	Mach on ISIS  (1)
GND CHECK	-	6 kt	M 0.008	6 kt	M 0.008	6 kt	-
FL 50	250 kt	4 kt	M 0.005	4 kt	M 0.007	7 kt	-
FL 100	250 kt	4 kt	M 0.005	5 kt	M 0.008	8 kt	M 0.032
FL 200	300 kt	3 kt	M 0.007	5 kt	M 0.011	9 kt	M 0.033
FL 300	M 0.78	3 kt	M 0.010	5 kt	M 0.014	9 kt	M 0.025
FL 390	M 0.78	3 kt	M 0.010	4 kt	M 0.014	8 kt	M 0.025

(1) Mach values lower than M 0.50 in climb, and M 0.45 in descent, are not displayed on ISIS  .



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**AIRCRAFT SYSTEMS**

**NAVIGATION**

ADIRS - CONTROLS AND INDICATORS

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>NAVIGATION</b></p> <p align="center">GPS - DESCRIPTION</p>
---	---

<b>DESCRIPTION</b>
--------------------

Ident.: DSC-34-NAV-15-10-00018530.0001001 / 21 MAR 16


**Applicable to: ALL**

The Global Positioning System (GPS) is a satellite-based radio navigation aid. Worldwide, 24 satellites broadcast accurate navigation data that the aircraft use for precise determination of its position.

The aircraft has two independent GPS receivers. Depending of the aircraft configuration, each receiver consists:

- Of a GPS Sensor Unit (GPSSU), or
- Is integrated in the Multi Mode Receiver (MMR ). The GPS 1 receiver in MMR 1, and the GPS 2 receiver in MMR2.

The GPSSU or the MMR processes the received data, and transfers them to the ADIRU s. Then each ADIRU performs the GP-IRS hybrid position calculation. FMGCs use this hybrid position.



## **OPERATIONS**

GPS information are available on the FMS – GPS Monitor Page. *Refer to DSC-22\_20-50-10 Pages descriptions.*

- During normal operations  
The GPS receiver 1 supplies the ADIRU 1 and the ADIRU 3, and the GPS receiver 2 supplies the ADIRU 2.
- In case of failure of one GPS receiver  
All ADIRU s use the operative GPS receiver.
- In case of failure of ADIRUs
  - If the ADIRU 1 fails, ADIRU 3 is supplied by the GPS receiver 1, and ADIRU 2 is supplied by the GPS receiver 2.
  - If the ADIRU 2 fails, the ATT HDG selector has to be set to F/O 3 in order to maintain Side 1 and Side 2 segregation. In this case, the ADIRU 3 will be supplied with GPS receiver 2.
  - If two ADIRU s fail, the remaining ADIRU is supplied by its own side GPS receiver.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**NAVIGATION**

GPS - DESCRIPTION

Intentionally left blank


**COMPASS**

Ident.: DSC-34-NAV-20-00001367.0001001 / 19 DEC 12

Applicable to: ALL

There is a compass located on top of the windshield center post.  
The deviation card is located above the compass.

Note: Because of the location of the APU power on contactor in the cockpit, the APU start sequence may disturb the compass reading.



**DESCRIPTION OF THE ISIS**


Ident.: DSC-34-NAV-20-00018543.0002001 / 21 MAR 16

Applicable to: ALL

**GENERAL**

The ISIS system displays the following information:

- Attitude
- Airspeed and mach
- Altitude
- Barometric pressure
- LS function
- Bugs




(1) "+" / "-" activation pushbuttons

Two pushbuttons labelled "+" and "-" are used to adjust the level of brightness. The brightness of the screen automatically adjusts after power-up tests. This is because of the photosensitive cell located on the surface of the ISIS system display. The "+" and "-" pushbuttons then allow this initial brightness to be manually adjusted and changed.

*Note:* The system must be reset after 350 h of continuous electrical supply using the « ATT RST » pushbutton.

**ARCHITECTURE**




**ATTITUDE**

Ident.: DSC-34-NAV-20-00018575.0002001 / 21 MAR 16

Applicable to: ALL

*Note: When leveling the wings after performing a small turn of a small bank angle, the displayed roll attitude may temporarily be incorrect by a few degrees.*



- (1) Fixed aircraft symbol  
 The fixed aircraft symbol is in black, and outlined in yellow.  
 Depending of the aircraft configuration, the center of the fixed aircraft symbol is a point (like on the illustration above) or "V-bars".
- (2) Roll scale  
 The roll scale is in white.  
 The markers are at 0 (small yellow triangle), 10, 20, 30, 45, 60 ° of bank.
- (3) Roll index  
 The roll index is in black, and outlined in white. It indicates the bank angle.
- (4) Lateral acceleration index  
 The trapezoidal index moves beneath the roll index. It represents the aircraft's lateral acceleration.
- (5) Pitch scale  
 The pitch scale is in white. The scale shows markers every 2.5 ° between 30 ° nose up and 30 ° nose down. Beyond 30 °, large red arrowheads (V-shaped) indicate that the attitude has become excessive, and show the direction to follow in order to reduce it. The minimum pitch scale displayed is -17.5 ° +15 ° at 0 ° pitch.


(6) ATT RST

The attitude indication can be reset by pressing this pushbutton for at least 2 s. The aircraft must be level during this procedure. During the reset time (approximately 10 s), the “ATT 10 s” message is displayed on the screen. This pushbutton is also used to realign the system, if excessive aircraft movement is detected during the alignment phase.

**AIRSPEED**

Ident.: DSC-34-NAV-20-00018576.0002001 / 21 MAR 16

Applicable to: **ALL**



(1) Airspeed scale

A white scale moves in front of a yellow triangle indicating the airspeed. The scale ranges from 5 to 250 kt, with a mark every 5 kt, and from 250 to 520 kt, with a mark every 10 kt.

(2) Mach Number

The Mach number is displayed in green it goes greater than 0.5. And it disappears only when it goes below 0.45.

(3) Speed bug


When a speed bug is entered via the BUGS function, the corresponding speed mark is indicated by a cyan dash.



**ALTIMETER**

Ident.: DSC-34-NAV-20-00018577.0002001 / 21 MAR 16

Applicable to: ALL



(1) Altitude indication

The altitude indication is given as a white moving scale, and a green digital readout on a gray background.

The altitude scale ranges from -2 000 to 50 000 ft every 100 ft, with altitude digital indications every 500 ft.

For negative altitudes, "NEG" appears in the window in white.

The altitude box changes to cyan, when it also corresponds to a bug value.

Depending of the aircraft configuration, the altitude in meters is displayed above the altitude scale.

(2) Barometric reference

The barometric reference pressure is displayed in cyan.

The displayed barometric reference is:

- The standard barometric reference "STD", or
- Depending of the aircraft configuration, the barometric pressure is "hPa" or "hPa/ inHg".

(3) Barometric selection knob

This knob enables the selection of a barometric pressure, setting a variation of 10 hPa per knob rotation.

The standard barometric pressure can be selected by pressing the barometric knob. "STD" is then displayed, in place of the pressure value.

Pressing the knob again will display the selected barometric pressure.


(4) Altitude bug

When an altitude bug is entered through the bugs function, the corresponding altitude mark is indicated by a cyan dash, or by a cyan box when the dash covers the digital indication on the scale.

**LANDING SYSTEM FUNCTION**

Ident.: DSC-34-NAV-20-00001377.0005001 / 22 JUL 14

Applicable to: **ALL**



(1) Localizer / scale and index

(2) Glideslope / scale and index

When the LS pb is pressed, the deviation scales are displayed.

When deviation scales are displayed and the LS deviations are valid, the indexes appear.

The LS deviations that are displayed correspond to the LS approach:

- Selected on the MCDU, or
- Tuned on the RMP.

**Note:** *The LS approach corresponds to either ILS approach, or MLS approach, or GLS approach, or non precision approach using FLS.*

(3) LS selection pushbutton


Pressing the LS pb will display the LS scales. Pressing the LS pb again will remove the LS scales.

**CAUTION** Do not use the ISIS LS for takeoff using the localizer of the opposite runway, or for a back-course localizer approach. The LOC deviations are given in the wrong sense.

**BUGS FUNCTION**

Ident.: DSC-34-NAV-20-00018578.0001001 / 21 MAR 16

Applicable to: ALL




- (1) BUGS function selection pushbutton  
 Pressing the BUGS pushbutton will activate the BUGS function and display the bug values to be selected.
- (2) SPD BUG and ALT BUG columns  
 The SPD BUG column gives four speed values (in knots) that can be selected by the crew.  
 The ALT BUG column gives two altitude values (feet) to be selected by the crew.
- (3) BUGS value selection knob  
 It allows the bug value to be set by rotating the BARO knob. This value cannot be lower than 30 kt for a speed bug, or a negative value for an altitude bug.  
 Pressing the BARO setting knob, once a bug value box is activated, will deselect the bug value. The "OFF" label comes on close to the activated box.  
 The entered values are memorized by the system, when exiting the screen, by pressing the BUGS pushbutton (1), or after 15 s without any pilot action.
- (4) "+" / "-" box activation buttons  
 Access from one box to another is obtained by pressing the "+" or "-" pushbutton.  
 When a bug value is entered, access to the next box is obtained by pressing the "-" pushbutton. The box becomes active and flashes.  
 The "+" pushbutton can be used to return to a previous box.

*Note: Use of the ISIS bugs function is not recommended because, in the event that both PFDs are lost in flight, when the ISIS bugs were previously set for takeoff, then for the approach, the bugs would remain at the takeoff characteristic speed settings.*

**FLAGS**

Ident.: DSC-34-NAV-20-00018580.0002001 / 21 MAR 16

Applicable to: **ALL**



- (1) ATT flag (red)  
 When attitude data is lost, the red ATT flag appears.
- (2) SPD flag (red)  
 When airspeed data is lost, the red SPD flag appears.
- (3) M flag (red)  
 When mach number is lost, the red M flag appears.
- (4) ALT flag (red)  
 When altitude data is lost, the red ALT flag appears.

- (5) G/S flag (red)  
When glideslope information is lost, the red G/S flag appears.
- (6) LOC flag (red)  
When localizer data is lost, the red LOC flag appears.
- (7) ATT: RST (yellow)  
The “ATT: RST” flag appears:  
- When excessive aircraft movement is detected during the alignment phase, or  
- After 350 h of continuous electrical supply, or  
- When the “WAIT ATT” flag is displayed during more than 10 s.  
In both cases, press the ATT RST pb to reset/realign and recover the attitude indication.
- (8) MAINT flag (white)  
Maintenance required. This “MAINT flag” does not affect ISIS operation.  
Displayed only on ground phase (speed < 60 kt).
- (9) OUT OF ORDER (white)  
When an internal failure of the ISIS indicator occurs, the “OUT OF ORDER” message appears, accompanied by a fault code.
- (10) WAIT ATT flag (yellow)  
If the ISIS loses attitude data, its entire sphere is cleared to display the: “WAIT ATT” flag.  
- If the “WAIT ATT” flag is displayed during less than 10 s, a normal operation is recovered.  
- If attitude data are lost for more than 10 s, the “WAIT ATT” flag is then replaced by the “ATT: RST” flag.
- (11) ATT 10 s flag (yellow)  
This count down flag appears, when the flight crew press the ATT RST pb, in order to indicate that the attitude reset function is in progress.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**NAVIGATION**

**STANDBY INSTRUMENTS**

Intentionally left blank

**GENERAL**

Ident.: DSC-34-NAV-30-10-00018581.0001001 / 21 MAR 16

Applicable to: ALL

Three modes of tuning are available.

**1. Automatic Tuning**

This is the basic means for tuning nav aids.

In normal operation, the FMGC tunes nav aids automatically, with each FMGC controlling its own receivers.

If one FMGC fails, the remaining FMGC controls both sides receivers.

**2. Manual Tuning**

The flight crew can use the MCDU to override the automatic tuning of nav aids by FMGC in order to select a specific nav aid for visual display.

This does not affect the automatic function of the FMGC.




Any entry on one MCDU is sent to both FMGC in dual mode, or the remaining FMGC in single mode.

**3. Back Up Tuning**

If both FMGC s fail, the flight crew can use the RMPs (Radio Management Panels 1 and 2) on the pedestal for back up tuning.

The CAPT RMP controls VOR1 and ADF 1 .

The F/O RMP controls VOR2 and ADF 2 .


Either RMP controls ILS /GLS  / MLS , provided "STBY NAV" is selected on RMP 1 and RMP2. RMP3  is not used for nav aids tuning.

**ARCHITECTURE**

Ident.: DSC-34-NAV-30-10-00018582.0001001 / 21 MAR 16


Applicable to: ALL

**NORMAL OPERATION**







**FMGC 1 FAILURE**



**BACK UP TUNING**





 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>NAVIGATION</b> RADIO NAV - NAVAIDS
---	---

**VOR**

Ident.: DSC-34-NAV-30-20-00018657.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has two VOR receivers.







- The Navigation Displays (ND s) display VOR 1 and VOR 2 information, in accordance with the position of the ADF  /VOR selectors on the EFIS control panel (*Refer to DSC-31-45 ROSE Modes*).
- The DDRMI  also displays VOR 1 and VOR2 bearings, if the heading signal is valid.









**ILS/GLS  /MLS **

Ident.: DSC-34-NAV-30-20-00018658.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has two ILS /GLS  /MLS  receivers.

Note: *When the aircraft is equipped with MMR s, ILS and GLS  and MLS  receivers are in the MMR s (ILS 1/GLS1  /MLS1  in the MMR 1 and the ILS 2/GLS2  /MLS2  in the MMR2)*

- PFD 1 and ND 2 display ILS1/GLS1  /MLS1  information.
- PFD 2 and ND 1 display ILS2/GLS2  /MLS2  information.
- The PFD display the ILS /GLS  /MLS  information if the flight crew press the LS pb or ILS pb (depending of the aircraft configuration) on the EFIS control panel (*Refer to DSC-31-50 EFIS Control Panel*).
- The ND s display the ILS /GLS  /MLS  information if the flight crew selects the ROSE LS mode or the ROSE ILS mode (depending of the aircraft configuration) on the EFIS control panel (*Refer to DSC-31-50 EFIS Control Panel*).





**ADF **

Ident.: DSC-34-NAV-30-20-00018659.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft may be fitted with 1 ADF  or 2 ADF .

The ND s display ADF  information, depending on the position of the ADF /VOR selectors on the EFIS control panel (*Refer to DSC-31-45 ROSE Modes*).

The DDRMI  also displays ADF 1  and ADF 2  bearings, depending on the position of the ADF /VOR selector on the DDRMI .



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### NAVIGATION



RADIO NAV - NAVAIDS

### DME



Ident.: DSC-34-NAV-30-20-00018660.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has two DMEs.

The frequency that is automatically set on the DME corresponds to the frequency/channel that is set on the VOR, or ILS, or GLS , or MLS .

The NDs and the DDRMI  can display DME information associated with VOR.

The PFDs can display DME information associated with ILS/GLS /MLS  (*Refer to DSC-31-40 Trajectory Deviation - ILS Approach*).

### MARKER BEACON

Ident.: DSC-34-NAV-30-20-00001389.0001001 / 21 MAR 16

**Applicable to: ALL**


One marker beacon system is included in VOR receiver 1.

The PFD displays the outer, middle, and inner marker signals (*Refer to DSC-31-40 Trajectory Deviation - ILS Approach*).

**DIGITAL DISTANCE AND RADIO MAGNETIC INDICATOR  (DDRMI)**

Ident.: DSC-34-NAV-30-30-00018583.0001001 / 21 MAR 16

Applicable to: ALL





(1) Compass card

ADIRU1 normally supplies the signal that positions the compass card.

ADIRU 3 supplies this signal when selected by the ATT HDG SWITCHING selector.

(2) Bearings pointers

Indicate the magnetic bearing to the station received by VOR 1 or ADF 1  (dashed pointer) and VOR2 or ADF 2  (double pointer).

*Note:* Depending on the quality of the VOR beacon's signal, and mainly at distances greater than 25 NM from the station, the processing of the signal, on aircraft equipped with COLLINS or BENDIX VOR may lead to bearing pointer oscillations.

(3) DME1(2) counters

Indicates distance in nautical miles to/from DME station.



The counters indicate distances:


- in NM when the station is at more than 20 NM
- 1/10th of NM when the station is at less than 20 NM.

When the station is at less than 1 NM, 0 is shown.


The DME 1 and DME2 display are blanked or dashed when a fault is detected or data invalid.

(4) VOR/ADF selector 

- VOR1 or ADF 1  on the dashed pointer.
- VOR 2 or ADF 2  on the double pointer (if ADF 2 is not installed, then ADF1 may be selected).

The DDRMI  has also VOR /ADF flags and HDG flags when the associated information is not available.

The indicators display these flags if:

- The VOR or ADF receiver fails (associated to the VOR /ADF flag only)
- The DDRMI  has an internal failure
- The heading signal from ADIRS is not valid
- The power supply fails.

As long as the VOR /ADF flag is shown, and depending of the aircraft configuration, the associated bearing pointer remains:

- At the last valid position, or
- Into the horizontal line.

## RADIO MANAGEMENT PANEL (RMP)

Ident.: DSC-34-NAV-30-30-00018584.0001001 / 21 MAR 16

Applicable to: ALL



(1) ON/OFF sw

This switch controls the power supply to the panel.

(2) NAV key (transparent switchguard)

- Pressing this key engages the radio navigation backup mode. It takes control of the VOR , ILS , GLS <img alt="ILS symbol" data-bbox="308 235 325 252"/>, MLS <img alt="MLS symbol" data-bbox="395 235 412 252"/>, and ADF <img alt="ADF symbol" data-bbox="505 235 522 252"/>, receivers away from the FMGC and gives it to the RMP.
- The green monitor light comes on.
- Pressing the NAV key a second time returns control of the navigation radios to the FMGC.

*Note:* - The flight crew must select this backup tuning mode on both RMP 1 and RMP 2 if both FMGC s or both MCDU s fail. In the emergency electrical configuration, only RMP1 receives power

- Pressing the NAV key on RMP3 <img alt="RMP3 symbol" data-bbox="585 375 602 392"/>, has no effect
- In the NAV backup mode, the flight crew can select radio communication systems as it would in the normal mode.  
 Setting one RMP to NAV backup mode removes nav aids tuning from both FMGCs.
- When the flight crew uses an RMP to tune an ILS /DME or GLS <img alt="GLS symbol" data-bbox="845 470 862 487"/>, /DME or MLS <img alt="MLS symbol" data-bbox="308 485 325 502"/>, /DME , the PFD s do not display the DME distance.

(3) STBY NAV keys

When the NAV key is on and the flight crew presses one of these STBY NAV keys, the ACTIVE window displays the frequency/channel to which that receiver is tuned. The green monitor light on the selected key comes on, and the one on the previously selected STBY NAV or COM key goes out.

(4) Frequency/channel selector knob

Two concentric knobs allow the flight crew to preselect frequencies/channels for communication radios and stand-by navigation systems and select courses for VOR , ILS , GLS <img alt="GLS symbol" data-bbox="255 688 272 705"/>, and MLS <img alt="MLS symbol" data-bbox="365 688 382 705"/>.

The desired frequency, channel or course is set in the STBY/CRS window.

The outer and the inner knobs set a frequency/channel: the outer knob controls the most significant digits, the inner knob controls the least significant digits. A rate multiplier speeds up the tuning when the knob is rotated quickly.

The inner knob only sets a course.

(5) Transfer key

The flight crew presses this key to interchange ACTIVE and STBY frequencies/channels. This action tunes the selected receiver to the new ACTIVE frequency/channel.

(6) STBY /CRS window

The flight crew can make the displayed frequency /channel by rotating the tuning knob. The frequency/channel displayed in the window becomes the active frequency/channel when the flight crew presses the Transfer Key.

If this window displays a course, then the ACTIVE window displays the associated frequency/channel.

*Note: If the STBY /CRS window is displaying a course, then pressing the transfer key displays the active frequency/channel in both windows.*




(7) ACTIVE window

This window displays the frequency/channel of the selected navaid, which is identified by a green monitor light on the selection key.

(8) LOAD FUNCTION 

The flight crew can load the VHF frequency from the CPDLC CONTACT/MONITOR messages to the STBY/CRS window.

(9) BFO key 

If the ADF  is selected, pressing this key activates the BFO (Beat Frequency Oscillator). For most ADF, with BFO activated, the audio identification is heard. However there are some ADF where the BFO must be deactivated in order to hear the audio identification.





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**NAVIGATION**

**RADIO ALTIMETER - DESCRIPTION**

**GENERAL**

Ident.: DSC-34-NAV-40-10-00018585.0001001 / 21 MAR 16

Applicable to: ALL

The aircraft has two radio altimeters (RA).  
 CAPT PFD displays the RA 1 height, and the F/Os PFD displays the RA2 height.  
 If one RA fails, both PFD s display the height from the remaining RA.  
 For indication on the PFD, *Refer to DSC-31-40 Altitude (CONT'D)*.

**AUTOMATIC CALLOUT**

Ident.: DSC-34-NAV-40-10-00018656.0001001 / 21 MAR 16

Applicable to: ALL

**GENERAL**

The FWC generates a synthetic voice for radio height announcement below 2 500 ft. These announcements come through the cockpit loudspeakers, even if the speakers are turned off.

**PREDETERMINED CALL OUT**

The altitude call out uses the following predetermined threshold:

Height (feet)	Call out
2 500	TWO THOUSAND FIVE HUNDRED OR TWENTY FIVE HUNDRED
2 000	TWO THOUSAND
1 000	ONE THOUSAND
500	FIVE HUNDRED
400	FOUR HUNDRED
300	THREE HUNDRED
200	TWO HUNDRED
115	STANDBY <sup>(1)</sup>
100	ONE HUNDRED
90	STANDBY <sup>(1)</sup>
65	FLARE <sup>(1)</sup>
50	FIFTY
40	FORTY
30	THIRTY
20	TWENTY
10	TEN
5	FIVE
DH (or MDA /MDH) + 100	HUNDRED ABOVE
DH (or MDA /MDH)	MINIMUM

<sup>(1)</sup> These callouts are triggered only if the Steep Approach and Landing function  is active. In this case, the "ONE HUNDRED" callout is inhibited.

*Note: The reference altitude for callouts is the radio height for precision approaches (DH), and baro altitude (MDA /MDH) for non precision approaches.*

Pin programming enables Operators to select the required callouts. If the aircraft remains at a height that is in the detection zone for a height callout, the corresponding message is repeated at regular intervals.

### **INTERMEDIATE CALL OUT**

If time between two consecutive predetermined call outs exceeds a certain threshold, the present height is repeated at regular intervals.

The threshold is:

- 11 s above 50 ft
- 4 s below 50 ft

The repeating interval is 4 s.

### **RETARD ANNOUNCEMENT**

The loudspeaker announces RETARD at:

- 20 ft, or
- at 10 ft if autothrust is active and one autopilot is in LAND mode.

# **AIRCRAFT SYSTEMS**

SURVEILLANCE

Intentionally left blank

**DSC-34-SURV-10 ATC**

DSC-34-SURV-10-10 Description

Principle.....A

DSC-34-SURV-10-20 Controls and Indicators

Control Panels.....A

**DSC-34-SURV-30 Weather Radar**

DSC-34-SURV-30-10 Description

Description.....A

DSC-34-SURV-30-20 Predictive Windshear System

General.....A

Windshear Alerts During Takeoff Roll, Up to 100 knots.....B

Windshear Alerts Above 50 feet.....C

Windshear Alerts Inhibition.....D

DSC-34-SURV-30-30 Controls and Indicators

Control Panel.....A

Weather Radar indication on ND.....B

PWS  indication on PFD and ND .....C

Memo Display.....D

**DSC-34-SURV-40 GPWS**

DSC-34-SURV-40-10 Description

Overview.....A

Principle.....B

DSC-34-SURV-40-20 GPWS Basics Modes

Mode 1 : Excessive Rate of Descent.....A

Mode 2 : Excessive Terrain Closure Rate.....B

Mode 3 : Altitude Loss After Takeoff.....C

Mode 4 : Unsafe Terrain Clearance when Not in Landing Configuration.....D

Mode 5 : Descent Below Glideslope.....E

DSC-34-SURV-40-35 Predictive GPWS Functions

Terrain Awareness and Display.....A

Terrain Caution and Warning Envelope.....B

Terrain Clearance Floor.....C

Runway Field Clearance Floor.....D

*Continued on the following page*

*Continued from the previous page*

**DSC-34-SURV-40-40 Controls and Indicators**

Overhead Panel.....	A
Instrument Panels.....	B
Memo Display.....	C

**DSC-34-SURV-60 TCAS**

**DSC-34-SURV-60-10 Description**

Overview.....	A
Principle.....	B
Main Components.....	C
Intruder Detection Categories.....	D
TCAS Modes.....	E
Advisory Inhibition.....	F

**DSC-34-SURV-60-20 Controls and Indicators**

ATC/TCAS Panel.....	A
ND Indications.....	B
TCAS Messages.....	C
PFD Indications.....	D
Aural Messages.....	E
Memo Display.....	F

**PRINCIPLE**

Ident.: DSC-34-SURV-10-10-00020602.0002001 / 17 MAR 17


Applicable to: ALL

The aircraft has two ATC transponders (XPDR) which are controlled by a control panel (ATC /TCAS) on the center pedestal.

Only the selected XPDR operates.

The XPDR automatically responds to requests:

- From the ATC, to ensure effective air traffic surveillance
- From other aircraft that have a TCAS, to ensure that traffic alerts are triggered.



The XPDR is capable of elementary surveillance (ELS) and enhanced surveillance (EHS). It transmits the following data to the ATC center:

- The aircraft 24 bit address, the aircraft altitude, the flight number, the RA report
- The indicated airspeed, the Mach number, and the barometric vertical speed that are all supplied by the ADRs
- The magnetic heading, the roll angle, the ground speed, the track angle, the track angle rate, and the inertial vertical speed, that are all supplied by the IRs
- The selected altitude and barometric reference settings supplied by the FCUs.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**SURVEILLANCE**

ATC - DESCRIPTION


Intentionally left blank



**CONTROL PANELS**

Ident.: DSC-34-SURV-10-20-00020607.0012001 / 17 MAR 17

Applicable to: ALL



- (1) XPDR Selector  
 Selects XPDR 1 or 2.
- (2) IDENT Switch  
 The flight crew presses this button to send the aircraft identification signal.
- (3) Keypad  
 The flight crew uses these key to set the code assigned by ATC.
- (4) Code Display  
 The window displays the selected code.
- (5) ATC FAIL Light  
 This light comes on if the selected XPDR fails.
- (6) Mode Selector  
 STBY : Both XPDR and TCAS are electrically-supplied, but are on standby.  
 ALT RPTG : No altitude data is transmitted.  
 OFF

- XPNDR : In flight : Selected XPDR operates in all modes.  
Baro altitude data is transmitted.  
ATC 1 uses ADR 1 or ADR 3. ATC 2 uses ADR 2 or ADR 3.  
The TCAS is on standby.
- XPNDR : On ground : Selected XPDR only operates in mode S (Selective aircraft interrogation mode).
- TA-RA/TA : *Refer to DSC-34-SURV-60-20 ATC/TCAS Panel.*

(7) CLR Key




The flight crew uses this key to clear the code display.

Note: *As long as the four figures of the new code are not entirely written, the previous code remains.*

**DESCRIPTION**

Ident.: DSC-34-SURV-30-10-00014867.0002001 / 22 MAR 17

**Applicable to: ALL**

The aircraft is fitted with one or two  Multiscan weather radar systems with a Predictive WindShear (PWS ) function and a weather hazard prediction function .

The flight crew can display weather data on the CAPT and/or F/O NDs in either ARC or ROSE mode.

The flight crew can adjust the brightness of the weather image on the ND thanks the outer knob of the ND Brightness Control knob (*Refer to DSC-31-50 Other EFIS Controls*).

Note: *A low brightness setting of the weather display may reduce the visibility of weather data, and therefore reduce crew awareness of the weather situation.*


The flight crew can use the radar in the following modes:

- Multiscan Automatic mode: MULTISCAN sw set to AUTO (recommended), or
- Manual mode: MULTISCAN sw set to MAN.

When in Multiscan Automatic mode:

- The radar alternatively scans at two antenna tilt settings. The weather radar image that is displayed is the result of the stored and combined information from each beam.
- When the gain selector is set to the Calibrated position (CAL), the radar automatically adjusts the gain based on various parameters (aircraft altitude, geographical area, season, time of the day) to obtain the best weather display.
- To prevent unnecessary clutter display, the “Quiet and Dark cockpit” philosophy removes the weather that:
  - is not on the aircraft flight path
  - is not a threat to the aircraft (post convective cell).
- The Ground Clutter Suppression (GCS ) function removes the ground returns from the ND.

Multiscan Principle



When in Manual mode:

- The flight crew can adjust manually the antenna tilt settings, and can adjust gain either automatically or manually using knobs located on the radar control panel
- The GCS function is not available
- When the gain selector is set to CAL, there is no automatic gain adjustment based on altitude, geographical area, season and time of the day.

As a consequence, when the flight crew switches from the Multiscan Automatic mode with CAL gain to the Manual mode with CAL gain, the weather displayed on the ND may be significantly different.

**GENERAL**

Ident.: DSC-34-SURV-30-200-00020942.0004001 / 17 MAR 17

**Applicable to: ALL**

The weather radar has a Predictive WindShear system (PWS ) that operates when the PWS switch is in the AUTO position , and the aircraft radio height is below 2 300 ft, and

- Weather radar is ON (Radar sw on position 1 or 2), or
- Weather radar is OFF, and
  - At least one engine is running, and
  - Aircraft ground speed is greater than 30 kt, or
  - Aircraft longitudinal acceleration is above a given threshold during at least 0.5 s.

*Note:* If two weather radars are installed, when the selected weather radar fails, the flight crew can recover the PWS function by selecting the operative system on the Radar sw of the radar control panel.

The system scans the airspace for windshear within a range of 5 NM ahead of the aircraft. When the system detects windshear, a windshear symbol appears on the ND (*Refer to DSC-34-SURV-30-30 PWS (if installed) indication on PFD and ND*).

Predictive windshear warnings and cautions are associated to an aural alert and to a red (warning) or amber (caution) "W/S AHEAD" message on the PFD , whereas windshear advisories are only displayed on the ND (*Refer to DSC-34-SURV-30-30 PWS (if installed) indication on PFD and ND*) without message on the PFD.


<b>Alert Level</b>	<b>Aural Warning</b>	<b>PFD</b>	<b>ND (<i>Refer to DSC-34-SURV-30-30 PWS (if installed) indication on PFD and ND</i>)</b>
Warning (Approach)	«GO AROUND WINDSHEAR AHEAD»	W/S AHEAD (red)	Windshear icon
Warning (Takeoff)	«WINDSHEAR AHEAD» (twice)	W/S AHEAD (red)	Windshear icon
Caution	«MONITOR RADAR DISPLAY»	W/S AHEAD (amber)	Windshear icon
Advisory	Nil	Nil	Windshear icon

**WINDSHEAR ALERTS DURING TAKEOFF ROLL, UP TO 100 KNOTS**

Ident.: DSC-34-SURV-30-20-00020944.0001001 / 17 MAR 17

Applicable to: ALL

Windshear Alerts During Takeoff Roll, Up to 100 knots



During the takeoff roll, up to 100 kt, both warnings and cautions are available within a range of 3 NM.


Note: This is also applicable during taxi when weather radar is set to ON.

**WINDSHEAR ALERTS ABOVE 50 FEET**

Ident.: DSC-34-SURV-30-20-00006422.0001001 / 12 APR 16

Applicable to: ALL

Windshear Alerts Above 50 feet



During final approach, the visual and aural warning alerts are downgraded to caution alerts between 370 ft AGL and 50 ft AGL, and range between 1.5 NM and 0.5 NM.

**WINDSHEAR ALERTS INHIBITION**

Ident.: DSC-34-SURV-30-20-00006426.0002001 / 20 JUL 15

Applicable to: ALL

At takeoff, alerts are inhibited above 100 kt and up to 50 ft.

During landing, alerts are inhibited below 50 ft.

The aural alerts of the Predictive WindShear system (PWS):

- Have priority over TCAS , GPWS , and other FWC aural warnings
- Are inhibited by reactive windshear detection and aural messages of stall warnings.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### SURVEILLANCE

WEATHER RADAR - PREDICTIVE WINDSHEAR SYSTEM


Intentionally left blank



**CONTROL PANEL**

Ident.: DSC-34-SURV-30-30-00001402.0002001 / 21 MAR 17

Applicable to: ALL



(1) Radar sw

This switch sets one radar to ON or turns both radars to OFF.

Note: If only one radar is installed on the aircraft, either:

- a "INOP" or "DEACT" sticker replaces the "2", or
- a "ON/OFF" Radar sw replaces the "1/OFF/2" Radar sw.

Note: If only one radar is installed on the aircraft, no weather image is displayed on the Navigation Display (ND) when the "1/OFF/2" SYS sw is set to "2".

(2) GAIN knob

This knob adjusts the sensitivity of the radar.

CAL is the normal position of the knob :

- When in Multiscan Automatic mode and gain set to CAL, the radar automatically adjusts the gain according to various parameters (aircraft altitude, geographical area, season, time of the day) to obtain the best weather display
- When in Manual mode and gain set to CAL, the radar adjusts the gain to a calibrated setting.

(3) Display mode selector

WX : Weather mode :

Colors indicate the intensity of precipitation (black for the lowest intensity, green, amber and red indicate progressively higher intensity).


WX+T : Weather and Turbulence mode :

The ND indicates precipitation and turbulence areas. Turbulence areas are displayed in magenta (within 40 NM).

TURB  : Turbulence mode :

The ND only displays turbulence areas in magenta (within 40 NM).

WX+T+HZD: Weather, Turbulence and Hazard mode (recommended position) :

 : The ND indicates precipitation, turbulence areas in magenta (within 40 NM) and hazard prediction risk areas (*Refer to DSC-34-SURV-30-30 Weather Hazard Prediction Function Indication on ND*).

Hazard prediction function is only available when the MULTISCAN sw is set to AUTO.

*Note: When MULTISCAN sw is set to MAN, WX+T+HZD mode is equivalent to WX+T mode.*

MAP : Map mode :

The radar operates in ground mapping mode: black indicates water, green indicates the ground, and amber indicates cities and mountains.

(4) TILT knob

This knob adjusts the antenna tilt when MULTISCAN sw is set to MAN. Zero indicates the horizon reference provided by the IRS.

(5) MULTISCAN sw

AUTO : Activates Multiscan mode

Multiscan controls the tilt automatically and combines two scans done at different tilt angles to optimize weather detection and minimize ground clutter.


MAN : When set to MAN, the crew can manually adjust the tilt by using the TILT knob.

(6) GCS sw

The Ground Clutter Suppression (GCS) switch is spring-loaded to the AUTO position.

- AUTO : - If MULTISCAN sw is set to AUTO, the radar is in normal use. Ground clutter is not displayed on the screen  
 - If MUTLISCAN sw is set to MAN, the GCS sw has no utility. Ground clutter is displayed on the screen.

OFF : Ground clutter is displayed on the screen.

(7) PWS sw 


AUTO : Activates the Predictive WindShear function in accordance with activation conditions (*Refer to DSC-34-SURV-30-20 Windshear Alerts Above 50 feet*).

OFF : The Predictive WindShear function is off.

**WEATHER RADAR INDICATION ON ND**

Ident.: DSC-34-SURV-30-30-00001255.0007001 / 21 MAR 16

Applicable to: ALL



(1) Weather Radar Picture

- When the radar is operating, and when the ND is not in PLAN mode, the ND displays the weather radar picture.
- The weather echoes appear in different colors, depending on the precipitation rates (black, green, yellow, red or magenta for turbulence).
- The selected ND range will determine how often the image is refreshed.

(2) Tilt Angle

- The multiscan function of the weather radar alternatively scans at low and high beam, and automatically sets the tilt of these beams to optimize the weather radar detection. The displayed weather radar picture is the result of the storing and merging of the information from each beam.
- The tilt angle is the angle between the horizon and the radar beam axis. The value of the tilt angle is in degrees, and quarters of a degree. It appears in the lower right corner of the screen:
  - In green, when the MULTISCAN sw is set to AUTO. This value represents the average of the lower and the upper beam tilts.
  - In blue, next to the blue “MAN ” indication, when the flight crew sets the MULTISCAN sw to MAN.
  - When the multiscan function is lost, the tilt value is dashed and the “NO AUTO TILT” message appears in amber on the ND , until the flight crew sets the MULTISCAN sw to MAN.

(3) Gain Mode


- “MAN GAIN” appears in white, when the flight crew selects the manual gain mode.

(4) Failure Messages


The ND lists the detected failures.

If the message is in “red”, the ND does not display a radar image.

If the message is in “amber”, the image is not affected.

NO WXR (red)	:	Radar System failure.
WXR RT (red)	:	Radar transceiver failure.
WXR ANT (red)	:	Radar antenna failure.
WXR CTL (red)	:	Radar control unit failure.
WXR RNG (red)	:	Range error.
WXR WEAK (amber)	:	Calibration failure.
WXR ATT (amber)	:	Attitude control failure.
WXR STAB (amber)	:	Antenna stabilization failure.
PRED W/S (amber)	:	PWS  function failure.
NO AUTO TILT (amber)	:	Automatic tilt adjustment failure.
WXR TEST (amber)	:	Radar System test.

(5) PAC alert

When the flight crew sets the display mode selector to WX or WX+T, or WX+T+HZD  and sets the gain to CAL, and when the aircraft is within 80 NM of a storm cell, the Path Attenuation Compensation (PAC) alert is available.


The PAC alert displays a yellow arc on the outermost scale of the ND, when an intervening rainfall creates an attenuated area behind a storm cell (also called a radar shadow or attenuation effect).

*Note:* The PAC alert is only available when the MULTISCAN sw is in the AUTO position.

**PWS  INDICATION ON PFD AND ND**

Ident.: DSC-34-SURV-30-30-00020941.0002001 / 17 MAR 17

Applicable to: ALL



(1) W/S AHEAD message on the PFD

This message is displayed, when the Predictive WindShear system detects windshear ahead of the aircraft.

The message is in amber or red, depending on the level of the alert. Refer to *DSC-34-SURV-30-20 General*.

(2) Predictive WindShear area indication

A red and black symbol and two yellow radial lines indicate the predicted windshear area.

## AIRCRAFT SYSTEMS

### SURVEILLANCE

#### WEATHER RADAR - CONTROLS AND INDICATORS

Windshear indication is available in ARC and ROSE ND modes.

When the radar detects a windshear event and the ND range is set above 10 NM, a W/S SET RNG 10 NM (Windshear, set range to 10 NM) message appears. This message requests the flight crew to adjust the range on the corresponding ND.

Depending on the windshear alert level, ND indication may be associated with an aural message and a PFD message. *Refer to DSC-34-SURV-30-20 General.*

(3) PWS SCAN message on the ND

If only the PWS detection is active, the ND displays a PWS SCAN message when the PWS is active. In this mode, when the radar detects a windshear event, a windshear symbol and the weather returns appear automatically on the ND.

### MEMO DISPLAY

Ident.: DSC-34-SURV-30-30-00017051.0001001 / 21 MAR 16


Applicable to: ALL

The "PRED W/S OFF" message appears when windshear is set to OFF on the weather radar panel.

**PRED W/S OFF** : This memo appears in green during flight phases 2 and 6.

**PRED W/S OFF** : This memo appears in amber when:

- The aircraft is in flight phases 3, 4, 5, 7, 8, and 9.
- The T.O. CONFIG pb is pressed during flight phase 2.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> GPWS - DESCRIPTION
---	--


## OVERVIEW

Ident.: DSC-34-SURV-40-10-00021292.0001001 / 17 MAR 17

**Applicable to: ALL**

The purpose of the Ground Proximity Warning System (GPWS) is to warn the flight crew of potentially hazardous situations, such as a collision with terrain. It detects terrain collision threats and triggers applicable aural and visual indications.

The GPWS includes:

- Five basic modes active up to radio height of 2 500 ft.
  - Excessive rate of descent (Mode 1)
  - Excessive terrain closure rate (Mode 2)
  - Altitude loss after takeoff or go-around (Mode 3)
  - Terrain clearance not sufficient, if not in landing configuration (Mode 4)
  - Excessive descent below the glide slope (Mode 5).
- A predictive GPWS  function, based on a GPWS database, to display terrain information. It can be provided:
  - By Honeywell through Enhanced GPWS (EGPWS)
  - By ACSS as Ground Collision Avoidance System (GCAS ), through T2CAS or T3CAS.

The predictive GPWS is composed of:

- Mandatory functions such as the Forward Looking Terrain Alerting function
- Optional functions such as the obstacle database.

*Note: The terrain data are displayed on the ND and the brightness is controlled via the weather radar brightness control knob. If the weather radar brightness was set to low (due to bad weather) and a terrain alert occurs, then the brightness of the terrain display will also be low.*



## PRINCIPLE

Ident.: DSC-34-SURV-40-10-00021293.0001001 / 17 MAR 17

**Applicable to: ALL**

The GPWS computes the geometric altitude of the aircraft by using:

- Pressure altitude
- Radio altitude
- Temperature
- Barometric references


- GPS altitude for predictive GPWS 
- Data from the GPWS database for predictive GPWS  .



**MODE 1 : EXCESSIVE RATE OF DESCENT**



Ident.: DSC-34-SURV-40-20-00015115.0004001 / 13 JAN 14

Applicable to: ALL



Mode 1 triggers aural and visual alerts about excessive rates of descent, based on the radio height, and the rate of descent of the aircraft.


Mode 1 is active for all phases of the flight.

	<b>CAUTION</b>		<b>WARNING</b>	
<b>AURAL ALERT</b>	"SINK RATE, SINK RATE"		"PULL UP" (repeated as long as MODE 1 is triggered)	
<b>VISUAL ALERT</b>		The GPWS amber lights come on		The PULL UP red lights come on

**MODE 2 : EXCESSIVE TERRAIN CLOSURE RATE**




Ident.: DSC-34-SURV-40-20-00015116.0004001 / 03 AUG 17


Applicable to: ALL




Mode 2 triggers aural and visual alerts, based on the landing gear/flaps configuration of the aircraft, the radio height, and the RA rate of change.

There are two types of Mode 2 alerts, Mode 2A (active during climb, cruise, and initial approach), and Mode 2B (active during approach and 60 s after takeoff).


CONFIGURATION	Flaps not in Landing Position + Landing Gear Up (Mode 2A) Flaps in landing position + Landing Gear Up (Mode 2B)		
	CAUTION	WARNING	
AURAL ALERT	"TERRAIN, TERRAIN"	"PULL UP" (repeated as long as MODE 2 is triggered in the warning conditions)	"TERRAIN" (repeated as long as MODE 2 is triggered after leaving the warning conditions)
VISUAL ALERT	 The GPWS amber lights come on	 The PULL UP red lights come on	 The PULL UP red lights stay on

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> GPWS - GPWS BASICS MODES
---	--


<b>CONFIGURATION</b>	<b>Flaps in landing position + Landing Gear Down (Mode 2B)</b>
<b>AURAL ALERT</b>	<b>CAUTION</b>
	<b>"TERRAIN"</b> (repeated as long as MODE 2 is triggered)
<b>VISUAL ALERT</b>	 The GPWS amber lights come on

**MODE 3 : ALTITUDE LOSS AFTER TAKEOFF**

Ident.: DSC-34-SURV-40-20-00015117.0004001 / 19 SEP 13  
 Applicable to: ALL





Mode 3 triggers aural and visual alerts when the altitude significantly decreases after takeoff, and go-arounds with landing gear or flaps not in landing configuration.

	<b>CAUTION</b>
<b>AURAL ALERT</b>	<b>"DON'T SINK, DON'T SINK"</b> (repeated as long as MODE 3 is triggered)
<b>VISUAL ALERT</b>	 The GPWS amber lights come on

**MODE 4 : UNSAFE TERRAIN CLEARANCE WHEN NOT IN LANDING CONFIGURATION**


Ident.: DSC-34-SURV-40-20-00015118.0005001 / 13 JAN 14


Applicable to: ALL



There are three types of Mode 4 alerts, Mode 4A and Mode 4B (both active during cruise and approach), and Mode 4C (active during takeoff\*).

Mode 4A and Mode 4B trigger aural and visual alerts when terrain clearance is not sufficient based on the phase of flight, the configuration of the landing gear and the flaps, and the speed. Mode 4C triggers aural and visual alerts based on the minimum terrain clearance and the radio height of the aircraft. \*(Only EGPWS not T2CAS)

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> GPWS - GPWS BASICS MODES
---	--


<b>CONFIGURATION</b>	Landing gear Up (Mode 4A)	Flaps not in landing position + Landing gear down (Mode 4B)		Flaps not in landing position OR Landing Gear Up (Mode 4C)	
<b>AURAL ALERT</b>	<b>CAUTION</b>				
	"TOO LOW TERRAIN"	"TOO LOW GEAR"	"TOO LOW TERRAIN"	"TOO LOW FLAPS"	"TOO LOW TERRAIN"
<b>VISUAL ALERT</b>	 The GPWS amber lights come on				

**MODE 5 : DESCENT BELOW GLIDESLOPE**

Ident.: DSC-34-SURV-40-20-00015119.0004001 / 19 SEP 13  
 Applicable to: ALL



Mode 5 triggers aural and visual alerts, when the aircraft descends below the glide slope.

	<b>CAUTION</b>
<b>AURAL ALERT</b>	<b>"GLIDESLOPE"</b> (repeated as long as MODE 5 is triggered)
<b>VISUAL ALERT</b>	 The GPWS amber lights come on




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**SURVEILLANCE**

GPWS - GPWS BASICS MODES

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> GPWS - PREDICTIVE GPWS FUNCTIONS
---	--

**TERRAIN AWARENESS AND DISPLAY**

Ident.: DSC-34-SURV-40-35-00001417.0114001 / 29 JUN 16  
**Applicable to: ALL**

The Terrain Awareness and Display (TAD) function computes a caution and a warning envelope in front of the aircraft, depending on the aircraft altitude, the nearest runway altitude, the distance to the nearest runway threshold, the ground speed, and the turn rate. When the boundary of these envelopes conflicts with the terrain, or with an obstacle memorized in the database, the system generates the relevant alert:

Alert Level	Aural Warning	ND (Refer to DSC-31-45 Flags and Messages Displayed on ND)	Local Warning
<b>Warning</b>	<b>TERRAIN TERRAIN PULL UP</b>	- Automatic terrain display See * - Solid red areas - TERRAIN (red)	On each pilot's instrument panel, The pushbutton light comes on.
	<b>OBSTACLE OBSTACLE, PULL UP</b>	- Automatic terrain display See * - Solid red areas - OBST (red)	
<b>Caution</b>	<b>CAUTION TERRAIN</b>	- Automatic terrain display See * - Solid yellow areas - TERRAIN (amber)	
	<b>CAUTION OBSTACLE</b>	- Automatic terrain display See * - Solid yellow areas - OBST (amber)	

\* When the TERR pb-sw ON ND is set to ON, and ARC or ROSE mode is selected, the ND displays the terrain and the obstacles memorized in the database, depending on the aircraft's position. The terrain is displayed in various densities of green, yellow, red, or magenta, depending on the threat (Refer to DSC-31-45 Flags and Messages Displayed on ND). If an alert is generated (caution or warning), and TERR pb-sw ON ND is not selected, the terrain and the obstacles are automatically displayed, and the ON light of the TERR pb-sw ON ND comes on.


- Note:*
1. When **TERR pb-sw ON ND** is selected, the weather radar image is not displayed.
  2. The Geometric Altitude function can protect against certain **BARO** setting errors, provided the components used to compute the Geometric Altitude are valid and accurate enough.
  3. The **TAD** and **Terrain Clearance Floor (TCF)** functions operate using the pure lateral **GPS** position and, the **FMS1** position as backup.

If the crew identifies that navigation accuracy is low, it must set the enhanced modes to off, via the **TERR pb-sw**. The 5 **GPWS** modes remain active.

**TERRAIN CAUTION AND WARNING ENVELOPE**


Ident.: DSC-34-SURV-40-35-00006161.0002001 / 19 DEC 12

Applicable to: **ALL**






**VERTICAL ENVELOPE**



**HORIZONTAL ENVELOPE**




**TERRAIN CLEARANCE FLOOR**

Ident.: DSC-34-SURV-40-35-00006162.0002001 / 03 JUN 14

Applicable to: ALL

A terrain clearance floor envelope is stored in the database for each runway for which terrain data exist. The Terrain Clearance Floor (TCF) function warns of a premature descent below this floor, regardless of aircraft configuration.




If the airplane descends below this floor, a TOO LOW TERRAIN aural warning is announced, and the pushbutton light comes on, on the glareshield.

**RUNWAY FIELD CLEARANCE FLOOR**

Ident.: DSC-34-SURV-40-35-00006163.0002001 / 19 DEC 12

Applicable to: ALL

The Runway Field Clearance Floor (RFCF) provides an additional envelope protection, for runways that are significantly higher than the surrounding terrain. It is contained in a circle within the 5.5 NM of the runway threshold and it is based on the geometric altitude and the runway elevation.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### SURVEILLANCE


GPWS - PREDICTIVE GPWS FUNCTIONS

Intentionally left blank

**OVERHEAD PANEL**

Ident.: DSC-34-SURV-40-40-00001418.0002001 / 21 MAR 17

Applicable to: ALL



(1) SYS pushbutton

OFF : All basic GPWS alerts (Mode 1 to 5) are inhibited.

FAULT light : This amber light comes on, along with an ECAM caution, if the basic GPWS mode 1 to 5 malfunction.

*Note: If ILS 1 fails, only mode 5 is inhibited. Consequently, the FAULT light does not come on and the GPWS FAULT warning is not triggered.*

(2) G / S MODE pushbutton

OFF : Glideslope mode (mode 5) is inhibited.

(3) FLAP MODE pushbutton

OFF : Flap mode ("TOO LOW FLAPS" mode 4) is inhibited.  
 (To avoid nuisance warning in case of landing with flaps setting reduced).

(4) LDG FLAP 3 pushbutton

ON : Flap mode is inhibited when FLAPS CONF 3 is selected (to avoid nuisance warning in case of landing in CONF 3).  
 In this case, LDG MEMO displays "FLAPS ... 3" instead of "CONF ... FULL".

(5) TERR pushbutton


OFF : Inhibits the Terrain Awareness Display (TAD) and Terrain Clearance Floor (TCF) modes, and does not affect the basic GPWS mode 1 to 5. If OFF is selected the ECAM caution NAV GPWS TERR DET FAULT is displayed.

**FAULT** light : This amber light comes on, along with an ECAM caution, if the TAD or TCF mode fails. The terrain is not shown on the ND . The basic GPWS mode 1 to mode 5 are still operative if the SYS pushbutton OFF or FAULT lights are not illuminated.

### INSTRUMENT PANELS

Ident.: DSC-34-SURV-40-40-00001419.0003001 / 19 DEC 12

Applicable to: ALL




#### (1) GPWS – G/S pushbutton

**GPWS** : This red light comes on when any mode from 1 to 4, or any TAD or TCF alert is activated. A specific voice alert accompanies it.

**G/S** : Comes on amber when Mode 5 is activated. It is accompanied by the aural “GLIDE SLOPE” warning.

- Note:*
1. If the flight crew presses this button briefly when a glide slope warning is on, the G/S light goes out and the “GLIDE SLOPE” aural warning (soft or loud) stops.
  2. On ground, the GPWS can be tested by pressing this pushbutton. If the pushbutton is pressed briefly, some of the aural warnings sound and pushbutton captions, related to the GPWS, come on. If the pushbutton is pressed continuously, then all the aural warnings sound.



(2) TERR ON ND pushbutton

These pushbuttons are located on either side of the ECAM. Each pushbutton controls the onside terrain display.

**ON** : The terrain is displayed on the ND if the:

- TERR pb-sw is selected ON, and
- TERR FAULT light is not on.

The ON light comes on.

**OFF** : The terrain data is not displayed on the ND.

*Note:*

- If the Terrain Awareness Display (TAD) mode generates a caution or a warning, while the TERR ON ND is not switched ON, the terrain is automatically displayed on the ND s (see EGPWS specific caution and warning due to TAD mode) and the ON light of the TERR ON ND pushbutton come on.
- To differentiate between the terrain and the weather display, the terrain display sweeps from the center outward to both sides of the ND.

**MEMO DISPLAY**

**Applicable to: ALL**

Ident.: DSC-34-SURV-40-40-A-00017057.0001001 / 21 MAR 16

**GPWS FLAP 3** : This memo appears in green when GPWS LDG FLAP 3 pb-sw is ON.

Ident.: DSC-34-SURV-40-40-A-00017058.0001001 / 21 MAR 16

**GPWS FLAP MODE OFF** : This memo appears in green when GPWS FLAP MODE pb-sw is OFF.

Ident.: DSC-34-SURV-40-40-A-00017060.0004001 / 21 MAR 16

The TERR OFF memo appears when the TERR pb-sw is OFF.

**TERR OFF** : This memo appears in green when:

- The aircraft is in flight phase 2, before the Take Off Configuration test is launched.
- The aircraft is in flight phase 6.


**TERR OFF** : This memo appears in amber when:

- The aircraft is in flight phase 2, after the Take Off Configuration test.
- The aircraft is in flight phases 3, 4, 5, 7, 8 and 9.

Ident.: DSC-34-SURV-40-40-A-00017059.0007001 / 21 MAR 16

**TERR STBY** : Airborne TERR STBY memo appears in green when the aircraft position accuracy (computed by the EGPWS ) is not sufficient to allow the enhanced TCF and TAD modes to operate. These modes are not available until the TERR STBY memo disappears. If selected, the terrain data display on ND is automatically deselected when the TERR STBY memo is triggered.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> TCAS - DESCRIPTION</p>
---	--

**OVERVIEW**

Ident.: DSC-34-SURV-60-10-00020407.0001001 / 21 MAR 17  
**Applicable to: ALL**

The Traffic alert and Collision Avoidance System (TCAS):


- Detects and displays surrounding aircraft that have a transponder
- Calculates and display possible collision threats
- Triggers vertical speed orders, in order to avoid collisions.

**PRINCIPLE**

Ident.: DSC-34-SURV-60-10-00020408.0001001 / 21 MAR 17  
**Applicable to: ALL**

The TCAS detection capability is limited to intruders flying within a maximum range of 30 NM on either sides and approximately 30 NM to 80 NM longitudinally (depending on aircraft configuration and external conditions), and within a maximum altitude range of 9 900 ft above and below the aircraft.

TCAS Range



The TCAS obtains data transmitted by the transponders of nearby aircraft, and uses this data to evaluate possible collision threats.


The TCAS determines:

- The bearing of intruders, in relation to the bearing of the aircraft.
- The distance between the aircraft and intruders, and the rate of separation or closure.
- The relative altitude of intruders, if intruders have a Mode-C or Mode-S transponder.

The TCAS then calculates the intruder trajectory, the Closest Point of Approach (CPA), and the estimated time (TAU) before reaching the CPA.

The TAU is the ratio between the distance that separates both aircraft, and the sum of their speed.

TAU Definition



If the TCAS detects that the trajectory of an intruder may be a collision threat, it triggers:

- Audio and visual indicators
- Vertical speed orders, to ensure a sufficient trajectory separation and a minimal vertical speed variation considering all intruders.

**MAIN COMPONENTS**

Ident.: DSC-34-SURV-60-10-00020409.0001001 / 21 MAR 17


Applicable to: **ALL**

The system includes:

- A single channel TCAS computer
- Two TCAS antennas
- Two mode S ATC transponders, one active the other in standby

These transponders allow:

- Interface between the ATC /TCAS control panel and the TCAS computer
  - Communication between the aircraft and intruders equipped with a TCAS system.
- An ATC /TCAS control panel.



**INTRUDER DETECTION CATEGORIES**


Ident.: DSC-34-SURV-60-10-00020410.0001001 / 21 MAR 17

Applicable to: ALL


The TCAS divides the space surrounding the aircraft into the following four zones, in order to evaluate and categorize possible collision threats:





- Resolution Advisory (RA)
- Traffic Advisory (TA)
- Proximate intruders
- Other intruders.

TCAS Envelopes





Depending on the level of the collision threat, the TCAS triggers audio and visual indicators::

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>SURVEILLANCE</b></p> <p>TCAS - DESCRIPTION</p>
---	---

LEVEL	INTRUDER POSITION	DISPLAYED INFORMATION AND MESSAGE	
<b>Other intruders</b>	<ul style="list-style-type: none"> <li>- No collision threat</li> <li>- Any non proximate, TA , RA within the surveillance envelope (lateral range: Closer than 30 NM )</li> </ul>	<ul style="list-style-type: none"> <li>- ND: Intruder position</li> </ul>	
<b>Proximate</b>	<ul style="list-style-type: none"> <li>- No collision threat</li> <li>- Intruder in the vicinity of the A/C (closer than 6 NM laterally and ±1200 ft vertically)</li> </ul>	<ul style="list-style-type: none"> <li>- ND: Intruder position</li> </ul>	
<b>Traffic Advisory (TA)</b>	<ul style="list-style-type: none"> <li>- Potential collision threat</li> <li>- TAU is about 40 s</li> </ul>	<ul style="list-style-type: none"> <li>- ND: Intruder position</li> <li>- Aural messages</li> </ul>	
<b>Resolution Advisory (RA)</b>	<ul style="list-style-type: none"> <li>- Real collision threat</li> <li>- TAU is about 25 s</li> </ul>	<ul style="list-style-type: none"> <li>- ND: Intruder position</li> <li>- Aural messages</li> <li>- PFD: Vertical orders</li> <li>• Maintain actual V/S (Preventive Advisory) or</li> <li>• Modify V/S (Corrective Advisory)</li> </ul>	

TA /RA thresholds



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b> <b>SURVEILLANCE</b> TCAS - DESCRIPTION</p>
---	---

**TCAS MODES**

Applicable to: ALL

Ident.: DSC-34-SURV-60-10-10-00020411.0001001 / 21 MAR 17

**TCAS MODES**

The TCAS has three different modes of operations that can be selected on the ATC / TCAS control panel:

- The Traffic Advisory/Resolution Advisory (TA/RA) mode
- The Traffic Advisory Only (TA ONLY) mode
- The standby (STBY) mode.

Ident.: DSC-34-SURV-60-10-10-00020412.0001001 / 21 MAR 17

**TRAFFIC ADVISORY/RESOLUTION ADVISORY (TA/RA) MODE**

The TA/RA mode is the normal TCAS operating mode that enables:

- The ND to display all intruders
- The PFD to display the vertical speed orders that indicate the vertical direction that the aircraft should take, in order to avoid a collision.

Ident.: DSC-34-SURV-60-10-10-00020413.0001001 / 21 MAR 17

**TRAFFIC ADVISORY ONLY (TA ONLY) MODE**

The TA ONLY mode can be selected:

- Manually in case of aircraft degraded performance (engine failure, landing gear extended), or in specific airports, and for specific procedures (identified by operators) that may provide RA that are neither wanted nor appropriate (e.g. closely-spaced parallel or converging runways)
- Automatically, if TA/RA mode is previously selected and:
  - The windshear alert is triggered
  - The stall warning is triggered
  - GPWS alerts are triggered
  - Aircraft is below 1 000 ft AGL.

When the TCAS is operating in TA ONLY mode:

- All RA s are inhibited and converted into TAs
- TA threshold is set to TAU  $\leq 20$  s, irrespective of the aircraft altitude
- No vertical speed advisories are indicated on the PFDs
- "TA ONLY" is displayed on the NDs

Ident.: DSC-34-SURV-60-10-10-00020414.0001001 / 21 MAR 17

### **STANDBY MODE**


In the standby mode, the advisory generation and surveillance functions are not active. The TCAS does not trigger any alert. No TCAS information can be displayed on the PFD s and NDs.

### **ADVISORY INHIBITION**

Ident.: DSC-34-SURV-60-10-00020416.0007001 / 17 MAR 17

**Applicable to: ALL**

Some advisories are inhibited depending on the aircraft altitude:


- All intruders flying below 380 ft AGL when the own aircraft altitude is below 1 700 ft AGL
- All RA below 1 100 ft in climb and 900 ft in descent. In this case, the RA s are converted into TAs
- “Descend” RA below 1 100 ft AGL
- “Increase Descent” RA below 1 550 ft AGL
- All TA aural messages below 600 ft AGL in climb and below 400 ft AGL in descent
- The AP/FD TCAS  flight guidance mode is inhibited below 900 ft.



**ATC/TCAS PANEL**

Ident.: DSC-34-SURV-60-20-00001429.0064001 / 01 OCT 12

Applicable to: ALL



(1) Mode selector

- TA/RA : Normal position.  
TA s, RAs, proximate and other intruders are displayed.
- TA ONLY : This mode should be used, in case of degraded aircraft performance (engine failure, landing gear extended, or approach on parallel runways).  
All RA s are converted into TA s. TAs, proximate and other intruders are displayed.
- STBY : The TCAS and ATC are on standby.
- XPNDR : - The TCAS is on standby  
- On ground : The selected ATC Transponder only operates in the selective aircraft interrogation mode of Mode S  
- In flight : The selected ATC Transponder operates.

(2) TRAFFIC selector

- ABV : The altitude range is set to +7 000 ft above the aircraft, and -2 700 ft below the aircraft.
- N : The altitude range is set to -2 700 ft below the aircraft, and +2 700 ft above the aircraft.

BLW : The altitude range is set to -7 000 ft below the aircraft, and +2 700 ft above the aircraft.

(3) AUTO/ON selector or THRT/ALL selector

ON (or ALL) : All intruders are displayed.

AUTO (or THRT) : Proximate and other intruders are only displayed, if a TA or RA is already presented.

*Note:* Some TCAS control panels are equipped with a THRT/ALL selector, instead of the AUTO/ON selector. The associated functions remain unchanged.

**ND INDICATIONS**

Ident.: DSC-34-SURV-60-20-00020418.0002001 / 17 MAR 17

Applicable to: ALL

The traffic is displayed in all ROSE modes and ARC mode when 10, 20 or 40 NM range is selected. Only the 8 most threatening intruders are displayed.



(1) Proximate intruder

Indicated by a white filled diamond.

(2) TA intruder


Indicated by an amber circle.

Associated with the TRAFFIC-TRAFFIC aural message.

(3) RA intruder

Indicated by a red square.

Associated with vertical orders displayed on the PFD and aural messages.

(4) Other intruders 

Indicated by a white empty diamond.

*Note:* If the range of an intruder is not available, the intruder is not displayed. An intruder may be partially displayed when its range is out of scale.

(5) Relative altitude

Indicated in hundred of feet above or below the symbol depending on the intruder position.

(6) Vertical speed arrow

Displayed only if the intruder V/S > 500 ft/min.

Relative altitude and vertical speed arrow are displayed in the same color as the associated intruder symbol.

*Note:* If the altitude of an intruder is not available, neither altitude nor vertical speed indications are displayed.

(7) No bearing intruder

If the bearing of TA or RA intruder is not available the following data is presented in digital form at the bottom of the ND:

- range
- relative altitude and vertical speed arrow if available.

Displayed amber or red according to threat level.

(8) Range ring

A 2.5 NM white range ring is displayed when a 10 NM or 20 NM range is selected.

**TCAS MESSAGES**

Ident.: DSC-34-SURV-60-20-00020419.0001001 / 17 MAR 17

Applicable to: **ALL**



(1) Mode and range messages

Following messages can be displayed to draw pilot's attention:

**TCAS : REDUCE RANGE** : Displayed when a TA or RA is detected and ND range above 40 NM.

**TCAS : CHANGE MODE** : Displayed when a TA or RA is detected and ND mode is PLAN.

Displayed amber or red depending on the advisory level (TA or RA).

(2) TCAS operation messages

**TCAS** : Displayed in case of TCAS internal failure.


**TA ONLY** : Displayed white when the TA mode is selected automatically, or manually by the flight crew.

**PFD INDICATIONS**

Ident.: DSC-34-SURV-60-20-00020420.0005001 / 17 MAR 17

Applicable to: **ALL**

In case of RA detection, the vertical speed scale becomes rectangular and the PFD presents vertical orders on the vertical speed scale. The vertical speed scale background is normally grey, but may be partially replaced by green and/or red areas.



(1) Red area

Indicates the vertical speed range, when there is a high risk of conflict.

(2) Green area

Indicates the recommended vertical speed range. It is wider than the red area.

*Note:* - The aircraft can also fly in the grey vertical speed range, without the risk of conflict (preventive RA).

- The color of the digits corresponds to the appropriate area.

- In case of RA detection, the vertical speed needle that is normally green, becomes white.

(3) TCAS message

Appears in amber provided that the TCAS is not in standby, when the TCAS cannot deliver RA data, or in case of an internal TCAS failure.

**AURAL MESSAGES**

Ident.: DSC-34-SURV-60-20-00001433.0018001 / 08 FEB 13

Applicable to: ALL

TA /RA detection is associated with the following messages:

"TRAFFIC TRAFFIC"

: Only in case of TA detection.

"CLIMB CLIMB"

: Climb at the vertical speed indicated by the green area on the PFD.

**AIRCRAFT SYSTEMS**

**SURVEILLANCE**

**TCAS - CONTROLS AND INDICATORS**

- |  |   |   |
|--|---|---|
| "CLIMB, CROSSING CLIMB" (twice)              | : | Same as above. Indicates that you will cross through the intruder altitude.   |
| "INCREASE CLIMB" (twice)                     | : | Triggered after the CLIMB message, if vertical speed is insufficient to achieve safe vertical separation.                           |
| "DESCEND DESCEND"                            | : | Descend at the vertical speed indicated by the green area on the PFD.   |
| "DESCEND, CROSSING DESCEND" (twice)          | : | Same as above. Indicates that you will cross through the intruder altitude.   |
| "INCREASE DESCEND" (twice)                   | : | Triggered after the DESCEND message, if the vertical speed is insufficient to achieve safe vertical separation.                     |
| "LEVEL OFF, LEVEL OFF"                       | : | Set the Vertical Speed to 0.  |
| "CLIMB CLIMB NOW" (twice)                    | : | Triggered after the DESCEND message, if the intruder trajectory has changed.  |
| "DESCEND DESCEND NOW" (twice)                | : | Triggered after the CLIMB message, if the intruder trajectory has changed.  |
| "MONITOR VERTICAL SPEED"                     | : | Ensure that the vertical speed remains outside the red area.<br>Triggered only once, in case of preventive RA.                      |
| "MAINTAIN VERTICAL SPEED, MAINTAIN"          | : | Maintain the vertical speed indicated on the green area of the PFD.   |
| "MAINTAIN VERTICAL SPEED, CROSSING MAINTAIN" | : | Maintain the vertical speed indicated on the green area of the PFD.<br>Indicates that you will cross through the intruder altitude. |
| "CLEAR OF CONFLICT"                          | : | The range increases and separation is adequate. Return to assigned clearance.   |

**MEMO DISPLAY**

Ident.: DSC-34-SURV-60-20-00020422.0003001 / 17 MAR 17

Applicable to: **ALL**

- TCAS STBY** : This memo appears in green when:
- ATC STBY is selected by the crew, or
  - TCAS STBY is selected by the crew during flight phases other than 6, or
  - ALT RPTG sw is OFF, or
  - both ATC s or both RAs are failed, or
  - In the case of a triple ADR failure.

**TCAS STBY** : This memo appears in amber when the flight crew sets the TCAS on STBY in flight phase 6.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**SURVEILLANCE**

TCAS - CONTROLS AND INDICATORS

Intentionally left blank



# AIRCRAFT SYSTEMS

OXYGEN

Intentionally left blank

**DSC-35-10 General**

Description..... A

**DSC-35-20 Fixed Oxygen System for Cockpit**

**DSC-35-20-10 Description**

General..... A  
 Operation..... B  
 Schematic..... C  
 Mask Setting..... D  
 Mask Stowage..... E

**DSC-35-20-20 Controls and Indicators**

Overhead Panel..... A  
 Stowage Box..... B  
 Crew Oxygen Mask..... C  
 Pressure Regulator..... D  
 ECAM DOOR/OXY Page..... E

**DSC-35-30 Fixed Oxygen System for Cabin**

**DSC-35-30-10 Description**

General..... A  
 Operation..... B  
 Schematic..... C

**DSC-35-30-20 Controls and Indicators**

Overhead Panel..... A  
 Overhead Maintenance Panel..... B  
 Memo Display..... C

**DSC-35-40 Portable Oxygen System**

**DSC-35-40-10 Description**

Flight Crews Portable Oxygen System..... A  
 Using the Hood..... B




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### OXYGEN

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b></p> <p><b>OXYGEN</b></p> <p>GENERAL</p>
---	--

<b>DESCRIPTION</b>
--------------------

Ident.: DSC-35-10-00001448.0001001 / 20 DEC 10

**Applicable to: ALL**

The oxygen system consists of:

- A cockpit-fixed oxygen system, which supplies adequate breathing oxygen to the cockpit occupants in case of depressurization, or emission of smoke and noxious gases.
- A cabin-fixed oxygen system, which supplies oxygen for cabin occupants (passengers and cabin crew) in case of depressurization.
- A portable oxygen system, which is provided in both the cockpit and cabin and is to be used:
  - As PROTECTION for the crew during on board emergencies.
  - For FIRST AID purposes.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**OXYGEN**

GENERAL


Intentionally left blank

**GENERAL**

Ident.: DSC-35-20-10-00017801.0001001 / 21 MAR 16

Applicable to: ALL

The cockpit's fixed oxygen system consists of :

- A high-pressure cylinder, located in the left-hand lower fuselage.
- A pressure regulator, connected directly to the cylinder that delivers oxygen, at a pressure suitable for users.
- Two overpressure safety systems to vent oxygen overboard, through a safety port, if the pressure becomes too high.
- A supply solenoid valve that allows the crew to shut off the distribution system.
- Three (or four ) full-face quick-donning masks, stowed in readily-accessible boxes adjacent to the crewmembers' seats (one at each seat).

**OPERATION**

Ident.: DSC-35-20-10-00001450.0001001 / 21 MAR 16

Applicable to: ALL

The crewmember squeezes the red grips to pull the mask out of its box, and this action causes the mask harness to inflate.

A mask-mounted regulator supplies a mixture of air and oxygen or pure oxygen, or performs emergency pressure control. With the regulator set to NORMAL, the user breathes a mixture of cabin air and oxygen up to the cabin altitude at which the regulator supplies 100 % oxygen. The user can select 100 %, in which case the regulator supplies pure oxygen at all cabin altitudes.

If the situation calls for it, the user can use the emergency overpressure rotating knob and receive pure oxygen at positive pressure.


The storage box contains a microphone lead, with a quick-disconnect, for connection to the appropriate mask microphone cable.

Note: *Each mask may have a removable film that protects the visor against scratches. This strip is optional and may be removed from the mask at any time.*

**SCHEMATIC**

Ident.: DSC-35-20-10-00017802.0001001 / 21 MAR 16

Applicable to: ALL







**MASK SETTING**

Ident.: DSC-35-20-10-00016919.0001001 / 21 MAR 16

Applicable to: ALL



**Note:** The captain (first officer) must exercise caution and turn the head to the right (left) in the direction of the first officer (captain) in order to ensure fast donning of the mask when the HUD  on the captain (first officer) side is deployed.

**MASK STOWAGE**

Ident.: DSC-35-20-10-00001453.0001001 / 21 MAR 16

Applicable to: ALL

- ① - COIL THE HOSE AND PLACE IT IN THE BOTTOM OF THE STOWAGE BOX.



- ③ - PLACE THE MASK IN THE STOWAGE BOX.  
- MAKE SURE THE MASK REGULATOR IS FULLY SEATED AGAINST THE STOP IN THE STOWAGE BOX.



- ② - POSITION THE REMAINING HOSE IN THE MIDDLE OF THE MASK.  
- FOLD THE TWO HARNESS PORTIONS TOGETHER.



- ④ - CLOSE THE DOORS, THEN FULLY PRESS THE "RESET TEST" BUTTON.  
- ONCE THE "RESET TEST" BUTTON IS RELEASED, CHECK THAT THE "OXY ON" FLAG COMPLETELY DISAPPEARS.  
- PRESS THE EMERGENCY PRESSURE SELECTOR, AND CHECK THAT THE BLINKER REMAINS BLACK.  
- THEN, RETURN THE N/100% SELECTOR AT THE 100% POSITION.


**CAUTION:** Maintaining the pressure selector in the "EMERGENCY" position can deplete the crew oxygen cylinder.



**OVERHEAD PANEL**

Ident.: DSC-35-20-20-00017803.0001001 / 21 MAR 16

Applicable to: ALL



(1) CREW SUPPLY pb

This pushbutton controls the solenoid valve.


On : The valve is open, and supplies low pressure oxygen to the masks (normal position in flight).

OFF: The valve is closed, and the white light comes on.

**STOWAGE BOX**

Ident.: DSC-35-20-20-00001455.0001001 / 22 MAY 12

Applicable to: **ALL**




- (1) Blinker flowmeter (yellow)  
 This indicator flashes when oxygen is flowing.
- (2) RESET/TEST control slide  
 The crewmember presses the slide, and pushes it in the direction of the arrow to test: the operation of the blinker; the regulator supply; system sealing downstream of the valve; and the regulator sealing and system operation. Pressing the RESET control slide, after the oxygen mask has been used, cuts off the oxygen, and the mask microphone.
- (3) OXY ON flag  
 As soon as the left flap door opens, the mask is supplied with oxygen and, once it closes (mask still supplied with oxygen), the "OXY ON" flag appears.

**CREW OXYGEN MASK**

Ident.: DSC-35-20-20-00001456.0001001 / 21 MAR 16


Applicable to: ALL



**PRESSURE REGULATOR**

Ident.: DSC-35-20-20-00001457.0001001 / 24 NOV 15

Applicable to: ALL



- (1) Red grips  
Squeezing the right-hand side grip unlocks the two-flap door, and permits the harness to inflate.

(2) EMERGENCY pressure selector

Use of this selector creates an overpressure which eliminates condensation or fogging of the mask, and prevents smoke, smell or ashes from entering the mask.

- Pressing this knob generates an overpressure for a few seconds.
- Turning the knob, in the direction of the arrow, generates a permanent overpressure.


- Note:
1. *Overpressure supply is automatically started, when cabin altitude exceeds 30 000 ft.*
  2. *Overpressure supply is available only when the N/100% selector is set on the 100 % position.*

(3) N/100 % selector

This two-position button is locked down (100% position) when the crewmember pulls the mask out of the stowage. Pushing the button up from underneath releases it, and it pops up to the N (normal) position. Pressing it again returns it to 100 %.

100 % : The mask delivers 100 % oxygen.


N : The mask provides the flight crew with a mixture of air and oxygen. This mixture changes with cabin altitude. The higher the cabin altitude, the more oxygen the mask provides, until the mask supplies 100 % oxygen.



**ECAM DOOR/OXY PAGE**

Ident.: DSC-35-20-20-00001458.0004001 / 21 MAR 17

Applicable to: ALL





- (1) OXY pressure indication

It is in green, when the pressure is  $\geq 800$  PSI.  
It pulses in green, when the pressure is  $< 800$  PSI (the DOOR/OXY SD page is automatically displayed).  
It is in amber, when the pressure is  $< 400$  PSI.  
On ground, an amber half frame appears when oxygen pressure is  $< 1\ 500$  PSI.  
In this case, the flight crew must check that the remaining quantity is not below the minimum (*Refer to LIM-OXY Minimum Flight Crew Oxygen Pressure*).
- (2) REGUL LO PR indication

It is in amber, if oxygen pressure on the low-pressure circuit is low (50 PSI).
- (3) CKPT OXY indication

It is normally in white.  
It becomes amber, when:
  - Pressure goes below 400 PSI
  - Low oxygen pressure is detected
  - The overhead panel's OXYGEN CREW SUPPLY pb is OFF.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### OXYGEN

FIXED OXYGEN SYSTEM FOR COCKPIT - CONTROLS AND INDICATORS

Intentionally left blank


**GENERAL**

Ident.: DSC-35-30-10-00017804.0001001 / 13 MAY 16

Applicable to: ALL

In the case of depressurization, the fixed oxygen system in the cabin supplies oxygen to the cabin occupants.

Chemical generators produce the oxygen. Each generator feeds a group of 2, 3, or 4 masks.


Oxygen masks are located in containers above the passenger seats, in the lavatories, in each galley  , and at each cabin crew station.

*Note:* Gaseous generators  replace chemical generators in the lavatories.


**OPERATION**

Ident.: DSC-35-30-10-00016920.0001001 / 21 MAR 16




Applicable to: ALL

Each container has an electrical latching mechanism that opens automatically to allow the masks to drop, if the cabin pressure altitude exceeds 14 000 ft (+250, -750 ft), or 16 000 ft (+250, -750 ft) for the operation on high altitude airfields  .

Members of the flight crew can override the automatic control.

When the masks are released, the passenger address system automatically broadcasts prerecorded instructions  .

The generation of oxygen begins when the passenger pulls the mask towards the passenger seat.


The chemical reaction used for oxygen generation creates heat. Therefore, the smell of burning, smokes and cabin temperature increase may be associated with the normal operation of the oxygen generators. The mask receives pure oxygen under positive pressure for about 13 min  , 15 min  , or up to 22 min  , until the generator is exhausted.

A reset is available for the rearming of the system after the masks are restowed. A manual release tool allows crew members to open the doors manually in case of electrical failure.

**SCHEMATIC**

Ident.: DSC-35-30-10-00001461.0001001 / 16 MAY 12


Applicable to: **ALL**



**OVERHEAD PANEL**

Ident.: DSC-35-30-20-00017805.0001001 / 21 MAR 16

Applicable to: ALL




(1) PASSENGER SYS ON light

This light comes on in white, when the control for the oxygen mask doors is activated, and it remains on until the TMR RESET pb is pressed (*Refer to DSC-35-30-20 Overhead Maintenance Panel*).

(2) MASK MAN ON pb

The guard keeps this button in the AUTO position.

**AUTO** : The mask doors open automatically, when the cabin altitude exceeds 14 000 ft, or 16 000 ft if the HI ALT LANDING pb-sw  is set to ON.

**Pressed** : The mask doors open.

(3) HI ALT LANDING pb-sw 

This pushbutton-switch changes the altitude threshold for the deployment of the passenger oxygen masks.


**OFF** : The masks drop, if the cabin pressure exceeds 14 000 ft (+250, -750 ft).

**ON** : The masks drop, if the cabin pressure exceeds 16 000 ft (+250, -750 ft).

**OVERHEAD MAINTENANCE PANEL**

Ident.: DSC-35-30-20-00001463.0001001 / 11 FEB 11

Applicable to: ALL



(1) TMR RESET pushbutton

The maintenance crew uses this pushbutton to reset the control circuit, after the system has operated.

**ON** : The PASSENGER SYS ON light goes off.

**FAULT** : This light comes on in white, when the door latch solenoids are energized for more than 30 s.

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-35-30-20-A-00016865.0001001 / 21 MAR 16

**HI ALT SET** : This memo appears in green if the crew sets the HI ALT LANDING pb-sw to ON. In this case, the passenger mask release altitude is 16 000 ft (+250 ft, -750 ft).


**FLIGHT CREWS PORTABLE OXYGEN SYSTEM**

Ident.: DSC-35-40-10-00001465.0004001 / 17 MAR 11

Applicable to: ALL

The flight crew smoke hood located on the right back side of the cockpit, ensures the eyes and respiratory system protection of one flight crew member when fighting a fire and in case of smoke or noxious gas emissions or cabin depressurization.

The smoke hood is equipped with one solid state oxygen supply source and one CO<sub>2</sub> absorption system, contained in a life support pack which furnish an effective time of use of 15 min.



**USING THE HOOD**


Ident.: DSC-35-40-10-00006226.0004001 / 22 MAY 12

Applicable to: **ALL**

- 1 REMOVE UNIT FROM CASE AND TEAR OFF RED PULL STRIP AND REMOVE UNIT FROM BAG.



- 2 PULL OUT ACTUATION RING.



- 3 BEND DOWN AND GRASP HOOD OPENING WITH THUMBS AND PULL HOOD OVER HEAD.



- 4 PULL HOOD DOWN ON FOREHEAD TO ASSURE A SECURE FIT. CHECK NECK SEAL.





# **AIRCRAFT SYSTEMS**

PNEUMATIC

Intentionally left blank

**DSC-36-10 Description**

DSC-36-10-10 General

General.....	A
--------------	---

DSC-36-10-20 Engine Bleed System

General.....	A
Architecture.....	B
Air Bleed Selection.....	C
Pressure Regulation and Limitation.....	D
Temperature Regulation and Limitation.....	E

DSC-36-10-30 APU Bleed Air Supply

General.....	A
--------------	---

DSC-36-10-40 Crossbleed

General.....	A
ECAM Indication.....	B

DSC-36-10-50 Leak Detection

Leak Detection.....	A
---------------------	---

DSC-36-10-60 Operation Following Failures

BMC Failure.....	A
------------------	---

**DSC-36-20 Controls and Indicators**

Overhead Panel.....	A
ECAM Bleed Page.....	B
Memo Display.....	C




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PNEUMATIC

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank




 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>PNEUMATIC</b></p> <p style="text-align: center;">DESCRIPTION - GENERAL</p>
---	--

**GENERAL**

Ident.: DSC-36-10-10-00020804.0001001 / 17 MAR 17

**Applicable to: ALL**

The pneumatic system supplies high-pressure air for :

- Air conditioning
- Engine starting
- Wing anti-icing
- Water pressurization
- Hydraulic reservoir pressurization
- FWD cargo heating 
- AFT cargo heating 
- Fuel Tank Inerting System (FTIS)  .

High-pressure air has three sources :

- Engine bleed systems
- APU load compressor
- HP ground connection

*Note:* An external HP source may be used for air conditioning.

A crossbleed duct interconnects the engine bleed systems and receives air from the APU and ground sources when appropriate.

A valve mounted on the crossbleed duct allows the left side (engine 1) and right side (engine 2) to be interconnected.

Two Bleed Monitoring Computers (BMC 1 and BMC 2), the overhead control panel, and the ECAM control and monitor the operation of the pneumatic system.

A leak detection system detects any overheating in the vicinity of hot air ducts.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**PNEUMATIC**

DESCRIPTION - GENERAL

Intentionally left blank

**GENERAL**

Ident.: DSC-36-10-20-00001469.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has two similar engine bleed air systems.

Each system is designed to :

- select the compressor stage to use as a source of air
- regulate the bleed air temperature
- regulate the bleed air pressure.

A Bleed Monitoring Computer (BMC) controls and monitors each system.

Each BMC receives information about bleed pressure and temperature and valve position.

Each is connected with :

- other systems using air or information from the bleed system
- the other BMC.

Each supplies indications and warnings to the ECAM and CFDS.


If one BMC fails, the other one takes over most of the monitoring functions.

Each bleed valve is pneumatically operated and controlled electrically by its associated BMC.

**ARCHITECTURE**

Ident.: DSC-36-10-20-00001470.0005001 / 15 MAR 17

Applicable to: ALL





**AIR BLEED SELECTION**

Ident.: DSC-36-10-20-00001471.0003001 / 09 OCT 12

Applicable to: ALL

Air is normally bled from the intermediate pressure stage (IP) of engine's high-pressure (HP) compressor to minimize fuel penalty.


At low engine speed, when the pressure and temperature of the IP air are too low, the system bleeds air from the HP stage and maintains it at  $36 \pm 4$  PSI.

An intermediate pressure check valve downstream of the IP port closes to prevent air from the HP stage from being circulated to the IP stage.

✎ The HP valve closes automatically

- • In case of low upstream pressure
- • in case of excessive upstream pressure
- electrically when the bleed valve is closed electrically.

**ECAM INDICATION**



**PRESSURE REGULATION AND LIMITATION**

Ident.: DSC-36-10-20-00001472.0004001 / 15 MAR 17

Applicable to: **ALL**

The bleed valve, which is downstream of the junction of HP and IP ducting, acts as a shut-off and pressure regulating valve.

It maintains delivery pressure at  $45 \pm 5$  PSI.

*Note:* Bleed pressure may fluctuate between 38 and 56 PSI (with a maximum peak to peak pressure of 16 PSI) particularly at high engine power (takeoff or climb) up to FL 100.

The bleed valve is fully closed:

- Pneumatically:

- If upstream pressure goes below 8 PSI
- If there is return flow

- Electrically by means of:

- The BLEED pushbutton switch (switched OFF)
- The ENG FIRE pushbutton (pushed)
- The Bleed air Monitoring Computer (BMC) in the following cases:
  - Overtemperature
  - Overpressure
  - Leak
  - Open starter valve
  - Engine shutdown
  - APU bleed being ON.

If pressure regulation fails, the overpressure valve closes when the pressure goes over 85 PSI.

*Note:* If APU Bleed is ON and the crossbleed valve is SHUT, the Engine bleed valve 2, remains open.

**TEMPERATURE REGULATION AND LIMITATION**

Ident.: DSC-36-10-20-00001473.0001001 / 21 MAR 16

Applicable to: **ALL**

A precooler downstream of the bleed valve regulates the temperature of the bleed air.

The precooler is an air-to-air heat exchanger that uses cooling air bleed from the engine fan to regulate the temperature to approximately 200 °C.

The fan air valve controls fan air flow.

A spring keeps the fan air valve closed in the absence of pressure.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PNEUMATIC

DESCRIPTION - ENGINE BLEED SYSTEM

Intentionally left blank

**GENERAL**

Ident.: DSC-36-10-30-00001474.0001001 / 15 MAR 17

**Applicable to: ALL**

Air from the APU load compressor is available on ground and in flight.

The APU bleed valve operates as a shut-off valve to control APU bleed air.

The APU BLEED pb-sw, on the AIR COND panel, controls the APU bleed valve. When the flight crew selects ON with the pushbutton, APU bleed air supplies the pneumatic system, if the APU speed is above 95 %. This opens the crossbleed valve and closes the engine bleed automatically. If the APU bleed valve is opened, it automatically closes in the case of APU leak, left wing leak, or engine 1 leak (except during engine start). *Refer to DSC-36-10-50 Leak Detection.*

A check valve near the crossbleed duct protects the APU, when bleed air comes from another source.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PNEUMATIC

DESCRIPTION - APU BLEED AIR SUPPLY

Intentionally left blank

**GENERAL**

Ident.: DSC-36-10-40-00001476.0001001 / 21 MAR 16

Applicable to: ALL

A crossbleed valve on the crossbleed duct allows the air supply systems of the two engines to be isolated or interconnected.

On the AIR COND panel, a rotary selector controls the crossbleed valve electrically.


Two electric motors, one for automatic mode and one for manual mode, control the valve.

In automatic mode, the crossbleed valve opens when the system uses APU bleed air. It closes, if the system detects an air leak (except during engine start).

**ECAM INDICATION**

Ident.: DSC-36-10-40-00001478.0002001 / 21 MAR 16

Applicable to: ALL



**X-BLEED VALVE OPEN. AIR SUPPLIED FROM APU**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PNEUMATIC

DESCRIPTION - CROSSBLEED

Intentionally left blank



**LEAK DETECTION**

Ident.: DSC-36-10-50-00001479.0001001 / 15 MAR 17

**Applicable to: ALL**


Leak detection loops detect any overheating near the hot air ducts in the fuselage, pylons, and wings.

For the pylon and APU, the sensing elements are tied to form a single loop and for the wing, a double loop.

When the two wing loops detect a leak, or when one loop detects the leak and the other one is inoperative, they activate a wing leak signal.

BMC 1 and BMC2 each contain identical control logic for the system.

- A wing leak signal causes :
  - the bleed valve on the related side to close automatically
  - the associated FAULT light on the AIR COND panel to come on
  - the x-bleed valve to close automatically (except during an engine start)
  - the APU bleed valve to close automatically if the APU bleed valve is open and if the leak concerns the left wing (except during engine start).
- A pylon leak signal causes :
  - the bleed valve on the related side to close automatically
  - the FAULT light for the related engine on the AIR COND panel to come on
  - the x-bleed valve to close automatically (except during an engine start).
  - the APU bleed valve to close automatically if the APU bleed valve is open and if the leak concerns the pylon 1 (except during engine start).
- An APU leak signal causes :
  - the APU bleed valve to close automatically (except during engine start).
  - the FAULT light the APU BLEED pushbutton switch on the AIR COND panel to come on
  - the x-bleed valve to close automatically (except during an engine start).



**BMC FAILURE**

Ident.: DSC-36-10-60-00001480.0001001 / 21 MAR 16

**Applicable to: ALL**

If one BMC fails, the adjacent BMC takes over the monitoring of the bleed system to issue the following ECAM warnings if necessary :

- overpressure
- overtemperature
- wing leak.

Nevertheless, the associated FAULT light on the AIR COND panel is lost, and the associated bleed valve does not close automatically.

ENG BLEED LEAK warning is lost for the associated engine, as is also the APU BLEED LEAK warning if BMC1 has failed.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### PNEUMATIC


DESCRIPTION - OPERATION FOLLOWING FAILURES

Intentionally left blank

**OVERHEAD PANEL**

Ident.: DSC-36-20-00001481.0001001 / 20 DEC 16

Applicable to: ALL



(1) ENG 1 and ENG 2 BLEED pb sw

On : Bleed valve opens if :

- Upstream pressure is above 8 PSI.
- APU BLEED pushbutton switch is off or APU bleed valve is closed.
- There is no outside wing or pylon leak, and no overpressure or overtemperature has been detected.
- The ENG FIRE pushbutton has not been popped out.
- The engine start valve is closed.

FAULT It : This amber light comes on, and an ECAM caution appears, if :

- There is an overpressure downstream of the bleed valve.
- There is a bleed air overheat.
- There is a wing or engine leak on the related side.
- The bleed valve is not closed during engine start.
- The bleed valve is not closed with APU bleed ON.

It goes out when the ENG BLEED pushbutton switch is OFF if the fault has disappeared.

OFF : The bleed valve and HP valve close. The white OFF light comes on.

(2) APU BLEED pb sw

**ON** : The APU valve opens if N > 95 % and there is no leak in the APU or in the left side bleed. (If there is a leak on the right side, the x-bleed valve closes.)  
 The blue ON light comes on.

**Off** : The APU valve closes.

**FAULT** : This amber light comes on, and an ECAM caution appears, when the system light detects an APU leak.

(3) X-BLEED selector sw

**AUTO** : The crossbleed valve is open if the APU bleed valve is open.  
 The crossbleed valve is closed if the APU bleed valve is closed or, in case of a wing, pylon, or APU leak (except during engine start).


**OPEN** : The crossbleed valve is open.

**SHUT** : The crossbleed valve is closed.

**ECAM BLEED PAGE**

Ident.: DSC-36-20-00001482.0002001 / 09 OCT 12

Applicable to: **ALL**




(1) HP VALVES

- Crossline - Green : HP valve normally fully closed
- In line - Green : HP valve not fully closed
- Crossline - Amber : HP valve not in commanded (closed) position

(2) ENGINE BLEED VALVES

- In line - Green : BLEED valve normally open
- Crossline - Green : BLEED valve normally fully closed
- In line - Amber : BLEED valve not in commanded (open) position
- Crossline - Amber : BLEED valve not in commanded (closed) position

(3) ENGINE BLEED INDICATIONS



(A) Precooler inlet pressure

It is normally in green.

It becomes amber, if under 4 PSI, or if overpressure is detected by the BMC (threshold between 57 and 60 PSI).

(B) Precooler outlet temperature

It is normally in green.

It becomes amber, if the BMC detects an overheat or low temperature.

Overheat: Temperature exceeds:

- 290 °C for more than 5 s, or
- 270 °C for more than 15 s, or
- 257 °C for more than 55 s

Low temperature is detected, if the temperature is lower than 150 °C.

*Note: When the engines are at idle, and depending on the ambient temperature, the precooler outlet temperature may be below 150 °C (displayed amber).*

(4) APU BLEED VALVE

- Crossline - Green : The APU valve is not fully open, and the APU master switch is ON.  
 In line - Green : The APU valve is fully open, and the APU master switch is ON.  
 Crossline - Amber : The APU valve is fully closed, the APU master switch is ON, and the APU bleed switch is ON for more than 10 s.

(5) CROSSBLEED VALVE

- Crossline - Green : The crossbleed valve is normally closed.  
 In line - Green : The crossbleed valve is normally open.  
 Crossline - Amber : The crossbleed valve is not in the commanded (closed) position.  
 In line - Amber : The crossbleed valve is not in the commanded (open) position.  
 Transit - Amber : The crossbleed valve is in transit.

(6) GND HP ground connection indication



: Displayed in white when the aircraft is on ground.

(7) ANTI ICE indication

It is displayed in white, when the WING pushbutton on the ANTI-ICE panel is ON.

(8) Arrow



- : - It is normally not displayed, when the corresponding valve is closed.  
 - It is normally displayed in green, when the corresponding valve is open.  
 - It becomes amber, when the
- Valve is open and air pressure is low or high, or
  - Valve is open on ground for more than 10 s.

(9) Engine identification (1-2)

It is normally in white.

It becomes amber, when engine N2 is below idle.

**MEMO DISPLAY**

Ident.: DSC-36-20-00016746.0001001 / 21 MAR 16

Applicable to: **ALL**

**APU BLEED** : This memo appears in green, if the APU is available and the APU BLEED pb-sw is ON.



# **AIRCRAFT SYSTEMS**

WATER / WASTE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**WATER / WASTE**

PRELIMINARY PAGES - TABLE OF CONTENTS

**DSC-38-10 Description**

General.....	A
Potable Water.....	B
Wastewater System.....	C
Toilet System.....	D




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### WATER / WASTE

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>WATER / WASTE</b></p> <p style="text-align: center;">DESCRIPTION</p>
---	---

**GENERAL**

Ident.: DSC-38-10-00017274.0001001 / 21 MAR 16  
**Applicable to: ALL**

- The water and waste systems :
- Distribute potable water to the toilets and the galleys
  - Dispose waste water
  - Store toilet wastes.

The systems are insulated to prevent water leaks and ice build up.  
 Controls of the water and waste systems are located on the Forward Attendant Panel (FAP).



**POTABLE WATER**

**Applicable to: ALL**

Ident.: DSC-38-10-A-00017286.0002001 / 21 MAR 16


Potable water is stored in a 200 l water tank located in front of the wing box, behind the FWD cargo compartment.

On ground, the water system is pressurized by the air from the service panel pressure port. In flight, the water system is pressurized by the bleed air.

Potable water is piped to the galleys and lavatories. Manual shutoff valves  isolate wet galleys, the FWD lavatory, the MID lavatory  and the AFT lavatory from the water system. Manual shutoff valves are located under the washbasins or toilet bowls. The position of each valve is indicated by OPEN and SHUT legend.

The system can be filled or drained from the service panel under the fuselage. The indication of the water quantity in the water tank is displayed on the FAP and the aft service panel.

Ident.: DSC-38-10-A-00017435.0001001 / 21 MAR 16



**WASTEWATER SYSTEM**


Ident.: DSC-38-10-00017287.0001001 / 21 MAR 16

Applicable to: ALL

The waste/water (from galleys and lavatories) drains overboard through two heated drain masts. The forward mast drains the waste/water from the forward cabin. The aft mast drains the waste/water from the aft cabin.

The waste and water are discharged by:

- Gravity, on ground
- Differential pressure, in flight.



**TOILET SYSTEM**

Ident.: DSC-38-10-00017288.0002001 / 21 MAR 16

Applicable to: ALL

Differential pressure forces the waste from the toilet bowls into the waste tank. The waste tank has a usable capacity of 170 l. On ground, and in flight below 16 000 ft , the differential pressure is generated by the vacuum generator.

Clean water from the potable water system flushes toilets.


A flush control unit controls the flush sequence in each toilet.

The Vacuum System Controller (VSC) ensures system control, monitoring and fault reporting.


The VSC transmits information to:

- Flight attendant panel to indicate the waste tank levels and report system defects
- Centralized Fault Display System (CFDS) to signal the system defects to the maintenance.

Ground personnel services the waste tank via a service panel, located under the fuselage.


A manual shutoff valve isolates an inoperative toilet. In the case of an electrical failure of flush valve, the manual flush control  can be used. The manual flush control is located under each toilet bowl.

**ARCHITECTURE**





**SCHEMATIC**



**AIRCRAFT SYSTEMS**

**WATER / WASTE**

DESCRIPTION

Intentionally left blank

# **AIRCRAFT SYSTEMS**

## **MAINTENANCE SYSTEM**

Intentionally left blank

**DSC-45-10 Description**

General.....	A
Components.....	B
Modes of Operation.....	C
Architecture.....	D
Failure/Fault Classification.....	E
Functions of the Centralized Fault Display System (CFDS).....	F
Cockpit/CFDS Interface.....	G

**DSC-45-20 System Operation**

Maintenance Menu.....	A
Last (or Current) Leg Report.....	B
Last (or Current) Leg ECAM Report.....	C
Previous Leg Report.....	D
Avionics Status.....	E
System Report/Test.....	F
GMT/Date Initialization.....	G
Backup Mode.....	H
ACARS Print Program.....	I

**DSC-45-25 Data Loading**

General.....	A
Data Loading Selector on the Overhead Panel.....	B

**DSC-45-30 Printer**

General.....	A
System Description.....	B




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**MAINTENANCE SYSTEM**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>MAINTENANCE SYSTEM</b></p> <p style="text-align: center;">DESCRIPTION</p>
---	---

<b>GENERAL</b>
----------------

Ident.: DSC-45-10-00001490.0001001 / 21 MAR 16

**Applicable to: ALL**

The purpose of the Centralized Fault Display System (CFDS) is to make the maintenance task easier by displaying fault messages in the cockpit and permitting the flight crew to make some specific tests.

There are two levels of maintenance :

- at the line stop : removal and replacement of equipment
- at the main base : troubleshooting

<b>COMPONENTS</b>
-------------------

Ident.: DSC-45-10-00001491.0001001 / 21 MAR 16

**Applicable to: ALL**

The CFDS includes :

- the BITE (Built-In Test Equipment) for each electronic system
- a central computer, the Centralized Fault Display Interface Unit (CFDIU)
- two MCDU s (Multipurpose Control and Display Units), used also for FMGS (Flight Management and Guidance System), AIDS (Aircraft Integrated Data System), and ACARS (Aircraft Communication And Reporting System, if installed), which work with the CFDIU to display information or initiate tests
- one printer.

If a main channel of the CFDIU fails, the backup channel takes over.

<b>MODES OF OPERATION</b>
---------------------------

Ident.: DSC-45-10-00001492.0001001 / 22 MAR 16

**Applicable to: ALL**

The CFDS operates in two main modes :

- the NORMAL mode or REPORTING mode (in flight)
- the INTERACTIVE mode or MENU mode (on ground).


In NORMAL mode, the CFDS records and displays the failure messages transmitted by each system BITE.

In INTERACTIVE mode, the CFDS allows any BITE to be connected with the MCDU in order to display the maintenance data stored and formatted by the BITE or to initiate a test.


**ARCHITECTURE**

Ident.: DSC-45-10-00001493.0002001 / 19 DEC 12

Applicable to: ALL





 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>MAINTENANCE SYSTEM</b>  DESCRIPTION
---	---

**FAILURE/FAULT CLASSIFICATION**

Ident.: DSC-45-10-00017082.0001001 / 21 MAR 16

Applicable to: ALL

The Centralized Fault Display System (CFDS) identifies the faulty system and puts any failures or faults into one of three classes :

- Class 1: Failures indicated to the flight crew by means of the ECAM , or other flight deck effect. They must be repaired or entered in the MEL (Minimum Equipment List) before the aircraft can depart.
- Class 2: Faults indicated to maintenance personnel by the CFDS and which trigger a MAINT status entry on the maintenance part of the ECAM status page. The aircraft can operate with these faults, but they must be rectified within the timescale defined in the Trouble Shooting Manual (TSM).
- Class 3: Faults indicated to maintenance personnel by the CFDS , but which do not trigger a MAINT status. The operator may have these faults corrected at his convenience.

Failure/fault classes	Class 1	Class 2	Class 3
<b>Operational consequences</b>	YES	NO	NO
<b>Indication to the flight crew</b>	YES Automatically displayed - Warning or caution messages on Engine Warning Display - Flag or indication in the flight deck.	YES Available on ECAM status page.	NO
<b>Dispatch consequences</b>	Refer to MEL may be : "GO" "GO IF" "NO GO"	<i>Refer to MMEL/MI-00-08 ECAM and MAINTENANCE STATUS</i>	MEL not applicable
<b>Indication to the maintenance team</b>	YES Automatically print out at the end of each flight : Fault messages on the CFDS Post Flight Report.		YES Available on request through system report/Test


**FUNCTIONS OF THE CENTRALIZED FAULT DISPLAY SYSTEM (CFDS)**

Ident.: DSC-45-10-00001495.0002001 / 21 MAR 16

Applicable to: ALL

The main functions of the CFDS are :

- obtaining and storing messages transmitted by the connected system BITEs, or by the Flight Warning Computer (Warning and Caution titles)
- Detailing the maintenance phases.




- Presenting maintenance reports :
  - Last leg report
  - Last leg ECAM report
  - Previous leg report
  - Avionics status
  - System report test
  - Post-flight report.

**COCKPIT/CFDS INTERFACE**

Ident.: DSC-45-10-00001496.0001001 / 22 MAR 16

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**MAINTENANCE SYSTEM**

DESCRIPTION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**MAINTENANCE SYSTEM**  
SYSTEM OPERATION


## MAINTENANCE MENU

Ident.: DSC-45-20-00001497.0002001 / 14 MAY 12

**Applicable to: ALL**

The CFDS uses menus displayed on the MCDU. The operator selects functions or reports from these menus.

Pressing the MCDU MENU key and then selecting CFDS brings up the MAINTENANCE MENU page (different pages for the aircraft in flight and the aircraft on the ground).




### LAST (OR CURRENT) LEG REPORT

Ident.: DSC-45-20-00001498.0001001 / 21 MAR 16

Applicable to: ALL

The LAST LEG REPORT (on the ground) or the CURRENT LEG REPORT (in flight), list all class 1 failures and class 2 faults and all system failure and system fault messages received by the CFDS during the last flight leg or the current flight leg. Pressing the IDENT key displays a list of the systems

(called identifiers) affected by the failure or fault, which helps the pilot or maintenance person to identify the failure or fault.




**LAST (OR CURRENT) LEG ECAM REPORT**

Applicable to: ALL

Ident.: DSC-45-20-A-00001499.0001001 / 21 MAR 16

**GENERAL**

- In flight : The CURRENT LEG ECAM REPORT displays the primary and independent warning (class I) messages and MAINTENANCE STATUS (class II) messages of the current flight leg.
- On the ground : The LAST LEG ECAM REPORT displays the primary and independent warning (class I) messages plus MAINTENANCE STATUS (class II) messages of the last flight leg.



*Note:* This screen displays PRINT only if the printer is installed.

Ident.: DSC-45-20-A-00001500.0001001 / 14 MAY 12

### POST FLIGHT REPORT PRINT

At the end of a flight, LAST LEG and LAST LEG ECAM REPORTS are printed out automatically after the last engine shutdown. The flight or ground crew can also print them out by selecting POST FLIGHT REP PRINT.

The report first lists the ECAM warnings, then the FAULT messages.



## CFDS POST FLIGHT REPORT

A/C IDENT	DATE	GMT	FLTN	CITY PAIR
XY-ABCD	FEB23	2355	XY-1234	LFBO/LFPO

ECAM WARNINGS

GMT	ATA PH	
1012	27-00 06	SFCC 1 FAULT
0954	22-00 06	LAND3 INOP
0933	26-12 05	ENG 1 LOOP A FAULT
0922	22-00 05	ATS DISCONNECT
0915	28-21 04	FUEL L TK PUMP 1 LO PR
0904	36-22 04	BLEED LOOP

FAULT MESSAGES

GMT	ATA	
1105	26-12-00	CHECK LGCIU-PHC 1 INTERFACE (INTMT)
1012	27-00-00	EIU 1--NO SFCC 1 DATA
0954	22-00-00	FMGC 1
0933	36-11-00	BMC 1
0915	28-21-00	FUEL L TK PUMP 1 QM
0904	26-12-00	CHECK R WING LOOP A


COMMENTS


**PREVIOUS LEG REPORT**

Ident.: DSC-45-20-00001501.0001001 / 21 MAR 16

**Applicable to: ALL**

This report gives access to the POST FLIGHT REPORTS of the previous 63 flight legs.




On ground, the Operator can print copies of the screen. If ACARS is installed, the Operator can send the flight report (*Refer to DSC-45-20 Last (or Current) Leg ECAM Report - Post Flight Report Print*).

### AVIONICS STATUS

Ident.: DSC-45-20-00001502.0001001 / 21 MAR 16

Applicable to: ALL

This screen displays the list of systems affected by a failure or fault. If a system is affected by at least a Class 3 fault, CLASS 3 appears beside it. The display is continuously updated.




**SYSTEM REPORT/TEST**

Ident.: DSC-45-20-00001503.0001001 / 21 MAR 16


**Applicable to: ALL**

This screen gives the operator access to all electronic systems. The CFDIU enters into interactive dialogue with the selected system.



In the above example, the operator has called up menus of the selected systems :

- LAST or PREVIOUS LEG REPORT presents the list of Line-Replaceable Units (LRUs) affected by a failure.
- LRU IDENTIFICATION contains the part numbers of all LRUs in the system.
- GND SCANNING runs the flight monitoring on the ground and indicates the faulty LRU.
- CLASS 3 FAULTS lists class 3 faults detected by the system during the last flight leg.
- SYSTEM CONFIGURATION presents the system configuration in a digital form.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>AIRCRAFT SYSTEMS</b> <b>MAINTENANCE SYSTEM</b></p> <p>SYSTEM OPERATION</p>
---	--

*Note: These screens (except LAST or PREVIOUS LEG REPORT) are not shown above.*

<b>GMT/DATE INITIALIZATION</b>
--------------------------------


Ident.: DSC-45-20-00001504.0001001 / 21 MAR 16

**Applicable to: ALL**

A CFDIU clock is synchronized with the cockpit clock in order to keep GMT (UTC ) displayed on the ECAM lower display (except in flight Phases 1 and 2, if the weight and balance system is installed). If the cockpit clock fails, the CFDIU clock continues to display GMT (UTC ) on the ECAM lower display.

If electrical power is interrupted for more than 200 ms, the crew initializes GMT (UTC ) and the DATE via the MCDU :

- Write GMT (UTC) in the scratchpad, then press the “INIT GMT” key.
- Do the same for the month and day.




## BACKUP MODE

Ident.: DSC-45-20-00017066.0001001 / 21 MAR 16


Applicable to: ALL

If the main channel of the CFDIU fails, the backup channel allows the CFDS to operate in backup mode :

- On the ground only
- Through MCDU1 or MCDU3 
- In one mode of operation only : SYSTEM REPORT/TEST
- Without the PRINTER or ACARS.

The system changes over from main channel to backup channel :

- Automatically in case of an important failure (power supply, for example). In this case, when the operator selects CFDS on the MCDU MENU, it displays the BACKUP MODE page.
- Manually if the operator selects BACKUP MODE on the CFDS menu after a minor failure.



## ACARS PRINT PROGRAM

Ident.: DSC-45-20-00005361.0001001 / 14 FEB 11

Applicable to: **ALL**

This function gives access to reprogramming page.

The programming is provided by the ACARS or manually (on the ground or in flight) :



No star indicates an ACARS programming. The YES indicates that the REAL TIME FAIL will be automatically transmitted to the ACARS.

The star indicates a manually modified programming: pressing the corresponding key changes the YES into a NO. The YES indicates that the REAL TIME FAIL page will be printed simultaneously with the transmission to the ACARS.

**ACARS/PRINT PROGRAM**

1L	SEND	PRINT		1R
	NO POST FLT REP NO *			
2L	YES REAL TIME FAIL YES*			2R
3L	YES REAL TIME WARN NO*			3R
4L	*YES AVIONICS DATA YES			4R
5L				5R
6L	<RETURN	PRINT *		6R


Note: The CFDIU memorizes all manual programming so that at initialisation the last configuration will be retained.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**MAINTENANCE SYSTEM**  
SYSTEM OPERATION

Intentionally left blank


 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS MAINTENANCE SYSTEM</b></p> <p align="center">DATA LOADING</p>
---	---

**GENERAL**

Ident.: DSC-45-25-00001506.0001001 / 10 JAN 11

**Applicable to: ALL**

With the data loading system, it is possible to upload databases and operational software, or to download system reports from various onboard computers.


The data transfer is performed via 3.5 in disks and a portable data loader, or the aircraft fixed Multipurpose Disk Drive Unit  (MDDU).

**DATA LOADING SELECTOR ON THE OVERHEAD PANEL**

Ident.: DSC-45-25-00001507.0001001 / 19 DEC 12

**Applicable to: ALL**



When the data loading selector is ON, the 3 keys (NEXT, PREV, SEL CTRL) enable the display and selection of various applicable aircraft systems (FMGC , TCAS  etc...).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**MAINTENANCE SYSTEM**

DATA LOADING

Intentionally left blank

**GENERAL**

Ident.: DSC-45-30-00001508.0001001 / 21 MAR 16

**Applicable to: ALL**


The printer prints reports from the following systems (if installed) : ACARS , AIDS , FMGC , CFDIU and EVMU. It prints these on paper, and does so either on the ground or in flight.

The printer is installed at the rear of the pedestal on the right side.

**SYSTEM DESCRIPTION**

Ident.: DSC-45-30-00001509.0001001 / 21 MAR 16

**Applicable to: ALL**



- (1) SLEW sw :  
The SLEW switch is used to feed paper after having loaded a new roll.
- (2) PRINTER DOOR LATCH :  
The printer door latch locks the door used for loading paper.

# **AIRCRAFT SYSTEMS**

## INFORMATION SYSTEMS

Intentionally left blank



**DSC-46-10 Datalink**

DSC-46-10-10 General System Description

Overview.....	A
Architecture.....	B
Cockpit Interface.....	C

DSC-46-10-20 AOC Applications

DSC-46-10-20-10 General

General.....	A
--------------	---

DSC-46-10-40 Controls and Indicators

DSC-46-10-40-30 MCDU Datalink Pages

ATSU DATALINK.....	A
COMM MENU.....	B
VHF3 SCAN SELECT.....	C

DSC-46-10-40-40 MCDU Scratchpad Messages

MCDU Scratchpad Messages.....	A
-------------------------------	---

DSC-46-10-40-60 ECAM

Memo Display.....	A
-------------------	---

DSC-46-10-50 How To

Introduction.....	A
How to Initialize.....	B
How to Modify FLT Plan.....	C

**DSC-46-20 Electronic Flight Bag (EFB)**

DSC-46-20-20 Applications

Introduction.....	A
General.....	B
Landing Application.....	C
Takeoff Application.....	D
Loadsheet Application.....	E
OPS Library Application.....	F
Manager Application.....	G

**DSC-46-30 Electronic QRH (eQRH)**

General.....	A
--------------	---

*Continued on the following page*


*Continued from the previous page*

**DSC-46-40 Pax Entertainment & Connectivity Systems (If Installed)**


**DSC-46-40-10 General**


General..... A


**DSC-46-40-20 In Seat Power Supply System**


IN SEAT POWER SUPPLY SYSTEM  ..... A


**DSC-46-40-30 Controls and Indicators**


MOBILE COM PB-SW  ..... A

DISC IN PROG Light  ..... B

CINS RESET PB  ..... C

PAX COM PB-SW  ..... D

PAX SYS PB-SW  ..... E

PAX PERSONAL ELEC SPLY PB-SW  ..... F







MEMO DISPLAY..... G

## OVERVIEW

Ident.: DSC-46-10-10-00020333.0001001 / 17 MAR 17

Applicable to: ALL

The datalink has:

- AOC applications 
-  The flight crew uses the AOC applications to communicate with Airline Operational Center (AOC).
-  - ATC applications 
-  The flight crew uses the ATC applications to communicate with Air Traffic Control (ATC) centers.
-  The ATC datalink provides communication, navigation, and surveillance for Air Traffic Management (ATM) services.

The ATC datalink applications enable air traffic controllers to follow the aircraft navigation, and enhance the air traffic flow.


The datalink communication (messages exchange) between the aircraft and the ground is achieved:




- Automatically (without a flight crew action)
- Manually (with a flight crew action via the DCDU /MCDU and/or RMP).

The datalink messages are:







- Uplink (from a ground facilities to the flight crew), or
- Downlink (from the flight crew to an ground facilities).

### **COMMUNICATION AND NAVIGATION FOR AIR TRAFFIC MANAGEMENT**

At the beginning of the flight, the flight crew sends a notification message to the ATC center, via the MCDU, notification application .




-  Refer to *DSC-46-10-30-10 Notification* for more information.
-  Then, an air traffic controller will establish a connection between the aircraft and the ATC center. As a result, the flight crew can exchange messages with the ATC center, via the DCDU (CPDLC application ). The messages that the flight crew sends to the ATC center can be built with present frames and modified via the MCDU.

Depending on the type of datalink exchange, the datalink uses one of the following communication networks:

- ACARS (*Refer to DSC-23-30-30-10 Introduction*) for FANS A  / FANS A+  applications
- ACARS Air Traffic Services (ATS 623) for optional applications 
- Aeronautical Telecommunication Network (ATN) for FANS B  / FANS B+  applications
-  The ATN supports increasing volume of ATC and AOC communication.

## **L1 FUTURE AIR NAVIGATION SYSTEM (FANS)**


The ATC datalink provides:


- FANS A  applications, for operations in remote and in oceanic areas:
  - Notification
  - Controller-Pilot Data Link Communication (CPDLC)
  - Automatic Dependent Surveillance Contract (ADS-C).
- FANS B  applications, for operations in high-density continental areas:
  - Notification
  - Controller-Pilot Data Link Communication (CPDLC).
- Optional applications  (compatible only with FANS A+ or FANS B+):
  - Departure Clearance
  - Oceanic Clearance
  - Digital - Automatic Terminal Information Service (D-ATIS).

## **NAVIGATION AND SURVEILLANCE FOR AIR TRAFFIC MANAGEMENT**


The Automatic Dependent Surveillance (ADS ) system sends aircraft position and aircraft navigation data to ATC centers and other aircraft.



There are two different ADS applications:

- ADS-Contract (ADS-C) 

The ADS-C automatically sends aircraft surveillance data to connected ATC centers via ATC Datalink  in remote or oceanic areas.

**L2** *Refer to DSC-46-10-30-30 ADS-C for more information, about ADS-C application.*

- ADS-Broadcast (ADS-B) 

The ADS-B automatically broadcasts the aircraft position and navigation data to other users (ATC centers or other aircraft) equipped with a Mode S transponder. The ATC Datalink  does not host the ADS-B .


**L2** *Refer to DSC-34-SURV-10-10 ADS-B OUT for more information, about the ADS-B.*

## **L1 SERVICE PROVIDERS**

The role of a communication service provider is to deliver a message from the A/C to a ground end system and vice versa.

A datalink service provider ensures routing of datalink messages between the aircraft and ATC center.

- L2** For VHF communication, the two main providers are ARINC and SITA that operate worldwide networks.

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b>  <b>INFORMATION SYSTEMS</b></p> <p style="text-align: center;">DATALINK - GENERAL SYSTEM DESCRIPTION</p>
---	---

**LT REVERSION TO VOICE COMMUNICATION**

Voice communication is a primary means of communication on board.

The flight crew must revert from datalink communication to voice communication, if:

- There is an emergency situation (exchange of a critical or urgent message)
- There is a doubt about a datalink message, the voice should be used for clarification
- An operational timer of datalink message exchange times out
- A response to an ATC message was not correctly transmitted via datalink.

**CLOCK ACCURACY**

The required time precision for ATC datalink communications is +/-1 s UTC. If this constraint is not respected, a rejection of datalink message or acceptance of obsolete datalink message may occur.

Not respecting this constraint may lead to the rejection of messages or to the acceptance of obsolete messages.

For FANS operations, the flight crew should not manually set the clock during cockpit preparation.

**ARCHITECTURE**

**Applicable to: ALL**



Ident.: DSC-46-10-10-00020329.0001001 / 17 MAR 17

**AIR TRAFFIC SERVICE UNIT (ATSU)**

The ATSU controls all datalink communication and automatically selects the best available communication media:

- VHF
- HF 
- SATCOM  .

The ATSU hosts:

- AOC applications 
- ATC applications 
- Router services


The ATSU routers automatically select VHF frequency, depending on the aircraft position, in accordance with an entered scan mask (airline policy).


The scan mask means that a list of VHF datalink service providers, selected via the VHF3 SCAN SELECT page, is scanned, in accordance with their priority level. The VHF scan mask is compulsory for correct router operation. If there is no scan mask, the ECAM displays DATALINK ATSU FAULT – ATSU INIT FAULT.

*Refer to DSC-46-10-40-30 VHF3 SCAN SELECT for more information about the VHF3 SCAN SELECT page.*

Ident.: DSC-46-10-10-10-00020319.0001001 / 17 MAR 17

## **SATELLITE COMMUNICATIONS (SATCOM)**

The SATCOM system  provides voice and data services. The voice/data are transmitted via satellite, from the aircraft to the ground earth stations, and then switched through international telecommunications networks (ARINC, SITA, etc.) to anywhere in the world (airline operational centers, ATC centers, etc).

The ATSU (router) manages switching to/from SATCOM  (ACARS environments only).

Ident.: DSC-46-10-10-10-00020321.0002001 / 17 MAR 17

## **VERY HIGH FREQUENCY (VHF)**

The communication between the aircraft and VHF ground stations is established on a VHF frequency. The datalink system primarily uses the VHF 3 radio communication system. The ATSU router automatically selects a VHF frequency, depending on entered configuration, the scan mask for VHF DataLink (VDL), and the aircraft position.

VHF data link service providers are available in each geographical area. *Refer to DSC-23-30-30-40 World Map ACARS Frequencies* for a world map of VHF ACARS frequencies.

The VHF3 radio communication system has:

- Data mode
- Voice mode.

## **DATALINK/VOICE SWITCHING**

The VHF 3 can be used in the voice mode, in case of:

- VHF 1 failure
- VHF 2 failure
- Specific AOC functions (operator's customization).

The flight crew can switch datalink/voice via the RMP , or via VHF3 VOICE DIRECTORY page of the MCDU.

The voice frequency can be tuned by:


- ATSU automatically
- Fight crew, via the RMP.

Green **HF VOICE** memo indicates that VHF 3 datalink communication is interrupted, when the VHF 3 transceiver operates in the voice mode.



**COCKPIT INTERFACE**


Ident.: DSC-46-10-10-00020373.0001001 / 17 MAR 17

Applicable to: ALL




The cockpit interface of the datalink system has:

- Datalink Control and Display Unit (DCDU)  on the CAPT and F/O side  
The DCDU displays the uplink and downlink messages and enable the flight crew to control the datalink message exchange.
- ATC MSG pb-sw  on the CAPT and F/O side of the glareshield  
The ATC MSG pb-sw alerts when an uplink message is received and enables the flight crew to cancel the alert.

- Multipurpose Control and Display Unit (MCDU)  
The MCDU enables to manage AOC and ATC functions and data transfer to the DCDU 
- Printer  
Datalink messages can be printed, when displayed on the DCDU.
- RMP  
The RMP enables frequency tuning.
- ECAM  
The ECAM informs about the abnormal operation.




 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>AIRCRAFT SYSTEMS</b> <b>INFORMATION SYSTEMS</b> DATALINK - AOC APPLICATIONS
---	--

**General**

**GENERAL**

Ident.: DSC-46-10-20-10-00020385.0001001 / 17 MAR 17

Applicable to: ALL

The AOC applications  are datalink applications. The AOC applications enable an exchange of specific messages between the flight crew and the Airline Operational Control (AOC). The AOC applications are customized by each operator and depend on operator's choices and the datalink service provider.

*Note:* Details about AOC applications cannot be provided due to the wide range of customization by the operator.  
 Airbus does not supervise customization of AOC applications. It is recommended to insert AOC application description into this chapter in accordance with AOC applications installed on the aircraft.

The AOC applications can offer the following functions:

<b>EXAMPLE</b>	<ul style="list-style-type: none"> <li>- Preflight Functions:           <ul style="list-style-type: none"> <li>- Flight log</li> <li>- Departure Delay Message</li> <li>- Takeoff Delay Message</li> <li>- Weather Request</li> <li>- NOTAM Request</li> <li>- Loadsheet Request</li> <li>- Others</li> </ul> </li> <li>- En-Route Functions:           <ul style="list-style-type: none"> <li>- Flight log</li> <li>- Diversion Message</li> <li>- En-route Delay</li> <li>- Estimated Time of Arrival (ETA) Message</li> <li>- Weather Request</li> <li>- NOTAM Request</li> <li>- Others</li> </ul> </li> <li>- Postflight Functions:           <ul style="list-style-type: none"> <li>- Flight log</li> <li>- Flight summary</li> <li>- Gate delay</li> <li>- Others</li> </ul> </li> </ul>
----------------	---

The flight crew uses the datalink cockpit interface for the AOC applications.

**EXAMPLE**

**Flight Plan Modification**

This flight plan modification example is based on following assumptions:

- The AOC sends a flight plan modification message to the flight crew.
- The flight crew loads the flight plan modification in the FMGS , into the secondary F-PLN.
- The crew obtains ATC clearance before activating the modified flight plan.
- *Refer to DSC-46-10-50 How to Modify FLT Plan for the flight plan modification based on an AOC request.*

**MCDU Datalink Pages**

**ATSU DATALINK**

Ident.: DSC-46-10-40-30-00021081.0003001 / 17 MAR 17  
Applicable to: ALL



[1R] AOC MENU

When selected, the MCDU displays the AOC MENU page.


[6R] COMM

When selected, the MCDU displays the COMM MENU page.

**COMM MENU**

Ident.: DSC-46-10-40-30-00021090.0003001 / 17 MAR 17  
Applicable to: ALL

<b>EXAMPLE</b>	This is an example of the COMM MENU page. Information, that are displayed on the COMM MENU page and subsequent pages, accessible via the COMM MENU page, depend on datalink customization, selected by each operator for AOC applications.
----------------	--



<b>EXAMPLE</b>	[1L] COMM INIT	When selected, the DCDU displays the COMM INIT page.
	[2L] VHF3 DATA MODE	When selected, the DCDU displays the VHF3 DATA MODE page.
	[3L] VHF3 VOICE DIRECTORY	When selected, the DCDU displays the VHF3 VOICE DIRECTORY page.
	[6L] RETURN TO ATSU DLK	When selected, the MCDU displays the ATSU DATALINK page.
	[1R] COMM STATUS	When selected, the DCDU displays the COMM STATUS page.
	[2R] COMPANY CALL	When selected, the DCDU displays the COMM CONFIG page.
	[4R] MAINTENANCE	When selected, the MCDU displays the MAINTENANCE page.
	[6R] AUTO PRINT	Sets the auto-print on or off.

**VHF3 SCAN SELECT**

Ident.: DSC-46-10-40-30-00021254.0001001 / 17 MAR 17

Applicable to: ALL

<b>EXAMPLE</b>	This is an example of VHF3 SCAN SELECT pages. Information, that are displayed on the VHF3 SCAN SELECT pages, depend on datalink customization, selected by each operator.
----------------	---

**THE VHF 3 SCAN SELECT PAGE 1/4**



<b>EXAMPLE</b>	[1L] SITA EUR/AF	Selects the SITA Europe/Africa (datalink service provider).
	[5L]: NEW SCAN SELECT :	Selects the scan mask.
	ACTIVE SEL DISPLAY :	Displays the scan mask used by ATSU.
	[6L] RETURN	When selected, the MCDU displays the COMM CONFIG page.
	[1R] ARINC EUROPE	Selects the ARINC Europe (datalink service provider).
	[2R] ARINC MIDDLE EAST	Selects the ARINC Middle East (datalink service provider).
	[3R] ARINC INDIA	Selects the ARINC India (datalink service provider).
[5R] EMPTY SCAN ACTIVATE	Activates an empty scan mask to inhibit VHF datalink communication.	
[6R] SCAN SEL PRINT	When selected, the printer prints information.	

**THE VHF 3 SCAN SELECT PAGE 2/4**



EXAMPLE		
[1L]	SITA PACIFIC	Selects the SITA Pacific (datalink service provider).
[4L]	AVICOM JAPAN	Selects the AVCOM Japan (datalink service provider).
[5L]:	NEW SCAN SELECT :	Selects the scan mask.
	ACTIVE SEL DISPLAY :	Displays the scan mask used by ATSU.
[6L]	RETURN	When selected, the MCDU displays the COMM CONFIG page.
[1R]	ARINC RUSSIA	Selects the ARINC Russia (datalink service provider).
[2R]	ARINC ASIA	Selects the ARINC Asia (datalink service provider).
[3R]	ARINC AUSTRAL	Selects the ARINC Australia (datalink service provider).
[4R]	ARINC KOREA	Selects the ARINC Korea (datalink service provider).
[5R]	EMPTY SCAN ACTIVATE	Activates an empty scan mask, in order to inhibit VHF datalink communication.
[6R]	SCAN SEL PRINT	When selected, the printer prints information.

**THE VHF 3 SCAN SELECT PAGE 3/4**



<b>EXAMPLE</b>	[1L] SITA NORTH AM	Selects the SITA North America (datalink service provider).
	[2L] SITA SOUTH AM	Selects the SITA South America (datalink service provider).
	[3L] DEP V BRASIL	Selects the DEP V Brasil (datalink service provider).
	[5L]:	
	NEW SCAN SELECT :	Selects the scan mask.
	ACTIVE SEL DISPLAY :	Displays the scan mask used by ATSU.
	[6L] RETURN	When selected, the MCDU displays the COMM CONFIG page.
	[1R] ARINC AMERICA	Selects the ARINC America (datalink service provider).
[5R] EMPTY SCAN ACTIVATE	Activates an empty scan mask, in order to inhibit VHF datalink communication.	
[6R] SCAN SEL PRINT	When selected, the printer prints information.	

**THE VHF 3 SCAN SELECT PAGE 4/4**



EXAMPLE	
	[5L]: NEW SCAN SELECT : Selects the scan mask. ACTIVE SEL DISPLAY : Displays the scan mask used by ATSU.
	[6L] RETURN                      When selected, the MCDU displays the COMM CONFIG page.
	[1R] OLD ARINC EUROPE        Selects the OLD ARINC Europe (datalink service provider).
	[2R] ARINC AFRICA              Selects the ARINC Africa (datalink service provider).
	[3R] JACARS AUSTRAL          Selects the JACARS Australia (datalink service provider).
	[5R] EMPTY SCAN                Activates an empty scan mask, in order to inhibit VHF datalink communication.
	[6R] SCAN SEL PRINT            When selected, the printer prints information.



**MCDU Scratchpad Messages**

**MCDU SCRATCHPAD MESSAGES**

Applicable to: ALL

Ident.: DSC-46-10-40-10-00021338.0001001 / 17 MAR 17

**SCRATCHPAD MESSAGES ON THE COMM MENU PAGE**

MESSAGE	CONDITIONS
COMMAND NOT AVAIL	The command is not available.
DEFAULT VHF SP LIST	The new SCAN MASK is not available. The system displays the default SCAN MASK instead.
ENTER A/C REGISTR	The aircraft registration number is not valid. To enter this parameter, <i>Refer to DSC-46-10-50 How to Initialize.</i>
ENTER A/L ID	The airline identification number is not valid. To enter this parameter, <i>Refer to DSC-46-10-50 How to Initialize.</i>
ENTER VHF 3 SCAN MASK	No service provider has been selected.
FAILED COMMAND	The command, selected by the flight crew, cannot currently be performed.
FORMAT ERROR	The message was entered in an inappropriate format.
NOT ALLOWED	It is not permitted to press this key.
PRINT FAILED	A print command is not successful.
PRT MSG PRINT FAIL	Automatic print of an AOC uplink message was not successful.
VHF 3 CAN BE SET IN VOICE	VHF 3 datalink communications are lost. However, VHF 3 can be used in voice mode.
VHF 3 SWITCH IMPOSSIBLE	It is not possible to switch from VHF 3 voice mode to VHF 3 data mode.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

DATALINK - CONTROLS AND INDICATORS

Intentionally left blank

**ECAM**

**MEMO DISPLAY**

Applicable to: ALL

Ident.: DSC-46-10-40-60-A-00016906.0001001 / 21 MAR 16

**COMPANY ALERT** : This memo appears in green when the aircraft receives an uplink alert message, or when an AOC special condition requires a pilot action on the MCDU (depends on AOC programming). This memo pulses green for 180 s, then remains steady. It is associated with a buzzer for 1 s.

Ident.: DSC-46-10-40-60-A-00016904.0001001 / 21 MAR 16

**COMPANY CALL** : This memo appears in green when the aircraft receives a message from the ground requesting voice communication on VHF.

Ident.: DSC-46-10-40-60-A-00016903.0001001 / 21 MAR 16

**COMPANY DATALINK STBY** : This memo appears in green when AOC datalink air-ground communication is temporarily unavailable, but not lost.

Ident.: DSC-46-10-40-60-A-00016905.0001001 / 21 MAR 16

**COMPANY MSG** : This memo appears in green when the aircraft receives a message from the ground.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

DATALINK - CONTROLS AND INDICATORS

Intentionally left blank

## INTRODUCTION

Ident.: DSC-46-10-50-00021191.0002001 / 17 MAR 17

**Applicable to: ALL**

How To chapter contains examples of:

- How to initialize the datalink
- How to modify the flight plan.

Illustrations in How To are generic and do not reflect differences depending on the datalink standard installed in the aircraft.

## HOW TO INITIALIZE

Ident.: DSC-46-10-50-00021142.0002001 / 17 MAR 17

**Applicable to: ALL**

Datalink may be initialized:

- Automatically  
Datalink initializes automatically, provided that a list of service providers is scanned, and all required parameters are received, and validated by the ATSU.
- Manually  
Datalink may be initialized manually, when the system is not correctly initialized automatically.


The VHF3 SCAN SELECT page of the MCDU displays the list of service providers.  
The COMM CONFIG / COMM INIT page, on the MCDU displays required parameters.

### MANUAL INITIALIZATION

If one of required parameters is not valid, one or more manual entries may be required:

- **If ARN is not valid:**

The MCDU scratchpad displays ENTER A/C REGISTER:



The flight crew clears the scratchpad, and inserts the A/C registration via the MCDU scratchpad.

A/C REGISTR..... INSERT


*The flight crew inserts A/C ICAO registration via the MCDU scratchpad to A/C REGISTR.*

CONFIG ACTIVATE..... SELECT

*The flight crew selects 1R/CONFIG ACTIVATE to activate manual entry of the A/C registration.*

● **If the A/L ID is not valid:**

The MCDU scratchpad displays ENTER A/L IDENT:



The flight crew clears the scratchpad, and inserts the two-letter A/L ID code via the MCDU scratchpad.

A/L ID..... INSERT

*The flight crew inserts A/L ID code via the MCDU scratchpad to A/L ID.*

CONFIG ACTIVATE..... SELECT


*The flight crew selects 1R/CONFIG ACTIVATE to activate manual entry of the A/C registration.*

● **If VHF service provider is not selected**

and

**if the VHF3 SCAN/MASK SELECT menu can be accessed:**

The MCDU scratchpad displays ENTER VHF3 SCAN SELECT:



On the VHF3 SCAN SELECT page, select service providers, in the airline priority order, and activate the VHF SCAN SELECT function.



**EXAMPLE OF SELECTION OF DATALINK SERVICE PROVIDERS:**

Selection of SITA 725 and ARINC service providers :

1. Press 5L key: The asterisk next to SELECT indication disappears, then reappears.
2. Press 1L key to select SITA 725: SELECT indication goes off, and the priority number of selection 1 appears.
3. Press 1R key to select ARINC: SELECT indication goes off, and the priority number of selection 2 appears.
4. Press 5R key to activate the VHF SCAN SELECT function: The star next to SCAN SELECT ACTIVATE indication disappears, then reappears.

*Note: Modification of the SCAN SELECT setting may result in the loss of air-ground VHF datalink communication, and the increase of datalink service provider charges. Therefore, the SCAN SELECT setting should not be modified by the flight crew, unless the flight crew is instructed to do so.*

**HOW TO MODIFY FLT PLAN**

Ident.: DSC-46-10-50-00021153.0001001 / 21 MAR 17

Applicable to: ALL

● **When the scratchpad (1) displays the AOC SEC F-PLN UPLINK message:**

● **On the MCDU:**


SEC INDEX Page:


AOC F-PLN INSERT.....SELECT See (2)


*The flight plan is inserted in the secondary F-PLN See (3).*

*The flight can review and modify the flight plan.*


SEC F-PLN REQ DISPLAY.....SELECT See (4)

 *The DCDU automatically displays a datalink message See (5).*

 *The flight crew sends the message to the ATC from the DCDU.*







● **When ATC clearance is received:**

● **On the glareshield:**

ATC MSG pb..... PRESS  
*The aural and visual alerts stop.*

● **On the DCDU:**

STBY..... SELECT See (1)

**L2** *The message status changes to STBY on a blue background See (2).*

**L1** SEND.....SELECT See (3)

**L2** *The background color of the STBY message status changes to green.*

**L1** LOAD.....SELECT See (4)

*LOAD must be selected. Other selection may prevent loading of the clearance.*

*The LOAD SEC OK displays in the information field of the DCDU, if loading is successful.*

**L2** *The flight crew can review the clearance on the MCDU, in SEC F-PLN pages.*


L1



■ If the flight crew accepts the clearance:

WILCO.....SELECT See (5)

*The flight crew can activate the secondary F-PLN.*



■ **If the flight crew decides to modify the clearance:**

- The flight crew loads the clearance into the SEC F-PLN , on the MCDU and modifies it.
- The flight crew rejects the clearance by selecting UNABLE on the DCDU.
- The flight crew sends a new request (with the modified F-PLN ) to the ATC.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INFORMATION SYSTEMS**

DATALINK - HOW TO

Intentionally left blank

## INTRODUCTION

Ident.: DSC-46-20-20-00021223.0001001 / 25 JUL 17


**Applicable to: ALL**

The FlySmart with Airbus application suite is composed of:

- TAKEOFF application
- LANDING application
- LOADSHEET application
- IN-FLIGHT application (available on the latest FlySmart with Airbus applications for Windows version)
- Operational Documentation applications (OLB)
- Manager application (available for iPad version).

The FlySmart with Airbus application suite is designed to:

- Improve access to flight crew's operational information
- Reduce the quantity of paper documents in the cockpit by replacing them with electronic documents
- Enable reduced revision and distribution cycles to ensure better technical data accuracy
- Ease and improve the operational data updating process
- Provide an accurate and optimized computation of performance.

The FlySmart with Airbus application suite can be used by the flight crew on a Portable Electronic Device (PED ). The flight crew can use the power outlets  (110 VAC / 60 Hz) installed on each lateral console to plug their PED.

*Note: The power outlets (115 VAC / 400 Hz) located on the rear of the cockpit are for maintenance use only.*

## GENERAL

Ident.: DSC-46-20-20-00021224.0001001 / 20 MAR 17

**Applicable to: ALL**

The My Flight page enables:

- To check that FlySmart with Airbus applications are up to date. The My Flight page provides the version of the installed applications and data (EFB version)
- To start the Manager application, that enables to update the operational data (performance, manuals)
- To initialize the applications with the applicable aircraft tail number, flight number and citypair. This avoids multiple entries of the same data in the different applications.

There is one My Flight page per application. All the inputs that the user has entered on one My Flight page are retrieved by the other applications.

*Note:* On the My Flight page of OLB application, the user can only enter the a/c type and a/c registration.

### LANDING APPLICATION

Ident.: DSC-46-20-20-00021225.0001001 / 20 MAR 17

Applicable to: **ALL**

The Landing application aims at computing the landing performance data (maximum landing weight, approach speed) according to the aircraft configuration and external conditions (runway, surrounding obstacles, weather).

The Landing application allows straightforward computations and provides the optimized landing performance for the given conditions.

### TAKEOFF APPLICATION

Ident.: DSC-46-20-20-00021226.0001001 / 20 MAR 17

Applicable to: **ALL**

The Takeoff application aims at computing the takeoff performance data (maximum takeoff weight, takeoff speeds, flexible temperature) according to the aircraft configuration and external conditions (runway, surrounding obstacles, weather).

The Takeoff application allows straightforward computations and provides the optimized takeoff performance for the given conditions.

### LOADSHEET APPLICATION

Ident.: DSC-46-20-20-00021227.0001001 / 20 MAR 17

Applicable to: **ALL**

The Loadsheets application allows the flight crew users to prepare the aircraft loading and to check that all weights and CG remain within the loading operational envelope. This eases the computation of the ZFWCG, ZFW, TOW and TOCG, and enables last-minute changes to the passenger/cargo/fuel distribution.

Depending on airline's authority requirements, the Loadsheets application can also generate a load and trim sheet.

### OPS LIBRARY APPLICATION

Ident.: DSC-46-20-20-00021228.0001001 / 20 MAR 17

Applicable to: **ALL**

The OLB application enables the onboard consultation of any flight operations document published in the relevant format (e.g. airline's manuals), including the ones delivered by Airbus (FCOM, MEL, AFM, CDL, FCTM).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INFORMATION SYSTEMS**

ELECTRONIC FLIGHT BAG (EFB) - APPLICATIONS

MEL and CDL items (including missing items) selected on OLB application are automatically transferred to Takeoff and Landing applications.

**MANAGER APPLICATION**

Ident.: DSC-46-20-20-00021229.0001001 / 20 MAR 17

Applicable to: **ALL**

The Manager application aims at updating on the iPad the operational data used by FlySmart with Airbus applications for iPad: performance data and operational manuals.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

ELECTRONIC FLIGHT BAG (EFB) - APPLICATIONS

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**  
**INFORMATION SYSTEMS**  
ELECTRONIC QRH (EQRH)

**GENERAL**

Ident.: DSC-46-30-00021515.0001001 / 17 MAR 17

**Applicable to: ALL**

The electronic QRH (eQRH ) is an EFB application that enables the flight crew to:


- Manage the Normal Checklists and some Abnormal Procedures
- Access to some important operational data (OEBs, system architectures, performance...)

The eQRH has several main interfaces:

- My Aircraft page:

The My Aircraft page enables:

- To check that the eQRH application is up to date. The My Aircraft page provides the version of the installed application and data (EFB version)
- To initialize the eQRH application with the applicable aircraft tail number. The My Aircraft page retrieves automatically the aircraft tail number when defined in other FlySmart with Airbus applications




- EFB version:

If required, each flight crew member compares the EFB version with the valid version information that is given as reference by the airline. This ensures that the eQRH application and the data installed on their devices correspond to the latest updated version, provided by their airline's flight operations.


- eQRH application:

The eQRH application enables the pilot to manage the normal checklists and non-sensed Abnormal Procedures. It also gives access to some important operational data that may be required during the flight.



- (1) Access to My Aircraft page
- (2) Aircraft tail number and type
- (3) Working list

- (4) Search
- (5) Previous/Next Navigation
- (6) eQRH options
- (7) Rapid Access

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>INFORMATION SYSTEMS</b></p> <p align="center">PAX ENTERTAINMENT &amp; CONNECTIVITY SYSTEMS (IF INSTALLED) - GENERAL</p>
---	--

**GENERAL**

Ident.: DSC-46-40-10-00017604.0001001 / 21 MAR 16


**Applicable to: ALL**

The aircraft is equipped with cabin connectivity systems which enable passengers to use:

- Mobile phones for voice and data services, and/or
- Internet wireless connection for access to the World Wide Web

The use of mobile phones is prohibited in cockpit and lavatories.

The following table provides the list of controls dedicated to Pax Entertainment & Connectivity Systems:

<b>P/B</b> 	<b>EQUIPMENTS (FUNCTIONS)</b>	<b>DESCRIPTIONS</b>
GALLEY	Mobile, Wifi, IFE	<i>Refer to DSC-24-20 Overhead Panel</i>
COMMERCIAL	Mobile, Wifi, IFE	<i>Refer to DSC-24-20 Overhead Panel</i>
NO PED	Signs	<i>Refer to DSC-33-40-10 Overhead Panel</i>
PAX SYS	Mobile, Wifi, IFE, Seat actuators, PED	<i>Refer to DSC-46-40-30 PAX SYS PB-SW</i>
PAX PERSONAL ELEC SPLY	Mobile, Wifi, IFE, Seat actuators, PED	<i>Refer to DSC-46-40-30 PAX PERSONAL ELEC SPLY PB-SW</i>
MOBILE COM	Mobile, Wifi	<i>Refer to DSC-46-40-30 MOBILE COM PB-SW</i>
CINS reset	Mobile, Wifi	<i>Refer to DSC-46-40-30 CINS RESET PB</i>



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

PAX ENTERTAINMENT & CONNECTIVITY  
SYSTEMS (IF INSTALLED) - GENERAL

Intentionally left blank

**IN SEAT POWER SUPPLY SYSTEM** ◀

Ident.: DSC-46-40-20-00017606.0001001 / 10 NOV 15

**Applicable to: ALL**

The In-Seat Power Supply System (ISPSS ) provides electrical power to the In-Seat Power Supply Unit (ISPSU) outlets, and enables passengers to use Portable Electronic Devices (PED) and the In-Flight Entertainment (IFE) system.

It is possible for the flight crew to simultaneously disconnect power from all ISPSUs, In-Flight Entertainment (IFE) and Cabin Connectivity systems, via the PAX SYS pb-sw or the PAX PERSONAL ELEC SPLY pb-sw.

In the case of rapid cabin decompression, both the ISPSS and IFE system are automatically disconnected.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

PAX ENTERTAINMENT & CONNECTIVITY SYSTEMS  
(IF INSTALLED) - IN SEAT POWER SUPPLY SYSTEM


Intentionally left blank



**MOBILE COM PB-SW** 

Ident.: DSC-46-40-30-00017631.0001001 / 19 APR 16

Applicable to: ALL



The pushbutton-switch described here below is installed on the 45 VU panel on the overhead panel.




- ON : The mobile phone system is activated.
- OFF : The mobile phone system is deactivated.

*Note: When the pushbutton is released, the OFF light comes on in white however the system takes approximately 4 min to disconnect. During this disconnection process, the passengers can use their mobile phones.*

**DISC IN PROG LIGHT** ◀

Ident.: DSC-46-40-30-00019278.0001001 / 21 MAR 17

Applicable to: **ALL**



The pushbutton-switch described here below is installed on the 45 VU panel on the overhead panel.




*Note: After the release of Mobile Com pushbutton, the DISC IN PROG light comes in blue and remains on until the total disconnection of the system.*

**CINS RESET PB** ◀

Ident.: DSC-46-40-30-00017630.0001001 / 10 NOV 15

Applicable to: ALL



The pushbutton-switch described here below is installed on the 45 VU panel on the overhead panel.




When pressed, it resets all Cabin Connectivity systems.

**PAX COM PB-SW** 

Ident.: DSC-46-40-30-00021654.0001001 / 02 MAY 17

Applicable to: **ALL**



The pushbutton-switch described here below is installed on the 45 VU panel on the overhead panel.




**OFF** : The Cabin Connectivity system is cut-off. When the pushbutton-switch is released, the OFF light comes on in white.

**PAX SYS PB-SW** 

Ident.: DSC-46-40-30-00017735.0001001 / 10 NOV 15

Applicable to: ALL



The pushbutton-switch described here below is installed on the 56VU panel on the overhead panel.




- AUTO** : All ISPSUs, In-Flight Entertainment (IFE) and Cabin Connectivity systems are powered.
- OFF** : Simultaneously turns off all ISPSUs, In-Flight Entertainment (IFE) and Cabin Connectivity systems.

**PAX PERSONAL ELEC SPLY PB-SW** 



Ident.: DSC-46-40-30-00017629.0001001 / 21 MAR 17

Applicable to: **ALL**



The pushbutton-switch described here below is installed on the 56VU panel on the overhead panel.



- AUTO  : All ISPSUs, In-Flight Entertainment (IFE) and Cabin Connectivity systems are powered, if the pushbutton-switch located in the forward cabin is also in the on position
- OFF : Simultaneously turns off all ISPSUs, In-Flight Entertainment (IFE) system and Cabin Connectivity systems.
- INOP  : This label indicates that the ISPSS has been deactivated and is inoperative.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

## INFORMATION SYSTEMS

PAX ENTERTAINMENT & CONNECTIVITY SYSTEMS  
(IF INSTALLED) - CONTROLS AND INDICATORS

### MEMO DISPLAY

Ident.: DSC-46-40-30-00017628.0001001 / 10 NOV 15

Applicable to: ALL

**“GSM DISC < 4 MN”** : This memo appears in green, if the cockpit switch “Mobile Com” is pushed. It initiates a shutdown of the Cabin Connectivity systems within 4 minutes. The message disappears when the shutdown is completed.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**INFORMATION SYSTEMS**

PAX ENTERTAINMENT & CONNECTIVITY SYSTEMS  
(IF INSTALLED) - CONTROLS AND INDICATORS

Intentionally left blank



# AIRCRAFT SYSTEMS

APU

Intentionally left blank

**DSC-49-10 Description**

**DSC-49-10-10 General**

General.....A

**DSC-49-10-20 Main Components**

APU Engine.....A  
 Electronic Control Box.....B  
 Air Intake System.....C  
 Starter.....D  
 Fuel System.....E  
 Oil System.....F  
 Inlet Guide Vanes (IGV).....G  
 Air Bleed System.....H  
 Controls.....I  
 Ground Operation Safety Devices.....J

**DSC-49-20 Controls and Indicators**

Overhead Panel.....A  
 External Controls.....B  
 ECAM APU Page.....C  
 Memo Display.....D




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### APU

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>APU</b></p> <p style="text-align: center;">DESCRIPTION - GENERAL</p>
---	---

**GENERAL**

**Applicable to:** ALL

Ident.: DSC-49-10-10-A-00017436.0001001 / 21 MAR 17

The Auxiliary Power Unit (APU) is a self-contained unit that supplies the aircraft with pneumatic and electrical power.

**On the ground**

- It supplies bleed air for starting the engines and for the air conditioning system
- It supplies electrical power to the electrical system.

**During takeoff**


- It supplies bleed air for air conditioning (for example, when optimum aircraft performance is required).

**In flight**

- It backs up the electrical system
- It backs up the air conditioning
- It can be used to start the engines.

The APU may obtain power for starting from the aircraft's batteries or normal electrical system, or from ground service.

APU starting is permitted throughout the normal flight envelope (*Refer to LIM-APU Operational Envelope*).



### APU ENGINE

Ident.: DSC-49-10-20-00001528.0001001 / 21 MAR 16

**Applicable to: ALL**

The basic element of the APU is a single-shaft gas turbine that delivers mechanical shaft power for driving the accessory gearbox (electrical generator, starter, etc.) and produces bleed air (engine starting and pneumatic supply).

### ELECTRONIC CONTROL BOX

Ident.: DSC-49-10-20-00001529.0001001 / 21 MAR 16

**Applicable to: ALL**

The Electronic Control Box (ECB ) is a full-authority digital electronic controller that performs the bulk of the APU system logic for all modes of engine operation, such as :

- Sequences the start and monitors it.
- Monitors speed and temperature.
- Monitors bleed air.
- Sequences the shutdown.
- Controls the automatic shutdown.

### AIR INTAKE SYSTEM

Ident.: DSC-49-10-20-00001530.0001001 / 21 MAR 16

**Applicable to: ALL**

The air intake and an electrically operated flap allow external air to reach the compressor inlet.

### STARTER

Ident.: DSC-49-10-20-00001531.0001001 / 21 MAR 16

**Applicable to: ALL**

The ECB controls the electric starter. The starter engages if the air intake is fully open and the MASTER SW and the START pushbutton are ON.

### FUEL SYSTEM

Ident.: DSC-49-10-20-00001532.0001001 / 21 MAR 16

**Applicable to: ALL**

The left fuel feed line supplies the APU.

The required pressure is normally available from tank pumps.

If pressure is not available (batteries only or pumps off) the APU FUEL PUMP starts automatically.

The ECB controls the fuel flow.

## AIRCRAFT SYSTEMS

### APU

#### DESCRIPTION - MAIN COMPONENTS

### OIL SYSTEM

Ident.: DSC-49-10-20-00001533.0001001 / 21 MAR 16

Applicable to: ALL

The APU has an integral independent lubrication system (for lubrication and cooling).

### INLET GUIDE VANES (IGV)

Ident.: DSC-49-10-20-00001534.0001001 / 21 MAR 16

Applicable to: ALL

The IGVs control bleed air flow, and a fuel-pressure-powered actuator positions the IGVs. The ECB controls the actuator in response to aircraft demand.

### AIR BLEED SYSTEM

Ident.: DSC-49-10-20-00001535.0002001 / 03 FEB 11

Applicable to: ALL

The air bleed system is fully automatic.  
The APU speed is always 100 % whatever the air bleed system demand and the ground/flight configuration are.

### CONTROLS

Ident.: DSC-49-10-20-00001536.0001001 / 21 MAR 16

Applicable to: ALL

The flight crew uses the controls on the APU panel for routine shutdown. For emergency shutdown :

- the flight crew can push the APU FIRE handle, or
- the ground crew can push the APU SHUT OFF pushbutton on the interphone panel under the nose fuselage.

### GROUND OPERATION SAFETY DEVICES

Ident.: DSC-49-10-20-00001537.0001001 / 21 MAR 16

Applicable to: ALL

The APU may run without cockpit crew supervision when the aircraft is on the ground. In case of fire in the APU compartment :

- APU fire warnings operate in the cockpit.
- A horn in the nose gear bay sounds.
- The AVAIL light goes out.
- The FAULT light in the MASTER SW lights up.



- The APU shuts down.
- The APU fire extinguisher discharges.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### APU


DESCRIPTION - MAIN COMPONENTS

Intentionally left blank

**OVERHEAD PANEL**

Applicable to: ALL

Ident.: DSC-49-20-A-00017438.0001001 / 21 MAR 16



Ident.: DSC-49-20-A-00017685.0003001 / 21 MAR 16

(1) MASTER SW pb-sw

This switch controls the electric power supply for the operation of the APU and its protective features. It also controls the starting and shutdown sequences.

- ON** : The blue ON light comes on.  
 Electric power goes to the APU system; the ECB performs a power-up test.  
 The APU air intake flap opens.  
 The APU fuel isolation valve opens.  
 If no fuel tank pump is running, the APU fuel pump operates.  
 If the aircraft has ground power or main generator power, the APU page appears on the ECAM display.
- OFF** : Manual shutdown sequence.
- The ON light on the MASTER SW pb-sw, and the AVAIL light on the START pb go out.
  - If the aircraft was using APU bleed air, the APU keeps running for a cooling period of 60 to 120 s.
  - At 7 % the air inlet flap closes.

**FAULT It :** Depending on version of the ECB , this amber light comes on, and a caution appears on ECAM, when an automatic APU shutdown occurs, which can happen in case of:

- Fire (on ground only)
- Air inlet flap closed
- Overspeed
- No acceleration
- Slow start
- EGT overtemperature
- No flame
- Reverse flow
- Low oil pressure
- High oil temperature
- DC power lost (BAT OFF when aircraft on batteries only)
- Overcurrent
- Sensor failure
- IGV failure
- ECB failure
- No speed
- Underspeed
- Loss of overspeed protection
- Oil system shutdown
- Inlet overheat
- Clogged oil filter
- Loss of EGT thermocouples

Note: *In the case of an automatic, non-emergency shutdown, the air inlet flap closes 15 min after the APU speed is lower than 7%. If an automatic, non-emergency shutdown happens on ground, the 15 min countdown starts after liftoff.*

Ident.: DSC-49-20-A-00017439.0002001 / 21 MAR 16

(2) START pb-sw

- ON :** Blue ON light comes on.
- When the flap is completely open, the APU starter is energized.
  - 1.5 s after the starter is energized, the ignition is turned ON.
  - When N = 55 %. The APU starter is de-energized. The ignition is turned off.
  - 2 s after N reached 95 %, or when N is above 99.5 %:  
 The ON light on the START pb goes out.  
 The APU may now supply bleed air and electrical power to the aircraft systems.
  - 10 s later, the APU page disappears from the ECAM display.

AVAIL It : This green light comes on when N is above 99.5 % or 2 s after N reaches 95 %.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS


### APU

#### CONTROLS AND INDICATORS

#### EXTERNAL CONTROLS

Ident.: DSC-49-20-00001539.0001001 / 21 MAR 16


Applicable to: ALL



**ECAM APU PAGE**

Applicable to: ALL

Ident.: DSC-49-20-B-00017440.0001001 / 21 MAR 16



Ident.: DSC-49-20-B-00017441.0002001 / 21 MAR 16

**(1) AVAIL**

Displayed in green when APU N is above 99.5 % or 2 s after N is above 95 %.

Ident.: DSC-49-20-B-00017442.0001001 / 21 MAR 16

**(2) APU bleed air valve position**

- Inline-Green : The APU bleed air valve is not closed.
- Crossline-Green : The APU bleed air valve is closed.
- Crossline-Amber : The APU bleed air valve is closed and the APU bleed is ON.
- XX-Amber : The APU bleed air valve status information is not available, or the APU BLEED pb status is not available.

Ident.: DSC-49-20-B-00017443.0001001 / 21 MAR 16

**(3) APU bleed air pressure**

This box displays the relative bleed air pressure in green.



It shows an amber XX when the ADIRS 1 or the ADIRS 2 is not available or selected OFF or the data from the ECB are invalid or not transmitted.

Ident.: DSC-49-20-B-00017444.0001001 / 21 MAR 16

(4) APU GEN line contactor indication

Displayed in green when the APU GEN line contactor is closed.

Ident.: DSC-49-20-B-00017445.0001001 / 21 MAR 16

(5) APU GEN parameters

Identical to the APU GEN parameters on the ELEC page.

Ident.: DSC-49-20-B-00017446.0001001 / 21 MAR 16

(6) FUEL LO PR

Displayed in amber if APU fuel pressure gets low.

Ident.: DSC-49-20-B-00017447.0003001 / 21 MAR 16

(7) FLAP OPEN

- Displayed in green when APU air intake flap is fully open.
- Advisory if the flap is not fully closed 3 min after the MASTER sw has been turned OFF.


Ident.: DSC-49-20-B-00017448.0001001 / 21 MAR 16

(8) APU N

- Displays APU speed in green.
- Becomes amber when  $N \geq 102\%$ .
- Becomes red when  $N \geq 107\%$ .

Ident.: DSC-49-20-B-00017449.0002001 / 06 SEP 16

(9) APU EGT



- Displays APU EGT in green.
- Becomes amber when  $EGT \geq EGT\ MAX - 33\ ^\circ C$ .
- Becomes red when  $EGT \geq EGT\ MAX$  (automatic shutdown begins).

*Note:* ECB calculates EGT MAX and transmits it to the ECAM . It is a function of N during start, and a function of ambient temperature when the APU is running.

*Maximum EGT during start: 982 °C.*

*Maximum EGT with APU running:*

- 682 °C during at least 5 s.
- or, 700 °C to 742 °C depending on the ambient temperature.

Ident.: DSC-49-20-B-00017450.0001001 / 21 MAR 16

### (10) LOW OIL LEVEL

Advisory: Displayed if the ECB detects a low APU oil level when the aircraft is on the ground, and the APU is not running.

## MEMO DISPLAY

Ident.: DSC-49-20-00016689.0001001 / 21 MAR 16

Applicable to: **ALL**

**APU AVAIL** : This memo appears in green, when APU N is above 99.5 % or 2 s after N is above 95 % (depending on the aircraft configuration).

# AIRCRAFT SYSTEMS

DOORS

Intentionally left blank

**DSC-52-10 Description**

DSC-52-10-10 General

Description..... A


DSC-52-10-20 Passenger Doors

General..... A  
 Outside..... B  
 Inside..... C

DSC-52-10-30 Emergency Exits

Cockpit..... A  
 Cabin..... B

DSC-52-10-40 Cargo Doors

General..... A  
 Fwd and Aft Cargo Doors..... B  
 Bulk Cargo Door  ..... C  
 Location of Service Panels..... D

DSC-52-10-50 Avionics Compartment Access Door

Avionics Compartment Access Door..... A

DSC-52-10-60 Cockpit Door

Cockpit Door..... A

DSC-52-10-80 Escape Slides/Rafts

Door Slides..... A  
 Wing Slides..... B  
 Escape Slide Arrangement..... C

**DSC-52-20 Controls and Indicators**

DOOR/OXY SD Page..... A

**DSC-52-40 Cockpit Door Security System**

DSC-52-40-10 Description

Cockpit Door Description..... A

DSC-52-40-20 Cockpit Door Locking System (CDLS)

COCKPIT DOOR LOCKING SYSTEM (CDLS)..... A  
 Controls..... B

*Continued on the following page*

*Continued from the previous page*

**DSC-52-40-30 Cockpit Door Surveillance System (CDSS)**

General.....A  
Controls.....B

**DSC-52-50 How to**

How to Operate the Cockpit Door ..... A  
How to Operate the Fwd and Aft Cargo Door..... B  
How to Operate the Fwd and Aft Cargo Doors (Auxiliary Operation)..... C


**DESCRIPTION**

Ident.: DSC-52-10-10-00001544.0002001 / 22 MAY 12

Applicable to: ALL

The A320's fuselage has:

- Four passenger doors
- Four emergency exits in the cabin
- Cockpit emergency exits (two sliding windows)
- Three cargo compartment doors
- Four avionic compartment access doors.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**AIRCRAFT SYSTEMS**

**DOORS**

DESCRIPTION - GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>DOORS</b></p> <p style="text-align: center;">DESCRIPTION - PASSENGER DOORS</p>
---	--

**GENERAL**

Ident.: DSC-52-10-20-00017564.0001001 / 21 MAR 16

**Applicable to: ALL**

The aircraft has four plug-type doors that open outward and forward. There are two doors on each side of the fuselage (one door in the FWD section and one door in the AFT section).

The doors are operated from inside or outside of the aircraft. Normal operation is manual, with hydraulic damping.

Each door has emergency features:

- An escape slide stowed in a container attached to the inboard lower side of the door
- A damper actuator in normal mode, the damper actuator limits the door travel; in emergency mode, the damper actuator drives the automatic door opening
- A slide arming lever.

When the slide arming lever is in the ARMED position, the slide is connected to the floor brackets on both sides of the door. When the door is open, the slide inflates and deploys automatically. If the inflation bottle fails to discharge automatically, a crew member can open its valve to make it discharge. Opening the door from outside disarms the door and the escape slide.


Each passenger door has :

- A mechanical locking indicator that confirms the locked or unlocked position of the door
- One warning light to show the ARMED or DISARMED indication of the escape slides
- One CABIN PRESSURE warning light that illuminates in the case of a residual pressure in the cabin.

**OUTSIDE**

Ident.: DSC-52-10-20-00017565.0001001 / 21 MAR 16


Applicable to: ALL



**INSIDE**

Ident.: DSC-52-10-20-00001547.0002001 / 22 MAY 12

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### DOORS

DESCRIPTION - PASSENGER DOORS

Intentionally left blank


**COCKPIT**


Ident.: DSC-52-10-30-00017567.0001001 / 21 MAR 16

Applicable to: ALL

The two sliding windows in the cockpit are flight crew emergency exits.

A small compartment, located above each window, contains an escape rope that is long enough to reach the ground when lowered through either sliding window. The cockpit windows can only be opened from inside.




Emergency cockpit evacuation is also possible through the cockpit door escape panel . This panel is designed to be pushed open in the direction of the cabin after removal of the quick-release pins.

**CABIN**

Ident.: DSC-52-10-30-00017568.0001001 / 06 DEC 16

Applicable to: **ALL**


Two emergency exits are located on each side of the cabin, in addition to the passenger doors. The emergency exits are also equipped with escape slides. In the case of an emergency, the exits open inwards.



The slides of the overwing emergency exits are always in armed configuration.

To open :

- Remove HANDLE COVER : The HANDLE LIGHT and SLIDE ARMED indicator illuminate
- Pull CONTROL HANDLE : The EXIT moves inwards
- Lift EXIT from frame by holding the HANDLE RECESS
- Throw EXIT out.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


## AIRCRAFT SYSTEMS

### DOORS

DESCRIPTION - EMERGENCY EXITS

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b> <b>DOORS</b></p> <p align="center">DESCRIPTION - CARGO DOORS</p>
---	--

**GENERAL**

Ident.: DSC-52-10-40-00017569.0001001 / 21 MAR 16  
**Applicable to: ALL**

The aircraft has two cargo doors (FWD and AFT cargo doors) on the right side of the fuselage below the cabin floor.

**FWD AND AFT CARGO DOORS**


Ident.: DSC-52-10-40-00017570.0001001 / 21 MAR 16  
**Applicable to: ALL**

The FWD and AFT cargo doors hydraulically open outward and upward. The doors are hydraulically operated by the yellow hydraulic system. The door locking system (locked open/locked closed) is mechanical.

If the electric pump of the yellow hydraulic system fails, the system can be powered by using a hand pump, located on the hydraulic maintenance panel.

The FWD and AFT cargo doors open only from outside.

*Note: When the electric pump operates the FWD or AFT cargo door, the remaining yellow system devices that operate are the brakes and the engine 2 thrust reverser.*

**BULK CARGO DOOR **

Ident.: DSC-52-10-40-00017571.0001001 / 21 MAR 16  
**Applicable to: ALL**

The bulk cargo door opens inward and upward. The bulk cargo door is a plug-type door. The door is mechanically locked and manually operated.

The bulk cargo door opens from the outside or from the inside.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS



### DOORS

DESCRIPTION - CARGO DOORS

### LOCATION OF SERVICE PANELS

Ident.: DSC-52-10-40-00020676.0002001 / 17 MAR 17

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### DOORS

DESCRIPTION - CARGO DOORS

Intentionally left blank

**AVIONICS COMPARTMENT ACCESS DOOR**

Ident.: DSC-52-10-50-00017579.0001001 / 21 MAR 16

**Applicable to: ALL**

Four avionics compartment access doors enable an external access to the avionics compartment. The doors are manually operated, hinged doors. The doors open inwards. These doors are in the lower fuselage, around the nose landing gear bay.

**AIRCRAFT SYSTEMS**

**DOORS**

DESCRIPTION - AVIONICS COMPARTMENT ACCESS DOOR

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**DOORS**

DESCRIPTION - COCKPIT DOOR

**COCKPIT DOOR**

Ident.: DSC-52-10-60-00017573.0002001 / 21 MAR 17

**Applicable to: ALL**

*Refer to DSC-52-40-10 Cockpit Door Description for information about the secured cockpit door.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### DOORS

DESCRIPTION - COCKPIT DOOR


Intentionally left blank



**DOOR SLIDES**

Ident.: DSC-52-10-80-00001555.0001001 / 09 OCT 12


Applicable to: ALL



**WING SLIDES**

Ident.: DSC-52-10-80-00001556.0001001 / 09 OCT 12

Applicable to: ALL




**ESCAPE SLIDE ARRANGEMENT**


Ident.: DSC-52-10-80-00017577.0001001 / 21 MAR 16

Applicable to: ALL

There are two types of emergency slides: a single-lane escape slide/slideraft or a dual-lane escape slide/slideraft.



Each passenger door either has a single-lane escape slide, or a single-lane slideraft, and each emergency exit has a dual-lane escape slide.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### DOORS


DESCRIPTION - ESCAPE SLIDES/RAFTS


Intentionally left blank


**DOOR/OXY SD PAGE**

Ident.: DSC-52-20-00017645.0001001 / 21 MAR 16

Applicable to: ALL



- (1) Door symbol  
Green  : The door is closed and locked.  
Amber  : The door is not locked.
- (2) Door indication  
This appears in amber, when the door is not locked.
- (3) SLIDE indication  
This appears in white, when the slide is armed.
- (4) Stair symbol   
This appears in amber, when the stair door is not closed.

**Note:** For aircraft without FWD EMER EXIT  doors, the FWD EMER EXIT door symbols are always displayed in green.

Intentionally left blank

**COCKPIT DOOR DESCRIPTION**

Ident.: DSC-52-40-10-00017010.0001001 / 17 MAR 17


Applicable to: ALL


A forward-opening hinge door separates the cockpit from the passenger compartment. It has three electric locking strikes, controlled by the flight crew. In normal conditions, when the door is closed, they remain locked. When there is a request to enter the cockpit, the flight crew can authorize entry by unlocking the door, that remains closed until it is pushed open.

When the flight crew does not respond to requests for entry, the door can also be unlocked by the cabin crew, by entering a two to seven-digit code (programmed by the airline) on the keypad, installed on the lateral side of the Forward Attendant Panel (FAP).

The door is bulletproof and fully compliant with rapid decompression requirements.


A mechanical override enables the flight crew to open the door from the cockpit side.

A deadbolt  is installed at the level of the center latch area of the cockpit door. This deadbolt bolts the door from the cockpit side, in the event that more than one locking latch strike fails, or in the case of a total CLS failure.



- Note:
- 1. The escape panel enables the flight crew to evacuate the cockpit, in case of an emergency, when the door is jammed. This panel can only be removed from the cockpit side by pulling the quick release pins towards the center of the flap and kicking the panel open.*
  - 2. In case of an electrical supply failure, the door is automatically unlocked, but remains closed.*



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>AIRCRAFT SYSTEMS</b></p> <p align="center"><b>DOORS</b></p> <p align="center">COCKPIT DOOR SECURITY SYSTEM - COCKPIT DOOR LOCKING SYSTEM (CDLS)</p>
---	--

**COCKPIT DOOR LOCKING SYSTEM (CDLS)**

Ident.: DSC-52-40-20-00001007.0001001 / 21 MAR 17  
**Applicable to: ALL**

The Cockpit Door Locking System (CDLS) provides a means of electrically locking and unlocking the cockpit door. This system is mainly composed of :

- A keypad, located in the forward cabin, near the cockpit door,
- A toggle switch, located in the center pedestal's Cockpit Door panel,
- A control unit and its CKPT DOOR CONT normal panel, located on the overhead panel,
- A buzzer.

The keypad enables the cabin crew to request access to the cockpit. There are two different access request types : "Routine" and "Emergency" access request.

The toggle switch enables the flight crew to lock or unlock the cockpit door, following an access request, thereby allowing or denying the entry to the cockpit.

The cockpit door control unit is the system controller, in charge of :

- Locking or unlocking the door latches, upon flight crew action.
- Unlocking the door, in case of cockpit decompression (the door then opens towards the cockpit under differential pressure).
- Indicating system failures of electrical latches and pressure sensors.
- Activating the access request buzzer and turning on the keypad LEDs.


The buzzer sounds in the cockpit for 1 to 9 s to indicate that a routine access request has been made, or sounds continuously if an emergency access procedure has been initiated.

**CONTROLS**


**Applicable to: ALL**  
 Ident.: DSC-52-40-20-A-00001008.0001001 / 21 MAR 17

**KEYPAD**

The keypad is used by the cabin crew to request pilots to open the door.



(1) Locked/Unlocked Door Indicator

- GREEN light ON : The door has been unlocked either by a flight crew action, or automatically (during 5 s) when no flight crew action is performed during the delay following an emergency access request. The door can be pushed open.
- GREEN light flashes : An emergency request to enter the cockpit has been made; the buzzer will sound continuously in the cockpit, but no action has yet been taken by the flight crew.
- RED light ON : The flight crew has denied access, and the door remains locked.
- WHITE light ON  : The light comes on each time the cabin crew presses a key on the keypad.

(2) Digital Keypad

The keypad is used to sound the buzzer in the cockpit for 1 to 9 s (3 s by default), by entering a zero to seven-digit code, as programmed by the airline, followed by the '#' key. It is also used to enter the two to seven-digit emergency code, followed by the '#' key, when the flight crew does not respond.

*Note: During the test performed by the cockpit door control unit, the CDLS keypad remains operational, and the CDLS operates as follows:  
The control unit will store access codes that are entered, and the LOCKED/UNLOCKED DOOR INDICATOR (RED/GREEN LEDs) of the keypad will remain on, as long as the test is running.*

- *If the correct access code is entered on the keypad, the buzzer will not sound, until the test is completed.*
- *If the emergency access code is entered, the door will unlock. The cockpit buzzer and the LOCKED/UNLOCKED DOOR INDICATOR will be inoperative.*

Ident.: DSC-52-40-20-A-00018437.0001001 / 17 MAR 17

### **CENTRAL PEDESTAL COCKPIT DOOR PANEL**

The secured cockpit door opening is controlled by a toggle switch, located on the central pedestal.



#### **(1) COCKPIT DOOR toggle switch**

- UNLOCK position** : This position is used to enable the cabin crewmember to open the door. The switch must be pulled and maintained in the unlock position until the door is pushed open.
- NORM position** : All latches are locked, and EMERGENCY access is possible for the cabin crew.
- LOCK position** : Once the button has been moved to this position, the door is locked ; emergency access, the buzzer, and the keypad are inhibited for a preselected time (5 to 20 min).

*Note:*

1. *If the LOCK position has not been used by the pilot, for at least 5 to 20 min, the cabin crew is able to request emergency access to open the cockpit door.*
2. *The UNLOCK position overrides and resets any previous selection.*
3. *In case of an electrical supply failure, the cockpit door is automatically unlocked, but remains closed.*

(2) COCKPIT DOOR Fault Open indicator

OPEN light ON : The door is not closed.

OPEN light flashes : The cabin crew has started an emergency access procedure. If there is no reaction from the flight crew, the door will unlock at the end of the adjustable time delay (15 to 120 s).

FAULT : This light comes on when a system failure has been identified (Example : Latch, pressure sensors, control unit).  
 The operative item can be identified by checking the strike and pressure sensor status lights on the CKPT DOOR CONT panel.

Ident.: DSC-52-40-20-A-00001010.0001001 / 09 OCT 12

**OVERHEAD CONTROL PANEL**

The Cockpit Door Locking System's control panel is located on the overhead panel.



(1) Strikes' status lights

Off : The corresponding (upper, mid, or lower) locking latch is operative.

On : The corresponding (upper, mid, or lower) locking latch is faulty.

(2) Pressure sensor

Two redundant differential pressure sensors enable rapid pressure variation in the cockpit to be detected, in order to command simultaneous opening of all latches when a defined pressure drop is detected.

(3) Pressure sensor status lights

Off : The corresponding (1 or 2) pressure sensor is operative.

On : The corresponding (1 or 2) pressure sensor is faulty.


*Note:* These indicators enable the crew to identify the faulty item, when the Central Pedestal Fault indicator light is ON.

**GENERAL**

Ident.: DSC-52-40-30-00018415.0001001 / 17 MAR 17

Applicable to: ALL


The Cockpit Door Surveillance System (CDSS ) consists of three video cameras, that enable the flight crew to identify persons prior to authorizing their entry into the cockpit. The lower ECAM display displays the various camera views. A control panel, located on the central pedestal allows the flight crew members to select the CDSS display on the SD and to swap between the different camera views.



**CONTROLS**

Applicable to: ALL

Ident.: DSC-52-40-30-A-00018416.0003001 / 17 MAR 17



(1) Lower ECAM rotary selector

**CKPT ENTRY** : The lower ECAM displays the camera 1 image.

The camera images are not displayed on the Lower ECAM display in the case of:

- A subsequent automatic system page call following a warning, a caution, or an advisory, or
- A subsequent manual selection of a system page on the ECAM Control Panel (ECP), or
- A SD failure, or
- An EWD failure.

**OFF** : The lower ECAM display operates normally.

(2) Lower ECAM CAM SEL

Selects various camera image displays, when the lower ECAM rotary selector is set to the CKPT ENTRY position.

The image from camera 1 appears:

- Automatically, when the lower ECAM rotary selector is set to the CKPT ENTRY position.
- When images from cameras 2 and 3 are displayed, and after the flight crew presses the lower ECAM CAM SEL pb
- Automatically, when images from cameras 2 and 3 are displayed, and after a crew member uses the cabin keypad to make an entry request at least 30 s after a previous entry request.

Images from cameras 2 and 3 are displayed simultaneously on a split screen, when the image from camera 1 is displayed, and after the flight crew presses the lower ECAM CAM SEL pb.

- Note:
1. The message "PLEASE WAIT" is displayed during the transition between two video images when the flight crew requests an image change.
  2. The message "VIDEO NOT AVAIL" is displayed when the flight crew requests a video image and no image can be displayed.


**AIRCRAFT SYSTEMS**

**DOORS**

COCKPIT DOOR SECURITY SYSTEM - COCKPIT  
DOOR SURVEILLANCE SYSTEM (CDSS)

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>DOORS</b></p> <p style="text-align: center;">HOW TO</p>
---	--

**HOW TO OPERATE THE COCKPIT DOOR**

Ident.: DSC-52-50-00020495.0001001 / 17 MAR 17

Applicable to: ALL

The secured cockpit door operation is controlled by a toggle sw that is located on the COCKPIT DOOR panel (central pedestal).

**DOOR OPENING FROM THE COCKPIT**

To enable access to the cockpit, set and maintain the COCKPIT DOOR sw to the UNLOCK position until the door is fully opened. When the door is fully opened, the COCKPIT DOOR sw can be released to the NORM position.

**DOOR CLOSING FROM THE COCKPIT**

Close the door and check that the OPEN indicator goes off. If the COCKPIT DOOR sw is in the NORM position, the door is locked and emergency access is possible from the cabin. When the door is fully closed, if the cockpit door FAULT light is ON, *Refer to PRO-ABN-DOOR [QRH] COCKPIT DOOR FAULT.*

*Note: If the OPEN indicator is ON when the door is closed, the door may be unlocked. Repeat the above-mentioned opening/closing procedure.*


When the COCKPIT DOOR sw is in the LOCK position the door is locked. In this position, the emergency access, the buzzer, and the keypad are inhibited for a preselected time (5 to 20 min).

**ROUTINE ACCESS TO THE COCKPIT FROM THE CABIN (I.E. NORMAL ACCESS)**

To request access to the cockpit from the cabin, use the keypad to enter the code and validate with the “#” key.

**L2** The Operator defines this code (between 0 and 7 digits).

**L1** The buzzer sounds in the cockpit for 1 to 9 s (3 s by default).


After identification of the person (using the Cockpit Door Surveillance System  ) that requests access, set the COCKPIT DOOR sw to UNLOCK position to unlock the door. A steady green light on the keypad comes on, that indicates that the door is unlocked.

If the flight crew refuses access to the cockpit by setting the COCKPIT DOOR sw to LOCK position, a steady red light on the keypad comes on, that indicates that the door is locked. The keypad and the buzzer are inhibited for a defined period of time.

If the flight crew does not respond, the door remains locked. If the flight crew does not take any action after a routine cabin request, the cabin crew will be able to open the door with the emergency access procedure.

**EMERGENCY ACCESS FROM CABIN TO THE COCKPIT**

To request emergency access to the cockpit, use the keypad to enter the emergency code and validate with the “#” key.

- L2** The Operator defines this emergency code (between 2 and 7 digits).
- L1** The buzzer continuously sounds in the cockpit and the OPEN light flashes on the COCKPIT DOOR panel (central pedestal). In the cabin, the green light on the keypad flashes until the flight crew uses the COCKPIT DOOR sw to either lock or unlock the cockpit door. After identification of the person (via the Cockpit Door Surveillance system ) that requests access, use the COCKPIT DOOR sw to unlock the door. If the flight crew refuses access by setting the COCKPIT DOOR sw to LOCK position, the keypad and the buzzer are inhibited for a defined period of time. If the flight crew does not respond, after a preselected time between 15 and 120 s, the door automatically unlocks for 5 s and a steady green light on the keypad comes. The buzzer stops and indicates that the door is unlocked.

### **EVACUATION THROUGH THE DECOMPRESSION AND EVACUATION PANEL**

Pull the quick-release pins of the escape panel towards the center of the flap.  
Kick the escape panel toward the cabin and evacuate the cockpit.

## **HOW TO OPERATE THE FWD AND AFT CARGO DOOR**

Ident.: DSC-52-50-00020574.0003001 / 17 MAR 17

Applicable to: ALL

### **NORMAL OPERATION**

#### **OPENING**

On the cargo door, push the door handle flap inward to release the door handle from the recess of the door structure. Then, pull the door handle away and upward from the LOCKED to the UNLOCKED position.


Open the access door of the service panel to get access to the selector valve lever. Set the selector valve lever to the OPEN position and maintain the lever in this position until the green indicator light comes on. The green indicator light indicates that the door is fully opened and locked.

*Note:* The yellow hydraulic system is pressurized (the YELLOW ELEC PUMP is energized).  
The operation of the flight controls and PTU is inhibited.

When the door is fully open, release the selector valve lever. When released, the selector valve lever returns to the neutral position and shuts down the electrical pump.

#### **CLOSING**

In order to close the cargo door, set the selector valve lever to the CLOSE position and maintain the lever in this position until the green indicator light goes off. When this light goes off, it means that the door is fully closed and locked.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>DOORS</b></p> <p style="text-align: center;">HOW TO</p>
---	--

*Note:* At first the selector valve lever locks in an intermediate position maintaining a preset pressurization to prevent the door from dropping open.

When the door is fully closed, the selector valve lever returns to the neutral position and shuts down the electrical pump.

On the cargo door, push the door handle flap downwards to the LOCKED position. When the door is locked, the cargo door symbol appears in green on the DOOR/OXY SD page. The CARGO door indication on the ECAM goes off, and the handle flap mechanism locks the operating handle.

Close the access door of the service panel.

<b>HOW TO OPERATE THE FWD AND AFT CARGO DOORS (AUXILIARY OPERATION)</b>
---

Ident.: DSC-52-50-00020577.0002001 / 17 MAR 17

Applicable to: ALL

### **AUXILIARY OPERATION**

If there is an electrical failure or if the yellow hydraulic electric pump fails, the operator can open or close the cargo door with the use of the hand pump that is accessible via the ground service panel.

*Note:* Two persons are necessary for this operation.

### **MANUAL OPENING**

To open the cargo door with the use of the hand pump, unlock the cargo door by using the operating handle as for normal operation.

Open the ground service panel of the yellow hydraulic system that is in the belly fairing area.

Open the access door of the door service panel. Set the selector valve lever to the OPEN position and maintain the lever in this position during the operation of the hand pump.

Operate the hand pump until the cargo door is in the fully open position. The green light comes on and indicates that the door is fully opened and locked.

When the cargo door is fully opened, release the selector valve lever of the door service panel.

### **MANUAL CLOSING**

To close the cargo door, set the selector valve lever (on the door service panel) to the CLOSE position and maintain the lever in this position during the operation of the hand pump.

Operate the hand pump until the cargo door is in the fully closed position.

When the cargo door is fully closed, release the selector valve lever of the door service panel.

Lock the cargo door with the use of the operating handle as for normal operation.

Close the access door of the door service panel and of the ground service panel.

Intentionally left blank

# **AIRCRAFT SYSTEMS**

## COCKPIT WINDOWS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### COCKPIT WINDOWS

#### PRELIMINARY PAGES - TABLE OF CONTENTS

#### **DSC-56-10 General**

General.....A

#### **DSC-56-20 Fixed Windows**

Fixed Windows.....A

#### **DSC-56-30 Sliding Windows**

Sliding Windows.....A

#### **DSC-56-40 Description**

Description.....A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### COCKPIT WINDOWS

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**COCKPIT WINDOWS**

GENERAL

**GENERAL**

Ident.: DSC-56-10-00000998.0001001 / 17 MAR 17

**Applicable to: ALL**

The cockpit has fixed and sliding windows.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**COCKPIT WINDOWS**

GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### COCKPIT WINDOWS

#### FIXED WINDOWS

### FIXED WINDOWS

Ident.: DSC-56-20-00000999.0001001 / 17 MAR 17

**Applicable to: ALL**

There are four fixed windows :

- two windshields
- two fixed side windows



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**COCKPIT WINDOWS**

FIXED WINDOWS


Intentionally left blank

**SLIDING WINDOWS**

Ident.: DSC-56-30-00018432.0001001 / 17 MAR 17

Applicable to: ALL

The flight crew can use the sliding windows as emergency exits. Therefore they are not permitted to stow any object so that it protrudes into the window area from the side console. Members of the flight crew can use the control handle to slide each of the windows rearward, and can use a locking pin to lock each window open.



(1) Unlocking button

Flight crew presses this button to unlock the control handle.

(2) Control handle

- To open the window, the crew member pulls inward and rearward.
- To close the window, the crew member pushes forward.

(3) Locking pin

This pin locks the window open.

It is near the window's lower guide track and is visible when the window is open.

- Forward

Between the closed position and the one-third open position, the window is free to move forward and aft.

When the window is more than one-third open, this pin prevents it from moving forward.

- Aft

Flight crew must move the locking pin aft in order to close the window. Left sliding window.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**COCKPIT WINDOWS**

SLIDING WINDOWS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>COCKPIT WINDOWS</b></p> <p style="text-align: center;">DESCRIPTION</p>
---	--

**DESCRIPTION**

Ident.: DSC-56-40-00013772.0001001 / 17 MAR 17

Applicable to: ALL


**COCKPIT WINDSHIELD AND WINDOWS DESCRIPTION**

All cockpit windows are fail-safe design.

The windows are made of:

- A non structural ply, the Outer ply (1), which is only a protective layer
- Two structural plies, the Middle ply (2) and the Inner ply (3)  
Each structural ply is able to sustain individually the pressurization loads
- A heating film (4) to defog and/or de-ice the windshield/window
- Two interlayers (5).

Typical Structure Of A Cockpit Window (Cut View)



For information on cockpit window damage procedure, description and evaluation method, Refer to *FCTM/PR-AEP-MISC Cockpit Windshield/Window Cracked*.

Intentionally left blank



# **AIRCRAFT SYSTEMS**

ENGINES

Intentionally left blank

**DSC-70-05 Overview**

Overview..... A

**DSC-70-10 System Description**

Engine..... A  
 Engine..... B  
 LP Compressor Turbine Assembly..... C  
 HP Compressor Turbine Assembly..... D  
 Combustion Chamber..... E  
 Accessory Gearbox..... F

**DSC-70-20 FADEC**

General..... A  
 Architecture..... B  
 Functions ..... C  
 Idle Control..... D

**DSC-70-30 Thrust Control System (CFM+PW)**

**DSC-70-30-10 General**

General..... A

**DSC-70-30-20 Thrust Levers**

Thrust Levers..... A

**DSC-70-30-30 Thrust Rating Limit**

Thrust Rating Limit..... A

**DSC-70-30-40 Thrust Control**

Manual Mode..... A  
 Automatic Mode..... B

**DSC-70-40 Fuel System (CFM56)**

General..... A  
 Fuel pump Unit..... B  
 Shut-Off Valves..... C  
 Hydromechanical Unit..... D  
 IDG Cooling System ..... E

**DSC-70-50 Oil System**

General..... A

*Continued on the following page*

*Continued from the previous page*

**DSC-70-60 Airbleed System (CFM56)**

General.....	A
Cooling.....	B

**DSC-70-70 Thrust Reverser System**

General.....	A
Actuation Logic.....	B
Protection.....	C
Schematic.....	D

**DSC-70-80 Ignition and Starting**

**DSC-70-80-10 General**

General.....	A
--------------	---

**DSC-70-80-20 Architecture**

Architecture.....	A
-------------------	---

**DSC-70-80-30 Ignition System**

General.....	A
Ignition for Starting.....	B
Continuous Ignition.....	C

**DSC-70-80-40 Engine Starting System**

General.....	A
Automatic Starting.....	B
Automatic Starting Sequence.....	C
Manual Starting.....	D
Engine Ventilation (Dry Cranking).....	E

**DSC-70-90 Controls and Indicators**

**DSC-70-90-10 Overhead Panel**

ENG MAN START Panel.....	A
--------------------------	---

**DSC-70-90-20 Pedestal**

ENG MODE Selector and ENG MASTER Levers.....	A
Thrust Levers.....	B

**DSC-70-90-30 Maintenance Panel**

ENG FADEC GND PWR Panel.....	A
------------------------------	---

*Continued on the following page*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ENGINES**

PRELIMINARY PAGES - TABLE OF CONTENTS

*Continued from the previous page*

DSC-70-90-40 Engine Display

Engine/Warning Display.....	A
ENG SD Page.....	B

DSC-70-90-50 Memo Display

Memo Display.....	A
-------------------	---



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**OVERVIEW**

Applicable to: ALL

Ident.: DSC-70-05-10-00018242.0002001 / 21 MAR 16


The aircraft has two CFM International CFM56-5B engines that supply power to the aircraft.

Ident.: DSC-70-05-10-00018265.0001001 / 21 MAR 16


The engines are turbofan engines that have:

- A high bypass ratio,
- A Full Authority Digital Engine Control (FADEC),
- A fuel system,
- An oil system,
- An air system,
- A thrust reverser system,
- An ignition system and a start system.

Overview





 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>ENGINES</b> SYSTEM DESCRIPTION</p>
---	--

<b>ENGINE</b>
---------------

Ident.: DSC-70-10-00018361.0001001 / 21 MAR 16

**Applicable to: ALL**

The engine has:

- Two compressor turbine assemblies:
  - The Low Pressure (LP) compressor turbine assembly,
  - The High Pressure (HP) compressor turbine assembly.

**L2** Each turbine operates its associated compressor via a shaft.

- L1**- One accessory gearbox,  
- One combustion chamber.

The engine operates as follows:

1. The LP compressor, compresses the air.
2. Then, the air is divided into two flows:
  - Most of the air flows out of the core engine, and provides most of the engine thrust.
  - The remaining air enters the core engine.
3. The HP compressor compresses the air that enters the core engine.
4. The fuel is added to and mixed with the compressed air of the core engine. The mixture is ignited in the combustion chamber.
5. The gas that results from combustion drives the HP and the LP turbines.

The rotation speed of the fan provides the N1 engine parameter.

The rotation speed of the HP rotor provides the N2 engine parameter.

The N1 and N2 engine parameters appear on the Engine/Warning Display (E/WD).

**L2** The N1 and N2 engine parameters are current rotation speeds displayed in percentage.


**L1** The FADEC uses:

- The N1 engine parameter to compute the applicable engine thrust,
- The N1 and N2 engine parameters for engine control and monitoring.

**ENGINE**

Ident.: DSC-70-10-00018362.0002001 / 21 MAR 16

Applicable to: ALL



**LP COMPRESSOR TURBINE ASSEMBLY**


Ident.: DSC-70-10-00018289.0002001 / 21 MAR 16

Applicable to: ALL

**LP COMPRESSOR TURBINE ASSEMBLY**

The LP compressor turbine assembly has:

- One LP compressor,
  - L2 - One LP shaft,
  - L1 - One LP turbine.
- L2 The LP shaft connects the LP compressor to the LP turbine.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>ENGINES</b> SYSTEM DESCRIPTION</p>
---	--

**L3** The LP compressor has a fan and 4 stages, and the LP turbine has 4 stages.

## HP COMPRESSOR TURBINE ASSEMBLY

Ident.: DSC-70-10-00018290.0001001 / 21 MAR 16

Applicable to: ALL

### HP COMPRESSOR TURBINE ASSEMBLY

The HP compressor turbine assembly has:

- One HP compressor,
- L2** - One HP shaft,
- L1** - One HP turbine.

**L2** The HP shaft connects the HP compressor to the HP turbine.

**L3** The HP compressor has 9 stages, and the HP turbine has a single stage.

## COMBUSTION CHAMBER

Ident.: DSC-70-10-00018292.0001001 / 21 MAR 16

Applicable to: ALL

### COMBUSTION CHAMBER

The combustion chamber burns a mixture of fuel and HP air. The FADEC controls the fuel/air mixture in accordance with the position of the thrust lever and the aircraft operating conditions.

**L3** The combustion chamber is an annular assembly with fuel nozzles and two igniters.

The combustion chamber is between the HP compressor and the HP turbine.

## ACCESSORY GEARBOX

Ident.: DSC-70-10-00018364.0001001 / 21 MAR 16

Applicable to: ALL

### ACCESSORY GEARBOX

The accessory gearbox drives various accessories with mechanical power via the HP shaft for the operation of the engine and the aircraft systems.

- L2** The accessory gearbox of each engine operates:
  - The oil feed pump that provides the oil system with oil.
  - The main engine fuel pump that provides the combustion chamber with fuel.
  - The engine-driven hydraulic pumps that pressurize the GREEN and the YELLOW hydraulic systems.
  - The engine-driven generators that are the primary source of electrical power.

- The FADEC alternator that provides the FADEC with electrical power.
- The pneumatic starter that enables the engine start.

**GENERAL**

Ident.: DSC-70-20-00020869.0001001 / 17 MAR 17

**Applicable to: ALL**

Each powerplant has a FADEC (Full Authority Digital Engine Control) system.  
FADEC is a digital control system that performs complete engine management.  
FADEC has two-channel redundancy, with one channel active and one in standby.  
If one channel fails, the other automatically takes control.  
The system has a magnetic alternator for an internal power source.  
FADEC is mounted on the fan case.  
The Engine Interface Unit (EIU ) transmits to FADEC the data it uses for engine management.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**


**ENGINES**

**FADEC**

**ARCHITECTURE**

Ident.: DSC-70-20-00001566.0005001 / 21 MAR 16

Applicable to: ALL



**FUNCTIONS**

Ident.: DSC-70-20-00001567.0001001 / 21 MAR 16

Applicable to: ALL

The FADEC system performs the following functions :

**Control of gas generator**

- control of fuel flow
- acceleration and deceleration schedules
- variable bleed valve and variable stator vane schedules
- control of turbine clearance
- idle setting

**Protection against engine exceeding limits**

- protection against N1 and N2 overspeed
- monitoring of EGT during engine start

**Power management**

- automatic control of engine thrust rating
- computation of thrust parameter limits
- manual management of power as a function of thrust lever position
- automatic management of power (A/THR demand).

**Automatic engine starting sequence**

- control of :
  - the start valve (ON/OFF)
  - the HP fuel valve
  - the fuel flow
  - the ignition (ON/OFF)
- monitoring of N1, N2, FF and EGT
- initiation of abort and recycle (on the ground only)

**Manual engine starting sequence**

- passive monitoring of engine
- control of :
  - the start valve
  - the HP fuel valve
  - the ignition


**Thrust reverser control**

- Actuation of the blocker doors
- Engine setting during reverser operation

**Fuel recirculation control**

- Recirculation of fuel to the fuel tanks, depending on the engine oil temperature, the fuel system configuration, and the flight phase.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b></p> <p style="text-align: center;"><b>ENGINES</b></p> <p style="text-align: center;">FADEC</p>
---	---

**Transmission of engine parameters and engine monitoring information to cockpit indicators**

- Primary engine parameters
- Starting system status
- Thrust reverser system status
- FADEC system status

**Detection, isolation, and recording of failures**

**FADEC cooling**

**IDLE CONTROL**

Ident.: DSC-70-20-00015374.0001001 / 17 NOV 14

**Applicable to: ALL**

The FADEC has the following three idle modes :

**Modulated idle**

- Is regulated according to :
  - bleed system demand
  - ambient conditions
- Is selected :
  - In flight, when the flaps are retracted (FLAPS lever at zero position)
  - On ground, provided reverse is not selected.

**Approach idle**

- Is regulated according to aircraft altitude, regardless of bleed system demand.
- Is selected in flight, when the flaps are extended (FLAPS lever not at zero position)
- Allows the engine to accelerate rapidly from idle to go-around thrust.

**Reverse idle**

- Is selected on ground, when the thrust lever is in REV IDLE position.
- Is slightly higher than forward idle thrust.

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

THRUST CONTROL SYSTEM (CFM+PW) - GENERAL

### GENERAL

Ident.: DSC-70-30-10-00020872.0002001 / 17 MAR 17

**Applicable to: ALL**

A FADEC dedicated to each engine controls the thrust.

The pilot uses the thrust levers to set the thrust in manual mode, and the FMGS sets the thrust in automatic mode (A/THR function).

The FADEC prevents the thrust from exceeding the limit for the thrust lever position in both manual and automatic modes.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES


THRUST CONTROL SYSTEM (CFM+PW) - GENERAL

Intentionally left blank

**THRUST LEVERS**

Ident.: DSC-70-30-20-00020873.0002001 / 17 MAR 17

Applicable to: ALL



The thrust levers can only be moved manually.

They move over a sector that is divided into four operating segments.

The sector has five positions defined by detents or stops.

Thrust lever position is transmitted to the FADEC , which computes and displays the thrust rating limit and the N1 for that Thrust Lever Angle (TLA).

*Note:* There is no reverse idle detent. When the pilot moves the lever out of the idle stop by pulling up the reverse lever on the front of the thrust lever, he/she selects reverse idle.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

THRUST CONTROL SYSTEM (CFM+PW) - THRUST LEVERS


Intentionally left blank

**THRUST RATING LIMIT**

Ident.: DSC-70-30-30-00001571.0001001 / 21 MAR 16

Applicable to: ALL

The FADEC computes the thrust rating limit for each thrust lever position, as shown below. If the thrust lever is set in a detent, the FADEC selects the rating limit corresponding to this detent. If the thrust lever is set between two detents, the FADEC selects the rating limit corresponding to the higher detent.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

THRUST CONTROL SYSTEM (CFM+PW) - THRUST RATING LIMIT

Intentionally left blank



**MANUAL MODE**

Ident.: DSC-70-30-40-00001572.0001001 / 17 NOV 14

Applicable to: ALL


The engines are in the manual mode provided the A/THR function is:

- not armed or
- armed and not active (thrust lever not in the A/THR operating range and no alpha floor).

In these conditions, each engine is controlled by the position of its thrust lever.

The pilot controls thrust by moving the thrust lever between the IDLE and TOGA positions. Each position of the thrust lever within these limits corresponds to an N1.

When the thrust lever is in a detent, the corresponding N1 is equal to the N1 rating limit computed by the FADEC for that engine.



When the thrust lever is in the FLX/MCT detent:

- **On the ground**

The engine runs at the flex takeoff thrust rating if the crew has selected a flex takeoff temperature on the MCDU that is higher than the current Total Air Temperature (TAT).

Otherwise the engine produces Maximum Continuous Thrust (MCT).

- **After takeoff**

The pilot can change from FLX to MCT by moving the thrust lever to TOGA or CL, then back to MCT. After that, he cannot use the FLX rating.

*Note: Setting the thrust lever out of FLX/MCT detent without reaching TOGA or CL detent has no effect.*


The pilot can always get MAX TO thrust by setting the thrust levers to TOGA.

**AUTOMATIC MODE**

Ident.: DSC-70-30-40-00020874.0003001 / 17 MAR 17

Applicable to: ALL

In the autothrust mode (A/THR function active), the FMGC computes the thrust which is limited to the value corresponding to the thrust lever position (unless the alpha-floor mode is activated).



**INDICATIONS ON FMA**

The FADEC s monitor the positions of the thrust levers, and trigger appropriate indications on the FMA. *Refer to DSC-22\_30-100 Autothrust Annunciations (FMA Column 1) - Third Line.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

THRUST CONTROL SYSTEM (CFM+PW) - THRUST CONTROL

Intentionally left blank


**GENERAL**

Ident.: DSC-70-40-00020868.0001001 / 17 MAR 17

**Applicable to: ALL**

The fuel system supplies fuel to the combustion chamber at the required flow rate, pressure, and temperature.

The fuel flows from the tank, via the fuel pump unit and the fuel/oil heat exchanger, to the Hydromechanical Unit (HMU) and to the fuel nozzles.



**FUEL PUMP UNIT**

Ident.: DSC-70-40-00001586.0001001 / 21 MAR 16

Applicable to: ALL

The HP compressor shaft drives the HP fuel pump assembly. Fuel flows through the LP pump, then through the fuel/oil heat exchanger and the HP pump (gear pump).

The fuel then divides into a filtered flow for the servo fuel heater and the servo valves of the HMU , and an unfiltered flow for the metering valve of the HMU.

## SHUT-OFF VALVES

Ident.: DSC-70-40-00001587.0001001 / 12 MAY 16

Applicable to: ALL

Moving the ENG 1 (ENG 2) MASTER switch to OFF directly commands the closing of the LP and HP fuel shut off valves for that engine's fuel system.

It also closes the fuel return valve and opens the bypass valve.

## HYDROMECHANICAL UNIT

Applicable to: ALL

Ident.: DSC-70-40-A-00001588.0001001 / 17 MAR 17

### GENERAL

The FADEC controls the HMU, which :

- controls fuel flow to the engine combustion chamber
- controls fuel hydraulic signals to actuators
- protects against overspeeding.


Ident.: DSC-70-40-A-00020880.0001001 / 17 MAR 17

### FUEL FLOW

**L3** The Fuel Metering Valve (FMV) transforms FADEC orders through a torque motor and servo valve into fuel flow to the engine fuel nozzles.

The FMV resolver generates a feedback signal proportional to the FMV position.

The bypass valve maintains a constant pressure drop across the FMV to ensure that the metered fuel flow is proportional to the FMV position.




L1 The FADEC computes the fuel flow that will maintain the target N1.

As the FADEC maintains this N1, it allows N2 to vary while remaining between N2 minimum and N2 maximum. The FADEC also controls the engine parameters to :

- Limit acceleration and deceleration ;
- Avoid engine stall or flameout ;
- Limit maximum N1 and N2 ;
- Maintain air bleed pressure requirement.

The FADEC computes an N2 correction according to the bleed configuration.



Ident.: DSC-70-40-A-00001590.0001001 / 17 MAR 17

**OVERSPEED GOVERNOR SYSTEM**

Independent of the FADEC, the overspeed governor limits the N2 by opening the fuel bypass valve, in the event of a malfunction that could lead to an overspeed condition.



Ident.: DSC-70-40-A-00001592.0002001 / 17 MAR 17


**FUEL HYDRAULIC SIGNALS**

- Fuel hydraulic signals go to :
  - Low Pressure Turbine Clearance Control (LPTCC) valves  
 (Refer to DSC-70-60 General)
  - High Pressure Turbine Clearance Control (HPTCC) valves  
 (Refer to DSC-70-60 General)
  - Rotor Active Clearance Control ( RACC ) system  
 (Refer to DSC-70-60 General)
  - Variable Stator Vanes ( VSV )

The VSV system positions the compressor variable vanes.


The FADEC maintains optimum compressor efficiency at a steady state and an adequate stall margin for transient engine operation.

VSVs are fully closed during engine start and are fully open at high thrust.



- Variable Bleed Valves ( VBV )

The FADEC controls the VBV s, upstream of the HP compressor. Their setting depends on compressor inlet temperature and on N2. It varies between full open (start, low thrust, and during fast deceleration) and full closed (high thrust) positions.



**IDG COOLING SYSTEM**

Ident.: DSC-70-40-00001593.0001001 / 26 JUL 12

Applicable to: ALL

Some of the fuel flowing out of the HMU goes to cool the oil systems of the Integrated Drive Generators (IDGs). It then returns to the fuel pump unit or to the tank.

The Fuel Return Valve (FRV), controlled by the FADEC, ensures that this flow is adequate.

ⓘ At low engine thrust, if the oil going into the IDG is too hot, the cooling fuel is sent back to the tank (300 kg/h).

If oil temperature continues to rise, the ECU increases the minimum N2.



If oil temperature still keeps rising, the FADEC increases the fuel flow to the tank (from 300 to 600 kg/h, depending on fuel return temperature).

The fuel return valve is always mixing hot fuel with cold fuel so that the temperature of fuel returning to the tank stays below 100 °C (from 200 to 400 kg/h, depending on fuel return temperature).

Fuel recirculation to the tank is inhibited (FRV closed) in the following cases :

- at engine shutdown
- during takeoff and climb
- if :
  - wing tank level is below about 300 kg (660 lb).
  - there is fuel overflow in the surge tank
  - fuel feed is by gravity only.
- when fuel temperature in the wing tank in flight is above 52.5 °C

*Note: On the ground, high fuel temperature in the wing tank or fuel overflow in the surge tank does not inhibit the fuel recirculation to the wing tank (FRV remains open).*





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ENGINES**

FUEL SYSTEM (CFM56)

Intentionally left blank

**GENERAL**

Ident.: DSC-70-50-00001603.0001001 / 21 MAR 16

**Applicable to: ALL**

The oil system lubricates the engine components.


It contains :

- the oil tank
- the lube and scavenge pump modules
- the fuel/oil heat exchanger
- the filters, chip detectors, pressure relief and bypass valves.

**AIRCRAFT SYSTEMS**

**ENGINES**

**OIL SYSTEM**



**GENERAL**


Ident.: DSC-70-60-00001604.0002001 / 21 MAR 17

Applicable to: **ALL**

The air bleed system supplies the aircraft with compressed air.

It uses the air for:

- pneumatic system (*Refer to DSC-36-10-10 General*)
- cooling the engine compartment and the turbines.



**COOLING**

Ident.: DSC-70-60-00001605.0002001 / 21 MAR 16

Applicable to: **ALL**

**ROTOR ACTIVE CLEARANCE CONTROL (RACC) SYSTEM**

The FADEC controls the RACC system through the HMU . The RACC system controls the clearance between the rotor blades of the HP compressor and its stator case.

The RACC system uses fifth-stage compressor bleed air that has been modulated according to the N2 and the flight parameters. The bleed air goes to the N°3 bearing compartment, where it is mixed with fan boost discharge.

Clearances are at the maximum when the RACC valve is closed.

### **HP TURBINE CLEARANCE CONTROL (HPTCC) SYSTEM**

The FADEC controls the HPTCC system through the HMU . The HPTCC system controls the HP turbine clearance by modulating the HP compressor bleed air flow for cooling the HP turbine case. It optimizes HP turbine performance and reduces exhaust gas temperature.

### **LP TURBINE CLEARANCE CONTROL (LPTCC) SYSTEM**

The FADEC controls the LPTCC system through the HMU . The LPTCC system controls LP turbine clearance by modulating the fan bleed air flow for cooling the LP turbine case.




**GENERAL**

Ident.: DSC-70-70-00020918.0003001 / 17 MAR 17

Applicable to: ALL

The aircraft reverses engine thrust by using four pivoting blocker doors on each engine to deflect the fan airstream.



A hydraulic door jack positions each door.

- The green circuit powers the doors on ENG 1.
- The yellow circuit powers the doors on ENG 2.

The FADEC controls the thrust reverser system. Each FADEC channel performs control and monitoring functions. The systems for the two engines are independent of each other.

The thrust reverser system on each engine has :

- 4 actuators,
- 4 latches,
- Door position switches,
- A Hydraulic Control Unit (HCU) that :
  - Pressurizes the thrust reverser hydraulic system,
  - Regulates the speed of the blocker doors, and
  - Supplies actuators with hydraulic power.
- A hydraulic shutoff valve which allows hydraulic pressure to the HCU.

Each pivoting door moves independently (the doors are not synchronized).

The total actuation time is less than two seconds.

### ACTUATION LOGIC

Ident.: DSC-70-70-00020920.0001001 / 17 MAR 17

Applicable to: **ALL**

Deployment requires :

- One FADEC channel, operating with its associated throttle reverse signal ;
- Right and left main gear compressed signal from the corresponding LGCIUs ;
- A Thrust Lever Angle (TLA ) reverse signals from at least one Spoiler Elevator Computer (SEC).

Before deployment is completed, the FADEC sets reverse idle thrust on the engine that is having its thrust reversed.

### PROTECTION

Ident.: DSC-70-70-00020921.0006001 / 17 MAR 17

Applicable to: **ALL**

- IDLE PROTECTION


The FADEC will automatically select the thrust to idle :

- In case of inadvertent thrust reverser deployment (while thrust reversers are commanded stowed), as soon as the thrust reverser feedback position is above 15 % deployed (thrust decreasing toward idle, when the detected position is between 10 % and 15 % ).
- In case of inadvertent thrust reverser stowage (while thrust reversers are commanded deployed), as soon as the thrust reverser feedback position is below 78 % deployed (thrust decreasing toward idle between 90 % and 78 % ).

**SCHEMATIC**

Ident.: DSC-70-70-00020919.0006001 / 17 MAR 17

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ENGINES**

**THRUST REVERSER SYSTEM**

Intentionally left blank

**GENERAL**

Ident.: DSC-70-80-10-00020922.0001001 / 17 MAR 17

**Applicable to: ALL**

The FADEC controls and monitors the ignition and starting system according to:

- The position of the ENG MODE selector
- The position of the ENG MASTER sw
- The position of the ENG MAN START pb-sw
- The aircraft status (flight or ground)

The FADEC receives the previous inputs from the EIVMU /EIU.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**AIRCRAFT SYSTEMS**

**ENGINES**


IGNITION AND STARTING - GENERAL

Intentionally left blank

**ARCHITECTURE**

Ident.: DSC-70-80-20-00001617.0002001 / 21 MAR 16

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

IGNITION AND STARTING - ARCHITECTURE

Intentionally left blank




**GENERAL**

Ident.: DSC-70-80-30-00020923.0001001 / 17 MAR 17

Applicable to: ALL

The ignition system is for engine starting on the ground and restarting in flight. It consists of two identical independent circuits for each engine, normally controlled by the FADEC channel A and channel B. Each FADEC channel can control both igniters.



*Note:* Supply for igniter A switches to the STAT INV BUS BAR as soon as the static inverter is operative.

**IGNITION FOR STARTING**

Ident.: DSC-70-80-30-00020924.0002001 / 17 MAR 17

Applicable to: ALL

**ON THE GROUND**

Automatic start:

- During a first automatic start attempt only one igniter is supplied. The FADEC automatically alternates the igniters and/or channels used in successive start sequences.
- The ignition comes on automatically when N2 reaches 16 % and cuts off automatically when N2 reaches 50 %.

- During an automatic start, if the first attempt fails, the FADEC automatically initiates a new start attempt with both igniters energized.
- Manual start:
  - During a manual start both igniters are supplied, when the ENG MASTER sw is ON.
  - Both igniters are cut off when N2 reaches approximately 50 %.

**IN FLIGHT**

In case of start attempt in flight, when the ENG MASTER sw is ON, both igniters are supplied.

**CONTINUOUS IGNITION**

Ident.: DSC-70-80-30-00001620.0004001 / 21 MAR 16

Applicable to: ALL

Continuous ignition may be selected either manually or automatically to maintain engine combustion.


**MANUAL SELECTION**


In flight, continuous ignition is on when the ENG MODE selector is on IGN/START, if the corresponding engine is running.

Only one igniter is selected. If failed, both igniters are automatically selected.

On the ground after the engine is started, because ignition cuts off automatically, the flight crew must switch the ENG MODE selector to NORM then back to IGN/START to turn on continuous ignition.

**AUTOMATIC SELECTION**



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>AIRCRAFT SYSTEMS</b> <b>ENGINES</b></p> <p style="text-align: center;">IGNITION AND STARTING - ENGINE STARTING SYSTEM</p>
---	---

**GENERAL**

Ident.: DSC-70-80-40-00001621.0001001 / 21 MAR 16

**Applicable to: ALL**

The engine starting system consists of an air turbine starter and a start valve. The start valve admits air supplied by the pneumatic system to operate the starter. The FADEC controls the start valve electrically and bleed pressure is required for opening the start valve. If electrical control fails when the aircraft is on the ground, a handle allows the start valve to be operated manually.

**AUTOMATIC STARTING**

**Applicable to: ALL**

Ident.: DSC-70-80-40-10-00020932.0001001 / 21 MAR 17

**GENERAL**

This sequence is under the full authority of the FADEC, which controls:

- The start valve
- The igniters
- The fuel HP valves.

Ident.: DSC-70-80-40-10-00020933.0001001 / 21 MAR 17

**PROTECTION**

The FADEC :

- Detects a hot start, a hung start, a stall, or no light up
- Announces FAULT and identifies the fault in an ECAM message
- Runs an abort sequence if a start aborts on the ground
  - Closes the HP valve
  - Closes the start valve
  - Turns off ignition
  - Cranks the engine crank after the start abort in order to clear out fuel vapors
  - Controls any additional start attempts.

Ident.: DSC-70-80-40-10-00020934.0001001 / 21 MAR 17

**DRY CRANKING**

Depending on the engine thermal state, the FADEC can initiate a pre-start motoring (dry cranking) up to 60 s. Pre-start motoring is active during all ground starts and ground cranking procedures to limit the engine core speed below the bow rotor critical speed (bow rotor protection). The motoring time will vary depending on the residual thermal condition of the engine and depending on the

engine vibration level. During the engine motoring, the FADEC logic limits the maximum N2 around 30 %.

Ident.: DSC-70-80-40-10-00020935.0001001 / 21 MAR 17

### **WINDMILLING**

For an in-flight start, the FADEC decides whether the engine is windmilling fast enough or needs assistance from the starter in view of current engine parameters and flight environment parameters.


Flight crew may interrupt this start sequence by moving the ENG MASTER sw to OFF.

**AUTOMATIC STARTING SEQUENCE**

Applicable to: ALL

Ident.: DSC-70-80-40-20-00020925.0001001 / 21 MAR 17

**SEQUENCE OF THE AUTOMATIC START**



Ident.: DSC-70-80-40-20-00020926.0001001 / 21 MAR 17

**INITIAL CONFIGURATION OF THE CONTROLS**

The initial configuration prior an automatic engine start is the following :

- The ENG MASTER sw is set to OFF
- The ENG MODE selector is set to NORM
- The ENG MAN START pb-sw is set to OFF.

Ident.: DSC-70-80-40-20-00020927.0001001 / 21 MAR 17

### **FIRST STEP**

The flight crew must set the ENG MODE selector to IGN/START, leading to the following:

- The ENG SD page appears on the SD
- All engine parameters are available
- Pack valves automatically close.

After 30 s, if the flight crew does not set the ENG MASTER sw to ON (*Refer to DSC-70-80-40 Second Step*), pack valves automatically open again.

Ident.: DSC-70-80-40-20-00020928.0001001 / 21 MAR 17

### **SECOND STEP**

The flight crew must set the ENG MASTER sw to ON, and the following steps occur:

- The LP fuel valve opens
- The engine start valve opens
- The ignition starts:
  - On ground: when  $N_2 > 16\%$
  - In flight: Immediately.
- The HP fuel valve opens:
  - On ground: when  $N_2 > 22\%$
  - In flight: when  $N_2 > 15\%$ .
- When  $N_2 > 50\%$ :
  - The engine start valve closes
  - The ignition stops if on ground
  - The pack valves reopen if another engine is not started within 30 s.

Ident.: DSC-70-80-40-20-00020929.0001001 / 21 MAR 17

### **THIRD STEP**

The automatic engine start is finished.

The flight crew must set the ENG START selector to NORM.

Ident.: DSC-70-80-40-20-00020930.0001001 / 21 MAR 17

### **INTERRUPTION OF THE AUTOMATIC START**

When required by ECAM and after confirmation, the flight crew must set the ENG MASTER lever to OFF.

If the flight crew sets the ENG MASTER sw to OFF, the FADEC automatically :

- Closes the LP and the HP fuel shutoff valves
- Stops to energize the ignitor
- Closes the engine start valve.

## MANUAL STARTING

Ident.: DSC-70-80-40-00020937.0001001 / 17 MAR 17

Applicable to: ALL

If an automatic start is not successful, the flight crew can perform a manual start.

In the manual start sequence, the FADEC has limited control. As a result, the flight crew must monitor engine acceleration.

To perform a manual start, the flight crew must :

- Set the ENG MODE selector to IGN/START
- Set the ENG MAN START pb-sw to ON
- Set the ENG MASTER sw to ON.

The FADEC:

- Opens the engine start valve when the flight crew :
  - Sets the ENG MODE selector to IGN/START
  - Sets the ENG MAN START pb-sw to ON
- Opens the HP shutoff valve, and operates both igniters when the flight crew sets the ENG MASTER sw to ON
- Closes the engine start valve, and cuts off the ignition when N2 reaches 50 %.

For more information about the manual start sequence, *Refer to PRO-NOR-SUP-ENG Manual Engine Start - General.*

The FADEC makes a passive survey of the engine during the starting sequence : the flight crew is made aware of an abnormal start by a proper ECAM warning and has to interrupt the start sequence. The FADEC has not the authority to abort the manual start :

- in flight
- on ground, except if the start EGT limit is exceeded before reaching 50 % N2. In this case only, the FADEC aborts the start.

In flight, the FADEC always commands a starter-assisted air start.

**ENGINE VENTILATION (DRY CRANKING)**

Ident.: DSC-70-80-40-00020938.0001001 / 21 MAR 17

**Applicable to: ALL**

A dry cranking cycle ventilates the engine to remove fuel vapors after an unsuccessful start attempt on the ground.

The flight crew can manually select cranking by setting the ENG MODE selector to CRANK and the ENG MAN START pb-sw to ON (ENG MASTER sw OFF). Flight crew can stop the cranking by setting the ENG MAN START pb-sw to OFF.




**ENG MAN START PANEL**

Applicable to: ALL

Ident.: DSC-70-90-10-20-00018366.0001001 / 21 MAR 16

ENG MAN START Panel



Ident.: DSC-70-90-10-20-00018370.0001001 / 12 MAY 16

**ENG MAN START pb-sw**

- Off : - Aborts the manual start sequence of the associated engine, when the ENG MODE selector is set to IGN/START and the ENG MASTER lever is set to OFF, or
- Stops the dry crank process of the associated engine, when the ENG MODE selector is set to CRANK and the ENG MASTER lever is set to OFF.

**L13**

- ON (in blue) : - Initiates the manual start sequence of the associated engine, when the ENG MODE selector is set to IGN/START, or
- Initiates the wet crank process of the associated engine, when the ENG MODE selector is set to CRANK and the ENG MASTER lever is set to ON, or
  - Initiates the dry crank process of the associated engine, when the ENG MODE selector is set to CRANK and the ENG MASTER lever is set to OFF.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

CONTROLS AND INDICATORS - OVERHEAD PANEL

Intentionally left blank

**ENG MODE SELECTOR AND ENG MASTER LEVERS**

Applicable to: ALL

Ident.: DSC-70-90-20-30-00018367.0001001 / 12 OCT 16

ENG MODE selector and ENG MASTER Levers



Ident.: DSC-70-90-20-30-00018373.0001001 / 21 MAR 17

**ENG MODE START selector**

NORM : Normal mode of operation.

IGN/START : Use the IGN/START position to:

- Initiate the automatic or manual start sequences of the associated engine, when the ENG MASTER lever is set to OFF, or
- Initiate the ignitors in flight as required.

L18

- CRANK : Use the CRANK position to:
- Initiate the dry crank process of the associated engine, when the ENG MASTER lever is set to OFF and the ENG MAN START pb-sw is set to ON.
  - Initiate the wet crank process of the associated engine for maintenance purpose, when the ENG MASTER lever, and the ENG MAN START pb-sw are set to ON.

Ident.: DSC-70-90-20-30-00018371.0001001 / 12 MAY 16

### **ENG MASTER lever**

Also called ENG MASTER sw.

- ON : The FADEC:
- Initiates the automatic start sequence of the associated engine, when the ENG MODE selector is set to IGN/START, or
  - Initiates the manual start sequence of the associated engine, when the ENG MODE selector is set to IGN/START and the ENG MAN START pb-sw is set to ON.
- OFF : The FADEC:
- Shuts down the associated engine, or
  - Aborts the start sequence of the associated engine.

Ident.: DSC-70-90-20-30-00018372.0001001 / 21 MAR 17

### **ENG 1(2) FIRE light**

FIRE Light :

A fire is detected in the corresponding engine.

*Refer to DSC-26-20-20 ENG 1(2) FIRE Light*

### **ENG 1(2) FAULT light**

FAULT light :

This amber light comes on, and a caution appears on ECAM, if there is:


- The position of the HP fuel shutoff valve is abnormal, or
- The automatic start sequence of the associated engine aborts, or
- There is a malfunction of the thrust control.

**THRUST LEVERS**

Applicable to: ALL

Ident.: DSC-70-90-20-40-00018368.0001001 / 28 JUL 16

Thrust Levers



Ident.: DSC-70-90-20-40-00018376.0001001 / 21 MAR 16

**THRUST LEVERS**

The flight crew uses the thrust levers in order to:

- Adjust the thrust, or
- Select a thrust stop or detent, or

- Control the deployment and the stowage of the associated reversers, or
- Adjust the associated reverse thrust.

The flight crew can move each thrust lever individually.

**L2** The position of the thrust levers appears on the E/WD, via a blue circle on the thrust gauge.

**L1** The flight crew can move each thrust lever forward the Idle (0) stop, when the associated thrust reverser lever is set to the locked position.

The flight crew can move each thrust lever backward the Idle (0) stop, when the associated thrust reverser lever is in the unlocked position.

Ident.: DSC-70-90-20-40-00018377.0001001 / 12 OCT 16

### **THRUST DETENTS AND STOPS**

There are two stops and four detents:

- The Idle (0) stop,
- The Climb (CL) detent,
- The Maximum Continuous Thrust (MCT )/Flexible Take Off (FLX) detent,
- The Takeoff (TO )/Go-Around (GA) detent,
- The Rev Idle (R or REV) detent,
- The Rev Max (F or FULL) stop.

Ident.: DSC-70-90-20-40-00018378.0001001 / 21 MAR 16

### **THRUST REVERSER LEVERS**

The flight crew uses the thrust reverser levers in order to unlock the associated thrust lever.

The flight crew can move each thrust reverser lever upward to the unlocked position, when the associated thrust lever is set to the Idle (0) stop.

The thrust reverser levers are automatically reset to the locked position, when the flight crew moves the thrust levers forward the Idle (0) stop.

Ident.: DSC-70-90-20-40-00018379.0001001 / 21 MAR 16

### **A/THR Instinctive Disconnect pb**

Pressing the A/THR instinctive disconnect pb disconnects the A/THR.


**L2** For more information about A/THR instinctive disconnect pb, *Refer to DSC-22\_30-90 A/THR Disconnection - General.*

**ENG FADEC GND PWR PANEL**

Applicable to: ALL

Ident.: DSC-70-90-30-10-00018365.0001001 / 12 OCT 16

ENG FADEC GND PWR Panel



Ident.: DSC-70-90-30-10-00018369.0001001 / 21 MAR 16

**ENG FADEC GND PWR PB-SW**

- Off : The electrical network of the aircraft or the FADEC alternator automatically supplies the FADEC.
- ON : On ground, when pressed the electrical network of the aircraft supplies the FADEC when:
- The ENG FIRE pb-sw is not pressed,
  - The FADEC alternator does not supply the FADEC.

Intentionally left blank




**ENGINE/WARNING DISPLAY**

Applicable to: ALL

Ident.: DSC-70-90-40-50-00017843.0003001 / 12 OCT 16

Engine/Warning Display



Ident.: DSC-70-90-40-50-00017845.0001001 / 21 MAR 16

**A FLOOR INDICATION**

The alpha floor protection is active.

For more information, Refer to DSC-22\_30-90 A/THR Modes - ALPHA FLOOR

Ident.: DSC-70-90-40-50-00017846.0001001 / 21 MAR 16

**THRUST RATING MODE AND THRUST LIMIT VALUE**

Indicates the thrust limit value and the associated thrust rating mode based on:

- The position of the thrust levers,
- Aircraft on ground or in flight,
- The engine status, i.e. running or not running,
- The data entered in the T.O and CLB panels of the FMS ACTIVE/PERF page.




Ident.: DSC-70-90-40-50-00017847.0003001 / 21 MAR 16



Ident.: DSC-70-90-40-50-00018201.0001001 / 21 MAR 16

### THRUST RATING MODE

The thrust rating modes are:

- TOGA : Takeoff or go-around (TOGA) thrust rating mode is selected.
- MCT : Maximum Continuous Thrust (MCT) rating mode is selected.
- CLB : Climb (CLB) thrust rating mode is selected.
- FLX : Flexible (FLX) takeoff thrust rating mode is selected.
- DCLB : Derated Climb  (DCLB) thrust rating mode is selected.
- D04 : Derated Takeoff  thrust rating mode is selected.  
 There are several levels of derated takeoff: D04, D08, D12, D16, D20, ...
- GA SOFT : Go-around Soft  (GA SOFT) thrust rating mode is selected.
- MREV : Maximum Reverse (MREV) thrust rating mode is selected.

Ident.: DSC-70-90-40-50-00018203.0001001 / 21 MAR 16

### THRUST LIMIT VALUE

N1 value : Indicates the N1 limit value associated with the thrust rating mode.

 The thrust limit value disappears when the thrust reversers are selected.

Ident.: DSC-70-90-40-50-00017849.0001001 / 21 MAR 16

### FLEX TEMPERATURE

Cyan : Indicates the flexible temperature that the flight crew entered in the T.O panel of the FMS PERF page, when the FLX rating mode is selected

Dashes in cyan : Indicates that the Static Air Temperature is above the flexible temperature.

Ident.: DSC-70-90-40-50-00018209.0001001 / 21 MAR 16

**IDLE INDICATION**

Both engines are at idle speed, and the aircraft is in flight.


- L2 Pulses during 10 s, and then remains steady.

Ident.: DSC-70-90-40-50-00018210.0001001 / 21 MAR 16

**AVAIL INDICATION** 

The engine is started, and at or above idle.

- L2 On ground, appears steady during 10 s after a successful start. In flight, pulses during 1 min after a successful relight.

The AVAIL Indication  disappears when the flight crew moves the thrust lever forward the idle detent.

Ident.: DSC-70-90-40-50-00018211.0001001 / 21 MAR 16

**REV INDICATION**


REV in green : On ground, the thrust reverser system is fully deployed.

L12

REV in amber : The thrust reverser system is unlocked.  
In flight, the REV indication pulses during 9 s and then remains steady.

Ident.: DSC-70-90-40-50-00018213.0001001 / 21 MAR 16

**EGT INDICATOR**



Ident.: DSC-70-90-40-50-00018216.0002001 / 21 MAR 16

**CURRENT EGT**

L12

Green : The current EGT is in normal range.  
The scale goes from 0 °C to 1 000 °C.

Amber : The current EGT exceeds the EGT amber limit.

Red : The current EGT exceeds the EGT red limit.

Ident.: DSC-70-90-40-50-00018218.0003001 / 21 MAR 16

## EGT LIMIT

The amber line indicates the maximum EGT (i.e. the EGT limit).

L2 The maximum EGT is:

- 725 °C, during the engine start sequence on ground, or
- 915 °C, in all other cases.

The EGT limit does not appear:

- When a takeoff or a go-around mode is selected, or
- When the thrust reversers are selected, or
- If the alpha floor protection is activated.

Ident.: DSC-70-90-40-50-00018219.0001001 / 21 MAR 16

## EGT EXCEEDANCE

The EGT exceedance is the highest value that the EGT reached.

The EGT exceedance appears when:

- The current EGT exceeds the EGT red limit, or
- The EGT exceeded the EGT red limit.

L2 The red mark no longer appears at the next engine start sequence on ground, or after a maintenance action.

Ident.: DSC-70-90-40-50-00018220.0003001 / 21 MAR 16

## EGT RED LINE

The EGT red line appears between the EGT red limit and the end of the scale.

L2 The EGT red limit is 950 °C.

Ident.: DSC-70-90-40-50-00018228.0001001 / 21 MAR 16

## N1 INDICATOR



Ident.: DSC-70-90-40-50-00018229.0003001 / 04 JUL 17

## **CURRENT N1**

- Green : The current N1 is in normal range.
- Amber : The current N1 exceeds the N1 limit.
- L12 Red : The current N1 exceeds the N1 red limit.  
N1 red limit is 104 %.

L12

- Dashed : The accuracy of the N1 measurement is degraded.  
Two amber dashes appear over the last digit.

Ident.: DSC-70-90-40-50-00018231.0001001 / 21 MAR 16

## **N1 TREND**

The green triangle indicates the direction of the N1 trend, when the A/THR mode is active.

Ident.: DSC-70-90-40-50-00018232.0001001 / 21 MAR 16

## **N1 COMMAND**

Indicates the N1 target, when the A/THR mode is active.

Ident.: DSC-70-90-40-50-00018233.0001001 / 21 MAR 16

## **TRANSIENT N1**

The four green arcs indicate the difference between the N1 command and the current N1 , when the A/THR is active.

Ident.: DSC-70-90-40-50-00018235.0001001 / 21 MAR 16

## THRUST LEVER POSITION

The blue circle indicates the position of the thrust lever.

In manual mode, the blue circle corresponds to the N1 value reached after the stabilization of the engine parameters.

Ident.: DSC-70-90-40-50-00018236.0001001 / 21 MAR 16

## N1 LIMIT

The amber mark indicates the N1 limit.

**L2** This corresponds to the maximum N1 value when the thrust levers are in TO/GA detent.

Ident.: DSC-70-90-40-50-00018237.0001001 / 21 MAR 16

## N1 EXCEEDANCE

The N1 exceedance is the highest value that the N1 reached.

The N1 exceedance appears when the current N1 exceeds the N1 red limit.

The N1 exceedance remains even if the N1 value decreases below the N1 red limit.

**L2** The red mark no longer appears at the next engine start sequence on ground, or after a maintenance action.

Ident.: DSC-70-90-40-50-00018238.0003001 / 21 MAR 16

## N1 RED LINE

The N1 red line appears between the N1 red limit and the end of the scale.

**L2** The N1 red limit is 104 %.

Ident.: DSC-70-90-40-50-00018239.0002001 / 21 MAR 16

## N2

In a grey box : The engine start sequence or the crank process is in progress.

Green: : N2 is in normal range.

**L12** Red : N2 exceeds the N2 red limit.

N2 red limit is 105 %.

A red cross appears.

The red cross no longer appears at the next engine start sequence on ground, or after a maintenance action.

**L12**

Dashed : The accuracy of the N2 measurement is degraded.

Two amber dashes appear over the last digit.


Ident.: DSC-70-90-40-50-00018243.0001001 / 21 MAR 16

**FUEL FLOW**

Green : The fuel flow is normal.

*Note: If the system detects a discrepancy between the N1 , N2 , EGT and fuel flow values on the FADEC -DMC bus and the corresponding displayed values, an amber CHECK appears underneath the affected parameter.*

Ident.: DSC-70-90-40-50-00018244.0001001 / 21 MAR 16

**THRUST BUMP  INDICATION**

Green : Indicates that the thrust bump is engaged.

Amber : When on the ground, indicates that the thrust bump is selected but not engaged.


Cyan : When on the ground, Indicates that the thrust bump is selected.

## ENG SD PAGE

Applicable to: ALL

Ident.: DSC-70-90-40-60-00018259.0006001 / 21 MAR 16

### ENG SD page



Ident.: DSC-70-90-40-60-00018230.0001001 / 21 MAR 16

### FUEL USED INDICATION

L12

Green : Indicates the fuel used by each engine.  
This value automatically resets on ground, at the next engine start.  
Appears in multiples of 10 kg (20 lb).



L12

- Dashed : The value accuracy is degraded.  
Two amber dashes appear over all five digits.  
This occurs when the Fuel Flow is not valid in flight, for more than 1 min.

Ident.: DSC-70-90-40-60-00018260.0001001 / 21 MAR 16

### **FUEL FILTER CLOG INDICATION**

Indicates that the pressure loss across the fuel filter is excessive.

Ident.: DSC-70-90-40-60-00018262.0002001 / 22 MAR 16

### **OIL QUANTITY**

L12

- Green : The oil quantity is in normal range.  
The scale goes from 0 to 22 QT.
- Pulses green : The oil quantity goes below the oil advisory limit (3 QT), that corresponds to the amber mark.  
The needle and the oil quantity value pulse green.  
The indication pulses, when oil quantity goes below 3.25 QT , and remains pulsing as long as oil quantity is below 4.75 QT.

Ident.: DSC-70-90-40-60-00018261.0002001 / 21 MAR 16

### **OIL PRESSURE**

L12

- Green : The oil pressure is in normal range.  
The scale goes from 0 to 100 PSI.

L12

- Pulses green : The oil pressure is:
- Above the upper advisory limit, or  
The upper advisory limit is 90 PSI.  
The oil pressure stops pulsing when oil pressure goes below 85 PSI.
  - Between the upper red threshold and the lower advisory limit, when N2 is above 75 %.  
The advisory limit is 16 PSI.  
The oil pressure stops pulsing, when oil pressure goes below 20 PSI.

L12

- Red : The oil pressure is in the red range.  
The red range is between 0 and 13 PSI.

Ident.: DSC-70-90-40-60-00018263.0002001 / 21 MAR 16

**OIL TEMPERATURE**

- Green : The oil temperature is in normal range.
- Pulses green : The oil temperature is between 140 °C and 155 °C for less than 15 min.
- Amber : The oil temperature is:
  - Between 140 °C and 155 °C for more than 15 min, or
  - Above 155 °C.

Ident.: DSC-70-90-40-60-00018266.0001001 / 21 MAR 16

**OIL FILTER CLOG INDICATION**

Indicates that the pressure loss across the oil filter is excessive.


Ident.: DSC-70-90-40-60-00018267.0001001 / 21 MAR 16

**N1 , N2 VIBRATIONS**

- Green : The vibration of the LP (HP) rotor is in normal range.
- Pulses green : The level of LP (HP) rotor vibration is excessive.

Ident.: DSC-70-90-40-60-00018268.0002001 / 21 MAR 16

**STARTING SEQUENCE INDICATION**



Ident.: DSC-70-90-40-60-00018269.0001001 / 21 MAR 16

**IGNITION INDICATION**



: The igniter A (B) is used for the engine start sequence.



: Both igniters A and B are used for the engine start sequence or continuous ignition.

Ident.: DSC-70-90-40-60-00018270.0001001 / 21 MAR 16

### START VALVE



: The engine start valve is fully closed.



: The engine start valve is fully open.

Ident.: DSC-70-90-40-60-00018271.0001001 / 21 MAR 16

### STARTER INLET PRESSURE

Green : The starter inlet pressure is normal.

Amber : The starter inlet pressure is either:

- Abnormally high, or
- Abnormally low (below 21 PSI, when N2 is above 10 % and the starter valve is not closed).

Ident.: DSC-70-90-40-60-00018272.0006001 / 21 MAR 16

### NACELLE TEMPERATURE INDICATION

The nacelle temperature indication appears when the nacelle temperature of at least one engine goes above the advisory limit if not during the start sequence.

Green : The nacelle temperature is normal.

L12

Pulses green : The nacelle temperature goes above the advisory limit.  
The advisory limit is 240 °C.

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## AIRCRAFT SYSTEMS

### ENGINES

CONTROLS AND INDICATORS - MEMO DISPLAY

### MEMO DISPLAY

Applicable to: ALL

Ident.: DSC-70-90-50-A-00018777.0001001 / 13 MAY 16

**IGNITION** : This memo appears in green when continuous ignition is activated on any engine.

Intentionally left blank

# **PROCEDURES**

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**PRELIMINARY PAGES**  
TABLE OF CONTENTS

**PRO-ABN Abnormal and Emergency Procedures**

**PRO-NOR Normal Procedures**

**PRO-SPO Special Operations**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**PRELIMINARY PAGES**  
TABLE OF CONTENTS

Intentionally left blank

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	PRO-ABN- ABN-RESET	<b>System Reset Table</b>	NG01118	
	PRO-ABN- ABN-RESET	<b>System Reset Table - AIR</b>	00021167.0001001	20 MAR 17
<p>Criteria: K10463, K6443, K9458  <b>Applicable to: ALL</b>            Impacted DU: 00021069 System Reset Table - AIR  <u>Reason for issue:</u>            The TDU is issued to provide the ACSC C/B reset procedure to apply in the case of "PACK 1(2) REGUL FAULT" triggered on ground for aircraft equipped with ACSC 1803B0000-02.</p>				
	PRO-ABN- ABN-RESET	<b>System Reset Table - COM</b>	00021114.0028001	20 MAR 17
<p>Criteria: K12824, K12825, K3901, K8400, SA  <b>Applicable to: ALL</b>            Impacted DU: 00021089 System Reset Table - COM  <u>Reason for issue:</u>            CIDS Director Hardware 333B and On Board Replacement Module (OBRM) 33A are sensitive to short power supply interruptions. These power supply interruptions occur when the aircraft is supplied by external power. As a consequence, ECAM caution "COM CIDS 1+2 FAULT" or CIDS Maintenance status 'CIDS 1' or 'CIDS 2' could be spuriously triggered.            In such event, the flight crew should verify that the CIDS is functioning normally by checking the PA, Cabin Interphone and Cabin lighting function. If the ECAM caution is spurious, it can be removed by resetting the CIDS when the aircraft is powered by the APU.</p>				
	PRO-ABN- ABN-RESET	<b>System Reset Table - WHEEL</b>	00021059.0001001	20 MAR 17
<p>Criteria: SA  <b>Applicable to: ALL</b>            Impacted DU: 00021058 System Reset Table - WHEEL  <u>Reason for issue:</u>            The BSCU reset procedure for WHEEL N/W STRG FAULT is amended with a temporary procedure, in order to better address the spurious alerts that are currently encountered in-service.</p> <ul style="list-style-type: none"> <li>- Under the very specific conditions defined in the procedure, the flight crews can continue the flight without troubleshooting after a successful BSCU reset.</li> <li>- For aircraft with BSCU standard 10: The root cause of the spurious alerts that were triggered during taxiing with BSCU standard 10 has been cancelled. Therefore, the associated reset procedure has been removed.</li> </ul>				
	PRO-ABN-NAV	<b>NAV TCAS FAULT</b>	NG01075	
	PRO-ABN-NAV	<b>NAV TCAS FAULT</b>	00015480.0017001	14 FEB 14
<p>Criteria: 31-1373, 31-1414, P2590, P5669  <b>Applicable to: ALL</b>            Impacted DU: 00012434 NAV TCAS FAULT (If Installed)</p>				

Continued on the following page

**PROCEDURES**  
**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

*Continued from the previous page*

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	<p><u>Reason for issue:</u> Following the introduction of a TCAS monitoring function in the Flight Warning Computer (FWC ) F6 and F7, an issue has been detected on aircraft equipped with HONEYWELL TCAS computers. To operate, the TCAS needs to receive the ADR barometric altitude through the active transponder and the aircraft heading through IR1.</p> <p>As a consequence, on ground, an undue <b>NAV TCAS FAULT</b> alert is triggered when:</p> <ul style="list-style-type: none"> <li>- The ADIRUs are set to OFF or,</li> <li>- IR 1 is not aligned: at aircraft power up before IR 1 alignment or during transit when performing a fast or a complete alignment of IR1.</li> </ul> <p>As soon as the ADIRU s are powered and the IR 1 is aligned, the <b>NAV TCAS FAULT</b> automatically disappears. Therefore, on ground, if the alert is triggered while the ADIRU s are OFF, or while IR1 is not yet aligned, the flight crew can disregard the alert. The FWC F8 corrects the issue.</p>			

PRO-NOR-SOP-10	Taxi		NG00715	
PRO-NOR-SOP-10	Radar		00015299.0002001	03 AUG 17
<p>Criteria: P7929, P9902 <b>Applicable to: ALL</b> Impacted DU: 00015298 Taxi - Radar</p>				
<p><u>Reason for issue:</u> When in the AUTO position, the MultiScan AUTO mode adjusts the tilt according to the altitude of the aircraft. In cruise, MULTISCAN function provides a large view of the weather ahead, ie display of weather cells located on and below aircraft path. At low altitudes (below FL 200), the tilt is adjusted upward to manage clutter from strong ground targets. In some cases, the weather may be low-lying and therefore may be below the radar beam and not be displayed until the aircraft descends closer to the precipitation level. Therefore, this Temporary Revision is issued to indicate that, when the Multiscan is in the AUTO position, the GAIN should be manually set to +4 when the aircraft is below FL 200.</p> <p>In addition, the flight crew should temporarily set the MULTISCAN sw to MAN, if:</p> <ul style="list-style-type: none"> <li>- If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes</li> <li>- The weather display is ambiguous or unexpected, in order to better analyze the weather situation using manual tilt according to standard technique</li> <li>- In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.</li> </ul> <p>In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.</p>				

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	PRO-NOR-SOP-14	<b>Climb</b>	NG00723	
	PRO-NOR-SOP-14	<b>Climb - Initial Climb</b>	00013057.0006001	29 JUN 16
	<p>Criteria: P3379, P7425, P9207, SA</p> <p><b>Applicable to: ALL</b></p> <p><i>Impacted DU: 00010245 Climb - Initial Climb</i></p> <p><u>Reason for issue:</u></p> <p><u>Issue 2:</u></p> <p><i>The temporary information is reissued to provide more information concerning BPS issue in line with EASA SIB 2016-05.</i></p> <p><u>Issue 1:</u></p> <p><i>The temporary revision is issued to advise operators that above the transition level, when the flight crew selects "STD" on the FCU, the last QNH or QFE barometric pressure setting is transmitted to the ground, instead of the standard pressure value (1 013 hPa).</i></p> <p><i>Only the FCU selected altitude, if used by the ATC on ground, may be misinterpreted. The real aircraft altitude transmitted to the ground is not affected, because the standard barometric altitude is transmitted, regardless of the barometric setting selected on the FCU.</i></p> <p><i>In addition, the "STD" value is correctly transmitted to other aircraft systems.</i></p>			
	PRO-NOR-SOP-14	<b>Climb - Radar</b>	00013047.0003001	03 MAR 14
	<p>Criteria: P7929, P9902, SA</p> <p><b>Applicable to: ALL</b></p> <p><i>Impacted DU: 00010259 Climb - Radar</i></p> <p><u>Reason for issue:</u></p> <p><i>When in the AUTO position, the MultiScan AUTO mode adjusts the tilt according to the altitude of the aircraft. In cruise, MULTISCAN function provides a large view of the weather ahead, ie display of weather cells located on and below aircraft path.</i></p> <p><i>At low altitudes (below FL 200), the tilt is adjusted upward to manage clutter from strong ground targets. In some cases, the weather may be low-lying and therefore may be below the radar beam and not be displayed until the aircraft descends closer to the precipitation level.</i></p> <p><i>Therefore, this Temporary Revision is issued to indicate that, when the Multiscan is in the AUTO position, the GAIN should be manually set to +4 when the aircraft is below FL 200.</i></p> <p><i>In addition, the flight crew should temporarily set the MULTISCAN sw to MAN, if:</i></p> <ul style="list-style-type: none"> <li>- <i>If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes</i></li> <li>- <i>The weather display is ambiguous or unexpected, in order to better analyze the weather situation using manual tilt according to standard technique</i></li> <li>- <i>In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.</i></li> </ul> <p><i>In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.</i></p>			

*Continued on the following page*

**PROCEDURES**  
**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

*Continued from the previous page*

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	PRO-NOR-SOP-15	<b>Cruise</b>	NG00734	
	PRO-NOR-SOP-15	<b>Cruise - Radar Tilt</b>	00013068.0006001	20 SEP 16
	<p>Criteria: P7929, P9902, SA</p> <p><b>Applicable to: ALL</b></p> <p>Impacted DU: 00010291 Cruise - Radar Tilt</p> <p><u>Reason for issue:</u></p> <p>When in the AUTO position, the MultiScan AUTO mode adjusts the tilt according to the altitude of the aircraft. In cruise, MULTISCAN function provides a large view of the weather ahead, ie display of weather cells located on and below aircraft path.</p> <p>At low altitudes (below FL 200), the tilt is adjusted upward to manage clutter from strong ground targets. In some cases, the weather may be low-lying and therefore may be below the radar beam and not be displayed until the aircraft descends closer to the precipitation level.</p> <p>Therefore, this Temporary Revision is issued to indicate that, when the Multiscan is in the AUTO position, the GAIN should be manually set to +4 when the aircraft is below FL 200.</p> <p>In addition, the flight crew should temporarily set the MULTISCAN sw to MAN, if:</p> <ul style="list-style-type: none"> <li>- The weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes</li> <li>- The weather display is ambiguous or unexpected, in order to better analyze the weather situation using manual tilt according to standard technique</li> <li>- In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.</li> </ul> <p>In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.</p>			

	PRO-NOR-SOP-16	<b>Descent Preparation</b>	NG00916	
	PRO-NOR-SOP-16	<b>Descent PREPARATION - Radar</b>	00013353.0003001	03 MAR 14
	<p>Criteria: P7929, P9902, SA</p> <p><b>Applicable to: ALL</b></p> <p>Impacted DU: 00011545 Descent Preparation - Radar</p>			

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	<p><u>Reason for issue:</u></p> <p><i>When in the AUTO position, the MultiScan AUTO mode adjusts the tilt according to the altitude of the aircraft. In cruise, MULTISCAN function provides a large view of the weather ahead, ie display of weather cells located on and below aircraft path.</i></p> <p><i>At low altitudes (below FL 200), the tilt is adjusted upward to manage clutter from strong ground targets. In some cases, the weather may be low-lying and therefore may be below the radar beam and not be displayed until the aircraft descends closer to the precipitation level.</i></p> <p><i>Therefore, this Temporary Revision is issued to indicate that, when the Multiscan is in the AUTO position, the GAIN should be manually set to +4 when the aircraft is below FL 200.</i></p> <p><i>In addition, the flight crew should temporarily set the MULTISCAN sw to MAN, if:</i></p> <ul style="list-style-type: none"> <li>- <i>If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes</i></li> <li>- <i>The weather display is ambiguous or unexpected, in order to better analyze the weather situation using manual tilt according to standard technique</i></li> <li>- <i>In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.</i></li> </ul> <p><i>In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.</i></p>			

PRO-NOR-SOP-18-B	<b>Initial Approach</b>		NG01260	
PRO-NOR-SOP-18-B	<b>Initial Approach - Radar</b>		00014648.0003001	03 MAR 14
<p>Criteria: P7929, P9902, SA</p> <p><b>Applicable to: ALL</b></p> <p><i>Impacted DU: 00014647 Initial Approach - Radar</i></p>				

*Continued on the following page*

*Continued from the previous page*

M <sup>(1)</sup>	Localization	DU Title	DU identification	DU date
	<p><u>Reason for issue:</u></p> <p><i>When in the AUTO position, the MultiScan AUTO mode adjusts the tilt according to the altitude of the aircraft. In cruise, MULTISCAN function provides a large view of the weather ahead, ie display of weather cells located on and below aircraft path.</i></p> <p><i>At low altitudes (below FL 200), the tilt is adjusted upward to manage clutter from strong ground targets. In some cases, the weather may be low-lying and therefore may be below the radar beam and not be displayed until the aircraft descends closer to the precipitation level.</i></p> <p><i>Therefore, this Temporary Revision is issued to indicate that, when the Multiscan is in the AUTO position, the GAIN should be manually set to +4 when the aircraft is below FL 200.</i></p> <p><i>In addition, the flight crew should temporarily set the MULTISCAN sw to MAN, if:</i></p> <ul style="list-style-type: none"> <li>- <i>If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes</i></li> <li>- <i>The weather display is ambiguous or unexpected, in order to better analyze the weather situation using manual tilt according to standard technique</i></li> <li>- <i>In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.</i></li> </ul> <p><i>In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.</i></p>			

(1) Evolution code : N=New, R=Revised, E=Effectivity



# **PROCEDURES**

## ABNORMAL AND EMERGENCY PROCEDURES

Intentionally left blank

**PRO-ABN-ABN-00 INTRODUCTION**

Content.....	A
Procedure Layout.....	B
Abnormal and Emergency Callouts.....	C

**PRO-ABN-ABN-ADV [ADV] ECAM ADVISORY**

ECAM Advisory Conditions.....	A
-------------------------------	---

**PRO-ABN-ABN-MEM [MEM] MEMORY ITEMS**

[MEM] Memory Items.....	A
-------------------------	---

**PRO-ABN-ABN-QRH [QRH] PROCEDURES**

[QRH] Procedures.....	A
-----------------------	---

**PRO-ABN-ABN-RESET [RESET] SYSTEM RESET**

System Reset - General.....	A
System Reset Table.....	B


**PRO-ABN-A-ICE A-ICE**

[QRH] DOUBLE AOA HEAT FAILURE.....	A
<u>ANTI ICE</u> ALL PITOT.....	B
<u>ANTI ICE</u> CAPT(F/O) TAT.....	C
<u>ANTI ICE</u> CAPT + F/O PITOT.....	D
<u>ANTI ICE</u> CAPT + STBY PITOT.....	E
<u>ANTI ICE</u> CAPT PITOT or L(R) STAT or AOA.....	F
<u>ANTI ICE</u> CAPT PROBES.....	G
<u>ANTI ICE</u> ENG 1(2) VALVE CLSD.....	H
<u>ANTI ICE</u> ENG 1(2) VALVE OPEN.....	I
<u>ANTI ICE</u> F/O + STBY PITOT.....	J
<u>ANTI ICE</u> F/O PITOT or L( R) STAT or AOA.....	K
<u>ANTI ICE</u> F/O PROBES.....	L
<u>ANTI ICE</u> L + R WINDSHIELD.....	M
<u>ANTI ICE</u> L(R) WINDOW.....	N
<u>ANTI ICE</u> L(R) WINDSHIELD.....	O
<u>ANTI ICE</u> STBY PITOT or L(R) STAT or AOA.....	P
<u>ANTI ICE</u> STBY PROBES.....	Q

*Continued on the following page*

*Continued from the previous page*



**PRO-ABN-AIR AIR**

[QRH] Engine 1+2 Bleed Fault.....A  
AIR APU BLEED FAULT.....B  
AIR APU BLEED LEAK.....C  
AIR BLEED 1(2) OFF.....D  
AIR COND CTL 1(2) - A(B) FAULT.....E  
AIR ENG 1(2) BLEED ABNORM PR.....F  
AIR ENG 1(2) BLEED FAULT.....G  
AIR ENG 1(2) BLEED LO TEMP (OPPOSITE BLEED AVAILABLE).....H  
AIR ENG 1(2) BLEED LO TEMP (OPPOSITE BLEED NOT AVAILABLE).....I  
AIR ENG 1+2 BLEED LO TEMP.....J  
AIR ENG 1(2) BLEED HI TEMP.....K  
AIR ENG 1(2) BLEED NOT CLSD.....L  
AIR ENG 1(2) HP VALVE FAULT.....M  
AIR ENG 1(2) LEAK DET FAULT.....N  
AIR FWD(AFT) CRG VENT FAULT  .....O  
AIR L(R) WING or ENG 1(2) BLEED LEAK.....P  
AIR L(R) WNG LEAK DET FAULT.....Q  
AIR PACK 1(2) FAULT.....R  
AIR PACK 1+2 FAULT.....S  
AIR PACK 1(2) OFF.....T  
AIR PACK 1(2) OVHT.....U  
AIR PACK 1(2) REGUL FAULT.....V  
AIR X BLEED FAULT.....W

**PRO-ABN-APU APU**

APU AUTO (EMER) SHUT DOWN.....A  
APU FIRE DET FAULT.....B  
APU FIRE LOOP A(B) FAULT.....C

**PRO-ABN-APUF APU FIRE**

 APU FIRE  .....A

*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-AUTO\_FLT AUTO FLT**

AUTO FLT A/THR LIMITED..... A  
AUTO FLT A/THR OFF..... B  
 ■ AUTO FLT AP OFF ■..... C  
AUTO FLT FAC 1(2) FAULT..... D  
AUTO FLT FAC 1 + 2 FAULT..... E  
AUTO FLT FCU 1(2) FAULT..... F  
AUTO FLT FCU 1 + 2 FAULT..... G  
AUTO FLT REAC W/S DET FAULT..... H  
AUTO FLT RUD TRIM 1(2) FAULT..... I  
AUTO FLT RUD TRIM SYS..... J  
AUTO FLT RUD TRV LIM 1(2)..... K  
AUTO FLT RUD TRV LIM SYS..... L  
AUTO FLT YAW DAMPER 1(2)..... M  
AUTO FLT YAW DAMPER SYS..... N

**PRO-ABN-AVNCS AVIONICS SMOKE**

AVIONICS SMOKE ..... A

**PRO-ABN-BLEED BLEED**


BLEED MONITORING FAULT..... A  
BLEED MONIT SYS 1(2) FAULT..... B

**PRO-ABN-BRAKES BRAKES**

■ [MEM] LOSS OF BRAKING ■..... A  
 [QRH] ASYMMETRIC BRAKING..... B  
 [QRH] RESIDUAL BRAKING..... C  
BRAKES A/SKID N/WS FAULT or ANTI SKID N/WS OFF..... D  
BRAKES ALTN BRK FAULT..... E  
BRAKES ALTN L(R) RELEASED..... F  
BRAKES AUTO BRK FAULT..... G  
BRAKES BRK Y ACCU LO PR..... H  
BRAKES HOT..... I  
BRAKES NORM + ALTN FAULT..... J

*Continued on the following page*





*Continued from the previous page*

<u>BRAKES</u> NORM BRK FAULT.....	K
<u>BRAKES</u> PARK BRK FAULT  .....	L
<u>BRAKES</u> PARK BRK LO PR.....	M
<u>BRAKES</u> PARK BRK ON.....	N
<u>BRAKES</u> RELEASED.....	O
<u>BRAKES</u> SYS 1(2) FAULT.....	P

**PRO-ABN-NWS BRAKES-NWS**

<u>BRAKES-NWS</u> MINOR FAULT.....	A
------------------------------------	---








**PRO-ABN-CAB\_PR CAB PR**

[QRH] CABIN OVERPRESSURE.....	A
 CAB PR EXCESS CAB ALT  .....	B
 CAB PR EXCES RESIDUAL PR  .....	C
CAB PR LDG ELEV FAULT.....	D
CAB PR LO DIFF PR.....	E
CAB PR OFV NOT OPEN .....	F
CAB PR SAFETY VALVE OPEN.....	G
CAB PR SYS 1(2) FAULT.....	H
CAB PR SYS 1+2 FAULT.....	I

**PRO-ABN-C\_B C/B**

<u>C/B</u> TRIPPED.....	A
-------------------------	---




**PRO-ABN-COM COM**

<u>COM</u> ACARS FAULT  .....	A
<u>COM</u> CIDS 1 + 2 FAULT.....	B
<u>COM</u> HF 1(2) DATA FAULT  .....	C
<u>COM</u> SATCOM DATA FAULT  .....	D
<u>COM</u> SATCOM FAULT  .....	E
<u>COM</u> SINGLE PTT STUCK  .....	F
<u>COM</u> VHF 1(2)(3) /HF 1(2) EMITTING  .....	G
<u>COM</u> VHF 3 DATA FAULT  .....	H













*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-COND COND**

<u>COND</u> FWD CAB/AFT CAB/CKPT DUCT OVHT.....	A
<u>COND</u> FWD(AFT) CARGO DUCT OVHT  .....	B
<u>COND</u> FWD(AFT) CRG HEAT FAULT  .....	C
<u>COND</u> FWD(AFT) CRG ISOL VALVE  .....	D
<u>COND</u> HOT AIR FAULT.....	E
<u>COND</u> L+R CAB FAN FAULT.....	F
<u>COND</u> LAV + GALLEY FAN FAULT.....	G
<u>COND</u> TRIM AIR SYS FAULT.....	H

**PRO-ABN-CONFIG CONFIG**

 <u>CONFIG</u> L(R) SIDESTICK FAULT (BY TAKE OVER)  .....	A
 <u>CONFIG</u> PARK BRK ON  .....	B
 <u>CONFIG</u> PITCH TRIM NOT IN T.O RANGE  .....	C
 <u>CONFIG</u> RUD TRIM NOT IN T.O RANGE  .....	D
 <u>CONFIG</u> SLATS (FLAPS) NOT IN T.O CONFIG  .....	E
 <u>CONFIG</u> SPD BRK NOT RETRACTED  .....	F

**PRO-ABN-DATALINK DATALINK**

<u>DATALINK</u> ATSU FAULT.....	A
<u>DATALINK</u> COMPANY FAULT.....	B

**PRO-ABN-DOOR DOOR**

[QRH] COCKPIT DOOR FAULT.....	A
<u>DOOR</u> L(R)(FWD)(AFT) AVIONICS (IN FLIGHT).....	B
<u>DOOR</u> L(R)(FWD)(AFT) AVIONICS (ON GROUND).....	C
<u>DOOR</u> L(R) FWD(AFT) CABIN (IN FLIGHT).....	D
<u>DOOR</u> L(R) FWD(AFT) CABIN (ON GROUND).....	E
<u>DOOR</u> L(R) FWD(AFT) EMER EXIT (IN FLIGHT).....	F
<u>DOOR</u> L(R) FWD(AFT) EMER EXIT (ON GROUND).....	G
<u>DOOR</u> FWD(AFT)(BULK) CARGO (IN FLIGHT).....	H
<u>DOOR</u> FWD(AFT)(BULK) CARGO (ON GROUND).....	I

**PRO-ABN-EIS EIS**

[QRH] Display Unit Failure.....	A
<u>EIS</u> DMC 1(2)(3) FAULT.....	B
<u>EIS</u> DMC/FWC COM FAULT.....	C

*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-ELEC ELEC**

[QRH] C/B Tripped..... A  
 [QRH] ELEC EMER CONFIG SYS REMAINING..... B  
 ELEC AC BUS 1 FAULT..... C  
 ELEC AC BUS 2 FAULT..... D  
 ELEC AC ESS BUS ALTN..... E  
 ELEC AC ESS BUS FAULT..... F  
 ELEC AC ESS BUS SHED..... G  
 ELEC APU GEN FAULT..... H  
 ELEC BAT 1(2) FAULT..... I  
 ELEC BAT 1(2) OFF..... J  
 ELEC BCL 1(2) FAULT..... K  
 ELEC DC BAT BUS FAULT..... L  
 ELEC DC BUS 1 FAULT..... M  
 ELEC DC BUS 2 FAULT..... N  
 ELEC DC BUS 1+2 FAULT..... O  
 ELEC DC EMER CONFIG..... P  
 ELEC DC ESS BUS FAULT..... Q  
 ELEC DC ESS BUS SHED..... R  
 ■■■ ELEC EMER CONFIG ■■■..... S  
 ELEC EMER GEN 1 LINE OFF..... T  
 ■■■ ELEC ESS BUSES ON BAT ■■■..... U  
 ELEC GEN 1(2) or APU GEN OVERLOAD..... V  
 ELEC GEN 1(2) FAULT..... W  
 ELEC GEN 1(2) OFF..... X  
 ELEC IDG 1(2) DISCONNECTED..... Y  
 ELEC IDG 1(2) OIL LO PR/OVHT..... Z  
 ELEC STATIC INV FAULT..... AA  
 ELEC TR 1(2) FAULT..... AB

**PRO-ABN-ENG ENG**

■■■ [QRH] ENG DUAL FAILURE - FUEL REMAINING ■■■..... A  
 ■■■ [QRH] ENG DUAL FAILURE - NO FUEL REMAINING ■■■..... B  
 [QRH] ENG RELIGHT IN FLIGHT..... C  
 [QRH] ENGINE TAILPIPE FIRE..... D  
 [QRH] HIGH ENGINE VIBRATION..... E  
 [QRH] On Ground - Non ENG Shutdown after ENG Master OFF..... F

*Continued on the following page*



*Continued from the previous page*

[QRH] One Engine Inoperative - Circling Approach.....	G
[QRH] One Engine Inoperative - Straight-In Approach.....	H
ENG 1(2) BLEED STATUS FAULT (IN FLIGHT).....	I
ENG 1(2) BLEED STATUS FAULT (ON GROUND).....	J
ENG COMPRESSOR VANE.....	K
ENG 1(2) COMPRESSOR VANE.....	L
ENG 1(2) CTL VALVE FAULT.....	M
ENG DUAL FAILURE.....	N
ENG 1(2) EIU FAULT.....	O
ENG 1(2) FADEC A(B) FAULT.....	P
ENG 1(2) FADEC ALTERNATOR.....	Q
ENG 1(2) FADEC FAULT.....	R
ENG 1(2) FADEC HI TEMP.....	S
ENG 1(2) FAIL.....	T
ENG 1(2) FIRE (IN FLIGHT).....	U
ENG 1(2) FIRE (ON GROUND).....	V
ENG 1(2) FIRE DET FAULT.....	W
ENG 1(2) FIRE LOOP A(B) FAULT.....	X
ENG 1(2) FUEL CTL FAULT.....	Y
ENG 1(2) FUEL FILTER CLOG.....	Z
ENG 1(2) FUEL RETURN VALVE.....	AA
ENG 1(2) HP FUEL VALVE.....	AB
ENG 1(2) IGN FAULT (IGN A or B Fault).....	AC
ENG 1(2) IGN FAULT (IGN A+B FAULT).....	AD
ENG 1(2) LOW N1 (On Ground).....	AE
ENG 1(2) N1 or N2 or EGT or FF DISCREPANCY.....	AF
ENG 1(2) N1/N2/EGT OVER LIMIT.....	AG
ENG 1(2) OIL FILTER CLOG.....	AH
ENG 1(2) OIL HI TEMP.....	AI
ENG 1(2) OIL LO PR.....	AJ
ENG 1(2) ONE TLA FAULT.....	AK
ENG 1(2) OVSPD PROT FAULT.....	AL
ENG 1(2) PROBES FAULT.....	AM
ENG 1(2) REV ISOL FAULT.....	AN
ENG 1(2) REV PRESSURIZED.....	AO
ENG REV SET.....	AP
ENG 1(2) REV SWITCH FAULT.....	AQ

*Continued on the following page*

*Continued from the previous page*

ENG 1(2) REVERSE UNLOCKED.....	AR
ENG 1(2) REVERSER FAULT.....	AS
ENG 1(2) SENSOR FAULT.....	AT
ENG 1(2) SHUT DOWN.....	AU
ENG 1(2) STALL.....	AV
ENG 1(2) START FAULT.....	AW
ENG 1(2) START VALVE FAULT.....	AX
ENG 1(2) THR LEVER ABV IDLE.....	AY
ENG 1(2) THR LEVER DISAGREE.....	AZ
ENG 1(2) THR LEVER FAULT.....	BA
ENG THR LEVERS NOT SET.....	BB
ENG THRUST LOCKED.....	BC
ENG TYPE DISAGREE.....	BD
ENG VIB SYS FAULT.....	BE

**PRO-ABN-F CTL F/CTL**



[QRH] Landing with Slats or Flaps Jammed.....	A
[QRH] RUDDER JAM.....	B
[QRH] STABILIZER JAM.....	C
ACTIVE CONTROL LAW.....	D
ELEVATORS AND STABILIZER CONTROL AFTER FAILURE.....	E
F/CTL AIL SERVO FAULT.....	F
F/CTL ALTN LAW.....	G
F/CTL DIRECT LAW.....	H
F/CTL ELAC 1(2) FAULT (ONE COMPUTER FAILED).....	I
F/CTL ELAC 1(2) FAULT (BOTH COMPUTERS FAILED).....	J
F/CTL ELAC 1(2) PITCH FAULT.....	K
F/CTL ELEV SERVO FAULT.....	L
F/CTL FCDC 1(2) FAULT.....	M
F/CTL FCDC 1+2 FAULT.....	N
F/CTL FLAP ATTACH SENSOR.....	O
F/CTL FLAPS FAULT/LOCKED.....	P
F/CTL FLAP LVR NOT ZERO.....	Q
F/CTL FLAP SYS 1(2) FAULT.....	R
F/CTL FLAPS/SLATS FAULT/LOCKED.....	S
F/CTL GND SPLR 5 FAULT.....	T
F/CTL GND SPLR / 1+2 / 3+4 / FAULT.....	U
F/CTL GND SPLR NOT ARMED.....	V

*Continued on the following page*

*Continued from the previous page*

F/CTL L(R) AIL FAULT.....	W
F/CTL L(R) ELEV FAULT.....	X
■ F/CTL L+R ELEV FAULT ■.....	Y
F/CTL L(R) SIDESTICK FAULT.....	Z
F/CTL PITCH TRIM/MCDU/CG DISAGREE.....	AA
F/CTL SEC 1(2)(3) FAULT.....	AB
F/CTL SIDESTICK PRIORITY.....	AC
F/CTL SLAT(FLAP) TIP BRK FAULT.....	AD
F/CTL SLATS AND FLAPS FAULT IN CONF 0.....	AE
F/CTL SLATS FAULT/LOCKED.....	AF
F/CTL SLAT SYS 1(2) FAULT.....	AG
F/CTL SPD BRK 2 (3+4) FAULT.....	AH
F/CTL SPD BRK DISAGREE (SURFACES 3+4 AFFECTED).....	AI
F/CTL SPD BRK DISAGREE (SURFACES 2+3+4 AFFECTED).....	AJ
F/CTL SPD BRK FAULT.....	AK
F/CTL SPD BRK STILL OUT.....	AL
F/CTL SPLR FAULT.....	AM
F/CTL STABILIZER JAM.....	AN

**PRO-ABN-FUEL FUEL**

[QRH] FUEL IMBALANCE.....	A
[QRH] FUEL LEAK.....	B
[QRH] GRAVITY FUEL FEEDING.....	C
FUEL ACT XFR FAULT  .....	D
FUEL ACT PUMP LO PR  .....	E
FUEL APU LP VALVE FAULT.....	F
FUEL AUTO FEED FAULT.....	G
FUEL CTR TK PUMP 1(2) LO PR.....	H
FUEL CTR TK PUMPS LO PR.....	I
FUEL CTR TK PUMPS OFF.....	J
FUEL ENG 1(2) LP VALVE OPEN.....	K
FUEL FQI CH 1(2) FAULT.....	L
FUEL FUEL INERTING SYS FAULT.....	M
FUEL L (R) OUTER (INNER) TK HI TEMP.....	N
FUEL L (R) OUTER (INNER) TK LO TEMP.....	O
FUEL L (R) OUTER XFR CLOSED.....	P
FUEL L (R) OUTER XFR OPEN.....	Q

*Continued on the following page*

*Continued from the previous page*

FUEL L (R) TK PUMP 1(2) LO PR.....	R
FUEL L (R) TK PUMP 1 + 2 LO PR (CENTER TANK EMPTY).....	S
FUEL L (R) TK PUMP 1 + 2 LO PR (CENTER TANK NOT EMPTY).....	T
FUEL L (R) WING TK LO LVL.....	U
FUEL L + R WING TK LO LVL.....	V
FUEL X FEED VALVE FAULT.....	W

**PRO-ABN-FWS FWS**

FWS FWC 1 + 2 FAULT.....	A
FWS FWC 1(2) FAULT.....	B
FWS OEB/FWC DISCREPANCY.....	C
FWS SDAC 1 + 2 FAULT.....	D
FWS SDAC 1(2) FAULT.....	E

**PRO-ABN-HYD HYD**

HYD B ELEC PUMP LO PR or OVHT.....	A
HYD B RSVR LO AIR PR.....	B
HYD B RSVR LO LVL.....	C
HYD B RSVR OVHT.....	D
HYD G ENG 1 PUMP LO PR (PTU OPERATIVE).....	E
HYD G ENG 1 PUMP LO PR (PTU INOPERATIVE).....	F
HYD G RSVR LO AIR PR.....	G
HYD G RSVR LO LVL.....	H
HYD G RSVR OVHT.....	I
HYD Y ELEC PUMP LO PR or OVHT.....	J
HYD Y ENG 2 PUMP LO PR (PTU OPERATIVE).....	K
HYD Y ENG 2 PUMP LO PR (PTU INOPERATIVE).....	L
HYD Y RSVR LO AIR PR.....	M
HYD Y RSVR LO LVL.....	N
HYD Y RSVR OVHT.....	O
■ HYD B+Y SYS LO PR ■.....	P
■ HYD G+B SYS LO PR ■.....	Q
■ HYD G+Y SYS LO PR ■.....	R
HYD PTU FAULT.....	S
HYD RAT FAULT.....	T

*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-LG L/G**

[QRH] Landing with Abnormal L/G.....	A
[QRH] L/G GRAVITY EXTENSION.....	B
L/G DOORS NOT CLOSED.....	C
■ L/G GEAR NOT DOWN ■.....	D
■ L/G GEAR NOT DOWNLOCKED ■.....	E
L/G GEAR NOT UNLOCKED.....	F
L/G GEAR UNLOCK FAULT.....	G
L/G LGCIU 1(2) FAULT.....	H
L/G LGCIU 1+2 FAULT.....	I
L/G SHOCK ABSORBER FAULT (SHOCK ABSORBER EXTENDED ON GROUND).....	J
L/G SHOCK ABSORBER FAULT (SHOCK ABSORBER NOT EXTENDED AFTER LIFTOFF).....	K
L/G SYS DISAGREE.....	L

**PRO-ABN-MISC MISC**

■ [MEM] EMER DESCENT ■.....	A
■ [MEM] Stall Recovery ■.....	B
■ [MEM] Stall Warning At Lift-Off ■.....	C
[QRH] BOMB ON BOARD.....	D
[QRH] COCKPIT WINDSHIELD / WINDOW ARCING.....	E
[QRH] COCKPIT WINDSHIELD / WINDOW CRACKED.....	F
■ [QRH] DITCHING ■.....	G
■ [QRH] EMER EVAC ■.....	H
■ [QRH] EMER LANDING ALL ENG FAILURE ■.....	I
■ [QRH] FORCED LANDING ■.....	J
[QRH] OVERWEIGHT LANDING.....	K
[QRH] Severe Turbulence.....	L
[QRH] TAILSTRIKE.....	M
[QRH] VOLCANIC ASH ENCOUNTER.....	N

**PRO-ABN-NAV NAV**

[MEM] Unreliable Speed Indication.....	A
[QRH] ADR CHECK PROC.....	B
■ [QRH] ALL ADR OFF ■.....	C
[QRH] IR Alignment in ATT Mode.....	D
NAV ADR 1(2)(3) FAULT.....	E
NAV ADR 1+2(1+3)(2+3) FAULT.....	F
■ NAV ADR 1+2+3 FAULT ■.....	G







*Continued on the following page*

**PROCEDURES**



**ABNORMAL AND EMERGENCY PROCEDURES**

PRELIMINARY PAGES - TABLE OF CONTENTS

*Continued from the previous page*

NAV ADR DISAGREE.....	H
NAV ALTI DISCREPANCY.....	I
NAV CAPT(F/O)(STBY) AOA FAULT.....	J
NAV ATC/XPDR 1(2) FAULT.....	K
NAV ATC/XPDR 1+2 FAULT.....	L
NAV ATC/XPDR STBY.....	M
NAV ATT DISCREPANCY.....	N
NAV BARO REF DISCREPANCY.....	O
NAV FM/GPS POS DISAGREE  .....	P
NAV GPS 1(2) FAULT  .....	Q
NAV GPWS FAULT.....	R
NAV GPWS TERR DET FAULT.....	S
NAV HDG DISCREPANCY.....	T
NAV IAS DISCREPANCY.....	U
NAV ILS 1(2)(1+2) FAULT.....	V
NAV IR 1(2)(3) FAULT.....	W
NAV IR 1+2(1+3)(2+3) FAULT.....	X
NAV IR DISAGREE.....	Y
NAV IR NOT ALIGNED.....	Z
NAV LS TUNING DISAGREE.....	AA
NAV PRED W/S DET FAULT  .....	AB
NAV RA 1 AND 2 FAULT (DUAL RA FAILURE).....	AC
NAV RA 1(2) FAULT.....	AD
NAV RA DEGRADED.....	AE
NAV TCAS FAULT  .....	AF
NAV TCAS STBY.....	AG
 Stall Warning  .....	AH

**PRO-ABN-OVERSPEED OVERSPEED**

 OVERSPEED  .....	A
---	---

**PRO-ABN-RECORDER RECORDER**

RECORDER DFDR FAULT.....	A
RECORDER SYS FAULT.....	B

*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-SMOKE SMOKE**

■ [QRH] SMOKE / FUMES / AVNCS SMOKE ■	.....	A
■ [QRH] REMOVAL OF SMOKE / FUMES ■	.....	B
[QRH] SMOKE / FIRE FROM LITHIUM BATTERY	.....	C
■ SMOKE AFT CARGO SMOKE <img alt="warning icon" data-bbox="460 245 480 265"/> ■	.....	D
SMOKE AFT CRG DET FAULT <img alt="warning icon" data-bbox="430 265 450 285"/>	.....	E
■ SMOKE FWD CARGO SMOKE <img alt="warning icon" data-bbox="460 285 480 305"/> ■	.....	F
SMOKE FWD(AFT) CRG BTL 1(2) FAULT <img alt="warning icon" data-bbox="490 305 510 325"/>	.....	G
SMOKE FWD CRG DET FAULT <img alt="warning icon" data-bbox="430 325 450 345"/>	.....	H
SMOKE DET FAULT	.....	I
SMOKE LAVATORY DET FAULT	.....	J
■ SMOKE LAVATORY SMOKE ■	.....	K

**PRO-ABN-SURV SURV**

[MEM] EGPWS Cautions	.....	A
■ [MEM] EGPWS Warnings ■	.....	B
■ [MEM] TCAS WARNINGS ■	.....	C
■ [MEM] WINDSHEAR ■	.....	D
■ [MEM] WINDSHEAR AHEAD ■	.....	E

**PRO-ABN-VENT VENT**

VENT AVNCS SYS FAULT	.....	A
VENT BLOWER FAULT	.....	B
VENT EXTRACT FAULT	.....	C
VENT SKIN VALVE FAULT	.....	D

**PRO-ABN-WHEEL WHEEL**

[QRH] WHEEL TIRE DAMAGE SUSPECTED	.....	A
WHEEL HYD SEL FAULT	.....	B
WHEEL N/W STRG FAULT	.....	C
WHEEL TYRE LO PR <img alt="warning icon" data-bbox="360 745 380 765"/>	.....	D

*Continued on the following page*

*Continued from the previous page*

**PRO-ABN-W\_A ICE WING A.ICE**

WING A.ICE L(R) HI PR..... A  
WING A.ICE L(R) VALVE OPEN (FAILURE DETECTED IN FLIGHT)..... B  
WING A.ICE L(R) VALVE OPEN (FAILURE DETECTED ON GROUND)..... C  
WING A.ICE OPEN ON GND..... D  
WING A.ICE SYS FAULT (ONE WING VALVE REMAINS CLOSED WHEN THE WING ANTI-ICE IS TURNED ON)E  
WING A.ICE SYS FAULT (THE WING ANTI-ICE IS TURNED ON AFTER ONE ENGINE SHUTDOWN OR AFTER THE LOSS OF ONE BLEED)..... F

**PRO-ABN-90 Detailed Cabin / Cockpit Evacuation Procedure**

General..... A  
Cockpit-Assigned Duties for Evacuation..... B  
Cabin Crew-Assigned Areas for Evacuation..... C  
Communications..... D  
On Ground Evacuation..... E  
Cockpit Evacuation through Window..... F  
Evacuation on Water..... G



**CONTENT**


Ident.: PRO-ABN-ABN-00-00020862.0001001 / 20 APR 17

Applicable to: ALL

Abnormal and Emergency procedures involve actions that the flight crew must perform to ensure the overall safety of the flight, and adequate workload.

- L2 For more information about the management of abnormal operations, *Refer to FCTM/AOP-30-10 Introduction.*

Abnormal and Emergency Procedure Overview



**L1 [ADV] ECAM ADVISORY**

The [ADV] ECAM ADVISORY section provides direct access to the list of all advisories that can be displayed on the ECAM SD pages. The [ADV] section is also available in the QRH.

- L2 For more information, *Refer to [ADV] ECAM Advisory.*
- L1 Advisories are system parameters that start to deviate from their usual operational range. However, an advisory does not require flight crew actions, except monitoring.
- L2 For more information about Advisory function, *Refer to DSC-31-20 System Pages.*

**L1 [MEM] MEMORY ITEMS**

The [MEM] MEMORY ITEMS menu provides direct access to the list of memory items.

- L2 For more information, *Refer to [MEM] Memory Items.*

- L1 The content of the memory items are described in the applicable sub-sections of the abnormal and emergency procedures.  
Memory items are procedures, or critical immediate actions of an ECAM /QRH /OEB procedure, that the flight crew must apply by memory to ensure a safe flight path. In some time-critical situations, the flight crew has no time to refer to the ECAM and/or to the QRH.
- L2 For more information, *Refer to FCTM/AOP-10-40 Abnormal and Emergency Procedures.*

### L1 **[QRH] PROCEDURES**

The [QRH ] PROCEDURES menu provides direct access to the list of all the FCOM abnormal and emergency procedures that are also in the QRH.

- L2 For more information, *Refer to [QRH] Procedures.*

- L1 The content of the QRH procedures are described in the applicable sub-sections of the abnormal and emergency procedures.

*Note: Only the FCOM version of a procedure provides layer 2 and 3 information for consultation purpose.*

### **[RESET] SYSTEM RESET**

The [RESET] SYSTEM RESET section provides direct access to the table listing all the system resets that are permitted, and the condition to apply them. The [RESET] section is also available in the QRH.

- L2 For direct access to the table, *Refer to [RESET] System Reset.*

### L1 **SUB-SECTIONS OF ABNORMAL AND EMERGENCY PROCEDURES**

This part of the FCOM describes the detailed content of all abnormal and emergency procedures. All procedures are grouped in sub-sections that can be system related (e.g. AIR, FUEL, etc.) or non-system related (e.g. MISC, T.O, CONFIG, etc.).

The sub-sections are sorted by alphabetic order.

For each sub-section, procedures are listed in the following order:

1. The memory items  
The title of the memory items starts with the [MEM] prefix
2. The abnormal and emergency procedures of the QRH  
The title of these procedures starts with the [QRH] prefix
3. The ECAM procedures.

**PROCEDURE LAYOUT**

Applicable to: ALL

Ident.: PRO-ABN-ABN-00-A-00020863.0001001 / 17 MAR 17

**GENERAL**


The presentation of procedures is, as far as practicable, identical to the way it is displayed on the ECAM. The abbreviations are identical to those used on the cockpit panels.

All actions and information displayed on ECAM are provided in large letters. Other information, not on ECAM, is provided in small letters.

Expanded information is as far as practicable provided in layer 2. This information:

- Identifies the particular failures
- Explains actions for which the reason is not self-evident
- Provides some background on the reasons and /or the effects of a given action.

FCOM presentation of ABN or EMER procedures



Ident.: PRO-ABN-ABN-00-A-00020864.0001001 / 17 MAR 17


### **PROCEDURE TITLE**

The title of an abnormal or emergency procedure, displayed on the ECAM, appears on white background.

Abnormal procedure displayed on ECAM (amber caution) :

**CAB PR SAFETY VALVE OPEN**

Emergency procedure displayed on ECAM (red warning) :



The title of an abnormal or emergency procedure, that does not appear on the ECAM is on a grey background.

Abnormal procedure not displayed on ECAM :



Emergency procedure not displayed on ECAM :



### SEVERAL ALERTS UNDER THE SAME TITLE

When applicable, several alerts may be grouped under the same procedure title. However, depending on the failure, the actions that the flight crew should perform may differ.

*Note:* Alerts that have the same procedure title may be differentiated by a subtitle (e.g. ENG FIRE (On Ground) versus ENG FIRE (In Flight)).

Ident.: PRO-ABN-ABN-00-A-00020865.0001001 / 17 MAR 17


### ANNUNCIATIONS

When applicable, the annunciations section provides:

- The triggering conditions, that describe the cause of the alert activation
- The flight phase inhibition.

### FLIGHT PHASE INHIBITION

The Flight Phase Inhibition section indicates the flight phases during which the alert is inhibited. In the below example, the alert is inhibited in flight phase 1, and 10.



**L2** For more information, Refer to DSC-31-15 Flight Phases.

Ident.: PRO-ABN-ABN-00-A-00020866.0001001 / 17 MAR 17

**PROCEDURES AND STATUS**

The Procedure and Status section provides the procedure and the Status (including approach procedure, limitations, inoperative systems, etc.), with additional information when relevant.

**CONDITIONS**

**BLACK SQUARE**

When several procedures appear under the same title, a black square marks the starting point of each procedure.

For example:

<b><u>ANTI ICE CAPT (F/O) (STBY) PROBES</u></b>	
<input type="checkbox"/> <u>CAPT PROBES</u>	} a procedure to be applied
<input type="checkbox"/> <u>F / O PROBES</u>	} b a or b or c
<input type="checkbox"/> <u>STBY PROBES</u>	} c

Black squares also indicate parts of a procedure among which only one is applicable.  
For example:

<b><u>BRAKES HOT</u></b>	
BRK FAN (if installed) . . . . . ON	} a procedure to be applied
<input type="checkbox"/> <u>ON GROUND</u>	} b (a+b) or (a+c)
<input type="checkbox"/> <u>IN FLIGHT</u>	} c

The ECAM does not display black squares.

**BLACK DOT**

If an action depends on a precondition, a black dot identifies the precondition. If the precondition appears on ECAM, it appears in LARGE LETTERS. If not, it appears in small letters.

For example:

<b>F / CTL FLAPS FAULT</b>	
FLAPS LEVER .....RECYCLE	"If unsuccessful" does not appear on ECAM
● If unsuccessful :	
GPWS FLAP MODE ..... OFF	

**INDENTATION**

Indentation is used in order to identify when an action depends on a precondition/flight phase/procedure.

For example:

<p>■ <b>IN FLIGHT</b></p> <ul style="list-style-type: none"> <li>● If Flaps locked</li> </ul> <p style="padding-left: 40px;">APPR SPEED .....VREF +30</p> <p style="padding-left: 40px;">MAX SPEED ..... 250 kt</p>
---

- The APPR SPEED is equal to VREF +30 kt only if the flaps are locked, because "APPR SPEED.....VREF +30" is indented below "● If flaps locked".
- The MAX SPEED of 250 kt does not depend on the flaps locked condition because it is aligned with "● If Flaps locked". Therefore, MAX SPEED has to be respected whether the flaps are locked or not.

**MEMORY ITEMS**

Memory items are items that the flight crew must memorize, in order to be able to rapidly apply them, without referring to the ECAM , and/or to the QRH.

Memory items are surrounded by a black box in the FCOM /QRH procedure , in order to enable the flight crew to easily identify them.

Memory items



**ABNORMAL AND EMERGENCY CALLOUTS**

Applicable to: ALL

Ident.: PRO-ABN-ABN-00-B-00011915.0001001 / 17 MAR 17

**ECAM PROCEDURES**

1. "ECAM ACTION" is commanded by PF when required.
2. "CLEAR \_\_ (title of the system) ?" is asked by the PM for confirmation by the PF, that all actions have been taken/reviewed on the present WARNING/CAUTION or SYSTEM PAGE. e.g.: CLEAR HYDRAULIC ?
3. "CLEAR \_\_ (title of the system)" is the command by the PF that the action and review is confirmed. For status page; REMOVE STATUS will be used.
4. "ECAM ACTIONS COMPLETE" is the announcement by the PM that all APPLICABLE ACTIONS have been completed.
5. Should the PF require an action from the PM during ECAM procedures, the order "STOP ECAM" will be used. When ready to resume the ECAM the order "CONTINUE ECAM" will be used.

Ident.: PRO-ABN-ABN-00-B-00020059.0001001 / 17 MAR 17


**EMERGENCY CALL**

Some abnormal/emergency procedures require flight and cabin crews to use specific phraseology when communicating with each other. To ensure effective communication between the flight and cabin crews, the standard phraseology may be recalled at the preflight phase.

FROM	TO	PHRASEOLOGY	REMARKS
cockpit	cabin	Passenger Address (PA) System: "PURSER TO COCKPIT, PLEASE!"	The Purser, or any other cabin crewmember, must go to the cockpit
Cockpit	Cabin	Passenger Address (PA) System: "ATTENTION CREW! AT STATIONS!"	An emergency evacuation may soon be required.
cockpit	cabin	Passenger Address (PA) System: "CABIN CREW and PASSENGERS REMAIN SEATED!"	The captain decides that an evacuation is not required

*Continued on the following page*



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>ABNORMAL AND EMERGENCY PROCEDURES</b>  INTRODUCTION
---	---

*Continued from the previous page*

cockpit	cabin	Passenger Address (PA) System: "PASSENGERS EVACUATE!"	The captain orders an immediate evacuation
cabin	cockpit	Interphone: "PRIO CAPT"	Any crew member can make such a call. The flight crew must reply.

Ident.: PRO-ABN-ABN-00-B-00011916.0001001 / 31 AUG 17

## **MEMORY ITEMS**

The aim of such callouts is to callout the appropriate procedure by calling out, in most cases, the title of the procedure. This will allow the crew to be aware of the situation and be prepared to properly react (crew coordination, task sharing and communication).

### **GPWS**

As soon as avoidance manoeuvre is envisaged.  
"PULL UP TOGA"

### **REACTIVE WINDSHEAR**

"WINDSHEAR TOGA"

### **UNRELIABLE SPEED INDICATION**

"UNRELIABLE SPEED"

### **TCAS**

#### **■ For aircraft equipped with AP/FD TCAS function :**

As soon as a Traffic Advisory (TA) is triggered:

- If the AP/FD TCAS mode is armed : "TCAS blue"
- If the AP/FD TCAS mode does not arm : "TCAS, I have control"

#### **■ For aircraft not equipped with AP/FD TCAS function :**

As soon as a Traffic Advisory (TA) is triggered: "TCAS, I have control".

### **EMERGENCY DESCENT**

"EMERGENCY DESCENT"

### **LOSS OF BRAKING**


"LOSS OF BRAKING"

### **STALL RECOVERY**

As soon as any stall indication is recognized.  
"STALL, I have control"

**STALL WARNING AT LIFT-OFF**

"STALL, TOGA 15<sup>o</sup>"

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>ABNORMAL AND EMERGENCY PROCEDURES</b> [ADV] ECAM ADVISORY
---	--

**ECAM ADVISORY CONDITIONS**

Applicable to: ALL

SYSTEM	CONDITIONS	RECOMMENDED ACTION
--------	------------	--------------------

Ident.: PRO-ABN-ABN-ADV-A-00012117.0003001 / 17 MAR 17

APU	EGT > EGT MAX -33 °C (inhibited during APU start)	
	OIL QTY (message LOW OIL LEVEL pulsing)	If there is no oil leak, then the remaining oil quantity allows normal APU operation for about 10 h.

Ident.: PRO-ABN-ABN-ADV-A-00012107.0004001 / 31 AUG 17

CAB PR	CAB VERTICAL SPEED V/S > 1 800 ft/min	CPC changeover is recommended: MODE SEL : MAN Wait 10 s then: MODE SEL: AUTO
	CAB ALTITUDE altitude ≥ 8 800 ft	PACK FLOW: HI MODE SEL : MAN Manual pressure control If the cargo freight permits, set FWD ISOL VALVE: OFF to reduce the rate of cabin altitude increase.
	ΔP ≥ 1.5 PSI in phase 7	LDG ELEV : ADJUST If unsuccessful: MODE SEL : MAN Manual pressure control

Ident.: PRO-ABN-ABN-ADV-A-00012112.0001001 / 17 MAR 17

ELEC	IDG OIL TEMP ≥ 147 °C	Reduce IDG load if possible (GALLEY or GEN OFF). If required, restore when temperature has dropped. Restrict use of generator to short time, if temperature rises again excessively.
------	-----------------------	--

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[ADV] ECAM ADVISORY

*Continued from the previous page*

SYSTEM	CONDITIONS	RECOMMENDED ACTION
--------	------------	--------------------

Ident.: PRO-ABN-ABN-ADV-A-00012122.0002001 / 02 MAY 17

ENG	OIL PRESS P < 16 PSI	<ul style="list-style-type: none"> <li>- If oil pressure is between 16 and 13 PSI (advisory), continue normal operation.</li> <li>- If oil pressure is below 13 PSI (red indication) without the ENG OIL LO PR ECAM warning, continue normal engine operation (it can be assumed that the oil pressure transducer is faulty).</li> </ul> <p>In both cases, monitor other engine parameters especially oil temperature and oil quantity.</p>
	OIL PRESS P > 90 PSI	<p>Monitor other engine parameters closely for symptoms of engine malfunction.</p> <p>If high oil pressure is not accompanied by other abnormal indications operate engine normally for remainder of flight.</p> <p>Record high oil pressure and corresponding N2 readings for maintenance action.</p>
	OIL TEMP T > 140 °C	<p>A rise in oil temperature during normal steady-state operation indicates a system malfunction and should be closely monitored for other symptoms of engine malfunction.</p> <p><i>Note: If the OIL TEMP rise follows thrust reduction, increasing thrust may reduce oil temperature.</i></p> <p>In addition, a rise in oil temperature could be related to the IDG oil cooling system. To reduce oil temperature rise before limits are reached, the following are recommended:</p> <ol style="list-style-type: none"> <li>1. <b>Low Speed</b> - Increase engine speed to increase fuel flow and thereby cool IDG oil.</li> <li>2. <b>High Speed</b> - Reduce generator load or turn off generator. If oil temperature continues to rise, mechanically disconnect IDG.</li> </ol>
	OIL QTY < 3 qt	<p>If oil quantity low at high power setting, expect level increase after power reduction.</p> <p>Monitor affected engine oil parameters and crosscheck with other engine - If pressure and temperature remain normal, continue normal operation.</p>
	NAC TEMP ≥ 240 °C	<p>Monitor engine parameters and crosscheck with other engine</p>
	VIBRATION N1 ≥ 6 units N2 ≥ 4.3 units	<p><i>Refer to PRO-ABN-ENG [QRH] HIGH ENGINE VIBRATION</i></p>

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[ADV] ECAM ADVISORY

*Continued from the previous page*

SYSTEM	CONDITIONS	RECOMMENDED ACTION
--------	------------	--------------------

Ident.: PRO-ABN-ABN-ADV-A-00012114.0001001 / 21 MAR 17

FUEL	Difference between wing fuel quantities greater than 1 500 kg (3 307 lb)	FUEL MANAGEMENT: CHECK If a fuel leak is suspected, Refer to PRO-ABN-FUEL [QRH] FUEL LEAK. For limitations, Refer to LIM-FUEL Maximum Allowed Fuel Imbalance
	Fuel temp greater than 45 °C in inner cell, or 55 °C in outer cell	GALLEY: OFF
	Fuel temp lower than -40 °C in inner or outer cell	Consider descending to a lower altitude and/or increasing Mach to increase TAT.

Ident.: PRO-ABN-ABN-ADV-A-00012119.0028001 / 17 MAR 17

OXY	CKPT OXY Pulsing green: When pressure is < 800 PSI. Amber: When pressure is < 400 PSI.	If mask is not being used, check if it is correctly stowed, Refer to DSC-35-20-10 Mask Stowage.
-----	--	---



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[ADV] ECAM ADVISORY

Intentionally left blank

**[MEM] MEMORY ITEMS**

Applicable to: ALL

Ident.: PRO-ABN-ABN-MEM-ABN-MEM-00020871.0001001 / 17 MAR 17

**BRAKES**

[MEM] **LOSS OF BRAKING** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-MEM-ABN-MEM-00020948.0001001 / 17 MAR 17

**MISC**

[MEM] **EMER DESCENT** (*Refer to procedure*)

[MEM] **STALL RECOVERY** (*Refer to procedure*)

[MEM] **STALL WARNING AT LIFT OFF** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-MEM-ABN-MEM-00020949.0001001 / 01 JUN 17

**NAV**

[MEM] **UNRELIABLE SPEED INDICATION** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-MEM-ABN-MEM-00020950.0002001 / 17 MAR 17

**SURV**

[MEM] **GPWS/EGPWS CAUTIONS** (*Refer to procedure*)

[MEM] **GPWS/EGPWS WARNINGS** (*Refer to procedure*)

[MEM] **TCAS WARNINGS** (*Refer to procedure*)

[MEM] **WINDSHEAR** (*Refer to procedure*)

[MEM] **WINDSHEAR AHEAD** (*Refer to procedure*)

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[MEM] MEMORY ITEMS

Intentionally left blank



**[QRH] PROCEDURES**

Applicable to: ALL

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021342.0002001 / 17 MAR 17

A-ICE

[QRH] **DOUBLE AOA HEAT FAILURE** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021355.0001001 / 17 MAR 17

AIR

[QRH] **ENGINE 1+2 BLEED FAULT** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021352.0002001 / 17 MAR 17

BRAKES

[QRH] **ASYMMETRIC BRAKING** (*Refer to procedure*)

[QRH] **RESIDUAL BRAKING** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021343.0001001 / 17 MAR 17

CAB PR

[QRH] **CABIN OVERPRESSURE** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021346.0001001 / 17 MAR 17

DOOR

[QRH] **COCKPIT DOOR FAULT** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021511.0001001 / 17 MAR 17

EIS

[QRH] **DISPLAY UNIT FAILURE** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021345.0002001 / 17 MAR 17

ELEC

[QRH] **C/B TRIPPED** (*Refer to procedure*)

[QRH] **ELEC EMER CONFIG SYS REMAINING** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021356.0001001 / 17 MAR 17

ENG

[QRH] **ENG DUAL FAILURE - FUEL REMAINING** (*Refer to procedure*)

[QRH] **ENG DUAL FAILURE - NO FUEL REMAINING** (*Refer to procedure*)

- [QRH] **ENG RELIGHT IN FLIGHT** (Refer to procedure)
- [QRH] **ENG STALL** (Refer to procedure)
- [QRH] **ENG TAILPIPE FIRE** (Refer to procedure)
- [QRH] **HIGH ENGINE VIBRATION** (Refer to procedure)
- [QRH] **ON GROUND - NON ENG SHUTDOWN AFTER ENG MASTER OFF** (Refer to procedure)
- [QRH] **ONE ENGINE INOPERATIVE - CIRCLING APPROACH** (Refer to procedure)
- [QRH] **ONE ENGINE INOPERATIVE - STRAIGHT-IN APPROACH** (Refer to procedure)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021347.0001001 / 17 MAR 17

#### F/CTL

- [QRH] **LANDING WITH SLATS OR FLAPS JAMMED** (Refer to procedure)
- [QRH] **RUDDER JAM** (Refer to procedure)
- [QRH] **STABILIZER JAM** (Refer to procedure)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021348.0001001 / 17 MAR 17

#### FUEL

- [QRH] **FUEL IMBALANCE** (Refer to procedure)
- [QRH] **FUEL LEAK** (Refer to procedure)
- [QRH] **GRAVITY FUEL FEEDING** (Refer to procedure)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021353.0001001 / 17 MAR 17

#### L/G

- [QRH] **LANDING WITH ABNORMAL L/G** (Refer to procedure)
- [QRH] **L/G GRAVITY EXTENSION** (Refer to procedure)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021358.0001001 / 22 MAR 17

#### MISC

- [QRH] **BOMB ON BOARD** (Refer to procedure)
- [QRH] **COCKPIT WINDSHIELD / WINDOW ARCING** (Refer to procedure)
- [QRH] **COCKPIT WINDSHIELD / WINDOW CRACKED** (Refer to procedure)
- [QRH] **DITCHING** (Refer to procedure)
- [QRH] **EMER EVAC** (Refer to procedure)
- [QRH] **EMER LANDING** (Refer to procedure)
- [QRH] **FORCED LANDING** (Refer to procedure)
- [QRH] **OVERWEIGHT LANDING** (Refer to procedure)
- [QRH] **SEVERE TURBULENCE** (Refer to procedure)
- [QRH] **TAILSTRIKE** (Refer to procedure)
- [QRH] **VOLCANIC ASH ENCOUNTER** (Refer to procedure)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021354.0002001 / 17 MAR 17

**NAV**

- [QRH] **ADR CHECK PROC** (*Refer to procedure*)
- [QRH] **ALL ADR OFF** (*Refer to procedure*)
- [QRH] **IR ALIGNMENT IN ATT MODE** (*Refer to procedure*)
- [QRH] **NAV FM / GPS POS DISAGREE** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00020870.0001001 / 17 MAR 17

**SMOKE**

- [QRH] **SMOKE / FUMES / AVNCS SMOKE** (*Refer to procedure*)
- [QRH] **REMOVAL OF SMOKE / FUMES** (*Refer to procedure*)
- [QRH] **SMOKE / FIRE FROM LITHIUM BATTERY** (*Refer to procedure*)

Ident.: PRO-ABN-ABN-QRH-ABN-QRH-00021512.0001001 / 17 MAR 17

**WHEEL**

- [QRH] **WHEEL TIRE DAMAGE SUSPECTED** (*Refer to procedure*)




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[QRH] PROCEDURES

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b></p> <p><b>ABNORMAL AND EMERGENCY PROCEDURES</b></p> <p>[RESET] SYSTEM RESET</p>
---	--

**SYSTEM RESET - GENERAL**

Applicable to: ALL

Ident.: PRO-ABN-ABN-RESET-A-00012644.0001001 / 17 MAR 17

Some systems that operate abnormally can be recovered by a reset. The flight crew can perform a system reset with the use of:

- The associated cockpit control, or
- The associated circuit breaker.

**WARNING** Only perform one reset at a time, unless indicated differently.

Ident.: PRO-ABN-ABN-RESET-A-00012645.0001001 / 17 MAR 17

Guidelines to reset a system:

- Set the related normal cockpit control to OFF, or pull the corresponding circuit breaker
- Wait 3 s if a normal cockpit control is used, or 5 s if a circuit breaker is used (unless a different time is indicated)
- Set the related normal cockpit control to ON, or push the corresponding circuit breaker
- Wait 3 s for the end of the reset.

*Note:* The flight crew should report any in-flight reset to the maintenance.

Ident.: PRO-ABN-ABN-RESET-A-00014340.0001001 / 22 MAR 17

■ **On ground:**

Reset ECU (CFM) or EEC (IAE) or EIU only when engine shut down.

Reset BSCU only when aircraft stopped.

Systems not listed in the System Reset Table can be reset following the guidelines described above.

■ **In flight:**

**WARNING** The flight crew can attempt a system reset only when:

- An ECAM /OEB /FCOM /QRH procedure requests to reset the system, or
- The System Reset Table permits.

**CAUTION** Do not pull the following circuit breakers:

- SFCC
- ECU or EEC or EIU.

*Note:* Before taking any action on the cockpit C/B s, both the PF and PM must crosscheck and ensure the C/B label corresponds to the affected system.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

Refer to System Reset Table.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b></p> <p><b>ABNORMAL AND EMERGENCY PROCEDURES</b></p> <p>[RESET] SYSTEM RESET</p>
---	--

**SYSTEM RESET TABLE**

Applicable to: ALL

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00012654.0001001 / 20 MAR 17

A-ICE	<b>ANTI ICE</b> L(R)/WINDSHIELD (WINDOW) (WHC)	<i>Refer to PRO-ABN-A-ICE ANTI ICE L(R) WINDSHIELD, if applicable.</i>
-------	---	--

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00021069.0001001 / 20 MAR 17  
 Impacted by TDU: 00021167 System Reset Table - AIR

AIR	<p><b>AIR ENG 1(2) BLEED FAULT</b> or  <b>AIR ENG 1(2) BLEED ABNORM PR</b>                      (Engine Bleed Supply System)</p>	<p><i>Note:</i> Do not attempt more than one reset.</p> <p><b>On ground or in flight</b></p> <ul style="list-style-type: none"> <li>• If the <b>PACK (non-affected side) is operative, and If the Wing Anti-Ice is OFF:</b> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....OFF</li> <li>■ If the <b>ENG BLEED (affected side) pb-sw FAULT light is on:</b> <ul style="list-style-type: none"> <li>- Delay application of the reset until FAULT light extinguishes.</li> </ul> </li> <li>■ If the <b>ENG BLEED (affected side) pb-sw FAULT light is off:</b> <ul style="list-style-type: none"> <li>- X BLEED.....AUTO</li> <li>- PACK (affected side).....ON</li> <li>- ENG BLEED (affected side).....ON</li> <li>- Check that the affected Engine Bleed Valve is open on the <b>BLEED SD</b> page.                             <ul style="list-style-type: none"> <li>• If <b>AIR ENG (AFFECTED) BLEED FAULT</b> alert or <b>AIR ENG (AFFECTED) BLEED ABNORM PR</b> alert reoccurs, or If <b>Engine Bleed Valve (affected side) not open</b> on the <b>BLEED SD</b> page:                                     <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....OFF</li> <li>- X BLEED.....OPEN</li> </ul> </li> </ul> </li> </ul> </li> </ul> </li> </ul> <p><i>Note:</i> Record the <b>ENG BLEED</b> reset in the logbook (successful or unsuccessful).</p>
	<p><b>AIR ENG 1(2) BLEED NOT CLSD</b>                      (Engine Bleed Supply System)</p>	<p><i>Note:</i> Do not attempt more than one reset.</p> <p><b>On ground only</b></p> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....OFF</li> <li>■ If the <b>ENG BLEED (affected side) pb-sw FAULT light is on:</b> <ul style="list-style-type: none"> <li>- Delay application of the reset until FAULT light extinguishes.</li> </ul> </li> <li>■ If the <b>ENG BLEED (affected side) pb-sw FAULT light is off:</b> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....ON</li> </ul> </li> </ul> <p>- Check that the affected Engine Bleed Valve is closed on the <b>BLEED SD</b> page.</p>

*Continued on the following page*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
		<i>Note:</i> Record the ENG BLEED reset in the logbook (successful or unsuccessful).

*Continued on the following page*

## PROCEDURES

### ABNORMAL AND EMERGENCY PROCEDURES

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

[RESET] SYSTEM RESET

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: TDU / PRO-ABN-ABN-RESET-B-00021167.0001001 / 20 MAR 17  
 Impacted DU: 00021069 System Reset Table - AIR

AIR	<p><b>AIR PACK 1(2) REGUL FAULT (ACSC)</b></p>	<p><b>On ground only:</b></p> <ul style="list-style-type: none"> <li>- Pull C/B s W21 and W22 on 122VU</li> <li>- Pull C/B s X21 and X22 on 122VU</li> <li>- Pull C/B s Y18, Y20 and Y21 on 122VU</li> <li>- Pull C/B D8 on 49VU</li> <li>- Wait 5 s before pushing all the C/Bs.</li> </ul> <p><i>Note:</i> During the reset, a small increase of the engine thrust may be observed (N1 or EPR, as applicable). If the parking brake is set, vibrations can occur.</p>
	<p><b>AIR ENG 1(2) BLEED FAULT or AIR ENG 1(2) BLEED ABNORM PR (Engine Bleed Supply System)</b></p>	<p><i>Note:</i> Do not attempt more than one reset.</p> <p><b>On ground or in flight</b></p> <ul style="list-style-type: none"> <li>• <b>If the PACK (non-affected side) is operative, and If the Wing Anti-Ice is OFF:</b></li> <li>- ENG BLEED (affected side).....OFF                             <ul style="list-style-type: none"> <li>■ <b>If the ENG BLEED (affected side) pb-sw FAULT light is on:</b> <ul style="list-style-type: none"> <li>- Delay application of the reset until FAULT light extinguishes.</li> </ul> </li> <li>■ <b>If the ENG BLEED (affected side) pb-sw FAULT light is off:</b> <ul style="list-style-type: none"> <li>- X BLEED.....AUTO</li> <li>- PACK (affected side).....ON</li> <li>- ENG BLEED (affected side).....ON</li> <li>- Check that the affected Engine Bleed Valve is open on the <u>BLEED</u> SD page.                                     <ul style="list-style-type: none"> <li>• <b>If AIR ENG (AFFECTED) BLEED FAULT alert or AIR ENG (AFFECTED) BLEED ABNORM PR alert reoccurs, or If Engine Bleed Valve (affected side) not open on the <u>BLEED</u> SD page:</b> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....OFF</li> <li>- X BLEED.....OPEN</li> </ul> </li> </ul> </li> </ul> </li> </ul> </li> </ul> <p><i>Note:</i> Record the ENG BLEED reset in the logbook (successful or unsuccessful).</p>

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
	<p><b>AIR ENG 1(2) BLEED NOT CLSD</b>            (Engine Bleed Supply System)</p>	<p><i>Note:</i> Do not attempt more than one reset.</p> <p><b>On ground only</b></p> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....OFF               <ul style="list-style-type: none"> <li>■ <b>If the ENG BLEED (affected side) pb-sw FAULT light is on:</b> <ul style="list-style-type: none"> <li>- Delay application of the reset until FAULT light extinguishes.</li> </ul> </li> <li>■ <b>If the ENG BLEED (affected side) pb-sw FAULT light is off:</b> <ul style="list-style-type: none"> <li>- ENG BLEED (affected side).....ON</li> </ul> </li> </ul> </li> <li>- Check that the affected Engine Bleed Valve is closed on the <u>BLEED SD</u> page.</li> </ul> <p><i>Note:</i> Record the ENG BLEED reset in the logbook (successful or unsuccessful).</p>

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*



ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00021067.0001001 / 21 MAR 17

	<p><b>AUTO FLT FCU 1(2) FAULT</b> (FCU)</p>	<p><b>In flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B B05 on 49VU for FCU 1, or M21 on 121VU for FCU 2</li> <li>- Push it after 5 s</li> <li>- Check the displayed targets and the barometer reference, and correct them if necessary.</li> </ul> <p><b>On ground:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B B05 on 49VU for FCU 1, or M21 on 121VU for FCU 2</li> <li>- Push it after 5 s</li> <li>- If <b>AUTO FLT FCU 1+2 FAULT</b> disappears, check the displayed targets and barometer reference, and correct them if necessary (RESET successful)</li> <li>- If <b>AUTO FLT FCU 1+2 FAULT</b> remains, pull both C/B B05 on 49VU and M21 on 121VU</li> <li>- Push them after 7 min , with a delay of less than 5 s between side 1 and 2</li> <li>- Wait at least 30 s for FCU 1 and FCU 2 safety tests completion</li> <li>- Check the displayed targets and barometer reference, and correct them if necessary (RESET successful).</li> </ul>
<p>AUTO FLT</p>	<p><b>AUTO FLT FCU 1 + 2 FAULT</b> (FCU)</p>	<p><b>In flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B B05 on 49VU for FCU 1, and then pull M21 on 121VU for FCU 2</li> <li>- Push them after 5 s</li> <li>- Check the displayed targets and the barometer reference, and correct them if necessary.</li> </ul> <p><b>On ground:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B B05 on 49VU for FCU 1, and then pull M21 on 121VU for FCU 2</li> <li>- Push the C/Bs after 5 s</li> <li>- If <b>AUTO FLT FCU 1(2) FAULT</b> disappears, check the displayed targets and barometer reference, and correct them if necessary (RESET successful)</li> <li>- If <b>AUTO FLT FCU 1(2) FAULT</b> remains, pull again both C/B B05 on 49VU and M21 on 121VU</li> <li>- Push them after 7 min , with a delay of less than 5 s between side 1 and 2</li> <li>- Wait at least 30 seconds for FCU 1 and FCU 2 safety tests completion</li> <li>- Check the displayed targets and barometer reference, and correct them if necessary (RESET successful)</li> </ul>

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
		<p>FCU targets are synchronized on current aircraft values and displayed as selected targets.</p> <ul style="list-style-type: none"> <li>- Re-enter the barometer altimeter setting value, if necessary.</li> </ul>
	<b>AUTO FLT YAW DAMPER 1(2) FAULT</b> (FAC 1(2))	Refer to PRO-ABN-AUTO_FLT AUTO FLT YAW DAMPER 1(2), if applicable.
	<b>AUTO FLT REAC W/S DET FAULT</b>  (FAC 1+2)	For Reactive Windshear Detection  Fault. Depending on aircraft configuration, Refer to PRO-ABN-AUTO_FLT AUTO FLT REAC W/S DET FAULT or Refer to PRO-ABN-W_S WINDSHEAR DET FAULT.
	One MCDU locked or blank (MCDU)	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B for the locked or blank MCDU and push it back after 10 s.</li> </ul> <p>The circuit breakers for the MCDUs are:</p> <ul style="list-style-type: none"> <li>• AUTO FLT /MCDU 1 B1 ON 49 VU (Overhead Panel)</li> <li>• AUTO FLT /MCDU 2 N20 ON 121 VU (Right Rear Maintenance Panel)</li> <li>• AUTO FLT /MCDU 3 N21 ON 121 VU (Right Rear Maintenance Panel)</li> </ul>
	Both MCDU locked or blank or FMGC malfunction (FMGC)	<p><b>On ground:</b></p> <ul style="list-style-type: none"> <li>- Apply external power or APU generator power</li> <li>- Wait 2 min before resetting the FMGC circuit breakers</li> <li>- FD 1(or 2) (OFF)</li> <li>- Pull the C/B of the affected FMGC and reset it after 10 s.</li> </ul> <p>The circuit breakers for the FMGCs are:</p> <ul style="list-style-type: none"> <li>• AUTO FLT /FMGC 1 B2 ON 49 VU (Overhead Panel)</li> <li>• AUTO FLT /FMGC 2 M17 ON 121 VU (Right Rear Maintenance Panel)</li> </ul> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p><b>CAUTION</b> Always wait 1 min after the "PLEASE WAIT" message disappears from the MCDU , before engaging or reengaging the FD s and the AP of the reset FMGC.</p> </div> <p><i>Note:</i> Due to electrical transient, MANUAL FMGS RESET procedure may be unsuccessful. If so, the flight crew may attempt the same procedure with engines not running.</p> <p><b>In flight:</b></p> <ul style="list-style-type: none"> <li>- FD 1(or 2) (OFF)</li> <li>- Pull the C/B of the affected FMGC and reset it after 10 s.</li> </ul> <p>The circuit breakers for the FMGCs are:</p> <ul style="list-style-type: none"> <li>• AUTO FLT /FMGC 1 B2 ON 49 VU (Overhead Panel)</li> </ul>

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*






ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
		<ul style="list-style-type: none"> <li>• AUTO FLT /FMGC 2 M17 ON 121 VU (Right Rear Maintenance Panel)</li> </ul> <div style="border: 1px solid orange; padding: 5px; margin-top: 10px;"> <p><b>CAUTION</b> Always wait 1 min after the "PLEASE WAIT" message disappears from the MCDU , before engaging or reengaging the FD s and the AP of the reset FMGC.</p> </div>

Ident.: PRO-ABN-ABN-RESET-B-00021056.0001001 / 20 MAR 17

BRAKES	<p><b>BRAKES SYS 1(2) FAULT</b> or <b>BRAKES BSCU CH 1(2) FAULT</b> (BSCU)</p>	<p><b>On ground:</b></p> <ul style="list-style-type: none"> <li>- STOP aircraft</li> <li>- Set PARK BRK handle to ON</li> <li>- Confirm that towing bar is disconnected</li> <li>- Set A/SKID &amp; N/W STRG sw to OFF</li> <li>- Set A/SKID &amp; N/W STRG sw to ON.</li> </ul> <ul style="list-style-type: none"> <li>• IF UNSUCCESSFUL:               <ul style="list-style-type: none"> <li>- Pull C/B s M33 and M34 on 121VU for BSCU channel 1</li> <li>- Pull C/B s M36 and M35 on 121VU for BSCU channel 2</li> <li>- Push C/Bs.</li> </ul> </li> </ul> <p>After a successful reset, resume to normal operation.</p> <p><u>Note:</u> After any BSCU reset:</p> <ol style="list-style-type: none"> <li>1. Check brake efficiency</li> <li>2. Record BSCU reset in the logbook.</li> </ol> <p><b>In flight:</b></p> <p>When landing gear is up only:</p> <ul style="list-style-type: none"> <li>- Set A/SKID &amp; N/W STRG sw to OFF</li> <li>- Set A/SKID &amp; N/W STRG sw to ON</li> <li>- If required, rearm the autobrake.</li> </ul> <p>When landing gear is down: reset not authorized.</p> <p><u>Note:</u> After any BSCU reset:</p> <ul style="list-style-type: none"> <li>- Record BSCU reset in the logbook.</li> </ul>
--------	--	---

*Continued on the following page*

Continued from the previous page





ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
COM	<p><b>COM CIDS 1+2 FAULT</b> and/or Loss of Passenger Address and/or Loss of Cabin Interphone (CIDS)</p>	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/Bs in the following order: P13  and P14  on 121VU</li> <li>G01 and G02 on 49VU</li> <li>M05 and M06 on 121VU</li> <li>- Wait 10 s, then</li> <li>- Push the C/Bs in the following order: M05, M06, G01, G02, P13 , P14 </li> <li>- After CIDS reset, wait approximately 4 min, before recovering normal operation.</li> </ul>
	<p>Uncommanded EVAC horn activation  (CIDS)</p>	<p><b>On ground, or in flight:</b></p> <p>Press the EVAC HORN SHUT OFF pb, Set the EVAC CAPT &amp; PURS/CAPT sw to the CAPT only position. Wait for 3 s.</p> <ul style="list-style-type: none"> <li>• IF UNSUCCESSFUL: <ul style="list-style-type: none"> <li>- Pull the C/B s for DIR 2 in the following order: G02 on 49VU , M06 on 121VU.</li> </ul> </li> <li>• IF UNSUCCESSFUL: <ul style="list-style-type: none"> <li>- Pull the C/B s for DIR 1 in the following order: G01 on 49VU , M05 on 121VU</li> <li>- Wait for 1 min, then:</li> <li>- Push the C/B s for DIR 2 in the following order: M06 , G02 .</li> <li>- After CIDS reset, wait approximately 4 min, before recovering normal operation.</li> </ul> </li> </ul>
	<p>Frozen RMP (RMP)</p>	<p><b>On ground, or in flight:</b></p> <p>The flight crew must reset all the RMP s, one after the other via the RMP control panel:</p> <ul style="list-style-type: none"> <li>- Set RMP ON/OFF sw to OFF position</li> <li>- Wait 5 s</li> <li>- Set RMP ON/OFF sw to ON position.</li> </ul>
	<p>FAP freezing (FAP)</p>	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull FAP C/B s in the following order: H01 C/B on 49VU , Q14 on 121VU</li> <li>- Wait 10 s, then</li> <li>- Push the C/Bs in the following order: Q14, H01 C/B.</li> </ul>

Continued on the following page

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: TDU / PRO-ABN-ABN-RESET-B-00021114.0028001 / 20 MAR 17  
Impacted DU: 00021089 System Reset Table - COM

	<p><b>COM CIDS 1+2 FAULT</b> and/or Loss of Passenger Address and/or Loss of Cabin Interphone (CIDS)</p>	<p><b>Confirm if spurious:</b></p> <ul style="list-style-type: none"> <li>- Check PA function</li> <li>- Check cabin Interphone function</li> <li>- Check cabin Lighting function.</li> </ul> <p>If spurious, reset the CIDS when aircraft is self powered (APU or engine).</p> <p><b>On ground or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/Bs in the following order: P13  and P14  on 121VU G01 and G02 on 49VU M05 and M06 on 121VU</li> <li>- Wait 10 s, then</li> <li>- Push the C/Bs in the following order: M05, M06, G01, G02, P13 , P14 </li> <li>- After CIDS reset, wait approximately 4 min before recovering normal operation.</li> </ul>
COM	<p>Uncommanded EVAC horn actuation (CIDS)</p>	<p><b>On ground, or in flight:</b></p> <p>Press the EVAC HORN SHUT OFF pb. Set the EVAC CAPT &amp; PURS/CAPT sw to the CAPT only position. Wait for 3 s.</p> <ul style="list-style-type: none"> <li>• IF UNSUCCESSFUL:               <ul style="list-style-type: none"> <li>- Pull the C/B s for DIR 2 in the following order: G02 on 49VU , M06 on 121VU.</li> </ul> </li> <li>• IF UNSUCCESSFUL:               <ul style="list-style-type: none"> <li>- Pull the C/B s for DIR 1 in the following order: G01 on 49VU , M05 on 121VU</li> <li>- Wait for 1 min, then</li> <li>- Push the C/B s for DIR 2 in the following order: M06 , G02</li> <li>- After CIDS reset, wait approximately 4 min, before recovering normal operation.</li> </ul> </li> </ul>
	<p>Frozen RMP (RMP)</p>	<p><b>On ground, or in flight:</b></p> <p>The flight crew must reset all the RMP s one after the other via the RMP control panel:</p> <ul style="list-style-type: none"> <li>- Set RMP ON/OFF sw to OFF position</li> <li>- Wait 5 s</li> <li>- Set RMP ON/OFF sw to ON position.</li> </ul>

*Continued on the following page*



**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
	FAP freezing (FAP)	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull FAP C/B s in the following order: H01 C/B on 49VU , Q14 on 121VU</li> <li>- Wait 10 s, then</li> <li>- Push the C/Bs in the following order: Q14, H01 C/B.</li> </ul>

Ident.: PRO-ABN-ABN-RESET-B-00012659.0001001 / 03 AUG 17

DATALINK	ATSU Malfunction (ATSU)	<p>The ATSU reset should be attempted, only if:</p> <ul style="list-style-type: none"> <li>- Key selection has no effect on the DCDU or any of the MCDU ATSU DATALINK submenus</li> <li>- ADS-C or CPDLC are inoperative</li> </ul> <p>When the ATSU is reset, the following connections are no longer active:</p> <ul style="list-style-type: none"> <li>- CPDLC: <ul style="list-style-type: none"> <li>• The flight crew should send a notification to the ATC center to re-establish the CPDLC connection</li> </ul> </li> <li>- ADS-C: <ul style="list-style-type: none"> <li>• As no ADS-C disconnect message is sent, the ATC center(s) assumes that the ADS-C connection is still alive</li> <li>• The flight crew must check that ADS-C is ARMED or ON.</li> </ul> </li> </ul> <p><b>On ground or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the C/B s in the following order: L16, L15 on 121VU</li> <li>- Wait 5 s, then</li> <li>- Push the C/Bs in the following order: L15, L16.</li> </ul>
----------	-------------------------	---

Ident.: PRO-ABN-ABN-RESET-B-00014274.0001001 / 20 MAR 17

DOOR	Flickering or total loss of the video camera display (on the SD) accompanied by the "VIDEO NOT AVAIL" message. (CDSS)	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Set the VIDEO rotary selector to OFF, on the center pedestal VIDEO panel</li> <li>- Set the COCKPIT DOOR VIDEO pb-sw to OFF, on the overhead panel</li> <li>- Wait 2 min, then</li> <li>- Set the COCKPIT DOOR VIDEO pb-sw back to ON, on the overhead panel</li> <li>- Wait 15 s, then</li> <li>- Set the VIDEO rotary selector to "CKPT ENTRY", on the center pedestal VIDEO panel.</li> </ul>
------	---	--

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00012650.0001001 / 20 MAR 17

ELEC	GPU cannot be connected to the aircraft (GAPCU)	<p><b>On ground only:</b></p> <p>The GPU cannot be connected to the electrical network of the aircraft (AVAIL light is OFF):</p> <ul style="list-style-type: none"> <li>• If at least one power source (IDG 1 or 2, APU GEN or batteries) is connected to the electrical network of the aircraft <ul style="list-style-type: none"> <li>- Reset the EXT PWR pb switch on 35VU (Press and release).</li> </ul> </li> <li>• If no power source is connected to the electrical network of the aircraft <ul style="list-style-type: none"> <li>- Set the BAT 1 pb-sw and BAT 2 pb-sw to AUTO.</li> </ul> </li> </ul>
------	---	--


Ident.: PRO-ABN-ABN-RESET-B-00012660.0001001 / 20 MAR 17

ENG	ENG 1(2) FADEC A(B) FAULT (FADEC)	Refer to PRO-ABN-ENG ENG 1(2) FADEC A(B) FAULT, if applicable.
-----	---	--

Ident.: PRO-ABN-ABN-RESET-B-00012652.0001001 / 20 MAR 17

	F/CTL ELAC 1(2) FAULT F/CTL ALTN LAW F/CTL ELAC 1(2) PITCH FAULT (ELAC)	Refer to PRO-ABN-F/CTL section for associated procedure, if applicable.
F/CTL	ELAC or SEC malfunction (ELAC or SEC)	<p>ELAC or SEC may be reset.</p> <div style="border: 2px solid red; padding: 5px; margin: 10px 0;"> <p><b>WARNING</b> Do not reset more than one computer at a time. It is possible to reset flight control computers in flight, event if not requested by the ECAM, provided only one reset is performed at a time.</p> </div> <p><i>Note:</i> When an ELAC reset is performed on ground the crew must check the pitch trim position. If a reset is performed on ground, the flight crew must then perform a flight control check, Refer to PRO-NOR-SOP-10-TAXI.</p>

*Continued on the following page*

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>ABNORMAL AND EMERGENCY PROCEDURES</b>  [RESET] SYSTEM RESET
---	---

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00012653.0018001 / 20 MAR 17

FUEL	Loss of fuel quantity indication or Simultaneous triggering of <b>FUEL L OUTER XFR CLOSED</b> and <b>FUEL R OUTER XFR CLOSED</b> , although FUEL SD indicates no anomaly. (FQIC)	<p><b>On ground, or in flight:</b></p> <ul style="list-style-type: none"> <li>- Pull the 3 C/Bs:             <ul style="list-style-type: none"> <li>• Channel 1 (A13 on 49VU)</li> <li>• Channel 2 (M27 on 121VU)</li> <li>• Channel 1 and 2 (L26 on 121VU).</li> </ul> </li> <li>- Wait 5 s, before pushing the 3 C/Bs.</li> </ul> <p><i>Note:</i> The fuel quantity indication will be re-established within 1 min.</p>
------	--	---

Ident.: PRO-ABN-ABN-RESET-B-00012655.0002001 / 20 MAR 17

FWC	<b>FWS FWC 1(2) FAULT (FWC)</b>	<p><b>On ground:</b></p> <p>Pull, then push, the C/B of the affected FWC:</p> <ul style="list-style-type: none"> <li>- FWC 1 (F01 on 49VU)</li> <li>- FWC 2 (Q7 on 121VU).</li> </ul> <p>Wait 50 s after pushing the C/Bs.</p> <p><b>In flight:</b></p> <p>Pull, then push, the C/B of the affected FWC:</p> <ul style="list-style-type: none"> <li>- FWC 1 (F01 on 49VU)</li> <li>- FWC 2 (Q7 on 121VU).</li> </ul>
-----	---------------------------------	--

Ident.: PRO-ABN-ABN-RESET-B-00021057.0001001 / 21 MAR 17

L/G	<b>L/G LGCIU 1(2) FAULT (LGCIU 1(2))</b>	<p><b>On ground only:</b></p> <p>The flight crew must depressurize the green hydraulic system before resetting the LGCIU:</p> <ul style="list-style-type: none"> <li>- ENG 1 PUMP OFF</li> <li>- PTU OFF.</li> </ul> <p>When there is no green hydraulic pressure:</p> <ul style="list-style-type: none"> <li>- To reset LGCIU 1:             <ul style="list-style-type: none"> <li>• Pull C/B Q34 on 121VU , then C09 on 49VU</li> <li>• Wait for 15 s , then push the C/Bs.</li> </ul> </li> <li>- To reset LGCIU 2:             <ul style="list-style-type: none"> <li>• Pull C/B Q35 on 121VU</li> <li>• Wait for 15 s , then push the C/B.</li> </ul> </li> </ul> <p>After the LGCIU reset, restore green hydraulic pressure (ENG 1 PUMP ON, PTU AUTO).</p>
-----	--	---

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00012657.0048001 / 20 MAR 17



NAV	<p><b>NAV GPWS FAULT</b> and <b>NAV GPWS TERR DET FAULT</b> (EGPWS)</p>	<p><b>On ground, or in flight:</b>                      Perform the following reset when both alerts are displayed at the same time.</p> <ul style="list-style-type: none"> <li>- Pull C/B P07 on 121VU,</li> <li>- Set GPWS SYS pb and GPWS TERR pb to ON,</li> <li>- Wait 5 s, then push the C/B.</li> </ul>
	<p><b>NAV TCAS FAULT</b> (TCAS)</p>	<p><b>On ground only:</b></p> <ul style="list-style-type: none"> <li>- Pull C/B K10 on 121VU.</li> <li>- Wait 5 s, then push the C/B.</li> </ul>
	<p>ISIS malfunction (ISIS)</p>	<p><b>On ground only:</b>                      With aircraft not moving:</p> <ul style="list-style-type: none"> <li>- Pull C/B F12 on 49VU,</li> <li>- Wait 5 s, then push the C/B,</li> <li>- Normal operation is expected after approximately 2 min.</li> </ul> <p><u>Note:</u> <i>In the case of small aircraft motion during the C/B reset (refueling, cargo loading conditions, etc.), the ATT red flag may appear on the ISIS. In this case, press the RST P/B for 2 s wait 2 min additional to recover normal operation.</i></p>

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00012651.0016001 / 20 MAR 17

	<p><b>SMOKE DET FAULT</b> (CIDS-SDF)</p>	<p><b>On ground, or in flight:</b> Apply the following actions in the presented order:</p> <ul style="list-style-type: none"> <li>- Pull the C/B s C05 and C06 on 49VU , T17 and T18 on 122VU</li> <li>- Wait 10 s, then</li> <li>- Push simultaneously the C/B s C05 and C06 on 49VU</li> <li>- Within 2 s push simultaneously the C/B s T17 and T18 on 122VU</li> <li>- After CIDS reset, wait approximately 4 min before recovering normal operation.</li> </ul>
SMOKE	<p><b>SMOKE LAVATORY DET FAULT</b> with all lavatories declared inoperative on the FAP (CIDS or CIDS-SDF)</p>	<p><b>On ground, or in flight:</b> Apply the following actions in the presented order:</p> <ul style="list-style-type: none"> <li>- Pull the C/B s P13 and P14  on 121VU , G01 and G02 on 49VU , M05 or M06 and M06 or M07 on 121VU</li> <li>- Wait 10 s, then</li> <li>- Push the C/B s in the following order: M05 or M06 and M06 or M07 on 121VU , G01 and G02 on 49VU, P13 and P14  on 121VU.</li> <li>- After CIDS reset, wait approximately 4 min before recovering normal operation.</li> </ul> <p><b>If unsuccessful, on ground only:</b> Apply the following actions in the presented order:</p> <ul style="list-style-type: none"> <li>- Pull the C/B s C06 and C05 on 49VU , T17 and T18 on 122VU.</li> <li>- Wait 10 s, then</li> <li>- Push simultaneously the C/B s C06 and C05 on 49VU</li> <li>- Within 2 s push simultaneously the C/B s T17 and T18 on 122VU</li> <li>- After CIDS reset, wait approximately 4 min before recovering normal operation.</li> </ul>
	<p><b>SMOKE FWD (AFT) CARGO DET FAULT</b> <b>SMOKE FWD (AFT) CRG 1/2 BTL FAULT</b> (CIDS-SDF)</p>	<p><b>On ground:</b> Apply the following actions in the presented order:</p> <ul style="list-style-type: none"> <li>- Pull the C/B s C06 and C05 on 49VU , T17 and T18 on 122VU</li> <li>- Wait 10 s, then</li> <li>- Push simultaneously the C/B s C06 and C05 on 49VU</li> <li>- Within 2 s push simultaneously the C/B s T17 and T18 on 122VU</li> <li>- After CIDS reset, wait approximately 4 min before recovering normal operation.</li> </ul>

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
-------------	--	-----------------

Ident.: PRO-ABN-ABN-RESET-B-00021071.0001001 / 20 MAR 17

VENT	<p style="color: orange;">VENT AVNCS SYS FAULT (AEVC)</p>	<p><b>On ground only:</b></p> <ul style="list-style-type: none"> <li>- Pull C/B Y17 on 122VU</li> <li>- Wait 5 s before pushing the C/B.</li> </ul>
------	---	---

Ident.: PRO-ABN-ABN-RESET-B-00021068.0001001 / 20 MAR 17

WINDSHEAR	<p style="color: orange;">WINDSHEAR DET FAULT ⚠️ or <span style="color: orange;">AUTO FLT REAC W/S DET FAULT</span> ⚠️ (FAC 1+2)</p>	<p>For Reactive Windshear Detection ⚠️ Fault. Depending on aircraft configuration, refer to PRO-ABN-22 AUTO FLT REAC W/S DET FAULT or to PRO-ABN-22 WINDSHEAR DET FAULT.</p>
-----------	--	--

Ident.: PRO-ABN-ABN-RESET-B-00021058.0001001 / 20 MAR 17

Impacted by TDU: 00021059 System Reset Table - WHEEL

WHEEL	<p style="color: orange;">WHEEL N/W STRG FAULT or WHEEL N/W STRG FAULT (BSCU)</p>	<p><b>On ground only:</b></p> <ul style="list-style-type: none"> <li>- STOP aircraft</li> <li>- Set PARK BRK handle to ON</li> <li>- Confirm that towing bar is disconnected</li> <li>- Set A/SKID &amp; N/W STRG sw to OFF</li> <li>- Set A/SKID &amp; N/W STRG sw to ON.</li> </ul> <p>In the case of a <span style="color: orange;">WHEEL N/W STRG FAULT</span>, the flight crew may attempt a BSCU reset. However, even if the BSCU reset is successful, the flight crew must return to the gate for troubleshooting. The taxi speed must not exceed 10 kt.</p> <p><i>Note:</i> After any BSCU reset:</p> <ol style="list-style-type: none"> <li>1. Check brake efficiency</li> <li>2. Record the BSCU reset in the logbook.</li> </ol>
-------	---	---

*Continued on the following page*

*Continued from the previous page*

ECAM System	System malfunction or ECAM Alert (Affected System)	Reset Procedure
WHEEL	<p><b>WHEEL N.W STEER FAULT</b>  or  <b>WHEEL N/W STRG FAULT (BSCU)</b></p>	<p><b>On ground only:</b></p> <p><b>Case A</b></p> <p>If the three conditions below are fulfilled:</p> <ul style="list-style-type: none"> <li>- the <b>WHEEL N/W STRG FAULT</b> alert was triggered just after engine start</li> <li>- the N/W STRG DISC memo was displayed before the start of the pushback (before the aircraft starts moving)</li> <li>- the N/W STRG DISC memo remained displayed even after the pushback is finished (nosewheel steering selector bypass pin is in the steering position).</li> </ul> <p>Apply the below reset procedure.</p> <p>If the ECAM alert disappears after the reset, the flight crew may continue the flight without troubleshooting.</p> <p><b>Case B</b></p> <p>In all other cases, including in case of doubt on the above conditions, troubleshooting must be performed before continuing the flight, even if the ECAM alert disappears after the reset. For a return to the gate :</p> <ul style="list-style-type: none"> <li>- Apply the below reset procedure</li> <li>- The taxi speed must not exceed 10 kt.</li> </ul> <p><b>Reset Procedure:</b></p> <ul style="list-style-type: none"> <li>- STOP aircraft</li> <li>- Set PARK BRK handle to ON</li> <li>- Confirm that towing bar is disconnected</li> <li>- Set A/SKID &amp; N/W STRG sw to OFF</li> <li>- Set A/SKID &amp; N/W STRG sw to ON.</li> </ul> <p><b>Note:</b> After any BSCU reset:</p> <ol style="list-style-type: none"> <li>1. Check brake efficiency</li> <li>2. Check absence of aircraft veering</li> <li>3. Record the BSCU reset in the logbook.</li> </ol>



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

[RESET] SYSTEM RESET

Intentionally left blank



**[QRH] DOUBLE AOA HEAT FAILURE**

Ident.: PRO-ABN-A-ICE-00010253.0002001 / 17 MAR 17

Applicable to: **ALL**

In the case of double failure of alpha probe heaters, the choice made by the computers among the 3 ADR values may be erroneous.

One of affected ADRs.....OFF

*Keep preferably ADR 1 available as ADR1 is supplied in EMER ELEC config.*

**NAV ADR 1(2)(3) FAULT**

In the case of disagreement between the two remaining ADR s, the **NAV ADR DISAGREE** ECAM alert will trigger.

**ANTI ICE ALL PITOT**

Applicable to: **ALL**

Ident.: PRO-ABN-A-ICE-U-00017184.0003001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2**

This alert triggers when the heating systems of the CAPT , F/O and STBY pitot probes are failed.

Flight Phase Inhibition:



*Continued on the following page*

**ANTI ICE ALL PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-U-00018180.0004001 / 21 MAR 17

**L2** In the case of simultaneous pitot icing and in the same amount, ADR 1, ADR 2, and ADR 3 speeds will be in agreement, but incorrect. The following ECAM procedure avoids that the flight controls use erroneous, but coherent, sources.

**L1** **ADR 1(2)(3) P/B**..... **OFF**

**L2** Depending on the status of the static, AOA , and TAT heating, the ECAM requires that either ADR 1, 2 or 3 be switched OFF.

Note: In the case of subsequent, significant, speed discrepancy between the two remaining ADR s, the "ADR DISAGREE" ECAM caution will trigger.

**L1** ● **IF ICING EXPECTED:**  
**ADR 2(3) P/B**..... **OFF**

**L2** Depending on the status of the static, AOA , and TAT heating, the ECAM requires that either ADR 2 or 3 be switched OFF.

**L1** **UNREL SPD PROC**..... **APPLY**

**L2** Only one ADR is available, and the corresponding pitot probe may be affected by ice accretion. Be prepared to use the UNRELIABLE SPEED INDICATION procedure (Refer to procedure).

**L12**

**ASSOCIATED PROCEDURES**

**NAV ADR FAULT**

Single ADR FAULT or double ADR FAULT ECAM cautions may trigger, depending on the number of ADRs switched OFF.

**L12**

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

Alternate law becomes active, if:

- One ADR was already switched OFF, and the two remaining ADRs are not in agreement, or
- Two ADRs were switched OFF.

Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

A-ICE

**ANTI ICE ALL PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-U-00018298.0002001 / 21 MAR 16

**STATUS**

● **IF ICING EXPECTED:**

ADR 2(3) P/B..... OFF  
 UNREL SPD PROC..... APPLY

**INOP SYS**

CAPT PITOT  
 F/O PITOT  
 STBY PITOT  
 CAPT PROBES <sup>(1)</sup>  
 F/O PROBES <sup>(2)</sup>  
 STBY PROBES <sup>(3)</sup>  
 STEEP APPR  (If in ALTN  
 LAW)

<sup>(1)</sup> (If all CAPT PROBES heating is lost)

<sup>(2)</sup> (If all F/O PROBES heating is lost)

<sup>(3)</sup> (If all STBY PROBES heating is lost)

**ANTI ICE CAPT(F/O) TAT**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-E-00017171.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the heating system of the corresponding probe is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-E-00018299.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-A-ICE-E-00018889.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAPT(F/O) TAT

**ANTI ICE CAPT + F/O PITOT**

Applicable to: ALL

Ident.: PRO-ABN-A-ICE-R-00017177.0003001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the heating systems of the CAPT and F/O pitot probes are failed.

Flight Phase Inhibition:



*Continued on the following page*

**ANTI ICE CAPT + F/O PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-R-00018300.0002001 / 21 MAR 17

[L2] In the case of simultaneous pitot icing and in the same amount, ADR 1 and ADR 2 speeds will be in agreement, but incorrect. Therefore, flight controls will consider the remaining correct source as being faulty, and will reject the only correct source. The following ECAM procedure avoids that the flight controls use two erroneous, but coherent, sources.

[L1] ■ **If ADR 3 operative and ON:**  
ADR 1(2) P/B..... OFF

[L2] Depending on the status of the static, AOA, and TAT heating, the ECAM requires that either ADR 1 or 2 be switched OFF

Note: In the case of subsequent, significant, speed discrepancy between the two remaining ADR s, the “ADR DISAGREE” ECAM caution will trigger.

[L1] ■ **If ADR 3 failed or OFF:**

[L2] No action is required, as long as there are no icing conditions, in order to keep two independent speed sources.

[L1] ● **IF ICING EXPECTED:**  
ADR 1(2) P/B..... APPLY

[L2] Depending on the status of the static, AOA, and TAT heating, the ECAM requires that either ADR 1 or 2 be switched OFF.

[L1] UNREL SPD PROC.....APPLY

[L2] Only one ADR is available, and the corresponding pitot probe may be affected by ice accretion. Be prepared to use the UNRELIABLE SPEED INDICATION procedure (Refer to procedure).

[L1]

**ASSOCIATED PROCEDURES**

**NAV ADR FAULT**

*Continued on the following page*

**ANTI ICE CAPT + F/O PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-R-00018301.0002001 / 21 MAR 16

<p style="text-align: right; margin-bottom: 0;"><b>STATUS</b></p> <ul style="list-style-type: none"> <li>● If ADR 3 failed or OFF:</li> <li>● IF ICING EXPECTED:           <ul style="list-style-type: none"> <li>ADR 1(2) P/B.....OFF</li> <li>UNREL SPD PROC.....APPLY</li> </ul> </li> </ul>	<p style="text-align: center; margin-bottom: 0;"><b>INOP SYS</b></p> <p style="color: orange; margin-top: 10px;">CAPT PITOT F/O PITOT CAPT PROBES <sup>(1)</sup> F/O PROBES <sup>(2)</sup></p>
---	--

(1) (If all CAPT PROBES heating is lost)  
 (2) (If all F/O PROBES heating is lost)

**ANTI ICE CAPT + STBY PITOT**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-S-00017178.0003001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the heating systems of the CAPT and STBY pitot probes are failed.

Flight Phase Inhibition:



Continued on the following page

**ANTI ICE CAPT + STBY PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-S-00018302.0002001 / 21 MAR 17

[L2] In the case of simultaneous pitot icing and in the same amount, ADR 1 and ADR 3 speeds will be in agreement, but incorrect. Flight controls will consider the remaining correct source as being faulty, and will reject the only correct source. The following ECAM procedure avoids that the flight controls use two erroneous, but coherent, sources.

[L1] ■ **If ADR 2 operative and ON:**  
ADR 1(3) P/B..... OFF

[L2] Depending on the status of the static, AOA, and TAT heating, the ECAM requires that either ADR 1 or 3 be switched OFF

Note: In the case of subsequent, significant, speed discrepancy between the two remaining ADR s, the "ADR DISAGREE" ECAM caution will trigger.

[L1] ■ **If ADR 2 failed or OFF:**

[L2] No action is required, as long as there are no icing conditions, in order to keep two independent speed sources.

[L1] ● **IF ICING EXPECTED:**  
ADR 1(3) P/B..... APPLY

[L2] Depending on the status of the static, AOA, and TAT heating, the ECAM requires that either ADR 1 or 3 be switched OFF.

[L1] UNREL SPD PROC..... APPLY

[L2] Only one ADR is available, and the corresponding pitot probe may be affected by ice accretion. Be prepared to use the UNRELIABLE SPEED INDICATION procedure (Refer to procedure).

[L1]

**ASSOCIATED PROCEDURES**

**NAV ADR FAULT**

*Continued on the following page*



**ANTI ICE CAPT + STBY PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-S-00018303.0002001 / 21 MAR 16

	STATUS
<ul style="list-style-type: none"> <li>● If ADR 2 failed or OFF:</li> <li>● IF ICING EXPECTED:</li> </ul> <p style="margin-left: 20px;">ADR 1(3) P/B.....OFF</p> <p style="margin-left: 20px;">UNREL SPD PROC.....APPLY</p>	<p><b>INOP SYS</b></p> <p>CAPT PITOT</p> <p>STBY PITOT</p> <p>CAPT PROBES <sup>(1)</sup></p> <p>STBY PROBES <sup>(2)</sup></p>
<p><sup>(1)</sup> (If all CAPT PROBES heating is lost)</p> <p><sup>(2)</sup> (If all STBY PROBES heating is lost)</p>	

**ANTI ICE CAPT PITOT OR L(R) STAT OR AOA**

Applicable to: ALL

Ident.: PRO-ABN-A-ICE-C-00017169.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the heating system of the corresponding probe is failed.

Flight Phase Inhibition:

The diagram shows a horizontal timeline from 1 to 10. Above the timeline, various flight events are marked: ELEC PWR (1), 1ST ENG STARTED (2), 1ST ENG TO PWR (3), 80 kt (4), LIFTOFF (5), 1500 ft (6), 800 ft (7), TOUCHDOWN (8), 80 kt (9), 2ND ENG SHUTDN (10), and 5MN AFTER (10). A shaded grey area covers the timeline from phase 1 to phase 8, indicating that the alert is inhibited during these phases.

*Continued on the following page*

**ANTI ICE CAPT PITOT OR L(R) STAT OR AOA (Cont'd)**

Ident.: PRO-ABN-A-ICE-C-00018310.0002001 / 21 MAR 16

**AIR DATA SWTG** ..... **CAPT 3**

**L2** ADR 3 supplies data to PFD 1 and ND 1.

Note: AIR DATA SWTG should not be selected to CAPT 3 if ADR 3 is not available.

Ident.: PRO-ABN-A-ICE-C-00018900.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAPT PITOT  
CAPT L(R) STAT  
CAPT AOA

**ANTI ICE CAPT PROBES**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-G-00017173.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the captain probe heat computer is failed.

Flight Phase Inhibition:



*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

A-ICE

**ANTI ICE CAPT PROBES (Cont'd)**

Ident.: PRO-ABN-A-ICE-G-00010255.0002001 / 05 AUG 10

AIR DATA SWTG.....CAPT 3

**L2** Note: AIR DATA SWTG should not be selected to CAPT 3 if ADR 3 is not available.

Ident.: PRO-ABN-A-ICE-G-00010256.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

CAPT PROBES

**ANTI ICE ENG 1(2) VALVE CLSD**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-J-00017163.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the valve is abnormally closed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-J-00010269.0001001 / 05 AUG 10

AVOID ICING CONDITIONS

Continued on the following page

**ANTI ICE ENG 1(2) VALVE CLSD (Cont'd)**

Ident.: PRO-ABN-A-ICE-J-00010270.0001001 / 05 AUG 10

**STATUS**

**AVOID ICING CONDITIONS**

**INOP SYS**

ENG 1 (2) A. ICE

**ANTI ICE ENG 1(2) VALVE OPEN**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-K-00017162.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the valve is abnormally open.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-K-00010272.0001001 / 05 AUG 10

**THRUST LIM PENALTY**

*Continued on the following page*

**ANTI ICE ENG 1(2) VALVE OPEN (Cont'd)**

Ident.: PRO-ABN-A-ICE-K-00010273.0001001 / 05 AUG 10

**STATUS**

THRUST LIM PENALTY

**ANTI ICE F/O + STBY PITOT**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-T-00017179.0003001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the heating systems of the F/O and STBY pitot probes are failed.

Flight Phase Inhibition:



*Continued on the following page*

**ANTI ICE F/O + STBY PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-T-00018307.0002001 / 21 MAR 17

[L2] In the case of simultaneous pitot icing and in the same amount, ADR 2 and ADR 3 speeds will be in agreement, but incorrect. Therefore, flight controls will consider the remaining correct source as being faulty, and will reject the only correct source. The following ECAM procedure avoids that the flight controls use two erroneous, but coherent, sources.

[L1] ■ **If ADR 1 operative and ON:**  
ADR 2(3) P/B..... OFF

[L2] Depending on the status of the static, AOA , and TAT heating, the ECAM requires that either ADR 2 or 3 be switched OFF.

Note: In the case of subsequent, significant, speed discrepancy between the two remaining ADR s, the “ADR DISAGREE” ECAM caution will trigger.

[L1] ■ **If ADR 1 failed or OFF:**

[L2] No action is required, as long as there are no icing conditions, in order to keep two independent speed sources.

[L1] ● **IF ICING EXPECTED:**  
ADR 2(3) P/B..... APPLY

[L2] Depending on the status of the static, AOA , and TAT heating, the ECAM requires that either ADR 2 or 3 be switched OFF.

[L1] UNREL SPD PROC.....APPLY

[L2] Only one ADR is available, and the corresponding pitot probe may be affected by ice accretion. Be prepared to use the UNRELIABLE SPEED INDICATION procedure (Refer to procedure).

[L1]

**ASSOCIATED PROCEDURES**

**NAV ADR FAULT**

*Continued on the following page*

**ANTI ICE F/O + STBY PITOT (Cont'd)**

Ident.: PRO-ABN-A-ICE-T-00018308.0002001 / 21 MAR 16

	STATUS
<ul style="list-style-type: none"> <li>● If ADR 1 failed or OFF:</li> <li>● IF ICING EXPECTED:</li> </ul> <p style="margin-left: 20px;">ADR 2(3) P/B.....OFF</p> <p style="margin-left: 20px;">UNREL SPD PROC.....APPLY</p>	<p><b>INOP SYS</b></p> <p>F/O PITOT</p> <p>STBY PITOT</p> <p>F/O PROBES <sup>(1)</sup></p> <p>STBY PROBES <sup>(2)</sup></p>
<p><sup>(1)</sup> (If all F/O PROBES heating is lost)</p> <p><sup>(2)</sup> (If all STBY PROBES heating is lost)</p>	

**ANTI ICE F/O PITOT OR L ( R ) STAT OR AOA**

Applicable to: ALL

Ident.: PRO-ABN-A-ICE-D-00017170.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the heating system of the corresponding probe is failed.

Flight Phase Inhibition:

ELEC PWR	1ST ENG STARTED	1ST ENG TO PWR	80 kt	LIFTOFF	1500 ft	800 ft	TOUCHDOWN	80 kt	2ND ENG SHUTDN	5MN AFTER
1	2	3	4	5	6	7	8	9	10	

*Continued on the following page*

**ANTI ICE F/O PITOT OR L( R) STAT OR AOA (Cont'd)**

Ident.: PRO-ABN-A-ICE-D-00018309.0002001 / 21 MAR 16

**AIR DATA SWTG**..... **F/O 3**

**L2** ADR 3 supplies data to PFD 2 and ND 2.

Note: AIR DATA SWTG should not be selected to F/O 3 if ADR 3 is not available.

Ident.: PRO-ABN-A-ICE-D-00018901.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

F/O PITOT  
F/O L(R) STAT  
F/O AOA

**ANTI ICE F/O PROBES**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-H-00017174.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the F/O probe heat computer is failed.

Flight Phase Inhibition:



*Continued on the following page*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

A-ICE

**ANTI ICE F/O PROBES (Cont'd)**

Ident.: PRO-ABN-A-ICE-H-00010261.0002001 / 05 AUG 10

AIR DATA SWTG.....F/O 3

**L2** Note: AIR DATA SWTG should not be selected to F/O 3 if ADR 3 is not available.

Ident.: PRO-ABN-A-ICE-H-00010263.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

F/O PROBES

**ANTI ICE L + R WINDSHIELD**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-B-00017167.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the heating system of both windshields is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-B-00010236.0001001 / 25 FEB 14

Crew awareness.

Continued on the following page

**ANTI ICE L + R WINDSHIELD (Cont'd)**

Ident.: PRO-ABN-A-ICE-B-00010237.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

WSHLD HEAT

**ANTI ICE L(R) WINDOW**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-V-00017168.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

[2] This alert triggers when the heating system of the left(right) cockpit window is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-V-00010234.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*

**ANTI ICE L(R) WINDOW (Cont'd)**

Ident.: PRO-ABN-A-ICE-V-00010235.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

L(R) WNDW HEAT

**ANTI ICE L(R) WINDSHIELD**

Applicable to: ALL

Ident.: PRO-ABN-A-ICE-A-00017166.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2**

This alert triggers when the heating system of the left(right) windshield is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-A-00010232.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*

**ANTI ICE L(R) WINDSHIELD (Cont'd)**

Ident.: PRO-ABN-A-ICE-A-00010233.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

L(R) WSHLD HEAT

**ANTI ICE STBY PITOT OR L(R) STAT OR AOA**

Applicable to: ALL


Ident.: PRO-ABN-A-ICE-F-00017172.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**[L2]** This alert triggers when the heating system of the corresponding probe is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-F-00010250.0001001 / 25 FEB 14

Crew awareness.

**[L2]** If standby instruments are used, monitor air data information.

*Continued on the following page*

**ANTI ICE STBY PITOT OR L(R) STAT OR AOA (Cont'd)**

Ident.: PRO-ABN-A-ICE-F-00010251.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

STBY PITOT  
STBY L(R) STAT  
STBY AOA

**ANTI ICE STBY PROBES**

Applicable to: ALL

Ident.: PRO-ABN-A-ICE-I-00017176.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the standby probe heat computer is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-A-ICE-I-00010265.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**

**ABNORMAL AND EMERGENCY PROCEDURES**

A-ICE

**ANTI ICE STBY PROBES (Cont'd)**

Ident.: PRO-ABN-A-ICE-I-00010266.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

STBY PROBES

**[QRH] ENGINE 1+2 BLEED FAULT**

Ident.: PRO-ABN-AIR-00017611.0001001 / 21 MAR 17

Applicable to: ALL

Apply this procedure when both engine bleed supply systems are failed.

● **At ANY TIME of the procedure, if CAB PR EXCESS CAB ALT alert triggers: APPLY ECAM PROC**

■ **If AIR ENG 1 BLEED FAULT alert or AIR ENG 1 BLEED ABNORM PR alert and**

**if AIR ENG 2 BLEED FAULT alert or AIR ENG 2 BLEED ABNORM PR alert:**

X BLEED ..... SHUT  
 ENG 1 BLEED ..... OFF THEN ON  
 ENG 2 BLEED ..... OFF THEN ON

● **If reset unsuccessful (NO engine bleed recovered):**

DESCENT TO FL 100 / MEA -MORA..... INITIATE

L2

*Descend rapidly to FL 100 / MEA -MORA, to prevent excessive cabin altitude.*

L1

ENG 1 BLEED..... OFF

ENG 2 BLEED..... OFF

APU BLEED..... OFF

APU..... START

WING A.ICE..... OFF

AVOID ICING CONDITIONS

■ **If APU available:**

● **When at or below FL 200:**

KEEP WING A.ICE OFF

L2

*APU BLEED must not be used for wing anti-ice.*

L1

APU BLEED..... ON

L2

*When APU BLEED is ON and pressurization is recovered, reduce rate of descent and consider MAX FL 200.*

L1

■ **If APU bleed available:**

MAX FL: 200

ENG 1 BLEED..... ON

ENG 2 BLEED..... ON

APU BLEED..... OFF

*Continued on the following page*

**[QRH] ENGINE 1+2 BLEED FAULT (Cont'd)**

- **If no engine bleed recovered:**  
 APU BLEED..... ON  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 WING A.ICE NOT AVAILABLE

- **If PACK 1 inoperative:**  
 X BLEED..... OPEN  
*To supply the PACK 2 from the APU bleed.*

L2

L1

- **If APU bleed not available:**  
 CONTINUE DESCENT TO FL 100 / MEA-MORA  
 APU BLEED..... OFF

- **When at or below FL 100 / MEA-MORA:**  
 ENG 1 BLEED..... ON  
 ENG 2 BLEED..... ON

- **If no engine bleed recovered:**  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 WING A.ICE NOT AVAILABLE

- **When CAB PR ΔP < 1 psi:**  
 RAM AIR..... ON  
 MAX FL: 100 / MEA-MORA

- **If APU not available:**  
 CONTINUE DESCENT TO FL 100 / MEA-MORA  
 APU BLEED..... OFF

- **When at or below FL 100 / MEA-MORA:**  
 ENG 1 BLEED..... ON  
 ENG 2 BLEED..... ON

- **If no engine bleed recovered:**  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 WING A.ICE NOT AVAILABLE

*Continued on the following page*



**[QRH] ENGINE 1+2 BLEED FAULT (Cont'd)**

- When CAB PR  $\Delta P < 1$  psi:  
RAM AIR..... ON  
MAX FL: 100 / MEA-MORA

■ If at least one engine bleed failed due to bleed leak or engine fire or Start Air Valve failed open:

DESCENT TO FL 100 / MEA -MORA..... INITIATE

**L2** Descend rapidly to FL 100 / MEA -MORA, to prevent excessive cabin altitude.

- L1** X BLEED..... SHUT
- ENG 1 BLEED..... OFF
- ENG 2 BLEED..... OFF
- APU BLEED..... OFF
- APU..... START
- WING A.ICE..... OFF

AVOID ICING CONDITIONS

■ If **AIR ENG 2 BLEED FAULT** alert or **AIR ENG 2 BLEED ABNORM PR** alert:

- When at or below FL 100 / MEA-MORA:  
ENG 2 BLEED..... ON

- If engine 2 bleed not recovered:  
ENG 2 BLEED..... OFF

WING A.ICE NOT AVAILABLE

- When CAB PR  $\Delta P < 1$  psi:  
RAM AIR..... ON  
MAX FL: 100 / MEA-MORA

■ If **AIR ENG 1 BLEED FAULT** alert or **AIR ENG 1 BLEED ABNORM PR** alert:

■ If APU available:

- When at or below FL 200:  
KEEP WING A.ICE OFF

**L2** APU BLEED must not be used for wing anti-ice.

**L1** APU BLEED..... ON

**L2** When APU BLEED is ON and pressurization is recovered, reduce rate of descent and consider MAX FL 200.

Continued on the following page

**[QRH] ENGINE 1+2 BLEED FAULT (Cont'd)**

L1

■ **If APU bleed available:**

MAX FL: 200

ENG 1 BLEED.....ON

APU BLEED.....OFF

● **If engine 1 bleed not recovered:**

APU BLEED.....ON

ENG 1 BLEED..... OFF

WING A.ICE NOT AVAILABLE

■ **If APU bleed not available:**

CONTINUE DESCENT TO FL 100 / MEA-MORA

APU BLEED.....OFF

● **When at or below FL 100 / MEA-MORA:**

ENG 1 BLEED..... ON

● **If engine 1 bleed not recovered:**

ENG 1 BLEED..... OFF

WING A.ICE NOT AVAILABLE

● **When CAB PR ΔP < 1 psi:**

RAM AIR.....ON

MAX FL: 100 / MEA-MORA

■ **If APU not available:**

CONTINUE DESCENT TO FL 100 / MEA-MORA

APU BLEED.....OFF

● **When at or below FL 100 / MEA-MORA:**

ENG 1 BLEED..... ON

● **If engine 1 bleed not recovered:**

ENG 1 BLEED..... OFF

WING A.ICE NOT AVAILABLE

● **When CAB PR ΔP < 1 psi:**

RAM AIR.....ON

MAX FL: 100 / MEA-MORA

*Continued on the following page*

**[QRH] ENGINE 1+2 BLEED FAULT (Cont'd)**

- If neither **AIR ENG 1(2) BLEED FAULT** alert nor **AIR ENG 1(2) BLEED ABNORM PR** alert on any side:

NO ENGINE BLEED CAN BE RECOVERED  
WING A.ICE NOT AVAILABLE

- **When at or below FL 100 / MEA-MORA**

and

**CAB PR ΔP < 1 psi:**

RAM AIR.....ON

MAX FL: 100 / MEA-MORA

**AIR APU BLEED FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AIR-G-00017375.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the APU is running and the position of the APU bleed valve disagrees with the selected position of the APU BLEED pb-sw.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-G-00017552.0001001 / 21 MAR 16

Crew awareness.

*Continued on the following page*

**AIR APU BLEED FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-G-00011266.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

APU BLEED (If valve closed)

**AIR APU BLEED LEAK**

Applicable to: ALL


Ident.: PRO-ABN-AIR-F-00017376.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**[L2]** This alert triggers when the APU bleed leak detection loop detects a temperature above 124 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-F-00017553.0001001 / 21 MAR 16

**APU BLEED (IF NOT CLOSED).....OFF**

**[L2]** When the APU BLEED pb-sw is ON, the FAULT light remains on.  
 When the APU BLEED pb-sw is OFF, the FAULT light goes off when the overheat disappears.

*Continued on the following page*

**AIR APU BLEED LEAK (Cont'd)**

Ident.: PRO-ABN-AIR-F-00011100.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

APU BLEED

**AIR BLEED 1(2) OFF**

Applicable to: ALL

Ident.: PRO-ABN-AIR-AA-00017374.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the ENG 1(2) BLEED pb-sw is abnormally set to OFF.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AA-00017555.0001001 / 21 MAR 16

Crew awareness.

**AIR COND CTL 1(2) - A(B) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AIR-AC-00017315.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the lane A(B) of ACSC 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AC-00018084.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-AIR-AC-00010777.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

COND CTL 1(2)-A(B)

**AIR ENG 1(2) BLEED ABNORM PR**

Applicable to: ALL


Ident.: PRO-ABN-AIR-B-00017378.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the regulated pressure in the engine bleed duct is abnormal.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-B-00017584.0005001 / 21 MAR 16

- If wing anti-ice is off, and both packs are on:

PACK FLOW.....LO

**L2** The PACK FLOW selector must be set to LO, due to precooler performance.

- If wing anti-ice is on, and both packs are on:

PACK (AFFECTED).....OFF

**L2** One pack must be closed when the flight crew uses wing anti-ice because of precooler performance.

**L1** X BLEED.....OPEN

Continued on the following page

**AIR ENG 1(2) BLEED ABNORM PR (Cont'd)**

Ident.: PRO-ABN-AIR-B-00011089.0001001 / 05 AUG 10

**STATUS**

ONE PACK ONLY IF WAI ON

**INOP SYS**

ENG 1(2) BLEED  
PACK 1(2) (If closed)

**AIR ENG 1(2) BLEED FAULT**

Applicable to: **ALL**


Ident.: PRO-ABN-AIR-C-00017369.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- 2 This alert triggers when the engine 1(2) is running and:
- The engine bleed air pressure is above 57 PSI (+3/-0), or
  - The engine bleed air temperature is above:
    - 257 °C for more than 55 s
    - 270 °C for more than 15 s
    - 290 °C for more than 5 s.

Flight Phase Inhibition:



*Continued on the following page*



**AIR ENG 1(2) BLEED FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-C-00017605.0005001 / 21 MAR 16

ENG BLEED (AFFECTED, IF NOT AUTOMATICALLY CLOSED).....OFF

- L2** When the ENG BLEED pb-sw is ON, the FAULT light remains on.  
 When the ENG BLEED pb-sw is OFF, the FAULT light goes off when the failure (overheat or overpressure) disappears.

**L1** ● If wing anti-ice is off and both packs are on:  
 PACK FLOW.....LO

The PACK FLOW selector must be set to LO, due to precooler performance.

● If wing anti-ice is on and both packs are on:  
 PACK (AFFECTED).....OFF

- L2** One pack must be closed when the flight crew uses wing anti-ice because of precooler performance.

**L1** X BLEED.....OPEN

Ident.: PRO-ABN-AIR-C-00011092.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

ONE PACK ONLY IF WAI ON

ENG 1(2) BLEED  
 PACK 1(2) (If closed)

**AIR ENG 1(2) BLEED LO TEMP**  
(OPPOSITE BLEED AVAILABLE)

Applicable to: ALL


Ident.: PRO-ABN-AIR-M-00017379.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the associated engine bleed supplies bleed air at a temperature below 150 °C in flight and the WING A-ICE pb-sw is set to ON.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-M-00017560.0001001 / 21 MAR 16

A/THR..... OFF  
THR LEVER (AFFECTED ENGINE)..... ADVANCE

- L2 The thrust lever of the affected engine must be advanced, with the autothrust OFF.  
Low bleed temperature may be due to low outside air temperature. Therefore, increasing engine thrust may increase bleed temperature and clear the ECAM caution.

- L1 ● **IF UNSUCCESSFUL:**  
X BLEED..... OPEN  
ENG BLEED (AFFECTED)..... OFF  
ASSOCIATED PACK (IF OPPOSITE PACK ON)..... OFF

- L2 One pack must be closed, when the flight crew uses wing anti-ice, due to precooler performance.

*Continued on the following page*

**AIR ENG 1(2) BLEED LO TEMP (Cont'd)**  
 (OPPOSITE BLEED AVAILABLE)

Ident.: PRO-ABN-AIR-M-00011115.0001001 / 21 AUG 15

<b>STATUS</b>	<p style="text-align: center; margin: 0;"><b>INOP SYS</b></p> <p style="margin: 5px 0;">ENG 1(2) BLEED          PACK 1(2) (If selected OFF)</p>
---------------	---

**AIR ENG 1(2) BLEED LO TEMP**  
 (OPPOSITE BLEED NOT AVAILABLE)

**Applicable to: ALL**


Ident.: PRO-ABN-AIR-N-00018208.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the associated engine bleed supplies bleed air at a temperature below 150 °C in flight and the WING A-ICE pb-sw is set to ON.

Flight Phase Inhibition:



*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AIR

**AIR ENG 1(2) BLEED LO TEMP (Cont'd)**  
**(OPPOSITE BLEED NOT AVAILABLE)**

Ident.: PRO-ABN-AIR-N-00017561.0001001 / 21 MAR 16

A/THR..... OFF  
THR LEVER (AFFECTED ENGINE).....ADVANCE

**[L2]** *The thrust lever of the affected engine must be advanced, with the autothrust OFF.  
Low bleed temperature may be due to low outside air temperature. Therefore, increasing engine thrust may increase bleed temperature and clear the ECAM caution.*

**[L1]** ● **IF UNSUCCESSFUL:**  
WING A. ICE..... OFF  
AVOID ICING CONDITIONS

Ident.: PRO-ABN-AIR-N-00011117.0003001 / 17 MAR 17

**STATUS**

AVOID ICING CONDITIONS

**INOP SYS**

● **IF SEVERE ICE ACCRETION:**  
MIN SPD.....VLS +10 / G DOT  
MANEUVER WITH CARE  
LDG DIST PROC.....APPLY

WING A. ICE

**AIR ENG 1+2 BLEED LO TEMP**

Applicable to: ALL


Ident.: PRO-ABN-AIR-O-00017381.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both engine bleeds supply bleed air at a temperature below 150 °C in flight and the WING A-ICE pb-sw is set to ON.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-O-00011118.0001001 / 05 AUG 10

A/THR .....OFF  
THR LEVERS.....ADVANCE

**L2** The thrust lever of the affected engine must be advanced, with the autothrust OFF.  
Low bleed temperature may be due to low outside air temperature. Therefore, increasing engine thrust may increase bleed temperature and clear the ECAM caution.

**L1** ● **IF UNSUCCESSFUL:**  
WING A. ICE.....OFF  
AVOID ICING CONDITIONS

Continued on the following page

**AIR ENG 1+2 BLEED LO TEMP (Cont'd)**

Ident.: PRO-ABN-AIR-O-00011119.0003001 / 17 MAR 17

**STATUS**

**AVOID ICING CONDITIONS**

**INOP SYS**

● **IF SEVERE ICE ACCRETION:**

WING A. ICE

MIN SPD.....VLS +10 / G DOT

MANEUVER WITH CARE

LDG DIST PROC.....APPLY

**AIR ENG 1(2) BLEED HI TEMP**

Applicable to: ALL


Ident.: PRO-ABN-AIR-P-00017391.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the precooler outlet temperature is above 240 °C.

Flight Phase Inhibition:



Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AIR

**AIR ENG 1(2) BLEED HI TEMP (Cont'd)**

Ident.: PRO-ABN-AIR-P-00014306.0001001 / 21 AUG 15

■ **If wing anti-ice off:**

PACK 2 (1)..... OFF

■ **If wing anti-ice on and opposite pack off:**

*Note: If Wing Anti-Ice is required (icing conditions) while operating with one PACK, consider switching OFF the remaining pack, if aircraft's altitude permits.*

PACK 1 (2) OR WAI.....OFF

■ **If wing anti-ice on and affected pack off:**

PACK 2 (1) OR WAI.....OFF

Ident.: PRO-ABN-AIR-P-00014307.0005001 / 17 MAR 17

L12

**STATUS**

**AVOID ICING CONDITIONS**

● **IF SEVERE ICE ACCRETION:**

MIN SPD..... VLS+10/G DOT

*Note: In the case of severe ice accretion, with wing anti-ice failed, the Angle-of-Attack (AOA) protections remain efficient.*

**MANEUVER WITH CARE**

LDG DIST PROC.....APPLY

**INOP SYS**

WING A. ICE

**AIR ENG 1(2) BLEED NOT CLSD**

Applicable to: ALL


Ident.: PRO-ABN-AIR-A-00017372.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the engine bleed valve fails to close:
  - During engine start or when APU BLEED pb-sw is set to ON
  - At engine shutdown or when APU BLEED pb-sw is set to OFF with engine not running.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-A-00017562.0001001 / 21 MAR 16

**ENG BLEED (AFFECTED)..... OFF**

- [L2] Note: The warning may be triggered due to residual pressure between the HP or IP valves and the engine bleed valve after:
  - Engine shutdown, or
  - APU BLEED pb-sw is selected OFF with engine not running.

Ident.: PRO-ABN-AIR-A-00011087.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

**ONE PACK ONLY IF WAI ON**

**ENG 1(2) BLEED**



**AIR ENG 1(2) HP VALVE FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AIR-H-00017384.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the HP valve is abnormally closed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-H-00011103.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-AIR-H-00011104.0001001 / 05 AUG 10

**STATUS**

AIR PRESS LOW AT IDLE

**AIR ENG 1(2) LEAK DET FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AIR-I-00017389.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the pylon bleed leak detection loop is inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-I-00011105.0004001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-AIR-I-00011106.0004001 / 17 MAR 11

**STATUS**

**INOP SYS**

ENG 1(2) LK DET

**AIR FWD(AFT) CRG VENT FAULT** ⚠

Applicable to: ALL

Ident.: PRO-ABN-AIR-AE-00017337.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the forward(aft) cargo ventilation fan is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AE-00017933.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-AIR-AE-00017934.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

FWD(AFT) CRG HEAT ⚠  
 FWD(AFT) CRG VENT

**AIR L(R) WING OR ENG 1(2) BLEED LEAK**

Applicable to: ALL


Ident.: PRO-ABN-AIR-D-00017370.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] The **AIR L(R) WING LEAK** alert triggers when both wing bleed leak detection loops detect a temperature above 124 °C .
- The **AIR ENG 1(2) BLEED LEAK** alert triggers when the pylon bleed leak detection loop detects a temperature above 204 °C and engine 1(2) is running.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-D-00017563.0001001 / 21 MAR 16

**ENG BLEED (AFFECTED, IF NOT AUTOMATICALLY CLOSED).....OFF**

- [L2] *When the ENG BLEED pb-sw is ON, the FAULT light remains on.*
- When the ENG BLEED pb-sw is OFF, the FAULT light goes off when the overheat disappears.*

- [L1] ● **If left wing or engine 1 bleed leak:**
- APU BLEED (IF NOT CLOSED)..... OFF**
- X BLEED (IF NOT CLOSED)..... SHUT**
- WING ANTI-ICE..... OFF**
- AVOID ICING CONDITIONS**

*Continued on the following page*

**AIR L(R) WING OR ENG 1(2) BLEED LEAK (Cont'd)**

Ident.: PRO-ABN-AIR-D-00011096.0003001 / 17 MAR 17

STATUS	
<p><b>AVOID ICING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>● <b>IF SEVERE ICE ACCRETION:</b></li> <li>MIN SPD.....VLS +10 / G DOT</li> <li>MANEUVER WITH CARE</li> <li>LDG DIST PROC.....APPLY</li> </ul>	<p><b><u>INOP SYS</u></b></p> <p>WING A.ICE        ENG 1(2) BLEED        PACK 1(2)</p>

**AIR L(R) WNG LEAK DET FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AIR-J-00017387.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when both wing bleed leak detection loops are inoperative in one wing.

Flight Phase Inhibition:

Ident.: PRO-ABN-AIR-J-00011107.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*

**AIR L(R) WNG LEAK DET FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-J-00011108.0005001 / 17 MAR 11

**STATUS**

**INOP SYS**

L(R) WNG LK DET

**AIR PACK 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AIR-AF-00017290.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

[L2]

This alert triggers when:

- The position of the pack flow control valve disagrees with the commanded position, or
- The pack valve is closed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AF-00010712.0001001 / 05 AUG 10

**PACK (AFFECTED)..... OFF**

*Continued on the following page*

**AIR PACK 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-AF-00010713.0002001 / 16 NOV 11

**STATUS**

- **If ACSC 1 failed:**  
CKPT AT FIXED TEMP
- **If ACSC 2 failed:**  
CAB AT FIXED TEMP

**INOP SYS**

PACK 1(2)  
COND CTL 1(2)  
FWD CRG HEAT  (If ACSC  
1 failed)

**AIR PACK 1+2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AIR-AG-00017292.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when both ACSCs are failed.

Flight Phase Inhibition:




Continued on the following page

**AIR PACK 1+2 FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-AG-00017935.0001001 / 21 MAR 16

**PACK (AFFECTED)..... OFF**

**[L2]** The fault light goes off, when the failure disappears.

**Note:** The rate at which the cabin altitude increases may be minimized by closing the FWD CARGO ISOL VALVE  , if the cargo freight permits.

**[L1]** **DESCENT TO FL 100/MEA.**

**[L2]** Descend to FL 100, or MEA, whichever is higher.

**[L1]** ● **WHEN DIFF PR < 1 PSI AND FL BELOW 100:**

RAM AIR.....ON

MAX FL..... 100/MEA

● If FAULT was due to an overheat:

\_\_\_\_\_ ASSOCIATED PROCEDURES \_\_\_\_\_

**AIR PACK 1 (2) OVHT**

● **WHEN PACK OVHT OUT:**

PACK (AFFECTED).....ON

Ident.: PRO-ABN-AIR-AG-00017936.0002001 / 17 MAR 17

**STATUS**

**INOP SYS**

● **If packs not recovered:**

MAX FL..... 100/MEA

CKPT AT FIXED TEMP

CAB AT FIXED TEMP

● **If FAULT was due to an overheat:**

● **WHEN PACK OVHT OUT:**

PACK (AFFECTED).....ON

PACK 1 + 2  
COND CTL 1  
COND CTL 2  
FWD CRG HEAT 



**AIR PACK 1(2) OFF**

Applicable to: ALL

Ident.: PRO-ABN-AIR-AJ-00017294.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the PACK 1(2) pb-sw is set to OFF and no failure is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AJ-00017941.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-AIR-AJ-00010715.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

PACK 1(2)

**AIR PACK 1(2) OVHT**

Applicable to: ALL


Ident.: PRO-ABN-AIR-AK-00017284.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the pack compressor outlet temperature rises above 260 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AK-00017942.0001001 / 21 MAR 16

**PACK (AFFECTED)**..... OFF

**L2** High flow is automatically selected on the remaining pack.  
Fault light goes off, when the overheat disappears.

**L1** ● **WHEN PACK OVHT OUT:**  
**PACK (AFFECTED)**..... ON

Ident.: PRO-ABN-AIR-AK-00010711.0001001 / 10 JAN 11

**STATUS**

● **WHEN PACK OVHT OUT:**  
**PACK (AFFECTED)**..... ON

**INOP SYS**

PACK 1(2)<sup>(1)</sup>

<sup>(1)</sup> (If pack not recovered)

**AIR PACK 1(2) REGUL FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AIR-AL-00017298.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the temperature regulation performance is degraded.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-AL-00018089.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-AIR-AL-00010719.0003001 / 10 JAN 11

**STATUS**

**INOP SYS**

PACK 1(2) REGUL <sup>(1)</sup>  
HOT AIR <sup>(2)</sup>

<sup>(1)</sup> (In case of By Pass Valve or RAM Air Inlet failure)

<sup>(2)</sup> (In case of Flow Control Valve in backup mode)

**AIR X BLEED FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AIR-E-00017383.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the crossbleed valve position disagrees with the X-BLEED selector position.

Flight Phase Inhibition:



Ident.: PRO-ABN-AIR-E-00011097.0001001 / 05 AUG 10

X BLEED.....MAN CTL

- [L2] Select OPEN, when the APU BLEED pb-sw is ON, or for engine start, or when WING ANTI-ICE pb-sw is ON and one bleed is inoperative.  
 Select SHUT in other cases.

- [L1] ● If manual opening inoperative, and only one bleed available:  
 WING ANTI ICE.....OFF  
 AVOID ICING CONDITIONS

Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AIR

**AIR X BLEED FAULT (Cont'd)**

Ident.: PRO-ABN-AIR-E-00017612.0002001 / 21 MAR 16

**STATUS**

- If manual opening inoperative, and only one bleed available:  
 AVOID ICING CONDITIONS
  - IF SEVERE ICE ACCRETION:  
 MIN SPD..... VLS +10 / G DOT  
 MANEUVER WITH CARE  
 LDG DIST PROC.....APPLY
- X BLEED MAN CTL

**INOP SYS**

WING A.ICE  
 X BLEED



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AIR

Intentionally left blank

**APU AUTO (EMER) SHUT DOWN**

Applicable to: ALL

Ident.: PRO-ABN-APU-A-00016876.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:


L2

The APU AUTO SHUT DOWN alert triggers when an automatic shutdown of the APU occurs for a reason other than a fire.

The APU EMER SHUT DOWN triggers when:

- The APU SHUT OFF sw on the External Power Panel is pushed or,
- The APU FIRE pb is pushed or,
- An APU fire on ground is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-APU-A-00018193.0001001 / 21 MAR 16

MASTER SW.....OFF

Ident.: PRO-ABN-APU-A-00010106.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

APU

**APU FIRE DET FAULT**

Applicable to: ALL

Ident.: PRO-ABN-APU-D-00021359.0001001 / 17 MAR 17

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- Both loops are inoperative, or
- Fire Detector Unit is inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-APU-D-00021360.0001001 / 17 MAR 17

Crew awareness.

Ident.: PRO-ABN-APU-D-00021361.0001001 / 17 MAR 17

**STATUS**

**INOP SYS**


APU FIRE DET



**APU FIRE LOOP A(B) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-APU-B-00021362.0001001 / 17 MAR 17



Ident.: PRO-ABN-APU-B-00021363.0001001 / 17 MAR 17

**L2** Crew awareness.

Ident.: PRO-ABN-APU-B-00021364.0001001 / 17 MAR 17

**STATUS**

**INOP SYS**

APU LOOP A(B)

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

APU

Intentionally left blank

**APU FIRE**

Applicable to: ALL

Ident.: PRO-ABN-APUF-C-00017402.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- Fire is detected by both loops, or
- Fire is detected by one loop when the other loop is faulty, or
- A rupture occurs in both loops within 5 s.

Flight Phase Inhibition:



Ident.: PRO-ABN-APUF-C-00017925.0001001 / 21 MAR 16

**LAND ASAP**

APU FIRE P/B.....PUSH

L2

APU LP valve closes.

Aural warning stops.

APU FIRE pb-sw remains on, as long as a fire is detected.

L1

AGENT AFTER 10 S..... DISCH

L2

The 10 s delay allows the airflow to decrease, which increases the effect of the agent.

Automatic countdown on the ECAM.

L1

MASTER SW.....OFF

L2

Do not attempt to restart the APU.

Continued on the following page



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**

**ABNORMAL AND EMERGENCY PROCEDURES**

APU FIRE

**APU FIRE (Cont'd)**

Ident.: PRO-ABN-APUF-C-00012211.0001001 / 16 NOV 11

**STATUS**

**INOP SYS**

APU

**AUTO FLT A/THR LIMITED**

Applicable to: ALL

Ident.: PRO-ABN-AUTO\_FLT-S-00016943.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when A/THR is active but thrust levers are set below CL detent (2 engines), or MCT detent (1 engine).

This caution is repeated every 5 s as long as the thrust lever are not moved.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-S-00018689.0001001 / 21 MAR 16

**THR LEVERS.....MOVE**

L2

*Thrust lever must be set in the relevant detent.*

**AUTO FLT A/THR OFF**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-L-00016941.0002001 / 20 APR 17

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when this warning is displayed only for involuntary disconnection. The amber **A/THR OFF** and **ENG THRUST LOCKED** messages are displayed in the left lower part of ECAM upper DU.  
 For voluntary disconnection, an amber **A/THR OFF** message is displayed on the right lower part of ECAM upper DU.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-L-00018694.0002001 / 21 MAR 16

- L2 If the A/THR is failed, the flight crew may recover it by engaging the other AP , and then trying to re-engage the A/THR.

Note: If the A/THR is recovered with AP 2, A/THR will be lost again at AP 2 disengagement.

L1 **THR LEVERS**.....**MOVE**

- L2 If the thrust levers are not moved within 5 s, the “**ENG THRUST LOCKED**” warning is displayed (Refer to PRO-ABN-ENG ENG THRUST LOCKED).

*Continued on the following page*

**AUTO FLT A/THR OFF (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-L-00010469.0001001 / 05 AUG 10

STATUS	
<p style="color: green; font-weight: bold;">CAT 2 ONLY</p>	<p style="text-align: center; font-weight: bold; border-bottom: 1px solid black;"><u>INOP SYS</u></p> <p style="color: orange; font-weight: bold;">A/THR CAT 3</p>

**AUTO FLT AP OFF**

Applicable to: ALL

Ident.: PRO-ABN-AUTO\_FLT-K-00016947.0001001 / 21 MAR 16

ANNUNCIATIONS

Triggering Conditions:

L2 This alert triggers when this warning is displayed only for involuntary disconnection. For voluntary disconnection, a red **AP OFF** message is displayed in the right lower part of ECAM upper DU.

Flight Phase Inhibition:

ELEC PWR	1ST ENG STARTED	1ST ENG TO PWR	80 kt	LIFTOFF	1500 ft	800 ft	TOUCHDOWN	80 kt	2ND ENG SHUTDN	5MN AFTER
1	2	3	4	5	6	7	8	9	10	

Ident.: PRO-ABN-AUTO\_FLT-K-00018695.0001001 / 21 MAR 16

Crew awareness.

*Continued on the following page*

**AUTO FLT AP OFF (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-K-00017453.0002001 / 21 MAR 16

**STATUS**

**INOP SYS**

AP (Affected)  
CAT 2 <sup>(1)</sup>  
GLS AUTOLAND  <sup>(1)</sup>

<sup>(1)</sup> (If both AP lost)


**AUTO FLT FAC 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-G-00016911.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

 This alert triggers when one FAC computer is failed.

Flight Phase Inhibition:



*Continued on the following page*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AUTO FLT

**AUTO FLT FAC 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-G-00010457.0001001 / 05 AUG 10

FAC (AFFECTED)..... OFF THEN ON

● **IF UNSUCCESSFUL:**

FAC (AFFECTED)..... OFF

**L2** All functions are performed by the remaining FAC.

Ident.: PRO-ABN-AUTO\_FLT-G-00017506.0001001 / 21 MAR 16

**L12**

**STATUS**

**INOP SYS**

**BOTH PFD ON SAME FAC**

See <sup>(1)</sup>

**CAT 3 SINGLE ONLY**

CAT 3 DUAL  
 FAC 1(2)

<sup>(1)</sup> Characteristic speeds, displayed on the two PFD s, are computed by the same FAC.

**AUTO FLT FAC 1 + 2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-H-00016926.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the two FAC computers are failed.

Flight Phase Inhibition:



*Continued on the following page*

**AUTO FLT FAC 1 + 2 FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-H-00017454.0002001 / 22 MAR 17

**RUD WITH CARE ABV 160 KT**

**L2** Depending on when the failure occurs, the rudder travel limiter system may not be in the correct position for the flight speed. Therefore, to prevent damage to the aircraft structure, use the rudder with care, when the speed is above 160 kt.

At slats' extension, full rudder travel authority is recovered.

**L1** FAC 1 ..... OFF THEN ON  
 FAC 2..... OFF THEN ON

● **IF UNSUCCESSFUL:**

FAC 1 + 2..... OFF

**L2** With FAC 1 + 2 inoperative, the rudder travel limit system, rudder trim control, yaw damper and PFD characteristic speeds are lost.

**L12**

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

F/CTL normal laws are lost. All protections, except maneuver protections, are lost.

**L1** MAX SPEED..... 320 KT

**L2** Speed is limited, due to the loss of high-speed protections.

Continued on the following page

**AUTO FLT FAC 1 + 2 FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-H-00017456.0006001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT  
 RUD WITH CARE ABV 160 KT

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when  
 CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3..... ON




*Displayed, when flaps in CONF 3.*


APPR SPD..... VREF + 10 KT  
 LDG DIST PROC..... APPLY

ALTN LAW : PROT LOST  
 WHEN L/G DN : DIRECT LAW

See <sup>(2)</sup>

**INOP SYS**

- WINDSHEAR DET <sup>(1)</sup>
- REAC W/S DET <sup>(1)</sup>
- F/CTL PROT
- FAC 1 + 2
- AP 1 + 2
- A/THR
- CAT 2
- GLS AUTOLAND 
- STEEP APPR 
- ROW/ROP 

<sup>(1)</sup> (The REAC W/S DET inop sys replaces the WINDSHEAR DET inop sys on aircraft equipped with the PWS  )

<sup>(2)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).

**AUTO FLT FCU 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-AUTO\_FLT-J-00016923.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when only one FCU channel remain operative.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-J-00010464.0001001 / 05 AUG 10

BARO REF..... X CHECK

L2

One FCU channel is lost:

Therefore, crosscheck the barometric reference settings on the FCU and PFDs.

Ident.: PRO-ABN-AUTO\_FLT-J-00010465.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

FCU 1(2)

**AUTO FLT FCU 1 + 2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-I-00016946.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the FCU is completely loss.

Flight Phase Inhibition:



*Continued on the following page*

**AUTO FLT FCU 1 + 2 FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-I-00017463.0001001 / 21 MAR 16

**PFD BARO REF: STD ONLY**





**L2** With both FCU channels failed, the barometer reference automatically goes to 1 013 hPa.

Use standby altimeter, and change this to the actual barometer setting.

Do not insert the MDA (MDH) value on the MCDU PERF APPR Page (because the PFD altitude is referenced to STD, and not to the correct barometric value).

The PM must then perform the standard callouts ("HUNDRED ABOVE" and "MINIMUM"), using the STBY altimeter.

In addition:

- All FCU controls are inoperative.
- A/THR, AP 1 + 2, and FD 1 + 2 are not available.  
 (Except in LAND or GO AROUND mode where only A/THR is lost).
- On PFD:
  - Altitude alert is inoperative.
  - ILS/GLS  /MLS  deviation scales are displayed.
  - Flight path vector is displayed.
  - Mach indication is inoperative.
  - FMA is lost except in LAND or GA mode.
- On ND:
  - ROSE NAV mode with map (80 NM range) is displayed.
  - VOR /ADF needles:
    - Needle 1 is related to VOR1 only.
    - Needle 2 is related to ADF 2 only (ADF 1 if ADF2 not installed).
    - (VOR selection on DDRMI  is not affected)
    - (ADF selection on DDRMI  (if available) is not affected).
  - The weather radar image may be lost. If the image remains displayed it must be disregarded.  
 In all cases, red "WXR RNG" message is displayed.

Continued on the following page

**AUTO FLT FCU 1 + 2 FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-I-00017512.0002001 / 21 MAR 16

**STATUS**

**INOP SYS**

PFD BARO REF : STD ONLY

- If in LAND or GA:  
CAT 2 ONLY

FCU 1 + 2  
AP 1 + 2 <sup>(1)</sup>  
A/THR  
CAT 3 <sup>(2)</sup>  
CAT 2 <sup>(1)</sup>  
GPWS TERR

<sup>(1)</sup> (If not LAND or GA)

<sup>(2)</sup> (If in LAND or GA mode)

**AUTO FLT REAC W/S DET FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-N-00017473.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- 2 This alert triggers when the reactive windshear function is lost.

Flight Phase Inhibition:



*Continued on the following page*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AUTO FLT

**AUTO FLT REAC W/S DET FAULT (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-N-00017479.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-AUTO\_FLT-N-00017480.0001001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

REAC W/S DET

*Note:* On ground, this warning may appear spuriously. This warning is cancelled by resetting both FACs, one after the other.

- FAC 1: Pull then push AUTO FLT/FAC 1/26VAC and 28VDC circuit breakers BO3 and B04 on 49VU.
- FAC 2: Pull then push AUTO FLT/FAC 2/26VAC and 28VDC circuit breakers M18 and M19 on 121VU.

**AUTO FLT RUD TRIM 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-C-00016921.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when one rudder trim actuator is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-C-00010449.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-AUTO\_FLT-C-00017513.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAT 3 SINGLE ONLY

CAT 3 DUAL  
RUD TRIM 1(2)

**AUTO FLT RUD TRIM SYS**

Applicable to: ALL

Ident.: PRO-ABN-AUTO\_FLT-D-00016928.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the rudder trim system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-D-00010451.0002001 / 05 AUG 10

FAC 1..... OFF THEN ON  
 FAC 2..... OFF THEN ON

Ident.: PRO-ABN-AUTO\_FLT-D-00017464.0002001 / 21 MAR 16

**STATUS**

**INOP SYS**

- RUD TRIM
- AP 1 + 2
- CAT 2
- GLS AUTOLAND

**AUTO FLT RUD TRV LIM 1(2)**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-E-00016922.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when one rudder travel limitation actuator is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-E-00010453.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-AUTO\_FLT-E-00010454.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

RUD TRV LIM 1(2)

**AUTO FLT RUD TRV LIM SYS**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-F-00016929.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the rudder travel limitation system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-F-00017465.0003001 / 22 MAR 17

**RUD WITH CARE ABV 160 KT**

**L2** Depending on when the failure occurs, the rudder travel limiter system may not be in the correct position for the flight speed. Therefore, to prevent damage to the aircraft structure, use the rudder with care, when the speed is greater than 160 kt.  
At slats' extension, full rudder travel authority can be recovered.

**L1** FAC 1..... OFF THEN ON  
FAC 2..... OFF THEN ON

- If TLU (rudder or pedals) remains locked at high speed after slat extension:  
MAX X WIND FOR LDG 15 KT  
AUTO BRK.....DO NOT USE

**L2** Do not use the autobrake, so as not to delay the application of differential braking at landing roll.

**L1** ● AT LDG ROLL:  
DIFF BRAKING..... AS RQRD

Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AUTO FLT

**AUTO FLT RUD TRV LIM SYS (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-F-00017467.0003001 / 22 MAR 17

L12

**STATUS**

**RUD WITH CARE ABV 160 KT**

**INOP SYS**

- If TLU (rudder or pedals) remains locked at high speed after slat extension:

RUD TRV LIM

MAX X WIND FOR LDG 15 KT

AUTO BRK..... DO NOT USE

*Do not use the autobrake, so as not to delay the application of differential braking at landing roll.*

- AT LDG ROLL:

DIFF BRAKING..... AS RQRD

**CAT 3 SINGLE ONLY**

Note: An autoland must not be performed with a crosswind greater than 12 kt.

**AUTO FLT YAW DAMPER 1(2)**

Applicable to: ALL

Ident.: PRO-ABN-AUTO\_FLT-A-00016912.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one yaw damper actuator is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-A-00010444.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-AUTO\_FLT-A-00017515.0001001 / 21 MAR 16

**STATUS**

CAT 3 SINGLE ONLY

**INOP SYS**

CAT 3 DUAL  
 YAW DAMPER 1(2)

**AUTO FLT YAW DAMPER SYS**

Applicable to: ALL


Ident.: PRO-ABN-AUTO\_FLT-B-00016927.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the yaw damper system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-AUTO\_FLT-B-00017469.0002001 / 22 MAR 17

**L2** Loss of yaw dampers 1 + 2.

**L1** FAC 1..... OFF THEN ON  
FAC 2..... OFF THEN ON

● If fault remains:

**L12** \_\_\_\_\_ **ASSOCIATED PROCEDURES** \_\_\_\_\_

**F/CTL ALTN LAW**  
(PROT LOST)

*F/CTL normal laws are lost. All protections, except maneuver protections, are lost.*

**MAX SPEED**..... **320 KT**

*Continued on the following page*



**AUTO FLT YAW DAMPER SYS (Cont'd)**

Ident.: PRO-ABN-AUTO\_FLT-B-00017470.0003001 / 22 MAR 17

L12

**STATUS**

**MAX SPEED..... 320 KT**

*Speed is limited, due to the loss of high-speed protections.*

**APPR PROC**

**FOR LDG..... USE FLAP 3**

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

**GPWS LDG FLAP 3..... ON**

*Will be displayed, when flaps in CONF 3.*

**APPR SPD..... VREF + 10 KT**

**LDG DIST PROC..... APPLY**

**ALTN LAW : PROT LOST**  
**WHEN L/G DN : DIRECT LAW**

*See <sup>(1)</sup>*

**INOP SYS**

F/CTL PROT  
YAW DAMPER

AP 1 + 2

CAT 2

STEEP APPR 

GLS AUTOLAND 

<sup>(1)</sup> *At landing gear extension, control reverts to direct law in pitch, as well as in roll. Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AUTO FLT

Intentionally left blank

**AVIONICS SMOKE**

Applicable to: ALL


Ident.: PRO-ABN-AVNCS-M-00017405.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when smoke in the ventilation extraction duct is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-AVNCS-M-00014922.0001001 / 22 MAR 17

**L2** The description of this procedure is included in the SMOKE/FUMES/AVNCS SMOKE procedure  
 (Refer to procedure)

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

AVIONICS SMOKE

Intentionally left blank

**BLEED MONITORING FAULT**

Applicable to: ALL


Ident.: PRO-ABN-BLEED-L-00017385.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both BMC are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-BLEED-L-00011111.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-BLEED-L-00011112.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

BMC 1 + 2

**BLEED MONIT SYS 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-BLEED-K-00017388.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the BMC 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-BLEED-K-00011109.0004001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-BLEED-K-00011110.0004001 / 17 MAR 11

**STATUS**

**INOP SYS**

BMC 1(2)

**[MEM] LOSS OF BRAKING**

Ident.: PRO-ABN-BRAKES-00011315.0001001 / 17 MAR 17

Applicable to: ALL

● **IF NO BRAKING AVAILABLE:**

REV..... MAX

BRAKE PEDALS..... RELEASE

*Brake pedals should be released when the A/SKID & N/W STRG sw is switched OFF, since the pedal force or displacement produces more braking action in alternate mode than in normal mode.*

A/SKID OFF..... ORDER

L2 The PF orders the PM to set the A/SKID & N/W STRG sw to OFF.

L1 A/SKID & N/W STRG..... OFF

*Braking system reverts to alternate mode.*

BRAKE PEDALS.....PRESS

*Apply brake with care, since initial pedal force or displacement produces more braking action in alternate mode than in normal mode.*

MAX BRK PR.....1000 PSI

*Monitor brake pressure or BRAKES PRESS indicator. Limit brake pressure to approximately 1 000 PSI and, at low ground speed, adjust brake pressure as required.*

● **If STILL NO BRAKING:**

PARKING BRAKE.....SHORT AND SUCCESSIVE APPLICATIONS

*Use short successive parking brake applications to stop the aircraft. Brake onset asymmetry may be felt at each parking brake application. If possible, delay the use of the parking brake until low speed, to reduce the risk of tire burst and lateral control difficulties.*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**BRAKES**

**[QRH] ASYMMETRIC BRAKING**

Ident.: PRO-ABN-BRAKES-00011331.0001001 / 17 MAR 17

Applicable to: ALL

Apply this procedure when all brakes of one gear are released.

AVOID XWIND > 10 KT FROM SIDE OF AVAILABLE BRAKE

APPLY BRAKE PROGRESSIVELY ON AVAILABLE SIDE

USE RUDDER TO COUNTER LATERAL DEVIATION

● **If reverser inoperative on same side as inoperative brakes:** DO NOT USE REVERSERS

LDG DIST PROC.....APPLY

**[QRH] RESIDUAL BRAKING**

Ident.: PRO-ABN-BRAKES-00011318.0001001 / 17 MAR 17

Applicable to: ALL

● **In flight:**

BRAKE PEDALS.....PRESS SEVERAL TIMES

*Press the brake pedals several times. This could zero a residual pressure on the alternate system.*

● **If residual pressure remains:**

A/SKID & N/W STRG sel.....KEEP ON

● **For landing:**

AUTO/BRK..... MED

*Using MED mode gives immediate priority to normal braking upon landing gear touchdown, which cancels residual alternate pressure.*

● **If autobrake not available:**

APPLY BRAKING JUST AFTER TOUCHDOWN

POSSIBLE BRAKING ASYMMETRY

Note: *If tire damage is suspected after landing, Refer to LIM-LG Taxi with Deflated or Damaged Tires.*



**BRAKES A/SKID N/W S FAULT OR ANTI SKID N/W S OFF**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-J-00017807.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- There is a loss of normal brake system associated with Y HYD SYS LO PRESS, or
- Both BSCU channels are failed, or
- The A/SKID & N/W STRG sw is set to OFF.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-J-00018571.0001001 / 21 MAR 16

**MAX BRK PR..... 1000 PSI**

L2 Monitor brake pressure on the BRAKES PRESS indicator. Limit brake pressure to approximately 1 000 PSI and, at low ground speed, adjust brake pressure as required. Avoid landing on an icy runway.

Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**  
 BRAKES

**BRAKES A/SKID N/WS FAULT OR ANTI SKID N/WS OFF (Cont'd)**

Ident.: PRO-ABN-BRAKES-J-00018670.0003001 / 21 MAR 16

L12

**STATUS**

MAX BRK PR..... 1000 PSI

LDG DIST PROC..... APPLY

- **If Y SYS LO PR:**  
 BRK Y ACCU PR ONLY  
 CAT 3 SINGLE ONLY

See <sup>(1)</sup>

**INOP SYS**

- CAT 3 DUAL
- ANTI SKID
- N/W STRG
- NORM BRK
- AUTO BRK

<sup>(1)</sup> Note: Automatic rollout is not permitted as specified in QRH (Refer to QRH/OPS Required Equipment for CAT2 and CAT3).

**BRAKES ALTN BRK FAULT**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-R-00017816.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the alternate braking function is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-R-00018357.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-BRAKES-R-00011328.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

ALTN BRK

**BRAKES ALTN L(R) RELEASED**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-S-00017817.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the brakes of one gear is released. It is detected when the landing gear is downlocked, at least one engine is running, and alternate braking is active.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-S-00011329.0001001 / 05 AUG 10

- [L2] As long as the normal braking system is available, braking is normal. In alternate braking mode, braking of all wheels on one gear is lost.

- [L1] ● **If normal braking is lost:**  
ASYM BRK PROC.....APPLY

Ident.: PRO-ABN-BRAKES-S-00011330.0001001 / 11 MAY 12

**STATUS**

- **If normal braking is lost:**  
LDG DIST PROC.....APPLY

**INOP SYS**

ALTN L(R) BRK

**BRAKES AUTO BRK FAULT**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-N-00017806.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the autobrake is failed, after being armed.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-N-00018672.0004001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-BRAKES-N-00011314.0004001 / 29 MAR 12

**STATUS**

**INOP SYS**

AUTO BRK

**BRAKES BRK Y ACCU LO PR**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-T-00017820.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the yellow accumulator is in low pressure.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-T-00011332.0002001 / 05 AUG 10

**L2** The yellow electrical pump can be used to pressurize the accumulator. If the accumulator pressure is still low, chocks are required before Engine 1 shut down. This message is replaced on ground by **BRAKES PARK BRK LO PR** if parking brake is on and yellow hydraulic system pressure is low.

- L1**
- **On ground:**
    - **BEFORE ENG SHUT DOWN:**  
**CHOCKS CONSIDER**

Ident.: PRO-ABN-BRAKES-T-00011333.0001001 / 05 AUG 10

**STATUS**

- **If Y SYS LO PR**  
**NORM BRK ONLY**

**INOP SYS**  
**BRK Y ACCU**

**BRAKES HOT**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-M-00017786.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one brake temperature is above 300 °C. The alert disappears when the highest brake temperature is below 290 °C.

Flight Phase Inhibition:



*Continued on the following page*

**BRAKES HOT (Cont'd)**

Ident.: PRO-ABN-BRAKES-M-00018675.0008001 / 21 MAR 17

■ **On ground:**


**PARK BRK: PREFER CHOCKS**

[L2] If the **BRAKES HOT** alert is still on when the aircraft is parked, the flight crew should not set the **PARKING BRK ON**.

[L1] **BRK FAN**  ..... **ON**

[L2] **Note:** Before they select the brake fans  at the gate, the flight crew should first warn the ground personnel in order to avoid blowing carbon brake dust on them.

[L1] **DELAY T.O. FOR COOL**

- [L2] - Delay takeoff, until the brake temperature is below 300 °C with the brake fans **OFF**, and 150 °C with the brake fans  **ON**
- Refer to PRO-NOR-SOP-21 After Landing - Brake Temperature for brake temperature limitations requiring maintenance actions.

[L1] ■ **In flight:**

● **IF PERF PERMITS:**

**MAX SPEED**.....250/.60  
**L/G**.....**DN FOR COOL**

[L2] If performance permits, the landing gear should be extended or, if already extended, it should remain so, to improve brake cooling.

[L1] ● **FOR L/G RETRACTION:**

**MAX SPEED**.....220/.54

[L2] Reduce speed for landing gear retraction, when the brake temperature is within limits.

*Continued on the following page*



**BRAKES HOT (Cont'd)**

Ident.: PRO-ABN-BRAKES-M-00011312.0001001 / 05 AUG 10

L12

**STATUS**

MAX SPEED..... 280/67

See <sup>(1)</sup>

<sup>(1)</sup> As long as the landing gear is extended, limit the speed to 280 kt/M 0.67.  
 For landing gear retraction when the brake temperature is within limits, reduce the speed to 220 kt.

**BRAKES NORM + ALTN FAULT**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-Q-00017819.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the normal and alternate braking functions are lost. The parking brake is still available.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-Q-00018358.0001001 / 21 MAR 16

**PARK BRK ONLY**

Continued on the following page

**BRAKES NORM + ALTN FAULT (Cont'd)**

Ident.: PRO-ABN-BRAKES-Q-00011325.0001001 / 11 MAY 12

**STATUS**

PARK BRK ONLY

LDG DIST PROC..... APPLY

CAT 2 ONLY

**INOP SYS**

- CAT 3
- ANTI SKID
- N/W STRG
- NORM BRK
- AUTO BRK
- ALTN BRK

**BRAKES NORM BRK FAULT**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-O-00017814.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**[L2]** This alert triggers when the normal braking function is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-O-00018679.0001001 / 21 MAR 16

Crew awareness.

*Continued on the following page*

**BRAKES NORM BRK FAULT (Cont'd)**

Ident.: PRO-ABN-BRAKES-O-00011321.0001001 / 11 MAY 12

<b>STATUS</b>	
<p>LDG DIST PROC..... APPLY</p> <p>ALTN Y BRK WITH A/SKID            CAT 2 ONLY</p>	<p><b><u>INOP SYS</u></b></p> <p>CAT 3            NORM BRK            AUTO BRK</p>

**BRAKES PARK BRK FAULT ⚠**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-X-00017823.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when a discrepancy between the position of the parking brake handle and the applied parking brake pressure is detected.

Flight Phase Inhibition:

*Continued on the following page*

**BRAKES PARK BRK FAULT ⚠ (Cont'd)**

Ident.: PRO-ABN-BRAKES-X-00018359.0002001 / 20 MAY 16

- **On ground:**
  - If **PARKING BRK** handle is **OFF** and parking brake pressure is still applied:  
**BRK PRESS STILL APPLIED**
  - If **PARKING BRK** handle is **ON** and no parking brake pressure is applied:  
**BRK PRESS RELEASED**  
**PARK BRK..... OFF**
- **BEFORE ENG SHUT DOWN:**  
**CHCKS..... CONSIDER**

**BRAKES PARK BRK LO PR**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-U-00017821.0003001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the pressure in the yellow accumulator and hydraulic system is low and the parking brake is on.

Flight Phase Inhibition:



*Continued on the following page*

**BRAKES PARK BRK LO PR (Cont'd)**

Ident.: PRO-ABN-BRAKES-U-00018572.0003001 / 21 MAR 16

**L2** Chocks are required before Engine 1 shut down.

- L1** ● **On ground:**
- **BEFORE ENG SHUT DOWN:**  
CHOCKS CONSIDER

Ident.: PRO-ABN-BRAKES-U-00011335.0003001 / 05 AUG 10

**STATUS**

**NORM BRK ONLY**

**INOP SYS**

**BRK Y ACCU**

**BRAKES PARK BRK ON**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-Y-00017815.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the parking brake is ON in flight.

Flight Phase Inhibition:



*Continued on the following page*

**BRAKES PARK BRK ON (Cont'd)**

Ident.: PRO-ABN-BRAKES-Y-00018360.0001001 / 21 MAR 16

PARK BRK..... OFF

**BRAKES RELEASED**

Applicable to: ALL


Ident.: PRO-ABN-BRAKES-P-00017813.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- This alert triggers when the brake of one wheel is released. It is detected when the landing gear is downlocked, at least one engine is running, and normal braking is active.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-P-00018663.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-BRAKES-P-00011323.0001001 / 11 MAY 12

**STATUS**

LDG DIST PROC..... APPLY

**INOP SYS**

AUTO BRK

**BRAKES SYS 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-BRAKES-L-00017812.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one BSCU channel is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-BRAKES-L-00011309.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-BRAKES-L-00011310.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

BRK SYS 1(2)

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**BRAKES**

Intentionally left blank



**BRAKES-N/W** MINOR FAULT

Applicable to: ALL

Ident.: PRO-ABN-NWS-W-00017730.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when a minor fault of the nose wheel steering system is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-NWS-W-00011326.0001001 / 25 FEB 14

Crew awareness.

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**BRAKES-N/WS**

Intentionally left blank

**[QRH] CABIN OVERPRESSURE**

Ident.: PRO-ABN-CAB\_PR-00010761.0001001 / 17 MAR 17

Applicable to: ALL

Apply the following procedure (not displayed on ECAM) in case of total loss of cabin pressure control leading to overpressure.

PACK 1 OR 2.....OFF  
 VENTILATION BLOWER..... OVRD  
 VENTILATION EXTRACT..... OVRD

*Cabin air is extracted overboard*

$\Delta P$ ..... FREQUENTLY MONITOR

● **If  $\Delta P > 9$  PSI:**

**LAND ASAP**

PACK 1..... OFF  
 PACK 2..... OFF

● **10 min before landing:**

PACK 1..... OFF  
 PACK 2..... OFF  
 VENTILATION BLOWER..... AUTO  
 VENTILATION EXTRACT..... AUTO

● **Before door opening: CHECK  $\Delta P$  ZERO**

**CAB PR EXCESS CAB ALT**

Applicable to: ALL


Ident.: PRO-ABN-CAB\_PR-T-00017316.0005001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when:
- In climb or descent, the cabin altitude is above the higher of:
    - 9 550 ft, or
    - 1 000 ft above the airfield pressure altitude.
  - In cruise, the cabin altitude is above 9 550 ft.

Flight Phase Inhibition:



*Continued on the following page*

**CAB PR EXCESS CAB ALT (Cont'd)**

Ident.: PRO-ABN-CAB\_PR-T-00018066.0004001 / 20 DEC 16

Rely on the CAB PR EXCESS CAB ALT warning even if not confirmed on the CAB PRESS SD page. The warning can be triggered by a cabin pressure sensor different from the one used to control the pressure and display the cabin altitude on the SD.

● **If above FL 100:**  
 CREW OXY MASK.....USE

■ **If below FL 160:**  
 DESCENT.....INITIATE  
 MAX FL.....100/MEA

■ **If above FL 160:**  
 SIGNS.....ON

**EMER DESCENT:**  
 DESCENT.....INITIATE

● **If A/THR is not active:**  
 THR LEVERS.....IDLE

L2 *If the A/THR is active, check A/THR is at IDLE on the ED.*

L1 SPD BRK.....FULL

L2 *Extension of speedbrakes will significantly increase VLS.  
 In order to avoid autopilot disconnection and automatic retraction of speedbrakes due to possible activation of angle of attack protection, allow the speed to increase before starting to use speedbrakes.*

L1 SPD.....MAX/APPROPRIATE

L2 *Descend at maximum appropriate speed. However, if structural damage is suspected use the flight controls with care and reduce speed as appropriate. The landing gear may be extended. In this case, speed must be reduced to VLO/VLE.*

L1 ENG MODE SEL.....IGN  
 ATC.....NOTIFY

L2 *Notify ATC of the nature of the emergency, and state intention. The flight crew can communicate with the ATC using voice, or CPDLC when the voice contact cannot be established or has a poor quality.  
 Squawk 7700 unless otherwise specified by ATC.*

L12 *Note: To save oxygen, set the oxygen diluter selector to N position.*

*Continued on the following page*

**CAB PR EXCESS CAB ALT (Cont'd)**

*With the oxygen diluter left to 100 %, oxygen quantity may not be sufficient for the entire descent profile.*

*Ensure that the flight crew can communicate wearing oxygen masks. Avoid the continuous use of the interphone position to minimize the interference from the noise of the oxygen mask.*

**L1**      MAX FL..... 100/MEA

● **IF CAB ALT > 14 000 FT:**

**PAX OXY MASKS..... MAN ON**

**L2**      *This action confirms that the passenger oxygen masks are released.*

Note:      *When descent is established and if time permits, check that the **OUTFLOW VALVE** is closed on the **CAB PRESS SD** page. If it is not closed and  $\Delta P$  is positive, select the other CPC. If the **OUTFLOW VALVE** is still not closing set the cabin pressure **MODE SEL** pb to **MAN** and the **V/S CTL** sw to full down.*

*Notify the cabin crew when the aircraft reaches a safe flight level, and when cabin oxygen is no longer necessary.*

Ident.: PRO-ABN-CAB\_PR-T-00010755.0001001 / 05 AUG 10

**STATUS**

MAX FL..... 100/MEA

**CAB PR EXCES RESIDUAL PR**

Applicable to: ALL

Ident.: PRO-ABN-CAB\_PR-AE-00017328.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the differential pressure is still above 2.5 hPa (0.036 PSI) 12 s after the last engine shutdown.

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-AE-00018790.0002001 / 21 MAR 16

PACK 1.....OFF  
 PACK 2.....OFF  
 CABIN CREW.....ALERT

**CAB PR LDG ELEV FAULT**

Applicable to: ALL


Ident.: PRO-ABN-CAB\_PR-AF-00017325.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the LDG ELEV selector is set to AUTO and the landing field elevation of the FMGS is not available.

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-AF-00018936.0002001 / 21 MAR 16

**LDG ELEV.....ADJUST**

- L2** The flight crew must select the landing field elevation manually with the LDG ELEV selector. Refer to the LDG ELEV indication on the CRUISE page on the CAB PRESS SD page to adjust the required landing field elevation.

Note: If the landing is performed on QFE, set 0 ft on LDG ELEV selector.



**CAB PR LO DIFF PR**

Applicable to: ALL

Ident.: PRO-ABN-CAB\_PR-AG-00017320.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:


L2

This alert triggers when:

- The time to reach  $\Delta P = 0$  is less than 1.5 min, and
- The time to reach  $\Delta P = 0$  is less than the time for CAB ALT to reach landing field elevation +30 s, and
- The aircraft is at least 3 000 ft above the landing field elevation.

Note: *The alert remains, when the aircraft descends within 3 000 ft of the landing field elevation.*

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-AG-00010762.0002001 / 05 AUG 10

**EXPECT HI CAB RATE**

A/C V/S.....REDUCE

L2

*This line is not displayed in case of Emergency Descent due to Excessive Cabin Altitude.*

**CAB PR OFV NOT OPEN**

Applicable to: ALL


Ident.: PRO-ABN-CAB\_PR-AH-00017323.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers, on ground, when the outflow valve is not fully open (time delay 70 s).

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-AH-00018802.0001001 / 21 MAR 16

MODE SEL..... MAN  
 MAN V/S CTL..... FULL UP

**L2** It may take 10 s in manual mode before the crew notices a change of the outflow valve position.

**L1** ● **IF UNSUCCESSFUL :**  
 PACK 1..... OFF  
 PACK 2..... OFF

**CAB PR SAFETY VALVE OPEN**

Applicable to: ALL

Ident.: PRO-ABN-CAB\_PR-W-00017324.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers:

- On ground, if the safety valve is not fully closed, or
- In flight, if the safety valve is not fully closed for more than 1 min.

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-W-00018092.0002001 / 21 MAR 16

■ **IF DIFF PR ABV 8 PSI:**

MODE SEL.....MAN  
 MAN V/S CTL.....AS RQRD

L2

If overpressure is confirmed, reduce cabin ΔP.  
 It may take 10 s in manual mode before the flight crew notices a change of the outflow valve position.

L1

● **IF UNSUCCESSFUL:**

A/C FL.....REDUCE

■ **IF DIFF PR BELOW 0 PSI:**

EXPECT HI CAB RATE  
 A/C V/S.....REDUCE

Continued on the following page



**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

CAB PR

**CAB PR SAFETY VALVE OPEN (Cont'd)**

Ident.: PRO-ABN-CAB\_PR-W-00018093.0003001 / 21 MAR 16

**STATUS**

**MAN CAB PR CTL**

TGT V/S: CLIMB 500 FT/MIN

TGT V/S: DESC 300 FT/MIN

**A/C FL**

390  
 350  
 300  
 250  
 < 200

**CAB ALT TGT**

8 000  
 7 000  
 5 500  
 3 000  
 0

● **DURING FINAL APPR :**

MAN V/S CTL.....FULL UP

**CAUTION**

Check that  $\Delta P$  is zero before opening the doors.

**CAB PR SYS 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-CAB\_PR-U-00017326.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the cabin pressure controller is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-U-00010756.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-CAB\_PR-U-00010758.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

CAB PR 1 (2)

**CAB PR SYS 1+2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-CAB\_PR-V-00017319.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when both cabin pressure controllers are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-CAB\_PR-V-00010759.0001001 / 05 AUG 10

- [L2] Due to the slow closure of the outflow valve in manual pressurization mode and depending on the failure, the following procedure may not avoid the depressurization.

[L1] **MODE SEL**..... **MAN**  
**MAN V/S CTL**..... **AS RQRD**

- [L2] - It may take 10 s in manual mode before the crew notices a change of the outflow valve position. Use the cabin V/S indication to confirm the outflow valve operation.
- Monitor cabin V/S and CAB ALT frequently and adjust as necessary. Maintain aircraft altitude at or above cabin altitude.
- The two safety valves limit  $\Delta P$  to 8.6 PSI.

Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

CAB PR

**CAB PR SYS 1+2 FAULT (Cont'd)**

Ident.: PRO-ABN-CAB\_PR-V-00018107.0003001 / 21 MAR 16

L12

**STATUS**

**MAN CAB PR CTL**

TGT V/S : CLIMB 500 FT/MIN

TGT V/S : DESC 300 FT/MIN

**A/C FL**

390  
 350  
 300  
 250  
 < 200

**CAB ALT TGT**

8 000  
 7 000  
 5 500  
 3 000  
 0

**INOP SYS**

CAB PR 1+2

● **DURING FINAL APPR :**

V/S CTL.....FULL UP

*When on intermediate approach (below airfield pressure altitude +2 500 ft), adjust  $\Delta P = 0$ .*

**CAUTION**

Check that  $\Delta P$  is zero before opening the doors.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

CAB PR

Intentionally left blank



**C/B TRIPPED**

Applicable to: ALL


Ident.: PRO-ABN-C\_B-Y-00017390.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when one C/B is tripped in the designated zone.

Flight Phase Inhibition:



Ident.: PRO-ABN-C\_B-Y-00012551.0001001 / 25 FEB 14

Crew awareness.

- If one green circuit breaker (C/B) is tripped, one of the following messages appears after one minute, depending on the location of the affected C/B:

C/B TRIPPED ON OVHD PNL

C/B TRIPPED ON L(R) ELEC BAY

C/B TRIPPED REAR PNL J-M OR N-R OR S-V OR W-Z

**L2** Note: In flight, do not reengage a C/B that has tripped by itself, unless the Captain judges it necessary to do so for the safe continuation of the flight. This procedure should be adopted only as a last resort, and only one reengagement should be attempted. On ground, do not reengage the C/B of the fuel pump(s) of any tank. For all other C/B s, if the flight crew coordinates the action with maintenance, the flight crew may reengage a tripped C/B , provided that the cause of the tripped C/B is identified.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

C/B

Intentionally left blank

**COM ACARS FAULT** 

Applicable to: ALL

Ident.: PRO-ABN-COM-B-00016895.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2**

This alert triggers when there is a failure of ACARS.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-B-00017538.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-COM-B-00010037.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

ACARS

**COM CIDS 1 + 2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-COM-A-00016887.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when there is a total loss of CIDS.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-A-00010033.0001001 / 25 FEB 14

**L2** Passenger address, cabin and service interphone, and passenger signs are inoperative.

**L1** Crew awareness.

Ident.: PRO-ABN-COM-A-00010034.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

CIDS

**COM HF 1(2) DATA FAULT** 

Applicable to: ALL

Ident.: PRO-ABN-COM-F-00016896.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when data communications via HF 1(2) are inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-F-00017499.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-COM-F-00010045.0001001 / 17 MAR 11

**STATUS**

**INOP SYS**

HF 1(2) DATA

**COM SATCOM DATA FAULT** ⚠

Applicable to: ALL


Ident.: PRO-ABN-COM-D-00016899.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the ACARS transmissions via SATCOM are lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-D-00017548.0001001 / 21 MAR 16

**L2** Telephone transmissions are still available. ACARS ⚠ communications are inoperative.

**L1** Crew awareness.

Ident.: PRO-ABN-COM-D-00010041.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

SATCOM DATA

**COM SATCOM FAULT** ⚠

Applicable to: ALL


Ident.: PRO-ABN-COM-C-00016894.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the telephone and the ACARS ⚠ transmission are lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-C-00017500.0001001 / 21 MAR 16

**L2** ACARS ⚠ and telephone communications are inoperative.

**L1** Crew awareness.

Ident.: PRO-ABN-COM-C-00017502.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

SATCOM

**COM SINGLE PTT STUCK** 

Applicable to: ALL


Ident.: PRO-ABN-COM-G-00016902.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when any PTT transmission selector is jammed in the transmit position for more than 40 s (VHF ) or for more than 180 s (HF).

Flight Phase Inhibition:



*Continued on the following page*



**COM SINGLE PTT STUCK** ⚠️ (Cont'd)

Ident.: PRO-ABN-COM-G-00017503.0001001 / 21 MAR 16

ACP1 VHF 1(2)(3) TX..... DESELECT  
ACP1 HF 1(2) TX..... DESELECT

● **IF UNSUCCESSFUL:**

ACP2 VHF 1(2)(3) TX..... DESELECT  
ACP2 HF 1(2) TX..... DESELECT

● **IF UNSUCCESSFUL:**

ACP3 VHF 1(2)(3) TX..... DESELECT  
ACP3 HF 1(2) TX..... DESELECT

When the ACP linked to the faulty PTT is detected, the previous ECAM actions are replaced by the following ones:

AUDIO SWTG..... DO NOT USE

● **ON AFFECTED ACP:**

ALL TX KEYS..... DO NOT USE

● **ON ALL OTHER ACP:**

VHF 1(2)(3) TX..... RESELECT  
HF 1(2) TX..... RESELECT

Ident.: PRO-ABN-COM-G-00014765.0001001 / 26 NOV 12

**STATUS**

AUDIO SWTG..... DO NOT USE

**INOP SYS**

SINGLE PTT

**COM VHF 1(2)(3) /HF 1(2) EMITTING** ⚠

Applicable to: ALL


Ident.: PRO-ABN-COM-I-00016892.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- ⓘ For VHF 1(2)(3) EMITTING, the alert triggers when the transmitter emits more than 30 s or 60 s depending on aircraft configuration.  
For HF 1(2) EMITTING, the alert triggers when the transmitter emits more than 60 s.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-I-00017549.0001001 / 21 MAR 16

- ⓘ 1. If any Push To Talk (PTT) transmission selector (sidestick PTT ⚠, hand mike PTT ⚠, or ACP PTT switch ⚠) is jammed in the transmit position, try to release it in order to remove the caution.
2. If unsuccessful, deselect the identified failed VHF /HF transmission keys on the associated Audio Control Panel (ACP) to remove the caution. This ACP should only be used in reception mode. The associated PTT transmission selectors must not be used.

Note: In this case, the ACP of the unaffected side may be used to recover the deselected VHF /HF channel.

3. If no transmission key on the ACP is found in the "transmit" position, pull the affected VHF /HF C/B associated to the ECAM message : COM\HF1 C/B HA 14 on 49 VU, COM NAV\HF2 C/B L13 on 121 VU, COM\HF1 C/B G09 on 49 VU, COM NAV\HF2 C/B L04 on 121 VU, COM \HF3 C/B L05 on 121 VU.

**COM VHF 3 DATA FAULT** ⚠

Applicable to: ALL

Ident.: PRO-ABN-COM-E-00016897.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when data communication via VHF 3 are inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-COM-E-00017550.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-COM-E-00010043.0001001 / 17 MAR 11

**STATUS**

**INOP SYS**

VHF 3 DATA



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

COM

Intentionally left blank

**COND FWD CAB/AFT CAB/CKPT DUCT OVHT**

Applicable to: ALL

Ident.: PRO-ABN-COND-F-00017295.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The duct temperature rises above 88 °C, or
- The duct temperature rises above 80 °C four times during the same flight.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-F-00010720.0001001 / 05 AUG 10

● **WHEN DUCT TEMP < 70 DEG C:**

**HOT AIR**.....OFF THEN ON

L2

*Hot air pressure regulating valve reopens.*

Ident.: PRO-ABN-COND-F-00018037.0001001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

● **If system not recovered:**

**CAB TEMP BY PACK ONLY**

*Basic temperature regulation is by packs only (remains automatic).*

**HOT AIR**  
**FWD CRG HEAT** ⚠

**COND FWD(AFT) CARGO DUCT OVHT** 

Applicable to: ALL


Ident.: PRO-ABN-COND-G-00017339.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the duct temperature in the forward(aft) cargo compartment rises above 88 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-G-00018038.0001001 / 21 MAR 16

- **WHEN DUCT TEMP < 70 DEG C:**  
**HOT AIR**.....**OFF THEN ON**

- L2** Hot air pressure regulating valve reopens.

Ident.: PRO-ABN-COND-G-00018039.0001001 / 21 MAR 16

- L12** **STATUS**

- **If system not recovered:**  
**CAB TEMP BY PACK ONLY**  
Basic temperature regulation is by packs only (remains automatic).

**INOP SYS**  
**FWD(AFT) CRG HEAT**

**COND FWD(AFT) CRG HEAT FAULT** 

Applicable to: ALL

Ident.: PRO-ABN-COND-N-00017341.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers if the heating controller of the forward(aft) cargo compartment is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-N-00018040.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-COND-N-00018041.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

FWD(AFT) CRG HEAT

**COND FWD(AFT) CRG ISOL VALVE** ⚠

Applicable to: ALL


Ident.: PRO-ABN-COND-M-00017335.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers if the forward(aft) cargo isolation valve disagrees with the selected position.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-M-00018042.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-COND-M-00018043.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

FWD(AFT) CRG HEAT ⚠  
 FWD(AFT) CRG VENT ⚠



**COND HOT AIR FAULT**

Applicable to: ALL


Ident.: PRO-ABN-COND-I-00017296.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the position of the hot air pressure regulating valve disagrees with the commanded position.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-I-00018940.0001001 / 21 MAR 16

HOT AIR (IF NOT CLOSED)..... OFF

● **IF HOT AIR STILL OPEN and DUCT OVHT persists:**

PACK 1..... OFF

PACK 2..... OFF

DESCENT TO FL 100/MEA

**L2** Descend to FL 100, or MEA, whichever is higher.

**L1** ● **WHEN DIFF PR < 1 PSI AND FL BELOW 100:**

RAM AIR..... ON

MAX FL..... 100/MEA

*Continued on the following page*

**COND HOT AIR FAULT (Cont'd)**


Ident.: PRO-ABN-COND-I-00018044.0001001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

- **If HOT AIR closed only:**  
**CAB TEMP BY PACK ONLY**  
*Basic temperature regulation by packs only (remains automatic).*

PACK 1+2 (If PACKS OFF)  
HOT AIR  
FWD CRG HEAT 

**COND L+R CAB FAN FAULT**

Applicable to: ALL


Ident.: PRO-ABN-COND-R-00017297.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers if both recirculation fans are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-R-00018045.0001001 / 22 MAR 17

PACK FLOW.....HI

*Continued on the following page*

**COND L+R CAB FAN FAULT (Cont'd)**


Ident.: PRO-ABN-COND-R-00018046.0001001 / 21 MAR 16

<b>STATUS</b>	
	<b><u>INOP SYS</u></b>
	L+R CAB FAN

**COND LAV + GALLEY FAN FAULT**

Applicable to: ALL

Ident.: PRO-ABN-COND-S-00017300.0001001 / 21 MAR 16



Ident.: PRO-ABN-COND-S-00010751.0002001 / 25 FEB 14

- L2 Cabin zone temperature sensors are normally ventilated by the air extracted by the fan. Therefore, cabin zone temperature regulation is lost.
- L1 Crew awareness.

*Continued on the following page*

**COND LAV + GALLEY FAN FAULT (Cont'd)**

Ident.: PRO-ABN-COND-S-00010752.0011001 / 05 AUG 10

L12

**STATUS**

**INOP SYS**

● **If ACSC 2 is operative:**  
**CAB TEMP CKPT CTL ONLY**

- To adjust the cabin zone temperature, use the FWD CABIN and AFT CABIN zone temperature selectors (overhead panel). The selectors control the cabin duct temperature directly.
- Cockpit temperature regulation is normal.

● **If ACSC 2 is inoperative:**  
**CAB AT FIXED TEMP**

- FWD CABIN and AFT CABIN zone temperature selectors are inoperative.
- To adjust the cabin zone temperature, use the COCKPIT zone temperature selector (overhead panel). Cabin duct temperature is the same as cockpit duct temperature.
- Cockpit temperature regulation is normal.

GALLEY FAN  
 PACK 2 <sup>(1)</sup>  
 COND CTL 2 <sup>(1)</sup>

<sup>(1)</sup> (If ACSC 2 is inoperative)

**COND TRIM AIR SYS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-COND-AI-00017305.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- One trim air valve is failed, or
- There is an overpressure downstream of the hot air valve.

Flight Phase Inhibition:



Ident.: PRO-ABN-COND-AI-00010730.0001001 / 05 AUG 10

■ **One trim valve failed:**

A message corresponding to the affected valve is displayed:

- AFT CAB TRIM VALVE
- FWD CAB TRIM VALVE
- CKPT TRIM VALVE

■ **High pressure detected downstream of the hot air pressure regulating valve:**

TRIM AIR HI PR

L2

Note: If the warning and the TRIM AIR HI PR message are triggered when all trim air valves are closed (during the first 30 s after the packs are selected on, or in flight, if all zone heating demands are fulfilled), disregard them.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

COND

Intentionally left blank

**CONFIG L(R) SIDESTICK FAULT**  
**(BY TAKE OVER)**

Applicable to: ALL


Ident.: PRO-ABN-CONFIG-AA-00018894.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the L or R sidestick is inoperative (takeover pb pressed more than 30 s) and when thrust levers are set at TO , or Flex TO, or when pressing T.O CONFIG pb.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-AA-00018411.0001001 / 21 MAR 16

**L(R) TAKEOVER** .....**DEPRESS**

**L2** *The affected stick becomes operative.*

**CONFIG PARK BRK ON**

Applicable to: ALL


Ident.: PRO-ABN-CONFIG-Z-00017858.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the parking brake is on and thrust levers are set at TO or FLXTO power position.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-Z-00011302.0001001 / 05 AUG 10

- L2 Check that the parking brake handle is in the OFF position. If warning stays on, check that the brake pressure is at zero on the BRAKES PRESSURE indicator.



**CONFIG PITCH TRIM NOT IN T.O RANGE**

Applicable to: ALL

Ident.: PRO-ABN-CONFIG-AB-00018895.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

If the PITCH TRIM is not in TO configuration, this alert triggers:

- when thrust levers are set at TO , or Flex TO, or
- when pressing T.O CONFIG pb.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-AB-00011773.0001001 / 25 FEB 14

Crew awareness.

**CONFIG RUD TRIM NOT IN T.O RANGE**

Applicable to: ALL


Ident.: PRO-ABN-CONFIG-AC-00018896.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 If the RUD TRIM is not in TO configuration, this alert triggers:
- when thrust levers are set at TO , or Flex TO, or
  - when pressing T.O CONFIG pb.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-AC-00011776.0001001 / 25 FEB 14

Crew awareness.

**CONFIG SLATS (FLAPS) NOT IN T.O CONFIG**

Applicable to: ALL

Ident.: PRO-ABN-CONFIG-AD-00018897.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

If the slats or flaps are not in TO configuration, this alert triggers:

- when thrust levers are set at TO , or Flex TO, or
- when pressing T.O CONFIG pb.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-AD-00011758.0001001 / 25 FEB 14

Crew awareness.

**CONFIG SPD BRK NOT RETRACTED**

Applicable to: ALL


Ident.: PRO-ABN-CONFIG-AE-00018898.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 If the speed brakes are not retracted, this alert triggers:
- when thrust levers are set at TO , or Flex TO, or
  - when pressing T.O CONFIG pb.

Flight Phase Inhibition:



Ident.: PRO-ABN-CONFIG-AE-00011766.0001001 / 09 FEB 16

Crew awareness.

**DATALINK ATSU FAULT**

Applicable to: ALL

Ident.: PRO-ABN-DATALINK-A-00017150.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a failure in ATSU initialization associated with ATSU INIT FAULT ECAM message.

Flight Phase Inhibition:



Ident.: PRO-ABN-DATALINK-A-00018462.0001001 / 21 MAR 17

Crew awareness.

**ATSU INIT FAULT**

L2

Displayed, in case of failure upon ATSU initialization. Refer to DSC-46-10-50 How to Initialize.

Ident.: PRO-ABN-DATALINK-A-00018463.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

ATSU  
DATA COMPANY

**DATALINK COMPANY FAULT**

Applicable to: ALL


Ident.: PRO-ABN-DATALINK-C-00017151.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is a failure in the AOC datalink communications.

Flight Phase Inhibition:



Ident.: PRO-ABN-DATALINK-C-00018458.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-DATALINK-C-00018459.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

DATA COMPANY

**[QRH] COCKPIT DOOR FAULT**

Ident.: PRO-ABN-DOOR-00009968.0003001 / 17 MAR 17

Applicable to: ALL

CKPT DOOR CONT [OVHD PANEL] ..... CHECK

● **If one or more STRIKE status light on:**

COCKPIT DOOR..... OPEN

COCKPIT DOOR sw ..... UNLOCK 10 s THEN NORM

● **If two or more STRIKE status lights on:**

COCKPIT DOOR NOT INTRUSION PROOF.

● **If two CHAN status lights on:**

Automatic latch release is not available, in case of cockpit decompression.

● **If no status light on:**

TO UNLOCK THE DOOR: COCKPIT DOOR HANDLE AVAIL

**DOOR L(R)(FWD)(AFT) AVIONICS**  
**(IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-DOOR-A-00016888.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the L(R)(FWD)(AFT) avionics door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-A-00018945.0001001 / 21 MAR 16

- L2 No crew action required as long as cabin pressure is normal.

- L1 ● **IF ABN CAB V/S:**  
**MAX FL..... 100/MEA**

- L2 *Limit maximum flight level to FL 100, or MEA, or minimum obstacle clearance altitude. Avionics doors are of plug type. Therefore full depressurization is not recommended.*

Ident.: PRO-ABN-DOOR-A-00018944.0002001 / 21 MAR 16

**STATUS**

- **IF ABN CAB V/S:**  
**MAX FL..... 100/MEA**



**DOOR L(R)(FWD)(AFT) AVIONICS**  
**(ON GROUND)**

Applicable to: ALL

Ident.: PRO-ABN-DOOR-C-00019100.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the L(R)(FWD)(AFT) avionics door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-C-00019096.0001001 / 21 MAR 16

Crew awareness.

**DOOR L(R) FWD(AFT) CABIN**  
**(IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-DOOR-D-00019103.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the L(R) FWD(AFT) cabin door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-D-00019101.0001001 / 21 MAR 16

No crew action required as long as cabin pressure is normal.

● **IF ABN CAB V/S:**

MAX FL..... 100/MEA

- L2 Limit maximum flight level to FL 100, or MEA, or minimum obstacle clearance altitude. If door warning is accompanied by abnormal increase of cabin altitude, flight crew must reduce cabin  $\Delta P$  and altitude by descending.

Ident.: PRO-ABN-DOOR-D-00019104.0002001 / 21 MAR 16

**STATUS**

● **IF ABN CAB V/S:**

MAX FL..... 100/MEA

**DOOR L(R) FWD(AFT) CABIN**  
**(ON GROUND)**

Applicable to: ALL


Ident.: PRO-ABN-DOOR-E-00019106.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the L(R) FWD(AFT) cabin door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-E-00019102.0001001 / 21 MAR 16

**L2** The crew may confirm a cabin door warning by checking the visual indicator on the door.

**L1** Crew awareness.

**DOOR L(R) FWD(AFT) EMER EXIT**  
**(IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-DOOR-F-00019121.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- Ⓛ2 This alert triggers when the L(R) FWD(AFT) emergency exit door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-F-00019120.0001001 / 21 MAR 16

No crew action required as long as cabin pressure is normal.

● **IF ABN CAB V/S:**

**MAX FL..... 100/MEA**

- Ⓛ2 *Limit maximum flight level to FL 100, or MEA, or minimum obstacle clearance altitude. If door warning is accompanied by abnormal increase of cabin altitude, flight crew must reduce cabin  $\Delta P$  and altitude by descending.*

Ident.: PRO-ABN-DOOR-F-00019122.0004001 / 21 MAR 16

**STATUS**

● **IF ABN CAB V/S:**

**MAX FL..... 100/MEA**

**DOOR L(R) FWD(AFT) EMER EXIT**  
 (ON GROUND)

Applicable to: ALL

Ident.: PRO-ABN-DOOR-G-00019125.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the L(R) FWD(AFT) emergency exit door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-G-00019124.0001001 / 21 MAR 16

L2 The crew may confirm an emergency exit door warning by checking the visual indicator on the door.

L1

Crew awareness.

**DOOR FWD(AFT)(BULK) CARGO**  
**(IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-DOOR-B-00016890.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- ② This alert triggers when the FWD(AFT)(BULK) cargo door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-B-00019126.0001001 / 21 MAR 16

No crew action required as long as cabin pressure is normal.

● **IF ABN CAB V/S:**

MAX FL..... 100/MEA

- ② *Limit maximum flight level to FL 100, or MEA, or minimum obstacle clearance altitude. If door warning is accompanied by abnormal increase of cabin altitude, flight crew must reduce cabin  $\Delta P$  and altitude by descending.*

Ident.: PRO-ABN-DOOR-B-00018946.0002001 / 21 MAR 16

**STATUS**

● **IF ABN CAB V/S:**

MAX FL..... 100/MEA

**DOOR FWD(AFT)(BULK) CARGO**  
**(ON GROUND)**

Applicable to: ALL

Ident.: PRO-ABN-DOOR-H-00019129.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the FWD(AFT)(BULK) cargo door is not detected closed by the proximity sensors.

Flight Phase Inhibition:



Ident.: PRO-ABN-DOOR-H-00018947.0002001 / 21 MAR 16

L2 The crew may confirm a cargo door warning by checking the indication on the cargo door.

L1 Crew awareness.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

DOOR

Intentionally left blank



**[QRH] DISPLAY UNIT FAILURE**

Ident.: PRO-ABN-EIS-00021170.0002001 / 17 MAR 17

Applicable to: ALL

■ **If DU flashes:**

This phenomenon may be due to Intermittent Electrical Power Supply Interruptions. It is evidenced by one, or a combination, of the following :

- Flashing of PFD , ND , ECAM DUs (blank screen or INVALID DATA message),
- Flashing of MCDU,
- Intermittent flight control law reversion.

■ **If captain PFD, ND, ECAM DUs or MCDU 1 affected:**

GEN 1.....OFF

■ **If DUs flash continues :**

GEN 1.....ON

■ **If DUs flash stops :**

KEEP GEN 1 OFF

*Keep the generator OFF for the rest of the flight.*

RUD TRIM.....CHECK/RESET

*Use the slide slip indication to reset the rudder trim if necessary. Intermittent Electrical Power Supply Interruptions may cause offset in the rudder trim.*

APU START.....CONSIDER

■ **If first officer PFD, ND, lower ECAM or MCDU 2 affected:**

GEN 2.....OFF

■ **If DUs flash continues:**

GEN 2.....ON

■ **If DUs flash stops:**

KEEP GEN 2 OFF

*Keep the generator OFF for the rest of the flight.*

RUD TRIM.....CHECK/RESET

*Use the slide slip indication to reset the rudder trim if necessary. Intermittent Electrical Power Supply Interruptions may cause offset in the rudder trim.*

APU START.....CONSIDER

■ **If DU blank (with or without large amber “F”), or distorted:**

DU brightness knob (affected DU).....AS RQRD

*Continued on the following page*

**[QRH] DISPLAY UNIT FAILURE (Cont'd)**

*The DU can be switched off.*

CONSIDER ECAM/ND XFR

CONSIDER PFD/ND XFR

■ **If INVALID DISPLAY UNIT message displayed:**

This may be caused by a DU failure.

WAIT AT LEAST 40 s FOR AUTOMATIC DU RECOVERY

● **If DU not recovered:**

DU brightness knob..... AS RQRD

*The DU can be switched off.*

■ **If INVALID DATA message displayed (not on all DUs):**

CONSIDER EIS DMC SWITCHING

● **If unsuccessful:**

DU brightness knob (affected DU)..... OFF THEN ON

*Note: The ND display may disappear if too many waypoints and associated information are displayed. Reduce ND range, or deselect WPT or CSTR, and the ND display may automatically recover, after about 30 s.*

■ **If INVALID DATA message displayed on all DUs:**

AP, A/THR AND MCDU NAVIGATION DATA AVAILABLE

WAIT AT LEAST 40 s FOR AUTOMATIC DU RECOVERY

● **If one or more DUs not recovered:**

DUs brightness knob (all affected DUs)..... OFF

WAIT AT LEAST 40 s

DUs brightness knob (one by one)..... ON

● **If INVALID DATA message displayed on all DUs, when switching a given DU back ON:**

FAULTY DU brightness knob..... OFF AND KEEP OFF

REPEAT PROCEDURE

*Repeat the procedure starting at: If INVALID DATA message displayed on all DUs.*

■ **If inversion of E/WD and SD:**

ECAM UPPER DISPLAY brightness knob..... OFF THEN ON

*The same action on the EIS DMC SWITCHING selector produces the same effect.*

**EIS DMC 1(2)(3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-EIS-F-00017307.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when DMC 1, or DMC 2, or DMC 3 is failed.

Flight Phase Inhibition:



**L1** Note: (a) Inhibited only during first 15 s of Flight Phase 5.

Ident.: PRO-ABN-EIS-F-00010057.0002001 / 10 AUG 10

**■ DMC 1**  
EIS DMC SWITCH ..... CAPT 3

**L2** DMC 3 replaces DMC 1.

**L1** **■ DMC 2**  
EIS DMC SWITCH..... F/O 3

**L2** DMC 3 replaces DMC 2.

**L1** **■ DMC 3**  
Crew awareness.

*Continued on the following page*

**EIS DMC 1(2)(3) FAULT (Cont'd)**

Ident.: PRO-ABN-EIS-F-00010058.0001001 / 10 AUG 10

**STATUS**

**INOP SYS**

DMC 1(2)(3)

**EIS DMC/FWC COM FAULT**

Applicable to: ALL


Ident.: PRO-ABN-EIS-I-00017317.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**[L2]** This alert triggers when at least one of the FWC detects the loss of both DMC 1/3 and DMC2/3 busses.

Flight Phase Inhibition:



Ident.: PRO-ABN-EIS-I-00014308.0001001 / 25 FEB 14

Crew awareness.

**[QRH] C/B TRIPPED**

Ident.: PRO-ABN-ELEC-00012643.0001001 / 17 MAR 17

Applicable to: ALL

■ **On ground:**

Do not reengage the circuit breaker (C/B ) of the fuel pump(s) of any tank. For all other C/B , if the flight crew coordinates the action with maintenance, the flight crew may reengage a tripped C/B, provided that the cause is identified.

■ **In flight:**

Do not reengage a circuit breaker (C/B), unless the captain judges it necessary to do so for the safe continuation of the flight. Only one reengagement should be attempted.

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ELEC

**[QRH] ELEC EMER CONFIG SYS REMAINING**

Applicable to: ALL

ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	BAT ONLY	
		IN FLIGHT	ON THE GROUND

Ident.: PRO-ABN-ELEC-S-00018562.0004001 / 17 MAR 17

	ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	IN FLIGHT	ON THE GROUND
AIR COND PRESS	PRESS AUTO SYS 1	NORM	NORM	NORM
	MAN PRESS CTL	INOP	INOP	INOP <sup>(a)</sup>
	RAM AIR	NORM	NORM	NORM
	PACK VALVE 1	NORM	Closure Inop	Closure Inop
	PACK VALVE 2	Closure Inop	Closure Inop	Closure Inop <sup>(a)</sup>
	AVIONIC VENT	NORM	NORM	Partial
	FWD CRG ISOL VALVES	NORM	INOP	INOP

Ident.: PRO-ABN-ELEC-S-00012522.0001001 / 17 MAR 17

	ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	IN FLIGHT	ON THE GROUND
FMGS	FMGC (NAV FUNCTION)	N°1 only	Inop	Inop
	MCDU	N°1 only	Inop	Inop
	FAC	N°1 only	Inop	Inop
	FCU	ch 1 only	ch 1 only	ch 1 only

Ident.: PRO-ABN-ELEC-S-00018533.0002001 / 17 MAR 17

	ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	IN FLIGHT	ON THE GROUND
COM	VHF 1	NORM	NORM	NORM
	HF 1	NORM	INOP	INOP
	RMP 1	NORM	NORM	NORM
	ACP (CAPT , F/O)	NORM	NORM	NORM
	CIDS	NORM	NORM	NORM
	INTERPHONE	NORM	NORM	NORM
	CVR	NORM	INOP	INOP
	LOUDSPEAKER 1	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00012524.0001001 / 17 MAR 17

	ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	IN FLIGHT	ON THE GROUND
EMER EQPT	CREW OXY	NORM	NORM <sup>(b)</sup>	NORM <sup>(b)</sup>
	PAX OXY mask release (auto + man)	NORM	INOP	INOP
	SLIDES ARM/WARN	NORM	NORM	NORM

*Continued on the following page*

*Continued from the previous page*

ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	BAT ONLY	
		IN FLIGHT	ON THE GROUND

Ident.: PRO-ABN-ELEC-S-00012525.0002001 / 17 MAR 17

FIRE	ENG 1 LOOP	A only	A only	A only
	ENG 2 LOOP	B only	B only	B only
	APU LOOP	INOP	INOP	INOP <sup>(a)</sup>
	CARGO SMOKE DET	ch 1 only	INOP	INOP
	ENG FIRE EXT.	Bottle 1 only	Bottle 1 only	Bottle 1 only
	APU FIRE EXT.	Squib A only	Squib A only	Squib A only
	CARGO FIRE EXT.	INOP	INOP	INOP <sup>(a)</sup>
	APU AUTO EXT.	INOP	INOP	INOP <sup>(a)</sup>

Ident.: PRO-ABN-ELEC-S-00018017.0001001 / 17 MAR 17

FLT CTL	ELAC	N°1 only	N°1 + N°2	N°1 + N°2 <sup>(d)</sup>
	SEC	N°1 only	N°1 only	N°1 only
	FCDC	N°1 only	INOP	INOP
	SFCC	N°1 only	N°1 only	N°1 only
	Flaps pos ind	NORM	NORM	NORM <sup>(e)</sup>


Ident.: PRO-ABN-ELEC-S-00018018.0001001 / 17 MAR 17

FUEL	LP VALVE	NORM	NORM	NORM
	FQI channel 1	NORM	INOP	INOP
	X FEED VALVE	NORM	INOP	INOP
	INTERTANK TRANSFER VALVE	NORM	INOP	INOP

Ident.: PRO-ABN-ELEC-S-00012528.0001001 / 17 MAR 17

HYD	FIRE VALVES	NORM	NORM	NORM
-----	-------------	------	------	------

Ident.: PRO-ABN-ELEC-S-00018539.0002001 / 17 MAR 17

ICE-RAIN	WING A.ICE	NORM	INOP	INOP
	ENG A.ICE VALVE	OPEN	OPEN	OPEN
	CAPT PITOT	NORM	NORM	NORM <sup>(c)</sup>
	CAPT AOA	NORM	INOP	INOP
	RAIN REPELLENT (CAPT) 	NORM	NORM	NORM

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

ELEC

*Continued from the previous page*

ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	BAT ONLY	
		IN FLIGHT	ON THE GROUND

Ident.: PRO-ABN-ELEC-S-00018538.0002001 / 17 MAR 17

EIS	PFD 1	NORM	NORM	NORM <sup>(c)</sup>
	ND 1	NORM	INOP	INOP
	ECAM upper disp.	NORM	NORM	NORM <sup>(c)</sup>
	DMC 1 or 3	NORM	NORM	NORM <sup>(c)</sup>
	SDAC 1, FWC 1	NORM	NORM	NORM <sup>(c)</sup>
	ECAM CONT. panel	NORM	NORM	NORM
FLT INS	CLOCKS	NORM	NORM	NORM



Ident.: PRO-ABN-ELEC-S-00018537.0002001 / 17 MAR 17

L/G	LGCIU SYS 1	NORM	NORM	NORM
	BRK PRESS IND	NORM	NORM	NORM
	PARK BRK	NORM	NORM	NORM
	ABCU	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00012532.0001001 / 17 MAR 17

LIGHTS	EMER CKPT	NORM	NORM	NORM
	EMER CAB	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00018550.0005001 / 17 MAR 17


NAV	IR	N°1 only <sup>(e)</sup>	N°1 only <sup>(e)</sup>	N°1 only <sup>(e)</sup>
	ADR	N°1 only	N°1 only	N°1 only
	ADF 	N°1 only	INOP	INOP
	VOR	N°1 only	N°1 only	N°1 only <sup>(c)</sup>
	MMR	N°1 only	N°1 only	N°1 only <sup>(c)</sup>
	DME	N°1 only	INOP	INOP
	DDRMI 	NORM	NORM	NORM <sup>(c)</sup>
	ATC	N°1 only	INOP	INOP
	ISIS	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00018541.0002001 / 17 MAR 17

PNEU	ENG 1 BLEED	NORM	BMC 1 INOP	BMC 1 INOP
	ENG 2 BLEED	BMC 2 INOP	BMC 2 INOP	BMC 2 INOP
	APU BLEED	INOP	INOP	INOP <sup>(a)</sup>
	X BLEED (MAN CTL)	NORM	INOP	INOP

*Continued on the following page*



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>ABNORMAL AND EMERGENCY PROCEDURES</b>  ELEC
---	---

*Continued from the previous page*

ELEC EMER CONFIG SYS REMAINING	EMER GEN RUNNING	BAT ONLY	
		IN FLIGHT	ON THE GROUND

Ident.: PRO-ABN-ELEC-S-00018019.0002001 / 17 MAR 17

APU	ECB-STARTER	NORM <sup>(f)</sup>	NORM <sup>(g)</sup>	INOP <sup>(a)</sup>
	FUEL LP VALVE	NORM	NORM	NORM
	FUEL PUMP	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00018540.0002001 / 17 MAR 17

PWR PLT	FADEC	A+B <sup>(h)</sup>	A+B <sup>(h)</sup>	A+B <sup>(h)</sup>
	IGNITION	A only	A only	A only
	HP FUEL VALVE closure	NORM	NORM	NORM

Ident.: PRO-ABN-ELEC-S-00012537.0001001 / 17 MAR 17

MISC	MECH HORN	NORM	NORM	NORM
------	-----------	------	------	------

- (a) *Restored, when speed is below 100 kt.*
- (b) *Crew supply solenoid valve inoperative.*
- (c) *Lost, when the speed is below 50 kt.*
- (d) *Lost, 30 s after the last engine shutdown.*
- (e) *IR 2 and IR 3 are lost 5 min after failure of main generators but if IR 3 replaces IR 1 (ATT -HDG selector at CAPT 3), IR 3 remains supplied.*
- (f) *For APU start only.*
- (g) *Not available for 45 s, after the loss of both engine generators.*
- (h) *Channels A and B are self powered above 10 % N2 for IAE or PW engines, 12 % N2 for CFM56 engines, or 8 % N2 for CFM LEAP-1A engines. If N2 is below these values, only Channel A is powered.*

**ELEC AC BUS 1 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-I-00017346.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the AC 1 busbar is not supplied.

Flight Phase Inhibition:




*Continued on the following page*

**ELEC AC BUS 1 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-I-00017853.0004001 / 21 MAR 16

**L2** AC BUS 1 normally supplies the AC ESS BUS and, through TR1, the DC ESS BUS. In the case of an AC BUS 1 FAULT, both the AC and DC ESS BUS will be lost and therefore the AC ESS BUS FAULT and the DC ESS BUS FAULT will be displayed on the ECAM.

However, for aircraft equipped with AC ESS FEED Auto Switching , the AC ESS BUS and the DC ESS BUS will automatically recover, due to the fact that the AC BUS 2 will automatically supply the AC ESS BUS.

The flight crew can manually recover the AC ESS BUS and the DC ESS BUS by setting the AC ESS FEED pb-sw to ALTN, as requested by the AC ESS BUS FAULT ECAM procedure

**L1** **BLOWER**..... **OVRD**

**L2** *The avionics ventilation system is in the closed circuit configuration.  
 Air conditioning is added to the ventilation air.*

**L1** **FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

**L12**

**ASSOCIATED PROCEDURES**

**ENG 1 EPR MODE FAULT**

*This associated procedure is only applicable to aircraft equipped with IAE engines.  
 Refer to PRO-ABN-ENG ENG 1(2) EPR MODE FAULT (First Threshold).*

**SECONDARY FAILURES**

- \* AVNCS VENT
- \* HYD
- \* FUEL
- \* F/CTL

*Continued on the following page*

**ELEC AC BUS 1 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-I-00017867.0028001 / 22 MAR 17

L12

**STATUS**

**INOP SYS**

*See below*

LDG DIST PROC..... APPLY

FUEL CONSUMPT INCRSD

See <sup>(1)</sup>

FMS PRED UNRELIABLE

See <sup>(2)</sup>

SLATS SLOW

CAT 2 ONLY

**INOP SYS**

BLUE HYD

RA 1

L WNDW HEAT

CTR TK PUMP 1

CRG HEAT (if both FWD and aft crg heat installed)

FWD CRG HEAT

GND COOL

BRK SYS 1/BSCU CH 1

LAV DET

STEEP APPR

SPLR 3

CAPT TAT

CAT 3

VENT BLOWER

CRG vent (if both FWD and aft crg heat installed)

AFT CRG VENT

MAIN GALLEY

DMC 3

REVERSER 1

ADR 3

L WSHLD HEAT

L+R TK PUMP 1

GALLEY FAN

AFT CRG HEAT

FWD CRG VENT

B ELEC PUMP

GPWS

GPWS TERR

**Other INOP SYS**

Left cabin fan

ADF 1

HUD

EVMU eng 1 and eng 2

Hydraulic quantity indication

TCAS

Radar 1

ACARS /ATSU

MCDU 3

Printer

Partial galley

Stby Pitot/AOA

Brake fans 5, 6, 7 and 8

Engine 1 ignition B

COND Controller Lane A

PVI

*Continued on the following page*

**ELEC AC BUS 1 FAULT (Cont'd)**

Note: The warning may be caused by a sub BUS failure. Consequently, only a part of the above-listed systems may be lost.

- (1) This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.
- (2) Disregard FMS fuel predictions and refer to QRH/OPS Operational Data- Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**ELEC AC BUS 2 FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-J-00017348.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the AC 2 busbar is not supplied.

Flight Phase Inhibition:



Continued on the following page

**ELEC AC BUS 2 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-J-00017877.0002001 / 21 MAR 16

EXTRACT.....OVRD

**L2** The avionics ventilation system is in the closed circuit configuration.  
Air conditioning is added to the ventilation air.

**L1** ATC/XPDR.....SYS 1

**ASSOCIATED PROCEDURES**

**L/G LGCIU 2 FAULT**

**L12** **ASSOCIATED PROCEDURES**

**ENG 2 EPR MODE FAULT**

*This associated procedure is only applicable to aircraft equipped with IAE engines.  
Refer to PRO-ABN-ENG ENG 1(2) EPR MODE FAULT (First Threshold).*

**SECONDARY FAILURES**

- \* AVNCS VENT
- \* FUEL

*Continued on the following page*

**ELEC AC BUS 2 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-J-00017878.0005001 / 22 MAR 17

L12

**STATUS**




**INOP SYS**


See below

ENG 2 APPR IDLE ONLY  
FLS  : F-APP+RAW ONLY


**INOP SYS**



ADR 2  
FWC 2  
R WSHLD HEAT  
F/O PITOT  
R WNDW HEAT  
REVERSER 2  
PACK 2 REGUL  
RUD TRIM 2  
CTR TK PUMP 2   
ILS 2 (OR LS 2 for aircraft equipped  
with MLS  /GLS  /FLS  )  
GLS AUTOLAND 



Y ELEC PUMP  
DMC 2  
LGCIU 2  
F/O AOA  
L+R TK PUMP 2  
VENT EXTRACT  
MAIN GALLEY  
FAC 2  
ACT PUMP   
GPS 2   
ROW/ROP 

SDAC 2  
RECORDER SYS (OR FDIU)  
RA 2  
F/O TAT  
RUD TRV LIM 2  
GND COOL   
YAW DAMPER 2  
CAT 2  
BRK SYS 2 /BSCU CH 2  
ATC 2 or ATC/XPDR 2

**Other INOP SYS**

Right cabin fan  
DME 2  
MCDU 2  
F/O PFD and ND  
HF 2 

Brake fans 1, 2, 3 and 4   
RADAR 2   
ENG 2 ignition B  
QAR

ADF 2   
WXR 2   
VOR 2  
ECAM lower DU

**Note:** The warning may be caused by a sub BUS failure. Consequently, only a part of the above-listed systems may be lost.

**ELEC AC ESS BUS ALTN**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-Z-00017356.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the AC ESS busbar is supplied from the AC 2 busbar although the AC ESS FEED pb-sw is set to normal.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-Z-00017893.0001001 / 21 MAR 16

Crew awareness.



**ELEC AC ESS BUS FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-K-00017357.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the AC ESS busbar is not supplied.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-K-00012502.0002001 / 24 MAR 11

AC ESS FEED..... ALTN

**L2** AC BUS 2 supplies AC ESS BUS.

**L1** ATC/XPDR..... SYS 2

*Continued on the following page*

**ELEC AC ESS BUS FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-K-00018552.0014001 / 01 JUN 16

L12

**STATUS**

**INOP SYS**

*See below*


**INOP SYS**

ADR 1  
 CAPT PITOT  
 SDAC 1  
 GPWS  
 RUD TRIM 1  
 ATC 1 or ATC/XPDR 1

LS 1  
 CAPT AOA  
 FWC 1  
 GPWS terr  
 RUD TRV LIM 1  
 ROW/ROP 

GPS 1  
 CAT 2  
 DMC 1  
 YAW DAMPER 1  
 GLS AUTOLAND 

**Other INOP SYS**

RMP's lighting (RMP's still operative)  
 CVR  
 CAPT PFD  
 DDRMI 

VOR 1  
 ECAM upper display  
 DME 1  
 HF 1

MCDU 1  
 CAPT ND  
 APU fuel pump  
 Passenger oxygen masks (auto + manual)

**Note:** *The warning may be caused by a sub BUS failure. As a result, only a part of the above-listed systems may be lost.*

**ELEC AC ESS BUS SHED**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-L-00017349.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the AC SHED ESS busbar is not supplied.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-L-00012504.0002001 / 03 DEC 13

ATC/XPDR..... SYS 2

*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ELEC

**ELEC AC ESS BUS SHED (Cont'd)**

Ident.: PRO-ABN-ELEC-L-00018554.0004001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

CAPT AOA  
ATC 1 or ATC/XPDR 1  
See below

**Other INOP SYS**

MCDU 1  
CVR  
Passenger oxygen masks (auto  
+ manual)  
DME 1  
CAPT AOA heat  
APU fuel pump  
CAPT ND  
HF 1

Note: The warning may be caused by a failure in a sub BUS. Consequently only a part of the systems listed above may be lost.

**ELEC APU GEN FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-E-00017362.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The protection trip is initiated by the associated GCU, or
- The line contactor is open with APU GEN pb-sw set to ON.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-E-00012490.0002001 / 18 MAR 11

APU GEN..... OFF THEN ON

● IF UNSUCCESSFUL:

APU GEN..... OFF

*Continued on the following page*

**ELEC APU GEN FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-E-00012491.0001001 / 18 MAR 11

**STATUS**

**INOP SYS**

MAIN GALLEY <sup>(1)</sup>  
APU GEN

<sup>(1)</sup> (When only one GEN operating)

**ELEC BAT 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-F-00017367.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

<sup>[2]</sup> This alert triggers when the charging current increases at an abnormal rate.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-F-00017894.0001001 / 21 MAR 16

<sup>[2]</sup> Battery contactor is opened automatically by the battery charge limiter.

<sup>[L1]</sup> Crew awareness.

*Continued on the following page*

**ELEC BAT 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-F-00017895.0001001 / 21 MAR 16

STATUS	
<p style="color: green;">APU BAT START NOT AVAIL</p>	<p style="color: orange;"><b><u>INOP SYS</u></b></p> <p style="color: orange;">BAT 1(2)</p>

**ELEC BAT 1(2) OFF**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-G-00017371.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the BAT 1(2) pb-sw is set to OFF and no failure is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-G-00018943.0001001 / 21 MAR 16

Crew awareness.

*Continued on the following page*

**ELEC BAT 1(2) OFF (Cont'd)**

Ident.: PRO-ABN-ELEC-G-00012495.0001001 / 19 AUG 10

**STATUS**

APU BAT START NOT AVAIL

**ELEC BCL 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-H-00017377.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

[L2] This alert triggers when the battery charge limiter 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-H-00012496.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*



**ELEC BCL 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-H-00012497.0001001 / 19 AUG 10

STATUS	
<p style="color: green;">APU BAT START NOT AVAIL</p>	<p style="color: orange;"><b><u>INOP SYS</u></b></p> <p style="color: orange;">BCL 1(2)</p>

**ELEC DC BAT BUS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-W-00017358.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2**

This alert triggers when the DC BAT busbar is not supplied.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-W-00012545.0001001 / 22 MAR 16

Crew awareness.

*Continued on the following page*

**ELEC DC BAT BUS FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-W-00012546.0021001 / 21 MAR 16

L12




**APU BAT START NOT AVAIL**  
*ECB is no longer supplied*

**STATUS**

**INOP SYS**

**APU FIRE DET**

**Other INOP SYS**

APU ECB  
Stick and rudder pedals lock  
*(by AP)*  
Forward (aft) cargo fire  
extinguishing   
Forward (aft) cargo heat  
controller   
AFT Cargo isol valves   
APU fuel LP valve  
Manual pressure control

**Note:** *The warning may  
be caused by a  
sub BUS failure.  
Consequently,  
only a part of  
the above-listed  
systems may be  
lost.*

**ELEC DC BUS 1 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-M-00017350.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the DC 1 busbar is not supplied.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-M-00012507.0001001 / 15 DEC 15

BLOWER.....OVRD  
 EXTRACT.....OVRD

**L2** The Air conditioning system provides ventilation to the avionics. This ventilation air is exhausted overboard.

**L1**

**SECONDARY FAILURES**

\*AVNCS VENT

*Continued on the following page*

**ELEC DC BUS 1 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-M-00018555.0012001 / 22 MAR 17

L12

**STATUS**

**INOP SYS**

See below

CAT 3 SINGLE ONLY


**INOP SYS**



ACP 3  
 L. WSHLD HEAT  
 AVNCS VENT  
 REVERSER 1  
 CAT 3 DUAL


CAPT STAT heat  
 L. WNDW HEAT  
 GALLEY FAN  
 BRAKES SYS 1

STBY STAT heat  
 CTR TK PUMP 1   
 GND COOL   
 LAV DET

**Other INOP SYS**

Left cab fan  
 CFDIU  
 L CTR TK XFR valve   
 Eng 1 oil press and qty ind.

COND controller lane A  
 VHF 3   
 Hot air  
 TPIS 

Sel cal  
 RMP 3   
 Capt wiper  
 Brake temps ind.

Note: The warning may be caused by a sub BUS failure. Consequently, only a part of the above-listed systems may be lost.

**ELEC DC BUS 2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-N-00017352.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the DC 2 busbar is not supplied.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-N-00017898.0004001 / 21 MAR 16

AIR DATA SWTG..... F/O3  
BARO REF..... CHECK

L2 Since one FCU channel is lost, crosscheck the barometer reference settings on the FCU and PFD.

L1 ● If DC ESS BUS is failed:  
L/G..... GRVTY EXTN

L2 Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION.

L1 FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**SECONDARY FAILURES**

- \* CAB PRESS
- \* FUEL
- \* WHEEL
- \* F/CTL

Continued on the following page

**ELEC DC BUS 2 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-N-00017899.0013001 / 22 MAR 17

L12

**STATUS**

- **IF ABN CAB V/S:**  
 MAX FL..... 100/MEA
  - **If DC ESS BUS is failed:**  
 L/G..... GRVTY EXTN
- LDG DIST PROC..... APPLY

**INOP SYS**

*See below*

**FUEL CONSUMPT INCRSD**

*See* <sup>(3)</sup>

**FMS PRED UNRELIABLE**

*See* <sup>(4)</sup>

**ENG 2 APPR IDLE ONLY  
 BOTH PFD ON SAME FAC**

- **If DC ESS BUS is failed:**  
 L/G CONTROL NOT AVAIL
- SLATS/FLAPS SLOW  
 CAT 3 SINGLE ONLY

**INOP SYS**

SPLR 1+2+5

VHF 2

R WNDW HEAT

CAT 3 DUAL

R TK PUMP 2

REVERSER 2

Y ELEC PUMP (if selected ON)

ENG 2 LOOP A

ROW/ROP 

ELAC 2<sup>(1)</sup>

F/O STAT

AP 2

FAC 2

CTR TK PUMP 2 

CAB PR 2

BRK SYS 2

FCDC 2

SEC 2+3

R WSLHD HEAT

FCU 2

L TK PUMP 2

LGCIU 2

MAIN GALLEY





ENG 1 LOOP B


LGCIU 1 <sup>(2)</sup>

**Other INOP SYS**

*Continued on the following page*

**ELEC DC BUS 2 FAULT (Cont'd)**

SFCC 2	R cabin fan	F/O wiper
F/O rain rplnt	Eng 1 and 2 fire ext btl 2	Autobrake (due to loss of 2 SECS)
BMC 2	Bleed X feed auto control	RMP 2
FQI channel 2	CTR TK XFR valve R 	SDCU 2 or CIDS  2 SMOKE DETECT
Brake fan 	Eng 2 oil low press and qty ind	R loudspeaker
rudder trim ind	FMGC 2	CDLS 

- Note:**
- The warning may be caused by a sub BUS failure. Consequently, only a part of the above-listed systems may be lost.
  - The flight crew must monitor the CAB V/S, because the proximity sensor of the bulk cargo door  is no longer electrically supplied.

(1) Lost after 30 s, but recovered at landing gear extension.

(2) (If DC ESS BUS is failed)

(3) This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

(4) Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**ELEC DC BUS 1+2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-Q-00017353.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the DC 1 and DC 2 busbars are not supplied.

Flight Phase Inhibition:



*Continued on the following page*



**ELEC DC BUS 1+2 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-Q-00018565.0004001 / 21 MAR 16

BLOWER..... OVRD  
 EXTRACT..... OVRD  
 BARO REF..... CHECK

**L2** Crosscheck the barometer reference settings on the FCU and PFDs.

**L1** FUEL CONSUMPT INCRSD

FMS PRED UNRELIABLE

MAX BRK PR..... 1 000 PSI

**L2** Brake pressure must be limited to approximately 1 000 PSI, since antiskid is lost.

**L1**

**ASSOCIATED PROCEDURES**

**ELEC DC BAT BUS FAULT**

**SECONDARY FAILURES**

- \* CAB PRESS
- \* FUEL
- \* AIR COND
- \* BRAKES
- \* F/CTL

*Continued on the following page*

**ELEC DC BUS 1+2 FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-Q-00018566.0018001 / 22 MAR 17

L12

**STATUS**

MAX BRK PR..... 1000 PSI

INOP SYS

LDG DIST PROC..... APPLY

See below

FUEL CONSUMPT INCRSD

See <sup>(2)</sup>

FMS PRED UNRELIABLE

See <sup>(3)</sup>

ENG 1 APPR IDLE ONLY

ENG 2 APPR IDLE ONLY

BOTH PFD ON SAME FAC

CTR TK FUEL UNUSABLE

APU BAT START NOT AVAIL

SLATS/FLAPS SLOW

CAT 3 SINGLE ONLY

FLS  LIMITED TO F-APP+RAW

**INOP SYS**

SPLR 1+2+5

ELAC 2<sup>(1)</sup>

SEC 2+3

VHF 2

ACP 3

CAPT STAT heat

F/O STAT heat

STBY STAT heat

WSHLD HEAT

WNDW HEAT

AP 2

FCU 2

CAT 3 DUAL

FAC 2

SDCU

ANTI SKID

N/W STRG

LGCIU 2

REVERSER 1+2

CAB PRESS 2

AVNCS VENT

L+R CAB FAN

GALLEY FAN

CRG HEAT 

GND COOL 

MAIN GALLEY

Y ELEC PUMP

Brk sys 1+2

APU FIRE DET

LAV DET

ENG 1 LOOP B

ENG 2 LOOP A

PACK 2

FCDC 2

CTR TK PUMPS










L TK PUMP 2

R TK PUMP 2

Continued on the following page

**ELEC DC BUS 1+2 FAULT (Cont'd)**

**Other INOP SYS**

Selcal	Brake temp indication	Brake fans 
TPIS 	Capt and F/O wipers	Eng 1 and 2 oil pressure and quantity indication
AUTO BRK	Forward (aft) cargo isolation valves 	Manual pressure control
VHF 3 	RMP 2	RMP 3 
CFDIU	Right loudspeakers	SFCC 2
APU ECB	Forward (aft) cargo heat controller 	CDLS 
FMGC 2	Rudder trim indication	BMC 2
FQI channel 2	Eng 1 and 2 fire ext btl 2	X Bleed auto and manual control
Stick and rudder pedals lock (by AP)	Forward (aft) cargo fire extinguishing 	SDCU 2 or CIDS  2 SMOKE DETECT

**Note:** *The warning may be caused by a failure in a sub BUS. Consequently, only a part of the above-listed systems may be lost.*

- (1) *Lost after 30 s, but is recovered at landing gear extension.*
- (2) *This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*
- (3) *Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.*

**ELEC DC EMER CONFIG**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-X-00017359.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the DC 1, DC 2 and DC ESS busbars are not supplied.

Flight Phase Inhibition:



*Continued on the following page*

**ELEC DC EMER CONFIG (Cont'd)**

Ident.: PRO-ABN-ELEC-X-00018557.0006001 / 21 MAR 16

**LAND ASAP**

EMER ELEC PWR.....MAN ON

**L2** *The emergency generator supplies DC ESS BUS.  
But, DC BUS 1, DC BUS 2, and DC BAT BUS are still not supplied.*

**L1** FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**ASSOCIATED PROCEDURES**

**ELEC** **DC BUS 1 + 2 FAULT**

BLOWER.....OVRD  
EXTRACT.....OVRD  
BARO REF.....CHECK

**L2** *Crosscheck the barometer reference settings on the FCU and PFDs.*

**L1** MAX BRK PR.....1 000 PSI

**L2** *Brake pressure must be limited to approximately 1 000 PSI, since antiskid is lost.*

**L1** FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**ASSOCIATED PROCEDURES**

**ELEC** **DC BAT BUS FAULT**

**SECONDARY FAILURES**

- \* CAB PRESS
- \* HYD
- \* FUEL
- \* AIR COND
- \* BRAKES
- \* WHEEL
- \* F/CTL

*Continued on the following page*

**ELEC DC EMER CONFIG (Cont'd)**

Ident.: PRO-ABN-ELEC-X-00018558.0003001 / 21 MAR 16

L12

**STATUS**

MIN RAT SPEED..... 140 KT  
 PROC: GRVTY FUEL FEEDING  
 MAX BRK PR..... 1 000 PSI  
 FUEL GRVTY FEED

LDG DIST PROC..... APPLY

*Refer to the list of STATUS INFO of the ELEC DC BUS 1+2  
 BUS FAULT ECAM alert*

*See <sup>(1)</sup>*

**INOP SYS**

*Refer to the list of INOP SYS ON  
 ECAM of the ELEC DC BUS 1+2  
 FAULT ECAM alert*

**Note:** *To verify the other  
 INOP SYS not  
 displayed on the  
 ECAM, Refer to  
 PRO-ABN-ELEC  
 ELEC DC BUS  
 1+2 FAULT  
 - FWSPAGE  
 and Refer to  
 PRO-ABN-ELEC  
 ELEC DC BAT  
 BUS FAULT -  
 FWSPAGE.*

<sup>(1)</sup> **Note:** *DC ESS BUS is lost at landing gear extension.  
 Consequently, all means of communications are lost since all ACPs are lost.  
 To verify the list of STATUS INFO, Refer to PRO-ABN-ELEC ELEC DC BUS 1+2  
 FAULT - FWSPAGE*

**ELEC DC ESS BUS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-O-00017354.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the DC ESS busbar is not supplied.

Flight Phase Inhibition:



*Continued on the following page*

**ELEC DC ESS BUS FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-O-00012511.0005001 / 05 MAR 13

VHF 2 OR 3..... USE  
 AUDIO SWTG..... SELECT

[2] *ACP 1 and 2 are lost. Therefore, set the AUDIO SWTG rotary selector to CAPT 3 or F/O 3 to recover communications.*

[L1] **BARO REF**..... CHECK

[2] *Crosscheck the barometer reference settings on the FCU and the PFD.*

[L1] **GPWS SYS**..... OFF

● **If DC BUS 2 is failed:**

L/G..... GRVTY EXTN

[2] *Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION.*

[L1] **FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**  
**AVOID ICING CONDITIONS**

**ASSOCIATED PROCEDURES**

**NAV GPWS FAULT**

GPWS..... OFF

[2] *Note: To shut down the engines on ground, use the ENG FIRE pb-sw.*

[L1]

**SECONDARY FAILURES**

- \* CAB PRESS
- \* HYD
- \* F/CTL

*Continued on the following page*



**ELEC DC ESS BUS FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-O-00018671.0012001 / 25 JUL 17

L12



**STATUS**

- **If DC BUS 2 is failed:**  
L/G.....GRVTY EXTN  
LDG DIST PROC..... APPLY  
FUEL CONSUMPT INCRSD  
See <sup>(3)</sup>  
FMS PRED UNRELIABLE  
See <sup>(4)</sup>  
ENG 1 APPR IDLE ONLY  
ENG 2 APPR IDLE ONLY  
BOTH PFD ON SAME FAC
- **If DC BUS 2 is failed:**  
L/G CONTROL NOT AVAIL  
SLATS/FLAPS SLOW  
CAT 3 SINGLE ONLY

**INOP SYS**

See below

**INOP SYS**

- |              |   |  |
|--------------|---|--|
| B HYD        | SPLR 3  | VHF 1  |
| ACP 1+2      | WING A. ICE   | AP 1   |
| A/THR        | FCU 1   | FAC 1  |
| L TK PUMP 1  | R TK PUMP 1   | REV 2  |
| ENG 2 START  | CAB PR 1  | STEEP APPR  |
| VENT EXTRACT | B ELEC PUMP   | GPWS   |
| ENG 1 LOOP A | ENG 2 LOOP B  | FDC 1  |
| LGCIU 1      | LGCIU 2 <sup>(1)</sup>  | ALTN BRK   |
| AUTO BRK     | ROW/ROP  |  |

**Other INOP SYS**


BRK PRESS indicator

Flight interphone

EIU 2 <sup>(2)</sup>

Continued on the following page

**ELEC DC ESS BUS FAULT (Cont'd)**

Capt rain repellent   
HP fuel shutoff valves  
Hyd fire valves Eng 1 and 2  
Left loudspeaker

Avionics air cond valve  
SFCC 1  
Ram air inlet  
DC SHED ESS BUS

Standby compass light  
RMP 1  
ECAM Control Panel

Note: 1. The warning may be caused by a sub BUS failure. Consequently, only a part of the above-listed systems may be lost.

- (1) (If DC BUS 2 is failed)
- (2) Autothrust, eng start and reverser inop.
- (3) This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.
- (4) Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.


**ELEC DC ESS BUS SHED**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-P-00017355.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

 This alert triggers when the DC SHED ESS busbar is not supplied.

Flight Phase Inhibition:



*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ELEC

**ELEC DC ESS BUS SHED (Cont'd)**

Ident.: PRO-ABN-ELEC-P-00012513.0001001 / 30 MAR 12

EXTRACT.....OVRD

**L2** Cooling air is supplied by the air conditioning system, without overboard extraction.

**L1** AVOID ICING CONDITIONS

**SECONDARY FAILURES**

\*AVNCS VENT

*Continued on the following page*

**ELEC DC ESS BUS SHED (Cont'd)**

Ident.: PRO-ABN-ELEC-P-00018561.0005001 / 17 MAR 17

L12

**STATUS**

**AVOID ICING CONDITIONS**

● **IF SEVERE ICE ACCRETION**

MIN SPD.....VLS + 10/G DOT

MANEUVER WITH CARE

LDG DIST PROC.....APPLY

**BOTH PFD ON SAME FAC**

**CAT 3 SINGLE ONLY**

**INOP SYS**

WING A. ICE

AP 1

CAT 3 DUAL

FAC 1

VENT EXTRACT

AFT CRG HEAT 

FWD CRG HEAT 

AFT CRG VENT 

FWD CRG VENT 

FCDC 1

ROW/ROP 

*See below*

**Other INOP SYS**

Passenger oxygen mask (auto drop out)


X BLEED valve man ctl

FMGC 1

STBY ALTI vib

FQ1 channel 1

BMC 1

SDCU 1 or CIDS  1 SMOKE DETECT

**Note:** *The warning may be caused by a failure in a sub BUS. Consequently only a part of the systems listed above may be lost.*

*Continued on the following page*

**ELEC DC ESS BUS SHED (Cont'd)**

**ELEC EMER CONFIG**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-R-00018283.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the AC 1 and AC 2 busbars are not supplied.

Flight Phase Inhibition:



*Continued on the following page*

**ELEC EMER CONFIG (Cont'd)**

Ident.: PRO-ABN-ELEC-R-00018642.0006001 / 22 MAR 17

**LAND ASAP**

MIN RAT SPEED.....140 KT

**CAUTION** The RAT is capable of supplying the EMER GEN down to 125 kt, except during flare.

GEN 1 + 2..... OFF THEN ON

● **IF UNSUCCESSFUL:**

BUS TIE..... OFF

<sup>L2</sup> Setting BUS TIE pb-sw to OFF segregates both generator channels.

<sup>L1</sup> GEN 1 + 2.....OFF THEN ON

<sup>L2</sup> Note: If any generator reset is successful, reset both FAC's.

<sup>L1</sup> EMER ELEC PWR (IF EMER GEN NOT IN LINE)..... MAN ON  
 ENG MODE SEL..... IGN

<sup>L2</sup> Engines are fed by gravity only.

<sup>L1</sup> VHF1/HF1 <math>\leftrightarrow</math> /ATC1.....USE

<sup>L2</sup> Only VHF 1, HF 1 and ATC 1 are supplied in the electrical emergency configuration.

Note: FMGC 1, which is lost temporarily, can be regained by flight crew passing through the MCDU MENU page.

<sup>L1</sup> **FUEL GRVTY FEED**

<sup>L2</sup> Engines are fed by gravity only. Avoid negative Gs.

<sup>L1</sup> **PROC: GRVTY FUEL FEEDING**

<sup>L2</sup> Apply GRVTY FUEL FEEDING procedure (Refer to PRO-ABN-FUEL [QRH] GRAVITY FUEL FEEDING).

<sup>L1</sup> FAC 1..... OFF THEN ON

<sup>L2</sup> The rudder trim is recovered, although no indication is available.

<sup>L1</sup> BUS TIE.....AUTO

<sup>L2</sup> Setting BUS TIE pb-sw to AUTO enables the APU to take an available electrical channel.

<sup>L1</sup> APU (IF AVAIL)..... START

<sup>L2</sup> APU start is not available for 45 s after the loss of both engine generators. This 45 s delay prevents any interference with emergency generator coupling.

Continued on the following page

**ELEC EMER CONFIG (Cont'd)**

*If the APU is available, the APU may be started when below FL 250.*

**L1** **BLOWER + EXTRACT** .....OVRD

**L2** Cooling air is supplied by the air conditioning system and exhausted overboard through the extract valve.

**L1** **FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

**L2** Note: On IAE powered aircraft, the warning “EPR MODE FAULT N1 DEGRADED MODE” is displayed.

**L1**

**————— ASSOCIATED PROCEDURES —————**

**FLT CTL ALTN LAW**  
**(PROT LOST)**

**MAX SPEED** .....320 KT

**L2** Speed limited due to loss of flight control normal laws.

*Continued on the following page*

**ELEC EMER CONFIG (Cont'd)**


Ident.: PRO-ABN-ELEC-R-00018643.0023001 / 22 MAR 17

L12

**STATUS**

**INOP SYS**

MIN RAT SPEED..... 140 KT  
 MAX SPEED..... 320 KT  
 MAX BRK PR..... 1 000 PSI  
 FUEL GRVTY FEED  
 AVOID NEGATIVE G FACTOR

F/CTL PROT  
 REVERSER 1+2  
 ADR 2+3  
 IR 2  
 RA 1+2  
 SPLR 1+2+5  
 ELAC 2  
 SEC 2+3  
 A/CALL OUT  
 AP 1+2  
 A/THR  
 FUEL PUMPS  
 ANTI SKID  
 N/W STRG  
 CAT 2  
 STEEP APPR 

*Note: If there are discrepancies between airspeed indications on the Captain's PFD and on the STBY indicator, disregard the STBY indication (probe not deiced).*

**APPR PROC**

FOR LDG..... USE FLAP 3  
*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

APPR SPD..... VREF +10/140 KT  
*The approach speed must be at least minimum RAT speed (140 kt).*

LDG DIST PROC..... APPLY

FUEL CONSUMPT INCRSD

See <sup>(2)</sup>

FMS PRED UNRELIABLE

See <sup>(3)</sup>

ALTN LAW: PROT LOST  
 WHEN L/G DN: DIRECT LAW

SLATS/FLAPS SLOW

FLS  LIMITED TO F-APP + RAW

See <sup>(4)</sup>

See <sup>(1)</sup>

<sup>(1)</sup> For other systems' status: Refer to the "ELEC EMER CONFIG SYS REMAINING" table.

*Continued on the following page*



**ELEC EMER CONFIG (Cont'd)**

- (2) *This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*
- (3) *Disregard FMS fuel predictions and refer to QRH/PER-B Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.*
- (4) Note: *In ELEC EMER configuration, the center tank fuel is unusable.*

**ELEC EMER GEN 1 LINE OFF**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-AB-00017382.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the GEN 1 LINE pb-sw is abnormally set to OFF position.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-AB-00012550.0001001 / 25 FEB 14

- L2 With the GEN 1 LINE pb-sw (on the EMER ELEC PWR panel) in the OFF position, the GEN 1 line contactor is open and GEN 2 supplies the AC BUS 1 channel.

- L1 Crew awareness.

- L2 Set the GEN 1 LINE pb-sw to ON.

**ELEC ESS BUSES ON BAT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-AA-00018284.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the DC ESS and AC ESS busbars are supplied by the batteries.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-AA-00018021.0002001 / 21 MAR 16

- [L2] AC ESS BUS is supplied via the static inverter.

[L1] **LAND ASAP**

MIN RAT SPEED.....140 KT

- [L2] *Displayed, if the RAT is extended.*

[L1] EMER ELEC PWR.....MAN ON

- [L2] ESS BUSES are supplied by the emergency generator

**ELEC GEN 1(2) OR APU GEN OVERLOAD**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-T-00017363.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the load of one generator is above 100% of rated output.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-T-00018023.0002001 / 21 MAR 16

GALY/CAB.....OFF

Ident.: PRO-ABN-ELEC-T-00018024.0002001 / 21 MAR 16

**STATUS**

**INOP SYS**

GALY/CAB

**ELEC GEN 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-B-00017360.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when:

- The protection trip is initiated by the associated GCU, or
- The line contactor is open with the associated GEN pb-sw set to ON.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-B-00018025.0001001 / 21 MAR 16

GEN (AFFECTED).....OFF THEN ON

● **IF UNSUCCESSFUL:**

GEN (AFFECTED)..... OFF

*Continued on the following page*

**ELEC GEN 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-ELEC-B-00018026.0001001 / 21 MAR 16

L12

**STATUS**

Note: If available, the APU may be started, and the APU GEN used.

CAT 3 SINGLE ONLY

**INOP SYS**

MAIN GALLEY <sup>(1)</sup>  
GEN 1(2)  
CAT 3 DUAL

<sup>(1)</sup> (only if APU GEN is not online)

**ELEC GEN 1(2) OFF**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-C-00017361.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the GEN 1(2) pb-sw is set to OFF and no failure is detected.

Flight Phase Inhibition:



Continued on the following page

**ELEC GEN 1(2) OFF (Cont'd)**

Ident.: PRO-ABN-ELEC-C-00018027.0001001 / 21 MAR 16

**L2** Turn the affected GEN ON.

**L1** Crew awareness.

Ident.: PRO-ABN-ELEC-C-00018028.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

**CAT 3 SINGLE ONLY**

MAIN GALLEY <sup>(1)</sup>  
GEN 1(2)  
CAT 3 DUAL

<sup>(1)</sup> (only if APU GEN is not online)

**ELEC IDG 1(2) DISCONNECTED**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-D-00017366.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the IDG 1(2) is disconnected.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-D-00018029.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-ELEC-D-00018030.0001001 / 21 MAR 16

L12

**STATUS**

Note: If available, the APU may be started, and the APU GEN used.

**CAT 3 SINGLE ONLY**

**INOP SYS**

MAIN GALLEY <sup>(1)</sup>  
 GEN 1(2)  
 CAT 3 DUAL

<sup>(1)</sup> (only if APU GEN is not online)

**ELEC IDG 1(2) OIL LO PR/OVHT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-A-00018285.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- ② The alert **ELEC IDG 1(2) OIL LO PR** triggers when the IDG 1(2) oil pressure is low.
- The alert **ELEC IDG 1(2) OIL OVHT** triggers when the IDG 1(2) outlet oil temperature rises above 185 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-A-00018031.0001001 / 21 MAR 16

**IDG (AFFECTED).....OFF**

- ② *If the associated engine is running, the IDG (integrated drive generator) must be disconnected from the engine at, or above, idle to prevent damage to the disconnect mechanism.*
- Press the IDG pb-sw until the GEN FAULT light comes on. However, do not press for more than 3 s, to avoid damage to the disengage solenoid*
- The IDG FAULT light goes off, when the IDG is disconnected.*

*Continued on the following page*



**ELEC IDG 1(2) OIL LO PR/OVHT (Cont'd)**

Ident.: PRO-ABN-ELEC-A-00018032.0001001 / 21 MAR 16

L12

**STATUS**

Note: If available, the APU may be started and the APU GEN used.

CAT 3 SINGLE ONLY

**INOP SYS**

MAIN GALLEY <sup>(1)</sup>  
 GEN 1(2)  
 CAT 3 DUAL

<sup>(1)</sup> (only if APU GEN is not online)

**ELEC STATIC INV FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ELEC-AC-00017380.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

The alert triggers when the static inverter is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-AC-00012549.0001001 / 25 FEB 14

Crew awareness.

**ELEC TR 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ELEC-U-00017373.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the TR 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ELEC-U-00012541.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-ELEC-U-00018531.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAT 3 SINGLE ONLY

TR 1(2)  
CAT 3 DUAL

**[QRH] ENG DUAL FAILURE - FUEL REMAINING**

Applicable to: ALL

Ident.: PRO-ABN-ENG-X-00012309.0061001 / 17 MAR 17

As long as none of the engines recover, the flight crew must apply this paper procedure when required by the ECAM **ENG DUAL FAILURE** procedure. If time permits, clear ECAM alerts, and check the ECAM STATUS page.

**LAND ASAP**


OPTIMUM RELIGHT SPD..... 300 kt

**PITCH TARGET In case of speed indication failure:**

Gross Weight	Pitch (°)
At or below 50 000 kg/110 000 lb	-4.5
60 000 kg/132 000 lb	-3.5
70 000 kg/154 000 lb	-2.5

AVERAGE GLIDING DISTANCE : 2 NM / 1000 FT (300kt NO WIND)

DETERMINE LANDING STRATEGY

VHF1/HF1  /ATC1.....USE  
 ATC.....NOTIFY  
 TRANSPONDER.....SELECT A7700

Notify air traffic control of the nature of the emergency, and state intentions. If there is no contact with air traffic control Switch to code A7700, or transmit a distress message on one of the following frequencies: VHF frequency 121.5 MHz, HF 2 182 kHz or 8 364 kHz.

● **If no relight after 30 s:**

ENG MASTERS.....OFF 30 S / ON  
 Unassisted start attempts can be repeated until successful, or until APU bleed is available.

● **If unsuccessful:**

CREW OXY MASKS (above FL 100)..... ON  
 Cabin altitude will increase, due to the lack of engine bleed: The **EXCESS CAB ALT** warning could be triggered. Depending on the situation, to gain gliding distance, the flight crew may disregard the ECAM emergency descent requirement, because passengers will be provided with oxygen for a sufficient period of time.

APU (IF AVAIL).....START  
 If the APU is available, it may be started when below FL 250 and the APU BLEED may be used for engine start below FL 200.

WING ANTI ICE.....OFF

Continued on the following page

**[QRH] ENG DUAL FAILURE - FUEL REMAINING (Cont'd)**

APU BLEED.....ON

● **In sequence:**

ENG MASTERS (all non running engines)..... OFF

After 30 s

ENG MASTERS (one at a time).....ON

*Between each attempt to relight the same engine, wait at least 30 s with the associated  
 ENG MASTER lever set to OFF.*

*Continued on the following page*

**[QRH] ENG DUAL FAILURE - FUEL REMAINING (Cont'd)**

Ident.: PRO-ABN-ENG-X-00012310.0041001 / 17 MAR 17

- **When APU bleed is available or if engine restart is definitively considered impossible:**

OPTIMUM SPEED WITH ALL ENGINES INOPERATIVE (KNOTS)			
Gross Weight (1 000 kg)	At or below FL 200	FL 300	FL 400
78	241	251	261
76	237	247	257
72	229	239	249
68	221	231	241
64	213	223	233
60	205	215	225
56	197	207	217
52	189	199	209
48	181	191	201
44	173	183	193
40	165	175	185

AVERAGE GLIDING DISTANCE: 2.5 NM / 1000 FT (NO WIND)

AVERAGE RATE OF DESCENT: 1 600 FT/MIN

PREPARE CABIN AND COCKPIT

- Loose equipment secured.
- Survival equipments prepared.
- Belts and shoulder harnesses locked.

SIGNS..... ON

COMMERCIAL..... OFF

USE RUDDER WITH CARE

*As hydraulic power is only available from the RAT, avoid large and rapid rudder deflection.*

- **When below FL 150:**

RAM AIR..... ON

Ident.: PRO-ABN-ENG-X-00012311.0001001 / 17 MAR 17

BARO REF..... SET

CREW MASKS/OXY SUPPLY (below FL 100)..... OFF

ELT  (when conditions permit)..... ON

*Continued on the following page*



**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

ENG

**[QRH] ENG DUAL FAILURE - FUEL REMAINING (Cont'd)**

Ident.: PRO-ABN-ENG-X-00012312.0065001 / 09 MAY 17

● **If forced landing anticipated:**

AVERAGE GLIDING DISTANCE 1.2NM / 1000FT (CONF3, L/G DOWN, NO WIND)

● **For approach:**

FOR LANDING : USE FLAP 3

SLATS AVAIL ONLY

MIN APPR SPEED : 150 kt

VAPP..... DETERMINE

Gross Weight (1 000 kg)	40	44	48	52	56	60	64	68	72	76	78
VAPP	150	150	150	150	150	155	159	163	167	171	173

● **At a suitable altitude (not below 3 000 ft AGL):**

● **When in CONF 3 and VAPP:**

GRAVITY GEAR EXTN handcrank..... PULL AND TURN

FLT CTL DIRECT LAW

MAN PITCH TRIM NOT AVAILABLE

● **When L/G downlocked:**

L/G lever.....DOWN

APPROACH SPEED..... ADJUST

MAX SPEED : 200 kt

ADJUST SPEED TO REACH LANDING FIELD

SPLRs.....ARM

MAX BRK PR : 1 000 PSI

● **At 2 000 ft AGL:**

CABIN CREW..... NOTIFY FOR LANDING

● **At 500 ft AGL:**

BRACE FOR IMPACT.....ORDER

● **At touchdown:**

ENG MASTERS..... OFF

APU MASTER SW..... OFF

BRAKES ON ACCU ONLY

*Continued on the following page*

**[QRH] ENG DUAL FAILURE - FUEL REMAINING (Cont'd)**


● **When aircraft stopped:**

PARKING BRK.....ON  
 ATC.....NOTIFY  
 FIRE pb (ENGs & APU).....PUSH  
 AGENT (ENGs & APU).....DISCH

■ **If evacuation required:**

EVACUATION..... INITIATE

*Make a short and precise announcement to order the emergency evacuation.*

*Press the EVAC COMMAND pb .*

ELT  .....CHECK EMITTING

*If not, switch on the transmitter.*

■ **If evacuation not required:**

CABIN CREW and PASSENGERS (PA).....NOTIFY

*Continued on the following page*

**[QRH] ENG DUAL FAILURE - FUEL REMAINING (Cont'd)**

Ident.: PRO-ABN-ENG-X-00012313.0065001 / 17 MAR 17


- **If ditching anticipated:**
  - **For approach:**  
FOR LANDING : USE FLAP 3  
SLATS AVAIL ONLY  
MIN APPR SPEED : 150 kt  
VAPP..... DETERMINE

Gross Weight (1 000 kg)	40	44	48	52	56	60	64	68	72	76	78
VAPP	150	150	150	150	150	155	159	163	167	171	173

- **At a suitable altitude (not below 3 000 ft AGL):**

KEEP LANDING GEAR UP  
FOR FLARE: TARGET PITCH 11 ° & MIN V/S

*Note: Prefer ditching parallel to the swell. If that causes a strong crosswind, ditch into the wind.*

- **At 2 000 ft AGL:**  
CABIN CREW..... NOTIFY FOR DITCHING  
DITCHING pb..... ON
- **At 500 ft AGL:**  
BRACE FOR IMPACT..... ORDER
- **At touchdown:**  
ENG MASTERS..... OFF  
APU MASTER SW..... OFF
- **After ditching:**  
ATC (VHF 1)..... NOTIFY  
FIRE pb (ENGs & APU)..... PUSH  
AGENTs (ENGs & APU)..... DISCH  
EVACUATION..... INITIATE  
ELT  ..... CHECK EMITTING  
*If not, switch on the transmitter.*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

**[QRH] ENG DUAL FAILURE - NO FUEL REMAINING**

Applicable to: ALL

Ident.: PRO-ABN-ENG-Y-00012602.0108001 / 17 MAR 17

The flight crew must apply this paper procedure when required by the **ENG DUAL FAILURE** procedure. If time permits, clear ECAM alerts, and check the ECAM STATUS page.


OPTIMUM SPEED..... 220 kt / GREEN DOT  
*Initially, fly 220 kt, because the PFD may not display the correct green dot speed. Then fly the green dot speed according to the following table:*

**GREEN DOT SPEED WITH ALL ENGINES INOPERATIVE (KNOTS)**

Gross Weight (1000 kg)	At or below FL 200	FL 300	FL 400
68	221	231	241
64	213	223	233
60	205	215	225
56	197	207	217
52	189	199	209
48	181	191	201
44	173	183	193
40	165	175	185

AVERAGE GLIDING DISTANCE: 2.5 NM / 1000 FT (GREEN DOT NO WIND)  
 AVERAGE RATE OF DESCENT: 1600 FT/MIN

DETERMINE LANDING STRATEGY

VHF1/HF1  /ATC1.....USE  
 ATC.....NOTIFY  
 TRANSPONDER.....SELECT A7700

*Notify air traffic control of the nature of the emergency, and state intentions. Switch to code A7700, or transmit a distress message on one of the following frequencies: VHF frequency 121.5 MHz, HF 2 182 kHz or 8 364 kHz.*

CREW OXY MASKS (above FL 100).....ON

*Cabin altitude will increase due to the lack of engine bleed: The **EXCESS CAB ALT** warning could be triggered. Depending on the situation, to gain gliding distance, the flight crew may disregard the ECAM emergency descent requirement, because passengers will be provided with oxygen for a sufficient period of time.*

PREPARE CABIN AND COCKPIT

- Loose equipment secured.

*Continued on the following page*

**[QRH] ENG DUAL FAILURE - NO FUEL REMAINING (Cont'd)**

- Survival equipments prepared.
- Belts and shoulder harnesses locked.

SIGNS.....ON

COMMERCIAL.....OFF

USE RUDDER WITH CARE

*As hydraulic power is only available from the RAT, avoid large and rapid rudder deflection.*

● **When below FL 150:**

RAM AIR.....ON

*Switch ON the RAM AIR to ensure complete depressurization.*

Ident.: PRO-ABN-ENG-Y-00012317.0001001 / 17 MAR 17

BARO REF..... SET

CREW MASKS/OXY SUPPLY (below FL 100)..... OFF

ELT  (when conditions permit)..... ON

*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

**[QRH] ENG DUAL FAILURE - NO FUEL REMAINING (Cont'd)**

Ident.: PRO-ABN-ENG-Y-00012318.0065001 / 09 MAY 17

● **If forced landing anticipated:**

AVERAGE GLIDING DISTANCE 1.2NM / 1000FT (CONF3, L/G DOWN, NO WIND)

● **For approach:**

FOR LANDING : USE FLAP 3

SLATS AVAIL ONLY

MIN APPR SPEED : 150 kt

VAPP..... DETERMINE

Gross Weight (1000 kg)	40	44	48	52	56	60	64	68	72	76	78
VAPP	150	150	150	150	150	155	159	163	167	171	173

● **At a suitable altitude (not below 3 000 ft AGL):**

● **When in CONF 3 and VAPP :**

GRAVITY GEAR EXTN handcrank..... PULL AND TURN

FLT CTL DIRECT LAW

MAN PITCH TRIM NOT AVAILABLE

● **When L/G downlocked :**

L/G lever.....DOWN

APPROACH SPEED..... ADJUST

ADJUST SPEED TO REACH LANDING FIELD

MAX SPEED : 200 kt

SPLRs..... ARM

MAX BRK PR : 1 000 PSI

● **At 2 000 ft AGL:**

CABIN CREW..... NOTIFY FOR LANDING

● **At 500 ft AGL:**

BRACE FOR IMPACT..... ORDER

● **At touchdown:**

ENG MASTERS..... OFF

BRAKES ON ACCU ONLY

*Continued on the following page*

**[QRH] ENG DUAL FAILURE - NO FUEL REMAINING (Cont'd)**

● **When aircraft stopped:**

PARKING BRK.....ON  
 ATC.....NOTIFY

■ **If evacuation required:**

EVACUATION..... INITIATE

*Make a short and precise announcement to order the emergency evacuation.*

*Press the EVAC COMMAND pb .*

ELT  ..... CHECK EMITTING

*If not, switch on the transmitter*

■ **If evacuation not required:**

CABIN CREW and PASSENGERS (PA).....NOTIFY


*Continued on the following page*

**[QRH] ENG DUAL FAILURE - NO FUEL REMAINING (Cont'd)**

Ident.: PRO-ABN-ENG-Y-00012319.0065001 / 17 MAR 17

- **If ditching anticipated:**
  - **For approach:**  
 FOR LANDING : USE FLAP 3  
 SLATS AVAIL ONLY  
 MIN APPR SPEED : 150 kt  
 VAPP..... DETERMINE

Gross Weight (1 000 kg)	40	44	48	52	56	60	64	68	72	76	78
VAPP	150	150	150	150	150	155	159	163	167	171	173


- **At a suitable altitude (not below 3 000 ft AGL):**  
 KEEP LANDING GEAR UP  
 FOR FLARE: TARGET PITCH 11 ° & MIN V/S  
*Note: Prefer ditching parallel to the swell. If that causes a strong crosswind, ditch into the wind.*
- **At 2 000 ft AGL:**  
 CABIN CREW..... NOTIFY FOR DITCHING  
 DITCHING pb..... ON
- **At 500 ft AGL:**  
 BRACE FOR IMPACT..... ORDER
- **At touchdown:**  
 ENG MASTERS..... OFF
- **After ditching:**  
 ATC (VHF 1)..... NOTIFY  
 EVACUATION..... INITIATE  
 ELT  ..... CHECK EMITTING  
*If not, switch on the transmitter.*

**[QRH] ENG RELIGHT**  
**IN FLIGHT**

Ident.: PRO-ABN-ENG-00012594.0026001 / 17 MAR 17

Applicable to: ALL

Engine Relight Envelope



ENG MASTER (affected engine)..... OFF  
 THR LEVER (affected engine).....Check IDLE  
 ENG MODE sel.....IGN  
 X BLEED..... OPEN

*Continued on the following page*

**[QRH] ENG RELIGHT (Cont'd)**  
**IN FLIGHT**

*If outside the windmilling start envelope, the FADEC will open the starter valve.*

WING ANTI ICE (for starter assist).....OFF  
 ENG MASTER (affected engine)..... ON  
 ENG PARAMETERS (N2, EGT)..... MONITOR


*Engine light up should be achieved within 30 s after fuel flow increases.*

**AUTOMATIC START ABORT NOT AVAIL**

*Be aware that, unlike the procedure for auto start on ground, the crew must take appropriate action in case of an abnormal start.*

*Monitor N2. If uncertain about successful relight, move the thrust lever forward and check engine response.*

■ **When idle reached (ENG AVAIL):**

ENG MODE sel..... NORM  
 TCAS MODE sel  ..... TA/RA

*Check that the selector is at TA /RA since, if the **ENG SHUT DOWN** procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN) has been applied, the TCAS mode selector may have been set to the TA position.*

X BLEED..... AUTO  
 Affected SYS..... RESTORE

■ **If no relight:**

ENG MASTER (affected engine).....OFF

*Wait 30 s before attempting a new start (to drain the engine).*

**[QRH] ENGINE TAILPIPE FIRE**

Ident.: PRO-ABN-ENG-00017781.0001001 / 17 MAR 17

Applicable to: ALL

Internal engine fire may be encountered during engine start or engine shutdown.  
Internal engine fire may be seen by the ground crew, or the EGT may fail to decrease after the ENG MASTER lever is set to OFF.

**CAUTION** External fire agents can cause severe corrosive damage. Consider the use of external fire agents only if the following procedure does not stop engine tailpipe fire.

ENG MASTER (affected engine) ..... OFF

*Note:* Do not press the engine fire pushbutton, since this would cut off the FADEC power supply, which would prevent motoring sequence.

ENG MAN START pb (affected engine)..... OFF  
ESTABLISH AIR BLEED PRESS

Select the APU, or opposite BLEED, to motor the engine.

If APU BLEED is not available, and the opposite engine is shut down, connect external pneumatic power (if readily available).

BEACON ..... ON  
ENG MODE sel..... CRANK  
ENG MAN START pb (affected engine)..... ON

For aircraft equipped with IAE or PW6000 engines, the start valve automatically reopens, when N2 is below 10 %.

For aircraft equipped with CFM 56-5A/5B engines, the start valve automatically reopens, when N2 is below 20 %

For aircraft equipped with CFM LEAP-1A engines, the start valve automatically reopens, when N2 is below approximately 60 %

● **When fire stopped:**

ENG MAN START pb (affected engine).....OFF  
ENG MODE sel.....NORM

Maintenance action is due.



**[QRH] HIGH ENGINE VIBRATION**

Ident.: PRO-ABN-ENG-00012294.0006001 / 17 MAR 17

Applicable to: ALL

The VIB advisory on ECAM (N1 ≥ 6 units, N2 ≥ 4.3 units) is mainly a guideline for the flight crew to monitor engine parameters more closely.

The ECAM vibration advisory alone does not require engine shut down.

- Note:
1. High engine vibration may be accompanied by cockpit and cabin smoke and/or the smell of burning. This may be due only to compressor blade tip contact with associated abradable seals.
  2. High N1 vibration are generally accompanied by perceivable airframe vibrations. High N2 vibration can occur without perceivable airframe vibrations.

ENG PARAMETERS ..... CHECK

Check engine parameters and especially EGT; crosscheck with other engine. Report in maintenance log.

■ **If icing suspected:**

An increase of engine vibration in icing conditions with or without engine anti-ice may be due to fan blades and/or spinner icing. Icing may be suspected if N1 vibration occurs without other engine parameters variation.

A/THR ..... OFF  
 THRUST (one engine at a time)..... IDLE THEN INCREASE N1 > 80 %

*Reduce thrust to idle if flight conditions permit.*

*If ENG ANTI ICE is off, switch it ON at idle fan speed, one engine after the other with approximately 30 s interval.*

*To shed ice, it may be necessary to perform several thrust variations between idle and a thrust compatible with the flight phase. For efficient ice shedding, thrust should be increased to at least 80% N1 if flight conditions permit.*

*After each thrust variation, vibrations should decrease, indicating the progress of the ice shedding.*

*When the ice is shed, vibrations should return to normal and the flight crew can resume normal engine operation.*

■ **If icing not suspected:**

● **If above vibration advisory and flight conditions permit:**

THRUST (affected engine)..... REDUCE BELOW ADVISORY THRESHOLD

● **After landing: SHUT DOWN ENGINE WHEN POSSIBLE**

**[QRH] ON GROUND - NON ENG SHUTDOWN AFTER ENG MASTER OFF**

Ident.: PRO-ABN-ENG-00020795.0001001 / 17 MAR 17

Applicable to: ALL

The normal procedure to shut down an engine is to set the ENG MASTER lever to OFF. In the case where the engine does not shut down as expected, use the following procedure:

ECAM FUEL PAGE..... SELECT  
LP FUEL VALVE POSITION (affected engine)..... CHECK

■ **If LP fuel valve closed (cross line amber):**

NO CREW ACTION

■ **If LP fuel valve open:**

ENG FIRE pb-sw (affected engine)..... PRESS

*Using the ENG FIRE pb-sw will force the LP fuel valve to close. The engine will shut down after a time delay.*

GROUND STAFF..... NOTIFY

IN BOTH CASES, ENGINE WILL SHUT DOWN AFTER A TIME DELAY UP TO 2 MIN 30 S

*The engine shuts down when the remaining fuel between the LP fuel valve and the nozzles is burned. The time delay for engine shutdown depends on airport altitude and fuel recirculation system operation.*

**[QRH] ONE ENGINE INOPERATIVE - CIRCLING APPROACH**

Ident.: PRO-ABN-ENG-00010682.0004001 / 17 MAR 17

Applicable to: ALL

MAXIMUM WEIGHT FOR CIRCLING IN CONF 3 WITH GEAR DOWN (1000 KG)								
OAT (°C)	AIRPORT ELEVATION (feet)							
	0	2 000	4 000	6 000	8 000	10 000	12 000	14 000
0	77	76	69	63	58	53	48	45
5	77	76	69	63	58	53	48	45
10	77	76	69	63	58	53	48	45
15	77	76	69	63	58	53	48	45
20	77	76	69	63	58	53	48	45
25	77	75	69	63	58	53	48	45
30	77	72	68	63	58	53	48	
35	74	70	66	63	56	51		
40	71	67	63	59				
45	69	65	61					
50	67	63						
55	64							

● **If aircraft weight above maximum weight for circling in CONF 3 with gear down:**

DELAY GEAR EXTENSION TO MAINTAIN LEVEL FLIGHT

*The aircraft cannot maintain level flight, in CONF 3 and with the landing gear down.*

FOR LANDING: USE FLAP 3

*CONF 3 is preferred, to minimize a configuration change in short final.*

GPWS LDG FLAP 3.....ON

- Note:
- *If circling below 750 ft RA, "L/G GEAR NOT DOWN" alert will trigger. The pilot can cancel the aural warning by pressing the EMER CANC pb.*
  - *If the landing gear is not downlocked at 500 ft RA , GPWS "TOO LOW GEAR" aural alert will trigger.*

**[QRH] ONE ENGINE INOPERATIVE - STRAIGHT-IN APPROACH**

Ident.: PRO-ABN-ENG-00010681.0001001 / 17 MAR 17

Applicable to: ALL

- If NO level off expected during final approach:  
DELAY CONF FULL UNTILL ESTABLISHED ON FINAL DESCENT
- If level off expected during final approach:  
FOR LANDING: USE CONF 3

**ENG 1(2) BLEED STATUS FAULT  
(IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-ENG-W-00017963.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the status of one of the following valves is not received by the FADEC active channel:
- Bleed valves, or
  - Pack valves, or
  - Wing and engine anti ice valves, or
  - Cross-bleed valve.

Flight Phase Inhibition:



*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

**ENG 1(2) BLEED STATUS FAULT (Cont'd)**  
**(IN FLIGHT)**

Ident.: PRO-ABN-ENG-W-00018707.0001001 / 21 MAR 16

- If ENG ANTI ICE on:  
 ENG MODE SEL.....IGN

Ident.: PRO-ABN-ENG-W-00012303.0001001 / 17 AUG 10

**STATUS**

ENG 1(2) HI GND IDLE

**ENG 1(2) BLEED STATUS FAULT  
(ON GROUND)**

Applicable to: ALL

Ident.: PRO-ABN-ENG-V-00017965.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the status of one of the following valves is not received by the FADEC active channel:

- Bleed valves, or
- Pack valves, or
- Wing and engine anti ice valves, or
- Cross-bleed valve.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) BLEED STATUS FAULT (Cont'd)**  
**(ON GROUND)**

Ident.: PRO-ABN-ENG-V-00018708.0001001 / 21 MAR 16

**L2 HI GND IDLE**

*FADEC increases minimum idle as if valves were opened.*

**L1 ● If ENG ANTI ICE on:**  
**ENG MODE SEL..... IGN**

**L2** *When ENG anti ice is on, there is no automatic selection of continuous relight since FADEC does not know position of engine anti ice valves position.*

**L1 ● BEFORE T.O.:**  
**PACK (ASSOCIATED SIDE)..... OFF**

**L2** *Associated pack must be closed to reduce risk of excessive EGT.*

Ident.: PRO-ABN-ENG-V-00012301.0001001 / 17 AUG 10

**STATUS**

**ENG 1(2) HI GND IDLE**

**ENG COMPRESSOR VANE**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CY-00017907.0001001 / 31 AUG 17

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when there is a loss of the redundancy (i.e. one channel is detected faulty) of the compressor vane (i.e. VBV, VSV) control system on both engines. The control of the compressor vane is still fully operative on both engines.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CY-00017757.0001001 / 21 MAR 16

Crew awareness.



**ENG 1(2) COMPRESSOR VANE**

Applicable to: ALL

Ident.: PRO-ABN-ENG-N-00017966.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when either Variable Bleed Valve (VBV) or Variable Stator Vane (VSV) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-N-00017655.0003001 / 21 MAR 17

● **On ground:**

THR LEVERS (AFFECTED).....IDLE  
ENG MASTER (AFFECTED).....OFF

Depending on the type of failure, one of the following two messages is displayed:

AVOID RAPID THR CHANGES or

*If the A/THR is engaged, adjust the thrust levers to align the thrust lever commands with actual N1 and disconnect A/THR.*

ENG (AFFECTED) SLOW RESPONSE

*Continued on the following page*

**ENG 1(2) COMPRESSOR VANE (Cont'd)**

Ident.: PRO-ABN-ENG-N-00012155.0001001 / 17 AUG 10

**STATUS**

AVOID RAPID THR CHANGES

ENG (affected) SLOW RESPONSE

**ENG 1(2) CTL VALVE FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-Q-00017967.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when:
- The Burner Staging Valve (BSV) is failed, or
  - The HP Turbine Clearance (HPTC) system is failed, or
  - The Rotor Active Clearance Control (RACC) system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-Q-00018709.0001001 / 21 MAR 16

MAX N2.....96 %

- L2 Retard associated thrust lever to limit N2 to 96 %.

*Continued on the following page*

**ENG 1(2) CTL VALVE FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-Q-00012233.0001001 / 17 AUG 10

<b>STATUS</b>
MAX ENG (AFFECTED) N2.....96 %

**ENG DUAL FAILURE**

Applicable to: ALL

Ident.: PRO-ABN-ENG-S-00017909.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the two engines are failed.

Flight Phase Inhibition:

ELEC PWR	1ST ENG STARTED	1ST ENG TO PWR	80 kt	LIFTOFF	1500 ft	800 ft	TOUCHDOWN	80 kt	2ND ENG SHUTDN	5MN AFTER
1	2	3	4	5	6	7	8	9	10	10

*Continued on the following page*

**ENG DUAL FAILURE (Cont'd)**

Ident.: PRO-ABN-ENG-S-00012282.0370001 / 21 MAR 17

[L2] This warning inhibits the **ELEC EMER CONFIG** warning, and provides the flight crew with the immediate actions to take in the case of a dual engine failure. This procedure then directs the flight crew to apply the applicable QRH procedure, depending on if there is fuel or not.

When applying the **ENG DUAL FAILURE** QRH procedure:

- If one or more engines are recovered, apply the corresponding ECAM procedure instead
- If no engines are recovered, continue to apply the **ENG DUAL FAILURE** QRH procedure. If time permits, clear ECAM alerts, and check the ECAM STATUS page.

[L1] **LAND ASAP**  
**EMER ELEC PWR (IF EMER GEN NOT IN LINE).....MAN ON**

[L2] *Pressing EMER ELEC PWR MAN ON pb allows extension of RAT and emergency generator coupling.*

[L1] **THR LEVERS..... IDLE**  
**FAC 1..... OFF THEN ON**

[L2] *Resetting FAC 1 enables the recovery of characteristics speed displayed on the PFD. Resetting FAC 1 also enables rudder trim recovery, even if no indication is available. When the hydraulic power is lost, the right aileron is lost, and is in the upfloat position. Rudder trim may be used to compensate for this upfloating aileron.*

[L1] ■ **IF NO FUEL:**  
**OPT SPD.....220 KT/GREEN DOT**

[L2] *If there is no fuel remaining, the optimum speed is the green dot speed. Initially fly 220 kt then refer to the QRH procedure to get the accurate green dot speed.*

[L1] **ENG/NO FUEL PROC.....APPLY**

[L2] *Refer to procedure.*

[L1] ■ **IF FUEL REMAINS:**  
**ENG MODE SEL.....IGN**  
**OPT RELIGHT SPD.....300 KT**

[L2] *If there is fuel remaining, the optimum speed is the optimum relight speed. The ECAM provides reference to an envelope speed. In case of speed indication failure (volcanic ash), pitch attitude for optimum relight is provided in the QRH procedure.*

[L1] **ENG/FUEL PROC..... APPLY**

[L2] *Refer to procedure.*

*Continued on the following page*

**ENG DUAL FAILURE (Cont'd)**

Ident.: PRO-ABN-ENG-S-00012283.0044001 / 21 MAR 16

L12

**STATUS**

MIN RAT SPEED..... 140 KT  
 MAX SPEED ..... 320/0.77  
 MAX BRK PR..... 1000 PSI  
 MANEUVER WITH CARE  
 FUEL GRVTY FEED  
 AVOID NEGATIVE G FACTOR

**INOP SYS**

See below

**APPR PROC**

● **IF HYD NOT RECOVERED:**

FOR LDG.....USE FLAP 3

● **WHEN CONF 3 AND VAPP:**

L/G .....GRVTY EXTN

*(Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION). Being stabilized at VAPP before selecting the gear down enables the aircraft to be trimmed for approach.*

APPR SPD.....VREF +25 KT

*Approach speed must be increased, due to the loss of flaps.*

LDG DIST PROC..... APPLY

ALTN LAW: PROT LOST  
 WHEN L/G DN: DIRECT LAW

See <sup>(1)</sup>

BRK Y ACCU PR ONLY

See <sup>(2)</sup>

SLATS SLOW

**INOP SYS**

G+Y HYD

F/CTL PROT

STABILIZER

Continued on the following page

**ENG DUAL FAILURE (Cont'd)**

R AIL	REVERSER 1+2	ADR 2+3
IR 2+3	RA 1+2	SPLR 1+2+4+5
ELAC 2	SEC 2+3	FLAPS
YAW DAMPER	A/CALL OUT	AP 1+2
A/THR	FUEL PUMPS	ANTI SKID
N/W. STEER	AUTO BRK	CAT 2
L/G RETRACT	CAB PR 1+2	PACK 1+2

- (1) *At landing gear extension, control reverts to direct law in pitch as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).*
- (2) *7 full brake applications are available.*

**ENG 1(2) EIU FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-B-00017970.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the data bus between the EIU and ECU is failed.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) EIU FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-B-00017658.0002001 / 21 MAR 17

Crew awareness.

**L2** The following consequences affect the aircraft when this alert is triggered:

- Affected engine start is lost
- Autothrust control is lost
- Thrust reverser on the affected engine is lost
- When idle is selected, only approach idle is available
- Bleed corrections on N1 limit are lost (*Refer to PRO-ABN-ENG ENG 1(2) BLEED STATUS FAULT (In Flight)*).

Ident.: PRO-ABN-ENG-B-00017659.0001001 / 21 MAR 16

**L12**

**STATUS**

**INOP SYS**

**ENG 1(2) APPR IDLE ONLY**

*Minimum idle is lost.*

A/THR  
REVERSER 1(2)  
ENG 1(2) START

**ENG 1(2) FADEC A(B) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-AZ-00017972.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the associated FADEC channel is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-AZ-00017661.0001001 / 31 AUG 17

Crew awareness.

● **For aircraft equipped with CFM engines:**

L2 Note: Some cases of spurious FADEC fault have been experienced at engine start on ground.

The caution can be considered as spurious, if it disappears after application of the following procedure:

- Set the master sw to OFF, and wait until N2 speed goes below 5 % (If N2 indication is not available, wait 2 minutes before going to next step).
- Pull and reset the C/B 's of the affected ECU electrical supply (A04 or A05 on 49 VU or R41 or Q40 on 121 VU).
- Wait 10 s for the ECU power-up sequence, and restart the engine.



**ENG 1(2) FADEC ALTERNATOR**

Applicable to: ALL

Ident.: PRO-ABN-ENG-BA-00017974.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the electrical auto supply for the FADEC system is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-BA-00017662.0001001 / 21 MAR 16

Crew awareness.

**ENG 1(2) FADEC FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-BC-00017975.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both FADEC channels are lost.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) FADEC FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-BC-00017663.0005001 / 21 MAR 17

■ **On ground:**

THR LVR (AFFECTED) NOT ABOVE IDLE

ENG (AFFECTED) PARAMETERS.....CHECK

L2

*Due to the fact that engine indications are lost, other system pages such as HYD SD page, ELEC SD page or BLEED SD page must be used to check engine status.*

L1

● **IF ABN ENG OPERATION:**

ENG MASTER (AFFECTED)..... OFF

■ **In flight:**

THR LEVER (AFFECTED)..... IDLE

ENG (AFFECTED) PARAMETERS.....CHECK

L2

*Due to the fact that engine indications are lost, other system pages such as HYD SD page, ELEC SD page or BLEED SD page must be used to check engine status.*

L1

● **IF ABN ENG OPERATION:**

ENG MASTER (AFFECTED)..... OFF

L12

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

*(Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).*

Ident.: PRO-ABN-ENG-BC-00019553.0001001 / 13 MAY 16

**STATUS**

● **On ground:**

THR LVR 1(2) NOT ABOVE IDLE

**ENG 1(2) FADEC HI TEMP**

Applicable to: ALL


Ident.: PRO-ABN-ENG-BD-00017976.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when high temperature is detected by one or both channels.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) FADEC HI TEMP (Cont'd)**

Ident.: PRO-ABN-ENG-BD-00017664.0004001 / 21 MAR 17

- **If the ECU TEMP is above 105 °C:**

**FADEC OVHT**

L2

*Reducing engine power should decrease temperature in the ECU area.  
If overheating is severe enough, ECU failure could result in a significant loss of engine functions.*

L1

- **On the ground:**

THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (ASSOCIATED ENGINE).....OFF  
 ENG MODE SEL.....NORM  
 FADEC GND PWR..... CHECK OFF

- **In flight:**

ENG (AFFECTED) PARAMETERS.....CHECK

- **IF ABN ENG OPERATION:**

THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (ASSOCIATED ENGINE)..... OFF

L12

\_\_\_\_\_ **ASSOCIATED PROCEDURES** \_\_\_\_\_

**ENG 1(2) SHUT DOWN**

*(Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).*

**ENG 1(2) FAIL**

Applicable to: ALL


Ident.: PRO-ABN-ENG-BJ-00017982.0002001 / 06 JUN 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the engine core speed is below idle, with the ENG MASTER lever set to ON, and ENG FIRE pb not pushed.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) FAIL (Cont'd)**

Ident.: PRO-ABN-ENG-BJ-00017667.0003001 / 21 MAR 17

**L2** An engine flame-out may be recognized by a rapid decrease in EGT , N2 , FF , followed by decrease in N1 for CFM engines, or EPR for IAE engines.

Engine damage may be accompanied by:

- Loud noise,
- Significant increase in aircraft vibrations and/or buffeting,
- Repeated or uncontrollable engine stalls,
- Associated abnormal indications such as hydraulic fluid loss, or no N2 indication.

**L1**

**LAND ASAP**

**■ Before takeoff or after landing:**

THR LEVER (AFFECTED ENGINE)..... IDLE  
ENG MASTER (AFFECTED ENGINE)..... OFF

**■ IF DAMAGE:**

ENG FIRE P/B (AFFECTED ENGINE)..... PUSH  
AGENT 1..... DISCH

**■ IF NO DAMAGE:**

**L2**

For CFM engines, if conditions permit, do not restart the engine. A new engine start would erase FADEC troubleshooting data.

**L1**

ENG (AFFECTED) RELIGHT..... CONSIDER

**L2**

*If no damage, a new start sequence may be initiated.*

**L12**

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

*Apply the ENG SHUT DOWN procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN), if damage or if engine relight is unsuccessful.*

**L1**

**■ In flight:**

ENG MODE SEL..... IGN

**L2**



*Selection of continuous ignition confirms the immediate relight attempt made by the FADEC.*

**L1**

THR LEVER (AFFECTED ENGINE)..... IDLE

*Continued on the following page*

**ENG 1(2) FAIL (Cont'd)**

**L2** *Note:* In case of GPWS (EGPWS ) alerts, reduce speed with care below VLS with flaps extended (at light weights VMCA may be reached before  $\alpha_{Max}$ ) when applying the GPWS (EGPWS ) procedure.

**L1** ● **IF NO ENG RELIGHT AFTER 30 S:**

**L2** The 30 s countdown starts as soon as the **ENG 1(2) FAIL** alert is triggered.

**L1** **ENG MASTER (AFFECTED ENGINE)..... OFF**

■ **IF DAMAGE:**

**ENG FIRE P/B (AFFECTED ENGINE)..... PUSH**  
**AGENT 1 (AFTER 10 SECONDS IN FLIGHT)..... DISCH**

**L12**

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

**L2** Apply the **ENG SHUT DOWN** procedure (Refer to **PRO-ABN-ENG ENG 1(2) SHUT DOWN**), if damage or if engine relight is unsuccessful.  
 If high vibration occurs and continues after engine shutdown, reduce airspeed and descent to a safe altitude.  
 Attempt to determine and use a practical airspeed and altitude for minimum vibrations.

**L1** ■ **IF NO DAMAGE:**

**ENG (AFFECTED) RELIGHT..... CONSIDER**

**L2** Apply **ENG RELIGHT** (in flight) procedure (Refer to **PRO-ABN-ENG [QRH] ENG RELIGHT IN FLIGHT**).



**ENG 1(2) FIRE**  
**(IN FLIGHT)**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DQ-00017401.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- Fire is detected by both loops, or
- Fire is detected by one loop when the other loop is faulty, or
- A rupture occurs in both loops within 5 s.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) FIRE (Cont'd)**  
**(IN FLIGHT)**

Ident.: PRO-ABN-ENG-DQ-00018190.0002001 / 21 MAR 17

**LAND ASAP**

THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (AFFECTED)..... OFF

**L2** LP and HP valves close.

**L1** ENG FIRE P/B (AFFECTED)..... PUSH

**L2** When pushed:

- Aural warning stops
- The light remains on, until the fire is extinguished, regardless of the position of the ENG FIRE pb-sw
- FADEC is no longer supplied.

**L1** AGENT 1 AFTER 10 S..... DISCH

**L2** The 10 s delay allows N1 to decrease, reducing nacelle ventilation, and thereby increasing the effect of the agent.  
 Automatic countdown on the ECAM.

**L1** ATC..... NOTIFY

**L2** Notify ATC of the nature of the emergency, and state intentions

**L1** ● IF FIRE AFTER 30 S:

AGENT 2..... DISCH

**L2** Discharge the second agent, if the fire warning remains 30 s after the discharge of the first agent.

**L12**

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUTDOWN**

Do not attempt to restart the engine.

For the ENG SHUTDOWN procedure, see the ENG section (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).

**ENG 1(2) FIRE**  
**(ON GROUND)**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DR-00018553.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- Fire is detected by both loops, or
- Fire is detected by one loop when the other loop is faulty, or
- A rupture occurs in both loops within 5 s.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) FIRE (Cont'd)**  
**(ON GROUND)**

Ident.: PRO-ABN-ENG-DR-00018192.0004001 / 14 FEB 17

THR LEVERS..... IDLE

**L2** Full reverse may be used to stop the aircraft.

**L1** ● **WHEN A/C IS STOPPED:**

PARKING BRK..... ON

ATC (VHF 1)..... NOTIFY

**L2** Notify ATC of the nature of the emergency, and state intentions.  
 Only VHF 1 is available on batteries.

**L1** CABIN CREW (PA)..... ALERT  
 ENG MASTER (AFFECTED)..... OFF

**L2** Associated LP and HP valves close.

**L1** ENG FIRE P/B (AFFECTED)..... PUSH

**L2** When pushed:

- Aural warning stops
- The light remains on, until the fire is extinguished, regardless of the position of the ENG FIRE pb-sw
- FADEC is no longer supplied.

**L1** AGENT 1+2..... DISCH

EMER EVAC PROC..... APPLY

**L2** Refer to PRO-ABN-MISC [QRH] EMER EVAC or Refer to QRH/ABN-25 EMER EVAC

**ENG 1(2) FIRE DET FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DO-00020838.0001001 / 17 MAR 17

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- Both loops are inoperative, or
- Fire Detector Unit is inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DO-00020837.0001001 / 17 MAR 17

Crew awareness.

Ident.: PRO-ABN-ENG-DO-00020839.0001001 / 17 MAR 17

**STATUS**

**INOP SYS**

FIRE DET 1(2)


**ENG 1(2) FIRE LOOP A(B) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DP-00020841.0001001 / 17 MAR 17

**ANNUNCIATIONS**

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DP-00020840.0001001 / 17 MAR 17

**L2** Crew awareness.

Ident.: PRO-ABN-ENG-DP-00020842.0001001 / 17 MAR 17

**STATUS**

**INOP SYS**

ENG 1(2) LOOP A(B)

**ENG 1(2) FUEL CTL FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-O-00017983.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The Fuel Metering Valve (FMV) position is failed, or
- The FMV command is failed, or
- The FMV position feedback is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-O-00017679.0003001 / 21 MAR 16

● **On ground:**

THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (AFFECTED)..... OFF

AVOID RAPID THR CHANGES, or  
 ENG (AFFECTED) SLOW RESPONSE

L2 Depending on the type of failure, one of the above two messages is displayed.

*Continued on the following page*

**ENG 1(2) FUEL CTL FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-O-00017681.0001001 / 21 MAR 16

**STATUS**

AVOID RAPID THR CHANGES or

ENG (affected) SLOW RESPONSE

**ENG 1(2) FUEL FILTER CLOG**

Applicable to: ALL


Ident.: PRO-ABN-ENG-BK-00017984.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

<sup>[2]</sup> This alert triggers when the fuel filter is clogged.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-BK-00012068.0001001 / 18 AUG 14

Crew awareness.

<sup>[2]</sup> Maintenance action is due.



**ENG 1(2) FUEL RETURN VALVE**

Applicable to: ALL

Ident.: PRO-ABN-ENG-BP-00017986.0001001 / 13 MAY 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the fuel return valve is failed in closed, or in open position.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-BP-00012277.0001001 / 25 FEB 14

■ **VALVE NOT OPEN**

L2

The valve is failed closed.

L1

Crew awareness.

■ **VALVE NOT CLOSED**

L2

The valve is failed open.

L1

Crew awareness.

**ENG 1(2) HP FUEL VALVE**

Applicable to: ALL


Ident.: PRO-ABN-ENG-BY-00017955.0001001 / 13 MAY 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when HP fuel valve is failed in closed or open position.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-BY-00012096.0001001 / 13 MAY 16

■ **HP fuel valve failed closed, and associated engine below idle:**

**HP FUEL VALVE NOT OPEN**

● **On the ground:**

**MAN START (IF MAN START PERFORMED).....OFF**

**ENG MASTER (AFFECTED).....OFF**

■ **HP fuel valve failed open, and associated engine below idle**

or

**HP fuel valve failed closed, and associated engine at or above idle:**

**HP FUEL POS SWT FAULT**

**ENG 1(2) IGN FAULT (IGN A OR B FAULT)**

Applicable to: ALL

Ident.: PRO-ABN-ENG-J-00017956.0002001 / 20 APR 17


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when ignition circuit A or B is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-J-00012134.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-ENG-J-00012136.0001001 / 17 AUG 10

**STATUS**

**INOP SYS**

ENG 1(2) IGN A (B)

**ENG 1(2) IGN FAULT (IGN A+B FAULT)**

Applicable to: ALL


Ident.: PRO-ABN-ENG-K-00017957.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when both ignition circuits are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-K-00012139.0001001 / 12 JAN 11

**AVOID ADVERSE CONDITIONS**

Ident.: PRO-ABN-ENG-K-00012141.0001001 / 12 JAN 11

**STATUS**

**INOP SYS**

ENG 1(2) IGN

**ENG 1(2) LOW N1 (ON GROUND)**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CA-00017958.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when N1 rotation is failed during start.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CA-00012101.0004001 / 16 NOV 11

**L2** No N1 rotation during start.

**L1** ● **IF CONFIRMED:**

THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (AFFECTED)..... OFF

**ENG 1(2) N1 OR N2 OR EGT OR FF DISCREPANCY**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CC-00017959.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when a discrepancy between real and displayed values is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CC-00017696.0001001 / 21 MAR 16

- [L2] The upper ECAM upper displays a CHECK (or CHK) message below the affected indication. Normal indication may be recovered by switching from DMC 1 to DMC 3. If unsuccessful, and if both thrust levers are at the same position, crosscheck with the opposite parameter.

- [L1] Crew awareness.

**ENG 1(2) N1/N2/EGT OVER LIMIT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-CD-00018006.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- N1 is above 104 %, or
- N2 is above 105 %, or
- EGT is above 725 °C during start, or above 950 °C when the thrust levers are at TOGA or FLX/MCT position, or 915 °C in the other cases.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) N1/N2/EGT OVER LIMIT (Cont'd)**

Ident.: PRO-ABN-ENG-CD-00012079.0013001 / 21 MAR 17

■ **Max pointer indication:**

- [L2] EGT between 915 °C and 950 °C (except during takeoff, alpha floor activation, or reverse selected), or EGT between 950 °C and 970 °C, or  
 N1 between 104.0 % and 105.8 % or  
 N2 between 105.0 % and 105.8 %

[L1] **THR LEVER (OF AFFECTED ENGINE)..... BELOW LIMIT**

[L2] *Normal operation may be resumed and maintained until next landing. Report in maintenance log.*

[L1] ■ **Max pointer indication:**

- [L2] EGT above 970 °C or  
 N1 above 105.8 % or  
 N2 above 105.8 %

[L1] **THR LEVER (OF AFFECTED ENGINE)..... IDLE**  
**ENG MASTER (OF AFFECTED ENGINE)..... OFF**

[L2] *If conditions do not permit engine shutdown land ASAP using the minimum thrust required to sustain safe flight.*

[L12]

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

Apply the **ENG SHUT DOWN** procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).



**ENG 1(2) OIL FILTER CLOG**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CF-00017964.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the oil filter is clogged.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CF-00012078.0003001 / 18 AUG 14

Crew awareness.

**L2** Maintenance action is due, except if the caution is temporarily displayed during cold engine start with engine oil temperature lower than 40 °C.

**ENG 1(2) OIL HI TEMP**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CH-00017969.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the oil temperature is:
  - Between 140 °C and 155 °C for more than 15 min, or
  - Above 155 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CH-00017822.0002001 / 21 MAR 17

**THR LEVER (AFFECTED ENGINE)..... IDLE**  
**ENG MASTER (AFFECTED ENGINE)..... OFF**

- [L2] For aircraft equipped with IAE or PW6000 engines, operation above the maximum temperature require engine shutdown.

[L12]

**ASSOCIATED PROCEDURES**

**ENG 1 (2) SHUT DOWN**

Apply the **ENG SHUT DOWN** procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).

**ENG 1(2) OIL LO PR**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CI-00018002.0006001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when oil pressure is below 13 PSI.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CI-00018796.0001001 / 21 MAR 17

L2 Check oil pressure indication on ENG SD page.

L1 THR LEVER (OF AFFECTED ENGINE).....IDLE  
ENG MASTER (OF AFFECTED ENGINE).....OFF

L12

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

Carry out ENG SHUT DOWN procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).

Note: If oil pressure is low (< 13 PSI) is indicated only on ENG SD page (red indication) without the ENG OIL LO PR warning, it can be assumed, that the oil pressure transducer is faulty. Flight crew may continue engine operation while monitoring other engine parameters.


**ENG 1(2) ONE TLA FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-CM-00017977.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CM-00012144.0001001 / 25 FEB 14

Crew awareness.

**ENG 1(2) OVSPD PROT FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CN-00017980.0003001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the overspeed protection is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CN-00012166.0001001 / 25 FEB 14

Crew awareness.

**L12** Note: If the warning appears during engine start, shut down the engine. Restart the engine. If the warning still appears, maintenance action is due.

**ENG 1(2) PROBES FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CO-00017981.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when T12, PO or PT2 data are unavailable on both channels.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CO-00018734.0001001 / 21 MAR 16

Crew awareness.

**ENG 1(2) REV ISOL FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-CP-00017989.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the thrust reverser shut off valve is failed in open position.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CP-00018735.0001001 / 21 MAR 16

Crew awareness.

**ENG 1(2) REV PRESSURIZED**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CR-00017992.0001001 / 13 MAY 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when thrust reverser system is pressurized while:
  - For CFM engines: The reverser doors are stowed and locked, or
  - For IAE and PW engines: There is no reverse deployment order.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CR-00017702.0002001 / 21 MAR 16

- **In flight:**  
THR LEVER 1(2)..... IDLE

- [L2] *If flight conditions permit, reduce the thrust of the affected engine to IDLE as a precautionary measure.*

- [L1] ■ **On ground:**  
THR LVR 1(2) NOT ABOVE IDLE



**ENG REV SET**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DA-00017905.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the reverse thrust is selected in flight.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DA-00017776.0001001 / 21 MAR 16

THR LEVER (AFFECTED ENGINE)..... FWD THR

**ENG 1(2) REV SWITCH FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-CS-00017870.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the reverser permission switch is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CS-00012098.0001001 / 25 FEB 14

Crew awareness.

**ENG 1(2) REVERSE UNLOCKED**

Applicable to: ALL

Ident.: PRO-ABN-ENG-CT-00017871.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one or more reverser doors are not locked in stowed position in flight, or on ground with no deploy order.

Flight Phase Inhibition:



Note: (a) Alert not inhibited in the flight phases 4 and 5, if the engine thrust is automatically set to idle.

Continued on the following page

**ENG 1(2) REVERSE UNLOCKED (Cont'd)**

Ident.: PRO-ABN-ENG-CT-00012084.0007001 / 21 MAR 17

**L2** One or more reverser doors are not stowed.

If N1 is above 70 %, the auto-restow function is inhibited in flight and on ground.

**L1** ■ **On ground:**

**ENG 1(2) AT IDLE**

**L2** Only displayed, if the FADEC automatically sets the engine at idle (i.e. when 4 reverser doors are not stowed, or 1, 2, or 3 reverser doors are not stowed with the reverser pressurized).

**L1** THR LEVER (AFFECTED ENGINE)..... IDLE  
 ENG MASTER (AFFECTED ENGINE)..... OFF

■ **In flight:**

**LAND ASAP**

**ENG 1(2) AT IDLE**

**L2** Only displayed, if the engine is automatically set at idle.

**L1** THR LEVER (AFFECTED ENGINE)..... IDLE  
 MAX SPEED..... 300/.78

● **IF BUFFET:**

**L2** The warning alone, without buffet or vibration, may be a false warning.

**L1** MAX SPEED ..... 240 KT  
 ENG MASTER (AFFECTED ENGINE)..... OFF

● **If reverser is actually deployed:**

RUD TRIM ..... FULL R (L)  
 CONTROL HDG WITH ROLL

**L12** \_\_\_\_\_ **ASSOCIATED PROCEDURES** \_\_\_\_\_

**ENG 1(2) SHUT DOWN**

Apply the **ENG SHUT DOWN** procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).

**ENG 1(2) REVERSER FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-A-00017872.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the thrust reverser on one engine is failed (due to system components or inputs).

Flight Phase Inhibition:



Note: (a) Alert not inhibited in the flight phases 3, 4, 5, if engine thrust is automatically set to idle.

Ident.: PRO-ABN-ENG-A-00017703.0003001 / 21 MAR 16

- If reverser position fault with reverser pressurized:

**LAND ASAP**

**ENG 1(2) AT IDLE**

**L2** Thrust of the affected engine is locked at idle.

**L1** **THR LEVER 1(2)**..... IDLE

**L2** Set thrust lever of affected engine at idle.

Continued on the following page

**ENG 1(2) REVERSER FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-A-00012070.0001001 / 17 AUG 10

**STATUS**

**INOP SYS**

REVERSER 1(2)

**ENG 1(2) SENSOR FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-R-00017873.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when PS3 or T25 or T3 or N1 or N2 data is unavailable on both channels.

Flight Phase Inhibition:



Continued on the following page



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

**ENG 1(2) SENSOR FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-R-00012235.0003001 / 16 NOV 11

**L2** PS3, T25, T3, N1 , N2 data not available on both ECU channels.

**L1** ■ **On ground:**  
 THR LEVER (AFFECTED)..... IDLE  
 ENG MASTER (AFFECTED).....OFF

■ **In flight:**  
 AVOID RAPID THR CHANGES.

Ident.: PRO-ABN-ENG-R-00017707.0001001 / 21 MAR 16

**STATUS**

AVOID RAPID THR CHANGES.

**ENG 1(2) SHUT DOWN**

Applicable to: ALL


Ident.: PRO-ABN-ENG-I-00017874.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when ENG master is at off in phases 3 to 8, or ENG FIRE pb is pushed in phases 1, 2, 9 and 10.

Flight Phase Inhibition:




*Continued on the following page*



**ENG 1(2) SHUT DOWN (Cont'd)**

Ident.: PRO-ABN-ENG-I-00017837.0006001 / 20 MAR 17

**LAND ASAP**

- **If wing anti-ice ON:**
  - **If Elec Emer Config:**  
 PACK 1.....OFF  
 L2 *In Elec Emer config, only Pack 1 pb-sw can be set to off.*
  - L1 ■ **If not Elec Emer Config:**  
 PACK (AFFECTED SIDE) ..... OFF  
 L2 *One pack must be closed when wing anti-ice is in use due to precooler performance.*
- **If ENG FIRE pb not pushed:**  
 X BLEED (IF ENG FIRE PB NOT PUSHED)..... OPEN  
 L2 *X BLEED selector must be opened to have symmetrical wing anti-icing.*
- L1 ENG MODE SEL.....IGN  
 L2 *Continuous ignition is selected, in order to protect the remaining engine.*
- L1 ● **IF NO FUEL LEAK:**  
 IMBALANCE.....MONITOR
- TCAS MODE SEL  .....TA
- **If REV unlocked:**
  - **IF BUFFET:**  
 MAX SPEED ..... 240 KT
- **If ENG FIRE pb-sw pushed:**  
 X BLEED ..... SHUT  
 WING ANTI ICE.....OFF  
 AVOID ICING CONDITIONS

**SECONDARY FAILURES**

- \* HYD
- \* ELEC
- \* AIR BLEED

*Continued on the following page*

**ENG 1(2) SHUT DOWN (Cont'd)**

**L2** Note: *In some conditions, with full asymmetric power, the aircraft may be control-limited before reaching the protection system limit. Therefore, in extreme conditions, where low speed may be advantageous (GPWS , WINDSHEAR, etc.), reduce speed with care below VLS and respect the minimum control speed.*

*Continued on the following page*

**ENG 1(2) SHUT DOWN (Cont'd)**

Ident.: PRO-ABN-ENG-I-00017852.0005001 / 22 MAR 17

L12

**STATUS**

**INOP SYS**

- If ENG 1(2) FIRE pb-sw pushed:  
 AVOID ICING CONDITIONS
- IF SEVERE ICE ACCRETION:  
 MIN SPD..... VLS + 10/G DOT  
 MANEUVER WITH CARE  
 LDG DIST PROC..... APPLY
- If REV unlocked:  
 MAX SPEED..... 300/0.78

- CAT 3 DUAL
- ENG 1(2) BLEED
- PACK 1(2)
- MAIN GALLEY
- GEN 1(2)
- G ENG 1 PUMP or  
 Y ENG 2 PUMP
- WING A. ICE <sup>(1)</sup>
- AFT CRG HEAT
- STEER APPR

**APPR PROC**

- If REV unlocked:
  - 4 doors not stowed (CFM) or reverser deployed (IAE/PW):
    - IF BUFFET:  
 FOR LDG.....USE FLAP 1  
*This line is replaced by "FOR LDG : USE FLAP 1" when CONF 1 is selected, as a reminder.*  
 APPR SPD.....VREF + 55 KT  
 RUD TRIM.....5 DEG R(L)  
*When committed to land, set 5 ° rudder trim towards live engine.*  
 A/THR..... OFF  
 GPWS FLAP MODE..... OFF
    - WHEN LDG ASSURED:  
 L/G.....DOWN
    - AT 800 FT AGL:  
 TARGET SPD..... VREF + 40 KT  
 LDG DIST PROC.....APPLY

*Continued on the following page*

**ENG 1(2) SHUT DOWN (Cont'd)**

■ **1, 2, or 3 doors not stowed (CFM), or reverse detected unlocked (IAE/PW):**

● **IF BUFFET:**

FOR LDG.....USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3..... ON

APPR SPD.....VREF + 10 KT

LDG DIST PROC.....APPLY

● **If WING A/ICE off and ENG 1(2) FIRE pb-sw not pressed:**

● **IF PERF PERMITS:**


X BLEED.....OPEN

*If no obstacle constraint exists, open the XBLEED.  
To determine the single engine gross ceiling, decrease by 1 200 ft the result provided by the QRH table (Refer to QRH/PER-L Ceilings (Paper Only)) or by the performance application of FlySmart with Airbus.*

● **For A321 aircraft:**

ECON FLOW.....ON

AFT CRG HOT AIR  ..... OFF

*The ECON FLOW must be selected ON, and the aft cargo heat  must be selected OFF, due to precooler performance.*

● **IF NO ENG 1(2) DAMAGE:**

CONSIDER ENG 1(2) RELIGHT

CAT 3 SINGLE ONLY

ONE PACK ONLY IF WAI ON

See <sup>(2)</sup>

<sup>(1)</sup> (if affected ENG FIRE pb-sw pushed)

<sup>(2)</sup> Note: - If available, the APU may be started and the APU GEN used  
- If the ENG 1 FIRE pb-sw is pushed, APU bleed must not be used.

*Continued on the following page*

**ENG 1(2) SHUT DOWN (Cont'd)**

*If ENG 2 FIRE pb-sw is pushed, APU bleed may be used, provided the X BLEED rotary selector is set at SHUT.*

- After landing, the Fuel Used value of the engine, shutdown in flight, becomes incorrect.

**ENG 1(2) STALL**

Applicable to: ALL

Ident.: PRO-ABN-ENG-Z-00017876.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when an engine stall is detected.

Flight Phase Inhibition:



Continued on the following page

**ENG 1(2) STALL (Cont'd)**

Ident.: PRO-ABN-ENG-Z-00017749.0003001 / 17 MAR 17

**L2** A stall may be indicated by varying degrees of abnormal engine noises, accompanied by flame from the engine exhaust (and possibly from the engine inlet in severe case), fluctuating performance parameters, sluggish or no thrust lever response, high EGT and/or a rapid EGT rise when thrust lever is advanced. Engine stalls must be reported for maintenance action.

**L1** THR LEVER (AFFECTED ENGINE)..... IDLE  
 ENG MASTER (AFFECTED ENGINE)..... OFF

**ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

● **If N2 is above IDLE:**

**L2** This caution is not displayed on the ECAM.  
 Consequently, if the crew detects a stall, it must apply the following procedure:

**L1** ■ **On ground:**  
 THR LEVER (AFFECTED ENGINE)..... IDLE  
 ENG MASTER (AFFECTED ENGINE)..... OFF

■ **In flight:**  
 THR LEVER (AFFECTED ENGINE)..... IDLE  
 ENG PARAMETERS (AFFECTED ENGINE)..... CHECK

■ **If abnormal ENG parameters:**  
 ENG MASTER (AFFECTED ENGINE)..... OFF

**L12** **ASSOCIATED PROCEDURES**

**ENG 1(2) SHUT DOWN**

Apply the **ENG SHUT DOWN** procedure (Refer to PRO-ABN-ENG ENG 1(2) SHUT DOWN).

■ **If normal ENG parameters:**  
 ENG ANTI ICE (AFFECTED ENGINE)..... ON  
 WING ANTI ICE..... ON

**L2** Operation of ENG and WING ANTI ICE will increase the stall margin but EGT increases accordingly.

**L1** THR LEVER (AFFECTED ENGINE)..... SLOWLY MOVE FORWARD

*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

**ENG 1(2) STALL (Cont'd)**

- **If stall recurs:**  
 THR LEVER (AFFECTED ENGINE).....MOVE BACKWARD

L2

*Reduce thrust and operate below the stall threshold where stall recurs.*

L1

- **If stall does not recur:**  
 CONTINUE NORMAL ENGINE OPERATION

L2

Ident.: PRO-ABN-ENG-Z-00017748.0001001 / 21 MAR 16

**STATUS**

CONSIDER ENG 1(2) RELIGHT

**ENG 1(2) START FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-AD-00017995.0001001 / 13 MAY 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when start fault due to:
- No light up, or
  - Engine stall, or
  - Engine overtemperature (above 725 °C), or
  - Starter time exceeded, or
  - Low start air pressure, or
  - Thrust lever not at idle.

Flight Phase Inhibition:



Note: Alert inhibited in the flight phase 6, only if it is due to thrust lever not at idle.

*Continued on the following page*



**ENG 1(2) START FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-AD-00012100.0005001 / 13 MAY 16

**■ ENG 1(2) IGNITION FAULT:**

**L2** The engine does not start within the 18 s that follow the ignition start.

**L1** ● **In flight:**  
 ENG MASTER (AFFECTED)..... OFF

**L2** Wait 30 s before attempting a new start (to drain the engine).

**L1** ● **On the ground (auto start) :**

**L2** If the engine does not start, the FADEC can attempt an additional engine restart. After any start attempt that is not successful, a dry crank phase automatically occurs. The ECAM displays the following messages:

**L1** AUTO CRANK IN PROGRESS  
 NEW START IN PROGRESS

● **When the final dry cranking process is finished:**  
 ENG MASTER (AFFECTED)..... OFF

**L2** Following starter cooldown, the pilot must decide whether to attempt auto or manual start, or to report the no start condition for appropriate maintenance action.

**L1** ● **On the ground (manual start):**  
 ENG MASTER (AFFECTED)..... OFF  
 MAN START (AFFECTED)..... OFF  
 MODE SEL..... CRANK  
 MAN START (AFFECTED)..... ON

**L2** Note: ECAM does not display the last two lines of the above procedure.  
 Dry crank the engine for 30 s. The start valve automatically reopens when N2 is below 20 %.  
 After the starter cools, and for any subsequent attempt to start the engine, the flight crew must perform a manual start, or must report the “no start condition” to maintenance for appropriate action.

**L1** ■ **ENG 1(2) STALL, ENG 1(2) EGT OVERLIMIT:**  
 ● **In flight:**  
 ENG MASTER (AFFECTED)..... OFF

**L2** Wait 30 s before attempting a new start (to drain the engine).

Continued on the following page

**ENG 1(2) START FAULT (Cont'd)**

L1

● **On ground (auto start):**

L2

If the FADEC detects a stall or a potential EGT overheat, the FADEC will reduce the fuel schedule in stages, if necessary, to achieve a normal condition. The following message will be displayed on the ECAM:

L1

**NEW START IN PROGRESS**

● **If restart not possible:**

L2

If normal conditions cannot be achieved, the FADEC shuts off fuel and turn off ignition. Then a dry crank phase automatically occurs. The ECAM displays the following message:

L1

**AUTO CRANK IN PROGRESS**

**ENG MASTER (AFFECTED).....OFF**

L2

- *The fuel metering valve and starter air valve are automatically closed. Both igniters are turned off*
- *Setting ENG MASTER to OFF confirms automatic start abort*
- *In case of ENG STALL, consider making a XBLEED start, if pressure is low.*

L1

● **On ground (manual start):**

**ENG MASTER (AFFECTED)..... OFF**

**MAN START (AFFECTED)..... OFF**

**MODE SEL.....CRANK**

**MAN START (AFFECTED).....ON**

L2

*Note: ECAM does not display the last two lines of the above procedure.  
 Dry crank the engine for 30 s. The start valve automatically reopens when N2 is below 20 %.  
 After the starter cools, and for any subsequent attempt to start the engine, the flight crew must perform a manual start, or must report the "no start condition" to maintenance for appropriate action.*

L1

■ **STARTER TIME EXCEEDED:**

**MAN START (IF MANUAL START IS PERFORMED).....OFF**

**ENG MASTER (AFFECTED).....OFF**

■ **LO START AIR PRESS:**

**BLEED AIR SUPPLY..... CHECK**

*Continued on the following page*

**ENG 1(2) START FAULT (Cont'd)**

■ **THR LEVER NOT AT IDLE:**  
 THR LEVER..... IDLE

**ENG 1(2) START VALVE FAULT**

Applicable to: ALL


Ident.: PRO-ABN-ENG-D-00017932.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the start valve is stuck in closed or open position.

Flight Phase Inhibition:



*Continued on the following page*

**ENG 1(2) START VALVE FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-D-00018010.0002001 / 21 MAR 17

■ **START VALVE NOT CLOSED**

- [L2] Remove all bleed sources supplying the faulty start valve.
- [L1]
 

APU BLEED (IF ENG 1 AFFECTED).....	OFF
X BLEED.....	SHUT

  - **In flight:**

ENG BLEED (AFFECTED SIDE).....	OFF
--------------------------------	-----
  - **On the ground:**

MAN START (IF MAN START PERFORMED).....	OFF
ENG MASTER (AFFECTED SIDE).....	OFF
- [L2] *On the ground, consider application of "START VALVE MANUAL OPERATION" procedure.*

[L1] ■ **START VALVE NOT OPEN**

- **If opposite engine running:**

X BLEED.....	OPEN
--------------	------
- **If APU AVAIL below FL 200:**

APU BLEED.....	ON
----------------	----
- **If UNSUCCESSFUL:**

MAN START (IF MAN START PERFORMED).....	OFF
ENG MASTER (AFFECTED) (IF AUTO START PERFORMED).....	OFF
- [L2] *MAN START procedure is useless since in both cases, the start valve is controlled by FADEC.*
- [L2] *On the ground, consider application of "START VALVE MANUAL OPERATION" procedure.*

[L1] ● **EEC control of start valve failed (for IAE or PW 6000 engines):**

- **On the ground:**  
**START VALVE MAN ONLY**
- [L2] *Start valve must be manually opened (Refer to PRO-NOR-SUP-ENG Engine Start Valve Manual Operation).*
- [L1] ● **In flight:**  
**WINDMILL START ONLY.**
- [L2] *Windmilling start only is available since EEC cannot control the start valve.*

**ENG 1(2) THR LEVER ABV IDLE**

Applicable to: ALL

Ident.: PRO-ABN-ENG-CW-00017922.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- One thrust lever is above idle while the other thrust lever is in the reverse detent at landing.
- One thrust lever is above idle while the other thrust lever is at idle, at reverser deselection during landing roll.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-CW-00018748.0002001 / 21 MAR 16

L2

The repetitive "RETARD-RETARD" synthetic voice is triggered at landing.

L1

**THR LEVER (AFFECTED ENGINE)..... IDLE**

**ENG 1(2) THR LEVER DISAGREE**

Applicable to: ALL


Ident.: PRO-ABN-ENG-L-00017999.0004001 / 06 SEP 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when a discrepancy between both resolvers of a thrust lever is detected.

Flight Phase Inhibition:



Note: (a) Alert not inhibited in the flight phases 4 and 5, if the FADEC automatically selects IDLE thrust.

*Continued on the following page*

**ENG 1(2) THR LEVER DISAGREE (Cont'd)**

Ident.: PRO-ABN-ENG-L-00012146.0017001 / 02 MAY 17

**L2** Both Thrust Lever Angle (TLA) sensors not in agreement on one engine.

**L1**

**LAND ASAP**

■ **On ground (if both TLA not at TOGA or FLX/MCT or if only one TLA is at TOGA or FLX/MCT and the other is below IDLE):**

**ENG (AFFECTED) IDLE POWER ONLY.**

**L2**

*In that situation, the FADEC automatically selects IDLE.*


**L1**

**THR LEVER (AFFECTED)..... IDLE**

■ **During take-off (if both TLA are above IDLE):**

**ENG (AFFECTED) TO, FLX, OR DRT TO **

**L2**

*If both TLA are above IDLE, the FADEC automatically selects TO, FLX TO, or DRT TO  thrust until thrust reduction, after which the maximum available thrust is CLB.*

**L1**

■ **In cruise (with slats retracted):**

**AVAIL MAX POWER : CLB**

**L2**

*In flight, if the failure occurs while the thrust lever is between idle and MCT, and if the slats are not extended, (or when MN > 0.55, if the outside EIU is failed) the FADEC selects the larger TLA power limited to CLB.*

**L1**

**A/THR (IF ENGAGED) ..... KEEP ON**  
**A/THR (IF NOT ENGAGED AND IF SLATS ARE NOT EXTENDED) ..... ON**

**L2**

*With A/THR engaged, thrust is automatically managed between IDLE and higher TLA position.*

**L1**

■ **In approach (with slats extended):**

**ENG (AFFECTED) AT IDLE (WHEN SLATS ARE EXTENDED FOR APPROACH)..**

**L2**

*If TLA at, or below, MCT and if the slats are extended for approach, (or when MN < 0.47, if the outside EIU is failed).*

**L1**

**THR LEVER (AFFECTED)..... IDLE**

*Continued on the following page*

**ENG 1(2) THR LEVER DISAGREE (Cont'd)**

Ident.: PRO-ABN-ENG-L-00018067.0013001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

- If TLA at, or below, MCT

- **WHEN SLATS OUT:**

(Displayed, if slats not extended), or

- **WHEN MN < 0.47:**

(Displayed, if the onside EIU is failed)

**ENG (AFFECTED) AT IDLE**

*For any case of thrust lever disagree (TO, FLEX, or between Idle and MCT), the FADEC will command idle thrust for the approach when slats are extended (or when the Mach number is less than 0.47, if associated EIU is failed). It is independent of the autothrust condition. The affected engine's thrust remains definitively at idle, even for go-around.*

ENG 1(2) THR

ENG (affected) AVAIL MAX PWR: CLB  
 ON GND ENG (affected) MAX PWR: IDLE.



**ENG 1(2) THR LEVER FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-M-00018000.0003001 / 01 JUN 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when both resolvers on one thrust lever are failed.

Flight Phase Inhibition:



Note: (a) Alert not inhibited in flight phases 4 and 5 if the FADEC automatically selects IDLE thrust.

Continued on the following page

**ENG 1(2) THR LEVER FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-M-00018069.0009001 / 21 MAR 16

**LAND ASAP**

■ **On the ground:**

**ENG (AFFECTED) IDLE POWER ONLY.**

**[L2]** *Idle power is automatically selected by FADEC.  
If associated thrust reverser is already deployed, FADEC commands restow.*

**[L1]** **THR LEVER (AFFECTED)..... IDLE**

■ **In flight:**

**[L2]** If the selected thrust lever position at the time of fault detection is:  
TO or FLEX: FADEC freezes TO or FLEX TO thrust until slat retraction. At slat retraction it selects CLB thrust.  
Between IDLE and MCT: in manual thrust setting mode, engine rating freezes at CLB , or IDLE with slats extended (or MN < 0.47 if the FADEC no longer receives the slats position due to EIU failure). It is possible to activate autothrust. If selected, autothrust mode manages thrust between idle and CLB.

**[L1]** **ENG (AFFECTED) AT IDLE**

**[L2]** *For any case of thrust lever fault (TO, FLEX or between IDLE and MCT) the FADEC will command idle thrust for the approach when slats are extended (or when MN < 0.47 if associated EIU is failed). It is independant of the autothrust condition. Thrust of affected engine remains definitively at idle even for go around.*

**[L1]** **THR LEVER (AFFECTED) ..... IDLE**

**[L2]** *When slats are extended or MN < 0.47, if on side EIU is failed.*

**[L1]** ■ **A/THR engaged:**  
**A/THR..... KEEP ON**

■ **A/THR not engaged:**  
**ENG (AFFECTED) HI PWR IN MAN THR.**

**[L2]** *Inhibited when the FADEC commands the affected engine at IDLE.*

**[L1]** ● **BEFORE SLATS IN:**  
**A/THR ..... ON**  
**HI PWR ONLY**

**[L2]** *If thrust lever angle failed in TO or flex position.*

*Continued on the following page*

**ENG 1(2) THR LEVER FAULT (Cont'd)**

Ident.: PRO-ABN-ENG-M-00012152.0002001 / 14 NOV 11

L12

**STATUS**

- **WHEN SLATS OUT:**  
(Displayed if slats not extended) or,
- **WHEN MN < 0.47:**  
(Displayed if the onside EIU is failed).

ENG 1(2) AT IDLE

**INOP SYS**

REVERSER 1(2)  
ENG 1(2) THR

**ENG THR LEVERS NOT SET**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DD-00017892.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the levers position does not correspond to TO power mode.

Flight Phase Inhibition:



Continued on the following page

**ENG THR LEVERS NOT SET (Cont'd)**

Ident.: PRO-ABN-ENG-DD-00017863.0003001 / 21 MAR 16

**[L2]** At least one FADEC engaged a takeoff thrust mode that is not in accordance with the position of the thrust levers.

- Note:
1. The takeoff thrust mode is engaged when the flight crew sets the thrust levers above the CL position.
  2. The flex takeoff thrust mode is armed only if the flight crew entered a FLEX TO TEMP on the MCDU that is above the OAT.

- [L1]** ■ If the flex mode is not armed, and the flight crew sets the thrust levers below or at the MCT/FLX position:  
 THR LEVERS..... TO/GA
- If the flex mode is armed, and the flight crew sets the thrust levers below the MCT/FLX position:  
 THR LEVERS ..... MCT/FLX

**ENG THRUST LOCKED**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DE-00017888.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when thrust levers are not moved within 5 s, following an involuntary disconnection of the A/THR (or disconnection through the FCU pb).

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DE-00017865.0002001 / 21 MAR 16

THR LEVERS.....MOVE

**ENG TYPE DISAGREE**

Applicable to: ALL


Ident.: PRO-ABN-ENG-DF-00017881.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when a rating discrepancy between two engines is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DF-00017868.0001001 / 21 MAR 16

Crew awareness.

**ENG VIB SYS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-ENG-DG-00017879.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the vibration detection system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-ENG-DG-00012074.0001001 / 25 FEB 14

Crew awareness.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

ENG

Intentionally left blank



**[QRH] LANDING WITH SLATS OR FLAPS JAMMED**

Ident.: PRO-ABN-F\_CTL-00010683.0001001 / 17 MAR 17

Applicable to: ALL

LDG DIST PROC.....APPLY

Determine flap lever position for landing

- Repeat the following until landing configuration is reached:

SPD SEL..... VFE NEXT - 5 kt

AT VFE NEXT: SELECT FLAPS LEVER ONE STEP DOWN

*Note:*

- **OVERSPEED** alert, and **VLS** displayed on the **PFD**, are computed according to the actual flaps/slats position
- **VFE** and **VFE NEXT** are displayed on the **PFD** according to the **FLAPS** lever position. If not displayed, use the placard speeds
- If **VLS** is greater than **VFE NEXT** (overweight landing case), the **FLAPS** lever can be set in the required next position, while the speed is reduced to follow **VLS** reduction as surfaces extend. The **VFE** warning threshold should not be triggered. In this case, disconnect the **A/THR**. **A/THR** can be re-engaged when the landing configuration is established.

- When in landing **CONF** and in final approach:

DECELERATE TO CALCULATED **VAPP**

AP BELOW 500 ft AGL : DO NOT USE

- For Go-around:

		MAX SPEED				
Slats	Flaps	F = 0	0 < F ≤ 1	1 < F ≤ 2	2 < F ≤ 3	F > 3
	<b>S = 0</b>	NO LIMITATION	215 kt	200 kt	185 kt	177 kt (Not allowed)
	<b>0 &lt; S &lt; 1</b>	230 kt				177 kt
	<b>S = 1</b>		200 kt	185 kt	177 kt	
	<b>1 &lt; S ≤ 3</b>	177 kt				177 kt
	<b>S &gt; 3</b>	177 kt	177 kt	177 kt	177 kt	

- If **SLATS FAULT**:

- For circuit:

MAINTAIN SLATS/FLAPS CONFIGURATION

Recommended speed: MAX SPEED - 10 kt

Continued on the following page

**[QRH] LANDING WITH SLATS OR FLAPS JAMMED (Cont'd)**

● **For diversion:**

SELECT CLEAN CONFIGURATION

Recommended speed for flaps retraction: between MAX SPEED - 10 kt and MAX SPEED.

Recommended diversion speed: MAX SPEED - 10 kt.

INCREASED FUEL CONSUMPTION

■ **If FLAPS FAULT:**

● **For circuit:**

MAINTAIN SLATS/FLAPS CONFIGURATION

Recommended speed: MAX SPEED - 10 kt

● **For diversion:**

■ **If FLAPS jammed at 0:**

SELECT CLEAN CONFIGURATION

Recommended speed for slats retraction: between MAX SPEED - 10 kt and MAX SPEED

USE NORMAL OPERATING SPEEDS

■ **If FLAPS jammed > 0:**

MAINTAIN SLAT/FLAP CONFIGURATION

Recommended speed for diversion: MAX SPEED - 10 kt

*Note:* In case of a go-around with CONF FULL selected, the **L/G NOT DOWN** warning is triggered at landing gear retraction.

INCREASED FUEL CONSUMPTION

**CAUTION**

For flight with SLATS or FLAPS extended, fuel consumption is increased. Refer to the fuel flow indication. As a guideline, determine the fuel consumption in clean configuration at the same altitude without airspeed limitation (e.g. From ALTERNATE FLIGHT PLANNING tables) and multiply this result by the applicable Fuel Penalty Factor provided in the QRH, to obtain the fuel penalty required to reach the destination in the current configuration. Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table.

**[QRH] RUDDER JAM**

Ident.: PRO-ABN-F\_CTL-00011807.0001001 / 17 MAR 17

Applicable to: ALL

- L2** Rudder jamming may be detected by undue (and adverse) pedal movement during rolling maneuvers.  
This is because the yaw damper orders can no longer be sent to the rudder, but are fed back to the pedals.  
Use F/CTL SD page for a visual check of the rudder position.
- L1** ● **For approach:**  
AVOID LANDING WITH CROSSWIND FROM THE SIDE WHERE THE RUDDER IS DEFLECTED  
MAX CROSSWIND FOR LDG: 15 kt  
AUTO BRK.....DO NOT USE
- L2** *Do not use the autobrake, so as not to delay the application of differential braking at landing roll.*
- L1** FOR LANDING..... USE NORMAL CONF  
SPEED AND TRAJECTORY.....STABILIZE ASAP  
LDG DIST PROC..... APPLY
- **For landing:**  
DIFFERENTIAL BRAKING..... USE ASAP  
REVERSER: SYMMETRIC USE ONLY
- L2** *Use nosewheel steering handle below 70 kt.*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

F/CTL

**[QRH] STABILIZER JAM**

Ident.: PRO-ABN-F\_CTL-00011806.0001001 / 17 MAR 17

Applicable to: ALL

[L2] The ELACs may not detect a stabilizer jam when the pitch trim wheel is jammed.  
 The flight control normal law remains active in this case and there is no ECAM warning.  
 Apply the following procedure.

[L1] AP ..... OFF  
 MAN PITCH TRIM ..... CHECK

[L2] *The pitch trim wheel may not be fully jammed, the force needed may be higher than pre-takeoff manual setting.*

[L1] ● **If MAN PITCH TRIM available:**  
 TRIM FOR NEUTRAL ELEV

[L2] *If manual pitch trim is available, trim to maintain the elevator at the zero position (indications on F/CTL SD page).*

[L1] ● **If MAN PITCH TRIM not available:**  
 FOR LANDING: USE FLAP 3

[L2] *Do not select configuration full so as not to degrade the handling qualities.*

[L1] GPWS LDG FLAP 3 ..... ON

CAT 1 ONLY

**ACTIVE CONTROL LAW**

Ident.: PRO-ABN-F\_CTL-00018549.0001001 / 21 MAR 16

Applicable to: ALL

ACTIVE LAW ▶	PITCH		ROLL	YAW
	LAW	PROTEC		
ELAC 1 or 2 or SEC 1 or 2	NORM	NORM	NORM	NORM
ELAC 1 and 2 or both ailerons	ALTN	REDUCED	DIRECT	ALTN
2 SEC	NORM	NORM	NORM	NORM
3 SEC	ALTN	REDUCED	DIRECT	ALTN
2 FAC	ALTN	REDUCED	DIRECT	MECH
Yaw damper	ALTN	REDUCED	DIRECT	MECH
2 SFCC (slat channel)	ALTN	NO	DIRECT	ALTN
2 ADR or 2 IR (2nd self detected)	ALTN	REDUCED	DIRECT	ALTN
2 ADR (2nd not self detec.)	ALTN	NO ----- REDUCED <sup>(1)</sup>	DIRECT	ALTN
2 IR (2nd not self detec.)	DIRECT ----- ALTN <sup>(2)</sup>	NO ----- REDUCED <sup>(2)</sup>	DIRECT	MECH ----- ALTN <sup>(2)</sup>
3 ADR	ALTN	NO	DIRECT	MECH
3 IR	DIRECT	NO	DIRECT	MECH
2 RADIO ALT	NORM ----- DIRECT <sup>(4)</sup>	NORM ----- NO <sup>(4)</sup>	NORM ----- DIRECT <sup>(4)</sup>	NORM ----- MECH <sup>(4)</sup>
SPOILER 4 or 5 or (4 and 5)	NORM	NORM	NORM	NORM
All SPOILERS	ALTN	REDUCED	DIRECT	ALTN
1 AIL SERVO or 1 AILERON	NORM	NORM	NORM	NORM
1 ELEV SERVO	NORM	NORM	NORM	NORM
1 ELEVATOR	ALTN	REDUCED	DIRECT	ALTN
THS (jammed) <sup>(5)</sup>	NORM	NORM	NORM	NORM
	ALTN	REDUCED	DIRECT	ALTN
HYD G or Y or B	NORM	NORM	NORM	NORM
HYD G + Y	ALTN	REDUCED	DIRECT	MECH
HYD G + B	ALTN	NO	DIRECT	ALTN
HYD Y + B	NORM	NORM	NORM	NORM
on BATTERIES	ALTN	REDUCED	DIRECT	MECH
on EMER GEN	ALTN	REDUCED	DIRECT	MECH

Continued on the following page

**ACTIVE CONTROL LAW (Cont'd)**

ACTIVE LAW ▶ SYS FAILED▼	PITCH		ROLL	YAW
	LAW	PROTEC		
				----- ALTN <sup>(3)</sup>

- (1) *In case of AOA disagree*
- (2) *After the faulty IR is selected OFF*
- (3) *After FAC 1 is reset*
- (4) *When landing gear down (or CONF 2, if both LGCIUs faulty)*
- (5) *Depending where the failure is, control law may revert to alternate law*

**ELEVATORS AND STABILIZER CONTROL AFTER FAILURE**

Ident.: PRO-ABN-F\_CTL-00018591.0001001 / 09 FEB 16

Applicable to: ALL

	LEFT ELEVATOR		THS	RIGHT ELEVATOR	
	BLUE	GREEN	GREEN AND YELLOW	YELLOW	BLUE
<u>NORM OPERATION</u>		ELAC 2	ELAC 2	ELAC 2	
<u>SINGLE FAILURE</u>					
ELAC 2	ELAC 1		ELAC 1		ELAC 1
ELAC 1		ELAC 2	ELAC 2	ELAC 2	
SEC 2		ELAC 2	ELAC 2	ELAC 2	
SEC 1		ELAC 2	ELAC 2	ELAC 2	
G	ELAC 1		ELAC 1		ELAC 1
Y	ELAC 1		ELAC 1		ELAC 1
B		ELAC 2	ELAC 2	ELAC 2	
<u>DOUBLE FAILURE</u>					
ELAC + ELAC 1		SEC 2	SEC 2	SEC 2	
2					
+ SEC 2	ELAC 1		ELAC 1		ELAC 1
+ SEC 1	ELAC 1		ELAC 1		ELAC 1
+ G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B		SEC 2	SEC 2	SEC 2	
ELAC + SEC 2		ELAC 2	ELAC 2	ELAC 2	
1					
+ SEC 1		ELAC 2	ELAC 2	ELAC 2	
+ G	SEC 1		SEC 2	SEC 2	
+ Y		SEC 2	SEC 2		SEC 1
+ B		ELAC 2	ELAC 2	ELAC 2	
SEC 2 + SEC 1		ELAC 2	ELAC 2	ELAC 2	
+ G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B		ELAC 2	ELAC 2	ELAC 2	
SEC 1 + G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B		ELAC 2	ELAC 2	ELAC 2	
G + Y	ELAC 1		INOP		ELAC 1
B + G		Damped	ELAC 2	ELAC 2	
B + Y		ELAC 2	ELAC 2		Damped
<u>TRIPLE FAILURE</u>					
<u>ELAC 2</u>					
ELAC + SEC 2	SEC 1		SEC 1		SEC 1
1					
+ SEC 1		SEC 2	SEC 2	SEC 2	
+ G	SEC 1		SEC 2	SEC 2	

Continued on the following page

**ELEVATORS AND STABILIZER CONTROL AFTER FAILURE (Cont'd)**

+ Y		SEC 2	SEC 2		SEC 1
+ B		SEC 2	SEC 2	SEC 2	
SEC 2 + SEC 1	ELAC 1		ELAC 1		ELAC 1
+ G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B	Centered		Mechanical	Centered	
SEC 1 + G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B		SEC 2	SEC 2	SEC 2	
G + Y	ELAC 1		INOP		ELAC 1
B + G	Damped		SEC 2	SEC 2	
B + Y		SEC 2	SEC 2		Damped
<u>ELAC 1</u>					
SEC 2 + SEC 1		ELAC 2	ELAC 2	ELAC 2	
+ G	SEC 1		SEC 1		SEC 1
+ Y	SEC 1		SEC 1		SEC 1
+ B		ELAC 2	ELAC 2	ELAC 2	
SEC 1 + G	Damped		SEC 2	SEC 2	
+ Y		SEC 2	SEC 2		Damped
+ B		ELAC 2	ELAC 2	ELAC 2	
G + Y	SEC 1		INOP		SEC 1
B + G	Damped		ELAC 2	ELAC 2	
B + Y		ELAC 2	ELAC 2		Damped
SEC 2					
SEC 1 + G	ELAC 1		ELAC 1		ELAC 1
+ Y	ELAC 1		ELAC 1		ELAC 1
+ B		ELAC 2	ELAC 2	ELAC 2	
G + Y	ELAC 1		INOP		ELAC 1
B + G	Damped		ELAC 2	ELAC 2	
B + Y		ELAC 2	ELAC 2		Damped
SEC 1					
G + Y	ELAC 1		INOP		ELAC 1
B + G	Damped		ELAC 2	ELAC 2	
B + Y		ELAC 2	ELAC 2		Damped



**F/CTL AIL SERVO FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-AF-00016986.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a loss of one servojack on one aileron, or loss of one or both ELAC 1 rudder pedal transducers.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AF-00018412.0001001 / 21 MAR 16

Crew awareness.

**F/CTL ALTN LAW**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-K-00016965.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when alternate laws are active.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-K-00018413.0001001 / 22 MAR 17

**L2** Refer to DSC-27-20-20 General for flight characteristics.  
 With autopilot engaged the FMGC (AP mode) controls the aircraft.

**L1 (PROT LOST)**

**L2** All protections, except maneuver protections, are lost. Depending on the failure, static stability may be introduced.

**L1 Note:** In case of GPWS (EGPWS  $\triangleleft$ ) alerts, since protections are lost, respect stall warnings when applying the GPWS (EGPWS  $\triangleleft$ ) procedure.

**MAX SPEED**..... **320 KT**

**L2** (320/.77 if dual hydraulic system low pressure). Speed is limited to 320/.82 or 320/.77 for dual hydraulic failure, due to the loss of high-speed protection.

**L1 SPD BRK (IF L OR R ELEVATOR FAULT)** ..... **DO NOT USE**

Continued on the following page

**F/CTL ALTN LAW (Cont'd)**

Ident.: PRO-ABN-F\_CTL-K-00018414.0003001 / 22 MAR 17

L12

**STATUS**

**MAX SPEED**..... 320 KT  
(320/.77, if dual hydraulic system low pressure).  
**SPD BRK (IF L OR R ELEVATOR FAULT)**..... DO NOT USE

**APPR PROC**

**FOR LDG**..... **USE FLAP 3**  
*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*  
**GPWS LDG FLAP 3** .....ON  
**APPR SPD** ..... VREF+10  
**LDG DIST PROC** ..... APPLY

● **If no AP engaged:**

**WHEN L/G DN: DIRECT LAW**

*At landing gear extension, control reverts to direct law in pitch, as well as in roll. Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW.*

● **If AP engaged:**

**WHEN L/G DN AND AP OFF: DIRECT LAW**

*If the autopilot is disengaged:*

- Before landing gear extension, flight control alternate law is active.
- After landing gear extension, flight control direct law is active. Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW.

**ALTN LAW: PROT LOST**

**INOP SYS**

F/CTL PROT  
STEEP APPR 

**F/CTL DIRECT LAW**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-J-00016964.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when direct law is active.

Flight Phase Inhibition:





*Continued on the following page*

**F/CTL DIRECT LAW (Cont'd)**

Ident.: PRO-ABN-F\_CTL-J-00018420.0001001 / 22 MAR 17

**L2** PFD displays « USE MAN PITCH TRIM » in amber. *Refer to DSC-27-20-10-70 Aircraft Trimming*

**L1** (PROT LOST)

**L2** Note: *In case of GPWS (EGPWS ) alerts, since protections are lost, respect stall warning when applying the GPWS (EGPWS ) procedure.*

**L1** MAX SPEED.....320/.77

**L2** *Speed is limited, due to the loss of high-speed protection. Do not exceed M 0.77, so as not to degrade handling qualities.*

**L1** MAN PITCH TRIM (EXCEPT IF HYD Y + G SYS LO PR)..... USE

**L2** *Automatic trim is inoperative in direct law.*

**L1** MANEUVER WITH CARE

**L2** *Use small control inputs at high speed, since in direct law the controls are powerful. Use of manual thrust is recommended. Avoid large thrust changes.*

**L1** USE SPD BRK WITH CARE

**L2** *At high Mach numbers, use speed brakes with care to avoid too strong nose up changes.*

*Continued on the following page*

**F/CTL DIRECT LAW (Cont'd)**

Ident.: PRO-ABN-F\_CTL-J-00018422.0003001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320/.77  
 MANEUVER WITH CARE  
 USE SPD BRK WITH CARE

**APPR PROC**

FOR LDG..... USE FLAPS 3  
*This line is replaced by "FOR LDG : USE FLAP 3" when  
 CONF 3 is selected, as a reminder.*  
 GPWS LDG FLAP 3..... ON  
 MAN PITCH TRIM..... USE  
 APPR SPD..... VREF+10  
 LDG DIST PROC..... APPLY

**DIRECT LAW**

**INOP SYS**

F/CTL PROT  
 STEEP APPR 

**F/CTL ELAC 1(2) FAULT**  
**(ONE COMPUTER FAILED)**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-F-00016960.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when there is a failure of ELAC (FAULT It on ELAC pb), or when one sidestick transducer is faulty.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-F-00018425.0006001 / 21 MAR 16

**ELAC (AFFECTED)..... OFF THEN ON**

**L2 Note:** 1. In some sidestick transducer failure cases, ELAC 1(2) FAULT is triggered without the procedure, and FAULT It on associated pb does not come on.  
 2. If the ELAC 1 computer is reset on ground the pitch trim returns to the ground setting position (0°).

**L1 ● IF UNSUCCESSFUL:**  
**ELAC (AFFECTED)..... OFF**

**L2** Functions are performed by other ELAC.

**L1 FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

Continued on the following page

**F/CTL ELAC 1(2) FAULT (Cont'd)**  
**(ONE COMPUTER FAILED)**

Ident.: PRO-ABN-F\_CTL-F-00018426.0003001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**CAT 3 SINGLE ONLY**  
**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**ELAC 1(2)**  
**CAT 3 DUAL**

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.



**F/CTL ELAC 1(2) FAULT**  
**(BOTH COMPUTERS FAILED)**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-G-00018899.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a failure of ELAC (FAULT It on ELAC pb), or when one sidestick transducer is faulty.

Flight Phase Inhibition:



*Continued on the following page*

**F/CTL ELAC 1(2) FAULT (Cont'd)**  
**(BOTH COMPUTERS FAILED)**

Ident.: PRO-ABN-F\_CTL-G-00018433.0009001 / 22 MAR 17

ELAC 1..... OFF THEN ON

[2] **Note:** If the ELAC 1 computer is reset on ground, the pitch trim returns to the ground setting position (0°).

[L1] ELAC 2..... OFF THEN ON

● **If both ELAC FAULT remain:**

ELAC 1..... OFF

ELAC 2..... OFF

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

[2] Pitch and roll normal laws are lost: Refer to PRO-ABN-F\_CTL F/CTL ALTN LAW. THS motor 1 and both ailerons are lost. LAF is degraded and uses spoilers only.

[L1] **MAX SPEED**..... 320 KT

**FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

*Continued on the following page*

**F/CTL ELAC 1(2) FAULT (Cont'd)**  
**(BOTH COMPUTERS FAILED)**

Ident.: PRO-ABN-F\_CTL-G-00018434.0004001 / 22 MAR 17

L12

**STATUS**

**MAX SPEED**..... 320 KT

**INOP SYS**

**APPR PROC**

F/CTL PROT

L+R AIL

ELAC 1+2

AP 1+2

CAT 2

STEEP APPR 

**FOR LDG**..... **USE FLAP 3**

*This line is replaced by "FOR LDG : USE FLAP 3" when  
CONF 3 is selected, as a reminder.*

**GPWS LDG FLAP 3**..... **ON**

*Will be displayed when flaps in CONF 3*

**APPR SPD**..... **VREF+10 KT**

**LDG DIST PROC**..... **APPLY**

**ALTN LAW: PROT LOST**  
**WHEN L/G DOWN: DIRECT LAW**

*See <sup>(1)</sup>*

**FUEL CONSUMPT INCRSD**

*See <sup>(2)</sup>*

**FMS PRED UNRELIABLE**

*See <sup>(3)</sup>*

- <sup>(1)</sup> *At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).*
- <sup>(2)</sup> *This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*
- <sup>(3)</sup> *Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.*

**F/CTL ELAC 1(2) PITCH FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-H-00016977.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is a failure of pitch channel in ELAC 1(2).

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-H-00018447.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-F\_CTL-H-00018448.0001001 / 21 MAR 16

**STATUS**

**CAT 3 SINGLE ONLY**

**INOP SYS**

ELAC PITCH <sup>(1)</sup>  
CAT 3 DUAL

<sup>(1)</sup> (If ELAC 1 and 2 PITCH FAULT)

**F/CTL ELEV SERVO FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-P-00016979.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a loss of one servojack on one elevator.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-P-00018449.0001001 / 21 MAR 16

Crew awareness.

**CAUTION** Do not use speedbrakes above 350 kt/M 0.82 (VMO /MMO).

Ident.: PRO-ABN-F\_CTL-P-00018450.0001001 / 21 MAR 16

**STATUS**

CAT 3 SINGLE ONLY

**INOP SYS**

CAT 3 DUAL

**F/CTL FCDC 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-L-00016981.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is a failure of one FCDC.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-L-00011777.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-F\_CTL-L-00011778.0001001 / 18 AUG 10

**STATUS**

**INOP SYS**

FCDC 1(2)

**F/CTL FCDC 1+2 FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-M-00016963.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a failure of both FCDCs.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-M-00011779.0001001 / 18 AUG 10

**MONITOR F/CTL OVHD PNL**

L2

F/CTL data on ECAM is lost.

Control laws remains normal.

Note: When both FCDCs fails:

- F/CTL warning are not available on the ECAM.
- Stall warning may be triggered as in alternate or direct law (it may occur at speeds greater than  $V_{\alpha}$  max).
- Bank and pitch limits are no longer displayed on the PFD.
- $V_{\alpha}$  prot,  $V_{\alpha}$  max are lost on the PFD.
- $V_{sw}$ , displayed on the PFD, corresponds to the stall warning of the alternate or direct law.

Continued on the following page

**F/CTL FCDC 1+2 FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-M-00018451.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

F/CTL INDICATIONS LOST

FCDC 1 + 2  
 STEEP APPR 


**F/CTL FLAP ATTACH SENSOR**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-AH-00016989.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

 This alert triggers when there is failure of flap attachment's failure detection sensor.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AH-00018453.0001001 / 21 MAR 16

Crew awareness.



**F/CTL FLAPS FAULT/LOCKED**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-A-00011744.0002001 / 21 MAR 16

- **If flaps locked:**  
WING TIP BRK ON OR ALIGNMENT FAULT

MAX SPEED..... REFER TO PRO-ABN-F\_CTL F/CTL FLAPS/SLATS FAULT/LOCKED

**L2** Limit speed to the VFE corresponding to the next flap position

- L1** ● **If flaps not locked:**  
FLAPS LEVER..... RECYCLE

**L2** Return to the previous selection, then back to the desired position.

- L1** ● **If flaps extended:**  
FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

- L2** ● **If unsuccessful:**

Refer to PRO-ABN-F\_CTL [QRH] Landing with Slats or Flaps Jammed .

The autopilot may be used down to 500 ft AGL. As it is not tuned for abnormal configurations, its behavior can be less than optimum and must be monitored.

Continued on the following page

**F/CTL FLAPS FAULT/LOCKED (Cont'd)**

Ident.: PRO-ABN-F\_CTL-A-00018456.0004001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

FOR LDG (IF FLAPS  $\leq$  3).....USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder*

FLAPS (IF FLAPS > 3).....KEEP CONF FULL

GPWS FLAP MODE (IF FLAPS < 3).....OFF

GPWS LDG FLAP 3 (IF FLAPS  $\geq$  3).....ON

APPR SPD..... REFER

TO PRO-ABN-F\_CTL F/CTL FLAPS/SLATS FAULT/LOCKED

LDG DIST PROC..... APPLY

ENG 1 APPR IDLE ONLY (Only in case of FLAPS FAULT)

ENG 2 APPR IDLE ONLY (Only in case of FLAPS FAULT)

FUEL CONSUMPT INCRSD

See <sup>(2)</sup>

FMS PRED UNRELIABLE

See <sup>(3)</sup>

FLAPS

AP 1+2 <sup>(1)</sup>

A/THR <sup>(1)</sup>

Moreover, both FDs are lost <sup>(1)</sup>

CAT 2 <sup>(1)</sup>

GLS AUTOLAND 

STEEP APPR 

<sup>(1)</sup> (If both flap channels fault.)

<sup>(2)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(3)</sup> Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.

**F/CTL FLAP LVR NOT ZERO**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-AI-00018902.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the FLAP lever is not in the zero position, and the aircraft is above 22 000 ft.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AI-00018454.0001001 / 21 MAR 16

Crew awareness.

**F/CTL FLAP SYS 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-E-00016990.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is failure of flap channel in one SFCC.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-E-00011753.0002001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-F\_CTL-E-00011754.0002001 / 30 MAR 12

L12

**STATUS**

**APPR PROC**

- **In case of FLAP SYS 1 FAULT:**  
GPWS FLAP MODE.....OFF  
*Flap position signal to GPWS is lost.*

**ENG 1(2) APPR IDLE ONLY**  
**FLAPS SLOW**

**F/CTL FLAPS/SLATS FAULT/LOCKED**

Ident.: PRO-ABN-F\_CTL-00018457.0001001 / 17 MAR 17

Applicable to: ALL

MAX SPEED					
Flaps <sup>(1)</sup> Slats <sup>(1)</sup>	F = 0	0 < F ≤ 1	1 < F ≤ 2	2 < F ≤ 3	F > 3
S = 0	NO LIMITATION	215 kt	200 kt	185 kt	Not allowed (177 kt)
0 < S < 1	230 kt				
S = 1					
1 < S ≤ 3	200 kt				
S > 3					177 kt

<sup>(1)</sup> Slats/Flaps position displayed on the upper ECAM display.

APPR SPD					
Flaps <sup>(1)</sup> Slats <sup>(1)</sup>	F = 0	0 < F < 1	1 ≤ F < 2	2 ≤ F < 3	F ≥ 3
S = 0	VREF +60 (Appr) VREF +50 (Touch Down)	VREF +45	VREF +30	VREF +25	(FLAPS > 3 not allowed) VREF +25
0 < S < 1					
1 ≤ S ≤ 3	VREF +25	VREF +15	VREF +10		VREF +10
S > 3					VREF +5

<sup>(1)</sup> Slats/Flaps position displayed on the upper ECAM display.

**CAUTION**

For flight with SLATS or FLAPS extended, fuel consumption is increased. Refer to the fuel flow indication.

As a guideline, determine the fuel consumption in clean configuration, at the same altitude without airspeed limitation (e.g. from ALTERNATE FLIGHT PLANNING tables, Refer to PER-FPL-FLP-ALN-20 ALTERNATE PLANNING ISA), and multiply this result by the applicable Fuel Penalty Factor provided in the QRH (Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table) to obtain the fuel penalty required to reach the destination in the current configuration.

**F/CTL GND SPLR 5 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-Z-00016967.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when there is a loss of ground spoiler function in SEC 2.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-Z-00018903.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-F\_CTL-Z-00014253.0001001 / 23 MAY 12

**L12**

**STATUS**

LDG DIST PROC.....APPLY

**INOP SYS**

GND SPLR 5

**F/CTL GND SPLR / 1+2 / 3+4 / FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-S-00016968.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

- GND SPLR FAULT :  
 Loss of ground spoiler function in SEC 1+3, or 1+2, or 2+3, or 1+2+3.  
 If ground spoiler function is lost in SEC (1+2) or (1+3), one reverser is inoperative.  
 If ground spoiler function is lost in SEC (1+2+3), both reversers are inoperative.  
 In any case, the autobrake function is lost.
- GND SPLR 1+2(3+4) FAULT:  
 Loss of ground spoiler function in SEC 3 (or 1).

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-S-00018466.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-F\_CTL-S-00011793.0001001 / 11 MAY 12

**STATUS**

LDG DIST PROC..... APPLY

**INOP SYS**

GND SPLR (affected)

**F/CTL GND SPLR NOT ARMED**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-AJ-00016966.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when ground spoilers are not armed before landing.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AJ-00018905.0001001 / 21 MAR 16

Crew awareness.



**F/CTL L(R) AIL FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-N-00016975.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a loss of both servojacks on one aileron.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-N-00018474.0002001 / 21 MAR 16

Crew awareness.

**FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

*Continued on the following page*

**F/CTL L(R) AIL FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-N-00011783.0003001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

L (R) AIL

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.

**F/CTL L(R) ELEV FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-Q-00016974.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when there is a loss of both servojacks on one elevator, or activation of elevator flutter protection in ELAC.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-Q-00018484.0001001 / 22 MAR 17

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

**L2** Note: If the L(R) elevator fails, the ELAC s loose pitch control through the elevator. Therefore, the SEC s control pitch in alternate law. This is not the case, if the right elevator is lost, due to the failure of B+Y hydraulic circuits. Pitch normal law remains active in ELAC.

**L1** **MAX SPEED**.....**320 KT**

**L2** Speed is limited, due to the loss of high-speed protection.

**L1** **SPD BRK**.....**DO NOT USE**

Continued on the following page

**F/CTL L(R) ELEV FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-Q-00018490.0003001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT  
 SPD BRK.....DO NOT USE

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when  
 CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3.....ON

*Will be displayed, when flaps in CONF 3.*

APPR SPD.....VREF+10 KT  
 LDG DIST PROC..... APPLY

**ALTN LAW: PROT LOST**  
**WHEN L/G DN: DIRECT LAW**

See <sup>(1)</sup>

**INOP SYS**

F/CTL PROT  
 L (R) ELEV  
 ELAC PITCH  
 AP 1+2  
 CAT 2  
 GLS AUTOLAND   
 STEEP APPR 

<sup>(1)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll. Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW.

**F/CTL L+R ELEV FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-O-00016958.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both elevators are lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-O-00018491.0001001 / 22 MAR 17

**MAX SPEED**.....320/.77

**L2** Due to loss of high speed protections.

**L1** **MAN PITCH TRIM**..... **USE**

**L2** Only manual trim is available for pitch control.

**L1** **SPD BRK**..... **DO NOT USE**

**L2** Do not use speed brakes, because it is difficult to control the induced pitch moment with manual pitch trim only.

Continued on the following page

**F/CTL L+R ELEV FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-O-00018492.0009001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320/.77  
 SPD BRK.....DO NOT USE

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when  
 CONF 3 is selected, as a reminder*

GPWS LDG FLAP 3.....ON

*Will be displayed when flaps in CONF 3.*

MAN PITCH TRIM..... USE

APPR SPD..... VREF+10

LDG DIST PROC..... APPLY

PITCH MECH BACK UP  
 ROLL DIRECT LAW

**INOP SYS**

L+R ELEV  
 ELAC PITCH  
 AP 1+2  
 CAT 2  
 GLS AUTOLAND   
 STEEP APPR 

**F/CTL L(R) SIDESTICK FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-Y-00016959.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when transducers, on pitch or roll axis, are failed on one sidestick.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-Y-00011756.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-F\_CTL-Y-00014250.0001001 / 30 MAR 12

**STATUS**

**INOP SYS**

L(R) SIDESTICK

**F/CTL PITCH TRIM/MCDU/CG DISAGREE**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-AL-00016956.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the system detects that the real pitch value and the pitch trim value entered in the MCDU disagree.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AL-00018906.0025001 / 21 MAR 16

Crew awareness.



**F/CTL SEC 1(2)(3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-I-00016961.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is a failure of one SEC.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-I-00018502.0002001 / 21 MAR 16

SEC (AFFECTED)..... OFF THEN ON

● **IF UNSUCCESSFUL:**  
SEC (AFFECTED)..... OFF

L2 Associated spoilers are lost.  
If all spoilers are inoperative (3 SECs failed), roll direct law and pitch alternate law become active.

L1 SPD BRK (IF SEC 1 AFFECTED)..... DO NOT USE

L2 VLS would not be corrected, if speed brakes 2 extend (no speed brake position sent to FACs).

L1 ● If SEC 1 + 2 + 3 fail

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**PROT LOST**

Continued on the following page

**F/CTL SEC 1(2)(3) FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-I-00018504.0004001 / 01 JUN 16

L12

**STATUS**

SPD BRK.....DO NOT USE

(If SEC 1 is affected.)

● **If SEC 1 + 2 + 3 fail:**

FOR LDG.....USE FLAP 3

APPR SPD.....VREF + 10KT

LDG DIST PROC.....APPLY

● **(If SEC 1 + 2 + 3 fail).**

**ALTN LAW: PROT LOST**

- If no AP engaged and SEC 1 + 2 + 3 fail.

**WHEN L/G DN: DIRECT LAW**

*If SEC 1 + 2 + 3 fail. In such a case, the LGCIU information can no longer be sent to the ELAC . For the activation of DIRECT law, the ELAC uses the condition "slats and flaps in CONF 2", instead of "landing gear down".*

- If AP engaged and SEC 1 + 2 + 3 fail.

**WHEN L/G DN AND AP OFF: DIRECT LAW**

*If SEC 1 + 2 + 3 fail. In such a case, the LGCIU information can no longer be sent to the ELAC . For the activation of DIRECT law, the ELAC uses the condition "slats and flaps in CONF 2", instead of "landing gear down".*

**INOP SYS**

F/CTL PROT <sup>(1)</sup>

SPLR (associated)

SEC (affected)

REVERSER 1(2) <sup>(2)</sup>

AUTO BRK <sup>(3)</sup>

STEEP APPR  <sup>(4)</sup>

ROW/ROP 

<sup>(1)</sup> (If SEC 1 + 2 + 3 fail)

<sup>(2)</sup> (If SEC 1 + 2 fail, reverser 1 is not available for landing. If SEC 1 + 3 fail, reverser 2 is not available for landing)

<sup>(3)</sup> (If at least 2 SECs fail)

*Continued on the following page*

**F/CTL SEC 1(2)(3) FAULT (Cont'd)**

<sup>(4)</sup> (If at least SEC 1 fails.)

**F/CTL SIDESTICK PRIORITY**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-AM-00016983.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is failure in a sidestick priority logic circuit.

Flight Phase Inhibition:



*Continued on the following page*

**F/CTL SIDESTICK PRIORITY (Cont'd)**

Ident.: PRO-ABN-F\_CTL-AM-00018509.0001001 / 21 MAR 16

**CHECK PRIORITY LOGIC**

**[L2]** Check the integrity of flight control priority, as follows (not displayed on ECAM) :

**[L1]** ELAC 1..... OFF THEN ON

**[L2]** Note: When the ELAC 1 computer is reset on ground, the pitch trim returns to the ground setting position (0°).

**[L1]** ELAC 2..... OFF THEN ON

**[L2]** ■ **If the warning disappears:**

CAPT TAKE OVER pb..... PRESS (at least 3 seconds)

Check that the :

- Aural "priority left" message is activated.
- F/O red arrow light is on.

CAPT TAKE OVER pb..... RELEASE

F/O TAKE OVER pb..... PRESS (at least 3 seconds)

Check that the:

- Aural "priority right" message is activated
- CAPT red arrow light is on.

F/O TAKE OVER pb..... RELEASE

Check that the warning does not reappear.

Note: There is no need to move the sidestick for the check.

■ **If the warning does not disappear, or if the warning reappears after the above check:**

Maintenance action is due.

**F/CTL SLAT(FLAP) TIP BRK FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-AN-00016996.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is failure of one wing tip brake on slats or flaps, or failure of one wing tip brake solenoid on slats, or flaps.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AN-00018510.0001001 / 21 MAR 16

Crew awareness.

**F/CTL SLATS AND FLAPS FAULT IN CONF 0**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-C-00018511.0001001 / 22 MAR 17

FLAPS LEVER.....RECYCLE

- If both slat channels fail:

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**

(PROT LOST)

MAX SPEED..... 320 KT

*Continued on the following page*

**F/CTL SLATS AND FLAPS FAULT IN CONF 0 (Cont'd)**

Ident.: PRO-ABN-F\_CTL-C-00018512.0002001 / 22 MAR 17

L12

**STATUS**

**MAX SPEED..... 320 KT**

**ALTN LAW: PROT LOST**

**APPR PROC**

**FOR LDG..... USE FLAP 1**

*With FLAPS lever set at 1, AP /FD GO AROUND mode is available.*

**CTR TK PUMPS..... OFF**

**GPWS FLAP MODE..... OFF**

**APPR SPD..... VREF +60 KT**

*Approach with A/THR in selected mode is recommended.*

- **If both slat channels fail:**  
**WHEN L/G DN: DIRECT LAW**

- **AT 300 FT AGL:**  
**TARGET SPD..... VREF +50 KT**

*Reduce speed between 500 ft and 300 ft to reach VREF +50 kt at runway threshold, and disconnect A/THR, as the target speed may be below VLS.*

**LDG DIST PROC..... APPLY**

- **Only in case of FLAPS FAULT:**  
**ENG 1 APPR IDLE ONLY**  
**ENG 2 APPR IDLE ONLY**

**INOP SYS**

F/CTL PROT <sup>(1)</sup>  
 SLATS  
 FLAPS  
 AP 1+2 <sup>(2)</sup>  
 A/THR <sup>(2)</sup>  
 Moreover, both FDs are lost <sup>(2)</sup>  
 CAT 2 <sup>(2)</sup>  
 STEEP APPR 

<sup>(1)</sup> (If both slat channels fail.)

<sup>(2)</sup> (If both slat or flap channels fail.)

**F/CTL SLATS FAULT/LOCKED**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-B-00018517.0006001 / 22 MAR 17

● **If slats locked:**

WING TIP BRK ON

MAX SPEED..... REFER TO PRO-ABN-F\_CTL F/CTL FLAPS/SLATS FAULT/LOCKED

<sup>L2</sup> Speed is limited to the VFE corresponding to the next slat position.

<sup>L1</sup> ● **If slats not locked:**

FLAPS LEVER..... RECYCLE

<sup>L2</sup> Return to the previous selection, then back to the desired position.

<sup>L1</sup> ● **If slats extended:**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

● **If unsuccessful:**

<sup>L2</sup> Refer to PRO-ABN-F\_CTL [QRH] Landing with Slats or Flaps Jammed.

The autopilot may be used down to 500 ft AGL. As it is not tuned for the abnormal configurations, its behavior could be less than optimum and must be monitored.

<sup>L1</sup>  
<sup>L12</sup> Note: If there is a SLATS FAULT after both slat channels fail, alternate law becomes active (Refer to PRO-ABN-F\_CTL F/CTL ALTN LAW).

● **If slats not at zero:**

FUEL MODE SEL.....MAN

<sup>L2</sup> To allow CTR TK feeding.

<sup>L1</sup> CTR TK PUMPS.....AS RQRD

<sup>L2</sup> Set CTR TK PUMPS pb to OFF when CTR TK is empty or during approach.

Continued on the following page

**F/CTL SLATS FAULT/LOCKED (Cont'd)**

Ident.: PRO-ABN-F\_CTL-B-00018518.0004001 / 22 MAR 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

CTR TK PUMPS..... OFF

GPWS LDG FLAP 3..... ON

APPR SPD..... REFER

TO PRO-ABN-F\_CTL F/CTL FLAPS/SLATS FAULT/LOCKED

LDG DIST PROC..... APPLY

**CTR TK FEED: MAN ONLY**

● **If both slat channels fail, or slats are locked in clean configuration and flaps are at, or above, CONF 2:**

**ALTN LAW: PROT LOST**

**WHEN L/G DN: DIRECT LAW**

**FUEL CONSUMPT INCRSD**

See <sup>(2)</sup>

**FMS PRED UNRELIABLE**

See <sup>(3)</sup>

F/CTL PROT <sup>(1)</sup>

SLATS

AP 1+2 <sup>(1)</sup>

A/THR <sup>(1)</sup>

Moreover, both FDs are lost <sup>(1)</sup>

CAT 2 <sup>(1)</sup>

STEEP APPR  <sup>(1)</sup>

GLS AUTOLAND  <sup>(1)</sup>

<sup>(1)</sup> (If both slat channels fail.)

<sup>(2)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(3)</sup> Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.



**F/CTL SLAT SYS 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-D-00016995.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is failure of slat channel in one SFCC.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-D-00011751.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-F\_CTL-D-00011752.0001001 / 18 AUG 10

**STATUS**

SLATS SLOW

**F/CTL SPD BRK 2 (3+4) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-W-00016980.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when speedbrake lever transducers to SEC 3 (1) failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-W-00018519.0001001 / 21 MAR 16

● **If SPD BRK 3+4 affected:**

SPD BRK..... DO NOT USE

L2 Do not use speedbrakes since it is not efficient to use only surfaces n° 2, and would active the SPD BRK DISAGREE caution.

Ident.: PRO-ABN-F\_CTL-W-00018520.0001001 / 21 MAR 16

**STATUS**

● **If SPD BRK 3+4 affected:**

SPD BRK..... DO NOT USE

LDG DIST PROC..... APPLY

**INOP SYS**

SPD BRK (affected)  
 STEEP APPR (1)

(1) (if SPD BRK 3 and 4 are affected)

**F/CTL SPD BRK DISAGREE**  
(SURFACES 3+4 AFFECTED)

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-T-00016970.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a position disagree between surfaces and lever position.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-T-00018521.0001001 / 21 MAR 16

SPD BRK LEVER.....RETRACT  
SPD BRK.....DO NOT USE

Ident.: PRO-ABN-F\_CTL-T-00018522.0001001 / 21 MAR 16

**STATUS**

SPD BRK.....DO NOT USE

**INOP SYS**

SPD BRK 3+4  
STEEP APPR

**F/CTL SPD BRK DISAGREE**  
(SURFACES 2+3+4 AFFECTED)

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-U-00018907.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when there is a position disagree between surfaces and lever position.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-U-00018523.0001001 / 21 MAR 16

SPD BRK LEVER.....RETRACT

**F/CTL SPD BRK FAULT**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-V-00016971.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when speedbrake lever transducers to SEC 1 and 3 failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-V-00018534.0001001 / 21 MAR 16

**L2** In addition, associated ground spoilers are available only through reverse selection.

**L1** Crew awareness.

Ident.: PRO-ABN-F\_CTL-V-00018535.0002001 / 22 MAR 17

**STATUS**

SPD BRK.....DO NOT USE

**INOP SYS**

STEER APPR (1)

(1) (if SPD BRK 3 or 4 are affected)


**F/CTL SPD BRK STILL OUT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-AO-00016972.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Flight Phase Inhibition:



Ident.: PRO-ABN-F\_CTL-AO-00011810.0014001 / 25 FEB 14

Crew awareness.

**F/CTL SPLR FAULT**

Applicable to: ALL

Ident.: PRO-ABN-F\_CTL-R-00016976.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is a loss of one or more spoilers.

Flight Phase Inhibition:



*Continued on the following page*

**F/CTL SPLR FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-R-00018536.0003001 / 22 MAR 17

**[L2] Note:** *If heavy vibrations are felt, CONF 3 may be used for landing in order to reduce the buffeting.*

**[L1] ● If one or more spoilers are fully extended:**

Current Flight Level (FL) may not be maintained due to increased drag. Maintain a cruise FL as high as possible.

**OPT SPD..... G DOT+10KT**

**[L2]** *Whenever possible, target green dot speed +10 kt to minimize fuel consumption. However, if buffet is encountered at GDOT speed +10 kt, increase speed to fly out of buffet condition.*

**[L1] AP..... DO NOT USE**

**[L2]** *Depending on the failed spoiler position, the AP may not have enough authority to counteract the roll induced by spoiler runaway.*

**[L1] SPD BRK (IF SPOILERS 3+4 AFFECTED)..... DO NOT USE**

**[L2]** *Do not use speedbrakes, since using only surfaces N° 2 is not efficient and would activate the SPD BRK DISAGREE caution.*

**[L1] ● If one or more spoilers are extended:**

**FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

*Continued on the following page*



**F/CTL SPLR FAULT (Cont'd)**

Ident.: PRO-ABN-F\_CTL-R-00018544.0004001 / 21 MAR 17

L12

**STATUS**

- **If one or more spoilers are fully extended:**  
AP..... DO NOT USE
- **If spoilers 3+4 affected:**  
SPD BRK..... DO NOT USE

**INOP SYS**

SPLR (affected)  
SPD BRK <sup>(1)</sup>  
STEEP APPR <img alt="steep approach symbol" data-bbox="835 315 855 335"/> <sup>(2)</sup>

**APPR PROC**

- **If one or more spoilers are fully extended:**  
In clean configuration, if VLS is above VFE<sub>NEXT</sub>, the flight crew should deselect A/THR, decelerate to VFE<sub>NEXT</sub>, and select CONF 1 when below VFE<sub>NEXT</sub>. When established at CONF 1, the flight crew can reengage the A/THR and use managed speed again.  
FOR LDG.....USE FLAP 3  
*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*  
GPWS LDG FLAP 3 ..... ON  
APPR SPD : VREF + 10 KT

LDG DIST PROC..... APPLY

**FUEL CONSUMPT INCRSD**

See <sup>(3)</sup>

**FMS PRED UNRELIABLE**

See <sup>(4)</sup>

<sup>(1)</sup> (If spoilers 2+3+4 affected)  
<sup>(2)</sup> (if spoilers 3 and/or 4 affected)  
<sup>(3)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.  
<sup>(4)</sup> Disregard FMS fuel predictions and refer to QRH/OPS chapter in order to find the applicable Fuel Penalty Factor.

**F/CTL STABILIZER JAM**

Applicable to: ALL


Ident.: PRO-ABN-F\_CTL-X-00016973.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when there is a loss of the electrical control of the stabilizer (with or without jamming of the stabilizer).

Flight Phase Inhibition:



*Continued on the following page*

**F/CTL STABILIZER JAM (Cont'd)**

Ident.: PRO-ABN-F\_CTL-X-00018545.0001001 / 22 MAR 17

**L2** When the Flight Control Computers detect a loss of electrical control of the stabilizer, pitch control law reverts to alternate law. Depending on the type of failure, the MAN PITCH TRIM may still be available.

**L1** **MAN PITCH TRIM**..... **CHECK**

**L2** *The force needed on the PITCH TRIM wheel may be higher than during pre-takeoff manual setting.*

**L1** ● **IF MAN TRIM AVAIL:**

**TRIM FOR NEUTRAL ELEV**

**L2** *If manual pitch trim is available, trim to maintain the elevator at the zero position (indications on F/CTL SD page).*

**L1**

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

**MAX SPEED**..... **320 KT**

*Continued on the following page*

**F/CTL STABILIZER JAM (Cont'd)**

Ident.: PRO-ABN-F\_CTL-X-00018546.0003001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT

**APPR PROC:**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3..... ON

*Will be displayed when flaps in CONF 3*

● **IF MAN TRIM NOT AVAIL:**

● **WHEN CONF 3 AND VAPP:**

L/G..... DN

*Landing gear extension is delayed, in order to delay the switching to direct law.*

APPR SPD:..... VREF + 10 KT

LDG DIST PROC..... APPLY

**ALTN LAW: PROT LOST**

**WHEN L/G DN: DIRECT LAW**

*At landing gear extension, control reverts to direct law in pitch, as well as in roll. Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW.*

**INOP SYS**

- F/CTL PROT
- STABILIZER
- ELAC PITCH
- AP 1 + 2
- CAT 2
- GLS AUTOLAND 
- STEEP APPR 

**[QRH] FUEL IMBALANCE**

Ident.: PRO-ABN-FUEL-00011257.0002001 / 17 MAR 17

Applicable to: ALL

FOB..... CHECK

*Compare the FOB + FU , with the FOB at departure.*

*If the difference is significant, or if the FOB + FU decreases, suspect a fuel leak.*

**CAUTION**

A fuel imbalance may indicate a fuel leak.  
 Do not apply this procedure, if a fuel leak is suspected.  
*Refer to PRO-ABN-FUEL [QRH] FUEL LEAK.*

FUEL X FEED..... ON

● **On lighter side and in center tank:**

FUEL PUMPS..... OFF

● **When fuel balanced:**

FUEL PUMPS..... ON

FUEL X FEED..... OFF

*Note: There is no requirement to correct an imbalance, until the ECAM fuel advisory is displayed.*

**[QRH] FUEL LEAK**

Ident.: PRO-ABN-FUEL-00018665.0003001 / 17 MAR 17

Applicable to: **ALL**

A fuel leak may be detected, if:

- The sum of FOB and FU significantly less than FOB at engine start or is decreasing, or
- A passenger observes fuel spray from engine/pylon or wingtip/sharklet, or
- The total fuel quantity is decreasing at an abnormal rate, or
- A fuel imbalance is developing, or
- Fuel quantity in a tank is decreasing too fast (leak from engine/pylon, or hole in a tank), or
- The Fuel flow is excessive (leak from engine), or
- Fuel is smelt in the cabin.
- The destination EFOB turns to amber on the F-PLN (or on the FUEL PRED) page, or
- "DEST EFOB BELOW MIN" appears on the MCDU scratchpad.

If visibility permits, leak source may be identified by a visual check from the cabin.

**WHEN A LEAK IS CONFIRMED**

**LAND ASAP**

■ **Leak from engine/pylon confirmed by excessive fuel flow or visual check:**

THR LEVER (affected engine).....IDLE  
 ENG MASTER (affected engine)..... OFF  
 FUEL X FEED..... AS RQRD

*If the leak stops, the crossfeed valve can now be opened to re-balance fuel quantity, or to enable use of fuel from both wings.*

DO NOT RESTART AFFECTED ENGINE

■ **Leak from engine/pylon not confirmed or leak not located:**

Stop any fuel transfer, and then monitor the depletion rate of each inner tank, to determine if the leak is from an engine or a wing, or from the Center tank, or the APU feeding line.

FUEL X FEED.....MAINTAIN CLOSED

*The crossfeed valve must remain closed to prevent the leak from affecting both sides.*

CTR TK PUMP 1..... OFF  
 CTR TK PUMP 2..... OFF

*Each engine is fed via its associated inner tank only.*

INNER TANK FUEL QUANTITIES..... MONITOR

*Monitor the depletion rate of each inner tank.*

*Continued on the following page*

**[QRH] FUEL LEAK (Cont'd)**

- **If one inner tank depletes faster than other by at least 300 kg (660 lb) in less than 30 min:**

An engine leak may still be suspected. Therefore:

THR LEVER (engine on leaking side)..... IDLE  
 ENG MASTER (engine on leaking side)..... OFF  
 CTR TK PUMP 1..... ON  
 CTR TK PUMP 2..... ON  
 FUEL LEAK..... MONITOR

- **If leak stops:**

ENGINE LEAK CONFIRMED  
 FUEL X FEED..... AS RQRD  
 DO NOT RESTART AFFECTED ENGINE

- **If leak continues (after engine shutdown):**

WING LEAK SUSPECTED  
 ENGINE RESTART..... CONSIDER

**CAUTION** Do not apply the FUEL IMBALANCE procedure. Approach and landing can be done, even with one full wing/one empty wing.

- **If both inner tanks deplete at a similar rate:**

LEAK FROM CENTER TANK OR APU FEEDING LINE SUSPECTED

- **If fuel smell in cabin:**

APU..... OFF  
*This prevents additional fuel loss through the APU feeding line.*

- **When fuel quantity in one inner tank less than 3 000 kg (6 600 lb):**

CTR TK PUMP 1..... ON  
 CTR TK PUMP 2..... ON

- **For landing: DO NOT USE REVERSERS**

**[QRH] GRAVITY FUEL FEEDING**

Ident.: PRO-ABN-FUEL-00011261.0001001 / 17 MAR 17

Applicable to: ALL

ENG MODE SEL.....IGN

AVOID NEGATIVE G FACTOR

MAX FL: GRAVITY FEED CEILING

- Current FL if flight time above FL 300 > 30 min.
- FL 300 if flight time above FL 300 < 30 min.
- Highest of FL 150 or 7 000 ft above takeoff airport if FL 300 never exceeded.
- FL 100 for JET B.

● **When reaching gravity feed ceiling:**

FUEL X FEED..... OFF

● **If no fuel leak and with one engine running (fed by gravity):**

FUEL X FEED..... ON

BANK ANGLE..... 1° WING DOWN ON LIVE ENG SIDE

*The fuel from the wing tank on the engine running side is used.*

RUDDER TRIM..... USE

*Use rudder trim to maintain constant course and neutral stick.*

● **When fuel imbalance reaches 1 000 kg (2 200 lb):**

BANK ANGLE..... 2° or 3° WING DOWN ON LIVE ENG SIDE

*Use fuel from the opposite wing tank, until fuel imbalance is reduced to 0.*



**FUEL ACT XFR FAULT** ⚠

Applicable to: ALL

Ident.: PRO-ABN-FUEL-R-00016820.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The ACT quantity > 250 kg (550 lb) and
- The CTR TK quantity < 3 000 kg (6 600 lb).

Flight Phase Inhibition:



*Continued on the following page*

**FUEL ACT XFR FAULT** ⚠ (Cont'd)

Ident.: PRO-ABN-FUEL-R-00017614.0001001 / 21 MAR 16

ACT.....FWD

● **IF NECESSARY:**

DESCEND TO FL270

[L2]

- Note:
- ACT transfer rate depends on altitude and on remaining ACT fuel quantity.
  - If ACT transfer is uncertain, set the ACT pb to AUTO to avoid pump dry running.
  - ACT pb can be set back to FWD at lower Flight Level to recover remaining ACT fuel.

[L1]

● **WHEN ACT EMPTY:**

ACT.....AUTO

● **For A321 aircraft equipped with 1 ACT** ⚠ :

ACT UNUSABLE (IF AUTOMATIC AND MANUAL MODES ARE FAILED)

● **For aircraft equipped with 2 ACTs** ⚠ :

● **IF NO XFR:**

ACT UNUSABLE

PROC.....APPLY

**FUEL ACT PUMP LO PR** 

Applicable to: ALL


Ident.: PRO-ABN-FUEL-BB-00016811.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the ACT pump is in low pressure.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BB-00018877.0001001 / 21 MAR 16

**ACT LO LVL**

**L2** Note: Displayed if ACT is empty.

**L1** ACT.....OFF

**FUEL APU LP VALVE FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-BC-00016826.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the valve position disagrees with the selected position.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BC-00017633.0002001 / 21 MAR 16

Crew awareness.

**FUEL AUTO FEED FAULT**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-Q-00016698.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- CTR TK quantity > 250 kg (550 lb) and left or right wing tanks quantity < 5 000 kg (11 000 lb), or
- CTR TK pumps do not stop after slat extension or CTR TK level is low.

Flight Phase Inhibition:



*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

FUEL

**FUEL AUTO FEED FAULT (Cont'd)**

Ident.: PRO-ABN-FUEL-Q-00017666.0001001 / 21 MAR 16

FUEL MODE SEL.....MAN

<sup>[L2]</sup> The center tank pumps will run and feed the engines.

- <sup>[L1]</sup> ■ Fuel in one wing tank < 5 000 kg (11 000 lb ) and in center tank > 250 kg (550 lb ):
  - CTR TK PUMP 1.....ON
  - CTR TK PUMP 2.....ON

<sup>[L2]</sup> When the center tank is empty, CTR TK PUMP LO PR alert will come on.  
*For aircraft equipped with CFM engines only : If the center tank is not empty at slat extension, CTR TK PUMPS should be switched OFF. This action will prevent a possible wing tank overflow on ground, due to IDG fuel recirculation.*

- <sup>[L1]</sup> ■ CTR TK PUMPS running after slat extension, or LO LVL in center tank:
  - CTR TK PUMP 1.....OFF
  - CTR TK PUMP 2.....OFF

Ident.: PRO-ABN-FUEL-Q-00018882.0001001 / 21 MAR 16


**STATUS**

CTR TK FEED : MAN ONLY

**FUEL CTR TK PUMP 1(2) LO PR**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-M-00016843.0001001 / 21 MAR 16



Ident.: PRO-ABN-FUEL-M-00018914.0003001 / 21 MAR 16

● **IF NO FUEL LEAK:**

FUEL X FEED..... ON

CTR TK PUMP (AFFECTED)..... OFF

**L2** A fuel imbalance may occur, if the performance of the pumps of one wing is different from that of the other wing, and the CTR TK PUMP that is not affected stops automatically because:

- The L(R) INR TK is full, or
- The CTR TK is empty.

In this case, apply the FUEL IMBALANCE procedure, as required.

**L1** ● **WHEN CTR TK EMPTY:**

FUEL X FEED..... OFF

**L2** When the CTR TK is empty, the X FEED pb-sw must be turned off, to avoid a possible fuel imbalance.

Continued on the following page

**FUEL CTR TK PUMP 1(2) LO PR (Cont'd)**

Ident.: PRO-ABN-FUEL-M-00018918.0002001 / 21 MAR 16

**STATUS**

● **WHEN CTR TK EMPTY:**

FUEL X FEED.....OFF

**INOP SYS**

CTR TK PUMP 1(2)

**FUEL CTR TK PUMPS LO PR**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-N-00016845.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the pressure of the CTR TK pumps is low.

Flight Phase Inhibition:



*Continued on the following page*





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

FUEL

**FUEL CTR TK PUMPS LO PR (Cont'd)**

Ident.: PRO-ABN-FUEL-N-00011221.0003001 / 30 MAR 12

**L2** Set FUEL MODE SEL pb-sw to MAN, to avoid the possible triggering of the **FUEL CTR TK PUMPS OFF** ECAM caution.

**L1** CTR TK PUMP 1..... OFF  
 CTR TK PUMP 2..... OFF  
 FUEL X FEED..... OFF  
 CTR TK UNUSABLE

**L2** Gravity feeding from the center tank is not possible (no by-pass valve fitted on the center tank pumps).

Ident.: PRO-ABN-FUEL-N-00011222.0001001 / 13 AUG 10

**STATUS**

CTR TK FUEL UNUSABLE

**INOP SYS**

CTR TK PUMPS

**FUEL CTR TK PUMPS OFF**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-BE-00016846.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when both CTR TK PUMP 1 pb-sw and CTR TK PUMP 2 pb-sw are at OFF with no failure.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BE-00011260.0002001 / 10 JAN 11

- L2 The center tank pumps pushbuttons are OFF, with slats retracted.

- L1 CTR TK PUMP 1..... ON
- CTR TK PUMP 2..... ON

**FUEL ENG 1(2) LP VALVE OPEN**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-BG-00016814.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the valve remains in the open position.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BG-00011217.0001001 / 25 FEB 14

Crew awareness.

**FUEL FQI CH 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-BI-00016817.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when a FQI channel is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BI-00011216.0001001 / 25 FEB 14

Crew awareness.

**FUEL FUEL INERTING SYS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-U-00016823.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the fuel inerting system is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-U-00014390.0002001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-FUEL-U-00014391.0002001 / 30 MAR 12

**STATUS**

**INOP SYS**

FUEL INERT

**FUEL L (R) OUTER (INNER) TK HI TEMP**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-BL-00016825.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the fuel temperature:

- In outer cell, is above 55 °C on ground
- In outer cell, is above 60 °C in flight
- In inner cell, is above 45 °C on ground
- In inner cell, is above 54 °C in flight.

Flight Phase Inhibition:



*Continued on the following page*

**FUEL L (R) OUTER (INNER) TK HI TEMP (Cont'd)**

Ident.: PRO-ABN-FUEL-BL-00011214.0001001 / 13 AUG 10

**L2** This caution may spuriously trigger due to interference from communication equipment. Therefore, the flight crew should wait 2 min while the fuel temperature measurement is updated. After 2 min, if the ECAM caution has not disappeared, the flight crew must apply the following procedure:

**L1** GALLEY.....OFF

**L2** Reducing electrical loads reduce heat emitted by IDG.

**L1** ■ On the ground:

LIMITED TAXI TIME

● If temp reaches 60° C in outer cell or 54° C in inner cell:

DELAY T.O.

ENG MASTER (AFFECTED SIDE).....OFF

■ In flight:

ENG F. FLOW (AFFECTED SIDE).....INCREASE

**L2** Disconnect autothrust. Adjust the thrust lever to increase fuel flow through the IDG oil heat exchanger and decrease the temperature of the fuel returning to the outer cell.

**L1** ● IF TEMP ABV 65 DEG C in outer cell or 57 DEG C in inner cell:

APU.....AS RQRD

**L2** APU if available may be started and APU GEN used to allow IDG disconnection.

**L1** ● If opposite GEN avail:

IDG (AFFECTED SIDE).....OFF

**FUEL L (R) OUTER (INNER) TK LO TEMP**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-BM-00016827.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the fuel temperature is approximately below -43 °C.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BM-00011208.0001001 / 25 FEB 14

■ **On the ground before takeoff:**

**DELAY T.O**

**L2** *Do not takeoff until temperatures are within limits.*

**L1** ■ **In flight:**

Crew awareness.

**L2** Consider descending to a lower altitude and/or increasing Mach to increase TAT.



**FUEL L (R) OUTER XFR CLOSED**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-V-00016829.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when both transfer valves remain closed after inner tank reaches the low level.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-V-00014879.0006001 / 07 MAR 13

*Note:* When fuel quantity in affected wing reaches low level, corresponding FUEL WING TK LO LVL warning is triggered.

**L (R) OUTER TK UNUSABLE**

Ident.: PRO-ABN-FUEL-V-00014881.0006001 / 07 MAR 13

**STATUS**

**L (R) OUTER TK UNUSABLE**

**FUEL L (R) OUTER XFR OPEN**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-W-00016831.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when either transfer valve opens before inner tank reaches low level.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-W-00014882.0006001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-FUEL-W-00014883.0006001 / 07 MAR 13

**STATUS**

**INOP SYS**

L (R) CELL VALVE

**FUEL L (R) TK PUMP 1(2) LO PR**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-D-00016832.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the pressure of one tank pump is low.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-D-00011177.0002001 / 13 AUG 10

**TK PUMP (AFFECTED).....OFF**

**L2 Note:** Aircraft altitude must be limited to 35 000 ft if a single fuel pump feeds both engines with hot JET B (JP4) fuel (fuel temperature above 30 °C).

Ident.: PRO-ABN-FUEL-D-00011178.0001001 / 13 AUG 10

**STATUS**

**INOP SYS**

TK PUMP (affected)

**FUEL L (R) TK PUMP 1 + 2 LO PR**  
(CENTER TANK EMPTY)

Applicable to: ALL


Ident.: PRO-ABN-FUEL-C-00018184.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the pressure of the tank pumps is low.

Flight Phase Inhibition:



*Continued on the following page*

**FUEL L (R) TK PUMP 1 + 2 LO PR (Cont'd)**  
**(CENTER TANK EMPTY)**

Ident.: PRO-ABN-FUEL-C-00017648.0004001 / 21 MAR 16

- **IF NO FUEL LEAK:**  
 FUEL X FEED (IF ABOVE FL150)..... ON  
 ENG MODE SEL.....IGN

**L2** The selection of continuous relight protects against flame-out, caused by possible fuel supply surging.

- L1** TK PUMP 1 (AFFECTED).....OFF  
 TK PUMP 2 (AFFECTED).....OFF

- **WHEN TK (affected) FUEL RQRD:**  
 TK (AFFECTED) FEED.....GRVTY ONLY

**L2** Apply GRVTY FUEL FEED procedure, (Refer to PRO-ABN-FUEL [QRH] GRAVITY FUEL FEEDING).

Fuel from the affected tank may be used immediately if there is no ceiling limitation for gravity fuel feeding.

- L1** FUEL X FEED (IF BELOW FL150).....OFF

- **If FUEL X FEED off:**

**L2** As long as fuel X feed is closed, associated engine is fed by gravity only.

- L1** PROC: GRVTY FUEL FEEDING

**L2** Apply GRVTY FUEL FEED procedure, (Refer to PRO-ABN-FUEL [QRH] GRAVITY FUEL FEEDING).

- L1** AVOID NEGATIVE G FACTOR

**L2** Avoiding negative g will prevent fuel surging and therefore reduce the risk of engine malfunction.

Ident.: PRO-ABN-FUEL-C-00011175.0001001 / 13 AUG 10

**STATUS**

- **If FUEL X FEED off:**  
 PROC:GRVTY FUEL FEEDING  
 AVOID NEGATIVE G FACTOR  
 TK (AFFECTED) GRVTY FEED ONLY

**INOP SYS**

TK PUMPS (affected)

**FUEL L (R) TK PUMP 1 + 2 LO PR**  
**(CENTER TANK NOT EMPTY)**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-B-00018196.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the pressure of the tank pumps is low.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-B-00011170.0003001 / 26 JUL 12

**FUEL MODE SEL (IF CTR TK NOT FEEDING).....MAN**

**L2** Setting FUEL MODE SEL pb-sw to MAN will allow center tank pumps to run.  
If the center tank is not empty at slat extension, CTR TK PUMPs should be switched OFF. This action will prevent a possible wing tank overflow on ground, due to IDG fuel recirculation.

**L1** TK PUMP 1 (AFFECTED).....OFF  
TK PUMP 2 (AFFECTED).....OFF

● **WHEN TK (affected) FUEL RQRD:**

**L2** Apply the GRVTY FUEL FEEDING procedure, (*Refer to PRO-ABN-FUEL [QRH] GRAVITY FUEL FEEDING*).

**L1** TK (AFFECTED) FEED.....GRVTY ONLY  
PROC: GRVTY FUEL FEEDING

*Continued on the following page*

**FUEL L (R) TK PUMP 1 + 2 LO PR (Cont'd)**  
 (CENTER TANK NOT EMPTY)

Ident.: PRO-ABN-FUEL-B-00011171.0001001 / 13 AUG 10

STATUS	
<p>PROC:GRVY FUEL FEEDING</p> <p>TK (AFFECTED) GRVY FEED ONLY</p> <p>CTR TK FEED: MAN ONLY</p>	<p style="text-align: center;"><b>INOP SYS</b></p> <p style="text-align: center;">TK PUMPS (affected)</p>

**FUEL L (R) WING TK LO LVL**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-E-00016837.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when left or right wing tanks quantity is below 750 kg (1 650 lb). This alert is triggered by sensors getting dry and is independent from the fuel quantity indications.

Flight Phase Inhibition:

*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

FUEL

**FUEL L (R) WING TK LO LVL (Cont'd)**

Ident.: PRO-ABN-FUEL-E-00018927.0002001 / 21 MAR 16

- **If center tank not empty:**

FUEL MODE SEL..... MAN

- **IF NO FUEL LEAK AND FUEL IMBALANCE:**

FUEL X FEED..... ON

TK PUMP 1 (ON SIDE WITH LO LVL)..... OFF

TK PUMP 2 (ON SIDE WITH LO LVL)..... OFF

**L2** *Note:* TK PUMP 1+2 (on side with LO LVL) LO PR warning will be triggered.

Ident.: PRO-ABN-FUEL-E-00018928.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

- **If center tank not empty:**

CTR TK FEED: MAN ONLY

TK PUMPS



**FUEL L + R WING TK LO LVL**

Applicable to: ALL

Ident.: PRO-ABN-FUEL-BO-00016810.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the low level is detected in both wing inner tanks. The alert is triggered by sensors getting dry and is independent from the fuel quantity indications.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-BO-00018673.0003001 / 21 MAR 16

**LAND ASAP**

FUEL MODE SEL (IF CENTER TANK NOT EMPTY).....MAN  
ALL TK PUMPS.....ON

L2 All pumps in center tank and in wing tanks will run.

L1

■ **IF NO FUEL LEAK:**

FUEL X FEED.....ON

■ **IF GRVTY FEED:**

FUEL X FEED.....OFF

**FUEL X FEED VALVE FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FUEL-J-00016842.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the valve position disagrees with the selected position.

Flight Phase Inhibition:



Ident.: PRO-ABN-FUEL-J-00011206.0001001 / 25 FEB 14

**L2** If valve failed open, maintain fuel balance with selective use of pumps.  
 If valve failed closed and if unable to maintain an acceptable balance, land as soon as possible.

**L1** Crew awareness.

Ident.: PRO-ABN-FUEL-J-00011207.0001001 / 13 AUG 10

**STATUS**

**INOP SYS**

FUEL X FEED

**FWS FWC 1 + 2 FAULT**

Applicable to: ALL

Ident.: PRO-ABN-FWS-H-00017311.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when both FWC 1 and FWC 2 are failed, or when the communication between the FWC and the EIS is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-FWS-H-00010055.0001001 / 14 FEB 13

MONITOR SYS  
MONITOR OVERHEAD PANEL

**NOT AVAIL**

ECAM WARN  
ALTI ALERT  
STATUS  
A/CALL OUT  
MEMO

*Continued on the following page*

**FWS FWC 1 + 2 FAULT (Cont'd)**

Ident.: PRO-ABN-FWS-H-00010056.0001001 / 14 FEB 13

L2

**Other INOP SYS**

CAT2

*ECAM Cautions and Warnings, aural warnings, master caution and warning lights are lost. ECAM system pages are still available. therefore check regularly (more often than usual) cockpit panels for local warnings and ECAM system pages for system checks. Check the general status of the systems for the DES /APPR preparation.*

**FWS FWC 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FWS-G-00017310.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when either FWC 1 or, FWC 2 is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-FWS-G-00010059.0001001 / 10 AUG 10

Crew awareness.

*Continued on the following page*

**FWS FWC 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-FWS-G-00010060.0001001 / 10 AUG 10

<b>STATUS</b>	
<b>CAT 3 SINGLE ONLY</b>	<b><u>INOP SYS</u></b>
	CAT 3 DUAL FWC 1(2)

**FWS OEB/FWC DISCREPANCY**

Applicable to: ALL

Ident.: PRO-ABN-FWS-J-00017314.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when FWC 1 and FWC 2 do not have the same OEB s listed in their OEB reminder database.

Flight Phase Inhibition:

Ident.: PRO-ABN-FWS-J-00010050.0001001 / 10 AUG 10

**OEB DATABASE.....XCHECK**

**L2** This action is normally performed by maintenance.

**FWS SDAC 1 + 2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FWS-E-00017306.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both SDAC 1 and SDAC 2 are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-FWS-E-00010053.0001001 / 10 AUG 10

**MONITOR OVERHEAD PANEL**

**L2** Amber cautions are lost. Aircraft status on the ECAM STATUS page is lost.  
 Only red warnings, engine and fuel parameters, and slat/flap positions are available on the upper ECAM DU.

**L1** **ECAM ENG FUEL F/CTL WHEEL (L/G POS IND) SYS PAGES AVAIL.**

Ident.: PRO-ABN-FWS-E-00010054.0002001 / 10 AUG 10

**STATUS**

**INOP SYS**

SDAC 1 + 2

**FWS SDAC 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-FWS-D-00017308.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alerts triggers when either SDAC 1 or, SDAC 2 is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-FWS-D-00010051.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-FWS-D-00010052.0001001 / 10 AUG 10

L12

**STATUS**

**INOP SYS**

SDAC 1(2)

Note: Although the ECAM may display some symbols and/or parameters in amber, this does not always signify that additional systems are failed.

Intentionally left blank



**HYD B ELEC PUMP LO PR OR OVHT**

Applicable to: ALL

Ident.: PRO-ABN-HYD-T-00017137.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

LO PR: This alert triggers when the pump outlet pressure  $\leq 1\ 450$  PSI (the alert resets if pressure  $\geq 1\ 750$  PSI).

OVHT: This alert triggers when the blue electric pump overheats.

Flight Phase Inhibition:



*Note:* (a) The Flight Phase Inhibition 3 is only available for HYD B ELEC PUMP OVHT.

Ident.: PRO-ABN-HYD-T-00011661.0002001 / 27 NOV 12

BLUE ELEC PUMP.....OFF  
 FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**ASSOCIATED PROCEDURES**

**B SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD B ELEC PUMP LO PR OR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-T-00018313.0003001 / 21 MAR 17

L12

**STATUS**

**APPR PROC**

**HYD LO PR**

● **IF BLUE OVHT OUT:**

BLUE ELEC PUMP..... AUTO

LDG DIST PROC..... APPLY

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**SLATS SLOW**

**CAT 3 SINGLE ONLY**

**INOP SYS**

BLUE HYD

SPLR 3

CAT 3 DUAL

B ELEC PUMP

STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD B RSVR LO AIR PR**

Applicable to: ALL

Ident.: PRO-ABN-HYD-A-00017106.0002001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when the reservoir air pressure  $\leq$  22 PSI (the alert resets if pressure  $\geq$  25 PSI).

This alert triggers when the reservoir air pressure  $\leq$  30 PSI (detected in flight but only displayed on ground after landing).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-A-00011602.0002001 / 05 MAR 13

● **IF PRESS FLUCTUATES:**

BLUE ELEC PUMP.....OFF

**ASSOCIATED PROCEDURES**

**B SYS LO PR**

FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD B RSVR LO AIR PR (Cont'd)**

Ident.: PRO-ABN-HYD-A-00018312.0003001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

The probability of cavitation increases with altitude. Therefore, it may be possible to restore the system after descending to a lower altitude.

**HYD LO PR**  
**BLUE ELEC PUMP.....AUTO**

● **If sys not recovered:**  
**LDG DIST PROC.....APPLY**

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**SLATS SLOW**

**CAT 3 SINGLE ONLY**

**BLUE HYD**  
**SPLR 3**  
**CAT 3 DUAL**  
**B ELEC PUMP**  
**STEEP APPR **

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD B RSVR LO LVL**

Applicable to: ALL

Ident.: PRO-ABN-HYD-C-00017144.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

The alert triggers when the fluid quantity < 2.4 l (0.63 US Gal).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-C-00011606.0002001 / 05 MAR 13

BLUE ELEC PUMP ..... OFF

**ASSOCIATED PROCEDURES**

**B SYS LO PR**

FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD B RSVR LO LVL (Cont'd)**

Ident.: PRO-ABN-HYD-C-00018314.0003001 / 21 MAR 17

L12

**STATUS**

LDG DIST PROC..... APPLY

FUEL CONSUMPT INCRSD

See <sup>(1)</sup>

FMS PRED UNRELIABLE

See <sup>(2)</sup>

SLATS SLOW

CAT 3 SINGLE ONLY

**INOP SYS**

BLUE HYD

SPLR 3

CAT 3 DUAL

EMER GEN

B ELEC PUMP

STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD B RSVR OVHT**

Applicable to: ALL

Ident.: PRO-ABN-HYD-B-00017108.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the fluid temperature  $\geq 93$  °C (the alert resets if temperature  $\leq 88$  °C).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-B-00011604.0002001 / 05 MAR 13

BLUE ELEC PUMP ..... OFF

**ASSOCIATED PROCEDURES**

**B SYS LO PR**

FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD B RSVR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-B-00018315.0003001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

**HYD LO PR**

- **IF BLUE OVHT OUT:**  
BLUE ELEC PUMP..... AUTO
- **If sys not recovered:**  
LDG DIST PROC.....APPLY

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**SLATS SLOW**

**CAT 3 SINGLE ONLY**

- BLUE HYD
- SPLR 3
- CAT 3 DUAL
- B ELEC PUMP
- STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.



**HYD G ENG 1 PUMP LO PR**  
 (PTU OPERATIVE)

Applicable to: ALL

Ident.: PRO-ABN-HYD-N-00017136.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the pump outlet pressure  $\leq 1$  750 PSI (the alert resets if pressure  $\geq 2$  200 PSI).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-N-00011648.0001001 / 18 AUG 10

GREEN ENG 1 PUMP ..... OFF

Ident.: PRO-ABN-HYD-N-00011649.0001001 / 17 MAR 11

**STATUS**

**INOP SYS**

G ENG 1 PUMP

**HYD G ENG 1 PUMP LO PR**  
 (PTU INOPERATIVE)

Applicable to: ALL


Ident.: PRO-ABN-HYD-P-00018805.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the pump outlet pressure  $\leq 1$  750 PSI (the alert resets if pressure  $\geq 2$  200 PSI).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-P-00011652.0001001 / 18 AUG 10

GREEN ENG 1 PUMP ..... OFF

**ASSOCIATED PROCEDURES**

**G SYS LO PR**

**SECONDARY FAILURES**

- \*WHEEL
- \*F/CTL

*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

HYD

**HYD G ENG 1 PUMP LO PR (Cont'd)**  
**(PTU INOPERATIVE)**

Ident.: PRO-ABN-HYD-P-00018316.0002001 / 21 MAR 16

**STATUS**

L/G..... GRVTY EXTN  
 LDG DIST PROC..... APPLY

SLATS/FLAPS SLOW  
 CAT 3 SINGLE

**INOP SYS**

GREEN HYD  
 SPLR 1+5  
 CAT 3 DUAL  
 AUTO BRK  
 NORM BRK  
 L/G RETRACT  
 REVERSER 1  
 PTU  
 G ENG 1 PUMP  
 YAW DAMPER 1

**HYD G RSVR LO AIR PR**

Applicable to: ALL


Ident.: PRO-ABN-HYD-D-00017104.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the reservoir air pressure  $\leq 22$  PSI (the alert resets if air pressure  $\geq 25$  PSI).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-D-00011609.0002001 / 05 MAR 13

● **IF PRESS FLUCTUATES:**

- PTU..... OFF
- GREEN ENG 1 PUMP..... OFF

**G ENG 1 PUMP LO PR**

**ASSOCIATED PROCEDURES**

**G SYS LO PR**

- FUEL CONSUMPT INCRSD
- FMS PRED UNRELIABLE

**SECONDARY FAILURES**

- \*WHEEL
- \*F/CTL

*Continued on the following page*

**HYD G RSVR LO AIR PR (Cont'd)**

Ident.: PRO-ABN-HYD-D-00018317.0007001 / 21 MAR 17

L12

**STATUS**

**APPR PROC**

**HYD LO PR**

The probability of cavitation increases with altitude. Therefore, it may be possible to restore the system after descending to a lower altitude.

**GREEN ENG 1 PUMP..... ON**

● **IF HYD NOT RECOVERED:**

**L/G.....GRVTY EXTN**

*Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION*

**LDG DIST PROC.....APPLY**

**FUEL CONSUMPT INCRSD**

*See <sup>(1)</sup>*

**FMS PRED UNRELIABLE**

*See <sup>(2)</sup>*

**ALTN Y BRK WITH A/SKID**

**SLATS/FLAPS SLOW**

**CAT 3 SINGLE ONLY**

**INOP SYS**

GREEN HYD  
 SPLR 1 + 5  
 CAT 3 DUAL  
 AUTO BRK  
 NORM BRK  
 L/G RETRACT  
 REVERSER 1  
 YAW DAMPER 1

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD G RSVR LO LVL**

Applicable to: ALL


Ident.: PRO-ABN-HYD-F-00017142.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the fluid quantity < 3.5 l (0.92 US Gal).

Flight Phase Inhibition:



**L1** Note: The HYD G RSVR LO LVL alert is inhibited for the first 15 s of flight phase 5.

Ident.: PRO-ABN-HYD-F-00011614.0002001 / 05 MAR 13

PTU.....OFF  
 GREEN ENG 1 PUMP.....OFF  
 G ENG 1 PUMP LO PR

**ASSOCIATED PROCEDURES**

**G SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*WHEEL  
 \*F/CTL

*Continued on the following page*

**HYD G RSVR LO LVL (Cont'd)**

Ident.: PRO-ABN-HYD-F-00018320.0007001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

L/G..... GRVTY EXTN

*Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION*

LDG DIST PROC..... APPLY

FUEL CONSUMPT INCRSD

*See <sup>(1)</sup>*

FMS PRED UNRELIABLE

*See <sup>(2)</sup>*

ALTN Y BRK WITH A/SKID

SLATS/FLAPS SLOW

CAT 3 SINGLE ONLY

GREEN HYD  
 SPLR 1 + 5  
 CAT 3 DUAL  
 AUTO BRK  
 NORM BRK  
 L/G RETRACT  
 REVERSER 1  
 YAW DAMPER 1

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD G RSVR OVHT**

Applicable to: ALL


Ident.: PRO-ABN-HYD-E-00017107.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the fluid temperature  $\geq 93$  °C (the alert resets if temperature  $\leq 88$  °C).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-E-00011612.0002001 / 05 MAR 13

PTU..... OFF  
 GREEN ENG 1 PUMP..... OFF  
 G ENG 1 PUMP LO PR

**ASSOCIATED PROCEDURES**

**G SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*WHEEL  
 \*F/CTL

*Continued on the following page*



**HYD G RSVR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-E-00018321.0007001 / 02 MAY 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

**HYD LO PR**

- **IF GREEN OVHT OUT:**  
GREEN ENG 1 PUMP.....ON
- **IF HYD NOT RECOVERED:**  
L/G.....GRVTY EXTN  
*Refer to PRO-ABN-LG [QRH] L/G GRAVITY  
EXTENSION*  
LDG DIST PROC.....APPLY

**FUEL CONSUMPT INCRSD**

*See <sup>(1)</sup>*

**FMS PRED UNRELIABLE**

*See <sup>(2)</sup>*

- ALTN Y BRK WITH A/SKID**
- SLATS/FLAPS SLOW**
- CAT 3 SINGLE ONLY**

- GREEN HYD
- SPLR 1 + 5
- CAT 3 DUAL
- AUTO BRK
- NORM BRK
- L/G RETRACT
- REVERSER 1
- YAW DAMPER 1

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD Y ELEC PUMP LO PR OR OVHT**

Applicable to: ALL

Ident.: PRO-ABN-HYD-M-00017133.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

**L2** LO PR: This alert triggers when the yellow system pressure  $\leq 1$  450 PSI (the alert resets if pressure  $\geq 1$  750 PSI) with:

- Y ELEC PUMP pb at ON
- Y ENG PUMP and PTU not available.

OVHT: This alert triggers when the yellow electric pump overheats.

Flight Phase Inhibition:



Note: (a) The Flight Phase Inhibition 3 is only available for HYD Y ELEC PUMP OVHT.

*Continued on the following page*

**HYD Y ELEC PUMP LO PR OR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-M-00019032.0003001 / 21 MAR 16

YELLOW ELEC PUMP..... OFF

**ASSOCIATED PROCEDURES**

**Y SYS LO PR**

**BRK Y ACCU PR MONITOR**

**L2** This check is recommended to cover the case of a pipe rupture, which could lead to the simultaneous loss of the hydraulic system and the accumulator fluid. If this occurs, the loss of the accumulator should be observed on the indicator within 10 min. In that case: The only remaining braking means is the normal braking using green pressure, the parking brake should not be used since it is not available and the chocks should be in place before engine 1 shutdown.

**L1 FUEL CONSUMPT INCRSD**

**FMS PRED UNRELIABLE**

**SECONDARY FAILURES**

\*F/CTL

Continued on the following page

**HYD Y ELEC PUMP LO PR OR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-M-00018322.0004001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

**APPR PROC**

**HYD LO PR**

● **IF YELLOW OVHT OUT:**

**YELLOW ENG 2 PUMP.....ON**  
**PTU.....AUTO**

*The above two lines are only displayed, in case of an electrical pump overheat.*

**LDG DIST PROC..... APPLY**

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**FLAPS SLOW**

**CAT 3 SINGLE ONLY**

**YELLOW HYD**  
**SPLR 2+4**  
**CAT 3 DUAL**  
**N/W STRG**  
**REVERSER 2**  
**Y ELEC PUMP**  
**YAW DAMPER 2**  
**STEEP APPR **

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD Y ENG 2 PUMP LO PR**  
 (PTU OPERATIVE)

Applicable to: ALL

Ident.: PRO-ABN-HYD-O-00017135.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the pump outlet pressure  $\leq 1$  750 PSI (the alert resets if pressure  $\geq 2$  200 PSI).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-O-00011650.0001001 / 18 AUG 10

YELLOW ENG 2 PUMP ..... OFF

Ident.: PRO-ABN-HYD-O-00011651.0001001 / 18 AUG 10

**STATUS**

**INOP SYS**

Y ENG 2 PUMP

**HYD Y ENG 2 PUMP LO PR**  
(PTU INOPERATIVE)

Applicable to: ALL


Ident.: PRO-ABN-HYD-Q-00018806.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the pump outlet pressure  $\leq 1$  750 PSI (the alert resets if pressure  $\geq 2$  200 PSI).

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-Q-00011654.0001001 / 18 AUG 10

**YELLOW ENG 2 PUMP** ..... **OFF**

**ASSOCIATED PROCEDURES**

**Y SYS LO PR**

- L2 Note: If yellow system is affected, the yellow electrical pump may be used.

L1

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD Y ENG 2 PUMP LO PR (Cont'd)**  
**(PTU INOPERATIVE)**

Ident.: PRO-ABN-HYD-Q-00018323.0002001 / 21 MAR 16

L12

**STATUS**

LDG DIST PROC..... APPLY

FLAPS SLOW  
 CAT 3 SINGLE

See <sup>(1)</sup>

**INOP SYS**

YELLOW HYD  
 SPLR 2+4  
 CAT 3 DUAL  
 N/W STRG  
 REVERSER 2  
 PTU  
 Y ENG 2 PUMP  
 YAW DAMPER 2  
 STEEP APPR <img alt="steep approach symbol" data-bbox="838 428 858 442"/>

<sup>(1)</sup> Note: Following a yellow hydraulic system failure, the parking brake may be inoperative due to a yellow accumulator low pressure.

**HYD Y RSVR LO AIR PR**

Applicable to: ALL


Ident.: PRO-ABN-HYD-G-00017105.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the reservoir air pressure  $\leq 22$  PSI (the alert resets if pressure  $\geq 25$  PSI).

Flight Phase Inhibition:



*Continued on the following page*



**HYD Y RSVR LO AIR PR (Cont'd)**

Ident.: PRO-ABN-HYD-G-00011626.0003001 / 27 NOV 12

● **IF PRESS FLUCTUATES:**

PTU..... OFF  
 YELLOW ENG 2 PUMP..... OFF  
 YELLOW ELEC PUMP..... OFF

**BRK Y ACCU PR MONITOR**

**L2** This check is recommended to cover the case of a pipe rupture, which could lead to the simultaneous loss of the hydraulic system and the accumulator fluid. If this occurs, the loss of the accumulator should be observed on the indicator within 10 min. In that case : The only remaining braking means is normal braking, using green pressure. The parking brake should not be used since, it is not available. And, the chocks should be in place before Engine 1 shutdown.

**L1** **Y ENG 2 PUMP LO PR**

**ASSOCIATED PROCEDURES**

**Y SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD Y RSVR LO AIR PR (Cont'd)**

Ident.: PRO-ABN-HYD-G-00018324.0007001 / 21 MAR 17

**L12** The probability of cavitation increases with altitude.  
Therefore, it may be possible to restore the system after descending to a lower altitude.

**L12** **STATUS**

**APPR PROC**

HYD LO PR  
YELLOW ENG 2 PUMP..... ON

● **If sys not recovered:**  
LDG DIST PROC.....APPLY

FUEL CONSUMPT INCRSD

See <sup>(1)</sup>

FMS PRED UNRELIABLE

See <sup>(2)</sup>

FLAPS SLOW

CAT 3 SINGLE

**INOP SYS**

YELLOW HYD  
SPLR 2 + 4  
CAT 3 DUAL  
N/W STRG  
REVERSER 2  
YAW DAMPER 2  
STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

**HYD Y RSVR LO LVL**

Applicable to: ALL

Ident.: PRO-ABN-HYD-I-00017143.0002001 / 06 SEP 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the fluid quantity < 3.5 l (0.92 US Gal).

Flight Phase Inhibition:



L1 **Note:** (a) The HYD Y RSVR LO LVL alert is inhibited for the first 15 s of flight phase 5.

Continued on the following page

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

HYD

**HYD Y RSVR LO LVL (Cont'd)**

Ident.: PRO-ABN-HYD-I-00011631.0003001 / 05 MAR 13

- PTU..... OFF
- YELLOW ENG 2 PUMP..... OFF
- YELLOW ELEC PUMP..... OFF
- BRK Y ACCU PR MONITOR

**[L2]** This check is recommended to cover the case of a pipe rupture, which could lead to the simultaneous loss of the hydraulic system and the accumulator fluid. If this occurs, the loss of the accumulator should be observed on the indicator within 10 min. In that case: The only remaining braking means is normal braking, using green pressure. The parking brake should not be used since, it is not available. And, the chocks should be in place before Engine 1 shutdown.

**[L1]** Y ENG 2 PUMP LO PR

**ASSOCIATED PROCEDURES**

**Y SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD Y RSVR LO LVL (Cont'd)**

Ident.: PRO-ABN-HYD-I-00018326.0006001 / 21 MAR 17

L12

**STATUS**

**INOP SYS**

LDG DIST PROC..... APPLY

FUEL CONSUMPT INCRSD

See <sup>(1)</sup>

FMS PRED UNRELIABLE

See <sup>(2)</sup>

FLAPS SLOW

CAT 3 SINGLE

See <sup>(3)</sup>

YELLOW HYD  
SPLR 2 + 4  
CAT 3 DUAL  
N/W STRG  
REVERSER 2  
CARGO DOOR  
YAW DAMPER 2  
STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.

<sup>(3)</sup> Note: Following a yellow hydraulic system failure, the parking brake may be inoperative due to a yellow accumulator low pressure.

**HYD Y RSVR OVHT**

Applicable to: ALL


Ident.: PRO-ABN-HYD-H-00017109.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the fluid temperature  $\geq 93^\circ\text{C}$  (the alert resets if temperature  $\leq 88^\circ\text{C}$ ).

Flight Phase Inhibition:



*Continued on the following page*

**HYD Y RSVR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-H-00011629.0003001 / 05 MAR 13

- PTU.....OFF
- YELLOW ENG 2 PUMP.....OFF
- YELLOW ELEC PUMP.....OFF
- BRK Y ACCU PR MONITOR

**L2** This check is recommended to cover the case of a pipe rupture, which could lead to the simultaneous loss of the hydraulic system and the accumulator fluid. If this occurs, the loss of the accumulator should be observed on the indicator within 10 min. In that case: The only remaining braking means is normal braking, using green pressure. The parking brake should not be used since, it is not available. And, the chocks should be in place before Engine 1 shutdown.

**L1** Y ENG 2 PUMP LO PR

**ASSOCIATED PROCEDURES**

**Y SYS LO PR**

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**SECONDARY FAILURES**

\*F/CTL

Continued on the following page

**HYD Y RSVR OVHT (Cont'd)**

Ident.: PRO-ABN-HYD-H-00018327.0007001 / 21 MAR 17

L12

**STATUS**

**APPR PROC**

**HYD LO PR**

● **IF YELLOW OVHT OUT:**

YELLOW ENG 2 PUMP.....ON

● **If not recovered:**

LDG DIST PROC.....APPLY

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

**FLAPS SLOW**

**CAT 3 SINGLE**

**INOP SYS**

YELLOW HYD  
SPLR 2 + 4  
CAT 3 DUAL  
N/W STRG  
REVERSER 2  
YAW DAMPER 2  
STEEP APPR 

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.



**HYD B+Y SYS LO PR**

Applicable to: ALL

Ident.: PRO-ABN-HYD-L-00018917.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the blue and yellow systems pressure  $\leq 1$  450 PSI (the alert resets if pressure  $\geq 1$  750 PSI).

Flight Phase Inhibition:



*Continued on the following page*

**HYD B+Y SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-L-00018727.0002001 / 21 MAR 16

**[L2] Note:** If the yellow hydraulic system is lost due to low level, the "HYD PTU FAULT" ECAM message may appear, and requests that the flight crew switches the PTU off.

**[L1]** **LAND ASAP**

● If yellow sys lost by ENG 2 PUMP LO PR:  
YELLOW ELEC PUMP.....ON

● If blue sys lost by ELEC PUMP LO PR:  
RAT.....MAN ON

**[L2]** To extend the RAT, the flight crew must press the RAT MAN ON pb located on the Hydraulic overhead panel.

**[L1]** MIN RAT SPD.....140 KT

AFFECTED PUMPS.....OFF

MAX SPEED.....320/0.77

**[L2] Note:** Flight controls remain in normal law.

**[L1]** MANEUVER WITH CARE  
FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

**[L2]** ● If blue or yellow sys recovered:  
See procedure for single failure.

**[L1]** ● If neither system recovered:

**SECONDARY FAILURES**

\*F/CTL

*Continued on the following page*

**HYD B+Y SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-L-00018342.0009001 / 21 MAR 17

L12

**STATUS**

MIN RAT SPD..... 140 KT  
(If B PUMP LO PR)  
MAX SPEED..... 320/0.77  
MANEUVER WITH CARE

**APPR PROC**

**DUAL HYD LO PR**

(Line not displayed for dual LO LVL)

● **If sys lost by RSVR LO AIR PR:**

In approach, system lost by RSVR LO AIR PR may be recovered at low altitude.

RELATED PUMP..... ON

● **If sys lost by RSVR OVHT:**

In approach, system lost by RSVR OVHT may be recovered if OVHT indication disappears.

● **IF BLUE OVHT OUT:**

BLUE ELEC PUMP.....AUTO

● **IF YELLOW OVHT OUT:**

YELLOW ENG 2 PUMP..... ON

● **IF HYD NOT RECOVERED (line not displayed for dual LO LVL):**

● **For A321 aircraft:**



FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3..... ON

L/G.....GRVTY EXTN

**INOP SYS**

B+Y HYD  
R ELEV  
SPLR 2+3+4  
SPD BRK  
AP 1+2  
N/W STRG  
CARGO DOOR (If Y RSVR LO LVL)  
REVERSER 2  
B ELEC PUMP  
EMER GEN (If B RSVR LO LVL)  
YAW DAMPER 2  
CAT 2  
GLS AUTOLAND   
STEEP APPR 

Continued on the following page

**HYD B+Y SYS LO PR (Cont'd)**

*Landing gear is extended by gravity to preserve green system integrity Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION.*

● **For A321 aircraft:**

APPR SPD.....VREF +10 KT

LDG DIST PROC..... APPLY

**SLATS/FLAPS SLOW**

See <sup>(1)</sup>

**FUEL CONSUMPT INCRSD**

See <sup>(2)</sup>

**FMS PRED UNRELIABLE**

See <sup>(3)</sup>

<sup>(1)</sup> *Note: Following a yellow hydraulic system failure, the parking brake may be inoperative due to yellow accumulator low pressure.*

<sup>(2)</sup> *This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*

<sup>(3)</sup> *Disregard FMS fuel predictions and refer to QRH/OPS - Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.*

**HYD G+B SYS LO PR**

Applicable to: ALL

Ident.: PRO-ABN-HYD-J-00018920.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the green and blue systems pressure  $\leq 1$  450 PSI (the alert resets if pressure  $\geq 1$  750 PSI).

Flight Phase Inhibition:



*Continued on the following page*

**HYD G+B SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-J-00018349.0002001 / 22 MAR 17

<sup>[L2]</sup> **Note:** *If the green hydraulic system is lost due to low level, the "HYD PTU FAULT" ECAM message may appear, and requests the flight crew to switch the PTU off.*

<sup>[L1]</sup> **LAND ASAP**

● **If blue sys lost by ELEC PUMP LO PR:**

- RAT.....MAN ON
- MIN RAT SPD.....140 KT
- AFFECTED PUMPS.....OFF
- MANEUVER WITH CARE
- FUEL CONSUMPT INCRSD
- FMS PRED UNRELIABLE

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
 (PROT LOST)

<sup>[L2]</sup> The flight control normal laws and associated protections are lost. Only load factor limitation is furnished (alternate law without protection).

<sup>[L1]</sup> **MAX SPEED**.....320/0.77

<sup>[L2]</sup> *Speed is limited due to loss of high speed protection.*

<sup>[L1]</sup> **SPD BRK**.....DO NOT USE

■ **If blue sys recovered:**

See procedure for single failure.

■ **If blue sys not recovered:**

*Refer to PRO-ABN-F\_CTL [QRH] Landing with Slats or Flaps Jammed.*

**SECONDARY FAILURES**

- \*WHEEL
- \*F/CTL

*Continued on the following page*

**HYD G+B SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-J-00018350.0013001 / 22 MAR 17

L12

**STATUS**

MIN RAT SPD (IF RAT OUT)..... 140 KT  
(If B PUMP LO PR)  
MAX SPEED..... 320/0.77  
MANEUVER WITH CARE  
SPD BRK.....DO NOT USE

**APPR PROC**

**DUAL HYD LO PR**

(Line not displayed for a double LO LVL):

- If sys lost by RSVR LO AIR PR:  
RELATED PUMPS..... ON
- If sys lost by RSVR OVHT:
  - IF BLUE OVHT OUT:  
BLUE ELEC PUMP.....AUTO
  - IF GREEN OVHT OUT:  
GREEN ENG 1 PUMP..... ON
- IF HYD NOT RECOVERED (line not displayed for a double LO LVL):  
A/THR..... OFF  
*Select the target speed on the FCU . Due to the loss of slats and some flight control surfaces, the A/THR may not satisfactorily maintain speed.*  
FOR LDG.....USE FLAP 3  
*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*  
GPWS LDG FLAP 3..... ON
- WHEN SPD 200 KT (displayed when slats are retracted):  
L/G..... GRVTY EXTN

**INOP SYS**

G+B HYD  
F/CTL PROT  
L ELEV  
L+R AIL  
SPLR 1+3+5  
SLATS  
AP 1+2  
AUTO BRK  
NORM BRK  
L/G RETRACT  
REVERSER 1  
EMER GEN (If B RSVR LO LVL)  
B ELEC PUMP  
YAW DAMPER 1  
CAT 2  
GLS AUTOLAND   
STEEP APPR 

Continued on the following page

**HYD G+B SYS LO PR (Cont'd)**

*Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION*

*Extend the landing gear at 200 kt to revert sooner in direct law. This provides, below 200 kt, a better pitch control than in alternate law with one elevator lost and all slats lost.*

APPR SPD..... VREF +25 KT

*Approach speed must be increased, due to the loss of ailerons and slats.*

LDG DIST PROC..... APPLY

ALTN LAW: PROT LOST  
WHEN L/G DN: DIRECT LAW

See <sup>(1)</sup>

FUEL CONSUMPT INCRSD

See <sup>(2)</sup>

FMS PRED UNRELIABLE

See <sup>(3)</sup>

FLAPS SLOW

- <sup>(1)</sup> *At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).*
- <sup>(2)</sup> *This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*
- <sup>(3)</sup> *Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.*



**HYD G+Y SYS LO PR**

Applicable to: ALL

Ident.: PRO-ABN-HYD-K-00018921.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the green and yellow systems pressure  $\leq 1450$  PSI (the alert resets if pressure  $\geq 1750$  PSI).

Flight Phase Inhibition:



*Continued on the following page*

**HYD G+Y SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-K-00018352.0003001 / 22 MAR 17

**LAND ASAP**

PTU..... OFF

AFFECTED PUMPS..... OFF

- **If yellow sys lost by ENG 2 PUMP LO PR:**

    YELLOW ELEC PUMP..... ON

MANEUVER WITH CARE  
 FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

<sup>L2</sup> Flight control normal laws and associated protections are lost. Only load factor limitation, high and low speed stability are provided (alternate law with reduced protection).

<sup>L1</sup> **MAX SPEED**..... 320/0.77

<sup>L2</sup> *Speed is limited due to loss of high speed protection.*

- <sup>L1</sup> ■ **If yellow sys recovered:**

    See procedure for single failure.

- **If yellow sys not recovered:**

*Refer to PRO-ABN-F\_CTL [QRH] Landing with Slats or Flaps Jammed.*

**SECONDARY FAILURES**

\*F/CTL  
 \*WHEEL

*Continued on the following page*

**HYD G+Y SYS LO PR (Cont'd)**

Ident.: PRO-ABN-HYD-K-00018353.0014001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320/0.77  
MAX BRK PR..... 1 000 PSI  
MANEUVER WITH CARE




**APPR PROC**

**DUAL HYD LO PR**

*(Line not displayed for a double LO LVL)*

- **If sys lost by RSVR LO AIR PR:**  
RELATED PUMP..... ON
  - **If sys lost by RSVR OVHT:**
    - **IF GREEN OVHT OUT:**  
GREEN ENG 1 PUMP..... ON
    - **IF YELLOW OVHT OUT:**  
YELLOW ENG 2 PUMP..... ON
  - **IF HYD NOT RECOVERED (line not displayed for a double LO LVL):**  
FOR LDG.....USE FLAP 3  
*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*  
GPWS FLAP MODE.....OFF
  - **WHEN CONF 3 AND VAPP:**  
L/G..... GRVTY EXTN  
*Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION. Being stabilized at VAPP, before selecting the gear down, enables the aircraft to be trimmed for approach.*
- APPR SPD..... VREF +25 KT  
*Approach speed must be increased, due to the loss of flaps.*  
LDG DIST PROC..... APPLY

**INOP SYS**

G+Y HYD  
F/CTL PROT  
STABILIZER  
REVERSER 1+2  
SPLR 1+2+ 4+5  
FLAPS  
LAF   
YAW DAMPER  
AP 1+2  
ANTI SKID  
N/W STRG  
NORM BRK  
AUTO BRK  
L/G RETRACT  
CARGO DOOR (if Y RSVR LO LVL)  
CAT 2  
GLS AUTOLAND   
STEEP APPR 

*Continued on the following page*

**HYD G+Y SYS LO PR (Cont'd)**

ALTN LAW: PROT LOST  
WHEN L/G DN: DIRECT LAW

See <sup>(1)</sup>

BRK Y ACCU PR ONLY

See <sup>(2)</sup>

FUEL CONSUMPT INCRSD

See <sup>(3)</sup>

FMS PRED UNRELIABLE

See <sup>(4)</sup>

SLATS SLOW

See <sup>(5)</sup>

- <sup>(1)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).
- <sup>(2)</sup> 7 full brake applications are available.
- <sup>(3)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.
- <sup>(4)</sup> Disregard FMS fuel predictions and refer to QRH/OPS Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.
- <sup>(5)</sup> Note: Following a yellow hydraulic system failure, the parking brake may be inoperative due to yellow accumulator low pressure.

**HYD PTU FAULT**

Applicable to: ALL

Ident.: PRO-ABN-HYD-R-00017140.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- On ground, PTU does not run if the differential pressure is higher than 650 PSI between G and Y system, or
- In flight, PTU at AUTO position does not run when G or Y reservoir level is low, and G or Y system pressure is low.

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-R-00011657.0001001 / 31 AUG 17

L2 Note: This warning is triggered, if the last engine is started within 40 s following the end of the cargo doors operation. In this case, reset the warning by switching the yellow ELEC pump ON, then OFF.

L1

● If green or yellow reservoir low level and system low press:

PTU..... OFF

Continued on the following page

**HYD PTU FAULT (Cont'd)**

Ident.: PRO-ABN-HYD-R-00011658.0001001 / 18 AUG 10

**STATUS**

**INOP SYS**

PTU

**HYD RAT FAULT**

Applicable to: ALL


Ident.: PRO-ABN-HYD-S-00017141.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when:
- The RAT is not fully stowed, or
  - Pressure is present in the RAT stowing actuator, or
  - The RAT pump is not available.

Flight Phase Inhibition:



Ident.: PRO-ABN-HYD-S-00011659.0001001 / 16 NOV 11

Crew awareness.

*Continued on the following page*



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

HYD

**HYD RAT FAULT (Cont'd)**

Ident.: PRO-ABN-HYD-S-00011660.0001001 / 18 AUG 10

**STATUS**

**INOP SYS**

RAT



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

HYD

Intentionally left blank



**[QRH] LANDING WITH ABNORMAL L/G**

Applicable to: ALL

Ident.: PRO-ABN-LG-AD-00018650.0002001 / 17 MAR 17

The procedure is intended for use when the nose or main landing gear fail to extend and/or lock down following the application of the L/G GRVTY EXTN procedure.  
 It is preferable to use any available landing gear, rather than carry out a belly landing.  
 Under these circumstances, a hard surface runway landing is recommended.  
 Full advantage should be taken of any foam, spread on the runway.

**CAUTION** Do not apply this procedure if at least one green triangle is displayed on each landing gear on the WHEEL SD page. This is sufficient to confirm that the landing gear is downlocked. Disregard any possible GPWS "TOO LOW GEAR" aural alert.

Ident.: PRO-ABN-LG-AD-00018651.0002001 / 17 MAR 17

CABIN CREW.....NOTIFY  
*Notify the cabin crew of the nature of the emergency encountered and state intentions. Specify the amount of available preparation time.*

ATC.....NOTIFY  
*Notify ATC of the nature of the emergency and state intentions.*

GALY & CAB.....OFF

CONSIDER FUEL REDUCTION. This reduces VREF and, consequently, the load factor at impact and the energy to be dissipated.

● **If NOSE L/G abnormal:**

SHIFT CG AFT IF POSSIBLE

- 10 pax from front to rear moves the CG roughly 4 % aft
- 10 pax from mid to rear moves the CG roughly 2.5 aft.

● **If one MAIN L/G abnormal:**

FUEL DISTRIBUTION.....CONSIDER  
*Open the fuel X-FEED valve and switch off the pumps on the side with landing gear normally extended.*

OXYGEN CREW SUPPLY.....OFF

SIGNS.....ON

CABIN and COCKPIT (LOOSE EQPT).....SECURE

*Continued on the following page*

**[QRH] LANDING WITH ABNORMAL L/G (Cont'd)**

Ident.: PRO-ABN-LG-AD-00018652.0001001 / 17 MAR 17

● **For approach:**

GPWS SYS..... OFF

L/G lever..... CHECK DOWN

GRVTY GEAR EXTN handcrank..... TURN BACK TO NORMAL

*Rotating three turns back to normal may, in certain cases, pressurize the landing gear down actuators, thereby reducing the probability of gear collapse after touchdown.*

**DO NOT ARM AUTOBRAKE**

*Manual braking will enable better pitch and roll control. Moreover, with at least one main landing gear in the abnormal position the autobrake cannot be activated (ground spoilers not armed).*

EMER EXIT LT..... ON

CABIN REPORT..... OBTAIN

A/SKID & N/W STRG..... OFF

*With one main landing gear not extended, the reference speed used by the anti-skid to detect a wheel blockage is not correctly initialized. As a result, the anti-skid must be switched off to prevent permanent brake release.*

**MAX BRAKE PR : 1 000 PSI**

*Modulate the brake pressure to 1 000 PSI because the anti-skid is off.*

● **If one or both MAIN L/G abnormal: DO NOT ARM GROUND SPOILERS**

*To keep as much roll authority as possible for maintaining the wings level.*

*Ground spoiler extension would prevent spoilers from acting as roll surfaces.*

RAM AIR..... ON

*To ensure full depressurization of the aircraft before impact.*

DOME LT..... DIM

*Set the dome light to DIM to ensure that there is a light source after both engines are shut down after landing, in order to see and read the BRAKE PRESS indicator.*

● **At 500 ft AGL:**

BRACE FOR IMPACT..... ORDER

*Continued on the following page*

**[QRH] LANDING WITH ABNORMAL L/G (Cont'd)**

Ident.: PRO-ABN-LG-AD-00018654.0001001 / 17 MAR 17

● **At flare, touchdown and rollout:**

Engines should be shut down sufficiently early to ensure fuel is shut off before the nacelles impact, but sufficiently late to ensure adequate hydraulic supplies for the flight controls. Engine pumps continue to supply adequate hydraulic pressure for 30 s after engine shutdown. DO NOT USE REVERSE

● **If NOSE L/G abnormal:**

KEEP NOSE UP

*After touchdown, keep the nose off the runway by the use of the elevator. Then, lower the nose on to the runway before elevator control is lost.*

BRAKES..... SMOOTHLY APPLY

*Adapt braking to the efficiency of the elevator.*

BEFORE NOSE IMPACT : ALL ENG MASTERS OFF

● **If one MAIN L/G abnormal:**

AT TOUCHDOWN : ALL ENG MASTERS OFF

KEEP AFFECTED SIDE WING UP

*Use roll control, as necessary, to maintain the unsupported wing up as long as possible.*

● **If both MAIN L/G abnormal:**

DURING FLARE : ALL ENG MASTERS OFF

MIN PITCH ATT : 6 °

*Continued on the following page*

**[QRH] LANDING WITH ABNORMAL L/G (Cont'd)**

Ident.: PRO-ABN-LG-AD-00018655.0001001 / 09 MAY 17


● **When aircraft stopped:**

PARK BRK.....ON  
 ALL FIRE pb (ENG s & APU)..... PUSH  
 ALL AGENT (ENG s & APU)..... DISCH

■ **If evacuation required:**

EVACUATION..... INITIATE

*Make a short and precise announcement to order the emergency evacuation.*

*Press the EVAC COMMAND pb .*

■ **If evacuation not required:**

CABIN CREW and PASSENGERS (PA)..... NOTIFY


*Ensure that all the landing gears are secured before initiating the disembarkation (before switching OFF the seat belts signs).*

*Continued on the following page*

**[QRH] LANDING WITH ABNORMAL L/G (Cont'd)**

Ident.: PRO-ABN-LG-AD-00018711.0001001 / 17 MAR 17

REFERENCE AIRCRAFT ATTITUDE AFTER IMPACT



**[QRH] L/G GRAVITY EXTENSION**

Ident.: PRO-ABN-LG-00011286.0011001 / 17 MAR 17

Applicable to: ALL

**CAUTION** Do not apply this procedure if at least one green triangle is displayed on each landing gear on the WHEEL SD page. This is sufficient to confirm that the landing gear is downlocked. Disregard any possible GPWS "TOO LOW GEAR" aural alert.

GRAVITY GEAR EXTN handcrank..... PULL AND TURN  
*Rotate the handle clockwise 3 turns until reaching the mechanical stop, even if resistance is felt.*  
 L/G lever ..... DOWN

*The landing gear lever should be confirmed in the DOWN position for the following reasons:*

- To extinguish the UNLK lights on the landing gear indication panel
- To prevent the L/G CTL message from appearing on the WHEEL SD page
- To minimize the risk of landing gear retraction on the ground, due to an unknown system fault, when the free-fall system is reset.

GEAR DOWN indications (if available).....CHECK

*The L/G LGCIU 2 FAULT or BRAKES SYS 1(2) FAULT alert may be spuriously triggered after a gravity extension.*

- Note:
1. Depending on aircraft speed, the display may show the landing gear doors in the amber transit position.
  2. In the event of gravity extension, caused by the failure of both LGCIU s, landing gear position indication on ECAM are lost. LDG GEAR lights on LDG GEAR control panel remain available, if LGCIU 1 is electrically supplied.
  3. If the three green downlock arrows are not on, it is possible that the handcrank is not at the mechanical stop. Check that the handcrank is firmly against the mechanical stop.

■ **If successful:**

**DO NOT RESET LDG GEAR GRVTY EXTN**

Do not reset the free-fall system. This will avoid such undesirable effects as further loss of fluid, in the event of a leak, or possible landing gear unlocking, in the event of a gear selector valve jamming in the UP position.

- Note: *The free-fall system may be reset in flights used for training. If the green hydraulic system is available, resetting the free-fall system allows the landing gear doors to be closed and the nosewheel steering to operate.*  
*The flight crew should not reset the free-fall system on the ground after flight.*

*Continued on the following page*

**[QRH] L/G GRAVITY EXTENSION (Cont'd)**

■ **If unsuccessful:**

LDG WITH ABNORMAL L/G PROC.....APPLY

*Refer to PRO-ABN-LG [QRH] Landing with Abnormal L/G.*

**L/G DOORS NOT CLOSED**

Applicable to: ALL

Ident.: PRO-ABN-LG-D-00017734.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one gear door is not unlocked.

Flight Phase Inhibition:



*Continued on the following page*

**L/G DOORS NOT CLOSED (Cont'd)**

Ident.: PRO-ABN-LG-D-00011287.0003001 / 01 DEC 14

- **If the L/G lever is UP:**
  - **WHEN SPD < 220/0.54:**  
L/G LEVER..... RECYCLE

**L2** Note: To recycle the landing gear, the flight crew must perform the following actions:

- Move the landing gear lever down
- Wait for the landing gear to downlock and for the landing gear doors to close. Simultaneously monitor the WHEEL page on the System Display (SD)
- Move the landing gear lever up.

The active LGCIU changes when the landing gear is recycled.

- L1** ● **IF UNSUCCESSFUL:**  
MAX SPEED..... 250/0.60  
FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

Ident.: PRO-ABN-LG-D-00011288.0002001 / 17 MAR 17

<b>L12</b>	<b>STATUS</b>	
MAX SPEED..... 250/.60	INOP SYS	
FUEL CONSUMPT INCRSD	L/G DOOR	
See <sup>(1)</sup>		
FMS PRED UNRELIABLE		
See <sup>(2)</sup>		

<sup>(1)</sup> This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

<sup>(2)</sup> Disregard FMS fuel predictions and Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table in order to find the applicable Fuel Penalty Factor.



**L/G GEAR NOT DOWN**

Applicable to: ALL

Ident.: PRO-ABN-LG-AA-00017859.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:


L2

This alert triggers when:

1. L/G is not downlocked and radio height is lower than 750 ft and both engines N1 lower than 75% (or if engine shutdown N1 of remaining engine lower than 97%) or
2. L/G is not downlocked and radio height is lower than 750 ft and both engines are not at T.O power and flaps at 1, 2, 3 or FULL or
3. L/G is not downlocked and flaps at 3 or FULL and both radio altimeters are failed.

Note: In the cases 2 and 3 above, the aural warning can only be cancelled by the emergency cancel pushbutton.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-AA-00018573.0002001 / 21 MAR 16

L2

When this warning appears, the red arrow on the instrument panel comes on.

L1

Crew awareness.

**L/G GEAR NOT DOWNLOCKED**

Applicable to: ALL


Ident.: PRO-ABN-LG-C-00017860.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when one gear is not downlocked and L/G is selected down.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-C-00011284.0002001 / 01 DEC 14

- [L2] This warning appears, if the landing gear sequence is not completed after 30 s.

[L1] **L/G LEVER**..... **RECYCLE**

[L2] Note: To recycle the landing gear, the flight crew must perform the following actions:

- Move the landing gear lever up
  - Wait for the landing gear to uplock and for the landing gear doors to close. Simultaneously monitor the WHEEL page on the System Display (SD)
  - Move the landing gear lever down.
- The active LGCIU changes when the landing gear is recycled.

[L1] ● **IF UNSUCCESSFUL AFTER 120 s:**  
**L/G**..... **GRVTY EXTN**

- [L2] Rotate the handle clockwise about 3 turns until reaching the mechanical stop. Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION.

Continued on the following page

**L/G GEAR NOT DOWNLOCKED (Cont'd)**

Ident.: PRO-ABN-LG-C-00011285.0003001 / 21 MAR 16

L12

**STATUS**

L/G..... GRVY EXTN

CAT 3 SINGLE ONLY

See <sup>(1)</sup>

**INOP SYS**

CAT 3 DUAL

<sup>(1)</sup> If gravity extension is unsuccessful, Refer to PRO-ABN-LG [QRH] Landing with Abnormal L/G.

**L/G GEAR NOT UNLOCKED**

Applicable to: ALL

Ident.: PRO-ABN-LG-B-00017736.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one gear is not unlocked and L/G is not selected down.

Flight Phase Inhibition:



Continued on the following page

**L/G GEAR NOT UNLOCKED (Cont'd)**

Ident.: PRO-ABN-LG-B-00011061.0003001 / 01 DEC 14

**L2** This warning appears if the landing gear sequence is not completed after 30 s.

**L1** ■ **L/G doors closed:**

**AVOID EXCESS G FACTOR**

**L2** *Because the gear rests on the doors, avoid excessive load factors in order not to damage door structure.*

**L1** ■ **L/G doors not closed and shock absorber fault:**

**MAX SPEED**..... 220/0.54  
**L/G**..... DOWN  
**MAX SPEED**..... 280/0.67

■ **L/G doors not closed and no shock absorber fault:**

**MAX SPEED**..... 220/0.54  
**L/G LEVER**..... RECYCLE

**L2** *Note: To recycle the landing gear, the flight crew must perform the following actions:*

- Move the landing gear lever down
- Wait for the landing gear to downlock and for the landing gear doors to close. Simultaneously monitor the WHEEL page on the System Display (SD)
- Move the landing gear lever up.

*The active LGCIU changes when the landing gear is recycled.*

**L1** ● **IF UNSUCCESSFUL:**

**L/G**..... DOWN  
**MAX SPEED**..... 280/0.67

**FUEL CONSUMPT INCRSD**  
**FMS PRED UNRELIABLE**

*Continued on the following page*

**L/G GEAR NOT UNLOCKED (Cont'd)**

Ident.: PRO-ABN-LG-B-00018687.0002001 / 25 JUL 17

L12

**STATUS**

MAX SPEED..... 280/67

**INOP SYS**

FUEL CONSUMPT INCRSD

L/G RETRACT

FMS PRED UNRELIABLE

See <sup>(1)</sup>

<sup>(1)</sup>

*If the flight is continued (to destination or to alternate) with landing gear extended:*

- *Disregard FMS fuel predictions. Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table in order to find the applicable Fuel Penalty Factor*
- *Disregard FMS altitude and speed predictions. Time predictions are only valid in cruise*
- *Do not use the managed speed mode (except in approach)*
- *Do not use the CLB and the DES autopilot modes.*

*Also Refer to PRO-NOR-SUP-L/G- Flight with Gear Down.*

**L/G GEAR UPLOCK FAULT**

Applicable to: ALL


Ident.: PRO-ABN-LG-E-00017737.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when one gear uplock is engaged with corresponding gear downlocked.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-E-00011289.0002001 / 27 NOV 12

L/G.....KEEP DOWN

**L2** The landing gear must be left down to avoid structural damage, because the uplock device will stay in the locked position.

**L1** MAX SPEED.....280/.67

FUEL CONSUMPT INCRSD  
 FMS PRED UNRELIABLE

Continued on the following page

**L/G GEAR UNLOCK FAULT (Cont'd)**

Ident.: PRO-ABN-LG-E-00018719.0002001 / 25 JUL 17

L12

**STATUS**

MAX SPEED..... 280/67  
 L/G..... KEEP DOWN

**INOP SYS**

L/G RETRACT

**FUEL CONSUMPT INCRSD**

See <sup>(1)</sup>

**FMS PRED UNRELIABLE**

See <sup>(2)</sup>

<sup>(1)</sup> This message triggers when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.

- <sup>(2)</sup> If the flight is continued (to destination or to alternate) with landing gear extended:
- Disregard FMS fuel predictions. Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table in order to find the applicable Fuel Penalty Factor
  - Disregard FMS altitude and speed predictions. Time predictions are only valid in cruise
  - Do not use the managed speed mode (except in approach)
  - Do not use the CLB and the DES autopilot modes.
- Also Refer to PRO-NOR-SUP-L/G- Flight with Gear Down.

**L/G LGCIU 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-LG-G-00018059.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when LGCIU 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-G-00018681.0002001 / 21 MAR 16

● **If LGCIU 1 is failed:**

GPWS SYS.....OFF

**L2** GPWS receives "L/G in up position" information even if the landing gear is down.  
 Set the GPWS SYS pb-sw to OFF in order to prevent untimely warnings during the approach.

*Continued on the following page*



**L/G LGCIU 1(2) FAULT (Cont'd)**

Ident.: PRO-ABN-LG-G-00018682.0001001 / 21 MAR 16

L12


**STATUS**

**INOP SYS**

**ENG 1(2) APPR IDLE ONLY**

See <sup>(2)</sup>

LGCIU 1(2)  
 REVERSER 1(2)  
 GPWS <sup>(1)</sup>

- Note:**
1. The partial spoiler extension  at landing when only one main landing gear is compressed is not available. The spoilers extend normally on ground when wheel speed greater than 72 kt.
  2. Depending on the LGCIU failure, only a part of the above systems may be lost.

<sup>(1)</sup> (If LGCIU 1 is failed)

<sup>(2)</sup> When idle is selected on ground with slats extended, only approach idle is available.

**L/G LGCIU 1+2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-LG-V-00017739.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both LGCIUs are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-V-00018683.0002001 / 21 MAR 16

**L2** Normal landing gear control and position indications are lost. LDG GEAR lights on LDG GEAR control panel remain available if LGCIU 1 is electrically supplied.

**L1** L/G..... GRVTY EXTN

**L2** Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION.

**L1** GPWS SYS..... OFF

**L2** As LGCIU 1 is lost, GPWS receives "L/G in up position" information even if the landing gear is down.

Set the GPWS SYS pb-sw to OFF in order to prevent untimely warnings during approach.

*Continued on the following page*

**L/G LGCIU 1+2 FAULT (Cont'd)**



Ident.: PRO-ABN-LG-V-00018684.0006001 / 05 OCT 16

L12


**STATUS**

**INOP SYS**

- If the selected configuration is not FLAP 3:  
 FOR LDG.....USE FLAP 3
  - If the selected configuration is FLAP 3:  
 FOR LDG: USE FLAP 3
- L/G..... GRVTY EXTN

- REVERSER 1+2
- AP 1+2 <sup>(1)</sup>
- CAT 2 <sup>(1)</sup>
- A/THR
- GLS AUTOLAND 
- LGCIU 1
- LGCIU 2
- GPWS
- ROW/ROP 

L/G CONTROL NOT AVAIL  
 ENG 1 APPR IDLE ONLY  
 ENG 2 APPR IDLE ONLY

- Note:
1. The partial spoiler extension  at landing when only one main landing gear is compressed is not available. The spoilers extend normally on ground when wheel speed greater than 72 kt.
  2. In flight with both LGCIU s "faulty", whatever the landing gear configuration, when the flight crew switches ON Wing Anti-Ice pb, the Wing Anti-Ice pb will illuminate "on" and there will be only 30 s of heating. This loss of Wing Anti-ice will not have an ECAM/Aural warning, although BLEED SD page shows a "no-Anti-ice" legend.

<sup>(1)</sup> (Except in LAND mode)

**L/G SHOCK ABSORBER FAULT**  
(SHOCK ABSORBER EXTENDED ON GROUND)

Applicable to: ALL


Ident.: PRO-ABN-LG-AB-00017733.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when one shock absorber is not compressed after landing.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-AB-00011056.0001001 / 25 FEB 14

Crew awareness.

**L/G SHOCK ABSORBER FAULT**  
(SHOCK ABSORBER NOT EXTENDED AFTER LIFTOFF)

Applicable to: ALL

Ident.: PRO-ABN-LG-A-00018062.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one shock absorber is not extended when airborne.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-A-00011058.0003001 / 25 FEB 14

■ **Shock absorber not extended after liftoff and L/G unpluged :**

Crew awareness.

■ **Shock absorber not extended after liftoff and L/G not unpluged :**

MAX SPEED..... 280/67

■ **If L/G lever still down :**

L/G..... KEEP DOWN

■ **If L/G lever selected up :**

L/G..... DOWN

FUEL CONSUMPT INCRSD  
FMS PRED UNRELIABLE

*Continued on the following page*

**L/G SHOCK ABSORBER FAULT (Cont'd)**  
**(SHOCK ABSORBER NOT EXTENDED AFTER LIFTOFF)**

Ident.: PRO-ABN-LG-A-00011059.0003001 / 25 JUL 17

L12

**STATUS**

● **If L/G not uplocked:**

MAX SPEED.....280/.67  
 L/G.....KEEP DOWN

**INOP SYS**

L/G RETRACT

FUEL CONSUMPT INCRSD

FMS PRED UNRELIABLE

See <sup>(1)</sup>

<sup>(1)</sup>

*If the flight is continued (to destination or to alternate) with landing gear extended:*

- Disregard FMS fuel predictions. Refer to QRH/OPS Fuel Penalty Factors/ECAM Alert Table in order to find the applicable Fuel Penalty Factor
  - Disregard FMS altitude and speed predictions. Time predictions are only valid in cruise
  - Do not use the managed speed mode (except in approach)
  - Do not use the CLB and the DES autopilot modes.
- Also Refer to PRO-NOR-SUP-L/G- Flight with Gear Down.

Note: In few cases, autothrust and autopilot may also be lost.

If **WHEEL N.W. STEER FAULT** is also displayed, then the nose wheels may be at maximum deflection. (Turned 90 ° from center.) During landing, delay nose wheel touchdown for as long as possible.

**L/G SYS DISAGREE**

Applicable to: ALL

Ident.: PRO-ABN-LG-AC-00017861.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when LGCIU 1 and LGCIU 2 detect a discrepancy between the landing gear positions.

Flight Phase Inhibition:



Ident.: PRO-ABN-LG-AC-00018664.0002001 / 21 MAR 16

Crew awareness.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

L/G

Intentionally left blank



**[MEM] EMER DESCENT**

Ident.: PRO-ABN-MISC-00012092.0001001 / 17 MAR 17

Applicable to: ALL

CREW OXY MASKS..... USE  
 SIGNS..... ON  
 EMER DESCENT..... INITIATE

● **If A/THR not active:**

THR LEVERS..... IDLE

SPD BRK..... FULL

● **When descent established:**

SPEED..... MAX/APPROPRIATE

● **If structural damage suspected: MANEUVER WITH CARE**

CONSIDER L/G EXTENSION

ENG MODE SEL..... IGN

ATC..... NOTIFY

*Notify ATC of the nature of the emergency, and state intention. The flight crew can communicate with the ATC using voice, or CPDLC when the voice contact cannot be established or has poor quality.*

EMER DESCENT (PA)..... ANNOUNCE

*The flight crew must inform the cabin of emergency descent on the PA system.*

ATC XPDR 7700..... CONSIDER

*Squawk 7700 unless otherwise specified by ATC.*

CREW OXY MASKS DILUTION..... NORM

- To save oxygen, set the oxygen diluter selector to the N position
- If the oxygen diluter selector remains set to 100 %, oxygen quantity may be insufficient to cover the entire emergency descent profile
- Ensure that crew communication is established with oxygen masks. Avoid the continuous use of the interphone to minimize interference with the breathing noise in the oxygen mask.

MAX FL: 100/MEA-MORA

● **If CAB ALT above 14 000 ft:**

OXYGEN PAX MASK MAN ON..... PRESS

*This action confirms that the passenger oxygen masks are released.*

*Continued on the following page*

**[MEM] EMER DESCENT (Cont'd)**

*Note: Notify the cabin crew, when the aircraft reaches a safe flight level, and when cabin oxygen is no more necessary.*

**[MEM] STALL RECOVERY**

Ident.: PRO-ABN-MISC-00013768.0001001 / 17 MAR 17

Applicable to: ALL

As soon as any stall indication (could be aural warning, buffet...) is recognized, apply the immediate actions:

NOSE DOWN PITCH CONTROL.....APPLY

*This will reduce angle of attack*

*Note: In case of lack of pitch down authority, reducing thrust may be necessary.*

BANK.....WINGS LEVEL

● **When out of stall (no longer stall indications) :**

THRUST.....INCREASE SMOOTHLY AS NEEDED

*Note: In case of one engine inoperative, progressively compensate the thrust asymmetry with rudder.*

SPEEDBRAKES.....CHECK RETRACTED

FLIGHT PATH.....RECOVER SMOOTHLY

● **If in clean configuration and below 20 000 ft :**

FLAP1.....SELECT

*Note: If a risk of ground contact exists, once clearly out of stall (no longer stall indications), establish smoothly a positive climb gradient.*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

**[MEM] STALL WARNING AT LIFT-OFF**

Ident.: PRO-ABN-MISC-00013769.0001001 / 17 MAR 17

Applicable to: ALL

Spurious stall warning may sound in NORMAL law, if an angle of attack probe is damaged. In this case, apply immediately the following actions:

THRUST..... TOGA

At the same time:

PITCH ATTITUDE.....15 °

BANK.....WINGS LEVEL

*Note: When a safe flight path and speed are achieved and maintained, if stall warning continues, consider it as spurious.*

**[QRH] BOMB ON BOARD**

Ident.: PRO-ABN-MISC-00012095.0002001 / 17 MAR 17

Applicable to: ALL

**COCKPIT PROCEDURES**

**BACKGROUND**

To avoid the activation of an altitude-sensitive bomb, the cabin altitude should not exceed the value at which the bomb has been discovered.

To reduce the effects of the explosion, the aircraft should fly as long as possible with approximately 1 PSI differential pressure, to help the blast go outwards. 1 PSI differential pressure corresponds to a 2 500 ft difference between the aircraft and the cabin altitude. These conditions are achieved by using the manual pressure control.

**PROCEDURE**

The following procedure assumes that it is initiated during climb or cruise:


First, maintain the cabin altitude using manual pressure mode.

While maintaining the cabin altitude, descend the aircraft to the cabin altitude + 2 500 ft and maintain delta P at 1 PSI.

During further steps of descent, maintain delta P at 1 PSI using the cabin V/S target selector.

During the approach, use automatic pressure mode in order to reduce the differential pressure to zero at touchdown.

If flight conditions are different, the crew should adapt the procedure, bearing in mind the above-mentioned principles (background paragraph).



CKPT / CAB COM..... ESTABLISH

*Continued on the following page*

**[QRH] BOMB ON BOARD (Cont'd)**

■ **If landing and evacuation possible within 30 min:**

ATC / COMPANY..... NOTIFY  
 EVAC..... PREPARE

■ **If landing and evacuation NOT possible within 30 min:**

AIRCRAFT (IF CLIMBING)..... LEVEL OFF  
 CABIN PRESS MODE SEL..... MAN

*The purpose is to immediately prevent the cabin altitude from increasing, in order to avoid the activation of an altitude-sensitive bomb.*

MAINTAIN CAB ALT

*Use MAN V/S CTL selector to maintain the cabin altitude at the value it had when the bomb was discovered.*

ATC / COMPANY..... NOTIFY

*To obtain expert advice from explosive specialists.*

TRGT SPEED: PREFER LO IAS

*Low speed could reduce the consequences of possible structural damage, if the bomb explodes.*

DESCENT TO CAB ALT + 2 500 ft or MEA - MORA..... INITIATE

*Descending to 2 500 ft above the cabin altitude gives a cabin differential pressure of approximately 1 PSI, which helps to ensure that the blast goes outwards, if the bomb explodes.*

AVOID SHARP MANEUVERS

*Which might result in the bomb moving.*

MAINTAIN CAB ALT

*Use MAN V/S CTL selector to maintain the cabin altitude. Initially brief UP input should be required; but, be careful not to increase the cabin altitude.*

● **When at CAB ALT + 2 500 ft:**

MAINTAIN 1 PSI ΔP

*Use MAN V/S CTL selector to adjust delta P to 1 PSI. Brief DN input should be initially required to set 0 ft/min cabin vertical speed.*

GALLEY..... OFF

FUEL RESERVES..... DETERMINE

*When flying at cabin altitude + 2 500 ft, fuel consumption in CONF 1, with landing gear down, will be about 2.1 times that consumed in clean configuration.*

*Continued on the following page*

**[QRH] BOMB ON BOARD (Cont'd)**

● **When bomb secured at the LRBL or cannot be moved:**

*Least Risk Bomb Location (LRBL) is the center of the RH aft cabin door*

EMER EXIT LT..... ON

*To recover minimum cabin lighting when the COMMERCIAL pb-sw will be switched OFF*

COMMERCIAL..... OFF

● **If fuel permits:**

FLAPS..... AT LEAST CONF 1

L/G lever (except for flight over water)..... DOWN

*The detonation could damage the landing systems. Therefore, if fuel permits, configure the aircraft for landing as soon as possible. Reducing the speed will minimize stress on the aircraft structure.*

USE NORMAL CONF FOR LANDING

DURING FURTHER DESCENT: MAINTAIN MAX 1 PSI ΔP

*Use MAN V/S CTL selector to DN to adjust delta P to 1 PSI.*

● **During approach:**

CABIN PRESS MODE SEL..... AUTO

*This allows CPC to automatically control the cabin altitude to 0 during final approach.*

● **When aircraft on ground and stopped in a remote area (if possible):**

*Refer to PRO-ABN-MISC [QRH] EMER EVAC*

**CABIN PROCEDURES**

If a suspect device is found in the cabin:

**WARNING** Do not cut or disconnect any wires and do not open or attempt to gain entry to internal components of a closed or concealed suspect device. Any attempt may result in an explosion. Booby-trapped closed devices have been used on aircraft in the past.

**WARNING** Alternate locations must not be used without consulting with an aviation explosives security specialist. Never take a suspect device to the flight deck.

**CAUTION** The least risk bomb location for the aircraft structure and systems is center of the RH aft cabin door.

EOD PERSONNEL ON BOARD..... CHECK

*Continued on the following page*

**[QRH] BOMB ON BOARD (Cont'd)**

*Announce "Is there any EOD personnel on board ?". By using the initials, only persons familiar with EOD (Explosive Ordnance Disposal) will be made aware of the problem.*

- DO NOT OPEN THE BOMB
- DO NOT CUT BOMB'S WIRES
- SECURE BOMB AGAINST SLIPPING
- PROTECT BOMB AGAINST SHOCKS

*Secure in the attitude found and do not lift before having checked for an anti-lift ignition device.*

PASSENGERS..... LEAD AWAY FROM BOMB

*Move passengers at least 4 seat rows away from the bomb location. On full flights, it may be necessary to double up passengers to achieve standoff from the suspect device.*

*Passengers near the bomb should protect their heads with pillows, blankets.*

*All passengers must remain seated with seatbelts on and, if possible, head below the top of the head rest. Seat backs and tray tables should be in their full upright position.*

*Service items may need to be collected in order to secure tray tables.*

PORTABLE ELECTRONIC DEVICES..... SWITCH OFF

*The cabin crews must command passengers to switch off all portable electronic devices.*

BOMB.....CHECK NO ANTI-LIFT DEVICE

*To check for an anti-lift switch or lever, slide a string or stiff card, (such as the emergency information card) under the bomb, without disturbing the bomb.*

*If the string or card cannot be slipped under the bomb, it may indicate that an anti-lift switch or lever is present and that the bomb cannot be moved.*

*If a card is used and can be slid under the bomb, leave it under the bomb and move together with the bomb.*

*If it is not possible to move the bomb, then it should be surrounded with a single thin sheet of plastic (e. g. trash bag), then with wetted materials, and other blast attenuation materials such as seat cushions and soft carry-on baggage. Move personnel as far away from the bomb location as possible.*

EMERGENCY EQUIPMENT..... REMOVE AND STOW

*Emergency equipment (PBE, fire extinguisher, ...) located close to the LRBL must be removed and stowed in alternate location.*

GALLEY/IFE POWER.....OFF

*All galley and IFE equipment located close to the LRBL must be switched off.*

● **If the bomb can be moved:**

RH AFT CABIN DOOR SLIDE..... DISARM

LEAST RISK BOMB LOCATION (LRBL)..... PREPARE

*Continued on the following page*

**[QRH] BOMB ON BOARD (Cont'd)**

*Build up a platform of solid baggage against the door up to about 25 cm (10 in) below the middle of the door.*

*On top of this, build up at least 25 cm (10 in) of wetted material such as blankets and pillows. Place a single thin sheet of plastic (e. g. trash bag) on top of the wetted materials. This prevents any possible short circuit.*

<b>CAUTION</b>	<b>DO NOT OMIT THE PLASTIC SHEETS, AS THE SUSPECT DEVICE COULD GET WET AND POSSIBLY SHORT CIRCUIT ELECTRONIC COMPONENTS CAUSING INADVERTENT DEVICE ACTIVATION.</b>
----------------	--

BOMB INDICATION LINE.....POSITION

*Note: A bomb location indicator line is a 6 to 8 ft (1.8 to 2.4 m) (e.g. neckties, headset cord, or belts connected together) preferably of contrasting color, that helps the responding bomb squad find the precise location of the suspect device within the LRBL stack once constructed.*

*Position the bomb indication line from the location on the platform where you will place the suspect device, EXTENDING outward into the aisle.*

BOMB.....MOVE TO LRBL

*Carefully carry in the attitude found and place on top of the wetted materials in the same attitude and as close to the door structure as possible.*

<b>CAUTION</b>	<b>Ensure that the suspect device, when placed on the stack against the door, is above the slide pack but not against the door handle, and if possible, avoid placement in the view port.</b>
----------------	---

LEAST RISK BOMB LOCATION (LRBL).....COMPLETE

*Place an additional single thin sheet of plastic over the bomb.*

<b>CAUTION</b>	<b>DO NOT OMIT THE PLASTIC SHEETS, AS THE SUSPECT DEVICE COULD GET WET AND POSSIBLY SHORT CIRCUIT ELECTRONIC COMPONENTS CAUSING INADVERTENT DEVICE ACTIVATION.</b>
----------------	--

*Build up at 25 cm (10 in) of wetted material around the sides and on top of the bomb.*

**DO NOT PLACE ANYTHING BETWEEN THE BOMB AND THE DOOR, AND MINIMIZE AIRSPACE AROUND THE BOMB.**

*The idea is to build up a protective surrounding of the bomb so that the explosive force is directed in the only unprotected area into the door structure.*

*Fill the area around the bomb with seat cushions and other soft materials such as hand luggage (saturated with water or any other nonflammable liquid) up to the cabin ceiling,*

*Continued on the following page*




**[QRH] BOMB ON BOARD (Cont'd)**

*compressing as much as possible. Secure the LRBL stack in place using belt, ties or other appropriate materials. The more material stacked around the bomb, the less the damage will be.*

USE ONLY SOFT MATERIAL. AVOID USING MATERIALS CONTAINING ANY INFLAMMABLE LIQUID AND ANY METAL OBJECTS WHICH COULD BECOME DANGEROUS PROJECTILES.

**LRBL STACK**



**PASSENGERS..... MOVE/ADVISE**

*Move passengers at least 4 seat rows away from the least risk bomb location (RH aft cabin door). On full flights, it may be necessary to double up passengers to achieve standoff from the suspect device.*

*Passengers near the bomb should protect their heads with pillows, blankets. All passengers must remain seated with seatbelts on and, if possible, head below the top of the head rest. Seat backs and tray tables must be in their full upright position.*

**CABIN CREW..... NOTIFY COCKPIT CREW**

*Cabin crew notify the flight crew that the bomb is secured at the LRBL.*

**EVACUATION/DISEMBARKATION..... EXECUTE**

*Evacuate through normal and emergency exits on the opposite side of the "bomb" location. Do not use the door just opposite the "bomb".*

*Continued on the following page*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

**[QRH] BOMB ON BOARD (Cont'd)**

*Use all available airport facilities to disembark without delay.*

**[QRH] COCKPIT WINDSHIELD / WINDOW ARCING**

Ident.: PRO-ABN-MISC-00012099.0001001 / 17 MAR 17

Applicable to: **ALL**

Affected WINDOW / WINDSHIELD ANTI-ICE C/B..... PULL

*Pull the circuit breaker of the affected window/windshield heating system, in case of:*

- *Electrical arcing of the cockpit windshield/window, or*
- *Burning smell or smoke identified as coming from the bottom right corner of CAPT windshield or bottom left corner of the F/O windshield.*

*On the rear C/B panel:*

- ANTI-ICE L WSHLD AF10 C/B [123VU],
- ANTI-ICE R WSHLD AF03 C/B [123VU],
- ANTI-ICE/WINDOWS L X14 C/B [122VU],
- ANTI-ICE/WINDOWS R W14 C/B [122VU].



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

**[QRH] COCKPIT WINDSHIELD / WINDOW CRACKED**

Ident.: PRO-ABN-MISC-00012097.0001001 / 17 MAR 17

Applicable to: ALL

TOUCH THE CRACK WITH A PEN (OR CAREFULLY WITH FINGERNAIL)

■ **If no crack on cockpit side:**

NO LIMITATION

*The inner ply is not affected. Therefore, the window/windshield is still able to sustain the differential pressure up to the maximum flight level.*

■ **If cracks on cockpit side:**

MAX FL: 230 / MEA-MORA

*The inner ply is affected. The flight crew is not able to easily determine if other plies are affected. Descend to FL 230/MEA and reduce differential pressure to 5 PSI .*

Note: *The maximum flight level is restricted to FL 230/MEA to obtain  $\Delta P$  5 PSI , without resulting in an excessive cabin altitude and an EXCESS CAB ALT warning.*

The following procedure enables maintaining  $\Delta P$  5 PSI in manual cabin pressure mode.

CAB PRESS MODE SEL..... MAN

DISREGARD THE CAB ALT TARGET TABLE DISPLAYED ON THE ECAM

MAN V/S CTL.....AS RQRD

SET THE CABIN ALTITUDE ACCORDING TO THE TABLE BELOW TO MAINTAIN  $\Delta P$  5 PSI

FL	100	150	200	230
CABIN ALTITUDE	0	3 000	6 000	8 000

● **When starting the descent for approach:**

CAB PRESS MODE SEL..... AUTO

Note: *Due to the increased noise level, pay particular attention to visual warnings.*

● **If visibility not sufficient for approach due to damage:**

CONSIDER AUTOLAND

● **For approach, if AUTOLAND not available:**

CAB PRESS MODE SEL..... MAN

MAN V/S CTL..... FULL UP

MAX SPEED: 200 kt

PF SLIDING WINDOW..... OPEN

**[QRH] DITCHING**

Ident.: PRO-ABN-MISC-00012087.0056001 / 17 MAR 17

Applicable to: ALL

This procedure applies when engines are running. If engines are not running, *Refer to QRH/ABN-19 ENG DUAL FAILURE - FUEL REMAINING - DITCHING* or *Refer to QRH/ABN-19 ENG DUAL FAILURE - NO FUEL REMAINING - DITCHING*

ATC.....NOTIFY  
ATC XPDR 7700..... CONSIDER

PREPARE CABIN AND COCKPIT

*Notify the cabin crew of the nature of the emergency and state intentions.*

*Specify the available time:*

- Loose equipment secured
- Survival equipment prepared
- Belts and shoulder harnesses locked

GPWS SYS..... OFF  
GPWS TERR..... OFF

*Pressing OFF the SYS pb and TERR pb avoids nuisance warnings.*

SIGNS.....ON  
EMER EXIT LT..... ON  
COMMERCIAL.....OFF  
LDG ELEV.....SELECT 00  
BARO..... SET  
DISREGARD NORM C/Ls  
ELT (when conditions permit)..... ON

● **For approach and ditching:**

KEEP LANDING GEAR UP

SLATS / FLAPS.....MAX AVAIL

FOR FLARE: TARGET PITCH 11 ° & MIN V/S

*Note: Prefer ditching parallel to the swell. If that causes a strong crosswind, ditch into the wind.*

● **At 2 000 ft AGL:**

CAB PRESS MODE SEL..... AUTO

*The outflow valve would remain open, if the MODE SEL pb were not at AUTO.*

ALL BLEEDS (ENGs & APU)..... OFF

*Continued on the following page*

**[QRH] DITCHING (Cont'd)**

CABIN CREW.....NOTIFY FOR DITCHING  
DITCHING pb ..... ON

*The outflow valve, emergency ram air inlet, avionics ventilation inlet and extract valves, and pack flow control valves, and the forward cargo outlet isolation valve, close.*

● **At 500 ft AGL:**

BRACE FOR IMPACT..... ORDER

● **At touchdown:**

ALL ENG MASTERS..... OFF

APU MASTER SW.....OFF

● **After ditching:**

ATC (VHF 1)..... NOTIFY

*With engine and APU shut down, only VHF 1 is supplied.*

ALL FIRE pb (ENGs & APU).....PUSH

ALL AGENTS (ENGs and APU).....DISCH

EVACUATION..... INITIATE

ELT.....CHECK EMITTING

*If not, switch on the transmitter.*

*After impact the lowest point of the passenger exits (aft door) remains above the waterline for more than 7 min.*

**[QRH] EMER EVAC**

Ident.: PRO-ABN-MISC-00012083.0001001 / 09 MAY 17

Applicable to: ALL

Apply this procedure when considering an emergency evacuation, or when required by the ECAM. Carefully analyze the situation before deciding to evacuate passengers. However do not waste valuable time.

AIRCRAFT / PARKING BRK.....STOP / ON  
ATC (VHF1).....NOTIFY

*Notify ATC of the nature of the emergency, and state intentions.*

*Only VHF 1 is available on batteries.*

CABIN CREW (PA).....ALERT

*Make a short and precise announcement to warn that an emergency evacuation may be required.*

ΔP (only if MAN CAB PR has been used).....CHECK ZERO

*If ΔP is not at zero, MODE selector on MAN and V/S CTL FULL UP, to fully open the outflow valve.*

● **If ΔP not at zero:**

CAB PR MODE SEL.....MAN

V/S CTL.....FULL UP

ALL ENG MASTER.....OFF

*Associated LP and HP valves close.*

ALL FIRE pb (ENGs & APU).....PUSH

ALL AGENTS (ENGs & APU).....AS RQRD


*Engine Agent 2 is not available.*

*The use of agents is required if the ENG FIRE or APU FIRE is displayed.*

■ **If evacuation required:**

EVACUATION.....INITIATE

*Make a short and precise announcement to order the emergency evacuation.*

*Press the EVAC COMMAND pb  .*

■ **If evacuation not required:**

CABIN CREW AND PASSENGERS (PA).....NOTIFY



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

**[QRH] EMER LANDING**  
**ALL ENG FAILURE**

Ident.: PRO-ABN-MISC-00015075.0009001 / 17 MAR 17

Applicable to: ALL

Apply the following if not able to maintain altitude after the loss of thrust near the ground.

■ **If ditching anticipated:**

APU..... START  
 L/G LEVER..... CHECK UP  
 FOR LANDING..... USE FLAP 2

**L2** Only slats extend, and slowly.

**L1** VAPP..... DETERMINE

<b>Weight</b>	40 t / 90 klb	50 t / 110 klb	60 t / 130 klb	70 t / 155 klb	80 t / 175 klb	90 t / 200 klb	95 t / 210 klb
<b>VAPP</b>	150 kt	150 kt	163 kt	173 kt	183 kt	193 kt	198 kt

DITCHING pb ..... ON

**L2** Ditch the aircraft parallel to the swell. If that causes a strong crosswind, ditch the aircraft into the wind.

**L1** ● **At 500 ft AGL or below:**

BRACE FOR IMPACT..... ORDER

● **For flare:**

TOUCH DOWN AT MIN V/S  
 TARGET PITCH ATT 11 °

● **At touchdown:**

ALL ENG MASTERS..... OFF  
 APU MASTER SW..... OFF  
 EMER EVAC PROC..... APPLY

**L2** Refer to PRO-ABN-MISC [QRH] EMER EVAC

**L1** ■ **If forced landing anticipated:**

APU..... START  
 FOR LANDING..... USE FLAP 2

**L2** Only slats extend, and slowly.

**L1** VAPP..... DETERMINE

<b>Weight</b>	40 t	50 t	60 t	70 t	80 t	90 t	95 t
---------------	------	------	------	------	------	------	------

Continued on the following page

**[QRH] EMER LANDING (Cont'd)**  
**ALL ENG FAILURE**

	/ 90 klb	/ 110 klb	/ 130 klb	/ 155 klb	/ 175 klb	/ 200 klb	/ 210 klb
<b>VAPP</b>	150 kt	150 kt	163 kt	173 kt	183 kt	193 kt	198 kt

GND SPLRs..... ARM

● **At 1 000 ft AGL at the latest:**

GRAVITY GEAR EXTN handcrank..... PULL AND TURN

**[L2]** *Flight controls revert to direct law at landing gear extension. To ensure correct aircraft trimming for approach, extend the landing gear only when the aircraft is in CONF 2 and at VAPP. Disregard the "USE MAN PITCH TRIM" message on the PFD, because the stabilizer is jammed, due to not sufficient hydraulic power.*

**[L1]** ● **When L/G downlocked:**

L/G LEVER..... DOWN

● **At 500 ft AGL or below:**

BRACE FOR IMPACT..... ORDER

● **For flare:**

TOUCH DOWN AT MIN V/S

● **At touchdown:**

ALL ENG MASTERS..... OFF

APU MASTER SW..... OFF

EMER EVAC PROC..... APPLY

**[L2]** *Refer to PRO-ABN-MISC [QRH] EMER EVAC*



**[QRH] FORCED LANDING**

Ident.: PRO-ABN-MISC-00012090.0032001 / 09 MAY 17

Applicable to: ALL

If engines are not running, *Refer to QRH/ABN-19 ENG DUAL FAILURE - FUEL REMAINING - FORCED LANDING* or *Refer to QRH/ABN-19 ENG DUAL FAILURE - NO FUEL REMAINING - FORCED LANDING*

ATC.....NOTIFY  
ATC XPDR 7700..... CONSIDER

PREPARE CABIN AND COCKPIT

*Notify the cabin crew of the nature of the emergency and state intentions.*

*Specify the available time:*

- *Loose equipment secured.*
- *Survival equipment prepared.*
- *Belts and shoulder harnesses locked.*

GPWS SYS..... OFF  
GPWS TERR..... OFF

*Switching the SYS pb and TERR pb OFF avoids nuisance warnings.*

SIGNS..... ON  
EMER EXIT LT..... ON  
COMMERCIAL..... OFF  
LDG ELEV..... SET

*If not known, select an approximate value.*

BARO..... SET  
DISREGARD NORM C/Ls  
ELT (when conditions permit)..... ON

● **For approach and landing:**

RAM AIR..... ON

*Switch ON the RAM AIR to ensure complete cabin depressurization on ground.*

L/G lever ..... DOWN

SLATS / FLAPS..... MAX AVAIL

GND SPLR..... ARM


MAX BRK PR: 1000 PSI

● **At 2 000 ft AGL:**

CABIN CREW..... NOTIFY FOR LANDING

*Continued on the following page*

**[QRH] FORCED LANDING (Cont'd)**

- **At 500 ft AGL:**  
BRACE FOR IMPACT..... ORDER
  
- **At touchdown:**  
ALL ENG MASTERS..... OFF  
APU MASTER SW..... OFF  
  
BRAKES ON ACCU ONLY
  
- **When aircraft stopped:**  
PARKING BRK..... ON  
ATC (VHF 1)..... USE  
*With both engines and APU shut down, only VHF 1 is supplied.*  
ALL FIRE pb (ENGs & APU)..... PUSH  
ALL AGENTS (ENGs & APU)..... DISCH
  
- **If evacuation required:**  
EVACUATION..... INITIATE  
*Make a short and precise announcement to order the emergency evacuation.*  
*Press the EVAC COMMAND pb .*  
ELT..... CHECK EMITTING  
*If not, switch on the transmitter.*
  
- **If evacuation not required:**  
CABIN CREW AND PASSENGERS (PA)..... NOTIFY

**[QRH] OVERWEIGHT LANDING**

Ident.: PRO-ABN-MISC-00012093.0057001 / 17 MAR 17

Applicable to: ALL

USE CONF FULL FOR LANDING UNLESS SPECIFIED BY ABN PROC OR LIMITED BY LANDING PERF

MAX WEIGHT (1 000 kg) FOR LANDING IN CONF FULL (GO AROUND IN CONF 3 CLIMB GRADIENT 2.1 %)								
OAT (°C)	AIRPORT ELEVATION (feet)							
	0	2 000	4 000	6 000	8 000	10 000	12 000	14 000
<10	85	83	84	81	77	71	66	61
15	85	83	83	81	77	70	64	57
20	85	83	83	81	75	67	61	55
25	85	83	83	79	72	64	58	
30	84	83	81	77	69			
35	84	83	79	73	66			
40	84	81	75	69				
45	82	76	70					
50	78	72						
55								

- If aircraft weight above maximum weight for landing in conf FULL: USE FLAP 3 FOR LANDING

LDG DIST.....CHECK

- For approach:  
 PACK 1.....OFF OR SUPPLIED BY APU  
 PACK 2.....OFF OR SUPPLIED BY APU

*Selecting packs OFF (or supplied from APU) will increase the maximum thrust available from the engines, in the event of a go-around.*

- If landing CONF other than full: USE CONF 1+F FOR GO AROUND

SPEED AT RUNWAY THRESHOLD: VLS

*Reduce the selected speed on the FCU to reach VLS at runway threshold.*

MINIMIZE V/S AT TOUCHDOWN

- At main landing gear touchdown: USE MAX REVERSER
- After nosewheel touchdown: APPLY BRAKES AS NECESSARY

*Continued on the following page*

**[QRH] OVERWEIGHT LANDING (Cont'd)**

*Maximum braking may be used after nosewheel touchdown. But, if landing distance permits, delay or reduce braking to take full benefit of the available runway length.*

● **When landing completed:**

BRAKE FANS  ..... ON

*Be prepared for tire deflation, if temperatures exceed 800 °C.*

**[QRH] SEVERE TURBULENCE**

**Applicable to: ALL**

Ident.: PRO-ABN-MISC-10-00002202.0001001 / 17 MAR 17

Whenever possible, avoid areas with known or forecasted severe turbulence. If turbulence is unavoidable, aim to keep the speed in the region of the target speed given in this section, so as to provide the best protection against the effect of gust on the structural limits, whilst maintaining an adequate margin above VLS.

Sufficient buffet margin exists at optimum altitude. In order to further increase the margin to buffet onset, consider descending to a lower altitude.

Severe turbulence is defined as turbulence that causes large, abrupt changes in altitude and/or attitude. It usually causes large variations in airspeed. Occupants are forced violently against their seat belts and loose objects will move around the aircraft.

If severe turbulence occurs during a flight, the flight crew must make a logbook entry in order to initiate maintenance action.

*Note: Recommendations for severe turbulence are also applicable to extreme turbulence.*

Ident.: PRO-ABN-MISC-10-00002203.0001001 / 22 FEB 17

Before the aircraft enters an area where turbulence is expected:

- All loose equipment must be secured in the cockpit and in the cabin
- The flight crew must set the SEAT BELTS sw to ON.

Ident.: PRO-ABN-MISC-10-00002301.0001001 / 09 DEC 09

Keep the autopilot ON.

When thrust changes become excessive : Disconnect Autothrust.


For approach : Use A/THR for managed speed.

Ident.: PRO-ABN-MISC-10-00002208.0002001 / 22 MAY 12

Set the thrust to give the recommended speed (*Refer to PRO-ABN-MISC [QRH] Thrust Setting (N1) for Recommended Speed*). This thrust setting attempts to obtain, in stabilized conditions, the speed for turbulence penetration given in the graph below.

Only change thrust in case of an extreme variation in airspeed, and do not chase your Mach or airspeed.

A transient increase is preferable to a loss of speed, that decreases buffet margins and is difficult to recover.



Ident.: PRO-ABN-MISC-10-00007380.0009001 / 16 NOV 11

SEVERE TURBULENCE										
SPEED AND THRUST SETTING FOR RECOMMENDED TURBULENCE SPEED										
FL	SPD or Mach	GROSS WEIGHT (1000 kg)								
		44	48	52	56	60	64	68	72	76
N1 %										
390	0.76	80.0	81.0	82.0	83.1	–	–	–	–	–
370	0.76	79.1	79.8	80.7	81.6	82.6	83.6	–	–	–
350	0.76	78.8	79.3	80.0	80.7	81.5	82.4	83.3	84.3	–
330	0.76	78.8	79.3	79.8	80.4	81.0	81.8	82.6	83.4	84.2
310	275	78.1	78.6	79.2	79.8	80.3	80.9	81.5	82.3	83.1
290	275	76.6	77.1	77.6	78.2	78.9	79.6	80.3	81.0	81.7
270	275	75.1	75.6	76.1	76.7	77.3	78.0	78.7	79.6	80.5
250	275	73.5	74.0	74.5	75.1	75.8	76.5	77.2	77.9	78.8
200	275	69.9	70.3	70.7	71.2	71.8	72.4	73.0	73.7	74.4
150	250	61.9	62.6	63.3	64.0	64.9	65.9	66.9	68.0	68.9
100	250	58.3	59.0	59.6	60.2	61.0	61.8	62.6	63.5	64.5
50	250	54.3	54.9	55.6	56.3	57.1	58.0	59.0	60.0	60.8

Ident.: PRO-ABN-MISC-10-00007386.0001001 / 09 JUN 15

If the flight crew flies the aircraft manually:

- The flight crew may expect large variations in altitude, but should not chase altitude.
- The flight crew should consider descending to or below OPT FL, in order to increase the margin to buffet.

Ident.: PRO-ABN-MISC-10-00007388.0002001 / 29 SEP 15

Configuration FULL, or 3, can be used.

CONF FULL provides better handling capability in turbulent conditions, however, CONF 3 provides more energy and less drag.



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

**[QRH] TAILSTRIKE**

Ident.: PRO-ABN-MISC-00012273.0001001 / 17 MAR 17

Applicable to: ALL

**LAND ASAP**

MAX FL: 100 / MEA-MORA

*500 ft/min should be targeted for the climb, to minimize pressure changes, and for passenger and crew comfort. Similarly, the rate of descent must be limited to about 1 000 ft/min, except for the final approach that must be performed normally.*

*Notify the ATC of the aircraft's rate of climb.*

RAM AIR..... ON  
 PACK 1.....OFF  
 PACK 2.....OFF

**[QRH] VOLCANIC ASH ENCOUNTER**

Ident.: PRO-ABN-MISC-00012176.0001001 / 17 MAR 17

Applicable to: ALL

180° TURN.....INITIATE

*The performance of a 180 ° turn will usually enable the aircraft to exit the volcanic ash clouds as quickly as possible, because volcanic ash clouds can extend for hundreds of nautical miles.*

ATC.....NOTIFY

Note: *Electrostatic conditions may cause communication problems.*

A/THR..... OFF

*This prevents the autothrust from generating thrust variations.*

THRUST (IF CONDS PERMIT)..... REDUCE

*Reduced thrust minimizes ash ingestion.*

*If altitude permits, reduce thrust to idle. This maximizes engine surge margin and lowers engine turbine temperature.*

CREW OXY MASKS..... USE / 100 % / EMER

CABIN CREW.....NOTIFY

OXYGEN PASSENGER MASK MAN ON..... AS RQRD

*Depending on contamination.*

ENG ANTI ICE..... ON

WING ANTI ICE..... ON

PACK FLOW..... HI

*Maximum air bleed gives the engines additional stall margin.*

CARGO ISOL VALVES  ..... OFF

Note: *To prevent a cargo smoke warning being triggered*

ENGINE PARAMETERS..... MONITOR

*Monitor particularly EGT . If EGT exceeds limits, it may become necessary to consider a precautionary engine shutdown and engine restart in flight.*

Note: *In the case of precautionary shutdown:*

- *restart when clear of the volcanic ash cloud*
- *Upon restart, the engine may accelerate very slowly. Do not misinterpret this as a failure to start*
- *Consider that the compressor and turbine blades have been eroded and avoid sudden changes in thrust. Fuel flow and EGT may increase.*

*Continued on the following page*



**[QRH] VOLCANIC ASH ENCOUNTER (Cont'd)**

AIRSPPEED INDICATIONS.....MONITOR

*If airspeed is unreliable or lost, Refer to PRO-ABN-NAV UNRELIABLE SPEED INDICATION - Memory Items.*

Note: *If both engines flame out and speed indications are lost, Refer to DUAL ENGINE FAILURE procedure to get the required pitch attitude for the optimum relight speed. In case of engine failure, switch off the wing anti ice before engine restart.*

● **If visibility not sufficient for approach due to windshield damage:**

CONSIDER AUTOLAND

● **For approach, if AUTOLAND is not available:**

CAB PRESS MODE SEL.....MAN

MAN V/S CTL.....FULL UP

*Due to the increased noise level, pay particular attention to visual warnings.*

MAX SPEED: 200 kt

PF SLIDING WINDOW..... OPEN



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

MISC

Intentionally left blank

**[MEM] UNRELIABLE SPEED INDICATION**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AM-00017720.0002001 / 17 MAR 17

● **If the safe conduct of the flight is impacted:**

AP..... OFF  
 A/THR..... OFF  
 FD..... OFF

**PITCH/THRUST:**

Below THRUST RED ALT..... 15° / TOGA  
 Above THRUST RED ALT and Below FL 100..... 10° / CLB  
 Above THRUST RED ALT and Above FL 100..... 5° / CLB  
 FLAPS (if CONF 0(1)(2)(3))..... MAINTAIN CURRENT CONF  
 FLAPS (if CONF FULL)..... SELECT CONF 3 AND MAINTAIN  
 SPEEDBRAKES..... CHECK RETRACTED  
 L/G..... UP

When at, or above MSA or Circuit Altitude: Level off for troubleshooting.

*Continued on the following page*

**[MEM] UNRELIABLE SPEED INDICATION (Cont'd)**

Ident.: PRO-ABN-NAV-AM-00017722.0008001 / 17 MAR 17

- **To level off:**
- AP..... OFF
- A/THR..... OFF
- FD..... OFF
- SPEEDBRAKES..... CHECK RETRACTED
- PITCH/THRUST TABLE..... APPLY

**PITCH / THRUST FOR LEVEL OFF**

		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
<b>SLATS / FLAPS EXTENDED</b>				
CONF	PITCH	THRUST % N1 (Resultant speed)		
3	7°	64% (155 kt)	60% (140 kt)	56% (130 kt)
2	5.5°	62% (170 kt)	58% (160 kt)	54% (145 kt)
1+F	5°	62% (190 kt)	58% (175 kt)	54% (160 kt)
1	6.5°	62% (205 kt)	58% (190 kt)	54% (170 kt)
<b>CLEAN</b>				
PITCH	FL	THRUST % N1 (Resultant speed)		
4°	100	62% (245 kt)	60% (225 kt)	54% (205 kt)
at or below FL250	200	70% (245 kt)	66% (225 kt)	62% (205 kt)
3°	300	80% (265 kt)	76% (245 kt)	72% (225 kt)
above	350	84% (255 kt)	80% (240 kt)	76% (220 kt)
FL250	400	/	86% (235 kt)	80% (220 kt)

**FLYING TECHNIQUE TO STABILIZE SPEED**

Stabilize the altitude. When altitude is stabilized:

- If the pitch is above the target pitch, increase the thrust and maintain the altitude.
- If the pitch is below the target pitch, decrease the thrust and maintain the altitude.

When the pitch reaches the target pitch, adjust the thrust to keep this target pitch.

*Continued on the following page*

**[MEM] UNRELIABLE SPEED INDICATION (Cont'd)**

Ident.: PRO-ABN-NAV-AM-00017724.0002001 / 17 MAR 17

● **When flight path is stabilized:**

AP.....OFF  
 A/THR.....OFF  
 FD.....OFF  
 SPEEDBRAKES.....CHECK RETRACTED  
 FLIGHT PATH.....KEEP STABILIZED

RESPECT STALL WARNING

Ident.: PRO-ABN-NAV-AM-00017725.0003001 / 20 MAR 17

**AFFECTED ADR IDENTIFICATION**

PROBE/WINDOW HEAT.....ON  
 ALL SPEED INDICATIONS.....CROSSCHECK  
*ADR 3 and STBY speeds use the data of the same probe.*

■ **If at least one ADR confirmed reliable:**

RELIABLE AIR DATA.....USE  
 UNRELIABLE ADR pb(s).....OFF

■ **If affected ADR(s) cannot be identified, or all ADRs affected:**

● **When above FL 250:**

KEEP ONE ADR ON  
 TWO ADR pbs.....OFF  
*This prevents the flight control laws from using two coherent but unreliable ADR data.*

● **For flight continuation: USE PITCH/THRUST TABLES**

● **When below FL 250, if speed still unreliable:**

ALL ADR pbs.....OFF  
*All ADR s must be switched OFF to replace the PFD 's normal speed scale and altitude indication by the BUSS and GPS altitude indication.*  
 SPEED.....FLY THE GREEN

*Note: If the BUSS does not react to longitudinal stick input when flying the green area of the speed scale, the flight crew must disregard the BUSS and use pitch/thrust tables.*

NAV ADR 1+2+3 FAULT Procedure.....APPLY

*Continued on the following page*

**[MEM] UNRELIABLE SPEED INDICATION (Cont'd)**

Ident.: PRO-ABN-NAV-AM-00017726.0008001 / 17 MAR 17

**CLIMB**

**CLIMB IN CLEAN CONFIGURATION**

		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
THRUST	FL	PITCH (Resultant speed)		
<b>CLB</b>	<b>50</b>	11° (235 kt)	13° (215 kt)	16° (195 kt)
	<b>100</b>	10° (235 kt)	12° (215 kt)	14° (195 kt)
	<b>200</b>	7° (235 kt)	8° (220 kt)	10° (195 kt)
	<b>300</b>	5° (235 kt)	6° (220 kt)	7° (200 kt)
	<b>400</b>	/	4° (215 kt)	5° (195 kt)

**CRUISE**

**FLYING TECHNIQUE TO STABILIZE SPEED**

Stabilize the altitude. When altitude is stabilized:

- If the pitch is above the target pitch, increase the thrust and maintain the altitude.
- If the pitch is below the target pitch, decrease the thrust and maintain the altitude.

When the pitch reaches the target pitch, adjust the thrust to keep this target pitch.

**LEVEL FLIGHT IN CLEAN CONFIGURATION**

		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
PITCH	FL	THRUST % N1 (Resultant speed)		
<b>4° at or below FL250</b>	<b>100</b>	62% (245 kt)	60% (225 kt)	54% (205 kt)
	<b>200</b>	70% (245 kt)	66% (225 kt)	62% (205 kt)
<b>3° above FL250</b>	<b>300</b>	80% (265 kt)	76% (245 kt)	72% (225 kt)
	<b>350</b>	84% (255 kt)	80% (240 kt)	76% (220 kt)
	<b>400</b>	/	86% (235 kt)	80% (220 kt)

*Note: If the failure is due to radome destruction, the drag will increase and therefore N1 must be increased by 5 %. Fuel flow will increase by about 27 %.*

**DESCENT**

**DESCENT IN CLEAN CONFIGURATION**

		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
THRUST	PITCH	Resultant speed		
<b>IDLE</b>	<b>1°</b>	245 kt	230 kt	210 kt

*Continued on the following page*

**[MEM] UNRELIABLE SPEED INDICATION (Cont'd)**

**INITIAL / INTERMEDIATE APPROACH**

APPLY FLYING TECHNIQUE TO STABILIZE SPEED

LEVEL FLIGHT				
		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
WITH LANDING GEAR UP				
CONF	PITCH	THRUST % N1 (Resultant speed)		
0	5.5°	58% (225 kt)	54% (205 kt)	50% (185 kt)
1	6.5°	62% (205 kt)	58% (190 kt)	54% (170 kt)
1+F	5°	62% (190 kt)	58% (175 kt)	54% (160 kt)
2	5.5°	62% (170 kt)	58% (160 kt)	54% (145 kt)
WITH LANDING GEAR DOWN				
3	7°	70% (155 kt)	64% (140 kt)	60% (130 kt)

**FINAL APPROACH AT -3° DESCENT FLIGHT PATH**

APPROACH IN CONF 3 AND L/G EXTENDED				
		70 t 155 000 lb	60 t 130 000 lb	50 t 110 000 lb
CONF	PITCH	THRUST (% N1)		
3	4°	54%	50%	46%

**[QRH] ADR CHECK PROC**

Ident.: PRO-ABN-NAV-00015311.0001001 / 17 MAR 17

Applicable to: ALL

For the ADR CHECK procedure, apply the UNRELIABLE SPEED INDICATION procedure. Refer to PRO-ABN-NAV UNRELIABLE SPEED INDICATION - Memory Items.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

NAV

**[QRH] ALL ADR OFF**

Applicable to: ALL

Ident.: PRO-ABN-NAV-Y-00012464.0026001 / 20 MAR 17

Apply this QRH procedure when requested by the **NAV ADR 1+2+3 FAULT** ECAM alert.

SPEED.....FLY THE GREEN

*Fly within the green area of the speed scale to ensure safe flight.*

*For slats/flaps retraction, it is better to fly at the top of the green area of the speed scale.*

Note: *If the BUSS does not react to longitudinal stick input when flying the green area of the speed scale, the flight crew must disregard the BUSS and use pitch/thrust tables.*

WHEN ALL ADR OFF BOTH FMS LOST

BACK UP NAV.....USE

*Revert to Back Up Nav via the NAV B/UP prompt on the MCDU MENU page.*

USE RMP FOR NAVAID TUNING

PFD ALTITUDE: GPS

TCAS & ATC ALT RPTG INOP

CABIN PRESS MODE SEL.....MAN

MAN V/S CTL.....AS QRDR

Target CAB PRESS V/S:

- Climb: 500 ft/min
- Descent: 300 ft/min

AIRCRAFT CRZ FL	CAB ALT TARGET (ft)
410	8000
350	7000
300	5500
250	3000
<200	0

● **For approach:**

SPEED.....FLY THE GREEN

*Before extending the slats/flaps, it is better to fly at the bottom of the speed scale green area, and to be in straight flight.*

FOR LANDING: USE FLAP 3

GPWS LDG FLAP 3.....ON

LDG DIST PROC.....APPLY

*Continued on the following page*



**[QRH] ALL ADR OFF (Cont'd)**

APPR SPEED: BUSS TARGET SPEED

*During approach, BUSS TARGET SPEED (green triangle) indicates VAPP.*

● **When flap 2:**

LDG GEAR GRVTY EXTN handcrank.....PULL AND TURN

● **When landing gear downlocked:**

L/G lever.....DOWN

GEAR DOWN indications.....CHECK

L/G DOORS REMAIN OPEN

● **During final approach:**

MAN V/S CTL.....FULL UP

● **Before door opening: CHECK ΔP ZERO**

Ident.: PRO-ABN-NAV-Y-00017139.0001001 / 21 MAR 17

**STATUS**

**INOP SYS**

*Refer to PRO-ABN-NAV  
 NAV ADR 1+2+3 FAULT -  
 FWSPAGE.*

**Other INOP SYS**

RAT automatic extension  
 ATC ALTI MODE  
 TCAS  
 L/G RETRACT



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

NAV

**[QRH] IR ALIGNMENT IN ATT MODE**

Ident.: PRO-ABN-NAV-00012425.0006001 / 17 MAR 17

Applicable to: **ALL**

If IR alignment is lost, the navigation mode is inoperative (red ATT flag on PFD and red HDG flag on ND).

Aircraft attitude and heading may be recovered by applying the following procedure:

- IR MODE sel (affected IR)..... ATT
- KEEP SPEED, HEADING, AND FL CONSTANT FOR 30 s
- FMS DATA page..... SELECT
- The DATA INDEX page is displayed*
- IRS MONITOR key..... PRESS
- [SET HDG key] A/C HDG..... ENTER
- CROSSCHECK HEADING REGULARLY WITH STBY COMPASS AND UPDATE AS REQUIRED

**NAV ADR 1(2)(3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-A-00018111.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the ADR 1(2)(3) is failed.

Flight Phase Inhibition:



**Note:** (a) Not inhibited in flight phase 3 in the case of **NAV ADR 3 FAULT** while the ADR 3 is in use.

Not inhibited in flight phases 3, 5, and 7 in the case of **NAV ADR 1(2) FAULT**.

Continued on the following page

**NAV ADR 1(2)(3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-A-00017302.0003001 / 21 MAR 16

**Note:** In case of simultaneous failure of ADR and IR (same ADIRU), apply ADR FAULT procedure before IR FAULT procedure.

**ADR 1 FAULT:**  
 AIR DATA SWTG.....CAPT 3

Select ADR 3 to captain side.  
 For aircraft equipped with EGPWS  $\triangleleft$ , T2CAS  $\triangleleft$  or T3CAS  $\triangleleft$ , the GPWS TERR FAULT light comes on, because the predictive functions of the GPWS are inhibited. As such, the GPWS TERR pb-sw should be switched OFF.

ADR 1 P/B..... OFF

**ADR 2 FAULT:**  
 AIR DATA SWTG..... F/O 3

Select ADR 3 to first officer side.

ADR 2 P/B..... OFF  
 BARO REF..... CHECK

If ADR 2 fails, both baro reference channels are driven by the same FCU channel. Consequently the baro reference displays must be checked.

**ADR 3 FAULT:**  
 ADR 3 P/B..... OFF  
 AIR DATA SWTG (IF ADR 3 IN USE)..... NORM

Ident.: PRO-ABN-NAV-A-00017505.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAT 3 SINGLE ONLY

ADR 1(2)(3)  
 CAT 3 DUAL  
 GPWS<sup>(1)</sup>

<sup>(1)</sup> (in case of ADR 1 FAULT only)

**NAV ADR 1+2(1+3)(2+3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-B-00018113.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when two ADRs are failed.

Flight Phase Inhibition:



*Continued on the following page*

**NAV ADR 1+2(1+3)(2+3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-B-00017147.0003001 / 22 MAR 17




**L2** Flight control normal laws are lost. Pitch alternate law preserves the neutral static stability. All protections, except maneuver protections are lost.

Note: In case of a simultaneous ADR and IR (same ADIRU ) failure, apply the ADR FAULT procedure prior to the IR FAULT procedure.

**L1** ● **ADR 1+2 FAULT:**  
AIR DATA SWTG.....CAPT 3

**L2** Set ADR 3 pb-sw (if available) to the captain's side.

**L1** ADR (AFFECTED) P/B.....OFF

**L2** As the enhanced functions of the EGPWS  or the predictive functions of the GPWS (for aircraft equipped with T2CAS  or T3CAS ) are inhibited, the GPWS TERR FAULT light comes on. As such, the GPWS TERR pb-sw should be switched OFF.

**L1** \_\_\_\_\_ **ASSOCIATED PROCEDURES** \_\_\_\_\_

**F/CTL ALTN LAW**  
**(PROT LOST)**

MAX SPEED..... 320 KT

**L2** Speed is limited, due to the loss of high-speed protections.

**L1** ● **ADR 1+3 (or 2+3) FAULT:**

**L2** Air data information is lost on one PFD.

Note: In case of an ADR 1+3 FAULT, the landing gear safety valve is controlled closed:




- Landing gear retraction is inoperative
- Landing gear extension must be performed by gravity.

**L1** AIR DATA SWTG.....NORM

ATC/XPDR (IF ADR 1 FAILED).....SYS 2

ATC/XPDR (IF ADR 2 FAILED).....SYS 1

ADR (AFFECTED) P/B.....OFF

**L2** As the enhanced functions of the EGPWS  or the predictive functions of the GPWS (for aircraft equipped with T2CAS  or T3CAS ) are inhibited, the GPWS TERR FAULT light comes on in case of an ADR 1+3 FAULT. As such, the GPWS TERR pb-sw should be switched OFF.

*Continued on the following page*

**NAV ADR 1+2(1+3)(2+3) FAULT (Cont'd)**

L1

————— **ASSOCIATED PROCEDURES** —————

**F/CTL ALTN LAW**

(PROT LOST)

**MAX SPEED**..... 320 KT

L2

*Speed is limited, due to the loss of high-speed protections.*

*Continued on the following page*

**NAV ADR 1+2(1+3)(2+3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-B-00017397.0009001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF3 is selected, as a reminder.*

GPWS LDG FLAP 3..... ON

*Appears when CONF 3 is selected.*

● **If ADR 1+3 FAULT:**

L/G..... GRVTY EXTN

*Refer to PRO-ABN-LG [QRH] L/G GRAVITY EXTENSION*

APPR SPD..... VREF + 10 KT

LDG DIST PROC..... APPLY

ALTN LAW : PROT LOST




WHEN L/G DN : DIRECT LAW

*At L/G extension, control reverts to direct law in pitch and roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).*

FLS  LIMITED TO F-APP + RAW

● **If ADR 1 + 3 (or 2 + 3) FAULT:**

**BOTH PFD ON THE SAME FAC**

*As the enhanced functions of the EGPWS  or the predictive functions of the GPWS (for aircraft equipped with T2CAS  or T3CAS  ) are inhibited, the GPWS TERR FAULT light comes on in case of an ADR 1+3 FAULT. As such, the GPWS TERR pb-sw should be switched OFF.*

**INOP SYS**

F/CTL PROT

ADR 1 + 2 or (2 + 3) or (1 + 3)

AP 1 + 2

A/THR

ATC/XPDR 1 <sup>(1)</sup>

ATC/XPDR 2 <sup>(2)</sup>

RUD TRV LIM 1 <sup>(2)</sup> <sup>(3)</sup>

GPWS (if ADR 1 fault)

CAT 2

GLS AUTOLAND 

STEEP APPR 

ROW/ROP 

<sup>(1)</sup> (ATC/XPDR 1 in the case of ADR 1 failure)

<sup>(2)</sup> (ATC/XPDR 2 in the case of ADR 2 failure)

*Continued on the following page*



**NAV ADR 1+2(1+3)(2+3) FAULT (Cont'd)**

<sup>(3)</sup> (in the case of an ADR 1 + 3 FAULT or in the case of an ADR 2 + 3 FAULT)

**NAV ADR 1+2+3 FAULT**

Applicable to: ALL

Ident.: PRO-ABN-NAV-X-00018114.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the three ADRs are failed.

Flight Phase Inhibition:



Continued on the following page

**NAV ADR 1+2+3 FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-X-00017497.0003001 / 20 MAR 17

[L2] This procedure requires to turn off the three ADR s, and to use the Back Up Speed Scale (BUSS ) and GPS altitude.

Note: In case of a simultaneous ADR and IR (same ADIRU ) failure, apply the ADR FAULT procedure prior to the IR FAULT procedure.

- [L1] AP+FD..... OFF
- A/THR..... OFF
- PROBE/WINDOW HEAT..... ON
- ADR 1+2+3 P/B..... OFF

[L2] Note: The STALL WARNING is not lost.

- [L1] SPD..... FLY THE GREEN

[L2] Fly the green area of the speed scale to ensure safe flight.

[L1] Note: If the BUSS does not react to longitudinal stick input when flying the green area of the speed scale, the flight crew must disregard the BUSS and use pitch/thrust table.

- STBY INST.....MAY BE UNREL

[L2] Depending on the source of the ADR 3 pb-sw FAULT, the standby instruments' indication may be unreliable. Therefore, standby instrument must be used with care.

- [L1] ALL ADR OFF PROC.....APPLY

[L2] Refer to PRO-ABN-NAV [QRH] ALL ADR OFF.

[L1]

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**  
**MANEUVER WITH CARE**

[L2] Note: The rudder travel limiter is frozen at the value it had at the moment when the failure occurred, and may not be in correct position for the flight speed. At slats extension, full rudder travel authority is recovered.

- [L1] SPD BRK..... DO NOT USE

Continued on the following page

**NAV ADR 1+2+3 FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-X-00016858.0002001 / 22 MAR 17

**STATUS**

MANEUVER WITH CARE

SPD BRK.....DO NOT USE

STBY INST..... MAY BE UNREL

**APPR PROC**

FOR LDG..... USE FLAP 3

LDG.....GRVTY EXTN

ALTN LAW: PROT LOST  
 WHEN L/G DN: DIRECT LAW

**INOP SYS**

REAC W/S DET

PRED W/S DET 

F/CTL PROT

ADR 1+2+3

STEEP APPR 

RUD TRV LIM

YAW DAMPER

AP 1+2

A/THR

CAB PR 1+2

GPWS

GPWS TERR 

ATC/XPDR 1

ATC/XPDR 2

ROW/ROP 

**NAV ADR DISAGREE**

Applicable to: ALL

Ident.: PRO-ABN-NAV-U-00018110.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the following conditions occur:

- The ELAC rejected an ADR , or an ADR is faulty
- The speed or the Angle Of Attack (AOA ) from the two remaining ADRs are different.

Flight Phase Inhibition:



*Continued on the following page*

**NAV ADR DISAGREE (Cont'd)**

Ident.: PRO-ABN-NAV-U-00017130.0002001 / 22 MAR 17

**L2** The alternate law activates, and protections are lost.

**L1** AIR SPD..... X CHECK

**■ IF SPD DISAGREE:**

ADR CHECK PROC.....APPLY

**L2**

To determine the faulty ADR, *Refer to PRO-ABN-NAV UNRELIABLE SPEED INDICATION - Memory Items.*

**L1**

**■ IF NO SPD DISAGREE:**

AOA DISCREPANCY

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**

**(PROT LOST)**

MAX SPEED.....320 KT

*Continued on the following page*

**NAV ADR DISAGREE (Cont'd)**

Ident.: PRO-ABN-NAV-U-00017131.0001001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT

**APPR PROC**

FOR LDG..... USE FLAP 3

*Do not select CONF FULL, so as not to degrade handling qualities.*

GPWS LDG FLAP 3..... ON

*Displayed, when CONF 3 is selected.*

APPR SPD..... VREF +10

LDG DIST PROC..... APPLY

- **IF NO SPD DISAGREE:**  
RISK OF UNDUE STALL WARN

ALTN LAW: PROT LOST  
WHEN L/G DN: DIRECT LAW

See <sup>(1)</sup>

**INOP SYS**

F/CTL PROT  
STEEP APPR 

<sup>(1)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).

**NAV ALTI DISCREPANCY**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AO-000181116.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when the difference between the altitude displayed on the CAPT and F/O PFDs is greater than:

- 500 ft, if STD BARO reference is selected
- 250 ft, if QNH or QFE BARO reference is selected.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AO-00012411.0002001 / 09 APR 14

ALT..... X CHECK

L2 Crosscheck with the standby altimeter.

L1 AIR DATA SWTG..... AS RQRD

L2 Select ADR 3 to the faulty side.

**NAV CAPT(F/O)(STBY) AOA FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-V-00018124.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the CAPT (F/O )(STBY ) Angle Of Attack (AOA) sensor is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-V-00012458.0003001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-NAV-V-00012459.0003001 / 19 JUN 12

**STATUS**

**INOP SYS**

CAPT (F/O) (STBY)  
 AOA



**NAV ATC/XPDR 1(2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-NAV-Z-00018119.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the related transponder fails.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-Z-00013539.0001001 / 18 JAN 17

ATC/XPDR.....SYS 2(1)

Note: In case of flight in RVSM airspace, select AP1 if SYS1 is used and AP2 if SYS2 is used.

Ident.: PRO-ABN-NAV-Z-00013541.0001001 / 17 MAR 11

**STATUS**

**INOP SYS**

ATC/XPDR 1(2)

**NAV ATC/XPDR 1+2 FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AA-00018120.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both transponders fail.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AA-00013542.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-NAV-AA-00013543.0001001 / 17 MAR 11

**STATUS**

**INOP SYS**

TCAS  
 ATC/XPDR 1  
 ATC/XPDR 2

**NAV ATC/XPDR STBY**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AP-00018121.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the flight crew sets the ATC transponder on STBY in flight.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AP-00013545.0001001 / 25 FEB 14

Crew awareness.

**NAV ATT DISCREPANCY**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AQ-00018122.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the difference between the roll or pitch angle displayed on the CAPT and F/O PFDs is greater than 5 °.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AQ-00012410.0001001 / 19 AUG 10

ATT.....X CHECK

- L2 Crosscheck with standby horizon.

L1 ATT HDG SWTG.....AS RQRD

- L2 Select IR 3 (if available) to faulty side.

**NAV BARO REF DISCREPANCY**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AR-00018123.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the BARO reference is not the same on CAPT and F/O sides.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AR-00012413.0001001 / 16 NOV 11

BARO REF..... X CHECK

L2

Crosscheck the barometric reference selection, captain side versus first officer side.

**NAV FM/GPS POS DISAGREE** ⚠

Applicable to: ALL


Ident.: PRO-ABN-NAV-AG-00017090.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the FM and GPS positions disagree.

Flight Phase Inhibition:



Note: (a) Alert inhibited only for the first 15 s in flight phase 5.

*Continued on the following page*

**NAV FM/GPS POS DISAGREE  (Cont'd)**

Ident.: PRO-ABN-NAV-AG-00017148.0003001 / 17 MAR 17

A/C POS.....CHECK

The following procedure is not displayed on the ECAM:

■ **During climb, cruise, or descent:**

Check accuracy on the MCDU PROG page:

■ **If ESTIMATED ACCUR below REQUIRED ACCUR:**

CONSIDER NAV MODE AND ND ARC/ROSE NAV

■ **If ESTIMATED ACCUR above REQUIRED ACCUR:**

HDG/TRK MODE.....SELECT

USE RAW DATA

When possible, compare the positions of both FMs with the GPIRS position, on the MCDU POSITION MONITOR page:


■ **If one FM position agrees with inside GPIRS position:**

USE ASSOCIATED AP/FD

■ **If both FM positions DO NOT agree with inside GPIRS position:**

GPS..... Deselect

USE RAW DATA

■ **During ILS/MLS  /LOC approach:**

NAV MODE: DO NOT USE

CONTINUE APPROACH

■ **During LOC only approach with FLS  :**

NAV MODE: DO NOT USE

DISREGARD F-G/S DEVIATION

REVERT TO VERTICAL SELECTED MODE

■ **During RNAV GNSS, RNAV RNP, or GLS approach:**

- **If visual references not sufficient:** GO AROUND

■ **During VOR, VOR-DME, NDB, or NDB-DME approach:**

HDG/TRK MODE..... SELECT

USE RAW DATA

*Continued on the following page*

**NAV FM/GPS POS DISAGREE ⚠ (Cont'd)**

- If FLS ⚠ used:

LS pb.....PRESS

FLS deviations are removed from PFD.

**NAV GPS 1(2) FAULT ⚠**

Applicable to: ALL


Ident.: PRO-ABN-NAV-L-00018144.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the GPS 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-L-00017127.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-NAV-L-00017128.0001001 / 21 MAR 16

**STATUS**

- If both GPS FAULT

FLS ⚠ LIMITED TO F-APP + RAW

**INOP SYS**

GPS 1(2)



**NAV GPWS FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-N-00018129.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alerts triggers when the GPWS fails.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-N-00012443.0001001 / 16 NOV 11

GPWS.....OFF

**L2** This line remains displayed, even after the GPWS pb-sw has been switched OFF.

Ident.: PRO-ABN-NAV-N-00012444.0001001 / 19 AUG 10

**STATUS**

**INOP SYS**

GPWS




**NAV GPWS TERR DET FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AS-00018130.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2 This alert triggers when the enhanced TCF and TAD modes of the EGPWS  or the predictive function of the GPWS (for aircraft equipped with T2CAS  or T3CAS ) are inoperative.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AS-00017542.0001001 / 21 MAR 16

**GPWS TERR.....OFF**

- L2 The basic GPWS mode 1 to mode 5 are still operative if SYS pb-sw lights FAULT or OFF are not illuminated.

Ident.: PRO-ABN-NAV-AS-00019752.0001001 / 01 JUN 16

**STATUS**

**INOP SYS**

GPWS TERR  
 ROW/ROP 

**NAV HDG DISCREPANCY**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AT-00018131.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the difference between the headings on the CAPT and F/O displays (PFD and ND) is greater than 5 °.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AT-00012409.0003001 / 19 AUG 10

HDG.....X CHECK

L2 Compare the 3 IR headings on MCDU or crosscheck with standby compass.

L1 ATT HDG SWTG.....AS RQRD

L2 Select IR 3 (if available) to faulty side.

**NAV IAS DISCREPANCY**

Applicable to: ALL


Ident.: PRO-ABN-NAV-W-00018146.0003001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the speed displayed on the CAPT and F/O PFDs are different.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-W-00017528.0001001 / 21 MAR 16

AIR SPD.....X CHECK  
 AIR DATA SWTG.....AS RQRD

Ident.: PRO-ABN-NAV-W-00017525.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

CAT 3 SINGLE ONLY

CAT 3 DUAL

**NAV ILS 1(2)(1+2) FAULT**

Applicable to: ALL

Ident.: PRO-ABN-NAV-M-00018138.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the ILS 1(2)(1+2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-M-00017125.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-NAV-M-00017126.0002001 / 21 MAR 16

**STATUS**

**INOP SYS**

- ILS 1(2)(1+2)
- CAT 2 <sup>(1)</sup>
- GPWS <sup>(2)</sup>

<sup>(1)</sup> (If ILS 1 FAULT or if ILS 2 FAULT)

<sup>(2)</sup> (if ILS 1 FAULT on ground or if ILS 1+2 FAULT)

**NAV IR 1(2)(3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-D-00018140.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the IR 1(2)(3) is failed.

Flight Phase Inhibition:



Note: (a) Alert not inhibited in flight phase 3 in the case of **NAV IR 3 FAULT** while the ADR 3 is in use.

Alert not inhibited in flight phase 3 in the case of **NAV IR 1(2) FAULT**.

*Continued on the following page*

**NAV IR 1(2)(3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-D-00017521.0003001 / 21 MAR 16

**L2** Note: In case of a simultaneous ADR and IR (same ADIRU ) failure, apply the ADR FAULT procedure before the IR FAULT procedure.

- L1** ■ **IR 1 FAULT:**  
 ATT HDG SWTG..... CAPT 3  
 ATC/XPDR..... SYS 2
- **IR 2 FAULT:**  
 ATT HDG SWTG..... F/O 3  
 ATC/XPDR..... SYS 1
- **IR 3 FAULT:**  
 ATT HDG SWTG (IF IR 3 IN USE)..... NORM

**L2** This line is not displayed on the ECAM.

Ident.: PRO-ABN-NAV-D-00017123.0001001 / 21 MAR 16

**L12**

**STATUS**

**INOP SYS**

**IR MAY BE AVAIL IN ATT**

Refer to PRO-ABN-NAV [QRH] IR ALIGNMENT IN ATT MODE

**CAT 3 SINGLE ONLY**

IR 1(2)(3)  
 cat 3 DUAL  
 GPWS TERR <img alt="GPWS TERR icon" data-bbox="835 605 855 625"/> (1)  
 TCAS (1)  
 ATC/XPDR 1 (1)  
 ATC/XPDR 2 (2)  
 See (3)

(1) (In case of an IR 1 fault)

(2) (In case of an IR 2 fault )

(3) Note: In Case of an IR 1 fault, the TCAS may be inoperative (depending on the TCAS manufacturer). If the IR 1 is available in ATT mode, the TCAS can be recovered by entering the aircraft magnetic heading into the CDU , as per the IR ALIGNMENT IN ATT MODE procedure.

**NAV IR 1+2(1+3)(2+3) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-E-00018139.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when IR 1+2(1+3)(2+3) are failed.

Flight Phase Inhibition:



*Continued on the following page*



**NAV IR 1+2(1+3)(2+3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-E-00017111.0002001 / 22 MAR 17

**L2** Note: In case of a simultaneous ADR and IR (same ADIRU ) failure, apply the ADR FAULT procedure prior to the IR FAULT procedure.

**L1** ● **If IR 1 + 2 FAULT:**  
ATT HDG SWTG..... CAPT 3

**L2** Set IR 3 (If available) to the Captain's side.  
Attitude information is lost on first officer's PFD.

**L1** ● **If IR 1 + 3 (or 2 + 3) FAULT:**  
ATT HDG SWTG..... NORM

**L2** Attitude information is lost on one side (Captain or first officer).

**L1**

**ASSOCIATED PROCEDURES**

**F/CTL ALTN LAW**  
**(PROT LOST)**

**L2** Flight control normal laws are lost. Pitch alternate law with static stability becomes active.  
All protections, except maneuver protections, are lost.

**L1** MAX SPEED..... 320 KT

**L2** Speed is limited, due to the loss of high speed protection.

Continued on the following page

**NAV IR 1+2(1+3)(2+3) FAULT (Cont'd)**

Ident.: PRO-ABN-NAV-E-00016864.0004001 / 22 MAR 17

L12 **STATUS**

MAX SPEED..... 320 KT

**APPR PROC**

FOR LDG..... USE FLAP 3

*This line is replaced by "FOR LDG : USE FLAP 3" when CONF 3 is selected, as a reminder.*

GPWS LDG FLAP 3.....ON

*Will appear, when CONF 3 is selected.*

APPR SPD : VREF + 10 KT

LDG DIST PROC..... APPLY

ALTN LAW : PROT LOST

WHEN L/G DN : DIRECT LAW

*At landing gear extension, control reverts to direct law, in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).*

IR (AFFECTED) MAY BE AVAIL IN ATT

*Refer to PRO-ABN-NAV [QRH] IR ALIGNMENT IN ATT MODE*

FLS  LIMITED TO F-APP + RAW

**INOP SYS**

F/CTL PROT

IR 1 (2)(3)

IR 1+2 or 1+3 or 2+3

AP 1+2

A/THR

YAW DAMPER 1 <sup>(1)</sup>

YAW DAMPER 2 <sup>(2)</sup>

GPWS TERR  (if IR 1 fault)

TCAS

CAT 2

ATC/XPDR 1 <sup>(3)</sup>

ATC/XPDR 2 <sup>(4)</sup>

GLS AUTOLAND 

STEEP APPR  (if at least 2

IRs are lost)

ROW/ROP 

**Note:** *In case of an IR 1 fault, the TCAS may be inoperative (depending on the TCAS manufacturer). If the IR 1 is available in ATT mode, the TCAS can be recovered by entering the aircraft magnetic heading into the CDU , as per IR ALIGNMENT IN ATT MODE procedure.*

<sup>(1)</sup> (In case of an IR 1+3 fault)

<sup>(2)</sup> (In case of an IR 2+3 fault)

<sup>(3)</sup> (In the case of an IR 1 or IR 1+2 or IR 1+3 failure)

<sup>(4)</sup> (In the case of an IR 2 or IR 1+2 or IR 2+3 failure)

**NAV IR DISAGREE**

Applicable to: ALL

Ident.: PRO-ABN-NAV-G-00018147.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when one IR is failed, and the information received from the two remaining IRs is different.

Flight Phase Inhibition:



*Continued on the following page*

**NAV IR DISAGREE (Cont'd)**

Ident.: PRO-ABN-NAV-G-00016851.0001001 / 22 MAR 17

[L2] Direct law becomes active. All protections (pitch and roll) are lost.  
 [L1] ATT.....X CHECK

[L2] Use the standby horizon to determine the faulty IR.

[L1] ● **IF DISAGREE CONFIRMED:**  
**FAULTY IR..... OFF**

- [L2] - If the ADIRS Control Panel has the IR pb, turn off the faulty IR using the associated IR pb.
- [L2] - If the ADIRS Control Panel does not have the IR pb, set the ADIRS selector to OFF. This action will also switch off the associated ADR.

[L1] ELAC 2.....OFF THEN ON  
 ELAC 1.....OFF THEN ON

[L2] *Note:* When the ELAC 1 computer is reset on ground, the pitch trim returns to the ground setting position (0 °).  
 After corrective action (faulty IR switched off and ELACs reset), pitch alternate law with reduced protections is recovered.

[L1] \_\_\_\_\_ **ASSOCIATED PROCEDURES** \_\_\_\_\_

**F/CTL ALTN LAW**  
**(PROT LOST)**  
**MAX SPEED..... 320 KT**

*Continued on the following page*

**NAV IR DISAGREE (Cont'd)**

Ident.: PRO-ABN-NAV-G-00016852.0001001 / 22 MAR 17

L12

**STATUS**

MAX SPEED..... 320 KT

**APPR PROC**

FOR LDG..... USE FLAP 3

*Do not select CONF FULL, so as not to degrade handling qualities.*

GPWS LDG FLAP 3..... ON

*Will be displayed, when CONF 3 is selected.*

APPR SPD..... VREF + 10

LDG DIST PROC..... APPLY

ALTN LAW: PROT LOST  
WHEN L/G DN: DIRECT LAW

See <sup>(1)</sup>

**INOP SYS**

F/CTL PROT  
STEEP APPR 

<sup>(1)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).

**NAV IR NOT ALIGNED**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AU-00018141.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when there is a problem during IR alignment.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AU-00012570.0001001 / 19 AUG 10

**L2** This caution is available in Phase 2 (after first engine start, until takeoff)

**L1** POSITION DISAGREE

POSITION MISSING

PRESENT POS.....INSERT

EXCESS MOTION

IR 1 (2) (3) (1+2) (2+3) (1+2+3) IN ALIGN

**NAV LS TUNING DISAGREE**

Applicable to: ALL

Ident.: PRO-ABN-NAV-AI-00018151.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the tuning of MMR 1 and MMR 2 are different.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AI-00018932.0004001 / 21 MAR 16

Crew awareness.

L2

When the alert is triggered, the AP /FD:

- Inhibits APPR mode arming, or
- Disarms the APPR mode if already armed, or
- Reverts to basic AP /FD modes if APPR mode already engaged.

Ident.: PRO-ABN-NAV-AI-00014337.0001001 / 29 MAR 12

**STATUS**

**INOP SYS**

CAT 2

**NAV PRED W/S DET FAULT** ⚠

Applicable to: ALL


Ident.: PRO-ABN-NAV-F-00018855.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the predictive function is lost.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-F-00018853.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-NAV-F-00018854.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

PRED W/S DET



**NAV RA 1 AND 2 FAULT**  
 (DUAL RA FAILURE)

Applicable to: ALL


Ident.: PRO-ABN-NAV-J-00018403.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when both RAs are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-J-00012432.0001001 / 25 FEB 14

Crew awareness.

*Continued on the following page*

**NAV RA 1 AND 2 FAULT (Cont'd)**  
**(DUAL RA FAILURE)**

Ident.: PRO-ABN-NAV-J-00016850.0003001 / 01 JUN 16

L12

**STATUS**

**INOP SYS**

**WHEN L/G DN: DIRECT LAW**

See <sup>(1)</sup>

RA 1+2  
A/CALL OUT  
GPWS  
CAT 2  
GLS AUTOLAND   
STEEP APPR   
REAC W/S DET  
TCAS  
ROW/ROP 

<sup>(1)</sup> At landing gear extension, flight controls revert to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).  
ILS APPR mode cannot be engaged, LOC mode is available via the FCU LOC pb.

**NAV RA 1(2) FAULT**

Applicable to: ALL


Ident.: PRO-ABN-NAV-I-00018135.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the RA 1(2) is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-I-00012430.0001001 / 25 FEB 14

Crew awareness.

Ident.: PRO-ABN-NAV-I-00016849.0001001 / 01 JUN 16

**STATUS**

CAT 2 ONLY

**INOP SYS**

- RA 1(2)
- CAT 3
- GPWS (If RA 1 fault)
- ROW/ROP

**NAV RA DEGRADED**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AV-00018134.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the height that RA 1 and RA 2 provide are significantly different.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AV-00018933.0001001 / 21 MAR 16

Crew awareness.

**NAV TCAS FAULT** ⚠

Applicable to: ALL

Ident.: PRO-ABN-NAV-K-00018397.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when there is an internal failure of the TCAS.

Flight Phase Inhibition:



Ident.: TDU / PRO-ABN-NAV-K-00015480.0017001 / 14 FEB 14

Impacted DU: 00012434 NAV TCAS FAULT (If Installed)

Crew awareness.

**Note:** *On ground, if the alert is triggered while the ADIRU s are OFF, or while IR 1 is not yet aligned, the flight crew can disregard it. The alert automatically disappears once the ADIRU s are powered and upon the alignment of IR1.*

Ident.: PRO-ABN-NAV-K-00012434.0001001 / 25 FEB 14

Impacted by TDU: 00015480 NAV TCAS FAULT

Crew awareness.

*Continued on the following page*

**NAV TCAS FAULT** ⚠️ (Cont'd)

Ident.: PRO-ABN-NAV-K-00012435.0001001 / 19 AUG 10

**STATUS**

**INOP SYS**

TCAS

**NAV TCAS STBY**

Applicable to: ALL


Ident.: PRO-ABN-NAV-AW-00018133.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

② This alert triggers when the flight crew sets the TCAS on STBY in flight.

Flight Phase Inhibition:



Ident.: PRO-ABN-NAV-AW-00018847.0001001 / 21 MAR 16

Crew awareness.

**STALL WARNING**

Ident.: PRO-ABN-NAV-00013994.0001001 / 21 MAR 17

**Applicable to: ALL**

When the threshold is reached, a permanent aural warning is triggered "STALL + CRICKET" as long as a correct angle-of-attack is not recovered. (*Refer to PRO-ABN-MISC [MEM] Stall Recovery*).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

NAV

Intentionally left blank



**OVERSPEED**

Applicable to: ALL

Ident.: PRO-ABN-OVERSPEED-AX-00018108.0001001 / 20 APR 17

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The aircraft speed/mach is greater than VMO + 4 kt/MMO + 0.006, or
- The aircraft speed is greater than VLE + 4 kt, with L/G not unlocked or L/G doors not closed, or
- The aircraft speed is greater than VFE + 4 kt, with slats and/or flaps extended.

Flight Phase Inhibition:



Ident.: PRO-ABN-OVERSPEED-AX-00016848.0001001 / 21 MAR 16

VMO/MMO..... 350/.82

L2 (235/0.60 in case of dispatch with landing gear down).

L1 VLE..... 280/.67

VFE.....SEE BELOW

CONF	VFE
FULL	177
3	185
2	200
1+F	215
1	230

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

**OVERSPEED**

Intentionally left blank

**RECORDER DFDR FAULT**

Applicable to: ALL


Ident.: PRO-ABN-RECORDER-A-00017312.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the DFDR is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-RECORDER-A-00010046.0001001 / 10 AUG 10

Crew awareness.

Ident.: PRO-ABN-RECORDER-A-00010047.0001001 / 10 AUG 10

**STATUS**

**INOP SYS**

DFDR

**RECORDER SYS FAULT**

Applicable to: ALL


Ident.: PRO-ABN-RECORDER-B-00017313.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when the FDIU is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-RECORDER-B-00010048.0002001 / 10 AUG 10

Crew awareness.

Ident.: PRO-ABN-RECORDER-B-00010049.0002001 / 10 AUG 10

**STATUS**

**INOP SYS**

RECORDER SYS

**[QRH] SMOKE / FUMES / AVNCS SMOKE**

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-D-00012212.0004001 / 17 MAR 17

This procedure includes all the steps of the AVIONICS SMOKE ECAM procedure.

Apply this procedure when:

- The flight (cabin) crew suspect that smoke is coming from any of the following:
  - The avionics
  - The air conditioning
  - The cabin equipment
- Requested by the AVIONICS SMOKE ECAM procedure.
- There is a smell of smoke / fumes in the cockpit :
  - If the smell is similar to that of orange peels, suspect a toxic leak of rain repellent fluid.
  - If the smell is similar to that of pine needles, suspect a non-toxic leak.

If any other ECAM SMOKE alert triggers (CARGO, ...), the crew must first apply the ECAM procedure, then consider applying this procedure.

Note that these ECAM alerts may be caused by another source, that should usually first be detected by the flight crew/cabin crew/avionics smoke detectors.

The following explains the layout of this procedure:

- The procedure lines above the text boxes indicate the actions that the flight crew must immediately perform, if smoke is detected (with or without ECAM activation and regardless of the smoke source). These immediate actions correspond to the most common steps to be taken in smoke cases. In all cases, the flight crew must also be prepared to immediately perform a diversion. However, this diversion may be avoided if the smoke source is obvious, accessible and extinguishable or confirmed isolated (after completion of the immediate actions).
- The text boxes indicate the actions that the flight crew must consider, if at any time during the remainder of the procedure but always after the initial steps:
  - Smoke / fumes become the greatest threat and removal of smoke / fumes is required, and/or
  - The situation becomes critical and can no longer be controlled.
- The procedure lines below the text boxes indicate the actions that the flight crew must perform, as soon as they suspect a source of smoke. The actions will depend on whether the smoke is coming from the avionics, and/or air conditioning, and/or cabin equipment.

**LAND ASAP**

IF PERCEPTIBLE SMOKE APPLY IMMEDIATELY:

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

If smoke is confirmed, the following procedure must be applied.

OXY MASK / GOGGLE (if required).....USE/100%/EMERG

*Ensure crew communication is established. Avoid continuous use of the interphone to minimize interference from the oxygen mask breathing noise.*

*Turn the emergency knob to remove condensation or smoke from the mask.*

VENTILATION BLOWER..... OVRD

VENTILATION EXTRACT..... OVRD

*Avionics ventilation air is extracted overboard.*

CAB FANS.....OFF

*To prevent smoke from entering the cockpit and cabin.*

GALY & CAB.....OFF

SIGNS.....ON

CKPT / CABIN COM..... ESTABLISH

*Communication must be established with the cabin crew in order to follow up on the smoke origin and dissipation.*

● **If smoke source immediately obvious, accessible, and extinguishable:**

FAULTY EQPT..... ISOLATE

● **If smoke source not immediately isolated:**

DIVERSION..... INITIATE

DESCENT TO FL 100 / MEA -MORA ..... INITIATE

● **At ANY TIME of the procedure, if SMOKE / FUMES becomes the GREATEST THREAT:**

REMOVAL OF SMOKE / FUMES..... CONSIDER

*Refer to PRO-ABN-SMOKE [QRH] REMOVAL OF SMOKE / FUMES*

ELEC EMER CONFIG..... CONSIDER

*Refer to PRO-ABN-SMOKE [QRH] SMOKE / FUMES / AVNCS SMOKE - ELEC EMER CONFIG*

● **At ANY TIME of the procedure, if situation becomes UNMANAGEABLE:**

IMMEDIATE LANDING..... CONSIDER

*Depending on the situation, the Captain can consider an overweight landing, a tailwind landing, a ditching, a forced landing, etc.*

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

<sup>L1</sup> Guidelines to determine smoke source:

- If smoke initially comes out of the ventilation outlets, the crew may suspect AIR COND SMOKE. In addition, very shortly thereafter, several SMOKE warnings (cargo, lavatory, avionics) will be triggered. The displayed ECAM procedures must be applied.
- After an ENG or APU failure, smoke may come from the faulty item via the bleed system and be perceived in the cockpit and/or cabin. In such a case, it will be recirculated throughout the aircraft, until it completely disappears from the air conditioning system.
- If only the AVIONICS SMOKE warning is triggered, the crew may suspect avionics smoke.
- If the smoke is detected while an equipment is declared faulty, the crew may suspect that smoke is coming from this equipment.
- Avionics or forward galley smoke may be smelt, or may enter in the cockpit before ECAM warning activation.

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

Ident.: PRO-ABN-SMOKE-D-00012214.0005001 / 17 MAR 17

● **If Air COND smoke suspected:**

APU BLEED..... OFF  
 VENTILATION BLOWER and EXTRACT..... AUTO

*Note: When both VENTILATION BLOWER and VENTILATION EXTRACT are in the OVRD position, a single pack may not be able to maintain the cabin pressure.*

CARGO FWD ISOL VALVE..... OFF

*To prevent a cargo smoke warning from being triggered due to cabin smoke.*

PACK 1..... OFF

● **If smoke continues:**

PACK 1..... ON  
 PACK 2..... OFF

● **If smoke persists:**

PACK 2..... ON

*Restore normal configuration if PACK 2 is not suspected to cause smoke*

VENTILATION BLOWER..... OVRD

VENTILATION EXTRACT..... OVRD

REMOVAL OF SMOKE / FUMES..... CONSIDER

*Refer to PRO-ABN-SMOKE [QRH] REMOVAL OF SMOKE / FUMES*

● **If CABIN EQPT smoke suspected:**

● **If smoke continues:**

EMER EXIT LIGHT..... ON  
 COMMERCIAL..... OFF  
 SMOKE DISSIPATION..... CHECK  
 FAULTY EQPT..... SEARCH / ISOLATE

*Once the cabin has been secured, try to find the smoke source and isolate it.*

*Cabin lights, reading lights, passenger systems, galleys have dedicated control C/B in the cabin or cockpit.*

● **If smoke persists or if faulty equipment confirmed isolated:**

COMMERCIAL..... NORM

REMOVAL OF SMOKE / FUMES..... CONSIDER

*Refer to PRO-ABN-SMOKE [QRH] REMOVAL OF SMOKE / FUMES*

*Continued on the following page*



**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

Ident.: PRO-ABN-SMOKE-D-00012215.0001001 / 17 MAR 17

- **If smoke source cannot be determined and persists or AVNCS / ELECTRICAL smoke suspected:**  
ELEC EMER CONFIG..... CONSIDER  
*Refer to the end of the procedure to set ELEC EMER CONFIG.*
  
- **If smoke disappears within 5 min:**  
NORMAL VENTILATION..... RESTORE

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

Ident.: PRO-ABN-SMOKE-D-00012565.0019001 / 17 MAR 17

**TO SET ELEC EMER CONFIG**

EMER ELEC GEN 1 LINE..... OFF

*GEN 1 LINE contactor opens. GEN 1 remains running and supplies one fuel pump in each wing tank. AC BUS 1 is supplied by GEN 2 through the bus tie contactor.*

EMER ELEC PWR.....MAN ON

*RAT is extended and the EMER GEN is connected to the aircraft network. Check emergency generator parameters on the ELEC SD page (displayed automatically).*

● **When EMER GEN AVAIL:**

APU GEN..... OFF  
 GEN 2..... OFF

ELEC EMER CONFIG

*Two different procedures can be displayed on the ECAM, depending on whether the AVIONICS SMOKE ECAM caution is triggered or not before the flight crew sets the electrical emergency configuration.*

■ **If AVIONICS SMOKE not triggered:**

APPLY ELEC EMER CONFIG PROCEDURE, BUT DO NOT RESET GEN, EVEN IF REQUESTED BY ECAM

● **At 3 min or 2 000 ft AAL before landing:**

*Restore all generators only 3 min before landing or at 2 000 ft AAL to recover normal braking, while minimizing possible reactivation of a smoke source.*

GEN 2..... ON  
 EMER ELEC GEN 1 LINE..... ON

● **When aircraft stopped:**

ALL GENs..... OFF

■ **If AVIONICS SMOKE triggered:**

The ECAM displays a specific ELEC EMER CONFIG procedure. The flight crew must apply the following ECAM procedure.

MIN RAT SPEED..... 140 KT

Note: *The electrical configuration is the same as for loss of both generators (except that one fuel pump in each wing tank remains supplied).*

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

VHF 1 / HF 1 / ATC 1..... USE

*Only VHF 1, HF 1 and ATC 1 are supplied in this configuration. Notify the ATC of the nature of the emergency, and state intentions. If there is no contact with the ATC, switch to code A7700, or transmit a distress message on one of the emergency frequencies.*

FAC 1..... OFF THEN ON

*Rudder trim is recovered, despite the fact that no indication is available.*

● **At 3 min or 2 000 ft AAL before landing:**

Restore all generators only 3 min before landing or at 2 000 ft AAL to recover normal braking, while minimizing possible reactivation of a smoke source.

GEN 2..... ON

EMER ELEC GEN 1 LINE..... ON

**F/CTL ALTN LAW (PROT LOST)**

*Flight control normal laws and associated protections are lost. Only the load factor limitation, and the high and low speed stability remain (ALTN law with reduced protection).*

MAX SPEED..... 320 KT

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

Ident.: PRO-ABN-SMOKE-D-00012217.0057001 / 31 AUG 17

ECAM lower display is not available. STATUS SD page is displayed on the upper ECAM display, as long as the STATUS pb is pressed.

L12

**STATUS**

MIN RAT SPEED..... 140 KT  
MAX SPEED..... 320 KT  
MAX BRK PR..... 1000 PSI

FOR LDG..... USE FLAPS 3  
GPWS LDG FLAP 3..... ON  
APPR SPD..... VREF +10 KT  
LDG DIST PROC..... APPLY

ENG 1+2 APPR IDLE ONLY  
ENG 1+2 N1 DEGRADED MODE  
(IAE-powered aircraft)

ALTN LAW: PROT LOST  
WHEN L/G DN: DIRECT LAW  
CTR TK FUEL UNUSABLE  
FUEL CONSUMPT INCRSD

*This message is triggered when the failure (or combination of failures) affects the nominal aerodynamic characteristics of the aircraft.*

FMS PRED UNRELIABLE

*Disregard FMS fuel predictions and refer to QRH/OPS-Operational Data - Fuel Penalty Factors Tables in order to find the applicable Fuel Penalty Factor.*

SLATS/FLAPS SLOW

- **After recovery of normal electrical supply, the following STATUS will be displayed:**

MAX SPEED..... 320 KT  
APPR SPD..... VREF +10 KT  
LDG DIST PROC..... APPLY

**INOP SYS**

*Refer to PRO-ABN-ELEC-[QRH] ELEC EMER CONFIG SYS REMAINING.*

*Continued on the following page*

**[QRH] SMOKE / FUMES / AVNCS SMOKE (Cont'd)**

**APPR PROC**

- **3 MN/2000 FT BEFORE LDG:**  
 GEN 2..... ON  
 EMER ELEC GEN 1 LINE..... ON
- **WHEN A/C IS STOPPED:**  
 ALL GEN..... OFF

ALTN LAW: PROT LOST

See <sup>(1)</sup>

WHEN L/G DN: DIRECT LAW

See <sup>(2)</sup>

<sup>(1)</sup> Flight controls remain in alternate law, due to the loss of IR 2 and 3.

<sup>(2)</sup> At landing gear extension, control reverts to direct law in pitch, as well as in roll (Refer to PRO-ABN-F\_CTL F/CTL DIRECT LAW).

**[QRH] REMOVAL OF SMOKE / FUMES**

Ident.: PRO-ABN-SMOKE-00012218.0003001 / 17 MAR 17

Applicable to: ALL

Apply the REMOVAL OF SMOKE / FUMES QRH procedure, if smoke / fumes become the greatest threat when applying the SMOKE / FUMES / AVNCS SMOKE QRH procedure.

EMER EXIT LIGHT..... ON

■ **If fuel vapors:**

CAB FANS..... ON

*The recirculating air ventilates the air mixer bay and other fuselage area. This prevents fuel vapors from accumulating and the risk of explosion. Passenger health is not affected.*

PACK 1..... OFF

PACK 2..... OFF

■ **If no fuel vapors:**

CAB FANS..... OFF

*To prevent smoke from entering the cockpit and cabin.*

PACK FLOW..... HI

*To provide maximum airflow from the packs.*

*Do not shut down the air conditioning packs, and do not reduce ventilation in an attempt to smother the fire.*

*Do not deploy oxygen masks, if fire is suspected in the cabin.*

LDG ELEV..... 10 000 ft / MEA-MORA

DESCENT TO FL 100 / MEA -MORA ..... INITIATE

*The most effective means of smoke removal is use of ram air. Therefore, descent is initiated to FL 100 or the MEA -MORA , while the cabin altitude is increased to 10 000 ft or the MEA -MORA.*

*The increase in cabin altitude also reduces, at least temporarily, the smoke concentration. Cabin depressurization starts, when descent is initiated.*

ATC..... NOTIFY

SMOKE / FUMES / AVNCS SMOKE PROC..... CONTINUE

*Refer to PRO-ABN-SMOKE [QRH] SMOKE / FUMES / AVNCS SMOKE - GENERAL*

● **At FL 100 or MEA-MORA:**

● **If in ELEC EMER CONFIG:**

APU MASTER sw ..... ON

*Continued on the following page*

**[QRH] REMOVAL OF SMOKE / FUMES (Cont'd)**

*In electrical emergency configuration, when the APU MASTER sw is ON, the battery contactors will automatically close for a maximum of 3 min. This will enable the flight crew to manually control the outflow valve that is powered by the DC BAT BUS.*

- PACK 1..... OFF
- PACK 2..... OFF
- MODE SEL.....MAN
- MAN V/S CTL..... FULL UP
- RAM AIR..... ON

*At FL 100, or MEA -MORA, it is possible to open the RAM AIR valve when  $\Delta P$  is 1 PSI or below. Opening the RAM AIR enables flying with both packs OFF.*

APU MASTER sw .....OFF

● **If smoke persists:**

If there is smoke in the cockpit, open the cockpit (CKPT) window to evacuate the smoke.

- MAX SPEED: 200 kt
- COCKPIT DOOR..... OPEN
- HEADSETS..... ON
- PM SLIDING WINDOW..... OPEN

● **When window open:**

- NON-AFFECTED PACK(s)..... ON
- VISUAL WARNINGS (noisy CKPT)..... MONITOR

*Due to the increased noise level, pay particular attention to visual warnings.*

SMOKE / FUMES / AVNCS SMOKE PROC..... CONTINUE

*Refer to PRO-ABN-SMOKE [QRH] SMOKE / FUMES / AVNCS SMOKE - GENERAL*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

SMOKE

**[QRH] SMOKE / FIRE FROM LITHIUM BATTERY**

Ident.: PRO-ABN-SMOKE-00016024.0001001 / 17 MAR 17

Applicable to: ALL

If necessary, transfer control to the flight crew member seated on the opposite side of the fire.

CKPT / CAB COM..... ESTABLISH  
 STORAGE AFTER Li BAT FIRE cabin procedure..... REQUEST INITIATION

● **If flames:**

CREW OXY MASK (PF)..... USE  
 SMOKE HOOD (PM)..... USE  
 HALON EXTINGUISHER..... USE

● **If no flames or when flames extinguished:**

■ **If not possible to remove device from the cockpit:**

WATER or NON-ALCOHOLIC LIQUID..... POUR ON DEVICE  
 DEVICE..... MONITOR

■ **If possible to remove device from the cockpit:**

DEVICE..... TRANSFER TO CABIN

● **At ANY TIME of the procedure, if SMOKE becomes the GREATEST THREAT:**

REMOVAL OF SMOKE / FUMES procedure..... CONSIDER  
*Refer to PRO-ABN-SMOKE [QRH] REMOVAL OF SMOKE / FUMES*

● **At ANY TIME of the procedure, if situation becomes UNMANAGEABLE:**

IMMEDIATE LANDING..... CONSIDER  
*Depending on the situation, the Captain can consider an overweight landing, a tailwind landing, a ditching, a forced landing, etc.*

L2



**SMOKE AFT CARGO SMOKE** 

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-O-00018698.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when smoke in the AFT cargo compartment is detected.

Flight Phase Inhibition:



*Continued on the following page*

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

SMOKE


**SMOKE AFT CARGO SMOKE**  (Cont'd)

Ident.: PRO-ABN-SMOKE-O-00018589.0007001 / 21 MAR 16


**LAND ASAP**

AFT ISOL VALVE  (IF NOT AUTOMATICALLY CLOSED).....OFF  
 CAB FANS.....OFF

● **IF AFT CRG CLOSED (displayed on ground only):**



 Order the ground crew not to open the door of the affected cargo compartment, unless the passengers have disembarked and fire services are present. Also ensure that the AFT cargo door is closed before discharging the extinguishing agent.

 **AGENT**.....DISCH

 Note: Expect the **SMOKE** warning to remain after agent discharge, even if the smoke source is extinguished. Gases from the smoke source are not evacuated, and smoke detectors are also sensitive to the extinguishing agent.

 ● **ON GROUND BEFORE OPEN CRG DOOR:**

**PAX**.....DISEMBARK

 Note: For aircraft equipped with AFT Cargo Ventilation , if the warning has been displayed temporarily, and agent has not been discharged, normal cargo ventilation may be recovered when ventilation is required for livestock transportation:  
 C/B of CARGO VENT controller (S20 on 122VU, or C7 on 49VU, as installed for AFT CARGO) ..... PULL then PUSH

Ident.: PRO-ABN-SMOKE-O-00018590.0002001 / 21 MAR 16

**STATUS**

● **BEFORE OPEN CRG DOORS (displayed on ground only):**

**PAX**.....DISEMBARK

**INOP SYS**

AFT CRG VENT   
 AFT CRG HEAT 

**SMOKE AFT CRG DET FAULT** 

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-P-00018699.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2**

This alert triggers when the AFT smoke detection is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-P-00018592.0001001 / 21 MAR 16

● **IF NO LIVE STOCK:**

**AFT ISOL VALVE**  ..... **OFF**

Ident.: PRO-ABN-SMOKE-P-00018593.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

**AFT CRG DET** 

**SMOKE FWD CARGO SMOKE** ⚠

Applicable to: ALL


Ident.: PRO-ABN-SMOKE-E-00017408.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when smoke in the FWD cargo compartment is detected.

Flight Phase Inhibition:



*Continued on the following page*

**SMOKE FWD CARGO SMOKE**  (Cont'd)

Ident.: PRO-ABN-SMOKE-E-00018287.0005001 / 21 MAR 16

**LAND ASAP**

FWD ISOL VALVE  (IF NOT AUTOMATICALLY CLOSED)..... OFF  
CAB FANS.....OFF

● **IF FWD CRG CLOSED (displayed on ground only):**


**L2** Order the ground crew not to open the door of the affected cargo compartment, unless the passengers have disembarked and fire services are present. Also ensure that the FWD Cargo Door is closed before discharging the extinguishing agent.

**L1** AGENT..... DISCH

**L2** Note: Expect the SMOKE warning to remain after agent discharge, even if the smoke source is extinguished. Gases from the smoke source are not evacuated, and smoke detectors are also sensitive to the extinguishing agent.

**L1** ● **ON GROUND BEFORE OPEN CRG DOOR:**

PAX..... DISEMBARK

**L2** Note: For aircraft equipped with FWD Cargo Ventilation , if the warning has been displayed temporarily, and agent has not been discharged, normal cargo ventilation may be recovered when ventilation is required for livestock transportation:  
C/B of CARGO VENT controller (T20 on 122VU, or C8 on 49VU, as installed for FWD CARGO) ..... PULL then PUSH

Ident.: PRO-ABN-SMOKE-E-00018588.0002001 / 21 MAR 16

**STATUS**

● **BEFORE OPEN CRG DOOR (displayed on ground only):**

PAX.....DISEMBARK

**INOP SYS**

FWD CRG VENT   
FWD CRG HEAT 

**SMOKE FWD(AFT) CRG BTL 1(2) FAULT** ⚠

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-L-00017414.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when:

- FWD or AFT bottle 1 (2) ⚠ squib is failed, or
- FWD or AFT bottle 1 (2) ⚠ is at low pressure.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-L-00018325.0001001 / 21 MAR 16

- L2** If bottle 1 is lost, fire extinguishing capability is lost in the FWD(AFT) cargo compartment.  
If bottle 2 is lost, agent concentration will not be ensured after fire extinguishing.

**L1** Crew awareness.

**SMOKE FWD CRG DET FAULT** 

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-F-00017689.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the FWD smoke detection is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-F-00018336.0001001 / 21 MAR 16

● **IF NO LIVE STOCK:**

FWD ISOL VALVE  .....OFF

Ident.: PRO-ABN-SMOKE-F-00018337.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

FWD CRG DET 

**SMOKE DET FAULT**

Applicable to: ALL


Ident.: PRO-ABN-SMOKE-G-00017400.0002001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

L2 This alert triggers when both SDCU or CIDS-SDF are failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-G-00018423.0002001 / 21 MAR 16

● **IF NO LIVE STOCK:**

FWD ISOL VALVE ..... OFF

AFT ISOL VALVE ..... OFF

PAX SYS ..... OFF

Ident.: PRO-ABN-SMOKE-G-00012226.0011001 / 01 APR 11

**STATUS**

**INOP SYS**

SMOKE DET



**SMOKE LAVATORY DET FAULT**

Applicable to: ALL

Ident.: PRO-ABN-SMOKE-H-00017407.0002001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the lavatory smoke detection is failed.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-H-00018724.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-SMOKE-H-00012228.0001001 / 18 AUG 10

**STATUS**

**INOP SYS**

LAV DET

**SMOKE LAVATORY SMOKE**

Applicable to: ALL


Ident.: PRO-ABN-SMOKE-N-00017406.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when smoke in one of the lavatory is detected.

Flight Phase Inhibition:



Ident.: PRO-ABN-SMOKE-N-00018427.0002001 / 21 MAR 17

**L2** Communication must be established with the cabin crew in order to follow up on the smoke origin and dissipation.  
Consider applying the SMOKE/FUMES/AVNCS SMOKE QRH procedure.

**L1** CKPT/CAB COM.....ESTABLISH

**[MEM] EGPWS CAUTIONS**

Ident.: PRO-ABN-SURV-00018751.0009001 / 17 MAR 17

Applicable to: ALL

■ **"TERRAIN TERRAIN" - "TOO LOW TERRAIN" - "CAUTION TERRAIN" - "CAUTION OBSTACLE"**

■ **During night or IMC:**

Simultaneously:

AP.....	OFF
PITCH.....	PULL UP

L2

Pull to full backstick and maintain in that position.

L1

THRUST LEVERS.....	TOGA
SPEED BRAKES lever.....	CHECK RETRACTED
BANK.....	WINGS LEVEL or ADJUST

L2

Aircraft achieve the best climb performance when the wings are as level as possible.

L1

*Note:* For some airports, the operator may define a specific procedure.

■ **During daylight and VMC, with terrain and obstacles clearly in sight:**

FLIGHT PATH.....	ADJUST
------------------	--------

L2

Adjust pitch, bank and thrust to silence the alert.

L1

*Note:* For some airports, the operator may define a specific procedure.

■ **"SINK RATE"**

■ **Above 1 000 ft AAL in IMC or above 500 ft AAL in VMC:**

FLIGHT PATH.....	ADJUST
------------------	--------

L2

Adjust pitch and thrust to silence the alert.

L1

■ **Below 1 000 ft AAL in IMC or below 500 ft AAL in VMC:**

GO-AROUND.....	CONSIDER
----------------	----------

■ **"DON'T SINK"**

FLIGHT PATH.....	ADJUST
------------------	--------

L2

Adjust pitch and thrust to silence the alert.

*Continued on the following page*

**[MEM] EGPWS CAUTIONS (Cont'd)**

- L1 ■ **"TOO LOW GEAR" - "TOO LOW FLAPS"**  
 GO-AROUND.....PERFORM
- **"GLIDESLOPE"**
  - **Above 1 000 ft AAL in IMC or above 500 ft AAL in VMC:**  
 FLIGHT PATH.....ADJUST
- L2 Adjust pitch and thrust to reduce the vertical deviation from the glideslope.
- L1 ● **When conditions require a deliberate approach below glideslope:**  
 G/S MODE.....OFF
- **Below 1 000 ft AAL in IMC or below 500 ft AAL in VMC:**  
 GO-AROUND..... CONSIDER

**[MEM] EGPWS WARNINGS**

Ident.: PRO-ABN-SURV-00016878.0020001 / 17 MAR 17  
 Applicable to: ALL

- **"PULL UP" - "TERRAIN TERRAIN PULL UP" - "OBSTACLE OBSTACLE PULL UP"**  
 Simultaneously:  
 AP..... OFF  
 PITCH.....PULL UP
- L2 Pull to full backstick and maintain in that position.
- L1 THRUST LEVERS.....TOGA  
 SPEED BRAKES lever..... CHECK RETRACTED  
 BANK..... WINGS LEVEL or ADJUST
- L2 Aircraft achieve the best climb performance when the wings are as level as possible.  
 If the "TERRAIN TERRAIN PULL UP" or "OBSTACLE OBSTACLE PULL UP" aural alert triggers, a turning maneuver can be initiated if the flight crew concludes that turning is the safest action. The PULL UP maneuver must be performed before the turn towards the safe direction, as climbing increases the terrain clearance.

**[MEM] TCAS WARNINGS**

Ident.: PRO-ABN-SURV-00012455.0022001 / 17 MAR 17

Applicable to: ALL

■ **Traffic advisory: “TRAFFIC” messages:**

Do not perform a maneuver based on a TA alone.

■ **Resolution advisory: All “CLIMB” and “DESCEND” or “MAINTAIN VERTICAL SPEED MAINTAIN” or “LEVEL OFF, LEVEL OFF” or “MONITOR VERTICAL SPEED” type messages:**

AP (if engaged).....OFF

BOTH FDs..... OFF

Respond promptly and smoothly to a RA by adjusting or maintaining the pitch, as required, to reach the green area and/or avoid the red area of the vertical speed scale.

*Note:* Avoid excessive maneuvers while aiming to keep the vertical speed just outside the red area of the VSI, and within the green area. If necessary, use the full speed range between  $V_{\alpha max}$  and  $V_{MAX}$ .

Respect stall, GPWS, or windshear warning.

Notify ATC.

● **GO AROUND procedure must be performed when a RA “CLIMB” or “INCREASE CLIMB” is triggered on final approach:**

*Note:* Resolution Advisories (RA) are inhibited below 900 ft.

■ **When “CLEAR OF CONFLICT” is announced:**

Resume normal navigation in accordance with ATC clearance.

AP/FD can be reengaged as desired.

**[MEM] WINDSHEAR**

Ident.: PRO-ABN-SURV-00012271.0002001 / 17 MAR 17

Applicable to: ALL

A red flag “WINDSHEAR” is displayed on each PFD associated with an aural synthetic voice “WINDSHEAR” repeated three times.  
If windshear is detected either by the system or by pilot observation, apply the following recovery technique:

■ **At Takeoff:**

■ **If before V1:**

The takeoff should be rejected only if significant airspeed variations occur below indicated V1 and the pilot decides that there is sufficient runway remaining to stop the airplane.

■ **If after V1:**

THR LEVERS.....	TOGA
REACHING VR.....	ROTATE
SRS ORDERS.....	FOLLOW

*If necessary the flight crew may pull the sidestick fully back.*

*Note: If the FD bars are not displayed, move toward an initial pitch attitude of 17.5 °.  
Then, if necessary, to prevent a loss in altitude, increase the pitch attitude.*

■ **Airborne, initial climb or landing:**

THR LEVERS AT TOGA.....	SET OR CONFIRM
AP (if engaged).....	KEEP ON
SRS ORDERS.....	FOLLOW

*If necessary the flight crew may pull the sidestick fully back.*

*Note: 1. Autopilot disengages if the angle of attack value goes above  $\alpha$  prot.  
2. If the FD bars are not displayed, move toward an initial pitch attitude of 17.5 °.  
Then, if necessary, to prevent a loss in altitude, increase the pitch attitude.*

DO NOT CHANGE CONFIGURATION (SLATS/FLAPS, GEAR) UNTIL OUT OF WINDSHEAR.

CLOSELY MONITOR FLIGHT PATH AND SPEED.

RECOVER SMOOTHLY TO NORMAL CLIMB OUT OF WINDSHEAR.

**[MEM] WINDSHEAR AHEAD**

Ident.: PRO-ABN-SURV-00012272.0001001 / 17 MAR 17

Applicable to: ALL

The “W/S AHEAD” message is displayed on each PFD. The color of the message depends on the severity and location of the windshear

*Note:* When a predictive windshear alert (“WINDSHEAR AHEAD” or “GO AROUND WINDSHEAR AHEAD”) is triggered, if the flight crew makes a positive verification that no hazard exists, then the alert may be disregarded, as long as:

- There are no other signs of possible windshear conditions, and
- The reactive windshear system is operational.

*Known cases of spurious predictive windshear alerts have been reported at some airports, during either takeoff or landing, due to the specific obstacle environment. However, always rely on any reactive windshear (“WINDSHEAR”).*

**W/S AHEAD RED**

■ **Takeoff**

Associated with an aural synthetic voice “WINDSHEAR AHEAD, WINDSHEAR AHEAD”.

● **Before takeoff:**

Delay takeoff, or select the most favorable runway.

● **During the takeoff run:**

Reject takeoff.

*Note:* Predictive windshear alerts are inhibited above 100 kt until 50 ft.

● **When airborne:**

THR LEVERS.....TOGA

As usual, the slat/flap configuration can be changed, provided the windshear is not entered.

AP (if engaged).....KEEP ON  
 SRS ORDERS..... FOLLOW

If necessary the flight crew may pull the sidestick fully back.

- Note:*
1. Autopilot disengages if the angle of attack value goes above  $\alpha$  prot.
  2. If the FD bars are not displayed, move toward an initial pitch attitude of 17.5 °. Then, if necessary, to prevent a loss in altitude, increase the pitch attitude.

Continued on the following page

**[MEM] WINDSHEAR AHEAD (Cont'd)**

■ **Landing:**

Associated with an aural synthetic voice "GO AROUND, WINDSHEAR AHEAD".

GO-AROUND.....	PERFORM
AP (if engaged).....	KEEP ON

*If necessary the flight crew may pull the sidestick fully back.*

- Note:
1. Autopilot disengages if the angle of attack value goes above  $\alpha$  prot.
  2. If the FD bars are not displayed, move toward an initial pitch attitude of 17.5 °.  
 Then, if necessary, to prevent a loss in altitude, increase the pitch attitude.

**W/S AHEAD AMBER**

Apply precautionary measures, as indicated in FCTM Windshear Operational Recommendations  
 Refer to FCTM/PR-NP-SP-10-10-3 Operational Recommendations.



**VENT AVNCS SYS FAULT**

Applicable to: ALL

Ident.: PRO-ABN-VENT-AA-00017332.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The power up test is not satisfactory, or
- The AEVC is not supplied, or
- The valve position disagrees with the commanded position.

Flight Phase Inhibition:



Ident.: PRO-ABN-VENT-AA-00018047.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-VENT-AA-00010775.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

- AVNCS VENT
- VENT BLOWER <sup>(1)</sup>
- VENT EXTRACT <sup>(1)</sup>

<sup>(1)</sup> (If AEVC not supplied)

**VENT BLOWER FAULT**

Applicable to: ALL


Ident.: PRO-ABN-VENT-X-00017329.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** The alert triggers when the blowing pressure is low or there is a duct overheat.

Flight Phase Inhibition:



Ident.: PRO-ABN-VENT-X-00010768.0005001 / 12 APR 16

■ **If NO DC ESS BUS FAULT:**

**BLOWER**.....**OVRD**

**L2** The ventilation system is in closed circuit configuration and air from air conditioning is added to the ventilation air.

**L1** ■ **If DC ESS BUS FAULT:**

**LAND ASAP**

Ident.: PRO-ABN-VENT-X-00010769.0005001 / 27 MAY 13

**STATUS**

**INOP SYS**

**VENT BLOWER**

**VENT EXTRACT FAULT**

Applicable to: ALL


Ident.: PRO-ABN-VENT-Y-00017330.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when the extract pressure is low.

Flight Phase Inhibition:



Ident.: PRO-ABN-VENT-Y-00010770.0001001 / 05 AUG 10

**EXTRACT**.....**OVRD**

**L2** The ventilation system is in closed circuit configuration and air from air conditioning is added to the ventilation air.

Ident.: PRO-ABN-VENT-Y-00010771.0001001 / 05 AUG 10

**STATUS**

**INOP SYS**

VENT EXTRACT

**VENT SKIN VALVE FAULT**

Applicable to: ALL

Ident.: PRO-ABN-VENT-Z-00017331.0001001 / 21 MAR 16

**ANNUNCIATIONS**


Triggering Conditions:

L2

This alert triggers when:

- The extract valve is fully open in phase 3, or
- The extract valve is fully open in flight, or
- The inlet valve is not fully closed in flight.

Flight Phase Inhibition:



*Continued on the following page*

**VENT SKIN VALVE FAULT (Cont'd)**

Ident.: PRO-ABN-VENT-Z-00018941.0001001 / 21 MAR 16

● **If INLET valve not fully closed in flight:**

Crew awareness.

**L2** No action is required, since there is a non return valve in the air inlet.

**L1** ● **If EXTRACT valve affected:**

BLOWER.....OVRD  
EXTRACT.....OVRD

**L2** *These actions send additional closure signals to the inlet and extract valves.  
The weather radar image on both NDs may be lost, in case of insufficient ventilation.*

**L1** ● **IF UNSUCCESSFUL:**

MAX FL.....100/MEA  
CAB PR MODE SEL.....MAN  
MAN V/S CTL.....FULL UP

**L2** *The aircraft is manually depressurized.  
It may take 10 s in manual mode before the crew notices a change of the outflow valve position.*

Ident.: PRO-ABN-VENT-Z-00018942.0002001 / 21 MAR 16

**STATUS**

MAX FL: 100/MEA

MAN CAB PR CTL

TGT V/S: CLIMB 500 FT/MIN

TGT V/S: DESC 300 FT/MIN

**INOP SYS**

AVNCS VALVE

**A/C FL**

390  
350  
300  
250  
< 200

**CAB ALT TGT**

8 000  
7 000  
5 500  
3 000  
0

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

VENT

Intentionally left blank

**[QRH] WHEEL TIRE DAMAGE SUSPECTED**

Ident.: PRO-ABN-WHEEL-00019841.0001001 / 22 MAR 17

Applicable to: ALL

LDG DIST PROC.....APPLY

*Performance impact of one burst tire is equivalent to one brake released.*

TAXI WITH CARE

*Refer to LIM-LG Taxi with Deflated or Damaged Tires*

**WHEEL HYD SEL FAULT**

Applicable to: ALL

Ident.: PRO-ABN-WHEEL-AE-00017810.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the brake normal selector valve is failed, or the NWS selector valve is at open position.

Flight Phase Inhibition:



Continued on the following page

**WHEEL HYD SEL FAULT (Cont'd)**

Ident.: PRO-ABN-WHEEL-AE-00018363.0003001 / 21 MAR 16

- [L2] - If the normal brake selector valve is failed open, full green hydraulic pressure is present at normal servovalves' entry.  
Nosewheel steering remains available.
- On ground, do not tow the aircraft with the yellow hydraulic system pressurized: If the steering selector valve is failed open, nosewheel steering remains pressurized, and so towing may either break the towbar shear pin, or the nose gear (if towbarless towing).
- If the steering selector valve is failed open, setting A/SKID & N/W STRG sw to OFF will cause the nosewheel to go to maximum deflection.

[L1] A/SKID & N/W STRG.....KEEP ON

[L2] *As long as antiskid is operative, brake pressure is regulated by normal servovalves.*

**WHEEL N/W STRG FAULT**

Applicable to: ALL


Ident.: PRO-ABN-WHEEL-AF-00017744.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the nose wheel steering system is failed.

Flight Phase Inhibition:



*Continued on the following page*



**WHEEL N/W STRG FAULT (Cont'd)**

Ident.: PRO-ABN-WHEEL-AF-00018712.0001001 / 21 MAR 16

Crew awareness.

Ident.: PRO-ABN-WHEEL-AF-00018713.0001001 / 21 MAR 16

L12

**STATUS**

**INOP SYS**

CAT 3 SINGLE ONLY

See <sup>(1)</sup>

CAT 3 DUAL  
 N/W STRG

- <sup>(1)</sup> **Note:**
1. If the **L/G SHOCK ABSORBER FAULT** is also displayed, then the nose wheels may be at maximum deflection (turned 90 ° from center). During landing, delay nose wheel touchdown as long as possible.
  2. Automatic rollout is not permitted (Refer to QRH/OPS Required Equipment for CAT2 and CAT3).

**WHEEL TYRE LO PR** ⚠

Applicable to: ALL

Ident.: PRO-ABN-WHEEL-AG-00017824.0003001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

**L2** This alert triggers when one of the following cases occurs:

- One tire pressure is below:
  - 74% of nominal pressure between liftoff and engines shutdown, or
  - 89% of nominal pressure in other cases.
- There is difference of pressure between two wheels of the same axle that is above:
  - 21% of nominal pressure between liftoff and engines shutdown, or
  - 15% of nominal pressure in other cases.

Flight Phase Inhibition:



Ident.: PRO-ABN-WHEEL-AG-00018714.0001001 / 21 MAR 16

Crew awareness.

**WING A.ICE L(R) HI PR**

Applicable to: ALL

Ident.: PRO-ABN-W\_A\_ICE-Q-00017161.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the WING ANTI ICE pb-sw is set to ON and the pressure sensor (downstream of the valve) indicates a high pressure in the duct.

Flight Phase Inhibition:



Ident.: PRO-ABN-W\_A\_ICE-Q-00018328.0001001 / 21 MAR 16

**THRUST LIM PENALTY**

Ident.: PRO-ABN-W\_A\_ICE-Q-00018330.0001001 / 21 MAR 16

**STATUS**

THRUST LIM PENALTY

**INOP SYS**

WAI REGUL

**WING A.ICE L(R) VALVE OPEN**  
**(FAILURE DETECTED IN FLIGHT)**

Applicable to: ALL


Ident.: PRO-ABN-W\_A\_ICE-N-00017160.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- [L2] This alert triggers when the WING ANTI ICE pb-sw is set to OFF and one wing anti ice valve remains open, in flight.

Flight Phase Inhibition:



Ident.: PRO-ABN-W\_A\_ICE-N-00018331.0001001 / 21 MAR 16

WAI AVAIL IN FLT  
 WING ANTI ICE.....AS RQRD

- [L2] Wing anti-ice is available if needed and anyway is continually on, on failed side.

[L1] **THRUST LIM PENALTY**

- **After landing (automatic recall):**
  - ENG BLEED (AFFECTED SIDE)..... OFF
  - X BLEED (IF NOT CLOSED)..... SHUT
  - APU BLEED (IF LEFT WING AFFECTED)..... OFF
  - WING ANTI ICE..... OFF

*Continued on the following page*

**WING A.ICE L(R) VALVE OPEN (Cont'd)**  
 (FAILURE DETECTED IN FLIGHT)

Ident.: PRO-ABN-W\_A\_ICE-N-00018332.0001001 / 21 MAR 16

**STATUS**

- **In flight:**  
 THRUST LIM PENALTY  
 WAI AVAIL IN FLT

**INOP SYS**

- ENG 1(2) BLEED (On ground only)
- PACK 1(2) (On ground only)

**WING A.ICE L(R) VALVE OPEN**  
 (FAILURE DETECTED ON GROUND)

Applicable to: ALL

Ident.: PRO-ABN-W\_A\_ICE-M-00017495.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the WING ANTI ICE pb-sw is set to OFF and one wing anti ice valve remains open, on ground.

Flight Phase Inhibition:



Continued on the following page

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**

WING A.ICE

**WING A.ICE L(R) VALVE OPEN (Cont'd)**  
**(FAILURE DETECTED ON GROUND)**

Ident.: PRO-ABN-W\_A\_ICE-M-00018333.0001001 / 21 MAR 16

WING ANTI ICE..... OFF  
 ENG BLEED (AFFECTED SIDE)..... OFF  
 X BLEED (IF NOT CLOSED)..... SHUT  
 APU BLEED (IF LEFT WING AFFECTED AND IF APU RUNNING)..... OFF  
 WAI AVAIL IN FLT

■ **After takeoff when above 1 500 ft (automatic recall):**

WAI AVAIL IN FLT  
 ENG BLEED (AFFECTED SIDE)..... ON  
 WING ANTI ICE..... AS RQRD

**L2** *Wing anti ice is available if needed and anyway is continually on, on failed side.*

**L1** THRUST LIM PENALTY

■ **After landing (automatic recall):**

WING ANTI ICE..... OFF  
 ENG BLEED (AFFECTED SIDE)..... OFF  
 X BLEED (IF NOT CLOSED)..... SHUT  
 APU BLEED (IF LEFT WING AFFECTED)..... OFF

Ident.: PRO-ABN-W\_A\_ICE-M-00018334.0001001 / 21 MAR 16

**STATUS**

**INOP SYS**

● **Before takeoff:**

WAI AVAIL IN FLT

● **In flight:**

THRUST LIM PENALTY

ENG 1 (2) BLEED (On ground only)

PACK 1 (2) (On ground only)

**WING A.ICE OPEN ON GND**

Applicable to: ALL

Ident.: PRO-ABN-W\_A\_ICE-O-00017158.0001001 / 21 MAR 16


**ANNUNCIATIONS**

Triggering Conditions:

L2

This alert triggers when the aircraft is on ground and the wing anti ice valves remain open for more than 35 s after the WING ANTI ICE pb-sw is set to ON.

Flight Phase Inhibition:



Ident.: PRO-ABN-W\_A\_ICE-O-00018311.0001001 / 21 MAR 16

WING ANTI ICE..... OFF

Ident.: PRO-ABN-W\_A\_ICE-O-00018335.0001001 / 21 MAR 16

**STATUS**

WAI AVAIL IN FLT

**WING A.ICE SYS FAULT**

(ONE WING VALVE REMAINS CLOSED WHEN THE WING ANTI-ICE IS TURNED ON)

Applicable to: ALL


Ident.: PRO-ABN-W\_A\_ICE-P-00017159.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- L2** This alert triggers when the WING ANTI ICE pb-sw is set to ON and one wing anti ice valve remains closed.

Flight Phase Inhibition:



Ident.: PRO-ABN-W\_A\_ICE-P-00018338.0002001 / 21 MAR 16

WING ANTI ICE..... OFF  
 AVOID ICING CONDITIONS

*Continued on the following page*



**WING A.ICE SYS FAULT (Cont'd)**  
**(ONE WING VALVE REMAINS CLOSED WHEN THE WING ANTI-ICE IS TURNED ON)**

Ident.: PRO-ABN-W\_A\_ICE-P-00018339.0004001 / 17 MAR 17

L12

**STATUS**

**AVOID ICING CONDITIONS**

● **IF SEVERE ICE ACCRETION:**

**MIN SPD..... VLS +10/G DOT**  
**MANEUVER WITH CARE**

*Note: In the case of severe ice accretion, with wing anti-ice failed, the Angle-of-Attack (AOA) protections remain efficient. Manoeuvre with care: avoid large roll inputs at high AOA and high thrust setting. In the case of abnormal response in pitch or roll, release the backstick and reduce thrust.*

**LDG DIST PROC.....APPLY**

**INOP SYS**

WING ANTI ICE

**WING A.ICE SYS FAULT**

(THE WING ANTI-ICE IS TURNED ON AFTER ONE ENGINE SHUTDOWN OR AFTER THE LOSS OF ONE BLEED)

Applicable to: ALL


Ident.: PRO-ABN-W\_A\_ICE-AA-00017496.0001001 / 21 MAR 16

**ANNUNCIATIONS**

Triggering Conditions:

- ② This alert triggers when the WING ANTI ICE pb-sw is set to ON and one wing anti ice valve remains closed.


Flight Phase Inhibition:



Ident.: PRO-ABN-W\_A\_ICE-AA-00018340.0001001 / 21 MAR 16

X BLEED..... OPEN

- ② Note: The affected pack has to be selected OFF due to precooler performance.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>ABNORMAL AND EMERGENCY PROCEDURES</b> DETAILED CABIN / COCKPIT EVACUATION PROCEDURE
---	--

**GENERAL**

Ident.: PRO-ABN-90-00010415.0001001 / 15 OCT 12  
**Applicable to: ALL**

A successful outcome for an emergency situation depends, first of all, upon each crew member's perfect knowledge and execution of the duties assigned to him.

The captain should check frequently that all crew members know exactly their assigned positions and their specific duties, as well as the duties of the other crew members, in case of an abnormal or an emergency condition.

Since it is not possible to cover all the situations that may occur, the captain will be responsible for adapting the following instructions to obtain the best coordination of the emergency operation. Should it be physically impossible for the captain to carry out his duties, another crew member will substitute for him according to the chain of command. The procedures in this manual are AIRBUS procedures and should be considered to be a reference.

**COCKPIT-ASSIGNED DUTIES FOR EVACUATION**

Ident.: PRO-ABN-90-00010416.0001001 / 05 AUG 10  
**Applicable to: ALL**

■ **If it is NOT POSSIBLE to reach the passenger cabin:**

The cockpit crew should evacuate the aircraft via the cockpit clearview windows, by using the escape ropes.

On ground, each crewmember must help passengers, and direct them away from the aircraft.

■ **If it is POSSIBLE to reach the passenger cabin:**

<b>CAPT</b>	<ul style="list-style-type: none"> <li>- Is the last person to leave the cockpit: Proceeds to the cabin, and helps with passenger evacuation, as necessary</li> <li>- Is the last person to leave the aircraft: Checks that all persons have evacuated the aircraft</li> <li>- Evacuates the aircraft, via the rear door, or any other available exit, if he/she cannot reach the rear door.</li> <li>- On ground, he/she takes command of operations until rescue units arrive.</li> </ul>
<b>F/O</b>	<ul style="list-style-type: none"> <li>- Proceeds to the cabin, and takes the emergency equipment.</li> <li>- Evacuates the aircraft, using any available exit.</li> <li>- Helps passengers on ground, and directs them away from the aircraft.</li> </ul>

**PROCEDURES**

**ABNORMAL AND EMERGENCY PROCEDURES**

**DETAILED CABIN / COCKPIT EVACUATION PROCEDURE**

**CABIN CREW-ASSIGNED AREAS FOR EVACUATION**

Ident.: PRO-ABN-90-00010607.0001001 / 17 MAR 11

Applicable to: **ALL**

CABIN CREW DESIGNATION	ASSIGNED JUMPSEAT AND DOOR	ASSIGNED DOOR	ASSIGNED AREA
1 PURSER	DOOR 1 LH	FWD OUTBOARD	FWD/MID
1 CABIN CREW	DOOR 1 RH /LH	FWD INBOARD	FWD/MID
1 CABIN CREW	DOOR 2 RH	AFT CENTER	MID/AFT
1 CABIN CREW	DOOR 2 LH	REARWARD	MID/AFT

*Note:* These procedures are established for the minimum required number of 4 cabin crews.

**COMMUNICATIONS**

Ident.: PRO-ABN-90-00010418.0001001 / 04 JUL 17

Applicable to: **ALL**

1. EMERGENCY CALL			
FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	<ul style="list-style-type: none"> <li>- Press EMER pb-sw on the CALLS panel, or</li> <li>- Passenger Address (PA) System: "PURSER TO COCKPIT PLEASE!"</li> </ul>	Purser must immediately go to the cockpit.
<b>CABIN</b>	COCKPIT	<ul style="list-style-type: none"> <li>- Interphone: "PRIO CAPT"</li> </ul>	Any cabin crewmember can make such a call. The cockpit crew must reply.

**PROCEDURES**  
**ABNORMAL AND EMERGENCY PROCEDURES**  
DETAILED CABIN / COCKPIT EVACUATION PROCEDURE

**2. EMERGENCY ALERT**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	- PA System: "ATTENTION CREW! AT STATIONS!"	The cockpit crew makes a short and precise announcement to warn that an emergency evacuation may soon be required. Cabin crews must proceed to their emergency stations, and fasten their seatbelts.

**3. NOTIFICATION TO PASSENGERS**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	- SIGNS ON - PA System	For psychological reasons, the cockpit crew should be the first to inform of an intended emergency landing.
<b>PURSER</b>	CABIN	- CABIN LIGHTS 100 % - PA System	Purser informs passengers that they have to pay special attention to these warnings: - "FINISH PREPARATION" - "BRACE FOR IMPACT" - "PASSENGERS EVACUATE"



**4. FINISH PREPARATION**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	- Passenger Address (PA) System: "FINISH PREPARATION"	The cockpit crew gives this order a short time before an emergency landing.

**5. BRACE FOR IMPACT**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	- PA System: "BRACE FOR IMPACT!"	The cockpit crew announces to brace for impact approximately 1 min before landing.

**6. INITIATE EVACUATION (RESTRICTED EXITS)**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
<b>COCKPIT</b>	CABIN	- PA System: "PASSENGERS EVACUATE" - Activate EVAC signals 	The cockpit crew orders an immediate evacuation, and the cabin crew directs passengers to all available exits.
<b>CABIN</b>	COCKPIT AND CABIN	- EVAC SIGNAL SYSTEM  on FWD ATTND panel (FAP) - PA System or megaphone	Used by the cabin crew, if there is no signal or order from the cockpit, and if it is unmistakably clear that the aircraft must be evacuated.
<b>CABIN</b>	CABIN	- Verbal	The cabin crew stands up and shouts: - "SEATBELTS OFF!" - "LEAVE EVERYTHING!" - "GET OUT!" - "COME THIS WAY!"

**PROCEDURES**

**ABNORMAL AND EMERGENCY PROCEDURES**

**DETAILED CABIN / COCKPIT EVACUATION PROCEDURE**

**7. EVACUATION NOT REQUIRED**

FROM	TO	COMMUNICATION METHOD(S)	REMARKS
COCKPIT	CABIN	- PA System: "CABIN CREW and PASSENGERS REMAIN SEATED!"	When the Captain decides that an evacuation is not required, the cockpit crew makes an immediate announcement to this effect.

**ON GROUND EVACUATION**

Applicable to: ALL

Ident.: PRO-ABN-90-A-00010419.0001001 / 05 AUG 10

**COCKPIT CREW PROCEDURES**

The cockpit crew notifies the cabin crew of the nature of the emergency, and states intentions. The cockpit crew uses the Passenger Address system to make an appropriate announcement, such as: "PASSENGERS EVACUATE", and presses the EVAC COMMAND pb.

Ident.: PRO-ABN-90-A-00010420.0001001 / 05 AUG 10

**CABIN CREW PROCEDURES**

When the cabin receives the order to evacuate, each cabin crewmember must proceed as follows:  
 STAND UP AND SHOUT....."UNFASTEN SEATBELTS"  
 OUTSIDE CONDITIONS..... CHECK

■ **If outside conditions are safe:**

DOOR IN ARMED POSITION..... OPEN FIRMLY  
 SHOUT..... "COME THIS WAY"

● **If the door does not open automatically:**

DOOR.....PUSH AND OPEN MANUALLY  
 SLIDE (or SLIDERAFT) DEPLOYMENT.....CHECK FULL DEPLOYMENT  
*It takes approximately 4 s for the slide (or slideraft) to deploy.*

● **If the slide (or slideraft) does not automatically inflate:**


RED, MANUAL INFLATION HANDLE.....PULL  
*The red, manual inflation handle is located on the right-hand side of the slide (or slideraft) girt extension.*

ORDER..... "PASSENGERS EVACUATE"  
 PASSENGER EVACUATION .....EXPEDITE

● **If the slide (or slideraft) becomes unserviceable:**

PASSENGER EVACUATION.....STOP  
 PASSENGERS TO ANOTHER USABLE EXIT..... REDIRECT

TOTAL ZONE EVACUATION.....CHECK

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b></p> <p><b>ABNORMAL AND EMERGENCY PROCEDURES</b></p> <p>DETAILED CABIN / COCKPIT EVACUATION PROCEDURE</p>
---	---

CABIN CREW..... EVACUATE  
 PASSENGERS AWAY FROM THE AIRCRAFT.....DIRECT

■ **If outside conditions are unsafe:**

EXIT DOOR.....BLOCK  
 PASSENGERS TO NEAREST USABLE EXIT.....REDIRECT

**COCKPIT EVACUATION THROUGH WINDOW**

**Applicable to: ALL**

Ident.: PRO-ABN-90-B-00010421.0001001 / 05 AUG 10

**OPENING THE SLIDING WINDOW**

HANDLE..... PUSH DOWN AND PULL BACK  
*Pulling the handle backwards, opens the sliding window.*

Ident.: PRO-ABN-90-B-00010422.0001001 / 24 NOV 15

**COCKPIT EVACUATION WITH ESCAPE ROPE**

ESCAPE ROPE STOWAGE.....OPEN  
*The escape rope stowage is located above the sliding window, on either side of the overhead panel.*

ESCAPE ROPE..... UNROLL  
*Unroll the escape rope, and throw it through the window.*

SEAT.....STEP ON  
 ESCAPE ROPE..... GRASP  
*Grasp the escape rope firmly with both hands, and slide down along the rope.*

**EVACUATION ON WATER**

**Applicable to: ALL**

Ident.: PRO-ABN-90-C-00010423.0002001 / 17 MAR 11

**CABIN CREW RESPONSIBLE FOR TYPE "I" DOORS**

When the cabin receives the order to evacuate, each cabin crewmember must proceed as follows:

CHILDREN LIFEVESTS..... DISTRIBUTE  
 STAND UP AND SHOUT..... “UNFASTEN SEATBELTS – PUT ON YOUR LIFEVEST”

*Inflate the lifevest, only once outside the aircraft.*

ORDER.....“REMOVE SHOES”

● **If the Type I door is usable:**

DOOR IN ARMED POSITION..... OPEN  
 SLIDERAFT.....DEPLOY  
 RED, MANUAL INFLATION HANDLE..... PULL

*Do not wait for automatic inflation of the slideraft.*

■ **If the water level is close to the door sill:**

The slideraft inflates on the water.

SLIDERAFT..... LEAVE ATTACHED TO CABIN FLOOR  
 PASSENGER LIFEVESTS..... INFLATE WHEN BOARDING SLIDERAFT  
 PASSENGERS..... BOARD SLIDERAFT  
 TOTAL ZONE EVACUATION..... CHECK  
 LAST CREWMEMBER..... BOARD SLIDERAFT  
 SLIDERAFT..... SEPARATE FROM DOOR SILL

*The last crewmember must separate the slideraft from the door sill, and board with all the necessary safety equipment.*

MOORING LINE.....CUT  
 SURVIVAL KIT..... RETRIEVE

*The survival kit is attached to the slideraft via a lanyard.*

■ **If the water level is too far away from the door sill:**

SLIDERAFT..... DISCONNECT FROM DOOR SILL

*The slideraft remains tied to the aircraft by a 6 m (20 ft) mooring line.*

MOORING LINE..... HOLD

*To keep the slideraft close to the exit, hold the mooring line.*

PASSENGER LIFEVESTS..... INFLATE WHEN BOARDING SLIDERAFT  
 PASSENGERS..... BOARD SLIDERAFT  
 TOTAL ZONE EVACUATION..... CHECK  
 LAST CREWMEMBER..... BOARD SLIDERAFT

*The last crewmember must board with all the necessary safety equipment.*

MOORING LINE.....CUT  
 SURVIVAL KIT..... RETRIEVE

*The survival kit is attached to the slideraft via a lanyard.*



Note: *Evacuation is usually done through the passenger doors. However, if one of the passenger doors is not usable, the overwing exit may be used for evacuation. The cabin crew should install the lifeline to help passenger to stay on the wing. These passengers will, however, be obliged to wait on the wing until the slideraft arrives, and until all other passengers have evacuated from the passenger door exits, and have finished boarding the sliderafts.*

**PROCEDURES**

**ABNORMAL AND EMERGENCY PROCEDURES**

DETAILED CABIN / COCKPIT EVACUATION PROCEDURE

Intentionally left blank

# **PROCEDURES**

## NORMAL PROCEDURES

Intentionally left blank

**PRO-NOR-SOP Standard Operating Procedures**

**PRO-NOR-SOP-01 General Information**

Foreword..... A


**PRO-NOR-SOP-02 Flight Preparation**

Technical Condition of the Aircraft..... A  
 Weather Briefing..... B  
 NOTAMs..... C  
 GPS PRIMARY Availability (If Installed)..... D  
 Flight Plan and Operational Requirements..... E  
 Optimum Flight Level..... F  
 Fuel Requirements..... G

**PRO-NOR-SOP-03 Safety Exterior Inspection**

Safety Exterior Inspection..... A

**PRO-NOR-SOP-04 Preliminary Cockpit Preparation**

General..... A  
 Aircraft Setup..... B  
 Battery Check/Setup..... C  
 APU Fire Test/APU Start..... D  
 AIR COND..... E  
 Cargo Heat  ..... F  
 Cockpit Lights..... G  
 ECAM..... H  
 FMGS Pre-Initialization..... I  
 EFB..... J  
 Before Walkaround..... K

**PRO-NOR-SOP-05 Exterior Walkaround**


General..... A  
 Exterior Walkaround..... B

**PRO-NOR-SOP-06 Cockpit Preparation**

Introduction..... A  
 Overhead Panel..... B  
 CTR Instrument Panel..... C  
 Pedestal..... D  
 RMP..... E  
 ACARS..... F  
 FMGS Preparation..... G

*Continued on the following page*

*Continued from the previous page*

Glareshield.....	H
Lateral Consoles.....	I
Instrument Panels.....	J
ECAM Control Panel.....	K
ADIRS.....	L
Takeoff Briefing.....	M
PC Dedicated to Maintenance  .....	N
Flow Pattern.....	O

**PRO-NOR-SOP-07 Before Pushback or Start**

Before Start Clearance.....	A
At Start Clearance.....	B

**PRO-NOR-SOP-08 Engine Start**

Automatic Engine Start.....	A
Ground Run Up - Danger Areas.....	B

**PRO-NOR-SOP-09 After Start**

After Start.....	A
------------------	---

**PRO-NOR-SOP-10 Taxi**

Taxi.....	A
-----------	---

**PRO-NOR-SOP-11 Before Takeoff**

Before Takeoff.....	A
---------------------	---

**PRO-NOR-SOP-12 Takeoff**

Takeoff.....	A
--------------	---

**PRO-NOR-SOP-13 After Takeoff**

After Takeoff.....	A
--------------------	---

**PRO-NOR-SOP-14 Climb**

Climb.....	A
------------	---

**PRO-NOR-SOP-15 Cruise**

Cruise.....	A
-------------	---

**PRO-NOR-SOP-16 Descent Preparation**

Descent Preparation.....	A
--------------------------	---

*Continued on the following page*

*Continued from the previous page*

**PRO-NOR-SOP-17 Descent**

Descent Initiation.....	A
Descent Monitoring.....	B
Descent Adjustment.....	C
Approach Checklist.....	D
10 000 ft Flow Pattern.....	E

**PRO-NOR-SOP-18 Approach**

**PRO-NOR-SOP-18-A Approach General**

Introduction.....	A
Cross-Reference Table.....	B
Flying Reference.....	C
Stabilization Criteria.....	D
Approach Speed Technique.....	E
Discontinued Approach.....	F

**PRO-NOR-SOP-18-B Aircraft Configuration Management**

Initial Approach.....	A
Intermediate/Final Approach.....	B

**PRO-NOR-SOP-18-C Aircraft Guidance Management**

Approach using LOC G/S Guidance.....	A
Approach using FINAL APP Guidance.....	B
Approach using FPA Guidance.....	C
Circling Approach.....	D
RNAV Visual Approach.....	E
Visual Approach.....	F

**PRO-NOR-SOP-19 Landing**

Manual Landing.....	A
Autoland.....	B

**PRO-NOR-SOP-20 Go-Around**

Go Around with FD.....	A
------------------------	---

**PRO-NOR-SOP-21 After Landing**

After Landing.....	A
--------------------	---

**PRO-NOR-SOP-22 Parking**

Parking.....	A
--------------	---

*Continued on the following page*

*Continued from the previous page*

**PRO-NOR-SOP-23 Securing the Aircraft**

Securing the Aircraft..... A

**PRO-NOR-SOP-90 Standard Callouts**

Communications and Standard Terms..... A  
 Checklist Callouts..... B  
 Actions Commanded by PF..... C  
 FMA..... D  
 Altitude..... E  
 Flaps or Gear Callouts..... F  
 Flight Parameters..... G  
 PF/PM Duties Transfer..... H  
 Summary for Each Phase..... I

**PRO-NOR-SUP Supplementary Procedures**

**PRO-NOR-SUP-SUP Supplementary Procedures Menu**

Supplementary Procedures..... A

**PRO-NOR-SUP-ADVWXR Adverse Weather**

Airframe Deicing/Anti-Icing Procedure on Ground..... A  
 Ground Operations in Cold Weather Conditions..... B  
 Ground Operations in Heavy Rain..... C  
 Minimum Speed with Ice Accretion..... D  
 Operations on Contaminated Airports..... E  
 Operations with Volcanic Ash, Sand or Dust..... F  
 Securing the Aircraft for Cold Soak..... G  
 For Draining Water Procedure..... H  
 Water System Draining..... I

**PRO-NOR-SUP-COM Communication**

VHF, HF Utilization..... A

*Continued on the following page*



*Continued from the previous page*

**PRO-NOR-SUP-ENG Engines**

Manual Engine Start.....	A
Engine Start with External Pneumatic Power.....	B
Crossbleed Engine Start.....	C
Engine Start Valve Manual Operation.....	D
Engine Ventilation (Dry Cranking).....	E
One Engine Taxi - General.....	F
One Engine Taxi - At Departure.....	G
One Engine Taxi - At Arrival.....	H

**PRO-NOR-SUP-FUEL Fuel**

Refueling.....	A
Refueling with One Engine Running.....	B
Ground Fuel Transfer.....	C
Defueling.....	D

**PRO-NOR-SUP-LG L/G**

**PRO-NOR-SUP-LG-LG\_DN Flight with Landing Gear Down**

General.....	A
Limitations.....	B
Procedures.....	C
Takeoff.....	D
Flight Planning.....	E
Climb.....	F
Cruise.....	G
Holding.....	H
Descent.....	I
Go-Around.....	J
One Engine Inoperative.....	K

**PRO-NOR-SUP-LG-LG Operation with Nosewheel Steering Offset**

Operation with Nosewheel Steering Offset.....	A
---	---

**PRO-NOR-SUP-MISC Miscellaneous**

**PRO-NOR-SUP-MISC-D Pushback with Power Push Unit**

Pushback with Power Push Unit Via the Main Landing Gear.....	A
--	---

**PRO-NOR-SUP-MISC-A Hight Altitude Airport Operations**

High Altitude Airport Operations.....	A
---------------------------------------	---

*Continued on the following page*

*Continued from the previous page*

**PRO-NOR-SUP-MISC-C Operations at QNH Above 1050 hPa**

General.....	A
Consequences.....	B
Procedures.....	C

**PRO-NOR-SUP-NAV Navigation**

Insertion of Approach Minima.....	A
-----------------------------------	---

**PRO-NOR-SRP Systems Related Procedures**

**PRO-NOR-SRP-01 FMS**

**PRO-NOR-SRP-01-05 Introduction**

Introduction.....	A
-------------------	---

**PRO-NOR-SRP-01-10 Cockpit Preparation**

FMGS Initialization.....	A
Flight Plan Initialization.....	B
FMGS Data Insertion.....	C
FMGS Re-Initialization After a Canceled Flight.....	D

**PRO-NOR-SRP-01-15 Before Pushback or Start**

Change of Runway.....	A
TAKEOFF FROM INTERSECTION.....	B

**PRO-NOR-SRP-01-20 Taxi**

FCU Selection for Takeoff.....	A
FMA Mode Check.....	B
Selecting a Navigation Display.....	C
Selecting Takeoff Displays for Pilot's and Copilot's MCDU.....	D

**PRO-NOR-SRP-01-30 Takeoff**

Monitoring the Takeoff.....	A
PRESELECTING A HDG OR A TRK.....	B
Normal Takeoff Profile.....	C
No Flight Director Takeoff.....	D
TAKEOFF WITH NO V2 ENTRY.....	E
Takeoff Using the Localizer of the Opposite Runway.....	F

**PRO-NOR-SRP-01-40 Climb**

Monitoring the Climb Phase.....	A
Expedite Climb.....	B
Immediate Return to Origin Airport.....	C

*Continued on the following page*

*Continued from the previous page*

**PRO-NOR-SRP-01-50 Cruise**

Reaching Cruise Flight Level.....	A
Monitoring the Navigation Accuracy.....	B
Monitoring the Fuel Predictions.....	C
Entering a Step Climb or a Step Descent.....	D
Immediate Change of Level in Cruise.....	E
Preparation for Descent and Approach.....	F

**PRO-NOR-SRP-01-60 Descent**

DESCENT INITIATION.....	A
Descent Monitoring.....	B
Expedite Descent (If installed).....	C
Monitoring the Navigation in the Terminal Control Area.....	D
Too Steep Path.....	E
Holding Pattern.....	F
MANUAL TERMINATION.....	G

**PRO-NOR-SRP-01-70 Approach**

Initial Approach.....	A
ILS/MLS/GLS/FLS Approach.....	B
Switching from Non ILS to ILS Approach.....	C
Landing Categories.....	D
Warnings for ILS Approach.....	E

**PRO-NOR-SRP-01-80 Go-Around**

MONITORING THE GO-AROUND.....	A
Go-Around Profile.....	B
Missed Approach: Try Again.....	C
Missed Approach: Divert.....	D
Task Sharing During a Go-Around.....	E




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - GENERAL INFORMATION</p>
---	--

**FOREWORD**

Ident.: PRO-NOR-SOP-01-00010142.0001001 / 02 MAY 17

**Applicable to: ALL**

The procedures contained in this Chapter are recommended by Airbus, and are consistent with the other Chapters of this manual.

The Authorities do not certificate Standard Operating Procedures. The manufacturer presents them herein as the best way to proceed, from a technical and operational standpoint. They are continually updated and the revisions take into account Operator input, as well as manufacturer experience. In addition, Operators may amend them, as needed. However, the manufacturer recommends that Operators using the FCOM as onboard operational manual submit suggested changes to expedite publication, and maintain consistency of the manual. The Operator should note that they may rewrite this Chapter, at their own responsibility; this could, however, make it difficult to update the manual and keep it consistent with the other Chapters.

The following sections contain expanded information on normal procedures.

Standard Operating Procedures consist of inspections, preparations, and normal procedures. All items of a given procedure are listed in a sequence that follows a standardized scan of the cockpit panels, unless that sequence goes against the action priority logic, to ensure that all actions are performed in the most efficient way.

These procedures assume that all systems are operating normally, and that all automatic functions are used normally.

The FCOM also contains normal procedures that are non-routine procedures in the Supplementary Procedures chapter and in the Special Operations chapter.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - GENERAL INFORMATION

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - FLIGHT PREPARATION</p>
---	---

**TECHNICAL CONDITION OF THE AIRCRAFT**

Ident.: PRO-NOR-SOP-02-00010147.0001001 / 05 AUG 10

**Applicable to: ALL**

The crew will verify the technical state of the aircraft (deferred defect list), with regard to airworthiness, acceptability of malfunctions (MEL), and influence on the flight plan.

**WEATHER BRIEFING**

Ident.: PRO-NOR-SOP-02-00010148.0001001 / 05 AUG 10

**Applicable to: ALL**

- The crew will get a weather briefing
- The briefing should include:
  - Actual and expected weather conditions, including runway conditions for takeoff and climb-out
  - Significant weather enroute, including winds and temperatures
  - Terminal forecasts for destination and alternate airports
  - Actual weather for destination and alternates, for short range flights and recent past weather, if available
  - Survey of the meteorological conditions at airports along the planned route.

Weather can affect the choice of routing (for example, influence which route is quickest) and the choice of flight level. The flight crew must also consider the possibility of runways being contaminated at the departure and destination airfields. The flight crew must also verify ISA deviations and enroute icing conditions, and must consider the possibility of holding due to weather at the destination.

**NOTAMS**

Ident.: PRO-NOR-SOP-02-00010149.0002001 / 29 MAY 13


**Applicable to: ALL**

- The flight crew must examine NOTAMs for changes to routings, unserviceable nav aids, availability of runways and approach aids etc, all of which may affect the final fuel requirement
- In order to prevent the risks of projection of debris towards the trimmable horizontal stabilizer and the elevators, it is not recommended to takeoff from runways in bad condition (loose surface, under repair, covered with debris...)

**GPS PRIMARY AVAILABILITY (IF INSTALLED)**

Ident.: PRO-NOR-SOP-02-00014998.0002001 / 20 MAR 17

**Applicable to: ALL**

- **For RNP1 operations, RNAV(GNSS) approaches and RNAV (RNP)  approaches:**  
RAIM/AIME has been demonstrated to be available 100% of the time with 24 healthy satellites.

If required by operational regulation, for specific conditions (e.g RNAV(RNP), mountainous terrain or less than 24 satellites) an appropriate Ground-Based Prediction Program should be used to check the RAIM/AIME for each intended procedure (arrival, departure and alternate if required)

## FLIGHT PLAN AND OPERATIONAL REQUIREMENTS

Ident.: PRO-NOR-SOP-02-00010150.0001001 / 18 MAR 11

Applicable to: ALL

- The crew will check the company flight plan for routing, altitudes, and flight time
- The Captain will check the ATC flight plan and ensure that:
  - It is filled in and filed, in accordance with the prescribed procedures
  - It agrees with the fuel flight plan routing.
- The crew will check the estimated load figures, and will calculate the maximum allowable takeoff and landing weights.

## OPTIMUM FLIGHT LEVEL

Ident.: PRO-NOR-SOP-02-00010151.0001001 / 22 MAR 17

Applicable to: ALL

The flight crew should choose a flight level that is as close to the optimum as possible. To determine the optimum flight level, *Refer to QRH/PER-M Optimum & Maximum Altitudes (Paper Only)* or use the performance application of FlySmart with Airbus.

As a general rule, an altitude that is 4 000 ft below the optimum produces a significant penalty (approximately 5 % of fuel). Flight 8 000 ft below the optimum altitude produces a penalty of more than 10 % against trip fuel. (The usual contingency allowance is 5 %).

## FUEL REQUIREMENTS

Ident.: PRO-NOR-SOP-02-00010152.0001001 / 05 AUG 10

Applicable to: ALL

### COMPUTERIZED FLIGHT PLAN CHECK

In most cases the flight crew uses a computer-derived flight plan to obtain the correct fuel requirements. Although these computerized requirements are normally accurate, the flight crew must check them for gross errors.

The easiest way to do this is to use the "Quick Determination of F-PLN" tables (*Refer to PER-FPL-FLP-QFP-40 FLIGHT PLANNING M.78*). Although the aircraft will fly at ECON MACH that is based on the cost index, the M 0.78 table is accurate enough to permit the crew to check for gross error.

Ensure that both the captain and the first officer have verified that the fuel calculations and required fuel on board are correct and that the figure complies with the applicable regulations.



### **FUEL TRANSPORTATION**

The flight crew must check the policy covering the “tankering” of fuel on sectors where there is a favourable fuel price differential or operational requirement.


Remember that carrying unnecessary extra fuel increases the fuel consumption for that sector and therefore reduces the economy of the operation (lower flex temperature, more tire and brake wear, more time in climb phase, lower optimum flight level etc).

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - FLIGHT PREPARATION

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - SAFETY EXTERIOR INSPECTION</p>
---	---

**SAFETY EXTERIOR INSPECTION**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-03-A-00010153.0001001 / 05 AUG 10

Items marked by (\*) are the only steps to be completed during a transit stop.  
 This inspection ensures that the aircraft and its surroundings are safe for operations.  
 On arriving at the aircraft, check for obstructions in the vicinity, engineering activity, refueling, etc.

Ident.: PRO-NOR-SOP-03-A-00010154.0001001 / 04 MAR 14

\* WHEEL CHOCKS..... CHECK  
*If the wheel chocks are not in position, the flight crew must check that the parking brake is set with sufficient accumulator pressure.*

Ident.: PRO-NOR-SOP-03-A-00010155.0001001 / 18 MAR 11

\* LANDING GEAR DOORS.....CHECK POSITION

<b>WARNING</b>	<i>Do not pressurize the green hydraulic system without clearance from ground personnel, if any gear door is open. Remember that the green hydraulic system is pressurized if the yellow system is pressurized and the PTU is on AUTO.</i>
----------------	--

Ident.: PRO-NOR-SOP-03-A-00010156.0001001 / 05 AUG 10


\* APU AREA..... CHECK  
*Observe that the APU inlet and outlet are clear.*

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
- SAFETY EXTERIOR INSPECTION

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p>STANDARD OPERATING PROCEDURES - PRELIMINARY COCKPIT PREPARATION</p>
---	---

**GENERAL**

Ident.: PRO-NOR-SOP-04-00010164.0001001 / 20 MAR 17

**Applicable to: ALL**

Items marked by asterisks (\*) are the only steps to be completed after a transit stop without flight crew change. Otherwise, the new flight crew performs all the items.

The following procedure, performed by the PM, ensures that all the required checks are performed before applying electrical power to avoid inadvertent operation of systems and danger to the aircraft and personnel.

Included is APU starting and the establishment of electrical and pneumatic power.

For EFB operations, the following procedure performed by both pilots is based on the use of two EFBs/eQRH in order to reduce the risk of erroneous inputs.

Airbus recommends operating with two EFBs.

**DOCUMENTATION AND MAINTENANCE**

On entering the aircraft, obtain the technical (maintenance) log and verify that the certificate of maintenance and daily inspection (or similar) are up to date and signed. Check the deferred or carried-forward defects. If refueling has already been completed, check the uplift.

**AIRCRAFT SETUP**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-04-A-00021906.0001001 / 30 AUG 17

<b>WARNING</b>	Do not pressurize the hydraulic systems until clearance is obtained from ground personnel.
----------------	--


Ident.: PRO-NOR-SOP-04-A-00010165.0001001 / 03 MAR 14

**ENG**

ENG MASTERS 1, 2..... OFF  
ENG MODE selector..... NORM

Ident.: PRO-NOR-SOP-04-A-00011188.0001001 / 22 APR 16

**\*WEATHER RADAR**

\* RADAR sw ..... OFF  
\* WINDSHEAR / PWS sw  ..... OFF  
\* GAIN knob ..... AUTO/CAL  
\* MODE selector ..... AS RQRD

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
 - PRELIMINARY COCKPIT PREPARATION

Ident.: PRO-NOR-SOP-04-A-00010166.0001001 / 03 MAR 14

**L/G**

L/G lever..... DOWN

Ident.: PRO-NOR-SOP-04-A-00010167.0001001 / 03 MAR 14

**WIPERS**

Both WIPER selectors..... OFF

**BATTERY CHECK/SETUP**

Ident.: PRO-NOR-SOP-04-00010168.0001001 / 30 AUG 17

Applicable to: ALL

■ **If the aircraft has not been electrically supplied for 6 h or more, perform the following check:**

BAT 1 pb and BAT 2 pb..... CHECK OFF  
 BAT 1 and 2 VOLTAGE..... CHECK ABOVE 25.5 V

*Battery voltage above 25.5 V ensures a charge above 50 %.*

■ **If the battery voltage is at or below 25.5 V:**

A charging cycle of about 20 min is required.

BAT 1 pb and BAT 2 pb..... AUTO  
 EXT PWR pb-sw..... ON

*Check on ELEC SD page, that the battery contactor is closed and the batteries are charging.*

● **After 20 min:**

BAT 1 + 2 pb..... OFF  
 BAT 1 and 2 VOLTAGE..... CHECK ABOVE 25.5 V  
 BAT 1 + 2 pb..... AUTO


■ **If the battery voltage is above 25.5 V:**

BAT 1 pb and BAT 2 pb..... AUTO

*If the APU is started on batteries only, it should be started within 30 min after the selection of batteries to AUTO (35 min after battery selection to AUTO, the battery charge is less than 25 % of maximum capacity).*

■ **If the aircraft has been electrically supplied during the last 6 h:**

BAT 1 pb and BAT 2 pb..... AUTO

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p>STANDARD OPERATING PROCEDURES - PRELIMINARY COCKPIT PREPARATION</p>
---	---

- If the AVAIL light is on:  
EXT PWR pb-sw..... ON

**APU FIRE TEST/APU START**

Applicable to: ALL

Ident.: PRO-NOR-SOP-04-B-00010170.0001001 / 07 JUN 16

**APU FIRE**

APU FIRE pb-sw.....CHECK IN and GUARDED  
AGENT lights .....CHECK OFF  
APU FIRE TEST pb.....PRESS and MAINTAIN

Check :

- APU FIRE warning on ECAM + CRC + MASTER WARN light (if AC Power available).
- APU FIRE pb-sw lighted red.
- SQUIB light and DISCH light on

Ident.: PRO-NOR-SOP-04-B-00010171.0015001 / 17 MAR 17

**APU START**

- If the EXT PWR pb-sw ON light is on:  
APU MASTER SW pb-sw ..... ON  
APU START pb-sw .....ON

Note: Wait at least 3 s before selecting APU START pb-sw.

For more information on the APU start, Refer to DSC-49-20 Overhead Panel - Illustration.

For more information on APU starter limitations and APU operations during refueling:

- Refer to LIM-APU APU Start
- Refer to LIM-APU APU Start/Shutdown during Refueling/Defueling.

EXT PWR pb-sw ..... AS RQRD

The flight crew should keep ON the external power units to reduce the APU load, particularly in hot weather conditions.

- If the EXT PWR pb-sw ON light is off:  
APU MASTER SW pb-sw ..... ON  
APU START pb-sw .....ON

Note: Wait at least 3 s before selecting APU START pb-sw.

For more information on the APU start, Refer to DSC-49-20 Overhead Panel - Illustration.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
 - PRELIMINARY COCKPIT PREPARATION

*For more information on APU starter limitations and APU operations during refueling:*

- Refer to LIM-APU APU Start
- Refer to LIM-APU APU Start/Shutdown during Refueling/Defueling.

**AIR COND**

Ident.: PRO-NOR-SOP-04-00010177.0001001 / 14 OCT 15

Applicable to: ALL

**AIR COND**

● **When the APU is AVAIL:**

APU BLEED pb-sw..... ON

*Do not use APU BLEED, if the ground personnel confirms that a LP or HP ground air unit is connected to the aircraft.*

*To determine if an HP ground air unit is connected, the flight crew should also check on the BLEED SD page, if there is pressure in the bleed air system.*

ALL WHITE LIGHTS..... OFF

X BLEED selector..... AUTO

Zone temperature selectors..... AS RQRD

*Full range temperature 24 ± 6 °C (75 ± 11 °F).*

**CARGO HEAT**

Ident.: PRO-NOR-SOP-04-00010178.0001001 / 03 MAR 14

Applicable to: ALL

**CARGO HEAT**

TEMPERATURE selector ..... AS RQRD

**COCKPIT LIGHTS**

Ident.: PRO-NOR-SOP-04-00010172.0002001 / 23 JUN 15


Applicable to: ALL

**COCKPIT LIGHTS**

\* COCKPIT LIGHTS..... AS RQRD

*Set INT LT, FLOOD LT, INTEG LT (included glareshield and FCU).*



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> STANDARD OPERATING PROCEDURES - PRELIMINARY COCKPIT PREPARATION
---	---

**ECAM**

Ident.: PRO-NOR-SOP-04-00010204.0001001 / 04 SEP 17  
 Applicable to: ALL

**\* ECAM**

\* RCL pb .....PRESS 3 s  
*This action recalls all the warnings that the flight crew cleared or cancelled during the last flight.*

\* Check MEL if required.

● **On the DOOR SD page:**

\* OXY ..... CHECK PRESSURE

● **If the OXY pressure is half boxed in amber:**

MIN FLT CREW OXY CHART.....CHECK PRESSURE

*Verify that the pressure is sufficient for the scheduled flight (Refer to LIM-OXY Minimum Flight Crew Oxygen Pressure).*

● **On the HYD SD page:**

\* RESERVOIR FLUID LEVEL.....CHECK WITH NORMAL RANGE

Note: *The volume of the hydraulic fluid in the reservoirs may change with Outside Air Temperature. As a result, the reservoir fluid level that appears on the HYD SD page may be outside of the normal range with no HYD RSVR LO AIR PR or HYD RSVR LO LVL warning. If the fluid level is outside of the normal range, contact maintenance to determine if service is required.*



● **On the ENG SD page:**

\* ENG OIL QUANTITY..... CHECK NORMAL

*Check that the oil quantity is at or above 9.5 qt + estimated consumption (average estimated consumption ~ 0.5 qt/h).*

**FMGS PRE-INITIALIZATION**

Applicable to: ALL  
 Ident.: PRO-NOR-SOP-04-C-00014422.0001001 / 20 MAR 17

Perform FMGS Pre-Initialization in the case of ACARS  operations, or EFB operations with SYNCHRO AVIONICS .

At electrical power-up, the FMGS s and FCU run through various internal tests. Allow enough time (3 min) for tests' completion, and do not start to press pushbuttons until the tests are over. If the "PLEASE WAIT" message appears, do not press any MCDU key until the message clears.

\* FLT NBR.....INSERT

\* FROM/TO.....INSERT



AEROLÍNEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
- PRELIMINARY COCKPIT PREPARATION

**EFB**

Applicable to: ALL

Ident.: PRO-NOR-SOP-04-F-00021234.0001001 / 21 MAR 17

**EFB/EQRH START**

ALL EFB/eQRH..... START

● **In accordance with the Operator's policy or if required by operational regulation:**

EFB/eQRH VERSION..... CHECK

*If required, the flight crew performs this check unless a specific procedure is established as per Operator's policy to ensure that the correct version is onboard.*

*On the EFB STATUS page and the eQRH My aircraft page, check the EFB VERSION number and compare it with the valid version number given as reference by the Operator (e.g. on the company flight plan).*

**\*OPERATION ENGINEERING BULLETINS (OEB)**

\* OEB in eQRH..... CHECK

Go to the OEB section of the eQRH and review all OEB s (particularly red OEBs) that are applicable to the aircraft.

*Note: If there is a transfer of duties during this flight, the flight crew must remind the incoming flight crew of the applicable OEB(s) during the briefing that is done when transferring the duties.*

\* EFB SYNCHRO AVIONICS  ..... CLICK

Each flight crewmember checks (if retrieved from FMS) or enters:

- Aircraft Type
- Aircraft Registration
- Flight Number
- The departure and arrival airports

Both flight crewmembers crosscheck all the data.

REQUIRED APPLICATIONS..... START


Ident.: PRO-NOR-SOP-04-F-00021234.0001001 / 20 MAR 17


**\*ECAM/LOGBOOK CHECK**

\* RCL pb..... PRESS 3 s

*This action recalls all the warnings that the flight crew cleared or cancelled during the last flight*

\* Check MEL if required.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b></p> <p style="text-align: center;"><b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - PRELIMINARY COCKPIT PREPARATION</p>
---	---

- \* LOGBOOK or EFB E-LOGBOOK  ..... CHECK
- *In the logbook or EFB e-logbook, check the technical condition of the aircraft (deferred defect list) with regard to airworthiness, acceptability of the MEL , or the Configuration Deviation List (CDL), and influence on the flight plan.*
- *Crosscheck with ECAM recall.*
- \* MEL /CDL ITEMS (as appropriate)..... CHECK DISPATCH CONDITIONS  
*Access the MEL and CDL items via the Ops Library Browser.*
- \* MEL ITEMS (as appropriate)..... ACTIVATE  
*As appropriate, the activated MEL items are sent to the applicable performance applications.*
- \* CDL ITEMS (as appropriate)..... ACTIVATE & COMPLETE  
*Complete missing items of CDL items. As appropriate, the activated CDL items are sent to the applicable performance applications.*
- \* AIRCRAFT ACCEPTANCE..... PERFORM

Ident.: PRO-NOR-SOP-04-F-00021233.0001001 / 20 MAR 17

**\*PRELIMINARY PERFORMANCE DATA CALCULATION**

Each flight crewmember independently computes the preliminary performance data in accordance with the technical condition of the aircraft and/or any other criteria that may impact the aircraft performance (e.g. NOTAM, runway condition, aircraft configuration).

- \* AIRFIELD DATA..... OBTAIN  
*Obtain data needed for initializing the system, preparing the cockpit and for preliminary takeoff performance computation. The airfield data should include: RUNWAY IN USE, ALTIMETER SETTING, and WEATHER DATA.*

● **If the LOADSHEET application is used :**

PRELIMINARY LOADING..... COMPUTE AND CROSSCHECK

● **If dispatch under MEL and in accordance with the logbook:**

- \* MEL /CDL ITEMS (as appropriate)..... CHECK ACTIVATED  
*As appropriate, check that the MEL and CDL items are activated in the applicable performance application.*

PRELIMINARY TAKEOFF PERF..... COMPUTE AND CROSSCHECK



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
 - PRELIMINARY COCKPIT PREPARATION

**BEFORE WALKAROUND**

Applicable to: **ALL**

Ident.: PRO-NOR-SOP-04-E-00010173.0001001 / 05 AUG 10

**F/CTL**

FLAPS.....CHECK POSITION

*Check the upper ECAM display to confirm that the FLAPS position agrees with the handle position.*

\* SPEEDBRAKE lever..... CHECK RETRACTED and DISARMED

**WARNING** *If flight control surface positions do not agree with the control handle positions, check with the maintenance crew before applying hydraulic power.*

Ident.: PRO-NOR-SOP-04-E-00010174.0001001 / 18 MAY 16

**\* PARKING BRAKE**

ACCU PRESS indicator..... CHECK

*The ACCU PRESS indication must be in the green band. If required use the electric pump on yellow hydraulic system to recharge the brake accumulator.*

PARKING BRAKE handle..... ON

*When one brake temperature is above 500 °C, avoid applying the parking brake, unless operationally necessary.*

BRAKES PRESS indicator.....CHECK

*Check for normal indications.*

**WARNING** *Yellow and green hydraulic systems are pressurized from yellow electric pump. Get ground crew clearance before using the electric pump.*


Ident.: PRO-NOR-SOP-04-E-00010206.0001001 / 23 JUN 15

**EMERGENCY EQUIPMENT**

EMER EQPT..... CHECK

*Check the emergency equipments as follows:*

- Life jackets stowed
- Axe stowed
- Smoke hoods ☒ or portable oxygen equipment and full face masks ☒ stowed and serviceable
- Portable fire extinguisher lockwired and pressure in the green area
- Smoke goggles stowed (smoke hoods ☒)
- Oxygen masks stowed

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - PRELIMINARY COCKPIT PREPARATION</p>
---	--

- Flashlights stowed
- Escape ropes stowed

Ident.: PRO-NOR-SOP-04-E-00010207.0001001 / 14 SEP 12

**RAIN REPELLENT**

RAIN RPLNT indicators..... CHECK PRESSURE and QUANTITY

**CAUTION** Never use rain repellent to wash the windshield and never use it on a dry windshield.

Ident.: PRO-NOR-SOP-04-E-00010208.0001001 / 05 AUG 10

**REAR AND OVERHEAD CIRCUIT BREAKERS PANELS**

REAR and OVERHEAD CIRCUIT BREAKERS panels..... CHECK  
*Check that all circuit breakers are set. Reset as necessary.*

Ident.: PRO-NOR-SOP-04-E-00010209.0001001 / 25 JAN 17

**LANDING GEAR PINS AND COVERS**

\* GEAR PINS and COVERS..... CHECK ONBOARD and STOWED  
*Check that three are on board and stowed.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES  
- PRELIMINARY COCKPIT PREPARATION

Intentionally left blank

**GENERAL**

Ident.: PRO-NOR-SOP-05-00010360.0001001 / 17 MAY 17

Applicable to: ALL

The exterior walkaround ensures that the general condition of the aircraft is satisfactory and that the visible aircraft components and equipment are safe for the flight:

- There is no impact damage to the structure
- There is no evident fuel, oil, or hydraulic leak
- All ground access doors are closed.

The flight crew must perform a complete walkaround before each flight.

The parking brake must be set to ON during the exterior walkaround, in order to enable the flight crew to check brake wear indicators.


**WARNING** If any landing gear door is open, do not apply hydraulic power until clearance is obtained from ground personnel.

**EXTERIOR WALKAROUND**

Applicable to: ALL

Ident.: PRO-NOR-SOP-05-A-00010361.0001001 / 04 MAY 15

**SCHEMATIC**




(1) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH FWD Fuselage



- (2) Refer to PRO-NOR-SOP-05 Exterior Walkaround - Nose Section
- (3) Refer to PRO-NOR-SOP-05 Exterior Walkaround - Nose L/G
- (4) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH FWD Fuselage
- (5) Refer to PRO-NOR-SOP-05 Exterior Walkaround - Lower Center Fuselage
- (6) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH Center Wing
- (7) Refer to PRO-NOR-SOP-05 Exterior Walkaround - ENG 2 LH Side
- (8) Refer to PRO-NOR-SOP-05 Exterior Walkaround - ENG 2 RH Side
- (9) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH Wing Leading Edge
- (10) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH Wing Trailing Edge
- (11) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH L/G and Fuselage
- (12) Refer to PRO-NOR-SOP-05 Exterior Walkaround - RH AFT Fuselage
- (13) Refer to PRO-NOR-SOP-05 Exterior Walkaround - TAIL
- (14) Refer to PRO-NOR-SOP-05 Exterior Walkaround - APU
- (15) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH AFT Fuselage
- (16) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH Landing Gear
- (17) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH Wing Trailing Edge
- (18) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH Wing Leading Edge
- (19) Refer to PRO-NOR-SOP-05 Exterior Walkaround - ENG 1 LH Side
- (20) Refer to PRO-NOR-SOP-05 Exterior Walkaround - ENG 1 RH Side
- (21) Refer to PRO-NOR-SOP-05 Exterior Walkaround - LH Center Wing

Ident.: PRO-NOR-SOP-05-A-00010363.0001001 / 17 MAY 17

**LH FWD FUSELAGE**

AOA probes.....	CONDITION
F/O and CAPT static ports.....	CLEAR
Avionics equipment vent air inlet valve.....	CONDITION
Oxygen bay.....	CLOSED
Oxygen overboard discharge indicator.....	GREEN
Toilet servicing door  .....	CLOSED

Ident.: PRO-NOR-SOP-05-A-00010364.0001001 / 17 MAY 17

**NOSE SECTION**

Pitot probes..... CONDITION  
 STBY static ports..... CLEAR  
 TAT probes..... CONDITION  
 Radome and latches..... CONDITION/LATCHED  
 Forward avionics compartment door..... CLOSED  
 Ground electrical power door (if not required.)..... CLOSED

Ident.: PRO-NOR-SOP-05-A-00010365.0001001 / 17 MAY 17

**NOSE L/G**

Nose wheel chocks..... IN PLACE  
 Wheels and tires..... CONDITION  
 Nose gear structure..... CONDITION  
 Taxi, TO, turn-off lights..... CONDITION  
 Hydraulic lines and electrical wires..... CONDITION  
 Wheel well..... CHECK  
 Safety pin..... REMOVED


Ident.: PRO-NOR-SOP-05-A-00010366.0001001 / 17 MAY 17

**RH FWD FUSELAGE**

RH + AFT avionic compartment doors..... CLOSED  
 Avionic equipment vent air outlet valve..... CONDITION  
 F/O -CAPT static ports..... CLEAR  
 AOA probe..... CONDITION  
 Forward cargo door and selector panel..... CHECK

Ident.: PRO-NOR-SOP-05-A-00010367.0001001 / 20 DEC 16

**LOWER CENTER FUSELAGE**

Potable water drain panel  ..... CLOSED  
 Antennas..... CONDITION  
 Drain mast..... CONDITION  
 Emergency ram air inlet flap..... CONDITION  
 LP and HP ground connection doors..... CLOSED  
 Anticollision light..... CHECK  
 CTR TK magnetic fuel level..... FLUSH  
 Pack air intakes and outlets..... CLEAR

Ident.: PRO-NOR-SOP-05-A-00010368.0002001 / 17 MAY 17

**RH CENTER WING**

Yellow hydraulic bay door..... CLOSED  
 Fuel panel..... CLOSED  
 Inner tank magnetic fuel..... FLUSH  
 Fuel water drain valve inner tank..... NO LEAK  
 Landing light..... CONDITION  
 Slat 1..... CONDITION

Ident.: PRO-NOR-SOP-05-A-00010370.0015001 / 17 MAY 17

**ENG 2 LH SIDE**

Oil fill access door..... CLOSED  
 Thrust reversers..... CLOSED/LATCHED  
 Fan cowl doors..... CLOSED/LATCHED  
 Drain mast..... CONDITION/NO LEAK  
 Engine inlet and fan blades..... CHECK

Ident.: PRO-NOR-SOP-05-A-00010371.0006001 / 17 MAY 17

**ENG 2 RH SIDE**

Vent inlet..... CLEAR  
 Pressure-relief/Start valve handle access door..... CLOSED  
 Thrust reversers..... CLOSED/LATCHED  
 Fan cowl doors..... CLOSED/LATCHED  
 Turbine exhaust ..... CLEAR  
 Pylon/access panel..... CONDITION/CLOSED

Ident.: PRO-NOR-SOP-05-A-00010372.0001001 / 17 MAY 17

**RH WING LEADING EDGE**

Slats 2, 3, 4, 5..... CONDITION  
 Inner and outer cells magnetic fuel level..... FLUSH  
 Fuel water drain valve (outer cell, surge tank)..... NO LEAK  
 Refuel coupling..... CLOSED  
 Surge tank air inlet..... CLEAR  
 Fuel ventilation overpressure disc..... INTACT  
 Navigation light..... CONDITION  
 Wing tip..... CONDITION


Ident.: PRO-NOR-SOP-05-A-00010373.0001001 / 01 SEP 17

**RH WING TRAILING EDGE**

Static dischargers.....CHECK  
Control surfaces.....CONDITION  
Flaps and fairings.....CONDITION  
ANTENNAS ON TOP OF FUSELAGE.....CHECK CONDITION


Ident.: PRO-NOR-SOP-05-A-00010374.0001001 / 17 MAY 17

**RH L/G AND FUSELAGE**

Chocks.....REMOVED  
Wheels and tires.....CONDITION  
Brakes and brake wear ind.....CONDITION  
Torque link damper  .....CONDITION  
Hydraulic lines.....CHECK  
Landing gear structure.....CHECK  
Downlock springs.....CHECK  
Safety pin.....REMOVED  
Ground hydraulic connection yellow.....CLOSED  
Shroud fuel drain.....CONDITION/NO LEAK

Ident.: PRO-NOR-SOP-05-A-00010375.0001001 / 17 MAY 17


**RH AFT FUSELAGE**

RA Antennas.....CONDITION  
*Check that the RA antennas are clean.*  
Cargo door and selector panel.....CHECK  
Bulk door  .....CHECK  
Toilet service access door.....CLOSED  
Outflow valve.....CONDITION  
Drain mast .....CONDITION  
Flight recorder access door .....CLOSED

Ident.: PRO-NOR-SOP-05-A-00010376.0001001 / 17 MAY 17

**TAIL**

Stabilizer, elevator, fin, and rudder.....CONDITION  
Static dischargers.....CHECK  
Lower fuselage structure (tail impact on runway).....CONDITION

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - EXTERIOR WALKAROUND</p>
---	--

Ident.: PRO-NOR-SOP-05-A-00010377.0001001 / 05 AUG 10

**APU**

Access doors..... CLOSED  
Air intake..... CONDITION  
Drain..... CONDITION/NO LEAK  
Oil cooler air outlet ..... CLEAR  
Exhaust..... CLEAR  
Navigation light..... CONDITION  
Fire extinguisher overpressure indication (red disc)..... IN PLACE

Ident.: PRO-NOR-SOP-05-A-00010378.0001001 / 17 MAY 17

**LH AFT FUSELAGE**

Stabilizer, elevator, fin, and rudder..... CONDITION  
Potable water service door..... CLOSED  
Ground hydraulic connection blue door..... CLOSED  
Ground hydraulic connection green and reservoir filling door..... CLOSED

Ident.: PRO-NOR-SOP-05-A-00010379.0001001 / 17 MAY 17

**LH LANDING GEAR**

Chocks..... REMOVED  
Wheels and tires..... CONDITION  
Brakes and brake wear indicator..... CONDITION  
Torque link damper  ..... CONDITION  
Hydraulic lines..... CHECK  
Landing gear structure..... CHECK  
Downlock springs..... CHECK  
Safety pin..... REMOVED

Ident.: PRO-NOR-SOP-05-A-00010380.0001001 / 01 SEP 17

**LH WING TRAILING EDGE**

Flaps and fairing..... CONDITION  
Control surfaces..... CONDITION  
Static dischargers..... CHECK  
ANTENNAS ON TOP OF FUSELAGE..... CHECK CONDITION

Ident.: PRO-NOR-SOP-05-A-00010381.0001001 / 17 MAY 17

**LH WING LEADING EDGE**

Wing tip..... CONDITION

Navigation light..... CONDITION  
 Surge tank air inlet..... CLEAR  
 Fuel ventilation overpressure disc..... INTACT  
 Fuel water drain valve..... NO LEAK  
 Inner and outer cell magnetic fuel level..... FLUSH  
 Slats 2, 3, 4, 5..... CONDITION

Ident.: PRO-NOR-SOP-05-A-00010384.0007001 / 17 MAY 17

**ENG 1 LH SIDE**

Oil fill access door.....CLOSED  
 Thrust reversers..... CLOSED/LATCHED  
 Fan cowl doors..... CLOSED/LATCHED  
 Drain mast.....CONDITION/NO LEAK  
 Engine inlet and fan blades..... CHECK  
 Pylon/access panel..... CONDITION/CLOSED


Ident.: PRO-NOR-SOP-05-A-00010386.0007001 / 17 MAY 17


**ENG 1 RH SIDE**

Vent inlet..... CLEAR  
 Pressure relief/Start valve handle access door..... CLOSED  
 Thrust reversers..... CLOSED/LATCHED  
 Fan cowl doors..... CLOSED/LATCHED  
 Turbine exhaust..... CLEAR

Ident.: PRO-NOR-SOP-05-A-00010387.0001001 / 17 MAY 17

**LH CENTER WING**

Slat 1.....CONDITION  
 Wing leading edge ventilation intake  ..... CLEAR  
 Fuel water drain valves.....NO LEAK  
 Inner tank magnetic fuel..... FLUSH  
 Landing lights.....CONDITION  
 Hydraulic reservoir pressurization door..... CLOSED  
 RAT doors..... CLOSED

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION</p>
---	--

**INTRODUCTION**

Ident.: PRO-NOR-SOP-06-00011153.0001001 / 20 MAR 17  
**Applicable to: ALL**

Items marked by asterisks (\*) are the only steps to be completed after a transit stop without flight crew change. Otherwise, the new flight crew performs all the items.  
 The PF and PM should perform the cockpit preparation according to the panel scan sequence defined below (*Refer to Panel Scan Sequence*), and the task sharing defined in the QRH (*Refer to QRH/Normal Procedures - Cockpit Preparation*).

**OVERHEAD PANEL**

**Applicable to: ALL**  
 Ident.: PRO-NOR-SOP-06-A-00011155.0001001 / 31 JUL 13

**WHITE LIGHTS ON THE OVERHEAD PANEL**

- **During the scan sequence of the overhead panel:**
  - \* ALL WHITE LIGHTS..... EXTINGUISH

*It is a general rule to turn off all the white lights during the scan sequence; therefore, these actions are not listed here.*

Ident.: PRO-NOR-SOP-06-A-00015476.0001001 / 12 APR 16

**RCDR**

- \* RCDR GND CTL pb-sw..... ON
- In order to perform the test, ensure that the PARK BRK is on.*
- LOUDSPEAKER VOLUME knob..... OFF (BOTH SIDES)  
 ACP INT/RAD sw (CAPT and F/O).....SET to INT  
 INTERPHONE VOLUME RECEPTION KNOB (CAPT and F/O)..... RELEASE
- Turn down the volume to the minimum.*
- CVR TEST pb.....PRESS AND MAINTAIN
- The CVR test is successful when an audio test signal is heard through the loudspeakers and the CVR TEST pb is pressed and maintained.*  
*Depending on the CVR model, the audio test signal is:*

- For CVR 30 minutes:
  - A continuous tone, or
  - A short tone.
- For CVR 120 minutes:
  - A short tone, or
  - A short tone and a beep every 4 s, or
  - Two short tones and a beep every 4 s.

The audio test signal stops when the CVR TEST pb is released.

- Note:
- The flight crew may also hear an acoustic feedback (i.e. Larsen effect) during the test. The test is still valid even if this acoustic feedback (i.e. Larsen effect) is heard.
  - If the flight crew cannot hear the audio test signal through the loudspeakers, and if the CVR maintenance headset (22RK headset) is available, the flight crew can perform the CVR TEST through the CVR maintenance headset.
  - If an acoustic feedback (i.e. Larsen effect) is still heard, the flight crew can perform the CVR TEST using the 22RK headset and with the parking brake set to off. Before setting the parking brake to off, the flight crew must ensure that chocks are in place or brakes are applied. Set the parking brake to on when the CVR TEST is achieved.

Ident.: PRO-NOR-SOP-06-A-00011158.0001001 / 06 MAR 17

**EVAC**

CAPT & PURS/CAPT sw .....AS RQRD  
 Set the CAPT & PURS/CAPT sw on the EVAC panel as per Company Policy.

Ident.: PRO-NOR-SOP-06-A-00011159.0009001 / 17 MAR 17

**\*ADIRS**

All IR MODE selector..... NAV  
 Align or realign IRS as appropriate. Refer to FCTM/PR-NP-SOP-60 ADIRS Operations.


**L2** A complete IRS alignment must be performed in the following cases:

- Before the first flight of the day, or
- When there is a crew change, or
- When the GPS is not available and the NAVAIDS coverage is poor on the expected route, or
- When the GPS is not available and the expected flight time is more than 3 h.

A fast IRS alignment must be performed if a complete IRS alignment is not necessary.

To perform an alignment, the aircraft must be stopped on ground. Any aircraft movement will automatically restart the IRS alignment.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION</p>
---	--

Do not align IRS during engine start, or while the engines are running.

Ident.: PRO-NOR-SOP-06-A-00011160.0001001 / 05 JAN 15




**EXTERIOR LIGHTS**

STROBE sw..... AUTO  
 BEACON sw..... OFF  
 REMAINING EXTERIOR LIGHTS..... AS RQRD

Ident.: PRO-NOR-SOP-06-A-00011161.0001001 / 14 SEP 12

**\*SIGNS**

\* SIGNS sw..... ON/AUTO  
 \* EMER EXIT LT selector..... ARM

*Note: Leaving the EXIT selector or NO SMOKING selector or NO PORTABLE/ELEC DEVICE selector  ON prevents the emergency batteries from charging.  
 If the CIDS has been programmed (option) for a non-smoking flight, NO SMOKING or NO PORTABLE/ELEC DEVICE  signs are permanently on, with the EXIT sw or NO SMOKING sw or NO PORTABLE/ELEC DEVICE sw  at AUTO (with permanent charge of emergency batteries).*

Ident.: PRO-NOR-SOP-06-A-00010176.0001001 / 03 MAR 14

**PROBE/WINDOW HEAT**

PROBE/WINDOW HEAT pb..... CHECK AUTO

Ident.: PRO-NOR-SOP-06-A-00011162.0001001 / 13 AUG 10

**CABIN PRESS**

LDG ELEV knob..... AUTO

Ident.: PRO-NOR-SOP-06-A-00011163.0010001 / 20 SEP 16

**\*AIR COND**

\* PACK FLOW selector..... AS RQRD

Select:

LO : If the number of occupants is below 141.

HI : For abnormally hot and humid conditions.

NORM : For all other normal operating cases.

*If the APU is supplying, pack controllers select HI flow automatically, independent of the selector position.*

Ident.: PRO-NOR-SOP-06-A-00011164.0001001 / 09 APR 15

**ELEC**

Scan and check that there are no amber lights, except GEN FAULT lights.

ELEC pb (on the ECAM Control Panel).....PRESS  
 BAT 1 pb-sw and BAT 2 pb-sw.....OFF then ON

*This action initiates a charging cycle of the batteries.*

10 s after setting all BAT pb-sw ON, check on the ELEC SD page that the current charge of the battery is below 60 A, and is decreasing.

- **If the charge of at least one battery is not below 60 A:**

Wait until the end of the charging cycle of the batteries and perform this check again.

Ident.: PRO-NOR-SOP-06-A-00011166.0002001 / 23 JUN 15

**\*FUEL**

- **If the center tank is less than 200 kg (440 lb) for the flight:**

Apply the following procedure, if your airline is affected by FUEL CTR TK PUMPS LO PR cautions on ground or in flight when the center tank is less than 200 kg (440 lb):

FUEL MODE SEL pb-sw.....MAN  
 CTR TK PUMP 1 pb-sw and CTR TK PUMP 2 pb-sw..... OFF

- **If the center tank is NOT less than 200 kg (440 lb) for the flight:**

**CAUTION** If the FUEL MODE SEL pb is unduly left in the MAN position on ground, when the CTR TK PUMP 1 pb & CTR TK PUMP 2 pb are not in the OFF position: There is a possibility of fuel spillage, if there are any hidden failures.

FUEL MODE SEL pb..... CHECK AUTO

Ident.: PRO-NOR-SOP-06-A-00011167.0001001 / 21 MAR 17

**ENG 1 - ENG 2 FIRE**


ENG 1 FIRE pb-sw and ENG 2 FIRE pb-sw .....CHECK IN and GUARDED  
 AGENT 1 light and AGENT 2 light ..... CHECK OFF  
 ENG 1 TEST pb and ENG 2 TEST pb ..... PRESS and MAINTAIN

*For ENG FIRE TEST description, Refer to DSC-26-20-20 FIRE Panel*

Ident.: PRO-NOR-SOP-06-A-00011169.0001001 / 14 SEP 12

**AUDIO SWITCHING PANEL**

AUDIO SWITCHING selector ..... NORM

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION</p>
---	--

Ident.: PRO-NOR-SOP-06-A-00010185.0001001 / 26 MAY 14

**VENT**

ALL LIGHTS.....CHECK OFF

Ident.: PRO-NOR-SOP-06-A-00011174.0001001 / 14 SEP 12

**THIRD OCCUPANT AUDIO CONTROL PANEL**

PA knob .....RECEPT

- This allows cabin attendant announcements to be recorded on the CVR.
- For proper recording, set volume at or above medium range.

Ident.: PRO-NOR-SOP-06-A-00011176.0001001 / 14 SEP 12

**MAINTENANCE PANEL**

ALL LIGHTS.....CHECK OFF

<b>CTR INSTRUMENT PANEL</b>
-----------------------------

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-06-B-00011184.0001001 / 21 MAR 16

**CTR INSTRUMENT PANEL - ISIS**

\* ISIS..... CHECK

- Adjust brightness, check IAS, altimeter readings, altimeter settings and attitude display.
- Check no flags - Reset attitude, if necessary.

Note: Use of the ISIS bugs function is not recommended (Refer to DSC-34-NAV-20 Bugs Function)



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION

Ident.: PRO-NOR-SOP-06-B-00011185.0009001 / 20 SEP 16

#### **\*CLOCK**

CLOCK.....CHECK/SET

*Note:* 1. If the date is incorrect, set the date manually then set and keep the clock mode to internal (INT) mode for the whole flight.

2. To comply with the time precision requirement (+/- 1 s UTC) for ATC datalink communication, the flight crew must either:

- Use the clock in GPS mode, or
- Use the clock in INT mode and synchronize the clock with the GPS at least one time per day. This synchronization ensures that the UTC time drift is below +/- 1 s UTC.

For more information on the setting of the clock, Refer to DSC-31-55-10 General.

For more information on the use of the internal (INT) mode, Refer to DSC-31-55-20 Operation in Internal Mode.

Ident.: PRO-NOR-SOP-06-B-00011186.0001001 / 13 AUG 10

#### **NOSEWHEEL STEERING**

\* A/SKID & N/W STRG sw..... ON

### PEDESTAL

Applicable to: ALL

Ident.: PRO-NOR-SOP-06-C-00011187.0001001 / 13 AUG 10

#### **ACP**

INT knob ..... PRESS OUT / VOLUME CHECK

*Make sure that INT volume is turned up to permit contact with the ground crew.*

VHF ..... CHECK

*Check transmission and reception.*

HF (if required for flight).....CHECK

- Check transmission and reception.
- Do not transmit on HF during refueling.

Ident.: PRO-NOR-SOP-06-C-00011191.0001001 / 23 JUN 15

#### **COCKPIT DOOR**

If required by local Airworthiness Authorities:

ANN LT selector..... TEST

*Check that the OPEN and FAULT lights (on the pedestal), and the three LED lights (on the overhead panel) come on.*

ANN LT selector..... BRT

*Check that all lights go off.*

CKPT DOOR..... CHECK CORRECT OPERATION

- Set the COCKPIT DOOR sw to the UNLOCK position. Check that the door opens, and that the OPEN light comes on
- Then, with the door fully open, release the COCKPIT DOOR sw (check that it returns to NORM position). Close the door. Check that it is locked, and that the OPEN Indication goes off.

CKPT DOOR MECHANICAL OVERRIDE..... CHECK

*Check that the door opens normally, and that it closes when the mechanical override is used.*

Ident.: PRO-NOR-SOP-06-C-00011189.0001001 / 14 SEP 12

**SWITCHING PANEL**

All selectors..... CHECK NORM

Ident.: PRO-NOR-SOP-06-C-00011192.0001001 / 12 JUL 13

**\*ENG**

\* THRUST lever ..... IDLE

\* ENG MASTER sw ..... OFF

\* ENG MODE selector..... NORM

Ident.: PRO-NOR-SOP-06-C-00011195.0001001 / 06 SEP 16

**\*PARKING BRK**

ACCU PRESS indicator..... CHECK

*The ACCU PRESS indication must be in the green band. If required, use the electric pump on yellow hydraulic system to recharge the brake accumulator.*

**WARNING** Yellow and green hydraulic systems are pressurized from yellow electric pump. Get ground crew clearance before using the electric pump.

\* PARK BRK handle..... CHECK ON

\* BRAKES PRESS indicator..... CHECK

*Check for normal indications.*



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**

**FLIGHT CREW  
OPERATING MANUAL**

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION

● **If brakes are hot and chocks are in place:**

PARK BRK handle .....OFF

*This action increases the brake cooling.*

Ident.: PRO-NOR-SOP-06-C-00011198.0001001 / 07 FEB 11

**GRAVITY GEAR EXTN**

GRAVITY GEAR EXTN..... CHECK STOWED

Ident.: PRO-NOR-SOP-06-C-00011199.0001001 / 21 MAR 17

**ATC**

\* ATC ..... STBY

*ATC and TCAS are on standby. To prevent possible interference to radar surveillance systems, TCAS should not be selected before the holding point/lining up.*

ALT RPTG .....ON

ATC SYS 1..... SELECT

*For RVSM operations (Refer to PRO-SPO-50 General), select SYS 1 if AP 1 is used, and SYS 2 if AP 2 is used.*

*Only system 1 is available, in emergency electrical configuration.*

**RMP**

Ident.: PRO-NOR-SOP-06-00011202.0001001 / 30 JUN 14

**Applicable to: ALL**

RMP..... CHECK ON

Green NAV light.....CHECK OFF

SEL light.....CHECK OFF

COM FREQUENCIES..... TUNE

*Use VHF 1 for ATC (only VHF 1 is available in emergency electrical configuration), VHF 2 for ATIS and company frequencies. VHF 3 is normally devoted to ACARS.*

**ACARS**

Ident.: PRO-NOR-SOP-06-00011224.0001001 / 24 SEP 14

**Applicable to: ALL**

\* Initialize ACARS at that point or after FMGS PREPARATION, as per company policy.

**FMGS PREPARATION**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-06-D-00011226.0001001 / 13 AUG 10

At electrical power-up, the FMGS s and FCU run through various internal tests. Allow enough time (3 min) for tests' completion, and do not start to press pushbuttons until the tests are over. If the "PLEASE WAIT" message appears, do not press any MCDU key until the message clears.

Ident.: PRO-NOR-SOP-06-D-00011227.0001001 / 03 MAR 14


\* ENGINE & AIRCRAFT TYPE..... CHECK

*Press the DATA key, and display the STATUS page (if not displayed).*

Ident.: PRO-NOR-SOP-06-D-00011228.0001001 / 17 JUN 14

\* FM database validity..... CHECK

- Check DATA BASE validity and stored WPT /NAVAID S/RWY/ROUTES, if any.  
*If applicable, review the stored data for deletion decision.*
- On Honeywell FMS , the double AIRAC cycle of the NDB has one day in common (AIRAC#1 day 28 / AIRAC#2 day1) (Refer to DSC-22\_20-50-10-25 Aircraft Status Page).



*If the CHECK DATA BASE CYCLE message triggers, the active database is no longer valid. Therefore, on Day 28 of AIRAC Cycle #1, select AIRAC Cycle#2 prior to the first flight of the day.*

Ident.: PRO-NOR-SOP-06-D-00011229.0001001 / 28 MAR 11

\* NAVAID DESELECTION.....AS RQRD

*If NOTAMs warn of any unreliable DME or VOR /DME , display DATA, then POSITION MONITOR. Access the SEL NAVAID page, and deselect the related NAVAID.*


Ident.: PRO-NOR-SOP-06-D-00011231.0003001 / 20 AUG 12

\* FLIGHT PLAN INITIALIZATION.....COMPLETE

- Press the INIT key
- Insert CO RTE or city pair, and check FROM/TO
- Check/modify ALTN /CO RTE

- Enter flight number

*Note:* For ATC needs, the crew should enter exactly the entire flight number, as shown on the ICAO flight plan, without inserting any space, on the MCDU INIT page.

- Enter (and/or check) cost index
- Enter intended initial CRZ FL, or check if it was already supplied by the database. Modify it, if necessary, taking into account ATC constraints or expected gross weight
- Check and modify CRZ FL TEMP and tropopause level to agree with forecast
- Enter (and/or check) the expected ground temperature for take off (GND TEMP) 
- PRESS IRS INIT prompt
- Check alignment latitude/longitude.

Ident.: PRO-NOR-SOP-06-D-00011232.0001001 / 17 MAR 17

\* ADIRS POSITION INITIALIZATION.....AS APPROPRIATE  
 Confirm or insert position coordinates for the IRS alignment. Refer to FCTM/PR-NP-SOP-60 FMGS Preparation.

 IRS Alignment Based on GPS  Position available:

The position initialization is automatic. The position for the initialization of the IRS is the GPS position. However, the flight crew can manually override the automatic position initialization. The IRS crosschecks the flight crew's manual entry with the GPS position.

IRS Alignment Based on GPS  Position not available:

Apply the manual position initialization procedure.

Ident.: PRO-NOR-SOP-06-D-00011233.0015001 / 20 JUL 15

\* F-PLN A page.....COMPLETE AND CHECK  
 If CO RTE has been inserted, the F-PLN should automatically include the preferential or probable takeoff runway approach and landing runway, associated SID s, STAR s, transition and en-route waypoints. However some databases will only include departure and arrival airport IDENTs and en-route waypoints.



The flight crew must check, modify, or insert (as applicable) the F-PLN in the following order, according to the data given by ATIS , ATC, or MET:

- Lateral revision at departure airport. Select RWY , then SID , then TRANS using scroll keys.

Note: On the MCDU departure page, select only a runway associated with an ILS or NO NAVAIDS.

- Lateral revision at WPT for ROUTE modification if needed. (Refer to DSC-22\_20-30-10-05 Lateral Revisions).
- Vertical revision. Check or enter climb speed limit, constraints according to ATC clearance. Enter step altitude as appropriate.

\* WINDS..... AS APPROPRIATE

Choose between using trip wind and the forecast wind for CLB , CRZ and DES phases.(Refer to DSC-22\_20-30-20-05 Flight Phases).

\* F-PLN ..... CHECK

- Check the F-PLN using F-PLN page and ND PLAN mode versus the computer (paper) flight plan or navigation chart.
- Check DIST TO DEST along the F-PLN. Compare it with the total distance computed for the flight with the computer (paper) flight plan.

Ident.: PRO-NOR-SOP-06-D-00011234.0001001 / 18 MAR 11








\* SECONDARY FLIGHT PLAN..... AS APPROPRIATE

This is routinely a copy of the active flight plan. However, consideration may be given to the following:

- Copy the active F-PLN , but modify it at a suitable WPT for an immediate return to the departure airfield in the event of, for example, engine failure
- If weather is below landings minima at the departure airfield, the secondary flight plan should be that required for a diversion immediately after takeoff
- If there is a chance of a change in runway or SID during taxi, prepare for it by copying the active flight plan and making the necessary modifications.

Ident.: PRO-NOR-SOP-06-D-00011235.0001001 / 10 JUN 16

\* RADIO NAV..... CHECK

- Check the VOR , ILS / GLS  / MLS  , and ADF  tuned by the FMGC
- Modify them if required, and check that the correct identifier is displayed on the ND and PFD (VOR , ILS / GLS  / MLS  ). If unsatisfactory, go through the audio check. For GLS  / MLS  , no audio check is necessary.

**CAUTION** Do not enter an IDENT or channel associated with a GLS  / MLS  .

Ident.: PRO-NOR-SOP-06-D-00011238.0003001 / 20 MAR 17

**GROSS WEIGHT INSERTION (INIT B PAGE):**

- \* ZFW/ZFWCG..... INSERT
- \* BLOCK FUEL.....INSERT

If the LOADSHEET application is used, the PF enters the ZFWCG and ZFW as computed on his EFB.

**CAUTION** The characteristic speeds displayed on the MCDU (green dot, F, S, VLS ) are computed from the ZFW and ZFWCG entered by the crew on the MCDU. Therefore, this data must be carefully checked (Captain's responsibility).

- The flight crew should insert the weights after completing all other insertions. This is to avoid cycles of prediction computations at each change in flight plan, constraints, etc.
- If ZFW and ZFWCG are unavailable, it is acceptable to enter the expected values in order to obtain predictions. Similarly, the flight crew may enter the expected fuel on board, if refueling has not been completed at that time.
- If ZFW , ZFWCG, and BLOCK FUEL are inserted, the FM will provide all predictions, as well as the EXTRA fuel, if any.

Ident.: PRO-NOR-SOP-06-D-00011240.0001001 / 20 MAR 17

**TAKEOFF DATA INSERTION (PERF TAKEOFF PAGE):**

The PF inserts the takeoff data (computed on his EFB ) in the PERF TAKEOFF page of the MCDU.

- \* V1 , VR , V2..... INSERT
- \* FLX TO TEMP.....INSERT
- \* THR RED/ACC altitude..... SET or CHECK
- \* ENG OUT ACC altitude.....SET or CHECK
- \* FLAPS/THS reminder..... INSERT
- \* TO SHIFT..... AS RQRD

*Enter the takeoff SHIFT distance, if takeoff is to be from an intersection. This is essential for position updating at takeoff and, consequently, for navigation accuracy.*

- \* EFB / MCDU GREEN DOT..... COMPARE

Ident.: PRO-NOR-SOP-06-D-00011243.0001001 / 13 AUG 10

**CLIMB, CRUISE, DESCENT, SPEED PRESELECTION**

- \* PRESET SPEEDS.....AS RQRD

*If the flight is cleared for a close-in turn or close-in altitude constraint, the flight crew may preselect green dot speed on the PERF CLB page. Once the CLB phase is active, the preselected speed*

will be displayed in the FCU speed window and on the PFD (blue symbol). Once the turn is completed or the altitude cleared, the pilot will resume the managed speed profile by pressing the SPD selector on the FCU.

Similarly the pilot may select a CRZ MACH number on the PERF CRZ page (constant CRZ Mach segment, for example). When the CRZ phase is active, the preselected CRZ MACH number will be displayed in the FCU speed window and on the PFD. When ECON MACH number may be resumed, the crew presses the FCU SPD selector.

In either of the above cases, the pilot may cancel the CLB or CRZ preselected SPD /MACH prior to activating the related phase, by selecting ECON on the PERF CLB or CRZ pages.

SPD LIM is defaulted to 250 kt below 10 000 ft in the managed speed profile. This may be either cleared or modified on the VERT REV page at the origin (or a climb waypoint).

Ident.: PRO-NOR-SOP-06-D-00015496.0001001 / 20 MAR 17

**CHECK OF FMGS PREPARATION:**

\* FMS PREPARATION..... CHECK

After the PF prepared the FMS , the PM checks:

- The airfield data.
- All FMS entered data.
- The takeoff performance data with the data computed on his EFB.

GROSS WEIGHT INSERTION..... CHECK/CROSSCHECK

If the LOADSHEET application is used, the PM checks the ZFWCG and ZFW that the PF has entered in the FMGS with the loadsheet data computed on PM 's EFB.

TAKEOFF DATA INSERTION.....CROSSCHECK

The PM crosschecks the takeoff data that the PF has entered in the FMGS , with the takeoff data computed on PM 's EFB using the TAKEOFF application.

EFB /MCDU GREEN DOT..... COMPARE

The PM compares Green Dot speed computed by the FMGS and the Green Dot speed computed using the TAKEOFF application. A discrepancy indicates a difference in the TOW used in both systems (EFB /FMGS).

**GLARESHIELD**

Applicable to: ALL

Ident.: PRO-NOR-SOP-06-E-00020832.0001001 / 17 MAR 17

**\*EFIS CONTROL PANEL**

\* BAROMETRIC REFERENCE..... SET

- Set QNH (or QFE  $\nabla$ ) on the EFIS control panel and on the standby altimeter
- Check the barometric reference and altitude indications on the PFDs and on the standby altimeter.

**The maximum difference is:**

$\pm 20$  ft between both PFDs

**And depending on the aircraft configuration:**

$\pm 60$  ft between ISIS  $\nabla$  and PFDs, or

$\pm 300$  ft between mechanical standby altimeter and PFDs.

\* FD..... CHECK ON

\* ILS/LS..... AS RQRD

\* ND MODE and RANGE ..... AS RQRD

\* ADF/VOR sw ..... AS RQRD

*Display VOR and ADF pointers as needed.*

Ident.: PRO-NOR-SOP-06-E-00011248.0001001 / 24 SEP 14

**\*FCU**

\* SPD MACH window..... DASHED

\* HDG V/S -TRK FPA pb..... HDG V/S

\* ALT window..... INITIAL EXPECTED CLEARANCE ALT


Note: *Do not engage the autothrust on ground, as it may generate the AUTO FLT A/THR OFF warning at engine start.*

**LATERAL CONSOLES**

Ident.: PRO-NOR-SOP-06-00011249.0002001 / 23 JUN 15

Applicable to: ALL

**OXYGEN MASK TEST**



**WARNING** To prevent hearing damage to ground mechanics connected to the intercom system, inform them that a loud noise may be heard in the headset when performing this test.

- On the OXYGEN panel:  
 CREW SUPPLY pb..... CHECK ON
- On the glareshield:  
 LOUDSPEAKERS.....ON
- On the audio control panel:  
 INT reception knob..... PRESS OUT-ADJUST  
 INT/RAD sw.....INT
- On the mask stowage box:

**PROCEDURES**  
**NORMAL PROCEDURES**

**STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION**

- Press and hold the reset/test button in the direction of the arrow.
  - Check that the blinker turns yellow for a short time, and then goes black.
- Hold the reset/test button down, and press the emergency pressure selector.
  - Check that the blinker turns yellow and remains yellow, as long as the emergency pressure selector is pressed.
  - Listen for oxygen flow through the loudspeakers. Warn any engineer, whose headset may be connected to the nose intercom, that a loud noise may be heard when performing this check.
- Check that the reset/test button returns to the up position and the N 100 % selector is in the 100 % position.
- Press the emergency pressure selector again, and check that the blinker does not turn yellow. This ensures that the mask is not supplied.

On the ECAM DOOR/OXY page:

REGUL LO PR message.....CHECK OFF

*The crew must perform this check after having checked all masks. It ensures that the LP valve is open, (due to residual pressure between the LP valve and the oxygen masks, an LP valve failed in the closed position may not be detected during the oxygen mask test).*

**INSTRUMENT PANELS**

Ident.: PRO-NOR-SOP-06-00011252.0001001 / 17 MAR 16

Applicable to: **ALL**

PFD and ND brightness knob.....AS RQRD

*Check the ND outer ring is set to maximum brightness (radar/terrain display).*

LOUDSPEAKER knob .....SET


*Set the LOUDSPEAKER knob around the 1 o'clock position.*

\* PFD.....CHECK

- *Check PFD /ND not transferred.*
- *Check for correct display, when ATT and HDG are available.*
- *Check IAS , FMA , initial target ALT , altimeter readings, VSI, altimeter settings, heading and attitude display.*

\* ND.....CHECK

- *Check for correct display.*
- *Crosscheck compass indication on the ND and DDRMI.*
- *Check heading, initial waypoint, VOR ADF indications.*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p>STANDARD OPERATING PROCEDURES - COCKPIT PREPARATION</p>
---	--

**ECAM CONTROL PANEL**

Ident.: PRO-NOR-SOP-06-00011190.0001001 / 24 FEB 15  
**Applicable to: ALL**

**\*ECAM CONTROL PANEL**

- \* PRESS pb ..... PRESS  
*Check that the CAB PRESS page displays LDG ELEV AUTO, to confirm the correct position of the LDG ELEV knob.*
- \* STS pb .....PRESS  
*Check that INOP SYS display is compatible with MEL.  
 If a message is displayed in MAINTENANCE STATUS, Refer to MMEL/MI-00-08 ECAM and MAINTENANCE STATUS.*

**ADIRS**

Ident.: PRO-NOR-SOP-06-00011253.0002001 / 20 MAR 17  
**Applicable to: ALL**

- \* IRS ALIGN.....CHECK  
*On the POSITION MONITOR page, check that the IRS are in NAV mode, and check that the distance between each IRS and the FMS position is lower than 5 NM. Select ND in ROSE-NAV or ARC mode, and confirm that the aircraft position is consistent with the position of the airport, the SID and the surrounding NAVAIDs.*
- NAV CHARTS CLIPBOARD.....PREPARE

**TAKEOFF BRIEFING**

Ident.: PRO-NOR-SOP-06-00011256.0001001 / 20 MAR 17  
**Applicable to: ALL**

- \* TAKEOFF BRIEFING.....PERFORM

**PC DEDICATED TO MAINTENANCE **

Ident.: PRO-NOR-SOP-06-00011258.0001001 / 07 FEB 11  
**Applicable to: ALL**

- Check that the Personal Computer (PC) dedicated to maintenance use and located in front of lower stowage at RH rear corner is stowed.
- Check that the light of its manual switch is off. If not, switch it off.
- Check that its associated printer located in front of RH rear of the cockpit is stowed.

**FLOW PATTERN**


Ident.: PRO-NOR-SOP-06-00020280.0001001 / 17 MAR 17

Applicable to: ALL

**COCKPIT PREPARATION - FLOW PATTERN**

The scan pattern varies, depending on the pilot status, i.e PF , PM , CM1 , or CM2, and the areas of responsibility:

1. Overhead panel
2. Center instrument panel
3. Pedestal
4. FMGS preparation, and when both pilots are seated:
5. Glareshield
6. Lateral consoles and CM1/CM2 panels.





**BEFORE START CLEARANCE**

Applicable to: ALL

Ident.: PRO-NOR-SOP-07-A-00021624.0001001 / 19 APR 17

**LOADSHEET**

FINAL LOADSHEET.....CHECK

*Both crew members carefully check the Load and Trim Sheet (LTS), particularly for gross errors. Make sure that the load sheet data is correct (e.g correct flight, correct aircraft, dry operating index, configuration, Fuel on Board, etc.).*

ZFW /ZFWCG..... CHECK/REVISE

*The PF compares the ZFW and the ZFWCG with the previously-entered data, and adjust if necessary.*

ZFW /ZFWCG.....CROSSCHECK

*The PM crosschecks the ZFW and the ZFWCG entered in the FMS*

Check that the takeoff CG is within LTS operational limits.

FINAL LOADSHEET (CM1)..... SIGN and EXPORT

*If the loadsheet is modified, or if required by the authorities or by the airline policy, the CM1 sends the loadsheet to the ground via the EXPORT function on the LOADSHEET application.*

Ident.: PRO-NOR-SOP-07-A-00011255.0009001 / 09 JUN 15

FOB..... CHECK

- Check that ECAM fuel on board corresponds to the F-PLN.
- Check that fuel imbalance is within limits.
- Crosscheck that the sum of the Fuel On Board (FOB ) recorded at the end of the last flight and the fuel uplift (if any) is consistent with the current FOB. If an abnormal discrepancy is found, a maintenance action is due.

FOB after refuelling:	Abnormal discrepancy above:
Up to 6 tons (13200 lb)	400 kg (900 lb)
Between 6 tons (13200 lb) and 12 tons (26500 lb)	500 kg (1100 lb)
More than 12 tons (26500 lb)	600 kg (1300 lb)



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES  
- BEFORE PUSHBACK OR START

Ident.: PRO-NOR-SOP-07-A-00010189.0002001 / 20 MAR 17

#### **TAKEOFF DATA**

FINAL TAKEOFF DATA..... CONFIRM or RECOMPUTE

- *If takeoff conditions did not change, verify and confirm that the preliminary takeoff data are still valid*
- *If takeoff conditions have changed, calculate the final takeoff performance, using the T.O. PERF application on the EFB.*

FMS TAKEOFF DATA.....CHECK/REVISE AS RQRD

*The PF checks (or revises) the takeoff data on the INIT B and PERF pages of the MCDU.*

REVISED FMS TAKEOFF DATA.....CROSSCHECK

*The PM crosschecks the takeoff data on the MCDU (i.e. weights, speeds, flexible temperature, takeoff configuration), with the PM 's EFB takeoff data.*

EFB /MCDU GREEN DOT..... COMPARE

*The PM compares Green Dot speed computed by the FMGS and the Green Dot speed computed using the TAKEOFF application. A discrepancy indicates a difference in the TOW used in both systems (EFB /FMGS).*

Ident.: PRO-NOR-SOP-07-A-00010190.0001001 / 04 MAR 14

#### **SEATING POSITION**

SEATING POSITION..... ADJUST

*The seat is correctly adjusted, when the pilot's eyes are in line with the red and white balls.*

Ident.: PRO-NOR-SOP-07-A-00010192.0001001 / 23 DEC 14

#### **MCDU**

FMS PERF TO page..... SELECT

*It is recommended to display the PERF TO page on the PF side.*

FMS F-PLN page.....SELECT

*It is recommended to display the F-PLN page on the PM side*


Ident.: PRO-NOR-SOP-07-A-00010193.0001001 / 17 MAR 16

#### **ELEC**

EXT PWR.....CHECK AVAIL

#### **WARNING**

Disconnection of the external power with the EXT PWR pb-sw ON may cause injury to the ground engineer. Request disconnection of the external power only with the EXT PWR pb-sw AVAIL.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b></p> <p align="center"><b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - BEFORE PUSHBACK OR START</p>
---	---

EXT PWR DISCONNECTION..... REQUEST

Ident.: PRO-NOR-SOP-07-A-00021505.0001001 / 20 MAR 17

EFB/eQRH transmitting mode..... CONSIDER  
*In accordance with the Operator's policy or, as required by operational regulations.*

Ident.: PRO-NOR-SOP-07-A-00010194.0001001 / 12 FEB 13

**BEFORE START CHECKLIST DOWN TO THE LINE**

BEFORE START CHECKLIST down to the line..... COMPLETE

**AT START CLEARANCE**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-07-B-00010197.0001001 / 04 MAR 14

**PUSHBACK/START UP CLEARANCE**

PUSHBACK/START CLEARANCE..... OBTAIN  
*Obtain ATC pushback/startup clearance.*  
*Obtain ground crew clearance.*

Ident.: PRO-NOR-SOP-07-B-00015568.0001001 / 20 JAN 15

ATC..... SET FOR OPERATION  
*ATC is set in accordance with airport requirements.*

Ident.: PRO-NOR-SOP-07-B-00010199.0002001 / 04 MAR 14

**WINDOWS AND DOORS**

WINDOWS and DOORS..... CHECK CLOSED

- *To ensure that the sliding window is correctly closed and locked, push the handle of the sliding window fully forward to the closed position, and check that the red indicator is visible*
- *Check, on the ECAM lower display, that all the aircraft doors are closed*
- *When required by local airworthiness authorities, check that the cockpit door is closed and locked (no cockpit door open/fault indication).*

*If entry is requested, identify the person requesting entry before unlocking the door. With the cockpit door sw on NORM, the cockpit door is closed and locked. If entry is requested from the cabin, and if no further action is performed by the pilot, the cabin crew will be able to unlock the door by using the emergency access procedure. Except for crew entry/exit, the cockpit door should remain closed until engine shutdown.*

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
 - BEFORE PUSHBACK OR START

SLIDES.....CHECK ARMED

- Check, on the ECAM lower display, that all slides are armed.

ident.: PRO-NOR-SOP-07-B-00010200.0001001 / 04 MAR 14

**EXTERIOR LIGHTS**

BEACON sw..... ON

ident.: PRO-NOR-SOP-07-B-00010201.0001001 / 04 MAR 14

**THRUST LEVERS**

THRUST LEVERS..... IDLE

**CAUTION** Engines will start, regardless of the thrust lever position; thrust will rapidly increase to the corresponding thrust lever position, causing a hazardous situation, if thrust levers are not at IDLE.

ident.: PRO-NOR-SOP-07-B-00016807.0001001 / 06 SEP 16

**ACCU PRESSURE**

ACCU PRESS indicator..... CHECK

*The ACCU PRESS indication must be in the green band. If required, use the electric pump on yellow hydraulic system to recharge the brake accumulator.*

**WARNING** Yellow and green hydraulic systems are pressurized from yellow electric pump. Get ground crew clearance before using the electric pump.

ident.: PRO-NOR-SOP-07-B-00010202.0002001 / 24 NOV 15

**PARKING BRAKE AND NOSEWHEEL STEERING**

● **If pushback is not required:**

PARK BRK handle..... CHECK ON

BRAKES PRESS indicator..... CHECK

*Check for normal indications.*

BEFORE START CHECKLIST below the line.....COMPLETE

ident.: PRO-NOR-SOP-07-B-00010198.0002001 / 21 MAR 17

● **If pushback is required:**

N/W STRG DISC MEMO..... CHECK DISPLAYED

*In case of pushback (conventional or towbarless), the nosewheel steering selector bypass pin must be in the tow position. The ECAM's NW STRG DISC, or N WHEEL STEERG DISC memos indicate this to the flight crew.*

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES  
 - BEFORE PUSHBACK OR START

**CAUTION** *If the ECAM does not display the N WHEEL STEERG DISC memo, but the ground crew confirms that the tow pin is in the towing position, the flight crew should not start the engine during pushback. This is to avoid possible nose landing gear damage upon yellow hydraulic pressurization. To dispatch the aircraft in such a case, Refer to MMEL/MI-32-51 NWS Electrical Deactivation Box.*

*In case of a powerpush by the main landing gear, the nosewheel steering selector should remain in the normal position to steer the aircraft (Refer to PRO-NOR-SUP-MISC-D Pushback with Power Push Unit via the Main Landing Gear - Procedure 1/2).*

BEFORE START CHECKLIST below the line..... COMPLETE  
 PARK BRK handle ..... OFF

**CAUTION** *Do not use the brakes during pushback, unless required due to an emergency.*

● **When pushback is completed:**

PARK BRK handle ..... ON  
 BRAKE PRESS indicator..... CHECK

*Check for normal indications.*

*Ask the ground crew for towbar disconnection.*




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES  
- BEFORE PUSHBACK OR START

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> STANDARD OPERATING PROCEDURES - ENGINE START
---	---

**AUTOMATIC ENGINE START**

Ident.: PRO-NOR-SOP-08-00010162.0060001 / 31 AUG 17

**Applicable to: ALL**

Use the automatic engine start procedure in most circumstances. However, if the start aborts due to insufficient starter inlet air pressure (e.g. on high airfields, or in case of low pressure from an external pneumatic power group), it is recommended to use the manual start procedure, instead the automatic procedure.

If, during the engine start, the ground crew reports a fuel leak from the engine drain mast, run the engine at idle for 5 min. If the leak disappears during these 5 min, the aircraft can be dispatched without maintenance action. If the leak is still present after 5 min, shut down the engine and request the maintenance personnel to investigate the leakage source.

ENG MODE selector ..... IGN/START

*The lower ECAM displays the ENG SD page.*

ENGINE 2 START ..... ANNOUNCE

*Engine 2 is usually started first. It powers the yellow hydraulic system, that pressurizes the parking brake.*

ENG MASTER 2 ..... ON

- Do not set the ENG MASTER 2 lever to ON before all amber crosses and messages have disappeared on the engine parameters (upper ECAM display).
- Parameter callouts are not mandatory.
- In case the electrical power supply is interrupted during the start sequence (indicated by the loss of ECAM DUs), abort the start by setting to OFF the ENG MASTER 2 lever. Then, perform a 30 s dry crank.

ON ECAM UPPER DISPLAY	ON ECAM LOWER DISPLAY
N2 increases	Corresponding start valve in line. Bleed pressure indication green. Oil pressure increases.
At 16 % N2	Indication of the active igniter (A or B).
At 22 % N2 - FF increases  15 s (maximum) after fuel is on - EGT increases - N1 increases	
At 50 % N2	Start valve starts closing. (It is fully closed between 50 % and 56 % N2). Igniter indication off.

● **When idle is reached (AVAIL indication is displayed):**

ENG IDLE PARAMETERS..... CHECK

At ISA sea level : N1 about 19.5 %  
N2 about 58.5 %  
EGT about 390 °C  
FF about 275 kg/h (600 lb/h)

Grey background on N2 indication disappears.

ENGINE 1 START..... ANNOUNCE

ENG MASTER 1..... ON

Same procedure as for engine 2.

Both pack valves reopen with 30 s delay after the second engine N2 is above 50 %.


Note: A PTU FAULT is triggered, if the last engine is started within 40 s following the end of the cargo doors operation. Refer to PRO-ABN-HYD HYD PTU FAULT.



**GROUND RUN UP - DANGER AREAS**

Ident.: PRO-NOR-SOP-08-00010163.0006001 / 06 JAN 16

Applicable to: ALL




**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - ENGINE START

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - AFTER START</p>
---	--

**AFTER START**

Applicable to: ALL

Ident.: PRO-NOR-SOP-09-A-00010210.0002001 / 21 MAR 17

**ENG MODE**

ENG MODE selector ..... NORM

*For additional information on the automatic starting sequence, Refer to DSC-70-80-40 Sequence of the Automatic Start.*

After start, to avoid thermal shock, the pilot should operate the engine at idle or near idle for at least 2 min before advancing the thrust lever to high power. Taxi time at idle may be included in the warm-up period.

The last engine started must run for at least 2 min before takeoff initiation, to ensure that takeoff is not initiated before the center tank pumps test is finished, since takeoff on center tank is prohibited.

Ident.: PRO-NOR-SOP-09-A-00010211.0001001 / 26 OCT 12

**APU BLEED**

APU BLEED pb-sw..... OFF

- This action enables to avoid ingestion of engine exhaust gases.
- APU BLEED valve closes, ENG BLEED valves open.

Ident.: PRO-NOR-SOP-09-A-00010212.0005001 / 17 MAR 17

**ANTI-ICE**

**CAUTION** In icing conditions (*Refer to LIM-ICE\_RAIN Definition of Icing Conditions*), the flight crew must turn on the engine anti-ice and should not wait until seeing ice building up.

ENG ANTI-ICE pb-sw ..... AS RQRD

*Engine anti-ice must be set to ON during all ground operation, when icing conditions exist or are anticipated.*

*During ground operation, when in icing conditions for more than 30 min, the following procedure should be applied for ice shedding :*

**CAUTION** *If, during thrust increase, the aircraft starts to move, immediately retard the thrust levers to IDLE.*

*If ground surface conditions and the environment permit, the flight crew should accelerate the engines to approximately 70 % of N1 for 30 s at intervals not greater than 30 min.*

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - AFTER START

*In addition, this engine acceleration should also be performed just before take-off, with particular attention to engine parameters to ensure normal engine operation. If ground surface or environment do not permit to accelerate the engine to 70 % N1, then power setting and dwell time should be as high as practical.*

*When operating in conditions of freezing rain, freezing drizzle, freezing fog or heavy snow, ice shedding may be enhanced, by additional run ups at intervals, to not exceed 10 min, advancing throttles to 70 % N1 momentarily (no hold time).*

Ident.: PRO-NOR-SOP-09-A-00010213.0001001 / 21 MAR 17

WING ANTI-ICE pb-sw..... AS RQRD

*When icing conditions are encountered:*

- *The flight crew may turn on the wing anti-ice to prevent ice accretion on the wing leading edge.*
- *The flight crew must turn on the wing anti-ice if there is evidence of ice accretion, such as ice on the visual indicator, or on the wipers, or with the **SEVERE ICE DETECTED** alert. This is to remove any ice accumulation from the wing leading edge.*

Ident.: PRO-NOR-SOP-09-A-00010214.0001001 / 04 MAR 14

**APU**

- **If the APU is not required:**

APU MASTER SW..... OFF

Ident.: PRO-NOR-SOP-09-A-00010215.0001001 / 26 OCT 12

**GROUND SPOILERS**

GROUND SPOILERS..... ARM

Ident.: PRO-NOR-SOP-09-A-00010216.0001001 / 26 OCT 12

**RUDDER TRIM**

RUD TRIM position indication.....CHECK ZERO

- **If the RUD TRIM position indication is not at zero:**


RESET pb..... PRESS

*Note: After the reset, the flight crew may observe an indication of up to 0.3 ° (L or R) in the RUD TRIM position indication.*

Ident.: PRO-NOR-SOP-09-A-00010217.0001001 / 26 OCT 12

**FLAPS**

FLAPS lever..... SET FOR TAKEOFF

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - AFTER START</p>
---	--

FLAPS..... CHECK POSITION

*Check the position of the flaps on the ECAM upper display.*

● **If taxiing in icing conditions with rain, slush or snow:**

Maintain the flaps retracted until the aircraft reaches the holding point of the takeoff runway.

*This action prevents contamination of the slats/flaps mechanism.*

Ident.: PRO-NOR-SOP-09-A-00010218.0001001 / 26 OCT 12

**PITCH TRIM**

PITCH TRIM handwheel..... SET

*Set takeoff CG on pitch trim handwheel.*

Ident.: PRO-NOR-SOP-09-A-00010220.0001001 / 01 DEC 14

**ECAM STATUS**

STATUS REMINDER..... CHECK NOT DISPLAYED

● **If STS reminder is displayed:**

STS pb..... PRESS

Review the ECAM Status page.

Ident.: PRO-NOR-SOP-09-A-00015495.0001001 / 23 JUN 15

**N/W STEER DISC MEMO**

N/W STEER DISC MEMO..... CHECK NOT DISPLAYED

Ident.: PRO-NOR-SOP-09-A-00010221.0001001 / 05 NOV 15

**GROUND CREW**

CLEAR TO DISCONNECT..... ANNOUNCE

*The ground crew:*

- *Removes the chocks*
- *Disconnects the interphone*
- *Makes the hand signal on the left or right side.*

Ident.: PRO-NOR-SOP-09-A-00010222.0001001 / 26 OCT 12


**AFTER START CHECKLIST**


AFTER START CHECKLIST..... COMPLETE

Ident.: PRO-NOR-SOP-09-A-00020074.0001001 / 17 MAR 17

**AFTER START - FLOW PATTERN**

When the engines have started, the PF sets the ENG MODE selector to NORM to permit normal pack operation. At this time, the After Start Flow Pattern begins.



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> STANDARD OPERATING PROCEDURES - TAXI
---	---

**TAXI**

Applicable to: ALL

Ident.: PRO-NOR-SOP-10-A-00010226.0001001 / 15 MAY 13

**TAXI CLEARANCE**

TAXI clearance.....OBTAIN

Ident.: PRO-NOR-SOP-10-A-00010227.0001001 / 21 MAR 17

**EXTERIOR LIGHTS**

NOSE sw.....TAXI

● **When crossing a runway:**

STROBE sw.....ON

RWY TURN OFF & CAMERA sw  .....ON

 *The PF may ask the PM to set the exterior lights.*

Ident.: PRO-NOR-SOP-10-A-00010228.0001001 / 15 MAY 13

**PARK BRK**

PARK BRK handle.....OFF

BRAKES PRESSURE.....CHECK AT ZERO


*The flight crew may observe slight residual pressure on the triple indicator for a short period of time.*

Ident.: PRO-NOR-SOP-10-A-00010230.0001001 / 19 APR 17

**THRUST LEVER**

THRUST lever .....AS RQRD

*The flight crew will need a little power above idle thrust to move the aircraft.*

 For additional information on the thrust use during taxi, *Refer to FCTM/PR-NP-SOP-100 Taxi Roll and Steering.*

Ident.: PRO-NOR-SOP-10-A-00010231.0002001 / 17 MAR 17

**BRAKES**


**CAUTION** If the aircraft was parked in wet conditions for a long time, the first brake application at low speed is less effective.

BRAKE PEDALS.....PRESS

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - TAXI


BRAKES .....CHECK  
*If an arc is displayed above the brake temperature on the WHEEL SD page, set the brake fans  to ON.*

 For more information, *Refer to FCTM/PR-NP-SOP-100 Brake Check.*

ident.: PRO-NOR-SOP-10-A-00016023.0001001 / 17 MAR 17

**NOSEWHEEL STEERING**

TILLER or RUDDER PEDALS..... USE AS RQRD

 *For information on the nosewheel steering limitation, Refer to FCTM/PR-NP-SOP-100 Taxi Roll and Steering.*

ident.: PRO-NOR-SOP-10-A-00010243.0001001 / 22 MAR 17

**FLIGHT CONTROLS**

FLIGHT CONTROLS.....CHECK

 *For additional information on the flight controls check, Refer to FCTM/PR-NP-SOP-100 Flight Controls.*

ident.: PRO-NOR-SOP-10-A-00010244.0001001 / 15 MAY 13

**ATC CLEARANCE**

ATC clearance.....CONFIRM

ident.: PRO-NOR-SOP-10-A-00010248.0001001 / 20 MAR 17

**TAKEOFF DATA/CONDITIONS**

If the takeoff data has changed, or in the case of a runway change, prepare updated takeoff:

FINAL TAKEOFF DATA..... CONFIRM or RECOMPUTE

*If takeoff conditions changed, the PF and the PM independently compute again the takeoff data.*

FMS TAKEOFF DATA.....CHECK/REVISE AS RQRD

*If takeoff conditions changed, the PF revises the takeoff data in the FMS.*

REVISED FMS TAKEOFF DATA.....CROSSCHECK

*The PM crosschecks the takeoff data entered by the PF on the MCDU (i.e. weights, speeds, flexible temperature, takeoff configuration), with the PM 's EFB takeoff data.*

EFB/MCDU GREEN DOT.....COMPARE

*The PM compares Green Dot speed computed by the FMGS and the Green Dot speed computed using the TAKEOFF application. A discrepancy indicates a difference in the TOW used in both systems (EFB /FMGS).*

F-PLN (Runway)..... REVISE



FLAPS lever ..... AS APPROPRIATE  
*Select takeoff position.*  
 V1 , VR , V2..... REINSERT  
 FLX TO temperature.....REINSERT

Ident.: PRO-NOR-SOP-10-A-00015301.0001001 / 17 MAR 17

**AFS/FLIGHT INSTRUMENTS**

F-PLN (SID ,TRANS)..... REVISE or CHECK  
*Carefully confirm that the ATC clearance agrees with the FMS , if NAV mode is to be used.*  
 INITIAL CLIMB SPEED AND SPEED LIMIT..... MODIFY or CHECK  
*Use VERT REV at departure, or at a CLB waypoint.*  
 CLEARED ALTITUDE ON FCU ..... SET  
 HDG ON FCU .....IF REQUIRED, PRESET  
*If a heading is required by the ATC after takeoff, in case of a radar vector departure, preset the heading on the FCU . NAV mode will be disarmed.*  
*RWY TRK mode will keep the aircraft on the runway track.*  
 BOTH FD .....CHECK ON  
 PFD /ND ..... CHECK  
 TAKEOFF BRIEFING.....CONFIRM

**L2** *For additional information on the takeoff briefing confirmation, Refer to FCTM/PR-NP-SOP-100 Takeoff Briefing Confirmation.*

Ident.: TDU / PRO-NOR-SOP-10-A-00015299.0002001 / 03 AUG 17  
 Impacted DU: 00015298 Taxi - Radar

**RADAR..... ON**  
*To check the radar and the departure path, set the MULTISCAN sw to MAN. The flight crew can then set the radar to the AUTO position.*  
*Gain must be manually set to +4, when MULTISCAN selector is set to AUTO and when flying below FL 200.*


- Note:*
1. If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes
  2. If the weather display is ambiguous or unexpected, in order to better analyze the weather situation, use manual tilt according to standard technique.
  3. In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.
  4. In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.

PREDICTIVE WINDSHEAR SYSTEM  .....AUTO

Ident.: PRO-NOR-SOP-10-A-00015298.0002001 / 03 AUG 17  
 Impacted by TDU: 00015299 Taxi - Radar

RADAR..... ON

*To check the radar and the departure path, set the MULTISCAN sw to MAN. The flight crew can then set the radar to the AUTO position.*

PREDICTIVE WINDSHEAR SYSTEM  .....AUTO

Ident.: PRO-NOR-SOP-10-A-00010252.0001001 / 20 JAN 15

**ATC**

ATC code/mode..... CONFIRM/SET FOR TAKEOFF

Ident.: PRO-NOR-SOP-10-A-00010254.0001001 / 03 AUG 17

**TERR ON ND**

TERR ON ND  .....AS RQRD

*Consider selecting the radar display on the PF side, and TERR ON ND on the PM side only.*

Ident.: PRO-NOR-SOP-10-A-00010264.0001001 / 15 MAY 13

**AUTO BRK**

AUTO BRK MAX pb-sw..... ON

Ident.: PRO-NOR-SOP-10-A-00010268.0001001 / 04 MAR 14

**FINAL CHECK**

- T.O CONFIG pb.....TEST
- Check that ECAM upper display shows "T.O CONFIG NORMAL".*
- T.O MEMO.....CHECK NO BLUE
- CABIN REPORT.....RECEIVE
- Obtain cabin report from the purser, as a minimum : "CABIN SECURED FOR TAKEOFF"*


Ident.: PRO-NOR-SOP-10-A-00010271.0001001 / 15 MAY 13

**BEFORE TAKEOFF CHECKLIST**

- BEFORE TAKEOFF CHECKLIST down to the line.....COMPLETE

Ident.: PRO-NOR-SOP-10-A-00020075.0001001 / 17 MAR 17

**TAXI FLOW PATTERN**






**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - TAXI

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> STANDARD OPERATING PROCEDURES - BEFORE TAKEOFF
---	---

**BEFORE TAKEOFF**

Applicable to: ALL

Ident.: PRO-NOR-SOP-11-A-00010396.0001001 / 05 AUG 10

● If the brake fans  are running:  
 BRAKE TEMP..... CHECK

- If brake temperature is above 150 °C, delay takeoff.
- If brake temperature is below 150 °C, select brake fans off.

Ident.: PRO-NOR-SOP-11-A-00010388.0001001 / 05 AUG 10

TAKEOFF OR LINE UP CLEARANCE..... OBTAIN

Ident.: PRO-NOR-SOP-11-A-00010392.0002001 / 29 SEP 15


**EXTERIOR LIGHTS**

RWY TURN OFF sw..... ON  
 NOSE sw..... T.O  
 STROBE sw..... ON

*Set the STROBE sw to ON when entering the runway.*

LAND LIGHTS sw..... ON  
*Set the LAND LIGHTS sw to ON when entering the runway and takeoff clearance is received.*


 The PF may ask the PM to set the exterior lights.

 **Note:** Setting the RWY TURN OFF sw, the LAND LIGHTS sw and the NOSE sw to ON/T.O minimizes bird strike hazard during takeoff.

Ident.: PRO-NOR-SOP-11-A-00010389.0001001 / 04 MAR 14

**TCAS**

TCAS  Mode selector..... TA or TA /RA

 The flight crew should use the TA /RA mode as the default mode of the TCAS.  
 The flight crew may use the TA ONLY mode in specific airports, and for specific procedures (identified by Operators) that may provide resolution advisories that are neither wanted nor appropriate (e.g. closely-spaced parallel or converging runways).

Ident.: PRO-NOR-SOP-11-A-00010390.0001001 / 04 MAR 14

**APPROACH PATH CLEARED OF TRAFFIC**

APPROACH PATH..... CLEARED OF TRAFFIC  
*Check that the approach path is clear of traffic, visually and using TCAS display on ND.*

Ident.: PRO-NOR-SOP-11-A-00010399.0001001 / 16 MAR 11

CABIN CREW.....ADVISE

*Advise the cabin crew that takeoff is imminent.*

Ident.: PRO-NOR-SOP-11-A-00010397.0004001 / 16 MAR 11

ENG MODE selector.....AS RQRD

*Select IGN, if:*

- *The runway has standing water, or*
- *Heavy rain is falling, or*
- *Heavy rain or severe turbulence is expected after takeoff.*

Ident.: PRO-NOR-SOP-11-A-00010394.0001001 / 20 MAR 17

**SLIDING TABLE/EFB**

SLIDING TABLE.....STOW

EFB/eQRH transmitting mode..... CONSIDER

*In accordance with the Operator's policy or, as required by operational regulations.*


EFB/eQRH (with no mounted equipment)..... STOW

*In flight, both flight crewmembers should not use at the same time Flysmart with Airbus applications.*

Ident.: PRO-NOR-SOP-11-A-00010393.0001001 / 21 MAR 17

TAKEOFF RUNWAY.....CONFIRM

*Confirm that the line up is performed on the intended runway. Useful aids are:*

- *The runway markings,*
- *The runway lights,*  
*Be careful that in low visibility, edge lights could be mixed up with the center line lights.*
- *The ILS signal,*  
*If the runway is ILS equipped, the flight crew can press the ILS pb (or LS pb): The LOC deviation should be centered after line up.*
- *The runway symbol on the ND,*
- *The Runway Awareness and Advisory System .*

Ident.: PRO-NOR-SOP-11-A-00010391.0001001 / 05 AUG 10

PACK 1 and 2.....AS RQRD

*Consider selecting packs OFF, or APU bleed ON.*

*This will improve performance when using TOGA thrust.*

*In case of a FLEX takeoff, selecting packs OFF or APU bleed ON will reduce takeoff EGT, and thus reduce maintenance costs.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - BEFORE TAKEOFF

*The use of flex thrust may reduce maintenance costs. The effect is particularly significant with the first degrees of FLEX.*

*Use of APU bleed is not authorized, if wing anti-ice is to be used.*

Ident.: PRO-NOR-SOP-11-A-00010400.0001001 / 16 MAR 11

BEFORE TAKEOFF CHECKLIST below the line..... COMPLETE

*Read the checklist below the line, when line-up clearance is obtained.*

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - BEFORE TAKEOFF

Intentionally left blank



**TAKEOFF**

**Applicable to:** ALL

Ident.: PRO-NOR-SOP-12-A-00011559.0001001 / 28 JUL 14

The below procedure is the standard takeoff procedure. However, rolling takeoff is permitted.

TAKEOFF..... ANNOUNCE

Ident.: PRO-NOR-SOP-12-A-00011560.0006001 / 23 JUN 15

**THRUST SETTING**

THRUST LEVERS.....50 % N1 (1.05 EPR)

● **If the crosswind is at or below 20 kt and there is no tailwind:**

To counter the nose-up effect of setting engine takeoff thrust, apply half forward sidestick until the airspeed reaches 80 kt. Release the sidestick gradually to reach neutral at 100 kt.

BRAKES.....RELEASE

THRUST LEVERS..... FLX or TOGA

*Once the thrust levers are set to FLX or TOGA detent, the Captain keeps his hand on the thrust levers until the aircraft reaches V1.*

● **In case of tailwind, or if crosswind is greater than 20 kt:**

The PF applies full forward sidestick.

BRAKES.....RELEASE

THRUST LEVERS..... FLX or TOGA

- *The PF rapidly increases thrust to about 70 % N1 (1.15 EPR) then progressively to reach takeoff thrust by 40 kt ground speed, while maintaining sidestick full forward up to 80 kt. Release the sidestick gradually to reach neutral at 100 kt.*
- *Once the thrust levers are set to FLX or TOGA detent, the Captain keeps his hand on the thrust levers until the aircraft reaches V1.*

*Note:* ENG SD page replaces WHEEL SD page on the ECAM lower display.

DIRECTIONAL CONTROL..... USE RUDDER

*At 130 kt (wheel speed), the connection between nosewheel steering and the rudder pedals is removed. Therefore, in strong crosswinds, more rudder input will be required at this point to prevent the aircraft from turning into the wind.*

CHRONO.....START

PFD /ND.....MONITOR

1. *Check the FMA on the PFD . The following modes are displayed: MAN TOGA (or MAN FLX xx) /SRS /RWY (or blank) / A/THR (in blue).*



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

**STANDARD OPERATING PROCEDURES - TAKEOFF**

*Note: If an ILS that corresponds to the departure runway is tuned, RWY mode appears. If not, no lateral mode appears until the aircraft lifts off.*

2. Check the FMS position on the ND (aircraft on runway centerline).

*Note: If GPS PRIMARY is not available, check the FMS position update.*

FMA..... ANNOUNCE

Ident.: PRO-NOR-SOP-12-A-00011561.0001001 / 04 MAR 14

**BELOW 80 KT**

TAKEOFF N1..... CHECK

*Check that the actual N1 of the individual engines has reached the N1 rating limit, before the aircraft reaches 80 kt. Check EGT.*

THRUST SET..... ANNOUNCE

PFD and ENG indications..... MONITOR

*Scan airspeed, N1, and EGT throughout the takeoff.*

Ident.: PRO-NOR-SOP-12-A-00011562.0001001 / 13 AUG 10

**REACHING 100 KT**

ONE HUNDRED KNOTS..... ANNOUNCE

- *The PF crosschecks and confirms the speed indicated on the PFD*
- *Below 100 kt the Captain may decide to abort the takeoff, depending on the circumstances*
- *Above 100 kt, rejecting the takeoff is a more serious matter.*

Ident.: PRO-NOR-SOP-12-A-00011563.0001001 / 13 AUG 10

**AT V1**

V1..... ANNOUNCE


Ident.: PRO-NOR-SOP-12-A-00011564.0001001 / 13 AUG 10

**AT VR**

ROTATION ..... ORDER

ROTATION..... PERFORM

- *At VR, initiate the rotation to achieve a continuous rotation with a rate of about 3 °/s, towards a pitch attitude 15 ° (12.5 °, one engine is failed)*
- *Minimize the lateral inputs on ground and during the rotation, to avoid spoiler extension*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - TAKEOFF</p>
---	--

- *In strong crosswind conditions, small lateral stick inputs may be used, if necessary, to aim at maintaining wings level*
- *After lift-off, follow the SRS pitch command bar.*

**CAUTION** If a tailstrike occurs, avoid flying at an altitude requiring a pressurized cabin, and return to the originating airport for damage assessment.

Ident.: PRO-NOR-SOP-12-A-00011565.0001001 / 04 MAR 14

**WHEN POSITIVE CLIMB**

POSITIVE CLIMB..... ANNOUNCE  
L/G UP..... ORDER  
L/G..... SELECT UP  
AP..... AS RQRD

*Above 100 ft AGL , AP 1 or 2 may be engaged.*

Ident.: PRO-NOR-SOP-12-A-00011566.0002001 / 28 JUL 15

**AT THRUST REDUCTION ALTITUDE**

THRUST LEVERS..... CL  
*Move the thrust levers to the CL detent, when the flashing LVR CLB prompt appears on the FMA . A/THR is now active.*  
*In manual flight, the pilot must anticipate the change in pitch attitude in order to prevent the speed from decaying when thrust is reduced.*

PACK 1 and 2 (if applicable)..... ON  
*Select PACK 1 on after CLB thrust reduction.*  
*Select PACK 2, at least 10 s after PACK 1 is selected on, for passenger comfort.*

Note: 1. *Selecting pack on before reducing takeoff thrust would result in an EGT increase.*  
2. *If packs are not switched on after the takeoff phase, an ECAM caution will be triggered.*

Ident.: PRO-NOR-SOP-12-A-00011567.0002001 / 04 MAR 14

**AT ACCELERATION ALTITUDE**

Check the target speed change from V2 + 10 to the first CLB speed (either preselected or managed).

Note: 1. *When THR RED and ACC ALT are equal, the FMA will change from MAN FLX/SRS /NAV to THR CLB /CLB /NAV.*  
2. *If FCU -selected altitude is equal to or close to the acceleration altitude, then the FMA will switch from SRS to ALT\*.*

**ABOVE ACCELERATION ALTITUDE (OR ONCE IN CLIMB PHASE)**

The following procedure ensures that the aircraft is effectively accelerating toward climb speed.

● **At F speed:**

*Note:* For takeoff in CONF 1 + F, "F" speed does not appear.

FLAPS 1..... ORDER

FLAPS 1..... SELECT

● **At S speed:**

FLAPS 0..... ORDER

FLAPS 0..... SELECT

GND SPLRS..... DISARM

NOSE sw..... OFF


RWY TURN OFF sw..... OFF

OTHER EXTERIOR LIGHTS..... AS RQRD

*The flight crew can maintain the LAND LIGHTS selector set to ON, according to airline policy or regulatory recommendations.*

*Note:* The CRUISE SD page replaces the ENG SD page.

Ident.: PRO-NOR-SOP-12-A-00011570.0001001 / 18 DEC 12




**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - TAKEOFF

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - AFTER TAKEOFF</p>
---	--

**AFTER TAKEOFF**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-13-A-00010157.0001001 / 21 MAR 17


APU BLEED pb ..... AS RQRD  
*If the APU has been used to supply air conditioning during takeoff, set the APU BLEED pb to OFF.  
 For use of the APU BLEED, Refer to LIM-APU Operational Envelope.*

APU MASTER SW pb ..... AS RQRD

Ident.: PRO-NOR-SOP-13-A-00010158.0001001 / 05 AUG 10

ENG MODE selector.....AS RQRD  
*Select IGN, if severe turbulence or heavy rain is encountered.*

Ident.: PRO-NOR-SOP-13-A-00010159.0001001 / 05 AUG 10


TCAS  Mode selector ..... TA/RA  
*Select TA/RA, if the takeoff has been performed with TA only.*

Ident.: PRO-NOR-SOP-13-A-00010160.0002001 / 21 MAR 17

ENG ANTI-ICE pb-sw ..... AS RQRD  
*Engine anti-ice must be set to ON when icing conditions (Refer to LIM-ICE\_RAIN Definition of Icing Conditions) exist or are anticipated, except during climb when the SAT is below -40 °C (-40 °F).*

WING ANTI-ICE pb-sw ..... AS RQRD

*When icing conditions are encountered:*

- *The flight crew may turn on the wing anti-ice to prevent ice accretion on the wing leading edge.*
- *The flight crew must turn on the wing anti-ice if there is evidence of ice accretion, such as ice on the visual indicator, or on the wipers, or with the **SEVERE ICE DETECTED**  alert. This is to remove any ice accumulation from the wing leading edge.*

Ident.: PRO-NOR-SOP-13-A-00010161.0001001 / 05 AUG 10

AFTER TAKEOFF/CLIMB CHECKLIST down to the line..... COMPLETE



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - AFTER TAKEOFF

Intentionally left blank



**CLIMB**

Applicable to: ALL

Ident.: PRO-NOR-SOP-14-A-00010245.0002001 / 09 JUN 15  
 Impacted by TDU: 00013057 Climb - Initial Climb

Normal vertical mode is CLB or OP CLB with managed speed active.

PF MCDU ..... PERF CLB

- PF MCDU should be showing the PERF CLB page (allowing PF to monitor when the aircraft will reach the FCU selected altitude) but he may select other pages such as F-PLN page as may be tactically necessary.

With the AP engaged, the PF may revise the flight plan.

- The MCDU PROG page displays OPT FL and MAX REC FL. It is worth noting that this OPT FL is a function of the cost index (CI).

- The displayed MAX REC FL gives the aircraft at least a 0.3 g buffet margin. The pilot may enter a cruise flight level above this level into the MCDU and the FMGS will accept it, provided that it does not exceed the level at which the margin is reduced to 0.2 g.

PM MCDU ..... F-PLN

PM MCDU should be showing the F-PLN page (allowing him to enter any ATC long-term revisions to the lateral or vertical flight plan).

**CLIMB SPEED MODIFICATIONS**

- If ATC, turbulence or operational considerations lead to a speed change:

Select the new speed with FCU SPD knob and pull.

Speed target is now "selected".

To return to managed speed mode, push FCU SPD knob.

The speed target is now "managed".

Note: The best speed (and rate of climb) for long-term situations lies between green dot speed and ECON speed. At high altitude, acceleration from green dot to ECON speed can take a long time.

**EXPEDITE CLIMB** 

- If ATC requires a rapid climb through a particular level:

Push the EXP pb on the FCU.

The target speed is now green dot speed. FMA :THR CLB /EXP CLB/NAV

*Note: Use EXP only for short-term tactical situations. For the best overall economy fly at ECON IAS.*

*To return to ECON CLB speed:  
 Push ALT knob.  
 Check FMA : THR CLB /CLB /NAV*

**BAROMETRIC REFERENCE..... SET STD/CROSSCHECK**

*At transition altitude (baro setting flashing on PFD ) set STD on the EFIS control panel and standby altimeter.*

*Cross-check baro settings and altitude readings.*

**CRZ FL..... SET AS RQRD**

*- If ATC clears the aircraft to its intended CRZ FL or above, there is no need to modify the CRZ FL entered in the INIT A page during cockpit preparation. The MCDU will automatically take into account a higher CRZ FL selected with the FCU ALT knob.*

*- If ATC limits CRZ FL to a lower level than the one entered in the INIT A page (or present on the PROG page) the flight crew must insert this lower CRZ FL in the PROG page.*

*Otherwise there is no transition into CRZ phase : the managed speed targets and Mach are not modified, and SOFT ALT mode is not available. In that case FMA will display: MACH/ALT /NAV instead of MACH/ALT CRZ /NAV.*

Ident.: TDU / PRO-NOR-SOP-14-A-00013057.0006001 / 29 JUN 16  
 Impacted DU: 00010245 Climb - Initial Climb

Normal vertical mode is CLB or OP CLB with managed speed active.

**PF MCDU.....PERF CLB**

*- PF MCDU should be showing the PERF CLB page (allowing PF to monitor when the aircraft will reach the FCU selected altitude) but he may select other pages such as F-PLN page as may be tactically necessary.*

*With the AP engaged, the PF may revise the flight plan.*

*- The MCDU PROG page displays OPT FL and MAX REC FL . It is worth noting that this OPT FL is a function of the cost index (CI).*

*- The displayed MAX REC FL gives the aircraft at least a 0.3 g buffet margin. The pilot may enter a cruise flight level above this level into the MCDU and the FMGS will accept it, provided that it does not exceed the level at which the margin is reduced to 0.2 g.*

**PM MCDU..... F-PLN**

*PM MCDU should be showing the F-PLN page (allowing him to enter any ATC long-term revisions to the lateral or vertical flight plan).*

**CLIMB SPEED MODIFICATIONS**

- **If ATC, turbulence or operational considerations lead to a speed change:**

Select the new speed with FCU SPD knob and pull.

Speed target is now “selected”.

To return to managed speed mode, push FCU SPD knob.

The speed target is now “managed”.


*Note:* The best speed (and rate of climb) for long-term situations lies between green dot speed and ECON speed. At high altitude, acceleration from green dot to ECON speed can take a long time.

**EXPEDITE CLIMB** 

- **If ATC requires a rapid climb through a particular level:**

Push the EXP pb on the FCU.

The target speed is now green dot speed. FMA :THR CLB /EXP CLB/NAV

*Note:* Use EXP  only for short-term tactical situations. For the best overall economy fly at ECON IAS.

To return to ECON CLB speed:

Push ALT knob.

Check FMA : THR CLB /CLB /NAV

**BAROMETRIC REFERENCE..... SET STD/CROSSCHECK**

At transition altitude (baro setting flashing on PFD ) set STD on the EFIS control panel and standby altimeter.

Cross-check baro settings and altitude readings.

*Note:* When STD is set on the EFIS control panel, the transponder does not transmit to the Air Traffic Control (ATC) the standard barometric reference but the last QNH or QFE previously selected. The transmitted aircraft altitude is not affected. Only the FCU selected altitude, if used by the ATC, may be misinterpreted.

Upon ATC notification of an incorrect barometric reference value, the flight crew can select manually a barometric reference of 1 013 hPa and set again STD on the EFIS control panel.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - CLIMB

CRZ FL..... SET AS RQRD

- If ATC clears the aircraft to its intended CRZ FL or above, there is no need to modify the CRZ FL entered in the INIT A page during cockpit preparation. The MCDU will automatically take into account a higher CRZ FL selected with the FCU ALT knob.
- If ATC limits CRZ FL to a lower level than the one entered in the INIT A page (or present on the PROG page) the flight crew must insert this lower CRZ FL in the PROG page. Otherwise there is no transition into CRZ phase : the managed speed targets and Mach are not modified, and SOFT ALT mode is not available. In that case FMA will display: MACH/ALT /NAV instead of MACH/ALT CRZ /NAV.

Ident.: PRO-NOR-SOP-14-A-00010257.0001001 / 05 AUG 10

AFTER TAKEOFF/CLIMB CHECKLIST below the line..... COMPLETE

Ident.: PRO-NOR-SOP-14-A-00010258.0001001 / 17 MAR 17

ENG ANTI-ICE pb-sw ..... AS RQRD

*Engine anti-ice must be set to ON when icing conditions (Refer to LIM-ICE\_RAIN Definition of Icing Conditions) exist or are anticipated, except during climb when the SAT is below - 40 °C (-40 °F).*

Ident.: TDU / PRO-NOR-SOP-14-A-00013047.0003001 / 03 MAR 14

Impacted DU: 00010259 Climb - Radar

RADAR..... AS APPROPRIATE

*Gain must be manually set to +4, when MULTISCAN selector is set to AUTO and when flying below FL 200.*

- Note:
1. If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes.
  2. If the weather display is ambiguous or unexpected, in order to better analyze the weather situation, use manual tilt according to standard technique.
  3. In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.
  4. In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.

Ident.: PRO-NOR-SOP-14-A-00010259.0002001 / 16 MAR 11

Impacted by TDU: 00013047 Climb - Radar

RADAR..... AS APPROPRIATE


Ident.: PRO-NOR-SOP-14-A-00010260.0001001 / 04 MAR 14

**AT 10.000FT**

- LAND LIGHTS selector.....RETRACT
- SEAT BELTS sw.....AS RQRD
- EFIS option.....AS RQRD
- Select CSTR on one side, for grid MORA (if available), and ARPT on the other side.*
- ECAM MEMO..... REVIEW
- NAVAIDS..... CLEAR
- Clear manually tuned VOR s from MCDU RAD NAV page.*
- SEC F-PLN page..... AS RQRD
- Recopy the active flight plan in the secondary if an immediate return flight plan has been constructed previously.*
- OPT/MAX ALT.....CHECK

Ident.: PRO-NOR-SOP-14-A-00020076.0001001 / 17 MAR 17

**10 000 ft FLOW PATTERN**



**PROCEDURES**


**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - CLIMB

EFIS Option:

The PF will select CSTR for grid MORA

The PM will select ARPT

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - CRUISE</p>
---	---

**CRUISE**

Applicable to: ALL

Ident.: PRO-NOR-SOP-15-A-00010287.0001001 / 25 AUG 16

ECAM MEMO..... REVIEW  
ECAM SD PAGES.....REVIEW

*Periodically review system display pages and, in particular:*

- ENG : Oil pressure and temperature*
- BLEED : BLEED parameters*
- ELEC : Parameters, GEN loads*
- HYD : A slight decrease in quantity is normal.  
Fluid contraction during cold soak can be expected.  
Green system is lower than on ground, following landing gear retraction.*
- FUEL : Fuel distribution.*
- COND : Duct temperature, compared with zone temperature.  
Avoid large differences for passenger comfort.*
- FLT CTL : Note any unusual control surface position.*
- DOOR : Oxygen pressure.*

Ident.: PRO-NOR-SOP-15-A-00010288.0001001 / 17 MAR 17

FLIGHT PROGRESS..... CHECK

*Monitor flight progress in the conventional way.*

*When overflying a waypoint:*

- *Check track and distance to the next waypoint.*

*When overflying the waypoint, or at least every 30 min:*

- *Check FUEL : Check FOB (ECAM ), and fuel prediction (FMGC), and compare with the computer flight plan or the in-cruise quick-check table (Refer to QRH/PER-M In Cruise Quick Check at a Given Mach Number (Paper Only) or use the performance application of FlySmart with Airbus). Check that the sum of the fuel on board and the fuel used is consistent with the fuel on board at departure. If the sum is unusually greater than the fuel on board at departure, suspect a fuel quantity over read. If the sum is unusually smaller than the fuel on board at departure, or if it decreases, suspect a fuel leak.  
For more information about fuel leak, Refer to FCTM/PR-AEP-FUEL Fuel Leak.*

**CAUTION** *This check must also be performed each time a FUEL IMBALANCE procedure is necessary. Perform the check before applying the FUEL IMBALANCE procedure. If a fuel leak is confirmed, apply the FUEL LEAK procedure.*



AEROLÍNEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - CRUISE

Ident.: PRO-NOR-SOP-15-A-00010289.0001001 / 01 DEC 14

STEP FLIGHT LEVEL.....AS APPROPRIATE

Ident.: PRO-NOR-SOP-15-A-00010290.0001001 / 21 MAR 17

NAV ACCURACY.....MONITOR

*On aircraft equipped with GPS primary, no navigation accuracy check is required, as long as GPS PRIMARY is available.*

*Otherwise, a navigation accuracy check must be performed especially when any of the following occurs:*

- *GPS PRIMARY LOST appears on the ND (GPS  $\leftarrow$ )*
- *IRS only navigation*
- *The PROG page displays LOW accuracy*
- *“NAV ACCUR DOWNGRAD” appears on the MCDU.*

*Refer to DSC-22\_20-20-20 Estimated Position Uncertainty.*

Note: *Methods for checking accuracy:*

- **If the check is positive (error  $\leq$  3 N.m): FM position is reliable.**  
*Use ND (ARC or NAV) and managed lateral guidance.*
- **If the check is negative (error  $>$  3 N.m): FM position is not reliable.**  
*Use raw data for navigation and monitor it.*
- **If there is a significant mismatch between the display and the real position:**  
*Disengage MANAGED NAV mode and use raw data navigation (possibly switching to ROSE VOR, so as not to be misled by FM data).*

Ident.: TDU / PRO-NOR-SOP-15-A-00013068.0006001 / 20 SEP 16

Impacted DU: 00010291 Cruise - Radar Tilt

RADAR .....AS APPROPRIATE

*Gain must be manually set to +4, when MULTISCAN selector is set to AUTO and when flying below FL 200.*



- Note:
1. If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes.
  2. If the weather display is ambiguous or unexpected, in order to better analyze the weather situation, use manual tilt according to standard technique.
  3. In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.
  4. In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.

Ident.: PRO-NOR-SOP-15-A-00010291.0002001 / 07 MAR 13  
 Impacted by TDU: 00013068 Cruise - Radar Tilt

**RADAR** ..... **AS APPROPRIATE**

Ident.: PRO-NOR-SOP-15-A-00010296.0001001 / 21 MAR 16

- **If the oxygen mask has been used:**  
 OXYGEN MASK ..... CHECK  
*Check that the oxygen mask has been properly stowed, Refer to DSC-35-20-10 General.*




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - CRUISE

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - DESCENT PREPARATION</p>
---	--

**DESCENT PREPARATION**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-16-A-00011551.0001001 / 30 JUN 14

Descent preparation and approach briefing should be completed before top of descent.

Ident.: PRO-NOR-SOP-16-A-00011552.0006001 / 20 MAR 17

WEATHER AND LANDING INFORMATION.....OBTAIN  
*Check weather reports at ALTERNATE and DESTINATION airports. Airfield data should include runway in use for arrival.*

Note: *When operating in cold weather conditions, consider altitude correction. Refer to PER-OPD-GEN ALTITUDE TEMPERATURE CORRECTION.*

NAV CHARTS CLIPBOARD.....PREPARE

Ident.: PRO-NOR-SOP-16-A-00014394.0001001 / 27 APR 17

EFB LDG PERFORMANCE.....CHECK

Perform an in-flight landing performance assessment if the landing conditions changed compared with the landing computation at dispatch, or with a previous computation (e.g. runway, weather conditions, in-flight failure affecting performance, diversion).

Note:

1. *If the weather conditions are expected to change at the landing airport, or in the event of significant precipitation, the flight crew should consider a second calculation of the in-flight landing distance with the worst possible runway condition.*
2. *The selection of REV MAX is the standard practice for landing. However, on dry runways the flight crew may select REV IDLE. On WET runways (runway surface condition GOOD), the flight crew may select REV IDLE, if all the following conditions are satisfied:*

- *A landing distance assessment has been made with the following parameters:*
  - *MEDIUM TO POOR landing performance level for the in-flight landing distance computation*
  - *No reverser credit*
- *The result of this landing distance assessment is within the LDA.*

● **If landing conditions changed:**

LDG PERFORMANCE.....(RE)COMPUTE

*In the LDG PERF application, modify the selections in accordance with the estimated arrival conditions:*

- *In the AIRPORT/RUNWAY part, select the applicable runway*
- *In the CONDITIONS part, enter the estimated landing conditions*
- *In the AIRCRAFT STATUS part, check the selected items, if any*
- *Launch the computation and check the results versus Airline policy or applicable regulations.*

LDG PERFORMANCE.....CROSSCHECK

Ident.: PRO-NOR-SOP-16-A-00020100.0001001 / 17 MAY 17

ARRIVAL page..... COMPLETE/CHECK

*Insert APPR , STAR , APPR VIA and TRANS if applicable. (Access by lateral revision at destination.)*

F-PLN A page..... CHECK

- *Ensure that the inserted F-PLN agrees with planned approach and missed approach.*
- *Use the scroll key to check the F-PLN thoroughly, using ND in PLAN mode as necessary.*

*Tracks and distances between waypoints are displayed on the second line from the top of the MCDU. Approach and Missed Approach tracks and distances must be checked from the appropriate navigation charts.*

- *Check speed constraints. Add new speed constraints if required.*
- *Check altitude constraints. Add new altitude constraints if required.*


Note: *The FMS may have deleted the altitude constraints that are at or above the CRZ FL , or at or above any previous lower CRZ FL in the case of step climbs (Refer to DSC-22\_20-30-20-05 Vertical Constraints (Speed, Altitude, Time)).*

*In that case,*

- *Insert again the affected procedures (STAR , APPR VIA or TRANS)*  
*The FMS keeps the altitude constraints that are below the CRZ FL , and deletes again the altitude constraints that are above current CRZ FL . The FMS may also delete the altitude constraints that are at current CRZ FL , and the altitude constraint windows that have a constraint at or above current CRZ FL .*
- *Manually enter the altitude constraints that are below current CRZ FL using the MCDU Vertical Revision pages.*

*It is not possible to enter an altitude constraint at the CRZ FL.*



*In the case of an "AT" or "AT OR ABOVE" altitude constraint at the CRZ FL , the flight crew must select the DES mode only after the aircraft reaches the position of the altitude constraint to prevent an early descent.*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - DESCENT PREPARATION</p>
---	--

- In all cases, do not modify the final approach (FAF to runway or MAP), including altitude constraints.
- Identify the position and the altitude of Final Descent Point (FDP) and check the value of the FPA after this FDP.
- If a TOO STEEP PATH message is displayed after the FDP, do not use FINAL APP guidance for approach.
- Identify the Missed Approach Point.

Ident.: PRO-NOR-SOP-16-A-00020101.0001001 / 20 SEP 16

DES WIND page..... CHECK  
Enter winds for descent before T/D.

Note: With DPO , as the idle thrust margins are reduced, accurate winds have to be entered to be able to follow the computed vertical profile and thus maximize the benefits of DPO . Refer to DSC-22\_20-60-150 Descent Profile Optimization (if installed).

PERF CRUISE page..... CHECK  
Modify the cabin descent rate if different pressure rate is required.

PERF DES page..... CHECK  
Prior to descent, access PERF DES page and check ECON MACH/SPD. If a speed other than ECON is required, insert that MACH or SPD into the ECON field. This new MACH or SPD is now the one for the descent path and T/D computation, and it will be used for the managed speed descent profile (instead of ECON).  
A speed limit of 250 kt below 10 000 ft is the defaulted speed, in the managed speed descent profile. The flight crew may delete or modify it if necessary on the VERT REV at DEST page.


Ident.: PRO-NOR-SOP-16-A-00020102.0002001 / 21 MAR 17

PERF APPR page..... COMPLETE/CHECK  
Enter the QNH, temperature, and wind at destination.

**L13**  
Note: Insert the average wind given by the ATC or ATIS. Do not insert the gust value. During approach, the Ground Speed Mini function (manage speed mode) takes into account the instantaneous gust.  
For more information: Refer to Ground Speed Mini Function.  
For example, if the wind is 15020G35KT, insert 150/20.

Insert the minimum.

Note: To avoid undershooting the published minimum during go-around, due to aircraft inertia during pull-up, some Authorities may require Operators to add a specific number of feet to the published minimum.

**CAUTION** If the QNH altimeter setting is used for an aircraft with the QFE option  , Refer to PRO-NOR-SUP-NAV QNH use for aircraft equipped with QFE option.

Note: Changing the RWY or the type of approach automatically erases the previous minimum.

Note: After the activation of the SEC F-PLN , check the VAPP , and modify if necessary.

Check or modify the landing configuration. Always select the landing configuration on the PERF APP page: CONF FULL in the normal landing configuration. CONF 3 should be considered, depending on the available runway length and go-around performance, or if windshear/severe turbulence is considered possible during approach.

If the forecasted tailwind at landing is greater than 10 kt , refer to "LIM-12-Airport Operations and Wind Limitations" for the recommended/required landing configuration.



Check or modify the transition altitude.

PERF GO-AROUND page..... CHECK/MODIFY

Check THR RED ALT and ACC ALT, and modify, if necessary.

Ident.: PRO-NOR-SOP-16-A-00020103.0001001 / 20 SEP 16

RAD NAV page..... CHECK

- Set nav aids, as required, and check idents on the ND s (VOR -ADF ) and PFD s (ILS , GLS  , MLS  ). If a VOR /DME exists close to the airfield, select it and enter its ident in the BRG /DIST field of the PROG page, for NAV ACCY monitoring during descent.
- When the flight plan calls for an NDB approach, the system automatically tunes the ADF , only when the aircraft is passing the first fix of the approach. Therefore, it is convenient to manually tune the ADF earlier (before activating the approach phase).

Ident.: PRO-NOR-SOP-16-A-00020104.0001001 / 20 SEP 16

SEC F-PLN page..... AS RQRD

Before the top of descent, the SEC F-PLN should either be set to an alternate runway for destination, or to the landing runway in case of circling. In all cases, routing to the alternate should be available. If there is a last-minute runway change, then the flight crew only needs to activate the secondary F-PLN , without forgetting to check/set the new minimum and nav aids.

Ident.: PRO-NOR-SOP-16-A-00011554.0001001 / 03 MAR 14

GPWS LDG FLAP 3 pb-sw.....AS RQRD

If the pilot plans on landing in FLAPS 3 configuration, the GPWS LDG FLAP 3 pb-sw should be set to ON.

Ident.: PRO-NOR-SOP-16-A-00015490.0001001 / 03 MAR 14

**LDG ELEV.....CHECK**  
*Check that the LDG ELEV AUTO green is displayed on the ECAM CRUISE page, and check the associated value.*

Ident.: PRO-NOR-SOP-16-A-00011556.0001001 / 17 MAR 17

**AUTO BRK .....AS RQRD**  
*Use of autobrake is preferable.*  
*Use of MAX mode is not recommended at landing.*  
*On short or contaminated runways, use MED mode.*  
*On long runways, LO mode is recommended.*  
 [L2] *For more information, Refer to FCTM/PR-NP-SOP-160 Brakes Oxidation.*  
 [LT] **Note:** *If, on very long runways, the flight crew anticipates that braking will not be needed, use of the autobrake is not necessary.*  
*Firmly press the appropriate pushbutton, according to the runway length and condition, and check that the related ON light comes on.*

Ident.: PRO-NOR-SOP-16-A-00011555.0001001 / 10 JUL 14

**APPROACH BRIEFING.....PERFORM**

Ident.: PRO-NOR-SOP-16-A-00011547.0001001 / 23 JUN 15

**TERR ON ND <img alt="terrain icon" data-bbox="275 560 300 575" style="vertical-align: middle;"/> .....AS RQRD**  
 - *In mountainous areas, consider displaying terrain on ND.*  
 - *If use of radar is required, consider selecting the radar display on the PF side, and TERR ON ND on the PM side only.*  
 - *If NAV ACCURACY is LOW, do not use TERR on ND.*

Ident.: TDU / PRO-NOR-SOP-16-A-00013353.0003001 / 03 MAR 14  
 Impacted DU: 00011545 Descent Preparation - Radar

**RADAR.....ADJUST AS APPROPRIATE**  
*Gain must be manually set to +4, when MULTISCAN selector is set to AUTO and when flying below FL 200.*

- Note:**
1. If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt until displaying ground echoes.
  2. If the weather display is ambiguous or unexpected, in order to better analyze the weather situation, use manual tilt according to standard technique.
  3. In particular below FL 200, for situations with low-level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to Manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.
  4. In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and Manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.

Ident.: PRO-NOR-SOP-16-A-00011545.0001001 / 03 MAR 14  
Impacted by TDU: 00013353 Descent Preparation - Radar

**RADAR**..... **ADJUST AS APPROPRIATE**

Ident.: PRO-NOR-SOP-16-A-00011558.0004001 / 02 MAY 17


**CAUTION** In icing conditions (*Refer to LIM-ICE\_RAIN Definition of Icing Conditions*), the flight crew must turn on the engine anti-ice and should not wait until seeing ice building up.

ENG ANTI-ICE pb-sw ..... AS RQRD  
*Engine anti-ice must be set to ON before and during descent, event if the SAT is below -40 °C (-40 °F).*

*When ENG ANTI ICE is ON, the FADEC selects a higher idle thrust which gives better protection against flame-out.*

WING ANTI ICE pb-sw ..... AS RQRD

*When icing conditions are encountered:*

- *The flight crew may turn on the wing anti-ice to prevent ice accretion on the wing leading edge.*
- *The flight crew must turn on the wing anti-ice if there is evidence of ice accretion, such as ice on the visual indicators, or on the wipers, or with the **SEVERE ICE DETECTED**  alert. This is to remove any ice accumulation from the wing leading edge.*

*ANTI ICE ON reduces the descent path angle (when the engines are at idle). The pilot can compensate for this by increasing the descent speed, or by extending up to half speedbrakes.*

Ident.: PRO-NOR-SOP-16-A-00011557.0001001 / 03 MAR 14

DESCENT CLEARANCE.....OBTAIN





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - DESCENT PREPARATION

CLEARED ALTITUDE ON FCU..... SET  
*When clearance is obtained, set the ATC -cleared altitude (FL ) on the FCU (also considering what is the safe altitude).*  
*If the lowest safe altitude is higher than the ATC -cleared altitude, check with the ATC that this constraint applies.*  
*If it is confirmed, set the FCU altitude to the safe altitude, until it is safe to go to the ATC-cleared altitude.*




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - DESCENT PREPARATION

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - DESCENT</p>
---	--

**DESCENT INITIATION**

Ident.: PRO-NOR-SOP-17-00011541.0001001 / 03 NOV 14  
**Applicable to: ALL**

DESCENT..... INITIATE

*The normal method of initiating the descent is to select DES mode at the FMGS calculated top of descent (T/D).*

■ **If ATC requires an early descent:**

Use DES mode which will guide the aircraft down at a lower vertical speed in order to converge on the required descent path. (The pilot may use a V/S of -1 000 ft/min).

■ **If ATC delays the descent:**


Beyond T/D, the PFD and the MCDU display either "DECELERATE" or "T/D REACHED" message. This suggests to the crew that it starts reducing speed towards green dot speed (with ATC permission). When cleared to descend, select DES mode with managed speed active.

**DESCENT MONITORING**

Ident.: PRO-NOR-SOP-17-00011542.0003001 / 23 DEC 14  
**Applicable to: ALL**

PF MCDU ..... PROG /PERF DES

*PF MCDU should be set to PROG or PERF DES page:*

- *PROG page in order to get VDEV or RQD DIST TO LAND/DIRECT DIST TO DEST information*
- *PERF DES in order to get predictions down to any inserted altitude in DES /OP DES modes and EXP mode .*

PM MCDU ..... F-PLN


DESCENT..... MONITOR/ADJUST

*Refer to PRO-NOR-SRP-01-60 Descent Monitoring - DES Mode Engaged*

- When flying in NAV mode, use DES mode.

The aircraft descends along the descent flight path: the PFD and PROG page display VDEV, and so it can be monitored. All constraints of the flight plan are taken into account for the guidance.

- When the aircraft is flying in HDG or TRK mode, and thus out of the lateral F-PLN, DES mode is not available.

The ND s show a level-off symbol  along the flight path. Its position is based on the current active modes .AP /FD and A/THR

The flight crew can use this symbol to monitor the descent.

MCDU predictions assume a return to the lateral F-PLN and descent flight path.

Note that whenever the lateral mode is changed from NAV to HDG /TRK the vertical mode reverts to V/S at the value pertaining at the time of the mode change.

- From time to time during stabilized descent, the flight crew may select FPA to check that the remaining distance to destination is approximately the altitude change required divided by the FPA in degrees.

$$FPA (^{\circ}) = \Delta FL/DIST (NM)$$

## DESCENT ADJUSTMENT


Applicable to: ALL

Ident.: PRO-NOR-SOP-17-A-00011543.0002001 / 09 MAR 15

To increase the rate of descent:

- Increase descent speed (by use of selected speed) if comfort and ATC permit. It is economically better (Time/Fuel) than the following procedures.
- Maintain high speed as long as possible. (SPD LIM may be suspended, subject to ATC clearance).
- If the aircraft is high and at high speed, it is more efficient to keep the high speed to ALT\* and decelerate, rather than to mix descent and deceleration.
- If the aircraft goes below the desired profile, use SPEED and the V/S mode to adjust the rate of descent.


Note: EXPEDITE DESCENT.

If a high rate of descent is required, push the EXPED pushbutton  on the FCU . The target speed for the descent now becomes M 0.8 or 340 kt, whichever is lower. The FMA will display THRIDLE/EXP DES/NAV.

To return to DES mode, push the FCU ALT knob.

To return to SPEED/V/S modes, pull the FCU V/S knob.

In all cases, monitor the FMA to ensure that the mode engages properly.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - DESCENT</p>
---	--

Ident.: PRO-NOR-SOP-17-A-00011544.0001001 / 03 MAR 14

If engine anti-ice is selected in descent, the flight idle is increased. So, to maintain the rate of descent that the airplane had before engine anti-ice selection it may be necessary to use up to half speedbrakes to maintain the required rate of descent, in OPEN DES vertical mode. If the rate of descent has to be increased, full speedbrakes may be used.

In DES mode: If the aircraft is on, or below, the flight path and the ATC requires a higher rate of descent, do not use speedbrakes because the rate of descent is dictated by the planned flight path. Thus, the A/THR may increase thrust to compensate for the increase in drag. In this case, use OPEN DES with speedbrakes.

- Note:
1. If speedbrakes are used above 315 kt/M .75, with the AP engaged, their rate of retraction is low (total time for retraction from full extension is approximately 25 s). The ECAM memo page displays SPD BRAKES in amber until retraction is complete.
  2. In order to avoid overshooting the altitude, due to speedbrake retraction in ALT\* mode, retract the speedbrakes at least 2 000 ft before the selected altitude.

Ident.: PRO-NOR-SOP-17-A-00011546.0001001 / 14 JAN 16

BAROMETRIC REFERENCE..... SET

*Set QNH on the EFIS control panel and on the standby altimeter, when approaching the transition level and when cleared for an altitude.*

*Crosscheck BARO settings and altitude readings.*

Ident.: PRO-NOR-SOP-17-A-00011548.0001001 / 13 AUG 10

ECAM STATUS..... CHECK

- Check that there is no status reminder on the upper ECAM display.
- If there is a status reminder, check the aircraft STATUS.
- Check the ECAM status page before completing the approach checks. Take particular note of any degradation in landing capability, or any other aspect affecting the approach and landing.

Ident.: PRO-NOR-SOP-17-A-00021715.0001001 / 04 SEP 17

**AT 10 000 FT**

LAND lights selector..... SET

*LAND lights may be switched ON, according to the airline policy/regulatory recommendations.*

SEAT BELTS sw..... ON

EFIS option pb..... CSTR

*Select CSTR on both sides.*



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL





## PROCEDURES

### NORMAL PROCEDURES

#### STANDARD OPERATING PROCEDURES - DESCENT

ILS/LS pb.....AS QRDR

*Press the ILS/LS pb, if one of the following approaches is planned:*

- ILS, GLS  , MLS 
- ILS G/S out, LOC only or LOC B/C 
- Approach with the FLS function 

*The flight crew checks that:*

- Deviation scales are displayed on the PFD
- The IDENT is properly displayed on the PFD

RAD NAVAIDS.....SELECTED/IDENTIFIED

*Ensure that appropriate radio NAVAIDS are tuned and identified.*

*For NDB approaches, manually select the reference NAVAID.*

Ident.: PRO-NOR-SOP-17-A-00015500.0001001 / 03 MAR 14

ENG MODE selector.....AS QRDR

- Select IGN if the runway is covered with standing water, or if heavy rain or severe turbulence is expected during approach or go-around area.

Ident.: PRO-NOR-SOP-17-A-00015501.0001001 / 03 MAR 14

NAV ACCURACY.....CHECK

*On aircraft equipped with GPS primary, no navigation accuracy check is required, as long as GPS PRIMARY function is available.*

*Otherwise, crosscheck NAV ACCURACY using the PROG page (BRG /DIST computed data), and the ND (VOR /DME raw data).*

## APPROACH CHECKLIST

Ident.: PRO-NOR-SOP-17-00014491.0001001 / 03 MAR 14

Applicable to: ALL

### APPROACH CHECKLIST

APPROACH CHECKLIST.....PERFORMED

**10 000 FT FLOW PATTERN**

Ident.: PRO-NOR-SOP-17-00020073.0001001 / 17 MAR 17

Applicable to: ALL

10 000 ft FLOW PATTERN

→ PF ACTIONS  
→ PM ACTIONS

① EFIS option pb ..... CSTR  
② LS pb ..... AS RQRD  
③ NAV ACCY ..... CHECK

① LAND LIGHTS sw ..... SET  
② SEAT BELTS sw ..... ON  
③ EFIS option pb ..... CSTR  
④ LS pb ..... AS RQRD  
⑤ RADIO NAV ..... SELECT/IDENT  
⑥ ENG MODE selector... AS RQRD



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - DESCENT

Intentionally left blank





**Approach General**

**INTRODUCTION**

Ident.: PRO-NOR-SOP-18-A-00014490.0001001 / 29 MAY 13

Applicable to: ALL

The APPROACH section provides the standard operating procedures for the following approach types:

- ILS / MLS  / GLS  approaches
- Conventional approaches: VOR , VOR -DME , NDB , NDB -DME
- Approaches based on a LOC signal without any G/S signal: LOC ONLY, ILS G/S OUT, LOC B/C
- RNAV approaches including:
  - RNAV (GNSS) approaches with LNAV minimum or LNAV/VNAV minimum
  - RNAV (RNP ) approaches for which Authorization is Required (AR) - If capability installed.

Note: In relation to the names in the ICAO Performance-Based Navigation (PBN) Manual:



- "RNP APCH operations" corresponds to RNAV (GNSS) approaches
- "RNP AR APCH operations" corresponds to RNAV (RNP) approaches.

**CROSS-REFERENCE TABLE**

Ident.: PRO-NOR-SOP-18-A-00014489.0001001 / 29 MAY 13

Applicable to: ALL

This table provides Guidance Modes that may be used depending on the Approach Types.

	Guidance Modes per Approach Types				
	LOC G/S	FINAL APP	LOC FPA	NAV FPA	TRK FPA
<b>ILS / MLS</b>  <b>/ GLS</b> 	<i>Refer to APPR using LOC G/S</i>	N/A	N/A	N/A	N/A
<b>LOC ONLY</b> <b>ILS G/S OUT</b>	N/A	N/A	<i>Refer to APPR using FPA Guidance</i>	N/A	N/A
<b>LOC B/C</b>	N/A	N/A	N/A	N/A	<i>Refer to APPR using FPA Guidance</i>
<b>RNAV (GNSS) with LNAV/VNAV minima</b>	N/A	<i>Refer to APPR using FINAL APP</i>	N/A	Not Authorized	Not Authorized
<b>RNAV (GNSS) with LNAV minima</b>	N/A	<i>Refer to APPR using FINAL APP <sup>(1)</sup></i>	N/A	<i>Refer to APPR using FPA Guidance</i>	Not Authorized

*Continued on the following page*

**PROCEDURES**  
**NORMAL PROCEDURES**

**STANDARD OPERATING PROCEDURES - APPROACH**

*Continued from the previous page*

	<b>Guidance Modes per Approach Types</b>				
	<b>LOC G/S</b>	<b>FINAL APP</b>	<b>LOC FPA</b>	<b>NAV FPA</b>	<b>TRK FPA</b>
<b>RNAV (GNSS) with LPV minima</b>	N/A	Not Authorized	N/A	Not Authorized	Not Authorized
<b>VOR VOR -DME NDB NDB -DME</b>	N/A	<i>Refer to APPR using FINAL APP <sup>(1)</sup></i>	N/A	<i>Refer to APPR using FPA Guidance</i>	<i>Refer to APPR using FPA Guidance</i>

<sup>(1)</sup> *The FINAL APP is the recommended guidance mode for this type of approach.*

For Visual Approach, *Refer to Visual Approach*

For Circling Approach, *Refer to Circling Approach*

**FLYING REFERENCE**

Ident.: PRO-NOR-SOP-18-A-00014488.0001001 / 29 MAY 13

**Applicable to: ALL**

Use the following recommended flying reference:

- In vertical managed modes: HDG -V/S reference associated with the FD crossbars
- In vertical selected modes: TRK -FPA reference associated with FPD.

**STABILIZATION CRITERIA**

Ident.: PRO-NOR-SOP-18-A-00014487.0002001 / 06 DEC 16

**Applicable to: ALL**

The stabilization height is defined as one of the following:

- 1 000 ft above airfield elevation (AAL) in Instrument Meteorological Conditions (IMC), or
- 500 ft above airfield elevation (AAL) in Visual Meteorological Conditions (VMC), or
- Any other height defined in Operator policies or regulations.

In order for the approach to be stabilized, all of the following conditions must be satisfied before, or at the stabilization height:

- The aircraft is on the correct lateral and vertical flight path
- The aircraft is in the desired landing configuration

- The thrust is stabilized, usually above idle, and the aircraft is at target speed for approach

Note: In IMC, if the ATC requests a speed constraint that is not compatible with the speed and thrust stabilization at 1 000 ft AAL, a later speed and thrust stabilization can be acceptable provided that:

- The aircraft is in deceleration toward the target approach speed
  - The flight crew stabilizes speed and thrust as soon as possible and not later than 500 ft AAL.
- The flight crew does not detect any excessive flight parameter deviation.

If one of the above-mentioned conditions is not satisfied, the flight crew must initiate a go-around, unless they estimate that only small corrections are required to recover stabilized approach conditions.




Note: If the predicted tailwind at landing is greater than 10 kt, decelerated approach is not permitted, and the aircraft speed should be stabilized at around VREF + 5 kt in final.

## APPROACH SPEED TECHNIQUE

Ident.: PRO-NOR-SOP-18-A-00014485.0001001 / 29 MAY 13

Applicable to: ALL

### **DECELERATED APPROACH**

The decelerated approach with FD or AP /FD guidance is the standard flying technique for ILS / MLS  / GLS  approaches and approaches using FLS  or FINAL APP guidance.

### **EARLY STABILIZED APPROACH**

Under certain circumstances, the flight crew may decide to reduce the speed down to VAPP in the landing configuration at the Final Descent Point (i.e. approach via selected guidance, high glide path angle, low altitude intermediate approach, etc.). In order to obtain a valuable deceleration pseudo waypoint and to ensure a timely deceleration, the flight crew should enter VAPP as a speed constraint at the Final Descent Point.

**DISCONTINUED APPROACH**


Ident.: PRO-NOR-SOP-18-A-00015226.0001001 / 03 DEC 13

Applicable to: ALL

In order to discontinue an approach when the aircraft is at or above the altitude selected on the FCU, the flight crew can either:

- Apply the GO AROUND procedure, or
- Apply the discontinued approach technique.

When the aircraft is below the FCU altitude, the flight crew must apply the GO AROUND procedure.



● **If at or above the FCU altitude:**

Announce "CANCEL APPROACH".

To disarm any AP/FD approach mode, press APPR pb or LOC pb.

Note: Valid only for ILS / MLS  / GLS  / FLS  or FINAL APP guidance.

Select lateral mode as required (NAV or HDG mode).

Select vertical mode as required (level off or adjust V/S).

Select SPEED and adjust.

● **If F-PLN has no destination anymore:**

Perform a LAT REV at the last waypoint and redefine the destination in the NEW DEST field.


- Note:
1. *The FMS does not automatically string the previous flown approach in the active F-PLN when the aircraft overflies the last waypoint. The FMS has no more destination in the F-PLN.*
  2. *Because the thrust levers are not set to TOGA detent, the FMS remains in approach phase.*

**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - APPROACH

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - APPROACH</p>
---	---

**Aircraft Configuration Management**

**INITIAL APPROACH**

Applicable to: ALL

Ident.: PRO-NOR-SOP-18-B-A-00014494.0001001 / 29 MAY 13

**GENERAL**

The initial approach procedure described here is a general guidance whatever the type of approach expected.

Ident.: PRO-NOR-SOP-18-B-A-00014493.0001001 / 03 MAR 14

**INITIAL APPROACH**

F-PLN SEQUENCING.....ADJUST

- *The NAV mode will be available after GO AROUND if the F-PLN is properly sequenced. A good cue to monitor the proper F-PLN sequencing is the TO waypoint on the upper right side of the ND, which should remain meaningful.*
- *In NAV mode, the F-PLN will sequence automatically.*
- *In HDG /TRK mode, the F-PLN will sequence automatically only if the aircraft flies close to the F-PLN route.*

APPROACH PHASE.....CHECK/ACTIVATE

- *If the aircraft overflies the DECEL pseudo waypoint in NAV mode, the APPR phase activates automatically.*
- *If the aircraft is in HDG /TRK mode, approximately 15 NM from touchdown, activate and confirm APPROACH phase on the MCDU (PERF DES page).*

MANAGED SPEED..... CHECK

- *If ATC requires a particular speed, use selected speed. When the ATC speed constraint no longer applies, return to managed speed.*

FLIGHT PATH.....MONITOR

- *In NAV mode, use VDEV information on the PFD and PROG page.*
- *In HDG /TRK mode, use the energy circle on ND representing the required distance to land.*

SPEED BRAKES lever.....AS QRDR

- If the flight crew uses the speed brakes to increase the rate of deceleration or to increase the rate of descent, the VLS will increase as well:
  - The flight crew should ensure that appropriate speed margin exists before the extension of the speed brakes
  - If the speed brakes are extended, the flight crew should ensure that appropriate speed margin exists before the beginning of a turn.

*This will avoid the activation of the Alpha-Floor protection.*

Note: *In clean configuration, the VLS with speed brakes fully extended may be higher than green dot speed or VFE FLAP 1.*

Ident.: TDU / PRO-NOR-SOP-18-B-A-00014648.0003001 / 03 MAR 14  
 Impacted DU: 00014647 Initial Approach - Radar

**RADAR**

RADAR.....ADJUST AS APPROPRIATE

- Gain must be manually set to +4 when MULTISCAN selector is set to AUTO and when flying below FL 200.
- If the weather is good, or not significant, in order to check that the radar is operating correctly: down tilt under displaying ground echoes.
- If the weather display is ambiguous or unexpected, in order to better analyze the weather situation, use manual tilt according to standard technique.
- In particular below FL 200, for situations with low level weather, weather with low reflectivity or in front of suspected active cells, the flight crew should switch to manual mode and adjust the tilt setting downward until the weather is detected or the ground clutter appears on the upper part of the display.
- In addition, the flight crew may increase the manual gain control to display lower reflectivity targets. The manual gain control can be increased in both AUTO and manual modes to display lower levels of weather. In both cases, ground clutter may also be displayed as a result of low settings and/or increased gain.

Ident.: PRO-NOR-SOP-18-B-A-00014647.0001001 / 29 MAY 13  
 Impacted by TDU: 00014648 Initial Approach - Radar

**RADAR**

RADAR.....ADJUST AS APPROPRIATE



Ident.: PRO-NOR-SOP-18-B-A-00014492.0001001 / 29 MAY 13

**NAVIGATION ACCURACY**

NAV ACCURACY.....MONITOR

- *When GPS PRIMARY is available, no NAV ACCURACY monitoring is required.*
- *If GPS PRIMARY is lost, or GPS not installed, check on PROG page that the required navigation accuracy is appropriate to the phase of flight.*
- *If NAV ACCURACY is LOW, at least one ND must be in ROSE LS /VOR depending on the approach.*

**INTERMEDIATE/FINAL APPROACH**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-18-B-B-00014501.0001001 / 29 MAY 13

**GENERAL**

The intermediate and final approach procedure described here is general guidance whatever the type of approach expected.

Ident.: PRO-NOR-SOP-18-B-B-00014500.0001001 / 17 MAR 17

**AT GREEN DOT SPEED**

<b>CAUTION</b>	The flight crew should avoid extended flight in icing conditions with the slats extended.
----------------	---

FLAPS 1..... ORDER  
 FLAPS 1.....SELECT

- *FLAPS 1 should be selected more than 3 NM before the Final Descent Point.*
- *Check deceleration toward "S" speed.*
- *For decelerated approaches, the aircraft must reach or be established on the final descent with FLAPS 1 and "S" speed at or above 2 000 ft AGL.*
- *If the aircraft does not decelerate on the flight path or aircraft speed is significantly higher than "S" speed, extend the landing gear in order to slow down. The use of speedbrakes is possible. The flight crew should be aware that the use of speedbrakes causes an increase in VLS.*




TCAS Mode selector..... TA or TA /RA

- FAA recommends to select TA only mode:
  - In case of known nearby traffic which is in visual contact
  - At particular airports and during particular procedures identified by an Operator as having a significant potential for unwanted or inappropriate resolution advisories (closely spaced parallel runways, converging runway, low terrain along the final approach, etc.).

Ident.: PRO-NOR-SOP-18-B-B-00014499.0001001 / 09 MAR 15

**AT 2 000 FT AGL MINIMUM**

FLAPS 2..... ORDER  
 FLAPS 2.....SELECT

- Check deceleration toward "F" speed.
- For ILS / MLS  / GLS  and approaches using FLS  , if the aircraft intercepts the flight path below 2 000 ft AGL, select FLAPS 2 at one dot below the flight path.
- If the aircraft speed is significantly higher than "F" speed on the flight path, or the aircraft does not decelerate on the flight path, extend the landing gear in order to slow down the aircraft. The use of speed brakes is not recommended.
- When the speed brakes are deployed, extending the flaps beyond FLAPS 1 may induce a slight roll movement, and in calm conditions a small lateral control asymmetry may remain until disturbed by a control input or by an atmospheric disturbance.

Ident.: PRO-NOR-SOP-18-B-B-00014498.0001001 / 05 JAN 15

**WHEN FLAPS ARE AT 2**

L/G DOWN .....ORDER  
 L/G lever..... SELECT DOWN  
 AUTO BRK .....CONFIRM

- If the runway conditions have changed from the approach briefing, consider another braking mode.

GROUND SPOILERS .....ARM  
 NOSE sw.....TAXI  
 RWY TURN OFF sw..... ON

Ident.: PRO-NOR-SOP-18-B-B-00014497.0002001 / 20 MAR 17

**WHEN LANDING GEAR IS DOWN**

FLAPS 3.....ORDER  
 FLAPS 3.....SELECT

ECAM WHEEL SD page ..... CHECK

- *WHEEL* SD page appears below 15 500 ft when landing gear is extended.
- Check for three green indications on the landing gear indicator panel. At least one green triangle on each landing gear strut on the WHEEL SD page is sufficient to indicate that the landing gear is downlocked. Rely also on the "LDG GEAR DN" green LDG MEMO message to confirm that the landing gear is downlocked.

● **If residual pressure is indicated on the triple indicator:**

RESIDUAL BRAKING PROC..... APPLY

- Due to the accomplishment of the alternate braking functional test after the landing gear is downlocked, brief brake pressure indications may be observed on BRAKES PRESS.

FLAPS FULL..... ORDER

FLAPS FULL..... SELECT

- Retract the speed brakes before selecting FLAPS FULL to prevent a pitch down when the speed brakes automatically retract.
- Check deceleration towards VAPP.
- Check correct TO waypoint on the ND.

A/THR.....CHECK IN SPEED MODE OR OFF

WING ANTI-ICE pb-sw..... OFF

- Switch the WING ANTI ICE pb-sw to ON, only in severe icing conditions.

SLIDING TABLE  .....STOW

EFB/eQRH (with no mounted equipment)..... STOW

LDG MEMO.....CHECK NO BLUE

CABIN REPORT..... RECEIVE

CABIN CREW..... ADVISE

LANDING CHECKLIST..... COMPLETE

## PROCEDURES

### NORMAL PROCEDURES


#### STANDARD OPERATING PROCEDURES - APPROACH

FLIGHT PARAMETERS.....MONITOR

- The PF announces any FMA modification.
- The PM calls out, if:
  - The speed goes lower than the speed target -5 kt , or greater than the speed target +10 kt
  - The pitch attitude goes lower than -2.5 °, or greater than +10 ° nose up
  - The bank angle becomes greater than 7 °
  - The descent rate becomes greater than 1 000 ft/min
- Following PM flight parameter exceedance callout, the suitable PF response will be:
  - Acknowledge the PM callout, for proper crew coordination purposes
  - Take immediate corrective action to control the exceeded parameter back into the defined stabilized conditions
  - Assess whether stabilized conditions will be recovered early enough prior to landing, otherwise initiate a go-around.

Ident.: PRO-NOR-SOP-18-B-B-00014495.0001001 / 29 MAY 13

**PATTERN (DECELERATED)**




**PROCEDURES**

**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - APPROACH

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - APPROACH</p>
---	---



**Aircraft Guidance Management**

**APPROACH USING LOC G/S GUIDANCE**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-18-C-A-00014508.0001001 / 29 MAY 13

**GENERAL**

The following items are to be performed in addition to previous SOP chapters for ILS / MLS  / GLS  approach.

Ident.: PRO-NOR-SOP-18-C-A-00020896.0001001 / 20 MAR 17

**DESCENT PREPARATION**

APPROACH MINIMUM.....DETERMINE

- For CATII, CATIII approaches, always choose the lowest achievable minimum. The approach minimum is limited by:

- Crew qualification
- Airline Operating Manual requirement
- Aircraft technical status
- Airport status

- For CATIII with no DH, the flight crew should enter "NO" in the DH field of the MCDU to avoid false "HUNDRED ABOVE" or "MINIMUM" auto callouts which would not be applicable.

APPROACH BRIEFING.....PERFORM

For CATII, CATIII approaches, review the following items on top of the usual briefing:

- Task sharing and callouts
- Management of degraded guidance
- Low visibility procedures at the airport

Ident.: PRO-NOR-SOP-18-C-A-00014509.0001001 / 09 FEB 16

**INITIAL/INTERMEDIATE APPROACH**

APPR pb on FCU..... PRESS

- Press the APPR pb when:
  - Cleared for the approach
  - On the intercept trajectory for the final approach course
  - LOC deviation is available.

*This arms the LOC and G/S modes.*

Note: In NAV mode, the aircraft may leave the F-PLN to capture the LOC.

- LOC and/or G/S capture modes will engage no sooner than 3 s after being armed.
- ICAO defines the envelope where the quality of the G/S signal ensures a normal capture. This envelope is within 10 NM,  $\pm 8^\circ$  of the centerline of the ILS glide path and up to  $1.75 \theta$  and down to  $0.3 \theta$  ( $\theta$  = nominal glide path angle). When arming the approach well outside of the normal G/S capture envelope, a spurious G/S \* engagement may occur due to a wrong G/S deviation signal. Whenever the pilot notices the pitch movement, or the spurious G/S \*, or the trajectory deviation, he will immediately disconnect the AP, if engaged, to re-establish a normal attitude and will disengage APPR mode. It is then recommended to arm/rearm APPR (ILS) mode within the normal capture zone.

BOTH APs..... ENGAGE

- When APPR mode is selected, AP 1 and AP2 should be engaged.
- Above 5 000 ft AGL, the FMA displays CAT 1.
- Below 5 000 ft AGL, the FMA displays the correct approach capability for the intended approach.

LOC..... CHECK ARMED  
 G/S..... CHECK ARMED  
 LOC CAPTURE..... MONITOR  
 G/S CAPTURE..... MONITOR  
 GO AROUND ALTITUDE..... SET

Ident.: PRO-NOR-SOP-18-C-A-00014510.0002001 / 03 MAR 14

**GLIDE INTERCEPTION FROM ABOVE**

The following procedure should only be applied when established on the localizer. The flight crew must react without delay to meet the stabilization criteria.



In order to get the best rate of descent when cleared by ATC and below the limiting speeds, the flight crew should lower the landing gear and select flaps as required (at least CONF 2 should be selected to ensure that the aircraft speed will not increase).

● **If above the glideslope:**

APPR mode ..... ARM / CHECK ARMED  
 FCU ALTITUDE..... SET ABOVE A/C ALTITUDE  
 V/S MODE..... SELECT

- Select V/S 1 500 ft/min initially. V/S in excess of 2 000 ft/min will result in the speed increasing towards VFE.
- When reaching VFE , the AP maintains VFE and reduces the V/S without MODE REVERSION.

Ident.: PRO-NOR-SOP-18-C-A-00014511.0001001 / 04 JUL 17

**FINAL APPROACH**

FLIGHT PARAMETERS.....MONITOR

- The PM calls out if excessive deviation occurs:

- LOC: ½ dot
- GLIDE: ½ dot

*Refer to PRO-NOR-SOP-90 Approach*

AT 350 ft RA

LAND mode..... CHECK ENGAGED/ANNOUNCE

*If no LAND mode, autoland is not authorized.*

**FOR CAT I, CAT II, CAT III WITH DH APPROACH**

AT ENTERED MINIMUM +100 ft

ONE HUNDRED ABOVE.....MONITOR OR ANNOUNCE

AT ENTERED MINIMUM

MINIMUM..... MONITOR OR ANNOUNCE

Below minimum, the visual references must be the primary reference until landing.

For more information regarding transition to visual references, *Refer to*

*FCTM/PR-NP-SOP-250 Transition to Visual References.*

■ **If visual references are sufficient:**

CONTINUE.....ANNOUNCE

AP.....AS RQRD

*For Minimum Use Height of the AP Refer to LIM-AFS-10 Flight Management Function*

*For Manual Landing and Autoland procedure Refer to PRO-NOR-SOP-19 Landing - Flare*

■ **If visual references are not sufficient:**

GO AROUND..... ANNOUNCE

*Initiate a go around.*

**FOR CAT III WITHOUT DH APPROACH**

At 100 ft (Alert Height) if no failure

CONTINUE..... ANNOUNCE

Ident.: PRO-NOR-SOP-18-C-A-00021062.0002001 / 31 AUG 17

**MANAGEMENT OF DEGRADED GUIDANCE**

**EARLY/UNTIMELY FLARE MODE ENGAGEMENT**

- Perform a go around (thrust levers set to TOGA), or
- Disconnect AP , set both FDs to OFF and continue the approach using raw data or external visual references.

In association to an early/untimely FLARE mode engagement on the FMA, the following effects may occur:

- On the Primary Flight Display (PFD):
  - The RA height indication may be frozen at a positive or negative value,
  - Discrepancies between both PFDs may happen on the following indications:
    - RA heights,
    - FD orders,
    - FMA indications when both APs are engaged.
- Warnings and/or Callouts:
  - Untimely activation of the AUTOLAND warning light. *Refer to DSC-22\_30-30 Autoland Warning,*
  - Untimely Terrain Awareness and Warning System (TAWS) alerts,
  - Untimely or absence of "RETARD" callout,
  - Untimely L/G GEAR NOT DOWN ECAM warning,
  - Absence or interruption of RA automatic callout (height announcement),
- On the System Display (SD): A pulsing cabin differential pressure advisory may appear on the ECAM - CAB PRESS PAGE

Note: *This ECAM advisory has no consequence on the real cabin pressure.*

**FOR CAT II, CAT III OPERATIONS**

● **In the case of:**

- Amber caution (single chime), or
- Landing capability degradation.

Above 1000 ft:

ECAM / QRH PROCEDURE..... COMPLETE

REQUIRED EQUIPMENT..... CHECK

*Refer to QRH/OPS Required Equipment for CAT2 and CAT3*

APPROACH AND LANDING CAPABILITY..... CHECK

If required:

RVR..... CHECK

DH..... ADJUST

BRIEFING..... CONFIRM

● **If the flight crew does not complete all the above actions at 1 000 ft:**

GO AROUND..... PERFORM

Below 1000 ft:

● **If external visual references are not sufficient:**

GO AROUND..... PERFORM

Below 100 ft (Alert Height) for CAT 3 DUAL:

Approach may be continued unless autoland light comes on.

● **In the case of Autoland warning light:**

■ **Visual references not sufficient:**

GO AROUND..... PERFORM

■ **Visual references sufficient:**

Approach may be continued manually



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - APPROACH

**APPROACH USING FINAL APP GUIDANCE**

Applicable to: ALL

Ident.: PRO-NOR-SOP-18-C-C-00014521.0002001 / 29 MAY 13

**GENERAL**

The following items are to be performed in addition to previous SOP chapters in the following cases:

- RNAV (GNSS) approaches with LNAV and LNAV/VNAV minima
- Conventional approaches based on VOR or NDB using FINAL APP guidance.

Ident.: PRO-NOR-SOP-18-C-C-00014522.0003001 / 09 SEP 14

**AIRCRAFT EQUIPMENT**

For RNAV (GNSS) approaches, *Refer to PRO-SPO-51 RNP APCH / RNAV(GNSS) - Required RNP APCH Equipment*

Ident.: PRO-NOR-SOP-18-C-C-00015860.0001001 / 09 SEP 14

**FLIGHT PREPARATION**

For RNAV (GNSS ) approaches, GPS PRIMARY availability should be confirmed.  
*Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed)*


Ident.: PRO-NOR-SOP-18-C-C-00014524.0002001 / 08 AUG 17


**DESCENT PREPARATION**

WEATHER AND LANDING INFORMATION.....OBTAIN

- *The FMS vertical profile does not take into account the effect of low OAT. Therefore, vertical managed guidance:*
  - *Must not be used when the actual OAT is below the minimum temperature indicated on the approach chart or defined by the Operator, or*
  - *May not be used when temperature corrections are required (FINAL APP mode may not engage).*
- *For RNAV (GNSS ) approach with LNAV VNAV minima, use of QNH from a remote station is prohibited.*

F-PLN A page..... CHECK

- *If a TOO STEEP PATH is displayed after the Final Descent Point (FDP ), do not use FINAL APP guidance for approach. Use NAV FPA , TRK FPA or FLS  for approach.*
- *0.1 degree of difference between the MCDU and the charted final vertical path is acceptable*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - APPROACH</p>
---	---

- 1 degree of difference between the MCDU and the charted final lateral track is acceptable

*Note:* A higher lateral track value can be acceptable if the navigation database has been validated to exclude potential coding error.

- 3 degree of difference between the MCDU and the charted final lateral track is acceptable for conventional radio NAVAID approach.

PROG page.....COMPLETE

- Insert the reference RWY threshold in the BRG /DIST field for position monitoring during approach.

GO AROUND STRATEGY.....REVIEW

- The briefing should include a review of the "Management of Degraded Navigation" chapter.

Ident.: PRO-NOR-SOP-18-C-C-00014525.0003001 / 23 JUN 15

**DESCENT**

**At 10 000 ft:**

NAV ACCURACY.....CHECK

- If NAV accuracy is LOW, use TRK FPA mode for approach (Refer to APPR using FPA guidance).

● **For RNAV(GNSS) approach:**

GPS PRIMARY.....CHECK

- GPS PRIMARY must be available on at least 1 FMS.

BARO REF.....SET

- The vertical guidance requires a precise baro setting. The maximum acceptable discrepancy between altimeters is 100 ft.

Ident.: PRO-NOR-SOP-18-C-C-00014526.0002001 / 08 AUG 17

**INITIAL/INTERMEDIATE/FINAL APPROACH**

POSITION.....MONITOR

- Check that ATC clearances allow the aircraft to fly through the capture area of vertical profile. After a radar vectoring, consider a DIR TO RDL IN to sequence the F-PLN.

APPR pb on FCU .....PRESS

Press the APPR pb when all of the following conditions are satisfied:

- The aircraft is cleared for approach
- TO waypoint is the Final Descent Point.

APP NAV.....CHECK ARMED or ENGAGED

FINAL.....CHECK ARMED

- Check that the V/DEV scale is displayed on the PFD.
- At the Final Descent Point, a blue arrow on ND indicates that FINAL APP engagement conditions are met.


**At the Final Descent Point :**

FINAL APP.....CHECK ENGAGED

GO AROUND ALTITUDE.....SET

FLIGHT PARAMETERS.....MONITOR

- Monitor XTK error on ND.
- Monitor V/DEV on PFD.
- Crosscheck distances versus altitudes as published on the charts.
- If approaching on a conventional radio NAVAID procedure, monitor the lateral and vertical guidance using raw data.
- The PM calls out if excessive deviation occurs:
  - XTK > 0.1 NM
  - V/DEV > ½ dot

 On the vertical scale, one dot corresponds to 100 ft. Thus ½ dot is 50 ft.

 Refer to PRO-NOR-SOP-90 Approach

Ident.: PRO-NOR-SOP-18-C-C-00015015.0001001 / 29 MAY 13

**AT ENTERED MINIMUM +100 FT**

ONE HUNDRED ABOVE.....MONITOR OR ANNOUNCE

Ident.: PRO-NOR-SOP-18-C-C-00014527.0008001 / 04 JUL 17

**AT ENTERED MINIMUM**

MINIMUM.....MONITOR OR ANNOUNCE

Below minimum, the visual references must be the primary references until landing.  
 For more information regarding transition to visual references, Refer to FCTM/PR-NP-SOP-250  
 Transition to Visual References.

■ **If visual references are sufficient:**

CONTINUE.....ANNOUNCE

At the latest at the MAP or Minimum Use Height of the AP (whichever occurs first):  
 AP .....OFF

- For Minimum Use Height of the AP, Refer to LIM-AFS-10 Autopilot Function
- At minimum -50 ft, if the AP is still engaged, the message DISCONNECT AP FOR LDG pulses on the FMA to remind the flight crew that automatic landing is not available.

FD .....AS RQRD

**CAUTION** - From minima down to the MAP the FD provides an additional guidance. The FD must be switched off if the guidance is not relevant or not followed.  
 - After the MAP, disregard the FD as it reverts to HDG V/S.

■ **If visual references are not sufficient:**

GO AROUND.....ANNOUNCE

- Initiate a go around.

Ident.: PRO-NOR-SOP-18-C-C-00014528.0002001 / 23 JUN 15

**MANAGEMENT OF DEGRADED NAVIGATION**

● **For VOR and NDB approaches, be prepared to continue the approach with reference to appropriate raw data by reverting to:**

- NAV FPA, if the vertical guidance is not satisfactory
- TRK FPA, if the lateral guidance is not satisfactory.

● **For RNAV(GNSS) approaches with LNAV minima and LNAV/VNAV minima:**

- Use the appropriate remaining AP /FDin the following cases:
  - GPS PRIMARY LOST on one ND
  - NAV ACCUR DOWNGRAD on one FMGS.
- Discontinue the approach in the following cases, if external visual references are not sufficient to proceed visually:
  - GPS PRIMARY LOST on both NDs
  - XTK > 0.3 NM
  - NAV FM /GPS POS DISAGREE on ECAM
  - NAV ACCUR DOWNGRAD on both FMGS.

● **For RNAV(GNSS) approaches with LNAV/VNAV minima:**

- Discontinue the approach in the case of deviation of 75 ft below the vertical path (V/DEV>¾ dot).



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - APPROACH

**APPROACH USING FPA GUIDANCE**

Applicable to: ALL

Ident.: PRO-NOR-SOP-18-C-E-00014561.0002001 / 29 MAY 13

**GENERAL**

The following items are to be performed in addition to previous SOP chapters in the following cases:

- RNAV (GNSS ) approaches using mixed NAV FPA guidance with LNAV minima only
- Conventional approaches based on VOR and NDB using selected TRK FPA or mixed NAV FPA guidance
- ILS G/S OUT, LOC ONLY and back course localizer approaches.

The approach is flown in TRK FPA when:

- The approach is not stored in the database or
- NAV accuracy is LOW.

Ident.: PRO-NOR-SOP-18-C-E-00014560.0003001 / 09 SEP 14

**AIRCRAFT EQUIPMENT**

For RNAV (GNSS) approaches, *Refer to PRO-SPO-51 RNP APCH / RNAV(GNSS) - Required RNP APCH Equipment*

Ident.: PRO-NOR-SOP-18-C-E-00015861.0001001 / 09 SEP 14

**FLIGHT PREPARATION**

For RNAV (GNSS ) approaches, GPS PRIMARY availability should be confirmed.  
*Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed)*


Ident.: PRO-NOR-SOP-18-C-E-00014558.0002001 / 20 SEP 16

**DESCENT PREPARATION**

F-PLN A page..... CHECK

- *If a TOO STEEP PATH message is displayed after the Final Descent Point (FDP ), disregard the V/DEV or yoyo information on the PFD.*
- *For approaches using NAV FPA:*
  - *1 degree of difference between the MCDU and the charted final lateral track is acceptable.*
  - *3 degree of difference between the MCDU and the charted final lateral track is acceptable for conventional radio NAVAID approach.*
- *In all other cases, use TRK FPA mode for approach.*



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p>STANDARD OPERATING PROCEDURES - APPROACH</p>
---	---

PROG page.....COMPLETE

- Insert the reference RWY threshold in the BRG /DIST field for position monitoring during approach.

GO AROUND STRATEGY..... REVIEW

- The briefing should include a review of the "Management of Degraded Navigation" chapter.

Ident.: PRO-NOR-SOP-18-C-E-00014557.0003001 / 03 MAR 14

**DESCENT**

**At 10 000 ft:**

NAV ACCURACY..... CHECK

- If NAV accuracy is LOW, use TRK mode for approach.

● **For RNAV(GNSS) approach:**

GPS PRIMARY..... CHECK

- GPS PRIMARY must be available on at least 1 FMS.

Ident.: PRO-NOR-SOP-18-C-E-00014556.0002001 / 21 MAR 17

**INITIAL/INTERMEDIATE/FINAL APPROACH**

LATERAL GUIDANCE MODE..... SET FOR APPROACH

- Arm NAV or LOC mode as appropriate.

● **For LOC ONLY and ILS G/S OUT:**

LOC pb-sw ..... PRESS

- Press the LOC pb-sw when cleared for approach and on the intercept trajectory for the final approach course.

*Note:* In NAV mode, the aircraft may leave the F-PLN to capture the LOC.

LOC ..... CHECK ARMED

**CAUTION** Do not press the APPR pb

● **For back course localizer approaches:**

TRK FPA MODE..... USE FOR APPROACH

- Refer to FCTM/PR-NP-SOP-190-GUI Back Course Localizer Approach.

LATERAL PATH..... INTERCEPT

- Monitor NAV or LOC engagement as appropriate.

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - APPROACH

TRK FPA pb (Bird).....SELECT  
 FPA FOR FINAL APPROACH.....SET

**At 0.3 nm from the Final Descent Point:**

FPA selector ..... PULL  
 FPA MODE.....CHECK ENGAGED

- Check NAV FPA , TRK FPA or LOC FPA is engaged.

POSITION/FLIGHT PATH ..... MONITOR/ADJUST  
 GO AROUND ALTITUDE..... SET

- Set when below the go around altitude to avoid unexpected altitude capture.

FLIGHT PARAMETERS.....MONITOR

- Crosscheck distances versus altitudes as published on the charts.
- If approaching on a conventional radio NAVAID procedure, monitor the lateral and vertical guidance using raw data.
- For approaches using NAV FPA , monitor XTK error on ND to check the lateral guidance.
- The PM calls out if excessive lateral deviation occurs:
  - Approach using NAV MODE: XTK > 0.1 NM
  - Approach using LOC MODE: LOC ½ dot
  - Approach using TRK MODE:
    - VOR: ½ dot or 2.5 °
    - NDB: 5 °

*Refer to PRO-NOR-SOP-90 Flight Parameters in Approach*

ident.: PRO-NOR-SOP-18-C-E-00015017.0001001 / 29 MAY 13

**AT ENTERED MINIMUM +100 FT**

ONE HUNDRED ABOVE.....MONITOR OR ANNOUNCE

ident.: PRO-NOR-SOP-18-C-E-00014555.0013001 / 04 JUL 17


**AT ENTERED MINIMUM**

MINIMUM.....MONITOR OR ANNOUNCE

Below minimum, the visual references must be the primary references until landing.  
 For more information regarding transition to visual references, *Refer to FCTM/PR-NP-SOP-250 Transition to Visual References.*

■ **If visual references are sufficient:**

CONTINUE.....ANNOUNCE

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - APPROACH</p>
---	---

AP .....OFF

- *At minimum -50 ft, if the AP is still engaged, the message DISCONNECT AP FOR LDG pulses on the FMA to remind the flight crew that automatic landing is not available.*

FD .....OFF

- *The PF orders the PM to set both FDs OFF.*

RUNWAY TRACK.....CHECK/SET

- *If needed, the PF orders the PM to set the runway track.*

■ **If visual references are not sufficient:**

GO AROUND.....ANNOUNCE

- *Initiate a go around.*

Ident.: PRO-NOR-SOP-18-C-E-00014554.0002001 / 23 JUN 15

**MANAGEMENT OF DEGRADED NAVIGATION**

● **For VOR and NDB approaches in NAV FPA, if lateral guidance is not satisfactory:**

- Be prepared to continue the approach with reference to appropriate raw data by reverting to TRK FPA.

● **For RNAV(GNSS) approaches, with LNAV minima:**

- Use the appropriate remaining AP FD in the following cases:
  - GPS PRIMARY LOST on one ND
  - NAV ACCUR DOWNGRAD on one FMGS
- Discontinue the approach in the following cases, if external visual references are not sufficient to proceed visually:
  - GPS PRIMARY LOST on both NDs
  - XTK > 0.3 NM
  - NAV FM /GPS POS DISAGREE on ECAM
  - NAV ACCUR DOWNGRAD on both FMGS

**CIRCLING APPROACH**

Applicable to: ALL

Ident.: PRO-NOR-SOP-18-C-F-00014570.0001001 / 29 MAY 13

**GENERAL**

The circling approach is the visual phase of an instrument approach to bring an aircraft into position for landing on a runway which is not suitably located for a straight-in approach.

**CAUTION**

The flight crew must conduct the flight within the circling area, while maintaining required visual references at all times.

Ident.: PRO-NOR-SOP-18-C-F-00014569.0001001 / 29 MAY 13

## **APPROACH PREPARATION**

For a circling approach, the approach preparation should include the following additional items in the FMS programming.

### **F-PLN**

Introduce the instrument approach procedure, including the missed approach procedure for instrument approach.

### **SEC F-PLN**

The landing runway must be inserted into the SEC F-PLN.

Update the SEC F-PLN as follows:

- Copy the active F-PLN
- Revise the landing runway.

Ident.: PRO-NOR-SOP-18-C-F-00014568.0001001 / 29 MAY 13

## **INSTRUMENT APPROACH**

The flight crew flies a stabilized approach at "F" speed, configuration 3 and landing gear down.

Ident.: PRO-NOR-SOP-18-C-F-00014567.0001001 / 29 MAY 13

## **CIRCLING APPROACH**

### **● At the Circling MDA(H) at the latest:**

Perform a level off

### **● At MAP, if the flight crew finds no visual reference:**

Initiate a go around

### **● When required conditions for circling are satisfied:**

Select TRK FPA

Proceed to downwind leg

At any time in the downwind leg, activate the SEC F-PLN


Disconnect the AP and remove the FDs at the latest before starting the descent toward the runway

Set the landing configuration when appropriate, but ensure early stabilization in final.

If, at any time during the circling procedure, the required visual references are lost, initiate a go around following the missed approach of the initial instrument approach (unless otherwise specified).

Ident.: PRO-NOR-SOP-18-C-F-00014566.0001001 / 30 JUN 16

**CIRCLING APPROACH PATTERN**



## **RNAV VISUAL APPROACH**

Applicable to: ALL

Ident.: PRO-NOR-SOP-18-C-G-00016048.0001001 / 23 DEC 14

### **GENERAL**

The aircraft navigates using the RNAV system, but the position is monitored by visual reference to the ground, obstacles and other traffic.

RNAV visual approach must be stored and retrievable from the Navigation Database.

Ident.: PRO-NOR-SOP-18-C-G-00016049.0001001 / 23 DEC 14

### **EQUIPMENT REQUIRED**

- 1 FMS
- 1 GPS or 2 DME to update FM position
- Additional requirement if indicated on the approach chart.

Ident.: PRO-NOR-SOP-18-C-G-00016050.0001001 / 17 MAR 17

### **FMGC GUIDANCE MODE**

● **If no required accuracy is published:**

The use of FMGC guidance mode is at flight crew discretion.

● **If RNAV 1 or RNP 1 is required on the published approach chart:**

The flight crew should use adequate FMGC guidance modes.

*Note: The use of lateral and vertical managed guidance modes reduces the crew workload and improves energy management.*

For RNAV VISUAL approach including RF legs, *Refer to FCTM/PR-NP-SP-30 General* for RF leg flying technic.

Ident.: PRO-NOR-SOP-18-C-G-00016051.0001001 / 23 DEC 14

### **DESCENT PREPARATION**

For approach data insertion in the FMS , keep the BARO /MDA field empty on the PERF APPR Page.

Ident.: PRO-NOR-SOP-18-C-G-00016052.0001001 / 23 DEC 14

### **DESCENT**

For RNAV VISUAL approaches requiring GPS , check that GPS PRIMARY is available on at least 1 FMS.

Ident.: PRO-NOR-SOP-18-C-G-00016053.0001001 / 21 MAR 17

### **FINAL APPROACH**

The flight crew must disconnect the AP at the latest at the Minimum Use Height of the AP.  
*Refer to LIM-AFS-10 Autopilot Function*

### **VISUAL APPROACH**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-18-C-H-00014574.0002001 / 29 MAY 13

### **GENERAL**

Perform the approach on a nominal 3° glideslope using visual references. Approach to be stabilized by 500 ft AGL on the correct approach path, in the landing configuration, at VAPP.

Method:

- The AP is not used
- Both FDs are OFF
- FPV use is recommended
- A/THR use is recommended with managed speed.

Bear in mind the possible risk of optical illusions due to hindered night vision.

*Note: If the forecasted tailwind at landing is greater than 10 kt, decelerated approach is not allowed, and the speed should be stabilized around VREF + 5 kt in final.*

Ident.: PRO-NOR-SOP-18-C-H-00014573.0001001 / 08 AUG 13

### **INITIAL/INTERMEDIATE APPROACH**

The flight plan selected on the MCDU should include the selection of the landing runway. The downwind leg may also be part of the flight plan. This may be a useful indication of the aircraft position in the circuit on the ND.

However, visual references must be used.

Therefore, at the beginning of the downwind leg:

Manually ACTIVATE APPR

Select FDs to OFF

Select TRK FPA to have FPV displayed

Check A/THR active.

*Extend the downwind leg to 3 s/100 ft ( $\pm 1$  s/1 kt of headwind / tailwind).*

*Turn into base leg with a maximum of 30° of bank. Descent with approximate FPA, in FLAPS 2, at F speed.*

## **FINAL APPROACH**

The speed trend arrow and FPV help the flight crew make timely and correct thrust settings (if in manual thrust), and approach path corrections.

Avoid descending through the correct approach path with idle thrust. (Late recognition of this situation without a prompt thrust increase may lead to considerable speed decay and altitude loss).

Ensure that the aircraft is stabilized on the final descent path at VAPP (or ground speed mini) in the landing configuration with the thrust stabilized (usually above idle) at 500 ft above airfield elevation or as restricted by Operator policies/regulations.

If the aircraft is not stabilized, the flight crew must initiate a go around, unless they think that only small corrections are necessary to rectify minor deviations from stabilized conditions due, amongst others, to external perturbations.


Avoid any tendency to “duck under” in the late stages of the approach.

Avoid destabilizing the approach in the last 100 ft, in order to have the best chance of performing a good touchdown at the desired position.



Ident.: PRO-NOR-SOP-18-C-H-00014571.0001001 / 08 DEC 14

**VISUAL APPROACH (1 OR 2 ENGINES) PATTERN**






**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - APPROACH

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - LANDING</p>
---	--

**MANUAL LANDING**

Applicable to: ALL

Ident.: PRO-NOR-SOP-19-A-00010351.0011001 / 25 APR 17

**FLARE**

The cockpit cut-off angle is 20 °.

- **In stabilized approach conditions, the flare height is approximately 30 ft:**

FLARE..... PERFORM

*Avoid flaring high. Refer to Ground Clearance Diagram.*

ATTITUDE..... MONITOR

THRUST levers..... IDLE

*If autothrust is engaged, it automatically disconnects when the pilot sets both thrust levers to the IDLE detent.*

*In manual landing conditions, the "RETARD" callout is triggered at 20 ft radio height, in order to remind the pilot to retard the thrust levers.*

Note: The ground spoilers extension is inhibited if:

- Both thrust levers remain above the idle detent, or
- One thrust lever is above idle and one thrust lever is at idle detent.

Ident.: PRO-NOR-SOP-19-A-00010352.0001001 / 30 JUN 15

**AT TOUCHDOWN**

DEROTATION..... INITIATE

- Lower the nosewheel without undue delay.
- The PM continues to monitor the attitude.

ALL THRUST LEVERS..... REV MAX or REV IDLE

*The flight crew must select reverse thrust immediately after main landing gear touchdown.*

*The flight crew must immediately select REV MAX, if any of the following occurs at any time during the landing:*

- An emergency
- The deceleration is not as expected
- A failure affects the landing performance
- A long flare or a long touchdown
- An unexpected tailwind.

*A small pitch up may occur during thrust reversers deployment before nose landing gear touchdown. However, the flight crew can easily control this pitch up.*

*As soon as the flight crew selects reverse thrust, they must perform a full-stop landing.*

GROUND SPOILERS..... CHECK/ANNOUNCE

Check that the WHEEL SD page displays the ground spoilers extended after touchdown.

If no ground spoilers are extended:

- Verify and confirm that both thrust levers are set to IDLE or REV detent.
- Set both thrust reverser levers to REV MAX, and fully press the brake pedals.

Note: If ground spoilers are not armed, ground spoilers extend at reverser thrust selection.

REVERSERS..... CHECK/ANNOUNCE

Check that the ECAM E/WD displays that the reverse deployment is as expected (REV green).

DIRECTIONAL CONTROL..... MONITOR/ENSURE

- Monitor directional control, if the rollout is automatic.
- Ensure directional control, if rollout is manual. Use rudder pedals for directional control.
- Do not use the nosewheel steering control handle before reaching taxi speed.
- During rollout, the flight crew should avoid sidestick inputs (either lateral or longitudinal).
- If directional control problems are encountered, the flight crew should reduce thrust to reverse idle until directional control is satisfactory.

BRAKES..... AS RQRD

- Monitor the autobrake, if it is ON. When required, brake with the pedals
- Although the green hydraulic system supplies the braking system, if pedals are pressed rapidly, a brake pressure indication appears briefly on the BRAKE PRESS indicator.
- Braking may begin before the nosewheel has touched down, if required for performance reasons. However, when comfort is the priority, the flight crew should delay braking until the nosewheel has touched down.

Note: If no ground spoilers are extended, the autobrake is not activated.

DECELERATION..... CHECK/ANNOUNCE

The deceleration is felt by the flight crew, and confirmed by the speed trend on the PFD.


Ident.: PRO-NOR-SOP-19-A-00010353.0001001 / 17 JUL 13

**AT 70 KT**

SEVENTY KNOTS..... ANNOUNCE

BOTH THRUST LEVERS..... REV IDLE

*It is better to reduce thrust when passing 70 kt. However, high levels of reverse thrust may be used in order to control aircraft speed in the case of an emergency.*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - LANDING</p>
---	--

**CAUTION** *Avoid the use of high levels of reverse thrust at low airspeed, unless required due to an emergency. The distortion of the airflow, caused by gases reentering the compressor, can cause engine stalls that may result in excessive EGT.*

Ident.: PRO-NOR-SOP-19-A-00010354.0001001 / 17 MAR 11

**AT TAXI SPEED**

BOTH THRUST LEVERS..... FWD IDLE

- *When reaching taxi speed, and before leaving the runway, deselect the reversers.*
- *On snow-covered grounds, the reversers should be stowed when the aircraft speed reaches 25 kt.*
- *When deselecting the reversers, be careful not to apply forward thrust by moving the thrust levers beyond the FWD IDLE position.*

**CAUTION** *Except in an emergency, do not use the reverse thrust to control the aircraft speed while on taxiways.*

*On taxiways, the use of reversers, even when restricted to idle thrust, would have the following effects:*

- *The engines may ingest fine sand and debris that may be detrimental to the engines and airframe systems.*
- *On snow-covered areas, snow will recirculate into the air inlet, and may cause an engine flameout or rollback.*

Ident.: PRO-NOR-SOP-19-A-00010355.0001001 / 30 MAR 15

**BEFORE 20 KT**

AUTO BRK..... DISENGAGE

*Disengage the autobrake to avoid some brake jerks at low speed.  
The flight crew should use brake pedals to disengage the autobrake.*

**AUTOLAND**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-19-B-00020897.0001001 / 20 MAR 17

The following items must be performed in addition to previous *Refer to PRO-NOR-SOP-APPROACH USING LOC G/S.*



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - LANDING

Ident.: PRO-NOR-SOP-19-B-00020898.0001001 / 20 MAR 17

**AT 350 FT RA**

ILS /GLS  $\nabla$  /MLS  $\nabla$  COURSE on PFD.....CHECK  
*If the ILS /GLS  $\nabla$  /MLS  $\nabla$  course pointer and the runway track differ by more than 5 °, autoland is not authorized.*

Ident.: PRO-NOR-SOP-19-B-00020899.0001001 / 20 MAR 17

**AT 40 FT RA**

FLARE mode..... CHECK ENGAGED/ANNOUNCE  
*Monitor flare by flight instrument.*  
*If NO FLARE mode at 30 ft, discontinue the approach or perform a manual landing if visual references are acquired.*

Ident.: PRO-NOR-SOP-19-B-00020900.0001001 / 20 MAR 17

**AT 30 FT RA**

THRUST IDLE..... CHECK  
*Monitor thrust reduction.*

Ident.: PRO-NOR-SOP-19-B-00020901.0001001 / 20 MAR 17

**AT 10 FT RA**

BOTH THRUST LEVERS..... IDLE  
*Retard thrust levers at the "RETARD" autocalout.*  
 LATERAL GUIDANCE..... MONITOR  
*Monitor the lateral guidance by using external references.*

Ident.: PRO-NOR-SOP-19-B-00020902.0001001 / 11 JUL 17


**AT TOUCHDOWN**

*Note: In the case of NWS or Anti-Skid failure, set the AP OFF at touchdown.*

ROLL OUT mode.....CHECK ENGAGED/ANNOUNCE  
 BOTH THRUST LEVERS.....REV MAX or REV IDLE  
*The flight crew must select reverse thrust immediately after main landing gear touchdown.*

*The flight crew must immediately select REV MAX, if any of the following occurs at any time during the landing:*

- An emergency
- The deceleration is not as expected
- A failure affects the landing performance

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p align="center"><b>PROCEDURES</b>  <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - LANDING</p>
---	---

- A long flare or a long touchdown
- An unexpected tailwind.

*A small pitch up may occur during thrust reversers deployment before nose landing gear touchdown. However, the auto-flight system will control this pitch up.*

*As soon as the flight crew selects reverse thrust, they must perform a full-stop landing.*

**GROUND SPOILERS..... CHECK/ANNOUNCE**

*Check that the WHEEL SD page displays the ground spoilers extended after touchdown.*

*If no ground spoilers are extended:*

- Verify and confirm that both thrust levers are set to IDLE or REV detent.
- Set both thrust reverser levers to REV MAX, and fully press the brake pedals.

Note: *If ground spoilers are not armed, ground spoilers extend at reverser thrust selection.*

**REVERSERS..... CHECK/ANNOUNCE**

*Check that the ECAM E/WD displays that the reverse deployment is as expected (REV green).*

**DIRECTIONAL CONTROL.....MONITOR/ENSURE**

- Monitor directional control, if the rollout is automatic.
- Ensure directional control, if rollout is manual. Use rudder pedals for directional control.
- Do not use the nosewheel steering control handle before reaching taxi speed.
- During rollout, the flight crew should avoid sidestick inputs (either lateral or longitudinal).
- If directional control problems are encountered, the flight crew should reduce thrust to reverse idle until directional control is satisfactory.

**BRAKES..... AS RQRD**

- Monitor the autobrake, if it is ON. When required, brake with the pedals
- Although the green hydraulic system supplies the braking system, if pedals are pressed rapidly, a brake pressure indication appears briefly on the BRAKE PRESS indicator.
- Braking may begin before the nosewheel has touched down, if required for performance reasons. However, when comfort is the priority, the flight crew should delay braking until the nosewheel has touched down.

Note: *If no ground spoilers are extended, the autobrake is not activated.*

**DECELERATION..... CHECK/ANNOUNCE**

*The deceleration is felt by the flight crew, and confirmed by the speed trend on the PFD.*

Ident.: PRO-NOR-SOP-19-B-00020904.0001001 / 11 JUL 17

**AT 70 KT**

**SEVENTY KNOTS..... ANNOUNCE**

**BOTH THRUST LEVERS**..... REV IDLE

*It is better to reduce thrust when passing 70 kt. However, high levels of reverse thrust may be used in order to control aircraft speed in the case of an emergency.*

**CAUTION** | *Avoid the use of high levels of reverse thrust at low airspeed, unless required due to an emergency. The distortion of the airflow, caused by gases reentering the compressor, can cause engine stalls that may result in excessive EGT.*

Ident.: PRO-NOR-SOP-19-B-00020905.0001001 / 20 MAR 17

**BEFORE 20 KT**

**AUTO BRK**..... **DISENGAGE**

*Disengage autobrake before 20 kt to avoid some brake jerks at low speed.  
The flight crew should use brake pedals to disengage the autobrake.*

Ident.: PRO-NOR-SOP-19-B-00020906.0001001 / 20 MAR 17

**END OF ROLL OUT**

**BOTH THRUST LEVERS**.....**FWD IDLE**

- *When reaching taxi speed, and before leaving the runway, deselect the reversers.*
- *On snow-covered grounds, the reversers should be stowed when the aircraft speed reaches 25 kt.*
- *When deselecting the reversers, be careful not to apply forward thrust by moving the thrust levers beyond the FWD IDLE position.*

**CAUTION** | *Except in an emergency, do not use the reverse thrust to control the aircraft speed while on taxiways.*


*On taxiways, the use of reversers, even when restricted to idle thrust, would have the following effects:*

- *The engines may ingest fine sand and debris that may be detrimental to the engines and airframe systems.*
- *On snow-covered areas, snow will recirculate into the air inlet, and may cause an engine flameout or rollback.*

**AP**.....**OFF**

*Disengage the APs at the end of the roll out (when leaving the runway at the latest).*



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - GO-AROUND</p>
---	--

**GO AROUND WITH FD**

Applicable to: ALL

Ident.: PRO-NOR-SOP-20-A-00011576.0014001 / 30 JUN 15

Apply the following three actions simultaneously:

THRUST LEVERS..... TOGA

*If TOGA thrust is not required, set the thrust levers to TOGA detent then retard the thrust levers as required. This enables to engage the GO-AROUND phase, with associated AP /FD modes. The flight crew may use CL detent to have benefit of A/THR.*

Note: *If the thrust levers are not set briefly to TOGA detent, the FMS does not engage the GO-AROUND phase, and flying over, or close to the airport will sequence the Destination waypoint in the F-PLN.*

ROTATION..... PERFORM

*Initiate rotation towards 15 ° of pitch with all engines operative (approximately 12.5 ° if one engine is out) to get a positive rate of climb, then follow the SRS Flight Director pitch bars orders. When near the ground, avoid excessive rotation rate in order to prevent a tail strike.*

GO AROUND ..... ANNOUNCE  
FLAPS lever..... SELECT AS RQRD

*Retract one step of flaps.*

FMA..... ANNOUNCE

*The following modes are displayed: MAN TOGA / SRS / GA TRK or NAV / A/THR (in blue). Depending on the guidance modes during approach, NAV mode is either automatically armed or automatically engaged.*

POSITIVE CLIMB ..... ANNOUNCE

L/G UP ..... ORDER

L/G..... SELECT UP

NAV or HDG mode..... AS RQRD

*Reselect NAV or HDG, as required (minimum height 100 ft).*

AP..... AS RQRD

Note: *Go-around may be flown with both autopilots engaged. Whenever any other mode engages, AP 2 disengages.*

Ident.: PRO-NOR-SOP-20-A-00011579.0002001 / 13 AUG 10

**AT GO-AROUND THRUST REDUCTION ALTITUDE**

THRUST levers..... CL

*LVR CLB flashing on FMA.*

**AT GO-AROUND ACCELERATION ALTITUDE**

Monitor that the target speed increases to green dot.

● **If the target speed does not increase to green dot:**

ALT knob..... CHECK and PULL

● **At F speed:**

FLAPS 1..... ORDER

FLAPS 1..... SELECT

● **At S speed:**

FLAPS 0..... ORDER

FLAPS 0..... SELECT

GND SPLRS..... DISARM

NOSE sw..... OFF

RWY TURN OFF sw..... OFF


OTHER EXTERIOR LIGHTS..... AS RQRD

*The flight crew can maintain the LAND LIGHTS selector set to ON, according to airline policy or regulatory recommendations.*

Note: Consider the next step:

- Engage NAV mode, to follow the published missed approach procedure, or
- Prepare for a second approach by selecting the ACTIVATE APP PHASE, and CONFIRM on the PERF page.

AFTER TAKEOFF/CLIMB CHECKLIST down to the line..... COMPLETE

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - AFTER LANDING</p>
---	--

**AFTER LANDING**

**Applicable to: ALL**



Ident.: PRO-NOR-SOP-21-A-00011841.0001001 / 06 DEC 16

GRND SPLRS..... DISARM

Ident.: PRO-NOR-SOP-21-A-00011840.0001001 / 29 SEP 15

LAND LIGHTS selector ..... RETRACT  
OTHER EXTERIOR LIGHTS..... AS RQRD

*External lights can be turned off, unless they are needed.*

*Set the NAV & LOGO  to ON, as required, to turn on the navigation and logo lights .*

 *The PF may ask the PM to set the exterior lights.*

Ident.: PRO-NOR-SOP-21-A-00011842.0001001 / 22 APR 16

RADAR..... OFF

Ident.: PRO-NOR-SOP-21-A-00011843.0001001 / 06 JAN 16

PREDICTIVE WINDSHEAR SYSTEM  ..... OFF

*Switching the radar and predictive windshear system to OFF after landing avoids risk of radiating persons at the gate area.*

Ident.: PRO-NOR-SOP-21-A-00011844.0001001 / 13 DEC 10

ENG MODE selector..... NORM

Ident.: PRO-NOR-SOP-21-A-00011845.0001001 / 08 AUG 13

FLAPS..... RETRACT

*Set the FLAPS lever to position 0.*

*If the approach was made in icing conditions, or if the runway was contaminated with slush or snow, do not retract the flaps and slats until after engine shutdown and after the ground crew has confirmed that flaps and slats are clear of obstructing ice.*

*On ground, hot weather conditions may cause overheating to be detected around the bleed ducts in the wings, resulting in "AIR L (R) WING LEAK" warnings. Such warnings may be avoided during transit by keeping the slats in Configuration 1 when the OAT is above 30 °C.*

*To avoid damage on the RTL (Rudder Travel Limit Unit) mechanical stop, the SLATS/FLAPS should be retracted before all ADIRS are set to OFF simultaneously.*

Ident.: PRO-NOR-SOP-21-A-00011846.0001001 / 04 JUL 17

TCAS..... STBY

Ident.: PRO-NOR-SOP-21-A-00011847.0001001 / 20 JAN 15

ATC..... AS RQRD  
*ATC is set in accordance with airport requirements.*

Ident.: PRO-NOR-SOP-21-A-00011848.0001001 / 17 MAR 15

APU..... START  
*APU START may be delayed until just prior to engine shutdown.*

Note: *Prolonged use of the APU may cause a fuel imbalance. Pay particular attention to the fuel imbalance limitation for the next take-off.*

Ident.: PRO-NOR-SOP-21-A-00011849.0005001 / 17 MAR 17


**CAUTION** In icing conditions (*Refer to LIM-ICE\_RAIN Definition of Icing Conditions*), the flight crew must turn on the engine anti-ice and should not wait until seeing ice building up.

ANTI ICE..... AS RQRD

- *If engine anti-ice is used, take care to control taxi speed, especially on wet or slippery surfaces. (N1 ground idle is increased).*
- *During ground operation, when in icing conditions for more than 30 min, the following procedure should be applied for ice shedding:*

**CAUTION** *If, during thrust increase, the aircraft starts to move, immediately retard the thrust levers to IDLE.*

*If ground surface conditions and the environment permit, the flight crew should accelerate the engines to approximately 70 % of N1 for 30 s at intervals not greater than 30 min.*  
*If ground surface or environment do not permit to accelerate the engine to 70 % N1, then power setting and dwell time should be as high as practical.*  
*When operating in conditions of freezing rain, freezing drizzle, freezing fog or heavy snow, ice shedding may be enhanced, by additional run ups at intervals, to not exceed 10 min, advancing throttles to 70 % N1 momentarily (no hold time).*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">STANDARD OPERATING PROCEDURES - AFTER LANDING</p>
---	--

Ident.: PRO-NOR-SOP-21-A-00011850.0001001 / 17 MAR 17

**BRAKE TEMPERATURE..... CHECK**

- Check brake temperature on the WHEEL SD page for discrepancies and high temperature
- Maintenance action is due in the following cases:
  - The temperature difference between two brakes of a gear is more than 150 °C, and the temperature of one of these brakes is above or equal to 600 °C, or
  - The temperature difference between two brakes of a gear is more than 150 °C, and the temperature of one of these brakes is below or equal to 60 °C, or
  - The difference between the average temperature of the left gear brakes (combination of body and wing L/G s) and right brakes (combination of body and wing L/Gs) is above or equal to 200 °C, or
  - The temperature of one brake exceeds 900 °C.

**BRK FAN pb-sw  ..... AS REQUIRED**

*When the turnaround time is short or if the temperature of any brake is likely to exceed 500 °C, use the brake fans without delay. In other cases, the flight crew should delay brake fans selection to 5 min after landing, or approaching the gate, whichever occurs first.*

 For more information, Refer to FCTM/PR-NP-SOP-270 Use of Brake Fans.

Ident.: PRO-NOR-SOP-21-A-00011851.0001001 / 10 AUG 10


**AFTER LANDING CHECKLIST..... COMPLETE**

*Ensure that the after-landing checks are completed, once the aircraft has cleared the runway.*

Ident.: PRO-NOR-SOP-21-A-00020077.0001001 / 17 MAR 17

**AFTER LANDING - FLOW PATTERN**

After Landing Flow Pattern



**→ PF ACTIONS**

**→ PM ACTIONS**

**① GRND SPLRS .....DISARM**

**② RADAR/PREDICTIVE WINDSHEAR....OFF**


**③ ENG MODE SEL.....NORM**

**④ FLAPS.....RETRACT**

**⑤ { ATC.....AS RQRD  
TCAS.....SET on standby**

**⑥ APU.....START**

**⑦ ANTI ICE.....AS RQRD**

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">STANDARD OPERATING PROCEDURES - PARKING</p>
---	--


**PARKING**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-22-A-00011852.0001001 / 21 MAR 17

Prior to performing this check, consider “GROUND OPERATIONS IN HEAVY RAIN” (*Refer to PRO-NOR-SUP-ADVWXR Ground Operations in Heavy Rain*).

Ident.: PRO-NOR-SOP-22-A-00011853.0003001 / 20 JUL 15

- ACCU PRESS indicator..... CHECK  
*The ACCU PRESS indication must be in the green band. In case of low accumulator pressure, chocks are required before engine 1 shutdown.*
- PARKING BRAKE handle..... ON  
*When one brake temperature is above 500 °C (or 350 °C with brake fans  ON), avoid applying the parking brake, unless operationally necessary.*
- BRAKES PRESS indicator..... CHECK  
*Check for normal indications.*

Ident.: PRO-NOR-SOP-22-A-00011854.0001001 / 13 AUG 10

ANTI-ICE..... OFF

Ident.: PRO-NOR-SOP-22-A-00011855.0001001 / 13 AUG 10

APU BLEED pb-sw..... ON  
*Select APU bleed ON, just before engine shutdown, to prevent engine exhaust fumes from entering the air conditioning.*

Ident.: PRO-NOR-SOP-22-A-00011856.0004001 / 17 MAR 17

- **If the APU is not available:**  
EXT PWR pb..... ON
- **No less than 3 min after high thrust operations:**  
ALL ENG MASTERS ..... OFF

**CAUTION** *If JP4 fuel is used at ambient temperatures higher than 10 °C, dry motor the engines for 2 min after engine shutdown. This dry motor period should start approximately 90 s after the master lever is selected OFF.*

Check that engine parameters decrease.  
The DOOR/OXY SD page is displayed on the lower ECAM display.

**L2** Note: *The flight crew should operate the engines at or near idle thrust for a cooling period of 3 min before engine shutdown, in order to thermally stabilize the engines.*

*Idle reverse thrust and normal thrust to maneuver during taxi (i.e. at or near idle), are not considered as high thrust operations. Therefore, both of the following applies:*

- *If the flight crew uses idle reverse thrust for landing and normal thrust to maneuver during taxi after landing, the cooling period starts when the flight crew retards the thrust lever during the flare*
- *If the flight crew uses maximum reverse for landing, the cooling period starts when the flight crew sets the thrust lever to idle reverse during the landing rollout.*

*However, if operationally necessary, all engines can be shut down when the aircraft arrives at the gate, regardless of the time necessary for landing.*

*Before engine shutdown, routine cooling periods that last less than the recommended time, can result in engine degradation.*

Ident.: PRO-NOR-SOP-22-A-00011858.0001001 / 04 MAR 14

SLIDES.....CHECK DISARMED

*Check slides disarmed on the DOOR/OXY SD page. Warn the cabin crew, if any slide is not disarmed.*

Ident.: PRO-NOR-SOP-22-A-00011860.0001001 / 04 MAR 14

SEAT BELTS sw..... OFF

Ident.: PRO-NOR-SOP-22-A-00011859.0001001 / 23 JUN 15

BEACON lights..... OFF

*Turn off the BEACON lights, when all engines are spooled down.*

OTHER EXTERIOR LIGHTS..... AS RQRD

Ident.: PRO-NOR-SOP-22-A-00011857.0001001 / 13 AUG 10

GROUND CONTACT..... ESTABLISH

*Establish ground communication.*

*Check chocks in place.*

Ident.: PRO-NOR-SOP-22-A-00011862.0001001 / 13 AUG 10

FUEL PUMPS..... OFF

Ident.: PRO-NOR-SOP-22-A-00011864.0001001 / 04 JUL 17


ATC..... STBY



Ident.: PRO-NOR-SOP-22-A-00011865.0001001 / 20 OCT 16

IRS PERFORMANCE.....CHECK

- The NAV TIME is the cumulated block time since the latest IRS alignment (fast or complete).
- On the MCDU POSITION MONITOR page, read the deviation of each IRS position from the FMGC position and check that the value does not exceed the following:



Ident.: PRO-NOR-SOP-22-A-00011866.0001001 / 13 AUG 10


FUEL QUANTITY.....CHECK

Check that the sum of the fuel on board and the fuel used is consistent with the fuel on board at departure. If an unusual discrepancy is found, maintenance action is due.


Ident.: PRO-NOR-SOP-22-A-00011867.0001001 / 24 FEB 15

STS pb (ECAM Control panel).....PRESS  
*Check the STATUS page.*

Ident.: PRO-NOR-SOP-22-A-00011868.0001001 / 13 AUG 10

(BRAKE FAN  )..... OFF  
*Switch off, when not required.*

Ident.: PRO-NOR-SOP-22-A-00011869.0002001 / 13 AUG 10

PARKING BRAKE..... AS RQRD  
*The parking brake should be released after chocks are in place, if one brake temperature is above 300 °C (or above 150 °C with brake fans  ON).*  
*Releasing the parking brake prevents the critical structures from being exposed to high temperature levels for an extended time. However, if operational conditions dictate (e.g. slippery tarmac), the parking brake may remain applied.*  
*When parking with a flat tire on the nose gear, keep the parking brake on, to avoid aircraft yawing at parking brake release.*

Ident.: PRO-NOR-SOP-22-A-00011870.0001001 / 13 AUG 10

DUs..... DIM  
*Dim EFIS , ECAM and MCDU display units.*

Ident.: PRO-NOR-SOP-22-A-00014395.0001001 / 20 MAR 17

**EFB**

EFB/eQRH transmitting mode..... CONSIDER  
*In accordance with the Operator's policy or, as required by operational regulations.*

● **If performing transit stop:**

eQRH My Aircraft/FLIGHT..... CLEAR

Ident.: PRO-NOR-SOP-22-A-00011873.0001001 / 13 AUG 10

PARKING CHECKLIST..... COMPLETE

Ident.: PRO-NOR-SOP-22-A-00011874.0001001 / 13 AUG 10

**REPORT SEVERE ICING CONDITIONS**

*Report severe icing conditions in the log book, requiring inspections of the fan accoustic panels of the engines during the walkaround.*

**SECURING THE AIRCRAFT**

Applicable to: ALL

Ident.: PRO-NOR-SOP-23-A-00010336.0001001 / 17 MAR 17

**GENERAL**

Prior to performing this check, the following SUP Adverse Weather procedures should be taken into account when appropriate:

- Securing the aircraft for cold soak (*Refer to PRO-NOR-SUP-ADVWXR Securing the Aircraft for Cold Soak*).
- Water system draining (*Refer to PRO-NOR-SUP-ADVWXR For Draining Water Procedure - Introduction*).
- Ground operations in heavy rain (*Refer to PRO-NOR-SUP-ADVWXR Ground Operations in Heavy Rain*).
- Operations on contaminated airports (*Refer to PRO-NOR-SUP-ADVWXR Parking*).
- Operations with volcanic ash, sand or dust (*Refer to PRO-NOR-SUP-ADVWXR Securing the Aircraft*).

Ident.: PRO-NOR-SOP-23-A-00010337.0001001 / 30 JUN 15

**PARKING BRAKE**

PARK BRK handle.....CHECK ON  
*To reduce hydraulic leak rate in the brake accumulator, keep the parking brake on.*

Ident.: PRO-NOR-SOP-23-A-00010338.0001001 / 05 AUG 10

**OXYGEN CREW SUPPLY**

OXYGEN CREW SUPPLY pb.....OFF

Ident.: PRO-NOR-SOP-23-A-00010339.0001001 / 21 AUG 15

**ADIRS**

ALL IR MODE selectors..... OFF  
*After the shutdown of the ADIRS , the flight crew must wait 10 s before the shutdown of the electrical supply. This time ensures that the ADIRS memorize the most recent data.*

Ident.: PRO-NOR-SOP-23-A-00010340.0001001 / 05 AUG 10

**EXTERIOR LIGHTS**

EXTERIOR LIGHTS.....OFF

Ident.: PRO-NOR-SOP-23-A-00010341.0001001 / 05 AUG 10

**MAINTENANCE BUS**

MAINT BUS sw..... AS RQRD  
*Should electrical power be required for the crew or servicing personnel, consider setting the overhead MAINT BUS sw (in the forward cabin) to the ON position, prior to setting aircraft power to off.*

Ident.: PRO-NOR-SOP-23-A-00010342.0001001 / 04 MAR 14

**APU**

APU BLEED pb-sw..... OFF  
APU MASTER SW..... OFF  
*Switch off the APU after the passengers have disembarked.*

Ident.: PRO-NOR-SOP-23-A-00010343.0004001 / 04 MAR 14

**EMER LIGHTS AND SIGNS**

EMER EXIT LT sw..... OFF  
NO PORTABLE/ELEC DEVICE sw..... OFF

Ident.: PRO-NOR-SOP-23-A-00010344.0001001 / 05 AUG 10

**EXTERNAL POWER**

EXT PWR pb..... AS RQRD

Ident.: PRO-NOR-SOP-23-A-00010345.0001001 / 05 AUG 10

**BAT 1 AND 2**

BAT 1 pb-sw and BAT 2 pb-sw..... OFF  
*Wait until the APU flap is fully closed (about 2 min after the APU AVAIL light goes out), before switching off the batteries. Switching the batteries off before the APU flap is closed may cause smoke in the cabin during the next flight.  
If the batteries are off while the APU is running, APU fire extinguishing is not available.*

Ident.: PRO-NOR-SOP-23-A-00010346.0001001 / 05 AUG 10

**SECURING THE AIRCRAFT CHECKLIST**

SECURING THE AIRCRAFT CHECKLIST..... COMPLETE



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - SECURING THE AIRCRAFT

Ident.: PRO-NOR-SOP-23-A-00014412.0001001 / 20 MAR 17

**ELECTRONIC FLIGHT BAG EFB**

EFB/eQRH LAPTOPS..... SWITCH OFF




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - SECURING THE AIRCRAFT

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p>STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS</p>
---	--

**COMMUNICATIONS AND STANDARD TERMS**

Ident.: PRO-NOR-SOP-90-00011900.0001001 / 13 AUG 10  
**Applicable to: ALL**

Standard phraseology is essential to ensure effective crew communication. The phraseology should be concise and exact. The following Chapter lists the callouts that should be used as standard. They supplement the callouts identified in the SOP.  
 These standard Airbus callouts are also designed to promote situational awareness, and to ensure crew understanding of systems and their use in line operation.

**CHECKLIST CALLOUTS**

Ident.: PRO-NOR-SOP-90-00011901.0001001 / 20 DEC 10  
**Applicable to: ALL**

- “CHECK”: A command for the other pilot to check an item.
- “CHECKED”: A response that an item has been checked.
- “CROSSCHECKED”: A callout verifying information from both pilot stations.

If a checklist needs to be interrupted, announce: “HOLD CHECKLIST AT \_\_\_” and “RESUME CHECKLIST AT \_\_\_” for the continuation.  
 Upon completion of a checklist announce: “\_\_CHECKLIST COMPLETE”.

**ACTIONS COMMANDED BY PF**

**Applicable to: ALL**  
 Ident.: PRO-NOR-SOP-90-A-00011902.0001001 / 13 AUG 10

**GENERAL**

The following commands do not necessarily initiate a guidance mode change, eg.: selected to managed/managed to selected. The intent is to ensure clear, consistent, standard communication between crewmembers.  
 All actions performed on the FCU and MCDU must be checked on the PFD and ND (eg.: “FL 350 blue”, “FL 200 magenta”). Ensure that the correct FCU knob is used, then verify indications on the PFD /ND.

Ident.: PRO-NOR-SOP-90-A-00011904.0001001 / 09 JUN 15

**SET**

The “SET” command means using an FCU knob to set a value, but not to change a mode. SET is accomplished by only rotating the appropriate selection knob.

Example:

- "SET GO AROUND ALTITUDE \_\_ FT"
- "SET FL \_\_"
- "SET HDG \_\_"

Ident.: PRO-NOR-SOP-90-A-00011905.0001001 / 20 DEC 10

## **MANAGE/PULL**

The "MANAGE" command means pushing an FCU knob to engage, or arm, a managed mode or target.

The "PULL" command means pulling an FCU knob to engage a selected mode or target. Example:

- "PULL HDG 090" (HDG/TRK knob is pulled and turned).
- "MANAGE NAV" (HDG/TRK knob is pushed).
- "FL 190 PULL" (ALT knob is turned and pulled).
- "FL 190 MANAGE" (ALT knob is turned and pushed).
- "PULL SPEED 250 KNOTS" (SPD/MACH knob is pulled and turned).
- "MANAGE SPEED" (SPD/MACH knob is pushed).

*Note: If the value was previously set, there is no requirement to repeat the figure.  
Simply call e.g. PULL HDG: PULL SPEED: FL PULL.*

The VS/FPA knob has no managed function. The standard callouts for the use of this knob are as follows:

V/S Plus (or Minus) 700 PULL, or

FPA Minus 3 ° PULL (V/S/FPA knob is turned and pulled)

PUSH TO LEVEL OFF (V/S/FPA knob is pushed)

Ident.: PRO-NOR-SOP-90-A-00011906.0001001 / 13 AUG 10

## **ARM**

The "ARM \_\_" command means arming a system by pushing the specified FCU button.

e.g. : "ARM APPROACH"

e.g. : "ARM LOC."


Ident.: PRO-NOR-SOP-90-A-00011907.0001001 / 13 AUG 10

## **ON/OFF**

The simple ON or OFF command is used for the autopilot, flight directors, autothrust and the bird (flight path vector).

e.g.: BIRD ON (The HDG-V/S / TRK-FPA pb is pushed.)



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS
---	--

<b>FMA</b>
------------

Ident.: PRO-NOR-SOP-90-00011908.0001001 / 23 DEC 14

**Applicable to: ALL**

The PF should call out any FMA change, unless specified differently (e.g. CAT II & III task sharing). Therefore, the PF should announce:

- All armed modes with the associated color (e.g. blue, magenta): "G/S blue", "LOC blue".
- All active modes without the associated color (e.g. green, white): "NAV", "ALT".

The PM should check and respond, "CHECKED" to all FMA changes called out by the PF.

<b>ALTITUDE</b>
-----------------

Ident.: PRO-NOR-SOP-90-00011909.0001001 / 23 DEC 14

**Applicable to: ALL**

The PM calls out "one thousand to go" when passing 1 000 ft before the cleared altitude or FL , and the PF calls out "checked".

<b>FLAPS OR GEAR CALLOUTS</b>
-------------------------------

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-90-B-00011910.0001001 / 23 DEC 14

**FLAPS' CALLOUTS**

FLAPS' CONFIGURATION	CALLOUT
1	"FLAPS ONE"
1 + F	"FLAPS ONE"
0	"FLAPS ZERO"

The reply will be given when selecting the new flap position.

e.g.:

	CALLOUT	REMARK
PF	"FLAPS ONE"	
PM	"SPEED CHECKED"	PM checks the speed: - Above the S or F speed and accelerating (Takeoff) - Below VFE next and decelerating (Approach)
	"FLAPS ONE"	PM selects the FLAPS lever position and replies after checking the blue number on the ECAM flaps indicator to confirm the correct selection has been made.

ident.: PRO-NOR-SOP-90-B-00011911.0001001 / 23 DEC 14

**GEAR CALLOUTS**

	CALLOUT	REMARKS
PF	"GEAR UP (DOWN)"	
PM	"GEAR UP (DOWN)"	The PM selects the L/G lever position and replies after checking the red lights on the LDG GEAR indicator to confirm gear operation.

**FLIGHT PARAMETERS**

Applicable to: ALL

ident.: PRO-NOR-SOP-90-C-00011912.0001001 / 22 MAR 17

**APPROACH**

During approach, the PM announces:


- "SPEED" if the speed decreases below the speed target -5 kt or increases above the speed target +10 kt.
- "SINK RATE" when the descent rate exceeds 1 000 ft/min
- "BANK" when bank angle becomes greater than 7 °
- "PITCH" when pitch attitude becomes lower than -2.5 ° or higher than +10 °
- "LOC" or "GLIDE" when either localizer or glide slope deviation is:
  - ½ dot LOC
  - ½ dot GS.
- "CROSS TRACK" when the XTK is greater than 0.1 NM
- "V/DEV" when the vertical deviation is greater than ½ dot
- "COURSE" when greater than ½ dot or 2.5 ° (VOR ) or 5 ° (ADF).
- "\_\_\_ FT HIGH (LOW)" at altitude checks points.

*Note: The PM announces the attitude deviations until landing.*

ident.: PRO-NOR-SOP-90-C-00021570.0001001 / 22 MAR 17

**LANDING**

During landing, the PM announces:

- "PITCH PITCH", if the pitch attitude approaches the tail strike pitch limit indicator  , or reaches 10 °
- "BANK BANK", if the bank angle reaches 7 °.

Ident.: PRO-NOR-SOP-90-C-00011913.0001001 / 22 MAR 17

**GO-AROUND**

During a go-around, the PM announces:

- "BANK", if the bank angle becomes greater than 7 °
- "PITCH", if the pitch attitude becomes greater than 20 ° up or less than 10 ° up
- "SINK RATE", if there is no climb rate.

**PF/PM DUTIES TRANSFER**

Ident.: PRO-NOR-SOP-90-00011914.0001001 / 23 DEC 14

**Applicable to: ALL**

To transfer control, flight crewmembers must use the following callouts:

- To give control : The pilot calls out "YOU HAVE CONTROL". The other pilot accepts this transfer by calling out "I HAVE CONTROL", before assuming PF duties.
- To take control : The pilot calls out "I HAVE CONTROL". The other pilot accepts this transfer by calling out "YOU HAVE CONTROL", before assuming PM duties.

**SUMMARY FOR EACH PHASE**

**Applicable to: ALL**

Ident.: PRO-NOR-SOP-90-D-00011917.0001001 / 23 DEC 14

**TO REMOVE GROUND SUPPLY**

EVENT	PF or PM	GND Mech
Initial ground contact	GROUND (from) COCKPIT	COCKPIT (from) GROUND
External __ disconnection	REMOVE EXTERNAL __	EXTERNAL__ REMOVED

Ident.: PRO-NOR-SOP-90-D-00011918.0001001 / 23 DEC 14

**BEFORE ENGINE START/PUSH BACK**

EVENT	PF	PM
Before start up clearance received	BEFORE START C/L	DOWN TO THE LINE
After start up clearance received	BELOW THE LINE	BEFORE START C/L COMPLETE

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS

Ident.: PRO-NOR-SOP-90-D-00011919.0001001 / 17 MAR 16

PUSH BACK/ENGINE START		
EVENT	PF	GND Mech.
When ready for pushback, and pushback clearance received from ATC	GROUND (from) COCKPIT, CLEARED FOR PUSH	COCKPIT (from) GROUND, RELEASE BRAKES
Start of push	BRAKES RELEASED READY TO PUSH	
When ready to start engines	CLEAR TO START ? STARTING ENG(S)___	CLEAR TO START
When pushback completed	BRAKES SET	SET BRAKES
When ready to disconnect (after engine started, and parameters are stabilized)	CLEAR TO DISCONNECT (hand signals on left/right)	DISCONNECTING (hand signals on left/right)


Ident.: PRO-NOR-SOP-90-D-00011920.0001001 / 23 DEC 14

AFTER ENGINE START		
EVENT	PF	PM
All engines started and stabilized and GND is disconnected	AFTER START C/L	AFTER START C/L COMPLETE

Ident.: PRO-NOR-SOP-90-D-00011921.0002001 / 23 DEC 14

TAXI		
EVENT	PF	PM
When taxi clearance obtained	CLEAR LEFT (RIGHT) SIDE	CLEAR RIGHT (LEFT) SIDE
Brake check	BRAKE CHECK	
Flight control check in the following sequence (the check is possible before the start of taxi)	FLIGHT CONTROL CHECK	
1. Elevators		FULL UP, FULL DOWN, NEUTRAL
2. Ailerons/Spoilers		FULL LEFT, FULL RIGHT, NEUTRAL
3. Rudder <sup>(1)</sup>	RUDDER	FULL LEFT, FULL RIGHT, NEUTRAL
During taxi	BEFORE TAKEOFF C/L	DOWN TO THE LINE
Line up on the runway	BELOW THE LINE	BEFORE TAKEOFF C/L COMPLETE

<sup>(1)</sup> The PM should follow pedal movement with his/her feet

 <b>A318/A319/A320/A321</b> <b>FLIGHT CREW</b> <b>OPERATING MANUAL</b>	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> <b>STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS</b>
---	---

Ident.: PRO-NOR-SOP-90-D-00011922.0001001 / 23 DEC 14

TAKEOFF		
EVENT	PF	PM
Setting thrust levers to initial stabilization value	TAKEOFF	
Before passing 80 kt		THRUST SET
At 100 kt	CHECKED	ONE HUNDRED KNOTS
At V1		V1
At VR		ROTATE
Gear retraction	GEAR UP	POSITIVE CLIMB GEAR UP
If AP is engaged by PM	AP 1(2) ON	
Checklist	AFTER TAKEOFF/CLIMB C/L	DOWN TO THE LINE
At transition altitude	BELOW THE LINE	AFTER TAKEOFF/CLIMB C/L COMPLETE

Ident.: PRO-NOR-SOP-90-D-00011923.0001001 / 17 MAR 16

MALFUNCTION BEFORE V1 AT TAKEOFF		
EVENT	CAPT	F/O
If GO decision	GO	
If RTO decision	STOP	
- REV green on EWD - Deceleration		REVERSE GREEN <sup>(1)</sup> DECEL <sup>(2)</sup>

- (1) *If the reverse deployment is not as expected, call NO REVERSE ENGINE\_\_ or NO REVERSE, as appropriate*
- (2) *In case of failure or no positive deceleration, NO DECEL DECEL callout means that the deceleration is felt by the crew, and confirmed by the speed trend on the PFD.*

Ident.: PRO-NOR-SOP-90-D-00011924.0001001 / 12 MAY 16

ALTIMETER SETTING CHANGES TO/FROM QNH /QFE-STD		
EVENT	PF	PM
Barometric setting change and subsequent altimeter cross-check	SET STANDARD (SET QNH/QFE)  CHECKED	STANDARD (QNH/QFE) CROSS-CHECKED PASSING FL__(__FT) NOW

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS

Ident.: PRO-NOR-SOP-90-D-00011925.0001001 / 17 MAR 16

**APPROACH AND LANDING**

EVENT	PF	PM
Approach checklist	APPROACH C/L	APPROACH C/L COMPLETE
Activation of approach Phase	ACTIVATE APPROACH PHASE	APPROACH PHASE ACTIVATED
RA alive	CHECKED	RADIO ALTIMETER ALIVE <sup>(1)(2)</sup>
At G/S *, FINAL APP engagement, or below GA altitude for approach using FPA guidance	SET GA ALTITUDE __ FT	GA ALTITUDE - SET,
FAF	CHECKED	PASSING__(Fix Name),__ FT,
Landing checklist	LANDING C/L	LANDING C/L COMPLETE
1 000 ft RA	CHECKED	ONE THOUSAND <sup>(2)</sup>
100 ft above MDA /DH	CHECKED	ONE HUNDRED ABOVE <sup>(2)</sup>
MDA /DH visual reference	CONTINUE	MINIMUM <sup>(2)</sup>
MDA /DH no visual reference	GO AROUND-FLAPS	MINIMUM <sup>(2)</sup>
		ONE HUNDRED <sup>(2)</sup> FIFTY <sup>(2)</sup>
After touchdown Ground spoilers extended REV green on EWD		SPOILERS <sup>(3)</sup> REVERSE GREEN <sup>(4)</sup>
Deceleration		DECEL <sup>(5)</sup>
At 70 kt	CHECKED	SEVENTY KNOTS

(1) Crew awareness, crew should now keep RA in scan to landing

(2) PM monitors pin-programmed auto callout, or announces if inoperative.

(3) If the spoilers are not extended, call NO SPOILERS

(4) If the reverse deployment is not as expected, call NO REVERSE ENGINE\_\_ or NO REVERSE, as appropriate.

(5) DECEL Callout means that the deceleration is felt by the crew, and confirmed by the speed trend on the PFD .If no positive deceleration, NO DECEL.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS

Ident.: PRO-NOR-SOP-90-D-00015353.0001001 / 23 DEC 14

DISCONTINUED APPROACH		
EVENT	PF	PM
DISCONTINUED APPROACH decision	CANCEL APPROACH	

Ident.: PRO-NOR-SOP-90-D-00011926.0001001 / 17 MAR 16

GO AROUND		
EVENT	PF	PM
GO AROUND decision	GO AROUND - FLAPS	
Flaps retraction		FLAPS__
Gear retraction	GEAR UP	POSITIVE CLIMB GEAR UP
Checklist	AFTER TAKEOFF/CLIMB C/L	DOWN TO THE LINE
At transition altitude	BELOW THE LINE	AFTER TAKEOFF/CLIMB C/L COMPLETE

Ident.: PRO-NOR-SOP-90-D-00011927.0001001 / 23 DEC 14

AFTER LANDING		
EVENT	PF	PM
Checklist	AFTER LANDING C/L	AFTER LANDING C/L COMPLETE

Ident.: PRO-NOR-SOP-90-D-00011928.0001001 / 23 DEC 14

PARKING		
EVENT	PF	PM
Checklist	PARKING C/L	PARKING C/L COMPLETE

Ident.: PRO-NOR-SOP-90-D-00011929.0001001 / 23 DEC 14

SECURING THE AIRCRAFT		
EVENT	PF	PM
Checklist	SECURING THE AIRCRAFT C/L	SECURING THE AIRCRAFT C/L COMPLETE



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

STANDARD OPERATING PROCEDURES - STANDARD CALLOUTS

Intentionally left blank



**SUPPLEMENTARY PROCEDURES**

Applicable to: ALL

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020244.0001001 / 17 MAR 17

**ADVERSE WEATHER**

- [SUP] AIRFRAME DEICING/ANTI-ICING PROCEDURE ON GROUND (*Refer to procedure*)
- [SUP] GROUND OPERATIONS IN COLD WEATHER CONDITIONS (*Refer to procedure*)
- [SUP] GROUND OPERATION IN HEAVY RAIN (*Refer to procedure*)
- [SUP] MINIMUM SPEED WITH ICE ACCRETION (*Refer to procedure*)
- [SUP] OPERATIONS ON CONTAMINATED AIRPORTS (*Refer to procedure*)
- [SUP] OPERATIONS WITH VOLCANIC ASH, SAND OR DUST (*Refer to procedure*)
- [SUP] SECURING THE AIRCRAFT FOR COLD SOAK (*Refer to procedure*)
- [SUP] FOR DRAINING WATER PROCEDURE (*Refer to procedure*)
- [SUP] WATER SYSTEM DRAINING (*Refer to procedure*)

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020245.0001001 / 20 MAR 17

**COMMUNICATION**

- [SUP] VHF, HF UTILIZATION (*Refer to procedure*)

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020248.0001001 / 17 MAR 17

**ENGINE**

- [SUP] MANUAL ENGINE START (*Refer to procedure*)
- [SUP] ENGINE START WITH EXTERNAL PNEUMATIC POWER (*Refer to procedure*)
- [SUP] CROSSBLEED ENGINE START (*Refer to procedure*)
- [SUP] ENGINE START VALVE MANUAL OPERATION (*Refer to procedure*)
- [SUP] ENGINE VENTILATION (DRY CRANKING) (*Refer to procedure*)
- [SUP] ONE ENGINE TAXI (*Refer to procedure*)

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020249.0001001 / 17 MAR 17

**FUEL**

- [SUP] REFUELING (*Refer to procedure*)
- [SUP] REFUELING WITH ONE ENGINE RUNNING (*Refer to procedure*)
- [SUP] GROUND FUEL TRANSFER (*Refer to procedure*)
- [SUP] DEFUELING (*Refer to procedure*)

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020251.0001001 / 17 MAR 17

**LANDING GEAR**

- [SUP] OPERATION WITH NOSEWHEEL STEERING OFFSET (*Refer to procedure*)
- [SUP] FLIGHT WITH GEAR DOWN (*Refer to procedure*)



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SUPPLEMENTARY PROCEDURES -  
SUPPLEMENTARY PROCEDURES MENU

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020254.0001001 / 17 MAR 17

#### MISCELLANEOUS

[SUP] MISCELLANEOUS (*Refer to procedure*)

Ident.: PRO-NOR-SUP-SUP-SUP-00-00020252.0001001 / 17 MAR 17

#### NAVIGATION

[SUP] INSERTION OF APPROACH MINIMA (*Refer to procedure*)

**AIRFRAME DEICING/ANTI-ICING PROCEDURE ON GROUND**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ADVWXR-A-00020694.0001001 / 21 MAR 17

**BEFORE FLUID SPRAYING**

In all situations, it is the captain's responsibility to decide if the ground crew must deice/anti-ice the aircraft, and/or if additional deicing/anti-icing treatment are required.

<b>CAUTION</b>	<ul style="list-style-type: none"> <li>- Make sure that the low or high-pressure ground connectors do not supply any external air to the aircraft.</li> <li>- If it is necessary for the ground crew to repeatedly anti-ice the aircraft, they must deice the surfaces with a hot fluid mixture before applying a new layer of anti-icing fluid.</li> </ul>
----------------	---

COMMUNICATION WITH GROUND CREW.....ESTABLISH

**L2** Establish communication with the crew that will apply the procedure.

**L1** DEICING/ANTI-ICING FLUIDS TYPE..... CHECK APPROPRIATE

**L2** Check that the ground crew uses the correct deicing/anti-icing fluids, in accordance with the applicable operator requirements and aircraft maintenance manual (AMM).

**L1** DO NOT START THE ENGINES DURING FLUID SPRAYING

**L2** Engines and APU can be either stopped or running during deicing/anti-icing.

<b>CAUTION</b>	<ul style="list-style-type: none"> <li>- The ground crew should take care when spraying deicing fluid, and make sure that the engines and APU do not ingest any fluid.</li> <li>- Do not move flaps, slats, ailerons, spoilers or elevators if they are not free of ice.</li> <li>- Always ensure that both left and right side of the aircraft receive the same complete and symmetrical deicing/anti-icing treatment.</li> </ul>
----------------	--

**L2** *Note:* In case of frost formation on one or several areas of the wing, the Captain can request a local deicing application only on the affected areas. The Captain shall take care that both wings receive the same symmetrical treatment, even if frost formation does not affect both wing symmetrically. For more information, refer to AMM.

**L1** CAB PRESS MODE SEL.....CHECK AUTO  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 APU BLEED..... OFF

DITCHING pb..... ON

**L2** *Outflow valve, pack valves, and avionic ventilation inlet and extract valves close. This prevents deicing/anti-icing fluid from entering the aircraft. Avionic ventilation is in a closed circuit with both fans running. In view of the low OAT, there is no time limit for this configuration.*

**L1** *Note: For passenger comfort reason, it is not recommended to operate on ground with both PACKS set to OFF for more than 20 min.*

*Note: If the “**VENT AVNCS SYS FAULT**” alert appears, reset the AEVC circuit breaker at the end of the aircraft deicing/anti-icing procedure.  
 AIR COND /AVNCS VENT/CTL D06 on 49VU.  
 AIR COND /AVNCS /VENT/MONG Y17 on 122 VU.*

THRUST LEVERS.....CHECK IDLE  
 “AIRCRAFT PREPARED FOR SPRAYING”..... INFORM GROUND CREW

Ident.: PRO-NOR-SUP-ADVWXR-A-00002311.0001001 / 20 SEP 16

**UPON COMPLETION OF THE SPRAYING OPERATION**

DITCHING pb.....OFF  
 OUTFLOW VALVE.....CHECK OPEN

*On the ECAM PRESS page, confirm that the outflow valve indication reaches the open green position to avoid any unexpected aircraft pressurization.*


ENG BLEED 1 + 2.....ON  
 PITOTS and STATICS (ground crew).....CHECK

**CAUTION** When the OAT is low (below -5 °C) during snow/freezing rain precipitations , melted snow or raindrops may drip from the cockpit windshields and freeze on the fuselage below. This could create ice build up on the forward fuselage that could possibly disturb the airflow around the static/pitot/angle-of-attack probes, and result in unreliable air data measurements during takeoff. Therefore, during taxi out before takeoff, beware of this possible build up of ice. The area around static/pitot/angle-of-attack probes must be free of ice/snow before starting takeoff.

GROUND EQUIPMENT..... REMOVE  
 DEICING/ANTI-ICING REPORT.....RECEIVED

*The information from ground personnel, who performed the deicing/anti-icing and post-application check, must include (ANTI-ICING CODE):*

- Type of fluid used
- The mix ratio of fluid to water (for example 75/25)
- When the holdover time began.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p align="center">SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER</p>
---	---

● **At least 5 minutes after completion of spraying operation:**

APU BLEED.....AS RQRD

*Note:* There is a risk of de-icing fluid ingestion by the APU air intake, resulting in specific odors, or smoke warnings. Therefore:

- Keep the APU running with the APU BLEED OFF for 5 min after spraying completion before setting the APU BLEED to ON (if required),
- Consider APU BLEED OFF for takeoff.

NORMAL PROCEDURE..... RESUME

Apply appropriate normal procedures. Pay special attention to the flight control check. In freezing precipitation, perform the appropriate checks to evaluate aircraft icing. Base the decision on whether to takeoff, or to re-protect the aircraft, on the amount of ice that has built up on the critical surfaces since the last deicing/anti-icing, as revealed by a personal inspection from the inside and outside of the aircraft. Make this inspection before the holdover time expires, or just before takeoff.

**GROUND OPERATIONS IN COLD WEATHER CONDITIONS**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ADVWXR-B-00020703.0001001 / 21 MAR 17

**GENERAL**

For ground operations on contaminated runways, Refer to PER-TOF-CTA-10 GENERAL and Refer to PRO-NOR-SUP-ADVWXR General.

The following procedures supplement the normal operating procedures.

Ident.: PRO-NOR-SUP-ADVWXR-B-00020698.0001001 / 21 MAR 17


**SAFETY EXTERIOR INSPECTION**

PROTECTIVE COVERS..... REMOVED  
 APU INTAKE.....CHECK FREE OF SNOW AND ICE  
 PACKS INLET/OUTLET DOORS.....CHECK FREE OF SNOW AND ICE  
 OUTFLOW VALVES.....CHECK FREE OF SNOW AND ICE  
 PRESSURE RELIEF VALVES.....CHECK FREE OF SNOW AND ICE  
 ABOVE ITEMS.....DEICE IF NECESSARY

Ident.: PRO-NOR-SUP-ADVWXR-B-00020699.0001001 / 21 MAR 17

**PRELIMINARY COCKPIT PREPARATION**

PRELIMINARY COCKPIT PREPARATION - SOP.....COMPLETED

 APU is started and the air conditioning is on.

**PROCEDURES**  
**NORMAL PROCEDURES**

**SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER**

*Note:* - Ground power should be used to start the APU if the OAT is -15 °C (5 °F) or below.  
 - With cockpit temperatures below -15 °C (5 °F), the display units may not be available.

**L1 ● If the avionics bay is cold soaked:**

- L2** The aircraft was parked without electrical ground supply or without air conditioning.
- L1** IRS..... INITIATE ALIGNMENT
- L2** For temperatures at or below -15 °C (5 °F) in the avionics bay, the IRS alignment requires 15 min.
- L1** WINDSHIELD AND UPPER COCKPIT FUSELAGE..... ICE/SNOW REMOVED

**CAUTION** With ice or snow accumulated on the windshield and/or the upper cockpit fuselage, and if the PROBE/WINDOW HEAT is on, melted ice or snow running down from these areas could re-freeze on the fuselage area below, if the temperature is very low. This could create ice build-up on the forward fuselage that could possibly disturb the airflow around the static/pitot/angle-of-attack probes.

- PROBE COVERS..... CHECK REMOVED
- L2** Ensure that the probe covers are removed in order to prevent the covers from melting.
- L1** PROBE/WINDOW HEAT..... ON

Ident.: PRO-NOR-SUP-ADVWXR-B-00020700.0001001 / 21 MAR 17

**EXTERIOR WALKAROUND**


SURFACES ..... CHECK FREE OF FROST, ICE AND SNOW

- L2** Check critical surfaces: leading edges, upper wing surfaces, vertical and horizontal stabilizers, all control surfaces, slats and flaps.

*Note:* Thin hoarfrost is acceptable on the upper surface of the fuselage. Refer to LIM-ICE\_RAIN Definition of Thin Hoarfrost

On the underside of the wing tank areas, a maximum layer of 3 mm (0.125 in) of frost is acceptable.

- L1** LANDING GEAR..... CHECK FREE OF FROST, ICE AND SNOW
- L2** Check gear assemblies, lever locks, tires and doors
- L1** ENGINES..... CHECK FREE OF FROST, ICE AND SNOW
- L2** Check inlets, inlet lips, fans, spinners, fan exhaust ducts, reversers assemblies.
- L1** ENGINE FANS..... CHECK FREE ROTATION

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER
---	---

- L2 Check that engine fans are not stuck and can rotate freely.
- L1 DRAINS, BLEEDS, PROBES.....CHECK FREE OF FROST, ICE AND SNOW
- L2 Probes: pitot tubes, static ports, TAT sensors and AOA sensors.
- L1 FUEL TANK VENTS..... CHECK FREE OF FROST, ICE AND SNOW
- RADOME..... CHECK FREE OF FROST, ICE AND SNOW
- WATER SUPPLIES..... CHECK NOT FROZEN AND REFILLED
- L2 Commercial water supplies should have been previously emptied prior to aircraft cold soak.

Ident.: PRO-NOR-SUP-ADVWXR-B-00020701.0001001 / 21 MAR 17

**AFTER START**

- **After first engine start:**
- PROBE/WINDOW HEAT.....AUTO
- L2 Heating will continue to operate automatically.
- L1 NORMAL PROCEDURE..... RESUME

**GROUND OPERATIONS IN HEAVY RAIN**

Ident.: PRO-NOR-SUP-ADVWXR-00020720.0001001 / 21 MAR 17

**Applicable to: ALL**

On ground (Aircraft taxiing or parked) in case of heavy rain, water may enter the avionics ventilation system via the skin air inlet valve.

- **When on ground:**
- EXTRACT.....OVRD
- L2 This closes the skin air inlets, preventing rainwater from entering the avionics bay.
- L1 PACK 1 ON..... CHECK
- PACK 2 ON..... CHECK
- L2 Air conditioning compensates the avionics cooling reduction when the skin air inlet is closed.
- L1 ● **If air conditioning not available:**
- L2 When the aircraft avionics are powered, closing the skin air inlet valve reduces avionics cooling capability. With air conditioning not available, the reduced cooling is efficient for a limited period of time, depending on the outside temperature.

- L1
- Aircraft should not remain powered more than:
    - OAT  $\leq$  39 °C (102 °F): no limit
    - 39 °C (102 °F) < OAT  $\leq$  45 °C (113 °F): 3 h
    - 45 °C (113 °F) < OAT: 30 min

● **After takeoff:**

EXTRACT..... AUTO

**MINIMUM SPEED WITH ICE ACCRETION**

Ident.: PRO-NOR-SUP-ADVWXR-00020722.0002001 / 21 MAR 17

Applicable to: ALL

Evidence of ice accretion can be ice on the visual indicator (between the two cockpit windshields) or on the windshield wipers.

**CAUTION** Extended flight in icing conditions with the slats extended should be avoided.

■ **If wing anti ice is operative:**

■ **In CONF clean, 1, 2 or 3:**

MIN SPEED: VLS + 10 kt

■ **In CONF FULL:**

MIN SPEED: VLS + 5 kt

The minimum speed takes into account ice accretion on non-heated structure.

■ **If wing anti ice is not operative:**

MIN SPEED: VLS + 10 kt/GREEN DOT

The minimum speed takes into account ice accretion on the entire airframe when anti-ice is inoperative.

**OPERATIONS ON CONTAMINATED AIRPORTS**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ADVWXR-C-00020729.0001001 / 21 MAR 17

**GENERAL**

If the ground surfaces are not contaminated but the weather corresponds to icing conditions with falling rain, slush or snow, anticipate a probable resulting runway/surfaces contamination.

There is a low probability of fluid ingestion by the engines which should anyway not degrade the safety. The risk of ingestion is independent of the depth of the contaminant.



Ident.: PRO-NOR-SUP-ADVWXR-C-00020726.0002001 / 21 MAR 17

**SPURIOUS ALERTS**

The radio altimeter indication may fluctuate on contaminated surfaces and trigger auto callouts or GPWS warnings. These alerts can be disregarded.

*Note:* Spurious GPWS warnings may trigger at the apron, during taxi, takeoff and landing runs.

The radio altimeter may also not compute valid data:

- On surfaces covered with snow, ice or deicing fluid, and/or
- Due to deicing fluid on the antenna.

*Note:* As a result, the "**NAV RA 1(2)(1+2) FAULT**" ECAM alert may be triggered. This alert may disappear when the radio altimeter provides valid data again, when:

- The aircraft is on a non-contaminated surface, or
- The antenna is cleaned, or
- A period of time elapses after deicing, allowing the fluid covering the antenna to dry. The taxi time between deicing spot and holding point may be sufficient.

In case of invalid LGCIU information, disregard the following alerts if triggered:

- **ENG DUAL FAILURE**
- **ANTI-ICE CAPT(F/O) TAT FAULT**
- **L/G SHOCK ABSORBER FAULT**

Ident.: PRO-NOR-SUP-ADVWXR-C-00020725.0001001 / 21 MAR 17

**PARKING**

- **After engine shutdown and before shutting down electrical supply:**  
FLAPS/SLATS..... CONFIRM FREE OF CONTAMINATION

**L2** Perform a visual inspection to determine if the flaps/slats mechanism is free of contamination. If necessary, perform decontamination.

**L1** YELLOW ELEC PUMP pb..... ON  
 BLUE ELEC PUMP pb..... AUTO  
 BLUE PUMP OVRD pb..... ON  
 SLATS/FLAPS..... RETRACT

**L2** Monitor slats/flaps retraction on ECAM upper display.

- **When slats and flaps are retracted:**  
 YELLOW ELEC PUMP pb..... OFF  
 BLUE PUMP OVRD pb..... OFF  
 NORMAL PROCEDURE..... RESUME

**OPERATIONS WITH VOLCANIC ASH, SAND OR DUST**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ADVWXR-G-00020733.0001001 / 21 MAR 17

**PRELIMINARY COCKPIT PREPARATION**

APU..... AVOID USE

L2 *Request ground power for air conditioning and electricity. If ground power is not available, the APU should be used only to start the engines.*

L1 WINDSHIELD WIPERS..... DO NOT USE

L2 *Do not use the windshield wipers to remove ash, sand or dust.*

L1 ● **For takeoff performance:**

**BRAKING PERFORMANCE MAY BE DEGRADED**

L2 A layer of volcanic ash, sand or dust on the runway may degrade the braking efficiency.

Ident.: PRO-NOR-SUP-ADVWXR-G-00020734.0001001 / 21 MAR 17

**EXTERIOR WALKAROUND**

SURFACES AND EQUIPMENT.....CHECK FREE OF DEPOSITS

L2 *Ground maintenance should remove ash, sand or dust that has settled on exposed lubricated surfaces and could penetrate seals or enter the engine gas path, air conditioning system, air data probes, access doors and panels and other orifices on the aircraft.*

L1 ENGINE/APU INLETS..... CHECK FREE OF DEPOSITS

L2 Inspect the inlets and order them cleaned of deposit. Have the area within 8 m (25 ft) of the engine inlet cleaned of volcanic ash, as much as practical.

Ident.: PRO-NOR-SUP-ADVWXR-G-00020735.0001001 / 21 MAR 17

**ENGINE START**

Use external pneumatic supply, if available, to start the engines. *Refer to PRO-NOR-SUP-ENG Engine Start with External Pneumatic Power.*

ENGINE..... CRANK

L2 *Before starting the engines, ventilate them by dry cranking at maximum motoring speed for two minutes. This will blow away any contaminant ash that may have entered the booster area.*

Ident.: PRO-NOR-SUP-ADVWXR-G-00020736.0001001 / 21 MAR 17

**TAXI**

- ONE ENGINE TAXI.....DO NOT PERFORM
- L2 *Minimize the thrust during taxi.*
  - L1 ENG 1 BLEED..... OFF
  - ENG 2 BLEED..... OFF
  - L2 Keep engine bleed valves closed for taxiing, especially in volcanic ash.
  - L1 FOR 180 ° TURN ON RUNWAY: INITIATE THE TURN DOWNWIND
  - L2 In order to prevent ash, sand or dust ingestion.

Ident.: PRO-NOR-SUP-ADVWXR-G-00020737.0001001 / 21 MAR 17

**TAKEOFF**

- ASH, SAND OR DUST..... ALLOW TO SETTLE
- L2 *Allow ash, sand or dust to settle on runway before starting the takeoff roll.*
  - L1 PACK OFF TAKEOFF..... CONSIDER
  - L2 *This will prevent air conditioning system contamination.*
  - L1 ROLLING TAKEOFF..... CONSIDER

Ident.: PRO-NOR-SUP-ADVWXR-G-00020738.0001001 / 21 MAR 17

**AFTER TAKEOFF**

- MINIMIZE TIME IN SAND OR DUST CLOUD
- L2 *Climb to quickly exit the sand/dust cloud. If possible, altitude constraints may be disregarded in coordination with ATC.*
  - L1 ENG 1 BLEED..... ON
  - ENG 2 BLEED..... ON

Ident.: PRO-NOR-SUP-ADVWXR-G-00020739.0001001 / 21 MAR 17

**IN FLIGHT**

- AVOID ASH, SAND OR DUST CLOUD
- **If sand or dust cloud encounter:**
  - MINIMIZE TIME IN SAND OR DUST CLOUD
  - L2 *If possible and in coordination with ATC, adapt flight path (route and altitude) to exit the cloud.*
  - L1 ● **If ash cloud encounter:**
  - VOLCANIC ASH ENCOUNTER PROCEDURE..... APPLY



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER

*Refer to PRO-ABN-MISC [QRH] VOLCANIC ASH ENCOUNTER .*

ident.: PRO-NOR-SUP-ADVWXR-G-00020740.0001001 / 21 MAR 17

**DESCENT PREPARATION**

AUTOLAND RECOMMENDED

**L2** *Deposits on the windshield and landing lights may significantly reduce visibility during approach and landing. Consider a diversion to an airport where autoland is possible.*

**L1** ● **For landing performance:**  
 CONSIDER IDLE REVERSE  
 BRAKING PERFORMANCE MAY BE DEGRADED

**L2** *A layer of volcanic ash, sand or dust on the runway may degrade the braking efficiency.*

ident.: PRO-NOR-SUP-ADVWXR-G-00020741.0001001 / 21 MAR 17

**DESCENT**

AVOID LEVEL FLIGHT IN ASH, SAND OR DUST CLOUD

*If possible and in coordination with ATC, perform holding patterns and last level off before final descent outside of the cloud.*

ident.: PRO-NOR-SUP-ADVWXR-G-00020742.0001001 / 21 MAR 17

**LANDING**

● **Before Landing:**  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 PACK 1 and 2..... AS REQUIRED

**L2** *Consider to set the packs OFF in order to avoid contamination of the air conditioning system.*

**L1** ● **During Landing:**  
 REVERSERS.....AS REQUIRED

**L2** *If it appears that maximum reverse thrust is needed, apply reverse thrust when the main landing gear touches down. Limit the use of reverse thrust as much as possible, because reverse flow may throw up ash, sand or dust and impair visibility.*


ident.: PRO-NOR-SUP-ADVWXR-G-00020744.0001001 / 21 MAR 17

**AFTER LANDING**

ONE ENGINE TAXI.....DO NOT PERFORM

**L2** *Minimize thrust during taxi.*

**L1** APU..... AVOID USE

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER</p>
---	---

FOR 180 ° TURN ON RUNWAY: INITIATE THE TURN DOWNWIND

Ident.: PRO-NOR-SUP-ADVWXR-G-00020745.0001001 / 21 MAR 17

**SECURING THE AIRCRAFT**

If the aircraft is parked at an airport covered with volcanic ash, sand or dust, install engine inlet covers and other protective covers and plugs.

In addition:

- **After switching off all bleeds and before switching off the electrical AC power:**  
DITCHING pb..... ON
- L2 *This closes the outflow valve, pack valves and avionics ventilation inlet and extract valves.*
- L1 ● **After switching off the electrical AC power and the batteries:**  
DITCHING pb..... OFF
- L2 *All the applicable valves will open at the next power-up.*
- L1 PROTECTIVE COVERS..... INSTALL
- L2 *Request ground crew to install protective covers and plugs, in order to protect the aircraft and engines from volcanic ash, sand or dust.*
- L1 LOGBOOK..... REPORT ASH, SAND OR DUST CLOUD ENCOUNTER

**SECURING THE AIRCRAFT FOR COLD SOAK**

Ident.: PRO-NOR-SUP-ADVWXR-00020772.0001001 / 21 MAR 17  
Applicable to: ALL

**WHEN SECURING THE AIRCRAFT**

- **After switching off all bleeds and before switching off the electrical AC power:**  
DITCHING pb ..... ON
- L2 *This closes the outflow valve, pack valves and avionics ventilation inlet and extract valves.*
- L1 ● **When the chocks are in place:**  
PARKING BRAKE pb ..... OFF
- L2 *Releasing the parking brake prevents the brakes from freezing.*
- L1 ● **After switching off the electrical AC power and the batteries:**  
DITCHING pb ..... OFF
- L2 *All the applicable valves will open at the next power-up.*
- L1 PROTECTIVE COVERS..... INSTALL
- L2 *Request ground crew to install protective covers and plugs, in order to protect the wheels, the engines and the probes from snow and ice.*

- L1 WATER SYSTEM DRAINING.....REQUEST
- L2 *Request maintenance actions to drain the water system for cold soak prevention purposes.  
 Refer to PRO-NOR-SUP-ADVWXR Water System Draining.*


**FOR DRAINING WATER PROCEDURE**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ADVWXR-D-00002313.0001001 / 21 MAR 17

**INTRODUCTION**

This procedure uses electrical power.



- ACCESS PLATFORM(S).....PUT IN POSITION
- SHUTOFF VALVE IN GALLEYS/TOILETS..... CHECK OPEN
- FWD/AFT ACCESS PANEL DOORS..... OPEN
- DRAIN PORT CAPS..... REMOVE

*Remove drain port caps on forward drain and aft service panels.*

- DRAIN HOSES.....CONNECT

Connect drain hoses to :

- the drain port on the forward drain panel.
- the full/drain port on the aft service panel.

Ident.: PRO-NOR-SUP-ADVWXR-D-00002314.0001001 / 21 MAR 17

**ON THE FORWARD DRAIN PANEL**

- DRAIN CONTROL HANDLE.....TURN LEFT

*Turn the control handle to drain.*

Ident.: PRO-NOR-SUP-ADVWXR-D-00002315.0001001 / 21 MAR 17

**ON THE AFT SERVICE PANEL**

FILL/DRAIN CONTROL HANDLE.....TURN TO “DRAIN” AND PULL  
*Turn the handle to the “DRAIN” position and pull it out to its mechanical stop to drain.*  
*The indicator light comes on.*

Ident.: PRO-NOR-SUP-ADVWXR-D-00002316.0001001 / 21 MAR 17

**WHEN THE WATER SYSTEM IS DRAINED**

In freezing conditions, the drain valves must stay open to prevent damage to the system. Do not put on the caps and leave the access door open.

DRAIN HOSES.....DISCONNECT  
 PANELS..... CLEAN AND DRY  
 ACCESS PLATFORM(S)..... REMOVE

<b>WATER SYSTEM DRAINING</b>
------------------------------

Ident.: PRO-NOR-SUP-ADVWXR-00002205.0001001 / 21 MAR 17

**Applicable to: ALL**

Drain the water system, if the OAT requires it, as shown below :

Configuration			Exposure time	Water tank drain
Air Conditioning	Cabin temperature	Outside Air Temperature		
ON	Above 10 °C (50 °F)	Between 0 °C and -15 °C (32 °F and 5 °F)	None	Not required
OFF		Below -15 °C (5 °F)	1 h 15 min	Required
		Between 0 °C and -7 °C (32 °F and 19.4 °F)	1 h 30 min	
		Between -7 °C and -15 °C (19.4 °F and 5 °F)	0 h 30 min	
		Below -15 °C (5 °F)	Any	



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SUPPLEMENTARY PROCEDURES - ADVERSE WEATHER

Intentionally left blank



**VHF, HF UTILIZATION**

**Applicable to:** ALL


Ident.: PRO-NOR-SUP-COM-A-00002210.0001001 / 21 MAR 17

- Note:
1. Reception of some frequencies could be noisy, on one or more VHF's. In such cases, try selecting an unaffected one.
  2. If two frequencies are closer than 2 MHz (between VHF 1 and 2, or between VHF 3 and 2), or closer than 6 MHz (between VHF1 and 3), some interference may occur.

Ident.: PRO-NOR-SUP-COM-A-00002211.0002001 / 22 MAR 17

**TUNING**

The pilot should normally use his inside RMP to tune any one of the VHF or HF radios. If the SEL lights come on, when tuning the radio, the pilot should turn them off by selecting the appropriate radio system dedicated to his RMP.



ON/OFF switch..... CHECK ON  
VHF or HF key..... PRESS

The green light comes on.  
ACTIVE and STBY/CRS windows display active and preset frequencies, respectively.

Note: When an RMP tunes a transceiver that is normally associated with another RMP, the SEL lights on both RMPs come on.

**TO CHANGE FREQUENCY**

Rotating knob..... TURN  
Make the STBY/CRS window display the new frequency.

*Outer knob is for units, inner knob for decimals.*

Transfer key..... PRESS

*This interchanges the ACTIVE and STBY frequencies.*

*The receiver is now tuned to the new ACTIVE frequency.*

AM key (if necessary)..... PRESS

*Green light comes on.*

SEL It..... CHECK OFF

*If SEL light is on, select the appropriate radio systems dedicated to the on side RMP.*

**FAILURE CASES**

When an RMP fails :

- The affected RMP no longer controls the selected receiver.
- The frequency displays disappear and the green VHF or HF lights go out.

Affected RMP..... SWITCH OFF

*One RMP can control all receivers.*

- *if RMP 1 fails tune VHF 1 through RMP 3*
- *if RMP 2 fails tune VHF 2 through RMP 3*
- *if RMP 3 fails tune, HF1 <del> through RMP 1, HF2 <del> through RMP 2*
- *if two RMP 's fail, tune all receivers through the remaining RMP.*

Ident.: PRO-NOR-SUP-COM-A-00002212.0004001 / 03 JAN 11

**TRANSMISSION AND RECEPTION**

Note: *If the VHF3 VOICE DIRECTORY page is customized with user frequencies:*

- *Use it as a pure directory*
- *Do not press the key adjacent to the desired frequency for direct turning*
- *VHF 3 in VOICE mode should either be tuned using the MANUAL FREQ field, or using the RMP.*



VHF or HF transmission key..... PRESS

*Green bars on the selected system key light up.*

*Microphones and PTT command are connected to the selected system.*

VHF or HF reception key..... PRESS

*The integrated white light comes on.*

*The receiver brings in the selected system.*

*To adjust the volume, turn the key.*

**Note:** Do not use VHF 3 for communications with ATC , if ACARS is installed, unless VHF 1 and VHF 2 are inoperative.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - COMMUNICATION

Intentionally left blank

**MANUAL ENGINE START**

**Applicable to: ALL**

Ident.: PRO-NOR-SUP-ENG-A-00009443.0001001 / 21 MAR 17

Pilots normally use automatic starting to start an engine.

However, manual starting is recommended in the following cases:

- **After aborting a start, because of:**
  - Engine stall
  - Engine EGT overlimit
  - Low start air pressure
- **When expecting a start abort, because of:**
  - Degraded bleed performance, due to hot conditions, or at a high-altitude airfields.
  - An engine with a reduced EGT margin, in hot conditions, or at a high-altitude airfields.
  - Marginal performance of the external pneumatic power group.

Ident.: PRO-NOR-SUP-ENG-A-00020858.0003001 / 17 MAR 17

**MANUAL ENGINE START PROCEDURE**

*Note:* During a manual engine start, if the flight crew suspects an engine start malfunction, or if an engine-related ECAM alert is triggered, the PF must abort the start sequence as follows:

- Before the PF sets the ENG MASTER lever to ON, the PF must set the ENG MAN START pb-sw to OFF
- After the PF sets the ENG MASTER lever to ON, the PF must set the ENG MASTER lever to OFF, and then the ENG MAN START pb-sw to OFF.


*In that case, the flight crew should consider a dry crank cycle of the affected engine before they perform another start attempt (Refer to PRO-NOR-SUP-ENG Engine Ventilation (Dry Cranking)).*

*Then, in the case of an ECAM alert, the PF must announce "ECAM actions", in accordance with the ECAM management philosophy.*

THR LEVERS.....IDLE

**CAUTION** The engines start regardless of the thrust lever position. If the thrust levers are not set to IDLE, the thrust rapidly increases to the corresponding thrust lever position, causing a hazardous situation.

ENG MODE sel..... NORM THEN IGN/START

 The lower ECAM displays the engine page.

**L1** *Note:* If both engines are started manually, the following procedure applies one engine at a time.

● **When all engines parameters are available on the upper ECAM display (no amber crosses displayed):**

ENG MAN START pb-sw..... ON  
 START VALVE.....CHECK IN-LINE  
 OIL PRESS INCREASE..... CHECK  
 N2 INCREASE..... CHECK

● **If the N2 does not reach 20 %:**

PACK VALVES.....CHECK CLOSED

● **If the APU bleed is used for engine start and the pack valves are closed, shed the APU electrical loads as follows:**

Shedding APU electrical loads enables to increase bleed air pressure.

**L2** GALY & CAB.....OFF

● **If needed, shed also:**

BLUE ELEC PUMP (on ground only).....OFF  
 FUEL X FEED..... ON  
 FUEL PUMPS (except R TK PUMP 2)..... OFF  
 BLOWER..... OVRD  
 CAB FANS.....OFF

● **When N2 reaches 22 % or the maximum motoring speed (20 % minimum):**

*Note:* The maximum motoring speed is defined as the speed at which N2 acceleration is less than 1 % in approximately 5 s.

ENG MASTER..... ON  
 CHRONO..... START

**L2** The PM starts the timing in order to monitor the light-up duration.

**L1** IGNITERS A AND B..... CHECK ON  
 FUEL FLOW INCREASE..... CHECK

● **15 s maximum after fuel flow increase:**

EGT INCREASE..... CHECK  
 N1 INCREASE..... CHECK

If the electrical power supply is interrupted during the start sequence (indicated by loss of ECAM displays), abort the start by setting the ENG MASTER lever to OFF. Then perform a 30 s dry crank (*Refer to PRO-NOR-SUP-ENG Engine Ventilation (Dry Cranking)*).

● **When N2 reaches 50 %:**

START VALVE (between 50 and 56 % N2)..... CHECK CROSS LINE  
 IGNITERS A AND B..... CHECK OFF  
 MAIN ENG PARAMETERS..... CHECK NORMAL  
 SECONDARY ENG PARAMETERS..... CHECK NORMAL

L2 *The gray background on the N2 indication disappears.*

L1

Note: CFM 56-5B1/B2 engines, N2 accelerates slowly from 50 % to idle. Start abort is not required as long as N2 increases.

ENG MAN START pb-sw..... OFF  
 ENG MODE sel..... NORM

● **When no other engine requires to be started manually:**

SHEDDED SYSTEMS..... RESTORE  
 SOP - ENGINE START..... RESUME

**ENGINE START WITH EXTERNAL PNEUMATIC POWER**

Ident.: PRO-NOR-SUP-ENG-00020859.0002001 / 17 MAR 17

Applicable to: ALL

● **Before connecting external pneumatic power :**

PACK 1..... OFF  
 PACK 2..... OFF

L2

Packs are selected off to prevent any possible contamination of the packs by the external pneumatic power.

L1

APU BLEED..... OFF  
 ENG 1 BLEED..... OFF  
 ENG 2 BLEED..... OFF  
 X BLEED..... OPEN

EXTERNAL PNEUMATIC POWER CONNECTION..... REQUEST

● **When cleared to start :**

ENG 2..... START

Note: As necessary, engine 1 can also be started by using the external pneumatic power.  
 If engine 1 is started first, check the brake ACCU pressure prior to engine start.  
 The minimum recommended starter air supply pressure is 30 PSI, when the start valve is open.  
 Two external pneumatic power units may be used in parallel if necessary.

● **After Engine 2 is started :**

EXT PWR..... CHECK AVAIL

**WARNING** Disconnection of the external power with the EXT PWR pb-sw ON may cause injury to the ground engineer. Request disconnection of the external power only with the EXT PWR pb-sw AVAIL.

EXT PWR DISCONNECTION..... REQUEST

*Note:* The external electrical power can be removed after the second engine start.

■ **If external pneumatic power is used to start engine 1 :**

ENG 1..... START

● **When engine 1 is started:**

EXTERNAL PNEUMATIC POWER REMOVAL..... REQUEST  
 X BLEED..... AUTO  
 ENG 1 BLEED..... ON  
 ENG 2 BLEED..... ON  
 PACK 1..... ON  
 PACK 2..... ON

■ **If the crossbleed engine start procedure is used to start engine 1 :**

EXTERNAL PNEUMATIC POWER REMOVAL..... REQUEST  
 PACK 1..... ON  
 PACK 2..... ON  
 ENG 2 BLEED..... ON  
 CROSSBLEED ENGINE START PROC..... APPLY

*Refer to PRO-NOR-SUP-ENG Crossbleed Engine Start*

**CROSSBLEED ENGINE START**

Ident.: PRO-NOR-SUP-ENG-00020860.0001001 / 17 MAR 17

Applicable to: ALL

**CAUTION** Do not perform the crossbleed engine start procedure during pushback. Simultaneous use of engine bleed supply and external pneumatic power supply is prohibited.

One engine must be running in order to supply air for other engine start.


● **Before second engine start :**

APU BLEED..... OFF

**L2** The BLEED valve of the supplying engine reopens and the cross bleed valve closes.

**L1** ENG BLEED (supplying engine)..... ON



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - ENGINES
---	---

- ENG BLEED (receiving engine)..... OFF
- L2** The bleed valve of receiving engine is closed to avoid reverse flow leakage.
- L1** X BLEED..... OPEN
- **When cleared to start :**  
 AREA CLEAR OF OBSTACLES..... CONFIRM
- L2** Ensure increased power jet wake does not constitute any hazard to people or installation behind the aircraft.
- L1** THR LEVER (supplying engine)..... ADJUST FOR BLEED PRESSURE  
 Adjust thrust of supplying engine to obtain an engine bleed pressure of 30 PSI before start initiation, and at least 25 PSI during the start sequence.  
 If the thrust required to obtain the appropriate engine bleed pressure exceeds 40 % N1, pay particular attention to the surrounding area.
- Note:* If the supplying engine is a DAC engine, preset a 30 % N1 before launching the start sequence.
- RECEIVING ENGINE..... START  
 Apply the normal engine start procedure.
- **After start :**  
 THR LEVER (supplying engine)..... IDLE  
 X BLEED..... AUTO  
 ENG BLEED (receiving engine)..... ON  
 PACK 1..... ON  
 PACK 2..... ON

### ENGINE START VALVE MANUAL OPERATION

Ident.: PRO-NOR-SUP-ENG-00020861.0001001 / 17 MAR 17

**Applicable to: ALL**

#### **BEFORE ENGINE START**

Advise ground crew to prepare for manual engine start valve operation.

**WARNING** To ensure safety of the ground crew when starting an engine with manual operation of the start valve, the flight crew should start the affected engine first.

#### **ENGINE START**

AUDIO CONTROL PANEL..... CAB  
 GROUND CREW CLEARANCE..... OBTAIN

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - ENGINES

- **When the ground crew is ready:**  
 “ENGINE 1(2) START”..... ANNOUNCE  
 ENG MODE sel..... IGN/START  
 ENG MASTER..... ON  
 “OPEN START VALVE AND KEEP OPEN”.....ORDER  
*If not maintained in the OPEN position by the ground crew, the start valve closes.*
- **When N2 at 50 %:**  
 “CLOSE START VALVE”..... ORDER  
 SOP – ENGINE START..... RESUME

**ENGINE VENTILATION (DRY CRANKING)**

Ident.: PRO-NOR-SUP-ENG-00020943.0001001 / 17 MAR 17

Applicable to: ALL

On ground, after:

- An unsuccessful manual engine start, or
- An unsuccessful automatic start not followed by an automatic dry crank,


the flight crew can perform a dry crank cycle on the affected engine to remove the fuel vapors.

- **Before dry crank:**  
 ENG MASTER (affected engine)..... CHECK OFF  
 ENG MODE sel..... CHECK NORM  
 ENG MAN START pb-sw (affected engine).....CHECK OFF
- **Dry crank:**  
 ENG MODE sel..... CRANK  
 ENG MAN START pb-sw (affected engine)..... ON

*Note:* To clear fuel vapors, a 30 seconds dry crank cycle is the minimum required.

<sup>L2</sup> *Note:* A manual start sequence can be initiated following a dry crank cycle (Refer to PRO-NOR-SUP-ENG Manual Engine Start - Procedure). The flight crew should consider the starter limitations (Refer to LIM-ENG Starter).

- <sup>L1</sup> ● **When the dry crank is completed:**  
 ENG MAN START pb-sw (affected engine)..... OFF  
 ENG MODE sel..... NORM

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - ENGINES</p>
---	--

**ONE ENGINE TAXI - GENERAL**

**Applicable to: ALL**

Ident.: PRO-NOR-SUP-ENG-CA-00021004.0001001 / 17 MAR 17

Except in some operational conditions (e.g. uphill slopes, slippery taxiways or high gross weights), brake life and fuel savings may govern company policy on permitting aircraft to taxi with one engine shut down.

Before applying this procedure, the flight crew should be aware of the following:

- Taxi with one engine shut down may require higher thrust than usual. Caution must therefore be exercised to avoid excessive jet-blast and the risk of Foreign Object Damage (FOD)
- Slow or tight turns in the direction of the operating engine may not be possible at high gross weights
- When one engine taxi is planned, pay particular attention to the fuel imbalance limitation for the next take-off.

**ONE ENGINE TAXI - AT DEPARTURE**

**Applicable to: ALL**

Ident.: PRO-NOR-SUP-ENG-CB-00021005.0002001 / 17 MAR 17

BRAKE ACCU PRESS.....CHECK

*If necessary, use the Y ELEC PUMP to pressurize the brake accumulator.*

ENG 1..... START

*Engine 1 pressurizes the green hydraulic system, providing normal braking.*

X BLEED.....OPEN

*Open the cross bleed valve in order to supply both packs with engine 1.*

APPLY THE “AFTER START” NORMAL PROCEDURE, BUT:

- Keep the APU running and switch the APU BLEED to OFF.
- The APU generator provides power to the engine fire extinguisher, prevents electrical transients and enables galley operation. Closing the APU BLEED prevents engine exhaust gases ingestion in the air conditioning system.

- Delay the ECAM STATUS check and the wing anti-ice setting until all engines are started.

Ident.: PRO-NOR-SUP-ENG-CB-00021007.0002001 / 17 MAR 17

**BEFORE RELEASING THE PARKING BRAKE**

Y ELEC PUMP..... ON

*This pressurizes the yellow hydraulic system, providing nosewheel steering without using the PTU.*

- L1** APPLY THE “TAXI” NORMAL PROCEDURE, BUT:
- Delay the flight controls check until all engines are started
  - Arm the autobrake after the flight controls check.

Ident.: PRO-NOR-SUP-ENG-CB-00021008.0006001 / 01 JUN 17

**BEFORE TAKEOFF**

ENGINE WARM-UP TIME BEFORE TAKEOFF (remaining engine).....CONSIDER  
*The second engine must be started soon enough before takeoff, in order to take into account the engine start time and ensure the applicable engine warm-up time (Refer to PRO-NOR-SOP-09 After Start - ENG Mode Selector).*

● **For ENG 2 start and when taxiing in a straight line:**

*Note:* During the engine start, a slight jerk forward may occur if the brakes are applied while the aircraft is moving.

*Note:* Maintain taxi in a straight line during at least 5 s after the selection of the ENG 2 master lever to ON, in order to ensure the PTU auto-test is completed.

Y ELEC PUMP.....OFF

- L2** *The yellow electric pump must be set to OFF to enable PTU automatic test during engine 2 start.*


**L1** APU BLEED..... ON  
 ENG 2..... START

APU..... AS RQRD  
 X BLEED..... AUTO

APPLY THE “AFTER START” NORMAL PROCEDURE, INCLUDING:

- ECAM STATUS check
- Selection of the ENG 2 anti-ice and wing anti-ice, as required.

AFTER START CHECKLIST..... COMPLETE  
 FLIGHT CONTROLS..... CHECK  
 AUTO BRK..... MAX

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - ENGINES</p>
---	---

**ONE ENGINE TAXI - AT ARRIVAL**

Applicable to: ALL

Ident.: PRO-NOR-SUP-ENG-CC-00021009.0001001 / 17 MAR 17

APU..... START

*Start the APU before shutting down one engine, in order to provide power to the engine fire extinguisher and avoid electrical transients.*

Ident.: PRO-NOR-SUP-ENG-CC-00021010.0001001 / 17 MAR 17

● **After high thrust operations:**

ENGINE MINIMUM COOLING TIME..... CONSIDER  
*Refer to PRO-NOR-SOP-22 Parking - ENG MASTER Levers.*

● **When the APU indicates AVAIL and taxiing in a straight line:**

*Note: During engine shutdown, a slight jerk forward may occur if the brakes are applied while the aircraft is moving.*

ENG 2..... SHUT DOWN  
Y ELEC PUMP..... ON

*This avoids running the PTU.*

Ident.: PRO-NOR-SUP-ENG-CC-00021011.0001001 / 17 MAR 17

● **At parking:**


Y ELEC PUMP..... OFF  
ENG 1..... SHUT DOWN

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - ENGINES

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - FUEL</p>
---	---

**REFUELING**

Applicable to: ALL


Ident.: PRO-NOR-SUP-FUEL-A-00021256.0002001 / 25 JUL 17

- WARNING**
1. Prior initiation of any ground fuel operations, obey the below fuel safety precautions. This will prevent injury to people and/or damage to the aircraft.
  2. Do not request or perform any ground fuel operations if a fire or engine overheat warning is displayed.
  3. If the APU fails during any ground fuel operations, do not restart the APU. For APU use during refueling/defueling *Refer to LIM-APU APU Start/Shutdown during Refueling/Defueling.*
  4. Do not refuel in bad weather conditions and electrical storms.

**PREPARATION**

SAFETY PRECAUTIONS.....APPLY

*During refueling operations, ensure that:*

- HF transmission (including HF transmission via the HF DATA LINK  pb) is not performed
- The aircraft is properly bonded to the tanker
- The tanker and the aircraft grounding requirement is based on local regulations. Always connect the ground cable to the parking ground point (or to the tanker) before connecting it to the aircraft.
- The external lighting is not operated (except for NAV & LOGO).

*In the cockpit, check that the PARK BRK is ON and that the ACCU PRESS has sufficient pressure. If the PARK BRK cannot be set to ON, check that the chocks are in place.*

ACCESS PLATFORM.....IN POSITION

MAX REFUELING PRESSURE: 50 PSI (3.5 bar)

● **On refueling control panel:**

TEST sw..... LTS

*Lights on the panel come on. FUEL QTY and the PRESELECTED and ACTUAL displays show 8's.*

TEST sw..... HI.LVL

*HI LVL lights change state if the high level sensors and their circuits are serviceable.*

Ident.: PRO-NOR-SUP-FUEL-A-00021257.0002001 / 21 MAR 17

**AUTOMATIC REFUELING**

● **On cockpit refueling control panel:**

REFUEL PWR pb-sw.....ON

*Cockpit panel takes priority. The CKPT light comes on and REFUELG is displayed on the ECAM MEMO.*

[PRESELECTOR sw] REQUESTED BLOCK FUEL..... SET

REFUEL CTL pb-sw..... ON

*Refueling starts. When refueling is finished, the END light comes on.*

REFUEL CTL pb-sw.....OFF

REFUEL PWR pb-sw..... OFF

● **On refueling control panel:**

REFUEL VALVES sel.....CHECK NORM and GUARDED

[PRESELECTOR sw] REQUESTED BLOCK FUEL..... SET

MODE SELECT sw..... REFUEL

START REFUELING

*When the refueling is finished the END light comes on.*

ACTUAL QUANTITY.....CHECK

*The actual quantity must be within 100 kg (220 lb) of the preselected quantity.*

MODE SELECT sw.....OFF and GUARDED

Ident.: PRO-NOR-SUP-FUEL-A-00021260.0001001 / 21 MAR 17

**MANUAL REFUELING**

REFUEL VALVES sel..... SHUT

MODE SELECT sw..... REFUEL

REFUEL VALVES sel (tanks to be filled)..... OPEN

START REFUELING

FUEL QTY.....MONITOR

● **When the contents of the tanks reach the required level :**

Corresponding REFUEL VALVES sel..... SHUT

MODE SELECT sw.....OFF and GUARDED

REFUEL VALVES sel..... NORM and GUARDED



**REFUELING WITH ONE ENGINE RUNNING**

Ident.: PRO-NOR-SUP-FUEL-00001677.0003001 / 21 MAR 17

**Applicable to: ALL**

- Refuel with one engine running only at airports where no external ground pneumatic power is available and only when APU is unserviceable.
- Only the RH fuel couplings can be used.
- Overwing gravity filling is not permitted.
- Disembark all passengers.
- Obtain airport authorization.  
The Airport Fire Department should standby at the aircraft during the entire refueling procedure.
- Point the aircraft into the wind at a location where the slope is negligible.  
Set the parking brake and check its pressure.  
Run engine n° 1 at ground idle with its generator connected.
- Do not start engine n° 2, do not shut down engine n° 1 or do not attempt to start the APU before all fueling operations have been completed.
- Position the fuel truck under the extremity of the right wing. Its pressure should not exceed 30 PSI.
- Follow manual refueling procedure.

**OPERATION MONITORING**

**DURING THE ENTIRE REFUELING PROCEDURE :**

- Monitor the fuel truck shut off valve.
- Be sure that the fueling company is keeping permanent control of the emergency fuel shut off device.
- Have a flight crew member in the cockpit monitoring all systems and the running engine.
- Have a qualified ground crew member at the fueling station to operate the refuel valve switches.
- Monitor the refueling closely and be prepared to close the refuel valves in order not to exceed the following fuel quantities :

DENSITY (kg/l)	0.77	0.78	0.79	0.8	0.81	0.82	0.83
L(R) WING (kg)	5 710	5 780	5 860	5 930	6 005	6 080	6 160
CENTER (kg)	6 030	6 110	6 190	6 270	6 350	6 430	6 500

**AFTER SECOND ENGINE START :**

- **Reset the 3DMCs in order to reinitialize the fuel used values :**
  - DMC 1 SPLY C/B (E11 on 49VU)..... PULL
  - DMC 2 SPLY C/B (Q8 on 121 VU).....PULL
  - DMC 3 SPLY C/B (Q9 on 121 VU).....PULL
  - DMC 3 SPLY STBY (E10 on 49 VU).....PULL

- **After 5 s :**  
 All C/B's.....PUSH

*Note: The T.O MEMO does not appear automatically since one engine is kept running.*

**GROUND FUEL TRANSFER**

Ident.: PRO-NOR-SUP-FUEL-00021258.0001001 / 25 JUL 17


Applicable to: ALL

**WARNING**

1. Prior initiation of any ground fuel operations, obey the below fuel safety precautions. This will prevent injury to people and/or damage to the aircraft.
2. Do not request or perform any ground fuel operations if a fire or engine overheat warning is displayed.
3. If the APU fails during any ground fuel operations, do not restart the APU. For APU use during refueling/defueling *Refer to LIM-APU APU Start/Shutdown during Refueling/Defueling.*

SAFETY PRECAUTIONS.....APPLY


*During ground operations, ensure that:*

- HF transmission is not performed (including HF transmission via the HF DATA LINK  pb)
- If connected :
  - The aircraft is properly bonded to the tanker
  - The tanker and the aircraft grounding requirement is based on local regulations. Always connect the ground cable to the parking ground point (or to the tanker) before connecting it to the aircraft
  - The external lighting is not operated (except for NAV & LOGO).

*In the cockpit, check that the PARK BRK is ON and that the ACCU PRESS has sufficient pressure. If the PARK BRK cannot be set to ON, check that the chocks are in place.*

ACCESS PLATFORM.....IN POSITION

- **On cockpit overhead FUEL panel:**  
 PUMPS (of the tanks not to be defueled)..... OFF  
 MODE SEL pb-sw .....MAN  
 PUMPS (of the tank to be defueled)..... ON
- **if left wing and/or center tanks is (are) to be defueled :**  
 X FEED.....ON  
*OPEN light comes on.*
- **On refueling control panel :**  
 REFUEL VALVES sel (of tanks not to be filled)..... SHUT  
 REFUEL VALVES sel (of tanks to be filled)..... OPEN

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b></p> <p style="text-align: center;">SUPPLEMENTARY PROCEDURES - FUEL</p>
---	--

MODE SELECT sw ..... DEFUEL/XFR

*OPEN light comes on.*

FUEL QTY..... MONITOR

● **When the tank contents reach the required level :**

Corresponding REFUEL VALVES sel..... SHUT

MODE SELECT sw .....OFF and GUARDED

*OPEN light goes out.*

REFUEL VALVES sel.....NORM and GUARDED

Set cockpit FUEL panel to normal configuration.

<b>DEFUELING</b>
------------------


Ident.: PRO-NOR-SUP-FUEL-00021259.0001001 / 25 JUL 17

Applicable to: ALL

<b>WARNING</b>	<ol style="list-style-type: none"> <li>1. Prior initiation of any ground fuel operations, obey the below fuel safety precautions. This will prevent injury to people and/or damage to the aircraft.</li> <li>2. Do not request or perform any ground fuel operations if a fire or engine overheat warning is displayed.</li> <li>3. If the APU fails during any ground fuel operations, do not restart the APU. For APU use during refueling/defueling <i>Refer to LIM-APU APU Start/Shutdown during Refueling/Defueling.</i></li> <li>4. Do not defuel in bad weather conditions and electrical storms.</li> <li>5. Defueling by suction is not possible</li> </ol>
----------------	--

SAFETY PRECAUTIONS.....APPLY

*During defueling operations, ensure that:*

- HF transmission (including HF transmission via the HF DATA LINK  pb) is not performed
- The aircraft is properly bonded to the tanker
- The tanker and the aircraft grounding requirement is based on local regulations. Always connect the ground cable to the parking ground point (or to the tanker) before connecting it to the aircraft
- The external lighting is not operated (except for NAV & LOGO).

*In the cockpit, check that the PARK BRK is ON and that the ACCU PRESS has sufficient pressure. If the PARK BRK cannot be set to ON, check that the chocks are in place.*

ACCESS PLATFORM.....IN POSITION

MAX DEFUELING PRESSURE: 11 PSI (0.75 bar)

● **On cockpit overhead FUEL panel:**

PUMPS..... OFF

● **On refueling control panel:**

REFUEL VALVES sel..... NORM  
 MODE SELECT sw ..... DEFUEL/XFR  
*OPEN light comes on*

● **On cockpit overhead FUEL panel :**

MODE SEL pb-sw ..... MAN  
 PUMPS (of the tank(s) to be defueled)..... ON  
 X FEED..... ON  
*OPEN light comes on*  
 FUEL QTY..... MONITOR

● **When tank contents reach required level**

Corresponding PUMPS..... OFF

● **On refueling control panel:**

MODE SELECT sw ..... OFF and GUARDED  
*OPEN light goes out*  
 REFUEL VALVES sel..... NORM and GUARDED  
 Set cockpit FUEL panel to normal configuration.

## Flight with Landing Gear Down

### GENERAL

Ident.: PRO-NOR-SUP-LG-LG\_DN-00001997.0001001 / 04 SEP 17

Applicable to: ALL

It is possible to perform a flight with the landing gear locked down and the doors closed.

This chapter applies to either of the following two situations:

- The dispatch of an aircraft with the landing gear down, or
- The continuation of the flight when a landing gear retraction failure happens after takeoff.

The limitations, procedures and performance associated to a flight with the landing gear down are described below.

### LIMITATIONS

Ident.: PRO-NOR-SUP-LG-LG\_DN-00001999.0002001 / 04 SEP 17

Applicable to: ALL

For a flight with the landing gear down, all of the following supplementary limitations apply:

- Consider a VMO /MMO of 235 kt/M 0.60
- Landing gear doors must be closed
- Avoid icing conditions
- Do not use managed speeds, except during the approach
- Do not use CLB and DES autopilot modes
- Disregard FMS fuel, altitude, speed, and time prediction. Time prediction is valid on waypoints in cruise only
- Use the TCAS in TA ONLY mode
- The ALTITUDE ALERT feature is not available
- Do not perform ETOPS flight.

*Note:* Ditching with the landing gear down is not assessed.

### PROCEDURES

Applicable to: ALL

Ident.: PRO-NOR-SUP-LG-LG\_DN-B-00002000.0002001 / 04 SEP 17

#### PREFLIGHT

In addition to the SOPs apply the following:

● **VMO/MMO setting:**

VMO/MMO sw.....L/G DOWN

L2 *The switch is located in the avionics compartment (on the 188VU panel). This switch changes the VMO/MMO to 235 kt/M 0.60. As a result, an alert is triggered if the speed exceeds the flight with gear down speed limitation.*

L1 **CAUTION** *In the case of continuation of the flight after a gear retraction failure, the flight crew can not access the VMO/MMO switch. Therefore, the airspeed/Mach number must be carefully monitored in order not to exceed 235 kt/M 0.60 as there is no alert if the aircraft exceeds this limitation.*

Ident.: PRO-NOR-SUP-LG-LG\_DN-B-00002003.0012001 / 04 SEP 17

**FLIGHT CONTROLS**

Failure cases, which would normally lead to ALTN law, will degrade F/CTL laws down to DIRECT law, if the landing gear is extended.

**FAILURE OF BOTH ENGINES**

When both engines are failed, to ease the handling of all the different ECAM procedures resulting from this all engine flame out situation, it is recommended to use the ENG DUAL FAILURE QRH procedure, and if time permits, to clear the ECAM.

Follow all the steps of the QRH procedure, except those that are modified by the procedure below :

■ **If APU is not available**

- Attempt an APU start
- . If APU start is unsuccessful, a windmilling relight can be performed, as long as the speed is above 300 kt (corresponding N2 above 12 %). In this case, increase the aircraft speed and disregard VMO warning.

■ **If APU is available :** perform an assisted relight, when below FL 200.

- Flight controls are in direct laws. Use manual pitch trim as necessary (not indicated on PFD if APU GEN not available).


**TAKEOFF**

Applicable to: ALL

Ident.: PRO-NOR-SUP-LG-LG\_DN-C-00021928.0006001 / 04 SEP 17

**GENERAL**

The recommended takeoff configuration is 1 + F, as this provides the best climb gradient.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b></p> <p><b>NORMAL PROCEDURES</b></p> <p>SUPPLEMENTARY PROCEDURES - L/G</p>
---	--

It is not recommended to takeoff with tailwind.

To take into account the most limiting aspects of the takeoff, the second segment condition and the final segment condition are considered.

Once the takeoff weight determined, read the corresponding speeds in the RTOW chart.

Ident.: PRO-NOR-SUP-LG-LG\_DN-C-00002006.0017001 / 04 SEP 17

**SECOND SEGMENT CONDITIONS**

The MTOW for a flight with gear down can be determined with use of the basic RTOW chart published for a normal flight.

To simplify calculations, a weight reduction percentage is applied for each configuration, regardless of the limitation. This weight reduction takes into account the most critical case which is obstacle clearance.

<b>Takeoff configuration</b>	<b>1 + F</b>	<b>2</b>	<b>3</b>
<b>Weight reduction</b>	22 %	19 %	19 %

**MTOW DETERMINATION**


Enter the basic RTOW chart with the runway conditions (temperature, pressure, etc.) desired aircraft configuration, and obtain the basic MTOW.

Obtain the weight reduction percentage corresponding to the desired takeoff configuration from the above table.

Reduce the previous basic MTOW by this percentage to obtain the MTOW, limited by the second segment condition.

Ident.: PRO-NOR-SUP-LG-LG\_DN-C-00002007.0405001 / 04 SEP 17


<b>FINAL SEGMENT CONDITIONS - LANDING GEAR DOWN - ONE ENGINE INOP</b>		
MAX. CLIMB THRUST SPEED VLS AIR CONDITIONING ON ANTI ICING OFF	CG 25 %	GROSS GRADIENT 1.2 %



**MTOW DETERMINATION**

Enter the chart with the airport's OAT . Move up to the position corresponding to the airport's pressure altitude. Then, move right and obtain the MTOW limited by the final segment condition. In the case of CG forward of 25 %, decrease the obtained weight by 400 kg (900 lb).



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - L/G</p>
---	--

**FLIGHT PLANNING**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002011.0001001 / 04 SEP 17

Applicable to: ALL

**GENERAL**

Flying with the gear down induces additional drag and therefore deteriorates aircraft performance. This drag affects all phases of the flight where the landing gear is normally retracted.

**MAXIMUM TAKEOFF WEIGHT DETERMINATION**

The MTOW for the flight with gear down is determined by keeping the lowest of the weights given by:

- The second segment condition
- The final segment condition
- The en-route conditions
- The go-around conditions.

To determine the MTOW for a flight with the gear down, perform all following steps:

1. Determine the MTOW limited by the second segment condition (*Refer to PRO-NOR-SUP-LG-LG\_DN Second Segment Conditions*).
2. Determine the MTOW limited by the final segment condition (*Refer to PRO-NOR-SUP-LG-LG\_DN Final Segment Conditions*).
3. Keep the lowest of the above weights as the MTOW.
4. With the MTOW determined in step 3, check the obstacle clearance along the planned route (en-route).

To determine the One Engine Inoperative (OEI) obstacle clearance:

- *Refer to PRO-NOR-SUP-LG-LG\_DN Driftdown Net Flight Path - One Engine Inoperative*
- *Refer to PRO-NOR-SUP-LG-LG\_DN Gross Ceilings - One Engine Inoperative.*

If necessary, reduce the takeoff weight, in order to obtain the appropriate obstacle clearance.

5. Determine the go-around limiting weight (*Refer to PRO-NOR-SUP-LG-LG\_DN Go-Around*). If necessary, reduce the MTOW to comply with this requirement.
6. Keep the lowest MTOW from steps 3, 4, and 5.

**FLIGHT PLAN**

The flight planning can be performed with the use of the tables provided in this procedure, or with a planning software (PEP, FlySmart, etc.).

**FUEL BURN CORRECTION**

The climb, cruise, and descent tables are determined for ISA conditions. For each degree Celsius above ISA and per nautical mile of air distance, add a fuel burn correction of 0.05 kg/°C/NM air distance (0.11 lb/°C/NM air distance).

## **CLIMB**

Climb at 230 kt/M 0.50 with the use of maximum climb thrust.

*Refer to PRO-NOR-SUP-LG-LG\_DN Climb.*

## **CRUISE**

The recommended cruise speed is 230 kt/M 0.50.

*Refer to PRO-NOR-SUP-LG-LG\_DN Cruise.*

## **HOLDING**

The holding configuration is CONF 1.

*Refer to PRO-NOR-SUP-LG-LG\_DN Holding.*

## **DESCENT**

The recommended descent speed is 230 kt/M 0.50.

*Refer to PRO-NOR-SUP-LG-LG\_DN Descent.*

## **GO-AROUND**

*Refer to PRO-NOR-SUP-LG-LG\_DN Go-Around.*

## **LANDING**

The landing is standard.

## **ENGINE FAILURE**

In case of engine failure, select maximum continuous thrust (MCT) on the remaining engine and adopt the specified driftdown speed.

For obstacle clearance and depending on the chosen strategy:

- *Refer to PRO-NOR-SUP-LG-LG\_DN Driftdown Net Flight Path - One Engine Inoperative*
- *Refer to PRO-NOR-SUP-LG-LG\_DN Gross Ceilings - One Engine Inoperative.*

**Note:** *The OEI required obstacle clearances are 1 000 ft in climb or level flight, and 2 000 ft in descent.*

For fuel burn calculations with one engine inoperative and landing gear down, use the standard OEI cruise fuel flow and apply the fuel penalty as per QRH/OPERATIONAL DATA/FUEL PENALTY FACTORS.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PROCEDURES**  
**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - L/G

**CLIMB**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002012.0009001 / 14 FEB 11

Applicable to: ALL

<b>CLIMB 230KT/M.50 - ALL ENGINES - L/G DOWN</b>									
MAX. CLIMB THRUST LIMITS				ISA		FROM BRAKE RELEASE			
NORMAL AIR CONDITIONING				CG=25.0%		TIME (MIN)		FUEL (KG)	
ANTI-ICING OFF						DISTANCE (NM)		TAS (KT)	
WEIGHT AT BRAKE RELEASE (1000KG)									
FL	50	52	54	56	58	60	62	64	66
<b>290</b>	21 1651	23 1778	25 1921	27 2085	30 2277	33 2507			
	98 279	106 280	116 281	127 282	140 283	156 284			
<b>270</b>	18 1500	20 1607	21 1725	23 1858	25 2009	27 2183	30 2389		
	85 277	92 278	99 279	108 279	117 280	129 281	143 282		
<b>250</b>	16 1356	17 1447	19 1546	20 1655	21 1778	23 1915	25 2073	28 2257	31 2475
	74 274	79 275	85 275	92 276	99 277	107 278	117 279	129 280	143 282
<b>240</b>	15 1295	16 1369	17 1459	18 1559	20 1669	21 1792	23 1932	25 2091	27 2277
	68 272	73 273	78 273	84 274	91 275	98 276	106 277	116 278	128 279
<b>220</b>	13 1143	14 1214	15 1289	16 1371	17 1461	18 1559	19 1668	21 1790	22 1928
	58 267	62 268	66 268	70 269	75 270	81 271	87 272	94 273	102 274
<b>200</b>	11 999	12 1057	12 1119	13 1185	14 1256	15 1333	16 1417	17 1509	18 1610
	48 260	51 260	54 261	57 262	61 263	65 263	69 264	74 265	80 266
<b>180</b>	9 845	9 892	10 940	11 992	11 1047	12 1105	12 1167	13 1233	14 1304
	37 250	40 250	42 251	44 251	47 252	50 253	53 253	56 254	59 255
<b>160</b>	7 718	8 756	8 795	9 837	9 880	10 926	10 975	11 1026	11 1080
	29 240	31 240	33 241	35 241	37 242	38 242	41 243	43 244	45 244
<b>140</b>	6 611	6 642	7 675	7 709	7 744	8 781	8 820	9 861	9 904
	23 230	25 231	26 231	27 232	29 232	30 233	32 233	34 234	35 234
<b>120</b>	5 517	5 543	6 570	6 598	6 627	6 657	7 689	7 722	7 756
	19 220	20 221	21 221	22 222	23 222	24 223	25 223	26 224	28 224
<b>100</b>	4 432	4 454	5 475	5 498	5 522	5 546	5 572	6 598	6 626
	14 209	15 210	16 211	17 211	18 212	18 212	19 213	20 213	21 214
<b>50</b>	2 243	2 254	2 266	3 278	3 290	3 303	3 317	3 330	3 344
	6 171	7 172	7 173	7 173	8 174	8 175	9 175	9 176	9 177
<b>15</b>	1 123	1 128	1 133	1 139	1 145	1 151	1 157	2 163	2 170
	2 108	2 109	2 110	2 110	3 111	3 112	3 113	3 113	3 114

11.0-08FOA320.214 CFM56-5B4/P SA211010005K250 0 018590 0 0 2 1.0 500.0 300.00 1 02230.000 .500.000 0 FCOM-N0-02-04-25-007-140

**CRUISE**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002014.0009001 / 14 FEB 11

Applicable to: ALL

<b>CRUISE - 230KT/M.50 - ALL ENGINES - L/G DOWN</b>												
MAX. CRUISE THRUST LIMITS					ISA		N1 (%)		MACH			
NORMAL AIR CONDITIONING					CG = 25.0%		KG/H/ENG		IAS (KT)			
ANTI-ICING OFF							NM/1000KG		TAS (KT)			
WEIGHT (1000KG)	FL100		FL200		FL220		FL240		FL270		FL290	
<b>48</b>	73.9	.417	83.4	.500	83.2	.500	83.2	.500	83.3	.500	83.5	.500
	1768	230	1810	228	1687	219	1577	210	1435	197	1359	188
	75.2	266	84.8	307	90.3	305	95.8	302	104.0	298	108.9	296
<b>50</b>	74.2	.417	83.6	.500	83.5	.500	83.5	.500	83.6	.500	84.0	.500
	1781	230	1825	228	1704	219	1596	210	1459	197	1387	188
	74.6	266	84.1	307	89.4	305	94.7	302	102.3	298	106.7	296
<b>52</b>	74.4	.417	83.8	.500	83.7	.500	83.8	.500	84.0	.500	84.5	.500
	1795	230	1841	228	1722	219	1616	210	1485	197	1417	188
	74.1	266	83.4	307	88.5	305	93.5	302	100.5	298	104.4	296
<b>54</b>	74.6	.417	84.0	.500	84.0	.500	84.1	.500	84.5	.500	85.1	.500
	1810	230	1857	228	1741	219	1638	210	1513	197	1454	188
	73.4	266	82.7	307	87.5	305	92.3	302	98.6	298	101.7	296
<b>56</b>	74.9	.417	84.3	.500	84.3	.500	84.4	.500	84.9	.500	85.7	.500
	1826	230	1875	228	1761	219	1662	210	1543	197	1497	188
	72.8	266	81.9	307	86.5	305	90.9	302	96.7	298	98.9	296
<b>58</b>	75.1	.417	84.5	.500	84.6	.500	84.8	.500	85.4	.500	86.3	.500
	1843	230	1894	228	1782	219	1687	210	1574	197	1541	188
	72.1	266	81.1	307	85.5	305	89.6	302	94.8	298	96.0	296
<b>60</b>	75.4	.417	84.8	.500	84.9	.500	85.1	.500	86.0	.500		
	1861	230	1914	228	1805	219	1714	210	1616	197		
	71.5	266	80.2	307	84.4	305	88.2	302	92.3	298		
<b>62</b>	75.7	.417	85.1	.500	85.2	.500	85.5	.500	86.6	.500		
	1879	230	1935	228	1829	219	1742	210	1660	197		
	70.8	266	79.4	307	83.3	305	86.8	302	89.9	298		
<b>64</b>	76.0	.417	85.3	.500	85.5	.500	85.9	.500				
	1898	230	1957	228	1856	219	1772	210				
	70.0	266	78.5	307	82.1	305	85.3	302				
<b>66</b>	76.3	.417	85.6	.500	85.9	.500	86.3	.500				
	1918	230	1981	228	1883	219	1804	210				
	69.3	266	77.5	307	80.9	305	83.7	302				
<b>68</b>	76.6	.417	85.9	.500	86.2	.500						
	1939	230	2005	228	1912	219						
	68.6	266	76.6	307	79.7	305						

**HOLDING**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002017.0009001 / 04 SEP 17

Applicable to: ALL

<b>RACE TRACK HOLDING PATTERN - S SPEED - ALL ENGINES - L/G DOWN</b>								
MAX. CRUISE THRUST LIMITS					ISA		N1 (%)	
CONFIGURATION 1					CG=25.0%		FF (KG/H/ENG)	
NORMAL AIR CONDITIONING								
ANTI-ICING OFF								
WEIGHT (1000KG)	FL 15	FL 50	FL100	FL120	FL140	FL160	FL180	FL200
<b>46</b>	56.3 1248	59.1 1223	62.9 1206	64.7 1202	66.5 1198	68.3 1194	70.1 1192	71.9 1187
<b>48</b>	57.4 1297	60.3 1274	64.1 1260	66.0 1255	67.8 1251	69.5 1248	71.3 1243	73.2 1239
<b>50</b>	58.6 1347	61.3 1327	65.3 1313	67.2 1308	69.0 1304	70.7 1300	72.5 1296	74.4 1293
<b>52</b>	59.7 1398	62.3 1380	66.6 1366	68.3 1361	70.1 1357	71.8 1353	73.7 1348	75.5 1347
<b>54</b>	60.8 1449	63.3 1434	67.7 1419	69.5 1415	71.1 1410	72.9 1405	74.8 1402	76.7 1402
<b>56</b>	61.7 1501	64.3 1488	68.8 1472	70.5 1467	72.2 1463	74.0 1458	75.9 1457	77.8 1457
<b>58</b>	62.6 1554	65.4 1541	69.8 1525	71.5 1520	73.2 1516	75.1 1512	77.0 1512	78.9 1514
<b>60</b>	63.5 1607	66.4 1594	70.8 1578	72.4 1573	74.2 1569	76.1 1567	78.0 1568	79.8 1571
<b>62</b>	64.4 1659	67.4 1645	71.7 1631	73.4 1626	75.2 1622	77.1 1622	79.0 1624	80.8 1627
<b>64</b>	65.3 1713	68.4 1699	72.6 1684	74.4 1680	76.2 1677	78.1 1678	79.9 1681	81.7 1684
<b>66</b>	66.3 1766	69.3 1753	73.5 1738	75.3 1734	77.1 1733	79.1 1735	80.8 1738	82.6 1743
<b>68</b>	67.2 1819	70.2 1806	74.4 1792	76.2 1789	78.1 1789	80.0 1792	81.7 1796	83.4 1804
<b>70</b>	68.1 1872	71.1 1859	75.3 1847	77.1 1845	79.0 1846	80.8 1850	82.6 1854	84.2 1865
<b>72</b>	69.0 1926	71.9 1913	76.2 1901	78.0 1901	79.9 1904	81.6 1908	83.3 1914	85.0 1928
<b>74</b>	69.8 1981	72.7 1967	77.0 1957	78.9 1958	80.7 1962	82.4 1966	84.1 1975	85.7 1990
<b>76</b>	70.6 2033	73.4 2021	77.8 2013	79.7 2015	81.5 2019	83.2 2024	84.8 2036	
<b>78</b>	71.4 2085	74.2 2075	78.6 2069	80.5 2073	82.2 2077	83.9 2084	85.5 2099	

**DESCENT**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002016.0021001 / 14 FEB 11

Applicable to: **ALL**

<b>DESCENT - M.50/230KT - ALL ENGINES - L/G DOWN</b>									
IDLE THRUST			ISA				<b>MAXIMUM CABIN RATE OF DESCENT 350FT/MIN</b>		
NORMAL AIR CONDITIONING			CG=25.0%						
ANTI-ICING OFF									
WEIGHT (1000KG)	45				55				IAS (KT)
	TIME (MIN)	FUEL (KG)	DIST. (NM)	N1	TIME (MIN)	FUEL (KG)	DIST. (NM)	N1	
FL									
<b>290</b>	7.1	67	33	IDLE	8.2	77	38	IDLE	188
<b>270</b>	6.6	63	30	IDLE	7.6	74	35	IDLE	197
<b>250</b>	6.1	60	28	IDLE	7.1	70	32	IDLE	205
<b>240</b>	5.8	58	26	IDLE	6.8	68	31	IDLE	210
<b>220</b>	5.4	55	24	IDLE	6.3	64	28	IDLE	219
<b>200</b>	4.9	51	22	IDLE	5.8	60	26	IDLE	228
<b>180</b>	4.5	47	20	IDLE	5.2	55	23	IDLE	230
<b>160</b>	4.0	41	17	IDLE	4.6	48	20	IDLE	230
<b>140</b>	3.4	34	15	IDLE	4.0	40	17	IDLE	230
<b>120</b>	2.9	28	12	IDLE	3.4	32	14	IDLE	230
<b>100</b>	2.3	21	10	IDLE	2.7	25	11	IDLE	230
<b>50</b>	1.0	9	4	IDLE	1.2	10	5	IDLE	230
<b>15</b>	.0	0	0	IDLE	.0	0	0	IDLE	230

11.0-08FOA320-214 CFM56-5B4/P 23101000C5KG250 0 018990 0 0-1-350.0 15.0 .00 0 02 .500230.000 .000 0 FCOM-NO-02-04-25-008-170

**GO-AROUND**

Ident.: PRO-NOR-SUP-LG-LG\_DN-00002010.0001001 / 04 SEP 17

Applicable to: **ALL**

Refer to *PER-GOA-GEN GENERAL* for go-around requirements.

Further decrease the basic limiting weight by 15 %.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**  
SUPPLEMENTARY PROCEDURES - L/G


**ONE ENGINE INOPERATIVE**

Applicable to: ALL

Ident.: PRO-NOR-SUP-LG-LG\_DN-D-00002019.0013001 / 04 SEP 17


**EN ROUTE NET FLIGHT PATH - L/G DOWN - ONE ENGINE INOP**

MAX. CONTINUOUS THRUST GREEN DOT SPEED HIGH AIR CONDITIONING ANTI ICE OFF	ISA CG = 23 %	MINIMUM ENGINE
--	------------------	----------------





Ident.: PRO-NOR-SUP-LG-LG\_DN-D-00004080.0005001 / 04 SEP 17



**BLEED CORRECTIONS**

		ISA	≥ ISA +10
LONG RANGE	ENGINE ANTI ICE ON	-500 ft	-2 800 ft
	TOTAL ANTI ICE ON	-1 300 ft	-4 600 ft
GREEN DOT	ENGINE ANTI ICE ON	-200 ft	-1 700 ft
	TOTAL ANTI ICE ON	-1 200 ft	-3 500 ft



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - L/G

Intentionally left blank

**Operation with Nosewheel Steering Offset**

**OPERATION WITH NOSEWHEEL STEERING OFFSET**

Applicable to: ALL

Ident.: PRO-NOR-SUP-LG-LG-A-00020945.0001001 / 17 MAR 17

During taxi in a straight line, the crew may notice aircraft veering tendency. This can be due to external conditions (crosswind, slope....), or to a nosewheel steering offset.

A nosewheel steering offset is usually notified through consecutive crew reports. The NWS offset value is determined regarding the necessary rudder trim input used to cancel the veering tendency.

Ident.: PRO-NOR-SUP-LG-LG-A-00020946.0001001 / 17 MAR 17

When the NWS offset is within admissible limits, the flight crew can operate the aircraft as follows:

**CAUTION** A rudder trim reset must be performed before takeoff. When the rudder trim adjustment is above the maintenance tolerance ( $\pm 0.5^\circ$  NWS offset corresponding to  $\pm 3^\circ$  rudder trim necessary to taxi straight), the flight crew must systematically and accurately report the rudder trim value in the logbook.


NWS Offset	Necessary Rudder Trim Input	Procedure
Offset $\leq 0.5^\circ$	Trim $\leq 3^\circ$	<ul style="list-style-type: none"> <li>● <b>Taxi:</b> RUDDER TRIM.....ADJUST Adjust trim until the aircraft taxies in a straight line. Check input value.</li> <li>● <b>Before takeoff:</b> RUDDER TRIM.....RESET</li> </ul>
$0.5^\circ < \text{Offset} \leq 1.5^\circ$	$3^\circ < \text{Trim} \leq 8.8^\circ$	<ul style="list-style-type: none"> <li>● <b>Taxi:</b> RUDDER TRIM.....ADJUST Adjust trim until the aircraft taxies in a straight line. Check input value.</li> <li>● <b>Before takeoff:</b> RUDDER TRIM.....RESET</li> <li>● <b>Landing:</b> <ul style="list-style-type: none"> <li>● <b>For autoland:</b> MAX CROSSWIND.....10 kt</li> </ul> </li> </ul>
Offset $> 1.5^\circ$	Trim $> 8.8^\circ$	<p>MAINTENANCE ACTION.....REQUEST Do not attempt takeoff. Request for troubleshooting.</p>

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - L/G

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - MISCELLANEOUS
---	---

**Pushback with Power Push Unit**

**PUSHBACK WITH POWER PUSH UNIT VIA THE MAIN LANDING GEAR**

Applicable to: ALL

Ident.: PRO-NOR-SUP-MISC-D-A-00020472.0002001 / 17 MAR 17

When pushback is performed with a Power Push Unit (PPU) via the main landing gear, this procedure replaces the BEFORE PUSHBACK OR START SOP.

- **Before start clearance**  
 SOP - BEFORE START CLEARANCE.....PERFORM
  - L2 Refer to PRO-NOR-SOP-07 Before Start Clearance.
  - L1 BEFORE START CHECKLIST down to the line..... COMPLETE  
 NW STRG DISC MEMO.....CHECK NOT DISPLAYED
  - L2 The ground crew should check that the towing lever is in the normal position.
- L1 ● **At start clearance**  
 PUSHBACK/START CLEARANCE.....OBTAIN
  - L2 Obtain ATC pushback/start clearance.  
 Obtain ground crew clearance.
  - L1 ATC..... SET FOR OPERATION
  - L2 ATC is set in accordance with airport requirements.
  - L1 WINDOWS AND DOORS.....CHECK CLOSED
  - L2 - To ensure that the sliding window is correctly closed, push the handle of the sliding window fully forward to the closed position, and check that the red indicator is visible.  
 - Check, on the ECAM lower display, that all the aircraft doors are closed.  
 - When required by local airworthiness authorities, check that the cockpit door is closed and locked (no cockpit door open/fault indication).  
 If entry is requested, identify the person requesting entry before unlocking the door. With the cockpit door sw on NORM, the cockpit door is closed and locked. If entry is requested from the cabin, and if no further action is performed by the pilot, the cabin crew will be able to unlock the door by using the emergency access procedure. Except for crew entry/exit, the cockpit door should remain closed until engine shutdown.
  - L1 SLIDES..... CHECK ARMED
  - L2 - Check, on the ECAM lower display, that all slides are armed.
  - L1 BEACON sw.....ON

THRUST LEVERS.....IDLE

**CAUTION** Engines will start, regardless of the thrust lever position; thrust will rapidly increase to the corresponding thrust lever position, causing a hazardous situation, if thrust levers are not at IDLE.

ACCU PRESS indicator.....CHECK

**L2** The ACCU PRESS indication must be in the green band. If required, use the electric pump on yellow hydraulic system to recharge the brake accumulator.

**L1** PARK BRK handle.....CHECK ON  
 BRAKES PRESS indicator..... CHECK

**L2** Check for normal indication.

**L1** BEFORE START CHECKLIST below the line..... COMPLETE

Ident.: PRO-NOR-SUP-MISC-D-A-00020473.0002001 / 17 MAR 17

ENG 2..... START

**L2** Engine 2 is usually started first to pressurize the yellow hydraulic system, making the nosewheel steering and parking brake available.

Ident.: PRO-NOR-SUP-MISC-D-A-00020474.0001001 / 17 MAR 17

**PUSHBACK**

Due to a face-to-face situation between the ground personnel and the flight crew, a clear understanding of directional phraseology is essential.

PARK BRK handle.....OFF  
 BRAKES PRESS indicator.....CHECK ZERO

**L2** A slight residual pressure may remain for a short period of time on the triple indicator. Advise the ground crew that the parking brake is off and that the pushback can be started.

**L1** **CAUTION** Do not use the brakes during pushback, except in case of emergency.  
 Do not move flight controls or flap lever.

**L2** In case of emergency, order the ground crew to separate the PPU and move it away from the evacuation areas. Nevertheless, evacuation is possible with the PPU in place.

**L1** STEERING HANDWHEEL.....AS REQUIRED

**L2** Steer the aircraft using guidance from the ground crew.

**L1** ● **When pushback is completed:**

PARK BRK handle.....ON  
 BRAKES PRESS indicator..... CHECK  
 GROUND CREW..... ADVISED TO REMOVE PPU



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - MISCELLANEOUS

● **When PPU is removed and ground crew clearance obtained:**

ENG 1..... START

SOP - AFTER START..... RESUME

*Refer to PRO-NOR-SOP-09 After Start*

**PROCEDURES**

**NORMAL PROCEDURES**

SUPPLEMENTARY PROCEDURES - MISCELLANEOUS

Intentionally left blank



## High Altitude Airport Operations

### HIGH ALTITUDE AIRPORT OPERATIONS

Applicable to: ALL

Ident.: PRO-NOR-SUP-MISC-A-A-00020650.0017001 / 20 MAR 17

**TAKEOFF ON AIRPORT WITH AN ELEVATION OF 9 200 FT OR ABOVE**

**COCKPIT PREPARATION**

HIGH ALT LDG pb-sw (for all on ground operation).....ON

**BEFORE PUSHBACK OR START**

ACCU PRESS..... CHECK

L2

If required, use the HYD YELLOW ELEC PUMP to recharge the brake accumulator.

L1

GEN 1..... OFF

GEN 2..... OFF

G ENG PUMP..... OFF

Y ENG PUMP..... OFF

**ENGINE START**

● **When idle is reached**

GEN 1..... ON

GEN 2..... ON

G ENG PUMP..... ON

Y ENG PUMP..... ON

**TAKEOFF**

*Note: For A/C operating under FAA requirements, as long as the cabin altitude is above 12 000 ft in flight, at least one pilot must use the oxygen mask continuously.*

APU BLEED..... AS RQRD

L2

Packs may be supplied for takeoff by the engine bleed, or by the APU bleed up to 17 000 ft depending on the takeoff performance requirement.

L1

**CRUISE**

LDG ELEV AUTO [CRUISE page].....CHECK

● **When cabin altitude below 12 000 ft and decreasing:**

HIGH ALT LDG pb-sw..... OFF

CHECK THAT CABIN ALTITUDE DECREASES BELOW 9 550 ft +/- 350 ft

**L2** This will allow the CAB PR EXCESS CAB ALT alert to trigger again if necessary despite the clear action.

**L1 LANDING ON AIRPORTS WITH AN ELEVATION OF 9 200 FT OR ABOVE**

**CRUISE**

- If **CAB ALT** exceeds 8 000 ft:  
 LDG ELEV: 8 000 ft:..... SET

**L2** Manually selecting a landing field elevation overrides the FMGS landing field elevation for the remaining time of cruise.

**L1** *Note:* A step descent or turbulence conditions may trigger an early CPC descent mode detection, leading the CPC to start controlling to the landing field elevation pressure.

**DESCENT PREPARATION**

*Note:* For A/C operating under FAA requirements, at least one pilot must use the oxygen mask continuously until landing.

HIGH ALT LDG pb-sw..... ON

**L2** Passengers oxygen masks would drop when cabin altitude is above 14 000 ft +250/-750 ft if HIGH ALT LDG pushbutton switch is OFF.

**L1** *Note:* Passengers oxygen masks drop above 16 000 ft +250/-750 ft cabin altitude if HIGH ALT LDG pushbutton switch is ON.

LDG ELEV..... AUTO

**L2** CPC starts controlling the pressure to the landing field elevation at beginning of descent.

**L1 AFTER LANDING**

HIGH ALT LDG pb-sw (for all on ground operation)..... ON



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**

**FLIGHT CREW  
OPERATING MANUAL**

**PROCEDURES  
NORMAL PROCEDURES**

**SUPPLEMENTARY PROCEDURES - MISCELLANEOUS**

**Operations at QNH Above 1050 hPa**

**GENERAL**

Ident.: PRO-NOR-SUP-MISC-C-00002100.0015001 / 03 FEB 11

Applicable to: ALL

Some airlines may occasionally experience high barometric correction settings above 1 050 hPa, or 31.0 inHg on some airfields, due to polar anticyclonic air mass conditions occurring near the polar area during winter.

The FMS , FCU , ISIS instrument, PFD , and CPCS are capable of operating at QNH /QFE up to 1 100 hPa, or 32.48 inHg.

However, the ATC/TCAS operates only up to 1050 hPa (i.e. as long as the aircraft altitude remains above -1000 feet standard pressure altitude).

Therefore, when using QNH , or QFE for QFE pin-programmed aircraft, for departure and arrival, the crew should be aware of the following consequences, and should apply the following procedures.

It is necessary for the airline to obtain operational approval from its national airworthiness authorities.

**CONSEQUENCES**

Ident.: PRO-NOR-SUP-MISC-C-00002102.0038001 / 17 MAR 11

Applicable to: ALL

**ON THE ATC-TCAS:**

For takeoff, approach and landing, the ATC altitude reporting and the TCAS TA/RA function may generate erroneous altitude information and nuisance TCAS alerts for other aircraft, if the aircraft standard altitude is below -1 000 ft standard pressure altitude.

To avoid this, it is recommended to set ALT RPTG to OFF when the QNH exceeds 1 050 hPa, and to inform the ATC . As a consequence the TCAS reverts to STBY mode.

**PROCEDURES**

Ident.: PRO-NOR-SUP-MISC-C-00002104.0015001 / 20 MAR 17

Applicable to: ALL

**BEFORE TAKEOFF**

ALT RPTG ..... OFF

**L2** ALT RPTG OFF memo and TCAS STBY memo appear on the WD.

**L1** ATC..... NOTIFY

**L2** Notify the ATC that the altitude reporting is not available.

**L1 TAKEOFF**

- Above 1 000 ft, when time permits:

ALT RPTG ..... ON

- L2** As a result, the TCAS automatically reverts to its previous setting.


**L1 APPROACH**

- Before final approach:

ATC.....NOTIFY

- L2** Notify the ATC that the altitude reporting will be turned off.

**L1** ALT RPTG ..... OFF

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SUPPLEMENTARY PROCEDURES - NAVIGATION
---	--


**INSERTION OF APPROACH MINIMA**

Applicable to: ALL

Ident.: PRO-NOR-SUP-NAV-A-00015222.00011001 / 21 MAR 17

**QNH USE FOR AIRCRAFT NOT EQUIPPED WITH QFE OPTION**

This table explains how the flight crew must insert the approach minimum on the MCDU PERF APPR page.

		Guidance Modes			
		LOC G/S CAT II & CAT III approaches	LOC G/S CAT I approaches	FINAL APP	NAV FPA LOC FPA LOC B/C FPA  TRK FPA
MCDU PERF APPR page	BARO field	---	DA	DA or MDA	MDA
	RADIO field	DH or RA	---		
FMA display		"RADIO XXX"	"BARO XXXX"		

Ident.: PRO-NOR-SUP-NAV-A-00015222.00011001 / 21 MAR 17

**QFE USE FOR AIRCRAFT NOT EQUIPPED WITH QFE OPTION**

The crew should not use QFE on aircraft with a "QNH only" pin programming (incorrect profile computation of the managed vertical modes CLB , DES and FINAL APPR, possible false GPWS warnings in mountainous areas).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SUPPLEMENTARY PROCEDURES - NAVIGATION

Intentionally left blank

## Introduction

## INTRODUCTION

Ident.: PRO-NOR-SRP-01-05-00003959.0001001 / 09 OCT 12


Applicable to: ALL

*Note: This chapter is an amplification of the SOP. Anytime it was feasible, the same chapters and the same titles of paragraph were retained.*

The following discussion of the FMGS uses this flight plan as an example.

**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS





## Cockpit Preparation

### FMGS INITIALIZATION

Ident.: PRO-NOR-SRP-01-10-00003960.0002001 / 22 MAY 12

Applicable to: ALL

#### CHECKING THE CLOCK DATE

CHECK the CLOCK DATE and ADJUST, if necessary.

*If the date in the active database does not match the clock date, the MCDU displays “CHECK DATA BASE CYCLE”. If this message appears, check the period of validity in the second database and select it, if required.*



#### **CAUTION**

*Cycling the navigation database deletes the active and secondary flight plans. Do not cycle it while airborne because doing so will delete the flight plan, eliminate all speed predictions, and blank the ND. If the aircraft is in managed speed, Green Dot becomes the speed target.*

#### CHECKING STORED WAYPOINTS, NAVAIDS, RUNWAYS, OR ROUTES

PRESS the DATA key.

PRESS the next page key.

SELECT, successively, as required:

- STORED WAYPOINT
- STORED NAVAIDS
- STORED RUNWAYS
- STORED ROUTES

CHECK the contents of each of these data storages and DELETE items, as appropriate.

**NAVAIDS DESELECTION**

- If NOTAMS indicate that selected NAVAIDs are unreliable or unserviceable, deselect them as follows:


PRESS the DATA key.


SELECT the POSITION MONITOR page.

SELECT the SELECTED NAVAIDS page.

Under “DESELECT”, INSERT the NAVAID identifier in the brackets.

The pilot can only make six deselections.





**FLIGHT PLAN INITIALIZATION**


Applicable to: ALL

Ident.: PRO-NOR-SRP-01-10-A-00003961.0025001 / 22 MAY 12

**GENERAL**

Follow SOP instructions, when the route is a company route stored in the database.





If waypoints, NAVAIDs or airports are not in the NAV database, the crew must define and store them manually, using the “data stored” function.

Ident.: PRO-NOR-SRP-01-10-A-00003962.0046001 / 23 JUN 15

### **ALIGNING IRS**

The alignment phase is completed, when the ADIRS is initialized to an appropriate position. If the GPS is available, initialization is automatic, using the GPS position. Flight crew intervention is not necessary.

However, automatic initialization may be manually overridden by flight crew entry, at any moment during the alignment phase. In this case, perform the following procedure as soon as possible, to prevent delays if an alignment error occurs:

PRESS the INIT key, and then the IRS INIT prompt.

*IRS INIT page is displayed with the airport reference point as default coordinates.*

If necessary, PRESS [1L] and/or [1R] and use scroll keys to adjust the latitude and/or longitude values.

*For example, this can be used to enter the gate precise coordinates when the aircraft is intended to fly without GPS on long segments without radio coverage.*

## PROCEDURES

### NORMAL PROCEDURES

#### SYSTEMS RELATED PROCEDURES - FMS

PRESS the ALIGN ON REF prompt and CONFIRM ALIGN\* prompt.

*The displayed coordinates are sent to ADIRS for initialization.*

*The alignment status changes to ALIGNING ON REF.*

- **If the "CHECK IRS/AIRPORT POS" or "REF/GPS POS DIF" or "REF/LAST IRS POS DIF" message is displayed:**

CHECK the departure airport on INIT A page and CORRECT it if necessary.

REALIGN the IRS per the procedure described previously.

- **If a new FROM or a new CO RTE is entered after IRS alignment is already completed, the ALIGN ON REF prompt is displayed in [6R]:**

REALIGN the IRS per the procedure described previously.

Ident.: PRO-NOR-SRP-01-10-A-00003963.0010001 / 22 MAY 12

**LATERAL FLIGHT PLAN**

**SELECTING A DEPARTURE**

**1** SELECT [1L] [2L] [3L] [4L] [5L] [6L] [1R] [2R] [3R] [4R] [5R] [6R]

```

FROM TIME SPD/ALT ←
LFBO32L
H 3 2 6
9 0 0
    
```

**2** SELECT [1L] [2L] [3L] [4L] [5L] [6L] [1R] [2R] [3R] [4R] [5R] [6R]


```


LAT REV FROM LFBO
43°37.4N/001°22.8E
<DEPARTURE FIX INFO>
LL XING/INCR/NO
[ ]°/[ ]°/[ ]
NEXT WPT
[ ]
    
```

**3** SELECT [1L] [2L] [3L] [4L] [5L] [6L] [1R] [2R] [3R] [4R] [5R] [6R]

```

DEPARTURES FROM LFBO ←
RWY SID TRANS
33L AFR1D NONE
AVAILABLE RUNWAYS
←15L 3000M
146 ILS TG/108.90
←15R 3500M
146 ILS TBS/110.70
33L 3500M
326 ILS TBN/109.30
←33R 3000M
326
<RETURN
    
```



You may use the "NEXT PAGE" , or the "←" or "→" keys to gain access to the listings of runways, SIDs, and transitions.

Procedure


- PRESS the F-PLN key on MCDU
- SELECT the DEPARTURE prompt [1L] key
- SELECT the RWY in USE, SID and TRANS
- CHECK the resulting temporary F-PLN
- If it is correct, INSERT it using [6R] key.
- If it is not correct, ERASE it using [6L] key.



Ident.: PRO-NOR-SRP-01-10-A-00003964.0004001 / 22 MAY 12

**VERTICAL FLIGHT PLAN**

**ENTERING/MODIFYING A SPEED LIMIT**




PRESS the F-PLN key on the MCDU.  
SELECT VERTICAL REVISION at the FROM waypoint.  
WRITE a new speed limit/altitude and ENTER.

*The crew can insert one climb speed limit and one descent speed limit into the vertical flight plan, or modify or clear the limits that are already in it.*  
*The speed limit is defined by a speed and an altitude (for example, 230/9 000), which means that the managed speed target will be limited by the speed limit when the aircraft flies below the specified altitude.*  
*In both climb and descent, 250 kt at 10 000 ft is the default speed limit in the vertical flight plan.*  
*The vertical revision page presents the climb speed (CLB SPD) limit if the revised waypoint is between departure and top of descent.*

The vertical revision page shows the descent speed (DES SPD) limit, if the revised waypoint is between top of descent and destination.

It can be deleted by a clear action, the field reverts to brackets. It can also be cleared directly on the F-PLN A page by clearing the SPD LIM pseudo-waypoint.

**ENTERING A SPEED CONSTRAINT**



**F-PLN A PAGE**

1L	2L	3L	4L	5L	6L	1R	2R	3R	4R	5R	6R
FROM	TIME	SPD/ALT	AI101→								
LFBO15L	----	---/	490								
H146°	BRG143°	6MN									
TOU/08←	----	---/	+900								
(SPD)	TRK306°										
(LIM)	----	---/----									
C300°											
TOU	----	---/----									
LMG2D											
AGN	----	---/----									
DEST	TIME	DIST	EFOB								
EGLL27R	----	541	----								

**F-PLN A PAGE WITHOUT PREDICTIONS**

VERT REV AT AGN

1L	2L	3L	4L	5L	6L	1R	2R	3R	4R	5R	6R
EFOB =	---	EXTRA =	---								
CLB SPD LIM		RTA>									
250/10000											
SPD CSTR		ALT CSTR									
*[ ]		[ ]*									
MACH/START WPT											
*[ ]/AGN											
<WIND		STEP	ALTS>								
*CLB		DES*									
190											

**F-PLN A PAGE**

1L	2L	3L	4L	5L	6L	1R	2R	3R	4R	5R	6R
FROM	TIME	SPD/ALT	AI101→								
LFBO15L	----	---/	490								
H146°	BRG143°	6MN									
TOU/08←	----	---/	+900								
(SPD)	TRK306°										
(LIM)	----	---/----									
C300°											
TOU	----	---/----									
LMG2D											
AGN	----	190/----									
DEST	TIME	DIST	EFOB								
EGLL27R	----	541	----								

Procedure

PRESS the F-PLN key on the MCDU.

SELECT the VERT REV page at the revised waypoint.

WRITE the speed constraint value into the scratchpad and ENTER it in 3L.

INSERT the constraint using the appropriate \*CLB or DES \* prompt when displayed. If CLB and DES are not displayed, insertion occurs when the value is entered in 3L.

*The system displays the climb (CLB ) or the descent (DES) prompt at [6L] or [6R] when the predictions are not yet available or when the waypoint is part of the cruise phase as originally defined.*

*When predictions are not yet available, the constraints are displayed on the F-PLN A page in magenta.*

*When predictions are available, the speed constraint is highlighted by a star (\*).*

*\* If the predicted speed matches the constraint, the star is magenta.*

*\* If the prediction is that the aircraft will miss the speed constraint, the star is amber.*

*If a speed constraint cannot be met (by more than 10 kt), the FMGS generates the message "SPD ERROR AT WPT XX".*

*A speed constraint may be assigned to any waypoint in the climb or the descent phase except the FROM, origin, or destination waypoints, and any pseudo waypoint.*


*When a speed constraint is assigned to a waypoint, the constraint will limit the managed speed target as follows:*

- In takeoff or climb phase until you pass the constrained waypoint.
- In descent an approach phase, after passing the constrained waypoint.

*Speed constraints are observed by the FMGS when NAV mode and speed managed are active.*


### ENTERING A SPEED CONSTRAINT THROUGH F-PLN A PAGE

You may also enter a speed constraint through the F-PLN A page.



*Note:* You may delete the constraint using the clear key on the relevant right hand key.  
 However if there is an altitude constraint assigned at that point, the clear action deletes it too.

**ENTERING AN ALTITUDE CONSTRAINT**



Procedure

PRESS the F-PLN key on the MCDU.

SELECT the “VERT REV” page at the revised waypoint.

WRITE an altitude constraint in the scratchpad and ENTER it in 3R.

INSERT the constraint using \*CLB or DES\* prompt when it is displayed. Otherwise the value is inserted when it is entered in 3R field.

*The system displays the \*CLB or DES\* prompt, when the predictions are not yet available, or when the waypoint is part of the cruise phase as originally defined.*

Note: *In case of QFE operations, the altitude constraints must be converted and entered as an altitude in feet.*

You or the database may assign an altitude constraint to any waypoint in the climb or descent phases except the FROM, origin, or destination waypoints, or any pseudo waypoint.

An altitude constraint may be defined as an “at”, an “at or above”, or an “at or below” constraint. In certain procedures, the database may define an altitude constraint as a window in which the aircraft should fly.

Enter “AT” constraints with no sign.

Enter “AT or ABOVE” constraints preceded by a + sign (+FL 130, for example).

Enter “AT or BELOW” constraints preceded by a – sign (-15 000, for example).

enter four or five-digit number when entering altitude. Include the lead zero (0 500 ft , for example).

*For flight level, enter a two- or three-digit number, with or without the letters “FL”. The lead zero is optional. (Examples : +FL 120 or +120 ; -FL 090 or -90 or -090)*

Enter the altitude value as either altitude or flight level ; the MCDU displays the selected value as an “ALT ” or “FL,” as appropriate for the transition altitude.

*The constraint must be higher than the thrust reduction altitude and lower than the cruise flight level.*

*Once inserted in the flight plan, the altitude constraint (ALT CSTR) is displayed in magenta as long as predictions are not available.*

*When predictions are available, the altitude constraints are replaced by the predicted altitude at relevant waypoints highlighted by a star.*

*\* If the predicted altitude matches the constraint the star is magenta. If the predicted altitude is missed (by more than 250 ft), the star is amber.*

**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

MAGENTA

	FROM	TIME	SPD / ALT	A 110	→
1L	LFBO15L	----	---/	490	
	H146°	BRG143°	5NM		
2L	TOU/08←	----	---/	+900	
	(SPD)	TRK306°			
3L	(LIM)	----	---/----		
	C300°				
4L	TOU	----	---/----		
	LMG2D				
5L	AGN	----	---/	FL120	
	DEST	TIME	DIST	EFOB	
6L	EGLL27R	----	541	----	↑↓

F-PLN A PAGE WITHOUT PREDICTIONS

	FROM	TIME	SPD / ALT	A 110	→
1L	LFBO15R	0000	---/	490	
	H146°	BRG143°	5NM		
2L	TOU/08←	02	250/★3360		
	(SPD)	TRK300°	9		
3L	(LIM)	04	250/FL100		
	C300°		7		
4L	TOU	05	298/FL120		
	LMG2D		22		
5L	AGN	09	*/★FL120		
	DEST	TIME	DIST	EFOB	
6L	EGLL27R	0124	542	6.4	↑↓

F-PLN A PAGE WITH PREDICTIONS AND STARS

The vertical revision page displays “ALT ERROR”, along with the difference between the constraint and the predicted altitude at the revised waypoint.


VERT REV AT LACOU	
EFOB=14.5	EXTRA=0.8
1L	CLB SPD LIM
	210 / 7000
2L	SPD CSTR
	★[ ]
3L	ALT CSTR
	5000
4L	ALT ERROR
	-500
5L	<WIND
	STEP ALTS>
6L	<RETURN

ND Display

An altitude-constrained waypoint is marked by a circle (⊙) on the navigation display.

This circle is white when the guidance does not take the altitude constraint into account. It is magenta if the guidance system takes the altitude constraint into account and predicts that it will be matched.


It is amber if the guidance system takes the altitude constraint into account and predicts that it will not be matched.



The aircraft should be at or below FL 120 at AGN and above FL 180 at LACOU.

Entering an Altitude Constraint Through F-PLN A Page

The pilot may also enter an altitude constraint directly through the F-PLN A page. When entering the value into the scratchpad do not forget the slash e.g. /-120 or /-FL 120. If the slash is omitted the value will be considered as a speed constraint if it is within the range value.



Use CLR to delete them directly from the flight plan page, as well. However, if there is also a speed constraint assigned at that waypoint, the clear action deletes it too.

### ENTERING AN ESTIMATED TIME OF TAKEOFF (ETT)

In Preflight Phase:

SELECT the SEC F-PLN key on the MCDU.

SELECT a VERT REV at any waypoint.

SELECT the Required Time of Arrival (RTA) prompt (2R).


*The MCDU displays the RTA page.*

ENTER the Estimated Takeoff Time in the [ 6R ] field.

*The format is HHMMSS (entry of seconds is not mandatory).*

ENTER it in the 6R field





If the aircraft has not taken off by the time entered as estimated takeoff time, the MCDU displays the “CLK IS TAKE OFF TIME” message, meaning that the system will replace your estimated takeoff time with the actual time.

When beginning the takeoff roll, the system automatically adopts that clock time as the takeoff time.

If the origin airport is changed, or the clock time is invalid, the system automatically deletes the estimated takeoff time.

Ident.: PRO-NOR-SRP-01-10-A-00003965.0001001 / 15 FEB 11

### **FLIGHT PLAN CHECK**

CHECK the EOSID on the ND plan mode (yellow line).

*Note:* If the details of the EOSID require review, select the EOSID as a TMPY F-PLN and review it as TMPY. Then ERASE it.

Ident.: PRO-NOR-SRP-01-10-A-00003966.0001001 / 09 DEC 09

### **SECONDARY F-PLN**

For details : Refer to DSC-22\_20-60-50 Secondary Flight Plan.

Ident.: PRO-NOR-SRP-01-10-A-00003967.0001001 / 15 FEB 11

**RADIO NAV**

Whenever a NAVAID IDENT is correctly decoded, in agreement with that published, no audio check is necessary.

Morse decoding is displayed on the ND for VOR/DME, VOR/TAC, DME , ADF , and on the PFD for ILS.

Preferably use the identifier for NAVAID entry.

If the ADF IDENT is not in the database, be sure to include a decimal point when tuning the frequency (e.g 315. or 325.7).



*Note: Whenever, the runway ILS is intended to be retained for guidance after the takeoff phase, it is recommended to manually tune the ILS by its identifier.*


**FMGS DATA INSERTION**

Applicable to: ALL

Ident.: PRO-NOR-SRP-01-10-B-00003968.0024001 / 05 OCT 16

**WEIGHT/CG INSERTION AND FUEL PLANNING**

The flight crew must enter the Zero Fuel Weight (ZFW ) and Zero Fuel Weight Center of Gravity (ZFWCG ) values on the INIT B page, to allow the FMS to perform the fuel planning computations.



**PROCEDURE**

PRESS the INIT key, and the Next (“→”) key to access the INIT B page.

ENTER the ZFW and ZFWCG value in the [ 1R ] field.

The “FUEL PLANNING →” prompt appears in the [ 3R ] field.

*Note:* As long as the final Load and Trim Sheet is not available, the crew should insert the estimated ZFW /ZFWCG in order to get fuel estimates. The ZFW and ZFWCG values must be updated with the final Load and Trim Sheet values.

CHECK/MODIFY the TAXI [ 1L ], RTE RSV [ 3L ] and FINAL TIME [ 5L ] values.

The TAXI, RTE RSV and FINAL TIME fields display the default values specified in the AMI file (for example, “0.4” for TAXI, “5.0 %” for RTE RSV and “0045” for FINAL TIME). The flight crew may modify these values.

Note: At takeoff, the RTE RSV field will automatically be reset to 0. The RTE RSV fuel is then added to the EXTRA fuel, which ensures that the EXTRA fuel and MIN DEST FOB values are consistent in flight.

ENTER an ALTN fuel value in the [4L] field, as necessary.

The flight crew may enter the ALTN fuel value planned on the Computerized Flight Plan (CFP), as necessary.

ENTER a MIN DEST FOB value in the [6L] field, as necessary.

Note: MIN DEST FOB (equal to ALTN + FINAL) can be increased at flight crew discretion (e.g. when HOLD is expected at destination).

ENTER the TRIP WIND value in the [ 5R ] field, as necessary.

In no wind profile has been entered in the F-PLN, the crew may enter an average TRIP WIND in this field, to obtain more realistic fuel/time predictions before departure.

Note:

1. The flight crew should only enter a TRIP WIND to obtain realistic fuel/time predictions, on ground. Then, the flight crew should enter a wind profile using the WIND pages, for fuel/time predictions in flight. As soon as flight crew has entered a wind profile on the WIND pages, the TRIP WIND will be erased.
2. If the crew has already defined a wind profile, even partially (such as climb wind), it is not possible to enter a TRIP WIND.

ENTER the planned BLOCK fuel, as indicated in the computerized flight plan (CFP)

If the planned BLOCK fuel is not available, the crew may obtain a prediction of the minimum BLOCK fuel required for the flight by pressing the FUEL PLANNING prompt [3R].

Pressing this prompt makes the FMS compute the minimum required BLOCK fuel, which is the BLOCK fuel required to have EXTRA fuel = 0, based on the parameters entered on the INIT and F-PLN pages.

The computed BLOCK fuel value is displayed in the [2R] field, and a BLOCK CONFIRM prompt appears in the [3R] field.

Note: In order to obtain a realistic fuel computation, the flight crew should ensure that the F-PLN initialization has been completed (including insertion of the ALTN F-PLN and/or ALTN fuel and/or MIN DEST FOB if necessary), and that flight parameters, such as CRZ FL, steps climbs (if any), and winds, have been inserted.

- When the final Load and Trim Sheet (LTS) data are available:

**INIT FUEL PLANNING** ↔

[1L]	TAXI	ZFW / ZFWCG	[1R]
	0.4	51.2 / 24.7	
[2L]	TRIP / TIME	BLOCK	[2R]
	10.4 / 0415	14.4	
[3L]	RTE RSV / %	CONFIRM*	[3R]
	1.2 / 5.0		
[4L]	ALTN / TIME	TOW / LW	[4R]
	0.6 / 0017	65.2 / 54.8	
[5L]	FINAL / TIME	TRIP WIND	[5R]
	1.8 / 0045	HD000	
[6L]	MIN DEST FOB	EXTRA / TIME	[6R]
	2.4	0.0 / 0000	
	1.6		

1 WRITE →

2 ENTER ←

**INIT FUEL PREDICTION** ↔

[1L]	TAXI	ZFW / ZFWCG	[1R]
	0.4	51.2 / 24.7	
[2L]	TRIP / TIME	BLOCK	[2R]
	10.4 / 0415	16.0	
[3L]	RTE RSV / %		[3R]
	1.2 / 5.0		
[4L]	ALTN / TIME	TOW / LW	[4R]
	0.6 / 0017	66.8 / 56.4	
[5L]	FINAL / TIME	TRIP WIND	[5R]
	1.8 / 0045	HD000	
[6L]	MIN DEST FOB	EXTRA / TIME	[6R]
	2.4	1.6 / 0020	

ENTER the final ZFW/ZFWCG [1R], and the required BLOCK fuel [2R].

*The FMS computes the predictions, based on the entered BLOCK fuel, and estimates the EXTRA fuel value.*

CHECK the resulting computed data, against the data planned on the CFP: TRIP fuel, RTE RSV fuel, ALTN fuel, FINAL and EXTRA fuel values.

*If necessary, the flight crew may modify the ALTN or FINAL fuel values.*

PRINT the PREFLIGHT REPORT, if necessary.

*When the final Load and Trim Sheet values (ZFW /ZFWCG /BLOCK) have been entered, the crew may print the pre-flight report, which provides a copy of the F-PLN with the associated FMS predictions.*

Ident.: PRO-NOR-SRP-01-10-B-00003969.0010001 / 15 FEB 11

### **TAKEOFF WITH NO WEIGHT/CG DATA**

If the crew does not enter ZFW /ZFWCG data prior takeoff, or if the FMGC loses these values due to a power interruption, the following will occur:

- At takeoff, the Speed Reference System (SRS ) mode is available (provided a V2 has been inserted)
- When the aircraft leaves the SRS mode, the target speed becomes the current speed and reverts to selected.

*Note: If the AP /FD has reverted to ALT or V/S (FPA ) mode, the associated A/THR mode is SPEED. In this case, the system will probably reduce thrust, because the speed will be equal to, or greater than, the target speed.*

● **When appropriate, to regain FMS predictions and associated managed modes:**

INSERT the ZFW/ZFWCG values on the FUEL PRED page.

Ident.: PRO-NOR-SRP-01-10-B-00003970.0007001 / 15 FEB 11

### **INSERTING WEIGHT/CG DATA AFTER ENGINE START**

The flight crew must enter the ZFW /ZFWCG values on INIT B page prior to engine start. If these data have not been entered at engine start, the MCDU displays the "INITIALIZE WEIGHTS" amber message in the scratchpad. After engine start, the crew should enter the ZFW /ZFWCG values on the FUEL PRED page.

PRESS to the FUEL PRED key.

INSERT the ZFW /ZFWCG values in the [4R] field.

*This allows predictions and performance computation.*

CHECK the resulting computed data, against the data planned on the CFP: TRIP fuel, RTE RSV fuel, ALTN fuel, FINAL and EXTRA fuel values.


*If necessary, the flight crew may modify the ALTN or FINAL fuel values.*

PRINT the PREFLIGHT REPORT, if necessary.


*When the final load sheet values (ZFW /ZFWCG /BLOCK) have been entered, the crew may print the pre-flight report, which provides a copy of the F-PLN with the associated FMS predictions.*

Ident.: PRO-NOR-SRP-01-10-B-00003971.0001001 / 22 MAR 16

**TAKEOFF DATA INSERTION**



**PROCEDURE**


- PRESS the PERF key on the MCDU.
- WRITE successively and ENTER : V1 , VR , V2.
- WRITE and ENTER FLX TEMP or DRT TO .
- CHECK/MODIFY the THR RED ALT (Thrust reduction altitude) See \*.
- CHECK/MODIFY the ACC ALT (acceleration altitude) See \*.
- CHECK/MODIFY the ENG OUT ACC (engine out acceleration altitude) See \*.
- CHECK/MODIFY the TRANS ALT (transition altitude) See \*.
- WRITE and ENTER T.O. SHIFT.

CHECK V1 , V2 on PFD See \*\*

- \* *Altitudes less than 400 ft above airfield elevation cannot be selected.*
- \*\* *If the PFD does not display V2 at the top of its speed scale, check that at least one FD is ON.*

**ENTERING A FLEX TEMPERATURE**

WRITE the desired flex temperature in the scratchpad and ENTER using the [4R] key.



Ident.: PRO-NOR-SRP-01-10-B-00003972.0003001 / 22 MAY 12


**CLIMB SPEED PRESELECTION**

If the managed speeds for the initial climb are not suitable, the pilot can preselect an appropriate climb speed on the “PERF CLB” page, as long as the climb phase is not active.

The CLB SPD preselection applies, when the:

- ATC specifies an initial climb speed.
- Initial climb speed must be lower than normal because:
  - There are to be turns greater than 120 ° in the initial climb out.
  - Obstacle clearance, or some other situation, requires a high climb angle.
  - The airfield has a risk area to be quickly cleared (birds reported, for example).





## PROCEDURE

PRESS the PERF key on the MCDU.

*The PERF TAKE OFF page is displayed.*

SELECT the “NEXT PHASE” [6R] key to display the CLB page.

WRITE a climb speed and ENTER it.

To revert to managed speed, select MANAGED by pressing [3L].

When the aircraft is transitioning into the climb phase, the preselected value becomes the target speed:


- The selected speed target is active.
- The primary flight display shows the target speed in blue.
- The FCU’s speed window displays the new speed or Mach number.

Ident.: PRO-NOR-SRP-01-10-B-00003973.0003001 / 09 OCT 12

## **CRUISE MACH (SPEED) PRESELECTION**

The pilot preselects a cruise Mach, when a Mach number other than the ECON cruise Mach number is required.

When the aircraft transitions to the cruise phase, the speed target symbol goes to the preselected value and “SELECTED” becomes the active speed mode (blue target on PFD , target MACH shown in the speed/Mach window of the FCU).



## PROCEDURE

PRESS the PERF key on the MCDU.

PRESS the “NEXT PHASE” [6R] key on the MCDU , until the CRZ page is accessed.

WRITE a cruise Mach (or speed) in the scratchpad and ENTER it in [4L].

To revert to managed speed, PRESS [3L].

*When the cruise phase is active, you cannot preselect a cruise Mach or speed.*

Ident.: PRO-NOR-SRP-01-10-B-00004095.0001001 / 09 OCT 12

## ENTERING A HEADING/TRACK PRESET FUNCTION

The heading/track preset allows the pilot to preset a takeoff or go-around heading or track before commanding the aircraft to take up that heading or track (manual activation).

The flight crew can enter a heading or a track preset while the aircraft is on the ground and until takeoff.

## PROCEDURE

- **Before takeoff:**


SET the appropriate HDG or TRK in the FCU window.

*This disarms the navigation mode and allows the runway mode to remain engaged after takeoff.*

● **After takeoff:**

PULL HDG/TRK knob.

*The heading or track mode engages on the preset value.*



The direction in which the pilot rotates the HDG/TRK selection knob usually determines the direction of the turn. A left rotation (decreasing heading) produces a left turn; a right rotation produces a right turn.

However, when a heading has been preset before takeoff or go-around, the direction of the turn will be such as to cause the shortest turn at the moment of engagement.

**CANCELLING THE HEADING/TRACK PRESET FUNCTION**

The pilot can cancel the heading preset by pushing the HDG/TRK knob back in again. This engages or arms the NAV mode.

**FMGS RE-INITIALIZATION AFTER A CANCELED FLIGHT**

Ident.: PRO-NOR-SRP-01-10-00013064.0001001 / 16 NOV 11

Applicable to: ALL

If the flight crew initially prepared a flight with all the data associated with this flight (takeoff speeds, winds, etc.), and if this flight is later canceled and replaced by another flight, the flight crew may use the following procedure to initialize the FMGS again:

PREPARE the new flight data in the secondary flight plan, using SEC INIT A, SEC INIT B, and SEC PERF pages

ACTIVATE the secondary flight plan.

Note: When the flight crew activates the secondary flight plan, the following data of the primary flight plan is lost if the secondary flight plan does not include any replacement data:


- Alternate data
- Winds and cruise TEMP at waypoints as inserted on CRZ WIND pages
- Departure and arrival selection (STAR , APP, RWY ) and approach parameters (QNH , TEMP , WIND, TRANS ALT , VAPP , MDA /MDH , DH , LDG CONF)
- Altitude, speed, and time constraints
- Steps
- CMS
- Offsets
- Flaps/THS
- Preselected cruise and descent speeds.

**Before Pushback or Start**

**CHANGE OF RUNWAY**


Ident.: PRO-NOR-SRP-01-15-00003975.0003001 / 22 MAY 12

Applicable to: ALL



**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS



The screenshot shows two pages from the FMS. The top page is the 'DEPARTURES FROM LFBO' page. It displays a table with columns for RWY, SID, and TRANS. The current selection is RWY 15R, SID LMG1A, and TRANS NONE. Below the table, there are options for ANET1S, ANET1W, LMG1A, LMG2N, and ERASE. A 'SELECT' prompt is visible on the left. Callout 1 points to the 'DEPARTURES' prompt, callout 2 to the 'SELECT' prompt, and callout 3 to the 'SELECT' prompt on the right.

1L	DEPARTURES FROM LFBO	1R
2L	RWY SID TRANS	2R
3L	15R LMG1A NONE	3R
4L	SIDS AVAILABLE TRANS	4R
5L	←ANET1S	5R
6L	←ANET1W	6R
	LMG1A	
	←LMG2N	
	EOSID	
	←ERASE EO15B INSERT*	

The bottom page is the 'FROM A1101' page. It displays a table with columns for FROM, TIME, SPD, and ALT. The current selection is LFBO15R, TIME 0000, SPD ---, and ALT 490. Below the table, there are options for M146, TOU/08, (SPD), (LIM), C300, TOU, LMG2N, AGN, DEST, TIME, DIST, EFOB, and CHECK TAKE OFF DATA. Callout 1 points to the 'FROM' prompt, callout 2 to the 'SELECT' prompt, and callout 3 to the 'SELECT' prompt on the right.

1L	FROM A1101	1R
2L	LFBO15R 0000 --- / 490	2R
3L	M146 * BRG143 * SNM	3R
4L	TOU/08 ← 02 250 / * 3360	4R
5L	(SPD) TRK300 * 9	5R
6L	(LIM) 04 250 / FL100	6R
	C300 * 7	
	TOU 05 298 / FL120	
	LMG2N 22	
	AGN 09 " / FL120	
	DEST TIME DIST EFOB	
	EGLL27R 0124 542 6.4	
	CHECK TAKE OFF DATA ↑↓	

PRESS the F-PLN key on the MCDU.  
 SELECT the LAT REV at origin.  
 SELECT the DEPARTURE prompt [1L].  
 SELECT the new RWY in use.  
 SELECT the appropriate SID and TRANS.  
 CHECK the resulting temporary F-PLN and INSERT it.

*CHECK TAKE OFF DATA comes up in the scratchpad if the PERF TO page had been filled in.*  
 ENTER the new V1 , VR , V2 , FLEX TEMP or CONF, as appropriate.

Note: *If the previously selected SID is compatible with the new runway, it automatically appears in the temporary flight plan. Any revision the pilot may have made to the previous SID will not be transferred.*  
*If the pilot still wants it, he has to reenter it.*

**TAKEOFF FROM INTERSECTION**

Ident.: PRO-NOR-SRP-01-15-00003976.0001001 / 09 DEC 09

**Applicable to: ALL**

Use RTOW or FCOM to revise takeoff parameters :  
PRESS the [PERF] key on MCDU  
ENTER the takeoff shift  
ENTER the new V1 , VR , V2 , FLX TEMP, or CONF, as appropriate

*Note: The insertion of the shift in takeoff position permits the system to make an accurate revision to its navigation data at takeoff.*

**PROCEDURES**

**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

Intentionally left blank



**Taxi**

**FCU SELECTION FOR TAKEOFF**

Ident.: PRO-NOR-SRP-01-20-00003978.0004001 / 09 OCT 12

Applicable to: ALL



**PROCEDURE**


- ENSURE that HDG – V/S modes are selected (change over pb).
- CONFIRM or SELECT the first cleared altitude
- CROSS CHECK on PFD the target altitude
- CONFIRM both FDs ON

**FMA MODE CHECK**

Ident.: PRO-NOR-SRP-01-20-00003979.0002001 / 22 MAY 12

Applicable to: ALL

- CHECK that the FMA CLB (or ALT) mode is armed



**Note:** ALT (in blue or magenta) may be displayed instead of CLB if the FCU altitude or a constraint is set at or below the acceleration altitude.

If a HDG /TRK was preset, NAV is disarmed.



**SELECTING A NAVIGATION DISPLAY**

Ident.: PRO-NOR-SRP-01-20-00003980.0001001 / 22 MAY 12

Applicable to: ALL

SET the minimum range to display the first waypoint after departure or as required for weather radar.

ARC mode  
 FOR DEPARTURE  
 IN GENERAL  
 DIRECTION  
 OF RUNWAY  
 HEADING



Rose NAV mode  
 FOR DEPARTURE  
 IN DIRECTION  
 OPPOSITE TO  
 THAT OF RUNWAY  
 HEADING



**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

**SELECTING TAKEOFF DISPLAYS FOR PILOT'S AND COPILOT'S MCDU**

Ident.: PRO-NOR-SRP-01-20-00003981.0001001 / 23 DEC 14

Applicable to: ALL

**TAKE OFF**

	V1	FLP RETR	RWY
1L	132	F=143	15R
2L	VR	SLT RETR	TO SHIFT
	134	S=185	[M][ ]*
3L	V2	CLEAN	FLAPS/THS
	145	O=200	2/UP1.0
4L	TRANS ALT FLEX TO TEMP		
	4000		45°
5L	THR RED/ACC	ENG OUT	ACC
	1990/1990		1990
6L		NEXT	
		PHASE>	

PF SELECTS PERF T.O. PAGE

FROM A1101→

	TIME	SPD/ALT	
1L	LFBO15R	0000	132 / 490
2L	H146°	BRG143°	5NM
	TOU/08←	02	250 / * 3360
3L	(SPD)	TRK300°	9
	(LIM)	04	250 / FL100
4L	C300°		7
	TOU	05	298 / FL120
5L	LMG2D		22
	AGN	09	" / * FL120
6L	DEST	TIME	DIST EFOB
	EGLL27R	0124	542 6.4

↑↓

PM SELECTS F-PLN A PAGE

**Takeoff**

**MONITORING THE TAKEOFF**

Ident.: PRO-NOR-SRP-01-30-00003983.0007001 / 09 OCT 12


Applicable to: ALL

● **At power set (thrust levers in FLX or TOGA position)**

CHECK that the navigation is updated to the runway threshold by verifying that the aircraft symbol is centered on the runway threshold of the navigation display.


CHECK the FMA for appropriate mode selection

*Note:* - RWY mode appears if an ILS is tuned to a station corresponding to the departure runway. Otherwise no lateral mode comes up until the aircraft has lifted off.



● **At 30 ft**

- **If NAV is armed**, it engages automatically.
- **If NAV is not armed**, RWY TRK mode engages and remains displayed until the crew selects another lateral mode.




● **At 100 ft**

Engage AP1 or AP2.

*The FMGS has an internal delay that prevents the AP from engaging 5 s after liftoff and if the aircraft is below 100 ft.*

● **At thrust reduction altitude**

“LVR CLB” flashes in the first column of the FMA




**Procedure**

SET the thrust levers to the CL detent

*A/THR activates automatically*

CHECK that A/THR turns to white in the 5th FMA column.

CHECK that THR CLB appears in green in the first column.



Depending on the next level off altitude, CLB or ALT is armed and displayed in the second column.

ALT is armed:


- in blue if the next predicted level-off is the FCU -selected altitude (target altitude blue at the top of the ALT scale)
- in magenta if the next predicted level-off is an ALT CSTR (target altitude magenta at the top of the ALT scale)

● **At acceleration altitude**

The vertical phase automatically switches to climb.

CLB mode engages. The target speed jumps to initial climb speed on the PFD.





**Procedure**

CHECK that “CLB” appears in green in the second FMA column.

- The speed reference system (SRS ) mode remains engaged until CLB phase is engaged, which occurs at ACCEL ALT or at any other vertical mode engagement, whichever comes first.
- If during takeoff the FCU altitude is set below the current aircraft altitude, the system ignores the FCU altitude and the aircraft remains in SRS mode until the pilot selects an altitude above the aircraft altitude or engages any other mode.

**PRESELECTING A HDG OR A TRK**

Ident.: PRO-NOR-SRP-01-30-00003984.0001001 / 16 NOV 11

Applicable to: ALL


**PROCEDURE**

- **If a HDG or a TRK was preselected on the ground :**  
PULL OUT the HDG/TRK selector knob when required  
CHECK that the HDG/TRK mode is active and displayed on the FMA  
*When a HDG or TRK is preset, OP CLB mode will engage at the acceleration altitude. (CLB mode is not available in HDG/TRK mode).*

**NORMAL TAKEOFF PROFILE**

Ident.: PRO-NOR-SRP-01-30-00003985.0002001 / 22 MAY 12

Applicable to: ALL



**NO FLIGHT DIRECTOR TAKEOFF**


Ident.: PRO-NOR-SRP-01-30-00003986.0004001 / 09 OCT 12

Applicable to: ALL

If a takeoff is initiated without FDs, the system responds as follow:

- There are no FD bars.
- There is no A/THR arming.
- There is no guidance available.
- The target speed on the PFD is that selected on the FCU or is defaulted to 100 kt.
- Setting the thrust levers to the CL detent does not activate A/THR.

Note: Do not engage the autothrust prior to selecting a target speed on the FCU.



**PROCEDURE**

Establish initial climb of 15 °

● **When reaching the thrust reduction altitude (THR RED ALT):**

- SELECT a climb speed.
- SET the thrust levers to CL detent.
- ACTIVATE the autothrust.
- TURN ON the FDs (basic modes engage).
- SELECT appropriate mode.
- Failure of both FDs after the start of takeoff:

- The FD bars disappear.
- The FCU window displays the target speed, which synchronizes on V2, or the current speed (if it is higher).
- The autothrust remains armed.
- At thrust reduction altitude, LVR CLB flashes. If the pilot set the thrust levers to the CLB detent, the autothrust becomes active in selected SPD mode (no FDs selected). If the current speed is greater than the target speed, the thrust decreases.
- At acceleration altitude the target speed does not change, since it is selected.

**TAKEOFF WITH NO V2 ENTRY**

Ident.: PRO-NOR-SRP-01-30-00003987.0001001 / 16 NOV 11

Applicable to: ALL

If V2 is not inserted, the speed reference system (SRS) will not engage for takeoff. 5 s after lift off, V/S mode will engage. When V/S engages the current airspeed becomes the FCU target speed.

To regain a normal speed target, the pilot must :

SELECT the appropriate climb speed on the FCU and PULL out the knob.

● **At ACC ALT :**

PUSH the A/THR pb on the FCU.

SET the thrust levers to CL detent.

PUSH in the SPD selector knob to get a managed speed target.

**TAKEOFF USING THE LOCALIZER OF THE OPPOSITE RUNWAY**

Ident.: PRO-NOR-SRP-01-30-00003988.0005001 / 09 OCT 12

Applicable to: ALL

● **If the localizer, of the ILS associated with the opposite runway, must be used for takeoff:**

SELECT the RAD NAV PAGE.

ENTER the ILS IDENT.


*If the ILS is in the database, the system tunes the proper frequency.*

*Check that the ILS front course is displayed in the CRS field.*

Note: *This may trigger the "RWY /ILS MISMATCH" message. Disregard it.*

● **If the ILS is not in the database:**

SET the appropriate frequency, and SET the ILS front course in the CRS field.



DESELECT the LS pb on the FCU.

*Since the PFD displays reverse deviation.*

DESELECT the LS pb on ISIS.

*Since ISIS displays LOC reverse deviation.*

SELECT ROSE-ILS on one ND.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SYSTEMS RELATED PROCEDURES - FMS

Intentionally left blank


**Climb**

**MONITORING THE CLIMB PHASE**

Ident.: PRO-NOR-SRP-01-40-00003989.0031001 / 23 DEC 14

Applicable to: ALL

The PF MCDU should display the PERF CLB page allowing him to monitor the climb.  
 The PM MCDU should display the F-PLN page to allow the pilot to monitor time, speed and altitude predictions. This page also displays matched or missed information for constraints.



CHECK vertical mode CLB if NAV is engaged.  
 CHECK vertical mode OP CLB if HDG /TRK is engaged.

**MONITORING THE ND (ROSE NAV OR ARC)**

Displays the lateral and vertical paths, in the current AP /FD active modes.



THE ↗ BLUE SYMBOL INDICATES WHERE THE FCU ALTITUDE WILL BE REACHED.

THE ↗ MAGENTA SYMBOL INDICATES WHERE THE NEXT F-PLN ALT CSTR WILL BE REACHED.

IF THE FCU ALTITUDE IS SET AT NEXT ALT CSTR, THE ↗ SYMBOL IS BLUE.

○ SYMBOL AROUND WAYPOINT INDICATES AN ALTITUDE CONSTRAINT :

- WHITE : DISREGARDED IN THE CURRENT AP/FD MODES.
- MAGENTA : PREDICTED AS MATCHED IN THE CURRENT MODES.
- AMBER : PREDICTED AS MISSED IN THE CURRENT MODES.


**MONITORING THE AP /FD MODES AND FMA**

If CLB mode is engaged, the flight mode annunciator (FMA ) and the navigation display (ND) show the tactical situation as follows:

**CASE 1**


The FCU selected altitude is set above the next altitude constraint






**CASE 2**

The FCU selected altitude is set at the next altitude constraint  
 The aircraft will automatically levels off at this altitude.



To resume the climb automatically when the waypoint AAA is reached, apply the following procedure during the level off (Position 4):

SELECT the FCU altitude to the next constraint (if any) or the cruise FL.  
PUSH the FCU ALT selector knob to arm CLB mode.



**RECOMMENDATION:**

To ensure that you will not miss the next constraint, it is recommended to select the FCU altitude to the next constraint as described above.

**MONITORING THE CONSTRAINTS**

SPEED, ALTITUDE and TIME constraint can be checked using MCDUs. Each constraint is preceded by a star that indicates if the constraint is matched (magenta star) or missed (amber star).

**ALTITUDE CONSTRAINT**

- If an altitude constraint is predicted as missed, use the following procedure:

SET the FCU ALT to the next ALT CSTR  
 CHECK the position of the level off symbol on the ND (blue arrow) with respect to the waypoint with the constraint.  
 DECREASE the target speed until the constraint is met.



**SPEED CONSTRAINT**


CHECK the SPD CSTR predictions on the MCDU.  
*A magenta or amber star (\*) indicates that the aircraft will match or miss the constraint.*  
*If the aircraft is to miss the constraint by more than 10 kt, the MCDU scratchpad displays "SPD ERROR AT WPT ----".*

**"CHECK WEIGHT" MESSAGE.**

*Refer to DSC-22\_20-90-20 "CHECK WEIGHT" Message*

**HDG /TRK MODE ENGAGEMENT**

- If HDG/TRK is engaged, the guidance does not consider any F-PLN constraint. Therefore if the flight crew disengages NAV, CLB mode reverts to OP CLB.



**SPEED SELECTION**

● **If a specific speed is required:**

TURN and PULL the SPD selector knob. (This changes the target speed to blue on the PFD speed scale).

Predictions on the F-PLN page assume that the speed remains selected until the next SPD LIM or SPD CSTR, or the next phase, whichever comes first.

**EXPEDITE CLIMB**


Ident.: PRO-NOR-SRP-01-40-00003990.0002001 / 11 FEB 11

Applicable to: ALL


The flight may use the expedite mode temporarily to clear a specified altitude or to match a constraint.

PRESS EXPED pb on the FCU.

The AP acquires and maintains Green Dot speed. There is no benefit to use expedite mode above FL 250. The mach corresponding to green dot is too low to maintain an increased vertical speed.



DEPRESS



FMA in EXPEDITE CLB

To revert to normal climb:  
 PUSH ALT knob CLB mode will engage.


*Note: Pulling ALT knob or V/S knob or SPD/MACH knob also disengages EXPEDITE.  
 PRESSING EXPED pb never disengages the mode.*

**IMMEDIATE RETURN TO ORIGIN AIRPORT**

Ident.: PRO-NOR-SRP-01-40-00003991.0003001 / 23 JUN 15

Applicable to: ALL

- If the SEC F-PLN has been prepared for an immediate return to the airport of origin:  
 ACTIVATE the SEC F-PLN.  
 PERFORM a DIR TO the appropriate waypoint.
- If the SEC F-PLN has not been prepared for an immediate return to the airport of origin:



**FROM**

	FROM	UTC	SPD / ALT	
1L	AGN	10 13	FL220	1R
2L	LMG1	BRG004	93NM	2R
3L	LMG	10 25	.78 / FL290	3R
4L	UR10	TRK006	97	4R
5L	AMB	10 38	. / .	5R
6L	UR10		16	6R

**LAT REV FROM LMG**

45° 49.0N / 001° 01.6E

LL XING / INCR / NO  
 [ ] ° / [ ] ° / [ ]

NEXT WPT [ ]

NEW DEST [ ]

AIRWAYS>

<RETURN LFBO

PERFORM a lateral revision at TO waypoint  
 ENTER the departure airport ident in the NEW DEST field and INSERT the temporary flight plan.  
 PERFORM a lateral revision at the new destination  
 SELECT: APPR – STAR – VIA – TRANS and INSERT

- **When cleared to divert:**
  - PERFORM a DIR TO the suitable waypoint.
  - ENTER QNH, WIND, MDA/MDH, LDG CONF.
  - CHECK RAD NAV page.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SYSTEMS RELATED PROCEDURES - FMS

Intentionally left blank




**Cruise**

**REACHING CRUISE FLIGHT LEVEL**

Ident.: PRO-NOR-SRP-01-50-00003992.0002001 / 03 NOV 14

Applicable to: ALL

On reaching the cruise flight level, the flight crew should be sure that the FMA displays “ALT CRZ ” in its second column, which ensures that the aircraft is at cruise flight level and at Economy Cruise Mach (ECON CRZ MACH).



The FMGS engages the “soft altitude” (SOFT ALT ) mode 2 min after the cruise flight level is captured and Mach stabilized. (SOFT ALT) mode allows the aircraft to deviate  $\pm 50$  ft from the target altitude to minimize the thrust variation and reduce the fuel consumption.

- **If the FMA does not display ALT CRZ at the assigned flight level**, soft altitude mode will not engage and the predictions will be computed at the preplanned flight level. This will occur when the ATC assigned flight level is lower than the preplanned flight level entered on the PROG page.
- **If the FMA does not display ALT CRZ at the assigned FL (as may occur when the ATC-assigned FL is lower than the preplanned FL selected initially):**

PRESS the [PROG].

ENTER the current cruise flight level.

*Note:* If the current cruise flight level is above the preplanned FL , selecting the FCU updates it automatically.

**“SET SPD AUTO” OR “SET MANAGED SPD” OR “CHECK SPEED MODE”**

- **If the climb phase was flown in selected speed and if the cruise phase is planned to be flown in managed speed (ECON MACH/SPEED) , “SET SPD AUTO” or “SET MANAGED SPEED” or “CHECK SPEED MODE” appears on the PFD and MCDU as a reminder.**


PRESS the FCU speed selector knob to activate the managed Mach.

## MONITORING THE NAVIGATION ACCURACY

Applicable to: ALL

Ident.: PRO-NOR-SRP-01-50-A-00003993.0001001 / 22 MAY 12

### GENERAL

On aircraft equipped with GPS PRIMARY, the navigation accuracy check is not required as long as GPS PRIMARY  is available.

Otherwise, navigation accuracy shall be checked periodically in cruise.


The PROG page displays an estimated accuracy as being high or low (center of sixth line):

- “HIGH” means that the FMGS estimates the FM position accurate enough to meet the EN ROUTE criteria,
- “LOW” means that the pilot must compare raw data from tuned nav aids with corresponding data computed by FM and shown on the ND or MCDU PROG page. The appearance of the message “NAV ACCUR DOWNGRAD” on the MCDU calls for a similar crosscheck.

*Note: The pilot should make such a comparison periodically, even if the PROG page is displaying “HIGH” and nav aids are available: this allows him to quantify the FM position error.*

The method for checking the accuracy is explained in the SOP and in Evaluation of position accuracy chapter (*Refer to DSC-22\_20-20-20 General*).

A quick check is explained here below when the TO waypoint is a DME type. (VOR /DME or VOR /TAC or DME or TAC)



Ident.: PRO-NOR-SRP-01-50-A-00003994.0013001 / 22 NOV 11

**POSITION DISCREPANCY**

- If there is a discrepancy between the raw data position and the FM position:

PRESS the DATA key on the MCDU.

SELECT the POSITION MONITOR page.

SELECT "FREEZE".

*On the other MCDU : Select the GPS MONITOR page.*

POSITION FROZEN AT 1035						GPS MONITOR												
1L	FMS 1	4610.2N/00618.3E	1R	1L	GPS1 POSITION	46°10.2N/006°13.3E	1R	2L	FMS 2	4610.2N/00618.8E	2R	2L	TTRK	UTC	GS	450	2R	
2L			2R	2L	MERIT	GPS	ALT	MODE/SAT	3L	GPS	4610.1N/00618.2E	3R	3L	100M	32000	NAV/6	3R	
3L			3R	3L	GPS2 POSITION	46°10.2N/006°13.3E	4R	4L	MIX IRS	4609.7N/00618.0E	4R	4L	TTRK	UTC	GS	450	4R	
4L			4R	4L	MERIT	GPS	ALT	MODE/SAT	5L	IRS1	IRS2	IRS3	5R	5L	100M	32000	NAV/6	5R
5L			5R	5L	TTRK	UTC	GS	450	6L	NAV 0.4	NAV 0.2	NAV 0.4	6R	6L	100M	32000	NAV/6	6R
6L			6R	6L	← UNFREEZE	NAVAIDS>												

**MONITORING THE FUEL PREDICTIONS**

Ident.: PRO-NOR-SRP-01-50-00003995.0013001 / 14 FEB 11

Applicable to: ALL

The F-PLN and FUEL PRED pages display fuel and time predictions throughout the flight. These predictions are meaningful if the lateral and vertical flight plan, and the entered winds are kept accurate enough as the flight progresses.

**PROCEDURE**

In addition to the Fuel Management procedure described in the SOPs (*Refer to PRO-NOR-SOP-15 Cruise - Flight Progress*), periodically apply the following actions:

**KEEP ACCURATE FMS PREDICTIONS**

*Periodically UPDATE the F-PLN elements (F-PLN waypoints, step altitudes, predicted winds).*

CHECK the MIN DEST FOB value on the FUEL PRED page

*The MIN DEST FOB value is computed by the FMS and by default it is equals to ALTN + FINAL. ALTN , FINAL and MIN DEST FOB can be modified by the flight crew.*

*At the beginning of the CRZ phase, and/or after any change of destination or alternate airport, check that the MIN DEST FOB value is meaningful. Otherwise, update the MIN DEST FOB value, as appropriate.*

CHECK the DEST EFOB value on the F-PLN or FUEL PRED page

*MONITOR the EFOB at destination on the F-PLN or FUEL PRED page. If necessary, ADAPT the flight strategy.*

**"DEST EFOB BELOW MIN" MESSAGE**

If the predicted EFOB at destination becomes less than the MIN DEST FOB value displayed on the FUEL PRED page:

- The destination EFOB turns to amber on the F-PLN , FUEL PRED and PERF (CLB , CRZ , DES) pages, and REPORT page.
- The "DEST EFOB BELOW MIN " amber message is displayed on the MCDU scratchpad, after 2 min (if the FMS is in CRZ or DES phase).

*Note: If the flight crew has cleared the "DEST EFOB BELOW MIN " message, and if the predicted EFOB at destination is still less than the MIN DEST FOB value, the "DEST EFOB BELOW MIN" message will appear again at the beginning of the descent phase.*

**PROCEDURE**

- **If the "DEST EFOB BELOW MIN" message is triggered on the MCDU:**

CHECK the DEST EFOB value on the F-PLN or FUEL PRED page,

CHECK the hypothesis used by the FMS to compute the fuel predictions,  
*Check that the F-PLN elements (F-PLN waypoints, step altitudes, predicted winds) are up-to-date, to ensure that the FMS predictions are accurate.*  
*Check that the MIN DEST FOB fuel value is meaningful and corresponds to the planned fuel strategy.*  
ADAPT the flight strategy as required.

### ENTERING A STEP CLIMB OR A STEP DESCENT

Ident.: PRO-NOR-SRP-01-50-00003996.0002001 / 22 MAY 12

Applicable to: ALL

The crew may use the STEP ALTS page to enter up to four geographic step points or one optimal step (computed by the FMGS) at any waypoint of the cruise.

#### **PROCEDURE**

PRESS the PERF key.

SELECT "STEP ALTS" prompt.

*The PERF PAGE displays this prompt in cruise phase. The crew may also call up the STEP ALTS page using a vertical revision at any cruise waypoint.*

#### **ENTERING AN OPTIMAL STEP (ONLY STEP CLIMB)**

WRITE a step altitude or FL into the scratchpad.

ENTER the step altitude or FL in the [1R] field.

CHECK the FUEL and TIME SAVINGS predictions on the 5L and 5R fields.

PUSH the INSERT prompt [6R] if adequate.

*After insertion, the optimum step climb is updated only when the flight crew presses the UPDATE prompt [6R].*


*The ND shows symbols for the start of climb (S/C) and the top of climb (T/C). The MCDU shows the associated pseudo-waypoints.*

*It is possible to convert an optimum step to a geographic step by overwriting the [1L] field (see geographic step).*

#### ● **When reaching the step climb pseudo-waypoint:**

REQUEST climb clearance.

ADJUST the FCU altitude to the STEP ALT, and PUSH.



### **ENTERING A GEOGRAPHIC STEP**

WRITE a step altitude into the scratchpad.

*The format is position/altitude (or FL). The position can be a waypoint or waypoint/distance to waypoint. The waypoint/distance is an along track offset waypoint.*

ENTER it in [1L] to [4L] field.


*The entry of the initial geographic step point requires both a valid waypoint and altitude entries. When a step has been entered, the flight crew may change the position and the altitude independently. The flight crew cannot modify the position and the altitude in a single entry: To modify both, they should modify the position first, and then the altitude.*

CHECK the predictions

- **When reaching the step climb or descent pseudo-waypoint (S/C or S/D):**

REQUEST climb or descent clearance.

ADJUST the FCU altitude to the STEP ALT, and PUSH.



The DIST/TIME field may display the following messages:

- ABOVE MAX if the step altitude exceeds the MAX ALT.
- IGNORED if the start step point is less than 50 NM from the top of descent.
- STEP NOW when the aircraft is within 20 NM of the step point.

If the aircraft overflies the step waypoint without commencing a climb or a descent, the system deletes the step from the vertical F-PLN automatically (a "STEP DELETED" message is displayed on the MCDU scratchpad), and recomputes the predictions.

A step is not deleted if the FCU altitude is moved only partially towards the step altitude.

The flight phase remains "cruise" whenever a step is initiated.

**Note:** For an altitude restriction defined at a waypoint less than 50 NM before the top of descent and lower than the CRZ FL, it is recommended to enter an altitude constraint rather than a step.

**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

**IMMEDIATE CHANGE OF LEVEL IN CRUISE**

Ident.: PRO-NOR-SRP-01-50-00003997.0001001 / 14 FEB 11

Applicable to: ALL

When the pilot changes his flight level without inserting a step:

- If the FCU -selected altitude is above the previous CRZ FL , the CRZ FL on the PROG page changes to the new flight level.
- If the FCU -selected altitude is lower than the previous CRZ FL and if the distance to DEST is more than 200 NM, the CRZ FL on the PROG page changes.

In that case Mach target is managed as follows:

- At the start of the descent, the Mach target is the managed Mach number at the initial cruise flight level.
- When the aircraft reaches the new flight level, the Mach target switches either to the Mach number for the lower CRZ FL , or to the speed for the lower CRZ FL if the aircraft reaches the crossover altitude. This logic prevents the aircraft from exceeding VMO during descent.
- If the FCU -selected altitude is lower than the previous CRZ FL and the aircraft is within 200 NM of its destination, the system activates the descent phase.

The pilot may reactivate the cruise phase by entering a new cruise flight level in the PROG page.

**PREPARATION FOR DESCENT AND APPROACH**

Applicable to: ALL

Ident.: PRO-NOR-SRP-01-50-B-00003998.0001001 / 09 DEC 09

**GENERAL**

The preparation for descent and approach consists of :

- Entering PERF and WIND data
- Defining the lateral and vertical F-PLN
- Checking the tuning (auto or manual) of the appropriate nav aids

After receiving the arrival information, the flight crew should use the following procedure.



Ident.: PRO-NOR-SRP-01-50-B-00003999.0001001 / 22 MAY 12

**REVISION OF LATERAL F-PLN**

**1** SELECTION

```

LAT REV FROM EGLL
51° 28.6N / 000° 25.9W
ARRIVAL>
NEXT WPT [ ]
  
```

**2** SELECTION


```

ARRIVAL TO EGLL →
APPR  VIA  STAR  TRANS
-----
APPR  AVAILABLE
← ILS27L 3658M
    275 ILL / 109 . 50
← ILS27R 3902M
    275 IRR / 110 . 30
← 05    2357M
    047
<RETURN
    ↑↓
  
```

**3** SELECTION

```

ARRIVAL TO EGLL
APPR  VIA  STAR  TRANS
ILS27R -----
APPR  TRANS
<VIAS -----
STARS  AVAILABLE TRANS
←BIG1A
←BIG1B
←BIG1C
←ERASE
    INSERT*
    ↑
  
```



PERFORM a lateral revision at destination

SELECT an ARRIVAL

SELECT an APPROACH, a STAR, a TRANSITION, a VIA.

*When the pilot selects successive items, the page are automatically sequenced. But pressing "NEXT PAGE" key brings up the APPR and STAR page successively.*

CHECK the temporary revision including the missed approach.

INSERT the temporary revision, [6R] key.

Ident.: PRO-NOR-SRP-01-50-B-00004000.0001001 / 22 MAY 12

### **REVISION OF VERTICAL FLIGHT PLAN**

CHECK that the speed and altitude constraints as displayed on the ND . (Use the CSTR pusbutton).


ENTER any additional speed or altitude constraints using the vertical revision page.

*In order not to be too fast when commencing the approach, you may insert a speed constraint at the FAF (Final Approach Fix).*

*When all computations are completed.*

REVIEW the flight plan, using the approach chart.

*When the destination runway changes and if the previously selected STAR is compatible with the new runway, the system selects it automatically in the temporary F-PLN . If the flight crew has entered any revision or constraint on this STAR, it will not be transferred. The pilot must reenter it in order to retain it for this approach.*



Ident.: PRO-NOR-SRP-01-50-B-00004001.0002001 / 14 FEB 11

**ENTERING THE WINDS FOR DESCENT**

*Refer to DSC-22\_20-30-20-25 Wind - Temperature - QNH - General.*


Ident.: PRO-NOR-SRP-01-50-B-00004002.0002001 / 22 MAY 12

**PRESELECTING A MANAGED SPEED/MACH**

As long as the descent phase is not active, the PERF DES page may either be used to select a speed, or a Mach number, or both, to replace the optimum descent speed.

The Flight Guidance Computer then uses the entered speed, instead of the optimum speed for computing the descent profile.

When the system switches to the descent phase, it sets the MANAGED target speed to the entered speed. From there, the speed may only be modified by using the FCU selector knob. Once in descent phase, the pilot cannot modify the MANAGED speed again.



**PROCEDURE**

PRESS the PERF on MCDU.


SELECT the “NEXT PHASE” prompt.

WRITE the descent speed into the scratchpad and ENTER it.

*The 3L field displays the imposed managed speed value.*

Ident.: PRO-NOR-SRP-01-50-B-00004003.0003001 / 16 NOV 11

**MODIFICATION OF THE CABIN RATE**



**PROCEDURE**

- PRESS the MCDU's PERF.
- WRITE the new cabin rate in the scratchpad.
- ENTER it in the [4R] field.

Ident.: PRO-NOR-SRP-01-50-B-00004004.0010001 / 22 MAY 12

**ENTERING THE APPROACH DATA**

From PERF DES page, SELECT "NEXT PHASE" [ 6R ] key to display the APPR page.  
ENTER QNH , TEMP , WIND at destination (magnetic north reference), minimum in the RADIO or BARO fields.

*(The PFD displays the entered BARO or RADIO minimum value, only when the distance to destination is less than 250 NM).*

CHECK and, if necessary, MODIFY

- LDG CONF (landing configuration),
- VAPP (the FM-computed value may be modified),
- TRANS ALT (transition altitude).



The scratchpad displays “ENTER DEST DATA” if the approach page is not completed when the aircraft is 180 NM from destination.

SELECT “NEXT PHASE” in order to display the GO AROUND page.

CHECK and, if necessary, MODIFY the THR RED ALT and the ACC ALT.



Ident.: PRO-NOR-SRP-01-50-B-00004005.0001001 / 22 MAY 12

## **SELECTING THE RADIO NAVAIDS**

CHECK or SELECT the NAVAIDS appropriate for the approach.

*For an ILS procedure, the ILS will be autotuned.*

*NDBs must be manually entered.*

*Note:* When the destination has a VOR /DME , ENTER it manually in the VOR field. ENTER its identifier in the BRG /DIST field of the PROG page. This allows you to perform a permanent NAV accuracy check.



Ident.: PRO-NOR-SRP-01-50-B-00004006.0003001 / 08 DEC 16

### **COST INDEX FOR LONG-RANGE CRUISE**

The flight crew can use the table below to find an approximate Cost Index value that is calculated for cruise at long-range cruise speed. This value is valid for CRZ FL = OPT ALT ± 1 000 ft.

AIRCRAFT	ENGINE	CILRC	
		kg/min	100 lb/h
A318/A319/A320/A321	CFM 56-5-A1/A3	45	60
	CFM 56-5-A4/A5	40	55
	CFM 56-5-B1/B2/B3	65	85
	CFM 56-5-B4 (A321)	65	85
	CFM 56-5-B4 (A320)	55	75
	CFM 56-5-B4/P	25	35
	CFM 56-5-B5/B6/B7	25	35
	CFM 56-5-B5/2P CFM 56-5-B6/2P CFM 56-5-B7/2P	30	40
	CFM 56-5-B8/B9	15	20
	CFM LEAP-1A	40	55
	PW6122/PW6124	20	30
	PW1100G-JM	40	55
	V2500-A1	45	60
	V2522-A5/V2524-A5/ V2527M-A5	50	70
V2530-A5/V2533-A5	50	70	
V2527-A5/V2527E-A5	40	55	



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SYSTEMS RELATED PROCEDURES - FMS

Intentionally left blank



## Descent

### DESCENT INITIATION

Ident.: PRO-NOR-SRP-01-60-00004007.0001001 / 14 FEB 11

Applicable to: ALL

The top of descent, displayed on the F-PLN page (T/D) and on the ND (ND), is a position that the system calculates, assuming that the aircraft will begin its descent in DES mode with managed speed, and that the system will guide the aircraft along the descent profile computed with all the vertical F-PLN data (ALT CSTR, ECON or AUTO MACH/SPD, SPD CSTR, SPD LIMIT) to reach VAPP at 1 000 ft AGL.

*Note:* The ND does not display the top of descent when HDG (or TRACK) mode is engaged.

### PROCEDURES

● **When the aircraft reaches the top of descent (F/D) :**

SELECT the altitude target.

PUSH the ALT selector knob. DES mode engages.

CHECK the FMA annunciators.

### DESCENT MONITORING

Applicable to: ALL

Ident.: PRO-NOR-SRP-01-60-A-00004008.0007001 / 06 JUN 16

### DES MODE ENGAGED

When DES mode is engaged, NAV mode is engaged, and the system takes into account all altitude and speed constraints of the F-PLN.

The key parameter for monitoring the descent is the vertical deviation (VDEV) displayed on the PFD and on the PROG page, which indicates whether the aircraft is on, above, or below the descent profile.

### PROCEDURE

SET the ATC -cleared altitude on the FCU (considering also what is the safe altitude).

*If the lowest safe altitude is higher than the ATC -cleared altitude, check with ATC that this constraint applies.*

*If it is confirmed, SET the FCU altitude to the safe altitude until it is safe to go to the ATC-cleared altitude.*

MONITOR vertical deviation (VDEV) on the PFD and the PROG page.

MONITOR the speed change that occurs, when the aircraft reaches a speed change symbol (magenta ball) under managed speed.


MONITOR the FMA (ALT \*, ALT CST\*, ALT , ALT CST), when the aircraft reaches level symbols.

■ **If the aircraft is on the descent profile:**

The aircraft is considered to be on the vertical profile, when it is within 50 ft of it. VDEV is close to zero, and the system predicts that it will match constraints until the aircraft levels off at the next FCU altitude.

MONITOR the predicted descent point after the next level-off.


*A/THR adjusts thrust for the particular segment. The first FMA column may display “THR IDLE” or “SPEED”.*



■ **If the aircraft is above the descent profile:**

VDEV is down on the PFD and positive on the PROG page.

A/THR sets IDLE thrust and the AP increases speed by calling for down elevator. If the aircraft reaches the upper limit of the managed speed range, the aircraft diverges and maintains the upper limit speed.






**Procedure**


SELECT a descent speed higher than the upper limit when possible.

MONITOR the intercept symbol 

*When this symbol reaches the next ALT CSTR waypoint, "MORE DRAG" appears on the PFD, indicating that speedbrakes must be extended in order to match the next altitude constraint. This is an advisory message.*

Note: With DPO , when above the descent profile, the flight crew may have to extend the speed brakes in order to go back on the descent profile.

- If an altitude constraint is predicted to be missed by more than 250 ft, the vertical revision page shows ALT ERROR at the waypoint.



- If a speed constraint is predicted to be missed by more than 10 kt:  
 SELECT an appropriate speed.  
 RESUME managed speed when the aircraft is back on the descent path.
- If the aircraft is below the descent profile:  
 VDEV is up on the PFD and negative on the PROG page. The system maintains the target speed (managed or selected speed).  
 MONITOR the intercept symbol (⏏) on the ND and any leveling off at the next ALT CSTR.
- If the aircraft is flying at an altitude that is higher than both the descent speed limit altitude and the destination elevation +5 000 ft:  
 The FMGS maintains the V/S at -1 000 ft/min and the target speed, until the aircraft reaches the altitude constraint or intercepts the descent profile.

**PROCEDURES**


**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

- If the aircraft is flying at an altitude that is lower than either the descent speed limit altitude, or the destination elevation +5 000 ft:

The FMGS maintains the V/S at -500 ft/min and the target speed, until the aircraft reaches the altitude constraint or intercepts the descent profile.





● **If the rate of descent has to be increased (ATC requirement):**


SELECT OP DES mode

Increase the target speed or extend the speedbrakes.

Ident.: PRO-NOR-SRP-01-60-A-00004009.0002001 / 22 MAY 12

**OP DES , V/S OR FPA MODE ENGAGED**

- In either case, the aircraft is no longer guided on the descent profile and altitude constraints are disregarded. If NAV mode is engaged the ND displays a white circle on waypoint with an altitude constraint. If NAV mode is disengaged, the circle is removed.
- The PFD still shows VDEV for reference purposes.
- The target altitude is always the FCU selected altitude (shown in blue).  
On the ND , level-off symbol is blue (no constraint). If NAV mode is engaged and the speed target managed, speed constraints are considered.



When HDG or TRK mode is engaged, vertical position may also be assessed on the ND using the energy circle. It is displayed as a green arc oriented on the current track and centered on the aircraft current position.

*Note:* Altitude and speed predictions displayed on the F-PLN page assume an immediate return to DES mode.

**PROCEDURE**

SET the FCU altitude as cleared by ATC, while considering the applicable safe altitude.

*If the next safe altitude is higher than the ATC -cleared altitude, check with the ATC to verify that this constraint applies.*

*If confirmed, set the FCU altitude to the safe altitude, until it is safe to fly at the cleared altitude.*

MONITOR the speed target, when the aircraft reaches the speed change symbol.

MONITOR the FMA ALT \*, ALT, upon reaching the level symbol.



When in HDG /TRK mode, MONITOR the energy circle  on the ND.

The MCDU F-PLN page presents SPD /ALT constraint-matching predictions, which assume that DES mode is immediately re-engaged.

CHECK the predictions before re-engaging DES mode (in order to resume the descent profile).

*Note:* VDEV is available on the PFD even in HDG mode; it is a valuable tool for monitoring the descent, as long as crosstrack error (XTK) is less than 5 NM.

The aircraft automatically decelerates for approach, only if it flies over the DECEL pseudo waypoint with NAV mode engaged (or LOC \*, LOC).

### EXPEDITE DESCENT (IF INSTALLED)


Ident.: PRO-NOR-SRP-01-60-00004010.0001001 / 22 MAY 12

Applicable to: ALL

- **When ATC requires a rapid descent:**

DEPRESS THE EXPED pushbutton

*Flight guidance (FG) pitches the aircraft to acquire and maintain 0.80/340. FG orders a pitch rate that produces no more than 0.15 g. The pilot can use this mode to initiate an emergency descent. To resume normal descent, PUSH the ALT selection knob or engage any other vertical mode.*



**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

**MONITORING THE NAVIGATION IN THE TERMINAL CONTROL AREA**

Ident.: PRO-NOR-SRP-01-60-00004012.0002001 / 14 FEB 11

Applicable to: **ALL**

If the MCDU “AREA RNP IS XX.X” message or “PROCEDURE RNP IS XX.X” message is displayed, the pilot will manually-entered RNP value in the REQUIRED field of the PROG page and clear or modify it, if it is not in accordance with the RNP value specified in the area (NAV or approach chart).

**TOO STEEP PATH**

Ident.: PRO-NOR-SRP-01-60-00004013.0007001 / 22 MAY 12

Applicable to: **ALL**

“TOO STEEP PATH AHEAD” appears on the MCDU scratchpad, when the system predicts this situation, and TOO STEEP PATH is displayed on the F-PLN page.

When the aircraft is crossing the first waypoint of a TOO STEEP PATH, the system computes a flyable descent profile (with an idle segment). The VDEV makes a jump because it is related to a new profile.

**VERT REV AT FIR96**

EFOB=6.4 EXTRA=3.0  
 TOO STEEP PATH BEYOND  
 DES SPD LIM  
 250/FL100 RTA>  
 SPD CSTR ALT CSTR  
 \*[ ] +FL260

<WIND STEP ALTS>  
 <RETURN

1L	UB191 UTC SPD/ALT		A1101→	1R
	ABB 1238 .78/FL330			
2L	(T/D) 1239 .79/FL330		13NM	2R
	BIG1A TRK320° 21			
3L	FIR96 1242 310/ * FL260			3R
4L	-----TOO STEEP PATH-----			4R
	BIG1A			
5L	CLIFF 1246 293/ * FL120			5R
	DEST UTC DIST EFOB			
6L	EGLL27R 1301 149 6.1			6R
	TOO STEEP PATH AHEAD↑↓			

F.PLN A PAGE WITH A TOO STEEP PATH

**PROCEDURE**

- **When passing the first waypoint of the TOO STEEP PATH:**  
 MONITOR VDEV and predictions at the next CSTR waypoint.  
 If required, EXTEND the speedbrakes before seeing the “MORE DRAG” message.  
 CONSIDER using a holding pattern, if necessary.

**PROCEDURES**  
**NORMAL PROCEDURES**

SYSTEMS RELATED PROCEDURES - FMS

**HOLDING PATTERN**

Ident.: PRO-NOR-SRP-01-60-00004014.0001001 / 09 OCT 12

Applicable to: ALL

A hold may be required during the descent, and may be manually inserted.

**PROCEDURE**

PRESS the F-PLN key.


SELECT the lateral revision page.

SELECT the HOLD prompt.

CHECK the HOLDING data, and MODIFY it if necessary.

CHECK the temporary flight plan and INSERT the holding pattern in it.

*Note: If the holding fix is close to the DECEL pseudo waypoint and the speed is managed, manually activate the approach phase to change the managed target speed to approach speed (VAPP). This will avoid having an increase of speed not appropriate.*



**MANUAL TERMINATION**

Ident.: PRO-NOR-SRP-01-60-00004016.0001001 / 09 DEC 09

Applicable to: ALL

You should not use DES mode when entering a leg with manual termination. Manual termination, which is defined as a track or a heading with no termination, is always part of a database procedure. The computed descent flight profile may not be adequate when flying this type of leg.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PROCEDURES

### NORMAL PROCEDURES

SYSTEMS RELATED PROCEDURES - FMS

Intentionally left blank

## Approach


### INITIAL APPROACH

Ident.: PRO-NOR-SRP-01-70-00004017.0015001 / 17 MAR 11

Applicable to: ALL

#### UPON REACHING THE INITIAL APPROACH AREA

- Approach phase will activate automatically when flying over the DECEL pseudo waypoint with NAV , LOC \* , LOC , F-LOC\* or F-LOC mode engaged.
- You will activate manually the approach phase on the PERF page if:
  - HDG or TRK mode is engaged, or
  - You are flying a go around, or
  - An early deceleration is required




**MANAGED SPEED**

CHECK that managed speed is active: MONITOR the target speed.

*During the approach, the autothrust limits the speed of the current configuration. (GD, S, F, VAPP).*





● **If ATC requires a specific speed:**

SWITCH to selected speed (turn and pull the speed selector knob on the FCU).  
ADJUST the aircraft configuration accordingly.

● **If ATC orders successive step descents down to the final approach flight path:**

Use the V/S or FPA mode.  
MONITOR VDEV.

**NAV ACCURACY**

As required by the SOP.

For Non Precision Approaches flown with the FLS function, the flight crew must check the FLS capability.

Without installed GPS and when no DME is available for the accuracy check, use HIGH/LOW on the PROG page.

In this case, consider a "HIGH" to be equivalent to a positive crosscheck.

**ATC CLEARANCE**

MODIFY the F-PLN , RAD NAV , and PERF APPR data to agree with the latest clearance and landing information.

**ILS/MLS/GLS/FLS APPROACH**

Applicable to: ALL


Ident.: PRO-NOR-SRP-01-70-A-00004018.0001001 / 17 MAR 11

**INTERMEDIATE/FINAL APPROACH (ILS APPROACH ENTERED IN THE F-PLN)**

The preferred technique for flying an ILS approach is to fly a decelerated approach using the AP /FD s, the LOC and G/S modes, A/THR in the SPEED mode, managed speed target is recommended.

**DECELERATED APPROACH**

The decelerated approach technique brings the aircraft down to 1 000 ft, at VAPP . In most cases, the interception of the final descent path is achieved with CONF 1 at S speed.



(\*) The approach must be stabilized at approach speed (minimum ground speed) in the landing configuration before reaching 1 000 ft AGL.

Ident.: PRO-NOR-SRP-01-70-A-00004019.0009001 / 17 MAR 11

**APPROACH MODE ACTIVATION (LOC -G/S)**

● **When cleared by ATC and when appropriate:**

DEPRESS the APPR pushbutton to arm the APPR mode for the approach entered in the flight plan.

*Note:* If a NON PRECISION approach is selected in the active flight plan and if the flight crew manually tunes an ILS on the RAD NAV page, the MCDU and the PFD display "CHECK APPR SELECTION". This message is a reminder to the flight crew that, although an ILS is tuned on RAD NAV page, the available approach guidance modes are APP NAV -FINAL when the APPR pushbutton is pressed in on the FCU.

The FCU APPR pushbutton arms or engages LOC and G/S modes, if:

- An ILS approach is entered in the flight plan, or
- No approach, or only a runway, is entered in the flight plan, and an ILS is manually-tuned on the RAD NAV page, or
- Both RMP s are set to NAV , and an ILS is selected.

Ident.: PRO-NOR-SRP-01-70-A-00004020.0002001 / 17 MAR 11

## **AUTOLAND**

CHECK that the FMA displays the aircraft capability (CAT 2 or CAT 3) for the intended ILS approach.

MONITOR the radio automatic callout.

### ● **At 350 ft RA:**

CHECK that “LAND” is displayed on the FMA.

CHECK ILS course.

*If LAND is not displayed or if the ILS course is not correct, do not perform an autoland. The flight crew should perform a go-around, if visual references are not sufficient.*

### ● **Between 50 and 40 ft RA:**

CHECK that “FLARE” is displayed on the FMA.

### ● **At approximately 30 ft RA:**

CHECK that “IDLE” is displayed on the FMA, and that autothrust starts to reduce thrust toward IDLE.

### ● **At 10 ft, “RETARD” callout comes up:**

MOVE the thrust levers to IDLE.

*Autothrust disconnects.*

### ● **At touchdown:**

CHECK that “ROLL OUT” appears on the FMA.

Note: *In the case of tailwind during an automatic rollout, it is recommended to use manual braking without delay or automatic braking for an optimised runway centerline tracking.*

● **At the end of the Rollout:**

Disconnect the autopilot.

*If the flight crew does not disconnect the AP at the end of the rollout, and uses the nosewheel steering handwheel to taxi the aircraft off the runway, the following will occur:*

- *The AP will try to steer the aircraft back to the runway centerline, if the nosewheel steering handwheel is released and the aircraft heading is less than 20 ° off the runway centerline.*
- *The AP will automatically disconnect, if the aircraft heading is 20 ° or more off the runway centerline.*

Ident.: PRO-NOR-SRP-01-70-A-00004021.0001001 / 17 MAR 11

**MANUAL LANDING**

● **At DH:**

DISCONNECT the APs. SPEED mode remains engaged.

● **At 20 ft “RETARD” automatic call out comes up:**

MOVE the thrust levers to IDLE if they are not there already. (The A/THR disconnects).


● **At touch down:**

“ROLL OUT” appears on the FMA and the yaw bar comes up on the PFD.

Note: *The retard call out is only a reminder when a manual landing is performed.*

Ident.: PRO-NOR-SRP-01-70-A-00004022.0011001 / 22 MAY 12

**STANDARD ILS AUTOMATIC APPROACH**





Ident.: PRO-NOR-SRP-01-70-A-00004023.0001001 / 26 NOV 13

**EARLY SELECTION OF APPROACH MODE LOC -G/S**

Pressing the APPR pushbutton arms LOC and G/S.

When the aircraft is above 5 000 ft AGL , the Radio altimeter signals may not be valid. As long as the Radio altimeter signals are invalid, the FMA displays CAT 1.

- **When the aircraft is cleared for an ILS/MLS  /GLS  approach:**  
PRESS the APPR pb on the FCU.
- **When the aircraft is below 5 000 ft AGL:**  
Check that the FMA displays the correct capability for the intended approach.

Ident.: PRO-NOR-SRP-01-70-A-00004024.0002001 / 29 MAY 13

### GLIDESLOPE INTERCEPTION FROM ABOVE

If the aircraft is above the glideslope, the system will not capture the G/S automatically. The pilot must bring the aircraft onto the glideslope beam, and select an appropriate V/S to intercept it. *Refer to PRO-NOR-SOP-18-C Approach using LOC G/S Guidance - General.*

Ident.: PRO-NOR-SRP-01-70-A-00004025.0001001 / 17 MAR 11

### DATA LOCK

When the aircraft reaches 700 ft RA with APPR mode (LOC and G/S ) armed or engaged, the ILS FREQ and course are frozen in the receiver.

This function (ILS tune inhibit) is available, when at least one AP /FD is engaged. Any attempt to change the ILS frequency or CRS , via the MCDU or RMP, does not affect the receiver.

If the speed is managed, the system does not accept any modifications the pilot may enter on the PERF APPR page (surface wind, selected landing configuration, or VAPP) for speed guidance purposes below this altitude.

When the aircraft reaches 400 ft RA, LAND mode engages. The flight crew can only disengage this mode by engaging the GO AROUND mode.

Ident.: PRO-NOR-SRP-01-70-A-00004026.0001001 / 17 MAR 11

### USE OF RMP S FOR ILS /DME


If both FMGC s fail, the flight crew can use the RMP s (Radio Management Panels 1 and 2) for back up tuning. Either RMP controls ILS . Prior to select an ILS frequency on one of the RMP s, the flight crew has to select "NAV " button from RMP 1 and RMP 2.

If the ILS has a DME , the PFD will not display the DME distance. In this situation, the flight crew will fly without DME information. If necessary, increase the Decision height (DH) accordingly.

Ident.: PRO-NOR-SRP-01-70-A-00004027.0001001 / 22 MAY 12

### LOCALIZER (LOC) BEAM CAPTURE

The flight crew must always monitor the capture of a LOC beam. During this evolution, the PFD and ND must indicate that associated deviation indications move toward the centre of the scale. To avoid performing a false capture, the flight crew must be careful not to arm the LOC too early. The following graph shows the angle of interception versus distance to the runway threshold that ensures that the aircraft will not overshoot the axis by more than one and a half dot.



The capture begins when the deviation is two dots or less. It is programmed to line the aircraft up on the beam with a single overshoot, even if the intercept angle is large.

**Note:** ICAO requires LOC beam to ensure a normal capture within 10 NM and plus or minus 35 ° from the course centerline. Some ILS systems just meet the requirement and are subject to false capture outside these limits.

**SWITCHING FROM NON ILS TO ILS APPROACH**

Ident.: PRO-NOR-SRP-01-70-00004028.0002001 / 17 MAR 11

Applicable to: ALL

If an ILS approach is possible when a non ILS was previously scheduled, use one of the following procedures:

**USE OF SECOND FLIGHT PLAN**

Use a secondary flight plan to prepare the alternate ILS approach, time permitting.

COPY the ACTIVE flight plan.

REVISE the ARRIVAL: insert the ILS approach and the applicable STAR/VIA.

On the RAD NAV page, TUNE in the ILS manually.

REVISE the PERF APPR page.

**CHANGE OF THE CLEARANCE**

ATC changes the clearance from the non-ILS to the ILS approach.

● **If a secondary flight plan has been prepared:**

ACTIVATE the SEC F-PLN and adjust.

Follow subsequent standard procedures.

● **If a secondary flight plan has not been prepared:**

REVISE the ARRIVAL on the primary F-PLN, inserting the ILS approach.

REVISE the PERF APPR page.

Follow subsequent standard procedures.


**CAUTION**

If the pilot decides to fly the ILS approach without revising the arrival of the primary flight plan (a non ILS approach is in the F-PLN ), LOC and G/S modes will not be available when he presses the APPR pushbutton.

Consequently, he should:

- Manually TUNE in the ILS on the RAD NAV page: CHECK that the "CHECK APPR SELECTION" message comes up.
- Press the ILS pushbutton and select ROSE ILS on the EIS CONTROL panel.
- Use HDG , V/S or TRK , FPA modes to fly the ILS.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>NORMAL PROCEDURES</b> SYSTEMS RELATED PROCEDURES - FMS</p>
---	---

**LANDING CATEGORIES**

Ident.: PRO-NOR-SRP-01-70-00004038.0001001 / 16 NOV 11

**Applicable to: ALL**

Each FMGC computes its own landing category : CAT 1, CAT 2, CAT 3 single, and CAT 3 dual and displays the corresponding landing category on the FMAs.

Each category depends upon the availability of aircraft systems and functions.

When the landing capability downgrades, a triple click aural warning is activated.

**FAIL-OPERATIONAL AUTOMATIC LANDING SYSTEM**

An automatic landing system is fail-operational if, in the event of a failure below alert height, the remaining part of the automatic system allows the aircraft to complete the approach, flare, and landing. A CAT 3 DUAL system is a fail-operational automatic landing system.

*Note: In the event of a failure, the automatic landing system operates as a fail-passive system.*

**FAIL-PASSIVE AUTOMATIC LANDING SYSTEM**

An automatic landing system is fail-passive if, in the event of a failure, there is no significant out-of-trim condition or deviation of flight path or attitude, but the landing is not completed automatically. A CAT3 single system is a fail-passive automatic landing system.

*Note: With a fail-passive automatic landing system the pilot assumes control of the aircraft after a failure.*

Below 100 ft (radio altimeter), the FMGS freezes the landing capability until LAND mode is disengaged or both APs are off.

Therefore a failure occurring below 100 ft does not change the category of the system.

**ALERT HEIGHT**

The alert height is the height above touch down, above which a CAT3 autoland would be discontinued and a missed approach executed, if a failure occurred in either the airplane systems or the relevant ground equipments.

Below the alert height, if such a failure occurs, the flare, touchdown and roll out may be accomplished using the remaining automatic system.

**WARNINGS FOR ILS APPROACH**

Ident.: PRO-NOR-SRP-01-70-00004039.0010001 / 17 MAR 17

Applicable to: ALL

**AUTOLAND WARNING**

With "LAND" or "FLARE" green on the FMA and at least one AP engaged, the AUTOLAND red light appears on the glareshield when the aircraft is below 200 ft RA and one of the following events occurs:

- The autopilots are lost, or
- The aircraft gets too far off the beam (LOC or G/S flash on PFD), or
- Loss of LOC signal above 15 ft, or loss of glide signal above 100 ft (transmitter or receivers), or
- The difference between both radio altimeter indications is greater than 15 ft, or
- The FMGS detects a long flare.

**WARNING OF EXCESSIVE BEAM DEVIATION**

This warning is a flashing of the LOC and G/S scales on the PFD and ND ROSE ILS. It occurs whenever:

- G/S deviation is greater than 1 dot (above 100 ft RA).
- LOC deviation is greater than 1/4 dot (above 15 ft RA).

**WARNING ASSOCIATED WITH ILS "LANDING CAPABILITY"**

Any downgrading in the aircraft's capability for automatic approach and landing sounds a triple-click aural warning.

**FAILURE OF BOTH LOCALIZER AND GLIDESLOPE RECEIVERS**

The PFD and ND (rose ILS mode) display red LOC and G/S flags (if the ILS pushbutton has been pressed green). LOC and G/S scales disappear from the PFD.

If LOC or G/S modes are engaged and at least one AP /FD is engaged

- The AP disengages.
- The FD reverts to its HDG -V/S or TRK -FPA modes.

**FAILURE OF LOCALIZER OR GLIDESLOPE TRANSMITTER (WHEN CAPTURED)**

- The corresponding index is lost.
- The LOC and G/S scales flash.
- The corresponding FD bar flashes.

The FMA retains the LOC and G/S modes: If the transmitter failure is temporary, the AP s are able to regain these modes. If the failure is long-term, or if it occurs when the aircraft is below 200 ft RA, this allows the aircraft to perform a GO AROUND with one or 2 autopilots engaged.

**Go-Around**

**MONITORING THE GO-AROUND**

Ident.: PRO-NOR-SRP-01-80-00004054.0005001 / 09 JUL 13  
Applicable to: ALL

Engage the GO-AROUND phase and GO-AROUND modes by setting the thrust levers to the TOGA position, if at least CONF1 is selected.

When the GO-AROUND phase is engaged, the previously-flown approach is automatically strung back into the flight plan at the end of the missed approach procedure.

In the GO-AROUND phase, the system makes no predictions. Consequently, CLB and DES modes are not available, and the flight crew must monitor constraints.

When the aircraft leaves the GO-AROUND phase, all predictions and modes become available again. During a GO-AROUND phase, the managed speed is Green Dot.

ACTIVATE THE APPROACH PHASE MANUALLY  
THIS WILL SWITCH THE MANAGED  
SPEED TO APPROPRIATE  
SPEED (S, F, VAPP, VAPP TARGET)

4L	THR RED/ACC	ENG OUT ACC	4R
5L	1500/2000	2000	5R
6L	ACTIVATE	NEXT	6R
▶	← APPR PHASE	PHASE >	

PERF PAGE, GO-AROUND PHASE ACTIVE

**HEADING/TRACK PRESET FUNCTION IN GO-AROUND PHASE**

The flight crew can use the heading/track preset, when LOC \*, LOC , LAND or GA is engaged.

SET the appropriate heading, or track value, in the window of the FCU.


When necessary, PULL the HDG/TRK selection knob to engage the mode on the preset value.

*Note:* The heading/track preset is not available in non precision approach in AP /FD FINAL mode.

**GO-AROUND PROFILE**

Ident.: PRO-NOR-SRP-01-80-00004055.0043001 / 22 MAY 12  
Applicable to: ALL

- **WITH FD ON:**  
Apply SOP procedures



**MISSED APPROACH: TRY AGAIN**

Ident.: PRO-NOR-SRP-01-80-00004057.0008001 / 14 FEB 11

Applicable to: **ALL**

If the pilot intends to fly another approach to the destination:

- The flight plan has all the necessary data for the missed approach
- Green Dot is the target speed.

- **When cleared by the ATC to follow the missed approach procedure:**  
ENGAGE NAV mode, or  
TURN and PULL the HDG selector knob to set a heading  
*HDG , or TRK , or NAV modes can only be engaged above 100 ft.*
- **When entering the initial approach area:**  
Activate the approach phase on the MCDU's PERF GO AROUND page
  - **If the APPR phase is not activated:**
    - Managed approach speed will not be available
    - The system will not furnish predictions
    - BARO /RADIO minima displays will not appear on the PFD.

**MISSED APPROACH: DIVERT**

Ident.: PRO-NOR-SRP-01-80-00004058.0001001 / 14 FEB 11

Applicable to: ALL

- **If the crew decides to divert to the alternate:**  
ENABLE ALTN, preferably at the TO waypoint.
- **When cleared to a waypoint:**  
PERFORM a DIRECT TO.

The system automatically reverts to CLB phase, and modifies the target speed from Green Dot to initial speed.

The system automatically sets the CRZ FL to the defaulted alternate CRZ FL (FL 220 or 310), and retains the previous cost index.




The pilot may adjust these as necessary.

Note: *Diversion may also be initiated by entering a NEW DEST in the LAT REV page at the TO waypoint, or by using the secondary F-PLN, if prepared. Refer to DSC-22\_20-60-30 General.*

**TASK SHARING DURING A GO-AROUND**

Ident.: PRO-NOR-SRP-01-80-00004059.0002001 / 20 JUL 15

Applicable to: **ALL**

PF	PM
<p>-Announce "GO AROUND, FLAPS". Simultaneously set thrust levers to TO GA.</p> <p>-Monitor the flight path.</p>	<p>-Announce "FLAPS_". Retract flaps one step, and monitor engine parameters.</p>
	
<p><u>When rate of climb is positive:</u></p>	
<p>-Announce "GEAR UP"</p>	<p>-Announce "POSITIVE CLIMB". -Retract the gear and confirm "GEAR UP".</p>
<p><u>When LVR CLB flashes on FMA:</u></p>	
<p>-Set thrust levers to CL detent.</p> <p>-Push or Turn/pull HDG/TRK sel knob on FCU, according to ATC clearance.</p>	
	
<p><u>At go-around acceleration altitude:</u></p>	
<p>-Monitor that the target speed increases to Green Dot.</p>	
	
<p>● If the speed target does not increase to Green Dot:          -CHECK and PULL the altitude selector knob to engage OP CLB          The speed target increases to Green Dot          -Retract flaps on schedule.</p>	

# **PROCEDURES**

SPECIAL OPERATIONS

Intentionally left blank



**PRO-SPO-20 Flight Without Cabin Pressurization**

General.....	A
Oxygen Requirements.....	B
Flight Planning and Execution.....	C
Systems.....	D
Performance Data.....	E
Flight Planning from Brake Release to Landing.....	F
Ground Distance/Air Distance Conversion.....	G

**PRO-SPO-40 Extended Range Operations**

**PRO-SPO-40-10 General**

General.....	A
--------------	---

**PRO-SPO-40-20 Operational Limitations**

Definitions.....	A
Area of Operation.....	B

**PRO-SPO-40-30 Dispatch Consideration**

MMEL.....	A
ETOPS Fuel Scenarios.....	B
ETOPS Critical Fuel Reserves.....	C
ETOPS Fuel Requirements.....	D
Weather Minima.....	E

**PRO-SPO-40-40 Diversion During Extended Range Operations**

Diversion Decision Making.....	A
Diversion Performance Data.....	B
Guidelines for Diversion Procedure.....	C

**PRO-SPO-40-50 Procedures**

General.....	A
Normal Procedures.....	B
Abnormal and Emergency Procedures.....	C

**PRO-SPO-40-60 Performance**

General.....	A
Maximum Diversion Distance.....	B
ETOPS Fuel Requirement from Critical Point to Landing - All Engines - Cruise at LRC.....	C
ETOPS Fuel Requirement from Critical Point to Landing - One Engine Out - Cruise at 350kt.....	D
ETOPS Fuel Requirement from Critical Point to Landing - One Engine Out - Cruise at 320kt.....	E
ETOPS Fuel Requirement from Critical Point to Landing - Example.....	F

*Continued on the following page*

*Continued from the previous page*

**PRO-SPO-45 Engine Intermix Operations**

Engine Intermix Type 1.....	A
Engine Intermix Type 2.....	B

**PRO-SPO-50 Reduced Vertical Separation Minimum - RVSM**

General.....	A
Required Equipments/Functions for RVSM.....	B
RVSM Normal Procedure.....	C
RVSM Abnormal and Emergency Procedure.....	D

**PRO-SPO-51 Required Navigation Performance (RNP)**


General.....	A
RNAV 10 / RNP 10.....	B
RNAV 5 / BRNAV.....	C
RNAV 1 RNAV 2 / P-RNAV - Terminal RNAV.....	D
RNP 4.....	E
RNP 2 in Oceanic and Remote Continental Area.....	F
RNP 2 in Domestic Area.....	G
RNP 1 / Terminal RNP 1- Basic RNP 1.....	H
RNP APCH / RNAV(GNSS).....	I

**PRO-SPO-60 Operations on Narrow Runways**

General.....	A
Limitations.....	B
Procedures.....	C
Performance.....	D

**PRO-SPO-85 ILS PRM Approach**

Overview.....	A
Break out Turn and Climb Procedure.....	B
Break out Turn and Descent Procedure.....	C

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p align="center"><b>PROCEDURES</b>  <b>SPECIAL OPERATIONS</b></p> <p align="center">FLIGHT WITHOUT CABIN PRESSURIZATION</p>
---	--

**GENERAL**

Ident.: PRO-SPO-20-00001883.0001001 / 12 NOV 15  
**Applicable to: ALL**

Flight without cabin pressurization can result of:

- Dispatch under MEL
- Departure following a structural damage
- Depressurization in flight

The flight crew must decide the flight level and the airspeed depending on:

- The cause of the depressurization
- The distance to fly
- The topographic conditions
- The meteorological conditions, and
- The passengers on board the aircraft.

Revenue flight is permitted without cabin pressurization, provided that the oxygen requirements below are achieved.

After a MEL dispatch with both PACKs inoperative, the flight without cabin pressurization is permitted provided the flight is performed without passengers.

**OXYGEN REQUIREMENTS**

Ident.: PRO-SPO-20-00001884.0001001 / 21 MAR 17  
**Applicable to: ALL**

**CREW MEMBERS**

See FAR 121.329 or AIR-OPS CAT.IDE.A.235

**PASSENGERS**

For flight at cabin pressure altitudes above 10 000 ft, up to and including 14 000 ft, there must be enough oxygen to supply 10 % of the passengers for the flight at those altitudes that lasts more than 30 min.

For flight at cabin pressure altitudes above 14 000 ft, up to and including 15 000 ft, there must be enough oxygen for 30 % of the passengers.

For flight at cabin pressure altitudes above 15 000 ft, there must be enough oxygen for all passengers.

## **FLIGHT PLANNING AND EXECUTION**

Applicable to: ALL

Ident.: PRO-SPO-20-A-00001981.0001001 / 21 MAR 17

### **ALTITUDE**

Flight route planning should consider the above-stated restriction in cabin altitude. If cabin altitude exceeds  $9\,550 \pm 350$  ft, the EXCESS CAB ALT warning on the ECAM will be activated. When above 14 000 ft, the passenger oxygen masks will drop automatically. Therefore, the recommended maximum altitude for prolonged flight is FL 100. The minimum altitude should be selected by respecting :

- The Minimum Safe Altitude (MSA),
- Turbulence, which is uncomfortable for passengers and,
- Low Outside Air Temperature (OAT), which can be uncomfortable for passengers when the cabin is ventilated by ram air only.

Ident.: PRO-SPO-20-A-00001983.0001001 / 21 MAR 17

### **AIRPEED**

If decompression is due to structural damage, consider airspeed reduction. Use slats and flaps, as necessary, to establish low speed conditions. In addition, turbulent conditions are uncomfortable for passengers, and gust response should be minimized by reducing airspeed.

Ident.: PRO-SPO-20-A-00001984.0001001 / 21 MAR 17

### **CLIMB AND DESCENT RATE**

Takeoff must be performed normally, and the rate of climb must be limited to about 500 ft/min, to ease the pressure change felt by passengers and crew. Likewise, the rate of descent must be limited to about 1 000 ft/min, except for the final approach which must be performed normally. Notify the ATC of any performance deficiency by a remark in the flight plan.

Ident.: PRO-SPO-20-A-00001985.0004001 / 21 MAR 17

### **EMER DESCENT IN CASE OF RAPID DEPRESSURIZATION**

In the event of depressurization, oxygen is supplied to passengers through an individual mask. The capacity of the units is such that the aircraft must descend and remain below the following profile.



**SYSTEMS**

Ident.: PRO-SPO-20-00001990.0002001 / 23 JUN 15

Applicable to: ALL

**FAILURE OCCURRING IN FLIGHT**

Apply the abnormal and emergency procedures required by ECAM.

**FAILURE PRESENT AT DISPATCH**

● **If flight with both packs inoperative:**

In that case, the flight must be performed with no passengers.

PACK 1 and 2..... OFF  
 RAM AIR..... ON

*Note: If the "AVIONICS SMOKE" procedure has to be applied, the following flight time limitations have to be considered to protect the avionic equipment :*

- At ISA +40 : 0.5 h*
- At ISA +30 : 1.5 h*
- At ISA +20 : 4 h*
- At ISA +10 and below : No limitation.*

MAX FL .....100 or MSA

● **If both CAB PRESS systems are inoperative, or if there is structural damage:**

TEST OF THE MANUAL OPERATION OF THE OUTFLOW VALVE ON GROUND:

PACK 1 pb-sw and PACK 2 pb-sw ..... OFF  
 OUTFLOW VALVE FULLY OPEN.....CHECK

*Check that the outflow valve is fully open on the CAB PRESS SD page*

RPCU CB (X23 ON 122VU)..... PULL  
 MODE SEL pb ..... MAN

MAN V/S CTL ..... DN

*Check that the outflow valve is fully closed on the CAB PRESS SD page*

MAN V/S CTL ..... UP

*Check that the outflow valve is fully open on the CAB PRESS SD page*

MODE SEL pb ..... AUTO

RPCU CB (X23 ON 122VU)..... PUSH

PACK 1 pb-sw and PACK 2 pb-sw ..... ON

MAX FL ..... 100 or MSA

*Between FL 80 and FL 150, oxygen must be provided for 2 % of the passengers. This is provided by the portable oxygen system. When it is no longer available, descend to FL 80. For performance at FL 80/250 kt : Use data for FL 100/LRC (Refer to PER-CRZ-CRT-30 LONG RANGE CRUISE - ISA) and increase fuel consumption by 6 %.*

**TAKEOFF**

Limit the aircraft's rate of climb to about 500 ft/min.

- **If both CAB PRESS systems are inoperative, or if there is structural damage:**

- **WHEN IN CLEAN CONFIGURATION:**

MODE SEL pb ..... MAN

V/S CTL sw ..... AS RQRD

*Use V/S CTL pb to set the outflow valve opening to 50 %.*

OUTFLOW VALVE HALF OPEN..... CHECK

*The outflow valve opening is limited to 50 %, to prevent the cabin air suction effect.*

**CLIMB**

*Note: The EXCESS CAB ALT warning may occur.  
 Use the ECAM CLR pb to clear the warning.*

**DESCENT**

Limit the aircraft's rate of descent to about 1 000 ft/min. Perform the final approach normally.

**PERFORMANCE DATA**

Ident.: PRO-SPO-20-00001991.0002001 / 10 JAN 11

Applicable to: ALL

The following table enables the fuel consumption and the time needed from takeoff to landing to be determined in case of flight without cabin pressurization.

The table is established for :

- Takeoff
- Climb from 1 500 ft at 250 kt
- Long range cruise speed at FL 100
- Descent to 1 500 ft at 250 kt
- Approach and landing : IMC procedure 120 kg or 260 lb (6 min)
- ISA temperature
- CG = 25 %
- Normal air conditioning
- Anti ice OFF

The table (*Refer to PRO-SPO-20 Ground Distance/Air Distance Conversion*) gives the conversion from ground distance to air distance

Following tables have been calculated using databases for CFM 56–5–B /P. If the engines fitted on the aircraft are not /P, the fuel consumption has to be increased by 3 %.

Note: For each degree Celcius above ISA temperature apply a correction of 0.01 (kg/°C/NM) or 0.022 (lb/°C/NM).

**FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING**

Ident.: PRO-SPO-20-00001992.0022001 / 10 JAN 11

Applicable to: ALL

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING							
CLIMB : 250 KT - CRUISE : LONG RANGE - DESCENT : 250KT							
IMC PROCEDURE : 120 KG (6MIN)							
		<b>FL 100</b>					
NORMAL AIR CONDITIONING		ISA		FUEL CONSUMED (KG)			
ANTI-icing OFF		CG = 25.0%		TIME (H.MIN)			
AIR DIST. (NM)	INITIAL WEIGHT (1000KG)						
	50	55	60	65	70	75	80
<b>220</b>	1895 0.55	1968 0.53	2040 0.52	2110 0.51	2183 0.51	2257 0.50	2336 0.50
<b>240</b>	2039 0.59	2119 0.57	2197 0.55	2271 0.55	2348 0.54	2426 0.54	2509 0.54
<b>260</b>	2183 1.04	2270 1.01	2353 0.59	2432 0.58	2513 0.58	2595 0.57	2682 0.57
<b>280</b>	2326 1.08	2420 1.05	2509 1.03	2593 1.02	2678 1.01	2763 1.01	2854 1.01
<b>300</b>	2470 1.13	2571 1.09	2665 1.07	2753 1.05	2842 1.04	2932 1.04	3026 1.04
<b>320</b>	2613 1.17	2721 1.13	2821 1.10	2914 1.09	3007 1.08	3100 1.07	3199 1.07
<b>340</b>	2756 1.21	2871 1.17	2977 1.14	3074 1.12	3171 1.11	3269 1.11	3371 1.11
<b>360</b>	2899 1.26	3020 1.21	3133 1.18	3234 1.16	3336 1.15	3437 1.14	3543 1.14
<b>380</b>	3042 1.30	3170 1.25	3288 1.21	3394 1.20	3500 1.18	3605 1.18	3715 1.17
<b>400</b>	3185 1.35	3319 1.30	3444 1.25	3554 1.23	3664 1.22	3773 1.21	3886 1.21
<b>420</b>	3327 1.39	3468 1.34	3599 1.29	3713 1.27	3828 1.25	3941 1.24	4058 1.24
<b>440</b>	3469 1.44	3616 1.38	3754 1.33	3873 1.30	3992 1.29	4108 1.28	4229 1.28
<b>460</b>	3611 1.48	3765 1.42	3909 1.36	4032 1.34	4155 1.32	4276 1.31	4400 1.31
<b>480</b>	3753 1.53	3913 1.46	4064 1.40	4192 1.38	4319 1.36	4443 1.35	4572 1.34
<b>500</b>	3895 1.57	4061 1.50	4219 1.44	4351 1.41	4482 1.39	4611 1.38	4743 1.38
<b>520</b>	4036 2.01	4209 1.55	4373 1.48	4510 1.45	4645 1.43	4778 1.41	4913 1.41
<b>540</b>	4177 2.06	4357 1.59	4528 1.52	4668 1.48	4808 1.46	4945 1.45	5084 1.45
<b>560</b>	4318 2.10	4505 2.03	4682 1.55	4827 1.52	4971 1.50	5112 1.48	5255 1.48
<b>580</b>	4459 2.15	4652 2.07	4836 1.59	4986 1.56	5134 1.53	5279 1.52	5425 1.51
<b>600</b>	4600 2.19	4799 2.12	4990 2.03	5144 1.59	5297 1.57	5446 1.55	5595 1.55
<b>620</b>	4741 2.24	4946 2.16	5144 2.07	5302 2.03	5460 2.00	5612 1.58	5766 1.58
<b>640</b>	4881 2.28	5093 2.20	5298 2.11	5460 2.07	5622 2.04	5779 2.02	5936 2.01
<b>660</b>	5021 2.33	5240 2.25	5451 2.14	5618 2.10	5784 2.07	5945 2.05	6106 2.05
<b>680</b>	5161 2.37	5386 2.29	5605 2.18	5776 2.14	5946 2.11	6112 2.09	6275 2.08
<b>700</b>	5301 2.42	5532 2.34	5758 2.22	5934 2.18	6108 2.14	6278 2.12	6445 2.12
<b>AIR CONDITIONING OFF</b>		<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = - 2.5 %		ΔFUEL = + 5 %		ΔFUEL = + 9 %			





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

FLIGHT WITHOUT CABIN PRESSURIZATION

**GROUND DISTANCE/AIR DISTANCE CONVERSION**

Ident.: PRO-SPO-20-00001994.0001001 / 10 JAN 11

Applicable to: ALL

GROUND DIST. (NM)	AIR DISTANCE (NM)						
	TAIL WIND		WIND COMPONENTS (KT)			HEAD WIND	
	+150	+100	+ 50	0	-50	-100	-150
<b>40</b>	27	30	35	<b>40</b>	48	59	76
<b>60</b>	41	46	52	<b>60</b>	71	88	115
<b>80</b>	54	61	69	<b>80</b>	95	117	153
<b>100</b>	68	76	86	<b>100</b>	119	146	191
<b>120</b>	81	91	104	<b>120</b>	143	176	229
<b>140</b>	95	106	121	<b>140</b>	166	205	267
<b>160</b>	108	121	138	<b>160</b>	190	234	305
<b>180</b>	122	137	155	<b>180</b>	214	264	344
<b>200</b>	135	152	173	<b>200</b>	238	293	382
<b>220</b>	149	167	190	<b>220</b>	261	322	420
<b>240</b>	163	182	207	<b>240</b>	285	352	458
<b>260</b>	176	197	224	<b>260</b>	309	381	496
<b>280</b>	190	213	242	<b>280</b>	333	410	534
<b>300</b>	203	228	259	<b>300</b>	357	439	573
<b>320</b>	217	243	276	<b>320</b>	380	469	611
<b>340</b>	230	258	293	<b>340</b>	404	498	649
<b>360</b>	244	273	311	<b>360</b>	428	527	687
<b>380</b>	257	288	328	<b>380</b>	452	557	725
<b>400</b>	271	304	345	<b>400</b>	475	586	763
<b>420</b>	285	319	362	<b>420</b>	499	615	802
<b>440</b>	298	334	380	<b>440</b>	523	645	840
<b>460</b>	312	349	397	<b>460</b>	547	674	878
<b>480</b>	325	364	414	<b>480</b>	571	703	916
<b>500</b>	339	380	432	<b>500</b>	594	732	954
<b>520</b>	352	395	449	<b>520</b>	618	762	992
<b>540</b>	366	410	466	<b>540</b>	642	791	1031
<b>560</b>	379	425	483	<b>560</b>	666	820	1069
<b>580</b>	393	440	501	<b>580</b>	689	850	1107
<b>600</b>	406	455	518	<b>600</b>	713	879	1145



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

FLIGHT WITHOUT CABIN PRESSURIZATION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

EXTENDED RANGE OPERATIONS - GENERAL

**GENERAL**

Ident.: PRO-SPO-40-10-00002029.0001001 / 23 JUN 15

**Applicable to: ALL**

The system design and the reliability of the engine installation of this airplane comply with the criteria for Extended Twin Operations (ETOPS ) flights set forth in AMC 20-6 rev. 2 (EASA) or FAR 25.1535 (FAA), when the aircraft is configured, maintained and operated in accordance with the Airbus CMP (Configuration, Maintenance and Procedure) document.

This statement of ability does not constitute an approval to conduct Extended-Range Operations. The ETOPS EXTENDED OPERATIONS Chapter of the AFM APPENDICES AND SUPPLEMENTS Section refers to the approved Standard for Extended-Range Operations and the applicable limitations, procedures and performance references.

The operator is responsible for showing that he is complying with the regulation of his nation and for obtaining operational approval from his national authorities. The operator may amend this chapter, as needed.

The airplane must be configured in accordance with the Airbus Standard for Extended-Range Operations. However, the authorities may under certain conditions allow the operator to conduct ETOPS flights with limited maximum diversion time (for example, 75 min diversion time in a benign area of operation) without showing full compliance with these standards.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

EXTENDED RANGE OPERATIONS - GENERAL

Intentionally left blank

## DEFINITIONS

Ident.: PRO-SPO-40-20-00002031.0001001 / 23 JUN 15

Applicable to: ALL

For the purpose of EU-OPS 1-245 and FAR 121-161, Extended-Range Operations are those intended to be conducted over a route that contains a point beyond 60 min from an adequate airport at the selected one-engine-inoperative speed in still air and ISA (or prevailing delta ISA) conditions. An adequate airport is an airport which satisfies the aircraft performance requirements applicable at the expected landing weight, and sufficiently equipped to be safely used. In particular, at the anticipated time of use, it should be available and equipped with the necessary services, including ATC, weather information, nav aids and emergency services. An ETOPS (en-route) alternate airport is a confirmed adequate airport which satisfies the dispatch weather minima requirements for ceiling and visibility within the required validity period.

## AREA OF OPERATION

Ident.: PRO-SPO-40-20-00002032.0001001 / 21 MAR 17

Applicable to: ALL

The ETOPS area of operations is the airspace within which the distance to an ETOPS adequate airport is less than the ETOPS Max Diversion distance.

The ETOPS maximum diversion distance from an adequate airport must be determined for ISA (or prevailing delta ISA ) and no-wind conditions, taking into account aircraft performance with one engine inoperative and the remaining engine operating at MCT.

To determine the ETOPS maximum diversion distance from an adequate airport, the operator must define a One Engine Inoperative diversion speed for performance computation.

The same approved one-engine-inoperative diversion speed (*Refer to PER-OEI-GEN STRATEGY*) must be considered for :

- Establishing the area of operation,
- Calculating the single-engine fuel planning,
- Conducting the diversion in case of engine failure (conditions permitting).

The operator has to define an aircraft weight at diversion that is considered for the ETOPS Maximum Diversion Distance calculation. This aircraft weight can be taken as a representative but conservative value of the aircraft gross weight at the critical point of the route or at the various critical points of all the routes included in a given sector.

The approved one-engine-inoperative descent and cruise speed must be chosen so that the associated net flight path clears the en-route obstacles with the regulatory margin. However, a speed other than the approved one-engine-inoperative speed may be used as the basis for obstacle clearance as long as the fuel required with that speed is covered by the critical fuel scenario.

*Refer to PER-OEI-GEN STRATEGY* for these two one-engine-inoperative speeds.

When the one-engine-inoperative diversion speed is chosen, the maximum distance from a diversion airport, can be directly determined for different maximum diversion times, with the help of the tables provided in this section. The area of possible ETOPS operation can then be drawn on plotting charts. Another way to determine the maximum distance to a diversion airport is to read the one-engine-inoperative cruise TAS (for the reference gross weight and at the FL for best TAS ) in the cruise tables (*Refer to PER-OEI-GEN STRATEGY*) taking into consideration the appropriate speed strategy and the minimum altitude for clearing possible obstacles. The maximum distance the aircraft can travel to a diversion airport is this one-engine-inoperative-TAS multiplied by the maximum allowed diversion time granted to the operator.

Operators whose authorities require that an approved one-engine-inoperative speed be published in the Flight Manual must use this approved speed.

**M MEL**

Ident.: PRO-SPO-40-30-00002035.0001001 / 03 DEC 13

Applicable to: ALL

The M MEL has been approved taking into consideration the duration of the average ETOPS flight and the maximum diversion time granted to the airframe/engine combination.

The M MEL published by Airbus and approved by the EASA can be used to establish the airline MEL, which must be approved by the operator's national authorities.

This MEL will probably be adapted to the airline network, environment and organization.

Other determining parameters will be :

- The maximum and the average diversion times on the route.
- The equipment of the enroute alternates.
- The navigation and communication facilities.
- The average meteorological conditions.


**ETOPS FUEL SCENARIOS**

Ident.: PRO-SPO-40-30-00012899.0001001 / 23 JUN 15

Applicable to: ALL

According to EASA AMC20-6 rev 2 and FAA 121.646 for establishing the ETOPS critical fuel reserves, the operator must consider three diversion scenarios:

- Pressurization Failure + Engine Failure



- Pressurization Failure  
 Same Flight Profile as above, but all engines operating and Diversion Cruise Speed\* set to LRC.
- Engine Failure  
 Same Flight Profile as above, but standard descent speed and Diversion Cruise at the FL \*\* appropriate to gross engine out ceiling at the selected ETOPS diversion speed.
- FAA Fuel Requirements  
 For the first two scenarios, involving depressurization, the required block fuel must be calculated in accordance with the operator's ETOPS fuel policy and using the regulatory ETOPS critical fuel reserves *Refer to PRO-SPO-40-30 ETOPS Critical Fuel Reserves.*  
 Depending on the approved one-engine-inoperative speed selected for the single-engine diversion strategy, either of these two scenarios may result in the higher fuel requirement.  
 The scenario resulting in the higher fuel requirement is called the ETOPS critical fuel scenario, and the associated minimum block fuel requirement is the ETOPS critical fuel plan.  
 Note that, it is not necessary to calculate the 3rd scenario (engine failure), as this scenario is never critical, due to the higher diversion flight level.



**ETOPS CRITICAL FUEL RESERVES**

Ident.: PRO-SPO-40-30-00012901.0001001 / 23 JUN 15

Applicable to: ALL

For the computation of the ETOPS critical fuel reserves and of the complete ETOPS critical fuel planning according to EASA AMC 20-6 rev 2 and FAR 121.646, the diversion fuel must include the following fuel provisions:

- Fuel burn-off from the critical point to the end of descent at the alternate airport
- Fuel for 15 min of holding at 1 500 ft and green dot speed at the alternate
- Fuel for an instrument approach and landing
- Fuel to account for errors in wind forecasting (5 % wind speed factor on actual forecast wind speeds or 5 % fuel if actual forecast wind speeds are not used)
- Fuel to account for aircraft deterioration (use a demonstrated performance factor or 5 %)
- Fuel to account for any Configuration Deviation List (CDL ) or MEL item
- Fuel to account for Icing Effects (if forecast) for the critical mission
- Fuel to account for APU use (only for the one-engine-inoperative scenario, if APU is operative)

**WIND ERRORS**

A 5 % wind speed factor (i.e. an increment to headwind or a decrement to tailwind) on the actual forecast wind should be used to account for potential errors. However if the operator is not using the actual forecast wind based on a wind model acceptable to the certification authorities then 5 % of the fuel for the critical scenario is required as a reserve fuel.

**ICING**

The most critical scenario must be compensated for the greater of:

- A. The effect of airframe icing during 10 % of the time during which icing is forecast, including ice accumulation on unprotected surfaces, and the fuel used by engine and wing anti-ice during this period.
- B. Fuel for engine and wing anti-ice for the entire time during which icing is forecast.

*Note:* The ETOPS icing fuel reserve is always limited by (B)

Unless a reliable icing forecast is available, icing may be presumed to occur when the Total Air Temperature (TAT) is less than +10 °C, or if the outside air temperature is between 0 °C and -20 °C with a relative humidity of 55 % or more.

**APU**

Fuel consumption of 80 kg/h / or 176 lb/h (APU GEN ON, APU BLEED OFF).

In view of our experience, Airbus recommends that the operator includes a contingency fuel provision from departure to the Critical Point (CP), when computing the ETOPS critical fuel planning.

**ETOPS FUEL REQUIREMENTS**

Ident.: PRO-SPO-40-30-00012902.0001001 / 17 NOV 11

Applicable to: **ALL**

The operator must compare the entire ETOPS critical fuel planning for the ETOPS critical fuel scenario with the standard fuel planning computed in accordance with the company fuel policy and applicable operational requirements. The higher of the two fuel requirements must be considered as the minimum required block fuel for the flight.

**WEATHER MINIMA**

Ident.: PRO-SPO-40-30-00002046.0001001 / 23 JUN 15

Applicable to: **ALL**

Weather forecasts for en-route alternates must meet the operator's applicable weather minimum requirements.

This paragraph provides the applicable minima required by EASA (EU-OPS 1/AMC 20-6 rev. 2) and FAA (AC120-42B).

**A. EASA DISPATCH WEATHER MINIMA (EU-OPS 1/AMC 20-6 REV. 2)**

An airplane cannot be dispatched unless the meteorological forecasts at ETOPS en-route alternate airports meet the weather minima listed here for a period commencing at the earliest potential time of landing and ending one hour after the latest expected time of landing:

Approach Type	Min ETOPS Ceiling	Min ETOPS Visibility
Precision approach	DH /DA +200 ft	Authorised visibility +800 m
Non-Precision or Circling approach	MDH /MDA +400 ft	Authorised visibility +1 500 m
CAT II/CAT III approach	Specific approval required	Specific approval required

**B. FAA DISPATCH WEATHER MINIMA (AC 120-42B)**

An airplane cannot be dispatched unless the meteorological forecasts at ETOPS en-route alternate airports meet the weather minima listed here for a period commencing at the earliest potential time of landing and ending at the latest expected time of landing:

**PROCEDURES**  
**SPECIAL OPERATIONS**

EXTENDED RANGE OPERATIONS - DISPATCH CONSIDERATION

Approach Type	Min ETOPS Ceiling	Min ETOPS Visibility
Two or more instrument approaches	Higher of the two (M)DH /DA +200 ft	Higher of the two authorised visibility +800 m
Single Precision approach or Non-Precision approach or Circling approach	(M)DH /DA +400 ft	Authorised visibility +1 600 m
CAT II approach	300 ft	1 200 m or RVR1 200 m
CAT III approach	200 ft	800 m or RVR550 m



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

EXTENDED RANGE OPERATIONS - DISPATCH CONSIDERATION

Intentionally left blank

**DIVERSION DECISION MAKING**

Ident.: PRO-SPO-40-40-00002048.0001001 / 21 MAR 17

Applicable to: ALL

The technical criteria governing a re-routing or diversion decision can be classified into four categories, as follows :

- Loss of MNPS capability, before entering the MNPS area (as applicable).
- Weather minima at diversion airport(s) going below the company/crew en-route minima, before reaching the ETOPS Entry Point, or diversion airport(s) becoming unsuitable for any reason.
- Failure cases requiring a diversion to the nearest airport (cases leading to a LAND ASAP message on the ECAM and/or in the QRH).
- Failure cases resulting in increased fuel consumption, exceeding the available fuel reserves.

**Comments and Recommendations**

- Electrical generation

If one IDG fails, a diversion is required in case of :

- Blue hydraulic circuit low level, low pressure or overheat, or
- APU no start, or
- APU or APU generator inoperative, or
- Second IDG failure.

- Fuel system

Some failure cases may lead to fuel gravity feeding which implies flight at lower altitude or to some fuel being unusable. The flight crew's evaluation of the actual situation and the fuel remaining may lead to the decision that a diversion is required.

- Hydraulic system :

If low level, low pressure or overheat on blue hydraulic circuit, a diversion is required in case of :

- One IDG failure, or
- APU no start, or
- APU/APU GEN failure.

- APU :

If APU/APU GEN fails, a diversion is required in case of :

- Blue hydraulic circuit low level, low pressure or overheat, or
- One IDG failure.

**PROCEDURES**  
**SPECIAL OPERATIONS**

EXTENDED RANGE OPERATIONS - DIVERSION  
DURING EXTENDED RANGE OPERATIONS

**DIVERSION PERFORMANCE DATA**

Ident.: PRO-SPO-40-40-00002049.0001001 / 21 MAR 17

Applicable to: **ALL**

Chapter PER-OEI-GEN contains three single engine descent and cruise procedures:

1. The standard strategy,
2. The obstacle strategy,
3. Fixed speed strategies (ETOPS).

For ETOPS operations, any one of the above diversion strategies can be used provided that the selected strategy and speed schedule are used in :

- Establishing the area of operation (maximum diversion distance),
- Calculating the diversion fuel requirements for the single-engine ETOPS fuel scenario,
- Demonstrating the applicable obstacle clearance requirements (net flight path and net ceiling).

During the diversion, the flight crew is expected to use the planned speed schedule.

However, based on the evaluation of the actual situation, the pilot in command has the authority to deviate from this planned one-engine-inoperative speed.


**GUIDELINES FOR DIVERSION PROCEDURE**

Ident.: PRO-SPO-40-40-00002050.0001001 / 21 MAR 17

Applicable to: **ALL**

- Complete the related failure procedure,
- Inform ATC,
- Initiate the descent,
- Determine which en route alternate is the most suitable (per company procedure),
- Divert to the chosen en route alternate,
- Comply with the pre-planned diversion strategy and speed schedule, or adjust the speed schedule, as dictated by the evaluation of the actual situation.

**Note:** *For detailed guidelines and procedures for conducting the diversion (lateral and vertical navigation), Refer to DSC-22\_20-60-30 - How to Execute a Diversion.*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b> EXTENDED RANGE OPERATIONS - PROCEDURES</p>
---	---

**GENERAL**

Ident.: PRO-SPO-40-50-00002051.0001001 / 26 JUN 17  
**Applicable to: ALL**

For ETOPS flights, the flight crew must apply the below procedures, in addition to the SOP (refer to chapter PRO-NOR-SOP) and the ABNORMAL and EMERGENCY procedures (refer to chapter PRO-ABN).

**NORMAL PROCEDURES**

**Applicable to: ALL**  
 Ident.: PRO-SPO-40-50-A-00021794.0002001 / 26 JUN 17

**COCKPIT PREPARATION**

**FUEL**

Before each ETOPS flight, the flight crew must check that the fuel crossfeed valve is operating correctly :

FUEL X FEED ..... ON

*On the ECAM FUEL page, check that the fuel crossfeed valve is open (indication is inline green).*

FUEL X FEED..... OFF

*Check that the fuel crossfeed valve is closed.*

**ABNORMAL AND EMERGENCY PROCEDURES**

Ident.: PRO-SPO-40-50-00002053.0007001 / 21 MAR 17  
**Applicable to: ALL**

**ELECTRICAL EMERGENCY CONFIGURATION**

The flight crew must complete the ECAM procedure using the following:

**AIR CONDITIONING**

As cockpit and cabin temperature control is lost, it is recommended to open the cockpit door.

**PRESSURIZATION**

If one engine (or one bleed system) is failed, forward cargo ventilation must be closed to avoid CAB PR EXCESS CAB ALT from being triggered on the ECAM during descent or cruise.

## **FUEL**

As all fuel pumps are lost, the engines are fed by gravity. *Refer to GRVTY FUEL FEEDING Procedure.*

## **ENGINE ANTI-ICE**

Engine anti-ice valves are permanently open, although the ECAM memo ENG A. ICE is not displayed on the ECAM (except if the ENG A. ICE pushbutton is at ON).

## **WING ANTI-ICE**

If only one ENG BLEED is available, PACK 1 must be switched OFF, to avoid having both packs and wing anti-ice supplied by a single bleed source.

## **BLUE HYDRAULIC CIRCUIT LOW LEVEL OR LOW PRESSURE OR OVERHEAT**

Start the APU to ensure availability of the APU generator.

## **ENGINE OR IDG FAILURE**

Start the APU and use the APU electrical channel.



**GENERAL**

Ident.: PRO-SPO-40-60-00002054.0001001 / 25 AUG 15

**Applicable to: ALL**

The two following cases result in a fuel consumption increase:

- RAT extended
- In electrical emergency configuration, the engine anti-ice valves are permanently open.

**MAXIMUM DIVERSION DISTANCE**

Ident.: PRO-SPO-40-60-00002055.0035001 / 21 MAR 17

Applicable to: ALL



The following computation conditions have been used in accordance with the interpretation of the EU-OPS 1.245 and FAR 121.161:

- ISA conditions
- No wind
- Optimum diversion level after engine failure
- Single engine diversion speed schedule.

Note: Obstacles have not to be considered to determine if a route is or is not an ETOPS route.

**MAXIMUM DIVERSION DISTANCE**

SPEED SCHEDULE	A/C WEIGHT AT CRITICAL POINT (KG)	FL FOR DIVERSION	DIVERSION TIME (MIN)				
			60	90	120	150	180
<b>MCT /VMO</b>	50 000	160	414	616	818	-	-
	55 000	160	413	614	815	1 017	1 219
	60 000	160	412	612	812	1 012	1 213
	65 000	160	410	608	807	1 007	1 206
	70 000	160	408	605	802	1 000	1 198
	75 000	160	405	600	795	992	1 188
<b>MCT/320 kt</b>	50 000	160	412	613	814	-	-
	55 000	160	412	613	814	1 015	1 215
	60 000	160	412	612	812	1 012	1 213
	65 000	160	410	608	807	1 007	1 206
	70 000	160	408	605	802	1 000	1 198
	75 000	160	405	600	795	992	1 188

**ETOPS FUEL REQUIREMENT FROM CRITICAL POINT  
TO LANDING - ALL ENGINES - CRUISE AT LRC**


Ident.: PRO-SPO-40-60-00002056.0018001 / 21 MAR 17

Applicable to: ALL

Assumptions:

- EMER descent
- Long range cruise at FL 100
- Final descent 250 kt
- Holding 15 min at FL 15
- IFR procedure

Not included: 5 % correction on wind value - Anti icing if icing is forecast - performance factor.



**ETOPS FUEL REQUIREMENT FROM CRITICAL POINT  
TO LANDING - ONE ENGINE OUT - CRUISE AT 350KT**

Ident.: PRO-SPO-40-60-00002057.0017001 / 21 MAR 17


Applicable to: ALL

Assumptions:

- EMER descent
- Cruise 350 kt at FL 100
- Final descent 250 kt
- Holding 15 min at FL 15

- IFR procedure
- APU fuel burn.

Not included: 5 % correction on wind value - Anti icing if icing is forecast - performance factor.



**ETOPS FUEL REQUIREMENT FROM CRITICAL POINT  
 TO LANDING - ONE ENGINE OUT - CRUISE AT 320KT**

Ident.: PRO-SPO-40-60-00002058.0018001 / 21 MAR 17


Applicable to: ALL

Assumptions:

- EMER descent
- Cruise 320 kt at FL 100

- Final descent 250 kt
- Holding 15 min at FL 15
- IFR procedure
- APU fuel burn.

Not included: 5 % correction on wind value - Anti icing if icing is forecast - performance factor.



**ETOPS FUEL REQUIREMENT FROM CRITICAL POINT TO LANDING - EXAMPLE**

Ident.: PRO-SPO-40-60-00014769.0001001 / 21 MAR 17

Applicable to: ALL

*Note: The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in "kg", the same method can be applied for "lb".*

Assumptions:


- Aircraft weight at critical point: 65 000 kg
- Diversion speed: 320 kt
- Diversion time: 120 min
- Distance from Critical point to diversion airport: 700 NM
- Wind: 50 kt headwind
- Forecasted icing condition on diversion: 40 min
- Aircraft perf factor: 5 %

For the determination of the ETOPS fuel requirement, the greatest fuel quantity of the two following scenarios must be considered (the scenario Engine failure only, without pressurization failure, is never limiting):

1. Pressurization failure - One Engine Inoperative - 320 kt

- Determine the corrected wind for diversion taking into account the 5 % wind speed factor:  $50 \times 1.05 = 52.5$  kt
- Enter the ETOPS Fuel from Critical Point to Landing - One Engine Out - Cruise at 320kt graph to determine the corresponding fuel consumption: 6 900 kg

ETOPS FUEL FROM CRITICAL POINT TO LANDING - ONE ENGINE OUT - CRUISE AT 320KT




- Determine the final ETOPS fuel requirement, sum of perf factor fuel, icing fuel and fuel determined the step before:
  - Fuel for icing condition (Total anti-ice scenario is limiting):  $3.5\% \times 40 / 120 = 1.17\%$
  - Fuel for perf factor: 5 %
  - Final ETOPS fuel requirement:  $6\,900 \times 1.0117 \times 1.05 = 7\,330$  kg

2. Pressurization failure - All Engines Operative - LRC speed



- Determine the corrected wind for diversion taking into account the 5 % wind speed factor:  $50 \times 1.05 = 52.5$  kt
- Enter the ETOPS Fuel from Critical Point to Landing - All Engines - Cruise at LRC graph to determine the corresponding fuel consumption: 6 700 kg



- Determine the final ETOPS fuel requirement, sum of perf factor fuel, icing fuel and fuel determined the step before:
  - Fuel for icing condition (total anti-ice scenario is limiting):  $6\% \times 40 / 120 = 2\%$
  - Fuel for perf factor: 5 %
  - Final ETOPS fuel requirement:  $6\,700 \times 1.02 \times 1.05 = 7\,176$  kg

The final ETOPS fuel requirement for this diversion is 7 330 kg. The limiting scenario is a pressurization failure and One Engine Out at a diversion speed of 320 kt.

## ENGINE INTERMIX TYPE 1

Applicable to: ALL

Ident.: PRO-SPO-45-A-00002059.0001001 / 30 JUN 14

The following information provides the conditions and procedures necessary in order to temporarily operate an A318/A319/A320/A321 aircraft when a CFM56–5B Single Annular Combustor (SAC) engine is intermixed with a CFM56–5B Double Annular Combustor (DAC) engine.

This engine intermix configuration is indicated in the cockpit with the following placard: "CAUTION: ENGINE INTERMIX TYPE 1" or "CAUTION: ENGINE INTERMIX".

Ident.: PRO-SPO-45-A-00002060.0001001 / 07 DEC 10

### ENGINE PARAMETERS

Engine parameters differ significantly, when the engines are at idle:

- EGT : Up to 250 °C higher on the DAC engine.
- FUEL FLOW : Up to 25 % higher on the DAC engine.
- N1 : Higher on the DAC engine.
- N2 : Lower on ground on the DAC engine; higher in flight on the DAC engine.

Ident.: PRO-SPO-45-A-00002061.0001001 / 07 DEC 10

### CROSSBLEED ENG START

The DAC engine has insufficient acceleration capability to sustain idle speed with a large bleed offtake, when it operates with only 20 injectors. Therefore, it is necessary to preset a 30 % N1 on the supplying engine before launching the start sequence.

Ident.: PRO-SPO-45-A-00004068.0001001 / 07 DEC 10

### TAKEOFF PROCEDURE

- The PF must progressively adjust engine thrust in two steps:
  - Step 1 : Idle to 50 % N1.  
Brakes released, when the 50 % N1 is stabilized on both engines.
  - Step 2 : Both engines N1 to takeoff thrust.

This procedure enables a significantly slower acceleration from ground idle to N1 = 50 % for the double annular combustor.

- Other standard operating procedures apply for takeoff.

Ident.: PRO-SPO-45-A-00002062.0001001 / 07 DEC 10

### ENGINE RESPONSE


In flight, when the aircraft is in clean configuration, the DAC engine may accelerate from idle more slowly than the SAC engine. This is particularly evident, if the acceleration follows a deceleration.


There is no significant effect on aircraft handling. This difference in engine response disappears when the slats are extended.

Ident.: PRO-SPO-45-A-00004067.0001001 / 09 OCT 12

**ENGINE RELIGHT**

The DAC engine relight envelope is more restrictive than the SAC engine relight envelope. Therefore, in case of engine intermix, the flight crew must use the DAC engine relight procedure with the corresponding chart (See chart below).



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b> ENGINE INTERMIX OPERATIONS
---	--

## ENGINE INTERMIX TYPE 2

Applicable to: ALL

Ident.: PRO-SPO-45-B-00012731.0007001 / 06 MAR 17

The following information provides the necessary conditions and procedures in order to temporarily operate an A318/A319/A320/A321 with engine intermix configuration between two different SAC engines among CFM56–5Bx classic, the CFM56–5Bx/P, the CFM56-5Bx/3 and the CFM56-5Bx/P “TI HPC kit”.

FADEC intermix configuration 5BM software (installed on CFM56-5B classic) with FADEC 5BR software is indicated in the cockpit with the following placard: “CAUTION: ENGINE INTERMIX TYPE 2”.

*Note:* When FADEC Standard “5BR” or subsequent is installed on both engines, engine thrust behavior is harmonized (transient thrust dissymmetry no longer exist). Therefore, a placard is not necessary and is not displayed.

Ident.: PRO-SPO-45-B-00012732.0001001 / 07 DEC 10

### **ENGINE PARAMETERS**

In the case of only one operative pack configuration (only one pack OFF):

- N1 : At idle up to 9 % higher on the CFM56-5B/3 TI engine, on ground or in flight in clean configuration.
- N2 : At idle up to 11 % higher on the CFM56-5B/3 TI engine, on ground or in flight in clean configuration.

Ident.: PRO-SPO-45-B-00012733.0001001 / 07 DEC 10

### **TAKEOFF PROCEDURE**

In the case of only one operative pack configuration, due to the difference in N2 at idle between engines, the following takeoff procedure is recommended:

- The PF progressively adjusts engine thrust in two steps:
  - Step 1 : From idle to about 50 % N1 on brakes.
  - Step 2 : From both engines at similar N1 to takeoff thrust after brakes release.
- Other standard operative procedures apply for takeoff.

Ident.: PRO-SPO-45-B-00012734.0007001 / 14 MAY 12

### **ENGINE RESPONSE**

In the case of only one operative pack configuration, due to the difference in N2 at idle between engines, the CFM56–5B/3 TI engine may accelerate from idle to high thrust faster than the CFM56–5B/P SAC engine when the aircraft is on ground or in flight in clean configuration. There is no significant effect on aircraft handling.

The difference in engine response disappears in flight when the slats are extended.


*Note: Depending on the FADEC standard, the flight crew may observe a different deceleration between the two engines (CFM56-5B/P engine is faster to decelerate) when the aircraft is above FL 100 and in unsymmetrical bleed configuration or with the APU BLEED ON.*


Ident.: PRO-SPO-45-B-00016162.0010001 / 02 MAY 17

**ENGINE RELIGHT**

For SAC-TI engine the maximum altitude for the engine relight envelope is reduced, compared with the SAC engine relight envelope. Therefore, in case of engine intermix, the flight crew must use the SAC-TI engine relight envelope below.

Engine Relight Envelope



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b> REDUCED VERTICAL SEPARATION MINIMUM - RVSM
---	--

**GENERAL**

Ident.: PRO-SPO-50-00020828.0001001 / 17 MAR 17  
**Applicable to: ALL**

The A318/A319/A320/A321 aircraft systems are designed to comply with the design criteria of the EASA and FAA regulations (documents references provided in the AFM ) for the RVSM capability. In addition, operators must obtain an operational approval from their national airworthiness authorities, in order to operate within the RVSM airspace. The EASA and FAA regulations (documents references provided in the AFM) also indicate the requirements for obtaining operational approval.

**REQUIRED EQUIPMENTS/FUNCTIONS FOR RVSM**

Ident.: PRO-SPO-50-00020955.0002001 / 17 MAR 17  
**Applicable to: ALL**

RVSM regulations require the following equipment/functions in order to be operative:

- 2 ADR s + 2 DMCs
- 1 transponder
- 1 Autopilot function
- 1 FCU channel (for altitude target selection and OP CLB /OP DES mode engagement)
- 2 PFD functions (for altitude indication)
- 1 FWC (for altitude alert function).

**RVSM NORMAL PROCEDURE**

Ident.: PRO-SPO-50-00020830.0002001 / 17 MAR 17  
**Applicable to: ALL**

For flights in RVSM airspace, the flight crew must apply the standard procedures, in addition to the following RVSM procedures.

**FLIGHT PREPARATION**

The flight crew must take into account the conditions that may affect operations in RVSM airspace, including:

- RVSM APPROVAL..... CHECK
- L2** *Verify that the aircraft is approved for RVSM operations.*
- L1** WEATHER..... CHECK
- L2** *Review the weather forecasted for the flight route. If severe turbulence is expected, this may affect the ability to maintain aircraft altitude.*
- L1** REQUIRED EQUIPMENT FOR RVSM..... CHECK
- L2** *Check that the required equipment is operative (MEL).*

**PROCEDURES**  
**SPECIAL OPERATIONS**

REDUCED VERTICAL SEPARATION MINIMUM - RVSM

The flight crew should review the maintenance logs and forms, in order to ensure that the equipment required for RVSM is satisfactory.

**L1** ALTITUDES..... CHECK

**L2** Check that the difference between each altitude indication (in the QNH reference) displayed on PFDs and the airport elevation is less than 75 ft.

Check that the difference between the two primary altitude indications on the PFDs is less than the tolerance specified in SOP. Refer to PRO-NOR-SOP-06 Glareshield - EFIS Control Panel.

**L1** **IN FLIGHT**

**BEFORE ENTERING RVSM AIRSPACE**

REQUIRED EQUIPMENT FOR RVSM .....OPERATIVE

**L2** If any of the required equipment fails before the aircraft enters RVSM airspace, the flight crew must request new clearance, to avoid this airspace.

**L1** ALTITUDES..... CHECK

**L2** Check on the PFDs that the difference between altitude indications (in the standard baro setting) is less than the specified tolerance in the table below.

If only two ADR s are operative, the altimeter indications on PFD and standby altimeter should be recorded. This information may be useful in case of subsequent PFD altitude discrepancy, or loss of both remaining ADRs.

		Comparison of Altitude Indication (ft)		
Flight Level	Speed or Mach Number	Difference between ADR 1 and ADR 2 (on PFDs)	Difference between ADR 3 and ADR 1/2 (on PFDs)	Difference between STBY ALTI and ADRs
FL 50	250 kt	50 (15 m)	65 (20 m)	130 (40 m)
FL 100	250 kt	55 (17 m)	80 (24 m)	185 (56 m)
FL 200	300 kt	90 (27 m)	135 (41 m)	295 (90 m)
FL 300	M 0.78	130 (40 m)	195 (59 m)	390 (119 m)
FL 390	M 0.78	130 (40 m)	195 (59 m)	445 (136 m)

**IN RVSM AIRSPACE**

AP.....KEEP ENGAGED

**L2** Ensure that autopilot is engaged for cruise, and for flight level changes.


**L1** AP GUIDANCE..... MONITOR

**L2** During flight level transitions, do not exceed or go below the assigned flight level by more than 150 ft.

**L1** ● **Approximately every hour:**  
ALTITUDES.....CHECK

**L2** Check that the difference between the altitude indications on PFD s is less than the specified tolerance. For more information, See table in "Before Entering RVSM airspace".



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b></p> <p align="center">REDUCED VERTICAL SEPARATION MINIMUM - RVSM</p>
---	--

*Regular check of the flight deck instruments should be sufficient.*

**L1 AT THE END OF THE FLIGHT**

ANY MALFUNCTIONS or DEVIATIONS..... REPORT

- L2** *Report any malfunction of the systems that enable the aircraft to maintain altitude, including:*
- *Any malfunction or loss of required equipment*
  - *Any deviation involving the functions that enable the aircraft to maintain altitude.*

**RVSM ABNORMAL AND EMERGENCY PROCEDURE**

Ident.: PRO-SPO-50-00020831.0002001 / 17 MAR 17

**Applicable to: ALL**


ATC..... NOTIFY

*When the aircraft is in RVSM airspace, the flight crew must notify the ATC of the following situations, because they may affect the aircraft's ability to maintain the flight level:*

- *The failure of both autopilots*
- *The loss of altimeter system redundancy (only one PFD indication remaining)*
- *An excessive discrepancy in altitude indications, and no way to identify the valid indication*
- *The failure of any other equipment, that affects the aircraft's ability to maintain flight level*
- *The encounter of greater than moderate turbulence.*

*If the flight crew cannot notify the ATC or obtain the ATC clearance before deviating from the assigned flight level, they should follow the established contingency procedure and obtain the ATC clearance as soon as possible.*

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b></p> <p align="center">REQUIRED NAVIGATION PERFORMANCE (RNP)</p>
---	---

**GENERAL**

**Applicable to: ALL**

Ident.: PRO-SPO-51-A-00015857.0001001 / 20 MAR 17

**GENERAL**

The Performance Based Navigation (PBN ) concept implies that the aircraft follows the defined track with a requested navigation performance. The PBN includes RNAV and RNP operations. For RNAV and RNP operations, an operational approval from the airline's national authorities may be required.

The AFM provides regulatory compliances associated with PBN operations.

Ident.: PRO-SPO-51-A-00015859.0001001 / 09 SEP 14

**RNAV/RNP CAPABILITY**

Before the aircraft enters an RNAV /RNP airspace, RNAV /RNP capability is based on:

- The required RNAV /RNP equipment that is described in each RNAV /RNP section of the FCOM
- Navigation Accuracy HIGH displayed on the MCDU PROG page
- Any specific local requirements published in the Aeronautical Information Publication (AIP).

When the aircraft flies in RNAV /RNP airspace, RNAV /RNP capability is based on:

- Navigation Accuracy HIGH displayed on the MCDU PROG page
- Any specific local requirements published in the Aeronautical Information Publication (AIP).

**RNAV 10 / RNP 10**

**Applicable to: ALL**

Ident.: PRO-SPO-51-B-00015854.0001001 / 09 SEP 14

**GENERAL**

RNAV 10 operations correspond to RNP 10 operations.

In RNAV 10 airspace, the aircraft is expected to fly for a long period of time outside radio navaid coverage.

Ident.: PRO-SPO-51-B-00015855.0001001 / 09 SEP 14

**REQUIRED RNAV 10 EQUIPMENT**







The minimum navigation equipment required to enter RNAV 10 airspace is:

- Two FMGC s (or one FMGC and one BACK UP NAV ☞)
- Two MCDUs
- Two IRS

Ident.: PRO-SPO-51-B-00015863.0001001 / 11 APR 17

## **PROCEDURE**

### **MANAGEMENT OF DEGRADED NAVIGATION**

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST  on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
- **If the GPS PRIMARY LOST  message is displayed on both NDs/MCDUs, RNAV 10 operations can be continued:**
  - With no time restriction if radio navaids update is available
  - For 5.7 hr from the time of the last position update if radio navaids update is not available. After 5.7 hr, the navigation accuracy must be considered LOW regardless of the navigation accuracy that is displayed on the MCDU PROG page.
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should crosscheck the position data using the POSITION MONITOR page, the IRS 1(2)(3) pages, and the GPS MONITOR page  in order to identify which FMGC position is correct:**
  - FMS 1/FMS 2 POS DIFF
  - CHECK IRS 1(2)(3)/FM POSITION 
  - CHECK A/C POSITION 
  - NAV FM/GPS POS DISAGREE 

The flight crew should resume navigation with the FMGC that provides the correct position.

- **If NAV ACCUR DOWNGRAD is displayed on both sides:**
  - As per design FMS REQ ACCUR is set by default; this default value (e.g. 2 NM in cruise, 1 NM in terminal area) is more restrictive than overflown airspace required navigation performance.
  - Any change on FMS REQ ACCUR to be in accordance with airspace requirement is at flight crew's discretion; and should be set back to default value when leaving intended airspace.

If NAV ACCUR DOWNGRAD remains displayed, the flight crew should inform ATC that the RNAV 10 capability is lost.

## RNAV 5 / BRNAV

Applicable to: ALL

Ident.: PRO-SPO-51-C-00015851.0001001 / 20 MAR 17

### GENERAL

RNAV 5 operations correspond to European BRNAV operations.

Ident.: PRO-SPO-51-C-00015852.0001001 / 06 JUL 17

### REQUIRED RNAV 5 EQUIPMENT






The minimum navigation equipment required to enter RNAV 5 airspace is:

- One FMGC
- One MCDU
- One GPS or one DME receiver to update FM position
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side)
- One IRS.

Ident.: PRO-SPO-51-C-00015864.0001001 / 11 APR 17

### PROCEDURE

#### MANAGEMENT OF DEGRADED NAVIGATION

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST  on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should check the navigation accuracy with navaid raw data via the MCDU PROG page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST  on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF
  - CHECK IRS 1(2)(3)/FM POSITION 
  - CHECK A/C POSITION 
  - NAV FM/GPS POS DISAGREE 

The flight crew should resume navigation with the FMGC that provides the correct position.

● **If NAV ACCUR DOWNGRAD is displayed on both sides:**

- As per design FMS REQ ACCUR is set by default; this default value (e.g. 2 NM in cruise, 1 NM in terminal area) is more restrictive than overflow airspace required navigation performance.
- Any change on FMS REQ ACCUR to be in accordance with airspace requirement is at flight crew's discretion; and should be set back to default value when leaving intended airspace.

If NAV ACCUR DOWNGRAD remains displayed, the flight crew should inform ATC that the RNAV 5 capability is lost.

**RNAV 1 RNAV 2 / P-RNAV - TERMINAL RNAV**

Applicable to: ALL

Ident.: PRO-SPO-51-D-00015848.0001001 / 20 MAR 17

**GENERAL**

RNAV 1(2) operations correspond to P-RNAV TERMINAL RNAV operations.  
The AIP may specify that GPS equipment is required.

Ident.: PRO-SPO-51-D-00015849.0001001 / 06 JUL 17

**REQUIRED RNAV 1(2) EQUIPMENT**

The minimum navigation equipment required to enter RNAV 1/RNAV2 airspace is:

- One FMGC
- One MCDU
- One GPS or one DME receiver to update the FM position
- Two IRS
- One FD in NAV mode
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side).

Ident.: PRO-SPO-51-D-00015865.0001001 / 20 MAR 17






**PROCEDURE**

**BEFORE ENTERING RNAV 1(2) AIRSPACE**

The FMS navigation database provides the terminal procedure (RNAV SID , RNAV STAR , RNAV TRANSITION, etc.) of the flight plan. The flight crew must crosscheck the terminal procedure from the published charts with the FMS navigation database on the F-PLN page (waypoint sequences, tracks, distances, and altitude or speed constraints). The flight crew must

not modify the procedure that is provided by the navigation database, unless required by the ATC (DIR TO, radar vectoring, insertion of waypoints from the navigation database).

### MANAGEMENT OF DEGRADED NAVIGATION

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST  on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
  
- **If one of the following messages is displayed, the flight crew should check the navigation accuracy with navaid raw data via the MCDU PROG page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST  on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF
  - CHECK IRS 1(2)(3)/FM POSITION 
  - CHECK A/C POSITION 
  - NAV FM/GPS POS DISAGREE 

The flight crew should resume navigation with the FMGC that provides the correct position.

- **If NAV ACCUR DOWNGRAD is displayed on both sides:**

The flight crew should inform the ATC that the RNAV 1(2) capability is lost.

## RNP 4

Applicable to: ALL

Ident.: PRO-SPO-51-E-00015845.0001001 / 09 SEP 14


### GENERAL

In this airspace, the aircraft is expected to fly for a long period of time outside radio navaid coverage.

Ident.: PRO-SPO-51-E-00015846.0001001 / 09 SEP 14

### REQUIRED RNP 4 EQUIPMENT

The minimum navigation equipment required to enter RNP 4 airspace is:



- Two FMGC s (or one FMGC and one BACK UP NAV 
- Two MCDUs
- Two IRS

- One GPS
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side).

Ident.: PRO-SPO-51-E-00015866.0001001 / 11 APR 17

## PROCEDURE

### MANAGEMENT OF DEGRADED NAVIGATION

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should crosscheck the position data using the POSITION MONITOR page, the IRS 1(2)(3) pages, and the GPS MONITOR page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF
  - CHECK IRS 1(2)(3)/FM POSITION 
  - CHECK A/C POSITION 
  - NAV FM /GPS POS DISAGREE

The flight crew should resume navigation with the FMGC that provides the correct position.

- **If NAV ACCUR DOWNGRAD is displayed on both sides:**
  - As per design FMS REQ ACCUR is set by default; this default value (e.g. 2 NM in cruise, 1 NM in terminal area) is more restrictive than overflown airspace required navigation performance.
  - Any change on FMS REQ ACCUR to be in accordance with airspace requirement is at flight crew's discretion; and should be set back to default value when leaving intended airspace.

If NAV ACCUR DOWNGRAD remains displayed, the flight crew should inform ATC that the RNAV 4 capability is lost.



## **RNP 2 IN OCEANIC AND REMOTE CONTINENTAL AREA**

Applicable to: ALL

Ident.: PRO-SPO-51-I-00021541.0001001 / 20 MAR 17


### **GENERAL**

In this airspace, the aircraft is expected to fly for a long period of time outside radio navaid coverage.

Ident.: PRO-SPO-51-I-00021542.0001001 / 20 MAR 17

### **REQUIRED RNP 2 IN OCEANIC AND REMOTE CONTINENTAL AREA EQUIPMENT**

The minimum navigation equipment required to enter RNP 2 oceanic and remote continental airspace is:

- Two FMGC s (or one FMGC and one BACK UP NAV )
- Two MCDUs
- Two IRS
- One GPS
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side).

Ident.: PRO-SPO-51-I-00021544.0001001 / 20 MAR 17

### **PROCEDURE**



#### **FLIGHT PREPARATION**

RAIM /AIME availability should be confirmed for RNP 2 in oceanic and remote continental area operations.

*Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed)*

#### **MANAGEMENT OF DEGRADED NAVIGATION**

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should crosscheck the position data using the POSITION MONITOR page, the IRS 1(2)(3) pages, and the GPS MONITOR page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF

- CHECK IRS 1(2)(3)/FM POSITION 
- CHECK A/C POSITION 
- NAV FM /GPS POS DISAGREE

The flight crew should resume navigation with the FMGC that provides the correct position.

- **If NAV ACCUR DOWNGRAD is displayed on both sides:**

The flight crew should inform the ATC that the RNP 2 capability is lost.

### RNP 2 IN DOMESTIC AREA

Applicable to: ALL

Ident.: PRO-SPO-51-J-00021545.0001001 / 20 MAR 17

#### REQUIRED RNP 2 IN DOMESTIC AREA EQUIPMENT

The minimum navigation equipment required to enter RNP 2 domestic airspace is:

- One FMGC
- One MCDU
- One GPS
- Two IRS
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side).

Ident.: PRO-SPO-51-J-00021546.0001001 / 20 MAR 17



#### PROCEDURE




##### **FLIGHT PREPARATION**

RAIM /AIME availability should be confirmed for RNP 2 in domestic area operations.

*Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed)*

##### **MANAGEMENT OF DEGRADED NAVIGATION**

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST  on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should check the navigation accuracy with navaid raw data via the MCDU PROG page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST  on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF

- CHECK IRS 1(2)(3)/FM POSITION 
- CHECK A/C POSITION 
- NAV FM/GPS POS DISAGREE 

The flight crew should resume navigation with the FMGC that provides the correct position.

● **If NAV ACCUR DOWNGRAD is displayed on both sides:**

The flight crew should inform the ATC that the RNP 2 capability is lost.

**RNP 1 / TERMINAL RNP 1- BASIC RNP 1**

Applicable to: ALL

Ident.: PRO-SPO-51-F-00015842.0001001 / 20 MAR 17

**GENERAL**

RNP 1 operations correspond to RNP 1 Terminal operations.

Ident.: PRO-SPO-51-F-00015843.0001001 / 17 MAR 16

**REQUIRED RNP 1 EQUIPMENT**

The minimum navigation equipment required to enter RNP 1 airspace is:

- One FMGC
- One MCDU
- One GPS
- Two IRS
- One FD in NAV mode
- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on one side).

Ident.: PRO-SPO-51-F-00015867.0001001 / 20 MAR 17

**PROCEDURE**

**FLIGHT PREPARATION**

RAIM/AIME availability should be confirmed for RNP 1 operations.






*Refer to PRO-NOR-SOP-02 GPS PRIMARY Availability (If Installed)*

**BEFORE ENTERING RNP 1 AIRSPACE**

The FMS navigation database provides the terminal procedure (RNAV SID , RNAV STAR , RNAV TRANSITION, etc.) of the flight plan. The flight crew must check the terminal procedure from the published charts with the FMS navigation database on the F-PLN page (waypoint sequences, tracks, distances, and altitude or speed constraints). The flight crew must not

modify the procedure that is provided by the navigation database, unless required by the ATC (DIR TO, radar vectoring, insertion of waypoints from the navigation database).

### MANAGEMENT OF DEGRADED NAVIGATION

- **If one of the following messages is displayed, the flight crew should resume navigation with the FMGC that provides the correct position:**
  - GPS PRIMARY LOST  on one ND /MCDU
  - NAV ACCUR DOWNGRAD on one ND /MCDU.
  
- **If one of the following MCDU or ECAM messages is displayed, the flight crew should check the navigation accuracy with navaid raw data via the MCDU PROG page in order to identify which FMGC position is correct:**
  - GPS PRIMARY LOST  on both ND s/MCDUs
  - FMS 1/FMS 2 POS DIFF
  - CHECK IRS 1(2)(3)/FM POSITION 
  - CHECK A/C POSITION 
  - NAV FM/GPS POS DISAGREE 

The flight crew should resume navigation with the FMGC that provides the correct position.

- **If NAV ACCUR DOWNGRAD is displayed on both sides:**

The flight crew should inform the ATC that the RNP 1 capability is lost.

## RNP APCH / RNAV(GNSS)

Applicable to: ALL

Ident.: PRO-SPO-51-G-00015839.0001001 / 20 MAR 17

### GENERAL

RNP APCH operations correspond to RNAV (GNSS ) or RNAV (GPS) operations.

Ident.: PRO-SPO-51-G-00015840.0001001 / 11 JUL 17

### REQUIRED RNP APCH EQUIPMENT

The minimum equipment required to start RNP APCH operations is:

- One FMGC
- One GPS
- Two IRS
- One MCDU
- One FD
- One PFD on the PF side

- Two ND s (the temporary display of ND information via the PFD /ND switch is permitted on PM side)
- Two FCU channels.

Ident.: PRO-SPO-51-G-00015868.0001001 / 09 SEP 14

## **PROCEDURE**

*Refer to PRO-NOR-SOP-18-C Approach using FINAL APP Guidance - General*

*Refer to PRO-NOR-SOP-18-C Approach using FPA Guidance - General*




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

REQUIRED NAVIGATION PERFORMANCE (RNP)

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b> OPERATIONS ON NARROW RUNWAYS
---	--

**GENERAL**

Ident.: PRO-SPO-60-00002094.0002001 / 03 JAN 11  
**Applicable to: ALL**

This chapter gives the limitations, procedures and performance for operations from/to runways with a width below 45 m .  
 This chapter does not constitute an operational approval to operate on narrow runways.  
 Such authorization must be obtained by the operator from the appropriate authorities.

**LIMITATIONS**

Ident.: PRO-SPO-60-00006122.0002001 / 21 MAR 17  
**Applicable to: ALL**

Minimum runway width.....30 m

The dispatch from/to narrow runways is not allowed in case of :

- Nose wheel steering inoperative
- One brake or more inoperative

Autoland is not allowed.

**PROCEDURES**

Ident.: PRO-SPO-60-00006123.0003001 / 21 MAR 17  
**Applicable to: ALL**

Diversion to a 45 m wide runway is recommended in case of :

- Rudder jam
- Rudder pedal jam
- Yaw damper system fault
- Rudder Travel Limit system fault
- All failures leading to the loss of the nose wheel steering (HYD Yellow system loss, double hydraulic failure, double BSCU fault, double LGCIU fault)

Maximum demonstrated crosswind for takeoff and landing:

Dry runway.....38 kt (gust included) for takeoff and landing  
 Wet runway.....33 kt (gust included) for takeoff and landing  
 Contaminated runway..... 10 kt (gust included) for takeoff and landing

Note: *These maximum demonstrated crosswind values are based on the assumption that the crew have been trained accordingly.*

Operations on icy runways have not been demonstrated.

**PROCEDURES**  
**SPECIAL OPERATIONS**

OPERATIONS ON NARROW RUNWAYS

**PERFORMANCE**

Ident.: PRO-SPO-60-00006124.0001001 / 23 JUN 15

Applicable to: ALL

For runways with a width above or equal to 40 m ., the basic takeoff performance remains unchanged.

For runways with a width below 40 m , the VMCG must be increased by the values indicated in the following table :

Runway Width	30 m	35 m	40 m
Δ VMCG(kt)	+ 2.5	+ 1.5	+ 0


No correction is required, when takeoff performance is determined by using the applicable approved data.

The minimum V1 values, published in the *Refer to PER-TOF-TOD-25-10 SPEEDS LIMITED BY VMCG/VMCA*, must be increased by 3 kt .

When using the takeoff performance for contaminated runways *Refer to PER-TOF-CTA-10 GENERAL*, the resulting V1 must be crosschecked with the corrected minimum V1.

Further decrease the takeoff weight by 3 t per knot increase in V1.



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PROCEDURES</b> <b>SPECIAL OPERATIONS</b>  ILS PRM APPROACH
---	--

**OVERVIEW**

Ident.: PRO-SPO-85-00020844.0001001 / 17 MAR 17  
**Applicable to: ALL**

The Precision Runway Monitor (PRM) system enables simultaneous close parallel ILS approaches. The air traffic controllers use the PRM system to monitor the aircraft position. If necessary, the ATC orders a break out, turn and climb or descent.

To perform PRM operations:

- The air traffic controllers and the flight crew must satisfy specific training requirements
- The ATC and the aircraft equipment must comply with specific requirements.

**BREAK OUT TURN AND CLIMB PROCEDURE**

Ident.: PRO-SPO-85-00020845.0001001 / 17 MAR 17  
**Applicable to: ALL**

Simultaneously:

AP..... OFF  
 BREAK OUT LEFT(RIGHT), HDG\_\_\_, ALT..... ANNOUNCE  
 THRUST LEVERS..... TOGA, and back to CL

- [L2]** *The SRS GA and the GA TRK modes engage. The THR CLB mode engages. The speed is managed. The speed target is the aircraft speed at SRS GA engagement. The FMS GO-AROUND phase becomes active. Therefore, the FMS reinserts the approach.*

**[L1]** TURN LEFT(RIGHT) AND CLIMB

- [L2]** *As the situation is urgent, the flight crew should temporarily disregard the FD orders.*

Then

**[L1]** HDG..... TURN AND PULL

- [L2]** *The GA TRK mode disengages, and the HDG mode engages.*

**[L1]** ALT.....TURN AND PULL

- [L2]** *The SRS GA mode disengages, and the OP CLB mode engages. The speed target becomes the FMS speed target of the CLIMB phase.*

**[L1]** SPEED.....PULL AND ADJUST

- [L2]** *For the initial break out procedure, adjust the speed (e.g. 160 kt), in order to avoid a significant acceleration, and an increase in workload.*

**[L1]** ● **When established on the break out path:**

AP.....ON

- [L2]** *Before engaging the AP , ensure that the FD bar orders correspond to the aircraft current path.*

- L1 SPEED.....SELECT AS RQRD
- FLAPS.....AS RQRD
- GEAR.....AS RQRD
- TCAS MODE SEL.....TA/RA AS RQRD

**BREAK OUT TURN AND DESCENT PROCEDURE**

Ident.: PRO-SPO-85-00020846.0001001 / 17 MAR 17

Applicable to: ALL

Simultaneously:

AP..... OFF  
TURN LEFT(RIGHT) AND MAINTAIN RATE OF DESCENT  
BREAK OUT LEFT(RIGHT), HDG \_\_, ALT..... ANNOUNCE

- L2 *As the situation is urgent, the flight crew should temporarily disregard the FD orders.*

Then

- L1 HDG..... TURN AND PULL

- L2 *The HDG mode engages. The vertical mode reverts to the V/S mode. The vertical speed target is the aircraft vertical speed at V/S engagement.*

- L1 ALT.....TURN AND PULL

- L2 *This action defines an altitude target. The OP DES mode and the THR IDLE mode engage. The speed target does not change.*

- L1 V/S.....MONITOR

**CAUTION** Depending on the speed target, the vertical speed may become excessive. If the rate of descent exceeds 1 000 ft/min, engage the V/S mode and limit the rate of descent to 1 000 ft/min.

● **When established on the break out path:**

AP.....ON

- L2 *Before engaging the AP, ensure that the FD bar orders correspond to the aircraft current path.*

- L1 ● **When cleared by ATC:**

ALT..... TURN

- L2 *Select an altitude target for go-around, in accordance with the ATC clearance.*

- L1 THRUST LEVERS..... TOGA, and back to CL

- L2 *The SRS GA and the GA TRK modes engage. The THR CLB mode engages.  
The speed is managed. The speed target is the aircraft speed at SRS GA engagement.  
The FMS GO-AROUND phase becomes active.*



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

ILS PRM APPROACH

- L1 HDG.....PULL
- L2 *The GA TRK mode disengages, and the HDG mode engages. The SRS GA mode remains engaged, until ALT\* engagement.*
- L1 SPEED.....SELECT AS RQRD
- FLAPS.....AS RQRD
- GEAR.....AS RQRD
- TCAS MODE SEL.....TA/RA AS RQRD



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PROCEDURES**  
**SPECIAL OPERATIONS**

ILS PRM APPROACH

Intentionally left blank

# LIMITATIONS

Intentionally left blank

**LIM-INT Introduction**

**LIM-AG Aircraft General**

**LIM-AIR Air Bleed/Cond/Press/Vent**

**LIM-AFS Auto Flight System**

**LIM-APU Auxiliary Power Unit**

**LIM-CAB Cabin Systems**

**LIM-COM Communication**

**LIM-ENG Engines**

**LIM-F\_CTL Flight Controls**

**LIM-FUEL Fuel**

**LIM-ICE\_RAIN Ice and Rain Protection**

**LIM-LG Landing Gear**

**LIM-NAV Navigation**

**LIM-OXY Oxygen**

**LIM-SURV Surveillance**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**PRELIMINARY PAGES**  
TABLE OF CONTENTS

Intentionally left blank



<b>M</b> <sup>(1)</sup>	<b>Localization</b>	<b>DU Title</b>	<b>DU identification</b>	<b>DU date</b>
	LIM-AFS-20 Criteria: A320 <b>Applicable to: ALL</b> <i>Impacted DU: NONE</i>	<b>Automatic Landing in Johannesburg</b>	00013685.0001001	25 APR 13
	LIM-AFS-20 Criteria: P10660, P3510, P3790, P4087, P4419, P4425, P6125, P6985, P7397, P9333, SA <b>Applicable to: ALL</b> <i>Impacted DU: NONE</i>	<b>Autoland Databases with Honeywell ADIRU</b>	00016880.0070001	25 NOV 15

(1) Evolution code : N=New, R=Revised, E=Effectivity



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

Intentionally left blank

**LIMITATIONS**

INTRODUCTION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**INTRODUCTION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Introduction.....A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**INTRODUCTION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**INTRODUCTION**

**INTRODUCTION**

Ident.: LIM-INT-00019839.0001001 / 04 SEP 17

**Applicable to: ALL**

This FCOM chapter contains operational limitations, related to the aircraft and associated systems. All references to airspeed, Mach and altitude relate to indicated airspeed, indicated Mach, and pressure altitude, unless otherwise noted.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**INTRODUCTION**

Intentionally left blank



# **LIMITATIONS**

AIRCRAFT GENERAL

Intentionally left blank

**LIM-AG-F\_CTL Flight Maneuvering Load Acceleration Limits**

Flight Maneuvering Load Acceleration Limits..... A

**LIM-AG-OPS Operational Parameters**

Environmental Envelope..... A

Airport Operations and Wind Limitations..... B

**LIM-AG-SPD Speeds**

Cockpit Window Open Maximum Speed..... A

Maximum Flaps/Slats Speeds..... B

Maximum Operating Speed VMO/MMO..... C

Maximum Speeds with the Landing Gear Extended..... D

Maximum Tire Speed..... E

Minimum Control Speeds..... F

Taxi Speed..... G

Wipers Maximum Operating Speed..... H

**LIM-AG-WGHT Weights**

Weight Limitations..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### AIRCRAFT GENERAL

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**LIMITATIONS**  
**AIRCRAFT GENERAL**

FLIGHT MANEUVERING LOAD ACCELERATION LIMITS

**FLIGHT MANEUVERING LOAD ACCELERATION LIMITS**

Ident.: LIM-AG-F\_CTL-00020793.0001001 / 17 MAR 17

Applicable to: ALL

Clean configuration.....-1 g to +2.5 g  
 Other configurations..... 0 g to +2 g

**LIMITATIONS**

**AIRCRAFT GENERAL**


FLIGHT MANEUVERING LOAD ACCELERATION LIMITS

Intentionally left blank

**ENVIRONMENTAL ENVELOPE**

Ident.: LIM-AG-OPS-00021818.0043001 / 19 JUL 17

Applicable to: ALL



**AIRPORT OPERATIONS AND WIND LIMITATIONS**

Applicable to: ALL

Ident.: LIM-AG-OPS-ARPT\_WIND-00020145.0001001 / 17 MAR 17

**RUNWAY SLOPE**

Runway slope (mean)..... ±2 %



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**LIMITATIONS**  
**AIRCRAFT GENERAL**  
**OPERATIONAL PARAMETERS**

Ident.: LIM-AG-OPS-ARPT\_WIND-00020135.0009001 / 17 MAR 17

**RUNWAY ALTITUDE**

Runway altitude..... 14 100 ft

Ident.: LIM-AG-OPS-ARPT\_WIND-00020146.0002001 / 17 MAR 17

**NOMINAL RUNWAY WIDTH**

Nominal runway width..... 45 m

Minimal runway width..... 30 m

Ident.: LIM-AG-OPS-ARPT\_WIND-00020148.0001001 / 17 MAR 17

**WIND FOR TAKEOFF AND LANDING**

Maximum demonstrated crosswind (takeoff and landing)..... 38 kt (gust included)

- Note:**
- *The maximum demonstrated crosswind value is not an Airplane Flight Manual (AFM) limitation : It is the maximum crosswind condition experienced during the aircraft certification campaign.*
  - *Airbus recommends that operators should not intentionally operate in crosswinds that exceed this value.*

Ident.: LIM-AG-OPS-ARPT\_WIND-00020157.0003001 / 17 MAR 17

**TAILWIND TAKEOFF**

Maximum tailwind for takeoff..... 15 kt

Ident.: LIM-AG-OPS-ARPT\_WIND-00020159.0003001 / 21 MAR 17

**TAILWIND LANDING**


Maximum tailwind for landing ..... 15 kt

- Note:** *For maximum tailwind for automatic landing and rollout, Refer to LIM-AFS-20 Maximum Wind Conditions for ILS/MLS (If Installed) CAT II or CAT III and for GLS (If Installed) CAT I.*

Ident.: LIM-AG-OPS-ARPT\_WIND-00020168.0002001 / 22 MAR 17

- Note:** *For landing with a tailwind greater than 10 kt, use FLAPS FULL only.*



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>AIRCRAFT GENERAL</b> OPERATIONAL PARAMETERS
---	---

Ident.: LIM-AG-OPS-ARPT\_WIND-00020166.0001001 / 04 JUL 17

### PASSENGER AND CARGO DOORS OPERATION

The following are the wind limitations for passenger and cargo doors operation:

- The maximum wind for passenger door operation is 65 kt
- The maximum wind for FWD and AFT cargo door operation is 40 kt (or 50 kt, if the aircraft nose is into the wind, or if the FWD and AFT cargo doors are on the leeward side)
- The FWD and AFT cargo doors must be closed before the wind speed exceeds 65 kt.

Ident.: LIM-AG-OPS-ARPT\_WIND-00020046.0003001 / 17 MAR 17

### MAXIMUM RECOMMENDED CROSSWIND ON WET AND CONTAMINATED RUNWAYS

Runway Surface Conditions		Maximum Crosswind for Takeoff (Gust included)	Maximum Crosswind for Landing (Gust included)
Runway State or / and Runway Contaminant	ESF <sup>(1)</sup> or PIREP <sup>(2)</sup>		
<b>Damp</b> <b>Wet</b> Up to 3 mm (1/8") of water <b>Slush</b> Up to 3 mm (1/8") <b>Dry snow</b> Up to 3 mm (1/8") <b>Wet snow</b> Up to 3 mm (1/8") <b>Frost</b>	<b>Good</b>	38 kt	38 kt
<b>Compacted snow</b> OAT at or below -15 °C	<b>Good to Medium</b>	29 kt	29 kt
<b>Dry snow</b> More than 3 mm (1/8"), up to 100 mm (4") <b>Wet snow</b> More than 3 mm (1/8"), up to 30 mm (6/5") <b>Compacted snow</b> OAT above -15 °C <b>Dry snow over compacted snow</b> <b>Wet snow over compacted snow</b> <b>Slippery when wet</b>	<b>Medium</b>	25 kt	25 kt
<b>Water</b> More than 3 mm (1/8"), up to 12.7 mm (1/2") <b>Slush</b> More than 3 mm (1/8"), up to 12.7 mm (1/2")	<b>Medium to Poor</b>	20 kt	20 kt
<b>Ice (cold &amp; dry)</b>	<b>Poor</b>	15 kt	15 kt

(1) *ESF: Estimated Surface Friction*

(2) *PIREP: Pilot Report of Braking Action*


*Note: The maximum crosswind values given in the above table are recommended values based on computations.*

Ident.: LIM-AG-OPS-ARPT\_WIND-00014451.0001001 / 22 MAY 12

### **TAKEOFF LIMITATIONS ON CONTAMINATED RUNWAYS**

Takeoff is not recommended on the following runway conditions:

- Wet ice
- Water on top of Compacted Snow
- Dry Snow or Wet Snow over Ice

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>AIRCRAFT GENERAL</b>  SPEEDS
---	---

**COCKPIT WINDOW OPEN MAXIMUM SPEED**

Ident.: LIM-AG-SPD-00001904.0001001 / 17 MAR 17  
**Applicable to: ALL**

Maximum speed.....200 kt

**MAXIMUM FLAPS/SLATS SPEEDS**


Ident.: LIM-AG-SPD-00020087.0001001 / 17 MAR 17  
**Applicable to: ALL**

Flaps Lever Position	Configuration on Slat/Flap Display	Max Speed	Flight Phase
0		VMO /MMO	CRUISE
1	1	230 kt	HOLDING
	1 + F	215 kt	TAKEOFF
2	2	200 kt	TAKEOFF/APPROACH
3	3	185 kt	TAKEOFF/APPROACH/LANDING
FULL	FULL	177 kt	LANDING

**MAXIMUM OPERATING SPEED VMO/MMO**

Ident.: LIM-AG-SPD-00019991.0002001 / 17 MAR 17  
**Applicable to: ALL**

VMO..... 350 kt  
 MMO..... M 0.82



**MAXIMUM SPEEDS WITH THE LANDING GEAR EXTENDED**

Ident.: LIM-AG-SPD-00001901.0001001 / 17 MAR 17

Applicable to: ALL

- Maximum speed with the landing gear extended (VLE).....280 kt /M 0.67
- Maximum speed at which the landing gear may be extended (VLO extension) ..... 250 kt /M 0.60
- Maximum speed at which the landing gear may be retracted (VLO retraction) ..... 220 kt /M 0.54

**MAXIMUM TIRE SPEED**

Ident.: LIM-AG-SPD-00001902.0001001 / 17 MAR 17

Applicable to: ALL

- Maximum ground speed..... 195 kt

**MINIMUM CONTROL SPEEDS**

Ident.: LIM-AG-SPD-00020161.0015001 / 17 MAR 17


Applicable to: ALL

**MINIMUM CONTROL SPEED FOR LANDING (VMCL)**

- VMCL..... 113 kt

**MINIMUM CONTROL SPEEDS IN THE AIR (VMCA ) AND ON THE GROUND (VMCG)**

Altitude (ft)	VMCA (kt IAS)	VMCG (kt IAS)		
		CONF 1 + F	CONF 2	CONF 3
-2 000	112	112	110	109
0	110	111	109	109
2 000	108	109	107	107
4 000	108	109	107	107
6 000	107	108	106	105
8 000	104	105	103	103
10 000	100	101	99	99
12 000	97	99	97	96
14 100	94	95	93	93

When the Thrust Bump  is used, consider the following VMCA / VMCG:

Altitude (ft)	VMCA (kt IAS)	VMCG (kt IAS)		
		CONF 1 + F	CONF 2	CONF 3
-2 000	111	112	110	109
0	110	111	109	109
2 000	108	109	107	107
4 000	108	109	107	107
6 000	108	109	107	106
8 000	105	106	104	104
10 000	102	103	101	101
12 000	99	100	98	97
14 100	95	97	95	95

**TAXI SPEED**

Ident.: LIM-AG-SPD-00019838.0001001 / 17 MAR 17

Applicable to: ALL

- When the taxi weight is higher than 76 000 kg (167 550 lb):


**CAUTION** Do not exceed a taxi speed of 20 kt during a turn.

**WIPERS MAXIMUM OPERATING SPEED**

Ident.: LIM-AG-SPD-00001903.0001001 / 17 MAR 17

Applicable to: ALL

Maximum speed.....230 kt

 **Note:** This limitation is applicable when the wipers are sweeping. It is not applicable if the wipers are not sweeping for any reasons.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**AIRCRAFT GENERAL**  
SPEEDS

Intentionally left blank



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**LIMITATIONS**  
**AIRCRAFT GENERAL**  
 WEIGHTS

**WEIGHT LIMITATIONS**

Ident.: LIM-AG-WGHT-00001893.0268001 / 18 MAR 11

**Applicable to: ALL**

Maximum taxi weight.....	77 400 kg (170 637 lb)
Maximum takeoff weight (brake release).....	77 000 kg (169 755 lb)
Maximum landing weight.....	66 000 kg (145 505 lb)
Maximum zero fuel weight.....	62 500 kg (137 788 lb)
Minimum weight.....	37 230 kg (82 079 lb)

In exceptional cases (in flight turn back or diversion), an immediate landing at weight above maximum landing weight is permitted, provided the pilot follows the overweight landing procedure.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**AIRCRAFT GENERAL**  
WEIGHTS

Intentionally left blank



# **LIMITATIONS**

AIR BLEED/COND/PRESS/VENT

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### AIR BLEED/COND/PRESS/VENT

#### PRELIMINARY PAGES - TABLE OF CONTENTS

General.....	A
APU Bleed Use with HP Air Start Unit.....	B
Avionics Ventilation.....	C
Cabin Pressure.....	D
Packs Use with LP Air Conditioning Unit.....	E




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### AIR BLEED/COND/PRESS/VENT

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>AIR BLEED/COND/PRESS/VENT</b>
---	--

**GENERAL**

Ident.: LIM-AIR-00020807.0001001 / 17 MAR 17  
**Applicable to: ALL**

With passengers on board, it is not recommended to exceed 20 min without air conditioning supply. The lack of fresh air supply will significantly reduce the cabin's air quality.

**APU BLEED USE WITH HP AIR START UNIT**

Ident.: LIM-AIR-00020084.0001001 / 17 MAR 17  
**Applicable to: ALL**

The flight crew must not use bleed air from the APU BLEED and from the HP Air Start Unit at the same time, to prevent any adverse effect on the Bleed Air System.

**AVIONICS VENTILATION**

Ident.: LIM-AIR-00020086.0001001 / 17 MAR 17  
**Applicable to: ALL**


During ground operations and depending on the Outside Air Temperature (OAT), the flight crew must limit the time that the aircraft electric power supply is used, in normal avionics ventilation system configuration, as follows:

OAT ≤ 49 °C	No limitation
49 °C < OAT ≤ 55 °C	2 h
55 °C < OAT ≤ 60 °C	1 h
60 °C < OAT ≤ 64 °C	0.5 h

**CABIN PRESSURE**

Ident.: LIM-AIR-00020085.0003001 / 17 MAR 17  
**Applicable to: ALL**

Maximum positive differential pressure..... 9.0 PSI  
 Maximum negative differential pressure.....-1.0 PSI  
 Safety relief valve setting..... 8.6 PSI



*Note:* Maximum differential pressure ( $\Delta p$ ) and safety valve setting tolerance =  $\pm 7$  hPa (0.1 PSI).

**PACKS USE WITH LP AIR CONDITIONING UNIT**

Ident.: LIM-AIR-00020083.0001001 / 17 MAR 17

Applicable to: **ALL**

The flight crew must not use conditioned air from the packs and from the LP Air Conditioning Unit at the same time, to prevent any adverse effect on the Air Conditioning system.


# **LIMITATIONS**

AUTO FLIGHT SYSTEM



Intentionally left blank



**LIM-AFS-10 General**

Autopilot Function.....	A
Flight Management Function.....	B
Use of NAV Mode.....	C
Use of FLS  .....	D
Navigation Database Validation.....	E

**LIM-AFS-20 Automatic Approach, Landing and Rollout**

ILS Category II.....	A
Special Authorization CAT II (SA CAT II).....	B
Other than Standard CAT II (OTS CAT II).....	C
ILS Category III Fail Passive (Single).....	D
ILS Category III Fail Operational (Dual).....	E
Engine-Out.....	F
Maximum Wind Conditions for ILS/MLS  CAT II or CAT III and for GLS  CAT I.....	G
Automatic Landing.....	H
Automatic Landing in Johannesburg.....	I
Autoland Databases with Honeywell ADIRU.....	J




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### AUTO FLIGHT SYSTEM

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>AUTO FLIGHT SYSTEM</b>  GENERAL
---	--

## AUTOPILOT FUNCTION

**Applicable to: ALL**




Ident.: LIM-AFS-10-10-00019567.0001001 / 17 MAR 17


The autopilot can be used with the following minimum values:

Ident.: LIM-AFS-10-10-00019753.0001001 / 17 MAR 17

At takeoff	100 ft AGL or 5 s after liftoff
------------	---------------------------------

Ident.: LIM-AFS-10-10-00019568.0001001 / 03 AUG 17

In non-precision approach using F-LOC  or F-G/S  (FLS  function)	200 ft AGL
---	------------


In non-precision approach using FINAL APP  , NAV FPA, NAV V/S, TRK FPA, HDG V/S, LOC V/S, LOC FPA	250 ft AGL
--	------------


Ident.: LIM-AFS-10-10-00019746.0005001 / 09 JUN 17

In circling approach	500 ft AGL for aircraft category C (600 ft AGL for aircraft category D).
----------------------	--

Ident.: LIM-AFS-10-10-00019747.0001001 / 17 MAR 17

ILS /MLS  approach when CAT1 is displayed on the FMA	160 ft AGL
---	------------

GLS  approach when AUTOLAND is not displayed on the FMA	160 ft AGL
--	------------

ILS /MLS  approach when CAT2 or CAT3 (single or dual) is displayed on the FMA	0 ft AGL if autoland
--	----------------------

Ident.: LIM-AFS-10-10-00019750.0001001 / 17 MAR 17

After a manual go-around	100 ft AGL
--------------------------	------------

Ident.: LIM-AFS-10-10-00019751.0001001 / 06 JUL 17

In all other phases	500 ft AGL
---------------------	------------

The AP or FD in OP DES or DES mode can be used in approach. However, its use is only permitted if the FCU selected altitude is set to, or above, the higher of the two: MDA /MDH or 500 ft AGL.

## FLIGHT MANAGEMENT FUNCTION

**Applicable to: ALL**

Ident.: LIM-AFS-10-20-00020069.0001001 / 17 MAR 17

FMGS lateral and vertical navigation is certified for:

- After takeoff, en route, and terminal area operations
- Navigation within RNAV /RNP airspace

- Instrument approach procedures (except ILS , LOC , LOC B/C , LDA , SDF, GLS  $\triangleleft$  , MLS  $\triangleleft$  and FLS  $\triangleleft$  final approaches)
- Missed approach procedures.

The FLS  $\triangleleft$  function is certified for:

- RNAV , RNAV (GNSS) , GPS , VOR , VOR /DME , NDB , NDB /DME instrument approach procedures, using FMS navigation for lateral and vertical navigation
- LOC , ILS (GS out), or LOC B/C instrument approaches, using FMS navigation for vertical navigation, associated with LOC or LOC B/C for lateral navigation.

Approval of the FMGS is based on the assumption that the navigation database is validated for intended use.

Obstacle clearance and adherence to airspace constraints remains a flight crew responsibility. Fuel, time predictions/performance information is provided for advisory purposes only.

**TAKEOFF IN GPS PRIMARY  $\triangleleft$**

For certain airports, where the difference between the local coordinate system and WGS 84 (geodesic standard used by GPS , FMS) is not negligible, a map shift may occur after takeoff. The flight crew must deselect the GPS for takeoff from these airports, until a safe altitude is reached.

Ident.: LIM-AFS-10-20-00020070.0002001 / 17 MAR 17

**NAVIGATION PERFORMANCE**


The navigation accuracy depends on:

- IRS drift, or
- One of the following:
  - Radio navaid availability, or
  - Elapsed time since last computation of radio navaid position.

RNP accuracy with GPS PRIMARY  $\triangleleft$  is:


	<b>With AP ON <sup>(1)</sup></b>	<b>With AP OFF and FD ON <sup>(1)</sup></b>	<b>With AP OFF and FD OFF</b>
<b>En route</b>	1 NM	1 NM	1.1 NM
<b>In terminal area</b>	0.5 NM	0.51 NM	0.51 NM
<b>In approach</b>	0.3 NM	0.3 NM	0.3 NM with F-LOC $\triangleleft$ deviation Not authorized without F-LOC $\triangleleft$ deviation

<sup>(1)</sup> - In NAV (all phases), or  
 - In F-LOC  $\triangleleft$  (approach phase)

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b> <b>AUTO FLIGHT SYSTEM</b></p> <p>GENERAL</p>
---	--

Ident.: LIM-AFS-10-20-00020389.0001001 / 17 MAR 17

### DEGRADED SITUATION

If GPS PRIMARY LOST  is displayed on the PFD , the navigation accuracy remains sufficient for RNP operations provided that, the RNP value is checked or entered on the MCDU and HIGH ACCURACY is displayed.


## USE OF NAV MODE

Applicable to: ALL

Ident.: LIM-AFS-10-30-00020334.0001001 / 17 MAR 17

### AFTER TAKEOFF


NAV mode may be used after takeoff provided that:

- GPS PRIMARY  is available, or
- The flight crew checked the FMGS takeoff updating.

Ident.: LIM-AFS-10-30-00020335.0001001 / 17 MAR 17

### IN TERMINAL AREA


NAV mode may be used in terminal area provided that:


- GPS PRIMARY  is available, or
- the appropriate RNP is checked or entered on the MCDU, and HIGH accuracy is displayed, or
- FMS navigation is crosschecked with navaid raw data.

Ident.: LIM-AFS-10-30-00020336.0001001 / 17 MAR 17

### APPROACH BASED ON RADIO NAVAIDS

A nav aids approach may be performed in NAV , APP NAV or FINAL APP , with AP or FD engaged, provided that:


- If GPS PRIMARY  is available, the reference nav aid may be unserviceable, or the airborne radio equipment may be inoperative, or not installed, provided that an operational approval is obtained
- If GPS PRIMARY is not available, the reference nav aid and the corresponding airborne radio equipment must be serviceable, tuned and monitored during the approach.

*Note:* FLS  is the recommended managed lateral and vertical guidance mode for radio nav aids approach.


Ident.: LIM-AFS-10-30-00020337.0001001 / 17 MAR 17

## **RNAV APPROACH**

An RNAV (RNP ) approach may be performed, with GPS PRIMARY not available, only if the radio navaid coverage supports the RNP value and HIGH accuracy is displayed on the MCDU with the specified RNP, and an operational approval is obtained.

An RNAV (GNSS) approach may be performed provided that GPS PRIMARY  is available.

*Refer to Guidance Modes per Approach Types*

Note: FLS  is the recommended managed lateral and vertical guidance mode for RNAV approach.

## **USE OF FLS**

Ident.: LIM-AFS-10-00020808.0001001 / 17 MAR 17

Applicable to: ALL

## **APPROACH BASED ON RADIO NAVAIDS**

A navaids approach may be flown with the FLS provided that:

- F-APP capability is displayed on FMA

In this case, the reference navaids may be unserviceable, or the airborne radio equipment may be inoperative, or not installed, provided that an operational approval is obtained.

- F-APP + RAW capability is displayed on FMA.

In this case, the reference navaids and the corresponding airborne radio equipment must be serviceable, tuned and monitored during the approach.

An ILS (G/S out), LOC , or LOC -B/C approach may be flown with the lateral LOC (LOC -B/C ) mode and with the F-G/S mode of FLS function provided that:

- F-APP capability is displayed on FMA

In this case, the reference navaids may be unserviceable, or the airborne radio equipment may be inoperative, or not installed, provided that an operational approval is obtained.


- F-APP + RAW capability is displayed on FMA.

In this case, the reference navaids and the corresponding airborne radio equipment must be serviceable, tuned and monitored during the approach.

## **RNAV (GNSS) APPROACH**

An RNAV (GNSS ) approach with LNAV minimum may be flown with the FLS provided that the F-APP capability is displayed on FMA.

An RNAV (GNSS) approach with LNAV /VNAV minimum must be flown with the FLS provided that the F-APP capability is displayed on FMA.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>LIMITATIONS</b> <b>AUTO FLIGHT SYSTEM</b></p> <p align="center">GENERAL</p>
---	--

**NAVIGATION DATABASE VALIDATION**

Applicable to: ALL

Ident.: LIM-AFS-10-40-00021656.0002001 / 08 AUG 17

**RNAV (GNSS ) APPROACHES AND APPROACHES BASED ON VOR /NDB**

To fly an approach in lateral managed mode or lateral and vertical managed mode, the approach stored in the Navigation database must be either:

- Produced by an approved supplier compliant with ED76/DO200A requirements, or
- Validated and approved by the Operator.

*Note: RNAV (GNSS ) approaches lateral trajectories are geometrically based on waypoints coordinates. Thus, validating waypoints coordinate ensure no coding error on the approach and correct lateral trajectory. Observed lateral track degree of difference between MCDU F-PLN page display and charts may come from inconsistency between FMS MagVar and charted MagVar, which has no effect on lateral trajectory.*




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**AUTO FLIGHT SYSTEM**

GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b></p> <p><b>AUTO FLIGHT SYSTEM</b></p> <p>AUTOMATIC APPROACH, LANDING AND ROLLOUT</p>
---	---


**ILS CATEGORY II**

Ident.: LIM-AFS-20-00020136.0001001 / 17 MAR 17  
**Applicable to: ALL**

Minimum decision height..... 100 ft AGL  
 At least one autopilot must be engaged in APPR mode, and CAT 2 or CAT 3 SINGLE or CAT 3 DUAL must be displayed on the FMA.  
 For manual landing, AP should be disconnected no later than 80 ft AGL.


**SPECIAL AUTHORIZATION CAT II (SA CAT II)**

Ident.: LIM-AFS-20-00020138.0001001 / 17 MAR 17  
**Applicable to: ALL**

Minimum decision height..... 100 ft AGL  
 At least one autopilot must be engaged in APPR mode, and CAT 2 or CAT 3 SINGLE or CAT 3 DUAL must be displayed on the FMA.  
 With HUD  , the flight crew must use the HUD to monitor the approach and perform an automatic landing or a manual landing. If the flight crew performs an automatic approach without automatic landing, the autopilot must be disengaged no later than at 80 ft AGL.  
 Without HUD, the flight crew must perform an automatic landing.

**OTHER THAN STANDARD CAT II (OTS CAT II)**

Ident.: LIM-AFS-20-00020139.0001001 / 17 MAR 17  
**Applicable to: ALL**

Minimum decision height..... 100 ft AGL  
 At least one autopilot must be engaged in APPR mode, and CAT 2 or CAT 3 SINGLE or CAT 3 DUAL must be displayed on the FMA.  
 With HUD  , the flight crew must use the HUD to monitor the approach and perform an automatic landing or a manual landing. If the flight crew performs an automatic approach without automatic landing, the autopilot must be disengaged no later than at 80 ft AGL.  
 Without HUD, the flight crew must perform an automatic landing.

**ILS CATEGORY III FAIL PASSIVE (SINGLE)**

Ident.: LIM-AFS-20-00020140.0001001 / 17 MAR 17  
**Applicable to: ALL**

Minimum decision height..... 50 ft AGL  
 A/THR must be used in selected or managed speed.  
 At least one autopilot must be engaged in APPR mode, and CAT 3 SINGLE or CAT 3 DUAL must be displayed on the FMA.



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**LIMITATIONS**

**AUTO FLIGHT SYSTEM**

AUTOMATIC APPROACH, LANDING AND ROLLOUT

**ILS CATEGORY III FAIL OPERATIONAL (DUAL)**

Ident.: LIM-AFS-20-00020141.0008001 / 17 MAR 17

Applicable to: ALL

Alert height..... 100 ft AGL

A/THR must be used in selected or managed speed.

Both autopilots must be engaged in APPR mode, and CAT 3 DUAL must be displayed on the FMA.

■ **CAT III with DH:**

Minimum Decision Height..... 20 ft AGL

■ **CAT III without DH:**

Minimum Runway Visual Range..... 75 m

**ENGINE-OUT**

Ident.: LIM-AFS-20-00020142.0001001 / 17 MAR 17

Applicable to: ALL

CAT II and CAT III fail passive autoland are only approved in configuration FULL, and if engine-out procedures are completed before reaching 1 000 ft in approach.

**MAXIMUM WIND CONDITIONS FOR ILS/MLS ⚠ CAT II OR CAT III AND FOR GLS ⚠ CAT I**

Ident.: LIM-AFS-20-00020144.0001001 / 17 MAR 17

Applicable to: ALL

Headwind : 30 kt

Tailwind : 10 kt

Crosswind : 20 kt

*Note: Wind limitation is based on the surface wind reported by ATC . If the wind displayed on the ND exceeds the above-noted autoland limitations, but the tower reports a surface wind within the limitations, then the autopilot can remain engaged. If the tower reports a surface wind beyond limitations, only CAT I automatic approach without autoland can be performed.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### AUTO FLIGHT SYSTEM

AUTOMATIC APPROACH, LANDING AND ROLLOUT

## AUTOMATIC LANDING

Applicable to: ALL

Ident.: LIM-AFS-20-10-00020149.0001001 / 17 MAR 17

ILS/MLS CAT II and CAT III autoland and GLS CAT I autoland are approved in CONF 3 and CONF FULL.

Ident.: LIM-AFS-20-10-00020150.0001001 / 17 MAR 17

Automatic landing is demonstrated:

- With CAT II and CAT III ILS /MLS beam and CAT I GLS beam.

Ident.: LIM-AFS-20-10-00020151.0001001 / 17 MAR 17

- With a glide slope angle between  $-2.5^{\circ}$  and  $-3.15^{\circ}$

Ident.: LIM-AFS-20-10-00020152.0003001 / 17 MAR 17

- With an airport elevation at or below 9 200 ft

Ident.: LIM-AFS-20-10-00020155.0001001 / 17 MAR 17

Automatic landing is not allowed below -1 000 ft pressure altitude.

Ident.: LIM-AFS-20-10-00020156.0001001 / 17 MAR 17

Automatic rollout performance is approved on dry and wet runways, but performance on snow-covered or icy runways was not demonstrated.

Ident.: LIM-AFS-20-10-00020158.0001001 / 17 MAR 17

Automatic landing system performance is demonstrated with CAT II or CAT III ILS /MLS airport installation. However, automatic landing in CAT I or better weather conditions is possible on CAT I ground installations or on CAT II/III ground installations when ILS/MLS sensitive areas are not protected, if the following precautions are taken:

- The airline checked that the ILS /MLS beam quality, and the effect of the terrain profile before the runway have no adverse effect on AP /FD guidance. Particularly, the effect of terrain profile within 300 m before the runway threshold must be evaluated
- The flight crew is aware that LOC or G/S beam fluctuations, independent of the aircraft system, may occur. The PF is prepared to immediately disconnect the autopilot, and to take the appropriate action, should not satisfactory guidance occur
- At least CAT2 capability is displayed on the FMA and the flight crew uses CAT II/III procedures
- Visual references are obtained at an altitude appropriate for the CAT I approach. If not, a go-around must be performed.

## AUTOMATIC LANDING IN JOHANNESBURG

Ident.: TDU / LIM-AFS-20-00013685.0001001 / 25 APR 13

Applicable to: ALL

Impacted DU: NONE

Automatic landing is not permitted on Johannesburg 03R/21L runways.



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

### LIMITATIONS

#### AUTO FLIGHT SYSTEM

AUTOMATIC APPROACH, LANDING AND ROLLOUT

#### AUTOLAND DATABASES WITH HONEYWELL ADIRU

Ident.: TDU / LIM-AFS-20-00016880.0070001 / 25 NOV 15

Applicable to: **ALL**

Impacted DU: NONE

The below table provides for each concerned airport, the dates when the following limitations begin:

- AUTOLAND is not allowed
- ROLLOUT is not allowed.

CAT II approaches without AUTOLAND are still allowed.

Airport code	Airport Location	Month/Year
PAFA	FAIRBANKS INTL AK USA	September 2016
PANC	ANCHORAGE INTL AK USA	June 2018

*Note: This limitation is applicable until end of 2020. From 2021, without a revision of this limitation, AUTOLAND and ROLLOUT will not be allowed on any airport.*

The above limitations do not apply if three new ADIRU with updated magnetic variation tables are installed and Operators ensure previous standards are not installed.

# **LIMITATIONS**

AUXILIARY POWER UNIT

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**AUXILIARY POWER UNIT**

PRELIMINARY PAGES - TABLE OF CONTENTS

General.....A  
APU Start/Shutdown during Refueling/Defueling..... B  
Operational Envelope..... C



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


## LIMITATIONS

### AUXILIARY POWER UNIT

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b> <b>AUXILIARY POWER UNIT</b></p>
---	---

**GENERAL**

**Applicable to: ALL**  
Ident.: LIM-APU-10-00020088.0001001 / 17 MAR 17

**APU START**

After three consecutive APU start attempts, the flight crew must wait 60 min before a new start attempt.

Ident.: LIM-APU-10-00020089.0001001 / 17 MAR 17

**ROTOR SPEED**

Maximum N speed..... 107 %

Ident.: LIM-APU-10-00020090.0002001 / 17 MAR 17

**EGT**

Maximum EGT for APU start (below 25 000 ft)..... 900 °C  
Maximum EGT for APU start (above 25 000 ft)..... 982 °C  
Maximum EGT for APU running (with 5 s confirmation for shutdown)..... 682 °C  
Maximum EGT for APU running (for immediate shutdown)..... 700 °C to 742 °C

**APU START/SHUTDOWN DURING REFUELING/DEFUELING**

Ident.: LIM-APU-00020091.0001001 / 17 MAR 17  
**Applicable to: ALL**


During refuel/defuel procedures, APU starts or shutdown are permitted with the following restrictions:

- If the APU failed to start or following an automatic APU shutdown, do not start the APU
- If a fuel spill occurs, perform a normal APU shutdown.

**OPERATIONAL ENVELOPE**

Applicable to: ALL

Ident.: LIM-APU-20-00019832.0026001 / 17 MAR 17



Ident.: LIM-APU-20-00021771.0001001 / 04 JUL 17

**APU BLEED**

- Max altitude to assist engine start..... 20 000 ft
- Max altitude for air conditioning and pressurization (single pack operation)..... 20 000 ft
- Max altitude for air conditioning and pressurization (dual pack operation)..... 15 000 ft
- Use of APU bleed air for wing anti-ice is not permitted.

# LIMITATIONS

CABIN SYSTEMS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**CABIN SYSTEMS**

PRELIMINARY PAGES - TABLE OF CONTENTS

Power Supply for Portable Electronic Device (PED)..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**CABIN SYSTEMS**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**CABIN SYSTEMS**

**POWER SUPPLY FOR PORTABLE ELECTRONIC DEVICE (PED)**

Ident.: LIM-CAB-00020226.0001001 / 22 MAR 17

**Applicable to: ALL**

The In-Seat Power Supply System (ISPSS) for the Portable Electronic Device (PED) carried by the passengers must be turned off during takeoff and landing.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**CABIN SYSTEMS**

Intentionally left blank



# LIMITATIONS

COMMUNICATION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS  
COMMUNICATION**

PRELIMINARY PAGES - TABLE OF CONTENTS

GSM Onboard <img alt="triangle icon" data-bbox="308 151 331 164"/> ..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**COMMUNICATION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GSM ONBOARD** 

Ident.: LIM-COM-00020293.0001001 / 17 MAR 17

**Applicable to: ALL**

The use of mobile phones is prohibited in the toilets and the cockpit.

It is prohibited to use the GSM Onboard System:

- Below 3 000 m AGL (approximately 10 000 ft)
- In some geographical areas (refer to the “Regional Operation Data for the Onboard Mobile Telephony System” document for the identification of these geographical areas).

*Note: The GSM Onboard System is able to identify the above-mentioned flight conditions. If the system identifies any of these conditions, it automatically turns off.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**COMMUNICATION**


Intentionally left blank

# LIMITATIONS

ENGINES

Intentionally left blank



Thrust Setting/EGT Limits.....	A
Shaft Speeds.....	B
Oil.....	C
Starter.....	D
Reverse Thrust.....	E
Reduced Thrust Takeoff.....	F
Soft Go-Around  .....	G



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### ENGINES

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>ENGINES</b>
---	--------------------------------------

**THRUST SETTING/EGT LIMITS**

Ident.: LIM-ENG-00019960.0004001 / 20 MAR 17  
**Applicable to: ALL**

Operating Conditions		Time Limit	EGT Limit
Takeoff <sup>(1)</sup> and Go-around	All engines operative	5 min	950 °C
	One engine inoperative	10 min	
Maximum Continuous Thrust (MCT)		Not limited	915 °C
Starting	On ground		725 °C
	In flight		

<sup>(1)</sup> Includes TOGA, FLEX, and DERATE  thrust modes.

**SHAFT SPEEDS**

Ident.: LIM-ENG-00020355.0002001 / 20 MAR 17  
**Applicable to: ALL**

Maximum N1 ..... 104 %

Note: The N1 limit depends on the ambient conditions and on the configuration of the engine air bleed. These parameters may limit N1 to a value that is less than the above-mentioned N1 value (Refer to PER-THR-MTO MAXIMUM TAKEOFF).

Maximum N2 ..... 105 %

**OIL**

Ident.: LIM-ENG-00020354.0001001 / 20 MAR 17  
**Applicable to: ALL**

**OIL TEMPERATURE**


Maximum continuous temperature..... 140 °C  
 Maximum transient temperature (15 min)..... 155 °C  
 Minimum starting temperature..... -40 °C  
 Minimum temperature before takeoff..... -10 °C

**OIL QUANTITY**

Minimum oil quantity..... Refer to PRO-NOR-SOP-04 ECAM

**OIL PRESSURE**

MIN/MAX Oil Pressure (ECAM Indication)




**STARTER**

Ident.: LIM-ENG-00020356.0001001 / 20 MAR 17

Applicable to: **ALL**

- A standard automatic start that includes up to three start attempts, is considered one cycle
- For ground starts (automatic or manual), a 20 s pause is required between successive cycles
- A 15 min cooling period is required, subsequent to four failed cycles
- The starter must not be run when N2 is above 20 %.

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>ENGINES</b>
---	--------------------------------------

**REVERSE THRUST**

Ident.: LIM-ENG-00020357.0002001 / 20 MAR 17

**Applicable to: ALL**

Selection of the reverse thrust is prohibited in flight.  
 Backing the aircraft with reverse thrust is not permitted.  
 Maximum reverse should not be used below 70 kt.

**REDUCED THRUST TAKEOFF**

**Applicable to: ALL**

Ident.: LIM-ENG-10-00020358.0020001 / 20 MAR 17

**FLEX TAKEOFF**

Takeoff at reduced thrust, so-called as FLEX takeoff, is permitted only if the airplane meets all performance requirements at the takeoff weight, with the operating engines at the thrust available for the flexible temperature (TFLEX).

Takeoff at reduced thrust is permitted with any inoperative item affecting the performance only if the associated performance shortfall has been applied to meet the above requirements.

FLEX takeoff is not permitted on contaminated runways.

TFLEX cannot be:

- Higher than TMAXFLEX, equal to ISA + 70 °C.
- Lower than the flat temperature (TREF).
- Lower than the actual OAT.

Ident.: LIM-ENG-10-00020359.0001001 / 20 MAR 17

**DERATED TAKEOFF** 

Selection of TOGA thrust is not permitted when a derated takeoff is performed, except when requested in any abnormal or emergency procedures.

The use of reduced thrust takeoff (FLEX takeoff) is not permitted in association with derated takeoff.

The use of derated takeoff is permitted regardless of the runway condition (dry, wet, or contaminated).

**SOFT GO-AROUND** 

Ident.: LIM-ENG-00020363.0001001 / 20 MAR 17

**Applicable to: ALL**

The use of soft go-around is prohibited with one engine inoperative.

Intentionally left blank

# LIMITATIONS

FLIGHT CONTROLS

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**FLIGHT CONTROLS**

PRELIMINARY PAGES - TABLE OF CONTENTS

Flight Maneuvering Load Acceleration Limits..... A  
Maximum Altitude Flaps/Slats Extended..... B  
Maximum Flaps/Slats Speeds..... C  
Use of Flight Controls..... D




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**FLIGHT CONTROLS**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b> <b>FLIGHT CONTROLS</b></p>
---	--

**FLIGHT MANEUVERING LOAD ACCELERATION LIMITS**

Ident.: LIM-F\_CTL-00020162.0001001 / 17 MAR 17  
**Applicable to: ALL**

*Refer to LIM-AG-F\_CTL Flight Maneuvering Load Acceleration Limits.*

**MAXIMUM ALTITUDE FLAPS/SLATS EXTENDED**

Ident.: LIM-F\_CTL-00020160.0001001 / 17 MAR 17  
**Applicable to: ALL**

Maximum operating altitude with slats and/or flaps extended.....20 000 ft

**MAXIMUM FLAPS/SLATS SPEEDS**

Ident.: LIM-F\_CTL-00020163.0001001 / 17 MAR 17  
**Applicable to: ALL**

*Refer to LIM-AG-SPD Maximum Flaps/Slats Speeds.*

**USE OF FLIGHT CONTROLS**

Ident.: LIM-F\_CTL-00020000.0001001 / 17 MAR 17  
**Applicable to: ALL**

<b>CAUTION</b>	Rapid and large alternating control inputs, especially in combination with large changes in pitch, roll or yaw (e.g. large sideslip angles) may result in structural failures at any speed.
----------------	---

Intentionally left blank

# LIMITATIONS

FUEL

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### FUEL

#### PRELIMINARY PAGES - TABLE OF CONTENTS

Certified Fuel.....	A
Fuel Mixability.....	B
Fuel Temperature.....	C
Fuel Temperature Limits when JP4 and JET B Fuels are Used.....	D
Maximum Allowed Fuel Imbalance.....	E
Minimum Fuel Quantity for Takeoff.....	F



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### FUEL

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b>  <b>FUEL</b>
---	---------------------------------------

**CERTIFIED FUEL**

Ident.: LIM-FUEL-00019707.0001001 / 17 MAR 17

**Applicable to: ALL**

The fuel system is certified with: JET A, JET A1, JET B, JP4, JP5, JP8, N° 3 JET, RT, and TS-1, in accordance with engine manufacturers and fuel specifications.

**FUEL MIXABILITY**

Ident.: LIM-FUEL-00012852.0001001 / 03 JAN 11

**Applicable to: ALL**

The various types of fuel can be mixed in all proportions.

The freezing point of a fuel mixture varies, based on non-linear laws. If required, determine the fuel freezing point of the fuel mixture.

**FUEL TEMPERATURE**

Ident.: LIM-FUEL-00019708.0001001 / 17 MAR 17

**Applicable to: ALL**

	JET A1/JP8/ N°3 JET	JET A	JP5	RT	TS-1	JET B	JP4
<b>MINI</b>	-43 °C	-36 °C <sup>(1)</sup>	-42 °C	-45 °C	-45 °C	-46 °C	-54 °C
<b>MAXI</b>	54 °C					49 °C	

<sup>(1)</sup> For JET A only, if TAT reaches -34 °C, monitor the fuel temperature on the FUEL SD page, to ensure that it remains above -36 °C.

**FUEL TEMPERATURE LIMITS WHEN JP4 AND JET B FUELS ARE USED**

Ident.: LIM-FUEL-00019709.0001001 / 17 MAR 17

**Applicable to: ALL**

If the wing fuel temperature exceeds 30 °C at engine start, the altitude must be limited to 35 000 ft until the center tank is empty.

If the wing fuel temperature exceeds 40 °C at engine start, the altitude must be limited to 30 000 ft until the center tank is empty.

If the wing fuel temperature exceeds 49 °C at engine start, the altitude must be limited to 25 000 ft until the center tank is empty.

Reason : At high altitude with high fuel temperature, the pressure supplied by the center tank pumps becomes lower than the pressure supplied by the wing tank pumps.

**LIMITATIONS**

**FUEL**

**MAXIMUM ALLOWED FUEL IMBALANCE**

Ident.: LIM-FUEL-00020435.0001001 / 17 MAR 17

Applicable to: ALL

The following tables indicate the maximum allowed wing imbalance at takeoff, in flight, and at landing.

**FUEL IMBALANCE AT TAKEOFF**

**INNER TANKS (OUTER TANKS BALANCED)**

Tank Fuel Quantity (Heavier Tank)	Maximum Asymmetry
Full	500 kg (1 102 lb)
3 000 kg (6 613 lb)	1 050 kg (2 314 lb)
1 450 kg (3 196 lb)	1 450 kg (3 196 lb)

The variation is linear between these values.

**OUTER TANKS (INNER TANKS BALANCED)**

<b>Maximum Asymmetry</b>	370 kg (815 lb)
--------------------------	-----------------

**FUEL IMBALANCE IN FLIGHT AND AT LANDING**

**INNER TANKS (OUTER TANKS BALANCED)**

Tank Fuel Quantity (Heavier Tank)	Maximum Asymmetry
Full	1 500 kg (3 306 lb)
4 300 kg (9 479 lb)	1 600 kg (3 527 lb)
2 250 kg (4 960 lb)	2 250 kg (4 960 lb)

The variation is linear between these values, and there is no limitation below 2 250 kg (4 960 lb).

**OUTER TANKS**

<b>Maximum Asymmetry</b>	690 kg (1 521 lb) <sup>(1)</sup>
--------------------------	----------------------------------

<sup>(1)</sup> The maximum fuel imbalance in the outer wing fuel tanks (one full/one empty) is allowed provided that:

- The fuel quantity of the outer and inner wing fuel tanks of one side is equal to the fuel quantity of the outer and inner wing fuel tanks on the other side, or
- On the side of the lighter outer tank, the fuel quantity of the inner tank is more than the fuel quantity of the opposite inner tank. The difference between the fuel quantity in the inner tanks should not be more than 3 000 kg (6 613 lb).

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b></p> <p><b>FUEL</b></p>
---	--

*Note: In exceptional conditions (i.e. fuel system failure), the above-mentioned values for maximum fuel imbalance may be exceeded without significant effect to the aircraft handling qualities. The aircraft remains fully controllable in all flight phases.*

<b>MINIMUM FUEL QUANTITY FOR TAKEOFF</b>
--

Ident.: LIM-FUEL-00019771.0001001 / 17 MAR 17

**Applicable to: ALL**


Minimum fuel quantity for takeoff.....1 500 kg (3 307 lb)  
 The ECAM alerts that are related to fuel low level in the wing tanks (**FUEL WING TK LO LVL**, etc.) must not appear for takeoff.

Intentionally left blank

# **LIMITATIONS**

ICE AND RAIN PROTECTION

Intentionally left blank

Definition of Icing Conditions.....A  
Definition of Severe Ice Accretion.....B  
Definition of Thin Hoarfrost.....C  
Rain Repellent  .....D  
Wipers Maximum Operating Speed.....E



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### ICE AND RAIN PROTECTION

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



## LIMITATIONS

### ICE AND RAIN PROTECTION

#### DEFINITION OF ICING CONDITIONS

Ident.: LIM-ICE\_RAIN-00020608.0001001 / 17 MAR 17

**Applicable to: ALL**

- Icing conditions exist when the OAT (on ground or after takeoff) or the TAT (in flight) is at or below 10 °C and visible moisture in any form is present (such as clouds, fog with visibility of one nautical mile or less, rain, snow, sleet or ice crystals).
- Icing conditions also exist when the OAT on the ground and for takeoff is at or below 10 °C and operating on ramps, taxiways or runways where surface snow, standing water or slush may be ingested by the engines, or freeze on engines, nacelles or engine sensor probes.

#### DEFINITION OF SEVERE ICE ACCRETION

Ident.: LIM-ICE\_RAIN-00020609.0001001 / 17 MAR 17

**Applicable to: ALL**

Ice accretion is considered severe when the ice accumulation on the airframe reaches approximately 5 mm (0.2 in) thick or more.

#### DEFINITION OF THIN HOARFROST

Ident.: LIM-ICE\_RAIN-00020610.0001001 / 17 MAR 17

**Applicable to: ALL**

Thin hoarfrost is typically a white crystalline deposit which usually develops uniformly on exposed surfaces on cold and cloudless nights.

It is so thin that surface features (lines or markings) can be distinguished beneath it.

#### RAIN REPELLENT

Ident.: LIM-ICE\_RAIN-00020224.0001001 / 17 MAR 17

**Applicable to: ALL**

The flight crew should only use the rain repellent in the case of moderate to heavy rain.

#### WIPERS MAXIMUM OPERATING SPEED

Ident.: LIM-ICE\_RAIN-00020225.0001001 / 17 MAR 17

**Applicable to: ALL**

*Refer to LIM-AG-SPD Wipers Maximum Operating Speed.*

Intentionally left blank

# LIMITATIONS

LANDING GEAR

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**LANDING GEAR**

PRELIMINARY PAGES - TABLE OF CONTENTS

Braking System.....	A
Brake Temperature.....	B
Maximum Speeds with the Landing Gear Extended.....	C
Maximum Tire Speed.....	D
Nosewheel Steering (NWS).....	E
Taxi with Deflated or Damaged Tires.....	F




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**LANDING GEAR**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>LIMITATIONS</b> <b>LANDING GEAR</b></p>
---	--


**BRAKING SYSTEM**

Ident.: LIM-LG-00020233.0001001 / 17 MAR 17  
**Applicable to: ALL**

The braking system is not designed to hold the aircraft in a stationary position when a high thrust level is applied on at least one engine.  
 During ground procedures that require a thrust increase with braking, the flight crew must ensure that the aircraft remains stationary, and must be ready to immediately retard the thrust levers to IDLE.

**BRAKE TEMPERATURE**

Ident.: LIM-LG-00020255.0001001 / 17 MAR 17  
**Applicable to: ALL**

Maximum brake temperature for takeoff (brake fans  off).....300 °C

**MAXIMUM SPEEDS WITH THE LANDING GEAR EXTENDED**

Ident.: LIM-LG-00020237.0001001 / 17 MAR 17  
**Applicable to: ALL**

*Refer to LIM-AG-SPD Maximum Speeds with the Landing Gear Extended.*

**MAXIMUM TIRE SPEED**

Ident.: LIM-LG-00020238.0001001 / 17 MAR 17  
**Applicable to: ALL**

*Refer to LIM-AG-SPD Maximum Tire Speed.*

**NOSEWHEEL STEERING (NWS)**

Ident.: LIM-LG-00020236.0001001 / 17 MAR 17  
**Applicable to: ALL**

For NWS angle limit, *Refer to DSC-20-30 Taxiing.*  
 Towbarless operation on the nose landing gear (towing and pushback) is approved when using the accepted towbarless towing vehicles listed in the Airbus WISE ISI 09.11.00001, with the following information:  
 Maximum NWS angle..... 85 °



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**LANDING GEAR**

**TAXI WITH DEFLATED OR DAMAGED TIRES**

Ident.: LIM-LG-00020235.0001001 / 01 JUN 17

Applicable to: **ALL**

To vacate the runway or taxi at low speed with tire(s) deflated (not damaged), all of the following limitations apply:

- If maximum one tire per gear is deflated (consider three gears)  
Maximum taxi speed during turn..... 7 kt
- If two tires are deflated on the same main gear (maximum one main gear)  
Maximum taxi speed..... 3 kt
- For the nosewheel steering (NWS) angle  
Maximum NWS angle..... 30 °

In addition, if tire damage is suspected, the flight crew must ask for an aircraft inspection prior to vacate the runway or taxi. If the ground crew suspects that a tire burst may damage the landing gear, maintenance action is due.

For more information, *Refer to FCTM/PR-AEP-LG Taxi with Deflated or Damaged Tires.*



# LIMITATIONS

NAVIGATION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**NAVIGATION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Inertial Reference System (IRS).....A




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**NAVIGATION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>LIMITATIONS</b></p> <p><b>NAVIGATION</b></p>
---	--

**INERTIAL REFERENCE SYSTEM (IRS)**

Ident.: LIM-NAV-00020081.0001001 / 17 MAR 17

Applicable to: ALL

**IR GROUND ALIGNMENT**

Ground alignment of the IRS is possible in latitudes between 73 ° North and 73 ° South.

**MAGNETIC (MAG) REFERENCE**

■ **If all ADIRUs have the same magnetic variation table:**

In NAV mode, the IR will not provide valid magnetic heading and magnetic track angle:

- North of 73 ° North, and
- South of 60 ° South.

Flying at latitudes beyond these limits is prohibited.

■ **If one ADIRU has a different magnetic variation table:**

In NAV mode, the IR will not provide valid magnetic heading and magnetic track angle:

- North of 60 ° North, between 30 ° West and 160 ° West, and
- North of 73 ° North, and
- South of 55 ° South.

Flying at latitudes beyond these limits is prohibited.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**NAVIGATION**

Intentionally left blank

# LIMITATIONS

OXYGEN

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### OXYGEN

PRELIMINARY PAGES - TABLE OF CONTENTS

Minimum Flight Crew Oxygen Pressure.....A




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## LIMITATIONS

### OXYGEN

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>LIMITATIONS</b> <b>OXYGEN</b>
---	-------------------------------------

**MINIMUM FLIGHT CREW OXYGEN PRESSURE**

Ident.: LIM-OXY-00020232.0004001 / 17 MAR 17

Applicable to: ALL

REF Temperature <sup>(1)</sup>		°C	-10	0	10	20	30	40	50
		°F	14	32	50	68	86	104	122
<b>MIN Bottle Pressure (PSI)<sup>(2)</sup></b>	2 Crewmembers		716	744	771	798	826	853	880
	2 Crewmembers + 1 OBS		874	907	940	974	1 007	1 040	1 073
	2 Crewmembers + 2 OBS		1 103	1 145	1 187	1 229	1 270	1 312	1 354

(1) REF Temperature :

- On ground : REF Temperature = (OAT + Cockpit TEMP) / 2
- In flight : REF Temperature = CAB TEMP (°C) - 10 °C, or  
REF Temperature = CAB TEMP (°F) - 18 °F

(2) Minimum Bottle Pressure to Cover:

- Preflight checks
- The use of oxygen, when only one flight crewmember is in the cockpit
- Unusable quantity (to ensure regulator operation with minimum pressure)
- Normal system leakage
- The most demanding case among the following:
  - Protection after loss of cabin pressure, with mask regulator on NORMAL (diluted oxygen):
    - During emergency descent for all flight crewmembers and observers for 22 min
    - During cruise at FL 100 for two flight crewmembers for 98 min.
  - Protection against smoke with 100 % oxygen for all flight crewmembers and observers during 15 min at 8 000 ft cabin altitude.

Note: The above times that are based on the use of a sealed mask may be shorter for bearded crew (in terms of performance, pressure, or duration).

Intentionally left blank

# LIMITATIONS

SURVEILLANCE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**  
**SURVEILLANCE**

PRELIMINARY PAGES - TABLE OF CONTENTS

GPWS / Predictive GPWS <img alt="warning symbol" data-bbox="390 150 415 170"/> ..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS**

**SURVEILLANCE**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank




**GPWS / PREDICTIVE GPWS** 

Ident.: LIM-SURV-00019775.0001001 / 17 MAR 17


**Applicable to: ALL**

Aircraft navigation must not be based on the use of the terrain display .

The terrain display is intended to serve as a situation awareness tool only, and may not provide the accuracy on which to solely base terrain avoidance maneuvering.

The predictive GPWS  functions should be inhibited (TERR pushbutton to OFF, on the GPWS panel) when the aircraft position is less than 15 NM from the airfield:

- For operations from/to runways not incorporated in the predictive GPWS database.
- For specific approach procedures, which were previously identified as potentially causing false terrain alerts.

Only aircraft with Man-made Obstacle Function  can display obstacles on ND and trigger alerts, based on a dedicated database which includes artificial obstacles worldwide.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**LIMITATIONS  
SURVEILLANCE**

Intentionally left blank

**OPERATIONS  
ENGINEERING BULLETINS**

Intentionally left blank

M <sup>(1)</sup>	Identification	T <sup>(2)</sup>	E <sup>(3)</sup>	Rev. Date	Title
	OEB41 issue 3	W	N	15 OCT 15	Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan
	Criteria: P10762 <b>Applicable to: ALL</b>				
	OEB46 issue 1	W	N	05 NOV 13	No Engagement of Guidance Mode
	Criteria: 27-1234, 27-1243 <b>Applicable to: ALL</b>				

(1) Evolution code : N=New, R=Revised, E=Effectivity

(2) Type of OEB: R=Red, W=White

(3) Affects ECAM: Y=Yes, N=No



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**PRELIMINARY PAGES**

LIST OF EFFECTIVE OPERATIONS ENGINEERING BULLETIN

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

M	Localization	DU Title	DU identification	DU date
---	--------------	----------	-------------------	---------

No Temporary Documentary Unit



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

Intentionally left blank



# **OPERATIONS ENGINEERING BULLETINS**

GENERAL DESCRIPTION

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**GENERAL DESCRIPTION**

PRELIMINARY PAGES - TABLE OF CONTENTS

General Description..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**GENERAL DESCRIPTION**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**GENERAL DESCRIPTION**

Applicable to: ALL

Ident.: OEB-GEN-A-00014181.0001001 / 23 NOV 11

An Operations Engineering Bulletin (OEB) is issued to rapidly inform operators of any deviations from initial design objectives that have a significant operational impact. An OEB provides the operators with technical information and temporary operational procedures that address these deviations.

Ident.: OEB-GEN-A-00014182.0001001 / 23 NOV 11

**TYPE OF OEB**

OEBs can either be red or white, depending on their level of priority.

- RED OEBs are issued to indicate that non-compliance with the recommended procedures may have a significant impact on the safe operation of the aircraft.
- WHITE OEBs are issued to indicate that non-compliance with the recommended procedures may have a significant impact on aircraft operation.

Airbus strongly recommends that all Operators rapidly apply the OEB corrective actions as soon as they become available, particularly for red OEBs.

Ident.: OEB-GEN-A-00014183.0001001 / 23 JUN 15

**OEB CONTENT AND MANAGEMENT**

An OEB:

- Is temporary and usually focuses on one operational subject only,
- Is included in the OEB section of both the FCOM and QRH . The procedural part of each white or red OEB (OEB PROC ) is provided in the OEB section of the QRH, so that the flight crew can easily access the procedures,
- Remains applicable until the appropriate corrective actions are completed.

*Note: After installation of the OEB corrective modification/Service Bulletins (SB): if an Operator reinstalls any spare equipment for which there was an associated OEB , it is Operator's responsibility to ensure that this OEB be applied again for the applicable aircraft.*

**OEB IN THE FCOM**

The content of each OEB includes:

- The reason for issue,
- Technical explanations of the deviation from the initial design objectives,
- The operational impact if the flight crew does not apply the OEB procedure,

*Continued on the following page*

**GENERAL DESCRIPTION (Cont'd)**

- The conditions for applying the OEB procedures :
  - ECAM warning/caution affected by the OEB,
  - Cockpit effects,
  - Flight phases,
  - Specific event.
- The OEB operational procedure(s) to be applied,
- The corrective actions that cancel the OEB (if available),
- The OEB REMINDER codes, (if applicable).

**OEB IN THE QRH**

Each FCOM OEB has an associated "OEB PROC" in the OEB section of the QRH, that includes:

- The title of the OEB PROC,
- The "ECAM ENTRY" field:  
 This section identifies whether or not one of the possible conditions for applying the OEB PROC is an ECAM warning/caution.  
 The flight crew must disregard the ECAM procedure and/or STATUS of the ECAM alerts listed in the "ECAM ENTRY" field and must apply the QRH 's OEB procedure instead.
- The OEB operational procedure(s) that the flight crew must apply.

**FCOM LIST OF EFFECTIVE OEB**

The List of Effective Operations Engineering Bulletins (LEOEB) enables to review all the Operations Engineering Bulletins (OEB s) that are applicable to the fleet. Each time an OEB is issued or revised, the LEOEB is updated.

M <sup>(1)</sup>	Identification	T <sup>(2)</sup>	E <sup>(3)</sup>	REV. Date	Title
	OEB38 issue 1	R	N	18 MAR 11	Erroneous Radio Altimeter Height Indication
Criteria: SA Applicable to: ALL					

(1) Evolution code: N=New, R=Revised, E=Effectivity  
 (2) Type of OEB: R=Red, W=White  
 (3) Affects ECAM: Y=Yes, N=No

The FCOM LEOEB consists of:

*Continued on the following page*

**GENERAL DESCRIPTION (Cont'd)**

The "M" field that may provide the following Evolution Code:

- The "N" letter indicates a new OEB, or
- The "R" letter indicates a revised OEB, or
- The "E" letter indicates an aircraft validity change on the OEB.

The "Identification" field which identifies the OEB with its identification number.

*Note: The FCOM OEB and associated QRH OEB PROC have the same OEB number in order to be consistent. However, the issue number of the QRH OEB PROC and the FCOM OEB may be different, because a revision of an FCOM OEB does not necessarily result in a revision of the corresponding QRH OEB PROC, that only provides the procedure part.*

The "T" field indicates the Type of OEB:

- The "W" letter indicates a white OEB, or
- The "R" letter indicates a red OEB.

*Note: OEBs are listed by type of OEB (RED OEBs first, then WHITE OEBs), and in numerical order for each type of OEB. This enables the flight crew to easily review the OEBs before flight.*

The "E" field indicates whether or not the OEB affects ECAM procedure(s). This enables the flight crew to easily review the OEBs before flight particularly for Operators that use the OEB REMINDER function:

- The "Y" letter indicates that the OEB affects only ECAM procedure(s),
- The "N" letter indicates that at least one of the procedures provided in the OEB does not affect ECAM procedure(s).

**CAUTION**

When Airbus provides the Operator with the LEOEB, the information "AFFECTS ECAM : Y" ("E" field) does not necessarily mean that (for Operators using the OEB REMINDER function) the Operator's maintenance personnel has activated the OEB REMINDER codes for this OEB onboard the aircraft. It is the Operator's responsibility to define a suitable process for providing the flight crew with confirmation that the OEB REMINDER codes are activated for the ECAM alerts affected by OEBs.

The "Rev Date" field indicates the date at which the OEB content was issued/changed

The "Title" field provides the OEB title.

*Continued on the following page*

**GENERAL DESCRIPTION (Cont'd)**

**QRH LIST OF EFFECTIVE OEB**

The List of Effective Operations Engineering Bulletins (LEOEB) enables to review all the Operations Engineering Bulletins (OEBs) that are applicable to the fleet. Each time an OEB is issued or revised, the LEOEB is updated.

Identification	Title
<b>OEB26</b> <b>Issue 1</b>	<b>Erroneous Radio Altimeter (RA) Height Indication</b> ECAM Entry None
OEB33 Issue 1	Pack Flow Monitoring ECAM Entry None
OEB34 Issue 1	NAV ADR 1+2+3 FAULT ECAM Warning Undue Activation ECAM Entry NAV ADR 1+2+3 FAULT
<b>OEB35</b> <b>Issue 2</b>	<b>Loss of AP and ATHR Associated with Alternate Law Reversion</b> ECAM Entry None

The QRH LEOEB consists of:

The "Identification" field which identifies the OEB with its identification and issue number.

*Note: The FCOM OEB and associated QRH OEB PROC have the same OEB number in order to be consistent. However, the issue number of the QRH OEB PROC and the FCOM OEB may be different, because a revision of an FCOM OEB does not necessarily result in a revision of the corresponding QRH OEB PROC, that only provides the procedure part.*

Red OEB identification number and title are in bold font. White OEB identification number and title are in regular font. This enables the flight crew to easily review the OEBs before flight.

*Note: OEBs are listed in numerical order regardless of the type of OEB (red or white).*

The "Title" field provides the OEB title and the "ECAM Entry" part of the OEB PROC. This enables the flight crew to easily review the OEBs before flight particularly for Operators that use the OEB REMINDER function.

*Continued on the following page*



**GENERAL DESCRIPTION (Cont'd)**

**CAUTION**

When Airbus provides the Operator with the LEOEB, the information “ECAM Entry” does not necessarily mean that (for Operators using the OEB REMINDER function) the Operator’s maintenance personnel has activated the OEB REMINDER codes for this OEB onboard the aircraft. It is the Operator’s responsibility to define a suitable process for providing the flight crew with confirmation that the OEB REMINDER codes are activated for the ECAM alerts affected by OEBs.

A vertical bar in the margin of the QRH LEOEB identifies that the OEB is either new, revised or has an aircraft validity change.

Ident.: OEB-GEN-A-00014184.0001001 / 23 NOV 11

**REVIEW OF THE OEB**

In accordance with the Standard Operating Procedures, and before each flight, the flight crew must review all OEBs that are applicable to their aircraft. If the OEB conditions are applicable, the flight crew must apply the operational procedure(s) that is in the QRH OEB section.

Ident.: OEB-GEN-A-00014185.0001001 / 23 NOV 11

**DISTRIBUTION**

OEBs are distributed to all affected Operators. The Operators shall provide flight crews with the content of the OEB without delay.

Ident.: OEB-GEN-A-00014186.0001001 / 23 JUN 15

**OEB REMINDER FUNCTION**

The OEB reminder function provides operational help to the flight crew by enabling them to clearly identify on the ECAM all procedures and STATUS messages superseded by an OEB procedure. When a situation causes an ECAM warning/caution to trigger, a message informs the flight crew in real time that there is an OEB for the displayed ECAM warning/caution and/or STATUS, and as a result, that the ECAM procedure and/or STATUS is changed. In this case, a specific ECAM message informs the flight crew to refer to the QRH. For more information *Refer to FCOM DSC-31-OEB Reminder.*

The OEB reminder function may not be activated for some OEBs. For example, when an OEB procedure supersedes an ECAM procedure, under specific conditions only, the OEB reminder function is not activated, in order to let the flight crew assess the need to apply the OEB procedure or the ECAM procedure.

The OEB reminder function does not relieve the flight crew of their responsibility to review the applicable OEBs during the cockpit preparation.

*Continued on the following page*

**GENERAL DESCRIPTION (Cont'd)**

**OEB REMINDER CODE**

The maintenance personnel must enter specific OEB REMINDER code(s) in the FWC OEB database in order to update the ECAM.

These OEB REMINDER codes are provided in the FCOM OEB chapter only, and are sent to the Operator's Flight Operations department along with the associated QRH OEB PROC. This is to ensure that the OEB database is not updated before the OEB procedure is available in the QRH and FCOM onboard documentation.

Good coordination between the Airline's/Operator's Flight Operations department and the Airline's/Operator's Engineering department must be established, in order to:

- Ensure that the QRH OEB section is updated onboard the aircraft before the activation of the OEB REMINDER function for a specific OEB.
- Rapidly send information about the OEB REMINDER codes to the Engineering department for a rapid update of the ECAM.
- Provide the flight crew with confirmation that the OEB REMINDER codes are activated onboard the aircraft for the ECAM alerts affected by OEBs.

**CAUTION**

As soon as the maintenance personnel has embodied the corrective action that cancels the OEB on a specific aircraft, the Operator must ensure that:

1. Maintenance personnel has deactivated the OEB REMINDER function for the specific OEB, before informing their Flight Operations department of the installation of the OEB correction action.
2. The QRH OEB section onboard the aircraft is updated to remove the specific OEB from the applicable aircraft.

# **OPERATIONS ENGINEERING BULLETINS**

ERRONEOUS ALTERNATE FUEL  
PREDICTIONS UPON MODIFICATION OF  
A COMPANY ROUTE IN THE ALTERNATE  
FLIGHT PLAN

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**  
**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION**  
**OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**  
PRELIMINARY PAGES - TABLE OF CONTENTS

Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan..... A  
Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan..... B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**  
**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION**  
**OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**  
PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

**OEB41 Issue 3**

**Associated with QRH OEB Proc N°: OEB41/1.0**  
**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION**  
**OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**

Ident.: OEB-41-00013609.0001001 / 15 OCT 15

Applicable to: ALL

Approved by: Head of Airbus Flight Operations & Training Support

- This OEB covers a significant operational issue. Non-compliance with this OEB may have a significant impact on the operations of the aircraft. The Operators shall distribute its content to all flight crews without delay. An extract of this OEB is provided for insertion in the QRH.
- It is recommended that all Operators accelerate the incorporation of all corrective Service Bulletins as soon as they become available.

**Reason for issue:**

Issue 3:

This OEB is reissued to update the "Cancelled by" section with the name of the FMS standards cancelling the OEB. There is no technical change.

Issue 2:

This OEB is reissued to enhance the display of the MCDU FUEL PRED page (without technical change).

The objective is to address format standardization and enhanced readability.

Issue 1:

This OEB replaces the A320 OEB 204

This OEB is issued to inform the operators of the following: Erroneous alternate (ALTN ) fuel predictions are experienced when the flight crew modifies a company route (CO RTE ) previously inserted in the alternate Flight Plan (F-PLN).

This OEB provides an explanation and operational recommendations in case of erroneous ALTN fuel predictions.

**Applicable to:**

Aircraft with Honeywell FMGC Release 1A "H2" (MOD 38778, Airbus SB A320 22-1269 and MOD 38779, Airbus SB A320 22-1270)

**Cancelled by:**

FMS Honeywell standard H2C and subsequent.

The FMS standard H2C is installed by the following FMGC standards:

**OPERATIONS ENGINEERING BULLETINS  
ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION  
OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**

- FMGC standard H2CC14 (MOD 157166)
- FMGC standard H2CPC14 (MOD 161459)
- FMGC standard H2CI14 (MOD 156957)
- FMGC standard H2CPI13 (MOD 155494)

*Note: The interchangeability code, given in the Illustrated Part Catalog (IPC), indicates the conditions for interchangeability of equipment. After installation of corrective modification(s)/SB(s), if an Operator reinstalls any equipment affected by this OEB, it is the Operator's responsibility to ensure that the recommendations given in this OEB are applied again for the applicable aircraft.*

Operations Engineering Bulletins are issued by Airbus, as the need arises, to quickly transmit technical and procedural information. They are distributed to all FCOM holders and to others who need advice of changes to operational information.

The information in the OEB is recommended by Airbus, but may not be approved by Airworthiness Authorities. If the procedures contained in this OEB differ from the procedures in the AFM, the AFM remains the reference.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**  
**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION**  
**OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**

M	Localization	T	DU Title	DU identification	DU date
	OEB-41		Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan	00013609.0001001	15 OCT 15
	Criteria: P10762 <b>Applicable to: ALL</b>				
	OEB-41		Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan	00013610.0001001	15 OCT 15
	Criteria: P10762 <b>Applicable to: ALL</b>				

**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION  
OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN**

Ident.: OEB-41-00013610.0001001 / 15 OCT 15


Applicable to: ALL

**EXPLANATION**

When the flight crew modifies the CO RTE in the ALTN F-PLN , the FMS no longer computes the ALTN fuel predictions (refer to the below illustration).

This CO RTE could be extracted from the Navigation database or stored by the flight crew.

The modification of the CO RTE by the flight crew could be for example an entry of a departure or an arrival procedure.



The consequences of the CO RTE modification are:

- The fuel predictions are set to zero for the ALTN (solid circles) on FUEL PRED page (also on INIT FUEL PRED if done on ground)  
This condition is sufficient to apply the operational recommendations provided in the "PROCEDURE" paragraph.
- The Estimated Fuel On Board (EFOB ) and the predicted UTC (solid circles) at ALTN destination becomes equal to the EFOB and the UTC at the Primary Destination
- If the ALTN fuel and the MIN DEST FOB values on FUEL PRED page are both at their default value (i.e. have not been modified by the crew), the MIN DEST FOB (solid circle) becomes erroneous (equal to FINAL instead of FINAL+ ALTN ). Therefore, the MCDU scratchpad message "DEST EFOB BELOW MIN", is no longer triggered on the expected threshold
- If the flight crew had entered a value for the ALTN fuel, the entry is correctly used (but no more modifiable unless a new ALTN is entered)

*Continued on the following page*

**ERRONEOUS ALTERNATE FUEL PREDICTIONS UPON MODIFICATION**  
**OF A COMPANY ROUTE IN THE ALTERNATE FLIGHT PLAN (Cont'd)**

- If the flight crew had manually entered the MIN DEST FOB value on FUEL PRED page (but not the ALTN fuel value), then the message "CHECK MIN DEST FOB" is no longer triggered at the correct threshold

However, the new ALTN F-PLN is correctly displayed on the F-PLN page, the Navigation Display (ND ) and the INIT page correctly shows the ALTN identifier.

*Note: The EFOB of the primary destination remains correctly computed (dashed circle).*

The reason for the anomaly is that when the ALTN CO RTE is modified, the FMS erroneously assumes there is no alternate F-PLN anymore for the fuel predictions. An additional modification of the ALTN F-PLN enables to recover correct ALTN fuel predictions.

**PROCEDURE**

This procedure only applies when a CO RTE is used for ALTN F-PLN . In the case of ALTN fuel predictions erroneously set to zero further to a modification of this ALTN F-PLN:

ENTER manually a waypoint in the en-route F-PLN (neither in the departure, nor in the arrival), to start a new computation of ALTN fuel predictions

Maintain or delete the entered waypoint at convenience

Check the ALTN fuel predictions are correct

**CORRECTIVE ACTION**

Honeywell FMS standard H2C cancels this OEB (*Refer to OEB-41 Erroneous Alternate Fuel Predictions Upon Modification of a Company Route in the Alternate Flight Plan - Approval "Cancelled by" section*).

**END OF OEB41**

Intentionally left blank

# **OPERATIONS ENGINEERING BULLETINS**

NO ENGAGEMENT OF GUIDANCE MODE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**NO ENGAGEMENT OF GUIDANCE MODE**

PRELIMINARY PAGES - TABLE OF CONTENTS

No Engagement of Guidance Mode.....A  
No Engagement of Guidance Mode.....B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**OPERATIONS ENGINEERING BULLETINS**

**NO ENGAGEMENT OF GUIDANCE MODE**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**OEB46 Issue 1**  
**Associated with QRH OEB Proc N°: OEB46/1.0**  
**NO ENGAGEMENT OF GUIDANCE MODE**

Ident.: OEB-46-00015286.0001001 / 05 NOV 13

Applicable to: ALL

Approved by: Head of Airbus Flight Operations & Training Support

- This OEB covers a significant operational issue. Non-compliance with this OEB may have a significant impact on the operations of the aircraft. The Operators shall distribute its content to all flight crews without delay. An extract of this OEB is provided for insertion in the QRH.
- It is recommended that all Operators accelerate the incorporation of all corrective Service Bulletins as soon as they become available.

**Reason for issue:**

The objective of this OEB is to highlight that in the event of an erroneous Radio Altimeter (RA) height indication, guidance modes may not engage as expected.

**Applicable to:**

All A318/A319/A320/A321 aircraft equipped with the ELAC L97 standard (or subsequent ELAC standards).

**Cancelled by:**

FG C14 or FG PC14 or FG I15 or FG PI13 standards.

*Note: The interchangeability code, given in the Illustrated Part Catalog (IPC), indicates the conditions for interchangeability of equipment. After installation of corrective modification(s)/SB(s), if an Operator reinstalls any equipment affected by this OEB, it is the Operator's responsibility to ensure that the recommendations given in this OEB are applied again for the applicable aircraft.*

Operations Engineering Bulletins are issued by Airbus, as the need arises, to quickly transmit technical and procedural information. They are distributed to all FCOM holders and to others who need advice of changes to operational information.

The information in the OEB is recommended by Airbus, but may not be approved by Airworthiness Authorities. If the procedures contained in this OEB differ from the procedures in the AFM, the AFM remains the reference.

**OPERATIONS ENGINEERING BULLETINS**  
**NO ENGAGEMENT OF GUIDANCE MODE**

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

M	Localization	T	DU Title	DU identification	DU date
	OEB-46		No Engagement of Guidance Mode	00015286.0001001	05 NOV 13
	Criteria: 27-1234, 27-1243 <b>Applicable to: ALL</b>				
	OEB-46		No Engagement of Guidance Mode	00015287.0001001	05 NOV 13
	Criteria: 27-1234, 27-1243 <b>Applicable to: ALL</b>				

**NO ENGAGEMENT OF GUIDANCE MODE**

Ident.: OEB-46-00015287.0001001 / 05 NOV 13

Applicable to: ALL

**EXPLANATION**

If a RA transmits an erroneous height indication, this may have any of the following effects on the auto flight system depending on the flight phase. However, these effects may not necessarily occur in every case of an erroneous RA height indication.

Auto Flight System mode changes (indicated on FMA):

- NAV mode engagement is not possible after takeoff,
- In case of go-around and if the RA is still frozen at a very low height indication:
  - SRS and GA TRK modes engage,
  - NAV, HDG or TRK lateral modes cannot be selected,
  - LVR CLB will not be displayed on the FMA at THR RED ALT,
  - ALT\* and ALT will not engage at FCU altitude.

Disconnecting AP and resetting both FDs enable to recover basic mode (HDG and V/S).

**PROCEDURE**

■ **During go-around**

- **If SRS and GA TRK modes remain engaged and other guidance modes cannot be selected or engaged as expected:**

*Note:*

- *At the thrust reduction altitude, LVR CLB will not be displayed on the FMA,*
- *ALT\* and ALT will not engage at the FCU altitude.*

Disconnect APs.

Set both FDs to OFF then ON. FDs revert to basic modes (HDG - V/S).

Re-engage guidance modes as appropriate.

- **For the approach that follows the go-around:** Do not arm the G/S mode.

Flight crews must report, in the technical logbook, any of the above-listed consequences of erroneous RA height.

**CORRECTIVE ACTION**

FG C14 or FG PC14 or FG I15 or FG PI13.

**END OF OEB46**

Intentionally left blank

**PERFORMANCE**

Intentionally left blank

**PER-LOD Loading**

**PER-OPD Operating Data**

**PER-THR Thrust Ratings**

**PER-TOF Takeoff**

**PER-FPL Flight Planning**

**PER-CLB Climb**

**PER-CRZ Cruise**

**PER-HLD Holding**

**PER-DES Descent**

**PER-GOA Go Around**

**PER-LDG Landing**

**PER-OEI One Engine Inoperative**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**PRELIMINARY PAGES**  
TABLE OF CONTENTS

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

M	Localization	DU Title	DU identification	DU date
---	--------------	----------	-------------------	---------

No Temporary Documentary Unit



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**PRELIMINARY PAGES**

LIST OF EFFECTIVE TEMPORARY DOCUMENTARY UNITS

Intentionally left blank

**PERFORMANCE**

LOADING

Intentionally left blank

**PER-LOD-GEN GENERAL**

DEFINITIONS.....A

**PER-LOD-CGO CARGO LOADING**

GENERAL.....A

**PER-LOD-FUL FUEL**

USE OF MANUAL MAGNETIC INDICATORS (MMI).....A

**PER-LOD-WBA WEIGHT AND BALANCE**

**PER-LOD-WBA-LTS LOAD AND TRIM SHEET**

GENERAL.....A

DATA.....B

DESCRIPTION.....C

LOAD AND TRIM SHEET.....D

**PER-LOD-WBA-FIT FUEL INDEX TABLES**

**PER-LOD-WBA-FIT-10 FUEL INDEX TABLE**

GENERAL.....A

FUEL INDEX TABLE FOR INNER TANK.....B

FUEL INDEX TABLE FOR OUTER TANK.....C

FUEL INDEX TABLE FOR CENTER TANK.....D




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LOADING**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>LOADING</b></p> <p>GENERAL</p>
---	--

**DEFINITIONS**

Ident.: PER-LOD-GEN-00001661.0001001 / 09 DEC 09

Applicable to: ALL

**MANUFACTURER'S EMPTY WEIGHT (MEW)**

The weight of the structure, power plant, furnishings, systems and other items of equipment that are considered as integral part of the aircraft. It is essentially a "dry" weight, including only those fluids contained in closed systems (e.g. hydraulic fluid).

**OPERATIONAL EMPTY WEIGHT (OEW)**

The manufacturer's weight empty plus the operator's items i.e. the flight and cabin crew and their baggage, unusable fuel, engine oil, emergency equipment, toilet chemicals and fluids, galley structure, catering equipment, seats, documents etc.

**DRY OPERATING WEIGHT (DOW)**

The total weight of an aircraft ready for a specific type of operation excluding all usable fuel and traffic load.

Operational Empty Weight plus items specific to the type of flight i.e. catering, newspapers, pantry equipment etc.

**TAKEOFF FUEL**

The weight of the fuel onboard at takeoff.

**OPERATING WEIGHT**

The weight obtained by addition of the operational empty weight and the takeoff fuel.

**TOTAL TRAFFIC LOAD**

The weight of the payload including cargo loads, passengers and passengers bags.

**ZERO FUEL WEIGHT (ZFW)**

The weight obtained by addition of the total traffic load and the dry operating weight.

**TAKEOFF WEIGHT (TOW)**

The weight at takeoff. It is equal to the addition of the zero fuel weight and takeoff fuel.

**TRIP FUEL**

The weight of the fuel necessary to cover the normal leg without reserves.

**LANDING WEIGHT**

The weight at landing. It is equal to takeoff weight minus trip fuel.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**PERFORMANCE**

**LOADING**

GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p><b>PERFORMANCE</b></p> <p><b>LOADING</b></p> <p>CARGO LOADING</p>
---	--


**GENERAL**

Ident.: PER-LOD-CGO-00001662.0002001 / 09 DEC 09  
**Applicable to: ALL**

The aircraft has two lower deck cargo compartments :

- Forward cargo compartment, compartment 1.
- Aft cargo compartment, subdivided into compartments 3, 4 and 5.

The main access doors to forward and aft compartments are hydraulically operated.

A bulk cargo door  gives additional access to the aft cargo compartment. It is manually operated.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LOADING**

CARGO LOADING

Intentionally left blank

**USE OF MANUAL MAGNETIC INDICATORS (MMI)**


Applicable to: ALL

Ident.: PER-LOD-FUL-C-00001679.0007001 / 23 JUN 15

**GENERAL**

Indicators are installed as follows:

- Four in each wing tank: Three in the inner tank and one in the outer tank
- One in the center tank



**TO DETERMINE AIRCRAFT ATTITUDE**

Set ADIRS 1, 2, 3 to the NAV position.

On the LH or RH MCDU , press MCDU MENU pushbutton.

Select CFDS line key (LSK 4L).

Select SYSTEM REPORT/TEST line key (LSK 5L).

Select the line key adjacent to the FUEL indication.

On the MCDU control panel, push the NEXT PAGE key to display the FUEL Main Menu second page.

Select the line key adjacent to the INPUT PARAMETERS VALUES indication.

Use the Table given on the next page to determine the equivalent number and letter from PITCH and ROLL data.

Select RETURN line key (LSK 6L) until CFDS main menu appears.

Press MCDU MENU pushbutton.

**PERFORMANCE**

**LOADING**

**FUEL**

PITCH	REF	ROLL	REF
<b>Minus 1.5</b>	1	<b>Minus 1.5</b>	A
<b>Minus 1.0</b>	2	<b>Minus 1.0</b>	B
<b>Minus 0.5</b>	3	<b>Minus 0.5</b>	C
<b>0.0</b>	4	<b>0.0</b>	D
<b>Plus 0.5</b>	5	<b>Plus 0.5</b>	E
<b>Plus 1.0</b>	6	<b>Plus 1.0</b>	F
<b>Plus 1.5</b>	7	<b>Plus 1.5</b>	G

Note: 1. This procedure can only be used if:

- The PITCH and ROLL data is taken from the ADIRS (identified by an "A" after the PITCH and ROLL title).
- The PITCH data displayed for the LEFT, CTR, and RIGHT is no more or less than 0.1 of each other.
- The ROLL data displayed for the LEFT, CTR, and RIGHT is no more or less than 0.1 of each other.

2. The FQIS input parameters are not automatically updated. Use the NEXT PAGE control on the MCDU to cycle the pages to update the screen.

ACCESS PLATFORM.....IN POSITION

Ident.: PER-LOD-FUL-C-00001692.0001001 / 13 JAN 14

**TO DETERMINE FUEL QUANTITY IN THE OUTER TANK**

MMI number 5..... UNLOCK and WITHDRAW

The crewmember must withdraw the MMI slowly until he feels the magnetic attraction between the rod and float magnets.


Do not use force when withdrawing the MMI as this will disengage the float magnet from the rod magnet and bring the rod down onto the mechanical stop.

ROD GRADUATION (which aligns with bottom wing surface)..... READ MMI..... IN PLACE and LOCKED

Use the table for the applicable aircraft wing side, aircraft attitude (grid square letter and number), and the MMI stick number 5, to find the volume of fuel in the outer tank (See below).

Multiply the result by the specific gravity to find the fuel weight.

Note: The manual magnetic indication accuracy is around 5 %.

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PERFORMANCE</b></p> <p align="center"><b>LOADING</b></p> <p align="center">FUEL</p>
---	--

Ident.: PER-LOD-FUL-C-00001680.0003001 / 24 NOV 14

**TO DETERMINE FUEL QUANTITY IN THE INNER TANK**

MMI (from number 4 to number 2)..... UNLOCK and WITHDRAW

*The crewmember must withdraw the MMI slowly until he feels the magnetic attraction between the rod and float magnets.*

*Do not use force when withdrawing the MMI as this will disengage the float magnet from the rod magnet and bring the rod down onto the mechanical stop.*

ROD GRADUATION (which aligns with bottom wing surface)..... READ

MMI..... IN PLACE and LOCKED

*MMIs shall be withdrawn from number 4 to number 2 until one MMI measures fuel.*

Use the table for the applicable aircraft wing side, aircraft attitude (grid square letter and number), and the applicable MMI stick number to find the volume of fuel in the inner tank (Refer to FCOM - PER.LOD.FUL FUEL. C.USE OF MANUAL MAGNETIC INDICATORS (MMI) - WING TANKS).

Multiply the result by the specific gravity to find the fuel weight.

Note: *The manual magnetic indication accuracy is around 5 %.*

Ident.: PER-LOD-FUL-C-00009658.0001001 / 13 JAN 14

**TO DETERMINE FUEL QUANTITY IN THE CENTER TANK**

CENTER TANK MMI..... UNLOCK and WITHDRAW

*The crewmember must withdraw the MMI slowly until he feels the magnetic attraction between the rod and float magnets.*

*Do not use force when withdrawing the MMI as this will disengage the float magnet from the rod magnet and bring the rod down onto the mechanical stop.*

ROD GRADUATION (which aligns with bottom wing surface)..... READ

MMI..... IN PLACE and LOCKED

Use the table for the center tank, and for the applicable aircraft attitude (grid square letter and number) to find the volume of fuel in the center tank (See below).

Multiply the result by the specific gravity to find the fuel weight.

Note: *The manual magnetic indication accuracy is around 5 %.*

Ident.: PER-LOD-FUL-C-00001681.0004001 / 17 MAR 11

**WING TANKS (LITERS)**

M M I N <sup>o</sup>	R E A D I N G	LITERS ATTITUDE READING							R E A D I N G	LITERS ATTITUDE READING														
		A* LEFT WING				G				RIGHT WING				A		RIGHT WING			G		LEFT WING			
		1	2	3	4	5	6	7		1	2	3	4	5	6	7**	1	2	3	4	5	6	7	
2	2	2300	2250	2200	2200	2200	2200	2200	2	2850	2850	2850	2850	2850	2850	2800	2	2850	2850	2850	2850	2850	2850	2800
	4	2500	2450	2400	2400	2350	2350	2350	4	3050	3050	3050	3050	3050	3000	4	3050	3050	3050	3050	3050	3000	3000	
	6	2650	2600	2600	2600	2550	2500	2500	6	3200	3200	3200	3200	3200	3200	6	3200	3200	3200	3200	3200	3200	3150	
	8	2750	2750	2750	2700	2700	2650	2650	8	3300	3300	3300	3300	3300	3300	8	3300	3300	3300	3300	3300	3300	3250	
	10	2900	2900	2900	2900	2850	2850	2850	10	3500	3500	3500	3500	3450	3450	10	3500	3500	3500	3500	3450	3450	3400	
	12	3100	3100	3100	3100	3100	3050	3000	12	3650	3650	3600	3600	3600	3600	12	3650	3650	3600	3600	3600	3600	3600	
	14	3250	3250	3250	3250	3250	3250	3200	14	3800	3800	3750	3750	3750	3750	14	3800	3800	3750	3750	3750	3750	3750	
	16	3450	3450	3450	3450	3450	3400	3400	16	3950	3900	3900	3900	3900	3900	16	3950	3900	3900	3900	3900	3900	3900	
	18	3700	3650	3650	3650	3650	3600	3600	18	4050	4050	4050	4050	4050	4050	18	4050	4050	4050	4050	4050	4050	4050	
	20	3900	3900	3900	3900	3850	3850	3850	20	4200	4200	4200	4200	4200	4200	20	4200	4200	4200	4200	4200	4200	4200	
	22	4100	4100	4050	4050	4050	4050	4050	22	4250	4250	4250	4300	4300	4300	22	4250	4250	4250	4300	4300	4300	4300	
	24	4300	4300	4300	4300	4300	4300	4300	24	4400	4400	4400	4400	4450	4450	24	4400	4400	4400	4400	4450	4450	4450	
	26	4500	4500	4500	4500	4500	4500	4550	26	4500	4500	4550	4550	4550	4600	26	4500	4500	4550	4550	4550	4600	4600	
28	4700	4700	4750	4750	4750	4750	4750	28	4600	4650	4650	4700	4700	4800	28	4600	4650	4650	4700	4700	4750	4800		
30	4950	4950	4950	4950	5000	5000	5000	30	4750	4750	4800	4800	4850	4900	30	4750	4750	4800	4800	4850	4850	4900		
32	5100	5100	5150	5150	5150	5200	5200	32	4850	4850	4900	4900	4950	5000	32	4850	4850	4900	4900	4950	5000	5000		
	MAX								MAX							MAX								
3	2	4400	4350	4300	4250	4200	4150	4050	2	5050	5050	5100	5100	5100	5100	2	5050	5050	5100	5100	5100	5100	5100	
	4	4700	4700	4650	4600	4500	4400	4300	4	5150	5150	5200	5200	5200	5200	4	5150	5150	5200	5200	5200	5200	5200	
	6	4950	4950	4900	4850	4800	4700	4550	6	5250	5250	5300	5300	5300	5300	6	5250	5250	5300	5300	5300	5300	5300	
	8	5150	5100	5100	5050	5000	4950	4800	8	5350	5350	5400	5400	5400	5400	8	5350	5350	5400	5400	5400	5400	5400	
	10	5250	5250	5250	5250	5200	5150	5050	10	5450	5450	5500	5500	5500	5500	10	5450	5450	5500	5500	5500	5500	5500	
	12	5400	5400	5400	5400	5350	5300	5250	12	5500	5500	5550	5600	5600	5600	12	5500	5500	5550	5600	5600	5600	5650	
	14	5600	5600	5550	5550	5500	5500	5450	14	5600	5650	5650	5700	5700	5700	14	5600	5650	5650	5700	5700	5700	5750	
	16	5750	5750	5700	5700	5700	5650	5600	16	5650	5700	5700	5750	5750	5800	16	5650	5700	5700	5750	5750	5800	5800	
	18	5900	5900	5850	5850	5850	5850	5800	18	5800	5800	5850	5850	5900	5900	18	5800	5800	5850	5850	5900	5900	5950	
	20	6000	6000	6000	6000	6000	6000	6000	20	5900	5900	5950	5950	6000	6000	20	5900	5900	5950	5950	6000	6000	6050	

\* GRID SQUARE LETTER

\*\* GRID SQUARE NUMBER

**PERFORMANCE**

**LOADING**

**FUEL**

M M I N°	R E A D I N G	LITERS ATTITUDE READING							M M I N°	R E A D I N G	LITERS ATTITUDE READING						
		A LEFT WING				G RIGHT WING					A RIGHT WING				G LEFT WING		
		1	2	3	4	5	6	7			1	2	3	4	5	6	7
4	2	5700	5600	5550	5500	5450	5400	5300	2	6000	6050	6100	6100	6100	6100	6100	6100
	4	5850	5750	5700	5650	5600	5550	5500	4	6100	6100	6150	6150	6150	6150	6200	6200
	6	6000	5900	5850	5800	5750	5700	5650	6	6200	6200	6200	6250	6250	6250	6300	6300
	8	6150	6100	6050	6000	5950	5900	5850	8	6250	6300	6300	6350	6350	6350	6400	6400
	10	6300	6300	6250	6200	6150	6150	6100	10	6350	6400	6400	6400	6450	6450	6450	6450
	12	6450	6400	6400	6400	6350	6300	6250	12	6450	6450	6450	6500	6500	6550	6550	6550
	14	6550	6500	6500	6500	6500	6450	6450	14	6500	6550	6550	6550	6600	6600	6600	6650
	16	6600	6600	6600	6600	6600	6600	6550	16	6600	6600	6600	6650	6650	6700	6700	6750
	18	6650	6650	6650	6650	6650	6650	6650	18	6650	6700	6700	6750	6750	6750	6750	6800
	MAX								MAX								
5	2	650	600	550	550	550	500	500	2	700	700	700	700	700	700	700	700
	4	700	650	650	600	600	550	550	4	750	750	750	750	750	750	750	750
	6	750	700	700	650	650	650	600	6	800	800	800	800	750	750	750	750
	8	750	750	750	750	700	700	700	8	800	800	800	800	800	800	800	800
	10	800	800	800	750	750	750	750	10	850	850	850	850	850	850	850	850
	12	800	800	800	800	800	800	800	12	850	850	850	850	850	850	850	850
	14	850	850	850	850	850	850	850	14	850	850	850	850	850	850	850	850
	MAX	850	850	850	850	850	850	850	MAX	850	850	850	850	850	850	850	850

M M I N°	R E A D I N G	LITERS ATTITUDE READING							M M I N°	R E A D I N G	LITERS ATTITUDE READING						
		B* LEFT WING				F RIGHT WING					B RIGHT WING				F LEFT WING		
		1	2	3	4	5	6	7			1	2	3	4	5	6	7**
2	2	2350	2350	2300	2300	2250	2200	2200	2	2800	2750	2750	2750	2700	2700	2650	
	4	2550	2500	2500	2450	2450	2400	2400	4	2950	2950	2900	2900	2900	2900	2850	
	6	2750	2700	2700	2650	2650	2600	2600	6	3100	3100	3100	3100	3100	3050	3050	
	8	2850	2850	2800	2800	2800	2750	2750	8	3200	3200	3200	3200	3200	3200	3150	
	10	3000	3000	3000	3000	3000	2950	2900	10	3400	3400	3350	3350	3350	3350	3300	
	12	3150	3150	3200	3150	3150	3150	3100	12	3550	3550	3550	3550	3500	3500	3450	
	14	3350	3350	3350	3350	3350	3300	3300	14	3750	3700	3700	3700	3650	3650	3650	
	16	3550	3550	3550	3550	3500	3500	3450	16	3900	3850	3850	3850	3850	3800	3800	
	18	3750	3750	3750	3750	3700	3700	3650	18	4050	4000	4000	4000	4000	4000	3950	
	20	4000	3950	3950	3950	3950	3900	3900	20	4200	4150	4150	4150	4150	4150	4150	
	22	4150	4100	4100	4100	4100	4100	4100	22	4250	4250	4250	4250	4250	4250	4250	
	24	4300	4300	4300	4300	4300	4300	4300	24	4400	4400	4400	4400	4400	4400	4400	
	26	4500	4500	4500	4500	4500	4500	4500	26	4500	4500	4500	4550	4550	4550	4550	
	28	4700	4700	4700	4700	4700	4750	4750	28	4650	4650	4650	4650	4700	4700	4750	
	30	4850	4900	4900	4900	4950	4950	4950	30	4750	4750	4800	4800	4850	4850	4900	
	32	5050	5100	5100	5100	5100	5150	5150	32	4850	4900	4900	4950	4950	5000	5050	
MAX								MAX									
3	2	4550	4500	4500	4450	4400	4350	4300	2	5000	5000	5000	5000	5000	5000	4950	
	4	4800	4800	4800	4750	4650	4600	4500	4	5100	5100	5100	5100	5100	5100	5100	
	6	5050	5000	5000	5000	4900	4850	4750	6	5200	5200	5200	5250	5200	5200	5200	
	8	5150	5150	5150	5150	5100	5000	5000	8	5300	5300	5350	5350	5350	5350	5350	
	10	5300	5300	5300	5300	5250	5200	5150	10	5400	5400	5450	5450	5450	5450	5450	
	12	5450	5450	5450	5450	5400	5400	5350	12	5500	5500	5550	5550	5550	5550	5550	
	14	5600	5600	5600	5550	5550	5550	5500	14	5600	5600	5650	5650	5650	5650	5700	
	16	5700	5700	5700	5700	5700	5700	5700	16	5700	5700	5700	5750	5750	5750	5800	
	18	5850	5850	5850	5850	5850	5850	5850	18	5800	5800	5800	5850	5850	5850	5900	
	20	6000	6000	6050	6050	6050	6000	6000	20	5900	5900	5950	5950	6000	6000	6000	
MAX								MAX									

\* GRID SQUARE LETTER



**PERFORMANCE**

**LOADING**

**FUEL**

\*\* GRID SQUARE NUMBER

M I N	M M I N G	LITERS ATTITUDE READING							M I N	M M I N G	LITERS ATTITUDE READING						
		B LEFT WING				F RIGHT WING					B RIGHT WING				F LEFT WING		
		1	2	3	4	5	6	7			1	2	3	4	5	6	7
4	2								2	5950	5950	6100	6000	6050	6050	6050	
	4	5850	5750	5700	5650	5600	5600	5600	4	6050	6050	6100	6100	6100	6100	6150	
	6	6000	6000	5950	5900	5850	5800	5800	6	6150	6150	6200	6200	6200	6200	6200	
	8	6150	6150	6100	6100	6050	6000	6000	8	6250	6250	6250	6300	6300	6300	6300	
	10	6300	6300	6250	6250	6250	6200	6150	10	6350	6350	6350	6400	6400	6400	6400	
	12	6400	6400	6400	6400	6350	6350	6300	12	6400	6450	6450	6450	6500	6500	6500	
	14	6500	6500	6500	6500	6500	6500	6450	14	6500	6500	6550	6550	6600	6600	6600	
	16	6600	6600	6600	6600	6550	6550	6550	16	6600	6600	6600	6650	6650	6700	6700	
	18	6760	6770	6770	6770	6770	6770	6760	18	6750	6770	6800	6830	6850	6870	6880	
	MAX								MAX								
5	2	650	650	600	600	600	550	550	2	750	700	700	700	700	700	700	
	4	750	700	700	650	650	600	600	4	750	750	750	750	750	750	750	
	6	750	750	750	700	700	650	650	6	800	800	800	800	750	750	750	
	8	800	800	750	750	750	750	700	8	800	800	800	800	800	800	800	
	10	800	800	800	800	800	750	750	10	850	850	850	850	800	800	800	
	12	850	850	800	800	800	800	800	12	850	850	850	850	850	850	850	
	14	850	850	850	850	850	850	850	14	850	850	850	850	850	850	850	
	MAX	850	850	850	850	850	850	850	MAX	850	850	850	850	850	850	850	

M I N	M M I N G	LITERS ATTITUDE READING							M I N	M M I N G	LITERS ATTITUDE READING						
		C* LEFT WING				E RIGHT WING					C RIGHT WING				E LEFT WING		
		1	2	3	4	5	6	7			1	2	3	4	5	6	7**
2	2	2450	2400	2400	2400	2350	2350	2350	2	2700	2650	2650	2600	2600	2550	2550	
	4	2650	2600	2600	2600	2550	2550	2500	4	2850	2800	2800	2800	2800	2750	2750	
	6	2800	2800	2800	2800	2750	2750	2700	6	3000	3000	3000	3000	3000	2950	2900	
	8	2900	2900	2900	2900	2900	2850	2850	8	3100	3100	3100	3100	3100	3100	3050	
	10	3100	3100	3100	3100	3100	3050	3000	10	3300	3300	3300	3250	3250	3250	3200	
	12	3250	3250	3250	3250	3250	3250	3200	12	3450	3450	3450	3450	3450	3400	3350	
	14	3450	3450	3450	3450	3400	3400	3350	14	3650	3650	3600	3600	3600	3550	3550	
	16	3650	3650	3650	3600	3600	3550	3550	16	3800	3800	3800	3750	3750	3750	3700	
	18	3850	3850	3800	3800	3800	3750	3750	18	4000	3950	3950	3950	3900	3900	3900	
	20	4050	4050	4000	4000	4000	3950	3950	20	4150	4100	4100	4100	4100	4100	4100	
	22	4200	4200	4150	4150	4150	4100	4100	22	4250	4250	4200	4200	4200	4200	4200	
	24	4350	4350	4300	4300	4300	4300	4300	24	4350	4350	4350	4350	4350	4350	4350	
	26	4500	4500	4500	4500	4500	4500	4500	26	4500	4500	4500	4500	4500	4500	4550	
	28	4650	4650	4650	4700	4700	4700	4700	28	4650	4650	4650	4650	4700	4700	4700	
	30	4850	4850	4850	4850	4900	4900	4900	30	4750	4800	4800	4800	4850	4850	4850	
	32	5000	5000	5000	5050	5050	5100		32	4900	4900	4950	4950	5000	5000	5050	
MAX								MAX									
3	2	4650	4650	4650	4600	4600	4500	4500	2	4900	4900	4900	4900	4900	4850	4800	
	4	4900	4900	4900	4900	4900	4750	4650	4	5050	5100	5100	5100	5100	5100	5050	
	6	5100	5100	5100	5050	5050	5000	4900	6	5150	5200	5200	5200	5200	5150	5150	
	8	5200	5200	5200	5200	5200	5150	5100	8	5250	5300	5300	5300	5300	5300	5300	
	10	5300	5350	5350	5350	5300	5300	5250	10	5350	5400	5400	5400	5400	5400	5400	
	12	5450	5450	5450	5450	5450	5450	5400	12	5500	5500	5500	5500	5550	5550	5550	
	14	5600	5600	5600	5600	5600	5600	5550	14	5600	5600	5600	5650	5650	5650	5650	
	16	5700	5700	5700	5700	5700	5700	5700	16	5700	5700	5750	5750	5750	5750	5800	
	18	5800	5850	5850	5850	5850	5850	5850	18	5800	5800	5850	5850	5900	5900	5900	
	20	5950	5950	6000	6000	6000	6000	6000	20	5900	5950	5950	6000	6000	6000	6000	



\* GRID SQUARE LETTER

\*\* GRID SQUARE NUMBER

MMI <sup>Nº</sup>	READING	LITERS ATTITUDE READING							READING	LITERS ATTITUDE READING						
		C LEFT WING				E RIGHT WING				C RIGHT WING				E LEFT WING		
		1	2	3	4	5	6	7		1	2	3	4	5	6	7
4	2	5800	5750	5750	5700	5700	5700	5700	2	5900	5900	5900	5900	5950	5950	5950
	4	5950	5900	5900	5850	5850	5800	5800	4	6000	6000	6000	6050	6050	6050	
	6	6050	6050	6000	6000	6000	6000	5950	5950	6	6100	6100	6150	6150	6150	6150
	8	6200	6150	6150	6150	6150	6100	6100	8	6200	6250	6250	6250	6250	6250	6250
	10	6300	6300	6300	6300	6300	6250	6250	10	6300	6350	6350	6350	6350	6350	6350
	12	6400	6400	6400	6400	6400	6400	6400	12	6400	6400	6450	6450	6450	6450	6450
	14	6500	6500	6500	6500	6500	6500	6500	14	6500	6500	6550	6550	6550	6550	6550
	16	6600	6600	6600	6600	6600	6600	6600	16	6550	6600	6600	6600	6600	6600	6600
	18	6730	6740	6750	6750	6760	6760	6770	18	6750	6750	6770	6790	6800	6810	6820
	MAX								MAX							
5	2	700	700	650	650	600	600	600	2	750	700	700	700	700	650	650
	4	750	750	700	700	650	650	650	4	750	750	750	750	700	700	700
	6	750	750	750	750	700	700	700	6	800	800	750	750	750	750	750
	8	800	800	800	750	750	750	750	8	800	800	800	800	800	800	800
	10	800	800	800	800	800	800	800	10	850	850	850	800	800	800	800
	12	850	850	850	800	800	800	800	12	850	850	850	850	850	850	850
	14	850	850	850	850	850	850	850	14	900	900	850	850	850	850	850

MMI <sup>Nº</sup>	READING	LITERS ATTITUDE READING							READING	LITERS ATTITUDE READING							MMI <sup>Nº</sup>	
		D* BOTH WINGS								D BOTH WINGS								
		1	2	3	4	5	6	7		1	2	3	4	5	6	7**		
2	2	2550	2550	2500	2500	2450	2450	2450	2	5900	5850	5800	5800	5800	5800	5800		
	4	2750	2700	2700	2700	2650	2650	2600	4	6000	5950	5950	5950	5950	5950	5950		
	6	2900	2900	2850	2850	2850	2800	2800	6	6100	6100	6050	6050	6050	6050	6050		
	8	3000	3000	2950	2950	2950	2950	2900	8	6200	6200	6200	6200	6200	6200	6200		
	10	3200	3150	3150	3150	3150	3100	3050	10	6300	6300	6300	6300	6300	6300	6300		
	12	3350	3350	3350	3350	3300	3300	3250	12	6400	6400	6400	6400	6400	6400	6400		
	14	3550	3550	3550	3500	3500	3450	3450	14	6500	6500	6500	6500	6500	6500	6500		
	16	3750	3750	3700	3700	3650	3650	3600	16	6600	6600	6600	6600	6600	6600	6600		
	18	3950	3900	3900	3850	3850	3850	3800	18	6750	6750	6770	6800	6800	6810	6820		
	MAX								MAX									
	3	2	4350	4350	4350	4300	4300	4300	4300	2	700	700	700	650	650	650	600	
		4	4500	4500	4500	4500	4500	4500	4500	4	750	750	750	700	700	700	650	
		6	4750	4750	4750	4700	4700	4700	4700	6	800	800	750	750	750	750	700	
		8	4800	4800	4800	4850	4850	4850	4900	8	800	800	800	800	800	800	750	750
		10	4950	4950	5000	5000	5000	5050	5100	10	850	800	800	800	800	800	800	
		12	4950	4950	5000	5000	5000	5050	5100	12	850	850	850	850	850	850	850	
		14	4950	4950	5000	5000	5000	5050	5100	14	850	850	850	850	850	850	850	
		16	4950	4950	5000	5000	5000	5050	5100	MAX	850	850	850	850	850	850	850	
18		4950	4950	5000	5000	5000	5050	5100										
20		4950	4950	5000	5000	5000	5050	5100										
MAX																		
4		2	4800	4800	4800	4800	4750	4750	4600	2	700	700	700	650	650	650	600	
	4	5000	5000	5000	5000	4950	4900	4850	4	750	750	750	700	700	700	650		
	6	5100	5150	5150	5100	5100	5100	5050	6	800	800	800	800	800	800	750	750	
	8	5250	5250	5250	5250	5250	5200	5200	8	800	800	800	800	800	800	800		
	10	5350	5350	5350	5400	5400	5350	5350	10	850	800	800	800	800	800	800		
	12	5450	5500	5500	5500	5500	5500	5500	12	850	850	850	850	850	850	850		
	14	5600	5600	5600	5600	5600	5600	5600	14	850	850	850	850	850	850	850		
	16	5700	5700	5700	5750	5750	5750	5750	MAX	850	850	850	850	850	850	850		
	18	5800	5800	5850	5850	5850	5900	5900										
	20	5900	5900	5950	5950	5950	6000	6000										
MAX																		

- \* GRID SQUARE LETTER
- \*\* GRID SQUARE NUMBER

Ident.: PER-LOD-FUL-C-00001682.0001001 / 16 NOV 11

**CENTER TANK (LITERS)**

M M I N G	R E A D I N G	LITERS ATTITUDE MONITOR READING LINES A AND G*							M M I N G	R E A D I N G	LITERS ATTITUDE MONITOR READING LINES B AND F						
		1	2	3	4	5	6	7			1	2	3	4	5	6	7**
		2	300	300	350	350	350	350			350	2	300	300	300	300	300
4	400	450	450	500	500	500	500	4	400	450	450	450	500	500	500		
6	600	600	650	650	650	650	650	6	600	600	650	650	650	650	600		
8	750	750	750	750	750	750	750	8	750	750	750	750	750	750	750		
10	900	850	850	850	850	850	900	10	900	850	850	850	850	850	900		
12	1050	1000	1000	1000	1000	1000	1050	12	1050	1000	1000	1000	1000	1000	1050		
14	1250	1250	1200	1200	1200	1200	1200	14	1250	1200	1200	1200	1200	1200	1200		
16	1450	1450	1400	1400	1400	1400	1400	16	1450	1450	1450	1450	1400	1400	1400		
18	1650	1650	1600	1600	1600	1600	1600	18	1700	1700	1650	1650	1600	1600	1600		
20	1900	1850	1850	1850	1850	1800	1800	20	1900	1900	1900	1850	1850	1850	1800		
22	2100	2050	2050	2050	2050	2000	2000	22	2100	2100	2100	2050	2050	2000	2000		
24	2300	2250	2250	2250	2200	2200	2150	24	2300	2300	2250	2250	2200	2200	2150		
26	2450	2450	2450	2450	2450	2400	2350	26	2500	2500	2450	2450	2400	2350	2350		
28	2700	2650	2650	2650	2600	2550	2550	28	2700	2700	2650	2650	2600	2550	2500		
30	2900	2850	2850	2850	2800	2800	2750	30	2900	2900	2900	2850	2800	2800	2750		
32	3050	3050	3050	3050	3000	3000	2950	32	3100	3100	3100	3050	3050	3000	2950		
34	3250	3250	3250	3250	3200	3200	3150	34	3300	3300	3300	3250	3250	3200	3150		
36	3500	3500	3450	3450	3450	3400	3400	36	3500	3500	3500	3450	3450	3400	3400		
38	3700	3700	3700	3700	3650	3650	3600	38	3700	3700	3700	3700	3650	3650	3600		
40	3900	3900	3900	3900	3900	3850	3800	40	3950	3950	3950	3900	3900	3850	3800		
42	4100	4100	4100	4100	4100	4050	4050	42	4150	4150	4150	4100	4100	4050	4000		
44	4350	4350	4350	4300	4300	4250	4250	44	4350	4350	4350	4300	4300	4250	4200		
46	4550	4550	4550	4550	4500	4500	4450	46	4550	4550	4550	4550	4500	4500	4450		
48	4750	4750	4750	4700	4700	4650	4650	48	4750	4750	4750	4750	4700	4700	4650		
50	4950	4950	4950	4950	4900	4900	4850	50	4950	4950	4950	4950	4900	4900	4850		
52	5150	5150	5150	5150	5100	5100	5050	52	5150	5150	5150	5150	5150	5100	5050		
54	5400	5400	5400	5400	5350	5300	5250	54	5400	5400	5400	5400	5350	5300	5250		
56	5600	5600	5600	5600	5550	5500	5450	56	5600	5600	5600	5600	5550	5500	5450		
58	5800	5800	5800	5750	5750	5700	5650	58	5800	5800	5800	5800	5750	5750	5700		
60	6000	6000	6000	5950	5950	5900	5900	60	6000	6000	6000	6000	5950	5950	5900		
62	6200	6200	6200	6150	6150	6100	6100	62	6200	6200	6200	6200	6150	6150	6100		
64	6400	6400	6400	6400	6350	6300	6300	64	6400	6400	6400	6400	6350	6350	6300		
66	6600	6600	6600	6600	6550	6550	6500	66	6600	6600	6600	6600	6550	6550	6500		
68	6800	6800	6750	6750	6750	6700	6700	68	6800	6800	6800	6800	6750	6750	6700		
70	7000	6950	6950	6950	6900	6900	6900	70	7000	7000	7000	6950	6950	6950	6900		
72	7200	7200	7150	7150	7100	7100	7050	72	7200	7200	7150	7150	7150	7100	7100		
74	7400	7400	7350	7350	7300	7300	7300	74	7400	7400	7350	7350	7350	7300	7300		
76	7600	7600	7600	7550	7550	7500	7500	76	7600	7600	7600	7550	7550	7500	7500		
78	7850	7800	7800	7800	7750	7700	7700	78	7800	7800	7800	7750	7750	7700	7700		
MAX	7950	7900	7900	7900	7850	7800	7800	MAX	7900	7900	7850	7850	7850	7800	7800		

**PERFORMANCE**

**LOADING**

**FUEL**


M M I N G	LITERS ATTITUDE MONITOR READING LINES C AND E						
	1	2	3	4	5	6	7
	2	250	300	300	300	300	300
4	400	450	450	500	500	500	450
6	600	600	650	650	650	600	600
8	750	750	750	750	750	750	750
10	850	850	850	850	850	850	850
12	1050	1000	1000	1000	1000	1000	1000
14	1250	1200	1200	1200	1200	1200	1200
16	1450	1450	1450	1400	1400	1400	1400
18	1650	1650	1650	1650	1600	1600	1600
20	1900	1900	1900	1900	1900	1850	1800
22	2100	2100	2100	2100	2050	2050	2000
24	2300	2300	2250	2250	2250	2200	2200
26	2500	2500	2450	2450	2400	2400	2350
28	2700	2650	2650	2650	2600	2600	2550
30	2900	2900	2850	2850	2800	2800	2750
32	3100	3100	3100	3100	3050	3050	3000
34	3300	3300	3300	3250	3250	3200	3200
36	3500	3500	3500	3500	3450	3450	3400
38	3700	3700	3700	3700	3700	3650	3600
40	3950	3950	3950	3950	3900	3900	3850
42	4150	4150	4150	4150	4100	4100	4050
44	4350	4350	4350	4350	4300	4300	4250
46	4550	4550	4550	4550	4500	4500	4450
48	4750	4750	4750	4750	4750	4700	4650
50	4950	4950	4950	4950	4900	4900	4850
52	5150	5150	5150	5150	5100	5100	5050
54	5400	5400	5400	5400	5350	5300	5250
56	5600	5600	5600	5600	5550	5500	5450
58	5800	5800	5800	5800	5750	5700	5650
60	6000	6000	6000	6000	5950	5950	5900
62	6200	6200	6200	6200	6150	6100	6100
64	6400	6400	6400	6400	6350	6300	6300
66	6600	6600	6600	6600	6550	6550	6500
68	6800	6800	6800	6750	6750	6700	6700
70	7000	7000	7000	6950	6950	6900	6900
72	7200	7200	7150	7150	7150	7150	7100
74	7400	7400	7400	7350	7350	7300	7300
76	7600	7600	7600	7550	7550	7500	7500
78	7800	7800	7800	7750	7750	7700	7700
MAX	7900	7900	7850	7850	7850	7800	7800

M M I N G	LITERS ATTITUDE MONITOR READING LINES D						
	1	2	3	4	5	6	7
	2	300	300	300	300	300	300
4	450	450	500	500	500	500	500
6	600	600	650	650	650	650	600
8	750	750	750	750	750	750	750
10	900	900	900	900	900	900	900
12	1050	1000	1000	1000	1000	1000	1050
14	1250	1250	1200	1200	1200	1200	1200
16	1500	1450	1450	1450	1450	1400	1400
18	1700	1700	1700	1650	1650	1650	1600
20	1900	1900	1900	1900	1900	1850	1850
22	2100	2100	2100	2100	2050	2050	2000
24	2300	2300	2300	2250	2250	2200	2200
26	2500	2500	2450	2450	2400	2400	2350
28	2700	2700	2700	2650	2600	2600	2550
30	2900	2900	2900	2900	2850	2850	2750
32	3100	3100	3100	3100	3050	3050	3000
34	3300	3300	3300	3300	3250	3250	3200
36	3500	3500	3500	3500	3450	3450	3400
38	3700	3750	3750	3750	3700	3700	3650
40	3950	3950	3950	3950	3900	3900	3850
42	4150	4150	4150	4150	4100	4100	4050
44	4350	4350	4350	4350	4300	4300	4250
46	4550	4550	4550	4550	4500	4500	4450
48	4750	4750	4750	4750	4750	4700	4650
50	4950	4950	4950	4950	4900	4900	4850
52	5200	5200	5200	5150	5100	5100	5050
54	5400	5400	5400	5400	5350	5300	5250
56	5600	5600	5600	5600	5550	5500	5450
58	5800	5800	5800	5800	5750	5700	5650
60	6000	6000	6000	6000	5950	5950	5900
62	6200	6200	6200	6200	6150	6150	6100
64	6400	6400	6400	6400	6350	6350	6300
66	6600	6600	6600	6600	6550	6550	6500
68	6800	6800	6800	6800	6750	6750	6700
70	7000	7000	7000	7000	6950	6950	6900
72	7200	7200	7200	7150	7150	7150	7100
74	7400	7400	7400	7350	7350	7350	7300
76	7600	7600	7600	7550	7550	7550	7500
78	7800	7800	7800	7750	7750	7700	7700
MAX	7900	7900	7900	7900	7850	7850	7800

\* GRID SQUARE LETTER

\*\* GRID SQUARE NUMBER

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p><b>PERFORMANCE</b></p> <p><b>LOADING</b></p> <p>WEIGHT AND BALANCE - LOAD AND TRIM SHEET</p>
---	---

**GENERAL**

Ident.: PER-LOD-WBA-LTS-00001685.0001001 / 09 DEC 09  
**Applicable to: ALL**

This chart allows the determination of Aircraft CG location (MAC) function of dry operating weight, pantry adjustment, cargo loads, passengers and fuel on board.  
The operational limits shown on the load and trim sheet are more restrictive than the certified limits because error margins have been taken into account.

The load and trim sheet needs to be updated when :

- a modification which changes the aircraft certified limits is included or
- a modification (cabin layout, cargo arrangement ...) which influences the operational limits is made.

It is the airline responsibility to define a load and trim sheet and to keep it up to date. *Refer to PER-LOD-WBA-LTS DESCRIPTION* is a description of the Load and Trim Sheet utilization (*Refer to PER-LOD-WBA-LTS LOAD AND TRIM SHEET*), for a typical passenger arrangement.  
Refer to customized load and trim sheet for preparing a revenue flight.

**DATA**

Ident.: PER-LOD-WBA-LTS-00001686.0002001 / 23 JUN 15  
**Applicable to: ALL**

Dry Operating Weight = 42 500 kg and CG = 27 % (H-arm = 18.93 m)  
Deviation or adjustment = +100 kg in zone F  
Cargo = 5 500 kg with the following distribution:  
cargo 1 = 2 000 kg; cargo 3 = 1 500 kg; cargo 4 = 1 500 kg; cargo 5 = 500 kg  
Passengers = 145 PAX with the following distribution:  
cabin OA = 50; cabin OB = 55; cabin OC = 40  
Ramp Fuel = 13 200 kg; Taxi Fuel = 200 kg; Fuel Density = 0.785 kg/l

**DESCRIPTION**

Ident.: PER-LOD-WBA-LTS-00001687.0002001 / 12 FEB 11

Applicable to: ALL

- a. Enter Master data in (1).
- b. Compute Dry Operating Weight Index using the formula indicated in (2) and report in (3).
- c. Dry Operating Index = 53.4.
- d. Enter weight deviation or adjustment in (4) and read corresponding index variation in (5): +1.43.
- e. Calculate corrected index and report in (6): 54.83.
- f. Enter master data in table (7) and determine Zero Fuel Weight: 60 280 kg and Takeoff Weight: 73 280 kg.
- g. Enter cargo weight and passenger number per compartment in (8).
- h. Enter index scale (9) with corrected index and proceed through cargo and passenger scales (10).
- i. From the final point draw a vertical line which intersects (12) the zero fuel weight horizontal line (11).
- j. Check if the intersection point is within the Zero Fuel Weight operational limits, if not rearrange cargo loading.
- k. Read in table (13) the fuel index correction corresponding to Ramp Fuel Weight (13 200 kg) and Fuel Density (0.785 kg/l).  
 This example will be continued assuming the FUEL INDEX = -2 was found. Carry in fuel scale (14).
- l. From this point draw a vertical line which intersects (16) the takeoff weight horizontal line (15).
- m. Check if the intersection point is within the Takeoff Weight operational limits.
- n. Read zero fuel weight and CG position: 32.7 % and fill in table (17).
- o. Read takeoff CG position: 30.5 % and fill in table (18).

**CAUTION**

If there is no customized trim sheet for your airline in this section, do not use the information enclosed herein for day to day operation as margins and load CG vary with cabin and cargo layout.

*Note:* When referring to CG lower than 27 %, an operational margin is taken into account. It is the reason why performance at forward CG (lower than 25 %) must be used for operational CG lower than 27 %.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LOADING**

WEIGHT AND BALANCE - LOAD AND TRIM SHEET

**LOAD AND TRIM SHEET**

Ident.: PER-LOD-WBA-LTS-00001688.0002001 / 23 FEB 11

Applicable to: ALL

<b>AIRBUS</b>	<b>LOAD and TRIM SHEET</b>	A320-200 VERSION : 180 YC
---------------	----------------------------	------------------------------

<b>DRY OPERATING WEIGHT CONDITIONS</b> WEIGHT (kg)    H-one (m) ① <b>42 500</b> <b>18.93</b> ② H-stem: 18.5493 x W 1.00    + 50 ③ <b>WY OPERATING WEIGHT INDEX</b> <b>53.4</b>	<b>AIRCRAFT REGISTER:</b> DATE:    PREPARED BY: FLT No:    CAPT. SIGNATURE: FROM:    TO:	<b>DRY OPERATING WEIGHT</b> <b>42 500</b> <b>WEIGHT DEVIATION (FAVOUR)</b> <b>+ 100</b> <b>CORRECTED DRY OPERATING WEIGHT</b> <b>42 600</b> <b>CARGO</b> <b>+ 5 500</b> <b>PASSENGERS:</b> 114.15 x 18.12 = ⑦ <b>+ 12 180</b> <b>ZERO FUEL WEIGHT</b> <b>60 280</b> <b>RAMP FUEL:</b> <b>+ 13 200</b> <b>TAXI FUEL</b> <b>= 200</b> <b>TAKEOFF WEIGHT</b> <b>73 280</b>
---	---	---

④ ZONES WEIGHT DEVIATION (kg) D    +100	
---	--

<b>BASIC INDEX CORRECTION</b> DRY OPERAT. WEIGHT DEVIATION +100 kg    -1.22    +1.43 -100 kg    +1.22    -1.43	⑤ INDEX CORRECTION <b>1.43</b> ⑥ CORRECTED INDEX <b>54.83</b>
---	--

⑧ <table border="1" style="width:100%; border-collapse: collapse;"> <tr><th>ITEMS</th><th>NO</th><th>WEIGHT(kg)</th></tr> <tr><td>CARGO 1</td><td></td><td>2000</td></tr> <tr><td>CARGO 3</td><td></td><td>1500</td></tr> <tr><td>CARGO 4</td><td></td><td>1500</td></tr> <tr><td>CARGO 5</td><td></td><td>500</td></tr> <tr><td>CABIN OA</td><td>50</td><td></td></tr> <tr><td>CABIN OB</td><td>55</td><td></td></tr> <tr><td>CABIN OC</td><td>40</td><td></td></tr> </table>	ITEMS	NO	WEIGHT(kg)	CARGO 1		2000	CARGO 3		1500	CARGO 4		1500	CARGO 5		500	CABIN OA	50		CABIN OB	55		CABIN OC	40		
ITEMS	NO	WEIGHT(kg)																							
CARGO 1		2000																							
CARGO 3		1500																							
CARGO 4		1500																							
CARGO 5		500																							
CABIN OA	50																								
CABIN OB	55																								
CABIN OC	40																								

⑬ <b>FUEL INDEX CORRECTION</b> density 0.785 kg/l ⑭ index: weight (kg)    index: 3500 +1 11500 -2 4000 +1 12000 -2 4500 +0 12500 -2 5000 +0 13000 -2 5500 -1 13500 -3 6000 -1 14000 -4 6500 -2 14500 -4 7000 -2 15000 -5 7500 -2 15500 -6 8000 -3 16000 -7 8500 -3 16500 -8 9000 -3 17000 -9 9500 -3 17500 -9 10000 -3 18000 -10 10500 -3 18500 -11 11000 -3 FULL -11	⑮ <b>FUEL INDEX CORRECTION</b> ⑯ <b>MTOW = 77 000 kg</b> ⑰ <b>M1W = 64 800 kg</b> ⑱ <b>M2FW = 61 000 kg</b> ⑲ <b>GENERIC EXAMPLE</b> Irrelevant Data ! Do Not Use For Operational Purpose ! OPERATIONAL LIMITS: --- TAKEOFF --- ZFW
---	--

⑱ <b>TAKEOFF</b> CG % MAC    ⑳ 10   ㉑ 15	㉒ <b>ZFW CDU INPUT</b> WEIGHT (kg x 1000)    AIRCRAFT CG (% MAC) 18   10   13   13   12   17
---	--

CAUTION: WHEN THE T.O. CG IS LOWER THAN 97% MAC THE BASIC PERFORMANCE MUST BE CORRECTED  
 \* T.O. : Make CG correction at use appropriate RTOW chart.  
 - LOG : Make CG correction at LOG speed and distance.



**FUEL INDEX TABLE**

**GENERAL**

Ident.: PER-LOD-WBA-FIT-10-00012775.0002001 / 21 MAR 17

Applicable to: ALL

The fuel index table has been established assuming a fuel distribution in accordance with refuel distribution given in section *Refer to DSC-28-10-70 Refueling - Defueling* of this volume. If after refueling the actual distribution deviates from the chart values, the actual and the trim sheet CG will show a discrepancy. The following tables allow to determine the fuel index taking into account the actual fuel quantity in each tank. To determine the actual takeoff CG enter the tables with the actual fuel quantities in each tank, read the fuel index for each tank and use their sum to enter the trim sheet. Check that the actual CG is inside the operational limits. If the CG is outside the limits transfer fuel to achieve a distribution in accordance with the chart or rearrange the load.

Note: These tables are valid only when used with the following formula for the index:

$$I = W \times (H\text{-arm} - 18.85) / 1\,000 + K \text{ or } I = [(CG - 25) \times W \times 0.000042] + K$$

(Weight in kg, H-arm in m)

DATA : Fuel in left inner fuel tank = 4 500 kg  
 Fuel in right inner fuel tank = 4 500 kg  
 Fuel in left outer fuel tank = 200 kg  
 Fuel in right outer fuel tank = FULL  
 Fuel in center tank = 0 kg

		Weight	Index	
Inner tank	Left	4 500	-	3
	Right	4 500	-	3
Outer tank	Left	200		0
	Right	691	+	2
Center tank		0		0
TOTAL		9 891	-	4

Enter the trim sheet with a fuel index of -4



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LOADING**

WEIGHT AND BALANCE - FUEL INDEX TABLES

**FUEL INDEX TABLE FOR INNER TANK**

Ident.: PER-LOD-WBA-FIT-10-00012776.0001001 / 25 JUL 12

Applicable to: ALL

Note: These tables are valid only when used with the following formulae for the index:  
 $I=W \times (H\text{-arm} - 18.85) / 1\ 000 + K$  or  $I=[(CG-25) \times W \times 0.000042] + K$  (Weight in kg, H-arm in m)

Weight	Index
500	-1
1 000	-1
1 500	-2
2 000	-2
2 500	-2
3 000	-3
3 500	-3
4 000	-3
4 500	-3
5 000	-3
FULL	-2

**FUEL INDEX TABLE FOR OUTER TANK**

Ident.: PER-LOD-WBA-FIT-10-00012777.0001001 / 25 JUL 12

Applicable to: ALL

Note: These tables are valid only when used with the following formulae for the index:  
 $I=W \times (H\text{-arm} - 18.85) / 1\ 000 + K$  or  $I=[(CG-25) \times W \times 0.000042] + K$  (Weight in kg, H-arm in m)

Weight	Index
250	1
500	1
FULL	2



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LOADING

WEIGHT AND BALANCE - FUEL INDEX TABLES

### FUEL INDEX TABLE FOR CENTER TANK

Ident.: PER-LOD-WBA-FIT-10-00012778.0001001 / 25 JUL 12

Applicable to: ALL

Note: These tables are valid only when used with the following formulae for the index:  
 $I = W \times (H - \text{arm} - 18.85) / 1\,000 + K$  or  $I = [(CG - 25) \times W \times 0.000042] + K$  (Weight in kg, H-arm in m)

Weight	Index
500	-1
1 000	-1
1 500	-2
2 000	-3
2 500	-3
3 000	-4
3 500	-5
4 000	-6
4 500	-7
5 000	-7
5 500	-8
6 000	-9
FULL	-10



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LOADING

WEIGHT AND BALANCE - FUEL INDEX TABLES

Intentionally left blank

# PERFORMANCE

OPERATING DATA

Intentionally left blank

**PER-OPD-GEN GENERAL**

CONVERSIONS - IAS . MACH - TAS . MACH - SAT . TAT.....	A
INTERNATIONAL STANDARD ATMOSPHERE (ISA).....	B
CONVERSIONS - QNH - QFE - PRESSURE ALTITUDE.....	C
CONVERSIONS QFE HPA - IN. HG - FT.....	D
WIND COMPONENTS (FOR TAKEOFF AND LANDING).....	E
ALTITUDE TEMPERATURE CORRECTION.....	F

**PER-OPD-CON GROUND DISTANCE/AIR DISTANCE CONVERSION**

**PER-OPD-CON-AEO ALL ENGINES OPERATIVE**

GENERAL.....	A
M.78.....	B
LONG RANGE SPEED UP TO FL270.....	C
LONG RANGE SPEED ABOVE FL270.....	D

**PER-OPD-CON-OEI ONE ENGINE INOPERATIVE**

GENERAL.....	A
LONG RANGE SPEED.....	B
FIXED SPEEDS.....	C



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**OPERATING DATA**

PRELIMINARY PAGES - TABLE OF CONTENTS


Intentionally left blank



**CONVERSIONS - IAS . MACH - TAS . MACH - SAT . TAT**

Ident.: PER-OPD-GEN-00001962.0001001 / 23 FEB 11

Applicable to: ALL



**INTERNATIONAL STANDARD ATMOSPHERE (ISA)**

Ident.: PER-OPD-GEN-00001963.0001001 / 09 DEC 09


Applicable to: ALL

ALTITUDE (Feet)	TEMP (°C)	PRESSURE			PRESSURE RATIO $\sigma = P / P_0$	DENSITY $\rho = \rho / \rho_0$	SPEED OF SOUND (a) (kt)	ALTITUDE (meters)
		hPa	PS.I.	in. Hg.				
40,000	-56.5	188	2.72	5.54	0.1851	0.2462	573	12,192
39,000	-56.5	197	2.85	5.81	0.1942	0.2563	573	11,887
38,000	-56.5	206	2.99	6.10	0.2038	0.2710	573	11,582
37,000	-56.5	217	3.14	6.40	0.2138	0.2844	573	11,278
36,000	-56.3	227	3.30	6.71	0.2243	0.2961	573	10,973
35,000	-54.3	238	3.46	7.04	0.2353	0.3099	576	10,668
34,000	-52.4	250	3.63	7.38	0.2467	0.3220	579	10,363
33,000	-50.4	262	3.80	7.74	0.2586	0.3345	581	10,058
32,000	-48.4	274	3.98	8.11	0.2709	0.3473	584	9,754
31,000	-46.4	287	4.17	8.49	0.2837	0.3605	586	9,449
30,000	-44.4	301	4.36	8.89	0.2970	0.3741	589	9,144
29,000	-42.5	315	4.57	9.30	0.3107	0.3881	591	8,839
28,000	-40.5	329	4.78	9.73	0.3250	0.4025	594	8,534
27,000	-38.5	344	4.99	10.17	0.3398	0.4173	597	8,230
26,000	-36.5	360	5.22	10.63	0.3552	0.4325	599	7,925
25,000	-34.5	376	5.45	11.10	0.3711	0.4481	602	7,620
24,000	-32.5	393	5.70	11.60	0.3876	0.4642	604	7,315
23,000	-30.6	410	5.95	12.11	0.4046	0.4806	607	7,010
22,000	-28.6	428	6.21	12.64	0.4223	0.4975	609	6,706
21,000	-26.6	446	6.47	13.18	0.4406	0.5150	611	6,401
20,000	-24.6	466	6.75	13.75	0.4595	0.5328	614	6,096
19,000	-22.6	485	7.04	14.34	0.4791	0.5511	616	5,791
18,000	-20.7	506	7.34	14.94	0.4994	0.5699	619	5,486
17,000	-18.7	527	7.65	15.57	0.5203	0.5892	621	5,182
16,000	-16.7	549	7.97	16.22	0.5420	0.6090	624	4,877
15,000	-14.7	572	8.29	16.89	0.5643	0.6292	626	4,572
14,000	-12.7	595	8.63	17.58	0.5875	0.6500	628	4,267
13,000	-10.8	619	8.99	18.29	0.6113	0.6713	631	3,962
12,000	-8.8	644	9.35	19.03	0.6360	0.6932	633	3,658
11,000	-6.8	670	9.72	19.79	0.6614	0.7156	636	3,353
10,000	-4.8	697	10.10	20.58	0.6877	0.7385	638	3,048
9,000	-2.8	724	10.51	21.39	0.7148	0.7620	640	2,743
8,000	-0.8	753	10.92	22.22	0.7428	0.7860	643	2,438
7,000	+1.1	782	11.34	23.09	0.7716	0.8106	645	2,134
6,000	+3.1	812	11.78	23.98	0.8014	0.8359	647	1,829
5,000	+5.1	843	12.23	24.90	0.8320	0.8617	650	1,524
4,000	+7.1	875	12.69	25.84	0.8637	0.8881	652	1,219
3,000	+9.1	908	13.17	26.82	0.8962	0.9151	654	914
2,000	+11.0	942	13.67	27.82	0.9298	0.9428	656	610
1,000	+13.0	977	14.17	28.86	0.9644	0.9711	659	305
0	+15.0	1013	14.70	29.92	1.0000	1.0000	661	0
-1,000	+17.0	1050	15.23	31.02	1.0366	1.0295	664	-305

**CONVERSIONS - QNH - QFE - PRESSURE ALTITUDE**

Ident.: PER-OPD-GEN-00001964.0001001 / 09 DEC 09

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE  
OPERATING DATA**

GENERAL

**CONVERSIONS QFE HPA - IN. HG - FT**

Ident.: PER-OPD-GEN-00001965.0001001 / 08 FEB 11

Applicable to: ALL

QFE hPa	in. Hg	PRESS. ALT. ft	QFE hPa	in. Hg	PRESS. ALT. ft	QFE hPa	in. Hg	PRESS. ALT. ft
1050	31.01	- 989	960	28.35	1486	870	25.69	4157
1048	30.95	- 936	958	28.29	1543	868	25.63	4219
1046	30.89	- 883	956	28.23	1601	866	25.57	4281
1044	30.83	- 830	954	28.17	1658	864	25.51	4343
1042	30.77	- 776	952	28.11	1715	862	25.45	4405
1040	30.71	- 723	950	28.05	1773	860	25.40	4468
1038	30.65	- 669	948	27.99	1831	858	25.34	4531
1036	30.59	- 615	946	27.94	1889	856	25.28	4593
1034	30.53	- 562	944	27.88	1947	854	25.22	4656
1032	30.47	- 508	942	27.82	2005	852	25.16	4718
1030	30.42	- 454	940	27.76	2062	850	25.10	4781
1028	30.36	- 400	938	27.70	2120	848	25.04	4844
1026	30.30	- 346	936	27.64	2178	846	24.98	4907
1024	30.24	- 292	934	27.58	2236	844	24.92	4970
1022	30.18	- 238	932	27.52	2294	842	24.86	5033
1020	30.12	- 184	930	27.46	2353	840	24.81	5097
1018	30.06	- 129	928	27.40	2412	838	24.75	5161
1016	30.00	- 74	926	27.34	2471	836	24.69	5225
1014	29.94	- 20	924	27.29	2530	834	24.63	5289
1012	29.88	34	922	27.23	2589	832	24.57	5353
1010	29.83	89	920	27.17	2647	830	24.51	5417
1008	29.77	144	918	27.11	2707	828	24.45	5481
1006	29.71	199	916	27.05	2767	826	24.39	5545
1004	29.65	254	914	26.99	2826	824	24.33	5610
1002	29.59	309	912	26.93	2885	822	24.27	5675
1000	29.53	364	910	26.87	2944	820	24.21	5740
998	29.47	419	908	26.81	3004	818	24.16	5805
996	29.41	475	906	26.75	3064	816	24.10	5870
994	29.35	530	904	26.70	3124	814	24.04	5935
992	29.29	586	902	26.64	3183	812	23.98	6000
990	29.23	641	900	26.58	3243	810	23.92	6065
988	29.18	697	898	26.52	3303	808	23.86	6131
986	29.12	753	896	26.46	3363	806	23.80	6197
984	29.06	809	894	26.40	3424	804	23.74	6263
982	29.00	865	892	26.34	3484	802	23.68	6329
980	28.94	921	890	26.28	3545	800	23.62	6394
978	28.88	977	888	26.22	3606	798	23.56	6461
976	28.82	1033	886	26.16	3667	796	23.51	6528
974	28.76	1089	884	26.10	3728	794	23.45	6595
972	28.70	1145	882	26.05	3789	792	23.39	6661
970	28.64	1202	880	25.99	3850	790	23.33	6727
968	28.59	1259	878	25.93	3911	788	23.27	6794
966	28.53	1316	876	25.87	3973	786	23.21	6861
964	28.47	1373	874	25.81	4034	784	23.15	6928
962	28.41	1430	872	25.75	4096	782	23.09	6995



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**OPERATING DATA**  
  
GENERAL

**WIND COMPONENTS (FOR TAKEOFF AND LANDING)**


Ident.: PER-OPD-GEN-00001966.0001001 / 08 FEB 11



Applicable to: ALL

MULTIPLY	BY	TO GET
kt	1.852	km/h
kt	0.5144	m/s
m/s	3.6	km/h
m/s	1.9438	kt
km/h	0.5396	kt
km/h	0.2778	m/s

GIVEN	FIND
WIND DIRECTION RELATIVE TO RUNWAY HEADING=30 DEG	CROSS WIND COMPONENT=22.5 KT
WIND SPEED=45 KT	HEAD WIND COMPONENT=39.0 KT




**ALTITUDE TEMPERATURE CORRECTION**

Ident.: PER-OPD-GEN-00001967.0001001 / 12 FEB 11

Applicable to: ALL

**FOR HIGH ALTITUDE USE**



**FOR LOW ALTITUDE USE**

Values to be added by the pilot to minimum promulgated heights/altitude (ft)

Airport Temperature °C	Height above the elevation of the altimeter setting source (feet)								
	200	300	400	500	1 000	2 000	3 000	4 000	5 000
0	20	20	30	30	60	120	170	230	280

*Continued on the following page*





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE  
OPERATING DATA**

GENERAL

*Continued from the previous page*

Airport Temperature °C	Height above the elevation of the altimeter setting source (feet)								
	200	300	400	500	1 000	2 000	3 000	4 000	5 000
-10	20	30	40	50	100	200	290	390	490
-20	30	50	60	70	140	280	420	570	710
-30	40	60	80	100	190	380	570	760	950
-40	50	80	100	120	240	480	720	970	1 210
-50	60	90	120	150	300	590	890	1 190	1 500



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE  
OPERATING DATA**

GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
 CONVERSION - ALL ENGINES OPERATIVE

**GENERAL**

Ident.: PER-OPD-CON-AEO-00001657.0001001 / 23 FEB 11

Applicable to: ALL

The ground distance/air distance conversion tables show the air distance for a given ground distance due to the influence of the wind.

The Tables are given for :

- M .78
- Long range speed.

**M.78**

Ident.: PER-OPD-CON-AEO-00001658.0001001 / 28 JAN 11

Applicable to: ALL

GROUND DIST. (NM)	AIR DISTANCE (NM)						
	TAIL WIND		WIND COMPONENTS (KT)			HEAD WIND	
	+ 150	+ 100	+ 50	0	- 50	- 100	- 150
<b>10</b>	7	8	9	<b>10</b>	11	13	15
<b>20</b>	15	16	18	<b>20</b>	23	26	30
<b>30</b>	22	25	27	<b>30</b>	34	39	45
<b>40</b>	30	33	36	<b>40</b>	45	51	60
<b>50</b>	37	41	45	<b>50</b>	56	64	75
<b>100</b>	75	82	90	<b>100</b>	113	129	150
<b>200</b>	150	164	180	<b>200</b>	225	257	300
<b>300</b>	225	245	270	<b>300</b>	338	386	450
<b>400</b>	300	327	360	<b>400</b>	450	514	600
<b>500</b>	375	409	450	<b>500</b>	563	643	750
<b>1000</b>	750	818	900	<b>1000</b>	1125	1286	1501
<b>1500</b>	1125	1227	1350	<b>1500</b>	1688	1929	2251
<b>2000</b>	1500	1636	1800	<b>2000</b>	2248	2572	3001
<b>2500</b>	1875	2045	2250	<b>2500</b>	2813	3215	3752
<b>3000</b>	2250	2454	2700	<b>3000</b>	3375	3858	4502
<b>3500</b>	2624	2863	3150	<b>3500</b>	3938	4501	5252
<b>4000</b>	2999	3272	3600	<b>4000</b>	4500	5144	6003
<b>4500</b>	3374	3681	4050	<b>4500</b>	5063	5787	6753
<b>5000</b>	3749	4090	4500	<b>5000</b>	5626	6430	7503

FLIP23 A320211 M565A1PP 3410 03301.000011 0250300 .7800 00000 0 0300350 0 0 77 64 43 61 18580 FCOM-W0-03-50-002-001

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
CONVERSION - ALL ENGINES OPERATIVE

**LONG RANGE SPEED UP TO FL270**

Ident.: PER-OPD-CON-AEO-00001659.0001001 / 28 FEB 11

Applicable to: ALL

GROUND DIST. (NM)	AIR DISTANCE (NM)						
	TAIL WIND		WIND COMPONENTS (KT)			HEAD WIND	
	+150	+100	+ 50	0	-50	-100	-150
<b>10</b>	7	8	9	<b>10</b>	12	14	17
<b>20</b>	14	16	18	<b>20</b>	23	27	33
<b>30</b>	21	24	26	<b>30</b>	35	41	50
<b>40</b>	29	32	35	<b>40</b>	46	55	67
<b>50</b>	36	39	44	<b>50</b>	58	68	83
<b>100</b>	71	79	88	<b>100</b>	115	136	167
<b>200</b>	143	158	176	<b>200</b>	231	273	333
<b>300</b>	214	237	265	<b>300</b>	346	409	500
<b>400</b>	286	316	353	<b>400</b>	462	545	667
<b>500</b>	357	395	441	<b>500</b>	577	682	833
<b>1000</b>	714	789	882	<b>1000</b>	1154	1364	1667
<b>1500</b>	1071	1184	1324	<b>1500</b>	1731	2046	2500
<b>2000</b>	1429	1579	1765	<b>2000</b>	2308	2727	3334
<b>2500</b>	1786	1974	2206	<b>2500</b>	2885	3409	4167
<b>3000</b>	2143	2368	2647	<b>3000</b>	3462	4091	5000
<b>3500</b>	2500	2763	3088	<b>3500</b>	4039	4773	5834
<b>4000</b>	2857	3158	3529	<b>4000</b>	4615	5455	6667
<b>4500</b>	3214	3553	3971	<b>4500</b>	5192	6137	7500
<b>5000</b>	3571	3947	4412	<b>5000</b>	5769	6818	8334



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
 CONVERSION - ALL ENGINES OPERATIVE

**LONG RANGE SPEED ABOVE FL270**

Ident.: PER-OPD-CON-AEO-00001660.0001001 / 09 DEC 09

Applicable to: ALL

GROUND DIST. (NM)	AIR DISTANCE (NM)						
	TAIL WIND		WIND COMPONENTS (KT)			HEAD WIND	
	+ 150	+ 100	+ 50	0	- 50	- 100	- 150
<b>10</b>	8	8	9	<b>10</b>	11	13	15
<b>20</b>	15	16	18	<b>20</b>	22	26	30
<b>30</b>	23	25	27	<b>30</b>	34	38	45
<b>40</b>	30	33	36	<b>40</b>	45	51	60
<b>50</b>	38	41	45	<b>50</b>	56	64	75
<b>100</b>	75	82	90	<b>100</b>	112	128	149
<b>200</b>	150	164	180	<b>200</b>	225	256	299
<b>300</b>	226	246	270	<b>300</b>	337	385	448
<b>400</b>	301	328	360	<b>400</b>	449	513	597
<b>500</b>	376	410	450	<b>500</b>	562	641	746
<b>1000</b>	752	820	901	<b>1000</b>	1124	1282	1493
<b>1500</b>	1128	1230	1351	<b>1500</b>	1685	1923	2239
<b>2000</b>	1504	1639	1802	<b>2000</b>	2247	2564	2985
<b>2500</b>	1880	2049	2252	<b>2500</b>	2809	3205	3731
<b>3000</b>	2256	2459	2703	<b>3000</b>	3371	3846	4478
<b>3500</b>	2632	2869	3153	<b>3500</b>	3933	4487	5224
<b>4000</b>	3008	3279	3604	<b>4000</b>	4494	5128	5970
<b>4500</b>	3383	3689	4054	<b>4500</b>	5056	5769	6716
<b>5000</b>	3759	4098	4505	<b>5000</b>	5618	6410	7463

FLIP23 A320211 M565A1PP 3410 03301.000011 0250300 .7801 .00000 0 0300350 0 0 77 64 43 61 18580 FCOM-W0-03-50-004-001



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
CONVERSION - ALL ENGINES OPERATIVE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### OPERATING DATA

GROUND DISTANCE/AIR DISTANCE  
CONVERSION - ONE ENGINE INOPERATIVE

## GENERAL

Ident.: PER-OPD-CON-OEI-00004074.0001001 / 09 DEC 09

**Applicable to: ALL**

The ground distance/air distance conversion tables are used to calculate the air distance for a given ground distance due to the influence of the wind.

Tables are given for :

- LONG RANGE SPEED
- FIXED SPEEDS

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
CONVERSION - ONE ENGINE INOPERATIVE

**LONG RANGE SPEED**

Ident.: PER-OPD-CON-OEI-00001960.0001001 / 09 DEC 09

Applicable to: ALL


GROUND DIST. (NM)	AIR DISTANCE (NM)						
	TAIL WIND		WIND COMPONENTS (KT)			HEAD WIND	
	+150	+100	+ 50	0	-50	-100	-150
<b>10</b>	7	8	9	<b>10</b>	11	13	15
<b>20</b>	15	16	18	<b>20</b>	23	26	31
<b>30</b>	22	24	27	<b>30</b>	34	39	46
<b>40</b>	30	32	36	<b>40</b>	45	52	61
<b>50</b>	37	41	45	<b>50</b>	57	65	77
<b>60</b>	44	49	54	<b>60</b>	68	78	92
<b>70</b>	52	57	63	<b>70</b>	79	91	108
<b>80</b>	59	65	72	<b>80</b>	91	104	123
<b>90</b>	67	73	81	<b>90</b>	102	117	138
<b>100</b>	74	81	90	<b>100</b>	113	130	154
<b>200</b>	148	162	179	<b>200</b>	226	261	307
<b>300</b>	222	243	269	<b>300</b>	340	391	461
<b>400</b>	296	324	358	<b>400</b>	453	521	615
<b>500</b>	371	406	448	<b>500</b>	566	652	768
<b>600</b>	445	487	537	<b>600</b>	679	782	922
<b>700</b>	519	568	627	<b>700</b>	792	913	1076
<b>800</b>	593	649	717	<b>800</b>	905	1043	1230
<b>900</b>	667	730	806	<b>900</b>	1019	1173	1383
<b>1000</b>	741	811	896	<b>1000</b>	1132	1304	1537
<b>1100</b>	815	892	985	<b>1100</b>	1245	1434	1691
<b>1200</b>	889	973	1075	<b>1200</b>	1358	1564	1844
<b>1300</b>	963	1054	1164	<b>1300</b>	1471	1695	1998
<b>1400</b>	1038	1136	1254	<b>1400</b>	1585	1825	2152
<b>1500</b>	1112	1217	1344	<b>1500</b>	1698	1955	2305
<b>1600</b>	1186	1298	1433	<b>1600</b>	1811	2086	2459
<b>1700</b>	1260	1379	1523	<b>1700</b>	1924	2216	2613
<b>1800</b>	1334	1460	1612	<b>1800</b>	2037	2346	2766
<b>1900</b>	1408	1541	1702	<b>1900</b>	2150	2477	2920
<b>2000</b>	1482	1622	1791	<b>2000</b>	2264	2607	3074



**FIXED SPEEDS**

Ident.: PER-OPD-CON-OEI-00001961.0001001 / 09 DEC 09

Applicable to: ALL





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**OPERATING DATA**

GROUND DISTANCE/AIR DISTANCE  
CONVERSION - ONE ENGINE INOPERATIVE

Intentionally left blank

# PERFORMANCE

THRUST RATINGS

Intentionally left blank

**PER-THR-GEN GENERAL**

GENERAL..... A

**PER-THR-MTO MAXIMUM TAKEOFF**

DEFINITION..... A

MAXIMUM TAKEOFF..... B

**PER-THR-MGA MAXIMUM GO AROUND**

DEFINITION..... A

MAXIMUM GO AROUND..... B

**PER-THR-FLX FLEXIBLE TAKEOFF**

DEFINITION..... A

FLEXIBLE TAKEOFF..... B

**PER-THR-MCT MAXIMUM CONTINUOUS**

DEFINITION..... A

MAXIMUM CONTINUOUS..... B

**PER-THR-MCL MAXIMUM CLIMB**

DEFINITION..... A

MAXIMUM CLIMB..... B

**PER-THR-MCR MAXIMUM CRUISE**

DEFINITION..... A

MAXIMUM CRUISE..... B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**THRUST RATINGS**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**THRUST RATINGS**

GENERAL

**GENERAL**

Ident.: PER-THR-GEN-00004079.0001001 / 28 FEB 11

**Applicable to: ALL**

The thrust rating charts have been established for:

- Maximum takeoff
- Maximum go around
- Flexible takeoff
- Maximum continuous
- Maximum climb
- Maximum cruise



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE  
THRUST RATINGS**

GENERAL

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

MAXIMUM TAKEOFF

**DEFINITION**

Ident.: PER-THR-MTO-00001968.0001001 / 01 MAR 11

**Applicable to: ALL**

It is the maximum thrust certified for takeoff and is normally limited to five minutes.

This time is extended to ten minutes for engine out contingency, as authorized by the approved AFM.



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

**MAXIMUM TAKEOFF**

**MAXIMUM TAKEOFF**

Ident.: PER-THR-MTO-00001969.0017001 / 28 JAN 11

Applicable to: ALL

OAT (°C)	CFM56-5B4												
	N1 CORRECTIONS FOR AIR BLEED											OAT < CORNER POINT	OAT ≥ CORNER POINT
	TAKE OFF												
	N1												
	NO AIR BLEED											-7	-7
	MACH = .000											0.0	-1.6
	ENGINE ANTI ICE AND WING ANTI ICE ON											0.0	-2.4
	PRESSURE ALTITUDE (FT)												
	-2000.	-1000.	0.	1000.	2000.	3000.	4000.	5000.	6000.	7000.	8000.	9000.	9200.
-54.0	76.2	77.2	78.2	79.2	80.3	82.3	84.0	85.8	86.7	87.6	88.2	88.0	88.0
-50.0	76.9	77.9	78.9	79.9	81.0	83.0	84.7	86.5	87.5	88.3	88.9	88.8	88.7
-46.0	77.5	78.6	79.6	80.6	81.7	83.7	85.4	87.3	88.2	89.0	89.7	89.5	89.5
-42.0	78.2	79.2	80.2	81.3	82.4	84.4	86.1	88.0	88.9	89.8	90.4	90.2	90.2
-38.0	78.8	79.9	80.9	82.0	83.0	85.1	86.8	88.7	89.6	90.5	91.1	90.9	90.9
-34.0	79.5	80.5	81.5	82.6	83.7	85.7	87.5	89.4	90.3	91.2	91.8	91.6	91.6
-30.0	80.1	81.2	82.2	83.3	84.3	86.4	88.2	90.1	91.0	91.9	92.5	92.3	92.3
-26.0	80.7	81.8	82.8	83.9	85.0	87.1	88.8	90.7	91.7	92.5	93.2	93.0	93.0
-22.0	81.4	82.4	83.5	84.6	85.6	87.7	89.5	91.4	92.4	93.2	93.9	93.7	93.7
-18.0	82.0	83.1	84.1	85.2	86.3	88.4	90.2	92.1	93.1	93.9	94.6	94.4	94.4
-14.0	82.6	83.7	84.8	85.9	87.0	89.1	90.9	92.8	93.8	94.6	95.3	95.1	95.1
-10.0	83.2	84.3	85.4	86.5	87.6	89.7	91.5	93.4	94.4	95.3	95.9	95.7	95.7
-6.0	83.8	84.9	86.0	87.1	88.2	90.3	92.2	94.1	95.1	95.9	96.6	96.4	96.4
-2.0	84.4	85.5	86.6	87.7	88.8	90.9	92.8	94.7	95.7	96.6	97.3	97.1	97.0
2.0	85.0	86.1	87.2	88.3	89.4	91.6	93.4	95.4	96.4	97.2	97.9	97.7	97.7
6.0	85.6	86.7	87.8	88.9	90.0	92.2	94.1	96.0	97.0	97.9	98.6	98.4	98.3
10.0	86.2	87.3	88.4	89.5	90.7	92.8	94.7	96.7	97.7	98.5	99.2	99.0	99.0
14.0	86.8	87.9	89.0	90.2	91.3	93.5	95.3	97.3	98.3	99.2	99.9	99.7	99.6
18.0	87.4	88.5	89.6	90.8	91.9	94.1	95.9	97.9	98.9	99.8	100.1	99.1	98.8
22.0	88.0	89.1	90.2	91.3	92.5	94.7	96.6	98.6	99.3	99.4	99.1	97.9	97.7
26.0	88.5	89.7	90.7	91.9	93.1	95.3	97.2	98.3	98.5	98.5	98.0	96.8	96.6
30.0	89.1	90.2	91.3	92.5	93.6	95.9	97.4	97.6	97.7	97.6	97.3	96.5	96.4
34.0	89.7	90.8	91.9	93.1	94.2	96.5	96.8	97.0	97.1	97.1	97.0	96.2	96.1
38.0	90.2	91.4	92.5	93.7	94.8	96.1	96.3	96.4	96.6	96.6	96.6		
42.0	90.8	91.9	93.1	94.2	94.9	95.6	95.7	95.8	96.0				
46.0	91.4	92.5	93.2	93.9	94.5								
50.0	91.5	92.2	92.9	93.6	94.1								
54.0	91.2	92.0	92.7										
										OAT < CORNER POINT			
										OAT ≥ CORNER POINT			



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**  
**THRUST RATINGS**  
 MAXIMUM TAKEOFF

CFM56-5B4 TAKE OFF N1 NO AIR BLEED MACH=0.00	N1 CORRECTIONS FOR AIR BLEED										OAT < CORNER POINT	OAT > CORNER POINT
	AIR CONDITIONING ON										-7	-7
	ENGINE ANTI-ICE ON										0.0	-1.6
	ENGINE ANTI-ICE AND WING ANTI-ICE ON										0.0	-2.4
OAT (C)	PRESSURE ALTITUDE (FT)											
	7000.	8000.	9000.	9200.	10000.	11000.	12000.	13000.	14000.	14500.		
-54.0	87.6	88.2	88.0	88.0	87.8	88.2	88.4	88.6	88.6	88.5		
-50.0	88.3	88.9	88.8	88.7	88.6	88.9	89.2	89.3	89.3	89.3		
-46.0	89.0	89.7	89.5	89.5	89.3	89.7	89.9	90.1	90.1	90.0		
-42.0	89.8	90.4	90.2	90.2	90.0	90.4	90.7	90.8	90.8	90.8		
-38.0	90.5	91.1	90.9	90.9	90.7	91.1	91.4	91.5	91.5	91.5		
-34.0	91.2	91.8	91.6	91.6	91.4	91.8	92.1	92.2	92.2	92.2		
-30.0	91.9	92.5	92.3	92.3	92.1	92.5	92.8	92.9	92.9	92.9		
-26.0	92.5	93.2	93.0	93.0	92.8	93.2	93.5	93.6	93.6	93.6		
-22.0	93.2	93.9	93.7	93.7	93.5	93.9	94.1	94.3	94.3	94.3		
-18.0	93.9	94.6	94.4	94.4	94.2	94.6	94.8	95.0	95.0	95.0		
-14.0	94.6	95.3	95.1	95.1	94.9	95.3	95.5	95.7	95.7	95.7		
-10.0	95.3	95.9	95.7	95.7	95.6	95.9	96.2	96.3	96.3	96.3		
-6.0	95.9	96.6	96.4	96.4	96.2	96.6	96.9	97.0	97.0	97.0		
-2.0	96.6	97.3	97.1	97.0	96.9	97.3	97.5	97.6	97.7	97.6		
2.0	97.2	97.9	97.7	97.7	97.5	97.9	98.2	98.3	98.3	98.3		
6.0	97.9	98.6	98.4	98.3	98.2	98.6	98.8	99.0	99.0	98.9		
10.0	98.5	99.2	99.0	99.0	98.8	99.2	99.5	99.6	99.2	98.8		
14.0	99.2	99.9	99.7	99.6	99.1	99.0	98.6	98.0	97.1	96.6		
18.0	99.8	100.1	99.1	98.8	97.9	97.6	97.0	96.1	95.7	95.6		
22.0	99.4	99.1	97.9	97.7	96.7	96.2	95.9	95.7	95.4	95.2		
26.0	98.5	98.0	96.8	96.6	96.0	95.9	95.6	95.3	95.0	94.8		
30.0	97.6	97.3	96.5	96.4	95.8	95.7	95.4					
34.0	97.1	97.0	96.2	96.1	95.6							
38.0	96.7	96.6										
42.0												
46.0												
50.0												
54.0												
											OAT < CORNER POINT	
											OAT > CORNER POINT	



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

MAXIMUM TAKEOFF

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

MAXIMUM GO AROUND

**DEFINITION**

Ident.: PER-THR-MGA-00001971.0001001 / 23 FEB 11

**Applicable to: ALL**

It is the maximum permissible thrust during go-around.

**MAXIMUM GO AROUND**

Ident.: PER-THR-MGA-00001972.0024001 / 28 JAN 11

Applicable to: ALL

CFM56-5B4		N1 CORRECTIONS FOR AIR BLEED						OAT < CORNER POINT	OAT ≥ CORNER POINT		
GO AROUND		AIR CONDITIONING OFF						0.7	0.7		
N1		ENGINE ANTI ICE ON						0.0	-1.6		
AIR CONDITIONING ON		ENGINE ANTI ICE AND WING ANTI ICE ON						0.0	-2.4		
MACH = .225		PRESSURE ALTITUDE (FT)									
TAT (°C)	-2000.	-1000.	0.	1000.	2000.	3000.	4000.	5000.	6000.	7000.	
-54.0	77.7	78.7	79.6	80.2	80.9	82.1	83.4	84.8	86.2	86.8	
-50.0	78.4	79.4	80.3	80.9	81.6	82.8	84.2	85.5	86.9	87.6	
-46.0	79.1	80.1	81.0	81.6	82.3	83.5	84.9	86.2	87.6	88.3	
-42.0	79.8	80.7	81.7	82.3	83.0	84.2	85.6	87.0	88.4	89.0	
-38.0	80.4	81.4	82.3	83.0	83.6	84.9	86.3	87.6	89.1	89.7	
-34.0	81.1	82.0	83.0	83.6	84.3	85.5	86.9	88.3	89.7	90.4	
-30.0	81.7	82.7	83.6	84.3	85.0	86.2	87.6	89.0	90.4	91.1	
-26.0	82.4	83.3	84.3	85.0	85.6	86.9	88.3	89.7	91.1	91.8	
-22.0	83.0	84.0	84.9	85.6	86.3	87.5	89.0	90.4	91.8	92.5	
-18.0	83.7	84.6	85.6	86.3	86.9	88.2	89.6	91.1	92.5	93.2	
-14.0	84.3	85.3	86.2	86.9	87.6	88.9	90.3	91.7	93.2	93.9	
-10.0	84.9	85.9	86.8	87.5	88.2	89.5	90.9	92.4	93.8	94.5	
-6.0	85.5	86.5	87.5	88.2	88.8	90.1	91.6	93.0	94.5	95.2	
-2.0	86.1	87.1	88.1	88.8	89.5	90.8	92.2	93.7	95.1	95.8	
2.0	86.7	87.7	88.7	89.4	90.1	91.4	92.9	94.3	95.8	96.5	
6.0	87.3	88.3	89.3	90.0	90.7	92.0	93.5	94.9	96.4	97.1	
10.0	87.9	88.9	89.9	90.6	91.3	92.6	94.1	95.6	97.1	97.8	
14.0	88.5	89.6	90.5	91.3	91.9	93.3	94.8	96.2	97.7	98.4	
18.0	89.1	90.1	91.1	91.8	92.5	93.9	95.4	96.8	98.3	99.0	
22.0	89.7	90.7	91.7	92.4	93.1	94.5	96.0	97.4	99.0	99.6	
26.0	90.3	91.3	92.3	93.0	93.7	95.1	96.6	98.1	99.0	99.0	
30.0	90.8	91.9	92.9	93.6	94.3	95.7	97.2	97.7	98.5	98.4	
34.0	91.4	92.5	93.5	94.2	94.9	96.3	97.2	97.4	97.9	97.7	
38.0	92.0	93.0	94.0	94.8	95.5	96.7	96.9	96.9	97.2	97.0	
42.0	92.6	93.6	94.6	95.4	96.1	96.3	96.2	96.0	96.3	96.2	
46.0	93.1	94.2	95.2	95.7	95.7	95.5	95.3	95.2	95.4		
50.0	93.7	94.5	94.8	94.8	94.8	94.6	94.4				
54.0	93.3	93.6	93.9	94.0	93.9						
58.0	92.4	92.8	93.1								
62.0	91.6										
OAT < CORNER POINT											
OAT ≥ CORNER POINT											

**PERFORMANCE**  
**THRUST RATINGS**

**MAXIMUM GO AROUND**

CFM56-5B4	N1 CORRECTIONS FOR AIR BLEED										OAT < CORNER POINT	OAT > CORNER POINT
	AIR CONDITIONING OFF										0.7	0.7
GO AROUND N1	ENGINE ANTI-ICE ON										0.0	-1.6
AIR CONDITIONING ON	ENGINE ANTI-ICE AND WING ANTI-ICE ON										0.0	-2.4
MACH = .225												
TAT (C)	PRESSURE ALTITUDE (FT)											
	7000.	8000.	9000.	9200.	10000.	11000.	12000.	13000.	14000.	14500.		
-54.0	86.8	87.3	87.0	87.0	86.7	87.0	87.3	87.4	87.4	87.4		
-50.0	87.6	88.1	87.8	87.7	87.5	87.8	88.0	88.1	88.2	88.2		
-46.0	88.3	88.8	88.5	88.4	88.2	88.5	88.8	88.9	88.9	88.9		
-42.0	89.0	89.6	89.2	89.2	88.9	89.3	89.5	89.6	89.7	89.6		
-38.0	89.7	90.2	89.9	89.9	89.6	89.9	90.2	90.3	90.3	90.3		
-34.0	90.4	90.9	90.6	90.6	90.3	90.6	90.9	91.0	91.0	91.0		
-30.0	91.1	91.6	91.3	91.2	91.0	91.3	91.6	91.7	91.7	91.7		
-26.0	91.8	92.3	92.0	91.9	91.7	92.0	92.3	92.4	92.4	92.4		
-22.0	92.5	93.0	92.7	92.6	92.4	92.7	93.0	93.1	93.1	93.1		
-18.0	93.2	93.7	93.4	93.3	93.1	93.4	93.6	93.8	93.8	93.8		
-14.0	93.9	94.4	94.1	94.0	93.8	94.1	94.3	94.5	94.5	94.5		
-10.0	94.5	95.1	94.7	94.7	94.4	94.7	95.0	95.1	95.2	95.1		
-6.0	95.2	95.7	95.4	95.3	95.1	95.4	95.6	95.8	95.8	95.8		
-2.0	95.8	96.4	96.0	96.0	95.7	96.0	96.3	96.4	96.5	96.4		
2.0	96.5	97.0	96.7	96.6	96.4	96.7	96.9	97.1	97.1	97.1		
6.0	97.1	97.7	97.3	97.3	97.0	97.3	97.6	97.7	97.8	97.7		
10.0	97.8	98.3	98.0	97.9	97.7	98.0	98.2	98.4	98.4	98.4		
14.0	98.4	99.0	98.6	98.6	98.3	98.6	98.9	98.6	98.0	97.7		
18.0	99.0	99.6	99.3	99.1	98.2	98.1	97.7	97.2	96.4	95.9		
22.0	99.6	99.5	98.5	98.2	97.4	97.0	96.5	95.9	95.6	95.4		
26.0	99.0	98.7	97.6	97.4	96.5	96.1	95.8	95.5	95.1	94.9		
30.0	98.4	97.9	96.9	96.7	95.9	95.7	95.4	95.0	94.6			
34.0	97.7	97.3	96.3	96.2	95.5	95.3	95.0					
38.0	97.0	96.6	95.8	95.6	95.1							
42.0	96.2	95.9										
46.0												
50.0												
54.0												
											OAT < CORNER POINT	
											OAT > CORNER POINT	



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

MAXIMUM GO AROUND

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**THRUST RATINGS**

FLEXIBLE TAKEOFF

## DEFINITION

Ident.: PER-THR-FLX-00001973.0001001 / 23 FEB 11

**Applicable to: ALL**

It is a reduced takeoff thrust as compared to the maximum permissible. The related N1 is calculated as a function of the flexible temperature entered in the FMGS MCDU. The flexible temperature is a function of the aircraft weight and environmental conditions.

It guarantees that the regular performance requirements are met.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**PERFORMANCE**  
**THRUST RATINGS**  
FLEXIBLE TAKEOFF

**FLEXIBLE TAKEOFF**

Ident.: PER-THR-FLX-00001974.0035001 / 23 FEB 11

Applicable to: ALL

EXAMPLE : PRESS ALT : 2000 FT OAT=-10°C. FLX T=50°C.  
 - FLX TEMP 50°C > FLAT RATING TEMP (ISA+29=40°C)



PRESS ALT: 2000 FT → N1 FLEX = 85.6%

OAT (-10°C)

CFM56-5B4	N1 CORRECTIONS FOR AIR BLEED	
FLEX TAKEOFF N1	AIR CONDITIONING ON	- 0.7
MACH = .000	ENGINE ANTI ICE ON	0.0
	ENGINE AND WING ANTI ICE ON	0.0



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**THRUST RATINGS**  
FLEXIBLE TAKEOFF

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### THRUST RATINGS

MAXIMUM CONTINUOUS

## DEFINITION

Ident.: PER-THR-MCT-00001975.0001001 / 28 FEB 11

**Applicable to: ALL**

It is the maximum thrust certified for continuous use. This rating should be used, at the pilot's discretion, only when required to ensure safe flight (engine failure).

**MAXIMUM CONTINUOUS**

Ident.: PER-THR-MCT-00001976.0011001 / 28 JAN 11

Applicable to: ALL

CFM56-5B4		N1 CORRECTIONS FOR AIR BLEED										OAT < ISA + 10	OAT ≥ ISA + 10
MAXIMUM CONTINUOUS N1 AIR CONDITIONING ON* IAS = 230 KT		AIR CONDITIONING OFF										0.9	0.9
		ENGINE ANTI ICE ON										0.0	-1.4
		ENGINE ANTI ICE AND WING ANTI ICE ON										0.0	-3.2
TAT (°C)	PRESSURE ALTITUDE (FT)												
	-1000.	3000.	7000.	11000.	15000.	19000.	23000.	27000.	31000.	35000.	39000.		
-54.0	75.6	77.6	79.2	81.1	85.2	87.3	87.0	83.2	84.3	85.1	84.1		
-50.0	76.2	78.3	79.9	81.8	85.9	88.0	87.7	84.0	85.0	85.8	84.9		
-46.0	76.9	79.0	80.6	82.6	86.6	88.8	88.5	84.7	85.7	86.6	85.6		
-42.0	77.6	79.6	81.2	83.3	87.4	89.5	89.2	85.4	86.4	87.3	86.3		
-38.0	78.2	80.3	81.9	83.9	88.0	90.2	89.9	86.1	87.1	88.0	87.0		
-34.0	78.8	80.9	82.5	84.6	88.7	90.9	90.6	86.7	87.8	88.6	87.7		
-30.0	79.5	81.6	83.2	85.2	89.4	91.6	91.3	87.4	88.5	89.3	88.3		
-26.0	80.1	82.2	83.8	85.9	90.1	92.3	92.0	88.1	89.2	90.0	89.0		
-22.0	80.7	82.8	84.5	86.6	90.8	93.0	92.7	88.7	89.8	90.5	89.7		
-18.0	81.4	83.5	85.1	87.2	91.5	93.7	93.4	89.4	90.5	90.3	89.6		
-14.0	82.0	84.1	85.8	87.9	92.1	94.3	94.0	90.1	90.4	90.0	89.3		
-10.0	82.6	84.7	86.4	88.5	92.8	95.0	94.7	90.3	90.1	89.6	89.0		
-6.0	83.2	85.3	87.0	89.1	93.4	95.6	95.3	90.3	89.7	89.0	88.2		
-2.0	83.8	85.9	87.6	89.8	94.1	96.3	94.6	89.7	89.0	88.4	87.5		
2.0	84.4	86.5	88.3	90.4	94.7	96.3	93.9	89.0	88.4	87.7	86.9		
6.0	85.0	87.1	88.9	91.0	95.4	95.6	93.3	88.4	87.8	87.0	86.3		
10.0	85.5	87.8	89.5	91.6	94.8	94.8	92.8	87.8	87.2	86.2	85.7		
14.0	86.1	88.4	90.1	92.0	94.0	94.2	92.4	87.1	86.5				
18.0	86.7	88.9	90.7	91.5	93.3	93.6	91.9	86.5					
22.0	87.3	89.5	90.7	91.0	92.8	93.1	91.3						
26.0	87.8	90.1	90.2	90.5	92.2	92.5							
30.0	88.4	89.8	89.7	90.0	91.5	92.0							
34.0	89.0	89.3	89.5	89.4	90.9								
38.0	88.5	88.9	89.1	88.8									
42.0	88.0	88.7	88.7	88.1									
46.0	87.4	88.3	88.2										
50.0	86.8	87.9	87.7										
54.0	86.2	87.5											
											OAT < ISA + 10		
											OAT ≥ ISA + 10		

\* One engine inoperative – 1 pack operative on remaining engine.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**THRUST RATINGS**  
**MAXIMUM CLIMB**

**DEFINITION**

Ident.: PER-THR-MCL-00001977.0001001 / 23 FEB 11

Applicable to: ALL

It is the maximum thrust approved for normal climb.

**MAXIMUM CLIMB**

Ident.: PER-THR-MCL-00001978.0011001 / 28 JAN 11

Applicable to: ALL

CFM56-5B4	N1 CORRECTIONS FOR AIR BLEED										OAT < ISA + 10	OAT ≥ ISA + 10
	MAXIMUM CLIMB N1										.8	.8
	AIR CONDITIONING OFF										0.0	-1.3
	ENGINE ANTI ICE ON										0.0	-2.4
AIR CONDITIONING ON										0.0	-1.3	
ENGINE ANTI ICE AND WING ANTI ICE ON										0.0	-2.4	
TAT (°C)	PRESSURE ALTITUDE (FT)											
	-1000.	3000.	7000.	11000.	15000.	19000.	23000.	27000.	31000.	35000.	39000.	
-54.0	73.5	75.4	77.0	77.8	78.8	79.8	80.7	81.5	82.5	83.9	83.9	
-50.0	74.2	76.1	77.6	78.4	79.5	80.5	81.4	82.2	83.3	84.6	84.6	
-46.0	74.8	76.8	78.3	79.1	80.2	81.2	82.1	82.9	84.0	85.3	85.3	
-42.0	75.5	77.4	79.0	79.8	80.9	81.9	82.8	83.6	84.7	86.0	86.0	
-38.0	76.1	78.1	79.6	80.5	81.5	82.5	83.5	84.3	85.3	86.7	86.7	
-34.0	76.7	78.7	80.3	81.1	82.2	83.2	84.1	84.9	86.0	87.4	87.4	
-30.0	77.3	79.3	80.9	81.7	82.8	83.8	84.8	85.6	86.7	88.1	88.1	
-26.0	77.9	80.0	81.5	82.4	83.5	84.5	85.4	86.2	87.4	88.7	88.7	
-22.0	78.6	80.6	82.2	83.0	84.1	85.1	86.1	86.9	88.0	89.4	89.4	
-18.0	79.2	81.2	82.8	83.7	84.8	85.8	86.7	87.6	88.7	90.1	89.9	
-14.0	79.8	81.8	83.5	84.3	85.4	86.4	87.4	88.2	89.4	90.3	89.6	
-10.0	80.4	82.4	84.1	84.9	86.0	87.1	88.0	88.9	90.0	90.1	89.4	
-6.0	81.0	83.0	84.7	85.5	86.6	87.7	88.7	89.5	90.3	90.0	88.8	
-2.0	81.5	83.6	85.3	86.1	87.2	88.3	89.3	90.1	90.1	89.5	88.0	
2.0	82.1	84.2	85.9	86.7	87.9	88.9	89.9	90.1	90.0	88.8	87.4	
6.0	82.7	84.8	86.5	87.3	88.5	89.5	90.0	89.9	89.6	88.2	86.8	
10.0	83.3	85.4	87.1	87.9	89.1	89.8	89.8	89.7	89.0	87.5	86.2	
14.0	83.9	86.0	87.7	88.6	89.7	89.6	89.7	89.2	88.4	86.8	85.6	
18.0	84.4	86.6	88.2	89.1	89.4	89.3	89.2	88.6	87.7			
22.0	85.0	87.1	88.7	89.2	89.0	89.0	88.6	87.9	87.0			
26.0	85.5	87.7	88.3	88.9	88.7	88.5	88.0	87.2	86.3			
30.0	86.1	87.8	87.9	88.5	88.2	87.8	87.2	86.6				
34.0	86.6	87.4	87.3	87.8	87.5	87.1	86.5					
38.0	86.4	86.9	86.6	87.1	86.8	86.4						
42.0	85.9	86.2	85.9	86.4	86.0							
46.0	85.3	85.4	85.2	85.7	85.3							
50.0	84.5	84.7	84.4	85.0								
54.0	83.7	84.0										
OAT < ISA + 10												
OAT ≥ ISA + 10												



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**PERFORMANCE**

**THRUST RATINGS**

MAXIMUM CLIMB

Intentionally left blank



 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p><b>PERFORMANCE</b></p> <p><b>THRUST RATINGS</b></p> <p>MAXIMUM CRUISE</p>
---	--

**DEFINITION**

Ident.: PER-THR-MCR-00001979.0004001 / 02 FEB 11

**Applicable to: ALL**

It is the maximum thrust approved for normal cruise.

There is no thrust lever position corresponding to this thrust rating.

It is not displayed to the pilot, and the N1 limit which is displayed in cruise is the maximum climb N1.

The FMGS uses the maximum cruise N1 to compute the aircraft maximum speed.

In manual thrust setting, in cruise, the pilot should limit N1 to the maximum cruise N1 that is equal to the displayed maximum climb N1 minus 1.9 %.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**THRUST RATINGS**  
**MAXIMUM CRUISE**

**MAXIMUM CRUISE**

Ident.: PER-THR-MCR-00001980.0018001 / 28 FEB 11

Applicable to: ALL

CFM56-5B4		N1 CORRECTIONS FOR AIR BLEED										OAT < ISA+10	OAT ≥ ISA+10
MAXIMUM CRUISE N1 AIR CONDITIONING ON 250/300/.78		AIR CONDITIONING OFF										0.8	0.8
		NACELLE ANTI ICE ON										0.0	-1.3
		NACELLE ANTI ICE AND WING ANTI ICE ON										0.0	-2.4
TAT (°C)	PRESSURE ALTITUDE (FT)												
	-1000.	3000.	7000.	11000.	15000.	19000.	23000.	27000.	31000.	35000.	39000.		
-54.0	71.6	73.5	75.1	75.9	76.9	77.9	78.8	79.6	80.6	82.0	82.0		
-50.0	72.3	74.2	75.7	76.5	77.6	78.6	79.5	80.3	81.4	82.7	82.7		
-46.0	72.9	74.9	76.4	77.2	78.3	79.3	80.2	81.0	82.1	83.4	83.4		
-42.0	73.6	75.5	77.1	77.9	79.0	80.0	80.9	81.7	82.8	84.1	84.1		
-38.0	74.2	76.2	77.7	78.6	79.6	80.6	81.6	82.4	83.4	84.8	84.8		
-34.0	74.8	76.8	78.4	79.2	80.3	81.3	82.2	83.0	84.1	85.5	85.5		
-30.0	75.4	77.4	79.0	79.8	80.9	81.9	82.9	83.7	84.8	86.2	86.2		
-26.0	76.0	78.1	79.6	80.5	81.6	82.6	83.5	84.3	85.5	86.8	86.8		
-22.0	76.7	78.7	80.3	81.1	82.2	83.2	84.2	85.0	86.1	87.5	87.5		
-18.0	77.3	79.3	80.9	81.8	82.9	83.9	84.8	85.7	86.8	88.2	88.0		
-14.0	77.9	79.9	81.6	82.4	83.5	84.5	85.5	86.3	87.5	88.4	87.7		
-10.0	78.5	80.5	82.2	83.0	84.1	85.2	86.1	87.0	88.1	88.2	87.5		
-6.0	79.1	81.1	82.8	83.6	84.7	85.8	86.8	87.6	88.4	88.1	86.9		
-2.0	79.6	81.7	83.4	84.2	85.3	86.4	87.4	88.2	88.2	87.6	86.1		
2.0	80.2	82.3	84.0	84.8	86.0	87.0	88.0	88.2	88.1	86.9	85.5		
6.0	80.8	82.9	84.6	85.4	86.6	87.6	88.7	88.0	87.7	86.3	84.9		
10.0	81.4	83.5	85.2	86.0	87.2	87.9	87.9	87.8	87.1	85.6	84.3		
14.0	82.0	84.1	85.8	86.7	87.8	87.7	87.8	87.3	86.5	84.9	83.7		
18.0	82.5	84.7	86.3	87.2	87.5	87.4	87.3	86.7	85.8				
22.0	83.1	85.2	86.8	87.3	87.1	87.1	86.7	86.0	85.1				
26.0	83.6	85.8	86.4	87.0	86.8	86.6	86.1	85.3	84.4				
30.0	84.2	85.9	86.0	86.6	86.3	85.9	85.3	84.7					
34.0	84.7	85.5	85.4	85.9	85.6	85.2	84.6						
38.0	84.5	85.0	84.7	85.2	84.9	84.5							
42.0	84.0	84.3	84.0	84.5	84.1								
46.0	83.4	83.5	83.3	83.8	83.4								
50.0	82.6	82.8	82.5	83.1									
54.0	81.8	82.1											
OAT < ISA + 10													
OAT ≥ ISA + 10													

# PERFORMANCE

TAKEOFF

Intentionally left blank

**PER-TOF-THR THRUST OPTIONS**

PER-TOF-THR-FLX FLEXIBLE TAKEOFF

PER-TOF-THR-FLX-10 DEFINITION OF FLEXIBLE TAKEOFF

DEFINITION OF FLEXIBLE TAKEOFF.....A

PER-TOF-THR-FLX-20 USE OF FLEXIBLE TAKEOFF

USE OF FLEXIBLE TAKEOFF.....A

PER-TOF-THR-FLX-30 REQUIREMENTS

REQUIREMENTS.....A

PER-TOF-THR-FLX-40 RECOMMENDATION

GENERAL.....A

TAKEOFF PROCEDURE.....B

**PER-TOF-TOC TAKEOFF CHARTS**

PER-TOF-TOC-05 INTRODUCTION

TAKEOFF CHARTS.....A

PER-TOF-TOC-10 GENERAL (TEMPERATURE ENTRY)

PER-TOF-TOC-10-10 TAKEOFF PERFORMANCE

TAKEOFF PERFORMANCE.....A

PER-TOF-TOC-10-20 TAKEOFF CHART DESCRIPTION

GENERAL.....A

Corrections due to Different Takeoff Conditions.....B

DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART.....C

MINIMUM SPEEDS.....D

FLEX TEMPERATURE INDICATOR.....E

PER-TOF-TOC-10-30 ADDITIONAL INFORMATION

ONE ENGINE OUT CLIMB PROCEDURE.....A

TAKEOFF ON A WET RUNWAY.....B

DESCRIPTION OF TAKEOFF CHART.....C

EXAMPLE OF TAKEOFF CHART.....D

*Continued on the following page*

*Continued from the previous page*

PER-TOF-TOC-12 MTOW CALCULATION (TEMPERATURE ENTRY)

PER-TOF-TOC-12-10 DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS

DIRECT CHART READING..... A

CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS..... B

CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS..... C

CORRECTIONS FOR WET OR CONTAMINATED RUNWAYS..... D

CORRECTIONS PRODUCED ON THE RTOW CHART..... E

COMBINING CORRECTIONS FROM FCOM AND CHART..... F

PER-TOF-TOC-12-30 EXTRAPOLATION

EXTRAPOLATION..... A

PER-TOF-TOC-12-40 MAXIMUM STRUCTURAL TAKEOFF WEIGHT

MAXIMUM STRUCTURAL TAKEOFF WEIGHT..... A

PER-TOF-TOC-12-50 SUMMARY

SUMMARY..... A

PER-TOF-TOC-14 FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

PER-TOF-TOC-14-10 DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS

GENERAL..... A

CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS..... B

CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS..... C

CORRECTIONS FOR WET RUNWAY..... D

CORRECTIONS PRODUCED ON THE RTOW CHART..... E

COMBINING CORRECTIONS FROM FCOM AND CHART..... F

PER-TOF-TOC-14-20 FLEXIBLE TAKEOFF NOT POSSIBLE

FLEXIBLE TAKEOFF NOT POSSIBLE..... A

PER-TOF-TOC-14-25 FLEXIBLE TAKEOFF POSSIBLE BUT NOT USED

FLEXIBLE TAKEOFF POSSIBLE BUT NOT USED..... A

PER-TOF-TOC-14-30 SUMMARY

SUMMARY..... A

PER-TOF-TOC-16 GENERAL (WEIGHT ENTRY)

PER-TOF-TOC-16-10 TAKEOFF PERFORMANCE

TAKEOFF PERFORMANCE..... A

*Continued on the following page*

*Continued from the previous page*

**PER-TOF-TOC-16-20 TAKEOFF CHART DESCRIPTION**

GENERAL.....	A
CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS.....	B
DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART.....	C
MINIMUM SPEED.....	D

**PER-TOF-TOC-16-30 ADDITIONAL INFORMATION**

ONE ENGINE OUT CLIMB PROCEDURE.....	A
TAKEOFF ON A WET RUNWAY.....	B
RTOW CHARTS - COMPLEMENTARY INFORMATION.....	C
RTOW EXAMPLE.....	D

**PER-TOF-TOC-18 MTOW CALCULATION (WEIGHT ENTRY)**

**PER-TOF-TOC-18-10 DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS**

GENERAL.....	A
MTOW DETERMINATION.....	B
CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS.....	C
CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS.....	D
CORRECTIONS FOR WET OR CONTAMINATED RUNWAYS.....	E
CORRECTIONS PRODUCED ON THE RTOW CHART.....	F
COMBINING CORRECTIONS FROM FCOM AND CHART.....	G

**PER-TOF-TOC-18-20 EXTRAPOLATION**

EXTRAPOLATION.....	A
--------------------	---

**PER-TOF-TOC-18-30 MAXIMUM STRUCTURAL TAKEOFF WEIGHT**

MAXIMUM STRUCTURAL TAKEOFF WEIGHT.....	A
--	---

**PER-TOF-TOC-18-40 SUMMARY**

SUMMARY.....	A
--------------	---

**PER-TOF-TOC-20 FLEXIBLE TAKEOFF (WEIGHT ENTRY)**

**PER-TOF-TOC-20-10 DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS**

GENERAL.....	A
CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS.....	B
CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS.....	C
CORRECTIONS FOR WET RUNWAY.....	D
CORRECTIONS PRODUCED ON THE RTOW CHART.....	E
COMBINING CORRECTIONS FROM FCOM AND CHART.....	F

*Continued on the following page*

*Continued from the previous page*

PER-TOF-TOC-20-20 FLEXIBLE TAKEOFF NOT POSSIBLE  
FLEXIBLE TAKEOFF NOT POSSIBLE.....A

PER-TOF-TOC-20-30 SUMMARY  
SUMMARY.....A

**PER-TOF-TOD TAKEOFF DATA**

PER-TOF-TOD-24 QNH/BLEEDS CORRECTION  
EFFECT OF QNH AND BLEEDS (up to 9200 ft).....A  
EXAMPLE.....B  
EFFECT OF QNH AND BLEEDS FOR HIGH ALTITUDE OPERATIONS (above 9200 ft).....C  
EXAMPLES FOR HIGH ALTITUDE OPERATIONS.....D

PER-TOF-TOD-25 MINIMUM SPEEDS  
PER-TOF-TOD-25-10 SPEEDS LIMITED BY VMCG/VMCA  
SPEEDS LIMITED BY VMCG/VMCA.....A

PER-TOF-TOD-25-20 V2 LIMITED BY VMU/VMCA  
MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS).....A

**PER-TOF-CTA RUNWAY CONTAMINATION**

PER-TOF-CTA-10 GENERAL  
GENERAL.....A

PER-TOF-CTA-20 DEFINITIONS  
DEFINITIONS.....A  
EQUIVALENCES.....B

PER-TOF-CTA-30 OPERATIONAL CONDITIONS  
OPERATIONAL CONDITIONS.....A

PER-TOF-CTA-40 TAKEOFF PERFORMANCE  
PER-TOF-CTA-40-10 TAKEOFF PERFORMANCE  
TAKEOFF PERFORMANCE.....A

PER-TOF-CTA-40-20 TAKEOFF FROM A WET RUNWAY  
HOW TO PROCEED.....A  
NO THRUST REVERSERS OPERATIVE (NO CLEARWAY).....B  
ALL THRUST REVERSERS OPERATIVE (NO CLEARWAY).....C  
NO THRUST REVERSERS OPERATIVE (WITH CLEARWAY).....D  
ALL THRUST REVERSERS OPERATIVE (WITH CLEARWAY).....E

*Continued on the following page*





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

#### PRELIMINARY PAGES - TABLE OF CONTENTS

*Continued from the previous page*

#### PER-TOF-CTA-40-30 TAKEOFF FROM A CONTAMINATED RUNWAY

TAKEOFF FROM A 6.3 MM (1/4 INCH) WATER COVERED RUNWAY.....	A
TAKEOFF FROM A 12.7 MM (1/2 INCH) WATER COVERED RUNWAY.....	B
TAKEOFF FROM A 6.3 MM (1/4 INCH) SLUSH COVERED RUNWAY.....	C
TAKEOFF FROM A 12.7 MM (1/2 INCH) SLUSH COVERED RUNWAY.....	D
TAKEOFF FROM A COMPACTED SNOW COVERED RUNWAY.....	E

#### PER-TOF-CTA-40-40 EXAMPLE

TAKEOFF PERFORMANCE ON DRY RUNWAY.....	A
TAKEOFF PERFORMANCE ON WET RUNWAY.....	B
TAKEOFF PERFORMANCE ON RUNWAY COVERED WITH 1/2 INCH SLUSH.....	C



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

THRUST OPTIONS - FLEXIBLE TAKEOFF

## DEFINITION OF FLEXIBLE TAKEOFF

### DEFINITION OF FLEXIBLE TAKEOFF

Ident.: PER-TOF-THR-FLX-10-00001718.0001001 / 28 JAN 11

Applicable to: ALL

In many cases the aircraft takes off with a weight lower than the maximum permissible takeoff weight. When this happens, it can meet the required performance (runway, second segment, obstacle,...) with a decreased thrust that is adapted to the weight : this is called FLEXIBLE TAKEOFF and the thrust is called FLEXIBLE TAKEOFF THRUST.

The use of flexible takeoff thrust saves engine life.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

THRUST OPTIONS - FLEXIBLE TAKEOFF

Intentionally left blank

**USE OF FLEXIBLE TAKEOFF**

**USE OF FLEXIBLE TAKEOFF**

Ident.: PER-TOF-THR-FLX-20-00001719.0001001 / 09 DEC 09

Applicable to: ALL

The pilot can use flexible takeoff when the actual takeoff weight is lower than the maximum permissible takeoff weight for the actual temperature. The maximum permissible takeoff weight decreases when temperature increases, so it is possible to assume a temperature at which the actual takeoff weight would be the limiting one. This temperature is called FLEXIBLE TEMPERATURE or assumed temperature and is entered in the FADEC via the MCDU PERF TO page in order to get the adapted thrust.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

THRUST OPTIONS - FLEXIBLE TAKEOFF

Intentionally left blank


**REQUIREMENTS**

**REQUIREMENTS**

Ident.: PER-TOF-THR-FLX-30-00001792.0027001 / 15 MAR 11

Applicable to: ALL

- Thrust must not be reduced by more than 40 % of the full rated takeoff thrust.
- The flexible takeoff N1 cannot be lower than the Max climb N1 at the same flight conditions. The FADEC takes the above two constraints into account to determine flexible N1. The above two constraints also limit the maximum flexible temperature at ISA + 70 (85 °C at sea level).
- The flexible temperature cannot be lower than the flat rating temperature, TREF (ISA +29 up to 2 000 ft) (See Note) , or the actual temperature (OAT).



**Note:** TREF being a function of pressure altitude, read it on the takeoff chart.

- Flexible takeoff is not permitted on contaminated runways.
- The operator should check the maximum thrust (TOGA) at regular intervals in order to detect any engine deterioration, or maintain an adequate engine performance monitoring program to follow up the engine parameters.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

THRUST OPTIONS - FLEXIBLE TAKEOFF

Intentionally left blank



**RECOMMENDATION**

**GENERAL**

Ident.: PER-TOF-THR-FLX-40-00001720.0002001 / 15 DEC 15

Applicable to: ALL

- In order to extend engine life and save maintenance costs, it is recommended to use flexible thrust reduction.
- However, to improve the takeoff performance, the thrust can be increased by selecting a lower flexible temperature.

Using the same takeoff chart, for a given weight it is possible to :

- Select a temperature lower than the maximum determined one and keep the speeds defined at maximum temperature or,
- Move towards the left side (tailwind) of the takeoff chart while remaining within the same configuration and looking for the same actual takeoff weight at lower temperature.

This produces a lower flexible temperature and, in general, lower takeoff speeds ( $V1 / VR / V2$ ).

Using one of the two above possibilities, check that the selected temperature is greater than the actual temperature ( OAT ) and greater than the flat rating temperature ( TREF ).

**TAKEOFF PROCEDURE**

Ident.: PER-TOF-THR-FLX-40-00001721.0001001 / 28 JAN 11

Applicable to: **ALL**

Depending on environmental takeoff conditions, the following procedure is recommended.

CONDITIONS	PROCEDURE	REASON
Dry or wet well paved runway	<ul style="list-style-type: none"> <li>- Use the flap setting giving the highest flexible temperature.</li> <li>- When flexible temperature difference between two flap settings is low, use the highest flap setting.</li> </ul>	Extend engine life and save maintenance costs.
High altitude takeoff	Use CONF2/CONF3	Improve comfort
Badly paved runway or Accelerate stop distance limited runway	Use CONF2/CONF3 or Move towards left side of the takeoff chart	Improve comfort Improve stopping distance
Windshear expected along takeoff path	Use maximum thrust	Maintain acceleration capability
Contaminated runway	Use maximum thrust (flex forbidden)	Improve stopping distance Decrease time on runway. Required by regulations.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - INTRODUCTION

## TAKEOFF CHARTS

Ident.: PER-TOF-TOC-05-00001704.0001001 / 21 MAR 11

**Applicable to: ALL**

Takeoff charts are required to provide performance at takeoff. It is possible to present the charts in two different ways, one of which is selected by the airline. The different presentations are :

- temperature entry (temperature provided in the left column)
- weight entry (weight provided in the left column).

Both presentations are described here after. Sections PER-TOF-TOC-10, 12 and 14 are relative to temperature entry while PER-TOF-TOC-16, 18 and 20 are relative to weight entry.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - INTRODUCTION

Intentionally left blank


**TAKEOFF PERFORMANCE**

**TAKEOFF PERFORMANCE**


Ident.: PER-TOF-TOC-10-10-00001705.0001001 / 23 FEB 11

Applicable to: ALL

Takeoff optimization is calculated for a given runway and its obstacles and for given conditions of flap setting, temperature, wind and QNH. The calculation produces a maximum permissible takeoff weight (or a maximum takeoff temperature for an actual weight).  
 The takeoff thrust produced by the engine varies as follows :



The optimization process calculates the speeds which will produce the maximum takeoff weight. To do so, it takes into account the different takeoff limitations such as TOD , ASD , TOR, second segment..., as shown on the figure charts below.



On a typical runway, the performance of a twin engine aircraft, is generally limited by the one engine out operation at takeoff. The optimum V2 /VS and optimum V1 /VR are consequently unique.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)

Intentionally left blank

**TAKEOFF CHART DESCRIPTION**

**GENERAL**

Ident.: PER-TOF-TOC-10-20-00001706.0003001 / 03 MAR 11  
Applicable to: ALL


The takeoff chart (RTOW : Regulatory Takeoff Weight) is calculated for a specific aircraft version and for a particular runway specified at the top of the chart. The top of the chart also gives some information about the runway and lists the calculation assumptions.

The chart is given for 2 different configurations and 5 wind values per configuration. This allows the crew to select the configuration that gives either :

- the highest permissible takeoff weight, or, for a given weight,
- the highest flexible temperature.

If different configurations give equivalent performance, the crew should select the configuration associated with the lowest takeoff speeds.

For each temperature value (and for a given configuration and wind), the chart provides the following information :



The available limitation codes are :

- First segment : 1
- Second segment : 2
- Runway length : 3
- Obstacles : 4
- Tire speed : 5
- Brake energy : 6
- Maximum computation weight : 7
- Final takeoff : 8
- VMU : 9

**CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS**

Ident.: PER-TOF-TOC-10-20-00014608.0001001 / 18 JUL 12

Applicable to: **ALL**

Each takeoff chart is computed for a given set of conditions (air conditioning, QNH, anti ice...) specified at the top of the chart. If the actual takeoff conditions are different, the crew must apply corrections. Two types of correction are available :

- Conservative corrections on *Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS* (to be used when not provided on the chart).
- Corrections (less restrictive) listed on the chart, to be applied as explained below.


Note: - If the RTOW chart is based on the CG being at 25 %, the crew can find the takeoff performance at a more forward CG by decreasing the takeoff weight by 1 000 kg (2 200 lb) and increasing V1 , VR and V2 by 1 kt.  
 - 25 % CG is the basic certified limit, on which all takeoff computations are based. To take into account the operational margins, the above penalties must be applied when operational CG is forward 27 % CG.

**DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART**

Ident.: PER-TOF-TOC-10-20-00005368.0001001 / 08 JUL 15

Applicable to: **ALL**

The corrections are presented on 4 lines:



TVMC is a temperature value given per column. This is a fictitious value that indicates the temperature above which the speeds are close to a VMCG /VMCA limitation or are VMCG /VMCA limited.

Note: The lower two lines may be shaded on certain chart formats.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)

### MINIMUM SPEEDS

Ident.: PER-TOF-TOC-10-20-00005372.0001001 / 08 JUL 15

**Applicable to: ALL**

Minimum V1/VR/V2 due to VMCG /VMCA are provided on the bottom right side of the takeoff chart. They are only applicable in case of speed corrections. These speeds are conservative. They may be slightly higher than V1/VR/V2 displayed on the takeoff chart.

### FLEX TEMPERATURE INDICATOR

Ident.: PER-TOF-TOC-10-20-00005373.0001001 / 18 FEB 11

**Applicable to: ALL**

On the temperature entry chart, the temperature column may display asterisks or have a gray band to indicate temperature values above TMAX and which are flex temperature.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)

Intentionally left blank

**ADDITIONAL INFORMATION**

**ONE ENGINE OUT CLIMB PROCEDURE**

Ident.: PER-TOF-TOC-10-30-00001708.0001001 / 23 FEB 11

Applicable to: ALL

The performance given in the chart is consistent with the flight path specified for the aircraft with one engine out and takes into account significant obstacles.

When the procedure to be followed is not the standard instrument departure, the chart describes a specific procedure (EOSID).

When the specified procedure requires a turn, except if otherwise stated on the RTOW chart, the turn should be performed with a maximum bank of 15 ° until the aircraft reaches 1 500 ft or until green dot.

The acceleration height (or altitude) ensures that the net flight path clears the highest obstacle by at least 35 ft when accelerating in level flight to green dot speed after an engine failure, in the most adverse conditions.

**TAKEOFF ON A WET RUNWAY**

Ident.: PER-TOF-TOC-10-30-00001709.0002001 / 23 FEB 11

Applicable to: ALL


Takeoff charts computed for wet runway with a 15 ft screen height and/or use of reverse thrust may produce, in some conditions, a maximum takeoff weight (or flexible temperature) higher than that obtained for a dry runway. It is thus mandatory to compare both charts (dry and wet) and retain the lower of the two weights (or flexible temperature) and the associated speeds determined for a wet runway.

*Note: The crew need not compare the charts if the top of the wet runway chart specifies "DRY CHECK". (The comparison has already been inserted in the WET runway calculation).*


**DESCRIPTION OF TAKEOFF CHART**

Ident.: PER-TOF-TOC-10-30-00001710.0006001 / 23 FEB 11

Applicable to: ALL



AXXXXXX		ENGINE		AIRPORT NAME				15L		VERSION	DATE
QNH		1013 HPA		Elevation	489 FT	TORA	10000 FT	4 obstacles	XXXXXX	V8	
Air conditioning		AC OFF		Isa temp	14 C	TODA	10200 FT				
Anti-icing		AI OFF		Rwy slope	.08 %	ASDA	10000 FT				
OAT		CONF 1 + F				CONF 2				DRY	
°C	TAILWIND	TAILWIND	WIND	HEADWIND	HEADWIND	TAILWIND	TAILWIND	WIND	HEADWIND	HEADWIND	
	- 10.0 KT	- 5.0 KT	0 KT	+ 10.0 KT	+ 20.0 KT	- 10.0 KT	- 5.0 KT	0 KT	+ 10.0 KT	+ 20.0 KT	
46	72.8 3/4 141/45/47	74.3 3/4 145/48/49	75.9 3/4 150/50/51	76.9 3/4 153/53/54	78.0 3/4 154/54/55	72.6 3/4 141/46/46	74.2 3/4 145/48/49	75.7 3/4 150/51/51	76.9 3/4 153/53/53	77.9 3/4 155/55/55	
48	71.4 3/4 141/45/46	73.0 3/4 145/47/48	74.5 3/4 149/50/51	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				74.3 3/4 150/51/51	75.4 3/4 153/53/53	76.4 3/4 154/54/54	
50	70.1 3/4 140/44/46	71.6 3/4 145/47/48	73.1 3/4 149/49/50								
*52	68.8 3/4 140/44/45	70.2 3/4 145/46/47	71.7 3/4 149/49/50	72.6 4/4 150/50/51	73.5 4/4 151/51/52	68.6 3/4 140/45/45	70.0 3/4 145/47/47	71.5 3/4 150/50/50	72.5 3/4 151/51/51	73.4 4/4 153/53/53	
*54	67.4 3/4 140/43/44	68.9 3/4 145/46/47	70.2 3/4 148/48/49	71.1 4/4 149/49/50	72.0 4/4 150/50/51	67.3 3/4 140/44/44	68.7 3/4 145/47/47	70.1 3/4 149/49/49	71.0 4/4 151/51/51	71.9 4/4 152/52/52	



**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)

AXXXXXX	ENGINE		AIRPORT NAME				VERSION	DATE		
QNH	1013 HPA		Elevation	489 FT	TORA	10000 FT	15L	AXXXXXX V8		
Air conditioning	AC OFF		Isa temp	14 C	TODA	10200 FT	4 obstacles	DRY		
Anti-icing	AI OFF		Rwy slope	.08 %	ASDA	10000 FT				
OAT °C	CONF 1 + F					CONF 2				
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT
INFLUENCE OF RUNWAY CONDITION										
WET	+0/+0 0/+0/+0	+0/+0 -1/+0/+0	-0/-1 -1/+0/+0	-0/-1 0/+0/+0	-2/-1 -1/+0/+0	+0/+0 -1/+0/+0	+0/+0 0/+0/+0	+0/+0 0/+0/+0	+0/+0 0/+0/+0	-2/-1 -1/+0/+0
D QNH HPA	INFLUENCE OF DELTA PRESSURE									
-10	-8/-2 0/-1/-1 (+54)-8/-2 0/+0/+0	-9/-2 0/-1/-1 (+54)-9/-2 0/+0/+0	-1.4/-3 0/-1/-1 (+54)-1.4/-3 0/+0/+0	-1.0/-2 -1/-1/-1 (+34)-1.0/-2 -1/+0/+0	-1.0/-2 -1/-1/-1 (+54)-1.0/-2 -1/+0/+0	-8/-2 0/-1/-1 (+54)-8/-2 0/+0/+0	-8/-2 0/-1/-1 (+54)-8/-2 0/+0/+0	-1.0/-2 0/0/0 (+54)-1.0/-2 0/+0/+0	-1.2/-2 0/0/0 (+54)-1.2/-2 0/+0/+0	-1.1/-2 -1/-1/-1 (+54)-1.1/-2 -1/+0/+0
+10	+6/+0 +1/+0/+0 (+54)+2/+0 +1/+0/+0	+6/+0 +1/+0/+0 (+54)+2/+0 +1/+0/+0	+0/+0 +1/+1/+1 (+54)+0/+0 +1/+1/+1	+6/+0 +1/+1/+1 (+54)+2/+0 +1/+1/+1	+6/+0 +1/+1/+1 (+54)+2/+0 +1/+1/+1	+5/+0 +0/+0/+0 (+54)+3/+0 +0/+0/+0	+5/+0 +1/+0/+0 (+54)+1/+0 +1/+1/+1	+4/+0 +1/+1/+1 (+54)+2/+0 +1/+1/+1	+3/+0 +1/+1/+1 (+54)+1/+0 +1/+1/+1	+2/+0 +0/+1/+1 (+54)+0/+0 +0/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DT FLEX DV1-DVR-DV2 (KT) (TVMC OAT C) DW (1000 KG) DT FLEX DV1-DVR-DV2 (KT)	MTOW (1000 KG) codes V1min/VR/V2(KT)		*VMC *LIMITATION	Tref (OAT) =29 C Tmax (OAT) =50 C		Min acc height 784Ft Max acc height 1965Ft	Min QNH alt 1280Ft Max QNH alt 2461Ft	MINIMUM & MAXIMUM ACC. HEIGHT AND ALT.		
LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=time speed 6=brake energy 7=max weight 8=final takeoff 9=VMU					MIN V1/VR/V2 = 120/22/28 CHECK VMU LIMITATION CORRECT. V1/VR/V2 = .1KI/1000 Kg					
INFLUENCE CORRECTION ΔWEIGHT ΔT FLEX ΔV1/ΔVR/ΔV2 (TVMC) ΔWEIGHT ΔT FLEX ΔV1/ΔVR/ΔV2						MINIMUM VALUES OF V1/VR/V2 TO WHICH TAKEOFF SPEEDS MUST BE LIMITED WHEN DECREMENTS ARE APPLIED				
						V1/VR/V2 DECREMENTS FOR WEIGHTS BELOW THE LOWEST WEIGHT OF A COLUMN				



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)

### EXAMPLE OF TAKEOFF CHART

Ident.: PER-TOF-TOC-10-30-00014705.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - GENERAL (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES		AIRPORT NAME					Version	Date	
QNH	1013.25 HPA		Elevation	489 FT	TORA	3000 M	<b>15L</b>	A3XXXXXX	**V20	
Air cond.	AC OFF		Isa temp	14 C	TODA	3000 M		4 obstacles	DRY	
Anti-icing	AI OFF		Rwy slope	.08 %	ASDA	3000 M				
All reversers operating No reversers on dry runway										
OAT °C	CONF 1 + F					CONF 2				
	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
-20	80.2 4/6 156/56/58	80.2 4/6 162/62/64	83.6 3/4 167/67/69	84.8 3/4 170/70/72	85.8 3/4 173/73/75	80.4 4/6 154/54/59	80.4 3/4 159/59/64	83.4 3/4 164/64/69	84.4 3/4 167/67/72	85.2 3/4 169/69/74
-10	78.5 4/6 153/56/58	81.3 4/6 159/59/62	83.1 4/6 164/64/66	84.3 3/4 167/67/69	85.3 3/4 171/71/72	79.7 4/6 151/52/57	81.4 4/6 156/56/62	82.9 3/4 161/61/66	84.0 3/4 164/64/69	84.9 3/4 167/67/72
0	78.8 4/6 151/54/57	80.6 4/6 156/57/59	82.5 4/6 162/62/64	83.7 3/4 165/65/67	84.7 3/4 168/68/70	80.4 4/6 149/51/56	80.4 3/4 154/54/60	82.4 3/4 159/59/64	83.5 3/4 162/62/67	84.5 3/4 165/65/70
10	78.2 4/6 148/53/55	80.0 4/6 154/57/59	81.8 4/6 159/60/62	83.1 4/6 163/63/65	84.2 3/4 166/66/67	78.4 4/6 147/50/54	80.2 4/6 152/52/58	81.9 3/4 156/56/62	83.0 3/4 159/59/65	83.9 3/4 162/63/68
20	77.6 4/6 146/51/53	79.3 4/6 151/55/57	81.1 4/6 157/57/61	82.5 4/6 160/60/62	83.6 4/6 163/63/65	77.7 4/6 145/48/52	79.5 4/6 150/51/56	81.3 4/6 154/54/60	82.4 3/4 157/57/63	83.4 3/4 160/61/66
30	76.9 4/6 144/50/52	78.7 4/6 149/54/56	80.5 4/6 154/57/60	81.8 4/6 158/58/60	83.0 4/6 161/61/63	77.1 4/6 143/46/50	78.9 4/6 148/50/55	80.7 4/6 153/53/58	81.9 3/4 155/56/61	82.9 3/4 158/58/64
32	76.8 4/6 144/50/52	78.6 4/6 149/53/55	80.4 4/6 154/56/55	81.7 4/6 157/58/60	82.9 4/6 161/61/63	77.0 4/6 142/45/50	78.7 4/6 147/50/55	80.6 4/6 152/53/58	81.8 4/6 155/55/60	82.8 3/4 157/58/64
34	76.7 4/6 143/50/52	78.4 4/6 148/53/55	80.2 4/6 154/56/58	81.5 4/6 157/57/60	82.8 4/6 160/60/62	76.9 4/6 142/45/50	78.6 4/6 147/52/57	80.5 4/6 152/52/57	81.7 4/6 154/55/60	82.7 3/4 157/58/64
36	76.6 4/6 143/49/52	78.4 4/6 148/52/54	80.1 4/6 153/56/58	81.4 4/6 156/57/59	82.7 4/6 160/60/62	76.8 4/6 141/45/50	78.5 4/6 148/50/55	80.3 4/6 151/52/57	81.6 4/6 154/55/60	82.6 3/4 157/58/63
38	76.5 4/6 142/49/52	78.3 4/6 147/52/54	80.0 4/6 153/56/58	81.3 4/6 156/58/60	82.6 4/6 159/60/62	76.7 4/6 141/45/50	78.4 4/6 146/49/53	80.2 4/6 151/52/57	81.5 4/6 154/54/59	82.5 3/4 156/58/63
40	76.4 4/6 142/49/52	78.2 4/6 147/52/54	79.9 4/6 152/56/58	81.2 4/6 156/58/60	82.5 4/6 159/60/61	76.6 4/6 141/45/50	78.3 4/6 146/49/53	80.1 4/6 150/51/56	81.4 4/6 153/54/59	82.4 3/4 156/57/63
42	76.3 4/6 142/49/51	78.0 4/6 147/52/54	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>					81.3 4/6 153/54/59	82.3 3/4 156/57/62	83.3 3/4 157/58/64
44	76.1 4/6 142/49/51	77.9 4/6 146/51/53						81.1 4/6 153/53/58	82.1 3/4 156/57/62	83.1 4/6 157/58/64
46	75.5 4/6 142/48/50	77.2 4/6 148/50/52	78.9 4/6 152/55/57	80.2 4/6 155/56/58	80.7 4/6 154/56/58	75.7 4/6 141/45/49	77.3 4/6 145/47/52	79.1 4/6 150/50/55	80.5 4/6 152/53/58	81.5 4/6 154/55/60
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63
50	73.6 4/6 143/47/49	75.3 4/6 148/49/51	76.9 4/6 153/53/55	77.9 4/6 154/54/55	77.9 2/4 151/54/55	73.8 4/6 142/42/46	75.4 4/6 146/47/51	76.9 3/4 150/50/54	78.0 3/4 152/52/57	78.0 2/4 149/52/57
52	72.7 4/6 144/46/48	74.4 4/6 148/49/51	75.8 3/4 153/53/54	76.3 2/4 152/52/53	76.3 2/4 147/52/53	72.9 4/6 142/44/48	74.3 3/4 148/48/50	75.8 3/4 150/50/54	76.8 3/4 150/50/55	76.4 2/4 146/50/55
54	71.8 4/6 145/46/47	73.3 3/4 148/49/51	74.6 3/4 152/52/54	75.0 2/4 150/50/52	75.0 2/4 145/50/52	71.9 3/4 142/43/47	73.3 3/4 146/46/50	74.7 3/4 149/49/54	75.1 2/4 148/49/54	75.1 2/4 144/49/54
<b>INFLUENCE OF RUNWAY CONDITION</b>										
WET	-2.0/-6	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.5/-4	-1.2/-3	-1.2/-2	-1.6/-3
	-16/1/-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/-2	-14/0/-1	-13/0/-1	-12/-2/-2	-10/-1/-1	-4/-2/-2
	(+54) +2.0/-5	(+54) -1.5/-4	(+51) -1.3/-3	(+54) -1.1/-2	(+54) -0.8/-2	(+50) -0.9/-4	(+54) -1.5/-4	(+54) -1.3/-3	(+54) -1.2/-2	(+54) -1.3/-3
	-16/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-11/0/0	-10/0/0	-4/0/0
<b>INFLUENCE OF DELTA PRESSURE</b>										
D/DNH HPA	-10.0	0/0/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-0.7/-2	-1.2/-3	-0.8/-2	-0.8/-2
	0/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0
	(+54) 0.8/-2	(+54) -0.7/-2	(+54) -0.7/-2	(+54) -1.3/-3	(+54) -0.7/-2	(+54) -0.7/-2	(+54) -1.2/-3	(+54) -0.8/-2	(+54) -0.8/-2	(+54) -0.8/-2
	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0	-1/0/0
	+10.0	+0.2/0	+0.2/0	0/0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1	0/0/0	+1/+1/+1	+1/+1/+1
	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.0/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1	+1/+1/+1	0/0/0	+1/+1/+1	+1/+1/+1
LABEL: ROR INFLUENCE DW (1000 KG) DTLEFL DV1-DVR-DV2 (KT)	M/DNH (1000 KG) codes V/min/Vmax (kt)		*M/C LIMITATION		Trst (CAT) Tmax (CAT) = 54 C		Min solo height Max alt height		454 FT 1917 FT	
(T/MC) CAT C DW (1000 KG) DTLEFL DV1-DVR-DV2 (KT)	LIMITATION CODES: 1-1st segment 2-2nd segment 3-minute length 4-obstacles 5-8 ft/speed 6-brake energy 7-max weight 8-critical take-off thrust						Min V1/VRV2 = 108/111/117 CHECK VMMU LIMITATION Const. V1/VRV2 = 1.0 KT/1000 KG			



**DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS**

**DIRECT CHART READING**

Ident.: PER-TOF-TOC-12-10-00001712.0002001 / 23 FEB 11

Applicable to: ALL

The takeoff chart is computed for a given runway under a set of conditions, which are:

- OAT
- Wind
- Configuration
- QNH, air conditioning, anti ice...

Two configurations are produced on the chart. This enables the crew to select that giving the highest permissible takeoff weight. In case of equivalent performance, retain the configuration giving the lower takeoff speeds.

For a given configuration, enter the chart with the OAT and wind value to determine the maximum permissible weight. For an OAT or wind value not presented on the chart, interpolate between two consecutive temperature rows and/or two consecutive wind columns. Conservative OAT or wind values can also be considered. No extrapolation is allowed.

**CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS**

Ident.: PER-TOF-TOC-12-10-00001713.0002001 / 28 JAN 11

Applicable to: ALL

Retain the maximum takeoff weight, associated configuration and speeds from above.  
For conditions different from those of the chart, apply relevant corrections.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

**CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS**

Ident.: PER-TOF-TOC-12-10-00014706.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Corrections are given for QNH ≠ 1 013 hPa, air conditioning ON, anti ice ON(Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS).

1. For the given wind and temperature conditions, read the maximum takeoff weight.
2. Apply the published weight correction(s) to the maximum takeoff weight (for each correction) to determine the maximum permissible takeoff weight.
3. Read the speeds associated with the maximum permissible takeoff weight by entering the chart in the wind column.

**EXAMPLE 1**

DATA: OAT = 25 °C  
 Head Wind = 10 kt  
 Air conditioning ON  
 QNH = 1 013 hPa

Use the chart (Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART):


A3XXXXX	ENGINES		AIRPORT NAME						Version	Date
QNH Air cond Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation EAS temp Rwy slope	489 FT 14 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M	<b>15L</b> 4 obstacles	A3XXXXXX	**V20	
OAT °C	CONF 1 + F						CONF 2			
	TAILWIND +10.0 KT	TAILWIND +5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND +10.0 KT	TAILWIND +5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
-20	80.2 4/6 150/59/68	80.2 4/6 162/62/64	83.6 3/4 197/67/89	84.8 3/4 170/70/72	85.8 3/4 173/73/75	80.4 4/6 154/54/59	81.9 3/4 159/59/64	83.4 3/4 164/64/69	84.4 3/4 167/67/72	85.2 3/4 169/69/74
-10	79.5 4/6 163/66/66	81.3 4/6 159/68/62	83.1 4/6 164/64/69	84.3 3/4 167/67/69	85.3 3/4 171/71/72	79.7 4/6 151/52/57	81.4 4/6 156/56/62	82.9 3/4 161/61/66	84.0 3/4 164/64/69	84.9 3/4 167/67/72
0	78.8 4/6 151/64/57	80.6 4/6 160/60/62	82.5 4/6 162/62/64	83.7 3/4 165/65/67	84.7 3/4 168/68/70	79.0 4/6 149/51/56	80.8 4/6 154/54/60	82.4 3/4 159/59/64	83.6 3/4 162/62/67	84.5 3/4 165/65/70
10	78.2 4/6 148/53/55	80.0 4/6 154/57/59	81.8 4/6 159/60/62	83.1 4/6 163/63/65	84.2 3/4 166/66/67	78.4 4/6 147/50/54	80.2 4/6 152/52/58	81.9 3/4 156/56/62	83.0 3/4 159/59/65	83.9 3/4 162/63/68
20	77.6 4/6 146/51/53	79.3 4/6 151/55/57	81.1 4/6 157/57/61	82.5 4/6 160/60/62	83.6 4/6 163/63/65	77.7 4/6 145/48/52	79.5 4/6 150/51/56	81.3 4/6 154/54/60	82.4 3/4 157/57/63	83.4 3/4 160/61/66
30	76.9 4/6 144/50/52	78.7 4/6 149/54/56	80.5 4/6 154/57/60	81.8 4/6 158/59/60	83.0 4/6 161/61/63	77.1 4/6 143/46/50	78.9 4/6 148/50/55	80.7 4/6 153/53/58	81.9 3/4 155/56/61	82.9 3/4 158/59/64
32	76.8 4/6 144/50/52	78.6 4/6 149/53/55	80.4 4/6 154/56/55	81.7 4/6 157/58/60	82.9 4/6 161/61/63	77.0 4/6 142/45/50	78.7 4/6 147/50/55	80.6 4/6 152/53/58	81.8 4/6 155/56/60	82.8 3/4 157/59/64
34	76.7 4/6 143/50/52	78.4 4/6 148/53/55							81.7 4/6 154/55/60	82.7 3/4 157/58/64
36	76.6 4/6 143/49/52	78.4 4/6 148/52/54							76.1 4/6 154/55/60	76.6 3/4 157/58/63
38	76.5 4/6 142/49/52	78.3 4/6 147/52/54	80.0 4/6 153/56/58	81.3 4/6 156/58/60	82.6 4/6 159/60/62	76.7 4/6 141/45/50	78.4 4/6 146/48/53	80.2 4/6 151/52/57	81.5 4/6 154/54/59	82.5 3/4 156/58/63

Enter the 10 kt head wind column and interpolate for 25 °C, CONF 1+F,

- Maximum TO weight (1 000 kg) air conditioning OFF.....82.1
- Enter the 10 kt head wind column and interpolate for 25 °C, CONF 2,
- Maximum TO weight (1 000 kg) air conditioning OFF.....82.1
- Retain CONF 2 as takeoff configuration as the speeds are lower.
- Maximum TO weight (1 000 kg) air conditioning OFF.....82.1

Use the QNH/BLEEDS correction page:(Refer to *PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).

For example:



- Air conditioning correction..... -1.8
- Maximum permissible TO weight (1 000 kg) air conditioning ON..... 80.3
- Determine takeoff speeds for 80.3 (1 000 kg) in the 10 kt head wind column CONF 2 (interpolate when necessary).



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

A3XXXXX	ENGINES	AIRPORT NAME						Version	Date	
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	<b>15L</b>	A3XXXXXX	**V20		
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M		4 obstacles	DRY		
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M					
All reversers operating No reversers on dry runway										
OAT °C	CONF 1 + F						CONF 2			
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT
44	76.1 4/6 142/49/51	77.9 4/6 146/51/53	75.1 2/3 153/54/55	75.7 2/3 156/57/58	76.3 2/3 158/59/60	73.0 2/3 142/44/47	74.1 2/3 146/47/51	75.1 2/3 150/51/55	81.1 4/6 153/53/58	82.1 3/4 155/57/62
46	75.5 4/6 142/48/50	77.2 4/6 148/50/52	78.9 4/6 152/55/57	80.2 4/6 155/58/58	80.7 4/6 154/56/58	75.7 4/6 141/45/49	77.3 4/6 145/47/52	79.1 4/6 150/50/55	80.3 3/4 152/53/58	80.7 2/4 152/55/60
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63


V1 = 152 kt, VR = 153 kt, V2 = 158 kt.

**CORRECTIONS FOR WET OR CONTAMINATED RUNWAYS**

Ident.: PER-TOF-TOC-12-10-00001715.0001001 / 28 JAN 11

Applicable to: **ALL**

(Refer to PER-TOF-CTA-10 GENERAL)

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>TAKEOFF</b></p> <p style="text-align: center;">TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)</p>
---	---

**CORRECTIONS PRODUCED ON THE RTOW CHART**

Ident.: PER-TOF-TOC-12-10-00014707.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

For example: *Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*

A description of this correction is given on *Refer to PER-TOF-TOC-10-20 DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART*. The list of corrections is not exhaustive, however the most commonly used corrections are wet runway, QNH, air conditioning and/or anti ice. A maximum of three corrections can be produced on one chart.

To apply the corrections, proceed as follows:

1. Enter the chart with given OAT and wind to determine the maximum takeoff weight before correction.
2. Apply the first correction:
  - If OAT is less than or equal to TVMC (line 3), apply  $\Delta W$  correction from line 1 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 2.
  - Else, (for OAT greater than TVMC ), apply  $\Delta W$  correction from line 3 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 4.
3. To combine a second (and third, as applicable) correction:
  - If OAT is less than or equal to TVMC (line 3), apply  $\Delta W$  correction from line 1 and  $\Delta V1 / VR / \Delta V2$  corrections from line 2.
  - Check that the resulting speeds are higher than the minimum speeds displayed on the RTOW chart and that V2 is higher than the VMU limited speed (*Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)*).
  - If OAT is higher than TVMC (line 3) or if the above speed check is not fulfilled, apply  $\Delta W$  correction from line 3 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 4. No speed check is required.

- Note:
- QNH correction is given for  $\pm 10$  hPa . It is allowed to extrapolate linearly for greater QNH deviation.
  - When using a takeoff chart with failure cases, it is not allowed to combine two failure cases.
  - Corrections from the chart must be applied from top to bottom, i.e. in the RTOW on *Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*, apply the wet correction first.
  - If asterisk or dotted lines appear in the correction boxes, refer to more conservative corrections provided in the FCOM.
  - No speed check is required for the first correction. However, if the first influence correction follows a conservative FCOM correction, a speed check is required.



# PERFORMANCE

## TAKEOFF

**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

### EXAMPLE 2

DATA : CONF 2  
 OAT = 25 °C  
 Head Wind = 10 kt  
 QNH = 1 028 hPa  
 WET runway

In this example, we will consider CONF 2 as takeoff configuration. But same computation has to be done in CONF 1 and you must retain the best configuration.

Use the chart (*Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*)

A3XXXX	ENGINES			AIRPORT NAME				Version	Date	
QNH	1013.25 HPA			Elevation	488 FT	FORA	3000 M	<b>15L</b>	A3XXXXXX **V20	
Air cond.	AG OFF			Sea level	14 °C	TODA	3000 M			
Anti-icing	AI OFF			Rwy slope	.08 %	ASDA	3000 M			
All reversers operating										
No reversers on dry runway										
	CONF 1 + F						CONF 2			
OAT °C	TAILWIND +10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
-20	80.2 4/6 156/59/58	80.2 4/6 162/62/64	83.6 3/4 167/67/69	84.8 3/4 170/70/72	85.8 3/4 173/73/75	80.4 4/6 154/54/59	81.9 3/4 159/59/64	83.4 3/4 164/64/69	84.4 3/4 167/67/72	85.2 3/4 169/69/74
-10	79.5 4/6 163/59/58	81.3 4/6 159/59/62	83.1 4/6 164/64/66	84.3 3/4 167/67/69	85.3 3/4 171/71/72	79.7 4/6 151/52/57	81.4 4/6 156/56/62	82.9 3/4 161/61/66	84.0 3/4 164/64/69	84.9 3/4 167/67/72
0	78.8 4/6 151/54/57	80.6 4/6 156/57/59	82.5 4/6 162/62/64	83.7 3/4 165/65/67	84.7 3/4 168/68/70	79.0 4/6 149/51/56	80.8 4/6 154/54/60	82.4 3/4 159/59/64	83.5 3/4 162/62/67	84.5 3/4 165/65/70
10	78.2 4/6 148/53/55	80.0 4/6 154/57/59	81.8 4/6 159/60/62	83.1 4/6 163/63/65	84.2 3/4 166/66/67	78.4 4/6 147/50/54	80.2 4/6 152/52/58	81.9 3/4 156/56/62	83.0 3/4 159/59/65	83.9 3/4 162/63/68
20	77.6 4/6 146/51/53	79.3 4/6 151/55/57	81.1 4/6 157/57/61	82.5 4/6 160/60/62	83.6 4/6 163/63/65	77.7 4/6 145/48/52	79.5 4/6 150/51/56	81.3 4/6 154/54/60	82.4 3/4 157/57/63	83.4 3/4 160/61/66
30	76.9 4/6 144/50/52	78.7 4/6 149/54/56	80.5 4/6 154/57/60	81.8 4/6 158/58/60	83.0 4/6 161/61/63	77.1 4/6 143/46/50	78.9 4/6 148/50/55	80.7 4/6 153/53/58	81.9 3/4 155/55/61	82.9 3/4 158/58/64
32	76.8 4/6 144/50/52	78.6 4/6 149/53/55	80.4 4/6 154/56/55	81.7 4/6 157/56/60	82.9 4/6 161/61/63	77.0 4/6 142/45/50	78.7 4/6 147/50/55	80.6 4/6 152/53/58	81.8 4/6 155/55/60	82.8 3/4 157/56/64
34	76.7 4/6 143/50/52	78.4 4/6 148/53/55	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>							
36	76.6 4/6 143/49/52	78.4 4/6 148/53/54								
38	76.5 4/6 142/48/52	78.3 4/6 147/52/54								

- Enter the 10 kt head wind column and interpolate for 25 °C, CONF 2, max TO weight (1 000 kg).....82.1
- Read associated speeds as V1 = 156 kt, VR = 157 kt, V2 = 162 kt
- Apply WET correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES	AIRPORT NAME						Version	Date	
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	<b>15L</b>	A3XXXXXX	**V20		
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M		4 obstacles	DRY		
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M					
All reversers operating No reversers on dry runway										
OAT °C	CONF 1 + F					CONF 2				
	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
INFLUENCE OF RUNWAY CONDITION										
WET	-2/0/-5	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.5/-4	-1.2/-3	-1.2/-2	-1.5/-3
	-16/17/-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/2	-14/0/0	-13/0/0	-12/-2/-2	-10/-1/-1	-4/-2/-2
	(+54) +2.0/-5	(+54) -1.5/-4	(+54) -1.3/-3	(+54) -1.1/-2	(+54) -0.8/-2	(+54) -0.9/-4	(+54) -1.5/-4	(+54) -1.3/-3	(+54) -1.2/-2	(+54) -1.5/-3
	-16/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-11/0/0	-10/0/0	-4/0/0
INFLUENCE OF DELTA PRESSURE										
QNH HPA	-10.0	-0.8/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-0.7/-2	-1.2/-3	-0.8/-2	-0.8/-1
	(+54) -0.8/-2	(+54) -0.7/-2	(+54) -0.7/-2	(+54) -1.3/-3	(+54) -0.7/-2	(+54) -0.7/-2	(+54) -1.2/-3	(+54) -0.8/-2	(+54) -0.8/-2	(+54) -0.8/-2
	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0
	+10.0	+0.2/0	+0.2/0	0/0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0
	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.0/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DT/FLX DV1-DV2-DV2 (KT) (TVMC OAT C) DW (1000 KG) DT/FLX DV1-DV2-DV2 (KT)										
MTOW(1000 KG) codes V1max/VR/V2 (kt) LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=ice speed 6=brake energy 7=max weight 8=final take-off 9=VMU										
Tref (OAT) = 44 C Tmax (OAT) = 54 C Min acc height 454 FT Max acc height 1917 FT Min QNH at 953 FT Max QNH at 2400 FT Min V1/VR/V2 = 108/114/117 CHECK VMU LIMITATION Correct V1/VR/V2 = 1.0 KT/1000 KG										

- For OAT < TVMC (54 °C), ΔW = ..... -1.2  
 Intermediate weight (1 000 kg)..... = 80.9  
 Associated speeds,  
 V1 = 156 kt - 10 = 146 kt  
 VR = 157 kt - 1 = 156 kt  
 V2 = 162 kt - 1 = 161 kt  
 (No speed check required for first correction)
- Apply QNH correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

A3XXXXX	ENGINES	AIRPORT NAME				Version	Date
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF	Elevation Isa temp Rwy slope	489 FT 14 C 08 %	TORA TODA ASDA	3000 M 3000 M 3000 M	15L 4 obstacles	DRY A3XXXXXX **/20
OAT		CONF 1 + F				CONF 2	
°C	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT
						WIND 0 KT	HEADWIND +10.0 KT
							HEADWIND +20.0 KT
INFLUENCE OF RUNWAY CONDITION							
WET	-2.0/-5 -18/1/-1	-1.5/-4 -15/-2/-2	-1.2/-3 -13/-4/-4	-1.1/-2 -11/-3/-3	1.8/-2 -10/-2/-2	-0.9/-4 -14/0/-	-1.5/-4 -13/0/-
	(+54)-2.0/-4 -16/0/0	(+54)-1.5/-1 -15/0/0	(+54)-1.3/-3 -13/0/0	(+54)-1.1/-2 -11/0/0	(+54)-0.8/-2 -10/0/0	(+54)-0.9/-4 -14/0/0	(+54)-1.2/-2 -10/0/0
INFLUENCE OF DELTA PRESSURE							
QNH HPA							
-10.0	-0.8/-2 0/0/0 (+54)-0.8/-2 0/0/0	-0.7/-2 0/0/0 (+54)-0.7/-2 0/0/0	-0.7/-2 0/0/0 (+54)-0.7/-2 0/0/0	-1.3/-3 -1/0/0 (+54)-1.3/-3 0/0/0	-0.7/-2 0/0/0 (+54)-0.7/-2 0/0/0	-1.2/-3 0/0/0 (+54)-1.2/-3 0/0/0	-0.8/-2 -1/0/0 (+54)-0.8/-2 -1/0/0
+10.0	+0.2/0 0/0/0 (+54)+0.2/0 0/0/0	+0.2/0 0/0/0 (+54)+0.2/0 0/0/0	+0.2/0 0/0/0 (+54)+0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+54)+0.2/0 +1/+1/+1	+0.2/0 0/+1/+1 (+54)+0.2/0 0/+1/+1	+0.2/0 0/0/0 (+54)+0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+54)+0.2/0 +1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) D/FLEX DV1-DV6, DV2 (KT) (TVMC OAT C) DW (1000 KG) D/FLEX DV1-DV6, DV2 (KT)	MTOW(1000 KG) correc V1minVRV2 (kt)	TVMC LIMITATION	Trif (OAT) = 44 C Tmax (OAT) = 54 C	Min acc height 466 FT Max acc height 1917 FT	Min QNH alt. 953 FT Max QNH alt. 2408 FT	Min V1/VRV2 = 109/114/117 CHECK VMC LIMITATION Correct. V1/VRV2 = 1.0 KT/1000 KG	

For OAT < TVMC (54 °C),  $\Delta W = 0.2 \times 15/10 = \dots\dots\dots + 0.3$   
 Maximum permissible takeoff weight (1 000 kg)..... = 81.2

Associated speeds,

$V1 = 146 \text{ kt} + 1 \times 15/10 = 147 \text{ kt}$

$VR = 156 \text{ kt} + 1 \times 15/10 = 158 \text{ kt}$


$V2 = 161 \text{ kt} + 1 \times 15/10 = 163 \text{ kt}$

- Check that the speeds are higher than minimum speeds from the chart and from VMU table (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)).

It is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4.

	Takeoff Configuration : 2			
	TOW	V1	VR	V2
TOW (RTOW)	82.1	156	157	162
FCOM correction(s)				
Intermediate value	82.1	156	157	162
WET Correction	- 1.2	-10	-1	-1
Intermediate value	80.9	146	156	161
QNH Correction	+ 0.3	+1	+2	+2
Final value	81.2	147	158	163



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PERFORMANCE</b> <b>TAKEOFF</b></p> <p>TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)</p>
---	--

**COMBINING CORRECTIONS FROM FCOM AND CHART**

Ident.: PER-TOF-TOC-12-10-00014713.0001001 / 29 JUL 16  
**Applicable to: ALL**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Proceed as follows:

1. Enter the chart with selected configuration, OAT and wind to read the maximum takeoff weight.
2. Apply corrections from FCOM to determine an intermediate weight. Interpolate associated speeds for intermediate weight in the same column (same wind and configuration).
3. Apply corrections from RTOW chart as explained above.

**EXAMPLE 3**

DATA :      CONF 2  
              OAT        =    25 °C  
              Head wind =    10 kt  
              Air conditioning ON  
              QNH        =    1 028 hPa  
              WET runway

In this example, we will consider CONF 2 as takeoff configuration. But same computation has to be done in CONF 1 and you must retain the best configuration.

1. Use the chart (*Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*).



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**


**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

A3XXXX	ENGINES				AIRPORT NAME				Version	Date
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AG OFF AI OFF				Elevation Ist temp Rwy slope	489 FT 14 C .08 %	TORA ASDA 3000 M 3000 M	<b>15L</b> 4 obstacles	A3XXXXXX	**V20
<b>DRY</b>										
OAT °C	CONF 1 + F					CONF 2				
	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
-20	80.2 4/6 156/59/58	80.2 4/6 162/62/64	83.6 3/4 167/67/69	84.8 3/4 170/70/72	85.8 3/4 173/73/75	80.4 4/6 154/54/59	81.9 3/4 158/58/64	83.4 3/4 164/64/69	84.4 3/4 167/67/72	85.2 3/4 169/69/74
-10	79.5 4/6 163/59/58	81.3 4/6 159/59/62	83.1 4/6 164/64/66	84.3 3/4 167/67/69	85.3 3/4 171/71/72	79.7 4/6 151/52/57	81.4 4/6 156/56/62	82.9 3/4 161/61/66	84.0 3/4 164/64/69	84.9 3/4 167/67/72
0	78.8 4/6 151/54/57	80.6 4/6 156/57/59	82.5 4/6 162/62/64	83.7 3/4 165/65/67	84.7 3/4 168/68/70	79.0 4/6 149/51/56	80.8 4/6 154/54/60	82.4 3/4 159/59/64	83.5 3/4 162/62/67	84.5 3/4 165/65/70
10	78.2 4/6 148/53/55	80.0 4/6 154/57/59	81.8 4/6 159/60/62	83.1 4/6 163/63/65	84.2 3/4 166/66/67	78.4 4/6 147/50/54	80.2 4/6 152/52/58	81.9 3/4 156/56/62	83.0 3/4 159/59/65	83.9 3/4 162/63/68
20	77.6 4/6 146/51/53	79.3 4/6 151/55/57	81.1 4/6 157/57/61	82.5 4/6 160/60/62	83.6 4/6 163/63/65	77.7 4/6 145/48/52	79.5 4/6 150/51/56	81.3 4/6 154/54/60	82.4 3/4 157/57/63	83.4 3/4 160/61/66
30	76.9 4/6 144/50/52	78.7 4/6 149/54/56	80.5 4/6 154/57/60	81.8 4/6 158/58/60	83.0 4/6 161/61/63	77.1 4/6 143/46/50	78.9 4/6 148/50/55	80.7 4/6 153/53/58	81.9 3/4 155/55/61	82.9 3/4 158/58/64
32	76.8 4/6 144/50/52	78.6 4/6 149/53/55	80.4 4/6 154/56/55	81.7 4/6 157/56/60	82.9 4/6 161/61/63	77.0 4/6 142/45/50	78.7 4/6 147/50/55	80.6 4/6 152/53/58	81.8 4/6 155/55/60	82.8 3/4 157/58/64
34	76.7 4/6 143/50/52	78.4 4/6 148/53/55	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>					81.7 4/6 154/55/60	82.7 3/4 157/58/64	
36	76.6 4/6 143/49/52	78.4 4/6 148/52/54						81.7 4/6 154/55/60	82.7 3/4 157/58/64	
38	76.5 4/6 142/49/52	78.3 4/6 147/52/54						80.0 4/6 153/56/59	81.3 4/6 156/58/60	82.6 4/6 159/60/62

- Enter the 10 kt head wind column and interpolate for 25 °C, CONF 2,  
 Max TO weight (1 000 kg) air conditioning OFF..... 82.1  
 2. First, apply the QNH/Bleeds correction (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).



Max TO weight (1 000 kg) air conditioning OFF..... 82.1  
 Air conditioning correction..... - 1.8  
 Intermediate weight..... = 80.3  
 Determine the takeoff speeds for 80.3 (1 000 kg) in the 10 kt head wind column CONF 2 (interpolate when necessary)

A3XXXXX	ENGINES	AIRPORT NAME						Version	Date	
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	<b>15L</b>	<b>4 obstacles</b>	<b>DRY</b>	ADXXXXXX **v20	
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M					
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M					
All reversers operating No reversers on dry runway										
OAT °C	CONF 1 + F						CONF 2			
	TAILWIND -10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
44	76.1 4/6 142/49/51	77.9 4/6 146/51/53	75.1 2/3 153/54/55	75.7 2/3 156/57/58	76.3 2/3 158/59/60	73.0 2/3 142/44/47	74.1 2/3 146/47/51	75.1 2/3 150/51/55	81.1 4/6 153/53/58	82.1 3/4 155/57/62
46	75.5 4/6 142/48/50	77.2 4/6 148/50/52	78.9 4/6 152/55/57	80.2 4/6 155/56/58	80.7 4/6 154/56/58	75.7 4/6 141/45/49	77.3 4/6 145/47/52	78.1 4/6 150/50/55	80.3 3/4 152/53/58	80.7 2/4 152/55/60
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63

V1 = 152 kt , VR = 153 kt , V2 = 158 kt

3. Apply WET correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES	AIRPORT NAME				Version	Date			
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX **V20			
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M	4 obstacles	DRY			
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M					
All reversers operating										
No reversers on dry runway										
OAT °C	CONF 1 + F				CONF 2					
	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT
INFLUENCE OF RUNWAY CONDITION										
WET	-2.0/-5	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.2/-3	-1.2/-2	-1.5/-3	-1.5/-3
	-16/ -1/-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/2	-14/ 0/ 0	-13/ 0/ 0	-12/-2/-2	-10/-1/-1	-4/-2/-2
	(+54)+2.0/-5	(+54)-1.5/-4	(+54)-1.3/-3	(+54)-1.1/-2	(+54)-0.8/-2	(+54)-0.9/-4	(+54)-1.3/-3	(+54)-1.2/-2	(+54)-1.5/-3	(+54)-1.5/-3
	-16/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-12/0/0	-10/0/0	-4/0/0
INFLUENCE OF DELTA PRESSURE										
QNH HPA										
-10.0	-0.8/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-0.7/-2	-1.2/-3	-0.8/-2	-0.8/-2	-0.8/-1
	0/0/0	0/0/0	0/0/0	-1/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0
	(+54)-0.8/-2	(+54)-0.7/-2	(+54)-0.7/-2	(+54)-1.3/-3	(+54)-0.7/-2	(+54)-0.7/-2	(+54)-1.2/-3	(+54)-0.8/-2	(+54)-0.8/-2	(+54)-0.8/-2
	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0
+10.0	+0.2/0	0/0/0	0/0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/+1/+1	0/+1/+1	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1
	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/+1/+1	0/+1/+1	0/0/0	0/0/0	+1/+1/+1	+1/+1/+1
LABEL FOR INFLUENCE (SW-1000 KG) (DIFLEX) (V1-DVR-DV2-KT) (VMC-DAT-C) (SW-1000 KG) (DIFLEX) (V1-DVR-DV2-KT)										
MTOW(1000 KG) codes V1minVRV2 (kt) LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=tax speed 6=brake energy 7=max weight 8=final take-off 9=VMU										
*VMC LIMITATION Thr (DAT) = 44 C Tmax (DAT) = 54 C Min acc height 454 FT Max acc height 1917 FT Min QNH alt 953 FT Max QNH alt 2400 FT Min VMVRV2 = 108/116/117 CHECK-VMC LIMITATION Correct V1/VRV2 = 1.0 KT/1000 KG										

For OAT < TVMC (54 °C), ΔW = ..... -1.2  
 Intermediate weight..... = 79.1  
 Associated speeds,  
 V1 = 152 kt - 10 = 142 kt  
 VR = 153 kt - 1 = 152 kt  
 V2 = 158 kt - 1 = 157 kt  
 (No speed check required for first correction).  
 Apply QNH correction

A3XXXXX	ENGINES	AIRPORT NAME				Version	Date			
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX- **V20			
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M	4 obstacles	DRY			
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M					
All reversers operating										
No reversers on dry runway										
OAT °C	CONF 1 + F				CONF 2					
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT
INFLUENCE OF RUNWAY CONDITION										
WET	-2.0/-5	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.5/-4	-1.2/-3	-1.2/-2	-1.5/-3
	-18/1/-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/2	-14/0/0	-13/0/0	-12/-2/-2	-10/-1/-1	-4/-2/-2
	(+54) +2.0/-5	(+54) -1.5/-4	(+54) -1.3/-3	(+54) -1.1/-2	(+54) -0.8/-2	(+54) -0.9/-4	(+54) -1.5/-4	(+54) -1.3/-3	(+54) -1.2/-2	(+54) -1.5/-3
	-16/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-11/0/0	-10/0/0	-4/0/0
INFLUENCE OF DELTA PRESSURE										
DOW/HPA	-10.0	-0.8/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-1.2/-3	-0.8/-2	-0.8/-2	-0.8/-1
	0/0/0	0/0/0	0/0/0	-1/0/0	0/0/0	0/0/0	-1/1/-2	-1/0/0	-1/1/-1	-1/1/-1
	(+54) -0.8/-2	(+54) -0.7/-2	(+54) -0.7/-2	(+54) -1.3/-3	(+54) -0.7/-2	(+54) -1.2/-3	(+54) -0.8/-2	(+54) -0.8/-2	(+54) -0.8/-2	(+54) -0.8/-2
	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0	-1/0/0
	+10.0	+0.2/0	+0.2/0	0/0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/1/+1	0/1/+1	0/0/0	0/0/0	+1/1/+1	+1/1/+1
	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.0/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0	(+54) +0.2/0
	0/0/0	0/0/0	0/0/0	0/0/0	+1/1/+1	0/1/+1	0/0/0	0/0/0	+1/1/+1	+1/1/+1
LABEL FOR INFLUENCE		MTOW(1000 KG) INDEX		*VMC		Trst (OAT)		Min arc height		Min QRH alt
DW (1000 KG) DTPLEX		V1min/V2V2 940		%LIMITATION		Tmax (OAT)		464 FT		953 FT
DVI -LEVEL-DI2 (KT)		LIMITATION CODES:				94 C		1917 FT		2405 FT
DVI -LEVEL-DI2 (KT)		1-1st segment 2-2nd segment 3-runway length 4-obstacles								Min V1/V2V2 = 108/114/117
DVI -LEVEL-DI2 (KT)		Before speed Brake/energy 7-max weight 8-final take-off 9-VMU								CHECK VMU LIMITATION
										Correct: V1/V2V2 = 110 KT/1000 KG

For OAT < TVMC (54 °C),  $\Delta W = 0.2 \times 15/10 = \dots\dots\dots +0.3$   
 Max permissible takeoff weight..... = 79.4  
 Associated speed,  
 $V1 = 142 \text{ kt} + 1 \times 15/10 = 143 \text{ kt}$   
 $VR = 152 \text{ kt} + 1 \times 15/10 = 154 \text{ kt}$   
 $V2 = 157 \text{ kt} + 1 \times 15/10 = 159 \text{ kt}$

Check that the speeds are higher than minimum speeds from the chart and from VMU table (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS))(it is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4).

Since the speed check is fulfilled:  
 Max permissible takeoff weight = 79.4 (1 000 kg)  
 $V1 = 143 \text{ kt}$ ,  $VR = 154 \text{ kt}$ ,  $V2 = 159 \text{ kt}$ .

	Takeoff Configuration : 2			
	TOW	V1	VR	V2
TOW (RTOW)	82.1			
FCOM correction(s)	- 1.8			
Intermediate value	80.3	152	153	158
WET Correction	- 1.2	-10	-1	-1
Intermediate value	79.1	142	152	157
QNH Correction	+ 0.3	+1	+2	+2

Continued on the following page



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

*Continued from the previous page*

	Takeoff Configuration : 2			
	TOW	V1	VR	V2
Final value	79.4	143	154	159



**A318/A319/A320/A321**

**FLIGHT CREW  
OPERATING MANUAL**

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

## EXTRAPOLATION

### EXTRAPOLATION

Ident.: PER-TOF-TOC-12-30-00001716.0002001 / 01 MAR 11

Applicable to: ALL

For a takeoff weight lower than those displayed on the chart, associated speeds are calculated as follows :

1. For given configuration and wind, note the speeds associated with the takeoff weight in the row displaying the highest permissible temperature.
2. Apply speed corrections provided at the bottom of the RTOW chart to V1 , VR and V2 limited to the minimum speeds.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

## MAXIMUM STRUCTURAL TAKEOFF WEIGHT

### MAXIMUM STRUCTURAL TAKEOFF WEIGHT

Ident.: PER-TOF-TOC-12-40-00001717.0001001 / 18 MAR 11

Applicable to: ALL

The maximum structural takeoff weight is a weight limitation depending on the aircraft. This limitation is provided in the Flight Manual and in *Refer to LIM-AG-WGHT Weight Limitations*. Compare the maximum structural takeoff weight to the maximum permissible takeoff weight computed for given conditions and retain the lower of the two values.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (TEMPERATURE ENTRY)

Intentionally left blank

## DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS

### GENERAL

Ident.: PER-TOF-TOC-14-10-00001722.0002001 / 17 MAR 11

Applicable to: ALL

Before determining the flexible temperature, calculate the maximum permissible takeoff weight (see previous section) and ensure that the actual takeoff weight is lower than the determined maximum takeoff weight.

- Enter the RTOW chart with the wind condition to interpolate for the actual takeoff weight. Read the flexible temperature in the temperature column corresponding to the actual weight.
- Repeat this process for the other configuration available. Select the configuration giving the highest flexible temperature.

### CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS

Ident.: PER-TOF-TOC-14-10-00001723.0001001 / 03 MAR 14

Applicable to: ALL

When the takeoff conditions are different from those provided on the chart, apply the associated corrections.

- Note:*
- If the RTOW chart is based on the CG being at 25 %, the crew can determine the flexible temperature at a more forward CG by decreasing the flexible temperature by 2 °C. V1 , VR and V2 must be increased by 1 kt.
  - 25 % CG is the basic certified limit, on which all takeoff computations are based. To take into account the operational margins, the above penalties must be applied when operational CG is forward 27 % CG.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

**CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS**

Ident.: PER-TOF-TOC-14-10-00014714.0001001 / 29 JUL 16

Applicable to: ALL

**CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Corrections are given for QNH ≠ 1 013 hPa , air conditioning ON, anti ice ON (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).

1. For a given takeoff weight, wind condition and selected configuration, determine the flexible temperature. Retain the takeoff speeds associated with the actual weight.
2. Apply the published temperature correction. To combine two or more corrections, add the different corrections and apply to temperature value.  
 (No speed corrections required).

**EXAMPLE 2**

DATA : Actual takeoff weight = 75 600 kg  
 Head wind = 10 kt  
 Air conditioning ON  
 QNH = 1 013 hPa

Use the chart: (*Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*).

A3XXXXX	ENGINES			AIRPORT NAME						15L	Version	Date
QNH	1013.25 HPA			Elevation	489 FT	TORA	3000 M	4 obstacles	DRY	A3XXXXXX	**V28	
Air cond.	AC OFF			Sea temp	14 C	TODA	3000 M					
Anti-icing	AI OFF			Rwy slope	.08 %	ASDA	3000 M					
All reversers operating No reversers on dry runway												
OAT °C	CONF 1 + F						CONF 2					
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT		
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63		
50	73.6 4/6 143/47/49	75.3 4/6 148/49/51	76.9 4/6 153/53/55	77.9 4/6 154/54/56	77.9 2/4 151/54/55	73.8 4/6 142/42/46	75.4 4/6 146/47/51	76.9 3/4 150/50/54	78.0 3/4 152/52/57	78.0 2/4 149/52/57		
52	72.7 4/6 144/46/48	74.4 4/6 149/49/51	75.8 3/4 153/53/54	76.3 2/4 152/52/53	76.3 2/4 147/52/53	72.9 4/6 142/44/48	74.3 3/4 146/46/50	75.8 3/4 150/50/54	76.4 2/4 150/50/55	76.4 2/4 146/50/55		
54	71.8 4/6 145/46/47	73.3 3/4 149/49/51	74.8 3/4 152/52/54	75.0 2/4 150/50/52	75.0 2/4 145/50/52	71.9 3/4 142/43/47	73.3 3/4 146/46/50	74.7 3/4 149/49/54	75.1 2/4 148/49/54	75.1 2/4 144/49/54		

Determine the maximum permissible takeoff weight. The actual weight being lower than the maximum one, flexible takeoff is possible.

Enter the 10 kt head wind column and interpolate for 75 600 kg, CONF 1+F,

Flexible temperature..... 53 °C

Enter the 10 kt head wind column and interpolate for 75 600 kg, CONF 2,

Flexible temperature..... 53 °C


Retain CONF 2 as the speeds are lower.

Takeoff speeds are V1 = 149 kt, VR = 150 kt, V2 = 155 kt

Flexible temperature with air conditioning OFF..... 53 °C

Use the QNH/Bleeds corrections:(Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS).

For example:



Air conditioning correction ..... -3 °C

Flexible temperature..... = 50 °C

Check that OAT/TREF < flex temperature ≤ TMAXFLEX

TMAXFLEX is specified in LIM-70.

**CORRECTIONS FOR WET RUNWAY**

Ident.: PER-TOF-TOC-14-10-00001725.0001001 / 28 JAN 11

Applicable to: ALL

**CORRECTIONS FOR WET RUNWAY**

(Refer to PER-TOF-CTA-10 GENERAL)

**CORRECTIONS PRODUCED ON THE RTOW CHART**

Ident.: PER-TOF-TOC-14-10-00014717.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

For a description of this correction Refer to *PER-TOF-TOC-10-20 DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART*. The list of corrections is not exhaustive, however the most commonly used corrections are wet runway, QNH, air conditioning and/or anti-icing. A maximum of three corrections can be produced on one chart.

To apply the correction, proceed as follows:

1. Enter the chart with wind and selected configuration. Interpolate for actual takeoff weight. Read flexible temperature associated with this weight.

2. Apply the first correction:

Apply  $\Delta T_{flex}$  correction and apply speed corrections ( $\Delta V1 / \Delta VR / \Delta V2$ ).

Check that the resulting  $V2$  is higher than the VMU Limited speed (*Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)*). If the speed checks are not fulfilled, flexible takeoff is not possible. Set TOGA thrust and retain the speeds associated with maximum permissible takeoff weight or the speeds read in the chart of the actual weight if they are all lower. No speed correction is required for QNH and bleeds influence (Not applicable to maximum takeoff weight determination).

3. To combine a second and/or a third correction, proceed as per point 2, except that also the resulting speeds must be checked higher than the minimum speed displayed on the RTOW chart.

4. Check that the final flexible temperature is:

- higher than OAT and TREF
- limited to TMAXFLEX

If the check is fulfilled, retain final flexible temperature as the one to be inserted in the MCDU.

If the check is not fulfilled, (final flexible temperature lower than OAT or TREF), no flexible takeoff is possible.

Use TOGA thrust and retain speeds that have been calculated for the maximum permissible takeoff weight. (*Refer to PER-TOF-TOC-14-20 FLEXIBLE TAKEOFF NOT POSSIBLE*)

Note: - QNH correction is given for  $\pm 10$  hPa. It is allowed to extrapolate linearly for greater QNH deviation.

- Corrections from the chart must be applied from top to bottom, i.e. in the RTOW on Refer to *PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*, apply the wet influence first.

Note: - If asterisk or dotted lines appear in the influence boxes, refer to more conservative corrections provided in the FCOM.



**EXAMPLE 5**

DATA : CONF 2  
 Actual takeoff weight = 75 600 kg  
 Head wind = 10 kt  
 WET runway  
 Air conditioning OFF  
 QNH = 1 023 hPa

In this example, we will consider CONF 2 as takeoff configuration. But same computation has to be done in CONF 1 and you must retain the best configuration.

Use the chart: (Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART).

A3XXXXX	ENGINES	AIRPORT NAME				15L 4 obstacles	Version	Date		
QNH	1013,25 HPA	Elevation	489 FT	TORA	3000 M		A3XXXXXX	**V20		
Air cond.	AC OFF	Ica temp	14 °C	TODA	3000 M	DRY				
Anti-icing	AI OFF	Ray slope	.08 %	ASDA	3000 M					
All reversers operating No reversers on dry runway										
OAT °C	CONF 1 + F				CONF 2					
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63
50	73.8 4/6 143/47/49	75.3 4/6 148/49/51	76.9 4/6 153/52/55	77.9 4/6 154/54/55	77.9 2/4 151/54/55	73.8 4/6 142/42/46	75.4 4/6 146/47/51	76.9 3/4 150/50/54	78.0 3/4 152/52/57	78.0 2/4 149/52/57
52	72.7 4/6 144/46/48	74.4 4/6 149/49/51	75.8 3/4 153/53/54	76.3 2/4 152/52/53	76.3 2/4 147/52/53	72.9 4/6 142/44/48	74.3 3/4 146/46/50	75.8 3/4 150/50/54	76.4 2/4 150/50/55	76.4 2/4 146/50/55
54	71.8 4/6 145/46/47	73.3 3/4 149/49/51	74.8 3/4 152/52/54	75.0 2/4 150/50/52	75.0 2/4 145/50/52	71.9 3/4 142/43/47	73.3 3/4 146/46/50	74.7 3/4 149/49/54	75.1 2/4 148/49/54	75.1 2/4 144/49/54

Determine the maximum permissible takeoff weight (see example 2). The actual weight being lower than the maximum one, flexible takeoff is possible.

Enter the 10 kt head wind column and interpolate for 75 600 kg, CONF 2,

Flexible temperature..... 53 °C

Takeoff speeds are V1 = 149 kt, VR = 150 kt, V2 = 155 kt

Apply WET correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES	AIRPORT NAME						Version	Date		
QNH	1013.25 HPA AC OFF AI OFF	Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX	**V20			
Air cond.		Inst temp	14 C	TODA	3000 M		4 obstacles	DRY			
Anti-icing		Rwy slope	.08 %	ASDA	3000 M						
All reversers operating No reversers on dry runway											
OAT °C	CONF 1 + F				CONF 2						
	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	
INFLUENCE OF RUNWAY CONDITION											
WET	-2.0/-5	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.5/-4	-1.2/-3	-1.2/-2	-1.5/-3	
	-16/-1-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/2	-14/0/0	-13/0/0	-12/-2/-2	-10/-1/-1	-4/-2/-2	
	(+54)+2.0/-5	(+54)+1.5-4	(+54)+1.3-3	(+54)+1.1/-2	(+54)+0.8-2	(+54)+0.9-4	(+54)+1.3/-3	(+54)+1.2/-2	(+54)+1.5-3		
	-16/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-11/0/0	-10/0/0	-4/0/0	
INFLUENCE OF DELTA PRESSURE											
QNH HPA	-10.0	-0.8/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-0.7/-2	-1.2/-3	-0.8/-2	-0.8-2	-0.8-1
		(+54)+0.8/-2	(+54)+0.7/-2	(+54)+0.7/-2	(+54)+1.3/-3	(+54)+0.7/-2	(+54)+0.7/-2	(+54)+1.2/-3	(+54)+0.8/-2	(+54)+0.8-2	(+54)+0.8-1
	0/0/0	0/0/0	0/0/0	-1/0/0	0/0/0	0/0/0	0/0/0	-1/0/0	-1/0/0	-1/0/0	
	+10.0	+0.2/0	0/0/0	0/0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0
		(+54)+0.2/0	(+54)+0.0/0	(+54)+0.0/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0
		0/0/0	0/0/0	0/0/0	+1/+1/+1	0/+1/+1	0/+1/+1	0/+1/+1	+1/+1/+1	+1/+1/+1	+1/+1/+1
LABEL FOR INFLUENCE D/W:1000 KG DTR/FLEX: D/V1-DVR-DV2 (KT)		MTOW(1000 KG) codes V1min/VRV2 (kt)		*VMC LIMITATION	Thf (DAT) Tmax (DAT) = 54 C	Min acc height 464 FT	Max acc height 1917 FT	Min QNH alt 953 FT	Max QNH alt 2406 FT		
LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=taxi speed 6=brake energy 7=max weight 8=final take-off 9=VMU		Min V1/VRV2 = 108/116/117		CHECK-VMC LIMITATION Correct V1/VRV2 = 1.0 KT/1000 KG							

$\Delta T_{flex} = \dots\dots\dots -2 \text{ } ^\circ\text{C}$

Intermediate flex temperature..... = 51  $^\circ\text{C}$

Associated speeds,

V1 = 149 kt - 10 = 139 kt

VR = 150 kt - 1 = 149 kt

V2 = 155 kt - 1 = 154 kt

Check that V2 is higher than the VMU. (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)).

Apply QNH correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES	AIRPORT NAME				Version	Date		
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX- **V20		
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M	4 obstacles	DRY		
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M				
All reversers operating No reversers on dry runway									
CONF 1 + F				CONF 2					
OAT °C	TAILWIND -10.0 KT	TAILWIND -5.0 KT	WIND 0 KT	HEADWIND +10.0 KT	HEADWIND +20.0 KT	TAILWIND -10.0 KT	TAILWIND -5.0 KT		
						WIND 0 KT	HEADWIND +10.0 KT		
							HEADWIND +20.0 KT		
INFLUENCE OF RUNWAY CONDITION									
WET	-2.0/-5 -16/1/-1 (+54) +2.0/-5 -16/0/0	-1.5/-4 -15/-2/-2 (+54) -1.5/-4 -15/0/0	-1.2/-3 -13/-4/-4 (+54) -1.3/-3 -13/0/0	-1.1/-2 -11/-3/-3 (+54) -1.1/-2 -11/0/0	1.8/-2 -10/-2/2 (+54) -0.8/-2 -10/0/0	-0.9/-4 -14/0/-4 (+54) -0.9/-4 -14/0/0	-1.5/-4 -12/-2/-2 (+54) -1.3/-3 -12/0/0	-1.2/-2 -10/-1/-1 (+54) -1.2/-2 -10/0/0	-1.5/-3 -4/-2/-2 (+54) -1.5/-3 -4/0/0
INFLUENCE OF DELTA PRESSURE									
DOWN HPA	-0.8/-2 (+54) -0.8/-2 0/0/0	-0.7/-2 (+54) -0.7/-2 0/0/0	-0.7/-2 (+54) -0.7/-2 0/0/0	-1.3/-3 (+54) -1.3/-3 0/0/0	-0.7/-2 (+54) -0.7/-2 0/0/0	-1.2/-3 (+54) -1.2/-3 0/0/0	-0.8/-2 (+54) -0.8/-2 -1/0/0	-0.8/-2 (+54) -0.8/-2 -1/0/0	-0.8/-1 (+54) -0.8/-2 -1/0/0
+10.0	+0.2/0 (+54) +0.2/0 0/0/0	+0.2/0 (+54) +0.2/0 0/0/0	+0.2/0 (+54) +0.2/0 0/0/0	+0.2/0 (+54) +0.2/0 +1/+1/+1	+0.2/0 (+54) +0.2/0 0/+1/+1	+0.2/0 (+54) +0.2/0 0/0/0	+0.2/0 (+54) +0.2/0 0/0/0	+0.2/0 (+54) +0.2/0 +1/+1/+1	+0.2/0 (+54) +0.2/0 +1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DT FLEX DW (1000 KG) DT FLEX (TVMC OAT C) DW (1000 KG) DT FLEX DW (1000 KG) DT FLEX DW (1000 KG) DT FLEX									
MTOW 10000 KG 0000 V1 min V1/V2 90		*VMC % LIMITATION		Tref (OAT) Tmax (OAT) = 94 C	Min. a/c height Max. a/c height	464 FT 1917 FT	Min QRN alt Max QRN alt	953 FT 2405 FT	
LIMITATION CODES: 1-1st segment 2-2nd segment 3-runway length 4-obstacles Before speed Brake energy 7-max weight 8-final take-off 9-VMU						Min V1/V2/V2 = 100/114/117 CHECK VMU LIMITATION Correct V1/V2/V2 = 1.0 KT/1000 KG			

$\Delta T_{flex} = \dots\dots\dots 0 \text{ } ^\circ\text{C}$   
 Maximum flexible temperature..... = 51  $^\circ\text{C}$   
 No speed correction is required for QNH and bleed influence.  
 Takeoff speeds are V1 = 139 kt, VR = 149 kt, V2 = 154 kt  
 Check that OAT/TREF < flex temperature  $\leq$  TMAXFLEX  
 TMAXFLEX is specified in LIM-70.

	Takeoff Configuration: 1 + F			
	Tflex	V1	VR	V2
Chart temperature	53	149	150	155
FCOM correction(s)				
Intermediate value	53	149	150	155
WET Correction	-2	-10	-1	-1
Intermediate value	51	139	149	154
QNH Correction	0	0	0	0
Final value	51	139	149	154



# PERFORMANCE

## TAKEOFF

**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

### COMBINING CORRECTIONS FROM FCOM AND CHART

Ident.: PER-TOF-TOC-14-10-00014718.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

1. Apply corrections from FCOM (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).
  2. Apply corrections from the RTOW chart.
- Apply speed corrections except for QNH and bleed influences.


#### EXAMPLE 6

DATA: CONF 2  
 Actual takeoff weight = 75 600 kg  
 Head wind = 10 kt  
 Air conditioning ON  
 QNH = 1 028 hPa  
 WET runway

In this example, we will consider CONF 2 as takeoff configuration. But same computation has to be done in CONF 1 and you must retain the best configuration.  
 Use the chart (*Refer to PER-TOF-TOC-10-20 DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART*). Determine the maximum permissible takeoff weight (*Refer to PER-TOF-TOC-12-10 COMBINING CORRECTIONS FROM FCOM AND CHART: example 3*).  
 The actual weight being lower than the maximum one, flexible takeoff is possible.

A3XXXXX	ENGINES		AIRPORT NAME				Version		Date	
QNH	1013.25 HPA		Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX	**V20	
Air cond.	AC OFF		Sea temp	14 C	TODA	3000 M		4 obstacles	DRY	
Anti-icing	AI OFF		Rwy slope	.0B %	ASDA	3000 M				
All reversers operating										
No reversers on dry runway										
OAT °C	CONF 1 + F					CONF 2				
	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT	TAILWIND - 10.0 KT	TAILWIND - 5.0 KT	WIND 0 KT	HEADWIND + 10.0 KT	HEADWIND + 20.0 KT
48	74.5 4/6 143/48/50	76.2 4/6 148/50/52	77.9 4/6 153/53/55	79.1 4/6 155/53/55	79.3 2/4 153/55/57	74.7 4/6 141/44/48	76.4 4/6 146/47/51	78.0 3/4 150/50/55	79.1 3/4 152/53/57	79.5 4/6 155/58/63
50	73.6 4/6 143/47/49	75.3 4/6 148/49/51	76.9 4/6 153/53/55	77.9 4/6 154/54/56	77.9 2/4 151/54/56	73.8 4/6 142/42/46	75.4 4/6 146/47/51	76.9 3/4 150/50/54	78.0 3/4 152/52/57	78.0 2/4 149/52/57
52	72.7 4/6 144/48/48	74.4 4/6 149/49/51	75.8 3/4 153/53/54	76.3 2/4 152/52/53	76.3 2/4 147/52/53	72.9 4/6 142/44/48	74.3 3/4 146/46/50	75.8 3/4 150/50/54	76.4 2/4 150/50/55	76.4 2/4 146/50/55
54	71.8 4/6 145/48/47	73.3 3/4 149/49/51	74.8 3/4 152/52/54	75.0 2/4 150/50/52	75.0 2/4 145/50/52	71.9 3/4 142/43/47	73.3 3/4 146/46/50	74.7 3/4 149/49/54	75.1 2/4 148/49/54	75.1 2/4 144/49/54

Enter the 10 kt head wind column and interpolate for 75 600 kg, CONF 2,  
 Flexible temperature..... 53 °C  
 Takeoff speeds are V1 = 149 kt, VR = 150 kt, V2 = 155 kt  
 First, apply the correction (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).  
 Flexible temperature with air conditioning OFF..... 53 °C



Air conditioning correction..... -3 °C  
 Intermediate flexible temperature..... = 50 °C  
 No speed correction.  
 Apply WET correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)**

A3XXXXX	ENGINES	AIRPORT NAME						Version	Date			
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M	15L	A3XXXXXX	**V20				
Air cond.	AC OFF	Isa temp	14 C	TODA	3000 M		4 obstacles	DRY				
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M							
All reversers operating												
No reversers on dry runway												
OAT °C	CONF 1 + F						CONF 2					
	TAILWIND	TAILWIND	WIND	HEADWIND	HEADWIND	TAILWIND	TAILWIND	WIND	HEADWIND	HEADWIND	TAILWIND	
	-10.0 KT	-5.0 KT	0 KT	+10.0 KT	+20.0 KT	-10.0 KT	-5.0 KT	0 KT	+10.0 KT	+20.0 KT		
INFLUENCE OF RUNWAY CONDITION												
WET	-2.0/-5	-1.5/-4	-1.2/-3	-1.1/-2	1.8/-2	-0.9/-4	-1.5/-4	-1.2/-3	-1.2/-2	-1.5/-3	-1.5/-3	
	-18/-1-1	-15/-2/-2	-13/-4/-4	-11/-3/-3	-10/-2/2	-14/0/0	-13/0/0	-12/-2/-2	-10/-1/-1	-4/-2/-2		
	(+54)+2.0/-5	(+54)-1.5/-4	(+54)-1.3/-3	(+54)-1.1/-2	(+54)-0.8/-2	(+54)-0.9/-4	(+54)-1.3/-4	(+54)-1.3/-3	(+54)-1.2/-2	(+54)-1.5/-3		
	-18/0/0	-15/0/0	-13/0/0	-11/0/0	-10/0/0	-14/0/0	-13/0/0	-11/0/0	-10/0/0	-4/0/0		
INFLUENCE OF DELTA PRESSURE												
QNH HPA												
-10.0	-0.8/-2	-0.7/-2	-0.7/-2	-1.3/-3	-0.7/-2	-0.7/-2	-1.2/-3	-0.8/-2	-0.8/-2	-0.8/-1		
	0/0	0/0	0/0	-1/0	0/0	0/0	0/0	-1/0	-1/0	-1/0		
	(+54)-0.8/-2	(+54)-0.7/-2	(+54)-0.7/-2	(+54)-1.3/-3	(+54)-0.7/-2	(+54)-0.7/-2	(+54)-1.2/-3	(+54)-0.8/-2	(+54)-0.8/-2	(+54)-0.8/-2		
	0/0	0/0	0/0	0/0	0/0	0/0	0/0	-1/0	-1/0	-1/0		
+10.0	+0.2/0	+0.2/0	0.0/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0	+0.2/0		
	0/0	0/0	0/0	0/0	+1/+1/+1	0/+1/+1	0/0	0/0	+1/+1/+1	+1/+1/+1		
	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.0/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0	(+54)+0.2/0		
	0/0	0/0	0/0	0/0	+1/+1/+1	0/+1/+1	0/0	0/0	+1/+1/+1	+1/+1/+1		
LABEL FOR INFLUENCE		MTOW(1000 KG) codes		*VMC		Tf (OAT)		Min acc height		Min QNH alt		
DW(1000 KG) DIFLEX		V1min/V2 (kt)		LIMITATION		Tmax (OAT)		464 FT		953 FT		
DV1-DVR-DV2 (KT)								Max exc height		Max QNH alt		
(FMVC DAT C)								1917 FT		2400 FT		
DW(1000 KG) DIFLEX		LIMITATION CODES:		1=1st segment 2=2nd segment 3=runway length 4=obstacles				Min V1/V2 = 108/116/117		CHECK-VMC LIMITATION		
DV1-DVR-DV2 (KT)		5=tax speed 6=brake energy 7=tax weight 8=final take-off 9=VMU						Correct V1/V2 = 1.0 KT/1000 KG				

For flexible temperature < TVMC (54 °C),  $\Delta T_{flex}$  = ..... -2 °C  
 Intermediate flex temperature..... = 48 °C

Associated speeds,  
 V1 = 149 kt - 10 = 139 kt  
 VR = 150 kt - 1 = 149 kt  
 V2 = 155 kt - 1 = 154 kt

Check that V2 is higher than the VMU (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)).

Apply QNH correction





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

Intentionally left blank



**FLEXIBLE TAKEOFF NOT POSSIBLE**

**FLEXIBLE TAKEOFF NOT POSSIBLE**

Ident.: PER-TOF-TOC-14-20-00001726.0001001 / 30 SEP 13

Applicable to: ALL

In some cases when the actual takeoff weight is lower than the maximum permissible takeoff weight, but the flexible temperature is lower than TREF or OAT, flexible takeoff is not possible. It is mandatory to use TOGA thrust.

For speed determination:

- You can retain the speeds that have been calculated for the maximum permissible takeoff weight;  
OR
- You can retain the speeds associated with the actual takeoff weight provided they are all lower than the speeds calculated for the maximum permissible takeoff weight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

Intentionally left blank

**FLEXIBLE TAKEOFF POSSIBLE BUT NOT USED**

**FLEXIBLE TAKEOFF POSSIBLE BUT NOT USED**

Ident.: PER-TOF-TOC-14-25-00015228.0001001 / 30 SEP 13

Applicable to: ALL

If the flexible takeoff is possible, but the flight crew elects to perform the takeoff with TOGA thrust, for speed determination:

- You can retain the speeds that have been calculated for the maximum permissible takeoff weight;
- OR
- You can retain the speeds associated with the actual takeoff weight provided they are all lower than the speeds calculated for the maximum permissible takeoff weight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

Intentionally left blank



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

## SUMMARY



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF


TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

### SUMMARY

Ident.: PER-TOF-TOC-14-30-00006034.0001001 / 24 MAR 11

Applicable to: ALL

The flow diagram gives the different steps to follow.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (TEMPERATURE ENTRY)

Intentionally left blank




**TAKEOFF PERFORMANCE**

**TAKEOFF PERFORMANCE**


Ident.: PER-TOF-TOC-16-10-00001727.0001001 / 23 JUN 15

Applicable to: ALL

Takeoff optimization is calculated for a given runway and its obstacles and for given conditions of flap setting, temperature, wind and QNH. The calculation produces a maximum permissible takeoff weight (or a maximum takeoff temperature for an actual weight).  
 The takeoff thrust produced by the engine varies as follows :



The optimization process calculates the speeds which will produce the maximum takeoff weight. To do so, it takes into account the different takeoff limitations such as TOD , ASD , TOR, second segment..., as shown on the charts below.



On a typical runway, the performance of a twin engine aircraft, is generally limited by the one engine out operation at takeoff. The optimum V2 /VS and optimum V1 /VR are consequently unique.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (WEIGHT ENTRY)

Intentionally left blank

**TAKEOFF CHART DESCRIPTION**

**GENERAL**

Ident.: PER-TOF-TOC-16-20-00001728.0003001 / 28 FEB 11

Applicable to: ALL


The takeoff chart (RTOW : Regulatory Takeoff Weight) is calculated for a specific aircraft version and for a particular runway specified at the top of the chart. The top of the chart also gives some information about the runway and lists the calculation assumptions.

The chart is given for 2 different configurations and 4 wind values per configuration. This allows the crew to select the configuration that gives either :

- the highest permissible takeoff weight, or, for a given weight,
- the highest flexible temperature.

If different configurations give equivalent performance, the crew should select the configuration associated with the lowest takeoff speeds.

The left column of the chart contains weight entry. For each weight entry (and for a given configuration and wind), the chart provides the following information :



*Note:* The takeoff weight is the sum of the weight entry and the delta weight.

The available limitation codes are :

- First segment : 1
- Second segment : 2
- Runway length : 3
- Obstacles : 4
- Tire speed : 5
- Brake energy : 6
- Maximum computation weight : 7
- Final takeoff : 8
- VMU : 9

**CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS**

Ident.: PER-TOF-TOC-16-20-00001729.0105001 / 19 DEC 14

Applicable to: **ALL**

Each takeoff chart is computed for a given set of conditions (air conditioning, QNH, anti ice...) specified at the top of the chart. If the actual takeoff conditions are different, the crew must apply corrections.

Two types of corrections are available :

- Conservative corrections (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*) (to be used when not provided on the chart).
- Corrections (less restrictive) listed on the chart, to be applied as explained below.


- Note:
1. If the RTOW chart is based on the CG being at 25 %, the crew can find the takeoff performance at a more forward CG by decreasing the takeoff weight by 1 000 kg (2 200 lb) and increasing V1 , VR and V2 by 1 kt.
  2. 25 % CG is the basic certified limit, on which all takeoff computations are based. To take into account the operational margins, the above penalties must be applied when operational CG is forward 27 % CG.

**DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART**

Ident.: PER-TOF-TOC-16-20-00006633.0001001 / 08 JUL 15

Applicable to: **ALL**

The corrections are presented on 4 lines :



TVMC is a temperature value given per column. This is a fictitious value that indicates the temperature above which the speeds are close to a VMCG /VMCA limitation or are VMCG /VMCA limited.

Note: The lower two lines may be shaded on certain chart formats.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (WEIGHT ENTRY)

### MINIMUM SPEED

Ident.: PER-TOF-TOC-16-20-00006634.0001001 / 08 JUL 15

**Applicable to: ALL**

Minimum V1 /VR /V2 due to VMCG /VMCA are provided on the bottom right side of the takeoff chart. They are only applicable in case of speed corrections. These speeds are conservative. They may be slightly higher than V1 /VR /V2 displayed on the takeoff chart.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (WEIGHT ENTRY)

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (WEIGHT ENTRY)

## ADDITIONAL INFORMATION

### ONE ENGINE OUT CLIMB PROCEDURE

Ident.: PER-TOF-TOC-16-30-00001730.0001001 / 10 DEC 09

Applicable to: ALL

The performance given in the chart is consistent with the flight path specified for the aircraft with one engine out and takes into account significant obstacles.

When the procedure to be followed is not the standard instrument departure, the chart describes a specific procedure (EOSID).

When the specified procedure requires a turn, except if otherwise stated on the RTOW chart, the turn should be performed with a maximum bank of 15 ° until the aircraft reaches 1 500 ft or until green dot.

The acceleration height (or altitude) ensures that the net flight path clears the highest obstacle by at least 35 ft when accelerating in level flight to green dot speed after an engine failure, in the most adverse conditions.

### TAKEOFF ON A WET RUNWAY

Ident.: PER-TOF-TOC-16-30-00001731.0002001 / 10 DEC 09

Applicable to: ALL


Takeoff charts computed for wet runway with a 15 ft screen height and/or use of reverse thrust may produce, in some conditions, a maximum takeoff weight (or flexible temperature) higher than that obtained for a dry runway. It is thus mandatory to compare both charts (dry and wet) and retain the lower of the two weights (or flexible temperature) and the associated speeds determined for a wet runway.

Note: *The crew need not compare the charts if the top of the wet runway chart specifies "DRY CHECK". (The comparison has already been inserted in the WET runway calculation).*

**RTOW CHARTS - COMPLEMENTARY INFORMATION**

Ident.: PER-TOF-TOC-16-30-00001732.0063001 / 10 DEC 09

Applicable to: ALL





AXXXXXX		ENGINE		AIRPORT NAME				VERSION DATE	
QNH		1013 HPA		Elevation	489 FT	TORA	10000 FT	15L	AXXXXXX V8
Air cond.		AC OFF		Isa temp	14 C	TODA	10200 FT		4 obstacles
Anti-icing		AI OFF		Rwy slope	08 %	ASDA	10000 FT		
WEIGHT 1000 KG	CONF 1 + F				CONF 2				
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	
56	* 58 7/9 * 0 * 111/21/24	* 58 7/9 * 0 * 111/21/24	* 58 7/9 * 0 * 111/21/24	* 58 7/9 * 0 * 111/21/24	* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/21	
52	* 58 7/7 * 0 * 111/19/22	* 58 7/7 * 0 * 111/19/22	* 58 7/7 * 0 * 111/19/22	* 58 7/7 * 0 * 111/19/22	* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/22	* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/21	
48	* 58 7/7 * 0 * 111/18/22	* 58 7/7 * 0 * 111/18/22	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 58 7/7 * 0 * 111/19/21	* 58 7/7 * 0 * 111/19/21	
46	* 58 7/7 * 0 * 111/18/22	* 58 7/7 * 0 * 111/18/22					* 58 7/7 * 0 * 112/18/21	* 58 7/7 * 0 * 112/18/21	* 58 7/7 * 0 * 112/18/21
40	* 58 7/7 * 0 * 112/18/22	* 58 7/7 * 0 * 112/17/22	* 58 7/7 * 0 * 112/17/22	* 58 7/7 * 0 * 112/17/22	* 58 7/7 * 0 * 112/18/21	* 58 7/7 * 0 * 112/18/21	* 58 7/7 * 0 * 112/18/21	* 58 7/7 * 0 * 112/18/21	

TAKEOFF PARAMETERS	
MAX TEMPERATURE (58)	LIMITATION CODE (7-7)
DELTA WEIGHT (1000 KG) ( 0)	
V1 (KT IAS) - VR (KT IAS) - V2 (KT IAS)	
(118) (117) (122)	

AXXXXXX	ENGINE	AIRPORT NAME					VERSION	DATE		
QNH Air cond. Anti-icing	1013 HPA AC OFF AI OFF	Elevation Isa temp Rwy slope	489 FT 14 C .08 %	TORA TODA ASDA	10000 FT 10200 FT 10000 FT	<b>15L</b> 4 obstacles	AXXXXXX V8	<b>DRY</b>		
WEIGHT 1000 KG		CONF 1 + F			CONF 2					
TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT			
GRAD1/GRAD2 (KG/C)										
40****		40****		40/400	40/400	40****	30****	<b>30/410</b> → GRAD1/GRAD2		
INFLUENCE OF RUNWAY CONDITION										
WET	+0/+0 0/+0/+0 (+54) -4/-1 0/+0/+0	+0/+0 -1/+0/+0 (+54) -4/-1 -1/+0/+0	0/-1 -1/+0/+0 (+54) -2/-1 -1/+0/+0	-2/-1 -1/+0/+0 (+54) -5/-1 -1/+0/+0	+0/+0 -1/+0/+0 (+54) -2/-1 -1/+0/+0	+0/+0 0/+0/+0 (+54) -4/-1 0/+0/+0	+0/+0 0/+0/+0 (+54) -2/-1 0/+0/+0	-2/-1 -1/+0/+0 (+54) -4/-1 -1/+0/+0		
D QNH HPA INFLUENCE OF DELTA PRESSURE										
-10	-8/-2 0/-1/-1 (+54) -8/-2 0/+0/+0	-9/-2 0/-1/-1 (+54) -9/-2 0/+0/+0	-1 4/-3 0/-1/-1 (+54) -1 4/-3 0/+0/+0	-1 0/-2 -1/-1/-1 (+54) -1 0/-2 -1/+0/+0	-8/-2 0/-1/-1 (+54) -8/-2 0/+0/+0	-8/-2 0/-1/-1 (+54) -8/-2 0/+0/+0	-1 0/-2 0/0/0 (+54) -1 0/-2 0/+0/+0	-1 1/-2 -1/-1/-1 (+54) -1 1/-2 -1/+0/+0		
+10	+6/+0 +1/+0/+0 (+54) +2/+0 +1/+0/+0	+6/+0 +1/+0/+0 (+54) +2/+0 +1/+0/+0	+0/+0 +1/+1/+1 (+54) +0/+0 +1/+1/+1	+6/+0 +1/+1/+1 (+54) +2/+0 +1/+1/+1	+6/+0 +0/+0/+0 (+54) +3/+0 +0/+0/+0	+5/+0 +1/+0/+0 (+54) +1/+0 +1/+0/+0	+4/+0 +1/+1/+1 (+54) +2/+0 +1/+1/+1	+2/+0 +0/+1/+1 (+54) +0/+0 +0/+1/+1		
LABEL FOR INFLUENCE	MTOW(1000 KG) codes	*VMC	Tref (OAT) =29 C	Min acc height 784Ft	Min QNH alt 1280Ft	MINIMUM & MAXIMUM ACC. HEIGHT AND ALT. →				
DW (1000 KG) D/FLEX DV1-DVR-DV2 (KT) (TVMC OAT C)	V1min/VVR/V2(KT)	*LIMITATION	Tmax (OAT) =54 C	Max acc height 1965Ft	Max QNH alt 2461Ft					
DW (1000 KG) D/FLEX DV1-DVR-DV2 (KT)	LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=time speed 6=brake energy 7=max weight 8=final takeoff 9=VMU			MIN V1/VVR/V2 = 111/17/21 CHECK VMU LIMITATION CORRECT. V1/VR/V2 = 1 Kt/1000 Kg						
INFLUENCE CORRECTION ΔVWEIGHT ΔTFLEX ΔV1/ΔVR/ΔV2 (TVMC) WEIGHT TFLEX ΔV1/ΔVR/ΔV2				MINIMUM VALUES OF V1/VR/V2 TO WHICH TAKEOFF SPEEDS MUST BE LIMITED WHEN DECREMENTS ARE APPLIED						
				V1/VR/V2 DECREMENTS FOR WEIGHTS BELOW THE LOWEST WEIGHT OF A COLUMN						



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - GENERAL (WEIGHT ENTRY)

### RTOW EXAMPLE

Ident.: PER-TOF-TOC-16-30-00014719.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE						
ONH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXXX *	*20					
<b>DRY</b>															
WEIGHT	CONF 1 + F				CONF 2										
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	HEADWIND 10 KT						
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/58	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58	46 3/4 0.3 152/53/58						
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/45/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	52 2/4 0.4 150/50/55						
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	60 3/4 0.3 151/51/55						
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 149/49/53	66 4/4 0.6 149/49/53						
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	69 4/4 2.7 147/47/50						
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29						
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24					
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22		
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22					* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22		
<b>GRAD1/GRAD2 (KG/C)</b>															
	50****	50****					60****	60/460	50****	50****	60****	50/470	50/470		
<b>INFLUENCE OF RUNWAY CONDITION</b>															
WET	-1.4/-3 -11/-1/-1 (+69)-1.4/-3 -11/0/0	-1.1/-3 -10/-1/-1 (+69)-1.1/-3 -10/0/0	-0.7/-2 -9/-2/-2 (+69)-0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+69)-0.7/-2 -8/0/0	-1.3/-3 -10/-2/-2 (+69)-1.3/-3 -10/0/0	-1.3/-3 -9/-4/-4 (+69)-1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+69)-0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+69)-0.2/-1 -5/0/0	-0.2/-1 -5/0/0 (+69)-0.2/-1 -5/0/0						
<b>INFLUENCE OF DELTA PRESSURE</b>															
-10.0	-0.8/-2 0/0/-1 (+61)-0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61)-1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61)-0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61)-0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61)-0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61)-0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61)-0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61)-0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61)-0.7/-2 0/0/0						
+10.0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	0.0/0 0/0/0 (+69)0.0/0 0/0/0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	+0.2/0 0/0/0 (+69)+0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69)+0.2/0 +1/+1/+1	+0.2/0 +1/+1/+1 (+69)+0.2/0 +1/+1/+1						
<table border="0" style="width: 100%;"> <tr> <td style="width: 33%;"> <b>LABEL FOR INFLUENCE</b>            DW (1000 KG) DTFLX            DV1- DVN- DV2 (KT)            [TIME] OAT (C)            DW (1000 KG) DTFLX            DV1- DVN- DV2 (KT)         </td> <td style="width: 33%;"> <b>DATA CODES</b>            V1min-VRV2 (kt)            * VMC            * LIMITATION            Tref (OAT) = 44 C            Tmax(OAT) = 54 C         </td> <td style="width: 33%;">           Min acc height 519 FT            Max acc height 1934 FT            Min QNH alt 1004 FT            Max QNH alt 2423 FT         </td> </tr> <tr> <td colspan="2"> <b>LIMITATION CODES:</b>            1=1st segment 2=2nd segment 3=runway length 4=obstacles            5=fire speed 6=brake energy 7=maximum weight 8=final take-off 9=VMU         </td> <td>           Min V1/VRV2 = 115/20/22            CHECK VMU LIMITATION            Correct. V1/VRV2 &gt; 0.1 KT/1000 KG         </td> </tr> </table>										<b>LABEL FOR INFLUENCE</b> DW (1000 KG) DTFLX DV1- DVN- DV2 (KT) [TIME] OAT (C) DW (1000 KG) DTFLX DV1- DVN- DV2 (KT)	<b>DATA CODES</b> V1min-VRV2 (kt) * VMC * LIMITATION Tref (OAT) = 44 C Tmax(OAT) = 54 C	Min acc height 519 FT Max acc height 1934 FT Min QNH alt 1004 FT Max QNH alt 2423 FT	<b>LIMITATION CODES:</b> 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=fire speed 6=brake energy 7=maximum weight 8=final take-off 9=VMU		Min V1/VRV2 = 115/20/22 CHECK VMU LIMITATION Correct. V1/VRV2 > 0.1 KT/1000 KG
<b>LABEL FOR INFLUENCE</b> DW (1000 KG) DTFLX DV1- DVN- DV2 (KT) [TIME] OAT (C) DW (1000 KG) DTFLX DV1- DVN- DV2 (KT)	<b>DATA CODES</b> V1min-VRV2 (kt) * VMC * LIMITATION Tref (OAT) = 44 C Tmax(OAT) = 54 C	Min acc height 519 FT Max acc height 1934 FT Min QNH alt 1004 FT Max QNH alt 2423 FT													
<b>LIMITATION CODES:</b> 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=fire speed 6=brake energy 7=maximum weight 8=final take-off 9=VMU		Min V1/VRV2 = 115/20/22 CHECK VMU LIMITATION Correct. V1/VRV2 > 0.1 KT/1000 KG													

**DETERMINATION OF MAXIMUM TAKEOFF WEIGHT AND SPEEDS**

**GENERAL**

Ident.: PER-TOF-TOC-18-10-00001734.0002001 / 10 DEC 09

Applicable to: ALL

The takeoff chart is computed for a given runway under a set of conditions, which are :

- OAT
- Wind
- Configuration
- QNH, air conditioning, anti ice...

Two configurations are produced on the chart. This enables the crew to select that giving the highest permissible takeoff weight.

In case of equivalent performance, retain the configuration giving the lower takeoff speeds.

**MTOW DETERMINATION**

Ident.: PER-TOF-TOC-18-10-00013648.0002001 / 01 MAR 11

Applicable to: ALL

Enter the chart with the given configuration and actual wind column reading the temperature value. This temperature value stands for the OAT. Read the maximum takeoff weight corresponding to the actual OAT. Note that it is allowed to interpolate between two consecutive lines to obtain the maximum takeoff weight.

It is reminded that the takeoff weight is the sum of the weight entry and the delta weight. Similarly determine the takeoff speeds associated with the maximum takeoff weight.


In some cases, it may happen that the first temperature value (displayed for the highest weight entry) is higher than OAT. In this case, it is allowed to extrapolate the weight value to avoid unnecessary penalty. Use the Grad 1/Grad 2 gradients provided at the bottom of the corresponding column.

**CORRECTION TO WEIGHT**

Grad 1/Grad 2 are gradients provided for both sides of the flat rating temperature (TREF).

Grad 1 applies to temperatures below TREF and Grad 2 applies above TREF.

Read the lowest temperature of the column (corresponding to the highest weight entry).



● **If the lowest temperature and OAT are above TREF.**

Obtain weight increment by multiplying Grad 2 by the difference in temperature between OAT and lowest temperature. Add this weight increment to the maximum takeoff weight calculated for the lowest temperature.

● **If the lowest temperature and OAT are below TREF.**

Obtain weight increment by multiplying Grad 1 by the difference in temperature between OAT and lowest temperature. Add this weight increment to the maximum takeoff weight calculated for the lowest temperature.

● **If OAT is below TREF and lowest temperature is above TREF.**

The weight increment is calculated in two steps. Step one is multiplying Grad 2 by temperature difference between lowest temperature and TREF. Step two is multiplying Grad 1 by temperature difference between TREF and OAT. Add results from step one and two to maximum takeoff weight calculated for lowest temperature.

*Note: Use the weight gradients only to extrapolate above the maximum weight shown in the RTOW chart. They are not valid for interpolation between two boxes, between filled boxes or between one filled and one blank box.*

Repeat the above process for the other available configuration and retain the configuration giving the highest takeoff weight.

**CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS**

Ident.: PER-TOF-TOC-18-10-00001736.0002001 / 11 FEB 11

Applicable to: ALL

Retain the maximum takeoff weight, associated configuration and speeds from above.  
For conditions different from those of the chart, apply relevant corrections.

**CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS**

Ident.: PER-TOF-TOC-18-10-00014720.0001001 / 29 JUL 16

Applicable to: **ALL**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Corrections are given for QNH  $\neq$  1 013 hPa, air conditioning ON, anti ice ON.

1. For the given wind and temperature conditions, determine the maximum takeoff weight.
2. Apply the published weight correction(s) to the maximum takeoff weight (for each correction) to determine the maximum permissible takeoff weight.
3. Read the speeds associated with the maximum permissible takeoff weight by entering the chart in the wind column with the retained weight value.

**EXAMPLE A**

DATA : OAT = 25 °C  
Head Wind = 10 kt  
Air conditioning ON  
QNH = 1 013 hPa

Use the chart from (*Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*).





**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)**

A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF	Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX *
							DRY	
WEIGHT 1000KG	CONF 1 + F				CONF 2			
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT
80	-18 4/6 0.0 155/50/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/58	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	48 3/4 0.3 152/53/58
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/45/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.4 146/46/50	58 3/4 0.5 148/49/53	60 3/4 0.3 151/51/55
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 149/49/53
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22
48	* 69 7/7 * 0.0 * 118/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22
GRAD1/GRAD2 (KG/C)								
50****		50****		60****		60****		50/470

Enter the 10 kt head wind column CONF 1 + F, to read for 25 °C  
 The lowest temperature of the column is 45 °C, use Grad 1/Grad 2 to extrapolate the maximum  
 takeoff weight.

A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX*
							DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/56	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58	
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 148/48/53	
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22	
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	
GRAD1/GRAD2 (KG/C)									
	50****	50****	60****	60/460	50****	50****	60****	50/470	

T<sub>ref</sub> value is available on the bottom of this table.

Here, T<sub>ref</sub> is equal to 44 °C.

MAX TO weight (1 000 kg) air conditioning OFF = 80.6 + 0.46 × 1 + 0.06 × 19 = 82.2

Enter the 10 kt head wind column CONF 2, to read for 25 °C


The lowest temperature of the column is 46 °C, use Grad 1/Grad 2 to extrapolate the maximum takeoff weight.

MAX TO weight (1 000 kg) air conditioning OFF = 80.3 + 0.47 × 2 + 0.05 × 19 = 82.1

Retain CONF 1 + F as takeoff configuration.

Maximum TO weight (1 000 kg) air conditioning OFF..... 82.2

Use the QNH/BLEEDS correction page (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*):



Air conditioning..... -1.8  
 Maximum permissible TO weight (1 000 kg) air conditioning ON..... = 80.4  
 Determine takeoff speeds for 80.4 (1 000 kg) in the 10 kt head wind column CONF 1 + F  
 (interpolate when necessary).

A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX *
							DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/56	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/56	
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 148/48/53	
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22	
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	
GRAD1/GRAD2 (KG/C)									
50****		50****		60****		60-460		50****	
50****		60****		60****		60****		50-470	


V1 = 155 kt, VR = 156 kt, V2 = 158 kt

**CORRECTIONS FOR WET OR CONTAMINATED RUNWAYS**

Ident.: PER-TOF-TOC-18-10-00004071.0001001 / 10 DEC 09

Applicable to: **ALL**

(Refer to PER-TOF-CTA-10 GENERAL)

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PERFORMANCE</b> <b>TAKEOFF</b> TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)
---	--

**CORRECTIONS PRODUCED ON THE RTOW CHART**

Ident.: PER-TOF-TOC-18-10-00014721.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

(Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE).

A description of this correction is given in PER-TOF-TOC-16-20 (Refer to PER-TOF-TOC-16-20 DESCRIPTION OF THE CORRECTIONS ON TAKEOFF CHART). The list of corrections is not exhaustive, however the most commonly used corrections are wet runway, QNH, air conditioning and/or anti ice. A maximum of three corrections can be produced on one chart.

To apply the corrections, proceed as follows:

1. Determine the maximum takeoff weight before correction for the given OAT and wind condition.

2. Apply the first correction:

If OAT is less than or equal to TVMC (line 3), apply  $\Delta W$  correction from line 1 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 2.

Else, (for OAT greater than TVMC ), apply  $\Delta W$  correction from line 3 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 4.

3. To combine a second (and third, as applicable) correction:

If OAT is less than or equal to TVMC (line 3), apply  $\Delta W$  correction from line 1 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 2.

Check that the resulting speeds are higher than the minimum speeds displayed on the RTOW chart and that V2 is higher than the VMU limited speed (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)).

If OAT is higher than TVMC (line 3) or if the above speed check is not fulfilled, apply  $\Delta W$  correction from line 3 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 4. No speed check is required.

- Note:
- QNH correction is given for  $\pm 10$  hPa. It is allowed to extrapolate linearly for greater QNH deviation.
  - When using a takeoff chart with failure cases, it is not allowed to combine two failure cases.
  - Corrections from the chart must be applied from top to bottom, i.e. in the RTOW (Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE), apply the wet correction first.
  - If asterisk or dotted lines appear in the correction boxes, refer to more conservative corrections provided in the FCOM.
  - No speed check is required for the first correction. However, if the first influence correction follows a conservative FCOM correction, a speed check is required.

**EXAMPLE B**

DATA : CONF 1+F

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

OAT = 45 °C  
 Head wind = 10 kt  
 QNH = 998 hPa  
 WET runway

In this example, we will consider CONF 1+F as takeoff configuration. But same computation has to be done in CONF 2 and you must retain the best configuration.  
 Use the chart *Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*).

A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE		
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation 489 FT Isa temp 15 C Rwy slope .08 %	TORA 3000 M TODA 3000 M ASDA 3000 M				4 obstacles	DRY	AXXXXXXX * *20	
WEIGHT 1000KG	CONF 1 + F				CONF 2						
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT			
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/58	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58			
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55			
72	53 4/6 0.3 145/48/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55			
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 149/49/53			
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50			
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29			
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24			
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22			
GRAD1/GRAD2 (KG/C)											
50****		50****		60****		60/460		50****	50****	60****	50/470

- Enter the 10 kt head wind column CONF 1+F, to read for 45 °C max TO weight (1 000 kg).....80.6
- Read associated speeds as V1 = 155 kt, VR = 156 kt, V2 = 158 kt
- Apply WET correction



A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE	
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M		AXXXXXXX *	+20	
Air cond.	AC OFF	Isa temp	15 C	TODA	3000 M	4 obstacles	DRY		
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M				
All reversers operating No reversers on dry runway									
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	
INFLUENCE OF RUNWAY CONDITION									
WET	-1.4/-3 -1.1/-1/-1 (+89) -1.4/-3 -1.1/0/0	-1.1/-3 -1.0/-1/-1 (+69) -1.1/-3 -1.0/0/0	-0.7/-2 -9/-2/-2 (+69) -0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+69) -0.7/-2 -8/0/0	-1.3/-3 -1.0/-2/-2 (+69) -1.3/-3 -1.0/0/0	-1.3/-3 -9/-4/-4 (+69) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+69) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+89) -0.2/-1 -5/0/0	
INFLUENCE OF DELTA PRESSURE									
QNH HPA									
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0.0/0 0/0/0 (+69) 0.0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69) +0.2/0 +1/+1/+1	
LABEL FOR INFLUENCE DW (1000 KG) DTFLEX DV1 -DVR -DV2 (KT) (TVMC OAT C) DW (1000 KG) DTFLEX DV1 -DVR -DV2 (KT)	OAT C DW CODES V1min/VRV2 (kt)	* VMC ** LIMITATION	TIR (OAT) = 88 C Tmax(OAT) = 54 C	Min asc height: 515 FT Max asc height: 1934 FT	Min QNH alt: 1004 FT Max QNH alt: 2423 FT	Min V1/VRV2 = 115/20/22 CHECK VMU LIMITATION Correct: V1/VRV2 = 0.1 KT/1000 KG			
LIMITATION CODES: 1-1st segment 2-2nd segment 3-runway length 4-obstacles 5-tire speed 6-brake energy 7-max weight 8-final take-off 9-VMU									

For OAT < TVMC (69 °C), ΔW = ..... - 0.7  
Intermediate weight (1 000 kg)..... = 79.9

Associated speeds,

V1 = 155 kt - 8 = 147 kt

VR = 156 kt - 2 = 154 kt

V2 = 158 kt - 2 = 156 kt

(No speed check required for first correction)

- Apply QNH correction

A320XXX		ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway		1013.25 HPA AC OFF AI OFF		Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		AXXXXXX *	*20
WEIGHT		CONF 1 + F				CONF 2				
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	DRY	
INFLUENCE OF RUNWAY CONDITION										
WET	-1.4/-3 -1.1/-1 (+69) -1.4/-3 -1.1/0/0	-1.1/-3 -1.0/-1 (+69) -1.1/-3 -1.0/0/0	-0.7/-2 -0/-2 (+69) -0.7/-2 -0/0/0	-0.7/-2 -8/-2/-2 (+69) -0.7/-2 -8/0/0	-1.3/-3 -10/-2/-2 (+69) -1.3/-3 -10/0/0	-1.3/-3 -9/-4/-4 (+69) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+69) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+69) -0.2/-1 -5/0/0		
INFLUENCE OF DELTA PRESSURE										
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0		
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0/0/0 0/0/0 (+69) 0/0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69) +0.2/0 +1/+1/+1		
LABEL FOR INFLUENCE DW (1000 KG) DTFFLEX DV1 -DVR -DV2 (KT) (TVMC OAT C) DW (1000 KG) DTFFLEX DV1 -DVR -DV2 (KT)		OAT C DW CODES V1max/VRV2 (kt)		*VMC * LIMITATION	Tref (OAT) = 44 C Tmax(OAT) = 54 C	Min acc height 318 FT Max acc height 1924 FT	Min QNH alt 1094 FT Max QNH alt 2423 FT	Min V1/VR/V2 = 115/20/22 CHECK VMU LIMITATION Correct. V1/VR/V2 = 0.1 KT/1000 KG		

For OAT < TVMC (61 °C),  $\Delta W = -0.7 \times 15/10 = \dots\dots\dots - 1$   
 Maximum permissible takeoff weight (1 000 kg)..... = 78.9

Associated speeds,

$V1 = 147 \text{ kt} - 1 \times 15/10 = 145 \text{ kt}$

$VR = 154 \text{ kt} - 1 \times 15/10 = 153 \text{ kt}$


$V2 = 156 \text{ kt} - 1 \times 15/10 = 155 \text{ kt}$

- Check that the speeds are higher than minimum speeds from the chart and from VMU table (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)).

It is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4.

	Takeoff Configuration: 1 + F			
	TOW	V1	VR	V2
TOW (RTOW)	80.6	155	156	158
FCOM correction(s)				
Intermediate value	80.6	155	156	158
WET Correction	- 0.7	-8	-2	-2
Intermediate value	79.9	147	154	156
QNH Correction	- 1	-2	-1	-1
Final value	78.9	145	153	155



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>TAKEOFF</b></p> <p style="text-align: center;">TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)</p>
---	--

**COMBINING CORRECTIONS FROM FCOM AND CHART**

Ident.: PER-TOF-TOC-18-10-00014722.0001001 / 29 JUL 16  
**Applicable to: ALL**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Proceed as follows:

1. Determine the maximum takeoff weight by entering the chart with selected configuration, OAT and wind.
2. Apply corrections from FCOM to determine an intermediate weight. Interpolate associated speeds for intermediate weight in the same column (same wind and configuration).
3. Apply corrections from RTOW chart as explained above.

**EXAMPLE C**

DATA : OAT = 25 °C  
CONF 1+F  
Head wind = 10 kt  
Air conditioning ON  
QNH = 998 hPa  
WET runway

In this example, we will consider CONF 1+F as takeoff configuration. But same computation has to be done in CONF 2 and you must retain the best configuration.

1. Use the chart (*Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*).


A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Sea temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX *
							DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/58	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58	
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.4 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	68 4/4 0.6 149/49/53	
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	65 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22	
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/19/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22		
GRAD1/GRAD2 (KG/C)									
	50****	50****	60****	60/460	50****	50****	60****	50/470	

Enter the 10 kt head wind column CONF 1 + F, to read for 25 °C

MAX TO weight (1 000 kg) air conditioning OFF = 80.6 + 0.46 x 1 + 0.06 x 19 = 82.2

In this example, Tref is equal to 44 °C, therefore the correction for 25 °C is 19 x GRAD1 correction (60kg) + 1 x GRAD2 correction(460kg).

2. First, apply the QNH/BLEEDS correction (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).



Max TO weight (1 000 kg) air conditioning OFF..... 82.2  
 Air conditioning correction..... -1.8  
 Intermediate weight..... = 80.4  
 Interpolate takeoff speeds for 80.4 (1 000 kg) in the 10 kt head wind column,  
 V1 = 155 kt, VR = 156 kt, V2 = 158 kt

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

A320XXX	ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Isla temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX*
							DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/56	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58	
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 148/48/53	
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22	
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	
GRAD1/GRAD2 (KG/C)									
	50****	50****	60****	60/460	50****	50****	60****	50/470	

3. Apply WET correction



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)**

A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE
QNH	1013.25 HPA	Elevation	489 FT	TORA	3000 M		AXXXXXX *	+20
Air cond.	AC OFF	Isa temp	15 C	TODA	3000 M	4 obstacles	DRY	
Anti-icing	AI OFF	Rwy slope	.08 %	ASDA	3000 M			
All reversers operating No reversers on dry runway								
WEIGHT	CONF 1 + F				CONF 2			
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT
INFLUENCE OF RUNWAY CONDITION								
WET	-1.4/-3 -11/-1/-1 (+89) -1.4/-3 -11/0/0	-1.1/-3 -10/-1/-1 (+89) -1.1/-3 -10/0/0	-0.7/-2 -9/-2/-2 (+89) -0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+89) -0.7/-2 -8/0/0	-1.3/-3 -10/-2/-2 (+89) -1.3/-3 -10/0/0	-1.3/-3 -9/-4/-4 (+89) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+89) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+89) -0.2/-1 -5/0/0
INFLUENCE OF DELTA PRESSURE								
QNH HPA								
-10.0	-0.8/-2 0/0/-1 (+81) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+81) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+81) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+81) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+81) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+81) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+81) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+81) -0.7/-2 0/0/0
+10.0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	0.0/0 0/0/0 (+89) 0.0/0 0/0/0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	+0.2/0 0/0/0 (+89) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+89) +0.2/0 +1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DTFLEX DV1 -DVR -DV2 (KT) (TVMC OAT C) DW (1000 KG) DTFLEX DV1 -DVR -DV2 (KT)	OAT C DW CODES V1min/VRV2 (kt)	* VMC ** LIMITATION	TIR (OAT) = 88 C Tmax(OAT) = 54 C	Min asc height: 515 FT Max asc height: 1934 FT	Min QNH alt: 1004 FT Max QNH alt: 2423 FT	Min V1/VRV2 = 115/20/22 CHECK VMU LIMITATION Correct: V1/VRV2 = 0.1 KT/1000 KG		

For OAT < TVMC (69 °C), ΔW = .....-0.7  
 Intermediate weight..... = 79.7  
 Associated speeds,  
 V1 = 155 kt - 8 = 147 kt  
 VR = 156 kt - 2 = 154 kt  
 V2 = 158 kt - 2 = 156 kt  
 Apply QNH correction

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)**

A320XXX		ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH		1013.25 HPA		Elevation 489 FT		TORA 3000 M		4 obstacles	DRY	AXXXXXX * '20
Air cond.		AC OFF		Sea temp 15 C		TODA 3000 M				
Anti-icing		AI OFF		Rwy slope .08 %		ASDA 3000 M				
All reversers operating										
No reversers on dry runway										
WEIGHT		CONF 1 + F				CONF 2				
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT		
INFLUENCE OF RUNWAY CONDITION										
WET	-1.4/-3 -1.1/-1/-1 (+69) -1.4/-3 -1.1/0/0	-1.1/-3 -1.0/-1/-1 (+69) -1.1/-3 -1.0/0/0	-0.7/-2 -9/-2/-2 (+69) -0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+69) -0.7/-2 -8/0/0	-1.3/-3 -1.0/-2/-2 (+69) -1.3/-3 -1.0/0/0	-1.3/-3 -9/-4/-4 (+69) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+69) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+69) -0.2/-1 -5/0/0		
INFLUENCE OF DELTA PRESSURE										
QNH HPA										
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0		
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0/0/0 0/0/0 (+69) 0/0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69) +0.2/0 +1/+1/+1		
LABEL FOR INFLUENCE DW (1000 KG) DTFFLEX DV1-DVR-DV2 (KT)	OAT C DW CODES V1min/VRVZ (kt)		* VMCA * LIMITATION		Tfref (OAT) = 44 C Tfmax(OAT) = 54 C	Min acc height 515 FT Max acc height 1924 FT	Min QNH alt 1094 FT Max QNH alt 2423 FT			
LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=tail speed 6=brake energy 7=taxi weight 8=final take-off 9=VMU							Min V1/VR/V2 = 115/20/22 CHECK VMU LIMITATION Correct: V1/VR/V2 = 0.1 KT/1000 KG			

For OAT < TVMC (61 °C),  $\Delta W = -0.7 \times 15/10 = \dots\dots\dots -1$   
 Maximum permissible takeoff weight..... = 78.7

Associated speed,  
 $V1 = 147 \text{ kt} - 1 \times 15/10 = 145 \text{ kt}$   
 $VR = 154 \text{ kt} - 1 \times 15/10 = 153 \text{ kt}$   
 $V2 = 156 \text{ kt} - 1 \times 15/10 = 155 \text{ kt}$

Check that the speeds are higher than minimum speeds from the chart and from VMU table (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)). It is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4.

Since the speed check is fulfilled:  
 MAX permissible takeoff weight = 78.7 (1 000 kg)  
 $V1 = 145 \text{ kt}$ ,  $VR = 153 \text{ kt}$ ,  $V2 = 155 \text{ kt}$ .

	Takeoff Configuration: 1 + F			
	TOW	V1	VR	V2
TOW (RTOW)	82.2			
FCOM correction(s)	-1.8			
Intermediate value	80.4	155	156	158

Continued on the following page



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

*Continued from the previous page*

	Takeoff Configuration: 1 + F			
	TOW	V1	VR	V2
<b>WET Correction</b>	-0.7	-9	-2	-2
<b>Intermediate value</b>	79.7	147	154	156
<b>QNH Correction</b>	-1	-2	-1	-1
<b>Final value</b>	78.7	145	153	155



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

## EXTRAPOLATION

## EXTRAPOLATION

Ident.: PER-TOF-TOC-18-20-00001740.0002001 / 08 MAR 11

Applicable to: ALL

For OAT lower than the lowest temperature value of a wind column, it is possible to obtain a higher maximum permissible takeoff weight by using Grad 1/Grad 2 values. *Refer to PER-TOF-TOC-18-10 MTOW DETERMINATION* for more details.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

## MAXIMUM STRUCTURAL TAKEOFF WEIGHT

### MAXIMUM STRUCTURAL TAKEOFF WEIGHT

Ident.: PER-TOF-TOC-18-30-00001741.0001001 / 01 MAR 11

Applicable to: ALL

The maximum structural takeoff weight is a weight limitation depending on the aircraft. This limitation is provided in the Flight Manual and in the limitation chapter (*Refer to LIM-AG-WGHT Weight Limitations*).

Compare the maximum structural takeoff weight to the maximum permissible takeoff weight computed for given conditions and retain the lower of the two values.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)

Intentionally left blank



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - MTOW CALCULATION (WEIGHT ENTRY)


## SUMMARY

**SUMMARY**

Ident.: PER-TOF-TOC-18-40-00006114.0001001 / 17 MAR 11

Applicable to: **ALL**

The following flow diagram gives the different steps to follow.



## DETERMINATION OF FLEXIBLE TAKEOFF TEMPERATURE AND SPEEDS

### GENERAL

Ident.: PER-TOF-TOC-20-10-00013509.0002001 / 23 FEB 11

Applicable to: ALL

Before determining the flexible temperature, calculate the maximum permissible takeoff weight (see previous section) and ensure that the actual takeoff weight is lower than the determined maximum takeoff weight.

- For a given configuration and wind value, enter the RTOW chart with the actual takeoff weight to read the flexible temperature and associated speeds. It is reminded that the takeoff weight is the sum of the weight entry and the delta weight displayed in each box. It is allowed to interpolate between two consecutive rows and/or columns for weight and for wind values not displayed on the chart.
- Repeat this process for the other configuration available. Select that configuration giving the highest flexible temperature.

### CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS

Ident.: PER-TOF-TOC-20-10-00013506.0001001 / 12 MAY 16

Applicable to: ALL

When the takeoff conditions are different from those provided on the chart, apply the associated corrections.

- Note:
- *If the RTOW chart is based on the CG being at 25 %, the crew can determine the flexible temperature at a more forward CG by decreasing the flexible temperature by 2 °C. V1 , VR and V2 must be increased by 1 kt.*
  - *25 % CG is the basic certified limit, on which all takeoff computation are based. To take into account the operational margins, the above penalties must be applied when operational CG is forward 27 %CG.*

**CONSERVATIVE CORRECTIONS FOR QNH AND BLEEDS**

Ident.: PER-TOF-TOC-20-10-00014723.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Corrections are given for QNH  $\neq$  1 013 hPa, air conditioning ON, anti ice ON.

1. For a given takeoff weight and wind condition, read the flexible temperature. Retain the takeoff speeds associated with the actual weight.
2. Apply the published temperature correction. To combine two or more corrections, add the different corrections and apply to temperature value.  
(No speed corrections required).

**EXAMPLE D**

DATA :      Actual takeoff weight = 68 000 kg  
              Head wind               = 10 kt  
              Air conditioning ON  
              QNH                       = 1 013 hPa

Use the chart from *Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*. Determine the maximum permissible takeoff weight. The actual weight being lower than the maximum one, flexible takeoff is possible.





**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)**

A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF	Elevation Isa temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		4 obstacles	AXXXXXX *
						DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2			
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT
80	-18 4/6 0.0 155/50/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/56	12 4/6 0.0 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/45/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.4 146/46/50	58 3/4 0.5 148/49/53	60 3/4 0.3 151/51/55
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	66 4/4 0.6 149/49/53
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	68 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22
48	* 69 7/7 * 0.0 * 118/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22
GRAD1/GRAD2 (KG/C)								
50****		50****		60****		60****		50****
				60/460		50****		50****
						60****		50/470

Enter the 10 kt head wind column and interpolate for 68 000 kg, CONF 1 + F,  
 Flexible temperature..... 67 °C

Enter the 10 kt head wind column and interpolate for 68 000 kg, CONF 2,  
 Flexible temperature..... 66 °C

Retain CONF 1 + F for takeoff configuration.  
 Takeoff speeds are V1 = 153 kt, VR = 153 kt, V2 = 154 kt


Flexible temperature with air conditioning OFF..... 67 °C

Use the QNH/BLEEDS corrections (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*):

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)**




Air conditioning correction..... -3 °C  
 Flexible temperature..... = 64 °C

**CORRECTIONS FOR WET RUNWAY**

Ident.: PER-TOF-TOC-20-10-00013280.0001001 / 18 FEB 11

Applicable to: **ALL**

Refer to *PER-TOF-CTA-10 GENERAL*

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>TAKEOFF</b></p> <p style="text-align: center;">TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)</p>
---	--

**CORRECTIONS PRODUCED ON THE RTOW CHART**

Ident.: PER-TOF-TOC-20-10-00014724.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

A description of this correction is given on *Refer to PER-TOF-TOC-16-20 CORRECTIONS DUE TO DIFFERENT TAKEOFF CONDITIONS*. The list of corrections is not exhaustive, however the most commonly used corrections are wet runway, QNH, air conditioning and/or anti-icing. A maximum of three corrections can be produced on one chart.

To apply the correction, proceed as follows:

1. Enter the chart with selected configuration, wind and actual takeoff weight to read the flexible temperature associated with this weight.
2. Apply the first correction:  
If the flexible temperature is less than or equal to TVMC (line 3), apply  $\Delta T_{flex}$  correction from line 1 and apply speed corrections ( $\Delta V1 / \Delta VR / \Delta V2$ ) from line 2.

Else, (flexible temperature greater than TVMC), apply  $\Delta T_{flex}$  from line 3 and  $\Delta V1 / \Delta VR / \Delta V2$  corrections from line 4.

Check V2 against VMU limitation (*Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)*). If V2 is lower than V2 limited by VMU, flexible takeoff is not possible. Set TOGA thrust and retain the speeds associated with maximum permissible takeoff weight or the speeds read in the chart for the actual weight if they are all lower.

No speed correction is required for QNH and bleeds influence (Not applicable to maximum takeoff weight determination).

3. To combine a second and/or a third correction, proceed as per point 2.
4. Check that the final flexible temperature is:

- Higher than OAT and TREF
- Limited to TMAX FLEX

If the check is fulfilled, retain final flexible temperature as the one to be inserted in the MCDU

If the check is not fulfilled, (final flexible temperature lower than OAT or TREF), no flexible takeoff is possible.

Use TOGA thrust and retain speeds that have been calculated for the maximum permissible takeoff weight. (*Refer to PER-TOF-TOC-20-20 FLEXIBLE TAKEOFF NOT POSSIBLE*)

- Note:
- QNH correction is given for  $\pm 10$  hPa. It is allowed to extrapolate linearly for greater QNH deviation.
  - Corrections from the chart must be applied from the top to bottom, i.e in the RTOW on *Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*, apply the wet influence first

- Note:
- When the flexible temperature is higher than TVMC, it is allowed to limit the flexible temperature to TVMC and apply only corrections from lines 1 and 2.

- If asterisk or dotted lines appear in the correction boxes, refer to more conservative corrections provided in the FCOM.

**EXAMPLE E**

DATA : CONF 1+F  
 Actual takeoff weight = 68 000 kg  
 Head wind = 10 kt  
 QNH = 998 hPa  
 WET runway  
 Air conditioning OFF

In this example, we will consider CONF 1+F as takeoff configuration. But same computation has to be done in CONF 2 and you must retain the best configuration.

Use the chart from *Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE.*

Determine the maximum permissible takeoff weight.

The actual weight being lower than the maximum one, flexible takeoff is possible.

A320XXX		ENGINES		AIRPORT NAME				15L	VERSION	DATE
QNH		1013.25 HPA		Elevation	489 FT	TORA	3000 M		AXXXXXX *	*20
Air cond.		AC OFF		Isa temp	15 C	TODA	3000 M	4 obstacles	DRY	
Anti-icing		AI OFF		Rwy slope	.08 %	ASDA	3000 M			
All reversers operating										
No reversers on dry runway										
WEIGHT 1000KG	CONF 1 + F				CONF 2					
	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND - 10 KT	TAILWIND - 5 KT	WIND 0 KT	HEADWIND 10 KT		
80	-18 - 4/6 0.0 155/56/58	9 - 4/6 0.0 154/57/59	37 - 4/6 0.0 153/55/57	45 - 4/6 0.6 155/56/58	-15 - 4/6 0.0 153/53/58	12 - 4/6 0.0 151/52/57	40 - 4/6 0.1 150/51/56	48 - 3/4 0.3 152/53/58		
76	44 - 4/6 0.1 141/49/51	48 - 4/6 0.2 148/50/52	51 - 3/4 0.4 153/53/55	52 - 2/4 0.3 152/52/53	44 - 4/6 0.3 140/43/49	48 - 4/6 0.4 146/47/51	51 - 3/4 0.4 150/50/54	52 - 2/4 0.4 150/50/55		
72	53 - 4/6 0.3 145/46/48	56 - 3/4 0.2 148/48/50	59 - 3/4 0.0 152/52/53	60 - 3/4 0.4 154/54/55	53 - 3/4 0.4 142/43/47	56 - 3/4 0.2 146/46/50	58 - 3/4 0.5 149/49/53	60 - 3/4 0.3 151/51/55		
68	61 - 3/4 0.3 144/44/45	63 - 3/4 0.5 148/48/49	65 - 3/4 0.6 151/51/52	67 - 3/4 0.3 153/53/54	61 - 3/4 0.3 142/42/45	63 - 3/4 0.5 145/45/48	65 - 3/4 0.4 148/48/52	68 - 4/4 0.6 149/49/53		
64	68 - 3/4 0.5 143/43/44	69 - 3/4 1.1 147/47/48	69 - 3/4 2.2 151/51/52	69 - 3/4 3.0 153/53/54	66 - 3/4 0.6 141/41/44	69 - 3/4 1.0 144/44/47	69 - 4/4 2.0 147/47/50	69 - 4/4 2.7 147/47/50		
60	69 - 3/4 4.0 143/43/44	* 69 - 7/9 * 0.0 * 114/27/29	* 69 - 7/9 * 0.0 * 114/32/33	* 69 - 7/9 * 0.0 * 114/32/33	* 69 - 7/9 * 4.0 * 141/41/44	* 69 - 7/9 * 0.0 * 112/26/29	* 69 - 7/9 * 0.0 * 112/26/29	* 69 - 7/9 * 0.0 * 112/26/29		
56	* 69 - 7/9 * 0.0 * 114/27/29	* 69 - 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 - 7/9 * 0.0 * 112/21/24	* 69 - 7/9 * 0.0 * 112/21/24		
52	* 69 - 7/9 * 0.0 * 114/22/24	* 69 - 7/9 * 0.0 * 114/22/24					* 69 - 7/7 * 0.0 * 112/19/22	* 69 - 7/7 * 0.0 * 112/19/22	* 69 - 7/7 * 0.0 * 113/18/22	* 69 - 7/7 * 0.0 * 113/18/22
48	* 69 - 7/7 * 0.0 * 115/20/22	* 69 - 7/7 * 0.0 * 115/20/22	* 69 - 7/7 * 0.0 * 115/20/22	* 69 - 7/7 * 0.0 * 115/20/22	* 69 - 7/7 * 0.0 * 113/18/22	* 69 - 7/7 * 0.0 * 113/18/22	* 69 - 7/7 * 0.0 * 113/18/22	* 69 - 7/7 * 0.0 * 113/18/22		
GRAD1/GRAD2 (KG/C)										
50****		50****		60****		60-460		50****		50****

Enter the 10 kt head wind column and interpolate for 68 000 kg, CONF 1+F,  
 Flexible temperature..... 67 °C



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)**

Takeoff speeds are V1 = 153 kt, VR = 153 kt, V2 = 154 kt  
 Apply WET correction

A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF	Elevation 489 FT	TORA 3000 M	ISA temp 15 C	TODA 3000 M		+4 obstacles	AXXXXXXX *
		Rwy slope .08 %	ASDA 3000 M			DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2			
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT
INFLUENCE OF RUNWAY CONDITION								
WET	-1.4/-3 -11/-1/-1 (+99) -1.4/-3 -11/0/0	-1.1/-3 -10/-1/-1 (+99) -1.1/-3 -10/0/0	-0.7/-2 -9/-2/-2 (+99) -0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+99) -0.7/-2 -8/0/0	-1.3/-3 -10/-2/-2 (+99) -1.3/-3 -10/0/0	-1.3/-3 -9/-4/-4 (+99) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+99) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+99) -0.2/-1 -5/0/0
INFLUENCE OF DELTA PRESSURE								
D QNH HPA								
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0
+10.0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	0/0/0 0/0/0 (+99) 0.0/0 0/0/0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	+0.2/0 0/0/0 (+99) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+99) +0.2/0 +1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DTFLEX DVT1-DVR-DV2 (KT) (VMC-QAT C) DW (1000 KG) DTFLEX DVT1-DVR-DV2 (KT)	QAT C DW CODES V1min/VR/V2 (kt)	*VMC * LIMITATION	Tref (QAT) = 44 C Tmax(QAT) = 54 C	Min acc height 515 FT Max acc height 1934 FT	Min QNH alt 1004 FT Max QNH alt 2423 FT	Min V1/VR/V2 = 115/20/22 CHECK VMU LIMITATION Correct, V1/VR/V2 = 0.1 KT/1000 KG		

For flexible temperature < TVMC (69 °C), ΔTflex = ..... -2 °C  
 Intermediate flex temperature..... = 65 °C

Associated speeds,  
 V1 = 153 kt - 8 = 145 kt  
 VR = 153 kt - 2 = 151 kt  
 V2 = 154 kt - 2 = 152 kt

Check V2 against VMU limitation (Refer to PER-TOF-TOD-25-20 MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)). It is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4.  
 Apply QNH correction

A320XXX		ENGINES		AIRPORT NAME				15L		VERSION	DATE
QNH		1013.25 HPA		Elevation	489 FT	TORA	3000 M	4 obstacles	AXXXXXXX *	*20	
Air cond.		AC OFF		Isa temp	15 C	TODA	3000 M				
Anti-icing		AI OFF		Rwy slope	.08 %	ASDA	3000 M				
All reversers operating								DRY			
No reversers on dry runway											
WEIGHT		CONF 1 + F				CONF 2					
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT			
INFLUENCE OF RUNWAY CONDITION											
WET	-1.4/-3 -1.1/-1 -1 (+69) -1.4/-3 -1.1/0/0	-1.1/-3 -1.0/-1 -1 (+69) -1.1/-3 -1.0/0/0	-0.7/-2 -0/-2/-2 (+69) -0.7/-2 -0/0/0	-0.7/-2 -0/-2/-2 (+69) -0.7/-2 -0/0/0	-1.3/-3 -1.0/-2/-2 (+69) -1.3/-3 -1.0/0/0	-1.3/-3 -0.9/-4/-4 (+69) -1.3/-3 -0.9/0/0	-0.4/-1 -0.7/-2/-2 (+69) -0.4/-1 -0.7/0/0	-0.2/-1 -0/0/0 (+69) -0.2/-1 -0.5/0/0			
INFLUENCE OF DELTA PRESSURE											
QNH HPA											
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1 -1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1 -1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0			
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0/0/0 0/0/0 (+69) 0/0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0			
LABEL FOR INFLUENCE DW (1000 KG) DTFFLEX DV1 -DVR -DV2 (KT) (TVMC OAT C)		OAT C DW CODES V1min/VR/V2 (kt)		*VMC * LIMITATION	Tref (OAT) = 44 C Tmax(OAT) = 54 C	Min acc height 315 FT Max acc height 1924 FT	Min QNH alt 1094 FT Max QNH alt 2423 FT				
DW (1000 KG) DTFFLEX DV1 -DVR -DV2 (KT)		LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=brake speed 6=brake energy 7=max weight 8=final take-off 9=VMU				Min V1/VR/V2 = 115/20/22 CHECK VMU LIMITATION Correct. V1/VR/V2 = 0.1 KT/1000 KG					

For flex temperature  $\geq$  TVMC (61 °C),  $\Delta T_{flex} = -2 \times 15/10 = \dots \dots \dots -3 \text{ °C}$   
 Flexible temperature  $\dots \dots \dots = 62 \text{ °C}$

No speed correction is required for QNH and bleed influence.


Takeoff speeds are V1 = 145 kt, VR = 151 kt, V2 = 152 kt

Check that OAT/TREF < flex temperature  $\leq$  TMAXFLEX.

TMAXFLEX is specified in LIM-70.

For this example, if TMAXFLEX is equal to ISA + 45 °C (60 °C at airport elevation), Flex takeoff is not possible.

	Takeoff Configuration : 1 + F			
	Tflex	V1	VR	V2
Chart temperature	67	153	153	154
FCOM correction(s)				
Intermediate value	67	153	153	154
WET Correction	-2	-8	-2	-2
Intermediate value	65	145	151	152
QNH Correction	-3	0	0	0
Final value	62	145	151	152

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>TAKEOFF</b></p> <p style="text-align: center;">TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)</p>
---	--

**COMBINING CORRECTIONS FROM FCOM AND CHART**

Ident.: PER-TOF-TOC-20-10-00014725.0001001 / 29 JUL 16  
**Applicable to: ALL**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

1. Apply corrections from FCOM (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).
2. Apply corrections from the RTOW chart.  
Apply speed corrections except for QNH and bleed influences.

**EXAMPLE F**

DATA : Actual takeoff weight = 68 000 kg  
CONF 1+F  
Head wind = 10 kt  
Air conditioning ON  
QNH = 998 hPa  
WET runway

In this example, we will consider CONF 1+F as takeoff configuration. But same computation has to be done in CONF 2 and you must retain the best configuration.  
Use the chart (*Refer to PER-TOF-TOC-16-30 RTOW EXAMPLE*).  
Determine the maximum permissible takeoff weight (see example C). The actual weight being lower than the maximum one, flexible takeoff is possible.



**PERFORMANCE**


**TAKEOFF**

**TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)**

A320XXX	ENGINES		AIRPORT NAME				15L 4 obstacles	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF		Elevation Sea temp Rwy slope	489 FT 15 C .08 %	TORA TODA ASDA	3000 M 3000 M 3000 M		AXXXXXX *	* 20
							DRY		
WEIGHT 1000KG	CONF 1 + F				CONF 2				
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	
80	-18 4/6 0.0 155/56/58	9 4/6 0.0 154/57/59	37 4/6 0.0 153/55/57	45 4/6 0.6 155/56/58	-15 4/6 0.0 153/53/58	12 4/6 0.1 151/52/57	40 4/6 0.1 150/51/56	46 3/4 0.3 152/53/58	
76	44 4/6 0.1 141/49/51	48 4/6 0.2 148/50/52	51 3/4 0.4 153/53/55	52 2/4 0.3 152/52/53	44 4/6 0.3 140/43/49	48 4/6 0.4 146/47/51	51 3/4 0.4 150/50/54	52 2/4 0.4 150/50/55	
72	53 4/6 0.3 145/46/48	56 3/4 0.2 148/48/50	59 3/4 0.0 152/52/53	60 3/4 0.4 154/54/55	53 3/4 0.4 142/43/47	56 3/4 0.2 146/46/50	58 3/4 0.5 149/49/53	60 3/4 0.3 151/51/55	
68	61 3/4 0.3 144/44/45	63 3/4 0.5 148/48/49	65 3/4 0.6 151/51/52	67 3/4 0.3 153/53/54	61 3/4 0.3 142/42/45	63 3/4 0.5 145/45/48	65 3/4 0.4 148/48/52	68 4/4 0.6 149/49/53	
64	68 3/4 0.5 143/43/44	69 3/4 1.1 147/47/48	69 3/4 2.2 151/51/52	69 3/4 3.0 153/53/54	65 3/4 0.6 141/41/44	69 3/4 1.0 144/44/47	69 4/4 2.0 147/47/50	69 4/4 2.7 147/47/50	
60	69 3/4 4.0 143/43/44	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 0.0 * 114/32/33	* 69 7/9 * 4.0 * 141/41/44	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	* 69 7/9 * 0.0 * 112/26/29	
56	* 69 7/9 * 0.0 * 114/27/29	* 69 7/9 * 0.0 * 114/27/29	<b>DO NOT USE FOR OPERATIONAL PURPOSE</b>				* 69 7/9 * 0.0 * 112/21/24	* 69 7/9 * 0.0 * 112/21/24	
52	* 69 7/9 * 0.0 * 114/22/24	* 69 7/9 * 0.0 * 114/22/24					* 69 7/7 * 0.0 * 112/19/22	* 69 7/7 * 0.0 * 112/19/22	
48	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 115/20/22	* 69 7/7 * 0.0 * 113/19/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22	* 69 7/7 * 0.0 * 113/18/22		
GRAD1/GRAD2 (KG/C)									
50****		50****		60****		60/460		50****	
50****		50****		60****		60****		50/470	

- Enter the 10 kt head wind column and interpolate for 68 000 kg, CONF 1+F, Flexible temperature..... 67 °C
- Takeoff speeds are V1 = 153 kt, VR = 153 kt, V2 = 154 kt
- First, apply the correction from FCOM (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*).





Flexible temperature with air conditioning OFF..... 67 °C  
 Air conditioning correction..... -3 °C  
 Intermediate flexible temperature..... = 64 °C

- No speed correction.
- Apply WET correction

A320XXX		ENGINES		AIRPORT NAME				15L		VERSION	DATE
QNH		1013.25 HPA		Elevation 489 FT		TORA 3000 M		4 obstacles		AAXXXXXX * *20	
Air cond.		AC OFF		Sea temp 15 C		TODA 3000 M					
Anti-icing		AI OFF		Rwy slope .08 %		ASDA 3000 M					
All reversers operating										DRY	
No reversers on dry runway											
WEIGHT		CONF 1 + F				CONF 2					
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT			
INFLUENCE OF RUNWAY CONDITION											
WET	-1.4/-3 -1.1/-1/-1 (+69) -1.4/-3 -1.1/0/0	-1.1/-3 -1.0/-1/-1 (+69) -1.1/-3 -1.0/0/0	-0.7/-2 -0/-2/-2 (+69) -0.7/-2 -0/0/0	-0.7/-2 -0.7/-2/-2 (+69) -0.7/-2 -0/0/0	-1.3/-3 -1.0/-2/-2 (+69) -1.3/-3 -1.0/0/0	-1.3/-3 -0.9/-4/-4 (+69) -1.3/-3 -0.9/0/0	-0.4/-1 -0.2/-2 (+69) -0.4/-1 -0.2/0/0	-0.2/-1 -0.1/0/0 (+69) -0.2/-1 -0.1/0/0			
INFLUENCE OF DELTA PRESSURE											
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0			
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0/0/0 0/0/0 (+69) 0/0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69) +0.2/0 +1/+1/+1			
LABEL FOR INFLUENCE DW (1000 KG) DTFLX DV1-DVR-DV2 (KT) (VMC OAT C)		OAT C DW CODES V1min/VRV2 (kt)		*VMC * LIMITATION	Tref (OAT) = 44 C Tmax(OAT) = 54 C	Min acc height 515 FT Max acc height 1924 FT	Min QNH alt 1094 FT Max QNH alt 2423 FT				
DW (1000 KG) DTFLX DV1-DVR-DV2 (KT)		LIMITATION CODES: 1=1st segment 2=2nd segment 3=runway length 4=obstacles 5=tire speed 6=brake energy 7=mass weight 8=final take-off 9=VMU				Min V1/VR/V2 = 115/20/22 CHECK VMU LIMITATION Correct. V1/VR/V2 = 0.1 KT/1000 KG					

For flexible temperature < TVMC (69 °C),  $\Delta T_{flex} = \dots \dots \dots -2 \text{ °C}$   
 Intermediate flex temperature..... = 62 °C

Associated speeds,  
 V1 = 153 kt - 8 = 145 kt  
 VR = 153 kt - 2 = 151 kt  
 V2 = 154 kt - 2 = 152 kt

Check V2 against VMU limitation on FCOM *Refer to PER-TOF-TOD-25-10 SPEEDS LIMITED BY VMCG/VMCA.*

It is reminded that if the speed checks are not fulfilled, the corrections must be recalculated using those provided on lines 3 and 4.

- Apply QNH correction

A320XXX	ENGINES	AIRPORT NAME				15L	VERSION	DATE
QNH Air cond. Anti-icing All reversers operating No reversers on dry runway	1013.25 HPA AC OFF AI OFF	Elevation 489 FT Isa temp 15 C Rwy slope .08 %	TORA 3000 M TODA 3000 M ASDA 3000 M		4 obstacles	DRY	AXXXXXXX *	+20
WEIGHT	CONF 1 + F				CONF 2			
1000KG	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT
INFLUENCE OF RUNWAY CONDITION								
WET	-1.4/-3 -11/-1/-1 (+89) -1.4/-3 -11/0/0	-1.1/-3 -10/-1/-1 (+69) -1.1/-3 -10/0/0	-0.7/-2 -9/-2/-2 (+69) -0.7/-2 -9/0/0	-0.7/-2 -8/-2/-2 (+69) -0.7/-2 -8/0/0	-1.3/-3 -10/-2/-2 (+69) -1.3/-3 -10/0/0	-1.3/-3 -9/-4/-4 (+69) -1.3/-3 -9/0/0	-0.4/-1 -7/-2/-2 (+69) -0.4/-1 -7/0/0	-0.2/-1 -5/0/0 (+89) -0.2/-1 -5/0/0
INFLUENCE OF DELTA PRESSURE								
QNH HPA								
-10.0	-0.8/-2 0/0/-1 (+61) -0.8/-2 0/0/0	-1.2/-3 0/0/-1 (+61) -1.2/-3 0/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 -1/-1/-1 (+61) -0.7/-2 -1/0/0	-0.7/-2 0/0/0 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0	-0.7/-2 0/0/-1 (+61) -0.7/-2 0/0/0
+10.0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	0.0/0 0/0/0 (+69) 0.0/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 0/0/0 (+69) +0.2/0 0/0/0	+0.2/0 +1/+1/+1 (+69) +0.2/0 +1/+1/+1
LABEL FOR INFLUENCE DW (1000 KG) DTFLX DV1 -DVR -DV2 (KT) (TVMC OAT C) DW (1000 KG) DTFLX DV1 -DVR -DV2 (KT)	OAT C DW CODES V1min/VRV2 (kt)	* TVMC * LIMITATION	Tref (OAT) = 8a C Tmax(OAT) = 54 C	Min a/c height: 515 FT Max a/c height: 1934 FT	Min QNH alt: 1004 FT Max QNH alt: 2423 FT	Min V1/VRV2 = 115/20/22 CHECK VMU LIMITATION Correct: V1/VRV2 = 0.1 KT/1000 KG		

For flexible temperature  $\geq$  TVMC (61 °C),  $\Delta T_{flex} = -2 \times 15/10 = \dots\dots\dots -3 \text{ }^\circ\text{C}$   
 Flexible temperature..... = 59 °C

No speed correction is required for QNH and bleed influence.

Takeoff speeds are V1 = 145 kt, VR = 151 kt, V2 = 152 kt

Check that OAT/TREF < flex temperature  $\leq$  TMAXFLEX

TMAXFLEX is specified in LIM-70.

	Takeoff Configuration : 1 + F			
	Tflex	V1	VR	V2
<b>Chart temperature</b>	67	153	153	154
<b>FCOM correction(s)</b>	-3	0	0	0
<b>Intermediate value</b>	64	153	153	154
<b>WET Correction</b>	-2	-8	-2	-2
<b>Intermediate value</b>	62	145	151	152
<b>QNH Correction</b>	-3	0	0	0
<b>Final value</b>	59	145	151	152



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)

Intentionally left blank

**FLEXIBLE TAKEOFF NOT POSSIBLE**

**FLEXIBLE TAKEOFF NOT POSSIBLE**

Ident.: PER-TOF-TOC-20-20-00013281.0001001 / 18 FEB 11

Applicable to: ALL

In some cases when the actual takeoff weight is lower than the maximum permissible one but no flexible takeoff possible (that is flexible temperature lower than TREF or OAT):

- It is mandatory to use TOGA thrust
- You can retain the speeds that have been calculated for the maximum permissible takeoff weight;  
OR
- You can retain the speeds associated with the actual takeoff weight provided they are all lower than the speeds calculated for the maximum permissible takeoff weight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)

Intentionally left blank



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)

**SUMMARY**



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)


### SUMMARY

Ident.: PER-TOF-TOC-20-30-00013282.0001001 / 24 MAR 11

Applicable to: ALL

The flow diagram gives the different steps to follow







**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF CHARTS - FLEXIBLE TAKEOFF (WEIGHT ENTRY)

Intentionally left blank

**EFFECT OF QNH AND BLEEDS (UP TO 9200 FT)**

Ident.: PER-TOF-TOD-24-00012927.0090001 / 31 MAR 11

Applicable to: ALL

To take into account QNH deviation and/or bleeds ON apply		
CORRECTIONS ON TEMPERATURE IF FLEX TAKEOFF PERFORMED		CORRECTIONS ON WEIGHT IF TAKEOFF WITH FULL THRUST IS PERFORMED
No correction except if actual pressure altitude is between 2000 ft and 4000 ft: subtract 1°C/3hPa	QNH above 1013 hPa	No correction except if actual pressure altitude is between 2000 ft and 4000 ft: subtract 40 kg/hPa
Subtract 1°C/2hPa	QNH below 1013 hPa	Subtract 140 kg/hPa
Subtract 5°C	Engine A/ICE ON	Subtract 300 kg
Subtract 11°C	Total A/ICE ON	OAT ≤ ISA + 5 Subtract 950 kg
Subtract 7°C	Air Conditioning ON	OAT > ISA + 5 Subtract 1650 kg
Compare corrected temp (CT), flat rating temp (T REF) and OAT	CT higher than OAT and CT higher than TREF	Take CT as flex temp limited to ISA + 70
	Either conditions above not fulfilled	

- Note:**
- \* Corrections valid only for OAT < 10 °C
  - For high altitude operation, REFER TO PER-TOF-TOD-24 EFFECT OF QNH FOR HIGH ALTITUDE OPERATIONS (if applicable).

**EXAMPLE**

Ident.: PER-TOF-TOD-24-00014726.0001001 / 29 JUL 16

Applicable to: ALL

**TAKEOFF CHART DATA**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

Airport geometric elevation = 450 ft

QNH = 1 013 hPa

Anti ice OFF

Air conditioning OFF

**EXAMPLE 1 - FULL THRUST TAKEOFF**

Actual data : OAT = 5 °C


QNH = 998 hPa

Engine anti ice ON

Air conditioning OFF

Weight read in the takeoff chart: 73 000 kg.

Use the QNH/BLEEDS corrections (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS*) or (*Refer to PER-TOF-TOD-24 EFFECT OF QNH AND BLEEDS FOR HIGH ALTITUDE OPERATIONS*) for high altitude operations.



Read in the above table the corrections for high QNH and engine anti ice ON.

QNH correction:  $120 \text{ kg} \times (1013 - 998) = 1\,800 \text{ kg}$

Engine anti ice correction: No correction.

The maximum permissible takeoff weight is  $73\,000 - 1\,800 - 0 = 71\,200 \text{ kg}$

**EXAMPLE 2 - FLEXIBLE THRUST TAKEOFF**

Actual data : OAT = 5 °C  
 QNH = 1 004 hPa  
 Anti ice OFF  
 Air conditioning ON  
 TOW = 65 000 kg

Flexible temperature read on the takeoff chart: TFLEX = 55 °C.

Read TREF on the takeoff chart or on the quick reference table.

Read in the above table the correction for QNH and air conditioning ON:

QNH correction =  $1^\circ\text{C} / 3 \text{ hPa} \times (1\,004 - 1\,013) = -3^\circ\text{C}$

Air conditioning ON correction:  $-3^\circ\text{C}$

New flexible temperature =  $55 - 3 - 3 = 49^\circ\text{C}$


Check that the flexible temperature is above TREF and actual OAT.

Check that the flexible temperature is less than the maximum flexible temperature.

**EFFECT OF QNH AND BLEEDS FOR HIGH ALTITUDE OPERATIONS (ABOVE 9200 FT)**

Ident.: PER-TOF-TOD-24-00012926.0207001 / 24 MAR 11

Applicable to: ALL



*Note:* \* Corrections valid only for OAT < 10 °C

**EXAMPLES FOR HIGH ALTITUDE OPERATIONS**

Ident.: PER-TOF-TOD-24-00012925.0070001 / 18 MAR 11

Applicable to: ALL

**TAKEOFF CHART DATA**

Airport geometric elevation = 11 500 ft

QNH = 1 013 hPa

Anti ice OFF

Air conditioning OFF

OAT = 0 °C

MTOW = 73 000 kg

**EXAMPLE 1 - FULL THRUST TAKEOFF**

Actual data : QNH = 1 040 hPa

Engine anti ice ON

Air conditioning OFF

Determine the actual airport pressure altitude (1 hPa is equivalent to 28 ft according to the ISA model).

Pressure altitude =  $11\,500 - (1\,040 - 1\,013) \times 28 = 10\,744$  ft

Read in the above table the corrections for high QNH and engine anti ice ON.

QNH correction =  $60 \text{ kg} \times (11\,500 - 10\,744) / 28 \text{ hPa} = +1\,620$  kg

Engine anti ice correction: 1 800 kg

The maximum permissible takeoff weight is  $73\,000 + 1\,620 - 1\,800 = 72\,820$  kg

**EXAMPLE 2 - FLEXIBLE THRUST TAKEOFF**

Actual data : QNH = 1 040 hPa

Anti ice OFF

Air conditioning ON

TOW = 65 000 kg

TFLEX = 55 °C

Read TREF on the takeoff chart or on the quick reference table.

Determine the actual airport pressure altitude (1 hPa is equivalent to 28 ft according to the ISA model).

Pressure altitude =  $11\,500 - (1\,040 - 1\,013) \times 28 = 10\,744$  ft

Read in the above table the correction for QNH and air conditioning ON:

QNH correction =  $1 \text{ °C} / 11 \text{ hPa} \times (11\,500 - 10\,744) / 28 \text{ hPa} = +3 \text{ °C}$

Air conditioning ON correction = -5 °C

New flexible temperature =  $55 + 3 - 5 = 53 \text{ °C}$

Check that the flexible temperature is above TREF and actual OAT.

**PERFORMANCE**

**TAKEOFF**

TAKEOFF DATA - QNH/BLEEDS CORRECTION

Check that the flexible temperature is less than the maximum flexible temperature and retain the lower of the two.





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

TAKEOFF DATA - MINIMUM SPEEDS

**SPEEDS LIMITED BY VMCG/VMCA**

**SPEEDS LIMITED BY VMCG/VMCA**

Ident.: PER-TOF-TOD-25-10-00001754.0268001 / 08 JUL 15

Applicable to: ALL

All takeoff speeds have a minimum value limited by control. These minimum speeds are usually provided on each RTOW chart. If these speeds are not available, use the following conservative values. These speeds may be slightly higher than the minimum control speeds displayed on the RTOW chart.

MINIMUM V1 (KT IAS)												
CONF	PRESSURE ALTITUDE (FT)											
	-2 000	0	1 000	2 000	3 000	4 000	5000	6 000	7 000	8 000	9 200	14 100
<b>1 + F</b>	117	115	114	113	112	112	111	110	109	108	106	100
<b>2</b>	115	113	112	111	111	110	109	108	107	106	104	100
<b>3</b>	114	112	111	110	110	110	109	108	107	105	104	100

MINIMUM VR (KT IAS)												
CONF	PRESSURE ALTITUDE (FT)											
	-2 000	0	1 000	2 000	3 000	4 000	5000	6 000	7 000	8 000	9 200	10 200
<b>1 + F</b>	121	119	118	116	116	116	115	114	113	111	110	102
<b>2</b>	119	117	116	115	114	114	113	112	111	109	108	100
<b>3</b>	118	116	115	114	114	114	113	112	110	109	107	100

MINIMUM V2 (KT IAS)												
CONF	PRESSURE ALTITUDE (FT)											
	-2 000	0	1 000	2 000	3 000	4 000	5000	6 000	7 000	8 000	9 200	10 200
<b>1 + F</b>	124	121	120	119	119	119	118	117	115	114	112	104
<b>2</b>	123	121	120	119	119	119	117	116	115	114	112	103
<b>3</b>	123	121	120	119	119	118	117	116	115	114	112	103



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF DATA - MINIMUM SPEEDS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

TAKEOFF DATA - MINIMUM SPEEDS

**V2 LIMITED BY VMU/MCA**

**PERFORMANCE**

**TAKEOFF**

TAKEOFF DATA - MINIMUM SPEEDS

**MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)**

Ident.: PER-TOF-TOD-25-20-00001756.0095001 / 25 MAR 11

Applicable to: ALL

The following tables, one per configuration, provide the V2 limited by minimum unstick speed and minimum control speed in the air.

MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)								
CONFIGURATION 1+F								
PRESSURE ALTITUDE (FT)	TAKEOFF WEIGHT (1000 KG)							
	45	50	55	60	65	70	75	80
<b>-2000</b>	124	124	130	135	140	145	150	155
<b>0</b>	121	124	130	135	140	145	150	155
<b>1000</b>	120	124	130	135	140	145	151	155
<b>2000</b>	119	124	129	135	140	146	151	155
<b>3000</b>	119	124	130	135	140	146	151	156
<b>4000</b>	119	124	130	135	141	146	151	156
<b>5000</b>	119	124	130	135	141	146	151	156
<b>6000</b>	119	124	130	135	141	146	152	156
<b>7000</b>	119	124	130	136	141	146	152	156
<b>8000</b>	118	124	130	136	141	147	152	157
<b>9000</b>	118	124	130	136	141	147	152	157
<b>10000</b>	118	124	130	136	141	147	152	157
<b>11000</b>	118	124	130	136	142	147	153	157
<b>12000</b>	118	124	130	136	142	147	153	158
<b>13000</b>	118	124	130	136	142	148	153	158
<b>14100</b>	118	124	130	136	142	148	153	158


MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)								
CONFIGURATION 2								
PRESSURE ALTITUDE (FT)	TAKEOFF WEIGHT (1000 KG)							
	45	50	55	60	65	70	75	80
<b>-2000</b>	123	123	124	129	134	139	144	149
<b>0</b>	121	121	124	129	134	140	145	149
<b>1000</b>	120	120	124	129	135	140	145	149
<b>2000</b>	119	119	124	129	135	140	145	149
<b>3000</b>	119	119	124	129	135	140	145	150
<b>4000</b>	119	119	124	130	135	140	145	150
<b>5000</b>	117	119	124	130	135	140	146	150
<b>6000</b>	116	119	124	130	135	141	146	150
<b>7000</b>	115	119	124	130	135	141	146	150
<b>8000</b>	114	119	124	130	136	141	146	151
<b>9000</b>	113	119	124	130	136	141	146	151
<b>10000</b>	113	119	125	130	136	141	147	151
<b>11000</b>	113	119	125	130	136	141	147	151
<b>12000</b>	113	119	125	131	136	142	147	152
<b>13000</b>	113	119	125	131	136	142	147	152
<b>14100</b>	113	119	125	131	137	142	147	152

**PERFORMANCE**

**TAKEOFF**

TAKEOFF DATA - MINIMUM SPEEDS

MINIMUM V2 LIMITED BY VMU/VMCA (KT IAS)								
CONFIGURATION 3								
PRESSURE ALTITUDE (FT)	TAKEOFF WEIGHT (1000 KG)							
	45	50	55	60	65	70	75	80
<b>-2000</b>	123	123	123	124	129	134	139	143
<b>0</b>	121	121	121	124	129	135	140	144
<b>1000</b>	120	120	120	124	129	135	140	144
<b>2000</b>	119	119	119	124	130	135	140	144
<b>3000</b>	119	119	119	124	130	135	140	144
<b>4000</b>	118	118	119	124	130	135	140	144
<b>5000</b>	117	117	119	125	130	135	140	144
<b>6000</b>	116	116	120	125	130	135	140	145
<b>7000</b>	115	115	120	125	130	136	141	145
<b>8000</b>	114	114	119	125	130	136	141	145
<b>9000</b>	112	114	120	125	131	136	141	145
<b>10000</b>	110	114	120	125	131	136	141	145
<b>11000</b>	109	114	120	125	131	136	141	145
<b>12000</b>	109	114	120	126	131	137	142	146
<b>13000</b>	108	114	120	126	131	137	142	146
<b>14100</b>	109	115	120	126	132	137	142	146

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p align="center"><b>PERFORMANCE</b></p> <p align="center"><b>TAKEOFF</b></p> <p align="center">RUNWAY CONTAMINATION - GENERAL</p>
---	--

**GENERAL**

Ident.: PER-TOF-CTA-10-00001781.0001001 / 21 JUL 14

**Applicable to: ALL**

This section presents the recommendations of Airbus for operations from wet runways or from runways which are covered with contaminants such as standing water, slush or snow.

<p><b>CAUTION</b></p>	<p>Takeoff is not recommended:</p> <ul style="list-style-type: none"> <li>- From an icy runway</li> <li>- From a runway for which the depth of contaminant is greater than the performance levels or the equivalences published in the documentation or performance software.</li> </ul>
-----------------------	--



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


**PERFORMANCE**

**TAKEOFF**

RUNWAY CONTAMINATION - GENERAL

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>TAKEOFF</b></p> <p>RUNWAY CONTAMINATION - DEFINITIONS</p>
---	---

<b>DEFINITIONS</b>
--------------------

Ident.: PER-TOF-CTA-20-00001782.0001001 / 22 MAY 13

**Applicable to: ALL**

- DAMP : A runway is damp when the surface is not dry, but when the water on it does not give it a shiny appearance.
- WET : A runway is considered as wet when the surface has a shiny appearance due to a thin layer of water. When this layer does not exceed 3 mm depth, there is no substantial risk of hydroplaning.
- STANDING WATER : is caused by heavy rainfall and /or insufficient runway drainage with a depth of more than 3 mm.
- SLUSH : is water saturated with snow which spatters when stepping firmly on it. It is encountered at temperatures around 5 °C and its density is approximately 0.85 kg/l (7.1 lb/US Gal).
- WET SNOW : is a condition where, if compacted by hand, snow will stick together and tend to form a snowball. Its density is approximately 0.4 kg/l (3.35 lb/US Gal).
- DRY SNOW : is a condition where snow can be blown if loose, or if compacted by hand, will fall apart again upon release. Its density is approximately 0.2 kg/l (1.7 lb/US Gal).
- COMPACTED SNOW : is a condition where snow has been compressed.
- ICY : is a condition where the friction coefficient is 0.05 or below.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - DEFINITIONS**

**EQUIVALENCES**

Ident.: PER-TOF-CTA-20-00014919.0001001 / 21 JUL 14

Applicable to: **ALL**

For the below-listed reported contaminants, the following equivalent runway conditions can be retained for the takeoff performance determination.

Reported contaminant		Equivalent Runway Condition
Type of contaminant	Depth of contaminant	
Slush	≤ 3 mm (1/8 in)	Wet
Water	≤ 3 mm (1/8 in)	
Wet snow	≤ 3 mm (1/8 in)	6.3 mm (1/4 in) Slush 12.7 mm (1/2 in) Slush
	≤ 12.7 mm (1/2 in)	
	≤ 25.4 mm (1 in)	
Dry snow	≤ 3 mm (1/8 in)	Wet
	≤ 50.8 mm (2 in)	6.3 mm (1/4 in) Slush
	≤ 100 mm (4 in)	12.7 mm (1/2 in) Slush

**OPERATIONAL CONDITIONS**

Ident.: PER-TOF-CTA-30-00001783.0001001 / 14 DEC 09

Applicable to: ALL

**Performance penalties for takeoff as published in this section are computed with the following assumptions :**

- The contaminant is in a layer of uniform depth and density over the entire length of the runway.
- Antiskid and spoilers are operative.
- The friction coefficient is based on studies and checked by actual tests.
- The screen height at the end of takeoff segment is 15 ft, not 35 ft.

**In addition, for contaminated runways only :**

- There is drag due to rolling resistance of the wheels.
- There is drag due to spray on the airframe and gears.
- Reverse thrust is used for the deceleration phase.
- Maximum thrust is used for takeoff.

*Note: The net flight path clears obstacles by 15 ft instead of 35 ft.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

RUNWAY CONTAMINATION - OPERATIONAL CONDITIONS

Intentionally left blank

**TAKEOFF PERFORMANCE**

**TAKEOFF PERFORMANCE**

Ident.: PER-TOF-CTA-40-10-00013660.0003001 / 23 JUN 15

Applicable to: ALL

**CAUTION**

The method is based on the use of the RTOW charts established at optimum V2 /VS and optimum V1 /VR . In addition, when applying corrections for a wet runway, the RTOW charts should also have been established with V1 min (minimum V1 of the V1 range). The method should not be used with takeoff charts computed for other conditions. All tables have been established for TOGA (and Flexible Takeoff for wet runways). Do not use them for Derated thrust.

Correct the determined maximum takeoff weight on dry runway to take into account QNH and bleed effects, then apply the corrections given on the following pages.

- Note:
1. *The results obtained with this method may be different from the influence given at the bottom of the RTOW chart.*
  2. *On contaminated runway, in some cases, no MTOW can be determined with this method (box dashed below a given weight). A specific RTOW chart must then be computed.*
  3. *The published corrections are valid for charts calculated with forward CG and basic CG.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE

**TAKEOFF FROM A WET RUNWAY**

**HOW TO PROCEED**

Ident.: PER-TOF-CTA-40-20-00012966.0004001 / 24 MAR 11

Applicable to: ALL

1. Determine the maximum takeoff weight or flexible temperature and associated speeds on dry runway.
2. Two sets of tables are given depending on the use of thrust reversers and the presence of clearway. Select the table to use as applicable to your case.  
 The runway length in the table corresponds to the available takeoff run (TORA).
3. Apply the corrections shown in the table to the maximum takeoff weight or flexible temperature and associated speeds determined on dry runway.
4. Check that takeoff speeds are greater than the minimum values shown on the RTOW chart.

If one or more speeds are lower than these minimum values, apply the following procedure :

- Actual TOW = maximum TOW

- If V1 is lower than the minimum V1 (V1 limited by VMCG ), take this last value as V1 and further decrease weight by 3 000 kg (6 600 lb ) per knot difference between them. Check that VR and V2 are higher than or equal to the minimum values.
- If VR or/and V2 falls below the minimum values, takeoff is not possible.

- Actual TOW lower than maximum TOW

- If V1 corresponding to actual TOW is lower than the minimum V1 (V1 limited by VMCG) :
  - If maximum TOW has a V1 equal to or above minimum V1 , retain minimum V1 as V1 and decrease the flexible temperature by 4 °C per knot difference between them.
  - In the rare case when the V1 corresponding to maximum TOW falls below the minimum V1 , decrease maximum TOW by 3 000 kg (6 600 lb ) per knot difference between them. Limit the actual TOW to the value found after this decrement. Take V1 equal to minimum V1 and decrease the flexible temperature by 4 °C per knot difference between this last value and the V1 corresponding to the actual TOW . Check that VR and V2 are higher than or equal to the minimum values.
- If VR or V2 corresponding to actual TOW falls below the minimum values, and if VR and V2 corresponding to maximum TOW are above the minimum values, retain the minimum speed value for VR and V2.

5. Check that V2 is above the minimum V2 value due to VMU (*Refer to PER-TOF-TOD-25-10 SPEEDS LIMITED BY VMCG/VMCA*).

6. Check that the corrected flexible temperature is higher than OAT and Tref.

Note: - Do not extrapolate below the shortest runway length provided in the table.



- If no minimum speed value is available, use the conservative values provided on Refer to PER-TOF-TOD-25-10 SPEEDS LIMITED BY VMCG/VMCA.

**NO THRUST REVERSERS OPERATIVE (NO CLEARWAY)**

Ident.: PER-TOF-CTA-40-20-00012743.0048001 / 04 MAR 11

Applicable to: ALL

TAKEOFF CONFIGURATION	1 + F			2			3		
	RUNWAY LENGTH (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500
FLEX TO Temperature decrement (°C)	8	5	3	8	6	2	6	6	2
MAX TO Weight decrement (1 000 kg) (1 000 lb)	2.6 5.8	2.0 4.5	1.3 2.9	2.5 5.6	2.2 4.9	0.7 1.6	2.1 4.7	2.1 4.7	0.7 1.6
V1 decrement (kt)	15	14	14	16	14	14	14	15	13
VR and V2 decrement (kt)	2	1	1	2	1	2	1	2	0

**ALL THRUST REVERSERS OPERATIVE (NO CLEARWAY)**

Ident.: PER-TOF-CTA-40-20-00012744.0084001 / 04 MAR 11

Applicable to: ALL

TAKEOFF CONFIGURATION	1 + F			2			3		
	RUNWAY LENGTH (m) (ft)	2500 8000	3000 10000	3500 11500 and above	2000 6500	2500 8000	3000 10000 and above	1750 5750	2000 6500
FLEX TO Temperature decrement (°C)	3	2	0	3	1	0	2	1	1
MAX TO Weight decrement (1000 kg) (1000 lb)	1.0 2.3	0.6 1.4	0.0 0.0	0.8 1.8	0.3 0.7	0.0 0.0	0.6 1.4	0.2 0.5	0.1 0.3
V1 decrement (kt)	9	9	9	10	8	9	10	9	8
VR and V2 decrement (kt)	0	0	0	0	0	0	0	0	0

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**NO THRUST REVERSERS OPERATIVE (WITH CLEARWAY)**

Ident.: PER-TOF-CTA-40-20-00012745.0044001 / 08 FEB 11

Applicable to: ALL

TAKEOFF CONFIGURATION	1 + F			2			3		
<b>RUNWAY LENGTH</b> (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500	2 500 8 000 and above
<b>FLEX TO Temperature decrement (°C)</b>	15	9	9	14	11	4	15	12	5
<b>MAX TO Weight decrement (1 000 kg) (1 000 lb)</b>	5.4 12.0	4.1 9.1	3.8 8.4	4.6 10.2	4.2 9.3	1.6 3.6	4.5 10.0	4.5 10.0	2.2 4.9
<b>V1 decrement (kt)</b>	14	15	15	14	14	15	13	13	14
<b>VR and V2 decrement (kt)</b>	4	3	6	4	4	6	3	4	5

**ALL THRUST REVERSERS OPERATIVE (WITH CLEARWAY)**

Ident.: PER-TOF-CTA-40-20-00012941.0044001 / 28 JAN 11

Applicable to: ALL

TAKEOFF CONFIGURATION	1 + F			2			3		
<b>RUNWAY LENGTH</b> (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500	2 500 8 000 and above
<b>FLEX TO Temperature decrement (°C)</b>	11	5	2	10	8	3	11	9	3
<b>MAX TO Weight decrement (1 000 kg) (1 000 lb)</b>	3.9 8.6	2.3 5.1	0.9 2.0	3.3 7.3	3.1 6.9	1.0 2.3	3.3 7.3	3.3 7.3	1.3 2.5
<b>V1 decrement (kt)</b>	9	10	12	9	9	10	8	9	9
<b>VR and V2 decrement (kt)</b>	3	2	3	3	3	4	2	2	4



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE

**TAKEOFF FROM A CONTAMINATED RUNWAY**

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**TAKEOFF FROM A 6.3 MM (1/4 INCH) WATER COVERED RUNWAY**

Ident.: PER-TOF-CTA-40-30-00001786.0373001 / 22 FEB 17

Applicable to: ALL

- Determine maximum takeoff weight on dry runway.
- Apply the following weight decrement versus takeoff configuration, runway length and clearway availability to determine a corrected weight.

TAKEOFF CONFIGURATION	CONF 1 + F				CONF 2			CONF 3		
RUNWAY LENGTH (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500	4 000 13 00 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5750	2 000 6 500	2 500 8 000 and above
Δ Weight (1 000 kg) With clearway Without clearway	12.8 10.5	11.7 10.1	9.8 9.0	9.8 9.0	13.9 11.1	13.2 11.1	11.4 10.4	14.9 11.4	14.5 11.8	13.1 11.8

- Enter the following tables with the corrected weight to determine MTOW then determine takeoff speeds associated with actual TOW.

**CONF 1 + F**

CORRECTED WEIGHT (1 000 kg)	<55.2	55.2	56	58	58 to 78															
MTOW (1 000 kg)	-	46.7	50	58	EQUAL TO CORRECTED WEIGHT															

ACTUAL WEIGHT (1 000 kg)	<46.7	46.7	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
V2 (kt IAS)	124	124	126	129	131	134	136	138	141	143	145	148	150	152	155	157	159	161
VR (kt IAS)	121	121	123	126	128	131	133	135	138	140	142	145	147	149	152	154	156	158
V1 (kt IAS)	117	117	117	117	117	117	117	117	120	122	124	127	129	131	134	136	138	140

**CONF 2**

CORRECTED WEIGHT (1 000 kg)	<56.8	56.8	58	59	59 to 78													
MTOW (1 000 kg)	-	48.7	55	59	EQUAL TO CORRECTED WEIGHT													



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

ACTUAL WEIGHT (1 000 kg)	<48.7	48.7	50	52	54	56	58	59	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	125	125	127	129	132	134	137	138	139	141	143	146	148	150	153	155	157	159
<b>VR (kt IAS)</b>	119	119	121	123	126	128	131	132	133	135	137	140	142	144	147	149	151	153
<b>V1 (kt IAS)</b>	115	115	115	115	115	115	115	115	116	118	120	123	125	127	130	132	134	136

**CONF 3**

<b>CORRECTED WEIGHT (1 000 kg)</b>	<57.8	57.8	58	60	<b>60 to 78</b>													
<b>MTOW (1 000 kg)</b>	-	48	49	60	EQUAL TO CORRECTED WEIGHT													

ACTUAL WEIGHT (1 000 kg)	<48	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	126	126	128	131	133	135	138	140	142	145	147	149	151	153	155	157
<b>VR (kt IAS)</b>	118	118	121	123	126	128	130	133	135	137	140	142	144	146	148	150	152
<b>V1 (kt IAS)</b>	114	114	114	114	114	114	114	114	116	118	121	123	125	129	129	131	133

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**TAKEOFF FROM A 12.7 MM (1/2 INCH) WATER COVERED RUNWAY**

Ident.: PER-TOF-CTA-40-30-00001794.0117001 / 01 APR 11

Applicable to: ALL

- Determine maximum takeoff weight on dry runway.
- Apply the following weight decrement versus takeoff configuration, runway length and clearway availability to determine a corrected weight.

TAKEOFF CONFIGURATION	CONF 1 + F				CONF 2			CONF 3		
RUNWAY LENGTH (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500	4 000 13 000 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500	2 500 8 000 and above
Δ Weight (1 000 kg) With clearway Without clearway	16.7 14.4	15.7 14.1	12.9 12.0	10.4 9.6	17.3 13.3	16.6 14.5	15.5 14.5	17.5 14.0	17.5 14.8	16.3 15.0

- Enter the following tables with the corrected weight to determine MTOW then determine takeoff speeds associated with actual TOW.

**CONF 1 + F**

CORRECTED WEIGHT (1 000 kg)	<51.4	51.4	52	52.7	52.7 to 78															
MTOW (1 000 kg)	-	46.7	49	52.7	EQUAL TO CORRECTED WEIGHT															

ACTUAL WEIGHT (1 000 kg)	<46.7	46.7	48	50	52	52.7	54	56	58	60	62	64	66	68	70	72	74	76	78
V2 (kt IAS)	124	124	126	129	131	132	134	136	138	141	143	145	148	150	152	155	157	159	161
VR (kt IAS)	122	122	124	127	129	130	132	134	136	139	141	143	146	148	150	153	155	157	159
V1 (kt IAS)	117	117	117	117	117	117	119	121	123	126	128	130	133	135	137	140	142	144	146

**CONF 2**

CORRECTED WEIGHT (1 000 kg)	<52.9	52.9	54	54 to 78															
MTOW (1 000 kg)	-	48	54	EQUAL TO CORRECTED WEIGHT															

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	124	124	127	129	132	134	137	139	141	143	146	148	150	153	155	157	159
<b>VR (kt IAS)</b>	119	119	122	124	127	129	132	134	136	138	141	143	145	148	150	152	154
<b>V1 (kt IAS)</b>	115	115	115	115	115	117	120	122	124	126	129	131	133	136	138	140	142

**CONF 3**

<b>CORRECTED WEIGHT (1 000 kg)</b>	<54	54	56	<b>56 to 78</b>													
<b>MTOW (1 000 kg)</b>	-	48	56	<b>EQUAL TO CORRECTED WEIGHT</b>													

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	123	126	128	131	133	135	138	140	142	145	147	149	151	153	155	157
<b>VR (kt IAS)</b>	118	118	121	123	126	128	130	133	135	137	140	142	144	146	148	150	152
<b>V1 (kt IAS)</b>	114	114	114	114	114	114	116	119	121	123	126	128	130	132	134	136	138



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**TAKEOFF FROM A 6.3 MM (1/4 INCH) SLUSH COVERED RUNWAY**

Ident.: PER-TOF-CTA-40-30-00001787.0374001 / 25 MAR 11

Applicable to: ALL

- Determine maximum takeoff weight on dry runway.
- Apply the following weight decrement versus takeoff configuration, runway length and clearway availability to determine a corrected weight.

TAKEOFF CONFIGURATION	CONF 1 + F				CONF 2			CONF 3		
RUNWAY LENGTH (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500	4 000 13 000 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500	2 500 8 000 and above
Δ Weight (1 000 kg) With clearway Without clearway	13.2 10.9	11.8 10.2	9.8 9.0	9.8 9.0	14.5 11.7	13.8 11.7	11.6 10.6	15.2 11.5	15.2 12.5	13.9 12.6

- Enter the following tables with the corrected weight to determine MTOW then determine takeoff speeds associated with actual TOW.

**CONF 1 + F**

CORRECTED WEIGHT (1 000 kg)	<53.2	53.2	54	55	55 to 78															
MTOW (1 000 kg)	-	46.7	51	55	EQUAL TO CORRECTED WEIGHT															

ACTUAL WEIGHT (1 000 kg)	<46.7	46.7	48	50	52	54	55	56	58	60	62	64	66	68	70	72	74	76	78
V2 (kt IAS)	124	124	126	129	131	134	135	136	138	141	143	145	148	150	152	155	157	159	161
VR (kt IAS)	122	122	124	127	129	132	133	134	136	139	141	143	146	148	150	153	155	157	159
V1 (kt IAS)	117	117	117	117	117	117	117	118	120	123	125	127	130	132	134	137	139	141	143

**CONF 2**

CORRECTED WEIGHT (1 000 kg)	<54.8	54.8	56	56.7	56.7 to 76															
MTOW (1 000 kg)	-	48	53	56.7	EQUAL TO CORRECTED WEIGHT															





**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	56.7	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	124	124	127	129	132	134	135	137	139	141	143	146	148	150	153	155	157	159
<b>VR (kt IAS)</b>	119	119	122	124	127	129	130	132	134	136	138	141	143	145	148	150	152	154
<b>V1 (kt IAS)</b>	115	115	115	115	115	115	115	117	119	121	123	126	128	130	133	135	137	139

**CONF 3**

<b>CORRECTED WEIGHT (1 000 kg)</b>	<56.3	56.3	58	58.7	<b>58.7 to 78</b>													
<b>MTOW (1 000 kg)</b>	-	48	55	58.7	<b>EQUAL TO CORRECTED WEIGHT</b>													

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	58	58.7	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	123	126	128	131	133	135	136	138	140	142	145	147	149	151	153	155	157
<b>VR (kt IAS)</b>	118	118	121	123	126	128	130	131	133	135	137	140	142	144	146	148	150	152
<b>V1 (kt IAS)</b>	114	114	114	114	114	114	114	114	116	118	120	123	125	127	129	131	133	135

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**TAKEOFF FROM A 12.7 MM (1/2 INCH) SLUSH COVERED RUNWAY**

Ident.: PER-TOF-CTA-40-30-00001788.0369001 / 23 JUN 15

Applicable to: ALL

- Determine maximum takeoff weight on dry runway.
- Apply the following weight decrement versus takeoff configuration, runway length and clearway availability to determine a corrected weight.

TAKEOFF CONFIGURATION	CONF 1 + F				CONF 2			CONF 3		
<b>RUNWAY LENGTH</b> (m) (ft)	<b>2 500</b> <b>8 000</b>	<b>3 000</b> <b>10 000</b>	<b>3 500</b> <b>11 500</b>	<b>4 000</b> <b>13 000</b> and above	<b>2 000</b> <b>6 500</b>	<b>2 500</b> <b>8 000</b>	<b>3 000</b> <b>10 000</b> and above	<b>1 750</b> <b>5 750</b>	<b>2 000</b> <b>6 500</b>	<b>2 500</b> <b>8 000</b> and above
<b>Δ Weight (1 000 kg)</b> <b>With clearway</b> <b>Without clearway</b>	18.9 17.3	18.9 17.3	16.3 15.4	15.4 14.6	18.7 14.7	18.7 16.6	17.9 16.9	18.9 15.4	18.4 15.7	18.3 17.0

- Enter the following tables with the corrected weight to determine MTOW then determine takeoff speeds associated with actual TOW.

**CONF 1 + F**

<b>CORRECTED WEIGHT</b> (1 000 kg)	<47.8	47.8	48	<b>48 to 78</b>																
<b>MTOW</b> (1 000 kg)	-	46.7	48	EQUAL TO CORRECTED WEIGHT																

ACTUAL WEIGHT (1 000 kg)	<46.7	46.7	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2</b> (kt IAS)	124	124	126	129	131	134	136	138	141	143	145	148	150	152	155	157	159	161
<b>VR</b> (kt IAS)	123	123	125	128	130	133	135	137	140	142	144	147	149	151	154	156	158	160
<b>V1</b> (kt IAS)	117	117	117	120	122	125	127	129	132	134	136	139	141	143	146	148	150	152

**CONF 2**

<b>CORRECTED WEIGHT</b> (1 000 kg)	<49.5	49.5	50	<b>50 to 78</b>																
<b>MTOW</b> (1 000 kg)	-	47	50	EQUAL TO CORRECTED WEIGHT																



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

ACTUAL WEIGHT (1 000 kg)	<47	47	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	123	124	127	129	132	134	137	139	141	143	146	148	150	153	155	157	159
<b>VR (kt IAS)</b>	119	119	120	123	125	128	130	133	135	137	139	142	144	146	149	151	153	155
<b>V1 (kt IAS)</b>	115	115	115	115	117	120	122	125	127	129	131	134	136	138	141	143	145	147

**CONF 3**

CORRECTED WEIGHT (1 000 kg)	<51	51	52	52 to 78															
<b>MTOW (1 000 kg)</b>	-	48	52	EQUAL TO CORRECTED WEIGHT															

ACTUAL WEIGHT (1 000 kg)	<48	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	123	126	128	131	133	135	138	140	142	145	147	149	151	153	155	157
<b>VR (kt IAS)</b>	119	119	122	124	127	129	131	134	136	138	141	143	145	147	149	151	153
<b>V1 (kt IAS)</b>	114	114	114	114	117	119	121	124	126	128	131	133	135	137	139	141	143

**PERFORMANCE**

**TAKEOFF**

**RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE**

**TAKEOFF FROM A COMPACTED SNOW COVERED RUNWAY**

Ident.: PER-TOF-CTA-40-30-00001789.0347001 / 23 JUN 15

Applicable to: ALL

- Determine maximum takeoff weight on dry runway.
- Apply the following weight decrement versus takeoff configuration and runway length to determine a corrected weight.

TAKEOFF CONFIGURATION	CONF 1 + F				CONF 2			CONF 3		
	RUNWAY LENGTH (m) (ft)	2 500 8 000	3 000 10 000	3 500 11 500	4 000 13 000 and above	2 000 6 500	2 500 8 000	3 000 10 000 and above	1 750 5 750	2 000 6 500
Δ Weight decrement (1 000 kg) With clearway Without clearway	8.6 6.3	8.5 6.3	8.5 7.4	9.8 9.0	10.5 7.7	7.4 5.3	5.6 4.6	13.1 9.6	10.3 7.6	8.2 6.9

- Enter the following tables with the corrected weight to determine MTOW then determine takeoff speeds associated with actual TOW.

**CONF 1 + F<sub>1</sub>**

CORRECTED WEIGHT (1 000 kg)	<52.7	52.7	54	54 to 78															
MTOW (1 000 kg)	-	46.7	54	EQUAL TO CORRECTED WEIGHT															

ACTUAL WEIGHT (1 000 kg)	<46.7	46.7	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78
V2 (kt IAS)	124	124	126	129	131	134	136	138	141	143	145	148	150	152	155	157	159	161
VR (kt IAS)	123	123	125	128	130	133	135	137	140	142	144	147	149	151	154	156	158	160
V1 (kt IAS)	117	117	117	117	117	117	119	121	124	126	128	131	133	135	138	140	142	144

**CONF 2**

CORRECTED WEIGHT (1 000 kg)	<54.8	54.8	56	56.7	56.7 to 78													
MTOW	-	48	53	56.7	EQUAL TO CORRECTED WEIGHT													

*Continued on the following page*

*Continued from the previous page*

<b>CORRECTED WEIGHT (1 000 kg)</b>	<54.8	54.8	56	56.7	<b>56.7 to 78</b>													
<b>(1 000 kg)</b>																		

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	56.7	58	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	124	124	127	129	132	134	135	137	139	141	143	146	148	150	153	155	157	159
<b>VR (kt IAS)</b>	119	119	122	124	127	129	130	132	134	136	138	141	143	145	148	150	152	154
<b>V1 (kt IAS)</b>	115	115	115	115	115	115	115	117	119	121	123	126	128	130	133	135	137	139

**CONF 3**

<b>CORRECTED WEIGHT (1 000 kg)</b>	<56.3	56.3	58	58.7	<b>58.7 to 78</b>													
<b>MTOW (1 000 kg)</b>	-	48	55	58.7	EQUAL TO CORRECTED WEIGHT													

<b>ACTUAL WEIGHT (1 000 kg)</b>	<48	48	50	52	54	56	58	58.7	60	62	64	66	68	70	72	74	76	78
<b>V2 (kt IAS)</b>	123	123	126	128	131	133	135	136	138	140	142	145	147	149	151	153	155	157
<b>VR (kt IAS)</b>	119	119	122	124	127	129	131	132	134	136	138	141	143	145	147	149	151	153
<b>V1 (kt IAS)</b>	114	114	114	114	114	114	114	114	116	118	120	123	125	127	129	131	133	135



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE

Intentionally left blank

**EXAMPLE**

**TAKEOFF PERFORMANCE ON DRY RUNWAY**

Ident.: PER-TOF-CTA-40-40-00014730.0001001 / 29 JUL 16

Applicable to: ALL

**DATA**

The following data and graph are for example only, and are not for operational use. Even if the data in the following example is in "kg" and "m", the same method can be applied for "lb" and "ft".

Runway length : 3 000 m, OAT = 36 °C, no wind, CONF 1+F

Determine maximum takeoff weight on dry runway from RTOW chart (*Refer to PER-TOF-TOC-10-30 EXAMPLE OF TAKEOFF CHART*).

OAT °C	CONF 1 + F				
	TAILWIND -10 KT	TAILWIND -5 KT	WIND 0 KT	HEADWIND 10 KT	HEADWIND 20 KT
34.0	76.7 4/6 143/50/52	78.4 4/6 148/53/55	80.2 4/6 154/56/58	81.5 4/6 157/57/60	82.8 4/6 160/60/62
	76.6 4/6 143/49/52	78.4 4/6 148/52/54	80.1 4/6 153/56/58	81.4 4/6 156/57/59	82.7 4/6 160/60/62

Maximum TOW = 80 100 kg, V1 = 153 kt, VR = 156 kt, V2 = 158 kt.

**TAKEOFF PERFORMANCE ON WET RUNWAY**

Ident.: PER-TOF-CTA-40-40-00014731.0001001 / 29 JUL 16

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

With no thrust reversers operating and assuming that no clearway was used to compute the dry RTOW chart, use the table *Refer to PER-TOF-CTA-40-20 NO THRUST REVERSERS OPERATIVE (NO CLEARWAY)*.

TAKEOFF CONFIGURATION	1+F			2			3		
RUNWAY LENGTH	2500	3000	3500	2000	2500	3000	1750	2000	2500
(m)	8000	10000	11500	6500	8000	10000	5750	6500	8000
(ft)			AND ABOVE			AND ABOVE			AND ABOVE
FLEX TO TEMPERATURE DECREMENT (°C)	8	3	2	10	7	6	9	5	5
MAX TO WEIGHT DECREMENT (1000 kg)	2.4	0.9	0.8	2.8	2.2	2.2	2.5	1.5	1.5
(1000 lb)	5.3	2.0	1.8	6.2	4.9	4.9	5.6	3.4	3.4
V1 DECREMENT (kt)	16	16	14	16	15	15	15	15	15
VR AND V2 DECREMENT (kt)	3	3	2	3	4	7	1	3	4

- Maximum takeoff weight correction :  
 $MTOW = 80\ 100 - 900 = 79\ 200\ kg$ ,  $V1 = 153 - 16 = 137\ kt$ ,  $VR = 156 - 3 = 153\ kt$ ,  $V2 = 158 - 3 = 155\ kt$ .
- Flex temperature correction :  
 Assuming an actual takeoff weight of 75 000 kg and an initial flex temperature of 53 °C  
 $TOW = 75\ 000\ kg \Rightarrow Flex\ temperature = 53 - 3 = 50\ ^\circ C$   
 $V1 = 152 - 16 = 136\ kt$ ,  $VR = 153 - 3 = 150\ kt$ ,  $V2 = 154 - 3 = 151\ kt$ .

Check the resulting speeds against the minimum speeds as per procedure *Refer to PER-TOF-CTA-40-20 HOW TO PROCEED*.







**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### TAKEOFF

RUNWAY CONTAMINATION - TAKEOFF PERFORMANCE

V1 = 141 kt, VR = 147 kt, V2 = 148 kt

# PERFORMANCE

FLIGHT PLANNING

Intentionally left blank

**PER-FPL-GEN GENERAL**

PER-FPL-GEN-MFR MINIMUM RECOMMENDED FUEL REQUIREMENTS

MINIMUM RECOMMENDED FUEL REQUIREMENTS..... A

PER-FPL-GEN-FPL FLIGHT PLAN

FLIGHT PLAN..... A

**PER-FPL-FLP FLIGHT PREPARATION**

PER-FPL-FLP-QFP QUICK DETERMINATION OF FLIGHT PLANNING

PER-FPL-FLP-QFP-10 INTRODUCTION

INTRODUCTION..... A

PER-FPL-FLP-QFP-20 CORRECTION FOR DEVIATION FROM REFERENCE LANDING

WEIGHT

CORRECTION FOR DEVIATION FROM REFERENCE LANDING WEIGHT..... A

PER-FPL-FLP-QFP-30 EXAMPLE

EXAMPLE..... A

PER-FPL-FLP-QFP-40 FLIGHT PLANNING AT A GIVEN MACH NUMBER

FLIGHT PLANNING M.78..... A

PER-FPL-FLP-QFP-50 FLIGHT PLANNING AT LONG RANGE SPEED

FLIGHT PLANNING LRC..... A

PER-FPL-FLP-ALN ALTERNATE

PER-FPL-FLP-ALN-20 ALL ENGINES OPERATIVE

GENERAL..... A

CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT..... B

ALTERNATE PLANNING ISA..... C




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>FLIGHT PLANNING</b></p> <p style="text-align: center;">GENERAL - MINIMUM RECOMMENDED FUEL REQUIREMENTS</p>
---	---

**MINIMUM RECOMMENDED FUEL REQUIREMENTS**

Ident.: PER-FPL-GEN-MFR-00001837.0001001 / 08 FEB 11

**Applicable to: ALL**

The total fuel quantity required to fly a given sector is the sum of the following quantities:

**TAXI FUEL**

Quantity required for startup and taxi. Fuel calculation is based on a consumption of 11.5 kg/min or 25 lb/min

Average quantity (12 min) → 140 kg or 300 lb

**TRIP FUEL**

Fuel required from departure to destination includes the following quantities:

- Takeoff and climb at selected speed.
- Cruise at selected speed.
- Descent from cruising level to 1 500 ft above destination airport.
- Approach and landing. Fuel calculation is based on a consumption of 20 kg/min or 45 lb/min  
Average quantity (6 min IFR) → 120 kg or 270 lb

**RESERVE FUEL**

This quantity includes :

**“EN ROUTE” RESERVE FUEL (CONTINGENCY FUEL)**

- According to national regulations and company policy (generally based on a percentage of trip fuel).

**ALTERNATE FUEL**

- Fuel required to fly from destination to alternate airport.

It includes go-around 100 kg or 220 lb, climb to cruising level, cruise at long range speed, descent and approach procedure.

80 kg or 180 lb for 4 min VFR

**HOLDING FUEL**

Calculation of holding fuel should take into account the altitude of the alternate and the landing weight at the alternate. To use holding charts *Refer to PER-HLD-GEN GENERAL.*

A conservative quantity corresponding to a 30 min holding at 1 500 ft above alternate airport elevation at “green dot” speed in the clean configuration is 1 200 kg or 2 700 lb

**APU FUEL**

During ground operations, APU fuel consumption is about 130 kg/h or 290 lb/h (Packs ON, 90 KVA load on APU GEN).



**FLIGHT PLAN**


Ident.: PER-FPL-GEN-FPL-00001835.0001001 / 22 MAR 11

Applicable to: ALL

When no precalculated flight plan is available, flight planning can be determined by using the tables given in this chapter.

Fuel policy will be the same as for precalculated flight plan.

The graph on the following page defines the different terms used in this chapter.





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

GENERAL - FLIGHT PLAN

Intentionally left blank

## INTRODUCTION

### INTRODUCTION

Ident.: PER-FPL-FLP-QFP-10-00001827.0003001 / 02 MAY 12

Applicable to: ALL

The following flight planning tables allow the planner to determine trip fuel consumption and trip time required to cover a given air distance.

These tables are established for:

- Takeoff
- Climb profile 250 kt/300 kt/M 0.78
- Cruise Mach number M 0.78/LR
- Descent profile M 0.78/300 kt/250 kt
- Approach and landing 120 kg - 6 min IFR
- ISA
- CG = 33 %
- Normal air conditioning
- Anti ice OFF

They are based upon a reference landing weight of 55 000 kg and have been calculated using databases for CFM 56–5–B/P. If the engines fitted on the aircraft are neither /P, nor /3, the fuel consumption has to be increased by 3 %.

- Note:
1. In the tables, the asterisk (\*) means that a step climb of 4 000 ft must be flown to reach the corresponding FL.
  2. To obtain a flight plan at optimum cruise level, the highest flight level desired within the flight has to be selected in the table.
  3. For each degree Celsius above ISA temperature apply fuel correction  $0.015 \text{ (kg/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air Distance (NM)}$ .



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

Intentionally left blank



**A318/A319/A320/A321**

**FLIGHT CREW  
OPERATING MANUAL**

**PERFORMANCE**

**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

**CORRECTION FOR DEVIATION FROM REFERENCE LANDING WEIGHT**

**CORRECTION FOR DEVIATION FROM REFERENCE LANDING WEIGHT**

Ident.: PER-FPL-FLP-QFP-20-00001828.0001001 / 03 MAR 11

Applicable to: ALL

The fuel consumption must be corrected when the actual landing weight is different from the reference landing weight.

If it is lower (or greater) than the reference landing weight, subtract (or add) the value given in the correction part of the table per 1 000 kg below (or above) the reference landing weight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

Intentionally left blank



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

**EXAMPLE**

**EXAMPLE**

Ident.: PER-FPL-FLP-QFP-30-00014738.0001001 / 04 JUL 17

Applicable to: ALL

**INTRODUCTION**

This section provides an example explaining step by step how to perform a quick planning.

This example is based on an A320-232 aircraft, which most likely does not reflect your actual aircraft. Nevertheless, the principle is valid for any aircraft, provided the appropriate performance tables are used.

For actual calculations, access the appropriate tables corresponding to your current aircraft and desired flight profile by following the "refer to" indications specified at each step, and do not use the tables provided in the example.

**EXAMPLE**

The example is based on the following parameters:

- |   |                   |
|---|-------------------|
| - Aircraft used for the example           | A320-232          |
| - Zero Fuel Weight                        | 60 000 kg         |
| - Temperature                             | ISA conditions    |
| - Air conditioning                        | Normal            |
| - Anti-ice                                | Off               |
| - Cruise                                  | M 0.78 at FL 370  |
| - Departure - destination ground distance | 1 800 NM          |
| - Average wind on the leg to destination  | -40 kt (headwind) |
| - Reserve fuel                            | 5 %               |
| - Destination - alternate ground distance | 200 NM at FL 200  |
| - Average wind on the leg to alternate    | 0 kt              |

To calculate the flight plan, it is necessary to start from the minimum landing fuel at the alternate airport.

1. Determine the 30 minutes holding fuel required at alternate airport (at 1 500 ft AGL).  
(Refer to *PER-FPL-GEN-MFR MINIMUM RECOMMENDED FUEL REQUIREMENTS* for actual 30 min fuel value).  
For the example, the conservative value of 1 200 kg is chosen.  
The resulting landing weight at alternate is 60 000 + 1 200 = 61 200 kg.
2. Determine time, trip fuel, and fuel correction for the leg from destination to alternate airport:



ALTERNATE PLANNING FROM DESTINATION TO ALTERNATE AIRPORT GO-AROUND : 100 KG - CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE DESCENT : M.78/300KT/250KT - VMC PROCEDURE : 80 KG (4MIN)									
REF. LDG. WT AT ALTERNATE = 55000 KG NORMAL AIR CONDITIONING ANTI-ICING OFF		ISA CG = 33.0 %				FUEL CONSUMED (KG)			
AIR DIST. (NM)	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
	100	120	140	160	180	200	FL100 FL120	FL140 FL160	FL180 FL200
20									
40	529 0.12						2		
60	680 0.16	658 0.15					3		
80	832 0.20	805 0.20	803 0.20	803 0.20	805 0.19		5	4	4
100	984 0.24	952 0.24	945 0.24	941 0.23	939 0.23	938 0.22	6	6	5
120	1136 0.28	1099 0.28	1088 0.28	1080 0.27	1072 0.26	1065 0.26	7	7	6
140	1289 0.32	1246 0.32	1230 0.32	1218 0.30	1206 0.29	1192 0.29	9	8	6
160	1441 0.36	1393 0.36	1373 0.35	1357 0.34	1340 0.33	1319 0.32	10	10	7
180	1594 0.40	1541 0.40	1517 0.39	1496 0.38	1474 0.36	1446 0.35	11	11	8
200	1747 0.45	1689 0.44	1660 0.43	1635 0.41	1608 0.39	1573 0.38	13	12	9
220	1900 0.49	1837 0.48	1804 0.47	1774 0.45	1742 0.42	1701 0.42	14	14	9
240	2054 0.53	1995 0.52	1947 0.51	1914 0.48	1877 0.46	1828 0.45	15	15	10
260	2208 0.57	2134 0.56	2091 0.55	2054 0.52	2011 0.49	1955 0.48	17	16	11
280	2361 1.01						18	18	12
300	2515 1.05						20	19	12
320	2670 1.09	2580 1.08	2525 1.06	2474 1.02	2416 0.98	2338 0.98	21	20	13
340	2824 1.13	2730 1.12	2670 1.10	2615 1.06	2551 1.02	2466 1.01	22	22	14
360	2979 1.17	2879 1.16	2815 1.14	2755 1.09	2686 1.05	2593 1.04	24	23	14
380	3134 1.21	3029 1.20	2960 1.17	2896 1.13	2821 1.08	2721 1.07	25	24	15
400	3289 1.25	3179 1.23	3105 1.21	3037 1.16	2957 1.11	2849 1.10	26	26	16
420	3444 1.29	3329 1.27	3251 1.25	3178 1.20	3092 1.14	2977 1.13	28	27	17
440	3599 1.33	3479 1.31	3396 1.29	3319 1.23	3227 1.18	3105 1.17	29	28	17
460	3755 1.37	3629 1.35	3542 1.32	3461 1.27	3362 1.21	3233 1.20	31	30	18
480	3911 1.41	3780 1.39	3688 1.36	3602 1.30	3498 1.24	3361 1.23	32	31	19
500	4067 1.45	3931 1.43	3834 1.40	3744 1.33	3653 1.27	3489 1.26	33	32	19
LOW AIR CONDITIONING ΔFUEL = - 0.3 %		ENGINE ANTI ICE ON ΔFUEL = + 2 %				TOTAL ANTI ICE ON ΔFUEL = + 5 %			

- Convert the ground distance to air distance.  
(Refer to PER-OPD-CON-AEO GENERAL for conversion).  
On this leg, the average wind is zero. Therefore, the air distance equals the ground distance.
- Enter the table with the air distance and desired flight level to obtain time, trip fuel, and fuel correction.

(Refer to *PER-FPL-FLP-ALN-20 GENERAL* for actual table).

For 200 NM air distance at FL 200, the table provides 0 h 38 min, 1 573 kg and 9 kg/1 000 kg.

- c. Calculate the fuel burn correction regarding the estimated landing weight at the alternate airport.

Table reference weight : 55 000 kg

Estimated landing weight : 61 200 kg

Fuel correction 9 kg per 1 000 kg difference

The extra fuel burn is  $(61.2 - 55.0) \times 9 = 56$  kg.

- d. Calculate the total trip fuel from destination to alternate.

Trip fuel :  $1\ 573 + 56 = 1\ 629$  kg

The estimated landing weight at destination is  $61\ 200 + 1\ 629 = 62\ 829$  kg.

3. Determine time, trip fuel, and fuel correction for the leg from departure to destination airport at M 0.78:

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING										
CLIMB : 250KT/300KT/M.78 - CRUISE : M.78 - DESCENT : M.78/300KT/250KT										
IMC PROCEDURE : 120 KG (6MIN)										
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING				CG = 33.0 %		TIME (H.MIN)				
ANTI-ICING OFF						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)				
AIR DIST. (NM)	FLIGHT LEVEL									
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390	
1450	8794 3.22	8379 3.23	8063 3.25	7792 3.26	589 3.27	7563 3.27	46	67	103	
1475	8940 3.25	8518 3.26	8196 3.28	7919 3.29	693 3.30	7689 3.30	47	68	105	
1500	9085 3.28	8657 3.30	8328 3.31	8046 3.33	816 3.34	7814 3.34	48	69	107	
1525	9231 3.32	8795 3.33	8461 3.35	8174 3.36	939 3.37	7940 3.37	49	71	109	
1550	9377 3.35	8943 3.36	8594 3.38	8301 3.39	1063 3.40	8067 3.40	50	72	111	
1575	9523 3.38	9073 3.40	8727 3.41	8429 3.43	1187 3.44	8193 3.44	51	73	113	
1600	9669 3.41	9213 3.43	8861 3.45	8557 3.46	1311 3.47	8320 3.47	50	74	115	
1625	9815 3.45	9352 3.46	8994 3.48	8685 3.50	1435 3.50	8447 3.50	52	75	117	
1650	9962 3.48	9492 3.49	9128 3.51	8813 3.53	1559 3.54	8575 3.54	53	76	119	
1675	DO NOT USE FOR OPERATIONAL PURPOSE					1683	8703	54	78	121
1700						1808	8831	55	79	123
1725	10401 3.58	9911 3.59	9530 4.01	9198 4.03	1933 4.04	8959 4.04	56	80	125	
1750	10548 4.01	10051 4.03	9664 4.04	9326 4.06	2058 4.07	9087 4.07	57	81	127	
1775	10695 4.04	10191 4.06	9798 4.08	9455 4.10	2183 4.11	9216 4.11	58	82	129	
1800	10842 4.07	10332 4.09	9933 4.11	9584 4.13	2309 4.14	9345 4.14	59	84	132	
1825	10988 4.11	10472 4.12	10068 4.14	9713 4.16	2436 4.17	9475 4.17	60	85	134	
1850	11135 4.14	10613 4.16	10203 4.18	9842 4.20	2563 4.21	9605 4.21	61	86	136	
1875	11282 4.17	10754 4.19	10338 4.21	9972 4.23	2691 4.24	9747 4.24	62	87	138	
1900	11430 4.20	10895 4.22	10473 4.24	10101 4.26	2819 4.27	9877 4.27	63	89	140	
1925	11577 4.24	11036 4.26	10608 4.28	10231 4.30	2948 4.31	10006 4.31	64	90	142	
1950	11724 4.27	11177 4.29	10744 4.31	10361 4.33	3076 4.34	10136 4.34	65	91	144	
1975	11872 4.30	11318 4.32	10879 4.34	10491 4.36	3205 4.37	10266 4.38	66	93	146	
2000	12019 4.33	11460 4.35	11015 4.38	10621 4.40	3334 4.41	10396 4.41	67	94	149	
2025	12167 4.37	11601 4.39	11151 4.41	10751 4.43	3463 4.44	10526 4.44	68	95	151	
2050	12314 4.40	11743 4.42	11287 4.44	10881 4.46	3592 4.48	10657 4.48	70	97	153	
2075	12462 4.43	11885 4.45	11424 4.48	11012 4.50	3721 4.51	10787 4.51	71	98	155	
LOW AIR CONDITIONING				ENGINE ANTI ICE ON			TOTAL ANTI ICE ON			
ΔFUEL = - 0.4 %				ΔFUEL = + 3 %			ΔFUEL = + 5.5 %			

a. Convert the ground distance to air distance.

(Refer to PER-OPD-CON-AEO GENERAL for conversion).

For 1 800 NM ground distance and 40 kt headwind at M 0.78, the interpolation from the table provides 1 979 NM air distance.

- b. Enter the table with the air distance and desired flight level to obtain time, trip fuel, and fuel correction.  
(Refer to *PER-FPL-FLP-QFP-40 FLIGHT PLANNING M.78* for actual M 0.78 table).  
For 1 979 NM air distance at FL 370, the interpolation from the M 0.78 table provides 4 h 38 min, 10 226 kg and 146 kg/10 000 kg.
- c. Calculate the fuel burn correction regarding the estimated landing weight at the destination airport.  
Table reference weight : 55 000 kg  
Estimated landing weight : 62 829 kg  
Fuel correction 146 kg per 1 000 kg difference  
The extra fuel burn is  $(62.829 - 55) \times 146 = 1 143$  kg.
- d. Calculate the total trip fuel from departure to destination.  
Trip fuel :  $10 226 + 1 143 = 11 369$  kg
4. Determine the contingency (reserve) fuel.  
(Refer to company policy for fuel reserve value).  
The five percent of the departure - destination trip fuel is:  
 $11 369 \times 0.05 = 568$  kg.
5. Determine the taxi fuel at departure.  
(Refer to *PER-FPL-GEN-MFR MINIMUM RECOMMENDED FUEL REQUIREMENTS* for actual taxi fuel).  
For the example, the conservative value of 140 kg (12 min taxi time) is chosen.
6. Calculate the final block fuel.
- |  |           |
|--|-----------|
| - 30 min holding at alternate (1 500 ft AGL) | 1 200 kg  |
| - Trip fuel to alternate                     | 1 629 kg  |
| - Trip fuel to destination                   | 11 369 kg |
| - Contingency (reserve) fuel                 | 568 kg    |
| - Taxi fuel                                  | 140 kg    |
| Total block fuel                             | 14 906 kg |
| Block weight                                 | 74 906 kg |



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

**FLIGHT PLANNING AT A GIVEN MACH NUMBER**

**FLIGHT PLANNING M.78**

Ident.: PER-FPL-FLP-QFP-40-00001830.0024001 / 25 FEB 11

Applicable to: ALL

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : M.78 - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING				CG = 33.0 %					
ANTI-ICING OFF				TIME (H.MIN)					
AIR DIST. (NM)	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>200</b>	1628 0.38	1616 0.38	1610 0.38	1610 0.38			13	15	
<b>225</b>	1775 0.42	1754 0.42	1741 0.42	1734 0.42	1734 0.42		13	16	17
<b>250</b>	1921 0.45	1892 0.45	1871 0.45	1858 0.45	1853 0.45	1855 0.45	14	17	19
<b>275</b>	2068 0.48	2030 0.48	2002 0.48	1982 0.48	1972 0.49	1972 0.49	15	18	21
<b>300</b>	2215 0.51	2188 0.52	2132 0.52	2107 0.52	2092 0.52	2089 0.52	15	19	22
<b>325</b>	2361 0.55	2306 0.55	2263 0.55	2231 0.55	2211 0.55	2206 0.55	16	19	24
<b>350</b>	2508 0.58	2444 0.58	2394 0.58	2355 0.58	2331 0.59	2324 0.59	16	20	25
<b>375</b>	2655 1.01	2583 1.01	2525 1.02	2480 1.02	2451 1.02	2441 1.02	17	21	27
<b>400</b>	2802 1.04	2721 1.05	2656 1.05	2605 1.05	2571 1.05	2559 1.05	18	22	28
<b>425</b>	2950 1.08	2860 1.08	2787 1.08	2730 1.09	2691 1.09	2677 1.09	18	23	29
<b>450</b>	3097 1.11	2998 1.11	2918 1.12	2855 1.12	2811 1.12	2795 1.12	19	24	31
<b>475</b>	3244 1.14	3137 1.15	3050 1.15	2980 1.15	2932 1.15	2913 1.15	20	25	32
<b>500</b>	3391 1.17	3276 1.18	3181 1.18	3105 1.19	3052 1.19	3032 1.19	20	26	34
<b>525</b>	3539 1.21	3415 1.21	3312 1.21	3230 1.22	3173 1.22	3151 1.22	21	27	36
<b>550</b>	3687 1.24	3554 1.24	3444 1.25	3355 1.25	3294 1.25	3269 1.25	22	28	37
<b>575</b>	3834 1.27	3693 1.28	3576 1.28	3481 1.29	3415 1.29	3389 1.29	22	29	39
<b>600</b>	3982 1.30	3832 1.31	3708 1.31	3607 1.32	3536 1.32	3508 1.32	23	30	41
<b>625</b>	4130 1.34	3971 1.34	3840 1.35	3732 1.35	3657 1.36	3627 1.36	24	31	42
<b>650</b>	4278 1.37	4111 1.38	3972 1.38	3858 1.39	3779 1.39	3747 1.39	25	32	44
<b>675</b>	4426 1.40	4250 1.41	4104 1.41	3984 1.42	3900 1.42	3867 1.42	25	33	46
<b>700</b>	4574 1.43	4390 1.44	4236 1.45	4110 1.45	4022 1.46	3987 1.46	26	34	48
<b>725</b>	4722 1.47	4530 1.47	4369 1.48	4237 1.49	4144 1.49	4107 1.49	27	35	49
<b>750</b>	4870 1.50	4670 1.51	4501 1.51	4363 1.52	4267 1.52	4228 1.52	27	36	51
<b>775</b>	5019 1.53	4810 1.54	4634 1.55	4490 1.55	4389 1.56	4349 1.56	28	37	53
<b>800</b>	5167 1.57	4950 1.57	4767 1.58	4617 1.59	4512 1.59	4471 1.59	29	38	55
<b>825</b>	5316 2.00	5090 2.01	4900 2.01	4744 2.02	4634 2.02	4592 2.02	29	39	56
<b>LOW AIR CONDITIONING</b>				<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>		
ΔFUEL = -0.5 %				ΔFUEL = + 2 %			ΔFUEL = + 4.5 %		

FUP23D A320 214 CFM56 5B4P SA3420 03301.000011 0250300 7800 .00200 120 0300350 55 0 100100 40100 18580 FCOM:02 05 40 003 180



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

<b>FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING</b> <b>CLIMB : 250KT/300KT/M.78 - CRUISE = M.78 - DESCENT : M.78/300KT/250KT</b> <b>IMC PROCEDURE : 120 KG (6MIN)</b>									
REF. LANDING WEIGHT = 55000 KG			ISA			FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING			CG = 33.0 %			TIME (H.MIN)			
ANTI-ICING OFF						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
AIR DIST. (NM)	FLIGHT LEVEL								
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>825</b>	5316 2.00	5090 2.01	4900 2.01	4744 2.02	4634 2.02	4592 2.02	29	39	56
<b>850</b>	5464 2.03	5231 2.04	5033 2.05	4871 2.05	4757 2.06	4714 2.06	30	40	58
<b>875</b>	5613 2.06	5371 2.07	5166 2.08	4998 2.09	4880 2.09	4836 2.09	31	41	60
<b>900</b>	5762 2.10	5512 2.10	5299 2.11	5125 2.12	5004 2.13	4958 2.13	32	42	62
<b>925</b>	5911 2.13	5652 2.14	5433 2.15	5253 2.15	5127 2.16	5080 2.16	32	43	63
<b>950</b>	6060 2.16	5793 2.17	5566 2.18	5380 2.19	5251 2.19	5203 2.19	33	44	65
<b>975</b>	6209 2.19	5934 2.20	5700 2.21	5508 2.22	5374 2.23	5326 2.23	34	45	67
<b>1000</b>	6358 2.23	6075 2.24	5833 2.24	5636 2.25	5498 2.26	5449 2.26	35	46	69
<b>1025</b>	6507 2.26	6216 2.27	5967 2.28	5763 2.29	5622 2.29	5572 2.29	35	47	71
<b>1050</b>	6657 2.29	6357 2.30	6101 2.31	5892 2.32	5746 2.33	5695 2.33	36	48	73
<b>1075</b>	6806 2.32	6498 2.33	6235 2.34	6020 2.35	5871 2.36	5819 2.36	37	49	74
<b>1100</b>	6955 2.36	6639 2.37	6369 2.38	6148 2.39	5995 2.39	5943 2.39	38	50	76
<b>1125</b>	7105 2.39	6781 2.40	6503 2.41	6276 2.42	6120 2.43	6067 2.43	38	51	78
<b>1150</b>	7255 2.42	6923 2.43	6638 2.44	6405 2.45	6245 2.46	6191 2.46	39	52	80
<b>1175</b>	7405 2.45	7064 2.47	6772 2.48	6534 2.49	6370 2.49	6316 2.49	40	53	82
<b>1200</b>	7555 2.49	7206 2.50	6907 2.51	6662 2.52	6495 2.53	6441 2.53	41	55	84
<b>1225</b>	7705 2.52	7348 2.53	7041 2.54	6791 2.56	6621 2.56	6566 2.56	41	56	86
<b>1250</b>	7855 2.55	7490 2.56	7176 2.58	6921 2.59	6746 3.00	6691 3.00	42	57	87
<b>1275</b>	8005 2.58	7632 3.00	7311 3.01	7050 3.02	6872 3.03	6817 3.03	43	58	89
<b>1300</b>	8155 3.02	7775 3.03	7446 3.04	7179 3.06	6998 3.06	6943 3.06	44	59	91
<b>1325</b>	8305 3.05	7917 3.06	7582 3.08	7309 3.09	7124 3.10	7069 3.10	45	60	93
<b>1350</b>	8456 3.08	8059 3.10	7717 3.11	7439 3.12	7251 3.13	7195 3.13	45	61	95
<b>1375</b>	8606 3.12	8202 3.13	7852 3.14	7569 3.16	7377 3.16	7322 3.16	46	63	97
<b>1400</b>	8757 3.15	8345 3.16	7988 3.18	7699 3.19	7504 3.20	7449 3.20	47	64	99
<b>1425</b>	8908 3.18	8488 3.19	8124 3.21	7829 3.22	7631 3.23	7576 3.23	48	65	101
<b>1450</b>	9059 3.21	8630 3.23	8259 3.24	7959 3.26	7758 3.26	7704 3.26	49	66	103
<b>LOW AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %			ΔFUEL = + 2 %			ΔFUEL = + 4.5 %			

FLIP23D A320-214 CFM56-5B4/P SA3420 03301.000011 0250300 .7800 .00200 120 0300350 55 0 100100 40100 18590 FCOM.02.05.40.004-180



FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : M.78 - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG			ISA		FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING			CG = 33.0 %		TIME (H.MIN)				
ANTHICING OFF			CORRECTION ON FUEL CONSUMPTION (KG/1000KG)						
AIR	FLIGHT LEVEL						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)		
DIST.							FL290	FL330	FL370
(NM)	290	310	330	350	370	390	FL310	FL350	FL390
<b>1450</b>	9059 3.21	8630 3.23	8259 3.24	7959 3.26	7758 3.26	7704 3.26	49	66	103
<b>1475</b>	9210 3.25	8773 3.26	8395 3.27	8089 3.29	7885 3.30	7832 3.30	49	67	105
<b>1500</b>	9361 3.28	8917 3.29	8531 3.31	8220 3.32	8013 3.33	7944 3.33*	50	68	107
<b>1525</b>	9512 3.31	9060 3.33	8668 3.34	8351 3.36	8141 3.37	8074 3.37*	51	70	109
<b>1550</b>	9664 3.34	9203 3.36	8804 3.37	8481 3.39	8268 3.40	8205 3.40*	52	71	111
<b>1575</b>	9815 3.38	9347 3.39	8940 3.41	8612 3.42	8396 3.43	8336 3.43*	53	72	113
<b>1600</b>	9967 3.41	9490 3.42	9077 3.44	8744 3.46	8525 3.47	8467 3.47*	53	73	115
<b>1625</b>	10119 3.44	9634 3.46	9214 3.47	8875 3.49	8653 3.50	8598 3.50*	54	74	117
<b>1650</b>	10271 3.47	9778 3.49	9351 3.51	9006 3.52	8782 3.53	8730 3.53*	55	76	119
<b>1675</b>	10423 3.51	9922 3.52	9498 3.54	9138 3.56	8910 3.57	8862 3.57*	56	77	121
<b>1700</b>	10575 3.54	10066 3.56	9625 3.57	9270 3.59	9039 4.00	8993 4.00*	57	78	123
<b>1725</b>	10727 3.57	10210 3.59	9762 4.01	9402 4.02	9168 4.03	9125 4.03*	58	79	125
<b>1750</b>	10880 4.00	10354 4.02	9900 4.04	9534 4.06	9298 4.07	9257 4.07*	59	81	127
<b>1775</b>	11032 4.04	10499 4.05	10038 4.07	9667 4.09	9427 4.10	9390 4.10*	59	82	129
<b>1800</b>	11185 4.07	10643 4.09	10176 4.11	9800 4.12	9558 4.13	9522 4.13*	60	83	131
<b>1825</b>	11337 4.10	10798 4.12	10314 4.14	9933 4.16	9689 4.17	9655 4.17*	61	84	133
<b>1850</b>	11490 4.13	10932 4.15	10452 4.17	10066 4.19	9820 4.20	9788 4.20*	62	86	135
<b>1875</b>	11643 4.17	11077 4.19	10590 4.21	10199 4.22	9951 4.24	9921 4.23*	63	87	137
<b>1900</b>	11796 4.20	11222 4.22	10729 4.24	10333 4.26	10082 4.27	10054 4.27*	64	88	139
<b>1925</b>	11949 4.23	11367 4.25	10867 4.27	10466 4.29	10214 4.30	10188 4.30*	65	90	141
<b>1950</b>	12102 4.26	11512 4.28	11006 4.30	10600 4.33	10346 4.34	10321 4.33*	66	91	144
<b>1975</b>	12255 4.30	11658 4.32	11145 4.34	10734 4.36	10478 4.37	10455 4.37*	66	92	146
<b>2000</b>	12408 4.33	11803 4.35	11283 4.37	10868 4.39	10610 4.40	10589 4.40*	67	94	148
<b>2025</b>	12562 4.36	11948 4.38	11423 4.40	11002 4.43	10742 4.44	10723 4.44*	68	95	150
<b>2050</b>	12716 4.40	12094 4.42	11562 4.44	11137 4.46	10875 4.47	10858 4.47*	69	97	152
<b>2075</b>	12869 4.43	12240 4.45	11701 4.47	11271 4.49	11008 4.50	10992 4.50*	70	98	155
<b>LOW AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %			ΔFUEL = + 2 %			ΔFUEL = + 4.5 %			

FLIP23D A320-214 CFM56-584/P SA3420 03301.000011 0250300.7800.00200 120 0300350 55 0 100100 40100 18590 FCOM-02-05-40-005-180



FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : M.78 - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING				CG = 33.0 %		TIME (H.MIN)			
ANTI-ICING OFF				CORRECTION ON FUEL CONSUMPTION (KG/1000KG)					
AIR DIST. (NM)	FLIGHT LEVEL								
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>2075</b>	12869 4.43	12240 4.45	11701 4.47	11271 4.49	11008 4.50	10992 4.50*	70	98	155
<b>2100</b>	13023 4.46	12386 4.48	11840 4.50	11406 4.53	11141 4.54	11127 4.54*	71	99	157
<b>2125</b>	13177 4.49	12532 4.51	11980 4.54	11541 4.56	11275 4.57	11262 4.57*	72	101	159
<b>2150</b>	13321 4.53	12678 4.55	12120 4.57	11676 4.59	11408 5.01	11397 5.00*	73	102	161
<b>2175</b>	13485 4.56	12824 4.58	12260 5.00	11811 5.03	11542 5.04	11532 5.04*	74	104	163
<b>2200</b>	13640 4.59	12970 5.01	12400 5.04	11947 5.06	11676 5.07	11667 5.07*	75	105	165
<b>2225</b>	13794 5.02	13117 5.05	12540 5.07	12082 5.09	11810 5.11	11803 5.10*	76	107	168
<b>2250</b>	13948 5.06	13264 5.08	12680 5.10	12218 5.13	11945 5.14	11939 5.14*	77	108	170
<b>2275</b>	14103 5.09	13410 5.11	12821 5.14	12354 5.16	12080 5.17	12074 5.17*	78	109	172
<b>2300</b>	14258 5.12	13557 5.14	12962 5.17	12490 5.19	12214 5.21	12210 5.20*	79	111	174
<b>2325</b>	14412 5.15	13704 5.18	13102 5.20	12627 5.23	12350 5.24	12347 5.24*	80	112	177
<b>2350</b>	14567 5.19	13851 5.21	13243 5.24	12764 5.26	12485 5.27	12483 5.27*	81	114	179
<b>2375</b>	14723 5.22	13998 5.24	13384 5.27	12900 5.29	12621 5.31	12620 5.30*	81	115	181
<b>2400</b>	14878 5.25	14146 5.28	13526 5.30	13037 5.33	12758 5.34	12757 5.34*	82	117	183
<b>2425</b>	15034 5.28	14293 5.31	13667 5.33	13174 5.36	12894 5.37	12894 5.37*	83	119	186
<b>2450</b>	15190 5.32	14441 5.34	13808 5.37	13312 5.39	13031 5.41	13032 5.40*	84	120	188
<b>2475</b>	15346 5.35	14588 5.37	13950 5.40	13449 5.43	13168 5.44	13169 5.44*	85	122	190
<b>2500</b>	15502 5.38	14736 5.41	14092 5.43	13587 5.46	13305 5.48	13307 5.47*	86	123	192
<b>2525</b>	15658 5.41	14884 5.44	14234 5.47	13725 5.49	13442 5.51	13445 5.50*	87	125	195
<b>2550</b>	15815 5.45	15033 5.47	14376 5.50	13863 5.53	13580 5.54	13584 5.54*	88	126	197
<b>2575</b>	15971 5.48	15181 5.51	14518 5.53	14001 5.56	13718 5.58	13722 5.57*	89	128	199
<b>2600</b>	16128 5.51	15330 5.54	14660 5.57	14139 5.59	13856 6.01	13861 6.00*	90	129	201
<b>2625</b>	16284 5.55	15479 5.57	14803 6.00	14278 6.03	13994 6.04	14000 6.04*	91	131	204
<b>2650</b>	16441 5.58	15628 6.00	14946 6.03	14416 6.06	14133 6.08	14139 6.07*	92	133	206
<b>2675</b>	16598 6.01	15777 6.04	15089 6.07	14555 6.09	14271 6.11	14279 6.10*	93	134	209
<b>2700</b>	16755 6.04	15926 6.07	15232 6.10	14694 6.13	14410 6.14	14418 6.14*	94	136	211
<b>LOW AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %			ΔFUEL = + 2 %			ΔFUEL = + 4.5 %			

FLIP23D A320-214 CFM56-5B4/P SA3420 03301.000011 0250300 .7800 .00200 120 0300350 55 0 100100 40100 18590 FCOM.02.05.40.006-180

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : M.78 - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG			ISA		FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING			CG = 33.0 %		TIME (H.MIN)				
ANTHICING OFF			FLIGHT LEVEL				CORRECTION ON FUEL CONSUMPTION (KG/1000KG)		
AIR							FL290	FL330	FL370
DIST.							FL310	FL350	FL390
(NM)	290	310	330	350	370	390			
<b>2700</b>	16755 6.04	15926 6.07	15232 6.10	14694 6.13	14410 6.14	14418 6.14*	94	136	211
<b>2725</b>	16912 6.08	16076 6.10	15375 6.13	14833 6.16	14550 6.18	14558 6.17*	95	137	214
<b>2750</b>	17070 6.11	16225 6.14	15519 6.17	14973 6.20	14689 6.21	14698 6.20*	96	139	216
<b>2775</b>	17227 6.14	16375 6.17	15663 6.20	15113 6.23	14829 6.25	14838 6.24*	97	141	218
<b>2800</b>	17385 6.17	16525 6.20	15807 6.23	15254 6.26	14969 6.28	14979 6.27*	99	142	220
<b>2825</b>	17542 6.21	16675 6.24	15951 6.27	15395 6.30	15109 6.31	15119 6.31*	100	144	222
<b>2850</b>	17700 6.24	16825 6.27	16095 6.30	15535 6.33	15251 6.35	15260 6.34*	101	146	225
<b>2875</b>	17858 6.27	16975 6.30	16240 6.33	15677 6.36	15393 6.38	15402 6.37*	102	148	227
<b>2900</b>	18016 6.30	17125 6.33	16384 6.36	15818 6.40	15535 6.41	15543 6.41*	103	150	229
<b>2925</b>	18175 6.34	17275 6.37	16529 6.40	15960 6.43	15675 6.45*	15685 6.44*	104	151	231
<b>2950</b>	18333 6.37	17426 6.40	16674 6.43	16101 6.46	15820 6.48*	15827 6.47*	105	153	234
<b>2975</b>	18492 6.40	17577 6.43	16819 6.46	16243 6.50	15964 6.52*	15969 6.51*	106	155	236
<b>3000</b>	18650 6.43	17727 6.47	16964 6.50	16385 6.53	16109 6.55*	16112 6.54*	107	157	238
<b>3025</b>	18809 6.47	17878 6.50	17109 6.53	16528 6.56	16255 6.58*	16254 6.57*	108	159	240
<b>3050</b>	18968 6.50	18030 6.53	17255 6.56	16670 7.00	16400 7.01*	16397 7.01*	109	161	243
<b>3075</b>	19127 6.53	18181 6.56	17401 7.00	16813 7.03	16545 7.05*	16540 7.04*	110	162	245
<b>3100</b>	19286 6.56	18333 7.00	17546 7.03	16956 7.06	16691 7.08*	16683 7.07*	111	164	247
LOW AIR CONDITIONING			ENGINE ANTI ICE ON				TOTAL ANTI ICE ON		
ΔFUEL = -0.5 %			ΔFUEL = + 2 %				ΔFUEL = + 4.5 %		

FLP230 A320-214 CFM56-5B4/P SA3420 03301 033011 0250300 .7800 .00200 120 0300350 55 0 100100 40100 18590 FCOM-02-05-40-007-180



**A318/A319/A320/A321**

FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

FLIGHT PREPARATION - QUICK DETERMINATION OF FLIGHT PLANNING

**FLIGHT PLANNING AT LONG RANGE SPEED**

**FLIGHT PLANNING LRC**

Ident.: PER-FPL-FLP-QFP-50-00001831.0071001 / 17 MAR 11

Applicable to: ALL

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING				CG = 33.0 %					
ANTI-ICING OFF				TIME (H.MIN)					
AIR DIST. (NM)	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>200</b>	1599 0.39	1602 0.39	1605 0.39	1609 0.38			15	16	
<b>225</b>	1732 0.43	1731 0.43	1730 0.42	1731 0.42	1733 0.42		16	17	18
<b>250</b>	1865 0.47	1860 0.46	1855 0.46	1852 0.45	1852 0.45	1855 0.45	18	19	20
<b>275</b>	1998 0.51	1999 0.50	1980 0.49	1974 0.49	1971 0.49	1973 0.48	19	20	21
<b>300</b>	2132 0.54	2118 0.54	2105 0.53	2096 0.52	2090 0.52	2090 0.52	20	21	23
<b>325</b>	2265 0.58	2247 0.57	2231 0.56	2218 0.56	2209 0.55	2208 0.55	22	23	25
<b>350</b>	2399 1.02	2377 1.01	2357 1.00	2341 0.99	2329 0.99	2325 0.99	23	24	26
<b>375</b>	2532 1.06	2507 1.05	2483 1.04	2463 1.03	2448 1.02	2443 1.02	24	26	28
<b>400</b>	2666 1.09	2637 1.08	2609 1.07	2586 1.06	2568 1.06	2562 1.05	25	27	30
<b>425</b>	2801 1.13	2767 1.12	2735 1.11	2708 1.10	2688 1.09	2680 1.09	27	28	31
<b>450</b>	2935 1.17	2897 1.16	2861 1.14	2831 1.13	2808 1.12	2798 1.12	28	30	33
<b>475</b>	3069 1.21	3027 1.19	2988 1.18	2954 1.17	2928 1.16	2917 1.15	29	31	35
<b>500</b>	3204 1.24	3158 1.23	3114 1.21	3078 1.20	3048 1.19	3036 1.19	31	33	37
<b>525</b>	3339 1.28	3289 1.26	3241 1.25	3201 1.23	3169 1.22	3155 1.22	32	34	38
<b>550</b>	3474 1.32	3420 1.30	3368 1.28	3325 1.27	3290 1.26	3275 1.25	33	36	40
<b>575</b>	3609 1.36	3551 1.34	3496 1.32	3448 1.30	3411 1.29	3394 1.29	35	37	42
<b>600</b>	3744 1.39	3682 1.37	3623 1.35	3572 1.34	3532 1.32	3514 1.32	36	38	44
<b>625</b>	3880 1.43	3813 1.41	3750 1.39	3696 1.37	3653 1.36	3634 1.35	38	40	46
<b>650</b>	4016 1.47	3945 1.45	3878 1.42	3821 1.41	3774 1.39	3754 1.39	39	41	48
<b>675</b>	4152 1.50	4076 1.48	4006 1.46	3945 1.44	3896 1.43	3875 1.42	40	43	49
<b>700</b>	4288 1.54	4208 1.52	4134 1.49	4070 1.47	4018 1.46	3996 1.45	42	44	51
<b>725</b>	4424 1.58	4340 1.55	4262 1.53	4194 1.51	4140 1.49	4117 1.49	43	46	53
<b>750</b>	4561 2.02	4473 1.59	4391 1.56	4319 1.54	4262 1.53	4238 1.52	44	47	55
<b>775</b>	4697 2.05	4605 2.03	4520 2.00	4445 1.98	4385 1.96	4360 1.95	46	48	57
<b>800</b>	4834 2.09	4738 2.06	4648 2.03	4570 2.01	4507 1.99	4482 1.99	47	50	59
<b>825</b>	4971 2.13	4870 2.10	4777 2.07	4696 2.05	4630 2.03	4604 2.02	48	51	60
<b>LOW AIR CONDITIONING</b>				<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>		
ΔFUEL = -0.5 %				ΔFUEL = + 2.5 %			ΔFUEL = + 5 %		

FPL23D A320 214 CFM56 584P SA3420 03301.000011 0250300 .7801 .00200 120 0300350 55 0 100100 40100 18580 FCOM:02:05:40:008:180

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING				CG = 33.0 %		TIME (H.MIN)			
ANTI-ICING OFF						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
AIR DIST. (NM)	FLIGHT LEVEL								
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>825</b>	4971 2.13	4870 2.10	4777 2.07	4696 2.05	4630 2.03	4604 2.02	48	51	60
<b>850</b>	5108 2.16	5003 2.13	4907 2.10	4821 2.08	4753 2.06	4726 2.05	50	53	62
<b>875</b>	5246 2.20	5137 2.17	5036 2.14	4947 2.11	4876 2.09	4849 2.09	51	54	64
<b>900</b>	5383 2.24	5270 2.21	5166 2.17	5073 2.15	5000 2.13	4971 2.12	53	56	66
<b>925</b>	5521 2.27	5403 2.24	5295 2.21	5200 2.18	5123 2.16	5094 2.15	54	57	68
<b>950</b>	5659 2.31	5537 2.28	5425 2.24	5326 2.22	5247 2.20	5218 2.19	55	59	70
<b>975</b>	5797 2.35	5671 2.31	5555 2.28	5453 2.25	5371 2.23	5341 2.22	57	60	72
<b>1000</b>	5936 2.38	5805 2.35	5686 2.31	5580 2.28	5495 2.26	5465 2.25	58	62	74
<b>1025</b>	6074 2.42	5939 2.38	5816 2.35	5707 2.32	5620 2.30	5589 2.29	60	63	75
<b>1050</b>	6213 2.46	6073 2.42	5947 2.38	5834 2.35	5744 2.33	5713 2.32	61	65	77
<b>1075</b>	6352 2.49	6207 2.46	6077 2.42	5961 2.39	5869 2.36	5837 2.35	62	66	79
<b>1100</b>	6491 2.53	6342 2.49	6208 2.45	6089 2.42	5994 2.40	5962 2.39	64	67	81
<b>1125</b>	6630 2.57	6477 2.53	6340 2.49	6217 2.45	6119 2.43	6087 2.42	65	69	83
<b>1150</b>	6770 3.00	6612 2.56	6471 2.52	6345 2.49	6244 2.46	6212 2.45	67	70	85
<b>1175</b>	6910 3.04	6747 3.00	6603 2.56	6473 2.52	6370 2.50	6337 2.49	68	72	87
<b>1200</b>	7049 3.08	6883 3.03	6734 2.59	6601 2.55	6495 2.53	6463 2.52	69	73	89
<b>1225</b>	7190 3.11	7018 3.07	6866 3.02	6729 2.59	6621 2.56	6589 2.55	71	75	91
<b>1250</b>	7330 3.15	7154 3.10	6999 3.06	6858 3.02	6747 3.00	6715 2.99	72	76	93
<b>1275</b>	7470 3.18	7290 3.14	7131 3.09	6987 3.06	6874 3.03	6841 3.02	74	78	95
<b>1300</b>	7611 3.22	7426 3.18	7264 3.13	7116 3.09	7000 3.06	6968 3.05	75	79	97
<b>1325</b>	7752 3.26	7562 3.21	7396 3.16	7246 3.12	7127 3.10	7095 3.09	77	81	99
<b>1350</b>	7893 3.29	7699 3.25	7529 3.20	7375 3.16	7254 3.13	7223 3.12	78	83	101
<b>1375</b>	8035 3.33	7836 3.28	7663 3.23	7505 3.19	7381 3.16	7350 3.15	80	84	103
<b>1400</b>	8176 3.37	7973 3.32	7796 3.26	7635 3.22	7509 3.20	7478 3.19	81	86	105
<b>1425</b>	8318 3.40	8110 3.35	7930 3.30	7765 3.26	7637 3.23	7606 3.22	82	87	107
<b>1450</b>	8460 3.44	8247 3.39	8063 3.33	7896 3.29	7764 3.26	7735 3.25	84	89	109
<b>LOW AIR CONDITIONING</b>				<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %				ΔFUEL = + 2.5 %		ΔFUEL = + 5 %			

FLIP23D A320-214 CFM56-5B4/P SA3420 03301.000011 0250300 .7801 .00200 120 0300350 55 0 100100 40100 18590 FCOM.02.05.40.009-180

<b>FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING</b>									
<b>CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE - DESCENT : M.78/300KT/250KT</b>									
<b>IMC PROCEDURE : 120 KG (6MIN)</b>									
REF. LANDING WEIGHT = 55000 KG			ISA		FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING			CG = 33.0 %		TIME (H.MIN)				
ANTHICING OFF			CORRECTION ON FUEL CONSUMPTION (KG/1000KG)						
AIR DIST. (NM)	FLIGHT LEVEL								
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390
<b>1450</b>	8460 3.44	8247 3.39	8063 3.33	7896 3.29	7764 3.26	7735 3.25	84	89	109
<b>1475</b>	8502 3.47	8394 3.42	8197 3.37	8026 3.32	7892 3.30	7863 3.29	85	90	111
<b>1500</b>	8744 3.51	8522 3.46	8332 3.40	8157 3.36	8021 3.33	7990 3.32*	87	92	113
<b>1525</b>	8887 3.55	8660 3.49	8466 3.43	8289 3.39	8149 3.36	8121 3.35*	88	93	115
<b>1550</b>	9029 3.58	8798 3.53	8600 3.47	8419 3.42	8278 3.40	8251 3.39*	90	95	117
<b>1575</b>	9172 4.02	8936 3.56	8735 3.50	8550 3.46	8407 3.43	8400 3.42*	91	96	119
<b>1600</b>	9315 4.05	9075 4.00	8870 3.54	8682 3.49	8536 3.46	8513 3.45*	93	98	121
<b>1625</b>	9458 4.09	9213 4.03	9005 3.57	8813 3.52	8665 3.50	8644 3.49*	94	100	123
<b>1650</b>	9601 4.12	9352 4.07	9141 4.00	8945 3.56	8795 3.53	8775 3.52*	96	101	125
<b>1675</b>	9745 4.16	9491 4.10	9276 4.04	9078 3.59	8924 3.56	8907 3.55*	97	103	127
<b>1700</b>	9888 4.20	9630 4.14	9411 4.07	9210 4.02	9054 3.59	9039 3.59*	99	104	129
<b>1725</b>	10032 4.23	9770 4.17	9546 4.11	9342 4.06	9185 4.03	9170 4.02*	100	106	131
<b>1750</b>	10176 4.27	9910 4.21	9682 4.14	9474 4.09	9315 4.06	9303 4.05*	102	108	133
<b>1775</b>	10321 4.30	10050 4.24	9818 4.17	9607 4.12	9446 4.09	9435 4.09*	103	109	135
<b>1800</b>	10465 4.34	10190 4.27	9954 4.21	9740 4.16	9577 4.13	9567 4.12*	105	111	138
<b>1825</b>	10610 4.37	10330 4.31	10090 4.24	9873 4.19	9708 4.16	9700 4.15*	106	113	140
<b>1850</b>	10755 4.41	10470 4.34	10226 4.28	10006 4.22	9840 4.19	9833 4.19*	108	114	142
<b>1875</b>	10900 4.45	10611 4.38	10363 4.31	10140 4.26	9972 4.23	9966 4.22*	109	116	144
<b>1900</b>	11045 4.48	10752 4.41	10500 4.34	10273 4.29	10105 4.26	10100 4.26*	111	118	146
<b>1925</b>	11191 4.52	10893 4.45	10637 4.38	10407 4.32	10237 4.29	10233 4.29*	112	119	148
<b>1950</b>	11337 4.55	11034 4.48	10774 4.41	10541 4.36	10370 4.33	10367 4.32*	114	121	151
<b>1975</b>	11483 4.59	11176 4.52	10911 4.45	10675 4.39	10503 4.36	10501 4.36*	115	123	153
<b>2000</b>	11629 5.02	11318 4.55	11049 4.48	10810 4.42	10636 4.39	10635 4.39*	117	124	155
<b>2025</b>	11775 5.06	11460 4.58	11187 4.51	10944 4.46	10769 4.43	10769 4.42*	118	126	157
<b>2050</b>	11922 5.09	11602 5.02	11325 4.55	11079 4.49	10903 4.46	10904 4.46*	120	128	159
<b>2075</b>	12068 5.13	11744 5.05	11463 4.58	11214 4.52	11037 4.49	11039 4.49*	121	129	162
<b>LOW AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %			ΔFUEL = + 2.5 %			ΔFUEL = + 5 %			

FLIP23D A320-214 CFM56-584/P SA3420 03301.000011 0250300.7801 .00200 120 0300350 55 0 100100 40100 18590 FCOM-02-05-40-010-180



FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING									
CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)			
NORMAL AIR CONDITIONING				CG = 33.0 %		TIME (H.MIN)			
ANTI-ICING OFF						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
AIR	FLIGHT LEVEL								
DIST.						FL290	FL330	FL370	
(NM)	290	310	330	350	370	FL310	FL350	FL390	
<b>2075</b>	12068 5.13	11744 5.05	11463 4.58	11214 4.52	11037 4.49	11039 4.49*	121	129	162
<b>2100</b>	12215 5.16	11887 5.09	11601 5.01	11349 4.56	11171 4.53	11174 4.52*	123	131	164
<b>2125</b>	12363 5.20	12029 5.12	11739 5.05	11485 4.59	11306 4.56	11309 4.56*	124	133	166
<b>2150</b>	12510 5.23	12172 5.16	11978 5.08	11620 5.02	11440 4.59	11444 4.59*	126	134	168
<b>2175</b>	12658 5.27	12315 5.19	12017 5.11	11756 5.06	11575 5.03	11579 5.02*	127	136	170
<b>2200</b>	12806 5.30	12459 5.22	12156 5.15	11892 5.09	11710 5.06	11715 5.06*	129	138	173
<b>2225</b>	12954 5.34	12603 5.26	12295 5.18	12028 5.12	11846 5.09	11851 5.09*	130	139	175
<b>2250</b>	13102 5.37	12746 5.29	12435 5.22	12165 5.16	11981 5.13	11987 5.12*	132	141	177
<b>2275</b>	13251 5.41	12891 5.33	12575 5.25	12301 5.19	12117 5.16	12124 5.16*	134	143	179
<b>2300</b>	13400 5.44	13035 5.36	12715 5.28	12438 5.22	12253 5.19	12260 5.19*	135	145	181
<b>2325</b>	13549 5.48	13179 5.39	12855 5.32	12576 5.25	12390 5.23	12397 5.22*	137	146	184
<b>2350</b>	13698 5.51	13324 5.43	12996 5.35	12713 5.29	12527 5.26	12534 5.26*	138	148	186
<b>2375</b>	13848 5.55	13469 5.46	13136 5.38	12851 5.32	12664 5.29	12672 5.29*	140	150	188
<b>2400</b>	13997 5.58	13614 5.50	13277 5.42	12989 5.35	12801 5.33	12809 5.32*	141	152	190
<b>2425</b>	14147 6.02	13760 5.53	13418 5.45	13127 5.39	12939 5.36	12947 5.36*	143	153	193
<b>2450</b>	14297 6.05	13906 5.56	13559 5.48	13265 5.42	13077 5.39	13085 5.39*	144	155	195
<b>2475</b>	14448 6.09	14051 6.00	13701 5.52	13404 5.45	13215 5.43	13223 5.42*	146	157	197
<b>2500</b>	14598 6.12	14197 6.03	13842 5.55	13542 5.49	13354 5.46	13362 5.45*	148	159	199
<b>2525</b>	14748 6.16	14344 6.06	13984 5.58	13681 5.52	13492 5.49	13500 5.49*	149	161	201
<b>2550</b>	14898 6.19	14490 6.10	14126 6.02	13820 5.55	13631 5.53	13639 5.52*	151	162	204
<b>2575</b>	15048 6.22	14637 6.13	14269 6.05	13960 5.58	13770 5.56	13778 5.55*	152	164	206
<b>2600</b>	15199 6.26	14784 6.17	14411 6.08	14099 5.62	13910 5.59	13917 5.59*	154	166	208
<b>2625</b>	15350 6.29	14931 6.20	14554 6.11	14239 6.05	14050 6.03	14057 6.02*	156	168	211
<b>2650</b>	15501 6.33	15078 6.23	14697 6.15	14379 6.08	14190 6.06	14197 6.05*	157	170	213
<b>2675</b>	15652 6.36	15225 6.27	14840 6.18	14519 6.11	14330 6.09	14337 6.09*	159	171	215
<b>2700</b>	15804 6.40	15373 6.30	14984 6.21	14660 6.15	14471 6.13	14477 6.12*	160	173	217
<b>LOW AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %			ΔFUEL = + 2.5 %			ΔFUEL = + 5 %			

FLIP23D A320-214 CFM56-5B4/P SA3420 03301.000011 0250300 .7801 .00200 120 0300350 55 0 100100 40100 18590 FCOM.02.05.40.011-180

FLIGHT PLANNING FROM BRAKE RELEASE TO LANDING										
CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE - DESCENT : M.78/300KT/250KT										
IMC PROCEDURE : 120 KG (6MIN)										
REF. LANDING WEIGHT = 55000 KG			ISA		FUEL CONSUMED (KG)					
NORMAL AIR CONDITIONING			CG = 33.0 %		TIME (H.MIN)					
ANTHICING OFF			CORRECTION ON FUEL CONSUMPTION (KG/1000KG)							
AIR	FLIGHT LEVEL						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
DIST.							FL290	FL330	FL370	
(NM)	290	310	330	350	370	390	FL310	FL350	FL390	
<b>2700</b>	15804 6.40	15373 6.30	14984 6.21	14660 6.15	14471 6.13	14477 6.12*	180	173	217	
<b>2725</b>	15955 6.43	15521 6.33	15127 6.25	14801 6.18	14612 6.16	14618 6.15*	162	175	220	
<b>2750</b>	16107 6.47	15669 6.37	15272 6.28	14941 6.21	14753 6.19	14758 6.19*	164	177	222	
<b>2775</b>	16260 6.50	15818 6.40	15416 6.31	15082 6.25	14894 6.23	14899 6.22*	165	179	224	
<b>2800</b>	16412 6.53	15966 6.43	15561 6.35	15224 6.28	15036 6.26	15041 6.25*	167	181	226	
<b>2825</b>	16564 6.57	16115 6.47	15706 6.38	15366 6.31	15178 6.29	15182 6.29*	169	183	229	
<b>2850</b>	16717 7.00	16264 6.50	15851 6.41	15508 6.34	15321 6.33	15324 6.32*	170	184	231	
<b>2875</b>	16870 7.04	16413 6.53	15996 6.44	15650 6.38	15470 6.36*	15466 6.35*	172	186	233	
<b>2900</b>	17023 7.07	16563 6.57	16142 6.48	15792 6.41	15614 6.39*	15609 6.39*	174	188	235	
<b>2925</b>	17177 7.10	16713 7.00	16288 6.51	15935 6.44	15758 6.43*	15751 6.42*	175	190	238	
<b>2950</b>	17330 7.14	16863 7.03	16434 6.54	16078 6.48	15903 6.46*	15894 6.45*	177	192	240	
<b>2975</b>	17484 7.17	17013 7.07	16580 6.57	16221 6.51	16048 6.49*	16037 6.49*	179	194	242	
<b>3000</b>	17638 7.21	17163 7.10	16726 7.01	16364 6.54	16193 6.53*	16181 6.52*	180	196	245	
<b>3025</b>	17792 7.24	17314 7.13	16873 7.04	16508 6.58	16338 6.56*	16324 6.55*	182	198	247	
<b>3050</b>	17947 7.27	17465 7.16	17020 7.07	16652 7.01	16483 6.59*	16468 6.59*	184	200	249	
<b>3075</b>	18102 7.31	17616 7.20	17167 7.10	16796 7.04	16629 7.03*	16612 7.02*	185	202	252	
<b>3100</b>	18257 7.34	17767 7.23	17315 7.14	16940 7.07	16775 7.06*	16756 7.05*	187	204	254	
LOW AIR CONDITIONING			ENGINE ANTI ICE ON			TOTAL ANTI ICE ON				
ΔFUEL = -0.5 %			ΔFUEL = + 2.5 %			ΔFUEL = + 5 %				

FPL230 A320-214 CFM56-5B4/P SA3420 03301 030011 0250300 .7801 .00200 120 0300350 55 0 100100 40100 18590 FCOM-02-05-40-012-180



**ALL ENGINES OPERATIVE**

**GENERAL**

Ident.: PER-FPL-FLP-ALN-20-00001832.0009001 / 25 FEB 14

Applicable to: ALL

The alternate planning tables enable the flight crew to determine the fuel consumption and time required to cover a given air distance from go-around at destination airport to landing at alternate airport.

These tables are established for:

- Go-around: 100 kg or 220 lb
- Climb profile: 250 kt/300 kt/M .78
- Long range speed
- Descent profile: M .78/300 kt/250 kt
- Approach and landing at alternate airport: 80 kg or 180 lb (4 min)
- ISA
- CG = 33 %
- Normal air conditioning
- Anti ice OFF

Following tables have been calculated using databases for CFM 56-5-B /P. If the engines fitted on the aircraft are not /P or /3, the fuel consumption has to be increased by 3 %.

- Note:
1. In the tables, the asterisk (\*) means that a step climb of 4 000 ft must be flown to reach the corresponding flight level.
  2. The flight level shown on the top of each column is the final flight level.
  3. For each degree Celsius above ISA temperature apply a fuel correction of  
 $0.015 \text{ (kg/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air distance (NM)}$   
or  $0.033 \text{ (lb/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air distance (NM)}$

**CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT**

Ident.: PER-FPL-FLP-ALN-20-00001834.0001001 / 28 FEB 11

Applicable to: ALL

The alternate planning tables are based on a reference landing weight at alternate.

The fuel consumption must be corrected when the landing weight is different from the reference landing weight.

If it is lower (or greater) than the reference weight, subtract (or add) the value given in the correction part of the table per 1 000 kg or 1 000 lb below (or above) the reference weight.

**ALTERNATE PLANNING ISA**

Ident.: PER-FPL-FLP-ALN-20-00001833.0025001 / 02 MAR 11

Applicable to: ALL

ALTERNATE PLANNING FROM DESTINATION TO ALTERNATE AIRPORT GO-AROUND : 100 KG - CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE DESCENT : M.78/300KT/250KT - VMC PROCEDURE : 80 KG (4MIN)									
REF. LDG. WT AT ALTERNATE = 55000 KG NORMAL AIR CONDITIONING ANTI-CING OFF			ISA CG = 33.0 %			FUEL CONSUMED (KG)			
AIR DIST. (NM)	FLIGHT LEVEL						CORRECTION ON FUEL CONSUMPTION (KG/1000KG)		
	100	120	140	160	180	200	FL100 FL120	FL140 FL160	FL180 FL200
<b>20</b>									
<b>40</b>	522 0.12						2		
<b>60</b>	676 0.16	659 0.16	660 0.16				3	4	
<b>80</b>	831 0.19	807 0.20	802 0.20	801 0.19	805 0.19		5	5	5
<b>100</b>	986 0.23	955 0.23	943 0.23	937 0.23	934 0.23	937 0.22	6	5	6
<b>120</b>	1140 0.27	1103 0.27	1085 0.27	1072 0.26	1064 0.26	1061 0.26	7	6	7
<b>140</b>	1296 0.31	1251 0.31	1227 0.30	1208 0.30	1208 0.30	1193 0.29	8	7	8
<b>160</b>	1451 0.34	1400 0.34	1369 0.34	1344 0.33	1323 0.33	1309 0.33	9	8	9
<b>180</b>	1606 0.38	1548 0.38	1511 0.37	1480 0.37	1452 0.36	1434 0.36	10	9	10
<b>200</b>	1762 0.42	1697 0.42	1653 0.41	1616 0.40	1582 0.40	1559 0.40	11	10	11
<b>220</b>	1918 0.46	1846 0.45	1796 0.44	1752 0.44	1712 0.43	1684 0.43	12	11	12
<b>240</b>	2074 0.49	1995 0.49	1938 0.48	1889 0.47	1842 0.47	1809 0.46	13	12	12
<b>260</b>	2231 0.53	2144 0.53	2081 0.51	2025 0.51	1972 0.50	1934 0.50	14	13	13
<b>280</b>	2387 0.57	2294 0.56	2224 0.55	2162 0.54	2103 0.54	2059 0.53	15	14	14
<b>300</b>	2544 1.00	2443 1.00	2367 0.59	2299 0.57	2233 0.57	2184 0.57	16	15	15
<b>320</b>	2701 1.04	2593 1.04	2510 1.02	2436 1.01	2364 1.01	2310 1.00	17	16	16
<b>340</b>	2858 1.08	2743 1.07	2653 1.06	2573 1.04	2494 1.04	2435 1.04	18	16	17
<b>360</b>	3014 1.12	2893 1.11	2796 1.09	2710 1.08	2625 1.08	2561 1.07	19	17	18
<b>380</b>	3171 1.15	3043 1.14	2940 1.13	2847 1.11	2756 1.11	2687 1.11	20	18	19
<b>400</b>	3329 1.19	3193 1.18	3084 1.16	2984 1.15	2886 1.15	2813 1.14	21	19	20
<b>420</b>	3486 1.23	3343 1.22	3227 1.20	3122 1.18	3018 1.18	2939 1.17	22	20	21
<b>440</b>	3643 1.26	3494 1.25	3371 1.23	3259 1.22	3149 1.22	3065 1.21	23	21	22
<b>460</b>	3801 1.30	3644 1.29	3515 1.27	3397 1.25	3280 1.25	3192 1.24	24	22	23
<b>480</b>	3959 1.34	3795 1.32	3659 1.30	3534 1.28	3412 1.29	3318 1.28	25	23	24
<b>500</b>	4117 1.37	3946 1.36	3803 1.34	3672 1.32	3543 1.32	3445 1.31	26	24	25
LOW AIR CONDITIONING ΔFUEL = - 0.5 %			ENGINE ANTI ICE ON ΔFUEL = + 3 %			TOTAL ANTI ICE ON ΔFUEL = + 6.5 %			

F1P23D A320-214 CFM56-58A/P SA3520 03901.000010 100250300 .7801 .00200 80 0300300 55 0 100100 40100 18590 FCOM-02-05-50-002-180

ALTERNATE PLANNING FROM DESTINATION TO ALTERNATE AIRPORT								
GO-AROUND : 100 KG - CLIMB : 250KT/300KT/M.78 - CRUISE : LONG RANGE								
DESCENT : M.78/300KT/250KT - VMC PROCEDURE : 80 KG (4MIN)								
REF. LANDING WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)		
NORMAL AIR CONDITIONING				CG = 33.0 %		TIME (H.MIN)		
ANTI-ICING OFF				CORRECTION ON FUEL CONSUMPTION (KG/1000KG)				
AIR DIST. (NM)	FLIGHT LEVEL					FL230	FL310	FL390
	230	270	310	350	390	FL270	FL350	FL390
<b>100</b>								0
<b>120</b>	1065 0.25					7		0
<b>140</b>	1183 0.29	1193 0.28				9		0
<b>160</b>	1301 0.32	1303 0.31	1319 0.30			10	10	0
<b>180</b>	1419 0.35	1413 0.34	1422 0.33			11	12	0
<b>200</b>	1538 0.38	1523 0.37	1524 0.36	1531 0.35		12	13	0
<b>220</b>	1656 0.42	1633 0.40	1627 0.39	1629 0.38		13	14	0
<b>240</b>	1775 0.45	1744 0.43	1730 0.42	1724 0.41		14	15	0
<b>260</b>	1893 0.48	1854 0.46	1832 0.45	1822 0.44	1822 0.43	15	16	17
<b>280</b>	2012 0.52	1965 0.49	1935 0.48	1919 0.46	1915 0.46	16	17	18
<b>300</b>	2131 0.55	2076 0.52	2038 0.51	2016 0.49	2009 0.49	17	18	20
<b>320</b>	2250 0.58	2186 0.55	2142 0.54	2113 0.52	2103 0.51	18	19	21
<b>340</b>	2369 1.02	2297 0.58	2245 0.56	2211 0.55	2196 0.54	19	21	23
<b>360</b>	2489 1.05	2408 1.01	2348 0.59	2308 0.58	2290 0.57	20	22	24
<b>380</b>	2608 1.08	2519 1.04	2452 1.02	2406 1.00	2385 0.59	21	23	26
<b>400</b>	2728 1.12	2630 1.07	2555 1.05	2504 1.03	2479 1.02	22	24	27
<b>420</b>	2847 1.15	2742 1.10	2659 1.08	2602 1.06	2573 1.05	23	25	27
<b>440</b>	2967 1.18	2853 1.13	2763 1.11	2700 1.09	2668 1.07	24	26	28
<b>460</b>	3087 1.21	2965 1.16	2867 1.14	2798 1.11	2762 1.10	25	27	30
<b>480</b>	3207 1.25	3076 1.19	2971 1.17	2896 1.14	2857 1.13	26	28	31
<b>500</b>	3327 1.28	3188 1.22	3075 1.20	2994 1.17	2952 1.16	27	29	32
<b>LOW AIR CONDITIONING</b>				<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>		
ΔFUEL = - 0.5 %				ΔFUEL = + 3 %		ΔFUEL = + 5 %		

FLP23D A320-214 CFM56-584/P SA3520 03301.000010 100250300.7801.00200.80 0300300.55.0 100100.40100 18590 FCOM-02-05-50-003-180



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**FLIGHT PLANNING**

FLIGHT PREPARATION - ALTERNATE

Intentionally left blank

# PERFORMANCE

CLIMB

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CLIMB

PRELIMINARY PAGES - TABLE OF CONTENTS

#### PER-CLB-GEN GENERAL

GENERAL..... A

#### PER-CLB-CLT CLIMB TABLES

CLIMB - ISA +10..... A

CLIMB - ISA +20..... B



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL


## PERFORMANCE

### CLIMB

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>CLIMB</b></p> <p>GENERAL</p>
---	--

**GENERAL**

Ident.: PER-CLB-GEN-00001982.0001001 / 15 FEB 11

**Applicable to: ALL**

Climb tables are established at MAX CLIMB THRUST with air conditioning in normal mode and anti ice OFF.

The climb speed profile is :

- 250 kt from 1 500 ft up to FL 100
- acceleration from 250 kt to 300 kt
- climb at 300 kt then M .78 up to selected altitude.

All charts are established with a center of gravity corresponding to 33 %.

Intentionally left blank

**CLIMB - ISA +10**

Ident.: PER-CLB-CLT-00001987.0065001 / 15 FEB 11

Applicable to: ALL

CLIMB - 250KT/300KT/M.78														
MAX. CLIMB THRUST			ISA+10			FROM BRAKE RELEASE								
NORMAL AIR CONDITIONING			CG=33.0%			TIME (MIN)		FUEL (KG)						
ANTI-ICING OFF						DISTANCE (NM)		TAS (KT)						
FL	WEIGHT AT BRAKE RELEASE (1000KG)													
	52	54	56	58	60	62	64							
<b>390</b>	19	1392	20	1470	21	1552	23	1642	24	1742	26	1853		
	124	396	132	397	141	398	150	400	161	401	173	403		
<b>370</b>	17	1301	18	1369	19	1440	20	1514	21	1594	22	1679	23	1770
	109	389	115	390	122	391	129	392	136	392	144	393	153	395
<b>350</b>	15	1225	16	1287	17	1351	18	1418	19	1487	20	1561	21	1639
	98	382	103	383	108	384	114	384	120	385	126	386	133	387
<b>330</b>	14	1156	15	1213	15	1272	16	1333	17	1396	18	1462	19	1532
	88	375	92	376	97	376	102	377	107	378	113	378	118	379
<b>310</b>	13	1088	14	1140	14	1195	15	1251	16	1309	16	1370	17	1433
	79	367	83	368	87	368	91	369	96	369	100	370	105	370
<b>290</b>	12	1015	12	1063	13	1113	13	1165	14	1218	15	1273	15	1330
	70	357	73	357	77	358	80	358	84	359	88	359	92	360
<b>270</b>	10	927	11	971	11	1016	12	1062	12	1109	13	1158	14	1209
	59	343	62	344	65	344	68	345	71	345	75	345	78	346
<b>250</b>	9	847	10	887	10	927	11	969	11	1012	11	1056	12	1101
	51	330	53	331	56	331	58	332	61	332	64	332	66	332
<b>240</b>	9	810	9	847	10	886	10	925	10	966	11	1008	11	1051
	47	324	49	324	51	325	54	325	56	325	59	326	61	326
<b>220</b>	8	739	8	773	8	808	9	844	9	880	10	918	10	957
	40	311	42	312	44	312	46	312	48	313	50	313	52	313
<b>200</b>	7	673	7	703	8	735	8	767	8	800	9	834	9	869
	34	298	36	299	37	299	39	299	41	300	43	300	44	300
<b>180</b>	6	609	6	637	7	665	7	694	7	724	8	755	8	786
	29	285	30	285	32	286	33	286	34	286	36	287	37	287
<b>160</b>	5	549	6	574	6	600	6	626	6	652	7	680	7	708
	24	271	25	272	27	272	28	272	29	273	30	273	31	273
<b>140</b>	5	492	5	514	5	537	5	560	6	584	6	609	6	634
	20	257	21	257	22	258	23	258	24	258	25	259	26	259
<b>120</b>	4	437	4	457	5	477	5	498	5	519	5	541	5	564
	17	242	18	242	18	243	19	243	20	243	21	243	22	244
<b>100</b>	3	349	3	365	4	381	4	398	4	415	4	432	4	450
	12	214	12	214	13	215	13	215	14	216	14	216	15	216
<b>50</b>	2	227	2	237	2	248	2	259	2	270	3	281	3	293
	6	176	6	177	7	177	7	178	7	178	8	178	8	179
<b>15</b>	1	142	1	148	1	155	2	161	2	168	2	175	2	183
	3	128	3	128	3	129	3	129	3	130	4	130	4	130
<b>LOW AIR CONDITIONING</b>			<b>HIGH AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>					
ΔFUEL = - 0.6 %			ΔFUEL = + 0.6 %			ΔFUEL = + 2.5 %			ΔFUEL = + 5 %					

11.0.08FOA320-214 CPM56-5B4/P SA21100000C5KG330 0 018590 0 0 2 1.0 500.0 300.00 1 03250.000300.000 790 10 FCOM-NO-03-05-10-004-170

**PERFORMANCE**

**CLIMB**

**CLIMB TABLES**

<b>CLIMB - 250KT/300KT/M.78</b>								
MAX. CLIMB THRUST			ISA+10			FROM BRAKE RELEASE		
NORMAL AIR CONDITIONING			CG=33.0%			TIME (MIN)		FUEL (KG)
ANTI-ICING OFF						DISTANCE (NM)		TAS (KT)
FL	WEIGHT AT BRAKE RELEASE (1000KG)							
	66	68	70	72	74	76	78	
<b>390</b>								
<b>370</b>	25 1870 163 396	26 1981 175 398	28 2106 189 400					
<b>350</b>	22 1721 141 388	23 1809 149 389	24 1904 158 390	26 2008 168 392	27 2124 179 394	29 2254 192 396	31 2403 208 399	
<b>330</b>	20 1604 124 380	21 1680 131 381	22 1761 138 382	23 1848 145 383	24 1941 153 384	25 2042 163 386	27 2152 173 388	
<b>310</b>	18 1498 110 371	19 1566 116 372	20 1638 121 373	20 1714 127 374	21 1794 134 375	22 1879 141 376	24 1970 149 377	
<b>290</b>	16 1389 97 360	17 1451 101 361	18 1515 106 362	18 1582 111 363	19 1653 116 364	20 1728 122 365	21 1806 128 366	
<b>270</b>	14 1261 82 346	15 1315 85 347	15 1372 89 348	16 1430 93 348	17 1491 97 349	17 1555 102 350	18 1622 106 351	
<b>250</b>	12 1148 69 333	13 1196 72 334	14 1246 75 334	14 1297 79 335	15 1351 82 336	15 1407 86 337	16 1465 89 337	
<b>240</b>	12 1095 64 326	12 1140 67 327	13 1188 69 328	13 1236 72 328	14 1287 76 329	14 1339 79 330	15 1394 82 331	
<b>220</b>	10 996 54 313	11 1037 57 314	11 1079 59 315	12 1123 61 315	12 1168 64 316	13 1214 67 317	13 1263 69 318	
<b>200</b>	9 904 46 301	10 941 48 301	10 979 50 302	10 1018 52 302	11 1058 54 303	11 1099 56 304	12 1142 59 305	
<b>180</b>	8 818 39 287	8 851 41 288	9 885 42 288	9 920 44 289	9 955 46 290	10 992 48 291	10 1031 49 291	
<b>160</b>	7 737 33 274	7 766 34 274	8 797 36 275	8 828 37 275	8 860 38 276	9 893 40 277	9 927 41 278	
<b>140</b>	6 660 27 259	7 686 28 260	7 713 30 261	7 741 31 261	7 769 32 262	8 799 33 263	8 829 35 264	
<b>120</b>	6 586 23 244	6 610 23 245	6 634 24 246	6 659 25 246	6 684 26 247	7 710 27 248	7 737 28 249	
<b>100</b>	4 468 16 217	5 487 16 218	5 506 17 218	5 526 18 219	5 546 18 220	5 567 19 221	5 588 20 222	
<b>50</b>	3 304 8 180	3 316 9 180	3 328 9 182	3 341 9 183	3 354 10 184	3 367 10 185	3 380 10 186	
<b>15</b>	2 190 4 131	2 198 4 132	2 205 4 133	2 213 4 134	2 221 4 136	2 229 5 137	2 237 5 139	
<b>LOW AIR CONDITIONING</b>			<b>HIGH AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>
ΔFUEL = - 0.6 %			ΔFUEL = + 0.6 %			ΔFUEL = + 2.5 %		ΔFUEL = + 5 %

11.0-08FOA320-214 CFM56-5B4/P SA21100000C5K6390 0 018590 0 0 2 1.0 500.0 300.00 1 03250.000300.000 .780 10 FCOM-NO-03-05-10-005-170



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**CLIMB**

**CLIMB TABLES**

**CLIMB - ISA +20**

Ident.: PER-CLB-CLT-00001989.0021001 / 15 FEB 11

Applicable to: ALL

<b>CLIMB - 250KT/300KT/M.78</b>								
MAX. CLIMB THRUST			ISA+20			FROM BRAKE RELEASE		
NORMAL AIR CONDITIONING			CG=33.0%			TIME (MIN)		FUEL (KG)
ANTI-ICING OFF						DISTANCE (NM)		TAS (KT)
FL	WEIGHT AT BRAKE RELEASE (1000KG)							
	52	54	56	58	60	62	64	
<b>390</b>	25 1691 174 412	27 1799 187 413	29 1920 202 415					
<b>370</b>	22 1558 150 404	24 1648 159 405	25 1743 169 406	27 1845 181 407	28 1957 193 408	30 2081 207 410	33 2221 224 412	
<b>350</b>	20 1458 133 397	21 1538 141 398	22 1622 149 399	24 1711 158 400	25 1806 168 401	27 1907 178 402	28 2018 190 403	
<b>330</b>	18 1367 119 390	19 1440 126 391	20 1516 133 391	21 1596 140 392	23 1680 148 393	24 1769 157 394	25 1864 166 395	
<b>310</b>	17 1277 106 381	18 1343 112 382	18 1412 118 383	19 1484 124 383	20 1559 131 384	21 1639 138 385	23 1723 145 386	
<b>290</b>	15 1178 92 370	16 1238 97 371	17 1300 102 371	17 1364 107 372	18 1431 113 373	19 1502 119 373	20 1575 125 374	
<b>270</b>	13 1062 77 355	14 1115 81 356	14 1169 85 356	15 1226 89 357	16 1284 94 357	17 1345 99 358	17 1408 103 358	
<b>250</b>	11 962 65 341	12 1008 68 342	13 1057 72 342	13 1106 75 343	14 1158 79 343	14 1211 83 344	15 1267 86 344	
<b>240</b>	11 915 60 334	11 959 63 335	12 1005 66 335	12 1052 69 336	13 1100 72 336	13 1151 76 337	14 1202 79 337	
<b>220</b>	9 829 51 321	10 868 53 321	10 909 56 322	11 950 58 322	11 994 61 322	12 1038 64 323	12 1084 67 323	
<b>200</b>	8 748 43 307	9 783 45 307	9 819 47 308	10 856 49 308	10 895 51 308	10 934 53 309	11 975 56 309	
<b>180</b>	7 673 36 293	8 704 37 293	8 736 39 293	8 769 41 294	9 804 43 294	9 839 44 294	9 875 46 295	
<b>160</b>	6 602 30 278	7 630 31 278	7 659 32 279	7 689 34 279	8 719 35 279	8 750 37 280	8 783 39 280	
<b>140</b>	6 537 24 263	6 561 26 263	6 587 27 263	6 613 28 264	7 640 29 264	7 668 31 264	7 696 32 265	
<b>120</b>	5 474 20 246	5 496 21 246	5 518 22 247	5 542 23 247	6 565 24 247	6 590 25 248	6 615 26 248	
<b>100</b>	4 375 14 216	4 392 14 217	4 410 15 217	4 429 16 217	4 448 16 218	5 467 17 218	5 487 18 219	
<b>50</b>	2 243 7 176	3 254 7 177	3 265 8 177	3 277 8 177	3 289 8 178	3 302 9 178	3 314 9 179	
<b>15</b>	2 150 3 123	2 157 3 124	2 164 3 124	2 172 4 124	2 179 4 125	2 187 4 125	2 195 4 126	
<b>LOW AIR CONDITIONING</b>			<b>HIGH AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>
ΔFUEL = - 0.6 %			ΔFUEL = + 0.6 %			ΔFUEL = + 2.5 %		ΔFUEL = + 5 %

11.0.08FOA320-214 CFM56-5B4/P SA211000005KG330 0 018590 0 0 2 1.0 500.0 300.00 1 03250.000300.000 790 20 FCOM-NO-03-05-10-008-170

**PERFORMANCE**

**CLIMB**

**CLIMB TABLES**

<b>CLIMB - 250KT/300KT/M.78</b>														
MAX. CLIMB THRUST			ISA+20			FROM BRAKE RELEASE								
NORMAL AIR CONDITIONING			CG=33.0%			TIME (MIN)		FUEL (KG)						
ANTI-ICING OFF						DISTANCE (NM)		TAS (KT)						
FL	WEIGHT AT BRAKE RELEASE (1000KG)													
	66		68		70		72		74		76		78	
<b>390</b>														
<b>370</b>														
<b>350</b>	30 2138 203 405	32 2271 218 406	34 2423 235 409											
<b>330</b>	27 1966 176 396	28 2075 187 398	30 2195 199 399	32 2328 213 401	34 2478 229 403	37 2650 248 405								
<b>310</b>	24 1811 154 387	25 1906 162 388	27 2007 172 389	28 2118 183 391	30 2238 194 392	32 2370 207 394	34 2517 222 396							
<b>290</b>	21 1653 132 375	22 1734 139 376	23 1821 146 377	25 1914 154 378	26 2014 163 379	27 2121 173 380	29 2237 184 382							
<b>270</b>	18 1474 109 359	19 1543 114 360	20 1616 120 361	21 1692 126 361	22 1774 132 362	23 1860 139 363	24 1952 147 364							
<b>250</b>	16 1324 91 345	16 1384 95 345	17 1447 99 346	18 1512 104 347	19 1581 109 347	20 1654 114 348	21 1731 120 349							
<b>240</b>	15 1256 83 338	15 1313 87 338	16 1371 91 339	17 1432 95 339	18 1496 100 340	18 1564 104 341	19 1635 109 342							
<b>220</b>	13 1132 70 324	13 1181 73 324	14 1233 76 325	15 1286 79 325	15 1342 83 326	16 1400 87 326	17 1461 91 327							
<b>200</b>	11 1017 58 309	12 1061 61 310	12 1106 63 310	13 1153 66 311	13 1202 69 311	14 1253 72 312	14 1306 75 313							
<b>180</b>	10 912 48 295	10 951 51 295	11 991 53 296	11 1033 55 296	12 1075 57 297	12 1120 60 297	13 1166 62 298							
<b>160</b>	9 816 40 280	9 850 42 281	9 886 44 281	10 922 46 282	10 960 47 282	11 999 49 283	11 1040 52 283							
<b>140</b>	8 726 33 265	8 756 35 265	8 788 36 266	8 820 38 266	8 853 39 267	9 888 41 267	9 924 42 268							
<b>120</b>	7 641 27 249	7 668 28 249	7 696 29 250	7 724 31 250	8 753 32 251	8 784 33 251	8 816 35 252							
<b>100</b>	5 508 19 219	5 529 19 220	5 551 20 220	6 574 21 221	6 597 22 222	6 621 23 223	6 646 24 223							
<b>50</b>	3 327 10 179	3 341 10 180	3 355 10 181	4 369 11 182	4 384 11 182	4 399 12 183	4 415 12 184							
<b>15</b>	2 203 4 127	2 211 4 127	2 220 5 128	2 229 5 129	2 238 5 130	2 247 5 131	2 257 5 132							
<b>LOW AIR CONDITIONING</b>			<b>HIGH AIR CONDITIONING</b>			<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>					
ΔFUEL = - 0.6 %			ΔFUEL = + 0.6 %			ΔFUEL = + 2.5 %			ΔFUEL = + 5 %					

11.0-08FOA320-214 CFM56-5B4/P SA21100000C5KG390 0 018590 0 0 2 1.0 500.0 300.00 1 03250.000300.000 .780 20 FCOM-NO-03-05-10-009-170

**PERFORMANCE**

CRUISE

Intentionally left blank



**PER-CRZ-ALT ALTITUDE**

**PER-CRZ-ALT-10 OPTIMUM AND MAXIMUM ALTITUDES**

DEFINITIONS.....A

**PER-CRZ-ALT-20 WIND ALTITUDE TRADE FOR CONSTANT SPECIFIC RANGE**

WIND ALTITUDE TRADE FOR CONSTANT SPECIFIC RANGE.....A

**PER-CRZ-CRT CRUISE TABLES**

**PER-CRZ-CRT-10 GENERAL**

GENERAL.....A

**PER-CRZ-CRT-20 CRUISE AT M.78**

CRUISE - M.78 - ISA.....A

CRUISE - M.78 - ISA+20.....B

**PER-CRZ-CRT-30 CRUISE AT LONG RANGE**

LONG RANGE CRUISE - ISA.....A

LONG RANGE CRUISE - ISA+20.....B

**PER-CRZ-ICQ IN CRUISE QUICK CHECK**

**PER-CRZ-ICQ-10 GENERAL**

GENERAL.....A

CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT.....B

**PER-CRZ-ICQ-20 EXAMPLE**

EXAMPLE FOR THE QRH USE.....A




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p style="text-align: center;"><b>PERFORMANCE</b> <b>CRUISE</b></p> <p style="text-align: center;">ALTITUDE - OPTIMUM AND MAXIMUM ALTITUDES</p>
---	---

**DEFINITIONS**

Ident.: PER-CRZ-ALT-10-00001995.0001001 / 22 MAR 17

**Applicable to: ALL**

- Optimum altitude : the altitude at which the airplane covers the maximum distance per kilogram (pound) of fuel (best specific range). It depends on the actual weight and the deviation from ISA.
- Maximum altitude is defined as the lower of:
  - maximum altitude at maximum cruise thrust in level flight and
  - maximum altitude at maximum climb thrust with 300 ft/min vertical speed.

*Refer to QRH/PER-M Optimum & Maximum Altitudes (Paper Only) or use the performance application of FlySmart with Airbus.*

The QRH charts are established for a center of gravity at 33 % MAC.

Maximum and optimum altitudes are given for different temperatures at long range speed and M 0.78.

- Note:
1. The  $n = 1.3 g$  ( $n = 1.4 g$ ) curve indicates the buffet margin.
  2. Definition of the maximum altitude in the FMGC is different (Refer to DSC-22\_20-50-10 MCDU).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE


ALTITUDE - OPTIMUM AND MAXIMUM ALTITUDES

Intentionally left blank

**WIND ALTITUDE TRADE FOR CONSTANT SPECIFIC RANGE**

Ident.: PER-CRZ-ALT-20-00001998.0007001 / 10 DEC 09

Applicable to: ALL



GIVEN : Weight : 65 000 kg (143 300 lb)  
 Wind at FL 350 : 10 kt head

FIND : Minimum wind difference to descend to FL 310 :  $(40 - 10) = 30$  kt

RESULTS : Descent to FL 310 may be considered provided the tail wind at this altitude is more than  $(36 - 10) = 26$  kt.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE

ALTITUDE - WIND ALTITUDE TRADE FOR CONSTANT SPECIFIC RANGE

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE

CRUISE TABLES - GENERAL

## GENERAL

Ident.: PER-CRZ-CRT-10-00004112.0002001 / 01 DEC 14

**Applicable to: ALL**

Cruise tables are established:

- for ISA and ISA + 20
- with normal air conditioning and anti ice OFF
- from FL 290 to FL 390 at M 0.78
- from FL 100 to FL 390 at long range speed
- with a 33 % center of gravity.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**CRUISE**

CRUISE TABLES - GENERAL

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE

CRUISE TABLES - CRUISE AT M.78

### CRUISE - M.78 - ISA

Ident.: PER-CRZ-CRT-20-00002005.0010001 / 09 DEC 09

Applicable to: ALL

CRUISE - M.78												
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA CG=33.0%		N1 (%) KG/H/ENG NM/1000KG		MACH IAS (KT) TAS (KT)				
WEIGHT (1000KG)	FL290		FL310		FL330		FL350		FL370		FL390	
<b>50</b>	80.8	.780	80.6	.780	80.4	.780	80.4	.780	80.9	.780	82.0	.780
	1305	302	1211	289	1127	277	1053	264	994	252	954	241
	176.9	462	188.9	458	201.3	454	213.5	450	225.0	447	234.6	447
<b>52</b>	80.9	.780	80.7	.780	80.6	.780	80.7	.780	81.3	.780	82.5	.780
	1315	302	1222	289	1139	277	1066	264	1011	252	975	241
	175.6	462	187.3	458	199.2	454	210.8	450	221.2	447	229.3	447
<b>54</b>	81.1	.780	80.9	.780	80.9	.780	81.0	.780	81.7	.780	82.9	.780
	1324	302	1232	289	1152	277	1082	264	1030	252	1000	241
	174.3	462	185.7	458	196.8	454	207.8	450	217.2	447	223.6	447
<b>56</b>	81.2	.780	81.1	.780	81.1	.780	81.3	.780	82.1	.780	83.5	.780
	1335	302	1244	289	1166	277	1098	264	1051	252	1030	241
	173.0	462	184.0	458	194.6	454	204.7	450	212.9	447	217.1	447
<b>58</b>	81.4	.780	81.3	.780	81.4	.780	81.7	.780	82.5	.780	84.1	.780
	1345	302	1257	289	1180	277	1116	264	1074	252	1063	241
	171.6	462	182.1	458	192.2	454	201.5	450	208.3	447	210.5	447
<b>60</b>	81.6	.780	81.6	.780	81.7	.780	82.1	.780	83.0	.780	84.7	.780
	1356	302	1271	289	1196	277	1135	264	1099	252	1097	241
	170.2	462	180.1	458	189.6	454	198.1	450	203.6	447	203.9	447
<b>62</b>	81.8	.780	81.8	.780	82.0	.780	82.5	.780	83.5	.780	85.4	.780
	1368	302	1284	289	1213	277	1157	264	1129	252	1133	241
	168.7	462	178.2	458	187.0	454	194.4	450	198.1	447	197.4	447
<b>64</b>	82.0	.780	82.0	.780	82.3	.780	82.9	.780	84.0	.780		
	1382	302	1299	289	1231	277	1180	264	1162	252		
	167.1	462	176.2	458	184.3	454	190.5	450	192.6	447		
<b>66</b>	82.2	.780	82.3	.780	82.7	.780	83.3	.780	84.6	.780		
	1396	302	1315	289	1250	277	1205	264	1196	252		
	165.4	462	174.0	458	181.4	454	186.5	450	187.1	447		
<b>68</b>	82.4	.780	82.6	.780	83.1	.780	83.7	.780	85.2	.780		
	1409	302	1332	289	1272	277	1235	264	1232	252		
	163.8	462	171.8	458	178.3	454	182.1	450	181.6	447		
<b>70</b>	82.6	.780	82.9	.780	83.4	.780	84.2	.780	85.9	.780		
	1424	302	1350	289	1296	277	1267	264	1269	252		
	162.1	462	169.5	458	175.1	454	177.4	450	176.3	447		
<b>72</b>	82.9	.780	83.2	.780	83.8	.780	84.7	.780				
	1441	302	1370	289	1321	277	1301	264				
	160.2	462	167.1	458	171.7	454	172.8	450				
<b>74</b>	83.1	.780	83.6	.780	84.2	.780	85.3	.780				
	1458	302	1391	289	1348	277	1337	264				
	158.4	462	164.5	458	168.2	454	168.2	450				
<b>76</b>	83.4	.780	83.9	.780	84.6	.780	85.9	.780				
	1475	302	1414	289	1380	277	1374	264				
	156.5	462	161.8	458	164.3	454	163.7	450				
<b>78</b>	83.7	.780	84.3	.780	85.1	.780	86.5	.780				
	1495	302	1439	289	1414	277	1411	264				
	154.4	462	159.0	458	160.5	454	159.3	450				
<b>LOW AIR CONDITIONING</b> ΔFUEL = -0.5 %				<b>ENGINE ANTI ICE ON</b> ΔFUEL = +2.0 %				<b>TOTAL ANTI ICE ON</b> ΔFUEL = +4.5 %				



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**CRUISE**

CRUISE TABLES - CRUISE AT M.78

**CRUISE - M.78 - ISA+20**

Ident.: PER-CRZ-CRT-20-00002015.0009001 / 09 DEC 09

Applicable to: ALL

CRUISE - M.78												
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF						ISA+20 CG=33.0%		N1 (%) KG/H/ENG NM/1000KG		MACH IAS (KT) TAS (KT)		
WEIGHT (1000KG)	FL290		FL310		FL330		FL350		FL370		FL390	
<b>50</b>	84.3	.780	84.1	.780	84.0	.780	84.0	.780	84.6	.780	85.7	.780
	1376	302	1278	289	1188	277	1112	264	1049	252	1007	241
	174.9	481	186.8	477	199.3	474	211.3	470	222.8	468	232.2	468
<b>52</b>	84.4	.780	84.3	.780	84.2	.780	84.3	.780	85.0	.780	86.2	.780
	1386	302	1288	289	1201	277	1126	264	1067	252	1030	241
	173.6	481	185.3	477	197.1	474	208.7	470	219.1	468	227.0	468
<b>54</b>	84.6	.780	84.5	.780	84.5	.780	84.6	.780	85.4	.780	86.7	.780
	1396	302	1300	289	1216	277	1142	264	1087	252	1057	241
	172.3	481	183.7	477	194.8	474	205.6	470	215.1	468	221.1	468
<b>56</b>	84.8	.780	84.7	.780	84.7	.780	85.0	.780	85.8	.780	87.2	.780
	1407	302	1312	289	1230	277	1160	264	1109	252	1089	241
	171.0	481	181.9	477	192.6	474	202.5	470	210.8	468	214.7	468
<b>58</b>	84.9	.780	84.9	.780	85.0	.780	85.4	.780	86.2	.780		
	1418	302	1326	289	1245	277	1178	264	1133	252		
	169.7	481	180.0	477	190.2	474	199.4	470	206.3	468		
<b>60</b>	85.1	.780	85.1	.780	85.3	.780	85.8	.780	86.7	.780		
	1430	302	1340	289	1262	277	1198	264	1161	252		
	168.3	481	178.1	477	187.7	474	196.0	470	201.4	468		
<b>62</b>	85.3	.780	85.4	.780	85.6	.780	86.2	.780	87.2	.780		
	1443	302	1355	289	1280	277	1221	264	1193	252		
	166.8	481	176.2	477	185.0	474	192.3	470	196.0	468		
<b>64</b>	85.5	.780	85.6	.780	86.0	.780	86.5	.780				
	1457	302	1370	289	1299	277	1246	264				
	165.1	481	174.2	477	182.3	474	188.5	470				
<b>66</b>	85.7	.780	85.9	.780	86.4	.780	87.0	.780				
	1472	302	1388	289	1319	277	1273	264				
	163.5	481	172.0	477	179.5	474	184.5	470				
<b>68</b>	85.9	.780	86.2	.780	86.7	.780	87.4	.780				
	1486	302	1406	289	1342	277	1305	264				
	161.9	481	169.8	477	176.4	474	180.0	470				
<b>70</b>	86.2	.780	86.5	.780	87.1	.780	87.9	.780				
	1502	302	1425	289	1367	277	1339	264				
	160.2	481	167.6	477	173.2	474	175.4	470				
<b>72</b>	86.4	.780	86.9	.780	87.5	.780						
	1519	302	1445	289	1394	277						
	158.4	481	165.2	477	169.9	474						
<b>74</b>	86.7	.780	87.2	.780	87.9	.780						
	1537	302	1468	289	1424	277						
	156.5	481	162.6	477	166.3	474						
<b>76</b>	87.0	.780	87.6	.780								
	1556	302	1492	289								
	154.7	481	160.0	477								
<b>78</b>	87.3	.780	87.9	.780								
	1576	302	1519	289								
	152.6	481	157.2	477								
<b>LOW AIR CONDITIONING</b>						<b>ENGINE ANTI ICE ON</b>			<b>TOTAL ANTI ICE ON</b>			
ΔFUEL = -0.5 %						ΔFUEL = +2.0 %			ΔFUEL = +4.5 %			



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**CRUISE**

**CRUISE TABLES - CRUISE AT LONG RANGE**

**LONG RANGE CRUISE - ISA**

Ident.: PER-CRZ-CRT-30-00002018.0009001 / 10 DEC 09

Applicable to: ALL

LONG RANGE CRUISE												
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF					ISA CG=33.0%		N1 (%) KG/H/ENG NM/1000KG		MACH IAS (KT) TAS (KT)			
WEIGHT (1000KG)	FL100		FL150		FL200		FL230		FL250		FL270	
<b>50</b>	58.3	.439	64.1	.513	67.8	.557	68.9	.571	70.3	.590	72.2	.620
	1028	242	1065	259	1014	255	964	246	951	244	957	247
	136.2	280	151.0	321	168.8	342	179.8	347	186.6	355	193.5	370
<b>52</b>	59.5	.450	65.0	.522	68.1	.558	69.7	.579	71.2	.600	73.6	.640
	1075	249	1099	263	1029	255	995	249	987	248	1007	255
	133.7	287	148.7	327	166.6	343	176.5	351	183.0	361	189.7	382
<b>54</b>	61.9	.482	66.4	.536	68.6	.561	70.6	.588	72.3	.615	75.0	.657
	1171	267	1145	270	1050	257	1029	253	1030	255	1055	262
	131.3	308	146.6	336	164.1	345	173.3	357	179.6	370	186.0	392
<b>56</b>	63.6	.502	67.7	.549	69.4	.568	71.5	.597	73.6	.633	75.7	.666
	1240	278	1189	277	1082	260	1065	258	1081	263	1086	266
	129.1	320	144.5	344	161.3	349	170.2	362	176.3	381	182.9	397
<b>58</b>	64.6	.513	68.5	.555	70.1	.575	72.4	.609	74.9	.650	76.2	.669
	1283	284	1219	280	1113	263	1105	263	1130	270	1110	267
	127.5	327	142.7	348	158.6	353	167.2	370	173.1	391	180.0	400
<b>60</b>	65.6	.521	68.8	.557	70.8	.582	73.5	.624	75.9	.663	76.6	.672
	1321	289	1236	281	1145	267	1152	270	1172	276	1131	268
	126.0	333	141.1	349	156.0	357	164.4	379	170.2	399	177.3	401
<b>62</b>	66.5	.530	69.1	.558	71.5	.590	74.7	.640	76.4	.667	77.3	.679
	1358	294	1252	282	1180	270	1202	277	1198	278	1164	272
	124.6	338	139.6	349	153.5	362	161.6	389	167.7	402	174.2	405
<b>64</b>	67.3	.538	69.4	.559	72.3	.598	75.8	.654	76.9	.670	78.0	.687
	1393	298	1268	282	1216	274	1249	284	1220	279	1199	275
	123.2	343	138.0	350	151.1	367	159.0	397	165.3	404	171.1	410
<b>66</b>	68.2	.545	69.7	.560	73.2	.610	76.6	.665	77.3	.673	78.7	.696
	1427	302	1285	283	1259	280	1288	289	1242	280	1235	279
	121.9	348	136.5	351	148.8	374	156.6	404	163.0	405	168.1	415
<b>68</b>	68.8	.550	70.3	.565	74.1	.623	77.1	.669	77.9	.680	79.4	.704
	1453	305	1315	285	1306	286	1314	290	1276	284	1273	282
	120.7	351	134.6	354	146.5	383	154.5	406	160.3	409	165.2	420
<b>70</b>	69.4	.554	70.9	.571	75.2	.637	77.5	.672	78.5	.688	80.1	.713
	1479	307	1347	288	1356	293	1337	292	1312	287	1312	286
	119.6	354	132.7	358	144.3	391	152.5	408	157.7	414	162.4	422
<b>72</b>	69.8	.557	71.5	.577	76.2	.650	77.9	.674	79.2	.695	80.8	.726
	1500	309	1381	292	1404	299	1359	293	1349	290	1350	290
	118.4	355	130.9	361	142.2	399	150.5	409	155.1	419	159.6	431
<b>74</b>	70.1	.558	72.1	.583	77.0	.661	78.4	.681	79.8	.703	81.2	.729
	1518	310	1413	295	1448	305	1394	296	1386	294	1386	293
	117.3	356	129.1	365	140.2	406	148.2	413	152.6	423	157.0	435
<b>76</b>	70.3	.559	72.7	.589	77.6	.667	79.0	.687	80.5	.712	81.7	.737
	1535	310	1449	298	1480	308	1428	299	1426	298	1424	296
	116.3	357	127.4	369	138.5	410	146.0	417	150.2	429	154.3	440
<b>78</b>	70.6	.560	73.4	.596	78.0	.671	79.6	.693	81.1	.720	82.2	.744
	1551	311	1485	302	1506	309	1463	302	1465	301	1463	299
	115.2	357	125.7	373	136.8	412	143.8	421	147.9	433	151.8	444
<b>LOW AIR CONDITIONING</b> ΔFUEL = -0.5 %					<b>ENGINE ANTI ICE ON</b> ΔFUEL = +2.5 %			<b>TOTAL ANTI ICE ON</b> ΔFUEL = +5 %				

**PERFORMANCE**

**CRUISE**

CRUISE TABLES - CRUISE AT LONG RANGE

LONG RANGE CRUISE												
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA CG = 33.0%		N1 (%) KG/H/ENG NM/1000KG		MACH IAS (KT) TAS (KT)				
WEIGHT (1000KG)	FL290		FL310		FL330		FL350		FL370		FL390	
<b>50</b>	74.8	.662	75.5	.671	76.9	.694	78.4	.722	79.9	.749	81.8	.771
	976	253	941	246	933	244	932	243	935	242	939	238
	200.6	392	209.3	394	216.4	404	223.4	416	229.9	430	235.7	442
<b>52</b>	75.3	.666	76.3	.680	77.8	.706	79.1	.733	80.6	.759	82.4	.778
	1000	255	974	249	970	248	969	247	970	245	972	240
	197.2	394	204.9	399	211.6	410	218.1	423	224.3	435	229.5	446
<b>54</b>	75.8	.669	77.1	.690	78.7	.718	79.8	.745	81.3	.768	83.1	.783
	1022	256	1009	253	1009	253	1008	251	1007	248	1007	242
	193.9	396	200.6	405	207.0	418	213.0	429	218.7	441	222.9	449
<b>56</b>	76.5	.676	77.9	.699	79.3	.727	80.5	.754	82.0	.775	83.6	.783
	1051	259	1043	257	1044	256	1043	255	1041	251	1038	242
	190.4	400	196.5	410	202.6	423	208.3	434	213.4	445	216.3	449
<b>58</b>	77.2	.685	78.8	.710	80.0	.738	81.2	.763	82.5	.781	84.3	.786
	1086	263	1082	261	1083	260	1080	258	1075	253	1076	243
	186.6	406	192.6	417	198.2	429	203.6	440	208.2	448	209.3	451
<b>60</b>	78.0	.694	79.5	.721	80.6	.747	81.8	.771	83.1	.784	85.0	.788
	1122	266	1121	266	1119	264	1116	261	1109	254	1116	244
	183.0	411	188.7	423	194.1	434	199.0	444	202.8	450	202.5	452
<b>62</b>	78.7	.703	80.1	.730	81.2	.755	82.4	.777	83.6	.784	85.8	.789
	1158	270	1157	269	1155	267	1150	263	1140	254	1156	244
	179.6	416	185.0	428	190.1	439	194.7	448	197.2	450	195.8	453
<b>64</b>	79.5	.713	80.7	.739	81.8	.764	82.9	.781	84.2	.786	86.1	.780
	1197	274	1197	273	1194	270	1182	265	1179	255	1170	241
	176.3	422	181.3	434	186.1	444	190.3	450	191.4	451	191.1	447
<b>66</b>	80.2	.723	81.3	.748	82.5	.771	83.4	.784	84.9	.788		
	1235	278	1233	276	1231	273	1217	266	1218	255		
	173.1	428	177.9	439	182.2	449	185.8	452	185.6	452		
<b>68</b>	80.7	.730	81.8	.755	83.0	.776	83.9	.784	85.6	.789		
	1272	281	1270	279	1264	275	1247	266	1258	256		
	170.0	432	174.5	443	178.6	452	181.3	452	180.0	453		
<b>70</b>	81.3	.739	82.4	.764	83.5	.780	84.4	.786	86.2	.789		
	1311	285	1309	283	1296	277	1285	267	1296	256		
	166.8	437	171.1	448	175.0	454	176.3	453	174.7	453		
<b>72</b>	81.8	.747	83.0	.771	83.9	.783	85.0	.788	86.4	.772		
	1348	288	1346	285	1331	278	1324	267	1291	250		
	163.9	442	167.9	452	171.2	456	171.6	454	171.5	443		
<b>74</b>	82.3	.753	83.5	.776	84.4	.784	85.6	.789				
	1394	291	1392	289	1362	278	1363	268				
	161.1	446	164.8	455	167.5	456	166.8	455				
<b>76</b>	82.8	.761	84.0	.780	84.8	.785	86.2	.789				
	1423	294	1415	289	1398	279	1402	268				
	158.3	450	161.8	458	163.4	457	162.3	455				
<b>78</b>	83.4	.768	84.4	.782	85.4	.787	86.5	.782				
	1462	297	1446	290	1436	279	1417	265				
	155.5	455	158.7	459	159.4	458	159.0	451				
<b>LOW AIR CONDITIONING</b>				<b>ENGINE ANTI ICE ON</b>				<b>TOTAL ANTI ICE ON</b>				
ΔFUEL = -0.5 %				ΔFUEL = +2.5 %				ΔFUEL = +5 %				

**LONG RANGE CRUISE - ISA+20**

Ident.: PER-CRZ-CRT-30-00002033.0009001 / 10 DEC 09

Applicable to: ALL

LONG RANGE CRUISE						
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA +20 CG=33.0%	N1 (%) KG/H/ENG NM/1000KG	MACH IAS (KT) TAS (KT)
WEIGHT (1000KG)	FL100	FL150	FL200	FL230	FL250	FL270
<b>50</b>	60.7 .440	67.8 .528	70.4 .553	71.7 .568	73.2 .587	75.0 .614
	1083 243	1144 266	1045 253	998 245	985 243	987 244
	134.6 291	149.9 343	169.0 353	179.9 359	186.6 368	193.4 382
<b>52</b>	64.0 .482	68.7 .534	70.8 .554	72.6 .576	74.1 .596	76.5 .634
	1207 267	1173 269	1062 254	1031 248	1022 247	1041 252
	132.1 319	148.0 347	166.7 354	176.5 364	182.9 374	189.4 394
<b>54</b>	66.3 .508	69.5 .541	71.3 .558	73.4 .584	75.1 .610	78.0 .652
	1295 281	1203 273	1086 255	1065 252	1065 253	1092 260
	129.8 336	146.2 352	164.1 356	173.2 369	179.4 382	185.6 405
<b>56</b>	67.1 .514	70.4 .547	72.1 .565	74.3 .593	76.4 .627	78.8 .661
	1325 285	1232 276	1119 259	1101 256	1116 260	1128 264
	128.4 340	144.5 356	161.2 361	170.0 374	176.0 393	182.3 411
<b>58</b>	67.6 .518	71.0 .552	72.8 .572	75.1 .602	77.8 .643	79.3 .665
	1347 287	1256 278	1153 262	1138 260	1167 267	1154 266
	127.2 343	142.8 359	158.5 365	167.0 380	172.7 403	179.3 414
<b>60</b>	68.3 .523	71.3 .553	73.6 .579	76.2 .616	78.9 .658	79.8 .668
	1375 290	1274 279	1187 265	1187 266	1215 274	1177 267
	125.8 346	141.1 360	155.8 370	164.0 389	169.6 412	176.5 415
<b>62</b>	69.1 .530	71.7 .555	74.4 .587	77.4 .633	79.5 .663	80.5 .676
	1408 294	1293 280	1223 269	1240 274	1243 276	1213 270
	124.5 350	139.5 361	153.2 375	161.2 400	167.0 415	173.2 420
<b>64</b>	69.8 .535	72.0 .556	75.1 .594	78.7 .649	80.0 .666	81.2 .684
	1437 297	1311 281	1259 273	1292 281	1269 277	1250 273
	123.2 354	137.9 361	150.8 380	158.4 409	164.5 418	170.1 425
<b>66</b>	70.5 .541	72.4 .557	75.9 .603	79.6 .660	80.5 .670	81.9 .692
	1467 300	1330 281	1298 277	1336 286	1296 279	1289 277
	121.9 358	136.3 362	148.4 385	155.9 417	162.0 420	167.0 430
<b>68</b>	71.2 .546	73.0 .563	76.8 .616	80.1 .664	81.1 .677	82.6 .700
	1496 303	1363 284	1347 283	1365 288	1333 282	1328 281
	120.7 361	134.3 366	146.1 393	153.7 420	159.2 424	164.0 436
<b>70</b>	71.9 .551	73.6 .568	77.9 .631	80.5 .667	81.8 .685	83.4 .710
	1525 305	1396 287	1401 290	1390 290	1371 286	1370 285
	119.5 364	132.4 370	143.7 403	151.6 421	156.6 429	161.1 441
<b>72</b>	72.3 .554	74.2 .574	79.0 .643	81.0 .670	82.4 .692	84.1 .719
	1548 307	1431 290	1451 296	1416 291	1409 289	1412 289
	118.3 366	130.5 373	141.6 411	149.5 423	154.0 434	158.3 447
<b>74</b>	72.6 .555	74.8 .580	80.0 .656	81.6 .677	83.1 .700	84.6 .727
	1567 308	1464 293	1500 302	1453 294	1448 292	1452 292
	117.2 367	128.7 377	139.5 419	147.2 428	151.4 439	155.6 452
<b>76</b>	72.9 .556	75.4 .586	80.6 .663	82.2 .684	83.8 .708	85.1 .735
	1585 308	1500 296	1537 306	1491 297	1490 296	1494 295
	116.0 368	127.0 381	137.7 423	144.9 432	149.0 444	152.9 457
<b>78</b>	73.2 .557	76.1 .592	81.0 .666	82.8 .691	84.5 .717	85.7 .743
	1603 309	1538 300	1564 307	1529 300	1533 300	1537 299
	114.9 369	125.3 385	136.0 425	142.6 436	146.6 449	150.3 462
<b>LOW AIR CONDITIONING</b> ΔFUEL = -0.5 %			<b>ENGINE ANTI ICE ON</b> ΔFUEL = +2.5 %		<b>TOTAL ANTI ICE ON</b> ΔFUEL = +5 %	




**PERFORMANCE**

**CRUISE**

CRUISE TABLES - CRUISE AT LONG RANGE

LONG RANGE CRUISE												
MAX. CRUISE THRUST LIMITS NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA +20 CG = 33.0%		N1 (%) KG/H/ENG NM/1000KG		MACH IAS (KT) TAS (KT)				
WEIGHT (1000KG)	FL290		FL310		FL330		FL350		FL370		FL390	
<b>50</b>	77.9	.657	78.7	.667	80.3	.691	81.9	.719	83.5	.748	85.5	.769
	1012	251	979	244	973	242	974	242	982	241	987	237
	200.2	405	208.6	408	215.5	419	222.1	433	228.1	448	233.6	461
<b>52</b>	78.5	.662	79.6	.677	81.1	.700	82.6	.730	84.2	.757	86.1	.776
	1039	253	1016	248	1010	246	1015	246	1021	244	1023	240
	196.6	409	204.0	415	210.6	425	216.7	440	222.4	454	227.3	465
<b>54</b>	79.0	.666	80.4	.686	82.1	.713	83.4	.742	85.0	.766	86.7	.781
	1064	255	1052	252	1052	251	1057	250	1059	248	1061	242
	193.1	411	199.7	420	205.8	433	211.5	447	216.8	459	220.8	468
<b>56</b>	79.7	.673	81.3	.696	82.8	.724	84.1	.751	85.6	.774	87.3	.781
	1096	258	1090	256	1092	255	1095	254	1096	250	1093	242
	189.4	415	195.4	426	201.2	439	206.7	453	211.5	464	214.3	468
<b>58</b>	80.5	.682	82.1	.707	83.5	.735	84.7	.760	86.2	.780	87.3	.756
	1133	261	1130	260	1135	259	1134	257	1133	252	1082	233
	185.7	421	191.3	432	196.6	446	201.9	458	206.3	468	209.4	453
<b>60</b>	81.3	.691	82.9	.717	84.2	.745	85.4	.768	86.8	.782		
	1172	265	1172	264	1176	263	1173	260	1167	253		
	182.0	426	187.4	439	192.4	453	197.3	463	200.9	469		
<b>62</b>	82.1	.700	83.5	.727	84.8	.754	86.0	.774	87.3	.783		
	1209	268	1213	268	1215	267	1209	262	1203	254		
	178.5	432	183.5	445	188.4	458	192.9	466	195.2	470		
<b>64</b>	82.9	.709	84.2	.738	85.4	.762	86.5	.780	87.7	.778		
	1250	273	1256	272	1255	270	1245	264	1224	252		
	175.1	438	179.8	451	184.4	463	188.5	470	190.5	467		
<b>66</b>	83.6	.719	84.8	.746	86.0	.770	87.1	.783	87.8	.750		
	1292	277	1296	276	1294	273	1281	265	1210	242		
	171.8	444	176.3	457	180.6	467	184.0	471	185.6	449		
<b>68</b>	84.1	.727	85.4	.754	86.6	.775	87.6	.783				
	1331	280	1334	279	1330	275	1315	266				
	168.6	449	172.9	461	176.9	470	179.4	472				
<b>70</b>	84.7	.736	85.9	.761	87.1	.779	88.0	.782				
	1374	284	1375	282	1364	276	1346	265				
	165.4	454	169.5	466	173.3	473	175.0	471				
<b>72</b>	85.3	.745	86.5	.768	87.6	.783	88.1	.761				
	1415	287	1414	284	1403	278	1335	257				
	162.4	460	166.3	470	169.5	475	171.6	458				
<b>74</b>	85.8	.752	87.0	.773	88.0	.783						
	1454	290	1450	287	1435	278						
	159.6	464	163.2	473	165.7	475						
<b>76</b>	86.3	.759	87.5	.777	88.1	.768						
	1494	293	1484	288	1430	272						
	156.7	468	160.2	475	163.0	466						
<b>78</b>	86.9	.766	87.9	.781	88.1	.743						
	1535	296	1522	290	1419	262						
	153.9	473	157.1	478	159.1	451						
<b>LOW AIR CONDITIONING</b> ΔFUEL = -0.5 %				<b>ENGINE ANTI ICE ON</b> ΔFUEL = +2.5 %				<b>TOTAL ANTI ICE ON</b> ΔFUEL = +5 %				



 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PERFORMANCE</b> <b>CRUISE</b> IN CRUISE QUICK CHECK - GENERAL
---	--

**GENERAL**

Ident.: PER-CRZ-ICQ-10-00002036.0001001 / 22 MAR 17

**Applicable to: ALL**

In cruise, a quick check table (*Refer to QRH/PER-M In Cruise Quick Check at a Given Mach Number (Paper Only)*) or use the performance application of FlySmart with Airbus) allows the flight crew to determine the fuel consumption and the time required to cover a given air distance from any moment in cruise to land.

The QRH table is established for:

- Cruise Mach number: M 0.78
- Descent profile: M 0.78/300 kt/250 kt
- Approach and landing: 120 kg or 270 lb -6 min IMC
- ISA
- CG = 33 %
- Normal air conditioning
- Anti ice OFF

- Note:
1. In the table, the asterisk "\*" means that a step climb of 4 000 ft has been made to reach the corresponding flight level.
  2. The flight level shown on the top of each column is the final flight level.
  3. For each degree celsius above ISA apply a fuel correction of  
 $0.005 \text{ (kg/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air Distance (NM)}$   
 or  $0.011 \text{ (lb/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air Distance (NM)}$

**CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT**

Ident.: PER-CRZ-ICQ-10-00002039.0001001 / 22 MAR 16

**Applicable to: ALL**

The in cruise quick check table is based on a reference initial weight.

The fuel consumption must be corrected when the actual weight is different from the reference initial weight.

If it is lower (or greater) than the reference weight, subtract (or add) the value given in the correction part of the table per 1 000 kg or 1 000 lb below (or above) the reference weight.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**CRUISE**

IN CRUISE QUICK CHECK - GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**CRUISE**

IN CRUISE QUICK CHECK - EXAMPLE

**EXAMPLE FOR THE QRR USE**

Ident.: PER-CRZ-ICQ-20-00014741.0001001 / 22 MAR 17

Applicable to: ALL

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

**In-cruise quick check with cruise at M.78**

FL 370

Actual cruise weight : 55 000 kg

Remaining ground distance : 800 NM

ISA +10

Average wind during flight : -40 kt (head wind)

- Evaluation of air distance to be covered

- Use the “Ground Distance/Air Distance” conversion table (*Refer to PER-OPD-CON-AEO M.78*)

AIR DISTANCE (NM) - M.78							
GROUND DIST. (NM)	WIND COMPONENTS (KT)						
	TAILWIND +150	+100	+50	0	-50	-100	HEADWIND -150
10	7	8	9	10	11	13	15
20	15	16	18	20	23	26	30
30	22	25	27	30	34	39	45
40	30	33	36	40	45	51	60
50	37	41	45	50	56	64	75
100	75	82	90	100	113	129	150
200	150	164	180	200	225	257	300
300	225	245	270	300	338	386	450
400	300	327	360	400	450	514	600
500	375	409	450	500	563	643	750
1000	750	818	900	1000	1125	1286	1501
1500	1125	1227	1350	1500	1688	1929	2251
2000	1500	1636	1800	2000	2250	2572	3001
2500	1875	2045	2250	2500	2813	3215	3752
3000	2250	2454	2700	3000	3375	3858	4502
3500	2624	2863	3150	3500	3938	4501	5252
4000	2999	3272	3600	4000	4500	5144	6003
4500	3374	3681	4050	4500	5063	5787	6753
5000	3749	4090	4500	5000	5626	6430	7503

The corresponding air distance is : 880 NM

- Determination of the fuel consumption and time for the reference initial weight in cruise.
- Enter table (*Refer to QRH/PER-M In Cruise Quick Check at a Given Mach Number (Paper Only)*) with an air distance of 880 NM and FL 370 for ISA.

IN CRUISE QUICK CHECK FROM ANY MOMENT IN CRUISE TO LANDING										
CRUISE : M.78 - DESCENT : M.78/300KT/250KT										
IMC PROCEDURE : 120 KG (6MIN)										
REF. INITIAL WEIGHT = 60000 KG			ISA			FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING			CG = 33.0 %							
ANTI-ICING OFF						TIME (H.MIN)				
AIR DIST. (NM)	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)				
	290	310	330	350	370	390	FL290 FL310	FL330 FL350	FL370 FL390	
725	4001 1.43	3772 1.44	3583 1.45	3427 1.46	3313 1.46	3278 1.46	16	24	42	
750	4145 1.47	3909 1.47	3712 1.48	3551 1.49	3433 1.49	3397 1.49	17	25	43	
775	4290 1.50	4045 1.51	3842 1.52	3675 1.52	3552 1.53	3516 1.53	18	26	45	
800	4434 1.53	4181 1.54	3971 1.55	3799 1.56	3672 1.56	3634 1.56	18	27	46	
825	4578 1.56	4317 1.57	4100 1.58	3922 1.59	3791 2.00	3752 2.00	19	28	48	
850	4722 2.00	4452 2.01	4229 2.01	4046 2.02	3910 2.03	3870 2.03	20	29	49	
875	4866 2.03	4588 2.04	4358 2.05	4169 2.06	4029 2.06	3988 2.06	20	30	51	
900	5010 2.06	4724 2.07	4486 2.08	4292 2.09	4148 2.10	4106 2.10	21	31	52	
925	5153 2.09	4859 2.10	4615 2.11	4415 2.12	4266 2.13	4222 2.13	22	32	54	
950	5297 2.13	4995 2.14	4743 2.15	4538 2.16	4385 2.16	4340 2.16	22	33	55	
975	5440 2.16	5130 2.17	4871 2.18	4661 2.19	4503 2.20	4456 2.20	23	34	57	
1000	5584 2.19	5265 2.20	DO NOT USE FOR OPERATIONAL PURPOSE							58
1025	5727 2.22	5400 2.23	DO NOT USE FOR OPERATIONAL PURPOSE							60
1050	5870 2.25	5535 2.27	5258 2.28	5028 2.29	4857 2.30	4806 2.30	25	36	61	
1075	6013 2.29	5670 2.30	5383 2.31	5150 2.32	4974 2.33	4922 2.33	26	37	63	
1100	6156 2.32	5805 2.33	5511 2.34	5272 2.36	5092 2.36	5038 2.36	26	38	64	
1125	6299 2.35	5940 2.37	5639 2.38	5394 2.39	5209 2.40	5153 2.40	27	39	65	
1150	6442 2.39	6074 2.40	5766 2.41	5516 2.42	5326 2.43	5269 2.43	28	40	67	
1175	6584 2.42	6209 2.43	5893 2.44	5637 2.46	5443 2.46	5384 2.46	28	41	68	
1200	6727 2.45	6343 2.46	6020 2.48	5759 2.49	5560 2.50	5499 2.50	29	42	70	
1225	6869 2.48	6477 2.50	6148 2.51	5880 2.52	5676 2.53	5614 2.53	30	43	71	
1250	7012 2.52	6611 2.53	6274 2.54	6001 2.56	5793 2.56	5729 2.56	30	44	72	
1275	7154 2.55	6745 2.56	6401 2.58	6122 2.59	5909 3.00	5843 3.00	31	45	74	
1300	7296 2.58	6879 2.59	6528 3.01	6243 3.02	6025 3.03	5957 3.03	31	46	75	
1325	7439 3.01	7013 3.03	6655 3.04	6364 3.06	6141 3.07	6071 3.07	32	46	76	
1350	7581 3.05	7147 3.06	6781 3.08	6485 3.09	6257 3.10	6185 3.10	33	47	78	
LOW AIR CONDITIONING			ENGINE ANTI ICE ON			TOTAL ANTI ICE ON				
ΔFUEL = - 0.5 %			ΔFUEL = + 3 %			ΔFUEL = + 6 %				

Fuel consumption : 4 053 kg

Time needed : 2 h 07 min

- Correction due to real in cruise weight of 55 000 kg
  - $\Delta$  fuel consumption : -51 kg per 1 000 kg below reference
  - $\Delta$  fuel :  $-51 \times (60 - 55) = -255$  kg
- Temperature correction :
  - $\Delta$  fuel consumption : +0.005 kg per 1 °above ISA and per 1 NM Air distance
  - $\Delta$  fuel :  $+0.005 \times 10 \times 880 = 44$  kg

**RESULT**

Fuel :  $4\ 053 - 255 + 44 = 3\ 842$  kg

Time : 2 h 07 min



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### CRUISE

IN CRUISE QUICK CHECK - EXAMPLE

Intentionally left blank

# PERFORMANCE

HOLDING

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE  
HOLDING**

PRELIMINARY PAGES - TABLE OF CONTENTS

**PER-HLD-GEN GENERAL**

GENERAL.....A

**PER-HLD-HLD HOLDING TABLES**

CONF 0 - GREEN DOT SPEED.....A




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### HOLDING

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b>  <b>FLIGHT CREW</b>  <b>OPERATING MANUAL</b></p>	<p><b>PERFORMANCE</b></p> <p><b>HOLDING</b></p> <p>GENERAL</p>
---	--

**GENERAL**

Ident.: PER-HLD-GEN-00002129.0001001 / 01 DEC 14

**Applicable to: ALL**

Holding table contains information about the total fuel flow that allows the flight crew to plan holding and reserve fuel requirements.

It is established for flight in a race track holding pattern in clean configuration at green dot speed.

This chart is established with air conditioning in normal mode and the center of gravity at 33 %.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**HOLDING**

GENERAL

Intentionally left blank

**CONF 0 - GREEN DOT SPEED**

Ident.: PER-HLD-HLD-00002146.0023001 / 16 FEB 11

Applicable to: ALL

<b>RACE TRACK HOLDING PATTERN - GREEN DOT SPEED</b>								
MAX. CRUISE THRUST LIMITS					ISA		N1 (%)	
CLEAN CONFIGURATION					CG=33.0%		FF (KG/H/ENG)	
NORMAL AIR CONDITIONING								
ANTI-ICING OFF								
WEIGHT (1000KG)	FL 15	FL 50	FL100	FL140	FL180	FL200	FL220	FL250
<b>46</b>	45.6 890	47.9 873	51.1 839	54.0 813	57.5 794	58.9 789	60.6 787	63.5 784
<b>48</b>	46.5 926	48.9 908	52.1 871	55.1 844	58.4 828	59.9 823	61.7 821	64.7 818
<b>50</b>	47.4 962	49.8 940	53.0 901	56.2 876	59.4 861	61.0 859	62.8 855	65.8 851
<b>52</b>	48.3 997	50.6 971	53.9 931	57.3 908	60.3 896	62.0 892	63.9 889	66.7 884
<b>54</b>	49.2 1033	51.4 1002	54.9 963	58.3 942	61.3 931	63.0 926	65.0 924	67.7 916
<b>56</b>	50.1 1065	52.2 1033	55.8 994	59.1 975	62.2 964	64.0 960	66.1 955	68.6 949
<b>58</b>	50.8 1097	52.9 1063	56.8 1026	59.9 1008	63.2 997	65.1 994	66.9 988	69.5 982
<b>60</b>	51.5 1128	53.7 1094	57.7 1059	60.7 1043	64.1 1031	66.1 1026	67.7 1021	70.4 1016
<b>62</b>	52.2 1158	54.5 1125	58.7 1092	61.6 1078	65.1 1065	66.9 1058	68.6 1054	71.2 1049
<b>64</b>	52.9 1189	55.3 1156	59.4 1126	62.4 1110	66.0 1097	67.7 1091	69.4 1087	72.1 1084
<b>66</b>	53.6 1219	56.1 1188	60.1 1159	63.2 1143	67.0 1129	68.5 1124	70.3 1120	72.9 1119
<b>68</b>	54.3 1250	56.9 1221	60.9 1193	64.1 1176	67.7 1162	69.3 1157	71.1 1154	73.7 1155
<b>70</b>	55.0 1282	57.8 1254	61.6 1228	64.9 1210	68.4 1195	70.1 1191	71.8 1188	74.6 1192
<b>72</b>	55.8 1314	58.6 1287	62.3 1261	65.7 1243	69.2 1228	70.8 1224	72.5 1223	75.4 1230
<b>74</b>	56.5 1347	59.4 1321	63.1 1294	66.6 1275	69.9 1262	71.6 1258	73.3 1258	76.1 1269
<b>76</b>	57.2 1380	60.2 1355	63.8 1327	67.4 1307	70.6 1296	72.3 1292	74.0 1295	76.9 1309
<b>78</b>	58.0 1413	60.8 1389	64.5 1360	68.2 1339	71.3 1330	73.0 1328	74.8 1332	77.6 1350
LOW AIR CONDITIONING $\Delta FF = - 0.3 \%$	ENGINE ANTI ICE ON $\Delta FF = + 5 \%$		TOTAL ANTI ICE ON $\Delta FF = + 9 \%$		PER 1° ABOVE ISA $\Delta FF = + 0.3 \%$		STRAIGHT LINE $\Delta FF = - 5 \%$	



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**HOLDING**

HOLDING TABLES

Intentionally left blank

**PERFORMANCE**

DESCENT

Intentionally left blank





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### DESCENT

PRELIMINARY PAGES - TABLE OF CONTENTS

#### PER-DES-GEN GENERAL

GENERAL..... A

#### PER-DES-STD STANDARD

DESCENT- M.78/300KT/250KT..... A

#### PER-DES-EMG EMERGENCY

EMER Descent..... A



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### DESCENT

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### DESCENT

#### GENERAL

## GENERAL

Ident.: PER-DES-GEN-00002131.0001001 / 09 DEC 09

Applicable to: ALL

Descent tables are established for normal descent speed M .78 / 300 kt /250 kt and emergency descent at MMO/VMO with airbrakes extended, down to 1 500 ft with :

- Normal air conditioning
- CG = 33 %
- Anti ice OFF

For normal descent, cabin vertical speed is limited to 350 ft/min



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**DESCENT**

GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
 FLIGHT CREW  
 OPERATING MANUAL

**PERFORMANCE**

**DESCENT**

STANDARD

**DESCENT- M.78/300KT/250KT**

Ident.: PER-DES-STD-00002133.0037001 / 09 DEC 09

Applicable to: ALL

DESCENT - M.78/300KT/250KT									
IDLE THRUST NORMAL AIR CONDITIONING ANTI-ICING OFF			ISA CG=33.0%		MAXIMUM CABIN RATE OF DESCENT 350FT/MIN				
WEIGHT (1000KG)	45				65				IAS (KT)
	FL	TIME (MIN)	FUEL (KG)	DIST. (NM)	N1	TIME (MIN)	FUEL (KG)	DIST. (NM)	
<b>390</b>	16.1	204	101	68.8	17.4	165	106	IDLE	241
<b>370</b>	14.6	174	89	69.9	16.7	160	100	IDLE	252
<b>350</b>	12.9	134	77	72.1	16.0	156	95	IDLE	264
<b>330</b>	12.0	119	70	IDLE	15.4	153	91	IDLE	277
<b>310</b>	11.6	117	67	IDLE	14.8	149	86	IDLE	289
<b>290</b>	11.1	114	64	IDLE	14.2	145	82	IDLE	300
<b>270</b>	10.6	110	59	IDLE	13.4	141	76	IDLE	300
<b>250</b>	10.0	107	55	IDLE	12.7	136	71	IDLE	300
<b>240</b>	9.7	105	53	IDLE	12.3	133	68	IDLE	300
<b>220</b>	9.1	100	49	IDLE	11.5	127	62	IDLE	300
<b>200</b>	8.5	94	45	IDLE	10.6	119	56	IDLE	300
<b>180</b>	7.8	86	40	IDLE	9.8	109	51	IDLE	300
<b>160</b>	7.1	78	36	IDLE	8.8	97	45	IDLE	300
<b>140</b>	6.3	67	31	IDLE	7.9	83	39	IDLE	300
<b>120</b>	5.6	57	27	IDLE	6.9	70	33	IDLE	300
<b>100</b>	4.9	48	23	IDLE	6.0	58	28	IDLE	300
<b>50</b>	1.7	15	7	IDLE	2.1	18	9	IDLE	250
<b>15</b>	.0	0	0	IDLE	.0	0	0	IDLE	250
<b>CORRECTIONS</b>	<b>LOW AIR CONDITIONING</b>		<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>		<b>PER 1° ABOVE ISA</b>		
TIME	-		+ 6 %		+ 6 %		-		
FUEL	- 2 %		+ 28 %		+ 44 %		+ 0.2 %		
DISTANCE	-		+ 3 %		+ 4 %		+ 0.3 %		

11.0.08F0A320.214 CFM56-5B4/P SA23100000C5KG330 0 018590 0 0-1.350.0 15.0 .00 0 03 .780390.000250.000 0 FCOM-ND 03-05-30-002-170



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**DESCENT**

STANDARD

Intentionally left blank

**EMER DESCENT**

Ident.: PER-DES-EMG-00002134.0201001 / 21 MAR 17

Applicable to: ALL

<b>EMERGENCY DESCENT - M.82/350KT</b>									
IDLE THRUST NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA CG=33.0%		AIRBRAKES EXTENDED			
WEIGHT (1000KG)	45				65				IAS (KT)
	FL	TIME (MIN)	FUEL (KG)	DIST. (NM)	N1	TIME (MIN)	FUEL (KG)	DIST. (NM)	
<b>390</b>	4.8	48	34	IDLE	6.6	66	47	IDLE	255
<b>370</b>	4.5	46	32	IDLE	6.2	64	44	IDLE	267
<b>350</b>	4.3	45	30	IDLE	5.9	62	42	IDLE	279
<b>330</b>	4.0	43	28	IDLE	5.6	60	40	IDLE	292
<b>310</b>	3.8	42	27	IDLE	5.3	59	38	IDLE	306
<b>290</b>	3.6	41	25	IDLE	5.1	57	35	IDLE	319
<b>270</b>	3.4	40	24	IDLE	4.8	56	33	IDLE	333
<b>250</b>	3.3	38	22	IDLE	4.6	54	32	IDLE	347
<b>240</b>	3.2	38	21	IDLE	4.5	53	31	IDLE	350
<b>220</b>	2.9	36	20	IDLE	4.1	51	28	IDLE	350
<b>200</b>	2.7	33	18	IDLE	3.8	47	25	IDLE	350
<b>180</b>	2.4	30	16	IDLE	3.4	42	22	IDLE	350
<b>160</b>	2.2	27	14	IDLE	3.1	38	20	IDLE	350
<b>140</b>	1.9	23	12	IDLE	2.7	32	17	IDLE	350
<b>120</b>	1.6	19	10	IDLE	2.3	26	14	IDLE	350
<b>100</b>	1.4	15	8	IDLE	1.9	21	12	IDLE	350
<b>50</b>	.7	7	4	IDLE	1.0	9	6	IDLE	350
<b>0</b>	.0	0	0	IDLE	.0	0	0	IDLE	350

11.0-08FOA320-214 CFM56-5B4/P SA23310000C5KG330 0 018590 0 0-1 .0 .0 .00 0 02 .820390.000 .000 0 FCOM-NO.03-05-30-003-170



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**DESCENT**

**EMERGENCY**

Intentionally left blank



**PERFORMANCE**

GO AROUND

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**GO AROUND**

PRELIMINARY PAGES - TABLE OF CONTENTS

**PER-GOA-GEN GENERAL**

GENERAL..... A  
PROCEDURE..... B

**PER-GOA-ACG APPROACH CLIMB LIMITING WEIGHT**

**PER-GOA-ACG-NOR NORMAL**

CONF 2..... A  
CONF 3..... B

**PER-GOA-ACG-CAT CAT II**

CAT II - CONF 2..... A  
CAT II - CONF 3..... B




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### GO AROUND

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>GO AROUND</b></p> <p>GENERAL</p>
---	--

**GENERAL**

Ident.: PER-GOA-GEN-00002140.0001001 / 28 JAN 11

**Applicable to: ALL**

In the go around configuration corresponding to the all engine procedure, the minimum steady gradient one engine inoperative required by the regulations is 2.1 % at a speed not exceeding 1.4 Vs. This requirement is also called approach climb performance by regulations.

The following tables allow to determine the go around limiting weight which satisfies the required gradient with the certified go around configurations 3 and 2.

The required gradient of 2.1 % is considered at the airport reference altitude. The power setting is "GO AROUND" thrust with the air conditioning ON. The speed is 1.23 Vs of the specified configuration. For the occasional cases where approach climb performance is found restrictive, a correction is given for an increased speed, up to 1.4 Vs.

*Note: Landing climb performance (2 engines running) is never limiting.*

**PROCEDURE**

Ident.: PER-GOA-GEN-00002141.0001001 / 21 MAR 17

Applicable to: ALL

According to airport pressure altitude and temperature determine if the slats/flaps setting must be restricted as a function of the landing weight, in order to meet the go around gradient requirement of 2.1 %.

Establish the final approach configuration with one more step of flaps. If the approach is interrupted, retract the flaps by one step during the go-around.

In case of category 2 and 3 approaches, JAR -OPS requires a regulatory approach climb gradient of 2.5 % to be maintained.

Use the tables for CAT II & III approaches to determine the maximum approach climb limiting weight according to airport pressure altitude and temperature.

- Note:
1. If circumstances dictate, landing may be made at a weight corresponding to the maximum structural takeoff weight. (Refer to PRO-ABN-MISC [QRH] OVERWEIGHT LANDING).
  2. When icing conditions are predicted during the flight and TAT is 10 °C or below and there is an evidence of significant ice accretion, to take into account ice formation on the non heated structure:
    - Decrease the approach climb limiting weight by 4.5 %
    - In CONF FULL, the approach speed must not be lower than VREF +5 kt, or in CONF 3, the approach speed must not be lower than VLS +10 kt.For Landing Performance assessment, refer to QRH PER-A.
  3. In the following tables corrections for anti ice are only valid for OAT lower than 10 °C.
  4. Use the CAT II tables in case of CAT III approach calculation.



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**GO AROUND**

APPROACH CLIMB LIMITING WEIGHT - NORMAL

**CONF 2**

Ident.: PER-GOA-ACG-NOR-00002142.0322001 / 24 MAR 11

Applicable to: ALL

<b>APPROACH CLIMB LIMITING WEIGHT (1000 KG) - CONF 2</b>												
ONE ENGINE OUT							High Air Conditioning			Gradient : 2.1 %		
ONE ENGINE AT GO AROUND THRUST							Anti Ice OFF			V = 1.23 Vs		
OAT (°C)	PRESSURE ALTITUDE (FT)											
	-2000	0	200	400	600	800	1000	2000	5000	9200	12000	14100
≤10	84.6	83.6	83.4	83.1	82.9	82.7	82.4	81.3	81.6	73.1	65.9	60.4
20	84.2	83.3	83.1	82.8	82.6	82.4	82.1	81.1	81.3	70.5	60.5	54.4
22	84.1	83.2	83.0	82.8	82.5	82.3	82.1	81.0	81.3	69.3	59.5	53.6
24	84.1	83.2	82.9	82.7	82.5	82.2	82.0	81.0	80.9	68.1	58.6	
26	84.0	83.1	82.9	82.7	82.4	82.2	82.0	80.9	79.9	66.8	57.7	
28	83.9	83.1	82.8	82.6	82.4	82.1	81.9	80.9	79.0	65.7		
30	83.9	83.0	82.8	82.6	82.3	82.1	81.9	80.8	78.0	64.6		
32	83.8	83.0	82.8	82.5	82.3	82.1	81.8	80.8	77.0	63.5		
34	83.8	82.9	82.7	82.5	82.3	82.0	81.8	80.8	76.2	62.3		
36	83.7	82.9	82.7	82.5	82.2	82.0	81.8	80.7	74.7	61.2		
38	83.7	82.9	82.7	82.4	82.2	82.0	81.8	80.7	72.9			
40	83.7	82.9	82.6	82.4	82.2	82.0	81.8	80.7	71.1			
42	83.6	82.8	82.6	82.4	82.2	81.9	81.7	78.8	69.4			
44	83.6	82.8	82.2	81.6	81.0	80.4	79.9	77.0	67.7			
46	83.5	80.9	80.3	79.8	79.2	78.6	78.1	75.5				
48	83.4	79.1	78.5	78.0	77.4	76.8	76.4	73.7				
50	81.5	77.3	76.7	76.3	75.8	75.3	74.7	72.0				
52	79.6	75.7	75.1	74.6	74.0	73.5	73.0					
54	77.6	73.9	73.3	72.8								
55	76.8	73.0										
CORRECTIONS	AIR CONDITIONING OFF			ENGINE ANTI ICE ON			TOTAL ANTI ICE ON			SPEED INCREASE (PER 0.01 Vs)		
WEIGHT	+ 1400 kg			- 300 kg up to 9200 ft - 3600 kg above 9200 ft			- 1100 kg up to 5000 ft - 7000 kg above 5000 ft			+ 200 kg		

**PERFORMANCE**

**GO AROUND**

APPROACH CLIMB LIMITING WEIGHT - NORMAL

**CONF 3**

Ident.: PER-GOA-ACG-NOR-00002143.0387001 / 24 MAR 11

Applicable to: ALL

<b>APPROACH CLIMB LIMITING WEIGHT (1000 KG) - CONF 3</b>												
ONE ENGINE OUT								High Air Conditioning		Gradient : 2.1 %		
ONE ENGINE AT GO AROUND THRUST								Anti Ice OFF		V = 1.23 Vs		
OAT (°C)	PRESSURE ALTITUDE (FT)											
	-2000	0	200	400	600	800	1000	2000	5000	9200	12000	14100
≤10	84.4	83.4	83.2	82.9	82.7	82.5	82.2	81.1	81.4	72.8	65.6	60.1
20	84.0	83.1	82.9	82.6	82.4	82.2	81.9	80.8	81.1	70.2	60.2	54.2
22	83.9	83.0	82.8	82.6	82.3	82.1	81.9	80.8	81.1	69.0	59.2	53.3
24	83.9	83.0	82.7	82.5	82.3	82.0	81.8	80.7	80.6	67.8	58.3	
26	83.8	82.9	82.7	82.5	82.2	82.0	81.8	80.7	79.7	66.5	57.5	
28	83.7	82.9	82.6	82.4	82.2	81.9	81.7	80.6	78.8	65.4		
30	83.7	82.8	82.6	82.4	82.1	81.9	81.7	80.6	77.8	64.4		
32	83.6	82.8	82.6	82.3	82.1	81.9	81.6	80.6	76.8	63.3		
34	83.6	82.7	82.5	82.3	82.1	81.8	81.6	80.6	75.9	62.1		
36	83.5	82.7	82.5	82.3	82.0	81.8	81.6	80.5	74.4	60.9		
38	83.5	82.7	82.5	82.2	82.0	81.8	81.6	80.5	72.6			
40	83.5	82.7	82.4	82.2	82.0	81.8	81.6	80.5	70.8			
42	83.4	82.6	82.4	82.2	82.0	81.7	81.5	78.6	69.1			
44	83.4	82.5	82.0	81.4	80.8	80.3	79.7	76.8	67.5			
46	83.3	80.7	80.2	79.6	79.0	78.5	77.9	75.2				
48	83.2	78.9	78.3	77.8	77.2	76.7	76.2	73.4				
50	81.3	77.1	76.6	76.1	75.6	75.0	74.5	71.7				
52	79.4	75.4	74.9	74.3	73.8	73.2	72.7					
54	77.5	73.6	73.1	72.5								
55	76.6	72.7										
CORRECTIONS	AIR CONDITIONING OFF		ENGINE ANTI ICE ON		TOTAL ANTI ICE ON		SPEED INCREASE (PER 0.01 Vs)					
WEIGHT	+ 1400 kg		- 300 kg up to 9200 ft - 3600 kg above 9200 ft		- 1100 kg up to 5000 ft - 6900 kg above 5000 ft		+ 200 kg					



**CAT II - CONF 2**

Ident.: PER-GOA-ACG-CAT-00002144.0062001 / 24 MAR 11

Applicable to: ALL

<b>APPROACH CLIMB LIMITING WEIGHT (1000 KG) - CONF 2 - CAT II</b>												
ONE ENGINE OUT							High Air Conditioning			Gradient : 2.5 %		
ONE ENGINE AT GO AROUND THRUST							Anti Ice OFF					
OAT (°C)	PRESSURE ALTITUDE (FT)											
	-2000	0	200	400	600	800	1000	2000	5000	9200	12000	14100
≤10	83.0	82.0	81.8	81.6	81.4	81.1	80.9	79.8	80.0	71.7	64.7	59.4
20	82.6	81.7	81.5	81.3	81.1	80.8	80.6	79.5	79.8	69.2	59.5	53.6
22	82.6	81.7	81.4	81.2	81.0	80.8	80.5	79.5	79.7	68.0	58.5	52.8
24	82.5	81.6	81.4	81.2	80.9	80.7	80.5	79.4	79.3	66.9	57.6	
26	82.4	81.6	81.3	81.1	80.9	80.7	80.4	79.4	78.4	65.6	56.8	
28	82.4	81.5	81.3	81.1	80.8	80.6	80.4	79.3	77.5	64.6		
30	82.3	81.5	81.2	81.0	80.8	80.6	80.3	79.3	76.6	63.5		
32	82.3	81.4	81.2	81.0	80.8	80.5	80.3	79.3	75.8	62.4		
34	82.2	81.4	81.2	80.9	80.7	80.5	80.3	79.2	74.8	61.3		
36	82.2	81.3	81.1	80.9	80.7	80.5	80.3	79.2	73.3	60.1		
38	82.2	81.3	81.1	80.9	80.7	80.5	80.3	79.2	71.5			
40	82.1	81.3	81.1	80.9	80.7	80.4	80.2	79.1	69.8			
42	82.1	81.3	81.1	80.9	80.6	80.4	80.2	77.3	68.1			
44	82.0	81.2	80.6	80.1	79.5	79.0	78.4	75.8	66.6			
46	82.0	79.4	78.9	78.3	77.8	77.2	76.7	74.1				
48	81.9	77.6	77.1	76.6	76.1	75.7	75.1	72.4				
50	80.0	76.0	75.5	75.0	74.5	73.9	73.4	70.7				
52	78.1	74.3	73.8	73.3	72.7	72.2	71.7					
54	76.4	72.6	72.0	71.5								
55	75.6	71.7										
CORRECTIONS	AIR CONDITIONING OFF			ENGINE ANTI ICE ON				TOTAL ANTI ICE ON				
WEIGHT	+ 1400 kg			- 300 kg up to 9200 ft - 3400 kg above 9200 ft				- 1000 kg up to 5000 ft - 6700 kg above 5000 ft				

**PERFORMANCE**

**GO AROUND**

APPROACH CLIMB LIMITING WEIGHT - CAT II

**CAT II - CONF 3**

Ident.: PER-GOA-ACG-CAT-00002145.0062001 / 24 MAR 11

Applicable to: ALL

<b>APPROACH CLIMB LIMITING WEIGHT (1000 KG) - CONF 3 - CAT II</b>												
ONE ENGINE OUT								High Air Conditioning		Gradient : 2.5 %		
ONE ENGINE AT GO AROUND THRUST								Anti Ice OFF				
OAT (°C)	PRESSURE ALTITUDE (FT)											
	-2000	0	200	400	600	800	1000	2000	5000	9200	12000	14100
≤10	81.0	80.1	79.9	79.7	79.4	79.2	79.0	77.9	78.2	69.9	63.1	57.9
20	80.7	79.8	79.6	79.4	79.2	78.9	78.7	77.7	77.9	67.5	58.0	52.3
22	80.6	79.8	79.6	79.3	79.1	78.9	78.7	77.6	77.9	66.3	57.1	51.5
24	80.6	79.7	79.5	79.3	79.0	78.8	78.6	77.5	77.4	65.2	56.2	
26	80.5	79.7	79.4	79.2	79.0	78.8	78.5	77.5	76.6	64.0	55.4	
28	80.5	79.6	79.4	79.2	78.9	78.7	78.5	77.5	75.8	63.0		
30	80.4	79.6	79.3	79.1	78.9	78.7	78.5	77.4	74.9	62.0		
32	80.4	79.5	79.3	79.1	78.9	78.6	78.4	77.4	73.9	60.9		
34	80.3	79.5	79.3	79.1	78.8	78.6	78.4	77.4	73.0	59.8		
36	80.3	79.5	79.2	79.0	78.8	78.6	78.4	77.4	71.5	58.7		
38	80.2	79.4	79.2	79.0	78.8	78.6	78.4	77.4	69.8			
40	80.2	79.4	79.2	79.0	78.8	78.6	78.4	77.3	68.1			
42	80.1	79.4	79.2	79.0	78.7	78.5	78.3	75.6	66.5			
44	80.1	79.3	78.8	78.2	77.7	77.1	76.6	74.0	65.0			
46	80.1	77.6	77.0	76.6	76.1	75.6	75.0	72.3				
48	80.0	76.0	75.5	74.9	74.4	73.9	73.3	70.6				
50	78.1	74.3	73.8	73.2	72.7	72.2	71.7	69.0				
52	76.4	72.6	72.1	71.5	71.0	70.5	70.0					
54	74.7	70.9	70.4	69.8								
55	73.8	70.0										
CORRECTIONS	AIR CONDITIONING OFF		ENGINE ANTI ICE ON				TOTAL ANTI ICE ON					
WEIGHT	+ 1300 kg		- 300 kg up to 9200 ft - 3400 kg above 9200 ft				- 1000 kg up to 5000 ft - 6600 kg above 5000 ft					

**PERFORMANCE**

LANDING

Intentionally left blank

**PER-LDG-GEN GENERAL**

GENERAL.....	A
DISPATCH.....	B
Use of the Autobrake System.....	C

**PER-LDG-CTA RUNWAY CONTAMINATION**

**PER-LDG-CTA-10 GENERAL**

GENERAL.....	A
--------------	---

**PER-LDG-CTA-20 DEFINITIONS**

DEFINITIONS.....	A
EQUIVALENCES.....	B

**PER-LDG-DIS DISPATCH**

**PER-LDG-DIS-MAT Runway Condition Assessment Matrix for Landing**

Runway Condition Assessment Matrix for Landing.....	A
---	---

**PER-LDG-DIS-RLD REQUIRED LANDING DISTANCES / MANUAL LANDING**

RLD CONF FULL.....	A
RLD CONF 3.....	B
Example.....	C

**PER-LDG-DIS-RLA REQUIRED LANDING DISTANCES**

AUTOMATIC LANDING ON DRY RUNWAY.....	A
--------------------------------------	---




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

PRELIMINARY PAGES - TABLE OF CONTENTS

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>LANDING</b></p> <p>GENERAL</p>
---	--

**GENERAL**

Ident.: PER-LDG-GEN-00013287.0001001 / 19 APR 17

Applicable to: ALL

**REQUIRED LANDING DISTANCE (RLD) AT DISPATCH**

The RLD is the regulatory reference to be used for dispatch landing performance computation.

The RLD is the factored certified landing distance based on:

- Maximum manual braking initiated immediately after main gear touchdown
- Prompt selection of max reverse thrust, maintained to 70kt, and idle thrust to full stop (when credit is used)
- Antiskid and all spoilers operative
- The regulatory dispatch factor.

**MANUAL LANDING**

**CONTAMINATED RUNWAY**

If the surface is contaminated, EU-OPS operators must use the longer of the RLD for wet runway and the RLD for the applicable contaminant for dispatch.

**AUTOMATIC LANDING**

The RLD for automatic landing is defined as the RLD in manual landing corrected with the increment given in AFM. These increments assume maximum manual braking from main gear touchdown.

**IN-FLIGHT LANDING DISTANCE**

The flight crew should use the Landing Distances published in the QRH as the reference for In-Flight landing performance computation. The In-Flight Landing Distances reflect the performance achievable in a typical operational landing without margin, assuming realistic airborne phase from threshold to touchdown and deceleration on ground to full stop.

The In-Flight Landing Distances consider:

- Airborne phase of 7 seconds from threshold to touchdown
- Maximum manual braking initiated immediately after main gear touchdown
- Normal system delays in braking activation in case of autobrake
- Prompt selection of max reverse thrust, maintained to 70kt, and idle thrust to full stop (when credit is used)
- Antiskid and all spoilers operative.

### **FACTORED IN-FLIGHT LANDING DISTANCE**

The flight crew should apply an appropriate margin to the In-Flight Landing Distances published in the QRH to account for operational variability (e.g. in wind and runway condition reporting) and flying technique (e.g. speed and height above threshold, flare).

This factor should account for:

- The Applicable Regulations
- The Airline Policy
- The discretion of the Pilot.

The Factored In-Flight Landing Distance may in some cases, and in particular on contaminated runway, exceed the RLD considered at dispatch.

The requirements for dispatch remain unchanged and are based on the RLD. However, when arrival conditions are expected to be marginal it is recommended to make a preliminary calculation of In-Flight Landing Distance or Factored In-Flight Landing Distance at dispatch in order to nominate suitable destination alternates.

### **DISPATCH**


Ident.: PER-LDG-GEN-00013288.0001001 / 18 MAR 11

Applicable to: **ALL**

The pilot must check before departure that the available runway length at destination is at least equal to the required landing distance for the forecasted landing weight.

In case of aircraft system failure affecting landing distance known before the dispatch, the available runway length must be at least equal to the required landing distance with failure, i.e. the required landing distance without failure multiplied by the coefficient given in the Flight Manual or the MMEL.



 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>LANDING</b></p> <p>GENERAL</p>
---	--

**USE OF THE AUTOBRAKE SYSTEM**

Ident.: PER-LDG-GEN-00012045.0001001 / 22 MAY 12

**Applicable to: ALL**

The autobrake system is designed to help the pilot in case of :

- aborted takeoff or
- landing on short runways or
- operation with low visibility weather conditions

Furthermore, it ensures a straight roll-out and optimizes the landing distance on contaminated runways provided the contamination is evenly distributed.

At landing, select the braking mode according to :

- runway length
- configuration
- runway condition



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LANDING**

GENERAL

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

RUNWAY CONTAMINATION - GENERAL

### GENERAL

Ident.: PER-LDG-CTA-10-00013002.0001001 / 21 JUL 14

**Applicable to: ALL**

This section presents the recommendations of Airbus for operations from wet runways or from runways which are covered with contaminants such as standing water, slush or snow.




**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**LANDING**

RUNWAY CONTAMINATION - GENERAL

Intentionally left blank

 <p><b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL</p>	<p><b>PERFORMANCE</b></p> <p><b>LANDING</b></p> <p>RUNWAY CONTAMINATION - DEFINITIONS</p>
---	---

**DEFINITIONS**

Ident.: PER-LDG-CTA-20-00013004.0001001 / 31 AUG 17

Applicable to: ALL

- DAMP : A runway is considered as damp, when the surface of the runway is not dry, but the water on the surface does not cause a shiny appearance.
- WET : A runway is considered as wet, when the surface of the runway has a shiny appearance due to a thin film of water. When this film does not exceed 3 mm, there is no significant danger of hydroplaning.
- FROST : The deposit of ice crystals on the runway is referred to as frost. The direct sublimation of humidity contained in the air on a runway, when the surface temperature is below freezing, causes frost.
- COMPACTED SNOW : The maintenance personnel use a snow groomer to compress snow on a runway in order to obtain a hard surface.
- SLIPPERY WHEN WET: Notice to Airmen (NOTAM) report a runway as "slippery when wet", when the runway partially or entirely fails to satisfy the minimum (regulatory) friction requirement of the responsible authority.
- DRY SNOW : Dry snow is snow that, if compacted by hand, does not stay compressed when released. The wind can blow dry snow. The density of dry snow is approximately 0.2 kg/l (1.7 lb/US Gal).
- WET SNOW : Wet snow is snow that, if compacted by hand, stays compressed when released, and with which snowballs can be created. The density of wet snow is approximately 0.4 kg/l (3.35 lb/US Gal).
- STANDING WATER : Standing water occurs due to heavy rain and/or insufficient runway drainage with a depth of more than 3 mm.
- SLUSH : Slush is snow soaked with water, which spatters when stepped on firmly. Slush occurs at temperatures around 5 °C and has a density of approximately 0.85 kg/l (7.1 lb/US Gal).
- ICE (Cold and Dry) : Situation in which ice occurs on the runway in cold and dry conditions.
- WET ICE : When the ice on a runway melts, or there are loose/fluid contaminants on top of the ice, the ice is referred to as "wet ice". When there is wet ice on a runway, braking and directional control are difficult or not possible, because the runway surface is very slippery.

**PERFORMANCE**

**LANDING**

**RUNWAY CONTAMINATION - DEFINITIONS**

**EQUIVALENCES**

Ident.: PER-LDG-CTA-20-00014917.0001001 / 21 JUL 14

Applicable to: **ALL**

For the below-listed reported contaminants, the following equivalent runway conditions can be retained for the landing performance determination.

Reported contaminant		Equivalent Runway Condition
Type of contaminant	Depth of contaminant	
Slush	≤ 3 mm (1/8 in)	Wet
Water	≤ 3 mm (1/8 in)	
Wet snow	≤ 3 mm (1/8 in)	Slush
	≤ 30 mm (6/5 in)	
Dry snow	≤ 3 mm (1/8 in)	Wet
	≤ 100 mm (4 in)	Slush



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**LANDING**

DISPATCH - RUNWAY CONDITION ASSESSMENT MATRIX FOR LANDING

**RUNWAY CONDITION ASSESSMENT MATRIX FOR LANDING**

Ident.: PER-LDG-DIS-MAT-00014450.0001001 / 17 MAR 17

Applicable to: ALL

Runway Surface Conditions		Observations on Deceleration and Directional Control	Related Landing Performance		Maximum Crosswind for Landing (Gust included)
Runway State or / and Runway Contaminant	ESF <sup>(1)</sup> or PIREP <sup>(2)</sup>		Code	Level	
<b>Dry</b>	-	-	6	DRY	38 kt
<b>Damp</b> <b>Wet</b> Up to 3 mm (1/8") of water <b>Slush</b> Up to 3 mm (1/8") <b>Dry snow</b> Up to 3 mm (1/8") <b>Wet snow</b> Up to 3 mm (1/8") <b>Frost</b>	<b>Good</b>	Braking deceleration is normal for the wheel braking effort applied. Directional control is normal.	5	<b>GOOD</b>	38 kt
<b>Compacted snow</b> OAT at or below -15 °C	<b>Good to Medium</b>	Braking deceleration and controllability is between Good and Medium.	4	<b>GOOD TO MEDIUM</b>	29 kt
<b>Dry snow</b> More than 3 mm (1/8"), up to 100 mm (4") <b>Wet snow</b> More than 3 mm (1/8"), up to 30 mm (6/5") <b>Compacted snow</b> OAT above -15 °C <b>Dry snow over compacted snow</b> <b>Wet snow over compacted snow</b> <b>Slippery when wet</b>	<b>Medium</b>	Braking deceleration is noticeably reduced for the wheel braking effort applied. Directional control may be reduced.	3	<b>MEDIUM</b>	25 kt
<b>Water</b> More than 3 mm (1/8"), up to 12.7 mm (1/2") <b>Slush</b> More than 3 mm (1/8"), up to 12.7 mm (1/2")	<b>Medium to Poor</b>	Braking deceleration and controllability is between Medium and Poor. Potential for hydroplaning exists.	2	<b>MEDIUM TO POOR</b>	20 kt
<b>Ice (cold &amp; dry)</b>	<b>Poor</b>	Braking deceleration is significantly reduced for the wheel braking effort applied. Directional	1	<b>POOR</b>	15 kt

*Continued on the following page*

**PERFORMANCE**

**LANDING**

DISPATCH - RUNWAY CONDITION ASSESSMENT MATRIX FOR LANDING

*Continued from the previous page*

Runway Surface Conditions		Observations on Deceleration and Directional Control	Related Landing Performance		Maximum Crosswind for Landing (Gust included)
Runway State or / and Runway Contaminant	ESF <sup>(1)</sup> or PIREP <sup>(2)</sup>		Code	Level	
		control may be significantly reduced.			
Wet ice Water on top of Compacted Snow  Dry Snow or Wet Snow over ice	Nil	Braking deceleration is minimal to non-existent for the wheel braking effort applied. Directional control may be uncertain.	-	-	-

(1) *ESF: Estimated Surface Friction*

(2) *PIREP: Pilot Report of Braking Action*

Note: Refer for FCOM LIM-AFS chapter for Automatic Approach, Landing and Rollout limitations.





**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**LANDING**

DISPATCH - REQUIRED LANDING DISTANCES / MANUAL LANDING

**RLD CONF FULL**

Ident.: PER-LDG-DIS-RLD-00013995.0036001 / 22 MAY 12

Applicable to: ALL

The RLD in the first table considers: Sea Level (SL), ISA, no wind, no slope, no engine reverse thrust, manual landing, and VAPP=VLS.

Required landing distances (ft)						
Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Weight (1000 kg)						
46		3 820	4 390	4 490	4 450	4 600
50		3 990	4 590	4 760	4 750	4 900
54		4 160	4 790	5 030	5 040	5 210
58		4 350	5 000	5 300	5 340	5 550
62		4 550	5 230	5 570	5 650	5 960
66		4 930	5 660	5 840	5 960	6 390

Corrections on landing distances (ft)						
Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Altitude	Per 1 000 ft ABOVE SL	+ 180	+ 210	+ 260	+ 420	+ 410
Speed	Per 5 kt	+ 310	+ 370	+ 300	+ 380	+ 570
Wind	Per 5 kt TW	+ 480	+ 550	+ 510	+ 780	+ 1 070
Reverse	Per Thrust Reverser Operative	-	-	- 240	- 240	- 250
CG	Extended Forward CG	+ 80	+ 110	+ 150	+ 140	+ 170



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**

**LANDING**

DISPATCH - REQUIRED LANDING DISTANCES / MANUAL LANDING

**RLD CONF 3**


Ident.: PER-LDG-DIS-RLD-00013996.0036001 / 22 MAY 12

Applicable to: ALL

The RLD in the first table considers: Sea Level (SL), ISA, no wind, no slope, no engine reverse thrust, manual landing, and VAPP=VLS.

Required landing distances (ft)						
Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Weight (1000 kg)						
46		4 070	4 680	4 900	4 890	5 050
50		4 270	4 900	5 200	5 220	5 390
54		4 460	5 120	5 490	5 540	5 770
58		4 670	5 370	5 780	5 880	6 250
62		4 980	5 730	6 080	6 220	6 740
66		5 470	6 290	6 380	6 630	7 250

Corrections on landing distances (ft)						
Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Altitude	Per 1 000 ft ABOVE SL					
Speed	Per 5 kt	+ 340	+ 390	+ 320	+ 500	+ 660
Wind	Per 5 kt TW	+ 490	+ 560	+ 530	+ 880	+ 1 220
Reverse	Per Thrust Reverser Operative	-	-	- 290	- 300	- 300
CG	Extended Forward CG	+ 90	+ 100	+ 170	+ 210	+ 200

 <b>A318/A319/A320/A321</b> FLIGHT CREW OPERATING MANUAL	<b>PERFORMANCE</b> <b>LANDING</b> DISPATCH - REQUIRED LANDING DISTANCES / MANUAL LANDING
---	--

**EXAMPLE**

Ident.: PER-LDG-DIS-RLD-00014743.0001001 / 29 JUL 16

Applicable to: ALL

**EXAMPLE 1**

The following data and graphs are for example only, and are not for operational use. Even if the data in the following example is in “kg” and “m”, the same method can be applied for “lb” and “ft”.

**Required Landing Distance (RLD) determination with multiple corrections**

Data: Landing CONF = CONF FULL

LW = 58 T

DRY runway

Airport altitude = 2 000 ft

Approach speed = VLS

5 kt TW

ISA conditions

No slope

Read the reference distance for 58 T from RLD table:

Required Landing Distances (m)					
Runway State	Dry	Wet	Compacted snow	Slush	Standing Water
Weight (1000 kg)					
46	1 150	1 320	1 310	1 300	1 350
50	Do not use for operational purpose				
54	1 260	1 450	1 480	1 480	1 530
58	1 320	1 510	1 560	1 570	1 630
62	1 380	1 580	1 640	1 670	1 750
66	1 480	1 710	1 730	1 760	1 880

RLD (DRY, 0 ft, VLS, no wind) = 1 320 m

Read the different corrections:

Corrections on Landing Distances (m)						
Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Altitude	Per 1 000 ft ABOVE SL	+ 60	+ 70	+ 90	+ 130	+ 140
Speed	Per 5 kt	+ 100	+ 100	+ 80	+ 110	+ 160
Wind	Per 5 kt TW	+ 140	+ 170	+ 150	+ 220	+ 300
Reverse	Per Thrust Reverser Operative	-	-	- 90	- 90	- 110
CG	Extended Forward CG	+ 30	+ 30	+ 40	+ 40	+ 50

Altitude correction:  $60 \times 2 = +120$  m

Wind correction:  $140 \times 1 = +140$  m

RLD (DRY, 2 000 ft, VLS, 5 kt TW) =  $1\ 320 + 120 + 140 = 1\ 580$  m

**EXAMPLE 2**

**Required Landing Distance (RLD) calculation with WET CHECK (Mandatory for EASA operators)**

Data: Landing CONF = CONF FULL

LW = 58 T

Runway covered with STANDING WATER

Airport altitude = 2 000 ft

Approach speed = VLS

Credit for all thrust reversers

ISA conditions

No slope

**Required Landing Distances (m)**

Runway State Weight (1000 kg)		Dry	Wet	Compacted snow	Slush	Standing Water
50	1 210	1 390	1 400	1 390	1 440	
54	1 260	1 450	1 480	1 480	1 530	
58	1 320	1 510	1 560	1 570	1 630	
62	1 380	1 580	1 640	1 670	1 750	
66	1 480	1 710	1 730	1 760	1 880	

**Corrections on Landing Distances (m)**

Runway State		Dry	Wet	Compacted snow	Slush	Standing Water
Altitude	Per 1 000 ft ABOVE SL	+ 60	+ 70	+ 90	+ 130	+ 140
Speed	Per 5 kt	+ 100	+ 100	+ 80	+ 110	+ 160
Wind	Per 5 kt TW	+ 140	+ 170	+ 150	+ 220	+ 300
Reverse	Per Thrust Reverser Operative	-	-	- 90	- 90	- 110
CG	Extended Forward CG	+ 30	+ 30	+ 40	+ 40	+ 50

RLD (WATER, 2 000 ft, VLS, no wind, all reversers) =  $1\ 630 + 140 \times 2 - 110 \times 2 = 1\ 690$  m

Compare this distance to the landing distance in the same conditions on WET runway:

RLD (WET, 2 000 ft, VLS, no wind) =  $1\ 510 + 70 \times 2 = 1\ 650$  m



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

DISPATCH - REQUIRED LANDING DISTANCES / MANUAL LANDING

RLD (WET) < RLD (WATER), therefore RLD = 1 690 m



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

DISPATCH - REQUIRED LANDING DISTANCES / MANUAL LANDING

Intentionally left blank



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

DISPATCH - REQUIRED LANDING DISTANCES

### AUTOMATIC LANDING ON DRY RUNWAY

Ident.: PER-LDG-DIS-RLA-00013359.0204001 / 18 MAR 11

Applicable to: ALL

Determine the corrected required landing distance for manual landing from the data above.

The required landing distance for automatic landing is equal to the corrected required landing distance for manual landing except in the following case:

- In case of landing in CONF 3 with landing weight equal to or less than 55 000 kg and with no wind or headwind, it is equal to the corrected required landing distance for manual required landing increased by 310 ft.
- In case of landing in CONF FULL with landing weight equal to or less than 70 000 kg it is equal to the corrected required landing distance for manual required landing increased by 290 ft.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### LANDING

DISPATCH - REQUIRED LANDING DISTANCES

Intentionally left blank



# **PERFORMANCE**

ONE ENGINE INOPERATIVE

Intentionally left blank

**PER-OEI-GEN GENERAL**

INTRODUCTION.....A  
 FLIGHT PREPARATION.....B  
 STRATEGY.....C

**PER-OEI-ALT ALTITUDE**

**PER-OEI-ALT-10 CEILINGS**

Ceilings.....A

**PER-OEI-CRT CRUISE TABLES**

**PER-OEI-CRT-10 STANDARD AND OBSTACLE STRATEGIES**

LONG RANGE CRUISE - 1 ENGINE OUT - ISA.....A  
 LONG RANGE CRUISE - 1 ENGINE OUT - ISA +20.....B

**PER-OEI-CRT-20 FIXED SPEED STRATEGIES**

CRUISE - MCT/VMO - 1 ENGINE OUT - ISA.....A  
 CRUISE - MCT/VMO - 1 ENGINE OUT - ISA +20.....B  
 CRUISE - MCT/320KT - 1 ENGINE OUT - ISA.....C  
 CRUISE - MCT/320KT - 1 ENGINE OUT - ISA +20.....D

**PER-OEI-ICQ IN CRUISE QUICK CHECK**

**PER-OEI-ICQ-10 STANDARD STRATEGIES**

IN CRUISE QUICK CHECK AT LONG RANGE SPEED.....A  
 CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT.....B

**PER-OEI-ICQ-20 FIXED SPEED STRATEGIES**

GENERAL.....A  
 CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT.....B  
 IN CRUISE QUICK CHECK VMO.....C  
 IN CRUISE QUICK CHECK 320KT.....D

**PER-OEI-HLD HOLDING**

HOLDING.....A

**PER-OEI-DES DESCENT**

**PER-OEI-DES-10 STANDARD STRATEGY**

DESCENT - M.78/300KT.....A

**PER-OEI-DES-15 OBSTACLE STRATEGY**

GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED - ISA.....A  
 GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED - ISA +20.....B

*Continued on the following page*



AEROLINEAS GALAPAGOS S.A.

**A318/A319/A320/A321**

**FLIGHT CREW  
OPERATING MANUAL**

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

**PRELIMINARY PAGES - TABLE OF CONTENTS**

*Continued from the previous page*

**PER-OEI-DES-20 FIXED SPEED STRATEGIES**

DESCENT - M.80/350KT ..... A

DESCENT - M.78/320KT ..... B

**PER-OEI-DES-30 DESCENT TO LANDING**

DESCENT TO LANDING..... A

## INTRODUCTION

Ident.: PER-OEI-GEN-00002064.0001001 / 10 DEC 09

**Applicable to: ALL**

This chapter provides the single engine performance data to be used for the conduct and monitoring of the flight following an engine failure.

The diversion strategy (descent and cruise speed schedules) shall be selected, and specified in the operator's routes specifications, as a function of the prevailing operational factors (e.g. obstacles clearance requirements and/or ETOPS operation).

## FLIGHT PREPARATION

Ident.: PER-OEI-GEN-00002065.0001001 / 01 DEC 14

**Applicable to: ALL**

In readiness for a possible engine failure occurring during the flight, any flight shall be planned so as to comply with any of the following requirements, as applicable :

- obstacle clearance,
- oxygen,
- maximum diversion distance (ETOPS operation).

The following FCOM sections provide flight preparation and fuel planning information :

- *Refer to PER-FPL-GEN-MFR MINIMUM RECOMMENDED FUEL REQUIREMENTS*, for Standard Fuel Planning,
- *Refer to PRO-SPO-40-10 General*, for Extended Range Operation (ETOPS) and associated fuel requirements.

**STRATEGY**

Ident.: PER-OEI-GEN-00002067.0001001 / 23 NOV 11

Applicable to: ALL

Depending on the prevailing operational constraints, the most appropriate diversion strategy shall be selected, out of the following options:

	STANDARD STRATEGY	OBSTACLE STRATEGY	FIXED SPEED STRATEGIES	
			320 kt	VMO
<b>DESCENT TO CEILING</b>	<ul style="list-style-type: none"> <li>M .78/300 kt</li> <li>MCT</li> </ul>	<ul style="list-style-type: none"> <li>Green Dot Speed</li> <li>MCT</li> </ul>	<ul style="list-style-type: none"> <li>M .78/320 kt</li> <li>MCT</li> </ul>	<ul style="list-style-type: none"> <li>M .80/350 kt</li> <li>MCT</li> </ul>
<b>CRUISE</b>	LR ceiling LR speed	<ul style="list-style-type: none"> <li><u>Obstacle not cleared:</u> Maintain Green Dot Speed at MCT</li> <li><u>Obstacle cleared :</u> Revert to standard strategy</li> </ul>	FL per Refer to PRO-SPO-40-60 ETOPS Fuel Requirement from Critical Point to Landing - One Engine Out - Cruise at 320kt MCT/320 kt	FL per Refer to PRO-SPO-40-60 ETOPS Fuel Requirement from Critical Point to Landing - One Engine Out - Cruise at 350kt MCT/350 kt
<b>DESCENT TO LANDING</b>	IDLE/M .78/300 kt/250 kt			
<b>Approx increase in fuel consumption compared with both engines operative</b>	+33 %			

For ETOPS operations, any of the above diversion strategies can be used provided that the selected strategy and speed schedule is used in:

- establishing the area of operation (maximum diversion distance), Refer to PRO-SPO-40-60 General,
- calculating the diversion fuel requirements for the single engine ETOPS critical scenario, Refer to PRO-SPO-40-30 ETOPS Fuel Scenarios,
- demonstrating the applicable obstacle clearance requirements (net flight path and net ceiling).

During the diversion, the flight crew is expected to use the planned speed schedule.

However, based on the evaluation of the actual situation, the pilot in command has the authority to deviate from this planned one engine inoperative speed.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

ALTITUDE - CEILINGS

**CEILINGS**

Ident.: PER-OEI-ALT-10-00016065.0001001 / 22 MAR 17

**Applicable to: ALL**

*Refer to QRH/PER-L Ceilings (Paper Only) or use the performance application of FlySmart with Airbus.*



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

ALTITUDE - CEILINGS

Intentionally left blank





**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

CRUISE TABLES - STANDARD AND OBSTACLE STRATEGIES

**LONG RANGE CRUISE - 1 ENGINE OUT - ISA**

Ident.: PER-OEI-CRT-10-00002108.0020001 / 10 DEC 09

Applicable to: ALL

LONG RANGE CRUISE - 1 ENGINE OUT												
MAX. CONTINUOUS THRUST LIMITS PACK FLOW HI ANTI-ICING OFF						ISA CG=33.0%		N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)		
WEIGHT (1000KG)	FL100		FL120		FL140		FL160		FL180		FL200	
<b>50</b>	75.5	.453	77.4	.472	78.9	.487	80.3	.500	81.8	.516	82.7	.525
	1891	251	1888	251	1867	250	1842	247	1824	245	1783	240
	153.0	289	158.3	299	163.9	306	169.6	312	175.1	319	180.8	322
<b>52</b>	76.7	.463	78.5	.480	79.7	.492	81.3	.508	82.5	.520	83.6	.532
	1967	256	1959	256	1924	253	1908	251	1876	247	1852	243
	150.1	295	155.3	304	160.9	309	166.1	317	171.5	322	176.6	327
<b>54</b>	77.8	.471	79.3	.486	80.7	.499	82.2	.515	83.1	.524	84.5	.540
	2041	261	2021	259	1991	256	1973	254	1929	249	1924	247
	147.4	301	152.5	308	157.8	314	162.8	321	168.1	324	172.5	332
<b>56</b>	78.9	.479	80.1	.492	81.6	.507	82.9	.519	83.9	.530	85.4	.547
	2112	265	2078	262	2059	260	2029	257	1998	252	1995	250
	144.9	306	149.9	311	154.7	319	159.7	324	164.4	328	168.6	336
<b>58</b>	79.7	.485	80.9	.498	82.5	.513	83.5	.523	84.7	.537	86.0	.552
	2175	268	2141	265	2126	264	2081	258	2068	256	2057	253
	142.4	310	147.3	315	151.9	323	156.7	326	160.9	333	164.9	339
<b>60</b>	80.4	.490	81.8	.504	83.3	.519	84.2	.528	85.6	.545	86.7	.556
	2233	271	2209	269	2187	266	2145	261	2141	259	2119	255
	140.1	313	144.6	320	149.1	326	153.7	330	157.5	337	161.3	342
<b>62</b>	81.1	.495	82.7	.511	83.8	.522	84.9	.534	86.3	.550	87.3	.561
	2292	274	2277	272	2239	268	2214	264	2209	262	2183	256
	137.9	316	142.1	324	146.5	328	150.6	333	154.3	341	157.7	344
<b>64</b>	82.0	.502	83.5	.517	84.4	.525	85.7	.541	86.9	.555	88.1	.567
	2363	278	2343	276	2293	270	2289	268	2272	264	2259	259
	135.5	320	139.7	327	144.0	330	147.6	338	151.1	343	154.1	348
<b>66</b>	82.8	.508	84.1	.520	85.1	.531	86.5	.548	87.5	.558	88.7	.570
	2431	281	2399	278	2362	273	2362	271	2334	266	2325	261
	133.3	324	137.4	330	141.3	334	144.7	342	148.1	346	150.6	350
<b>68</b>	83.6	.514	84.6	.523	85.8	.537	87.1	.552	88.1	.562	89.2	.571
	2499	284	2453	279	2433	276	2426	273	2401	268	2383	261
	131.2	328	135.2	332	138.7	338	142.0	344	145.0	348	147.2	351
<b>70</b>	84.3	.519	85.1	.527	86.5	.543	87.6	.556	88.8	.569	90.2	.581
	2563	287	2510	281	2506	279	2488	275	2481	271	2492	266
	129.1	331	133.0	334	136.2	341	139.4	347	141.9	352	143.1	357
<b>72</b>	84.8	.522	85.8	.532	87.2	.549	88.2	.559	89.4	.571	91.1	.588
	2619	289	2582	284	2580	282	2553	277	2544	272	2595	270
	127.1	333	130.7	337	133.7	345	136.7	349	139.0	353	139.3	361
<b>74</b>	85.3	.524	86.5	.538	87.7	.553	88.8	.563	89.9	.572	92.0	.595
	2672	291	2655	287	2645	284	2618	279	2602	273	2697	273
	125.3	335	128.4	341	131.4	348	134.2	351	136.1	354	135.6	366
<b>76</b>	85.8	.528	87.1	.544	88.2	.556	89.4	.568	90.8	.580	93.1	.606
	2731	293	2729	291	2707	286	2697	282	2710	277	2821	278
	123.4	337	126.3	345	129.2	350	131.5	355	132.6	359	132.0	372
<b>78</b>	86.4	.533	87.8	.549	88.8	.559	90.0	.572	91.6	.588	93.7	.607
	2802	295	2802	293	2772	288	2767	283	2817	281	2883	279
	121.4	340	124.2	348	126.9	352	128.9	357	129.3	364	129.3	373
<b>ENGINE ANTI ICE ON</b> ΔFUEL = + 3.5 %						<b>TOTAL ANTI ICE ON</b> ΔFUEL = + 7 %						

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

CRUISE TABLES - STANDARD AND OBSTACLE STRATEGIES

LONG RANGE CRUISE - 1 ENGINE OUT												
MAX. CONTINUOUS THRUST LIMITS						ISA		N1 (%)		MACH		
PACK FLOW HI						CG = 33.0%		KG/H		IAS (KT)		
ANTI-ICING OFF								NM/1000KG		TAS (KT)		
WEIGHT (1000KG)	FL210		FL220		FL230		FL240		FL250		FL260	
<b>50</b>	83.3	533	84.1	541	84.7	549	85.2	554	85.8	560	86.5	567
	1778	238	1777	237	1771	236	1759	233	1750	231	1752	229
	183.3	326	185.6	330	188.0	333	190.4	335	192.5	337	194.1	340
<b>52</b>	84.3	541	85.0	548	85.5	554	86.0	559	86.7	567	87.2	568
	1851	242	1846	241	1833	238	1821	235	1825	234	1807	230
	178.8	331	181.1	334	183.4	336	185.4	338	187.0	341	188.5	341
<b>54</b>	85.2	548	85.7	553	86.2	558	86.9	566	87.4	568	88.4	580
	1920	246	1907	243	1896	240	1898	239	1880	235	1912	235
	174.6	335	176.8	337	178.8	339	180.4	342	181.8	342	181.8	348
<b>56</b>	85.9	553	86.4	558	87.0	565	87.6	569	88.4	577	88.6	568
	1983	248	1970	245	1969	243	1958	240	1975	238	1917	229
	170.7	338	172.6	340	174.2	343	175.5	344	175.9	347	177.5	340
<b>58</b>	86.5	557	87.1	564	87.7	569	88.5	574	89.5	586	88.5	539
	2045	250	2041	248	2035	245	2039	242	2075	242	1899	217
	166.8	341	168.3	344	169.7	345	170.3	347	170.1	353	170.2	323
<b>60</b>	87.2	562	87.9	569	88.4	571	89.5	585	90.6	595		
	2112	252	2112	250	2100	246	2144	247	2178	246		
	162.9	344	164.2	347	165.2	347	164.9	353	164.5	358		
<b>62</b>	88.0	569	88.5	570	89.6	583	90.6	593	92.1	610		
	2190	255	2169	251	2211	251	2243	250	2302	253		
	159.0	348	160.2	347	160.0	354	159.7	358	159.3	367		
<b>64</b>	88.6	570	89.5	579	90.5	590	91.8	605	92.4	601		
	2247	256	2270	255	2306	254	2362	256	2323	249		
	155.2	349	155.5	353	155.2	358	154.8	366	155.7	362		
<b>66</b>	89.4	575	90.4	587	91.5	599	92.6	605	92.6	582		
	2327	258	2371	259	2413	258	2422	256	2315	241		
	151.2	352	150.9	358	150.6	363	151.0	366	151.3	350		
<b>68</b>	90.3	584	91.4	595	92.7	609	92.9	594				
	2434	263	2473	262	2523	263	2434	251				
	146.9	358	146.6	363	146.5	370	147.5	359				
<b>70</b>	91.2	591	92.6	606	93.1	601	93.0	569				
	2529	266	2595	267	2547	260	2418	240				
	142.9	362	142.4	370	143.3	365	142.3	344				
<b>72</b>	92.2	599	93.2	605	93.3	585						
	2638	269	2648	267	2543	252						
	138.9	366	139.3	369	139.7	355						
<b>74</b>	93.3	609	93.5	597	93.5	554						
	2752	274	2666	263	2524	238						
	135.4	373	136.4	364	133.1	336						
<b>76</b>	93.6	603	93.6	577								
	2778	271	2656	254								
	132.7	369	132.3	351								
<b>78</b>	93.9	591										
	2784	265										
	129.8	361										
ENGINE ANTI ICE ON						TOTAL ANTI ICE ON						
$\Delta$ FUEL = + 3.5 %						$\Delta$ FUEL = + 7 %						



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

**CRUISE TABLES - STANDARD AND OBSTACLE STRATEGIES**

**LONG RANGE CRUISE - 1 ENGINE OUT - ISA +20**

Ident.: PER-OEI-CRT-10-00002111.0063001 / 04 MAR 11

Applicable to: ALL

LONG RANGE CRUISE - 1 ENGINE OUT												
MAX. CONTINUOUS THRUST LIMITS PACK FLOW HI ANTI-ICING OFF						ISA +20 CG=33.0%		N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)		
WEIGHT (1000KG)	FL100		FL120		FL140		FL160		FL180		FL200	
<b>50</b>	78.2	.450	80.2	.468	81.8	.484	83.3	.498	84.9	.513	85.9	.523
	1957	249	1957	249	1940	248	1916	246	1901	244	1864	239
	152.2	298	157.3	308	162.7	316	168.2	322	173.6	330	179.1	334
<b>52</b>	79.4	.459	81.3	.477	82.6	.489	84.3	.506	85.6	.517	86.8	.530
	2036	254	2032	254	1999	251	1989	250	1958	246	1937	242
	149.3	304	154.3	313	159.6	319	164.7	328	169.9	333	174.8	339
<b>54</b>	80.5	.468	82.2	.483	83.7	.497	85.4	.513	86.3	.521	87.8	.538
	2113	259	2098	258	2075	255	2060	253	2015	248	2012	246
	146.5	309	151.4	318	156.4	324	161.3	332	166.4	335	170.7	343
<b>56</b>	81.7	.476	83.0	.488	84.7	.504	86.0	.517	87.1	.529	88.6	.545
	2190	263	2158	260	2147	259	2118	255	2090	251	2087	249
	143.8	315	148.7	321	153.3	329	158.1	335	162.7	340	166.8	348
<b>58</b>	82.6	.482	83.9	.495	85.6	.511	86.6	.521	88.0	.536	89.4	.550
	2260	267	2229	264	2217	262	2175	257	2165	255	2155	252
	141.3	319	145.9	325	150.4	333	155.1	337	159.2	345	163.0	351
<b>60</b>	83.3	.487	84.9	.502	86.3	.516	87.4	.526	88.9	.543	90.0	.554
	2322	270	2303	268	2280	265	2244	260	2243	258	2222	254
	138.9	323	143.3	330	147.6	337	152.0	341	155.7	349	159.4	354
<b>62</b>	84.1	.493	85.8	.509	86.9	.519	88.2	.533	89.6	.548	90.7	.559
	2388	273	2375	271	2337	267	2318	264	2314	261	2290	256
	136.6	326	140.7	334	145.0	339	148.9	345	152.4	353	155.8	357
<b>64</b>	85.0	.500	86.6	.515	87.5	.523	89.0	.539	90.2	.553	91.5	.565
	2464	277	2446	275	2396	269	2396	267	2381	263	2372	259
	134.2	331	138.2	338	142.4	341	145.9	350	149.3	356	152.1	361
<b>66</b>	85.8	.506	87.2	.518	88.3	.529	89.8	.546	90.8	.557	92.1	.567
	2537	280	2505	276	2471	272	2472	270	2449	265	2437	260
	131.9	335	135.9	340	139.7	345	143.0	354	146.2	358	148.6	362
<b>68</b>	86.6	.511	87.7	.521	89.0	.535	90.4	.550	91.5	.561	92.7	.569
	2607	283	2563	278	2546	275	2541	272	2520	267	2506	261
	129.8	338	133.7	343	137.1	349	140.3	356	143.2	361	145.1	364
<b>70</b>	87.4	.516	88.3	.525	89.7	.541	90.9	.554	92.2	.567	93.7	.580
	2674	286	2627	280	2624	278	2607	274	2604	270	2626	266
	127.7	342	131.4	345	134.5	353	137.6	359	140.1	365	141.0	370
<b>72</b>	87.9	.519	89.0	.531	90.4	.547	91.5	.557	92.8	.569	94.5	.584
	2732	288	2703	284	2701	281	2675	276	2668	271	2715	268
	125.7	343	129.1	349	132.1	357	135.0	361	137.1	366	137.4	373
<b>74</b>	88.3	.522	89.7	.536	91.0	.551	92.1	.562	93.3	.570	94.6	.573
	2789	289	2779	287	2772	284	2750	278	2735	272	2711	262
	123.8	345	126.9	353	129.7	360	132.3	364	134.1	367	134.8	366
<b>76</b>	88.9	.526	90.4	.542	91.5	.555	92.8	.567	93.9	.572	94.6	.556
	2856	291	2857	290	2839	285	2832	281	2803	272	2706	254
	121.9	348	124.7	356	127.5	362	129.7	367	131.2	368	131.1	355
<b>78</b>	89.5	.531	91.0	.547	92.1	.558	93.3	.569	94.0	.561	94.8	.528
	2930	294	2934	292	2909	287	2900	282	2801	267	2700	241
	119.9	351	122.6	360	125.2	364	127.2	369	128.8	361	124.8	337
<b>ENGINE ANTI ICE ON</b> ΔFUEL = + 3.5 %						<b>TOTAL ANTI ICE ON</b> ΔFUEL = + 7 %						

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

CRUISE TABLES - STANDARD AND OBSTACLE STRATEGIES

LONG RANGE CRUISE - 1 ENGINE OUT												
MAX. CONTINUOUS THRUST LIMITS PACK FLOW HI ANTI-ICING OFF						ISA +20 CG = 33.0%		N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)		
WEIGHT (1000KG)	FL210		FL220		FL230		FL240		FL250		FL260	
<b>50</b>	86.6	531	87.4	540	88.1	547	88.6	552	89.2	558	89.5	556
	1863	238	1862	237	1857	235	1846	233	1838	230	1799	225
	181.5	338	183.7	342	186.0	345	188.3	348	190.3	350	193.1	347
<b>52</b>	87.6	539	88.3	547	88.9	552	89.4	558	90.1	564	89.5	539
	1937	241	1934	240	1923	238	1914	235	1913	233	1787	217
	177.0	343	179.2	347	181.3	349	183.3	351	184.9	354	188.3	336
<b>54</b>	88.5	546	89.0	552	89.6	557	90.4	565	90.8	565	89.5	500
	2010	245	2000	242	1990	240	1993	238	1972	233	1764	201
	172.8	347	174.9	350	176.8	352	178.2	355	179.7	354	177.0	312
<b>56</b>	89.2	551	89.8	556	90.5	564	91.0	566	92.0	576		
	2076	247	2066	244	2069	243	2052	239	2083	238		
	168.8	351	170.6	353	172.1	356	173.4	356	173.5	361		
<b>58</b>	89.9	555	90.6	562	91.2	566	92.0	574	92.6	574		
	2142	249	2142	247	2133	244	2149	242	2131	237		
	164.9	353	166.4	356	167.6	358	168.0	361	168.7	360		
<b>60</b>	90.6	560	91.3	566	92.0	571	93.0	580	92.6	554		
	2215	251	2212	249	2212	246	2242	245	2121	229		
	160.9	356	162.2	359	162.9	360	162.8	365	163.8	347		
<b>62</b>	91.4	566	91.9	567	93.1	580	93.0	565	92.7	489		
	2294	254	2273	249	2323	250	2234	238	2095	201		
	157.0	360	158.1	359	157.8	366	159.2	356	146.4	307		
<b>64</b>	92.0	567	93.0	578	93.4	574	93.1	540				
	2354	254	2388	254	2350	247	2223	227				
	153.3	361	153.3	366	154.2	362	152.9	340				
<b>66</b>	92.9	574	93.7	581	93.4	555						
	2449	258	2469	256	2341	239						
	149.0	365	149.1	368	149.8	351						
<b>68</b>	93.9	582	93.8	567	93.6	517						
	2560	262	2463	249	2327	222						
	144.8	371	146.0	360	140.3	327						
<b>70</b>	94.2	576	93.9	546								
	2587	259	2455	240								
	141.7	367	141.1	346								
<b>72</b>	94.2	561										
	2582	252										
	138.3	357										
<b>74</b>	94.3	537										
	2574	241										
	132.8	342										
<b>76</b>												
<b>78</b>												
ENGINE ANTI ICE ON ΔFUEL = + 3.5 %						TOTAL ANTI ICE ON ΔFUEL = + 7 %						



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

CRUISE TABLES - FIXED SPEED STRATEGIES

**CRUISE - MCT/VMO - 1 ENGINE OUT - ISA**

Ident.: PER-OEI-CRT-20-00002112.0023001 / 09 DEC 09

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

**CRUISE TABLES - FIXED SPEED STRATEGIES**

Applicable to: ALL

<b>CRUISE - MCT/VMO - 1 ENGINE OUT</b>												
MAX. CONTINUOUS THRUST PACK FLOW HI ANTI-ICING OFF					ISA CG=33.0%		N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)			
WEIGHT (1000KG)	FL100		FL150		FL160		FL180		FL200		FL220	
<b>50</b>	89.6	.609	91.3	.641	91.4	.645	91.1	.644	91.3	.649	91.1	.647
	3249	338	3072	325	3010	321	2798	308	2663	299	2480	286
	119.6	389	130.7	402	133.7	403	142.5	399	149.7	399	158.9	394
<b>52</b>	89.6	.608	91.3	.640	91.5	.644	91.2	.643	91.4	.647	91.2	.645
	3251	338	3076	325	3015	321	2804	308	2673	298	2490	285
	119.3	388	130.3	401	133.3	402	141.9	398	148.7	398	157.8	393
<b>54</b>	89.6	.607	91.3	.639	91.5	.642	91.2	.641	91.5	.645	91.3	.642
	3252	337	3080	324	3019	320	2811	307	2683	297	2500	284
	119.1	387	129.9	400	132.8	401	141.2	397	147.8	397	156.5	391
<b>56</b>	89.6	.605	91.4	.637	91.6	.641	91.3	.639	91.6	.644	91.5	.640
	3254	337	3084	323	3024	319	2820	306	2694	296	2512	283
	118.8	386	129.4	399	132.2	400	140.4	396	146.8	395	155.2	390
<b>58</b>	89.6	.604	91.4	.636	91.6	.639	91.4	.638	91.8	.642	91.6	.637
	3255	336	3088	322	3029	318	2828	305	2705	295	2525	281
	118.4	386	128.9	398	131.7	399	139.6	395	145.7	394	153.8	388
<b>60</b>	89.6	.603	91.5	.634	91.7	.637	91.5	.636	91.9	.639	91.8	.634
	3257	335	3093	321	3035	317	2836	304	2717	294	2539	280
	118.1	385	128.4	397	131.1	398	138.8	394	144.6	393	152.2	386
<b>62</b>	89.7	.601	91.5	.632	91.7	.636	91.6	.634	92.0	.637	91.9	.630
	3259	334	3098	320	3041	316	2845	303	2731	293	2554	278
	117.7	384	127.8	396	130.4	397	137.9	392	143.3	391	150.4	384
<b>64</b>	89.7	.600	91.6	.630	91.8	.634	91.7	.631	92.2	.634	92.1	.627
	3260	333	3104	319	3047	315	2856	302	2745	292	2571	277
	117.4	383	127.2	395	129.8	395	136.9	391	142.0	390	148.6	382
<b>66</b>	89.7	.598	91.6	.628	91.9	.631	91.8	.629	92.3	.632	92.3	.622
	3258	332	3109	318	3054	314	2868	301	2761	291	2587	275
	117.1	381	126.5	393	129.1	394	135.8	389	140.5	388	146.6	379
<b>68</b>	89.7	.595	91.7	.626	91.9	.629	91.9	.626	92.5	.629	92.6	.617
	3257	331	3116	317	3061	313	2881	300	2779	289	2605	272
	116.7	380	125.9	392	128.3	393	134.6	388	139.0	386	144.4	376
<b>70</b>	89.7	.593	91.7	.624	92.0	.627	92.0	.623	92.7	.625	92.9	.612
	3255	330	3122	316	3068	312	2896	298	2797	287	2625	270
	116.3	379	125.1	391	127.5	391	133.3	386	137.3	384	142.1	373
<b>72</b>	89.7	.591	91.8	.621	92.1	.624	92.2	.620	92.9	.621	93.2	.605
	3253	328	3129	315	3077	310	2911	297	2817	286	2648	267
	115.9	377	124.4	389	126.6	390	131.9	384	135.5	382	139.3	369
<b>74</b>	89.7	.588	91.9	.619	92.2	.621	92.4	.617	93.1	.617	93.5	.597
	3251	327	3137	313	3086	309	2928	295	2836	283	2666	263
	115.5	376	123.5	387	125.6	388	130.4	382	133.6	379	136.4	364
<b>76</b>	89.7	.586	92.0	.616	92.3	.618	92.5	.613	93.4	.612	93.6	.577
	3249	325	3145	312	3097	307	2946	293	2857	281	2656	254
	115.1	374	122.6	386	124.6	386	128.8	380	131.6	376	132.3	351
<b>78</b>	89.7	.583	92.0	.612	92.4	.615	92.7	.609	93.7	.607		
	3246	324	3154	310	3109	305	2967	291	2883	279		
	114.6	372	121.6	384	123.3	383	127.1	377	129.3	373		
<b>ENGINE ANTI ICE ON</b>						<b>TOTAL ANTI ICE ON</b>						
ΔFUEL = + 1.5 %						ΔFUEL = + 4 %						



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

CRUISE TABLES - FIXED SPEED STRATEGIES

### CRUISE - MCT/VMO - 1 ENGINE OUT - ISA +20

Ident.: PER-OEI-CRT-20-00002115.0043001 / 09 DEC 09



**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

**CRUISE TABLES - FIXED SPEED STRATEGIES**

Applicable to: ALL

CRUISE - MCT/VMO - 1 ENGINE OUT												
MAX. CONTINUOUS THRUST PACK FLOW HI ANTI-ICING OFF					ISA+20 CG=33.0%	N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)				
WEIGHT (1000KG)	FL100		FL150		FL160		FL180		FL200		FL220	
<b>50</b>	90.1	.577	92.5	.612	92.7	.617	92.8	.620	93.1	.626	92.8	.621
	3029	321	2912	310	2864	307	2712	297	2595	288	2402	274
	126.1	382	136.6	398	139.5	400	147.2	399	154.0	400	163.9	394
<b>52</b>	90.1	.576	92.5	.610	92.8	.615	92.9	.619	93.2	.624	92.9	.619
	3028	320	2916	309	2869	306	2720	296	2604	287	2411	273
	125.8	381	136.1	397	138.9	399	146.3	398	153.0	398	162.6	392
<b>54</b>	90.1	.574	92.5	.609	92.8	.613	93.0	.617	93.3	.622	93.0	.616
	3027	319	2921	308	2874	305	2729	295	2615	286	2422	272
	125.5	380	135.5	396	138.3	397	145.4	397	151.8	397	161.1	390
<b>56</b>	90.1	.573	92.6	.607	92.9	.612	93.0	.615	93.5	.620	93.2	.612
	3026	318	2926	307	2880	304	2738	294	2626	285	2434	270
	125.2	379	134.9	395	137.6	396	144.4	395	150.7	396	159.4	388
<b>58</b>	90.1	.571	92.6	.605	92.9	.610	93.1	.613	93.6	.617	93.3	.608
	3025	317	2932	306	2886	303	2749	293	2637	284	2447	268
	124.9	378	134.2	393	136.8	395	143.4	394	149.4	394	157.6	386
<b>60</b>	90.1	.569	92.7	.603	93.0	.607	93.2	.610	93.7	.614	93.5	.604
	3023	316	2938	305	2892	302	2759	292	2650	282	2463	266
	124.5	376	133.4	392	136.1	394	142.3	393	148.0	392	155.5	383
<b>62</b>	90.1	.567	92.7	.601	93.0	.605	93.4	.608	93.9	.611	93.7	.599
	3022	314	2944	304	2899	300	2771	290	2665	281	2478	264
	124.1	375	132.7	391	135.2	392	141.1	391	146.5	390	153.3	380
<b>64</b>	90.1	.564	92.8	.598	93.1	.603	93.5	.605	94.0	.608	93.7	.591
	3020	313	2945	303	2906	299	2784	289	2680	279	2474	260
	123.6	373	132.0	389	134.4	390	139.8	389	144.9	388	151.5	375
<b>66</b>	90.1	.562	92.8	.595	93.2	.600	93.6	.602	94.2	.604	93.7	.581
	3018	312	2943	301	2913	298	2798	288	2699	277	2469	256
	123.1	372	131.4	387	133.4	389	138.4	387	143.0	386	149.1	368
<b>68</b>	90.1	.559	92.8	.591	93.2	.596	93.7	.598	94.4	.600	93.8	.567
	3017	310	2941	299	2911	296	2808	286	2720	275	2463	249
	122.6	370	130.7	385	132.7	386	137.1	385	140.9	383	146.0	360
<b>70</b>	90.1	.556	92.8	.588	93.2	.592	93.8	.593	94.5	.593	93.9	.546
	3014	308	2939	297	2909	294	2807	283	2718	272	2455	240
	122.0	368	130.0	382	131.8	383	135.9	382	139.3	379	141.1	346
<b>72</b>	90.1	.553	92.8	.583	93.2	.587	93.8	.587	94.5	.584		
	3012	307	2937	295	2907	291	2805	280	2715	268		
	121.4	366	129.1	379	130.8	380	134.6	378	137.4	373		
<b>74</b>	90.1	.549	92.8	.579	93.3	.582	93.8	.580	94.6	.573		
	3010	305	2935	292	2905	289	2804	277	2711	262		
	120.7	363	128.2	376	129.8	377	133.1	373	134.8	366		
<b>76</b>	90.1	.545	92.9	.573	93.3	.576	93.9	.572	94.6	.556		
	3007	302	2932	290	2903	286	2803	272	2706	254		
	119.9	361	127.1	373	128.5	373	131.2	368	131.1	355		
<b>78</b>	90.1	.540	92.9	.567	93.3	.569	94.0	.561	94.8	.528		
	3005	300	2929	287	2901	282	2801	267	2700	241		
	119.0	358	126.0	369	127.1	369	128.8	361	124.8	337		
<b>ENGINE ANTI ICE ON</b> ΔFUEL = + 1.5 %					<b>TOTAL ANTI ICE ON</b> ΔFUEL = + 4 %							





**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

CRUISE TABLES - FIXED SPEED STRATEGIES

**CRUISE - MCT/320KT - 1 ENGINE OUT - ISA**

Ident.: PER-OEI-CRT-20-00002116.0023001 / 09 DEC 09

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

**CRUISE TABLES - FIXED SPEED STRATEGIES**

Applicable to: ALL

<b>CRUISE - MCT/320KT - 1 ENGINE OUT</b>												
MAX. CONTINUOUS THRUST PACK FLOW HI ANTI-ICING OFF				ISA CG=33.0%		N1 (%) KG/H NM/1000KG		MACH IAS (KT) TAS (KT)				
WEIGHT (1000KG)	FL100		FL150		FL160		FL180		FL200		FL220	
<b>50</b>	86.7	.576	90.5	.631	91.2	.643	91.1	.644	91.3	.649	91.1	.647
	2868	320	2958	320	2984	320	2798	308	2663	299	2480	286
	128.3	368	133.6	395	134.4	401	142.5	399	149.7	399	158.9	394
<b>52</b>	86.8	.576	90.6	.631	91.4	.643	91.2	.643	91.4	.647	91.2	.645
	2883	320	2976	320	3004	320	2804	308	2673	298	2490	285
	127.6	368	132.8	395	133.5	401	141.9	398	148.7	398	157.8	393
<b>54</b>	87.0	.576	90.7	.631	91.5	.642	91.2	.641	91.5	.645	91.3	.642
	2899	320	2996	320	3019	320	2811	307	2683	297	2500	284
	126.9	368	132.0	395	132.8	401	141.2	397	147.8	397	156.5	391
<b>56</b>	87.1	.576	90.9	.631	91.6	.641	91.3	.639	91.6	.644	91.5	.640
	2917	320	3017	320	3024	319	2820	306	2694	296	2512	283
	126.1	368	131.0	395	132.2	400	140.4	396	146.8	395	155.2	390
<b>58</b>	87.3	.576	91.1	.631	91.6	.639	91.4	.638	91.8	.642	91.6	.637
	2934	320	3039	320	3029	318	2828	305	2705	295	2525	281
	125.4	368	130.1	395	131.7	399	139.6	395	145.7	394	153.8	388
<b>60</b>	87.4	.576	91.3	.631	91.7	.637	91.5	.636	91.9	.639	91.8	.634
	2954	320	3064	320	3035	317	2836	304	2717	294	2539	280
	124.5	368	129.0	395	131.1	398	138.8	394	144.6	393	152.2	386
<b>62</b>	87.6	.576	91.4	.631	91.7	.636	91.6	.634	92.0	.637	91.9	.630
	2975	320	3089	320	3041	316	2845	303	2731	293	2554	278
	123.7	368	128.0	395	130.4	397	137.9	392	143.3	391	150.4	384
<b>64</b>	87.8	.576	91.6	.630	91.8	.634	91.7	.631	92.2	.634	92.1	.627
	2997	320	3104	319	3047	315	2856	302	2745	292	2571	277
	122.8	368	127.2	395	129.8	395	136.9	391	142.0	390	148.6	382
<b>66</b>	88.0	.576	91.6	.628	91.9	.631	91.8	.629	92.3	.632	92.3	.622
	3019	320	3109	318	3054	314	2868	301	2761	291	2587	275
	121.8	368	126.5	393	129.1	394	135.8	389	140.5	388	146.6	379
<b>68</b>	88.2	.576	91.7	.626	91.9	.629	91.9	.626	92.5	.629	92.6	.617
	3043	320	3116	317	3061	313	2881	300	2779	289	2605	272
	120.9	368	125.9	392	128.3	393	134.6	388	139.0	386	144.4	376
<b>70</b>	88.4	.576	91.7	.624	92.0	.627	92.0	.623	92.7	.625	92.9	.612
	3067	320	3122	316	3068	312	2896	298	2797	287	2625	270
	120.0	368	125.1	391	127.5	391	133.3	386	137.3	384	142.1	373
<b>72</b>	88.6	.576	91.8	.621	92.1	.624	92.2	.620	92.9	.621	93.2	.605
	3092	320	3129	315	3077	310	2911	297	2817	286	2648	267
	119.0	368	124.4	389	126.6	390	131.9	384	135.5	382	139.3	369
<b>74</b>	88.8	.576	91.9	.619	92.2	.621	92.4	.617	93.1	.617	93.5	.597
	3119	320	3137	313	3086	309	2928	295	2836	283	2666	263
	118.0	368	123.5	387	125.6	388	130.4	382	133.6	379	136.4	364
<b>76</b>	89.0	.576	92.0	.616	92.3	.618	92.5	.613	93.4	.612	93.6	.577
	3148	320	3145	312	3097	307	2946	293	2857	281	2656	254
	116.9	368	122.6	386	124.6	386	128.8	380	131.6	376	132.3	351
<b>78</b>	89.2	.576	92.0	.612	92.4	.615	92.7	.609	93.7	.607		
	3178	320	3154	310	3109	305	2967	291	2883	279		
	115.8	368	121.6	384	123.3	383	127.1	377	129.3	373		
<b>ENGINE ANTI ICE ON</b>						<b>TOTAL ANTI ICE ON</b>						
ΔFUEL = + 2 %						ΔFUEL = + 5 %						



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

CRUISE TABLES - FIXED SPEED STRATEGIES

**CRUISE - MCT/320KT - 1 ENGINE OUT - ISA +20**

Ident.: PER-OEI-CRT-20-00002119.0023001 / 09 DEC 09

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

**CRUISE TABLES - FIXED SPEED STRATEGIES**

Applicable to: ALL

<b>CRUISE - MCT/320KT - 1 ENGINE OUT</b>												
MAX. CONTINUOUS THRUST PACK FLOW HI ANTI-ICING OFF					ISA+20 CG=33.0%	N1 (%) KG/H NM/1000KG	MACH IAS (KT) TAS (KT)					
WEIGHT (1000KG)	FL100		FL150		FL160		FL180		FL200		FL220	
<b>50</b>	90.0	.576	92.5	.612	92.7	.617	92.8	.620	93.1	.626	92.8	.621
	3017	320	2912	310	2864	307	2712	297	2595	288	2402	274
	126.4	381	136.6	398	139.5	400	147.2	399	154.0	400	163.9	394
<b>52</b>	90.1	.576	92.5	.610	92.8	.615	92.9	.619	93.2	.624	92.9	.619
	3028	320	2916	309	2869	306	2720	296	2604	287	2411	273
	125.8	381	136.1	397	138.9	399	146.3	398	153.0	398	162.6	392
<b>54</b>	90.1	.574	92.5	.609	92.8	.613	93.0	.617	93.3	.622	93.0	.616
	3027	319	2921	308	2874	305	2729	295	2615	286	2422	272
	125.5	380	135.5	396	138.3	397	145.4	397	151.8	397	161.1	390
<b>56</b>	90.1	.573	92.6	.607	92.9	.612	93.0	.615	93.5	.620	93.2	.612
	3026	318	2926	307	2880	304	2738	294	2626	285	2434	270
	125.2	379	134.9	395	137.6	396	144.4	395	150.7	396	159.4	388
<b>58</b>	90.1	.571	92.6	.605	92.9	.610	93.1	.613	93.6	.617	93.3	.608
	3025	317	2932	306	2886	303	2749	293	2637	284	2447	268
	124.9	378	134.2	393	136.8	395	143.4	394	149.4	394	157.6	386
<b>60</b>	90.1	.569	92.7	.603	93.0	.607	93.2	.610	93.7	.614	93.5	.604
	3023	316	2938	305	2892	302	2759	292	2650	282	2463	266
	124.5	376	133.4	392	136.1	394	142.3	393	148.0	392	155.5	383
<b>62</b>	90.1	.567	92.7	.601	93.0	.605	93.4	.608	93.9	.611	93.7	.599
	3022	314	2944	304	2899	300	2771	290	2665	281	2478	264
	124.1	375	132.7	391	135.2	392	141.1	391	146.5	390	153.3	380
<b>64</b>	90.1	.564	92.8	.598	93.1	.603	93.5	.605	94.0	.608	93.7	.591
	3020	313	2945	303	2906	299	2784	289	2680	279	2474	260
	123.6	373	132.0	389	134.4	390	139.8	389	144.9	388	151.5	375
<b>66</b>	90.1	.562	92.8	.595	93.2	.600	93.6	.602	94.2	.604	93.7	.581
	3018	312	2943	301	2913	298	2798	288	2699	277	2469	256
	123.1	372	131.4	387	133.4	389	138.4	387	143.0	386	149.1	368
<b>68</b>	90.1	.559	92.8	.591	93.2	.596	93.7	.598	94.4	.600	93.8	.567
	3017	310	2941	299	2911	296	2808	286	2720	275	2463	249
	122.6	370	130.7	385	132.7	386	137.1	385	140.9	383	146.0	360
<b>70</b>	90.1	.556	92.8	.588	93.2	.592	93.8	.593	94.5	.593	93.9	.546
	3014	308	2939	297	2909	294	2807	283	2718	272	2455	240
	122.0	368	130.0	382	131.8	383	135.9	382	139.3	379	141.1	346
<b>72</b>	90.1	.553	92.8	.583	93.2	.587	93.8	.587	94.5	.584		
	3012	307	2937	295	2907	291	2805	280	2715	268		
	121.4	366	129.1	379	130.8	380	134.6	378	137.4	373		
<b>74</b>	90.1	.549	92.8	.579	93.3	.582	93.8	.580	94.6	.573		
	3010	305	2935	292	2905	289	2804	277	2711	262		
	120.7	363	128.2	376	129.8	377	133.1	373	134.8	366		
<b>76</b>	90.1	.545	92.9	.573	93.3	.576	93.9	.572	94.6	.556		
	3007	302	2932	290	2903	286	2803	272	2706	254		
	119.9	361	127.1	373	128.5	373	131.2	368	131.1	355		
<b>78</b>	90.1	.540	92.9	.567	93.3	.569	94.0	.561	94.8	.528		
	3005	300	2929	287	2901	282	2801	267	2700	241		
	119.0	358	126.0	369	127.1	369	128.8	361	124.8	337		
<b>ENGINE ANTI ICE ON</b> ΔFUEL = + 2 %					<b>TOTAL ANTI ICE ON</b> ΔFUEL = + 5 %							

**IN CRUISE QUICK CHECK AT LONG RANGE SPEED**

Ident.: PER-OEI-ICQ-10-00002122.0001001 / 22 MAR 17

Applicable to: ALL

In cruise quick check tables (*Refer to QRH/PER-L In Cruise Quick Check Long Range (Paper Only)*) or use the performance application of FlySmart with Airbus) allow the flight crew to determine the fuel consumption and the time required to cover a given air distance from any moment in cruise to landing, with one engine inoperative.

The QRH tables are established for:

- Cruise Mach number : long range
- Descent profile : M .78/300 kt/250 kt
- Approach and landing : 120 kg or 270 lb - 6 min IMC
- ISA
- CG = 33 %
- Pack flow HI
- Anti ice OFF

- Note:
1. In the tables, the asterisk (\*) means that a step climb of 4 000 ft must be flown to reach the corresponding flight level.
  2. The flight level shown on the top of each column is the final flight level.
  3. For each degree Celsius above ISA temperature apply a fuel correction of 0.015 (kg/°C/NM) × Δ ISA (°C) × air distance (NM) or 0.033 (lb/°C/NM) × ΔISA (°C) × air distance (NM).

**CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT**

Ident.: PER-OEI-ICQ-10-00002123.0001001 / 21 MAR 17

Applicable to: ALL

The in cruise quick check tables are based on a reference initial weight.

A correction on the fuel consumption has to be made, when the actual initial weight is different from the reference initial weight.

If it is lower (or greater) than the reference weight, subtract (or add) the value given in the correction part of the table per 1 000 kg or 1 000 lb below (or above) the reference initial weight (*Refer to PER-OEI-DES-20 DESCENT - M.80/350KT*).



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

IN CRUISE QUICK CHECK - STANDARD STRATEGIES

Intentionally left blank

**GENERAL**

Ident.: PER-OEI-ICQ-20-00002125.0001001 / 14 NOV 11

**Applicable to: ALL**

The following in cruise quick check tables allow the flight crew to determine the fuel consumption and the time required to cover a given air distance from any moment in cruise to landing with one engine inoperative.

These tables are established for:

- Cruise speed: MCT /VMO , MCT/320 kt.
- Descent profile: M .78/300 kt/250 kt
- Approach and landing: 120 kg or 270 lb - 6 min IMC
- ISA
- CG = 33 %
- Pack flow HI
- Anti ice OFF

- Note:
1. In the tables, the asterisk "\*" means that a step climb of 4 000 ft has been made to reach the corresponding flight level.
  2. The flight level shown on the top of each column is the final flight level.
  3. For each degree Celsius above ISA apply a fuel correction of  
 $0.015 \text{ (kg/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air Distance (NM)}$   
or  $0.033 \text{ (lb/}^\circ\text{C/NM)} \times \Delta\text{ISA (}^\circ\text{C)} \times \text{Air Distance (NM)}$

**CORRECTION FOR DEVIATION FROM REFERENCE WEIGHT**

Ident.: PER-OEI-ICQ-20-00002126.0001001 / 21 MAR 17

**Applicable to: ALL**

The in cruise quick check tables are based on a reference initial weight. The fuel consumption must be corrected when the actual weight is different from the reference initial weight.

If it is lower (or greater) than the reference weight, subtract (or add) the value given in the correction part of the table per 1 000 kg or 1 000 lb below (or above) the reference weight (*Refer to PER-OEI-DES-20 DESCENT - M.80/350KT*).

**IN CRUISE QUICK CHECK VMO**

Ident.: PER-OEI-ICQ-20-00002127.0022001 / 10 DEC 09

Applicable to: ALL

IN CRUISE QUICK CHECK FROM ANY MOMENT IN CRUISE TO LANDING - ONE ENGINE FAILURE									
CRUISE : MCT/VMO - DESCENT : M.78/300KT/250KT									
IMC PROCEDURE : 120 KG (6MIN)									
REF. INITIAL WEIGHT = 55000 KG NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA CG = 33.0 %		FUEL CONSUMED (KG)			
						TIME (H.MIN)			
AIR DIST. (NM)	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)			
	100	150	160	180	200	220	FL100 FL150	FL160 FL180	FL200 FL220
<b>200</b>	1548 0.38	1399 0.38	1357 0.38	1257 0.38	1180 0.38	1098 0.38	0	0	0
<b>250</b>	2069 0.45	1785 0.45	1735 0.45	1612 0.46	1520 0.46	1418 0.46	0	0	1
<b>300</b>	2489 0.53	2171 0.53	2112 0.53	1967 0.53	1859 0.53	1738 0.54	1	1	2
<b>350</b>	2909 1.01	2556 1.00	2489 1.00	2322 1.01	2198 1.01	2058 1.01	1	2	4
<b>400</b>	3329 1.08	2941 1.08	2866 1.08	2676 1.08	2536 1.08	2378 1.09	2	2	5
<b>450</b>	3748 1.16	3326 1.15	3242 1.15	3030 1.16	2874 1.16	2697 1.17	2	3	6
<b>500</b>	4168 1.24	3711 1.23	3619 1.23	3383 1.23	3211 1.23	3015 1.24	3	4	7
<b>550</b>	4589 1.32	4095 1.30	3965 1.30	3737 1.31	3549 1.31	3333 1.32	3	5	8
<b>600</b>	5008 1.39	4479 1.38	4371 1.38	4090 1.38	3885 1.38	3651 1.39	4	5	9
<b>650</b>	5427 1.47	4863 1.45	4746 1.45	4442 1.46	4222 1.46	3968 1.47	4	6	10
<b>700</b>	5846 1.55	5247 1.53	5122 1.52	4795 1.53	4558 1.54	4286 1.55	5	7	11
<b>750</b>	6265 2.03	5631 2.00	5497 2.00	5147 2.01	4894 2.01	4602 2.02	5	7	12
<b>800</b>	6683 2.10	6014 2.08	5872 2.07	5499 2.08	5230 2.09	4919 2.10	6	8	13
<b>850</b>	7102 2.18	6397 2.15	6246 2.15	5851 2.16	5565 2.16	5235 2.18	6	9	14
<b>900</b>	7520 2.26	6780 2.22	6621 2.22	6202 2.23	5899 2.24	5550 2.25	7	9	15
<b>950</b>	7938 2.33	7162 2.30	6995 2.30	6553 2.31	6234 2.31	5865 2.33	7	10	16
<b>1000</b>	8356 2.41	7545 2.37	7369 2.37	6904 2.38	6568 2.39	6180 2.40	7	11	17
<b>1050</b>	8773 2.49	7927 2.45	7743 2.44	7254 2.46	6902 2.46	6495 2.48	8	11	18
<b>1100</b>	9191 2.56	8309 2.52	8116 2.52	7605 2.53	7235 2.54	6809 2.56	8	12	19
<b>1150</b>	9608 3.04	8690 3.00	8489 2.99	7955 3.01	7568 3.01	7123 3.03	9	13	20
<b>1200</b>	10025 3.12	9072 3.07	8862 3.07	8305 3.08	7901 3.09	7435 3.11	9	13	21
<b>1250</b>	10442 3.19	9454 3.14	9235 3.14	8654 3.16	8233 3.16	7750 3.18	10	14	22
<b>1300</b>	10859 3.27	9835 3.22	9608 3.22	9004 3.23	8565 3.24	8063 3.26	10	14	23
<b>1350</b>	11275 3.35	10216 3.29	9980 3.29	9353 3.31	8897 3.31	8375 3.33	12	15	24
<b>1400</b>	11692 3.43	10597 3.37	10352 3.36	9701 3.38	9228 3.39	8687 3.41	12	16	25
<b>ENGINE ANTI ICE ON</b> ΔFUEL = + 2.5 %					<b>TOTAL ANTI ICE ON</b> ΔFUEL = + 5 %				

F1P23D A320-214 CFM56-5B4/P SA3611 03301.001011 0250300.7800.00100 120 0300350 55 0 100100 40100 18590 FCOM-N0-03-06-50-014-170



**IN CRUISE QUICK CHECK 320KT**

Ident.: PER-OEI-ICQ-20-00002128.0022001 / 10 DEC 09

Applicable to: ALL

IN CRUISE QUICK CHECK FROM ANY MOMENT IN CRUISE TO LANDING - ONE ENGINE FAILURE										
CRUISE : MCT/320KT - DESCENT : M.78/300KT/250KT										
IMC PROCEDURE : 120 KG (6MIN)										
REF. INITIAL WEIGHT = 55000 KG				ISA		FUEL CONSUMED (KG)				
NORMAL AIR CONDITIONING				CG = 33.0 %						
ANTI-ICING OFF				TIME (H.MIN)						
AIR	FLIGHT LEVEL					CORRECTION ON FUEL CONSUMPTION (KG/1000KG)				
DIST.						FL100	FL160	FL200		
(N.M)	100	150	160	180	200	220	FL150	FL180	FL220	
<b>200</b>	1556 0.39	1381 0.38	1358 0.38	1257 0.38	1180 0.38	1098 0.38	2	0	0	
<b>250</b>	1950 0.47	1760 0.46	1737 0.45	1612 0.46	1520 0.46	1418 0.46	3	1	1	
<b>300</b>	2344 0.55	2139 0.53	2115 0.53	1967 0.53	1859 0.53	1738 0.54	4	1	1	
<b>350</b>	2737 1.03	2518 1.01	2493 1.00	2322 1.01	2198 1.01	2058 1.01	5	2	4	
<b>400</b>	3130 1.12	2896 1.08	2870 1.08	2676 1.08	2536 1.08	2378 1.09	6	3	5	
<b>450</b>	3523 1.20	3274 1.16	3248 1.15	3030 1.16	2874 1.16	2697 1.17	7	4	6	
<b>500</b>	3915 1.28	3651 1.24	3618 1.23	3383 1.23	3211 1.23	3015 1.24	8	5	7	
<b>550</b>	4306 1.36	4028 1.31	3993 1.30	3737 1.31	3549 1.31	3333 1.32	9	6	8	
<b>600</b>	4698 1.44	4404 1.39	4368 1.38	4090 1.38	3885 1.38	3651 1.39	10	7	9	
<b>650</b>	5089 1.52	4780 1.46	4742 1.45	4442 1.46	4222 1.46	3968 1.47	11	8	10	
<b>700</b>	5479 2.01	5156 1.54	5116 1.53	4795 1.53	4558 1.54	4286 1.55	12	9	11	
<b>750</b>	5869 2.09	5531 2.02	5489 2.00	5147 2.01	4894 2.01	4602 2.02	13	10	12	
<b>800</b>	6258 2.17	5906 2.09	5862 2.07	5499 2.08	5230 2.09	4919 2.10	14	11	13	
<b>850</b>	6648 2.25	6280 2.17	6234 2.15	5851 2.16	5565 2.16	5235 2.18	15	11	14	
<b>900</b>	7036 2.33	6654 2.24	6606 2.22	6202 2.23	5899 2.24	5550 2.25	16	12	15	
<b>950</b>	7425 2.41	7027 2.32	6977 2.30	6553 2.31	6234 2.31	5865 2.33	17	13	16	
<b>1000</b>	7813 2.49	7400 2.39	7348 2.37	6904 2.38	6568 2.39	6180 2.40	18	14	17	
<b>1050</b>	8201 2.58	7773 2.47	7719 2.45	7254 2.46	6902 2.46	6495 2.48	19	15	18	
<b>1100</b>	8588 3.06	8145 2.55	8089 2.52	7605 2.53	7235 2.54	6809 2.56	20	16	19	
<b>1150</b>	8975 3.14	8517 3.02	8459 3.00	7955 3.01	7568 3.01	7123 3.03	21	17	20	
<b>1200</b>	9361 3.22	8889 3.10	8828 3.07	8305 3.08	7901 3.09	7436 3.11	22	18	21	
<b>1250</b>	9748 3.30	9260 3.17	9197 3.15	8654 3.16	8233 3.16	7750 3.18	23	19	22	
<b>1300</b>	10134 3.38	9631 3.25	9565 3.22	9004 3.23	8565 3.24	8063 3.26	25	20	23	
<b>1350</b>	10519 3.46	10001 3.32	9933 3.30	9353 3.31	8897 3.31	8375 3.33	26	21	24	
<b>1400</b>	10905 3.55	10371 3.40	10301 3.37	9701 3.38	9228 3.39	8687 3.41	28	22	25	
<b>ENGINE ANTI ICE ON</b>					<b>TOTAL ANTI ICE ON</b>					
ΔFUEL = + 2.5 %					ΔFUEL = + 6 %					

FLP23D A320-214 CFM56-5B4/P SA3611 03301.001011 0250300 .7800 .00100 120 0300350 55 0 100100 40100 18590 FCOM-NO-03-06-50-015-170



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

IN CRUISE QUICK CHECK - FIXED SPEED STRATEGIES

Intentionally left blank



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

HOLDING

**HOLDING**

Ident.: PER-OEI-HLD-00002130.0024001 / 28 FEB 11

Applicable to: ALL

RACE TRACK HOLDING PATTERN - GREEN DOT SPEED - 1 ENGINE OUT								
MAX. CRUISE THRUST LIMITS					ISA		N1 (%)	
CLEAN CONFIGURATION					CG=33.0%		FF (KG/H)	
PACK FLOW HI								
ANTI-ICING OFF								
WEIGHT (1000KG)	FL 15	FL 50	FL100	FL120	FL140	FL160	FL180	FL200
<b>48</b>	61.2 1573	63.7 1562	68.1 1553	69.7 1549	71.4 1545	73.2 1544	75.1 1544	77.1 1549
<b>50</b>	62.2 1637	64.8 1626	69.2 1617	70.8 1613	72.5 1610	74.4 1610	76.4 1611	78.2 1618
<b>52</b>	63.1 1701	65.9 1691	70.2 1681	71.9 1677	73.7 1676	75.6 1677	77.5 1682	79.4 1687
<b>54</b>	64.1 1766	67.0 1758	71.2 1745	73.0 1742	74.8 1742	76.8 1744	78.6 1751	80.6 1757
<b>56</b>	65.1 1831	68.1 1823	72.3 1810	74.0 1808	75.9 1809	77.8 1815	79.7 1820	81.5 1830
<b>58</b>	66.1 1896	69.2 1885	73.3 1875	75.1 1875	77.1 1877	78.9 1884	80.8 1890	82.4 1906
<b>60</b>	67.1 1963	70.2 1949	74.3 1941	76.1 1943	78.1 1947	79.9 1953	81.7 1963	83.4 1982
<b>62</b>	68.1 2027	71.0 2014	75.3 2009	77.2 2011	79.0 2017	80.9 2024	82.6 2038	84.3 2066
<b>64</b>	69.1 2090	71.9 2079	76.3 2077	78.2 2081	80.0 2087	81.9 2095	83.4 2114	85.2 2153
<b>66</b>	70.1 2153	72.8 2145	77.2 2146	79.1 2150	80.9 2158	82.7 2170	84.3 2193	
<b>68</b>	70.9 2217	73.7 2211	78.2 2215	80.0 2220	81.8 2229	83.5 2246	85.2 2278	
<b>70</b>	71.7 2284	74.6 2278	79.1 2283	80.8 2291	82.7 2302	84.3 2322		
<b>72</b>	72.5 2350	75.4 2346	79.9 2354	81.7 2363	83.4 2377	85.1 2402		
<b>74</b>	73.3 2417	76.3 2416	80.7 2426	82.6 2436	84.2 2454			
<b>76</b>	74.1 2486	77.1 2486	81.6 2499	83.4 2510	85.0 2531			
<b>ENGINE ANTI ICE ON</b> △FF = + 3 %			<b>TOTAL ANTI ICE ON</b> △FF = + 6 %			<b>PER 1° ABOVE ISA</b> △FF = + 0.3 %		

11.0-08FOA320-214 CFM56-5B4/P SA14300010C6KG330 0.018590 0.0 1.0 1.0 180.0 30.00 0.01 1.000 .000 .000 0 FCOM-N0-03-06-55-001-200



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**

HOLDING

Intentionally left blank

**DESCENT - M.78/300KT**

Ident.: PER-OEI-DES-10-00002135.0020001 / 09 MAR 11

Applicable to: ALL

DESCENT - M.78/300KT - 1 ENGINE OUT									
MAX. CONTINUOUS THRUST LIMITS				ISA		MINIMUM RATE OF DESCENT 500FT/MIN			
PACK FLOW HI				CG=33.0%					
ANTI-ICING OFF									
WEIGHT (1000KG)	50				70				IAS (KT)
	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	
<b>390</b>	41.6	1408	280	MCT					241
<b>370</b>	39.8	1372	267	MCT	39.4	1386	264	MCT	252
<b>350</b>	38.1	1330	255	MCT	38.0	1353	253	MCT	264
<b>330</b>	36.5	1288	243	MCT	36.5	1315	243	MCT	277
<b>310</b>	35.1	1246	231	MCT	35.0	1274	231	MCT	289
<b>290</b>	33.6	1201	220	MCT	33.5	1226	219	MCT	300
<b>270</b>	31.5	1134	205	MCT	31.3	1156	203	MCT	300
<b>250</b>	29.1	1052	187	MCT	28.8	1072	185	MCT	300
<b>230</b>	26.0	942	165	MCT	25.9	967	164	MCT	300
<b>220</b>	24.0	867	151	V/S	24.0	896	151	V/S	300
<b>210</b>	22.0	793	137	V/S	22.0	818	137	V/S	300
<b>200</b>	20.0	719	124	V/S	20.0	741	124	V/S	300
<b>190</b>	18.0	645	111	V/S	18.0	665	111	V/S	300
<b>180</b>	16.0	572	98	V/S	16.0	589	98	V/S	300
<b>170</b>	14.0	499	85	V/S	14.0	514	85	V/S	300
<b>160</b>	12.0	427	72	V/S	12.0	439	72	V/S	300
<b>150</b>	10.0	355	60	V/S	10.0	365	60	V/S	300
<b>140</b>	8.0	283	47	V/S	8.0	291	47	V/S	300
<b>100</b>	.0	0	0	V/S	.0	0	0	V/S	300
<b>CORRECTIONS</b>		<b>ENGINE ANTI ICE ON</b>		<b>TOTAL ANTI ICE ON</b>		<b>PER 1° ABOVE ISA</b>			
TIME		- 0.3 %		- 1.5 %		-			
FUEL		+ 2 %		+ 4 %		+ 0.3 %			
DISTANCE		- 0.5 %		- 1.5 %		+ 0.2 %			

11.0-08FOA320-214 CFM56-5B4/P SA23200010C6KG330 0 018590 0 0 3 .0 500.00 0 02 .780300.000 .000 0 FCOM-NO-03-06-30-003-200



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

DESCENT - STANDARD STRATEGY

Intentionally left blank



**A318/A319/A320/A321**  
**FLIGHT CREW**  
**OPERATING MANUAL**

**PERFORMANCE**  
**ONE ENGINE INOPERATIVE**  
**DESCENT - OBSTACLE STRATEGY**

**GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED - ISA**

Ident.: PER-OEI-DES-15-00002080.0022001 / 09 DEC 09

Applicable to: ALL

GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED										
MAX. CONTINUOUS THRUST				ISA		DISTANCE (NM)		TIME (MIN)		
PACK FLOW HI				CG=33.0%		INITIAL SPEED(KT)		FUEL(1000KG)		
ANTI-ICING OFF				LEVEL OFF (FT)						
INIT. GW (1000KG)	INITIAL FLIGHT LEVEL									
	230	250	270	290	310	330	350	370	390	
<b>50</b>					83 16 196 .4 30700	205 38 198 1.0 31000	253 47 200 1.2 31200	284 52 202 1.3 31200	308 56 204 1.4 31300	
<b>52</b>					170 32 200 .9 29900	237 44 202 1.2 30000	273 51 204 1.3 30100	301 55 206 1.5 30200	322 58 208 1.5 30200	
<b>54</b>				102 20 202 .6 28700	207 39 204 1.1 29000	255 48 206 1.3 29100	287 53 208 1.5 29200	311 57 210 1.5 29200	331 60 212 1.6 29200	
<b>56</b>				174 33 206 1.0 27800	238 45 208 1.3 28000	276 51 210 1.5 28100	304 56 212 1.6 28200	324 59 214 1.6 28200	345 62 216 1.7 28200	
<b>58</b>			111 21 208 .6 26600	215 41 210 1.2 26900	262 49 212 1.5 27000	294 55 214 1.6 27100	320 59 216 1.7 27200	339 62 218 1.8 27200	358 65 220 1.8 27200	
<b>60</b>			179 34 212 1.1 25800	244 46 214 1.4 26000	283 53 216 1.6 26100	311 58 218 1.7 26100	334 61 220 1.8 26200	353 64 222 1.9 26200	369 67 224 1.9 26300	
<b>62</b>			101 19 216 .6 25300	176 33 218 1.0 25400	220 41 220 1.2 25400	240 44 222 1.3 25400	267 48 224 1.4 25400	302 54 226 1.6 25400	321 57 228 1.7 25400	
<b>64</b>			72 13 220 .4 25200	117 21 222 .7 25200	149 27 224 .8 25200	175 31 226 .9 25300	197 35 228 1.0 25300	216 37 230 1.1 25300	233 40 232 1.2 25300	
<b>66</b>			61 11 224 .4 25100	98 18 226 .6 25100	126 22 228 .7 25100	149 26 230 .8 25100	169 29 232 .9 25100	187 32 234 .9 25100	203 34 236 1.0 25100	
<b>68</b>		26 5 226 .2 24900	62 11 228 .4 25000	94 17 230 .5 25000	120 21 232 .7 25000	141 24 234 .8 25000	153 26 236 .8 25000	170 28 238 .8 25000	185 30 240 .9 25000	
<b>70</b>		119 21 230 .8 24500	158 28 232 1.1 24600	182 32 234 1.2 24600	205 36 236 1.3 24600	222 39 238 1.3 24700	238 41 240 1.4 24700	253 43 242 1.4 24700		
<b>72</b>		153 27 234 1.1 23900	190 34 236 1.3 24000	214 38 238 1.4 24000	234 41 240 1.5 24100	252 44 242 1.6 24100	268 46 244 1.6 24100	284 48 246 1.7 24100		
<b>74</b>		178 32 238 1.3 23400	210 37 240 1.5 23400	232 41 242 1.6 23500	253 44 244 1.7 23500	270 47 246 1.7 23500	286 49 248 1.8 23500	300 51 250 1.8 23500		
<b>76</b>	106 19 240 .8 22600	196 35 242 1.4 22800	223 39 244 1.6 22900	246 43 244 1.7 22900	264 46 248 1.8 22900	280 48 250 1.8 22900	295 50 252 1.9 23000	311 52 254 1.9 23000		
<b>78</b>	145 26 244 1.1 22100	209 37 246 1.6 22300	236 41 248 1.7 22300	256 44 250 1.8 22300	274 47 252 1.9 22300	291 50 254 1.9 22400	306 52 256 2.0 22400			
<b>CORRECTIONS</b>		<b>DISTANCE</b>			<b>TIME</b>		<b>FUEL</b>		<b>LEVEL OFF</b>	
ENGINE ANTI ICE ON		+ 3 %			+ 3 %		+ 7 %		- 100 FT	
TOTAL ANTI ICE ON		+ 8 %			+ 8 %		+ 10 %		- 700 FT	

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

**DESCENT - OBSTACLE STRATEGY**

**GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED - ISA +20**

Ident.: PER-OEI-DES-15-00002088.0022001 / 22 MAR 17

Applicable to: ALL

GROSS FLIGHT PATH DESCENT AT GREEN DOT SPEED										
MAX. CONTINUOUS THRUST		ISA +20				DISTANCE (NM)		TIME (MIN)		
PACK FLOW HI		CG=33.0%				INITIAL SPEED(KT)		FUEL(1000KG)		
ANTI-ICING OFF		LEVEL OFF (FT)								
INIT. GW (1000KG)	INITIAL FLIGHT LEVEL									
	230	250	270	290	310	330	350	370	390	
<b>50</b>				119 23 194 .6 28600	224 42 196 1.1 28900	273 51 198 1.3 29000	307 57 202 1.5 29100	333 61 202 1.5 29100	354 64 204 1.6 29200	
<b>52</b>				191 36 198 1.0 27700	255 48 200 1.3 27900	295 55 202 1.5 27900	324 60 204 1.6 28000	348 63 206 1.7 28100	368 66 208 1.7 28100	
<b>54</b>			138 27 200 .8 26400	231 44 202 1.2 26700	280 53 204 1.5 26800	314 58 206 1.6 26900	339 62 208 1.7 26900	362 66 210 1.8 27000	381 69 212 1.8 27000	
<b>56</b>			200 38 204 1.1 25500	262 50 206 1.4 25700	301 56 208 1.6 25800	330 61 210 1.7 25800	353 65 212 1.8 25900	374 68 214 1.9 25900	392 71 216 1.9 26000	
<b>58</b>			96 18 208 .5 25200	152 28 210 .8 25300	212 39 212 1.1 25300	243 44 214 1.3 25300	268 48 216 1.4 25300	291 52 218 1.4 25300	309 54 220 1.5 25300	
<b>60</b>			74 14 212 .4 25100	118 21 214 .6 25100	150 27 216 .8 25100	176 31 218 .9 25100	198 35 220 1.0 25100	218 38 222 1.0 25100	236 40 224 1.1 25100	
<b>62</b>		26 5 214 .2 24900	64 12 216 .4 25000	100 18 218 .5 25000	128 23 220 .7 25000	152 26 222 .8 25000	173 30 224 .8 25000	191 32 226 .9 25000	208 35 228 .9 25000	
<b>64</b>		121 22 218 .8 24500	165 30 220 1.0 24500	194 35 222 1.2 24600	214 38 224 1.2 24600	234 41 226 1.3 24600	253 44 228 1.4 24700	268 46 230 1.4 24700		
<b>66</b>		159 29 222 1.1 23900	197 35 224 1.2 24000	223 40 226 1.4 24000	245 43 228 1.5 24000	265 46 230 1.5 24100	281 49 232 1.6 24100	299 51 234 1.6 24100		
<b>68</b>	11 2 224 .1 22900	183 33 226 1.2 23300	216 39 228 1.4 23400	240 43 230 1.5 23400	260 46 232 1.6 23400	281 49 234 1.7 23500	296 51 236 1.7 23500	313 53 238 1.8 23500		
<b>70</b>	92 17 228 .7 22500	201 36 230 1.4 22700	230 41 232 1.5 22800	253 45 234 1.6 22800	273 48 236 1.7 22800	291 50 238 1.8 22900	308 53 240 1.8 22900	323 55 242 1.9 22900		
<b>72</b>	153 27 232 1.1 22000	215 38 234 1.5 22100	242 43 236 1.6 22200	263 46 238 1.7 22200	282 49 240 1.8 22200	298 51 242 1.9 22300	316 54 244 1.9 22300			
<b>74</b>	177 31 236 1.3 21500	227 40 238 1.6 21600	251 44 240 1.7 21600	272 47 242 1.8 21600	289 50 244 1.9 21700	307 52 246 1.9 21700	324 55 248 2.0 21700			
<b>76</b>	195 34 240 1.4 20900	237 41 242 1.7 21000	260 45 244 1.8 21100	279 48 246 1.9 21100	297 51 248 2.0 21100	314 53 250 2.0 21100	328 55 252 2.1 21100			
<b>78</b>	210 37 244 1.6 20400	245 43 246 1.8 20500	267 46 248 1.9 20500	287 49 250 2.0 20500	303 51 252 2.0 20500	320 54 254 2.1 20600	335 56 256 2.1 20600			
<b>CORRECTIONS</b>		<b>DISTANCE</b>			<b>TIME</b>		<b>FUEL</b>		<b>LEVEL OFF</b>	
ENGINE ANTI ICE ON		+ 3 %			+ 3 %		+ 7 %		- 100 FT	
TOTAL ANTI ICE ON		+ 8 %			+ 8 %		+ 10 %		- 700 FT	



- For LONG RANGE CRUISE table *Refer to PER-OEI-CRT-10 LONG RANGE CRUISE - 1 ENGINE OUT - ISA*
- For IN CRUISE QUICK CHECK *Refer to QRH/PER-L In Cruise Quick Check Long Range (Paper Only)* or use the performance application of FlySmart with Airbus.



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

DESCENT - OBSTACLE STRATEGY

Intentionally left blank

**DESCENT - M.80/350KT**

Ident.: PER-OEI-DES-20-00002136.0023001 / 22 FEB 11

Applicable to: ALL

DESCENT - M.80/350KT - 1 ENGINE OUT									
MAX. CONTINUOUS THRUST LIMITS				ISA		MINIMUM RATE OF DESCENT 500FT/MIN			
PACK FLOW HI				CG=33.0%					
ANTI-ICING OFF									
WEIGHT (1000KG)	50				70				IAS (KT)
	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	
<b>390</b>	24.8	1011	183	MCT					248
<b>370</b>	23.3	980	172	MCT	25.3	1060	188	MCT	260
<b>350</b>	21.9	946	162	MCT	24.1	1030	178	MCT	272
<b>330</b>	20.6	911	151	MCT	22.8	998	169	MCT	284
<b>310</b>	19.4	876	142	MCT	21.6	962	159	MCT	297
<b>290</b>	18.3	842	133	MCT	20.4	924	149	MCT	311
<b>270</b>	17.3	809	126	MCT	19.2	886	140	MCT	324
<b>250</b>	16.4	778	119	MCT	18.1	849	131	MCT	338
<b>230</b>	15.6	749	112	MCT	17.1	811	123	MCT	350
<b>220</b>	15.1	728	108	MCT	16.4	785	118	MCT	350
<b>210</b>	14.5	705	103	MCT	15.6	756	112	MCT	350
<b>200</b>	13.8	679	98	MCT	14.8	724	105	MCT	350
<b>190</b>	13.2	651	93	MCT	14.0	689	99	MCT	350
<b>180</b>	12.4	620	87	MCT	13.1	651	92	MCT	350
<b>170</b>	11.5	582	81	MCT	12.1	607	84	MCT	350
<b>160</b>	10.5	534	73	MCT	10.9	551	76	MCT	350
<b>150</b>	9.2	473	64	MCT	9.4	483	65	MCT	350
<b>140</b>	7.8	399	53	MCT	7.8	402	54	MCT	350
<b>100</b>	.0	0	0	V/S	.0	0	0	V/S	350
CORRECTIONS		ENGINE ANTI ICE ON		TOTAL ANTI ICE ON		PER 1° ABOVE ISA			
TIME		- 1.5 %		- 4.5 %		-			
FUEL		+ 0.5 %		-		+ 0.3 %			
DISTANCE		- 1.5 %		- 5 %		+ 0.3 %			

11.0-08FOA320-214 CFM56-5B4/P SA23200010C6KG330 0 018590 0 0 3 .0 500.00 0 02 .800350.000 .000 0 FCOM-NO-03-06-50-003-200

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

**DESCENT - FIXED SPEED STRATEGIES**

**DESCENT - M.78/320KT**

Ident.: PER-OEI-DES-20-00002137.0023001 / 02 FEB 11

Applicable to: ALL

<b>DESCENT - M.78/320KT - 1 ENGINE OUT</b>									
MAX. CONTINUOUS THRUST LIMITS			ISA		MINIMUM RATE OF DESCENT 500FT/MIN				
PACK FLOW HI			CG=33.0%						
ANTI-ICING OFF									
WEIGHT (1000KG)	50				70				IAS (KT)
	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	TIME (MIN)	FUEL (KG)	DIST. (NM)	MODE	
<b>390</b>	35.7	1327	250	MCT					241
<b>370</b>	34.0	1290	237	MCT	34.4	1315	240	MCT	252
<b>350</b>	32.3	1249	224	MCT	33.0	1282	230	MCT	264
<b>330</b>	30.7	1207	212	MCT	31.6	1244	219	MCT	277
<b>310</b>	29.2	1164	201	MCT	30.1	1202	208	MCT	289
<b>290</b>	27.8	1123	191	MCT	28.6	1158	197	MCT	302
<b>270</b>	26.6	1082	181	MCT	27.2	1113	186	MCT	315
<b>250</b>	25.2	1032	170	MCT	25.6	1056	173	MCT	320
<b>230</b>	23.3	966	156	MCT	23.5	981	157	MCT	320
<b>220</b>	22.3	927	148	MCT	22.3	938	149	MCT	320
<b>210</b>	21.1	882	140	MCT	21.1	890	140	MCT	320
<b>200</b>	19.7	828	130	MCT	19.7	834	130	MCT	320
<b>190</b>	18.0	755	118	V/S	18.0	763	118	MCT	320
<b>180</b>	16.0	669	104	V/S	16.0	678	104	V/S	320
<b>170</b>	14.0	584	90	V/S	14.0	591	90	V/S	320
<b>160</b>	12.0	499	77	V/S	12.0	505	77	V/S	320
<b>150</b>	10.0	415	64	V/S	10.0	420	64	V/S	320
<b>140</b>	8.0	332	50	V/S	8.0	335	50	V/S	320
<b>100</b>	.0	0	0	V/S	.0	0	0	V/S	320
CORRECTIONS		ENGINE ANTI ICE ON		TOTAL ANTI ICE ON		PER 1° ABOVE ISA			
TIME		- 0.6 %		- 3 %		-			
FUEL		+ 1.5 %		+ 5 %		+ 0.3 %			
DISTANCE		- 0.8 %		- 2.5 %		+ 0.3 %			

11.0.08FDA320-214 CFM56-5B4/P SA23200010C6KG330 0 018590 0 0 3 .0 500.00 0 02 .780320.000 .000 0 FCOM-ND-03-06-50-004-200

**PERFORMANCE**

**ONE ENGINE INOPERATIVE**

DESCENT - DESCENT TO LANDING

**DESCENT TO LANDING**

Ident.: PER-OEI-DES-30-00002138.0022001 / 09 DEC 09

Applicable to: ALL

DESCENT - M.78/300KT/250KT - 1 ENGINE OUT									
IDLE THRUST NORMAL AIR CONDITIONING ANTI-ICING OFF				ISA CG=33.0%					
WEIGHT (1000KG)	50				70				IAS (KT)
	FL	TIME (MIN)	FUEL (KG)	DIST. (NM)	N1	TIME (MIN)	FUEL (KG)	DIST. (NM)	
<b>390</b>	14.1	66	85	IDLE					241
<b>370</b>	13.5	64	80	IDLE	16.5	79	99	IDLE	252
<b>350</b>	12.9	62	76	IDLE	15.8	77	94	IDLE	264
<b>330</b>	12.4	61	72	IDLE	15.2	75	90	IDLE	277
<b>310</b>	11.9	59	69	IDLE	14.6	73	85	IDLE	289
<b>290</b>	11.4	58	65	IDLE	14.1	71	81	IDLE	300
<b>270</b>	10.9	56	61	IDLE	13.3	69	75	IDLE	300
<b>250</b>	10.3	54	56	IDLE	12.5	66	69	IDLE	300
<b>240</b>	9.9	53	54	IDLE	12.1	65	67	IDLE	300
<b>220</b>	9.3	51	50	IDLE	11.3	62	61	IDLE	300
<b>200</b>	8.7	48	45	IDLE	10.5	58	55	IDLE	300
<b>180</b>	8.0	44	41	IDLE	9.6	53	50	IDLE	300
<b>160</b>	7.3	39	37	IDLE	8.8	48	44	IDLE	300
<b>140</b>	6.6	34	32	IDLE	7.9	41	39	IDLE	300
<b>120</b>	5.9	29	28	IDLE	7.0	35	33	IDLE	300
<b>100</b>	5.2	25	24	IDLE	6.0	29	28	IDLE	300
<b>50</b>	1.9	8	8	IDLE	2.2	9	9	IDLE	250
<b>15</b>	.0	0	0	IDLE	.0	0	0	IDLE	250
CORRECTIONS		ENGINE ANTI ICE ON			TOTAL ANTI ICE ON			PER 1° ABOVE ISA	
TIME		+ 2.5 %			+ 3 %			+ 0.2 %	
FUEL		+ 22 %			+ 38 %			+ 0.5 %	
DISTANCE		+ 2.5 %			+ 3 %			+ 0.5 %	

11.0-08FOA320-214 CFM56-5B4/P SA23100010C5KG330 0 018590 0 0-1 .0 .00 0 03 .780300.000250.000 0 FCOM-ND-03-06-60-001-200



**A318/A319/A320/A321**  
FLIGHT CREW  
OPERATING MANUAL

## PERFORMANCE

### ONE ENGINE INOPERATIVE

DESCENT - DESCENT TO LANDING

Intentionally left blank