

# PEPWAVE

Broadband Possibilities

***MAX*** mobile router

## User Manual







Pepwave MAX Series:  
MAX 600 / 700 / HD2

Document Rev. 5.2  
September-11

#### COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice. Copyright © 2011 Pepwave Ltd. All Rights Reserved. Pepwave and the Pepwave logo are trademarks of Pepwave Ltd. Other brands or products mentioned may be trademarks or registered trademarks of their respective owners.

### Table of Contents

<b>1</b>	<b>INTRODUCTION AND SCOPE .....</b>	<b>4</b>
<b>2</b>	<b>GLOSSARY .....</b>	<b>5</b>
<b>3</b>	<b>PRODUCT FEATURES .....</b>	<b>6</b>
3.1	SUPPORTED NETWORK FEATURES .....	6
3.2	OTHER SUPPORTED FEATURES .....	7
<b>4</b>	<b>PEPWAVE MAX MOBILE ROUTER OVERVIEW .....</b>	<b>8</b>
4.1	MAX 600 .....	8
4.2	MAX 700 .....	8
4.3	MAX HD2 .....	10
<b>5</b>	<b>INSTALLATION.....</b>	<b>14</b>
5.1	PREPARATION .....	14
5.2	CONSTRUCTING THE NETWORK .....	14
5.3	CONFIGURING THE NETWORK ENVIRONMENT .....	15
5.4	MOUNTING THE UNIT.....	15
<b>6</b>	<b>CONNECTING TO WEB ADMIN INTERFACE.....</b>	<b>17</b>
<b>7</b>	<b>CONFIGURATION OF LAN INTERFACE(S) .....</b>	<b>19</b>
7.1	BASIC SETTINGS.....	19
7.2	WI-FI AP .....	22
<b>8</b>	<b>CONFIGURATION OF WAN INTERFACE(S) .....</b>	<b>24</b>
8.1	 ETHERNET WAN .....	25
8.2	 EXPRESS CARD /  PC CARD /  USB1 /  USB2.....	32
8.3	 WI-FI WAN .....	34
8.4	WAN HEALTH CHECK.....	37
8.5	BANDWIDTH ALLOWANCE MONITOR .....	39
<b>9</b>	<b>WI-FI SETTINGS .....</b>	<b>40</b>
9.1	STP (SPANNING TREE PROTOCOL) .....	42
<b>10</b>	<b>SITE-TO-SITE VPN .....</b>	<b>43</b>
10.1	CONFIGURING A SITE-TO-SITE VPN PROFILE .....	43
10.2	LINK FAILURE DETECTION.....	45
10.3	PEPWAVE MAX BEHIND NAT ROUTER .....	47
10.4	VPN STATUS .....	48
<b>11</b>	<b>MANAGEMENT OF OUTBOUND TRAFFIC TO WAN.....</b>	<b>49</b>
11.1	OUTBOUND POLICY .....	50
11.2	CUSTOM RULES FOR OUTBOUND POLICY.....	51

# User Manual

## PEPWAVE *MAX* mobile router

<b>12</b>	<b>PORT FORWARDING .....</b>	<b>58</b>
12.1	PORT FORWARDING SERVICE .....	58
12.2	UPNP / NAT-PMP SETTINGS .....	60
<b>13</b>	<b>NAT MAPPINGS.....</b>	<b>61</b>
<b>14</b>	<b>QOS .....</b>	<b>63</b>
14.1	USER GROUPS .....	63
14.2	BANDWIDTH CONTROL.....	64
14.3	APPLICATION .....	65
<b>15</b>	<b>FIREWALL .....</b>	<b>67</b>
15.1	OUTBOUND AND INBOUND FIREWALL .....	67
15.2	INTRUSION DETECTION AND DoS PREVENTION .....	71
<b>16</b>	<b>MISCELLANEOUS SETTINGS.....</b>	<b>72</b>
16.1	PPTP SERVER.....	72
16.2	SERVICE FORWARDING .....	73
16.3	SERVICE PASSTHROUGH.....	75
<b>17</b>	<b>SYSTEM SETTINGS.....</b>	<b>76</b>
17.1	ADMIN SECURITY .....	76
17.2	FIRMWARE UPGRADE .....	80
17.3	TIME .....	81
17.4	EMAIL NOTIFICATION.....	82
17.5	REMOTE SYSLOG .....	84
17.6	SNMP.....	85
17.7	CONFIGURATION .....	87
17.8	REBOOT .....	88
17.9	PING TEST.....	89
17.10	TRACEROUTE TEST .....	90
17.11	VPN TEST.....	90
<b>18</b>	<b>STATUS.....</b>	<b>91</b>
18.1	DEVICE.....	91
18.2	ACTIVE SESSIONS .....	92
18.3	CLIENT LIST .....	92
18.4	WINS CLIENT.....	93
18.5	SITE-TO-SITE VPN .....	93
18.6	UPNP / NAT-PMP .....	94
18.7	EVENT LOG .....	94
18.8	BANDWIDTH.....	95
<b>APPENDIX A. RESTORATION OF FACTORY DEFAULTS .....</b>		<b>99</b>
<b>APPENDIX B. DECLARATION.....</b>		<b>100</b>

# User Manual

## PEPWAVE *MAX* mobile router

### 1 Introduction and Scope

The Pepwave MAX Mobile Router provides link aggregation and load balancing across six WAN connections, allowing a combination of technologies like 3G HSDPA, EVDO, Wi-Fi, external WiMAX dongle, and Satellite to be utilized to connect to the Internet.

This manual presents how to set up the Pepwave MAX Mobile Router and provides an introduction to the features and usage of Pepwave MAX Mobile Router.

#### Tips

Want to know more about Pepwave MAX? Visit our [YouTube Channel](#) for a [video introduction!](#)



<http://www.youtube.com/PeplinkChannel#p/u/1/1ste4dQV-V8>

# User Manual

## PEPWAVE *MAX* mobile router

## 2 Glossary

The following terms, acronyms, and abbreviations are frequently used in this manual:

Term	Definition
<b>3G</b>	3rd Generation family of standards for wireless communications
<b>DHCP</b>	Dynamic Host Configuration Protocol
<b>WINS</b>	Windows Internet Name Service
<b>DNS</b>	Domain Name System
<b>EVDO</b>	Evolution-Data Optimized
<b>HSDPA</b>	High-Speed Downlink Packet Access
<b>GRE</b>	Generic Routing Encapsulation
<b>HTTP</b>	Hyper-Text Transfer Protocol
<b>ICMP</b>	Internet Control Message Protocol
<b>IP</b>	Internet Protocol
<b>LAN</b>	Local Area Network
<b>MAC Address</b>	Media Access Control Address
<b>MTU</b>	Maximum Transmission Unit
<b>MSS</b>	Maximum Segment Size
<b>NAT</b>	Network Address Translation
<b>PPPoE</b>	Point to Point Protocol over Ethernet
<b>QoS</b>	Quality of Service
<b>SNMP</b>	Simple Network Management Protocol
<b>TCP</b>	Transmission Control Protocol
<b>UDP</b>	User Datagram Protocol
<b>VPN</b>	Virtual Private Network
<b>VRRP</b>	Virtual Router Redundancy Protocol
<b>WAN</b>	Wide Area Network
<b>Wi-Fi</b>	Trademark of Wi-Fi Alliance for certified products based on IEEE 802.11 standards
<b>WiMAX</b>	Worldwide Interoperability for Microwave Access

### 3 Product Features

Pepwave MAX enables all LAN users to share broadband Internet connections, and provide advanced features to enhance Internet access. The following is the list of supported features on Pepwave MAX Mobile Router:

#### 3.1 Supported Network Features

##### 3.1.1 WAN

- Ethernet WAN Connection in Full/Half Duplex
- USB WAN connections
- PC Card WAN connection
- Express Card WAN connection
- Wi-Fi WAN connection
- Network Address Translation (NAT) / Port Address Translation (PAT)
- Inbound and Outbound NAT mapping
- IPsec NAT-T and PPTP packet passthrough
- MAC address clone and passthrough
- Customizable MTU and MSS values
- WAN connection health check
- Dynamic DNS (Supported service providers: changeip.com, dyndns.org, no-ip.org and tzo.com)

##### 3.1.2 LAN

- Wi-Fi AP
- Ethernet LAN ports
- DHCP server on LAN
- Static routing rules

##### 3.1.3 VPN

- Secure Site-to-Site VPN
- VPN load balancing and failover among selected WAN connections
- Site-to-Site VPN bandwidth bonding
- Ability to route Internet traffic to a remote VPN peer
- Optional pre-shared key setting
- Site-to-Site VPN Throughput, Ping and Traceroute Test
- PPTP server
- PPTP and IPsec passthrough

##### 3.1.4 Firewall

- Outbound (LAN to WAN) firewall rules
- Inbound (WAN to LAN) firewall rules per WAN connection
- Intrusion detection and prevention
- Specification of NAT mappings

# User Manual

## PEPWAVE *MAX* mobile router

### 3.1.5 Outbound Policy

- Link load distribution per TCP/UDP service
- Persistent routing for specified source and/or destination IP addresses per TCP/UDP service
- Traffic Prioritization and DSL optimization
- Prioritize and route traffic to VPN tunnels with Priority and Enforced algorithms

### 3.1.6 QoS

- Quality of Service for different applications and custom protocols
- User Group classification for different service levels
- Bandwidth usage control and monitoring on group- and user- level
- Application Prioritization for custom protocols and DSL optimization

## 3.2 Other Supported Features

- User-friendly web-based administration interface
- HTTP and HTTPS support for Web Admin Interface
- Configurable web administration port and administrator password
- Firmware upgrades, configuration backups, Ping, and Traceroute via Web Admin Interface
- Remote web based configuration (via WAN and LAN interfaces)
- Time server synchronization
- SNMP
- Email notification
- Read-only user for Web Admin
- Authentication and Accounting by RADIUS server for Web Admin
- Built-in WINS Servers
- Syslog
- SIP passthrough
- PPTP packet passthrough
- Event Log
- Active Sessions
- Client List
- WINS Client List
- UPnP / NAT-PMP
- Real-Time, Daily and Monthly Bandwidth Usage reports and charts


# User Manual

## PEPWAVE *MAX* mobile router

### 4 Pepwave MAX Mobile Router Overview

#### 4.1 MAX 600

##### 4.1.1 Front Panel Appearance



##### 4.1.2 LED Indicators

The statuses indicated by the Front Panel LEDs are as follows:

Power and Status Indicators		
<b>Power</b>	OFF	Power off
	Green	Power on
<b>Status</b>	OFF	System initializing
	Red	Booting up or busy
	Green	Ready state

Wi-Fi AP and Wi-Fi WAN Indicators		
<b>Wi-Fi WAN</b>	OFF	Disabled Intermittent
	Blinking	Trying to connect but not connected to any wireless network
	ON	Connected to wireless network(s) without traffic
	Continuous Blinking	Transferring data
<b>Wi-Fi AP</b>	OFF	Disabled Intermittent
	Blinking	Enabled but no client associated
	ON	Client(s) associated to wireless network
	Continuous Blinking	Transferring data to wireless network




# User Manual

## PEPWAVE *MAX* mobile router

LAN and Ethernet WAN Ports		
<b>Green LED</b>	ON	100 Mbps
	OFF	10 Mbps
<b>Yellow LED</b>	Solid	Port is connected without traffic
	Blinking	Data is transferring
	OFF	Port is not connected
<b>Port Type</b>	Auto MDI/MDI-X ports	

### 4.1.3 Rear Panel Appearance




# User Manual

## PEPWAVE *MAX* mobile router

### 4.2 MAX 700

#### 4.2.1 Front Panel Appearance



#### 4.2.2 LED Indicators

The statuses indicated by the Front Panel LEDs are as follows:

Status Indicators		
<b>Status</b>	OFF	System initializing
	Red	Booting up or busy
	Green	Ready state

Wi-Fi AP and Wi-Fi WAN Indicators		
<b>Wi-Fi WAN</b>	OFF	Disabled Intermittent
	Blinking	Trying to connect but not connected to any wireless network
	ON	Connected to wireless network(s) without traffic
	Continuous Blinking	Transferring data
<b>Wi-Fi AP</b>	OFF	Disabled Intermittent
	Blinking	Enabled but no client associated
	ON	Client(s) associated to wireless network
	Continuous Blinking	Transferring data to wireless network

# User Manual

## PEPWAVE *MAX* mobile router

LAN and Ethernet WAN Ports		
<b>Green LED</b>	ON	1000 Mbps
	OFF	10/100 Mbps
<b>Yellow LED</b>	Solid	Port is connected without traffic
	Blinking	Data is transferring
	OFF	Port is not connected
<b>Port Type</b>	Auto MDI/MDI-X ports	

### 4.2.3 Rear Panel Appearance




# User Manual

## PEPWAVE *MAX* mobile router

### 4.3 MAX HD2

#### 4.3.1 Front Panel Appearance



#### 4.3.2 LED Indicators

The statuses indicated by the Front Panel LEDs are as follows:

Status Indicators		
Status	OFF	System initializing
	Red	Booting up or busy
	Green	Ready state

Wi-Fi AP and Wi-Fi WAN Indicators		
Wi-Fi WAN / Cellular 1 / Cellular 2	OFF	Disabled Intermittent
	Blinking	Trying to connect but not connected to any wireless network
	ON	Connected to wireless network(s) without traffic
	Continuous Blinking	Transferring data

LAN and Ethernet WAN Ports		
Green LED	ON	1000 Mbps
	OFF	10/100 Mbps
Yellow LED	Solid	Port is connected without traffic
	Blinking	Data is transferring
	OFF	Port is not connected
Port Type	Auto MDI/MDI-X ports	

# User Manual

## PEPWAVE *MAX* mobile router

### 4.3.3 Rear Panel Appearance



# User Manual

## PEPWAVE *MAX* mobile router

### 5 Installation

Connecting the Network with Pepwave MAX Mobile Router:

#### 5.1 Preparation

Before installing Pepwave MAX Mobile Router, please prepare the following:


- At least one Internet/WAN access account and/or Wi-Fi access information.
- For each network connection,
  - **Ethernet WAN:** A 10/100BaseT UTP cable with RJ45 connector
  - **USB:** A USB modem
  - **Wi-Fi WAN:** A Wi-Fi antenna
  - **PC Card / Express Card WAN:** A PC Card/Express Card for the corresponding card slot.
- A computer with TCP/IP network protocol and a web browser installed. Supported browsers include Microsoft Internet Explorer 7.0 or above, Mozilla Firefox 3.0 or above, Apple Safari 3.1.1 or above, and Google Chrome 2.0 or above.

#### 5.2 Constructing the Network

At the high level, construct the network according to the following steps:

1. With an Ethernet cable, connect a computer to one of the LAN ports on the Pepwave MAX. Repeat with different cables for up to 4 computers to be connected.
2. With another Ethernet cable or a USB modem / Wi-Fi antenna / PC Card / Express Card, connect it to one of the WAN ports on the Pepwave MAX. Repeat the same procedure for other WAN ports.
3. Connect the power adapter to the power connector on the rear panel of Pepwave MAX, and then plug it into a power outlet.

The following figure schematically illustrates the configuration that results:



# User Manual

## PEPWAVE *MAX* mobile router

### 5.3 Configuring the Network Environment

To ensure that Pepwave MAX works properly in the LAN environment and can access the Internet via the WAN connections, please refer to the following setup procedures:


- LAN Configuration  
For basic configuration, refer to Section 7, **Connecting to Web Admin Interface**.  
For advanced configuration, go to Section 8, **Configuration of LAN Interface(s)**.
- WAN Configuration  
For basic configuration, refer to Section 7, **Connecting to Web Admin Interface**.  
For advanced configuration, go to Section 9, **Configuration of WAN Interface(s)**.

### 5.4 Mounting the Unit

#### 5.4.1 Wall Mount

Pepwave MAX can be mounted on the wall by screwing. After adding the screw on the wall, slide the MAX in the screw hole socket as indicated below.

Recommended Screw Specification: M3.5 x 20mm, Head Diameter 6mm, Head Thickness 2.4mm




# User Manual


## PEPWAVE *MAX* mobile router

### 5.4.2 Car Mount

Pepwave MAX can be mounted on a flat surface using the included car mounting plate. Place the car mount according to the label's direction, and screw it onto the device.



After mounting the plate on the back of the device, add screw on the plate on the flat surface.





# User Manual

## PEPWAVE *MAX* mobile router

### 6 Connecting to Web Admin Interface

1. Start a web browser on a computer that is connected with Pepwave MAX through LAN.
2. To connect to Web Admin Interface of Pepwave MAX, enter the following LAN IP address in the address field of the web browser:

http://192.168.50.1


(This is the default LAN IP address of Pepwave MAX.)

3. Enter the following to access the Web Admin Interface.


**User Name:** admin

**Password:** admin

(This is the default Username and Password of Pepwave MAX. The Admin and Read-only User Password can be changed at **System > Admin Security** of the Web Admin Interface.)



4. After successful login, the **Dashboard** of Web Admin Interface will be displayed. It looks similar to the following:



# User Manual

## PEPWAVE *MAX* mobile router

**Dashboard** shows the current WAN, LAN, Wi-Fi AP settings and statuses. You can simply change priority of WAN connections and switch on / off Wi-Fi AP in here. For further information about how-to set up these connections, please refer to Section 8 and 9.

**Device Information** shows the details about the device, including Model name, Firmware version and Uptime. For further information please refer to Section 19.

### Important Note

Configuration changes (e.g. WAN, LAN, Admin settings, etc.) will only take effect after clicking the **Save** button at the bottom of each page. The **Apply Changes** button causes the changes to be saved and applied.

# User Manual

## PEPWAVE *MAX* mobile router

## 7 Configuration of LAN Interface(s)

### 7.1 Basic Settings

The LAN Interface settings are located in **Network > LAN > Basic Settings**:

IP Settings	
IP Address *	192.168.50.1
Subnet Mask *	255.255.255.0 (/24)
Speed	Auto

DHCP Server Settings							
DHCP Server	<input checked="" type="checkbox"/> Enable						
IP Range	192.168.50.10 - 192.168.50.200						
Subnet Mask	255.255.255.0 (/24)						
Lease Time	1 Days 0 Hours 0 Mins 0 Seconds						
DNS Servers	<input checked="" type="checkbox"/> Assign DNS server automatically						
WINS Servers	<input checked="" type="checkbox"/> Assign WINS server <input checked="" type="radio"/> Built-in <input type="radio"/> External						
Extended DHCP Option	<table border="1"> <thead> <tr> <th>Option</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td colspan="2" style="text-align: center;">No Extended DHCP Option</td> </tr> <tr> <td colspan="2" style="text-align: center;"><input type="button" value="Add"/></td> </tr> </tbody> </table>	Option	Value	No Extended DHCP Option		<input type="button" value="Add"/>	
Option	Value						
No Extended DHCP Option							
<input type="button" value="Add"/>							
DHCP Reservation	<table border="1"> <thead> <tr> <th>Name</th> <th>MAC Address</th> <th>Static IP</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	Name	MAC Address	Static IP			
Name	MAC Address	Static IP					

Static Route Settings							
Static Route	<table border="1"> <thead> <tr> <th>Destination Network</th> <th>Subnet Mask</th> <th>Gateway</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	Destination Network	Subnet Mask	Gateway			
Destination Network	Subnet Mask	Gateway					

WINS Server Settings	
Enable	<input type="checkbox"/>

DNS Proxy Settings					
Enable	<input checked="" type="checkbox"/>				
DNS Caching	<input type="checkbox"/>				
Use Google DNS Server as Backup	<input type="checkbox"/>				
Local DNS Records	<table border="1"> <thead> <tr> <th>Host Name</th> <th>IP Address</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	Host Name	IP Address		
Host Name	IP Address				

\* Required

# User Manual

## PEPWAVE *MAX* mobile router

### IP Settings

**IP Address & Subnet Mask**

The IP address of Pepwave MAX on LAN.

**Speed**

This setting specifies the speed of the LAN Ethernet Port.

By default, **Auto** is selected and the appropriate data speed is automatically detected by Pepwave MAX.

In the event of negotiation issues, the port speed can be manually specified to circumvent the issues. You can also choose whether or not to advertise the speed to the peer by selecting the **Advertise Speed** checkbox.

### DHCP Server Settings

**DHCP Server**

When this setting is enabled, the DHCP server of Pepwave MAX automatically assigns an IP address to each computer that is connected via LAN and is configured to obtain an IP address via DHCP.

Pepwave MAX's DHCP server can prevent IP address collision on LAN.

**IP Range & Subnet Mask**

This setting allocates a range of IP address that will be assigned to LAN computers by the DHCP server of Pepwave MAX.

**Lease Time**

This setting specifies the length of time throughout which an IP address of a DHCP client remains valid. Upon expiration of the Lease Time, the assigned IP address will no longer be valid and the renewal of the IP address assignment will be required.

**DNS Servers**

This option allows you to input the DNS server addresses to be offered to the DHCP clients. If **Assign DNS server automatically** is selected, the Pepwave MAX's built-in DNS server address (i.e. LAN IP address) will be offered.

**WINS Server**

This option allows you to specify the Windows Internet Name Service (WINS) server. You may choose to use the **built-in WINS server** or **external WINS servers**.

When this unit is Site-to-Site VPN connected, other VPN peers can share this unit's built-in WINS server by entering this unit's LAN IP address in their DHCP WINS Servers setting. Therefore, all PC clients in the VPN can resolve the NetBIOS names of other clients in remote peers.

If you have enabled this option, a list of WINS clients will be displayed at **Status > WINS Clients**.

**Extended DHCP Option**

In addition to standard DHCP options (e.g. DNS server address, gateway address, subnet mask), you can specify the value of additional Extended DHCP Options defined in RFC 2132. In this case, you can pass additional configuration information to LAN hosts.

To define an Extended DHCP Option, click the **Add** button, choose the option that you want to define and enter its value. For values that are in IP address list format, you can enter one IP address per line in the provided text area input control. Each option is allowed to be defined once only.

**DHCP Reservation**

This setting reserves the assignment of fixed IP addresses for a list of computers on the LAN. The computers to be assigned fixed IP addresses on the LAN are



# User Manual

## PEPWAVE *MAX* mobile router

identified by their MAC addresses.



The fixed IP address assignment is displayed as a cross-reference list between the computers' Name, MAC addresses and fixed IP addresses.

The field Name (an optional field) is for you to define a name to represent the device. MAC addresses should be in the format of **00:AA:BB:CC:DD:EE**

Press  to create a new record. Press  to remove a record.

Reserved clients information can be imported from the Client List, located at **Status > Client List**. For more details, please refer to section 19.3.



### Static Route Settings

<b>Static Route</b>	<p>This table is for defining static routing rules for the LAN segment.</p> <p>A static route consists of the network address, subnet mask, and gateway address. The address and subnet mask values are in the format of <b>w.x.y.z</b></p> <p>The local LAN subnet and subnets behind the LAN will be advertised to the VPN. Remote routes sent over the VPN will also be accepted. Any VPN member will be able to route to the local subnets.</p> <p>Press  to create a new route. Press  to remove a route.</p>
---------------------	--

### WINS Server Settings

<b>Enable</b>	Check the box to enable the WINS Server. A list of WINS clients will be displayed at <b>Status &gt; WINS Clients</b> .
---------------	--

### DNS Proxy Settings

<b>Enable</b>	A check box to enable to DNS Proxy feature.
<b>DNS Caching</b>	This field is to enable DNS caching on the built-in DNS proxy server. When the option is enabled, queried DNS replies will be cached until the records' TTL has been reached. This feature can help improve the DNS lookup time. However, it cannot return the most updated result for those frequently updated DNS records. By default, it is <b>disabled</b> .
<b>Use Google DNS Server as Backup</b>	Check the box to enable this option, and the Pepwave MAX will automatically use Google DNS Server as a backup DNS server. The DNS proxy server will forward DNS requests to <a href="#">Google's Public DNS Servers</a> in the case if all WAN connections' DNS servers become unavailable. By default, it is <b>disabled</b> .
<b>Local DNS Records</b>	<p>This table is for defining custom local DNS records.</p> <p>A static local DNS record consists of a Host Name and an IP Address. When looking up the Host Name from the LAN to LAN IP of Pepwave MAX, the corresponding IP Address will be returned.</p> <p>Press  to create a new record. Press  to remove a record.</p>


# User Manual

## PEPWAVE *MAX* mobile router


### 7.2 Wi-Fi AP

The Wi-Fi LAN settings can be configured in **Network > LAN > Wi-Fi AP**.

Wi-Fi AP can also be switched on / off on the Dashboard.



Click **Add** button to create a new SSID.



Wireless Network Settings	
<b>Network Name (SSID)</b>	This setting allows you to specify a name to represent the virtual AP to be scanned by Wi-Fi clients.
<b>Enable</b>	When <b>Yes</b> is selected, this virtual AP is enabled. Select <b>No</b> to disable it. By default, it is enabled. You can also choose to enable or disable this virtual AP on the Dashboard - Connection Status of Wi-Fi AP, please refer to section 7 for information.
<b>Broadcast SSID</b>	When the box <b>Enable</b> is checked, this SSID can be scanned by Wi-Fi clients. By default, it is <b>enabled</b> .
<b>Multicast Filter</b>	When the box <b>Enable</b> is checked, multicast network traffic to the wireless SSID will be filtered. By default, it is <b>disabled</b> .
<b>Multicast Rate</b>	This field allows you to specify the transmit rate to be used for sending multicast network traffic. By default, Multicast Rate is set to <b>1M</b> .

Wireless Security Settings	
<b>Security Policy</b>	This setting specifies which security policy will be used for this wireless network. Available options:

# User Manual

## PEPWAVE *MAX* mobile router

- Open (No Encryption)

Wireless Security Settings	
Security Policy	Open (No Encryption)

- WPA/WPA2 – Personal

Wireless Security Settings	
Security Policy	WPA/WPA2 - Personal
Encryption	TKIP/AES:CCMP
Shared Key	<input type="text"/>
	<input checked="" type="checkbox"/> Hide Characters

- WPA/WPA2 – Enterprise

Wireless Security Settings	
Security Policy	WPA/WPA2 - Enterprise
Encryption	TKIP/AES:CCMP

RADIUS Server Settings	Primary Server	Secondary Server
Host	<input type="text"/>	<input type="text"/>
Secret	<input type="text"/>	<input type="text"/>
Authentication Port	1812 <input type="button" value="Default"/>	1812 <input type="button" value="Default"/>
Accounting Port	1813 <input type="button" value="Default"/>	1813 <input type="button" value="Default"/>

- 802.1X

Wireless Security Settings	
Security Policy	802.1X
WEP Key Size	40 bits (64-bit WEP)
Re-keying Period	0 seconds (0: Disable)

RADIUS Server Settings	Primary Server	Secondary Server
Host	<input type="text"/>	<input type="text"/>
Secret	<input type="text"/>	<input type="text"/>
Authentication Port	1812 <input type="button" value="Default"/>	1812 <input type="button" value="Default"/>
Accounting Port	1813 <input type="button" value="Default"/>	1813 <input type="button" value="Default"/>

- Static WEP

Wireless Security Settings	
Security Policy	Static WEP
Key Size	40 bits (64-bit WEP)
Key Format	ASCII
Encryption Key	<input type="text"/>
Shared Key Authentication	<input type="checkbox"/> Enable

### Access Control Settings

#### Restriction Mode


Access Control Settings	
Restriction Mode	Accept all except listed
MAC Address List	<input type="text"/> <input type="text"/> <input type="text"/>

This option allows you to perform access control through MAC address filtering. Available options are **None**, **Deny all except listed**, and **Accept all except listed**.

## 8 Configuration of WAN Interface(s)

The WAN Interface settings are located at: **Network > WAN**

To reorder different WANs' priority, just drag on the appropriate WAN by holding the left mouse button, move it to the desired priority (the first one would be the highest priority, the second one would be lower priority, and so on) and drop it by releasing the mouse button.



To disable a particular WAN connection, just drag on the appropriate WAN by holding the left mouse button, move it the **DISABLED** row and drop it by releasing the mouse button.

You can also do the above priority setting on the **Dashboard**, please refer to Section 7 for information.

Click the **Details** button in the corresponding row of connection to modify the connection setting.

### Important Note































Connection Details will be changed and become effective right AFTER clicking the **Save and Apply** button.



# User Manual

## PEPWAVE *MAX* mobile router

### 8.1 Ethernet WAN

WAN Port	
WAN Connection Name	Ethemet WAN1 <span>Default</span>
Connection Method 	DHCP 
IP Address	10.10.10.123
Subnet Mask	255.255.0.0
Default Gateway	10.10.10.1
DNS Servers	<input checked="" type="checkbox"/> Obtain DNS server address automatically 10.9.1.1 <input type="checkbox"/> Use the following DNS server address(es) DNS Server 1: <input type="text"/> DNS Server 2: <input type="text"/>
Hostname (Optional)	<input type="text"/> <input type="checkbox"/> Use custom hostname
Standby State 	<input checked="" type="radio"/> Remain connected <input type="radio"/> Disconnect
Upstream Bandwidth 	100  Mbps
Downstream Bandwidth 	100  Mbps
Health Check Method 	DNS Lookup 
Health Check DNS Servers 	Host 1: <input type="text"/> Host 2: <input type="text"/> <input checked="" type="checkbox"/> Use first two DNS servers as Health Check DNS Servers <input type="checkbox"/> Include public DNS servers
Timeout 	5  second(s)
Health Check Interval 	5  second(s)
Health Check Retries 	3 
Recovery Retries 	3 
Dynamic DNS 	Disabled 
Bandwidth Allowance Monitor 	<input checked="" type="checkbox"/> Enable
Action 	Email notification is currently disabled. You can get notified when usage hits 75%/95% of monthly allowance by enabling <a href="#">Email Notification</a> . <input checked="" type="checkbox"/> Disconnect when usage hits 100% of monthly allowance
Start Day	On 1st  of each month at 00:00 midnight
Monthly Allowance	10  GB
Port Speed 	Auto 
MTU 	<input type="radio"/> Auto <input checked="" type="radio"/> Custom Value: 1440 <span>Default</span>
MSS 	<input checked="" type="radio"/> Auto <input type="radio"/> Custom <input type="text"/>
MAC Address Clone 	00 : 1A : 11 : BB : AA : 22 <span>Default</span>
Reply to ICMP PING 	<input checked="" type="radio"/> Yes <input type="radio"/> No

Save and Apply Cancel

# User Manual

## PEPWAVE *MAX* mobile router

### Ethernet WAN Settings

<b>WAN Connection Name</b>	This field is for defining a name to represent this WAN connection.
<b>Connection Method</b>	<p>There are three possible connection methods for Ethernet WAN:</p> <ul style="list-style-type: none"><li>• <b>DHCP</b></li><li>• <b>Static IP</b></li><li>• <b>PPPoE</b></li></ul> <p>The connection method and details are determined by, and can be obtained from, the ISP.</p> <p>See the Sections 9.1.1, 9.1.2, and 9.1.3 for details of each connection method.</p>
<b>Standby State</b>	<p>This setting specifies the state of the WAN connection. The available options are <b>Remain connected</b> and <b>Disconnect</b>.</p> <p>The default state is <b>Remain Connected</b>.</p>
<b>Upstream Bandwidth</b>	This setting specifies the data bandwidth in the outbound direction from the LAN through the WAN interface.
<b>Downstream Bandwidth</b>	<p>This setting specifies the data bandwidth in the inbound direction from the WAN interface to the LAN.</p> <p>This value is referenced as the default weight value when using the custom rule <b>Default (Auto)</b>, the algorithm <b>Least Used</b>, or the algorithm <b>Persistence (Auto)</b> in Outbound Policy with <b>Managed by Custom Rules</b> chosen (see Section 12.1).</p>
<b>Health Check Method</b>	<p>This setting specifies the health check method for the WAN connection. The value of method can be configured as <b>Disabled</b>, <b>Ping</b> or <b>DNS Lookup</b>.</p> <p>The default method is <b>Disabled</b>.</p> <p>See Section 9.4 for configuration details.</p>
<b>Dynamic DNS</b>	<p>This setting specifies the dynamic DNS service provider to be used for the WAN based on supported dynamic DNS service providers:</p> <ul style="list-style-type: none"><li>• changeip.com</li><li>• dyndns.org</li><li>• no-ip.org</li><li>• tzo.com</li></ul> <p>Select <b>Disabled</b> to disable this feature.</p> <p>See Section 9.1.4 for configuration details.</p>
<b>Bandwidth Allowance Monitor</b>	<p>This option allows you to enable bandwidth usage monitoring on this WAN connection for each billing cycle. When this is not enabled, bandwidth usage of each month is still being tracked but no action will be taken.</p> <p>See Section 9.5 for configuration details.</p>

# User Manual

## PEPWAVE *MAX* mobile router

<b>Port Speed</b>	<p>This setting specifies port speed and duplex configurations of the WAN Port.</p> <p>By default, <b>Auto</b> is selected and the appropriate data speed is automatically detected by Pepwave MAX.</p> <p>In the event of negotiation issues, the port speed can be manually specified to circumvent the issues. You can also choose whether or not to advertise the speed to the peer by selecting the <b>Advertise Speed</b> checkbox.</p>
<b>MTU</b>	<p>This setting specifies the Maximum Transmission Unit.</p> <p>By default, MTU is set to <b>Custom 1440</b>.</p> <p>You may adjust the MTU value by editing the text field. Click <b>Default</b> to restore the default MTU value. Select <b>Auto</b> and the appropriate MTU value will be automatically detected. The auto-detection will run each time when the WAN connection establishes.</p>
<b>MSS</b>	<p>This setting should be configured based on the maximum payload size that the local system can handle. The MSS (Maximum Segment Size) is computed from the MTU minus 40 bytes for TCP over IPv4.</p> <p>If MTU is set to Auto, the MSS will also be set automatically.</p> <p>By default, MSS is set to <b>Auto</b>.</p>
<b>MAC Address Clone</b>	<p>This setting allows you to configure the MAC address.</p> <p>Some service providers (e.g. cable providers) identify the client's MAC address and require the client to always use the same MAC address to connect to the network. In such cases, change the WAN interface's MAC address to the original client PC's one via this field.</p> <p>The default MAC Address is a unique value assigned at the factory. In most cases, the default value is sufficient. Clicking the <b>Default</b> button restores the MAC Address to the default value.</p>
<b>Reply to ICMP PING</b>	<p>If this field is disabled, the WAN connection will not respond to ICMP PING requests.</p> <p>By default, this is <b>enabled</b>.</p>

# User Manual

## PEPWAVE *MAX* mobile router

### 8.1.1 DHCP Connection

The DHCP connection method is suitable if the ISP provides an IP address automatically by DHCP (e.g. Satellite Modem, WiMAX Modem, Cable, Metro Ethernet, etc.).

Connection Method ?	DHCP
IP Address	10.10.10.123
Subnet Mask	255.255.0.0
Default Gateway	10.10.10.1
DNS Servers	<input checked="" type="checkbox"/> Obtain DNS server address automatically 10.9.1.1 <input type="checkbox"/> Use the following DNS server address(es) DNS Server 1: <input type="text"/> DNS Server 2: <input type="text"/>
Hostname (Optional)	<input type="text"/> <input type="checkbox"/> Use custom hostname

#### DHCP Settings

##### IP Address / Subnet Mask / Default Gateway

This information is obtained from the ISP automatically.

##### DNS Servers

Each ISP may provide a set of DNS servers for DNS lookups. This setting specifies the DNS (Domain Name System) Servers to be used when a DNS lookup is routed through this connection.

Selecting **Obtain DNS server address automatically** results in the DNS Servers to be assigned by the WAN DHCP Server to be used for outbound DNS lookups over the connection. (The DNS Servers are obtained along with the WAN IP address assigned from the DHCP server.)

When **Use the following DNS server address(es)** is selected, you may enter custom DNS server addresses for this WAN connection into the **DNS server 1** and **DNS server 2** fields.

##### Hostname (Optional)




If your service provider's DHCP server requires you to supply a hostname value upon acquiring an IP address, you may enter the value here. If your service provider does not provide you with the value, you can safely bypass this option.

# User Manual

## PEPWAVE *MAX* mobile router

### 8.1.2 Static IP Connection

This Static IP connection method is suitable if ISP provides a static IP address to connect directly.

Connection Method 	Static IP 
IP Address	<input type="text"/>
Subnet Mask	255.255.255.0 
Default Gateway	<input type="text"/>
DNS Servers	<input checked="" type="checkbox"/> Use the following DNS server address(es) DNS Server 1: <input type="text"/> DNS Server 2: <input type="text"/>

#### Static IP Settings

**IP Address /  
Subnet Mask /  
Default Gateway**

These settings allow you to specify the information required in order to communicate on the Internet via a fixed Internet IP address.  
The information is typically determined by and can be obtained from the ISP.

**DNS Servers**



Each ISP may provide a set of DNS servers for DNS lookups. This field specifies the DNS (Domain Name System) Servers to be used when a DNS lookup is routed through this connection.  
You can input the ISP provided DNS server addresses into the **DNS server 1** and **DNS server 2** fields. If no address is entered here, this link will not be used for DNS lookups.

# User Manual

## PEPWAVE *MAX* mobile router

### 8.1.3 PPPoE Connection

This connection method is suitable if ISP provides login ID / password to connect via PPPoE.

Connection Method 	PPPoE 
IP Address	123.123.123.10
Subnet Mask	255.255.255.0
Default Gateway	123.123.123.1
PPPoE User Name	<input type="text"/>
PPPoE Password	<input type="password"/>
Confirm PPPoE Password	<input type="password"/>
Service Name (Optional)	<input type="text"/> Leave it blank unless it's provided by ISP
DNS Servers	<input checked="" type="checkbox"/> Obtain DNS server address automatically 123.123.123.1 210.210.210.1 <input type="checkbox"/> Use the following DNS server address(es) DNS Server 1: <input type="text"/> DNS Server 2: <input type="text"/>

PPPoE Settings	
<b>IP Address / Subnet Mask / Default Gateway</b>	This information is obtained from the ISP automatically.
<b>PPPoE User Name / Password</b>	Enter the required information in these fields in order to connect via PPPoE to the ISP. The parameter values are determined by and can be obtained from the ISP.
<b>Confirm PPPoE Password</b>	Verify your password by entering it again in this field.
<b>Service Name</b>	Service Name is provided by the ISP. <b>Note: Leave this field blank unless it is provided by your ISP.</b>
<b>DNS Servers</b>	<p>Each ISP may provide a set of DNS servers for DNS lookups. This setting specifies the DNS (Domain Name System) Servers to be used when a DNS lookup is routed through this connection.</p> <p>Selecting <b>Obtain DNS server address automatically</b> results in the DNS Servers assigned by the PPPoE server to be used for outbound DNS lookups over the WAN connection. (The DNS Servers are obtained along with the WAN IP address assigned from the PPPoE server.)</p> <p>When <b>Use the following DNS server address(es)</b> is selected, you can put custom DNS server addresses for this WAN connection into the <b>DNS server 1</b> and <b>DNS server 2</b> fields.</p>

# User Manual

## PEPWAVE *MAX* mobile router

### 8.1.4 Dynamic DNS Settings

Pepwave MAX provides the functionality to register the domain name relationships to dynamic DNS service providers. Through registration with dynamic DNS service provider(s), the default public Internet IP address of each WAN connection can be associated with a host name.

Either upon a change in IP address or every 23 days without link reconnection, Pepwave MAX will connect to the dynamic DNS service provider to perform an IP address update within the provider's records.

Dynamic DNS	<input type="text" value="changeip.com"/>
Account Name	<input type="text" value="demo"/>
Password	<input type="password" value="....."/>
Confirm Password	<input type="password" value="....."/>
Hosts	<input type="text"/>

Dynamic DNS Settings	
<b>Dynamic DNS</b>	<p>This setting specifies the dynamic DNS service provider to be used for the WAN based on supported dynamic DNS service providers:</p> <ul style="list-style-type: none"><li>• changeip.com</li><li>• dyndns.org</li><li>• no-ip.org</li><li>• tzo.com</li></ul> <p>Select <b>Disabled</b> to disable this feature.</p>
<b>Account Name / Email Address</b>	<p>This setting specifies the registered user name for the dynamic DNS service.</p>
<b>Password / TZO Key</b>	<p>This setting specifies the password for the dynamic DNS service.</p>
<b>Hosts / Domain</b>	<p>This field allows you to specify a list of host names or domains to be associated with the public Internet IP address of the WAN connection.</p> <p>If you need to enter more than one host, you can use a carriage return to separate them.</p>

### Important Note

In order to use dynamic DNS services, appropriate host name registration(s) as well as a valid account with a supported dynamic DNS service provider are required.


A dynamic DNS update is performed whenever a WAN's IP address changes. E.g. IP is changed after a DHCP IP refresh, reconnection, etc.

Due to dynamic DNS service providers' policy, a dynamic DNS host will automatically expire if the host record has not been updated for a long time. Therefore Pepwave MAX performs an update every 23 days even if a WAN's IP address has not changed.

# User Manual

## PEPWAVE *MAX* mobile router

### 8.2 Express Card / PC Card / USB1 / USB2

Express Card / PC Card / USB1 / USB2	
Wireless Adaptor	4G LTE Smart Modem
SIM Card IMSI	XXXXXXXXXXXX
Carrier	XXXXXXXXXX
Country/Region	United States
Signal Strength	-75 dBm 
IP Address	10.10.10.111
DNS Servers	10.10.10.11 10.10.10.12
WAN Connection Name	USB WAN <span style="float: right;">Default</span>
Standby State	<input type="radio"/> Remain connected <input checked="" type="radio"/> Disconnected
Operator Settings	<input checked="" type="radio"/> Auto <input type="radio"/> Custom
APN	-
Login	-
Password	-
Dial Number	-
SIM PIN (Optional)	•••• <input checked="" type="checkbox"/> Hide Characters
Health Checking Settings	
Method	SmartCheck
Timeout	5 second(s)
Health Check Interval	5 second(s)
Health Check Retries	3
Recovery Retries	3
Bandwidth Allowance Monitor	<input type="checkbox"/> Enable
Modem Specific Settings	
Network Type	3G preferred
GSM Frequency Band	All Bands

#### Express Card / PC Card / USB Settings

<b>SIM Card IMSI</b>	This is the International Mobile Subscriber Identity which uniquely identifies the SIM card. This is applicable to 3G modems only.
<b>Carrier</b>	This field shows the name of the carrier who issues the SIM card (for 3G) or the modem (for EVDO).
<b>Country/ Region</b>	This is the country/region of the carrier who issues the EVDO modem.
<b>Signal Strength</b>	This field shows the signal strength of the connection.
<b>IP Address</b>	This information is obtained from the carrier automatically.
<b>DNS Servers</b>	Each carrier may provide a set of DNS servers for DNS lookups. This field specifies the DNS (Domain Name System) Servers are currently effective when a DNS lookup is routed through this connection. This information is obtained from the carrier automatically or can be entered manually by users.



# User Manual


## PEPWAVE *MAX* mobile router

<b>WAN Connection Name</b>	This field is for defining a name to represent this WAN connection.
<b>Standby State</b>	This option allows you to choose whether to remain the connection connected or disconnected when this WAN connection is no longer in the highest priority and has entered the standby state. When <b>Remain connected</b> is chosen, upon bringing up this WAN connection to active, it will be immediately available for use.
<b>Operator Settings</b>	<p>This setting applies to 3G / EDGE / GPRS modem only. It does not apply to EVDO / EVDO Rev. A modem.</p> <p>This allows you to configure the APN settings of your connection. If <b>Auto</b> is selected, the mobile operator should be detected automatically. The connected device will be configured and connection will be made automatically afterwards. If there is any difficulty in making connection, you may select <b>Custom</b> to enter your carrier's <b>APN, Login, Password, and Dial Number</b> settings manually. The correct values can be obtained from your carrier.</p> <p>The default and recommended Operator Settings is <b>Auto</b>.</p>
<b>APN / Login / Password / Dial Number / SIM PIN</b>	<p>When <b>Auto</b> is selected, the information in these fields will be filled automatically. Select the option <b>Custom</b> and you may customize these parameters. The parameters values are determined by and can be obtained from the ISP.</p>
<b>Health Checking Settings</b>	<p>This setting allows you to specify the health check method for the WAN connection. The as available options are <b>Disabled</b> and <b>SmartCheck</b>.</p> <p>The default method is <b>SmartCheck</b>. See Section 9.4 for configuration details.</p>
<b>Bandwidth Allowance Monitor</b>	<p>This option allows you to enable bandwidth usage monitoring on this WAN connection for each billing cycle. When this is not enabled, bandwidth usage of each month is still being tracked but no action will be taken.</p> <p>See Section 9.5 for configuration details.</p>
<b>Modem Specific Settings</b>	The settings under this category may or may not be available depending on the model of the connected device.
<b>Network Type</b>	<p>This setting allows you to define your preference of using the 3G and/or 2G networks. 3G networks include HSPA / UMTS; 2G networks include EDGE / GPRS.</p> <p>If <b>3G only</b> or <b>2G only</b> is chosen, only the HSPA / UMTS or EDGE / GPRS network will be used, respectively. If the chosen network is not available, no other network will be used regardless of its availability. The modem connection will remain offline.</p> <p>If <b>3G preferred</b> or <b>2G preferred</b> is chosen, the chosen network will be used when it is available. If the chosen network is not available, the other network will be used whenever available.</p> <p>The default Network Type is <b>3G preferred</b>.</p>
<b>GSM Frequency Band</b>	<p>This setting allows you to specify which GSM frequency band to be used.</p> <p><b>GSM1900</b> is used in United States, Canada, and many other countries in the Americas.</p> <p><b>GSM900 / GSM1800 / GSM2100</b> is used in Europe, Middle East, Africa, Asia, Oceania, and Brazil.</p> <p>If <b>All Bands</b> is chosen, the appropriate frequency band will be used automatically.</p> <p>The default GSM Frequency Band is <b>All Bands</b>.</p>





# User Manual

## PEPWAVE *MAX* mobile router

### 8.3 Wi-Fi WAN

Wi-Fi WAN	
Network Name (SSID)	Wi-Fi Hotspot1 <span style="float: right;">Wireless Networks</span>
MAC Address (BSSID)	06:11:88:DD:BB:FF
Signal Strength	-45 dBm 
IP Address	10.10.10.123
Subnet Mask	255.255.255.0
Default Gateway	10.10.10.1
DNS Servers	10.10.10.1 10.10.10.2
WAN Connection Name	Wi-Fi Network <span style="float: right;">Default</span>
Standby State	<input checked="" type="radio"/> Remain connected <input type="radio"/> Disconnect
Health Check Method	DNS Lookup
Health Check DNS Servers	Host 1: <input type="text"/> Host 2: <input type="text"/> <input checked="" type="checkbox"/> Use first two DNS servers as Health Check DNS Servers <input type="checkbox"/> Include public DNS servers
Timeout	5 second(s)
Health Check Interval	5 second(s)
Health Check Retries	3
Bandwidth Allowance Monitor	<input type="checkbox"/> Enable
Wi-Fi Association Mode	<input type="radio"/> Stronger Signal Strength <input checked="" type="radio"/> Profile Priority
Connect to Any Open Mode AP	<input type="radio"/> Yes <input checked="" type="radio"/> No
Reply to ICMP PING	<input checked="" type="radio"/> Yes <input type="radio"/> No

Wi-Fi Connection Profiles  Drag and drop to change the profile priority		
Network Name (SSID)	Security	
Wi-Fi Hotspot1	 WPA/WPA2-Personal	
Wi-Fi Hotspot2	Open	

[Create Profile...](#)

Wi-Fi WAN Settings	
<b>Network Name (SSID)</b>	This is the Wi-Fi connection name broadcast from the Wi-Fi access point.
<b>MAC Address (BSSID)</b>	This field shows the MAC address of the device at the Wi-Fi access point.
<b>Signal Strength</b>	This field shows the signal strength of the Wi-Fi connection.

# User Manual

## PEPWAVE *MAX* mobile router

<b>IP Address / Subnet Mask / Default Gateway / DNS Servers</b>	This information is obtained from the Wi-Fi access point automatically.
<b>WAN Connection Name</b>	This field is for defining a name to represent this WAN connection.
<b>Standby State</b>	This setting specifies the state of the WAN connection while in standby. The available options are <b>Remain Connected</b> (hot standby) and <b>Disconnect</b> (cold standby).
<b>Health Check Method</b>	This setting allows you to specify the health check method for the WAN connection. The available options are <b>Disabled, Ping, and DNS Lookup</b> . The default method is <b>Disabled</b> . See Section 9.4 for configuration details.
<b>Bandwidth Allowance Monitor</b>	This option allows you to enable bandwidth usage monitoring on this WAN connection for each billing cycle. When this is not enabled, bandwidth usage of each month is still being tracked but no action will be taken. See Section 9.5 for configuration details.
<b>Wi-Fi Association Mode</b>	This option is to specify the Wi-Fi access point selection criteria during association. When <b>Stronger Signal Strength</b> is selected, the access point that matches one of the listed Wi-Fi Connection Profiles and has the strongest received signal will be selected regardless of its profile priority. When <b>Profile Priority</b> is selected, the access point that matches one of the listed of Wi-Fi Connection Profiles and has the highest priority will be selected. By default, <b>Stronger Signal Strength</b> is selected.
<b>Connect to Any Open Mode AP</b>	This option is to specify whether the Wi-Fi WAN will connect to any open mode access point it finds. By default, this is <b>disabled</b> .
<b>Reply to ICMP PING</b>	If this field is disabled, the WAN connection will not respond to ICMP PING requests. By default, this is <b>enabled</b> .

# User Manual

## PEPWAVE *MAX* mobile router

### 8.3.1 Create Wi-Fi Connection Profile

You can manually create a profile to connect to a Wi-Fi connection. It is useful for creating a profile for connecting to hidden-SSID access points. Click on the link **Create Profile...** and the following window will be displayed.

Wi-Fi Connection	
Network Name (SSID)	Wi-Fi Hotspot
Security	Open
IP Address	<input checked="" type="radio"/> Obtain an IP address automatically <input type="radio"/> Static

OK Cancel

Create Wi-Fi Connection Profile Settings																							
<b>Network Name (SSID)</b>	This field is for defining a name to represent this Wi-Fi connection.																						
<b>Security</b>	<p>This option allows you to select which security policy is used for this wireless network.</p> <p>Available options:</p> <ul style="list-style-type: none"><li><b>Open</b><table border="1"><tr><td>Security</td><td>Open</td></tr></table></li><li><b>WEP</b><table border="1"><tr><td>Security</td><td>WEP</td></tr><tr><td>Encryption Key</td><td><input type="text"/></td></tr><tr><td></td><td><input checked="" type="checkbox"/> Hide Characters</td></tr></table></li><li><b>WPA/WPA2 – Personal</b><table border="1"><tr><td>Security</td><td>WPA/WPA2-Personal</td></tr><tr><td>Shared Key</td><td><input type="text"/></td></tr><tr><td></td><td><input checked="" type="checkbox"/> Hide Characters</td></tr></table></li><li><b>WPA/WPA2 – Enterprise</b><table border="1"><tr><td>Security</td><td>WPA/WPA2-Enterprise</td></tr><tr><td>Login ID</td><td><input type="text"/></td></tr><tr><td>Password</td><td><input type="text"/></td></tr><tr><td>Password Again</td><td><input type="text"/></td></tr></table></li></ul> <p>The settings to be displayed under this row will vary depending on the selected security policy.</p>	Security	Open	Security	WEP	Encryption Key	<input type="text"/>		<input checked="" type="checkbox"/> Hide Characters	Security	WPA/WPA2-Personal	Shared Key	<input type="text"/>		<input checked="" type="checkbox"/> Hide Characters	Security	WPA/WPA2-Enterprise	Login ID	<input type="text"/>	Password	<input type="text"/>	Password Again	<input type="text"/>
Security	Open																						
Security	WEP																						
Encryption Key	<input type="text"/>																						
	<input checked="" type="checkbox"/> Hide Characters																						
Security	WPA/WPA2-Personal																						
Shared Key	<input type="text"/>																						
	<input checked="" type="checkbox"/> Hide Characters																						
Security	WPA/WPA2-Enterprise																						
Login ID	<input type="text"/>																						
Password	<input type="text"/>																						
Password Again	<input type="text"/>																						




# User Manual

## PEPWAVE *MAX* mobile router

### 8.4 WAN Health Check

To ensure traffic is routed to healthy WAN connections only, Pepwave MAX provides the functionality to periodically check the health of each WAN connection.

The Health Check settings for each WAN connection can be independently configured via **Network > WAN > Details**:

Health Check Settings	
<b>Method</b>	<p>This setting specifies the health check method for the WAN connection. The value of Method can be configured as <b>Disabled</b>, <b>Ping</b> or <b>DNS Lookup</b>. The default method is <b>DNS Lookup</b>.</p> <p>For Mobile Internet connection, the value of Method can be configured as <b>Disabled</b> or <b>SmartCheck</b>.</p>
<b>Health Check Disabled</b>	
	
<p>When <b>Disabled</b> is chosen in the Method field, the WAN connection will always be considered as up. The connection will not be treated as down in the event of IP routing errors.</p>	
<b>Health Check Method: PING</b>	
	
<p>The ICMP PING packets will be issued to test the connectivity with a configurable target IP address or host name. A WAN connection is considered as up if PING responses are received from either one or both of the PING Hosts.</p>	
<b>PING Hosts</b>	<p>This setting specifies IP addresses or host names with which connectivity is to be tested via ICMP Ping.</p> <p>If <b>Use first two DNS servers as Ping Hosts</b> is checked, the target PING Host will be the first DNS server for the corresponding WAN connection.</p> <p>Reliable PING hosts with a high uptime should be considered.</p> <p>By default, the first two DNS servers of the WAN connection are used as the PING Hosts.</p>
<b>Health Check Method: DNS Lookup</b>	
	
<p>DNS lookups will be issued to test the connectivity with target DNS servers. The connection will be treated as up if DNS responses are received from either one or both of the servers, regardless of whether the result was positive or negative.</p>	
<b>Health Check DNS Servers</b>	<p>This field allows you to specify two DNS hosts' IP address with which connectivity is to be tested via DNS Lookup.</p> <p>If <b>Use first two DNS servers as Health Check DNS Servers</b> is checked, the first two DNS servers will be the DNS lookup targets for checking a connection's health. If the box is not checked, field Host 1 must be filled and field Host 2 is optional.</p>

# User Manual


## PEPWAVE *MAX* mobile router

If the box **Include public DNS servers** is selected and no response is received from all specified DNS servers, DNS lookups will also be issued to some public DNS servers. A WAN connection will be treated as down only if there is also no response received from the public DNS servers.

Connections will be considered up if DNS responses are received from any one of the health check DNS servers, regardless of a positive or negative result.





By default, the first two DNS servers of the WAN connection are used as the Health Check DNS Servers.

### Health Check Method: SmartCheck

Method		SmartCheck ▼
--------	---	--------------

**SmartCheck** monitors the link status and is optimized for mobile networks with high traffic latency.

### Other Health Check Settings

Timeout		5 ▼	second(s)
Health Check Interval		5 ▼	second(s)
Health Retries		3 ▼	
Recovery Retries		3 ▼	

**Timeout** This setting specifies the timeout, in seconds, for ping/DNS lookup requests. Default Timeout is set to **5** second.

**Health Check Interval** This setting specifies the time interval, in seconds, between ping or DNS lookup requests. Default Health Check Interval is **5** seconds.

**Health Check Retries** This setting specifies the number of consecutive ping/DNS lookup timeouts after which Pepwave MAX is to treat the corresponding WAN connection as down. Default Health Retries is set to **3**.


For example, with the default Health Retries setting of 3, after consecutive 3 timeouts, the corresponding WAN connection will be treated as down.

**Recovery Retries** This setting specifies the number of consecutive successful ping/DNS lookup responses that must be received before Pepwave MAX treats a previously down WAN connection to be up again.

By default, Recover Times is set to **3**. For example, a WAN connection that is treated as down will be considered to be up again upon receiving 3 consecutive successful ping/DNS lookup responses.

### Automatic Public DNS Server Check on DNS Test Failure

In case the health check method is set to DNS Lookup and checks failed, the MAX will automatically perform DNS lookups on some public DNS servers. If the tests are success, it means the WAN may not be down but rather the target DNS server became malfunctioned. You will see the following warning message on the Main page.



 **Failed to receive DNS response from the health-check DNS servers for WAN connection 3. But public DNS server lookup test via the WAN passed. So please check the DNS server settings.**

# User Manual

## PEPWAVE *MAX* mobile router

### 8.5 Bandwidth Allowance Monitor

Bandwidth Allowance Monitor helps keep track of your network usage.

Bandwidth Allowance Monitor 	<input checked="" type="checkbox"/> Enable
Action 	Email notification is currently disabled. You can get notified when usage hits 75%/95% of monthly allowance by enabling <a href="#">Email Notification</a> . <input checked="" type="checkbox"/> Disconnect when usage hits 100% of monthly allowance
Start Day	On <input type="text" value="1st"/> of each month at 00:00 midnight
Monthly Allowance	<input type="text" value="10"/> <input type="text" value="GB"/>

Bandwidth Allowance Monitor	
<b>Action</b>	If the feature Email Notification is enabled, you will be notified through email when usage hits 75% and 95% of the monthly allowance. If the box <b>Disconnect when usage hits 100% of monthly allowance</b> is checked, this WAN connection will be disconnected automatically when the usage hits the monthly allowance. It will not resume connection unless this option has been turned off or the usage has been reset when a new billing cycle starts.
<b>Start Day</b>	This option allows you to define which day in the month each billing cycle begins.
<b>Monthly Allowance</b>	This field is for defining the maximum bandwidth usage allowed for the WAN connection each month.

# User Manual

## PEPWAVE *MAX* mobile router

### 9 Wi-Fi Settings

Wi-Fi settings can be configured at **Advanced > Wi-Fi Settings**:

Wi-Fi AP Radio Settings	
Protocol	802.11b/g
Operating Country	United States
Channel	1 (2.412 GHz)
Output Power	23 dBm (200 mW)

Wi-Fi WAN Radio Settings	
Output Power	23 dBm (200 mW)

Wi-Fi AP Advanced Settings	
STP	<input type="checkbox"/> Enable
Layer 2 Communication	<input checked="" type="checkbox"/> Enable
802.1X Version	<input type="radio"/> V1 <input checked="" type="radio"/> V2
Beacon Rate	1Mbps
Beacon Interval	100ms
DTIM	1
RTS Threshold	0
Slot Time	9 $\mu$ s
ACK Timeout	48 $\mu$ s
CTS Timeout	48 $\mu$ s

Wi-Fi AP Radio Settings	
<b>Protocol</b>	This option allows you to specify whether 802.11b and/or 802.11g client association requests will be accepted. Available options are <b>802.11b/g</b> , <b>802.11b Only</b> , and <b>802.11g Only</b> . By default, <b>802.11b/g</b> is selected.
<b>Operating Country</b>	This option set the country whose regulations the Pepwave MAX follows.
<b>Channel</b>	This option allows you to select which 802.11 RF channel will be utilized. <b>Channel 1 (2.412 GHz)</b> is selected by default.
<b>Output Power</b>	This option is for specifying the transmission output power for the Wi-Fi AP. By default, <b>23 dBm (200 mW)</b> or <b>20 dBm (100 mW)</b> (depending on which operating country you have chosen in the previous section) is selected.

**Note to US model owner: To comply with US FCC regulation, the country selection function has been completely removed from all US models. The above function is for non-US models only.**

Wi-Fi WAN Radio Settings	
<b>Output Power</b>	This option is for specifying the transmission output power for the Wi-Fi WAN. By default, <b>23 dBm (200 mW)</b> or <b>20 dBm (100 mW)</b> (depending on which operating country you have chosen in the previous section) is selected.



# User Manual

## PEPWAVE *MAX* mobile router




### Wi-Fi AP Advanced Settings

<b>STP</b>	<p>This option allows you to enable the Spanning Tree Protocol to prevent path redundancy. By default, it is <b>disabled</b>.</p> <p>See Section 10.1 for details.</p>
<b>Layer 2 Communication</b>	<p>This option allows you to choose whether clients on the network should be able to communicate with each other directly.</p> <p>If the checkbox <b>Enable</b> is selected, clients are allowed to communicate with each other directly, and traffic will not be passed to any uplink equipment.</p> <p>If this option is disabled, clients are not allowed to communicate directly. Traffic will be passed to uplink equipments/uplink routers before communication can be established among clients.</p> <p>By default, it is <b>enabled</b>.</p>
<b>802.1X Version</b>	<p>This option allows you to select between V1 or V2 of the 802.1X EAPOL.</p> <p>When <b>V1</b> is selected, both V1 and V2 clients are allowed to associate with this Wi-Fi AP.</p> <p>When <b>V2</b> is selected, only V2 clients can associate with this Wi-Fi AP.</p> <p>Most wireless clients support V2. Select the option V1 in case if there are stations that do not support V2.</p> <p>By default, <b>V2</b> is selected.</p>
<b>Beacon Rate</b>	<p>This option is for setting the transmit bit rate for sending a beacon.</p> <p>By default, <b>1Mbps</b> is selected.</p>
<b>Beacon Interval</b>	<p>This option is for setting the time interval between each beacon.</p> <p>By default, <b>100ms</b> is selected.</p>
<b>DTIM</b>	<p>This field allows you to set the frequency for the beacon to include Delivery Traffic Indication Message. The interval is measured in millisecond.</p> <p>The default value is set to <b>1 ms</b>.</p>
<b>RTS Threshold</b>	<p>This field allows you to set the minimum packet size for the unit to send an RTS using the RTS/CTS handshake. Setting this field to zero will disable this option.</p> <p>The default value is set to <b>0</b>.</p>
<b>Slot Time</b>	<p>This field is for specifying the unit wait time before it transmits a packet.</p> <p>By default, this field is set to <b>9 μs</b>.</p>
<b>ACK Timeout</b>	<p>This field is for setting the wait time to receive an acknowledgement packet before performing a retransmission.</p> <p>By default, this field is set to <b>48 μs</b>.</p>
<b>CTS Timeout</b>	<p>This field is for specifying the timeout interval for the unit to wait for a CTS response in the RTS/CTS handshake.</p> <p>By default, this field is set to <b>48 μs</b>.</p>

# User Manual

## PEPWAVE *MAX* mobile router

### 9.1 STP (Spanning Tree Protocol)

STP		<input checked="" type="checkbox"/> Enable
Bridge Priority		<input type="text" value="32768"/>
Ethernet Path Cost		<input type="text" value="100"/>

#### STP Settings

##### Bridge Priority

This parameter is set to give the likeliness for root switch election. By default, it is set to **32768**.

##### Ethernet Path Cost

This parameter specifies the preference to provide the best path from the switch to the root switch. By default, it is set to **100**.

# User Manual

## PEPWAVE *MAX* mobile router

### 10 Site-to-Site VPN



Pepwave Site-to-Site VPN functionality securely connects your MAX in different branch to another Pepwave MAX or Peplink device (only Peplink Balance 210/310/380/390/580/710/1350 are available for this function). The data, voice, or video communications between these locations are kept confidential across the public Internet.

The Site-to-Site VPN of the Pepwave MAX is specifically designed for multi-WAN environment. The Pepwave MAX can aggregate all WAN connections' bandwidth for routing Site-to-Site VPN traffic. Unless all the WAN connections of one site are down, the Pepwave MAX can still maintain VPN up and running.

VPN Bandwidth Bonding is supported in firmware 5.1+. All available bandwidth will be utilized to establish the VPN tunnel, and all traffic will be load balanced at packet level across all links. VPN Bandwidth Bonding is enabled by default.

#### Tip

You can define firewall rules to control access within the VPN network. Outbound traffic can be redirected and go through VPN tunnels with custom outbound policies, please refer to section 12 for details

#### 10.1 Configuring a Site-to-Site VPN Profile

The screenshot shows the 'Peplink Site-to-Site VPN' configuration page in the Pepwave MAX web interface. The interface includes a navigation menu on the left with options like 'Advanced', 'NAT Mappings', 'QoS', 'Firewall', and 'Misc. Settings'. The main content area displays the VPN configuration details.

VPN Connection	Peer Serial Number	Peer Address(es)	
VPN Connection 1	1824-1234-5678	10.10.10.151 10.10.10.152 10.10.10.153	Delete

[Add VPN Connection](#)

**Link Failure Detection**

Link Failure Detection Time [?](#)

- Recommended (Approx. 15 secs)
- Fast (Approx. 6 secs)
- Faster (Approx. 2 secs)
- Extreme (Under 1 sec)

Shorter detection time incurs more health checks and higher bandwidth overhead

[Save](#)

# User Manual

## PEPWAVE *MAX* mobile router

Pepwave MAX supports making two Site-to-Site VPN connections with a remote Pepwave MAX unit or a Peplink Balance 210/310/380/390/580/710/1350.

The local LAN subnet and subnets behind the LAN (defined under **Static Route** in the LAN settings page) will be advertised to the VPN. All VPN members (branch offices and headquarters) will be able to route to the local subnets.

Note that all LAN subnet and subnets behind it have to be unique. Otherwise, VPN members will not be able to access each other.

All data can be routed over the VPN with 256-bit AES encryption standard.

To configure, navigate to **Advanced > Site-to-Site VPN**, click the **Add VPN Connection** button to create a new VPN profile.

VPN Settings	
VPN Connection Name	<input type="text" value="VPN Connection 1"/>
Active	<input checked="" type="checkbox"/>
Encryption	<input checked="" type="radio"/> 256-bit AES <input type="radio"/> Off
Peer Serial Number	<input type="text" value="1824-1234-5678"/> <input type="checkbox"/> Remote client is set up in high availability mode.
Pre-shared Key (Optional)	<input type="text" value="....."/> <input checked="" type="checkbox"/> Hide Characters
Peer IP Addresses / Host Names (Optional)	<input type="text" value="123.123.123.1"/> <small>If this field is empty, this field on the peer site must be filled</small>
WAN Connection Priority	
1. Ethernet WAN	Priority: 1 (Highest) ▼
2. Express Card	Priority: 6 (Lowest) ▼
3. PC Card	Priority: 1 (Highest) ▼
4. USB1	Priority: 2 ▼
5. USB2	Priority: --- OFF --- ▼
6. Wi-Fi WAN	Priority: 1 (Highest) ▼

VPN Settings	
<b>Active</b>	Check this box to enable the VPN.
<b>Encryption</b>	By default, VPN traffic is encrypted with 256-bit AES standard. If the option Off is selected on both sides of a VPN connection, no encryption will be applied.
<b>Peer Serial Number</b>	Pepwave MAX only establishes VPN connection with a remote peer that has a serial number specified here. If the remote peer is in high availability setup, you can check the box Remote client is set up in high availability mode, and enter the second unit's serial number into the second text box.
<b>Pre-shared Key</b>	This is an optional field which defines the pre-shared key used for this particular VPN connection. The VPN connection's session key will be further protected by the factor of the pre-shared key. The connection will be up only if the pre-shared keys on each side match. When the remote peer is running firmware 5.0 or 5.1, this setting will be ignored.

# User Manual

## PEPWAVE *MAX* mobile router

### Peer IP Addresses / Host Names

Enter the remote peer's WAN IP address(es) or host name(s) here. Dynamic-DNS host names are accepted.

This field is optional. With this field filled, the Pepwave MAX will initiate connection to each of the remote IP addresses until success. If the field is empty, the Pepwave MAX will wait for connection from the remote peer. Therefore, at least one side of the two VPN peers has to have the field filled. Otherwise, VPN connection cannot be established.  
Enter one IP address or host name per line.

### WAN Connection Priority

### WAN Connection Priority

You can specify the priority of the WAN connections to be used for making VPN connections. WAN connections set to **OFF** will never be used. Only available WAN connections with the highest priority will be utilized.

## 10.2 Link Failure Detection

**Link Failure Detection**

Link Failure Detection Time ?

- Recommended (Approx. 15 secs)
- Fast (Approx. 6 secs)
- Faster (Approx. 2 secs)
- Extreme (Under 1 sec)

Shorter detection time incurs more health checks and higher bandwidth overhead

### Link Failure Detection

### Link Failure Detection Time

The bonded Site-to-Site VPN can detect routing failures on the path between two sites over each WAN connection. Failed WAN connections will not be used to route VPN traffic. Health check packets are sent to the peer to detect any failure. The more frequent checks it sends, the shorter detection time, but the higher bandwidth overhead will be consumed.

When **Recommended** is selected, a health check packet is sent out every 5 seconds, and the expected detection time is 15 seconds.

When **Fast** is selected, a health check packet is sent out every 3 seconds, and the expected detection time is 6 seconds.

When **Faster** is selected, a health check packet is sent out every 1 second, and the expected detection time is 2 seconds.

When **Extreme** is selected, a health check packet is sent out every 0.1 second, and the expected detection time is under 1 second.

By default, **Recommended** is selected.

### Important Note to Users Upgrading to Firmware 5.1+

The Site-to-Site VPN in firmware 5.1+ requires the same firmware version for all devices in the VPN network. Please make sure that both ends of the Pepwave MAX (or Peplink devices) are running with the same firmware version.

# User Manual


## PEPWAVE *MAX* mobile router

### Important Note

- When outbound Internet traffic is routed to remote Site-to-Site VPN peer, the remote peer will route the traffic to its first available WAN connection only.
- Pepwave proprietary Site-to-Site VPN used TCP and UDP port 32015 for establishing VPN connections. If you have a firewall in front of the devices, you will need to add firewall rules for these port and protocols which will allow inbound and outbound traffic pass-through the firewall.

### Tip

Want to know more about VPN Sub-Second Session Failover? Visit our [YouTube Channel](#) for a video tutorial!



<http://www.youtube.com/PeplinkChannel#p/u/0/FXPAJ37b4pQ>

# User Manual

## PEPWAVE *MAX* mobile router


### 10.3 Pepwave MAX Behind NAT Router

The Pepwave MAX supports establishing Site-to-Site VPN over WAN connections which are behind a NAT (Network Address Translation) router.

To be able for a WAN connection behind a NAT router to accept VPN connections, you can configure the NAT router in front of the WAN connection to forward TCP port 32015 to it.

If one or more WAN connections on **Unit A** can accept VPN connections (by means of port forwarding or not) while none of the WAN connections on the peer **Unit B** can do so, you should put all public IP addresses or host names of the **Unit A** to the **Unit B's Peer IP Addresses / Host Names** field. Leave the field in **Unit A** blank. With such setting, site-to-site VPN connection can be set up and all WAN connections on both sides will be utilized.

For example, see the following diagram:




One of the WANs of Router A is non-NAT'd (212.1.1.1). The rest of the WANs on Router A and all WANs on Router B are NAT'd. In such case, the **Peer IP Addresses / Host Names** field in Router B should be filled with all of the Router A's host names or public IP addresses (i.e. 212.1.1.1, 212.2.2.2 and 212.3.3.3), and the field in Router A can be left blank. The two NAT routers on WAN1 and WAN3 of Router A should inbound port forward TCP port 32015 to the Router A so that all WANs would be utilized to establish VPN.

# User Manual

## PEPWAVE *MAX* mobile router

### 10.4 VPN Status

VPN Status is shown in the *Dashboard*. The connection status of each connection profile is shown as below:

Site-to-Site VPN		Details
Branch A	 Established	
Branch B	 Connecting...	

By clicking the **Details** button at the top-right hand corner of Site-to-Site VPN table, you will be forwarded to **Status > Site-to-Site VPN**. You can view the subnet and WAN connection information of each VPN peer. Please refer to Section 19.5 for details.

#### IP subnets must be unique among VPN peers

The entire inter-connected Site-to-Site VPN network is one single non-NAT IP network. No two subnets in two sites shall be duplicated. Otherwise, connectivity problems will be experienced in accessing those subnets.




### 11 Management of Outbound Traffic to WAN

Pepwave MAX provides the functionality to flexibly manage and load balance outbound traffic among the WAN connections.

#### Important Note

Outbound Policy is applied only when more than one WAN connection is active.

The settings for managing and load balancing outbound traffic are located in **Advanced > Outbound Policy**.



# User Manual

## PEPWAVE *MAX* mobile router

### 11.1 Outbound Policy

There are three main selections for the Outbound Policy for Pepwave MAX:

- High Application Compatibility
- Normal Application Compatibility
- Managed by Custom Rules


The selections are explained as follows:

Outbound Policy Settings	
<b>High Application Compatibility</b>	<p>With the selection of this policy, outbound traffic from a source LAN device is routed through the same WAN connection regardless of the destination Internet IP address and protocol.</p> <p>This provides the highest application compatibility.</p>
<b>Normal Application Compatibility</b>	<p>With the selection of this policy, outbound traffic from a source LAN device to the same destination Internet IP address will persistently be routed through the same WAN connection regardless of protocol.</p> <p>This provides high compatibility to most applications, and users still benefit from WAN link load balancing when multiple Internet servers are accessed.</p>
<b>Managed by Custom Rules</b>	<p>With the selection of this policy, outbound traffic behavior can be managed by defining custom rules.</p> <p>Rules can be defined in a custom rule table. A default rule can be defined for connections that cannot be matched with any one of the rules.</p>

The default policy is **Normal Application Compatibility**.

#### Tip

Want to know more about how-to create outbound rules? Visit our [YouTube Channel](#) for a video tutorial!





[http://www.youtube.com/PeplinkChannel#p/u/2/m977ePdM\\_sl](http://www.youtube.com/PeplinkChannel#p/u/2/m977ePdM_sl)

# User Manual

## PEPWAVE *MAX* mobile router

### 11.2 Custom Rules For Outbound Policy


Click  in the Outbound Policy form. Choose **Managed by Custom Rules** and press the **Save** button. The following screen will then be displayed.



Service	Algorithm	Source	Destination	Protocol / Port
HTTPS Persis...	Persistence (Auto)	Any	Any	TCP 443
Default	(Auto)			

The bottom-most rule is **Default**. Edit this rule to change the device's default way to control outbound traffic for all connections that does not match any rules above it. Click on the service name **Default** to change its settings.

You may drag and drop a row to rearrange the priority of outbound rules.



Default Rule	
Default Rule	<input checked="" type="radio"/> Custom <input type="radio"/> Auto
Algorithm	Weighted Balance
Load Distribution Weight	Ethernet WAN 10
	PC Card 10
	Express Card 10
	USB1 10
	USB2 10
	Wi-Fi WAN 10
Terminate Sessions on Link Recovery	<input checked="" type="checkbox"/> Enable

By default, **Auto** is selected for the option **Default Rule**. You can select **Custom** in order to change the Algorithm to be used. Please refer to the upcoming sections for the details of the available algorithms.

To create a custom rule, click **Add Rule** at the bottom of the table, and the following window will be displayed:

# User Manual

## PEPWAVE *MAX* mobile router

**Add a New Custom Rule** ✕

New Custom Rule	
Service Name *	<input type="text"/>
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
Source	IP Network <input type="text"/> Mask: 255.255.255.0 <input type="text"/>
Destination	IP Network <input type="text"/> Mask: 255.255.255.0 <input type="text"/>
Protocol	TCP <input type="text"/> ← :: Protocol Selection Tool :: <input type="text"/>
Port *	Any Port <input type="text"/>
Algorithm	Weighted Balance <input type="text"/>
Load Distribution Weight	Ethernet WAN 10 <input type="text"/> Express Card 10 <input type="text"/> PC Card 10 <input type="text"/> USB1 10 <input type="text"/> USB2 10 <input type="text"/> Wi-Fi WAN 10 <input type="text"/>
Terminate Sessions on Link Recovery	<input type="checkbox"/> Enable

### New Custom Rule Settings

<b>Service Name</b>	This setting specifies the name of the custom rule.
<b>Enable</b>	<p>This setting specifies whether the outbound traffic rule takes effect. With an Enable value of <b>Yes</b>, the rule takes effect: traffic is matched, and actions are taken, by Pepwave MAX based on the other parameters of the rule. With an Enable value of <b>No</b>, the rule does not take effect: Pepwave MAX disregards the other parameters of the rule.</p>
<b>Source</b>	This setting specifies the source IP Address, IP Network or MAC Address for outbound traffic that matches the rule.
<b>Destination</b>	This setting specifies the destination IP Address or IP Network for outbound traffic that matches the rule.
<b>Protocol and Port</b>	This setting specifies the IP Protocol and Port of outbound traffic that matches this rule. You may select some common protocol from the <b>Protocol Selection Tool</b> drop-down menu.
<b>Algorithm</b>	<p>This setting specifies the behavior of Pepwave MAX for the custom rule. One of the following values can be selected:</p> <ul style="list-style-type: none"> <li>• Weighted Balance</li> <li>• Persistence</li> <li>• Enforced</li> <li>• Priority</li> <li>• Overflow</li> <li>• Least Used</li> <li>• Lowest Latency</li> </ul> <p>The upcoming sections present the details of the listed algorithms.</p>

# User Manual

## PEPWAVE *MAX* mobile router


### Terminate Sessions on Link Recovery

This setting specifies whether to terminate existing IP sessions on a less preferred WAN connection in the event that a more preferred WAN connection is recovered. This setting is applicable to the Algorithms: **Weighted**, **Persistence** and **Priority**.

By default, this is disabled. In this case, all existing IP sessions will not be terminated or affected when any other WAN connection is recovered. If it is set to enabled, existing IP sessions may be terminated when another WAN connection is recovered such that only the preferred healthy WAN connection(s) are used at any point in time.

### 11.2.1 Algorithm: Weighted Balance

This setting specifies the ratio of WAN connection usage to be applied on the specified IP Protocol & Port, and is applicable only when Algorithm is set to **Weighted Balance**.



The amount of matching traffic that is distributed to a WAN connection is proportional to the weight of the WAN connection relative to the total weight. Use the sliders to change the weight for each WAN.

Example: With the following weight settings:

- Ethernet WAN: 10
- PC Card: 0
- Express Card: 0
- USB1: 10
- USB2: 0
- Wi-Fi WAN: 5

Total weight is 25 = (10 + 0 + 0 + 10 + 0 + 5)

Matching traffic distributed to Ethernet WAN is 40% = (10 / 25) x 100%

Matching traffic distributed to PC Card is 0% = (0 / 25) x 100%

Matching traffic distributed to Express Card is 0% = (0 / 25) x 100%

Matching traffic distributed to USB1 is 40% = (10 / 25) x 100%

Matching traffic distributed to USB2 is 0% = (0 / 25) x 100%

Matching traffic distributed to Wi-Fi WAN is 20% = (5 / 25) x 100%

# User Manual

## PEPWAVE *MAX* mobile router

### 11.2.2 Algorithm: Persistence

The configuration of using Persistence for algorithm is the solution to the few situations where link load distribution for Internet services is undesirable.

For example, many e-banking and other secure websites, for security reasons, terminate the session when the client computer's Internet IP address changes during the session.

In general, different Internet IP addresses represent different computers. The security concern is that an IP address change during a session may be the result of an unauthorized intrusion attempt. Therefore, to prevent damages from the potential intrusion, the session is terminated upon the detection of an IP address change.

Pepwave MAX can be configured to distribute data traffic across multiple WAN connections. Also, the Internet IP depends on the WAN connections over which communication actually takes place. As a result, a LAN client computer behind Pepwave MAX may communicate using multiple Internet IP addresses. For example, a LAN client computer behind a Pepwave MAX with three WAN connections may communicate on the Internet using three different IP addresses.

With the algorithm Persistence of Pepwave MAX, rules can be configured to enable client computers to persistently utilize the same WAN connections for e-banking and other secure websites. As a result, a client computer will communicate with the other end using one IP address and eliminate the issues.

Algorithm	<input type="text" value="Persistence"/>																		
Persistence Mode	<input type="radio"/> By Source <input checked="" type="radio"/> By Destination																		
Load Distribution	<input type="radio"/> Auto <input checked="" type="radio"/> Custom																		
Load Distribution Weight	<table><tr><td>Ethernet WAN</td><td>10</td><td><input type="range"/></td></tr><tr><td>Express Card</td><td>10</td><td><input type="range"/></td></tr><tr><td>PC Card</td><td>10</td><td><input type="range"/></td></tr><tr><td>USB1</td><td>10</td><td><input type="range"/></td></tr><tr><td>USB2</td><td>10</td><td><input type="range"/></td></tr><tr><td>Wi-Fi WAN</td><td>10</td><td><input type="range"/></td></tr></table>	Ethernet WAN	10	<input type="range"/>	Express Card	10	<input type="range"/>	PC Card	10	<input type="range"/>	USB1	10	<input type="range"/>	USB2	10	<input type="range"/>	Wi-Fi WAN	10	<input type="range"/>
Ethernet WAN	10	<input type="range"/>																	
Express Card	10	<input type="range"/>																	
PC Card	10	<input type="range"/>																	
USB1	10	<input type="range"/>																	
USB2	10	<input type="range"/>																	
Wi-Fi WAN	10	<input type="range"/>																	

There are two modes for Persistence: **By Source** and **By Destination**.

#### By Source

The same WAN connection will be used for traffic matching the rule and originating from the same machine regardless of its destination. This option will provide the highest level of application compatibility.

#### By Destination

The same WAN connection will be used for traffic matching the rule, originating from the same machine, and going to the same destination. This option can better distribute load to WAN connections when there are only a few client machines.

The default mode is **By Source**.

When there are multiple client requests, they can be distributed (persistently) to WAN connections with a weight. If you choose **Auto** for **Load Distribution**, the weights will be automatically adjusted according to each WAN's Downstream Bandwidth which is specified in the WAN settings page (see Section 9 **Configuration of WAN Interface(s)**). If you choose **Custom**, you can customize the weight of each WAN manually by using the sliders.

# User Manual

## PEPWAVE *MAX* mobile router

### 11.2.3 Algorithm: Enforced

This setting specifies the WAN connection usage to be applied on the specified IP Protocol & Port, and is applicable only when the Algorithm is set to **Enforced**.

Algorithm ?	Enforced
Enforced Connection ?	VPN: VPN Connection 1
	WAN: Ethernet WAN
	WAN: Express Card
	WAN: PC Card
	WAN: USB1
	WAN: USB2
	WAN: Wi-Fi WAN
	VPN: VPN Connection 1

Matching traffic will be routed through the specified WAN connection regardless of the connection's health check status.

Starting from firmware 5.2, outbound traffic can be enforced to go through a specified Site-to-Site VPN connection. **(This applies only to Peplink Balance 210 or above)**

### 11.2.4 Algorithm: Priority

This setting specifies the priority of the WAN connections to be utilized to route the specified network service. The highest priority WAN connection available will always be used for routing the specified type of traffic. A lower priority WAN connection will be used only when all higher priority connections have become unavailable.

Algorithm ?	Priority	
Priority Order ?	Highest Priority	Not In Use
	WAN: Ethernet WAN	WAN: PC Card
	VPN: VPN Connection 1	
	WAN: Express Card	
	WAN: USB1	
	WAN: USB2	
	WAN: Wi-Fi WAN	
	Lowest Priority	

Starting from firmware 5.2, outbound traffic can be prioritized to go through Site-to-Site VPN connection(s). By default, VPN connections are not included in the priority list. **(This applies only to Peplink Balance 210 or above)**

#### Tip

Configure multiple distribution rules to accommodate different kinds of services.

# User Manual

## PEPWAVE *MAX* mobile router

### 11.2.5 Algorithm: Overflow

The traffic matching this rule will be routed through the healthy WAN connection that has the highest priority and is not in full load. When this connection gets saturated, new sessions will be routed to the next healthy WAN connection that is not in full load.

Algorithm	Overflow
Overflow Order	Highest Priority
	Ethernet WAN
	Express Card
	PC Card
	USB1
	USB2
	Wi-Fi WAN
	Lowest Priority

Drag and drop to specify the order of WAN connections to be used for routing traffic. Only the highest priority healthy connection that is not in full load will be utilized.

### 11.2.6 Algorithm: Least Used

Algorithm	Least Used
Connection	<input checked="" type="checkbox"/> Ethernet WAN <input checked="" type="checkbox"/> Express Card <input checked="" type="checkbox"/> PC Card <input checked="" type="checkbox"/> USB1 <input checked="" type="checkbox"/> USB2 <input checked="" type="checkbox"/> Wi-Fi WAN

The traffic matching this rule will be routed through the healthy WAN connection that is selected in the field **Connection** and has the most available downstream bandwidth. The available downstream bandwidth of a WAN connection is calculated from the total downstream bandwidth specified in the WAN settings page and the current downstream usage. The available bandwidth and WAN selection is determined every time when an IP session is made.

### 11.2.7 Algorithm: Lowest Latency

Algorithm	Lowest Latency
	Note: Use of Lowest Latency will incur additional network usage.
Connection	<input checked="" type="checkbox"/> Ethernet WAN <input checked="" type="checkbox"/> Express Card <input checked="" type="checkbox"/> PC Card <input checked="" type="checkbox"/> USB1 <input checked="" type="checkbox"/> USB2 <input checked="" type="checkbox"/> Wi-Fi WAN

The traffic matching this rule will be routed through the healthy WAN connection that is selected in the field *Connection* and has the lowest latency. Latency checking packets are issued periodically to a nearby router of each WAN connection to determine its latency value. The latency of a WAN is the packet round trip time of the WAN connection. Additional network usage may be incurred as a result.



# User Manual

## PEPWAVE *MAX* mobile router

### Tip

The round trip time of a "6M down / 640k up" link can be higher than that of a "2M down / 2M up" link. It is because the overall round trip time is lengthened by its lower upstream bandwidth despite of its higher downlink speed. Therefore this algorithm is good for two scenarios:

- All WAN connections are symmetric; or
- A latency sensitive application requires to be routed through the lowest latency WAN regardless the WAN's available bandwidth.

### 11.2.8 Expert Mode

Expert Mode is also available for advance users. Click the help test balloon and click the link turn on Expert Mode to switch on the feature.

Under Expert Mode, a special rule - "Site-to-Site VPN Routes" is displayed on the Custom Rules table. It represents all Site-to-Site VPN routes learned from remote VPN peers. By default, this bar is on the top of all custom rules. That means traffic for remote VPN subnets will be routed to its corresponding VPN peer. You can create custom Priority or Enforced rules and move them above the bar to override the Site-to-Site VPN Routes.

Upon disabling the Expert Mode, all rules above the bar will be deleted.

Service	Algorithm	Source	Destination	Protocol / Port	
HTTPS_Persis...	Persistence (Src) (Auto)	Any	IP Network 192.168.50.0/24	TCP 443	X
Site-to-Site VPN Routes					
Default	Lowest Latency				
Add Rule					

**Help** Close

This table allows you to fine tune how the outbound traffic should be distributed to the WAN connections.

Click the **Add Rule** button to add a new rule. Click the **X** button to remove a rule. Drag a rule to promote or demote its precedence. A higher position of a rule signifies a higher precedence. You may change the default outbound policy behavior by clicking the **Default** link.

If you require advanced control of S2S VPN traffic, [turn on Expert Mode](#).

## 12 Port Forwarding

### 12.1 Port Forwarding Service

Pepwave MAX can act as a firewall that blocks, by default, all inbound access from the Internet. By using **Port Forwarding**, Internet users can access the servers behind Pepwave MAX.

Inbound Port Forwarding rules can be defined at **Advanced > Port Forwarding**:

Service	IP Address(es)	Server	Protocol	Action
Web	Ethernet WAN: default	192.168.1.10	TCP:80	Delete
Add Service				

To define a new service, click the **Add Service** button, upon which the following appears:

Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No																												
Service Name *	web																												
IP Protocol	TCP <input type="button" value="←"/> :: Protocol Selection Tool :: <input type="button" value="→"/>																												
Port	Single Port <input type="button" value="→"/> Service Port: 80																												
Inbound IP Address(es) * (Require at least one IP address)	<table border="1"> <thead> <tr> <th colspan="2">Connection / IP Address(es)</th> <th>All</th> <th>Clear</th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/> Ethernet WAN</td> <td><input checked="" type="checkbox"/> 123.123.123.1 (Interface IP)</td> <td></td> <td></td> </tr> <tr> <td><input type="checkbox"/> Express Card</td> <td></td> <td></td> <td></td> </tr> <tr> <td><input type="checkbox"/> PC Card</td> <td></td> <td></td> <td></td> </tr> <tr> <td><input type="checkbox"/> USB1</td> <td></td> <td></td> <td></td> </tr> <tr> <td><input type="checkbox"/> USB2</td> <td></td> <td></td> <td></td> </tr> <tr> <td><input type="checkbox"/> Wi-Fi Hotspot</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Connection / IP Address(es)		All	Clear	<input checked="" type="checkbox"/> Ethernet WAN	<input checked="" type="checkbox"/> 123.123.123.1 (Interface IP)			<input type="checkbox"/> Express Card				<input type="checkbox"/> PC Card				<input type="checkbox"/> USB1				<input type="checkbox"/> USB2				<input type="checkbox"/> Wi-Fi Hotspot			
Connection / IP Address(es)		All	Clear																										
<input checked="" type="checkbox"/> Ethernet WAN	<input checked="" type="checkbox"/> 123.123.123.1 (Interface IP)																												
<input type="checkbox"/> Express Card																													
<input type="checkbox"/> PC Card																													
<input type="checkbox"/> USB1																													
<input type="checkbox"/> USB2																													
<input type="checkbox"/> Wi-Fi Hotspot																													
Server IP Address	<input type="text"/>																												

\* Required Fields

### Port Forwarding Settings

#### Enable

This setting specifies whether the inbound service rule takes effect. When **Yes** is selected, the inbound service rule takes effect. If the inbound traffic matches the specified IP Protocol and Port, action will be taken by Pepwave MAX based on the other parameters of the rule. When **No** is selected, the inbound service rule does not take effect. Pepwave MAX will disregard the other parameters of the rule.

#### Service Name

This setting identifies the service to the System Administrator. Valid values for this setting consist only of alphanumeric and the underscore “\_” characters.

### IP Protocol

The IP Protocol setting, along with the Port setting, specifies the protocol of the service as TCP, UDP, ICMP or IP.

Traffic that is received by Pepwave MAX via the specified protocol at the specified port(s) is forwarded to the LAN hosts specified by the Servers setting. (Please see below for details on the Port and Servers settings.)

Alternatively, the **Protocol Selection Tool** drop-down menu can be used to automatically fill in the Protocol and a single Port number of common Internet services (e.g. HTTP, HTTPS, etc.).

After selecting an item from the Protocol Selection Tool drop-down menu, the Protocol and Port number remains manually modifiable.

The Port setting specifies the port(s) that correspond to the service, and can be configured to behave in one of the following manners:


#### Any Port, Single Port, Port Range and Port Map



The screenshot shows a 'Port' label on the left, followed by a help icon (question mark in a circle) and a dropdown menu currently set to 'Any Port'.

**Any Port:** All traffic that is received by Pepwave MAX via the specified protocol is forwarded to the servers specified by the Servers setting.

For example, with IP Protocol set to **TCP**, and Port set to **Any Port**, all TCP traffic is forwarded to the configured servers.




The screenshot shows a 'Port' label on the left, followed by a help icon and a dropdown menu set to 'Single Port'. To the right is a 'Service Port:' label followed by an empty input field.

**Single Port:** Traffic that is received by Pepwave MAX via the specified protocol at the specified port is forwarded via the same port to the servers specified by the Servers setting.

For example, with IP Protocol set to **TCP**, and Port set to **Single Port** and **Service Port 80**, TCP traffic received on Port 80 is forwarded to the configured servers via Port 80.

### Port



The screenshot shows a 'Port' label on the left, followed by a help icon and a dropdown menu set to 'Port Range'. To the right is a 'Service Ports:' label followed by two empty input fields separated by a hyphen.

**Port Range:** Traffic that is received by Pepwave MAX via the specified protocol at the specified port range is forwarded via the same respective ports to the LAN hosts specified by the Servers setting.

For example, with IP Protocol set to **TCP**, and Port set to **Single Port** and **Service Port 80-88**, TCP traffic received on ports 80 through 88 is forwarded to the configured servers via the respective ports.



The screenshot shows a 'Port' label on the left, followed by a help icon and a dropdown menu set to 'Port Mapping'. To the right are two input fields: 'Service Port:' and 'Map to Port:'.

**Port Mapping:** Traffic that is received by Pepwave MAX via the specified protocol at the specified port is forwarded via a different port to the servers specified by the Servers setting.

For example, with IP Protocol set to **TCP**, and Port set to **Port Map**, **Service Port 80**, and **Map to Port 88**, TCP traffic on Port 80 is forwarded to the configured servers via Port 88.

(Please see below for details on the Servers setting.)

# User Manual

## PEPWAVE *MAX* mobile router

Port	<input type="text"/>	<input type="text"/>	Service Ports: <input type="text"/> - <input type="text"/>
	Range Mapping <input type="text"/>		Map to Ports: <input type="text"/> - <input type="text"/>

**Range Mapping:** traffic that is received by Peplink Balance via the specified protocol at the specified port range is forwarded via a different port to the servers specified by the Servers setting.

### Inbound IP Address(es)

This setting specifies the WAN connections and Internet IP address(es) from which the service can be accessed.  
It is required to select at least one IP address.

### Server IP Address

This setting specifies the LAN IP address of the server that handles the requests for the service.

## 12.2 UPnP / NAT-PMP Settings

UPnP and NAT-PMP are network protocols which allow a computer on the LAN to automatically configure the router to allow parties on the WAN to connect to itself. In this way, the process of inbound port forwarding is automated.

When a computer creates a rule using these protocols, the specified TCP/UDP port of all WAN connections' default IP address will be forwarded.

Check the corresponding box(es) to enable UPnP and/or NAT-PMP. Enable these features only if you trust the computers on the LAN.

UPnP / NAT-PMP Settings	
UPnP	<input checked="" type="checkbox"/> Enable
NAT-PMP	<input checked="" type="checkbox"/> Enable
<input type="button" value="Save"/>	

A table listing all the forwarded ports under these two protocols can be found at **Status > UPnP / NAT-PMP**.

# User Manual

## PEPWAVE *MAX* mobile router

### 13 NAT Mappings

The configuration of NAT Mappings allows the IP address mapping of all inbound and outbound NAT'ed traffic to and from an internal client IP address.

The settings to configure NAT Mappings are located at **Advanced > NAT Mappings**:

LAN Host	Inbound Mappings	Outbound Mappings	Action
192.168.1.23	(WAN1):29.123.123.13	(WAN1):29.123.123.13	Delete
192.168.1.24	(WAN2):30.21.21.12	(WAN2):30.21.21.12	Delete

To add a rule for NAT Mappings, click **Add NAT Rule**, upon which the following screen will be displayed:

LAN Host	<input type="text" value="192.168.50.12"/>												
Inbound Mappings	<p><b>Connection / Inbound IP Address(es)</b></p> <p><input checked="" type="checkbox"/> Ethernet WAN <input checked="" type="checkbox"/> 123.123.123.1 (Interface IP)</p> <p><input type="checkbox"/> Express Card</p> <p><input type="checkbox"/> PC Card</p> <p><input type="checkbox"/> USB1</p> <p><input type="checkbox"/> USB2</p> <p><input checked="" type="checkbox"/> Wi-Fi Hotspot <input checked="" type="checkbox"/> Interface IP</p>												
Outbound Mappings	<p><b>Connection / Outbound IP Address</b></p> <table border="1"><tr><td>Ethernet WAN</td><td>123.123.123.1 (Interface IP) ▼</td></tr><tr><td>Express Card</td><td>Interface IP ▼</td></tr><tr><td>PC Card</td><td>Interface IP ▼</td></tr><tr><td>USB1</td><td>Interface IP ▼</td></tr><tr><td>USB2</td><td>Interface IP ▼</td></tr><tr><td>Wi-Fi Hotspot</td><td>Interface IP ▼</td></tr></table>	Ethernet WAN	123.123.123.1 (Interface IP) ▼	Express Card	Interface IP ▼	PC Card	Interface IP ▼	USB1	Interface IP ▼	USB2	Interface IP ▼	Wi-Fi Hotspot	Interface IP ▼
Ethernet WAN	123.123.123.1 (Interface IP) ▼												
Express Card	Interface IP ▼												
PC Card	Interface IP ▼												
USB1	Interface IP ▼												
USB2	Interface IP ▼												
Wi-Fi Hotspot	Interface IP ▼												

# User Manual

## PEPWAVE *MAX* mobile router

### NAT Mapping Settings

<b>LAN Host</b>	This is the IP address of the host on the LAN that the system should map the selected connection IP address correspondences.
<b>Inbound Mappings</b>	<p>This setting specifies the WAN connections and corresponding WAN-specific Internet IP addresses on which the system should bind on. Any access to the specified WAN connection(s) and IP address(es) will be forwarded to the LAN Host.</p> <p>Note 1: Inbound Mapping is not needed for WAN connections in IP forwarding mode.</p> <p>Note 2: Each WAN IP address can be associated to one NAT Mapping only.</p>
<b>Outbound Mappings</b>	<p>This setting specifies the IP address of each WAN connection to be used for any outgoing traffic originating from the LAN Host.</p> <p>Note 1: If you do not want to use a specific WAN for outgoing accesses, you should still choose default here, then customize the outbound access rule in the Outbound Policy section.</p>

Click **Save** to save the settings when configuration has been completed.

### Important Note


Inbound firewall rules override the Inbound Mapping settings.

## 14 QoS


### 14.1 User Groups

LAN and PPTP clients can be categorized into three user groups - **Manager, Staff, and Guest**. This table allows you to define rules and assign client IP addresses or subnets to a user group. You can apply different bandwidth and traffic prioritization policies on each user group in the Bandwidth Control and Application sections.

The table is automatically sorted, and the table order signifies the rules' precedence. The smaller and more specific subnets are put towards the top of the table and have higher precedence; larger and less specific subnets are placed towards the bottom.

Click the **Add** button to define clients and their user group. Click the  button to remove the defined rule.

Two default rules are pre-defined and put at the bottommost. They are **All DHCP reservation clients** and **Everyone**, and they cannot be removed. **All DHCP reservation clients** represents the LAN clients defined in the DHCP Reservation table in the LAN settings page. **Everyone** represents all clients that are not defined in any rule above. Click on a rule to change its group.

Subnet / IP Address	User Group	Action
Guest Computer	Guest	
All DHCP reservation clients	Manager	
Everyone		

**Add / Edit User Group**

Client	Staff A
Subnet / IP Address	IP Address <input type="text" value="192.168.1.99"/>
Group	Manager <span style="border: 1px solid gray; padding: 2px;">Staff A (192.168.1.99)</span>


Add / Edit User Group	
<b>Subnet / IP Address</b>	<p>From the drop-down menu, choose whether you are going to define the client(s) by an <b>IP Address</b> or a <b>Subnet</b>.</p> <p>If IP Address is selected, enter a name defined in DHCP Reservation table or a LAN client's IP address. If Subnet is selected, enter a subnet address and specify its subnet mask.</p>
<b>Group</b>	<p>This field is to define which <b>User Group</b> the specified Subnet / IP Address belongs to.</p>

Once users have been assigned to a user group, their internet traffic will be restricted by rules defined for that particular group. Please refer to the following two sections for details.

### 14.2 Bandwidth Control

You can define a maximum download speed (over all WAN connections) and upload speed (for each WAN connection) that each individual Staff and Guest member can consume. No limit can be imposed on individual Manager members.

By default, Download and Upload Bandwidth Limits are set to unlimited (set as **0**).

Individual Bandwidth Limit 					
Enable	<input checked="" type="checkbox"/>				
User Bandwidth Limit	Download		Upload		
	Manager: Unlimited		Unlimited		
	Staff:	0 Mbps	0 Mbps	(0: unlimited)	
	Guest:	0 Mbps	0 Mbps	(0: unlimited)	



# User Manual

## PEPWAVE *MAX* mobile router

### 14.3 Application

#### 14.3.1 Application Prioritization

You can choose whether to apply the same Prioritization settings to all user groups or customize the settings for each group.

**Application Prioritization**

Apply same settings to all users  
 Customize

Three priority levels can be set for application prioritization: ↑ **High**, — **Normal**, and ↓ **Low**.

Four types of applications are predefined. Their priority for each user group can be selected from their corresponding drop down menu. Traffic types not defined in the table are assigned with normal priority.

Application	Priority			Action
	Manager	Staff	Guest	
PPTP and IPsec VPN	— Normal	— Normal	— Normal	
SIP/Vonage	↑ High	↑ High	↑ High	
Skype, Google Talk, RealVideo, and Windows Streaming Media	— Normal	— Normal	— Normal	
Secure Web (HTTPS)	— Normal	— Normal	— Normal	
<b>Custom Application</b>				
Testing	↓ Low	↓ Low	↓ Low	
<input type="button" value="Add"/>				

#### 14.3.2 Prioritization for Custom Application

Click the **Add** button to define a custom application. Click the button in the **Action** column to delete the custom application in the corresponding row.

**Add / Edit Application** ✕

Application Name:

Scope / Protocol:

Port:


Application Prioritization	
<b>PPTP and IPSec VPN</b>	When enabled, any PPTP and IPSec traffic will be prioritized.
<b>SIP/Vonage</b>	When enabled, any SIP and Vonage voice traffic will be prioritized.
<b>Skype, Google Talk, RealVideo, and Windows Streaming Media</b>	When enabled, voice and video traffic of Skype, Google Talk, RealVideo and Windows Streaming Media will be prioritized.
<b>Secure Web (HTTPS)</b>	When enabled, HTTPS (TCP port 443) traffic will be prioritized.

### 14.3.3 DSL/Cable Optimization

DSL/cable-based WAN connection has its upload bandwidth lower than the download bandwidth. When this option is enabled, the download bandwidth of the WAN can be fully utilized in any situation.

When a DSL/cable circuit's uplink is congested, the download bandwidth will be affected. Users will not be able to download data in full speed until the uplink becomes less congested. The DSL/Cable Optimization can relieve such issue. When it is enabled, the download speed will become less affected by the upload traffic.

By default, this feature is **enabled**.



## 15 Firewall

A firewall is a mechanism that selectively filters data traffic between the WAN side (the Internet) and the LAN side of the network. It can protect the local network from potential hacker attacks, offensive Web sites, and/or other inappropriate uses.

The firewall functionality of Pepwave MAX supports the selective filtering of data traffic in both directions:

- Outbound (LAN to WAN)
- Inbound (WAN to LAN)
- Intrusion Detection and DoS Prevention

With Site-to-Site VPN enabled (see Section 11), the firewall rules also apply to VPN tunneled traffic.

### 15.1 Outbound and Inbound Firewall

The outbound and inbound firewall settings are located in **Advanced > Firewall**:

**Outbound Firewall Rules** ( Drag and drop rows to change rule order ) ?

Rule	Protocol	Source IP Port	Destination IP Port	Policy
Default	Any	Any	Any	Allow

**Inbound Firewall Rules** ( Drag and drop rows to change rule order ) ?

Rule	Protocol	WAN	Source IP Port	Destination IP Port	Policy
Default	Any	Any	Any	Any	Allow

Upon clicking **Add Rule**, the following screen appears:

**Add a New Inbound Firewall Rule** X

**New Firewall Rule**

Rule Name *	<input type="text"/>
Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
WAN Connection ?	<input type="text" value="Any"/> ▾
Protocol ?	<input type="text" value="Any"/> ▾ ← :: Protocol Selection Tool :: ▾
Source IP & Port ?	<input type="text" value="Any Address"/> ▾
Destination IP & Port ?	<input type="text" value="Any Address"/> ▾
Action ?	<input checked="" type="radio"/> Allow <input type="radio"/> Deny
Event Logging ?	<input type="checkbox"/> Enable

# User Manual

## PEPWAVE *MAX* mobile router

### Inbound / Outbound Firewall Settings

**Rule Name** This setting specifies a name for the firewall rule.

**Enable** This setting specifies whether the firewall rule should take effect.  
When **Yes** is selected, the firewall rule takes effect. If the traffic matches the specified Protocol/IP/Port, actions will be taken by Pepwave MAX based on the other parameters of the rule.  
When **No** is selected, the firewall rule does not take effect. Pepwave MAX will disregard the other parameters of the rule.

**WAN Connection** This setting is applicable to Inbound Firewall Rules only.  
This setting specifies which WAN connection(s) the rule applies to:

- **Any (applies to all WAN connections)**
- **Ethernet WAN**
- **PC Card**
- **Express Card**
- **USB1**
- **USB2**
- **Wi-Fi WAN**

A value of **Any, Ethernet WAN, PC Card, ... and Wi-Fi WAN** specifies that the rule applies to all WAN connections, Ethernet WAN, PC Card, ... and Wi-Fi WAN, respectively.

**Protocol** This setting specifies the protocol to be matched by the rule.  
Via a drop-down menu, the following protocols can be specified:

- **TCP**
- **UDP**
- **ICMP**
- **IP**

Alternatively, the **Protocol Selection Tool** drop-down menu can be used to automatically fill in the Protocol and Port number of common Internet services (e.g. HTTP, HTTPS, etc.)

After selecting an item from the Protocol Selection Tool drop-down menu, the Protocol and Port number remains manually modifiable.

**Source IP & Port** This specifies the source IP address(es) and port number(s) to be matched for a firewall rule.  
A single address, or a network, can be specified as the Source IP & Port setting, as indicated with the following screenshots:

The screenshot shows a configuration interface for the Source IP & Port setting. It contains four rows of input fields:

- Row 1: A dropdown menu labeled "Single Address" followed by an "IP:" label and an empty text input field.
- Row 2: A dropdown menu labeled "Single Port" followed by a "Port:" label and an empty text input field.
- Row 3: A dropdown menu labeled "Network" followed by an "IP:" label and an empty text input field, and a "Mask:" label followed by a text input field containing "255.255.255.0" and a dropdown arrow.
- Row 4: A dropdown menu labeled "Port Range" followed by a "Port:" label and two empty text input fields separated by a hyphen.

In addition, a single port, or a range of ports, can be specified for the Source IP & Port setting.

# User Manual

## PEPWAVE *MAX* mobile router

### Destination IP & Port

This specifies the destination IP address(es) and port number(s) to be matched for a firewall rule.

A single address, or a network, can be specified as the Source IP & Port setting, as indicated with the following screenshots:

The screenshot shows a configuration interface for 'Destination IP & Port' with four rows of input fields:

- Row 1: 'Single Address' dropdown, 'IP:' label, and an empty text input field.
- Row 2: 'Single Port' dropdown, 'Port:' label, and an empty text input field.
- Row 3: 'Network' dropdown, 'IP:' label, an empty text input field, 'Mask:' label, and a dropdown menu with '255.255.255.0' selected.
- Row 4: 'Port Range' dropdown, 'Port:' label, and two empty text input fields separated by a hyphen.

In addition, a single port, or a range of ports, can be specified for the Source IP & Port setting.

### Action

This setting specifies the action to be taken by Pepwave MAX upon encountering traffic that matches the both of the following:

- Source IP & Port
- Destination IP & Port

With the value of **Allow** for the Action setting, the matching traffic passes through Pepwave MAX (to be routed to the destination).

If the value of the Action setting is set to **Deny**, the matching traffic does not pass through Pepwave MAX (and is discarded).

### Event Logging

This setting specifies whether or not to log matched firewall events.

The logged messages are shown on the page Status > Event Log.

A sample message is as follows:


```
Aug 13 23:47:44 Denied CONN=Ethernet WAN SRC=20.3.2.1  
DST=192.168.1.20 LEN=48 PROTO=TCP SPT=2260 DPT=80
```


- **CONN:** The connection where the log entry refers to
- **SRC:** Source IP address
- **DST:** Destination IP address
- **LEN:** Packet length
- **PROTO:** Protocol
- **SPT:** Source port
- **DPT:** Destination port

# User Manual

## PEPWAVE *MAX* mobile router


Upon clicking **Save** after entering required information, the following screen appears.






Rule	Protocol	Source IP Port	Destination IP Port	Policy	
No_web_access	TCP	Any Any	Any 80	Deny	
Default	Any	Any	Any	Allow	

To create an additional firewall rule, click **Add Rule** and repeat the above steps.

To reorder a rule's position, just drag the rule by holding the left mouse button, move it to the desired position, and place it by releasing the mouse button.



Rule	Protocol	Source IP Port	Destination IP Port	Policy	
No_web_access	TCP	Any Any	Any 80	Deny	
No FTP access		Any Any	Any 21	Deny	
Default	Any	Any	Any	Allow	

To remove a rule, click .

Rules are matched from top to the bottom. If a connection matches any one of the upper rules, the matching process will stop. If none of the rules is matching, the **Default** rule will be applied.

By default, the **Default** rule is set as **Allow** for both outbound and inbound accesses.


### Tip


If the default inbound rule is set as **Allow** for NAT enabled WANs, no inbound Allow firewall rules will be required for inbound Port Forwarding and inbound NAT Mapping rules. However, if the default inbound rule is set as **Deny**, a corresponding Allow firewall rules will be required.

# User Manual

## PEPWAVE *MAX* mobile router

### 15.2 Intrusion Detection and DoS Prevention



The Pepwave MAX supports detecting and preventing intrusions and Denial-of-Service (DoS) attacks from the Internet. To turn on this feature, click , check the box **Enable** for the **Intrusion Detection and DoS Prevention** and press the **Save** button.

When this feature is enabled, the Pepwave MAX will detect and protect the network from the following kinds of intrusions and denial-of-service attacks.

- Port Scan:
  - NMAP FIN/URG/PSH
  - Xmas Tree
  - Another Xmas Tree
  - Null Scan
  - SYN/RST
  - SYN/FIN
- SYN Flood Prevention
- Ping Flood Attack Prevention


# User Manual

## PEPWAVE *MAX* mobile router

### 16 Miscellaneous Settings

The miscellaneous settings include configuration for PPTP Server, Service Forwarding, and Service Passthrough.

#### 16.1 PPTP Server




Pepwave MAX has a built-in PPTP Server, which enables remote computers to conveniently and securely access the local network.

PPTP server setting is located at **Advanced > Misc. Settings > PPTP Server**.

Simply check the box to enable the PPTP server function. All connected PPTP sessions are displayed on the Client List at **Status > Client List**. Please refer to section 19.3 for details.


PPTP Server	
Enable	<input checked="" type="checkbox"/>
Listen On <span>?</span>	<b>Connection / IP Address(es)</b>
	<input checked="" type="checkbox"/> Ethernet WAN <input checked="" type="checkbox"/> 123.123.123.1 (Interface IP)
	<input type="checkbox"/> Express Card
	<input type="checkbox"/> PC Card
	<input type="checkbox"/> USB1
	<input type="checkbox"/> USB2
<input type="checkbox"/> Wi-Fi Hotspot	
User Accounts <span>?</span>	No User Account
	<input type="button" value="Add"/>

PPTP Server Setting	
<b>Listen On</b>	This setting is for specifying the WAN connection(s) and IP address(es) where the PPTP server should listen on.
<b>User Accounts</b>	This setting allows you to define the PPTP User Accounts. Click <b>Add</b> to input username and password to create an account. After adding the user accounts, you can click on a username to edit the account password. Click the button  to delete the account in its corresponding row.



### 16.2 Service Forwarding

Service Forwarding settings are located at **Advanced > Misc. Settings > Service Forwarding**:



Service Forwarding	
<b>SMTP Forwarding</b>	When this option is enabled, all outgoing SMTP connections destined for any host at TCP port 25 will be intercepted. These connections will be redirected to a specified SMTP server and port number. SMTP server settings for each WAN can be specified after selecting <b>Enable</b> .
<b>Web Proxy Forwarding</b>	When this option is enabled, all outgoing connections destined for the proxy server specified in Web Proxy Interception Settings will be intercepted. These connections will be redirected to a specified web proxy server and port number. Web Proxy Interception Settings and proxy server settings for each WAN can be specified after selecting <b>Enable</b> .
<b>DNS Forwarding</b>	When this option is enabled, all outgoing DNS lookups will be intercepted and redirected to the built-in DNS name server.  If any LAN device is using DNS name servers of a WAN connection, you may want to enable this option to enhance the DNS availability without modifying the DNS server setting of the clients. The built-in DNS name server will distribute DNS lookups to corresponding DNS servers of all available WAN connections. In this case, DNS service will not be interrupted even if any WAN connection is down.

#### 16.2.1 SMTP Forwarding

Some ISPs require their users to send e-mails via the ISP's SMTP server. All outgoing SMTP connections are blocked except those connecting to the ISP's. The Pepwave MAX supports intercepting and redirecting all outgoing SMTP connections (destined for TCP port 25) via a WAN connection to the WAN's corresponding SMTP server.

Connection	Enable Forwarding?	SMTP Server	SMTP Port
Ethernet WAN	<input checked="" type="checkbox"/>	10.10.1.1	25
Express Card	<input type="checkbox"/>		
PC Card	<input type="checkbox"/>		
USB1	<input checked="" type="checkbox"/>	10.10.2.1	25
USB2	<input type="checkbox"/>		
Wi-Fi WAN	<input type="checkbox"/>		

# User Manual

## PEPWAVE *MAX* mobile router

To enable the feature, select the **Enable** check box under **SMTP Forwarding Setup**. Check the box **Enable Forwarding?** for the WAN connection(s) that needs such forwarding. Enter the ISP's e-mail server address and TCP port number for each WAN.

The Pepwave MAX will intercept SMTP connections, choose a WAN with reference to the Outbound Policy, and then forward the connection to the forwarded SMTP server if the chosen WAN has enabled forwarding. If the forwarding is disabled for a WAN connection, SMTP connections for the WAN will be simply forwarded to the connection's original destination.

### Note

If you want to route all SMTP connections only to particular WAN connection(s), you should create a rule in Outbound Policy (see section 12.1).

## 16.2.2 Web Proxy Forwarding

Connection	Enable Forwarding?	Proxy Server IP Address : Port
Ethernet WAN	<input checked="" type="checkbox"/>	10.10.1.1 : 8123
Express Card	<input type="checkbox"/>	:
PC Card	<input type="checkbox"/>	:
USB1	<input checked="" type="checkbox"/>	10.10.2.1 : 8080
USB2	<input type="checkbox"/>	:
Wi-Fi WAN	<input checked="" type="checkbox"/>	10.10.3.1 : 8080

When this feature is enabled, the Pepwave MAX will intercept all outgoing connections destined for the proxy server specified in **Web Proxy Interception Settings**, choose a WAN connection with reference to the Outbound Policy, and then forward them to the specified web proxy server and port number. Redirected server settings for each WAN can be set here. If forwarding is disabled for a WAN, web proxy connections for the WAN will be simply forwarded to the connection's original destination.

## 16.2.3 DNS Forwarding

Forward Outgoing DNS Requests to Local DNS Proxy	Enable
<input checked="" type="checkbox"/>	Enable

When DNS Forwarding is enabled, all clients' outgoing DNS requests will also be intercepted and forwarded to the built-in DNS proxy server.

# User Manual

## PEPWAVE *MAX* mobile router

### 16.3 Service Passthrough

Service Passthrough settings can be found in **Advanced > Misc. Settings > Service Passthrough**:

Service Passthrough Support	
SIP (Standard SIP, Vonage)	<input checked="" type="radio"/> Standard Mode <input type="radio"/> Compatibility Mode <input checked="" type="checkbox"/> Define custom signal ports 1. <input type="text"/> 2. <input type="text"/> 3. <input type="text"/>
H.323	<input checked="" type="checkbox"/> Enable
FTP	<input checked="" type="checkbox"/> Enable <input type="checkbox"/> Define custom control ports
TFTP	<input type="checkbox"/> Enable
IPsec NAT-T	<input checked="" type="checkbox"/> Enable <input type="checkbox"/> Define custom ports <input checked="" type="checkbox"/> Route IPsec Site-to-Site VPN via <input type="text" value="Ethernet WAN"/>

(Registered trademarks are copyrighted by their respective owner)

Some Internet services required to be specially handled in a multi-WAN environment. The Pepwave MAX supports handling such services correctly such that Internet applications do not notice it is behind a multi-WAN router. Settings for Service Passthrough Support are available here.

Service Passthrough Support	
<b>SIP</b>	<p>Session Initiation Protocol, aka SIP, is a voice-over-IP protocol. Pepwave MAX can act as a SIP Application Layer Gateway (ALG) which binds connections for the same SIP session to the same WAN connection and translate IP address in the SIP packets correctly in NAT mode. Such passthrough support is always enabled and there are two modes for selection: <b>Standard Mode</b> and <b>Compatibility Mode</b>.</p> <p>If your SIP server's signal port number is non-standard, you can check the box <b>Define custom signal ports</b> and input the port numbers to the text boxes.</p>
<b>H.323</b>	<p>With this option enabled, protocols that provide audio-visual communication sessions will be defined on any packet network and passthrough the Balance.</p>
<b>FTP</b>	<p>FTP sessions consist of two TCP connections; one for control and one for data. In multi-WAN situation, they have to be binded to the same WAN connection. Otherwise, problems will arise in transferring files. By default, the Pepwave MAX monitors TCP control connections on port 21 for any FTP connections and binds TCP connections of the same FTP session to the same WAN.</p> <p>If you have an FTP server listening on a port number other than 21, you can check the box <b>Define custom control ports</b> and enter the port numbers to the text boxes.</p>
<b>TFTP</b>	<p>The Pepwave MAX monitors outgoing TFTP connections and routes any incoming TFTP data packets back to the client. Select <b>Enable</b> if you want to enable the TFTP Passthrough support.</p>
<b>IPsec NAT-T</b>	<p>This field is for enabling the support of IPsec NAT-T Passthrough. UDP ports 500, 4500 and 10000 are monitored by default.</p> <p>You may add more custom data ports that your IPsec system uses by checking the box Define custom ports. If the VPN contains IPsec Site-to-Site VPN traffic, you have to check the box Route IPsec Site-to-Site VPN and choose the WAN connection to route the traffic to.</p> <p>If you have IPsec Site-to-Site VPN traffic routed, check the Route IPsec Site-to-Site VPN option and select a WAN to force routing such traffic to the specified WAN.</p>

## 17 System Settings

### 17.1 Admin Security

There are two user accounts available for accessing the Web Admin. Usernames are **admin** and **user**. They represent two user levels - **admin** has full administration access, while **user** is a read-only account. The read-only account can only access the device's status information and cannot make any change on the device.



Admin Account UI



User Account UI

A web login session will be logged out automatically when it has been idled for a longer time than the **Web Session Timeout**. The default timeout is 4 hours 0 minute. Before the session expires, you may click the **Logout** button in the Web Admin to exit from the session.

For security reasons, after logging in to the administration interface at the first time, changing the administrator password is recommended.

Configuring the administration interface to be accessible only from the LAN can further improve system security.

Administrative Settings configuration is located at **System > Admin Security**.

# User Manual

## PEPWAVE *MAX* mobile router

Admin Settings <span style="float: right;">?</span>	
Router Name	MAX
Admin User Name	admin
Admin Password *	.....
Confirm Admin Password *	.....
Read-only User Name	user
User Password	
Confirm User Password	
Web Session Timeout	4 Hours 0 Minutes
Authentication by RADIUS <span style="float: right;">?</span>	<input checked="" type="checkbox"/> Enable
Auth Protocol	MS-CHAP v2
Auth Server	<input type="text"/> Port <input type="text"/> <span style="float: right;">Default</span>
Auth Server Secret	<input type="text"/> <input checked="" type="checkbox"/> Hide Characters
Auth Timeout	3 seconds
Accounting Server	<input type="text"/> Port <input type="text"/> <span style="float: right;">Default</span>
Accounting Server Secret	<input type="text"/> <input checked="" type="checkbox"/> Hide Characters
Network Connection	LAN
Security	HTTP / HTTPS
Web Admin Port	HTTP: 80 HTTPS: 443 <span style="float: right;">Default</span>
Web Admin Access	HTTP: LAN/WAN HTTPS: LAN Only

WAN Connection Access Settings															
Allowed Source IP Subnets <span style="float: right;">?</span>	<input type="radio"/> Any <input checked="" type="radio"/> Allow access from the following IP subnets only <input type="text"/>														
Allowed WAN IP Address(es)	<table border="1" style="width: 100%;"> <thead> <tr> <th colspan="2">Connection / IP Address(es) <span style="float: right;">All Clear</span></th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/> Ethernet WAN</td> <td><input checked="" type="checkbox"/> 210.10.10.2 (Interface IP)</td> </tr> <tr> <td><input type="checkbox"/> Express Card</td> <td></td> </tr> <tr> <td><input type="checkbox"/> PC Card</td> <td></td> </tr> <tr> <td><input type="checkbox"/> USB1</td> <td></td> </tr> <tr> <td><input type="checkbox"/> USB2</td> <td></td> </tr> <tr> <td><input type="checkbox"/> Wi-Fi WAN</td> <td></td> </tr> </tbody> </table>	Connection / IP Address(es) <span style="float: right;">All Clear</span>		<input checked="" type="checkbox"/> Ethernet WAN	<input checked="" type="checkbox"/> 210.10.10.2 (Interface IP)	<input type="checkbox"/> Express Card		<input type="checkbox"/> PC Card		<input type="checkbox"/> USB1		<input type="checkbox"/> USB2		<input type="checkbox"/> Wi-Fi WAN	
Connection / IP Address(es) <span style="float: right;">All Clear</span>															
<input checked="" type="checkbox"/> Ethernet WAN	<input checked="" type="checkbox"/> 210.10.10.2 (Interface IP)														
<input type="checkbox"/> Express Card															
<input type="checkbox"/> PC Card															
<input type="checkbox"/> USB1															
<input type="checkbox"/> USB2															
<input type="checkbox"/> Wi-Fi WAN															

### Admin Settings

<b>Router Name</b>	This field allows you to define a name for this Pepwave MAX unit.
<b>Admin User Name</b>	It is set as admin by default and is not customizable.
<b>Admin Password</b>	This field allows you to specify a new administrator password.
<b>Confirm Admin Password</b>	This field allows you to verify and confirm the new administrator password.

# User Manual

## PEPWAVE *MAX* mobile router


<b>Read-only User Name</b>	It is set as user by default and is not customizable.
<b>User Password</b>	This field allows you to specify a new user password. Once the user password is set, the feature of read-only user will be enabled.
<b>Confirm User Password</b>	This field allows you to verify and confirm the new user password.
<b>Web Session Timeout</b>	This field specifies the number of hours and minutes that a web session can remain idle before the balance terminates its access to Web Admin Interface. By default, it is set as 4 hours.
<b>Authentication by RADIUS</b>	With this box is checked, Web Admin will authenticate using an external RADIUS server. Authenticated users are treated as "admin" users with full read-write permission. Local "admin" and "user" accounts will be disabled. When the device is not able to communicate with the external RADIUS server, local accounts will be enabled again for emergency access. Authentication options will be available once this box is checked.
<b>Auth Protocol</b>	This specifies the authentication protocol used. Available options are MS-CHAP v2 and PAP.
<b>Auth Server</b>	This specifies the access address of the external RADIUS server.
<b>Auth Server Secret</b>	This is the secret for accessing the RADIUS server.
<b>Auth Timeout</b>	This option specifies the time value for authentication timeout.
<b>Accounting Server</b>	This specifies the access address of the external Accounting server.
<b>Accounting Server Secret</b>	This is the secret for accessing the Accounting server.
<b>Network Connection</b>	This option is for specifying the network connection which will be used for authentication connection. Users can choose from LAN, WAN and VPN connections.
<b>Security</b>	This option is for specifying the protocol(s) through which the Web Admin Interface can be accessible: HTTP HTTPS HTTP/HTTPS
<b>Web Admin Port</b>	These fields are for specifying the port number at which the Web Admin Interface can be accessible.
<b>Web Admin Access</b>	This option is for specifying the network interfaces through which the Web Admin Interface can be accessible: LAN only LAN/WAN If LAN/WAN is chosen, a WAN Connection Access Settings form will be displayed.

### WAN Connection Access Settings

This field allows you to restrict web admin access only from defined IP subnets.

- **Any** - Allow web admin accesses to be from anywhere, without IP address restriction.
- **Allow access from the following IP subnets only** - Restrict web admin access only from the defined IP subnets. When this is chosen, a text input area will be displayed beneath:

#### Allowed Source IP Subnets



The allowed IP subnet addresses should be entered into this text area. Each IP subnet must be in form of w.x.y.z/m

where w.x.y.z is an IP address (e.g. 192.168.0.0), and

m is the subnet mask in CIDR format, which is between 0 and 32 inclusively. For example: 192.168.0.0/24


To define multiple subnets, separate each IP subnet one in a line. For example:

192.168.0.0/24

10.8.0.0/16

This is to choose which WAN IP address(es) the web server should listen on.

#### Allowed WAN IP Address(es)




# User Manual

## PEPWAVE *MAX* mobile router

### 17.2 Firmware Upgrade

The firmware of Pepwave MAX is upgradeable through Web Admin Interface. Firmware upgrade functionality is located at **System > Firmware**:



There are two ways to upgrade the unit. The first method is online firmware upgrade. The system can Check, Download and Upgrade over the Internet. The second method is to upload a firmware file manually.

Click on the **Check again** button to use online upgrade. With online upgrade, Pepwave MAX checks online for new firmware. If a new firmware is available, the firmware will be automatically downloaded by Pepwave MAX. The upgrade process will subsequently be automatically initiated.

You may also download a firmware image from the Pepwave web site (<http://www.pepwave.com/>) and update the unit manually. Click **Browse** to select the firmware file from the local computer, and then click **Upgrade** to send the firmware to Pepwave MAX. Pepwave MAX will then automatically initiate the firmware upgrade process.

Please note that all Pepwave devices are equipped to be able to store two different firmware version in two different partitions. A firmware upgrade performed will always replace the inactive partition. If you want to keep the inactive firmware, you can simply reboot your device with the inactive firmware and then perform the firmware upgrade.

#### Firmware Upgrade Status

Status LED Information during firmware upgrade:

- **OFF** – Firmware upgrade in progress (DO NOT disconnect power.)
- **Red** – Unit is rebooting
- **Green** – Firmware upgrade successfully completed

#### Important Note

The firmware upgrade process may not necessarily preserve the previous configuration, and the behavior varies on a case-by-case basis. Consult the Release Notes for the particular firmware version.

Do not disconnect the power during firmware upgrade process.

Do not attempt to upload a non-firmware file, or a firmware file that is not qualified, or not supported, by Pepwave.

Upgrading a Pepwave MAX Mobile Router with an invalid firmware file will damage the unit, and may void the warranty.

#### Important Note

If the firmware is rolled back from 5.x to 4.x, the configurations will be lost.



# User Manual

## PEPWAVE *MAX* mobile router

### 17.3 Time

The Time Server functionality enables the system clock of Pepwave MAX to be synchronized with a specified Time Server.

The settings for Time Server configuration are located at **System > Time**:

Time Settings	
Time Zone	(GMT-08:00) Pacific Time (US & Canada) <input type="checkbox"/> Show all
Time Server	time.nist.gov <input type="button" value="Default"/>

Time Server Settings	
<b>Time Zone</b>	This specifies the time zone (along with the corresponding Daylight Savings Time scheme) in which Pepwave MAX operates. The Time Zone value affects the time stamps in the Event Log of Pepwave MAX and E-mail notifications. Checked the box <b>Show all</b> to show all available time zone options.
<b>Time Server</b>	This setting specifies the NTP network time server to be utilized by Pepwave MAX.

# User Manual

## PEPWAVE *MAX* mobile router

### 17.4 Email Notification

The Email Notification functionality of Pepwave MAX provides a System Administrator with up-to-date information on network status.

The settings for configuring Email Notification are found at **System > Email Notification**:

Email Notification Setup	
Email Notification	<input checked="" type="checkbox"/> Enable
SMTP Server	smtp.mycompany.com <input checked="" type="checkbox"/> Require authentication
SSL Encryption	<input type="checkbox"/> (Note: any server certificate will be accepted)
SMTP Port	25 <input type="button" value="Default"/>
SMTP User Name	smtuser
SMTP Password	•••••
Confirm SMTP Password	•••••
Sender's Email Address	admin@mycompany.com
Recipient's Email Address	system@mycompany.com staff@mycompany.com

Email Notification Settings	
<b>Email Notification</b>	This option is for enabling Email Notification. If the box <b>Enable</b> is checked, Pepwave MAX sends email messages to a System Administrator when the WAN status changes, or when new firmware is available. If the box Enable is not checked, Email Notification is disabled and Pepwave MAX will not send email messages.
<b>SMTP Server</b>	This field is for specifying the SMTP server to be used for sending email. If the server requires authentication, check the box <b>Require authentication</b> .
<b>SSL Encryption</b>	Check the box to enable SMTPS. When the box is checked, the next field <b>SMTP Port</b> will be changed to <b>465</b> automatically.
<b>SMTP Port</b>	This field is for specifying the SMTP Port number. By default, this is set to 25; when the <b>SSL Encryption</b> box is checked, the default port number will be set to <b>465</b> . You may customize the port number by editing this field. Click the button <b>Default</b> to restore to default.
<b>SMTP User Name / Password</b>	This setting specifies the SMTP username and password while sending email. These options are shown only if <b>Require authentication</b> check box is checked in SMTP Server setting.
<b>Confirm SMTP Password</b>	This field allows you to verify and confirm the new administrator password.

# User Manual

## PEPWAVE *MAX* mobile router

**Sender's Email Address** This setting specifies the sender email address reported by the email messages sent by Pepwave MAX.

**Recipient's Email Address** This setting specifies the email addresses to which Pepwave MAX should send the email messages to. You may enter multiple recipients' email addresses in this field.

After you have completed the settings, you can click the **Test Email Notification** button to test the settings before saving it. After it is clicked, you will see this screen to confirm the settings:

Test Email Notification	
SMTP Server	smtp.mycompany.com
SMTP Port	25
SMTP User Name	smptuser
Sender's Email Address	admin@mycompany.com
Recipient's Email Address	system@mycompany.com staff@mycompany.com

Click **Yes** to confirm. Wait a few seconds, and you will see a return message and the detailed test result.

**Test email sent. Email notification settings are not saved, it will be saved after clicked the 'Save' button.**

### Test Result

```
[INFO] Try email through connection #3
[<-] 220 ESMTP
[->] EHLO balance
[<-] 250-smtp Hello balance [210.210.210.210]
250-SIZE 100000000
250-8BITMIME
250-PIPELINING
250-AUTH PLAIN LOGIN
250-STARTTLS
```

# User Manual

## PEPWAVE *MAX* mobile router

### 17.5 Remote Syslog

The Remote Syslog functionality of Pepwave MAX enables event logging at a specified remote Syslog server.

The settings for configuring Remote System Log are found at **System > Remote Syslog**:

Remote Syslog Setup	
Remote Syslog	<input type="checkbox"/> Enable
Remote Syslog Host	<input type="text"/> Port: 514

Remote Syslog Settings	
<b>Remote Syslog</b>	This setting specifies whether or not to log events at the specified remote Syslog server.
<b>Remote Syslog Host</b>	This setting specifies the IP address or host name of the remote Syslog server.
<b>Port</b>	This setting specifies the port number of the remote Syslog service. By default, the Port setting has value is <b>514</b> .

# User Manual

## PEPWAVE *MAX* mobile router

### 17.6 SNMP

SNMP, or Simple Network Management Protocol, is an open standard that can be used to collect information from the Pepwave MAX Mobile Router.

SNMP configuration is located at **System > SNMP**:

SNMP Settings	
SNMP Device Name	MAX
SNMP Port	161 <input type="button" value="Default"/>
SNMPv1	<input checked="" type="checkbox"/> Enable
SNMPv2c	<input checked="" type="checkbox"/> Enable
SNMPv3	<input checked="" type="checkbox"/> Enable
<input type="button" value="Save"/>	

Community Name	Allowed Source Network	Access Mode	
kurt	192.168.50.1/24	Read Only	<input type="button" value="Delete"/>
<input type="button" value="Add SNMP Community"/>			

SNMPv3 User Name	Authentication / Privacy	Access Mode	
MyUser	MD5 / DES	Read Only	<input type="button" value="Delete"/>
<input type="button" value="Add SNMP User"/>			

SNMP Settings	
<b>SNMP Device Name</b>	This field shows the router name defined in <b>System &gt; Admin Security</b> .
<b>SNMP Port</b>	This option specifies the port which SNMP used. The default port is set as <b>161</b> .
<b>SNMPv1</b>	This option allows you to enable SNMP version 1.
<b>SNMPv2</b>	This option allows you to enable SNMP version 2.
<b>SNMPv3</b>	This option allows you to enable SNMP version 3.

To add a community for either SNMPv1 or SNMPv2, click the **Add SNMP Community** button in the **Community Name** table, upon which the following screen will be displayed:

SNMP Community Setting	
Community Name	MyCompany
Allowed Source Subnet Address	192.168.1.20
Allowed Source Subnet Mask	255.255.255.0 <input type="button" value="v"/>
<input type="button" value="Save"/>	

# User Manual

## PEPWAVE *MAX* mobile router

SNMP Community Settings	
<b>Community Name</b>	This setting specifies the SNMP Community Name.
<b>Allowed Source Subnet Address</b>	This setting specifies a subnet from which access to the SNMP server is allowed. Enter subnet address here (e.g. 192.168.1.0).
<b>Allowed Source Subnet Mask</b>	This setting specifies the subnet mask that corresponds to the subnet specified via Allowed Source Subnet Address (e.g. 255.255.255.0).

To define a user name for SNMPv3, click **Add SNMP User** in the **SNMPv3 User Name** table, upon which the following screen is displayed:

SNMPv3 User Setting	
User Name	snmpuser
Authentication Protocol	MD5 ▾
Authentication Password	mypassword
Privacy Protocol	DES ▾
Privacy Password	myprivpasswd

SNMPv3 User Settings	
<b>User Name</b>	This setting specifies a user name to be used in SNMPv3.
<b>Authentication Protocol</b>	This setting specifies via a drop-down menu the one of the following valid authentication protocols: <ul style="list-style-type: none"> <li>• NONE</li> <li>• MD5</li> <li>• SHA</li> </ul>
<b>Authentication Password</b>	This setting specifies the authentication password, and is applicable only if the MD5 or SHA authentication protocol is selected.
<b>Privacy Protocol</b>	This setting specifies via a drop-down menu the one of the following valid privacy protocols: <ul style="list-style-type: none"> <li>• NONE</li> <li>• DES</li> </ul>
<b>Privacy Password</b>	This setting specifies the privacy password, and is applicable only if the DES privacy protocol is selected.


# User Manual

## PEPWAVE *MAX* mobile router

### 17.7 Configuration

Backing up the Pepwave MAX settings immediately after successful completion of the initial setup is strongly recommended.

The functionality to download and upload Pepwave MAX settings is found at **System > Configuration**:



#### 17.7.1 Restore Configuration to Factory Settings

The **Restore Factory Settings** button is to reset the configuration to the factory default settings. You have to click the **Apply Changes** button to make the settings effective.

#### 17.7.2 Downloading Active Configurations

The **Download** button is to backup the current active settings. Click **Download** and save the configuration file.

#### 17.7.3 Uploading Configurations

To restore or change settings based on a configuration file, click **Browse...** to locate the configuration file on the local computer, and then click **Upload**.

The new settings can then be applied by clicking the **Apply Changes** button on the page header, or discard at the Main page of Web Administration Interface.

# User Manual

## PEPWAVE *MAX* mobile router


### 17.8 Reboot

This page provides a Reboot button for restarting the system.

For highest reliability, Pepwave MAX is equipped with two copies of firmware of different version. You can select the firmware version you would like the device to reboot with.

The firmware marked with **(Running)** is the current system boot up firmware.

Please note that a firmware upgrade will always replace the inactive firmware partition.



The screenshot shows a dialog box titled "Reboot System" with a question mark icon in the top right corner. The text inside the dialog box reads: "Select the firmware you want to use to start up this Pepwave MAX :". Below this text are two radio button options: "Firmware 1: v5.2.1 build 1223 (Running)" and "Firmware 2: v5.2.0 build 1208". The first option is selected. At the bottom of the dialog box is a red "Reboot" button.



# User Manual

## PEPWAVE *MAX* mobile router

### 17.9 Ping Test

The Ping Test tool in Pepwave MAX performs Pings through a specified Ethernet interface or a Site-to-Site VPN connection. You can specify the number of pings in the field **Number of times** to a maximum of 10 times, and Packet Size can be specified in the field **Packet Size** to a maximum of 1472 bytes.

The Ping utility is located at **System > Tools > Ping**, illustrated as follows:

**Ping**

Connection	Ethernet WAN
Destination	10.10.10.1
Packet Size	Packet Size 56
Number of times	Times 5

Start Stop

**Results** Clear Log

```
PING 10.10.10.1 (10.10.10.1) from 10.10.10.156 56(84) bytes of data.  
64 bytes from 10.10.10.1: icmp_req=1 ttl=64 time=1.01 ms  
64 bytes from 10.10.10.1: icmp_req=2 ttl=64 time=0.909 ms  
64 bytes from 10.10.10.1: icmp_req=3 ttl=64 time=0.830 ms  
64 bytes from 10.10.10.1: icmp_req=4 ttl=64 time=0.781 ms  
64 bytes from 10.10.10.1: icmp_req=5 ttl=64 time=0.770 ms  
  
--- 10.10.10.1 ping statistics ---  
5 packets transmitted, 5 received, 0% packet loss, time 4016ms  
rtt min/avg/max/mdev = 0.770/0.861/1.019/0.099 ms
```

#### Tip

A System Administrator can use the Ping utility to manually check the connectivity of a particular LAN/WAN connection.

# User Manual

## PEPWAVE *MAX* mobile router

### 17.10 Traceroute Test

The Traceroute Test tool in Pepwave MAX traces the routing path to the destination through a particular Ethernet interface or a Site-to-Site VPN connection.

The Traceroute Test utility is located at **System > Tools > Traceroute**, illustrated as follows:

Traceroute	
Connection	Ethernet WAN
Destination	pepwave.com
<input type="button" value="Start"/> <input type="button" value="Stop"/>	

Ethernet WAN

Ethernet WAN

USB2

LAN

S2SVPN: VPN Connection 1

Results	
tracert to pepwave.com [129.75.230.8] 30 hops max, 40 byte packets	
1	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms
2	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms
3	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms
4	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms
5	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms
6	129.75.230.8 [129.75.230.8] 0.000 ms 0.000 ms 0.000 ms

#### Tip

A System Administrator can use the Traceroute utility to analyze the connection path of a LAN/WAN connection.

### 17.11 VPN Test

The VPN Test tool can help to test the throughput between different VPN peers.

You can define the **Test Type**, **Direction**, and **Duration** of the test, and press **Go!** to perform the throughput test.

The VPN Test utility is located at **System > Tools > VPN Test**, illustrated as follows:

VPN Throughput Test	
VPN Profile	Headquarters
Test Type	<input checked="" type="radio"/> TCP <input type="radio"/> UDP
Direction	<input checked="" type="radio"/> Upload <input type="radio"/> Download
Duration	60 seconds (5 - 600)
<input type="button" value="Go!"/>	

Results	
Preparing throughput test.	
Starting throughput test... ok	
0.0313 MB / 1.00 sec =	0.2614 Mbps 0 retrans
0.1250 MB / 1.00 sec =	1.0485 Mbps 0 retrans

# User Manual

## PEPWAVE *MAX* mobile router

### 18 Status

This section displays the information of Pepwave MAX on the **Device**, **Active Sessions**, **Client List**, **WINS Client List**, **Site-to-Site VPN**, **UPnP / NAT-PMP**, **Event Log**, and **Bandwidth**.

#### 18.1 Device

System information is located at **Status > Device**:

System Information	
Router Name	MAX
Model	Pepwave MAX 600
Hardware Revision	1
Serial Number	2830-2345-C65B
Firmware	5.2.1 build 1223
Uptime	5 day 8 hour 46 minutes
System Time	Wed Jan 12 18:54:49 PST 2011
Diagnostic Report	<a href="#">Download</a>

Interface	MAC Address
LAN Port	00:11:22:33:44:11
Ethernet WAN	00:11:22:33:44:01
Express Card	00:11:22:33:44:02
PC Card	00:11:22:33:44:03
USB1	00:11:22:33:44:04
USB2	00:11:22:33:44:05
Wi-Fi WAN	00:11:22:33:44:06

[Legal](#)

System Information	
<b>Router Name</b>	This is the name specified in the field Router Name located in <b>System &gt; Admin Security</b> .
<b>Model</b>	This shows the model name and number of this device.
<b>Hardware Revision</b>	This shows the hardware version of this device.
<b>Serial Number</b>	This shows the serial number of this device.
<b>Firmware</b>	This shows the firmware version that this device is currently running.
<b>Uptime</b>	This shows the length of time since the device is rebooted.
<b>System Time</b>	This shows the current system time.
<b>Diagnostic Report</b>	A <b>Download</b> button is for exporting a diagnostic report file required for system investigation.

The second table shows the MAC address of each LAN/WAN interface connected.

#### Important Note

If you encounter issues and would like to contact Peplink Support Team (<http://www.peplink.com/contact/>), please download the diagnostic report file and attach it along with a description of your encountered issue.

In firmware 5.1 or before, Diagnostic Report file can be obtain at **System > Reboot**

# User Manual

## PEPWAVE *MAX* mobile router

### 18.2 Active Sessions

Information on Active Sessions is at **Status > Active Sessions**:

Filter: <input type="text"/>					
<input type="checkbox"/> Ethernet WAN	<input type="checkbox"/> Express Card	<input type="checkbox"/> PC Card			
<input type="checkbox"/> USB1	<input type="checkbox"/> USB2	<input type="checkbox"/> Wi-Fi WAN			
<input type="checkbox"/> VPN					

Outbound					
Protocol	Source IP	Destination IP	Service	Interface	Idle Time
TCP	192.168.1.110:4147	123.123.123.1:443	HTTPS	WAN1	00:00:02
ICMP	192.168.1.110	60.60.60.1		WAN1	00:00:02
TCP	192.168.1.110:2423	123.123.123.1:443	HTTP	WAN1	00:00:13
TCP	192.168.1.110:1144	123.123.123.123:5222	XMPP Client	WAN2	00:00:19
TCP	192.168.1.110:1156	65.65.65.1:1863		WAN1	00:00:22
UDP	192.168.1.110:62817	90.123.90.1:123	NTP	WAN2	00:00:29


  

Inbound					
Protocol	Source IP	Destination IP	Service	Interface	Idle Time
UDP	10.10.10.112:1024	192.168.1.110:514	Syslog	WAN1	00:00:20






This Active Sessions section displays the active inbound / outbound and UDP / TCP sessions of each WAN connection on Pepwave MAX.

A filter is available to help sort out the active session information. Enter a keyword in the field or check one of the WAN connection boxes for filtering.

### 18.3 Client List

The client list table is located at **Status > Client List**. It lists DHCP client IP addresses, their Names (retrieved from DHCP reservation table or defined by users), current **Download and Upload rate** and MAC addresses that the Pepwave MAX has offered IP addresses to since it is powered up. Network Name (SSID) and Signal refers to the information about Wi-Fi AP, which is the name of the Network and its signal strength. Clients can be imported into DHCP Reservation table by clicking the  button on the right-most column. Further update the record after the import by going to **Network > LAN**.

If PPTP Server in section 17.1 is enabled, you may see the corresponding connection name would be listed in the field of **Name**.

Client List							
IP Address	Name	Download (kbps)	Upload (kbps)	MAC Address	Network Name (SSID)	Signal	Import
192.168.50.1		0	0				
192.168.1.6		65	13	08:00:22:11:DC:0D	Wi-Fi	-69dBm	
192.168.1.9		0	0	01:00:22:CC:CC:01			
192.168.1.10		0	0	08:00:22:DD:CC:DD			
192.168.1.15	desktop	0	0	00:22:44:11:11:44			

Scale:  kbps  Mbps

# User Manual

## PEPWAVE *MAX* mobile router

### 18.4 WINS Client

The WINS client list table is located at **Status > WINS Client**. It lists WINS client IP addresses and their Names. This option will only be available when you have enabled the WINS Server in section 8.1.

Name of clients retrieved will be automatically matched into Client List in the previous section.







Click the button **Flush All** to flush all WINS client records.

WINS Client List	
Name ▲	IP Address
UserA	10.9.2.1
UserB	10.9.30.1
UserC	10.9.2.4

### 18.5 Site-to-Site VPN

This is a page showing the current status of Site-to-Site VPN, located at: **Status > Site-to-Site VPN**

Details about peer's WAN connections would be listed as below.

Site-to-Site VPN					
Peer	Remote Networks				
VPN Connection 1	192.168.0.0/24 192.168.1.0/24				
Ethernet WAN	 In Use	Rx: 103 kbps	Tx: 21 kbps	Drop rate: 0.00/sec	
Express Card	 Not In Use	Rx: n/a	Tx: n/a	Drop rate: n/a	
PC Card	 Not In Use	Rx: n/a	Tx: n/a	Drop rate: n/a	
USB1	 In Use	Rx: 16 kbps	Tx: 3 kbps	Drop rate: 0.00/sec	
USB2	 Not In Use	Rx: n/a	Tx: n/a	Drop rate: n/a	
Wi-Fi WAN	 In Use	Rx: 12 kbps	Tx: 2 kbps	Drop rate: 0.00/sec	
Total		Rx: 131 kbps	Tx: 26 kbps	Drop rate: 0.00/sec	







# User Manual


## PEPWAVE *MAX* mobile router

### 18.6 UPnP / NAT-PMP

The table that shows the forwarded ports under UPnP and NAT-PMP protocols is located at **Status > UPnP / NAT-PMP**.

This section appears only if you have enabled the function of UPnP / NAT-PMP as mentioned in Section 13.2.

Forwarded Ports						
External	Internal	Internal Address	Type	Protocol	Description	
47453	3392	192.168.1.100	UPnP	UDP	Application 031	
35892	11265	192.168.1.50	NAT-PMP	TCP	NAT-PMP 58	
4500	3560	192.168.1.20	UPnP	TCP	Application 013	
5921	236	192.168.1.30	UPnP	TCP	Application 047	
22409	8943	192.168.1.70	NAT-PMP	UDP	NAT-PMP 97	
2388	27549	192.168.1.40	UPnP	TCP	Application 004	

Click the button  to delete the single UPnP / NAT-PMP record in its corresponding row. To delete all records, click **Delete All** on the right-hand side below the table.

#### Important Note

UPnP / NAT-PMP records would be deleted immediately after clicking the button  or **Delete All** without the need to click Save or Confirm.

### 18.7 Event Log

Event Log information is located at **Status > Event Log**:

Event Log		Show [ 50   100   all ]	Refresh	Clear Log
Jul 30 19:36:55	Link health check monitor started			
Jul 30 19:40:31	WAN Priority Changed: (Priority 1:Ethernet WAN, Wi-Fi WAN   Priority 2: USB1)			
Jul 30 19:42:43	Health check status changed: (Ethernet WAN: UP)			
Jul 30 19:42:43	Time synchronization successful			
Jul 31 09:50:38	Wi-Fi AP: Client 00:11:22:AA:BB:CE Associated with wi-fi ap			

The log section displays a list of events that has taken place on the Pepwave MAX unit. Click the **Refresh** button to retrieve log entries again. Click the **Clear Log** button to clear the log. Select **50**, **100**, or **all** to show the corresponding number of events in the log.

# User Manual

## PEPWAVE *MAX* mobile router

### 18.8 Bandwidth

This section shows the bandwidth usage statistics, located at: **Status > Bandwidth**

Bandwidth usage at the LAN and when the device is switched off, are not recorded and not shown.

#### 18.8.1 Real-Time

The **Data Transferred since installation** shows you how many network traffic has been processed by your device since first boot.

Click **Show Details** in the top right hand corner of each table and the details of data transferred will be shown.

The check box **Stacked** below the data transferred graph can be checked to show the aggregated transferred rate of both traffic direction.

Data transferred since installation (Tue Oct 12 23:11:14 PST 2010)


	Download	Upload	Total
All WAN Connections	10.63 GB	12.99 GB	23.62 GB

Data transferred since last reboot

[\[ Hide Details \]](#)

	Download	Upload	Total
All WAN Connections	224 MB	178 MB	402 MB
Ethernet WAN	212 MB	175 MB	387 MB
Express Card	0 MB	0 MB	0 MB
PC Card	0 MB	0 MB	0 MB
USB1	0 MB	0 MB	0 MB
USB2	0 MB	0 MB	0 MB
Wi-Fi WAN	12 MB	3 MB	15 MB

Aggregated Transfer



#### 18.8.2 Daily

This page shows the daily bandwidth usage for all and each WAN connection.


Select the connection in which you want to check its usage from the drop down menu. If you have enabled **Bandwidth Monitoring** feature as shown in section 9.5, the **Current Billing Cycle** table for that WAN connection will be displayed.

Click on a date to view the client bandwidth usage of that specific date. This feature is not available if you have selected to view the bandwidth usage of only a particular WAN connection.


The Scale of the graph can be set to show in **Megabyte (MB)** or **Gigabyte (GB)**.

# User Manual

## PEPWAVE *MAX* mobile router



All WAN Daily Bandwidth Usage



Ethernet WAN Daily Bandwidth Usage



# User Manual

## PEPWAVE *MAX* mobile router


### 18.8.3 Monthly

This page shows the monthly bandwidth usage for each WAN connection.

If you have enabled **Bandwidth Monitoring** feature as shown in section 9.5, you can choose a particular connection to check its usage and select to show the monthly usage period in **Billing Cycle** or **Calendar Month**.

Click the first or second row to view the client bandwidth usage of the current month. This feature is not available if you have chosen to view the bandwidth usage of only a particular WAN connection.

The Scale of the graph can be set to show in **Megabyte (MB)** or **Gigabyte (GB)**.




*All WAN Daily Bandwidth Usage*

# User Manual

## PEPWAVE *MAX* mobile router

Monthly Usage	
Connection	Ethernet WAN ▾
Period	<input type="radio"/> Billing Cycle <input checked="" type="radio"/> Calendar Month
Scale	<input checked="" type="radio"/> MB <input type="radio"/> GB



Date	Download	Upload	Total
2011-01-01 to now	784 MB	595 MB	1 379 MB
2010-12-01 to 2010-12-31	2 291 MB	2 103 MB	4 394 MB
2010-11-01 to 2010-11-30	2 261 MB	2 896 MB	5 157 MB
2010-10-01 to 2010-10-31	471 MB	3 484 MB	3 955 MB

*Ethernet WAN Daily Bandwidth Usage*

### Tip

By default, the scale of data size is in **MB**. 1GB equals to 1024MB.

### Appendix A. Restoration of Factory Defaults

To restore the factory default settings on a Pepwave MAX unit, follow the steps below:

1. Locate the reset button on the front panel of Pepwave MAX unit.
2. With a paper clip, press the reset button and hold it for at least 10 seconds until the unit reboots itself.

After Pepwave MAX finishes rebooting, the factory default settings will be restored.

#### Important Note

All previous configurations and bandwidth usage data will be lost after restoring the factory default settings.

Regular backup of configuration settings is strongly recommended.

### Appendix B. Declaration

1. **The device supports time division technology**
2. **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- 1) Reorient or relocate the receiving antenna.
- 2) Increase the separation between the equipment and receiver.
- 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4) Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

#### **IMPORTANT NOTE**

##### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination.**

# PEP WAVE

Broadband Possibilities

[www.pepwave.com](http://www.pepwave.com)



What are we doing at the moment?  
Follow us on [Twitter!](#)  
<http://twitter.com/Peplink>



Want to know more about us?  
Add us on [Facebook!](#)  
<http://www.facebook.com/peplink>



Difficulties when configuring the device?  
Visit Our [YouTube Channel!](#)  
<http://www.youtube.com/PeplinkChannel>

## Contact Us:

### Sales

<http://www.pepwave.com/contact/sales/>

### Support

<http://www.pepwave.com/contact/>

### Business Development and Partnerships

<http://www.pepwave.com/partners/channel-partner-program/>

## Address:

### United States Office

800 West El Camino Real,  
Mountain View  
CA 94040  
United States  
Tel: +1 (650) 450 9669  
Fax: +1 (866) 625 4664

### Hong Kong Office

17/F, Park Building,  
476 Castle Peak Road  
Cheung Sha Wan  
Hong Kong  
Tel: +852 2990 7600  
Fax: +852 3007 0588