

# NEED MORE HELP? CALL US!


Instead of driving back to the store, call us for help on pairing, fit or usage of your new headset.

1-866-363-2583

**User Guide** 

# **Package Contents and Features**

⚠ Refer to separate Safety Guide before using headset.





2.5 hours......Full charge

Red status light glows while

charging. Do not use until

fully charged.

**NOTE** Never charge the battery where the temperature may fall below 32°F (0°C) or rise above 104°F (40°C). Do not use your headset while it is connected to the charger.

# What Is Bluetooth?

Bluetooth wireless technology provides a way for devices, like headsets and phones, to communicate with each other without wires. Pairing is the set-up process of introducing your headset to your phone. Before using your headset for the first time, you must pair it with your Bluetooth-enabled phone.

# Plantronics QuickPair™ Technology

To simplify the Bluetooth setup process, your new headset uses Plantronics QuickPair technology. This process is shown on the next page.

- The first time you turn your headset on, your headset automatically enters pairing mode for 10 minutes.
- Until you successfully pair your headset with a Bluetooth-enabled phone, every time you turn it on it will enter pairing mode.
- To later pair to a new phone, with the headset off, press and hold the One-Touch Button until the LED flashes red-blue, which indicates pairing mode status.


# Range (the distance between headset and phone)

- To maintain the connection, keep your headset within 33 feet of your phone.
- For the least amount of interference place the headset and phone on the same side of your body.

If you move too far from your phone and lose the Bluetooth connection:

- the headset may reconnect automatically within 60 seconds when you move closer to your phone (you will hear a low tone), OR
- you may have to tap the One-Touch Button to reconnect (you will hear a low tone). OR
- if neither of the above options work, you may have to reconnect to your headset using your phone's Bluetooth menu.

# **Pairing Your Headset**



# How to Pair Your Phone With Your Headset for the First Time

- 1 Turn on the Bluetooth feature on your phone.
  For most phones, select Settings/Tools > Connections >
  Bluetooth > On. See your phone's user guide for more information.
- 2 Turn on the QuickPair feature of your headset. Turn on your headset by pressing and holding the One-Touch Button until the LED flashes blue, then alternately flashes red-blue. If you don't see these flashes, press and hold the One-Touch Button until you see the red-blue flashes.
- 3 Set your Bluetooth phone to 'discover' to locate the headset. This usually involves going to 'setup,' 'connect,' or 'Bluetooth' menu on your phone and selecting the option to 'discover' or 'add a device.'
- 4 Once available headsets are listed, select your headset (FreeHand 1xx). If prompted for a passkey, enter 0000.

  When pairing is successful, the status light on your headset glows blue. Your phone will also confirm when pairing is complete.

# Call Us with Questions 1-866-363-BLUE (2583)

# **Headset Controls and Indicators**

and being the control button for any seconds until dismissed.  In phone to adjust None Red flash land press Send.  In phone to adjust None Red flashing and press Send.  In phone to adjust None Red flashing and press Send.  In phone to adjust None Red flashing and press Send.  In phone to adjust None Red flashing and press Send.  In phone to adjust None Red flashing and plash avery 20 seconds until dismissed.  In phone to adjust None Red flashing are also button in hone reached button as econds until dismissed.  In phone to adjust None Red flashing are also button as accords until dismissed.  In phone to adjust None are also button when a land cone-found.  In phone to adjust None are also button as accords until dismissed.  In phone to adjust None are also button and you hear a seconds until dismissed.			Status I inh	
Press and hold the One Short blue flash One-Touch Button for Off Short red flash, then 3 seconds.  Tap the One-Touch Button. None Ehrer the number on your Blue flash reery 2 seconds phone and press Send.  None Red flashing Deep your phone to adjust None Press and hold the One- Touch Button until you hear.  Tap One-Touch Button Press And And Other Duch Seconds until dismissed.  Press And And Che Duch Seconds until dismissed.  Press And And Che Duch Press And And One-Touch Button Press and Haddone-Touch None Button until you hear a bone.		ACTION	oratus Light	Die
One-Touch Button for Off Short red flash, then Jasechuck.  Tap the One-Touch Button. None Enter the number on your Blue flash every 2 seconds phone and press Send. until the call is ended. None Red flashing Lee your phone to adjust None Red flashing Lee your phone to adjust None Press and off the One-Touch Button a tone. Tap One-Touch Button will altone the manually reconnect. Header will automatically attend to reconnect when in range.	Turn the headset	Press and hold the	On: Short blue flash	On: Four rising tones then one
Seconds. turns off Tap the One-Touch Button. None Enter the number on your Blue flash every 2 seconds phone and press Send. until the call is ended. None Red flashing Use your phone to adjust None Touch Button None Touch Button at the connect one to manually reconnect. The One-Touch Button Seconds until dismissed. Press One-Touch Button None Press One-Touch Button None Press Amil automatically attempt to reconnect when in range. Press and hold One-Touch None Button until you hear a bone.	on or off	One-Touch Button for	Off: Short red flash, then	high tone
Tap the One-Touch Button. None Enter the number on your Blue flash every 2 seconds phone and press Send.  None None Nover phone to adjust None Nover you'n phone to adjust Or lover yolume. Nowhile the call is in progress. None Press and hold the One- Tap One-Touch Button Tiple blue flash every 20 Seconds until dismissed. Dess One-Touch Button None None Peass And I adromatically attempt to reconnect when In angle. Perss and Ald One-Touch None Press and Ald One-Touch None Press and Ald One-Touch None Press and Ald One-Touch None Button until you hear a bone.		3 seconds.	turns off	Off: High tone then four
Tap the One-Touch Button. None Enter the number on your Blue flash every 2 seconds phone and press Send, until the call is ended.  Use your phone to adjust None or lower volume. None press and hold the One- Touch Button until you hear a tone.  Press One-Touch Button None press and hold the One- Press One-Touch Button None press one-Touch Button None press All automatically attempt to reconnect. When the manually reconnect.  Press All automatically attempt to reconnect when in range.  Press and hold One-Touch None press and hold One-Touch None press and hold One-Touch None Button until you hear a bone.				descending tones
Enter the number on your Blue flash every 2 seconds phone and press Send. Until the call is ended.  None Red flashing  Whe the call is in progress, None press and hold the One a tone.  Touch Button until you hear a tone.  Touch Button numbly reconnect.  The One-Touch Button Seconds until dismissed.  Press One-Touch Button None once to manually reconnect.  Headse will automatically attempt to reconnect when in range.  Press and hold One-Touch None press and Hold One-Touch None bereas and Hold One-Touch None bereas and Hold One-Touch None bereas and Hold One-Touch None Button until you hear a bone.	Answer/end	Tap the One-Touch Button.	None	Brief tone at the beginning or
Enter the number on your Blue flash every 2 seconds phone and press Send.  None Red flashing Lee your phone to adjust Or lower volume None Press and offer to none The Dens and blue flash every 20 Press One-Touch Button Tip Dens and blue flash every 20 Press One-Touch Button The Charles and the flash every 20 Press One-Touch Button The Charles and Seconds until dismissed.  Press And All One-Touch Button Press and Mall offer flash Press and Mall offer flash Press and Mall One-Touch None The Button until you hear a bone.	a call			end of the call.
Phone and press Send, until the call is ended.  Use your phone to adjust not lower volume.  Valville the call is in progress, None press and hold the One-Touch Button until you hear a tone.  Press One-Touch Button in hone seconds until dismissed.  Press One-Touch Button None noce to manually reconnect. Headeds will automatically attempt to reconnect when in range.  Press and hold One-Touch None press and hold One-Touch None headed will automatically attempt to reconnect when in range.  Press and hold One-Touch None Button until you hear a bone.	Make a call	Enter the number on your	Blue flash every 2 seconds	No tone. Phone rings until
None Red flashing Use your phone to adjust None or lower volume. While the call is in progress, None press and hold the One- Touch Button until you hear. Tap One-Touch Button Seconds until dismissed. Press One-Touch Button Press American None once to manually reconnect. Headers will automatically attempt to reconnect when in raine. Press and bld One-Touch None Button until you hear a bone.		phone and press Send.	until the call is ended.	answered.
Use your phone to adjust None or lower volume. While the call is in progress, None press and hold the One- Tabor Button until you hear a tone. Tap One-Touch Button Records until dismissed. Press One-Touch Button None once to manually recornect. Headeds will automatically attempt to reconnect when in range. Press and hold One-Touch None Button until you hear a tone.	Battery level	None	Red flashing	Five rapid high tones every 10
Use your phone to adjust None or lower volume.  While the call oil in progress, None press and hold the One-Touch Button until you hear a tone.  The One-Touch Button Tiple blue flash every 20 seconds until dismissed.  Press One-Touch Button None once to manually reconnect. Headed automatically attempt to reconnect when in range.  Press and hold One-Touch None Button until you hear a tone.				seconds when battery is critically
Use your phone to adjust None  Vinite the call is in progress, None press and hold the One- Tab One-Touch Button Tiple blue flash every 20 Press One-Touch Button Tiple blue flash every 20 Press One-Touch Button Rome  Press Annually reconnect. Header will automatically attempt to reconnect when in range.  Press and held One-Touch None Button until you hear a bone.				low. Charge immediately.
or lower volume.  In from While the call is in progress, None hone, press and hold the One- a Touch Button until you hear a thore.  Press One-Touch Button Seconds until dismissed. Press One-Touch Button None once to manually recomect. Headest will automatically attempt to seconded with automatically attempt to seconded when in range. Press and hold One-Touch None Button until you hear a tone.	Adjust the volume	Use your phone to adjust	None	None
If from While the call is in pagess. None tend press and hold the One- tend part of the One- a from the first of the One- a from Tone Touch Button Thiple blue flash every 20 seconds until disnissed. The one to manually recornect. Headset will automatically attempt to reconnect when in range. Button until you hear a tone. Button until you hear a tone.		or lower volume.		
hone, press and hold the One- ed Touch Button until you hear a tone.  ed Tap One-Touch Button Triple blue flash every 20 seconds until dsmissed.  Press One-Touch Button None once to manually reconnect.  Headset will automatically attempt to ecconnect when in range.  Press and hold One-Touch None Button until you hear a tone.	Transfer a call from		None	Single low tone
Touch Button until you hear a tone.  a form a form in the button in target will automatically attempt to seconds until dismissed.  Press One-Touch Button Seconds until dismissed.  Press One-Touch Button None once to manually recornect.  Headset will automatically attempt to seconded when in range. In range in range when in range heres and hold One-Touch None Button until you hear a tone.	headset to phone,	press and hold the One-		
a tone.  The following the flash every 20 seconds until demissed.  Press One-Touch Button Triple blue flash every 20 seconds until demissed.  One to manually recornect.  Headset will automatically attempt to reconnect when in range.  Press and flash One-Touch None Button until you hear a brone.	or from phone to	Touch Button until you hear		
ed Tap One-Touch Button Triple blue flash every 20 seconds until dsmissed.  Press One-Touch Button None once to manually reconnect.  Headset will automatically attempt to reconnect when in range.  Press and hold One-Touch None Button until you hear a tone.	headset	a tone.		
Press One-Touch Button None once to manually recornect. Headset will automatically attempt to recornect when in range. Press and followed to when the respective to the press and followed to the press	Dismiss missed	Tap One-Touch Button	Triple blue flash every 20	None
Press One-Touch Button None once to manually reconnect. Headet will automatically attempt to reconnect when in range. Press and hold One-Touch None Button until you hear a tone.	call indicator		seconds until dismissed.	
once to manually reconnect. Headset will automatically attempt to reconnect when a trampt to reconnect when in range. Press and hold One-Touch None Button until you hear a tone.	Out of range	Press One-Touch Button	None	2 high tones when leaving
Headset will automatically attempt to reconnect when in range. All		once to manually reconnect.		range. Single high tone when
attempt to reconnect when in range. Press and hold One-Touch None Button unity you hear a tone.		Headset will automatically		back in range. Single low tone
in range. Press and hold One-Touch None Button until you hear a tone.		attempt to reconnect when		when manually or automatically
Press and hold One-Touch None Button until you hear a tone.		in range.		reconnected.
	Voice dial	Press and hold One-Touch	None	Single low tone
		Button until you hear a tone.		

# **Troubleshooting**

My headset
does not work
with my phone

Your headset may not have been in pairing mode when your phone was searching for it. Repeat the pairing process on page 4.

You may have made incorrect menu selections on your phone while pairing. Repeat the pairing process on <u>page 4</u>.

# Callers cannot hear me, or I cannot hear callers/dialing

Make sure the headset is turned on.

Your headset may be out of Bluetooth range or experiencing interference. Move the headset closer to your phone, and make sure your headset and phone are on the same side of your body.

Your headset battery is drained. Recharge the battery using the supplied AC power adapter.

The listening volume is too low. Increase the volume on your phone.

# My headset is flashing red then blue

Your headset is in Pairing mode. If you are not trying to pair the headset, reset it by simply turning headset off then on again. Otherwise, see Pairing on page 4.

# **Product Specifications**

Talk Time*	Up to 6.5 hours
Standby Time*	Up to 6 days
Charge Time	2.5 hours for full charge
Range	Up to 33 feet (10 meters) away from phone
Power Requirements	5V DC - 180 mA
Battery Type	Rechargeable lithium ion polymer
Storage/Usage Temperature	32° F - 104° F (0° C - 40° C)
Version	2.0 + EDR (Enhanced Data Rate)
	Supports your phone's Bluetooth Hands-free (HFP) and Headset (HSP) profiles.

<sup>\*</sup> Battery enabled. Performance may vary by device.

### Federal Communications Commission (FCC) Statement

### 15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

### 15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is

-Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference and
- 2) this device must accept any interference received, including interference that may cause undesired operation of the device.

# FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Industry Canada (IC) Statement

### 15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

### 15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the IC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

\*Reorient or relocate the receiving antenna.

- \*Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \*Consult the dealer or an experienced radio/TV technician for help.

### Operation is subject to the following two conditions:

- this device may not cause interference and
- this device must accept any interference, including interference that may cause undesired operation of the device.

### IC RF Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# Freehand 100



# CONFORMS TO ANSI/UL STD. 60950-1 CERTIFIED TO CAN/CSA STD. C22.2 NO. 60950-1

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

ATTENTION
IL Y A RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE
PAR UNE BATTERIE DE TYPE INCORRECT.
METTRE AU REBUT LES BATTERIES USAGÉES
CONFORMÉMENT AUX INSTRUCTIONS



Plantronics, Inc.

345 Enginal

Santa Cruz, CA 95060

United States

Tel: 800-544-4660

www.plantronics.com

© 2010 Plantronics, Inc. All rights reserved. Plantronics, the logo design, Plantronics FreeHand, QuickPair and Sound Innovation are trademarks or registered trademarks of Plantronics, Inc. The Bluetooth name and the Bluetooth trademarks are owned by Bluetooth SIG, Inc., and are used by Plantronics, Inc. under license. All other trademarks are the property of their respective owners.

U.S. Patents Pending xxxxx-xx (01/10)